

Standard Operating Procedure

Elevator Access Control Integration — Kantech KT Controllers

Document No.	SOP-LV-020
Related Documents	SOP-LV-010, SOP-LV-018
Revision	1.0
Effective Date	2026-07-23
Review Cycle	Annual
Applies To	Field Technicians, Installers
Jurisdiction	Ontario / Manitoba
Owner	Apex – Operations
Approved By	_____

NOTE ON THIS DOCUMENT:

This procedure is based on Kantech's own application note, "Controlling Elevator Access Using KT Controllers" (DN1603-0409). Elevator cab wiring is performed by qualified elevator servicing personnel, not Apex technicians — this SOP covers the access control side of the integration (controller, relay assignment, EntraPass configuration), not elevator mechanical or life-safety systems. Elevator recall and fire service functions are governed by elevator code and are outside this SOP's scope.

1. Purpose

This procedure defines the standard method for integrating Kantech KT controllers with elevator cab floor control, restricting cardholder access to specific floors based on their assigned access level.

2. Scope

Applies to Apex technicians configuring elevator floor access control using Kantech KT controllers and relay expansion modules, coordinating with the building's elevator service contractor for the cab-side wiring.

3. Requirements Before Starting

- One Kantech KT controller is required for every two elevator cabs being controlled.
- Relay expansion modules matched to the controller family and floor count: KREB-8 (for KT-200) or KT-4204/KT-4216 (for KT-300 and compatible controllers) — confirm the correct module and quantity against the building's actual floor count and cab count before ordering hardware.
- Belden #9553 cable (or equivalent specified by the elevator contractor) installed in the elevator cabs, run to the elevator control system — this cable is installed by qualified elevator servicing personnel, not Apex technicians.
- Serial numbers for the controller and all extension modules, recorded before installation.
- Building manager and elevator service technician contact information — this integration cannot be completed or tested without their coordination.

4. Coordination with Elevator Contractor

STOP — THIS IS NOT A SOLO SCOPE OF WORK:

Do not attempt to wire into elevator cab control systems. The cab-side connection is performed by qualified elevator servicing personnel. Apex's role is the access control side: the KT controller, relay modules, and EntraPass configuration. Schedule this work jointly with the building's elevator contractor — testing floor-by-floor access requires their participation.

5. Relay Assignment

- Each controlled floor is assigned to one relay on the expansion module(s). Confirm the floor-to-relay mapping against the elevator contractor's documentation before assigning relays in EntraPass — do not assume floor order matches relay numbering without confirming.
- Where a site has two elevator cabs on one controller, confirm which relays belong to which cab before configuration — mixing up cab assignment will grant or deny the wrong cab's floor access.

6. EntraPass Configuration — Elevator Doors

- In EntraPass, each elevator cab is defined as a door (Devices → Door), distinct from the physical building doors also on the system.
- Assign the relay(s) representing each floor to that elevator door's configuration, matching the floor-to-relay mapping confirmed in Section 5.
- Create floor groups in EntraPass to bundle floors that should be granted together under a single access level, where the application calls for grouped floor access rather than individual floor-by-floor assignment.
- Assign access levels to cardholders that include the specific floor(s) or floor group(s) they are authorized to reach — a cardholder can only access floors included in their assigned access level(s), the same privilege model used for building doors.

7. Testing

- Test each controlled floor individually with a credential authorized for that floor — confirm the correct floor (and only that floor, unless multiple floors are intentionally authorized) becomes selectable in the cab.
- Test with a credential NOT authorized for a given floor — confirm that floor remains restricted.
- Test both cabs independently where a site has more than one, confirming no cross-wiring between cabs' relay assignments.
- Coordinate with the elevator contractor to confirm the integration does not interfere with elevator recall, fire service operation, or any other life-safety elevator function — this confirmation must come from the elevator contractor, not be assumed by the access control technician.
- Record the controller serial number, relay module(s), and floor-to-relay mapping on the site configuration sheet.

8. References

- Kantech Application Note DN1603-0409 — Controlling Elevator Access Using KT Controllers
- Kantech EntraPass Administration Guide (version-specific — confirm current guide for the EntraPass edition/version in use at the site)
- SOP-LV-010 — KT-1/KT-2/KT-4/KT-400 Controller Default & Configuration
- SOP-LV-018 — Access Control Power Supply Sizing