

Standard Operating Procedure

KT-2 Controller — Default & Configuration Procedure

Document No.	SOP-LV-023
Related Documents	SOP-LV-004
Revision	1.0
Effective Date	2026-07-24
Review Cycle	Annual
Applies To	Field Technicians, Installers
Jurisdiction	Ontario / Manitoba
Owner	Apex – Operations
Approved By	_____

1. Purpose

This procedure defines the standard method for resetting a Kantech KT-2 door controller to factory default and configuring it for use on an Apex-installed access control system, ensuring consistent commissioning and reducing field errors.

2. Scope

Applies to all Apex technicians installing, replacing, or troubleshooting Kantech KT-2 controllers on EntraPass Special, Corporate, or Global Edition systems.

3. Regulatory & Reference Standards

- Ontario Occupational Health and Safety Act (OHSA) and O. Reg. 213/91 – Construction Projects
- Manitoba Workplace Safety and Health Act
- CSA C22.1 – Canadian Electrical Code, low-voltage wiring practices
- Manufacturer reference: Kantech KT-2 Installation Guide (Johnson Controls / Kantech Knowledge Exchange)

4. Tools & Materials Required

- Laptop with KT-Finder installed and EntraPass workstation access
- Ethernet patch cable
- Site IP addressing scheme / network configuration sheet
- PPE per SOP-LV-004

5. Factory Default Reset

The KT-2 uses a single Reset button on the main board — no jumpers are required.

1. Power down or isolate the controller if instructed by site procedure; otherwise the controller may remain powered.
2. Remove the front cover by unlocking the clip at the bottom.
3. Locate the Reset button in the lower right of the main board.
4. To perform a Factory Default DHCP reset: press the Reset button three (3) times, then hold for 3 seconds until you hear 5 beeps.
5. Confirm the Kantech shield LED shows the Factory Default DHCP pattern (continuous long pulses).
6. Replace the front cover.

6. Configuration (EntraPass)

1. Connect the laptop to the same network/subnet as the controller and open KT-Finder.
2. Confirm the controller appears in the list, identified by MAC address.

3. Assign a static IP address per the site's IP addressing scheme (recommended for EntraPass-managed controllers).
4. Set the operating mode to EntraPass mode (not Standalone/Cloud) unless the site specifically requires standalone operation.
5. In EntraPass, go to Devices → Connection configuration and add/confirm the connection.
6. In EntraPass, go to Devices → Configuring controllers, add the controller, select model KT-2, and enter its IP/MAC address.
7. Reload the controller (Operations → Manual operations on controllers → Reload) to push door, input, and relay configuration to the unit.

7. Verification

- Controller shows Online status in EntraPass
- Test at least one door, one input, and one relay before terminating remaining field wiring
- Confirm event messages appear correctly in the EntraPass message desktop
- Record controller MAC address, assigned IP, and location on the site network configuration sheet

8. Notes

If the controller fails to appear in KT-Finder after a factory default reset, confirm the laptop and controller are on the same broadcast domain/subnet, and that no managed switch port security is blocking DHCP broadcast traffic.

Confidential — Internal Use Only