

Standard Operating Procedure

KT-4 Controller — Default & Configuration Procedure

Document No.	SOP-LV-024
Related Documents	SOP-LV-004
Revision	1.0
Effective Date	2026-07-24
Review Cycle	Annual
Applies To	Field Technicians, Installers
Jurisdiction	Ontario / Manitoba
Owner	Apex – Operations
Approved By	_____

1. Purpose

This procedure defines the standard method for resetting a Kantech KT-4 door controller to factory default and configuring it for use on an Apex-installed access control system, ensuring consistent commissioning and reducing field errors.

2. Scope

Applies to all Apex technicians installing, replacing, or troubleshooting Kantech KT-4 controllers on EntraPass Special, Corporate, or Global Edition systems.

3. Regulatory & Reference Standards

- Ontario Occupational Health and Safety Act (OHSA) and O. Reg. 213/91 – Construction Projects
- Manitoba Workplace Safety and Health Act
- CSA C22.1 – Canadian Electrical Code, low-voltage wiring practices
- Manufacturer reference: Kantech KT-4 Installation Guide (Johnson Controls / Kantech Knowledge Exchange)

4. Tools & Materials Required

- Laptop with KT-Finder installed and EntraPass workstation access
- Ethernet patch cable
- Site IP addressing scheme / network configuration sheet
- PPE per SOP-LV-004

5. Factory Default Reset

The KT-4 uses a single Reset button on the main board — no jumpers are required. The button sequence confirms with a hold-and-beep step before and after the taps.

1. Locate the Reset button in the upper left of the main board.
2. Press and hold Reset for 3 seconds until you hear 5 beeps.
3. Press Reset three (3) times (for Factory Default DHCP).
4. Press and hold Reset for 3 seconds again until you hear 5 beeps to confirm.
5. Confirm the reset feedback LED and buzzer indicate the factory default DHCP pattern.

6. Configuration (EntraPass)

1. Connect the laptop to the same network/subnet as the controller and open KT-Finder.
2. Confirm the controller appears in the list, identified by MAC address.

3. Assign a static IP address per the site's IP addressing scheme (recommended for EntraPass-managed controllers).
4. Set the operating mode to EntraPass mode (not Standalone/Cloud) unless the site specifically requires standalone operation.
5. In EntraPass, go to Devices → Connection configuration and add/confirm the connection.
6. In EntraPass, go to Devices → Configuring controllers, add the controller, select model KT-4, and enter its IP/MAC address.
7. Reload the controller (Operations → Manual operations on controllers → Reload) to push door, input, and relay configuration to the unit.

7. Verification

- Controller shows Online status in EntraPass
- Test at least one door, one input, and one relay before terminating remaining field wiring
- Confirm event messages appear correctly in the EntraPass message desktop
- Record controller MAC address, assigned IP, and location on the site network configuration sheet

8. Notes

If the controller fails to appear in KT-Finder after a factory default reset, confirm the laptop and controller are on the same broadcast domain/subnet, and that no managed switch port security is blocking DHCP broadcast traffic.

Confidential — Internal Use Only