Inverter selection

Planning reference / not an installation manual or binding policy

01 / Confirm single/three phase, grid voltage, frequency and operating mode.

02 / Check continuous output, surge demand, PV input range and string design.

03 / Verify battery voltage, communication and supported battery models where applicable.

04 / Confirm local grid connection approval and protection requirements.

05 / Use the exact-model installation manual and qualified electrical installer.

This checklist does not establish product performance, compliance, supply or warranty commitments. Confirm exact-model parameters and contract terms in writing. Installation requires qualified professionals, the approved manual and local requirements.

逆变器选型

规划与沟通参考 / 非安装手册或正式政策

01 / 确认单相或三相、电网电压、频率与运行模式。

02 / 核对连续输出、启动需求、光伏输入范围及组串设计。

03 / 如适用，核实电池电压、通讯与支持的电池型号。

04 / 确认当地并网准入与电气保护要求。

05 / 使用具体型号的安装手册，并由合格电气人员实施。

本清单不构成产品性能、合规性、供货或质保承诺。具体参数与合同条款需逐型号书面确认。安装应由合格专业人员依据正式手册与当地要求实施。