Touch Accommodations

If you have trouble using the touch screen, adjust the following settings to change how the screen will respond to touches.

HOLD DURATION

Hold Duration

The duration you must touch the screen before a touch is recognized.

IGNORE REPEAT

Ignore Repeat

The duration in which multiple touches are treated as a single touch.