EE20,EW01, WE20,WW01

Top flange

	(disconnected)	(disconnected)	Board 8	
	C-side 8 (C08)	(disconnected)	Board 7	
■	C-side 7 (C09)	A-side 7 (C01)	Board 6	
D	C-side 6 (C10)	A-side 6 (C02)	Board 5	
9	C-side 5 (C11)	A-side 5 (C03)	Board 4	
T	C-side 4 (C12)	A-side 4 (C04)	Board 3	
CA	C-side 3 (C13)	A-side 3 (C05)	Board 2	
1	C-side 2 (C14)	A-side 2 (C06)	Board 1	
	C-side 1 (C15)	A-side 1 (C07)	Board 0	
AVOQA9 NANI				

	C-side 9 (C25)	A-side 8 (C16)	Board 8		
	C-side 8 (C26)	A-side 8 (C17)	Board 7		
■ 【III	C-side 7 (C27)	A-side 7 (C18)	Board 6		
Q	C-side 6 (C28)	A-side 6 (C19)	Board 5		
9	C-side 5 (C29)	A-side 5 (C20)	Board 4		
	C-side 4 (C30)	A-side 4 (C21)	Board 3		
T A	C-side 3 (C31)	A-side 3 (C22)	Board 2		
4	C-side 2 (C32)	A-side 2 (C23)	Board 1		
	C-side 1 (C33)	A-side 1 (C24)	Board 0		
AVO	AVODA9 NANI				

Middle flange