

Activity Detection

The Activity Detection symbol is a device extender for Cresnet and Ethernet devices.

Signal name and type	Description
Digital output: <activity>	Indicates that the control system has received analog, digital or serial data (below join 17000) from the Ethernet or Cresnet device. The output remains high for <Time> seconds. Any activity above join 17000 is ignored. High/1 = Activity detected; Low/0 = No activity detected
Double-precision parameter: <Time> (see Numeric Formats)	Sets the time that the <activity> output will remain high after activity is detected. If new data comes in while <activity> is high, then the <Time> count will start all over again. The <activity> output will not go low until the full <Time> duration has elapsed without new analog/digital/serial network activity being detected.

Device Status

The Device Status symbol is a device extender for plug-in control cards. It reports the connection status of the card.

Signal name and type	Description
Digital output: <offline>	Indicates that the plug-in card is offline; that is, that the card is unavailable for polling or is physically disconnected from its slot. The output remains high for as long as the card is offline. High/1 = Offline; Low/0 = Online

Device Information

➔ This topic applies to the following devices:

APAD

C2I-ADG-FRONT PANEL

C2I-AMS-FRONT PANEL

Signal Name and Type	Description
Digital input: <Trig>	Sends the five serial strings described below to the control system on the rising edge of the input. The serial information is also sent to the control system when: 1. the device reboots (i.e., after a firmware upload); or 2. power is removed and then reapplied (APAD only). High/1 (rising edge) = Re-transmit serial data; Low/0 = No effect
Serial output: <ProjectName>	The name of the VisionTools Pro-e project.
Serial output: <ProjectDate>	The project date, in MM/DD/YYYY format.
Serial output: <ProjectTime>	The project time, in HH:MM:SS format, 24-hour time format.
Serial output: <FirmwareVersion>	The firmware version without the leading "v". Given "APAD LCD 6-button Panel [v1.00.10, #F0ADAD01]," this string will have "1.00.10" (no quotes).
Serial output: <FirmwareName>	The firmware name. Given the previous example, this string will have "APAD" (no quotes).

Poll Manager

The Poll Manager symbol is a device extender for plug-in control cards and Cresnet devices and touchpanels. It takes the device on and offline without need to physically disconnect it from the network, and reports the current connection status of the device.

Signal Name and Type	Description
Digital input: <poll inhibit>	Takes the device offline for as long as the signal is high. This means the control system skip the device during polling. (By contrast, if the device were simply disconnected from the network the control system would still attempt to poll the device, which can lead to system slowdown in large-scale applications.) When the signal goes low, this puts the device back online and automatically refreshes all digital and analog inputs to the device. High/1 (level sensitive) = Inhibit polling; Low/0 = Resume polling
Digital input: <update request>	Refreshes all digital and analog inputs to the device, as well as any serial strings tied to a Make String Permanent symbol, on the rising edge of the signal. Digital and analog values are also refreshed automatically when a device goes online (and continually thereafter). High/1 (rising edge) = Update request; Low/0 = No effect
Digital output: <offline>	Indicates that the device is offline, and thus not being polled by the control system. The output remains high for as long as the device is not available for polling or physically disconnected from the network. High/1 = Device offline; Low/0 = Device online

infiNET Devices

 When defining a Poll Manager extender for use with the C2N-MNETGW (infiNET wireless gateway), Crestron recommends also defining an [infiNET Offline Manager](#) extender for each infiNET device that is communicating with the C2N-MNETGW. Otherwise if the C2N-MNETGW goes offline, the infiNET device will not indicate that it is offline. The <offline> output of the gateway's Poll Manager should be routed through an [OR](#) symbol together with the <offline> output of the device's infiNET Offline Manager.

Each infiNET device will require a separate OR symbol, programmed as follows:

1. Connect the <offline> output of the Poll Manager for the C2N-MNETWG to an input of the OR symbol.
2. Connect the <offline> output of the infiNET Offline Manager for the infiNET device to an input of the OR symbol. The output of the OR symbol will thus indicate the offline status if either the C2N-MNETGW or the infiNET device goes offline.

Poll Manager (2-Series Extended)

The Poll Manager (2-Series Extended) symbol is a device extender for plug-in control cards and for Cresnet devices and touchpanels. It takes the device on and offline without need to physically disconnect it from the network, and reports the current connection status and network activity of the device.

Signal Name and Type	Description
Digital input: <poll inhibit>	Takes the device offline for as long as the signal is high. This means the control system will skip the device during polling. (By contrast, if the device were simply disconnected from the network the control system would still attempt to poll the device, which can lead to system slowdown in large-scale applications.) When the signal goes low, this puts the device back online and automatically refreshes all digital and analog inputs to the device. High/1 (level sensitive) = Inhibit polling; Low/0 = Resume polling
Digital input: <update request>	Refreshes all digital and analog inputs to the device, as well as any serial strings tied to a Make String Permanent symbol, on the rising edge of the signal. Digital and analog values are also refreshed automatically when a device goes online (and continually thereafter). High/1 (rising edge) = Update request; Low/0 = No effect
	Indicates that the device is offline, and thus not being polled by the control system. The output remains high for as long as the device is not

Digital output: <offline>	available for polling or physically disconnected from the network. High/1 = Device offline; Low/0 = Device online
Digital output: <activity>	Indicates that the control system has received analog, digital or serial data (below join 17000) from the Ethernet or Cresnet device. The output remains high for <Time> seconds. Any activity above join 17000 is ignored. High/1 = Activity detected; Low/0 = No activity detected
Double-precision parameter: <Time> (see Numeric Formats)	Sets the time that the <activity> output will remain high after activity is detected. If new data comes in while <activity> is high, then the <Time> count will start all over again. The <activity> output will not go low until the full <Time> duration has elapsed without new analog/digital/serial network activity being detected.

See also [Make String Permanent](#)

Touchpanel Sleep/Wake Manager

The Touchpanel Sleep/Wake Manager symbol is a device extender for Cresnet and Ethernet touchpanels.

Signal Name and Type	Description
Digital input: <sleep>	Turns off the touchpanel's backlight on the rising edge of the input. High/1 (rising edge) = Turn off backlight; Low/0 = No effect
Digital input: <wake>	Turns on the touchpanel's backlight on the rising edge of the input. High/1 (rising edge) = Turn on backlight; Low/0 = No effect

Ethernet Offline Manager

The Ethernet Offline Manager is a device extender for Ethernet devices and touchpanels. It reports the current connection status of the device.

Signal Name and Type	Description
Digital input: <update request>	Refreshes all digital and analog inputs to the device, as well as any serial strings tied to a Make String Permanent symbol, on the rising edge of the signal. Digital and analog values are also refreshed automatically when a device goes online (and continually thereafter). High/1 (rising edge) = Update request; Low/0 = No effect
Digital output: <offline>	Indicates that the device is offline, and thus not being polled by the control system. The output remains high for as long as the device is not available for polling or physically disconnected from the network. High/1 = Device offline; Low/0 = Device online

See also [Make String Permanent](#)

Front Panel Status (Dual Ethernet + Brightness)

The Front Panel Status (Dual Ethernet + Brightness) symbol is a device extender for the C2I Front Panel slot of 2-Series control systems.

The extender is available only to control systems that accept the C2ENET-2 Ethernet card and which provide standard 2-Series error logging capabilities.

Signal Type and Name	Description
	Sets the brightness of the front panel LCD on the rising edge of the corresponding input, where <Bright_1> = minimum brightness and <Bright_4> = maximum brightness.

Digital inputs: <Bright_1> through <Bright_4>	Another way to change the brightness is to press the BKLT push button on the front panel itself. High/1 (rising edge) = Set brightness level from 1 to 4; Low/0 = No effect
Digital outputs: <Bright_1_FB> through <Bright_4_FB>	Indicates the current brightness setting of the front panel LCD. The output remains high for as long as the brightness is at the corresponding level. High/1 = Brightness at indicated level; Low/0 = Brightness not at indicated level
Digital outputs: <LinkA_LED>, <LinkB_LED>	Indicates that the corresponding LAN A or LAN B LED on the front panel is lit. The output remains high for as long as the LED is lit. High/1 = LED is on; Low/0 = LED is off
Digital output: <Err_LED>	Indicates that the ERR LED on the front panel is lit. The output remains high for as long as the LED is lit. High/1 = LED is on; Low/0 = LED is off

Front Panel Status (Dual Ethernet)

The Front Panel Status (Dual Ethernet) symbol is a device extender for the C2I Front Panel slot of 2-Series control systems equipped with front panel LEDs.

The extender is available only to control systems that accept the C2ENET-2 Ethernet card and which provide standard 2-Series error logging capabilities.

Signal Type and Name	Description
Digital outputs: <LinkA_LED>, <LinkB_LED>	Indicates that the corresponding LAN A or LAN B LED on the front panel is lit. The output remains high for as long as the LED is lit. High/1 = LED is on; Low/0 = LED is off
Digital output: <Err_LED>	Indicates that the ERR LED on the front panel is lit. The output remains high for as long as the LED is lit. High/1 = LED is on; Low/0 = LED is off

Front Panel Status (Error LED Only)

The Front Panel Status (Error LED Only) symbol is a device extender for the C2I Front Panel slot of 2-Series control systems.

The extender available to control systems that provide standard 2-Series error logging capabilities.

Signal Type and Name	Description
Digital output: <Err_LED>	Indicates that the ERR LED on the front panel is lit. The output remains high for as long as the LED is lit. High/1 = LED is on; Low/0 = LED is off

Front Panel Status (Single Ethernet)

Description

The Front Panel Status (Single Ethernet) symbol is available to single LAN control systems equipped with front panel LED and that support error logging.

Signal Type and Name	Description
Digital output: <LinkA_LED>	Indicates that the control system's LAN LED is lit. The output remains high for as long as the LED is lit. High/1 = LED is on; Low/0 = LED is off
Digital output: <Err_LED>	Indicates that the ERR LED is lit. The output remains high for as long as the LED is lit. High/1 = LED is on; Low/0 = LED is off

CNX-DVP4 Touch In Format

The CNX-DVP4 Touch In Format device extender controls the delivery of touch input data to the CNX-DVP4 over Cresnet or Ethernet. This allows Crestron devices such as an RF remote or Cresnet/Ethernet touchpanel to control the cursor. In both cases the RS-232 Touchscreen/Mouse port can still be used for

any other type of touch-in device, such as a mouse or third party touchscreen.

Signal name and type	Description
Serial input: <CrestronMouseDriver>	Touch input data in "Crestron Mouse Driver" format. This format is used by Crestron touchpanels to control the cursor over Cresnet or Ethernet.
Serial input: <MS_Mouse>	Touch input data in "MS Mouse" format. This format is used by Crestron wireless remotes to control the cursor wirelessly. For example, to control the cursor with a Crestron CNWM RF remote, connect the <data> output of the CNWM to the <MS_Mouse> input.
Serial input: <serial1>	Touch input data in "Touch-the-PC V2" format. This format is used by newer Crestron touchpanels to control the cursor over Cresnet or Ethernet.
Serial inputs: <serial2> through <serial14>	Not implemented.

CNX-DVP4 Touch Out Format

The CNX-DVP4 provides four inputs labeled VIDEO INPUT 1 through VIDEO INPUT 4 that support DVI/RGB sources and video sources (composite and S-Video).

Signal name and type	Description
Analog inputs: < DVI/RGB-1 > through < DVI/RGB-	These inputs determine the touch output format of the corresponding <text-i1> through <text-i16> outputs on the C2I-TPS touchpanel interface. (See the table below for the mapping of the analog inputs to the specific string.)

4> <SVID-1> through <SVID-4> <Composite-1A> through <Composite-4A> <Composite-1B> through <Composite-4B>	Valid values range from 0d to 4d, as follows: 0d = Crestron Mouse 1d = Boekeler Pointmaker Telestrator 2d = SMART Matisse (SC3) 3d = SMART Board (SC6) 4d = DVP4 Built-in Annotation
---	---

Each analog input determines the format of a specific serial output on the C2I-TPS-DI touchpanel interface, as shown in the following table:

CNX-DVP4DI Touch Out Input	C2I-TPS-DI Output
<DVI/RGB-1>	<text-i1>
<DVI/RGB-2>	<text-i2>
<DVI/RGB-3>	<text-i3>
<DVI/RGB-4>	<text-i4>
<SVID-1>	<text-i5>
<SVID-1>	<text-i6>
<SVID-3>	<text-i7>
<SVID-4>	<text-i8>
<Composite-1A>	<text-i9>
<Composite-1B>	<text-i10>
<Composite-2A>	<text-i11>
<Composite-2B>	<text-i12>
<Composite-3A>	<text-i13>
<Composite-3B>	<text-i14>
<Composite-4A>	<text-i15>
<Composite-4B>	<text-i16>