

# How To Use: DJ MINI



1. Turn on the **receiver** and the Transmitter **clip-on mic**. They pair automatically.
2. Connect the **receiver** to your device.
  - **Phone**: plug in the correct USB C or Lightning adapter.
  - **Camera**: use the small audio cable from the receiver to the camera mic input.
  - **Computer**: plug the receiver directly into a USB port and select it as the microphone in Sound Settings.
3. Clip the mic to your shirt near the center of your chest. Keep the mic facing outward. Make sure clothing does not rub the microphone. Use the wind cover outside.

#### **4. Check levels.**

Speak normally and watch the audio bar on the **receiver**.

- If the bar reaches the end, lower the gain.
- On computer, choose the DJI Mic as the input device and adjust input level if needed.

#### **5. Record.**

**Phone:** open your camera or video app and record.

**Camera:** record normally.

**Computer:** open your recording or call program and select the DJI Mic as the input.

---

#### **How to turn off**

1. Turn off the transmitter (clip-on mic): hold the power button until the light goes out.
  2. Turn off the receiver: hold its power button until the screen turns black.  
**Do not just unplug before powering off.** Power off first so the units disconnect cleanly.
- 

#### **Important care so it does not get damaged**

1. Do not yank cables. Hold the connector when unplugging.
2. Do not store the mic while still sweaty or damp. Let it air dry before putting in the case.
3. Avoid placing the mic under clothing layers that rub on it. This prevents wear on the mesh and prevents noise.

4. Keep the wind cover stored when not in use so it does not get crushed.
  5. Do not bend the receiver's plug while it is connected. Move the device gently instead.
- 

## **Common problems and fast fixes**

**No sound on phone:** unplug and plug the receiver back in, then reopen the camera app.

**No sound on camera:** set the camera audio input to Mic.

**No sound on computer:** open Sound Settings and choose the DJI Mic as the input.

**Distorted sound:** lower gain on the receiver.

**Wind noise:** always use the wind cover outside.