Project 4 Master Code

Table of Contents

Inital Variables and Constraints	1
Create bounds	1
Initalize wing object	2
Start fmincon	2

By 6110

Inital Variables and Constraints

computational values Change these for altering the analysis model

```
close all; clear all;
nodes =15; % number of nodes evaluated at
NCP=3;
NPP=4;
complex_step_size = 1e-60;
% model variables
mass =500; % kg
L = 7.5; % meter
E = 70*10^9; % Pa
Y=600 *10^6; % Yeild Stress Pa
rho = 1600.0; % density (kg /m^3)
w = (2.5 * 9.8 *.5* 500); % 2.5 * plane weight, note that the 2.5 is
put here to avoid as many calculations in the fmincon as possible
```

Create bounds

Creates linear bounds

```
rdist=2.5*10^-3; % thickness, m
rmin=1*10^-2; % min radi m
rmax = 5*10^-2; % max radi m

A=zeros(nodes,nodes*2); % prealloc
for i=1:nodes
    A(i, i)=1; % lower node
    A(i, i+nodes)=1; % upper node
    b(i)=rmax; % distance

lb(1,i)=rmin; %% lb for r_low
    ub(1,i)=rmax-rdist; %% ub for r_low
    lb(1,i+nodes)=rdist; % lb for thick
    ub(1,i+nodes)=rmax-rmin-rdist; %up for think
end
```

Initalize wing object

provide the nominal spar values as initial parameter

```
r_in = 0.0415*ones(nodes,1); % nominal values of inner radii
thicc = 0.0085*ones(nodes,1); % nominal values of annular thickness
x0 = [r_in;thicc]; % concactenated design vector
wing=Spar(w,L,rho,E,Y,nodes,x0,A,b,lb,ub,NCP,NPP,complex_step_size);
```

Start fmincon

Published with MATLAB® R2018b