

ARDUINO PIN#	CONNECTING PIN
D 0 1	N/A
D 0 2	WEST PED BUTTON
D 0 3	KEYPAD R 1 (PIN 1)
D 0 4	KEYPAD R 2 (PIN 2)
D 0 5	KEYPAD R 3 (PIN 3)
D 0 6	KEYPAD R 4 (PIN 4)
D 0 7	KEYPAD C 1 (PIN 5)
D 0 8	KEYPAD C 2 (PIN 6)
D 0 9	KEYPAD C 3 (PIN 7)
D 1 0	KEYPAD C 4 (PIN 8)
D 1 1	LCD (#1) RS (PIN 4)
D 1 2	LCD (#1) E (PIN 6)
D 1 3	LCD (#1) D4 (PIN 11)
D 1 4	LCD (#1) D5 (PIN 12)
D 1 5	LCD (#1) D6 (PIN 13)
D 1 6	LCD (#1) D7 (PIN 14)
D 1 7	NORTH PED REQUEST LED
D 1 8	EAST PED REQUEST LED
D 1 9	SOUTH PED REQUEST LED
D 2 0	WEST PED REQUEST LED
D 2 1	N/A

ARDUINO PIN#				CONNECTING PIN
D	2	2		ULN (#1) PIN #1 → NORTH_R
D	2	3		ULN (#1) PIN #2 → NORTH_Y
D	2	4		ULN (#1) PIN #3 → NORTH_G
D	2	5		ULN (#1) PIN #4 → NORTH_BG
D	2	6		ULN (#1) PIN #5 → EAST_R
D	2	7		ULN (#1) PIN #6 → EAST_Y
D	2	8		ULN (#1) PIN #7 → EAST_G
D	2	9		ULN (#1) PIN #8 → EAST_BG
D	3	0		ULN (#2) PIN #1 → SOUTH_R
D	3	1		ULN (#2) PIN #2 → SOUTH_Y
D	3	2		ULN (#2) PIN #3 → SOUTH_G
D	3	3		ULN (#2) PIN #4 → SOUTH_BG
D	3	4		ULN (#2) PIN #5 → WEST_R
D	3	5		ULN (#2) PIN #6 → WEST_Y
D	3	6		ULN (#2) PIN #7 → WEST_G
D	3	7		ULN (#2) PIN #8 → WEST_BG
D	3	8		ULN (#3) PIN #1 → PED_N_W
D	3	9		ULN (#3) PIN #2 → PED_N_S
D	4	0		ULN (#3) PIN #3 → PED_E_W
D	4	1		ULN (#3) PIN #4 → PED_E_S
D	4	2		ULN (#3) PIN #5 → PED_W_W

ARDUINO PIN#				CONNECTING PIN			
D	4	3		ULN (#3)	PIN #4	→	PED_W_S
D	4	4		ULN (#3)	PIN #7	→	PED_S_W
D	4	5		ULN (#3)	PIN #8	→	PED_S_S
D	4	6		GND SPEAKER (+)			
D	4	7		NORTH	LM393	PIN #1	
D	4	8		EAST	LM393	PIN #1	
D	4	9		SOUTH	LM393	PIN #1	
D	5	0		WEST	LM393	PIN #1	
D	5	1		NORTH PED BUTTON			
D	5	2		EAST PED BUTTON			
D	5	3		SOUTH PED BUTTON			
A	0	(D	5 4)	LCD (#2)	RS	(PIN 4)	
A	1	(D	5 5)	LCD (#2)	E	(PIN 6)	
A	2	(D	5 6)	LCD (#2)	D4	(PIN 11)	
A	3	(D	5 7)	LCD (#2)	D5	(PIN 12)	
A	4	(D	5 8)	LCD (#2)	D6	(PIN 13)	
A	5	(D	5 9)	LCD (#2)	D7	(PIN 14)	
A	6	(D	6 0)	MAINTENANCE RGB_R			
A	7	(D	6 1)	MAINTENANCE RGB_G			
A	8	(D	6 2)	MAINTENANCE RGB_B			

