

WSG Gripper

Basic information

The current setting of IP address in WSG 32 Control Panel is:

WSG Gripper 1: 172.20.1.1

WSG Gripper 2: 172.20.1.2

Setting of IP address in your Linux Wired Network:

Address: 172.20.1.x (x besides 1; 2); Mask: 255.255.255.0

If the IP address of the gripper is no longer assessable, follow Page 44, section 9.18: https://weiss-robotics.com/servo-electric/wsg-series/?file=files/downloads/wsg/um_wsg32_en.pdf&cid=11013

Usage

Python

In the browser, type the IP address of the gripper to enter the Control Panel.

- Interface select “TCP/IP”
- Enable “Use text based Interfaces”.
- Enable CRC.

WSG 32 Control Panel

Location: n/a, Contact: n/a

Settings

Diagnostics

Scripting

Motion

Help



Settings > Command Interface

Command Interface

Interface

Select the interface that is used for commands

TCP/IP

TCP Settings

Use text based Interface

Select this checkbox if you wish to use the text-based command interface. If not selected, the binary command interface is active.

☒ Enable

TCP Communication Port

This port is used as command interface. Valid port numbers are 100 to 65530.

1000

Enable error state on TCP disconnect

Disable this checkbox if you don't want the device to enter an error state if the connection is lost accidentally. Please refer to the manual for a detailed description for your device. By default, this option should be enabled.

☐ Enable error

Enable CRC

Select this checkbox if you wish the binary command interface to verify the CRC checksum on each incoming message. By default, this option should be enabled.

☒ Enable CRC

Network Configuration

To setup the device's Ethernet interface, please follow this link to the Advanced Network Configuration page.



Apply

Discard

Gripper

State

Idle

Position

[n/a]

Speed

0.0 mm/s

Force

0.0 N

STOP

ACK

System State

Referenced

Moving

Blocked Minus

Blocked Plus

Soft Limit Minus

Soft Limit Plus

Axis stopped

Target Pos reached

Force Control Mode

Fast Stop

Temperature Warning

Temperature Fault

Power Fault

Current Fault

Finger Fault

Command Failure

Script is running

Script Failure

Web Connection

Link Active

Powered by Weiss Robotics. Copyright © 2010-2021, all rights reserved.

Code:

- <https://github.com/real-stanford/minWSG>

ROS

In the browser, type the IP address of the gripper to enter the Control Panel.

Compared with the setting when using Python to control the gripper:

- Disable “Use text based Interface”

WSG 32 Control Panel

Location: n/a, Contact: n/a

Settings

Diagnostics

Scripting

Motion

Help

Settings > Command Interface

Command Interface

Interface

Select the interface that is used for commands

TCP/IP

TCP Settings

Use text based interface

Select this checkbox if you wish to use the text-based command interface. If not selected, the binary command interface is active.

☐ Enable

TCP Communication Port

This port is used as command interface. Valid port numbers are 100 to 65530.

1000

Enable error state on TCP disconnect

Disable this checkbox if you don't want the device to enter an error state if the connection is lost accidentally. Please refer to the manual for a detailed description for your device. By default, this option should be enabled.

☐ Enable error

Enable CRC

Select this checkbox if you wish the binary command interface to verify the CRC checksum on each incoming message. By default, this option should be enabled.

☒ Enable CRC

Network Configuration

To setup the device's Ethernet interface, please follow this link to the Advanced Network Configuration page.

➔

Apply

Discard

Code:

- Please use this repo: <https://github.com/mcubelab/wsg32-ros-pkg>

Code modification:

In the launch file `wsg_32_tcp_script.launch`:

- Change the corresponding IP address and port
- Change `default="script"` to:

```
<arg name="com_mode" default="auto_update" />
```

- Change node name to:

```
<node name="wsg_32_driver" pkg="wsg_32_driver" type="wsg_32_ip">
```