
Manufact urer	Mode l	Part No	Description	Picture	Maintenance Data
Boeing		1051-52- 53-54	PART 6, 51-00-26, PAGE 8-9, FIGURE 1	(3) Never the property of the control of the contro	
Boeing		1077	PART 6, 51-00-26, PAGE 8-9, FIGURE 1	(2) Steam in agreement of the contract of the	
Boeing		126	Surface Crack PART 6, 51-00-00, PAGE 10	Commence of the commence of th	
Boeing	737	127-XXX	Corrosion reference standard Calibration Block PART 6, 51-00- 00, PAGE 5	Shows Tolerand on the Market M	Calibration Block
Boeing		186A-B-C- D-E-F	PART 6, 51-00-00, PAGE 6	2 have been seen. 2 days Tales and the seen of the see	
Boeing		188A	For Protruding head fasteners PART 6, 51- 00-00, FIGURE 23, PAGE 12	2 John Warring Co.	
Boeing	737	189	737 NTM 51-01-00 PART 1 FIG. 4 PAGE 2-3	2 have the second of the secon	
Boeing		194	PART 6, 53-30-00, FIGURE 1, PAGE 5	0 0	
Boeing		194A	CMN NDT 53-30-00 PART 6, FIGURE 4, PAGE 6	00	


Boeing 737 335 PART6, 53-10-31, PAGE7



Boeing 737 A386 737 NDT 53-10-45 PART 6 PAGE 19



Boeing 737 A389A-A389B-A389C FIGURE 3, PART 6, 53-10-41, PAGE 13



ANDT 1049-1077- PART 6, 53-30-00, FİGURE 5, PAGE 6



Boeing

ANDT
1079ANDT
1082

Reference Standard
ANDT 1079-ANDT
1082



Boeing	737	ANDT 3006	PART6, 53-30-14, FIGURE 2, PAGE7	Calibration Block
Boeing	737	ANDT300 4	PART 6,53-30-12, FIGURE 2,PAGE7	
Boeing	737	ANDT301 6-B	PART6,53-10-54, FIGURE 2 PAGE8	
Boeing	737	ANDT301 9	PART 6, 53-30- 16,FIGURE 1, PAGE 5	
Boeing		ANDT412 6	PART6, 53-30-00, FIGURE 6, PAGE 5	

MD80-53-Boeing 303 NDT 1022-PART 6, 51-00-14, 23-24-25-Boeing 757 PAGE 7, FIGURE 3 26-27 Calibration Block, NDT 1087- DETAIL2, 53-30-00, Calibration Boeing 737 PART6, FIGURE9, **Block** 1..4 PAGE 10-11-12 Rail Guide, DETAIL2, NDT 1087-Boeing 737 53-30-00, PART6, Rail Guide FIGURE9, PAGE 12 Calibration Boeing 737 NDT 1088 **Block** NDT 1094- FIGURE 2, PART 4, Calibration Boeing 737 XXX-A 53-30-07, PAGE 13 Block

Boeing	757	NDT 1095	PART 6, 53-00-16, FIGURE 1, PAGE 8	*
Boeing	757	NDT 1099	FIGURE 1, PART 6, 53-30-14, PAGE 5	Calibration Block
Boeing	737	NDT 3038	737 NDT 57-50-02 PART 4 PAGE 8 FIG. 4	
Boeing	737	NDT 3092	MT-T-D PAGE 2-3 Form No: 4300-FR-011	
Boeing	757	NDT 512	757 NTM 57-10-01 PART 4, 57-10-01, FIG.3 PAGE6	


Boeing	757	NDT 514	757 NTM 57-20-01 PART 6 FIG. 2 PAGE 6-7	
Boeing	757	NDT 515	757 NTM 57-21-01 PART 4 FIG. 3 PAGE 6	
Boeing	757	NDT 516	757 NTM 57-23-01 PART 6 FIG. 1 PAGE 3	
Boeing		NDT 519	MT-T-D-0011, 2024 T3, PAGE 2-3 Form No: 4300-FR-011	
Boeing	757	NDT 527	PART 6 53-30-06 PAGE 8 FIGURE 2	*

PART4, 57-10-02, Boeing 757 NDT 537 FIGURE 3, PAGE8



Calibration Block

PART 4, 57-20-02, NDT 546 Boeing 757 FIGURE 2, PAGE 7



NDT1016-17-18-Boeing

1920-21-84

PART6, 51-00-00, FIGURE 16, PAGE 10



Boeing 757 t1/t2

NDT1039- FIGURE 3, PART 4, 53-30-01, PAGE 9



NDT1048 Boeing

Flash -Head Fastener Reference Standard PART6, 51-00-00, page11



PART 6, 51-00-NDT1084 -Boeing 00, FIGURE 16, PAGE 10 PART 6, 51-00-NDT1084 -00,FIGURE 16, PAGE Boeing 10 PART 6, 51-00-NDT1084 -00,FIGURE 16, PAGE Boeing NDT1086- PART4, 53-30-Boeing 767 050 05,FIGURE 2, PAGE10 Transducer Positioner, NDT1086-PART 4, 53-00-01, Boeing 767 FIGURE 3, PAGE 9

CMN NDT PART 4, NDT1096-Boeing 53-30-08, PAGE 34, (050-070)FIGURE 2 737 NDT 53-10-02 Boeing 737 NDT3001 PART 4 PAGE 8 FIG. 737 NDT 53-10-03 PART 4, FIGURE 3, Boeing NDT3012 737 PAGE 8 737 NDT 57-50-01 PART 4, FIGURE 2, Boeing 737 NDT3021

737 NDT 32-10-02 Boeing 737 NDT3023 PART 4 PAGE 11 FIG.

PAGE 8



737 NDT 53-10-04 NDT3024 Boeing 737 PART 4 FIG. 3 PAGE 10 NDT3038- PART 4, 57-50-Boeing 02,FIGURE 3, PAGE 7 FIGURE 2, PART 6, NDT3049 Boeing 737 53-10-67, PAGE 21 737 NDT 53-30-20 Boeing 737 NDT3050 PART 6 PAGE 6 NDT3065- PART 6-53-30-22, Boeing FIGURE 3, PAGE 6-7 STL

Boeing	737	NDT3068	737 NDT 52-10-02 PART 4 PAGE 7	
Boeing		NDT3118	PART 6, 52-30-01, FIGURE 3, PAGE 10	
Boeing	737	NDT3152- A	PART 6, 57-10-55, FIGURE 2, PAGE 8	*
Boeing	737	NDT3170	PART 4, 57-10-06, PAGE 16, FIGURE 2	*
Boeing	737	NDT3171	PART 4, 57-10-06, PAGE 17, FIGURE 3	*

Boeing	737	NDT369	Calibration Block, PART6, 53-30-05, FIGURE 5, PAGE 11	Calibration Block
Boeing	737	NDT392	737 NDT 53-30-03 PART 4 PAGE 7 FIG. 2	
Boeing	737	NDT396	PART 6, 53-30-09, PAGE 8, FIGURE 2	
Boeing	737	NDT398	Reference Standard 737 NDT 53-10-01 PART 4, PAGE 8	
Boeing	757	NDT514	757 NTM 57-20-01 PART 6 FIG. 2 PAGE 8 and 9	

Boeing	757	NDT518	Ultrasonic Inspection Reference standart 757 NTM: 57-21-02 Part 4 Fig.2 Page6		Ultrasonic Inspection
Boeing	757	NDT520	Eddy Current Inspection Reference standard 757 NTM: 52- 30-02 Part 6 Fig.2 Page 8		Eddy Current
Boeing	757	NDT528	PART 4, 55-10-04, PAGE 10, FIGURE 2		
Boeing	757	NDT531	PART 6, 53-60-01, PAGE 6, FIGURE 2		
Boeing	757	NDT542	PART 4, 55-10-07, PAGE 11, FIGURE 3	10	

Boeing	757	NDT555	PART 6, 53-10-19, PAGE 8, FIGURE 2	
Boeing	757	NDT562	PART 4, 57-25-01, PAGE 11, FIGURE 2	
Boeing	757	NDT575	PART 6, 53-60-12, PAGE 8, FIGURE 2	0 0
Boeing	757	NDT578	PART 6, 55-10-04, PAGE 10, FIGURE 2	