

This document provides additional assistance with wiring your Extron IP Link Pro Control Processor to your device. Different components may require a different wiring scheme than those listed below.

For complete operating instructions, refer to the user's manual for the specific IP Link Pro Control Processor or the documentation supplied by the manufacturer of the controlled device.

For more information on using Global Scriptor Modules, refer to the "[Guide to Using Scriptor Modules](#)" document.

Device Specifications

Device Type: Collaboration Systems
Manufacturer: WolfVision
Firmware Version: N/A
Model(s): Cynap Pure Pro, Cynap Core Pro

Tested on the Following Software and Firmware Versions

Global Scriptor Version	2.23.0.13
IP Link Pro Control Processor Firmware	3.18.0001-b002
IP Link Pro Control Processor xi Firmware	1.10.0001-b002
IP Link Pro Control Processor Q xi Firmware	1.10.0002-b002

Version History

Module Version	Date	Notes
1_1_1_0	3/21/2025	- Added commands: Streaming Mode, Visualizer Control, Window Status, BYOD Pin Display, File List Navigation, File List Root Path, File List Search Results, File List Search Set, File List Update, Open File Command, Window Control Close, Window Control Full Screen - Updated Window Start command to support Stream Input 3 – 20. - Added Window parameter and changed Value type to String - Added parameter: Number of File List Search.
1_0_2_0	6/4/2021	Initial Version

Module Notes

- Unidirectional variable must be set to 'True' if status is not required. Default value is 'False'.
Example: `InterfaceName.Unidirectional = 'True'`
- connectionCounter variable must be set to the number of queries that will be sent to the device before displaying 'Disconnected' if no response is received. Default value is 15.
Example: `InterfaceName.connectionCounter = 5`
- If login credentials are required, deviceUsername and devicePassword must be set accordingly.
Example: `InterfaceName.devicePassword = 'extron'`
- NumberOfFileListSearch variable must be set accordingly. Default value is '5'. NumberOfFileListSearch ranges from 1 to 15.
Example: `InterfaceName.NumberOfFileListSearch = '5'`

Supported Class and Example

EthernetClass
<code>InterfaceName = ModuleName.EthernetClass('192.168.254.254', 50915, Model='Cynap Pure Pro')</code>

Control Commands

Format with Qualifier:

```
InterfaceName.Set(Command, Value, {'Qualifier Key': 'Qualifier Value'})
```

Format without Qualifier:

```
InterfaceName.Set(Command, Value)
```

Command EndPresentation	Value None		
Qualifier Key 'Delete Recordings Folder'	Qualifier Value 'Yes'	Qualifier Value 'No'	
Qualifier Key 'Delete Snapshots Folder'	Qualifier Value 'Yes'	Qualifier Value 'No'	
Qualifier Key 'Power Off Mode'	Qualifier Value 'New Presentation' 'Screensaver'	Qualifier Value 'Standby'	Qualifier Value 'Screen Off'
# EndPresentation example InterfaceName.Set('EndPresentation', None, {'Delete Recordings Folder': 'Yes', 'Delete Snapshots Folder': 'Yes', 'Power Off Mode': 'New Presentation'})			
Command FileListNavigation	Value 'Up' 'Page Down'	Value 'Down'	Value 'Page Up'
# FileListNavigation example InterfaceName.Set('FileListNavigation', 'Up')			
Command FileListSearchSet	Value 1 – 15		
Qualifier Key 'File List Root Path'	Qualifier Value 'String'		
# FileListSearchSet example InterfaceName.Set('FileListSearchSet', 15, {'File List Root Path': 'String'})			
Command FileListUpdate	Value None		
Qualifier Key 'File List Root Path'	Qualifier Value 'String'		
# FileListUpdate example InterfaceName.Set('FileListUpdate', None, {'File List Root Path': 'String'})			
Command LoginCommand ¹	Value 'User'	Value 'Admin'	
# LoginCommand Admin example InterfaceName.Set('LoginCommand', 'Admin') # LoginCommand User example InterfaceName.Set('LoginCommand', 'User', {'Password': 'String'})			
Command MasterMute	Value 'On'	Value 'Off'	Value 'Toggle'
# MasterMute example InterfaceName.Set('MasterMute', 'On')			
Command MasterVolume	Value 0 to 100 in steps of 1 %		
# MasterVolume example InterfaceName.Set('MasterVolume', 100)			

Global Scripter Module Communication Sheet

Command	Value		
OpenFileCommand	None		
# OpenFileCommand example InterfaceName.Set('OpenFileCommand', None)			
Command	Value		
PowerOff	None		
# PowerOff example InterfaceName.Set('PowerOff', None)			
Command	Value	Value	
StreamingMode	'On'	'Off'	
# StreamingMode example InterfaceName.Set('StreamingMode', 'On')			
Command	Value	Value	Value
VideoRecording	'Start'	'Pause/Resume'	'Stop'
# VideoRecording example InterfaceName.Set('VideoRecording', 'Start')			
Command	Value	Value	Value
VisualizerControl	'Auto Focus On'	'Auto Focus Off'	'Freeze On'
	'Freeze Off'	'Preset Save'	'Preset Recall'
	'Auto Focus Toggle'	'Freeze Toggle'	'Power On'
	'Power Off'	'Power Toggle'	'Light On'
	'Light Off'	'Light Toggle'	'Capture Area Shift On'
	'Capture Area Shift Off'	'Capture Area Shift Toggle'	'One-Push Auto Focus'
Qualifier Key	Qualifier Value		
'Window'	'1' – '4'		
# VisualizerControl example InterfaceName.Set('VisualizerControl', 'Auto Focus On', {'Window': '1'})			
Command	Value		
WindowControlClose	None		
Qualifier Key	Qualifier Value		
'Window'	'1' – '4'		
# WindowControlClose example InterfaceName.Set('WindowControlClose', None, {'Window': '1'})			
Command	Value	Value	
WindowControlFullscreen	'On'	'Off'	
Qualifier Key	Qualifier Value		
'Window'	'1' – '4'		
# WindowControlFullscreen example InterfaceName.Set('WindowControlFullscreen', 'On', {'Window': '1'})			
Command	Value	Value	Value
WindowStart	'HDMI 1'	'HDMI 2'	'Webcam 1'
	'Webcam 2'	'Stream Input 1'	'Stream Input 2'
	'Stream Input 3'	'Stream Input 4'	'Stream Input 5'
	'Stream Input 6'	'Stream Input 7'	'Stream Input 8'
	'Stream Input 9'	'Stream Input 10'	'Stream Input 11'
	'Stream Input 12'	'Stream Input 13'	'Stream Input 14'
	'Stream Input 15'	'Stream Input 16'	'Stream Input 17'
	'Stream Input 18'	'Stream Input 19'	'Stream Input 20'
	Qualifier Key	Qualifier Value	Qualifier Value
'Window'	'1' – '4'	'Auto Arrange'	
# WindowStart example InterfaceName.Set('WindowStart', 'HDMI 1', {'Window': '1'})			

Global Scriptor Module Communication Sheet

Command ZoomMeetingStart ²	Value None		
Qualifier Key 'Window'	Qualifier Value '1' – '4'	Qualifier Value 'Auto Arrange'	
Qualifier Key 'Type'	Qualifier Value 'Host'	Qualifier Value 'Join'	
Qualifier Key 'Meeting ID'	Qualifier Value 'String'		
Qualifier Key 'Meeting Name'	Qualifier Value 'String'		
Qualifier Key 'Meeting Password'	Qualifier Value 'String'		
# ZoomMeetingStart example InterfaceName.Set('ZoomMeetingStart', None, {'Window': '1', 'Type': 'Host', 'Window': '1', 'Meeting ID': 'String', 'Meeting Name': 'String', 'Meeting Password': 'String'})			
Command ZoomWebconferenceControl	Value 'Toggle Audio Mute'	Value 'Leave Meeting'	Value 'Toggle Screenshare'
	'Toggle Video Mute'	'End Local Meeting'	'Toggle Audio Mute for All Participants (Local Meeting Only)'
	'Toggle Show Participants'		
Qualifier Key 'Window'	Qualifier Value '1' – '4'		
# ZoomWebconferenceControl example InterfaceName.Set('ZoomWebconferenceControl', 'Toggle Audio Mute', {'Window': '1'})			

¹ Admin Login always uses the password in the module script. User Login takes Login password parameter as password.

² Requires Meeting ID, Meeting Name and Meeting Password to be set.

Status Available

For all commands, call Update to receive the latest status. ConnectionStatus, and FileListSearchResults do not support the Update function. ConnectionStatus is triggered by the device providing a successful response to other Update function calls.

Format with Qualifier:

```
InterfaceName.Update(Command, {'Qualifier Key': 'Qualifier Value'})
Value = InterfaceName.ReadStatus(Command, {'Qualifier Key': 'Qualifier Value'})
InterfaceName.SubscribeStatus(Command, {'Qualifier Key': 'Qualifier Value'},
```

FeedbackHandler)

FeedbackHandler will be called only when the specified qualifier gets a new status.

Format without Qualifier:

```
InterfaceName.Update(Command)
Value = InterfaceName.ReadStatus(Command)
InterfaceName.SubscribeStatus(Command, None, FeedbackHandler)
FeedbackHandler will be called when any qualifier gets a new status.
```

Command BYODPinDisplay	Value 'String'	
# BYODPinDisplay example InterfaceName.Update('BYODPinDisplay') Value = InterfaceName.ReadStatus('BYODPinDisplay') InterfaceName.SubscribeStatus('BYODPinDisplay', None, FeedbackHandler)		
Command ConnectionStatus	Value 'Connected'	Value 'Disconnected'
# ConnectionStatus example Value = InterfaceName.ReadStatus('ConnectionStatus') InterfaceName.SubscribeStatus('ConnectionStatus', None, FeedbackHandler)		
Command FileListSearchResults	Value 'String'	
Qualifier Key 'Button'	Qualifier Value 1 – 15	
# FileListSearchResults example Value = InterfaceName.ReadStatus('FileListSearchResults', {'Button': 15}) InterfaceName.SubscribeStatus('FileListSearchResults', None, FeedbackHandler)		
Command StreamingMode	Value 'On'	Value 'Off'
# StreamingMode example InterfaceName.Update('StreamingMode') Value = InterfaceName.ReadStatus('StreamingMode') InterfaceName.SubscribeStatus('StreamingMode', None, FeedbackHandler)		
Command WindowControlFullscreen	Value 'On'	Value 'Off'
Qualifier Key 'Window'	Qualifier Value '1' – '4'	
# WindowControlFullscreen example InterfaceName.Update('WindowControlFullscreen', {'Window': '1'}) Value = InterfaceName.ReadStatus('WindowControlFullscreen', {'Window': '1'}) InterfaceName.SubscribeStatus('WindowControlFullscreen', None, FeedbackHandler)		

Global Scripter Module Communication Sheet

Command WindowStatus	Value 'String'
Qualifier Key 'Window'	Qualifier Value '1' – '4'
<pre># WindowStatus example InterfaceName.Update('WindowStatus', {'Window': '1'}) Value = InterfaceName.ReadStatus('WindowStatus', {'Window': '1'}) InterfaceName.SubscribeStatus('WindowStatus', None, FeedbackHandler)</pre>	

Network Communication

When configuring the Ethernet module, be sure device settings match those of the Global Scriptor ethernet interface.

Port Type: Ethernet (TCP)

Default Port: 50915

Logon Credentials Supported: Yes

Multi-Connection Capabilities: Undetermined

Port Changeability: No

Ethernet Module Configuration Description

Please refer to user manual for settings and changes to the network communication

Notes for the Device

Appendix A. Set Commands

End Presentation None Delete Recordings Folder No Delete Snapshots Folder No Power Off Mode New Presentation	\x09\xCBI\x03\x00\x00\x00
End Presentation None Delete Recordings Folder No Delete Snapshots Folder No Power Off Mode Screen Off	\x09\xCBI\x03\x00\x00\x02
End Presentation None Delete Recordings Folder No Delete Snapshots Folder No Power Off Mode Screensaver	\x09\xCBI\x03\x00\x00\x03
End Presentation None Delete Recordings Folder No Delete Snapshots Folder No Power Off Mode Standby	\x09\xCBI\x03\x00\x00\x01
End Presentation None Delete Recordings Folder No Delete Snapshots Folder Yes Power Off Mode New Presentation	\x09\xCBI\x03\x00\x01\x00
End Presentation None Delete Recordings Folder No Delete Snapshots Folder Yes Power Off Mode Screen Off	\x09\xCBI\x03\x00\x01\x02
End Presentation None Delete Recordings Folder No Delete Snapshots Folder Yes Power Off Mode Screensaver	\x09\xCBI\x03\x00\x01\x03
End Presentation None Delete Recordings Folder No Delete Snapshots Folder Yes	\x09\xCBI\x03\x00\x01\x01

Global Scriptor Module Communication Sheet

Revision: 3/21/2025

Power Off Mode Standby	
End Presentation None Delete Recordings Folder Yes Delete Snapshots Folder No Power Off Mode New Presentation	\x09\xCBI\x03\x01\x00\x00
End Presentation None Delete Recordings Folder Yes Delete Snapshots Folder No Power Off Mode Screen Off	\x09\xCBI\x03\x01\x00\x02
End Presentation None Delete Recordings Folder Yes Delete Snapshots Folder No Power Off Mode Screensaver	\x09\xCBI\x03\x01\x00\x03
End Presentation None Delete Recordings Folder Yes Delete Snapshots Folder No Power Off Mode Standby	\x09\xCBI\x03\x01\x00\x01
End Presentation None Delete Recordings Folder Yes Delete Snapshots Folder Yes Power Off Mode New Presentation	\x09\xCBI\x03\x01\x01\x00
End Presentation None Delete Recordings Folder Yes Delete Snapshots Folder Yes Power Off Mode Screen Off	\x09\xCBI\x03\x01\x01\x02
End Presentation None Delete Recordings Folder Yes Delete Snapshots Folder Yes Power Off Mode Screensaver	\x09\xCBI\x03\x01\x01\x03
End Presentation None Delete Recordings Folder Yes Delete Snapshots Folder Yes	\x09\xCBI\x03\x01\x01\x01

Global Scripter Module Communication Sheet

Power Off Mode Standby	
File List Update None	\x0C\xCB>\x00\x06String
Login Command Admin	\x09\xCBB\x08\x02\x06String
Login Command User	\x09\xCBB\x08\x01\x06String
Master Mute Off	\x09\xCBX\x01\x00
Master Mute On	\x09\xCBX\x01\x01
Master Mute Toggle	\x09\xCBX\x01\x02
Master Volume 0	\x09\xCBV\x01\x00
Master Volume 100	\x09\xCBV\x01d
Open File Command None	\x0D\xCB<\x00\x06String
Power Off None	\x09\xCB\x0C\x01\x00
Streaming Mode Off	\x09\xCB \x01\x00
Streaming Mode On	\x09\xCB \x01\x01
Video Recording Pause/Resume	\x09\xCB%\x01\x01
Video Recording Start	\x09\xCB%\x01\x00
Video Recording Stop	\x09\xCB%\x01\x02
Visualizer Control Auto Focus Off Window 1	\x09\xCB)\x02\x00\x05
Visualizer Control Auto Focus Off Window 4	\x09\xCB)\x02\x03\x05
Visualizer Control Auto Focus On Window 1	\x09\xCB)\x02\x00\x04
Visualizer Control Auto Focus On Window 4	\x09\xCB)\x02\x03\x04
Visualizer Control Auto Focus Toggle Window 1	\x09\xCB)\x02\x00\x0A
Visualizer Control Auto Focus Toggle Window 4	\x09\xCB)\x02\x03\x0A
Visualizer Control Capture Area Shift Off Window 1	\x09\xCB)\x02\x00\x13
Visualizer Control Capture Area Shift Off Window 4	\x09\xCB)\x02\x03\x13
Visualizer Control Capture Area Shift On Window 1	\x09\xCB)\x02\x00\x12
Visualizer Control Capture Area Shift On Window 4	\x09\xCB)\x02\x03\x12
Visualizer Control Capture Area Shift Toggle Window 1	\x09\xCB)\x02\x00\x14

Global Scriptor Module Communication Sheet

Visualizer Control Capture Area Shift Toggle Window 4	\x09\xCB)\x02\x03\x14
Visualizer Control Freeze Off Window 1	\x09\xCB)\x02\x00\x07
Visualizer Control Freeze Off Window 4	\x09\xCB)\x02\x03\x07
Visualizer Control Freeze On Window 1	\x09\xCB)\x02\x00\x06
Visualizer Control Freeze On Window 4	\x09\xCB)\x02\x03\x06
Visualizer Control Freeze Toggle Window 1	\x09\xCB)\x02\x00\x0B
Visualizer Control Freeze Toggle Window 4	\x09\xCB)\x02\x03\x0B
Visualizer Control Light Off Window 1	\x09\xCB)\x02\x00\x10
Visualizer Control Light Off Window 4	\x09\xCB)\x02\x03\x10
Visualizer Control Light On Window 1	\x09\xCB)\x02\x00\x0F
Visualizer Control Light On Window 4	\x09\xCB)\x02\x03\x0F
Visualizer Control Light Toggle Window 1	\x09\xCB)\x02\x00\x11
Visualizer Control Light Toggle Window 4	\x09\xCB)\x02\x03\x11
Visualizer Control One- Push Auto Focus Window 1	\x09\xCB)\x02\x00\x15
Visualizer Control One- Push Auto Focus Window 4	\x09\xCB)\x02\x03\x15
Visualizer Control Power Off Window 1	\x09\xCB)\x02\x00\x0D
Visualizer Control Power Off Window 4	\x09\xCB)\x02\x03\x0D
Visualizer Control Power On Window 1	\x09\xCB)\x02\x00\x0C
Visualizer Control Power On Window 4	\x09\xCB)\x02\x03\x0C
Visualizer Control Power Toggle Window 1	\x09\xCB)\x02\x00\x0E
Visualizer Control Power Toggle Window 4	\x09\xCB)\x02\x03\x0E
Visualizer Control Preset Recall Window 1	\x09\xCB)\x02\x00\x09

Global Scriptor Module Communication Sheet

Visualizer Control Preset Recall Window 4	\x09\xCB)\x02\x03\x09
Visualizer Control Preset Save Window 1	\x09\xCB)\x02\x00\x08
Visualizer Control Preset Save Window 4	\x09\xCB)\x02\x03\x08
Window Control Close None Window 1	\x09\xCB(\x02\x00\x00
Window Control Close None Window 4	\x09\xCB(\x02\x03\x00
Window Control Fullscreen Off Window 1	\x09\xCB(\x02\x00\x02
Window Control Fullscreen Off Window 4	\x09\xCB(\x02\x03\x02
Window Control Fullscreen On Window 1	\x09\xCB(\x02\x00\x01
Window Control Fullscreen On Window 4	\x09\xCB(\x02\x03\x01
Window Start HDMI 1 Window 1	\x0D\xCB,\x00\x05\x00\x02\x00\x01\x00
Window Start HDMI 1 Window 4	\x0D\xCB,\x00\x05\x03\x02\x00\x01\x00
Window Start HDMI 1 Window Auto Arrange	\x0D\xCB,\x00\x05\xFF\x02\x00\x01\x00
Window Start HDMI 2 Window 1	\x0D\xCB,\x00\x05\x00\x02\x00\x01\x01
Window Start HDMI 2 Window 4	\x0D\xCB,\x00\x05\x03\x02\x00\x01\x01
Window Start HDMI 2 Window Auto Arrange	\x0D\xCB,\x00\x05\xFF\x02\x00\x01\x01
Window Start Stream Input 1 Window 1	\x0D\xCB,\x00\x05\x00\x11\x00\x01\x00
Window Start Stream Input 1 Window 4	\x0D\xCB,\x00\x05\x03\x11\x00\x01\x00
Window Start Stream Input 1 Window Auto Arrange	\x0D\xCB,\x00\x05\xFF\x11\x00\x01\x00
Window Start Stream Input 10 Window 1	\x0D\xCB,\x00\x05\x00\x11\x00\x01\x09
Window Start Stream Input 10 Window 4	\x0D\xCB,\x00\x05\x03\x11\x00\x01\x09
Window Start Stream Input 10 Window Auto Arrange	\x0D\xCB,\x00\x05\xFF\x11\x00\x01\x09
Window Start Stream Input 11 Window 1	\x0D\xCB,\x00\x05\x00\x11\x00\x01\x0A
Window Start Stream	\x0D\xCB,\x00\x05\x03\x11\x00\x01\x0A

Global Scripter Module Communication Sheet

Input 11 Window 4	
Window Start Stream Input 11 Window Auto Arrange	\x0D\xCB, \x00\x05\xff\x11\x00\x01\x0A
Window Start Stream Input 12 Window 1	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x0B
Window Start Stream Input 12 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x0B
Window Start Stream Input 12 Window Auto Arrange	\x0D\xCB, \x00\x05\xff\x11\x00\x01\x0B
Window Start Stream Input 13 Window 1	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x0C
Window Start Stream Input 13 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x0C
Window Start Stream Input 13 Window Auto Arrange	\x0D\xCB, \x00\x05\xff\x11\x00\x01\x0C
Window Start Stream Input 14 Window 1	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x0D
Window Start Stream Input 14 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x0D
Window Start Stream Input 14 Window Auto Arrange	\x0D\xCB, \x00\x05\xff\x11\x00\x01\x0D
Window Start Stream Input 15 Window 1	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x0E
Window Start Stream Input 15 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x0E
Window Start Stream Input 15 Window Auto Arrange	\x0D\xCB, \x00\x05\xff\x11\x00\x01\x0E
Window Start Stream Input 16 Window 1	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x0F
Window Start Stream Input 16 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x0F
Window Start Stream Input 16 Window Auto Arrange	\x0D\xCB, \x00\x05\xff\x11\x00\x01\x0F
Window Start Stream Input 17 Window 1	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x10
Window Start Stream Input 17 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x10
Window Start Stream Input 17 Window Auto Arrange	\x0D\xCB, \x00\x05\xff\x11\x00\x01\x10
Window Start Stream	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x11

Global Scripter Module Communication Sheet

Input 18 Window 1	
Window Start Stream Input 18 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x11
Window Start Stream Input 18 Window Auto Arrange	\x0D\xCB, \x00\x05\xFF\x11\x00\x01\x11
Window Start Stream Input 19 Window 1	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x12
Window Start Stream Input 19 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x12
Window Start Stream Input 19 Window Auto Arrange	\x0D\xCB, \x00\x05\xFF\x11\x00\x01\x12
Window Start Stream Input 2 Window 1	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x01
Window Start Stream Input 2 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x01
Window Start Stream Input 2 Window Auto Arrange	\x0D\xCB, \x00\x05\xFF\x11\x00\x01\x01
Window Start Stream Input 20 Window 1	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x13
Window Start Stream Input 20 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x13
Window Start Stream Input 20 Window Auto Arrange	\x0D\xCB, \x00\x05\xFF\x11\x00\x01\x13
Window Start Stream Input 3 Window 1	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x02
Window Start Stream Input 3 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x02
Window Start Stream Input 3 Window Auto Arrange	\x0D\xCB, \x00\x05\xFF\x11\x00\x01\x02
Window Start Stream Input 4 Window 1	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x03
Window Start Stream Input 4 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x03
Window Start Stream Input 4 Window Auto Arrange	\x0D\xCB, \x00\x05\xFF\x11\x00\x01\x03
Window Start Stream Input 5 Window 1	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x04
Window Start Stream Input 5 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x04
Window Start Stream Input 5 Window Auto	\x0D\xCB, \x00\x05\xFF\x11\x00\x01\x04

Global Scriptor Module Communication Sheet

Arrange	
Window Start Stream Input 6 Window 1	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x05
Window Start Stream Input 6 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x05
Window Start Stream Input 6 Window Auto Arrange	\x0D\xCB, \x00\x05\xFF\x11\x00\x01\x05
Window Start Stream Input 7 Window 1	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x06
Window Start Stream Input 7 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x06
Window Start Stream Input 7 Window Auto Arrange	\x0D\xCB, \x00\x05\xFF\x11\x00\x01\x06
Window Start Stream Input 8 Window 1	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x07
Window Start Stream Input 8 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x07
Window Start Stream Input 8 Window Auto Arrange	\x0D\xCB, \x00\x05\xFF\x11\x00\x01\x07
Window Start Stream Input 9 Window 1	\x0D\xCB, \x00\x05\x00\x11\x00\x01\x08
Window Start Stream Input 9 Window 4	\x0D\xCB, \x00\x05\x03\x11\x00\x01\x08
Window Start Stream Input 9 Window Auto Arrange	\x0D\xCB, \x00\x05\xFF\x11\x00\x01\x08
Window Start Webcam 1 Window 1	\x0D\xCB, \x00\x05\x00\x10\x00\x01\x00
Window Start Webcam 1 Window 4	\x0D\xCB, \x00\x05\x03\x10\x00\x01\x00
Window Start Webcam 1 Window Auto Arrange	\x0D\xCB, \x00\x05\xFF\x10\x00\x01\x00
Window Start Webcam 2 Window 1	\x0D\xCB, \x00\x05\x00\x10\x00\x01\x01
Window Start Webcam 2 Window 4	\x0D\xCB, \x00\x05\x03\x10\x00\x01\x01
Window Start Webcam 2 Window Auto Arrange	\x0D\xCB, \x00\x05\xFF\x10\x00\x01\x01
Zoom Meeting Start None Window 1 Type Host	\x0D\xCB, \x004\x00\x1D\x000?type=host&id=String&name=String&password=String
Zoom Meeting Start None Window 1 Type Join	\x0D\xCB, \x004\x00\x1D\x000?type=join&id=String&name=String&password=String

Global Scripter Module Communication Sheet

Zoom Meeting Start None Window 4 Type Host	\x0D\xCB,\x004\x03\x1D\x000?type=host&id=String&name=String&password=String
Zoom Meeting Start None Window 4 Type Join	\x0D\xCB,\x004\x03\x1D\x000?type=join&id=String&name=String&password=String
Zoom Meeting Start None Window Auto Arrange Type Host	\x0D\xCB,\x004\xFF\x1D\x000?type=host&id=String&name=String&password=String
Zoom Meeting Start None Window Auto Arrange Type Join	\x0D\xCB,\x004\xFF\x1D\x000?type=join&id=String&name=String&password=String
Zoom Webconference Control End Local Meeting Window 1	\x09\xCD\x04\x02\x00\x04
Zoom Webconference Control End Local Meeting Window 4	\x09\xCD\x04\x02\x03\x04
Zoom Webconference Control Leave Meeting Window 1	\x09\xCD\x04\x02\x00\x01
Zoom Webconference Control Leave Meeting Window 4	\x09\xCD\x04\x02\x03\x01
Zoom Webconference Control Toggle Audio Mute for All Participants (Local Meeting Only) Window 1	\x09\xCD\x04\x02\x00\x05
Zoom Webconference Control Toggle Audio Mute for All Participants (Local Meeting Only) Window 4	\x09\xCD\x04\x02\x03\x05
Zoom Webconference Control Toggle Audio Mute Window 1	\x09\xCD\x04\x02\x00\x00
Zoom Webconference Control Toggle Audio Mute Window 4	\x09\xCD\x04\x02\x03\x00
Zoom Webconference Control Toggle Screenshare Window 1	\x09\xCD\x04\x02\x00\x02
Zoom Webconference Control Toggle Screenshare Window 4	\x09\xCD\x04\x02\x03\x02
Zoom Webconference Control Toggle Show	\x09\xCD\x04\x02\x00\x06

Global Scriptor Module Communication Sheet

Participants Window 1	
Zoom Webconference Control Toggle Show Participants Window 4	\x09\xCD\x04\x02\x03\x06
Zoom Webconference Control Toggle Video Mute Window 1	\x09\xCD\x04\x02\x00\x03
Zoom Webconference Control Toggle Video Mute Window 4	\x09\xCD\x04\x02\x03\x03

Appendix B. Update Commands

BYOD Pin Display	\x08\xCB\xE4\x00
Streaming Mode	\x08\xCB \x00