

## DS User's Guide

Generated by Doxygen 1.8.13

## Contents

<b>1 CFS Data Storage (DS) Documentation</b>	<b>2</b>
1.1 CFS Data Storage Introduction . . . . .	2
1.2 CFS Data Storage Overview . . . . .	3
1.3 CFS Data Storage Operation . . . . .	4
1.4 CFS Data Storage Commands . . . . .	5
1.5 CFS Data Storage Telemetry . . . . .	5
1.6 CFS Data Storage Events . . . . .	5
1.7 CFS Data Storage Deployment Guide . . . . .	6
1.8 CFS Data Storage Configuration . . . . .	6
1.9 CFS Data Storage Table Definitions . . . . .	6
1.10 CFS Data Storage Operational Constraints . . . . .	6
1.11 CFS Data Storage Frequently Asked Questions . . . . .	7
<b>2 Core Flight Executive Documentation</b>	<b>7</b>
2.1 Background . . . . .	8
2.2 Applicable Documents . . . . .	9
2.3 Version Numbers . . . . .	10
2.4 Dependencies . . . . .	11
2.5 Acronyms . . . . .	11
2.6 cFE Executive Services Overview . . . . .	13
2.6.1 Terminology . . . . .	14
2.6.2 Software Reset . . . . .	16
2.6.3 Reset Types and Subtypes . . . . .	16
2.6.4 Exception and Reset (ER) Log . . . . .	17
2.6.5 Application and Child Task Management . . . . .	17
2.6.6 Starting an Application . . . . .	17
2.6.7 Stopping an Application . . . . .	18

2.6.8	Restarting an Application . . . . .	18
2.6.9	Reloading an Application . . . . .	18
2.6.10	Listing Current Applications . . . . .	19
2.6.11	Listing Current Tasks . . . . .	20
2.6.12	Loading Common Libraries . . . . .	20
2.6.13	Basic File System . . . . .	20
2.6.14	Performance Data Collection . . . . .	21
2.6.15	Critical Data Store . . . . .	22
2.6.16	Memory Pool . . . . .	23
2.6.17	System Log . . . . .	25
2.6.18	Version Identification . . . . .	25
2.6.19	Executive Services Frequently Asked Questions . . . . .	26
2.7	cFE Executive Services Commands . . . . .	26
2.8	cFE Executive Services Telemetry . . . . .	27
2.9	cFE Executive Services Configuration Parameters . . . . .	28
2.10	cFE Event Services Overview . . . . .	31
2.10.1	Event Message Format . . . . .	32
2.10.2	Local Event Log . . . . .	33
2.10.3	Event Message Control . . . . .	33
2.10.4	Event Message Filtering . . . . .	35
2.10.5	EVS Registry . . . . .	35
2.10.6	EVS Counters . . . . .	36
2.10.7	Resetting EVS Counters . . . . .	37
2.10.8	Effects of a Processor Reset on EVS . . . . .	37
2.10.9	EVS squelching of misbehaving apps . . . . .	38
2.10.10	Frequently Asked Questions about Event Services . . . . .	38
2.11	cFE Event Services Commands . . . . .	39
2.12	cFE Event Services Telemetry . . . . .	41

2.13 cFE Event Services Configuration Parameters . . . . .	41
2.14 cFE Software Bus Overview . . . . .	42
2.14.1 Software Bus Terminology . . . . .	42
2.14.2 Autonomous Actions . . . . .	45
2.14.3 Operation of the SB Software . . . . .	45
2.14.4 Frequently Asked Questions about Software Bus . . . . .	49
2.15 cFE Software Bus Commands . . . . .	51
2.16 cFE Software Bus Telemetry . . . . .	52
2.17 cFE Software Bus Configuration Parameters . . . . .	52
2.18 cFE Table Services Overview . . . . .	53
2.18.1 Managing Tables . . . . .	54
2.18.2 cFE Table Types and Table Options . . . . .	55
2.18.3 Table Registry . . . . .	57
2.18.4 Table Services Telemetry . . . . .	58
2.18.5 Effects of Processor Reset on Tables . . . . .	58
2.18.6 Frequently Asked Questions about Table Services . . . . .	58
2.19 cFE Table Services Commands . . . . .	60
2.20 cFE Table Services Telemetry . . . . .	61
2.21 cFE Table Services Configuration Parameters . . . . .	61
2.22 cFE Time Services Overview . . . . .	62
2.22.1 Time Components . . . . .	64
2.22.2 Time Structure . . . . .	65
2.22.3 Time Formats . . . . .	65
2.22.4 Time Configuration . . . . .	66
2.22.5 Time Format Selection . . . . .	71
2.22.6 Enabling Fake Tone Signal . . . . .	72
2.22.7 Selecting Tone and Data Ordering . . . . .	72
2.22.8 Specifying Tone and Data Window . . . . .	73

2.22.9 Specifying Time Server/Client . . . . .	73
2.22.10 Specifying Time Tone Byte Order . . . . .	74
2.22.11 Virtual MET . . . . .	74
2.22.12 Specifying Time Source . . . . .	74
2.22.13 Specifying Time Signal . . . . .	75
2.22.14 Time Services Paradigm(s) . . . . .	76
2.22.15 Flywheeling . . . . .	76
2.22.16 Time State . . . . .	77
2.22.17 Initialization . . . . .	77
2.22.18 Power-On Reset . . . . .	78
2.22.19 Processor Reset . . . . .	79
2.22.20 Initialization . . . . .	79
2.22.21 Power-On Reset . . . . .	80
2.22.22 Processor Reset . . . . .	81
2.22.23 Normal Operation . . . . .	81
2.22.24 Client . . . . .	83
2.22.25 Server . . . . .	84
2.22.26 Setting Time . . . . .	85
2.22.27 Adjusting Time . . . . .	86
2.22.28 Setting MET . . . . .	86
2.22.29 Frequently Asked Questions . . . . .	86
2.23 cFE Time Services Commands . . . . .	87
2.24 cFE Time Services Telemetry . . . . .	88
2.25 cFE Time Services Configuration Parameters . . . . .	88
2.26 cFE Event Message Cross Reference . . . . .	89
2.27 cFE Command Mnemonic Cross Reference . . . . .	89
2.28 cFE Telemetry Mnemonic Cross Reference . . . . .	93

<b>3 Glossary of Terms</b>	<b>104</b>
<b>4 cFE Application Programmer's Interface (API) Reference</b>	<b>105</b>
<b>5 Osal API Documentation</b>	<b>112</b>
5.1 OSAL Introduction . . . . .	114
5.2 File System Overview . . . . .	114
5.3 File Descriptors In Osal . . . . .	115
5.4 Timer Overview . . . . .	116
<b>6 cFE Mission Configuration Parameters</b>	<b>116</b>
<b>7 Module Index</b>	<b>116</b>
7.1 Modules . . . . .	116
<b>8 Data Structure Index</b>	<b>119</b>
8.1 Data Structures . . . . .	119
<b>9 File Index</b>	<b>128</b>
9.1 File List . . . . .	129
<b>10 Module Documentation</b>	<b>132</b>
10.1 CFS Data Storage Mission Configuration . . . . .	132
10.1.1 Detailed Description . . . . .	132
10.1.2 Macro Definition Documentation . . . . .	132
10.2 CFS Data Storage Message IDs . . . . .	133
10.2.1 Detailed Description . . . . .	133
10.2.2 Macro Definition Documentation . . . . .	133
10.3 CFS Data Storage Message IDs . . . . .	134
10.3.1 Detailed Description . . . . .	134
10.3.2 Macro Definition Documentation . . . . .	134
10.4 CFS Data Storage Platform Configuration . . . . .	135

10.4.1 Detailed Description . . . . .	136
10.4.2 Macro Definition Documentation . . . . .	136
10.5 CFS Data Store Event IDs . . . . .	148
10.5.1 Detailed Description . . . . .	150
10.5.2 Macro Definition Documentation . . . . .	150
10.6 CFS Data Storage Command Structures . . . . .	178
10.6.1 Detailed Description . . . . .	178
10.7 CFS Data Storage Telemetry . . . . .	179
10.7.1 Detailed Description . . . . .	179
10.8 CFS Data Storage Command Codes . . . . .	180
10.8.1 Detailed Description . . . . .	180
10.8.2 Macro Definition Documentation . . . . .	180
10.9 CFS Data Storage Version . . . . .	199
10.9.1 Detailed Description . . . . .	199
10.9.2 Macro Definition Documentation . . . . .	199
10.10cFE Return Code Defines . . . . .	200
10.10.1 Detailed Description . . . . .	205
10.10.2 Macro Definition Documentation . . . . .	205
10.11cFE Resource ID APIs . . . . .	237
10.11.1 Detailed Description . . . . .	237
10.11.2 Function Documentation . . . . .	237
10.12cFE Entry/Exit APIs . . . . .	241
10.12.1 Detailed Description . . . . .	241
10.12.2 Function Documentation . . . . .	241
10.13cFE Application Control APIs . . . . .	243
10.13.1 Detailed Description . . . . .	243
10.13.2 Function Documentation . . . . .	243
10.14cFE Application Behavior APIs . . . . .	246

10.14.1 Detailed Description . . . . .	246
10.14.2 Function Documentation . . . . .	246
10.15cFE Information APIs . . . . .	251
10.15.1 Detailed Description . . . . .	251
10.15.2 Function Documentation . . . . .	251
10.16cFE Child Task APIs . . . . .	261
10.16.1 Detailed Description . . . . .	261
10.16.2 Function Documentation . . . . .	261
10.17cFE Miscellaneous APIs . . . . .	266
10.17.1 Detailed Description . . . . .	266
10.17.2 Function Documentation . . . . .	266
10.18cFE Critical Data Store APIs . . . . .	270
10.18.1 Detailed Description . . . . .	270
10.18.2 Function Documentation . . . . .	270
10.19cFE Memory Manager APIs . . . . .	276
10.19.1 Detailed Description . . . . .	276
10.19.2 Function Documentation . . . . .	276
10.20cFE Performance Monitor APIs . . . . .	284
10.20.1 Detailed Description . . . . .	284
10.20.2 Macro Definition Documentation . . . . .	284
10.20.3 Function Documentation . . . . .	285
10.21cFE Generic Counter APIs . . . . .	287
10.21.1 Detailed Description . . . . .	287
10.21.2 Function Documentation . . . . .	287
10.22cFE Registration APIs . . . . .	295
10.22.1 Detailed Description . . . . .	295
10.22.2 Function Documentation . . . . .	295
10.23cFE Send Event APIs . . . . .	297

10.23.1 Detailed Description . . . . .	297
10.23.2 Function Documentation . . . . .	297
10.24cFE Reset Event Filter APIs . . . . .	302
10.24.1 Detailed Description . . . . .	302
10.24.2 Function Documentation . . . . .	302
10.25cFE File Header Management APIs . . . . .	304
10.25.1 Detailed Description . . . . .	304
10.25.2 Function Documentation . . . . .	304
10.26cFE File Utility APIs . . . . .	309
10.26.1 Detailed Description . . . . .	309
10.26.2 Function Documentation . . . . .	309
10.27cFE Generic Message APIs . . . . .	315
10.27.1 Detailed Description . . . . .	315
10.27.2 Function Documentation . . . . .	315
10.28cFE Message Primary Header APIs . . . . .	316
10.28.1 Detailed Description . . . . .	316
10.28.2 Function Documentation . . . . .	316
10.29cFE Message Extended Header APIs . . . . .	327
10.29.1 Detailed Description . . . . .	327
10.29.2 Function Documentation . . . . .	327
10.30cFE Message Secondary Header APIs . . . . .	334
10.30.1 Detailed Description . . . . .	334
10.30.2 Function Documentation . . . . .	334
10.31cFE Message Id APIs . . . . .	339
10.31.1 Detailed Description . . . . .	339
10.31.2 Function Documentation . . . . .	339
10.32cFE Pipe Management APIs . . . . .	342
10.32.1 Detailed Description . . . . .	342

10.32.2 Function Documentation . . . . .	342
10.33cFE Message Subscription Control APIs . . . . .	349
10.33.1 Detailed Description . . . . .	349
10.33.2 Function Documentation . . . . .	349
10.34cFE Send/Receive Message APIs . . . . .	355
10.34.1 Detailed Description . . . . .	355
10.34.2 Function Documentation . . . . .	355
10.35cFE Zero Copy APIs . . . . .	358
10.35.1 Detailed Description . . . . .	358
10.35.2 Function Documentation . . . . .	358
10.36cFE Message Characteristics APIs . . . . .	361
10.36.1 Detailed Description . . . . .	361
10.36.2 Function Documentation . . . . .	361
10.37cFE Message ID APIs . . . . .	366
10.37.1 Detailed Description . . . . .	366
10.37.2 Function Documentation . . . . .	366
10.38cFE SB Pipe options . . . . .	369
10.38.1 Detailed Description . . . . .	369
10.38.2 Macro Definition Documentation . . . . .	369
10.39cFE Registration APIs . . . . .	370
10.39.1 Detailed Description . . . . .	370
10.39.2 Function Documentation . . . . .	370
10.40cFE Manage Table Content APIs . . . . .	376
10.40.1 Detailed Description . . . . .	376
10.40.2 Function Documentation . . . . .	376
10.41cFE Access Table Content APIs . . . . .	383
10.41.1 Detailed Description . . . . .	383
10.41.2 Function Documentation . . . . .	383

10.42cFE Get Table Information APIs . . . . .	388
10.42.1 Detailed Description . . . . .	388
10.42.2 Function Documentation . . . . .	388
10.43cFE Table Type Defines . . . . .	392
10.43.1 Detailed Description . . . . .	392
10.43.2 Macro Definition Documentation . . . . .	392
10.44cFE Get Current Time APIs . . . . .	396
10.44.1 Detailed Description . . . . .	396
10.44.2 Function Documentation . . . . .	396
10.45cFE Get Time Information APIs . . . . .	400
10.45.1 Detailed Description . . . . .	400
10.45.2 Function Documentation . . . . .	400
10.46cFE Time Arithmetic APIs . . . . .	403
10.46.1 Detailed Description . . . . .	403
10.46.2 Function Documentation . . . . .	403
10.47cFE Time Conversion APIs . . . . .	406
10.47.1 Detailed Description . . . . .	406
10.47.2 Function Documentation . . . . .	406
10.48cFE External Time Source APIs . . . . .	409
10.48.1 Detailed Description . . . . .	409
10.48.2 Function Documentation . . . . .	409
10.49cFE Miscellaneous Time APIs . . . . .	414
10.49.1 Detailed Description . . . . .	414
10.49.2 Function Documentation . . . . .	414
10.50cFE Resource ID base values . . . . .	416
10.50.1 Detailed Description . . . . .	416
10.50.2 Enumeration Type Documentation . . . . .	416
10.51cFE Clock State Flag Defines . . . . .	418

10.51.1 Detailed Description . . . . .	418
10.51.2 Macro Definition Documentation . . . . .	418
10.52OSAL Semaphore State Defines . . . . .	421
10.52.1 Detailed Description . . . . .	421
10.52.2 Macro Definition Documentation . . . . .	421
10.53OSAL Binary Semaphore APIs . . . . .	422
10.53.1 Detailed Description . . . . .	422
10.53.2 Function Documentation . . . . .	422
10.54OSAL BSP low level access APIs . . . . .	428
10.54.1 Detailed Description . . . . .	428
10.54.2 Function Documentation . . . . .	428
10.55OSAL Real Time Clock APIs . . . . .	429
10.55.1 Detailed Description . . . . .	429
10.55.2 Function Documentation . . . . .	429
10.56OSAL Core Operation APIs . . . . .	441
10.56.1 Detailed Description . . . . .	441
10.56.2 Function Documentation . . . . .	441
10.57OSAL Counting Semaphore APIs . . . . .	445
10.57.1 Detailed Description . . . . .	445
10.57.2 Function Documentation . . . . .	445
10.58OSAL Directory APIs . . . . .	451
10.58.1 Detailed Description . . . . .	451
10.58.2 Function Documentation . . . . .	451
10.59OSAL Return Code Defines . . . . .	456
10.59.1 Detailed Description . . . . .	457
10.59.2 Macro Definition Documentation . . . . .	458
10.60OSAL Error Info APIs . . . . .	467
10.60.1 Detailed Description . . . . .	467

10.60.2 Function Documentation . . . . .	467
10.61OSAL File Access Option Defines . . . . .	470
10.61.1 Detailed Description . . . . .	470
10.61.2 Macro Definition Documentation . . . . .	470
10.62OSAL Reference Point For Seek Offset Defines . . . . .	471
10.62.1 Detailed Description . . . . .	471
10.62.2 Macro Definition Documentation . . . . .	471
10.63OSAL Standard File APIs . . . . .	472
10.63.1 Detailed Description . . . . .	472
10.63.2 Function Documentation . . . . .	472
10.64OSAL File System Level APIs . . . . .	485
10.64.1 Detailed Description . . . . .	485
10.64.2 Function Documentation . . . . .	485
10.65OSAL Heap APIs . . . . .	494
10.65.1 Detailed Description . . . . .	494
10.65.2 Function Documentation . . . . .	494
10.66OSAL Object Type Defines . . . . .	495
10.66.1 Detailed Description . . . . .	495
10.66.2 Macro Definition Documentation . . . . .	495
10.67OSAL Object ID Utility APIs . . . . .	499
10.67.1 Detailed Description . . . . .	499
10.67.2 Function Documentation . . . . .	499
10.68OSAL Dynamic Loader and Symbol APIs . . . . .	506
10.68.1 Detailed Description . . . . .	506
10.68.2 Function Documentation . . . . .	506
10.69OSAL Mutex APIs . . . . .	511
10.69.1 Detailed Description . . . . .	511
10.69.2 Function Documentation . . . . .	511

10.70OSAL Network ID APIs . . . . .	516
10.70.1 Detailed Description . . . . .	516
10.70.2 Function Documentation . . . . .	516
10.71OSAL Printf APIs . . . . .	518
10.71.1 Detailed Description . . . . .	518
10.71.2 Function Documentation . . . . .	518
10.72OSAL Message Queue APIs . . . . .	520
10.72.1 Detailed Description . . . . .	520
10.72.2 Function Documentation . . . . .	520
10.73OSAL Select APIs . . . . .	525
10.73.1 Detailed Description . . . . .	525
10.73.2 Function Documentation . . . . .	525
10.74OSAL Shell APIs . . . . .	530
10.74.1 Detailed Description . . . . .	530
10.74.2 Function Documentation . . . . .	530
10.75OSAL Socket Address APIs . . . . .	531
10.75.1 Detailed Description . . . . .	531
10.75.2 Function Documentation . . . . .	531
10.76OSAL Socket Management APIs . . . . .	535
10.76.1 Detailed Description . . . . .	535
10.76.2 Function Documentation . . . . .	535
10.77OSAL Task APIs . . . . .	543
10.77.1 Detailed Description . . . . .	543
10.77.2 Function Documentation . . . . .	543
10.78OSAL Time Base APIs . . . . .	550
10.78.1 Detailed Description . . . . .	550
10.78.2 Function Documentation . . . . .	550
10.79OSAL Timer APIs . . . . .	556
10.79.1 Detailed Description . . . . .	556
10.79.2 Function Documentation . . . . .	556

<b>11 Data Structure Documentation</b>	<b>563</b>
11.1 CCSDS_ExtendedHeader Struct Reference . . . . .	563
11.1.1 Detailed Description . . . . .	563
11.1.2 Field Documentation . . . . .	563
11.2 CCSDS_PrimaryHeader Struct Reference . . . . .	564
11.2.1 Detailed Description . . . . .	564
11.2.2 Field Documentation . . . . .	564
11.3 CFE_ES_AppInfo Struct Reference . . . . .	565
11.3.1 Detailed Description . . . . .	566
11.3.2 Field Documentation . . . . .	566
11.4 CFE_ES_AppNameCmd Struct Reference . . . . .	571
11.4.1 Detailed Description . . . . .	572
11.4.2 Field Documentation . . . . .	572
11.5 CFE_ES_AppNameCmd_Payload Struct Reference . . . . .	572
11.5.1 Detailed Description . . . . .	573
11.5.2 Field Documentation . . . . .	573
11.6 CFE_ES_AppReloadCmd_Payload Struct Reference . . . . .	573
11.6.1 Detailed Description . . . . .	574
11.6.2 Field Documentation . . . . .	574
11.7 CFE_ES_BlockStats Struct Reference . . . . .	574
11.7.1 Detailed Description . . . . .	575
11.7.2 Field Documentation . . . . .	575
11.8 CFE_ES_CDSRegDumpRec Struct Reference . . . . .	575
11.8.1 Detailed Description . . . . .	576
11.8.2 Field Documentation . . . . .	576
11.9 CFE_ES_DeleteCDSCmd Struct Reference . . . . .	577
11.9.1 Detailed Description . . . . .	578
11.9.2 Field Documentation . . . . .	578

11.10CFE_ES_DeleteCDSCmd_Payload Struct Reference . . . . .	578
11.10.1 Detailed Description . . . . .	579
11.10.2 Field Documentation . . . . .	579
11.11CFE_ES_DumpCDSRegistryCmd Struct Reference . . . . .	579
11.11.1 Detailed Description . . . . .	579
11.11.2 Field Documentation . . . . .	580
11.12CFE_ES_DumpCDSRegistryCmd_Payload Struct Reference . . . . .	580
11.12.1 Detailed Description . . . . .	580
11.12.2 Field Documentation . . . . .	581
11.13CFE_ES_FileNameCmd Struct Reference . . . . .	581
11.13.1 Detailed Description . . . . .	581
11.13.2 Field Documentation . . . . .	581
11.14CFE_ES_FileNameCmd_Payload Struct Reference . . . . .	582
11.14.1 Detailed Description . . . . .	582
11.14.2 Field Documentation . . . . .	582
11.15CFE_ES_HousekeepingTlm Struct Reference . . . . .	583
11.15.1 Detailed Description . . . . .	583
11.15.2 Field Documentation . . . . .	583
11.16CFE_ES_HousekeepingTlm_Payload Struct Reference . . . . .	583
11.16.1 Detailed Description . . . . .	585
11.16.2 Field Documentation . . . . .	586
11.17CFE_ES_MemPoolStats Struct Reference . . . . .	596
11.17.1 Detailed Description . . . . .	597
11.17.2 Field Documentation . . . . .	597
11.18CFE_ES_MemStatsTlm Struct Reference . . . . .	598
11.18.1 Detailed Description . . . . .	599
11.18.2 Field Documentation . . . . .	599
11.19CFE_ES_NoArgsCmd Struct Reference . . . . .	599

11.19.1 Detailed Description . . . . .	600
11.19.2 Field Documentation . . . . .	600
11.20CFE_ES_OneAppTlm Struct Reference . . . . .	600
11.20.1 Detailed Description . . . . .	601
11.20.2 Field Documentation . . . . .	601
11.21CFE_ES_OneAppTlm_Payload Struct Reference . . . . .	601
11.21.1 Detailed Description . . . . .	601
11.21.2 Field Documentation . . . . .	602
11.22CFE_ES_OverWriteSysLogCmd Struct Reference . . . . .	602
11.22.1 Detailed Description . . . . .	602
11.22.2 Field Documentation . . . . .	602
11.23CFE_ES_OverWriteSysLogCmd_Payload Struct Reference . . . . .	603
11.23.1 Detailed Description . . . . .	603
11.23.2 Field Documentation . . . . .	603
11.24CFE_ES_PoolAlign Union Reference . . . . .	604
11.24.1 Detailed Description . . . . .	604
11.24.2 Field Documentation . . . . .	604
11.25CFE_ES_PoolStatsTlm_Payload Struct Reference . . . . .	605
11.25.1 Detailed Description . . . . .	605
11.25.2 Field Documentation . . . . .	605
11.26CFE_ES_ReloadAppCmd Struct Reference . . . . .	606
11.26.1 Detailed Description . . . . .	606
11.26.2 Field Documentation . . . . .	606
11.27CFE_ES_RestartCmd Struct Reference . . . . .	607
11.27.1 Detailed Description . . . . .	607
11.27.2 Field Documentation . . . . .	607
11.28CFE_ES_RestartCmd_Payload Struct Reference . . . . .	608
11.28.1 Detailed Description . . . . .	608

11.28.2 Field Documentation . . . . .	608
11.29 CFE_ES_SendMemPoolStatsCmd Struct Reference . . . . .	609
11.29.1 Detailed Description . . . . .	609
11.29.2 Field Documentation . . . . .	609
11.30 CFE_ES_SendMemPoolStatsCmd_Payload Struct Reference . . . . .	610
11.30.1 Detailed Description . . . . .	610
11.30.2 Field Documentation . . . . .	610
11.31 CFE_ES_SetMaxPRCountCmd Struct Reference . . . . .	611
11.31.1 Detailed Description . . . . .	611
11.31.2 Field Documentation . . . . .	611
11.32 CFE_ES_SetMaxPRCountCmd_Payload Struct Reference . . . . .	612
11.32.1 Detailed Description . . . . .	612
11.32.2 Field Documentation . . . . .	612
11.33 CFE_ES_SetPerfFilterMaskCmd Struct Reference . . . . .	612
11.33.1 Detailed Description . . . . .	613
11.33.2 Field Documentation . . . . .	613
11.34 CFE_ES_SetPerfFilterMaskCmd_Payload Struct Reference . . . . .	613
11.34.1 Detailed Description . . . . .	614
11.34.2 Field Documentation . . . . .	614
11.35 CFE_ES_SetPerfTriggerMaskCmd Struct Reference . . . . .	614
11.35.1 Detailed Description . . . . .	615
11.35.2 Field Documentation . . . . .	615
11.36 CFE_ES_SetPerfTrigMaskCmd_Payload Struct Reference . . . . .	615
11.36.1 Detailed Description . . . . .	616
11.36.2 Field Documentation . . . . .	616
11.37 CFE_ES_StartApp Struct Reference . . . . .	616
11.37.1 Detailed Description . . . . .	617
11.37.2 Field Documentation . . . . .	617

11.38CFE_ES_StartAppCmd_Payload Struct Reference . . . . .	617
11.38.1 Detailed Description . . . . .	618
11.38.2 Field Documentation . . . . .	618
11.39CFE_ES_StartPerfCmd_Payload Struct Reference . . . . .	619
11.39.1 Detailed Description . . . . .	620
11.39.2 Field Documentation . . . . .	620
11.40CFE_ES_StartPerfDataCmd Struct Reference . . . . .	620
11.40.1 Detailed Description . . . . .	621
11.40.2 Field Documentation . . . . .	621
11.41CFE_ES_StopPerfCmd_Payload Struct Reference . . . . .	621
11.41.1 Detailed Description . . . . .	622
11.41.2 Field Documentation . . . . .	622
11.42CFE_ES_StopPerfDataCmd Struct Reference . . . . .	622
11.42.1 Detailed Description . . . . .	622
11.42.2 Field Documentation . . . . .	623
11.43CFE_ES_TaskInfo Struct Reference . . . . .	623
11.43.1 Detailed Description . . . . .	624
11.43.2 Field Documentation . . . . .	624
11.44CFE_EVS_AppDataCmd_Payload Struct Reference . . . . .	626
11.44.1 Detailed Description . . . . .	626
11.44.2 Field Documentation . . . . .	626
11.45CFE_EVS_AppNameBitMaskCmd Struct Reference . . . . .	626
11.45.1 Detailed Description . . . . .	627
11.45.2 Field Documentation . . . . .	627
11.46CFE_EVS_AppNameBitMaskCmd_Payload Struct Reference . . . . .	627
11.46.1 Detailed Description . . . . .	628
11.46.2 Field Documentation . . . . .	628
11.47CFE_EVS_AppNameCmd Struct Reference . . . . .	629

11.47.1 Detailed Description . . . . .	629
11.47.2 Field Documentation . . . . .	629
11.48CFE_EVS_AppNameCmd_Payload Struct Reference . . . . .	630
11.48.1 Detailed Description . . . . .	630
11.48.2 Field Documentation . . . . .	630
11.49CFE_EVS_AppNameEventIDCmd Struct Reference . . . . .	631
11.49.1 Detailed Description . . . . .	631
11.49.2 Field Documentation . . . . .	631
11.50CFE_EVS_AppNameEventIDCmd_Payload Struct Reference . . . . .	632
11.50.1 Detailed Description . . . . .	632
11.50.2 Field Documentation . . . . .	632
11.51CFE_EVS_AppNameEventIDMaskCmd Struct Reference . . . . .	633
11.51.1 Detailed Description . . . . .	633
11.51.2 Field Documentation . . . . .	633
11.52CFE_EVS_AppNameEventIDMaskCmd_Payload Struct Reference . . . . .	634
11.52.1 Detailed Description . . . . .	634
11.52.2 Field Documentation . . . . .	634
11.53CFE_EVS_AppTlmData Struct Reference . . . . .	635
11.53.1 Detailed Description . . . . .	635
11.53.2 Field Documentation . . . . .	635
11.54CFE_EVS_BinFilter Struct Reference . . . . .	636
11.54.1 Detailed Description . . . . .	637
11.54.2 Field Documentation . . . . .	637
11.55CFE_EVS_BitMaskCmd Struct Reference . . . . .	637
11.55.1 Detailed Description . . . . .	638
11.55.2 Field Documentation . . . . .	638
11.56CFE_EVS_BitMaskCmd_Payload Struct Reference . . . . .	638
11.56.1 Detailed Description . . . . .	639

11.56.2 Field Documentation . . . . .	639
11.57CFE_EVS_HousekeepingTlm Struct Reference . . . . .	639
11.57.1 Detailed Description . . . . .	640
11.57.2 Field Documentation . . . . .	640
11.58CFE_EVS_HousekeepingTlm_Payload Struct Reference . . . . .	640
11.58.1 Detailed Description . . . . .	641
11.58.2 Field Documentation . . . . .	641
11.59CFE_EVS_LogFileCmd_Payload Struct Reference . . . . .	645
11.59.1 Detailed Description . . . . .	646
11.59.2 Field Documentation . . . . .	646
11.60CFE_EVS_LongEventTlm Struct Reference . . . . .	646
11.60.1 Detailed Description . . . . .	646
11.60.2 Field Documentation . . . . .	647
11.61CFE_EVS_LongEventTlm_Payload Struct Reference . . . . .	647
11.61.1 Detailed Description . . . . .	647
11.61.2 Field Documentation . . . . .	648
11.62CFE_EVS_NoArgsCmd Struct Reference . . . . .	649
11.62.1 Detailed Description . . . . .	649
11.62.2 Field Documentation . . . . .	649
11.63CFE_EVS_PacketID Struct Reference . . . . .	649
11.63.1 Detailed Description . . . . .	650
11.63.2 Field Documentation . . . . .	650
11.64CFE_EVS_SetEventFormatCode_Payload Struct Reference . . . . .	651
11.64.1 Detailed Description . . . . .	651
11.64.2 Field Documentation . . . . .	652
11.65CFE_EVS_SetEventFormatModeCmd Struct Reference . . . . .	652
11.65.1 Detailed Description . . . . .	652
11.65.2 Field Documentation . . . . .	653

11.66CFE_EVS_SetLogMode_Payload Struct Reference . . . . .	653
11.66.1 Detailed Description . . . . .	653
11.66.2 Field Documentation . . . . .	654
11.67CFE_EVS_SetLogModeCmd Struct Reference . . . . .	654
11.67.1 Detailed Description . . . . .	654
11.67.2 Field Documentation . . . . .	655
11.68CFE_EVS_ShortEventTlm Struct Reference . . . . .	655
11.68.1 Detailed Description . . . . .	655
11.68.2 Field Documentation . . . . .	655
11.69CFE_EVS_ShortEventTlm_Payload Struct Reference . . . . .	656
11.69.1 Detailed Description . . . . .	656
11.69.2 Field Documentation . . . . .	656
11.70CFE_EVS_WriteAppDataFileCmd Struct Reference . . . . .	657
11.70.1 Detailed Description . . . . .	657
11.70.2 Field Documentation . . . . .	657
11.71CFE_EVS_WriteLogFileCmd Struct Reference . . . . .	658
11.71.1 Detailed Description . . . . .	658
11.71.2 Field Documentation . . . . .	658
11.72CFE_FS_FileWriteMetaData Struct Reference . . . . .	659
11.72.1 Detailed Description . . . . .	659
11.72.2 Field Documentation . . . . .	659
11.73CFE_FS_Header Struct Reference . . . . .	661
11.73.1 Detailed Description . . . . .	661
11.73.2 Field Documentation . . . . .	661
11.74CFE_SB_AllSubscriptionsTlm Struct Reference . . . . .	663
11.74.1 Detailed Description . . . . .	664
11.74.2 Field Documentation . . . . .	664
11.75CFE_SB_AllSubscriptionsTlm_Payload Struct Reference . . . . .	664

11.75.1 Detailed Description . . . . .	665
11.75.2 Field Documentation . . . . .	665
11.76CFE_SB_HousekeepingTlm Struct Reference . . . . .	666
11.76.1 Detailed Description . . . . .	666
11.76.2 Field Documentation . . . . .	666
11.77CFE_SB_HousekeepingTlm_Payload Struct Reference . . . . .	667
11.77.1 Detailed Description . . . . .	668
11.77.2 Field Documentation . . . . .	668
11.78CFE_SB_Msg Union Reference . . . . .	672
11.78.1 Detailed Description . . . . .	672
11.78.2 Field Documentation . . . . .	673
11.79CFE_SB_MsgId_t Struct Reference . . . . .	673
11.79.1 Detailed Description . . . . .	674
11.79.2 Field Documentation . . . . .	674
11.80CFE_SB_MsgMapFileEntry Struct Reference . . . . .	674
11.80.1 Detailed Description . . . . .	675
11.80.2 Field Documentation . . . . .	675
11.81CFE_SB_PipeDepthStats Struct Reference . . . . .	675
11.81.1 Detailed Description . . . . .	676
11.81.2 Field Documentation . . . . .	676
11.82CFE_SB_PipeInfoEntry Struct Reference . . . . .	677
11.82.1 Detailed Description . . . . .	678
11.82.2 Field Documentation . . . . .	678
11.83CFE_SB_Qos_t Struct Reference . . . . .	680
11.83.1 Detailed Description . . . . .	681
11.83.2 Field Documentation . . . . .	681
11.84CFE_SB_RouteCmd Struct Reference . . . . .	681
11.84.1 Detailed Description . . . . .	682

11.84.2 Field Documentation . . . . .	682
11.85CFE_SB_RouteCmd_Payload Struct Reference . . . . .	682
11.85.1 Detailed Description . . . . .	683
11.85.2 Field Documentation . . . . .	683
11.86CFE_SB_RoutingFileEntry Struct Reference . . . . .	684
11.86.1 Detailed Description . . . . .	684
11.86.2 Field Documentation . . . . .	684
11.87CFE_SB_SingleSubscriptionTlm Struct Reference . . . . .	686
11.87.1 Detailed Description . . . . .	686
11.87.2 Field Documentation . . . . .	686
11.88CFE_SB_SingleSubscriptionTlm_Payload Struct Reference . . . . .	686
11.88.1 Detailed Description . . . . .	687
11.88.2 Field Documentation . . . . .	687
11.89CFE_SB_StatsTlm Struct Reference . . . . .	688
11.89.1 Detailed Description . . . . .	688
11.89.2 Field Documentation . . . . .	688
11.90CFE_SB_StatsTlm_Payload Struct Reference . . . . .	689
11.90.1 Detailed Description . . . . .	690
11.90.2 Field Documentation . . . . .	690
11.91CFE_SB_SubEntries Struct Reference . . . . .	694
11.91.1 Detailed Description . . . . .	695
11.91.2 Field Documentation . . . . .	695
11.92CFE_SB_WriteFileInfoCmd Struct Reference . . . . .	696
11.92.1 Detailed Description . . . . .	696
11.92.2 Field Documentation . . . . .	696
11.93CFE_SB_WriteFileInfoCmd_Payload Struct Reference . . . . .	697
11.93.1 Detailed Description . . . . .	697
11.93.2 Field Documentation . . . . .	697

11.94CFE_TBL_AbortLoadCmd Struct Reference . . . . .	697
11.94.1 Detailed Description . . . . .	698
11.94.2 Field Documentation . . . . .	698
11.95CFE_TBL_AbortLoadCmd_Payload Struct Reference . . . . .	698
11.95.1 Detailed Description . . . . .	699
11.95.2 Field Documentation . . . . .	699
11.96CFE_TBL_ActivateCmd Struct Reference . . . . .	699
11.96.1 Detailed Description . . . . .	700
11.96.2 Field Documentation . . . . .	700
11.97CFE_TBL_ActivateCmd_Payload Struct Reference . . . . .	700
11.97.1 Detailed Description . . . . .	701
11.97.2 Field Documentation . . . . .	701
11.98CFE_TBL_DelCDSCmd_Payload Struct Reference . . . . .	701
11.98.1 Detailed Description . . . . .	701
11.98.2 Field Documentation . . . . .	702
11.99CFE_TBL_DeleteCDSCmd Struct Reference . . . . .	702
11.99.1 Detailed Description . . . . .	702
11.99.2 Field Documentation . . . . .	702
11.10CFE_TBL_DumpCmd Struct Reference . . . . .	703
11.100.1 Detailed Description . . . . .	703
11.100.2 Field Documentation . . . . .	703
11.10CFE_TBL_DumpCmd_Payload Struct Reference . . . . .	704
11.101.1 Detailed Description . . . . .	704
11.101.2 Field Documentation . . . . .	705
11.10CFE_TBL_DumpRegistryCmd Struct Reference . . . . .	705
11.102.1 Detailed Description . . . . .	706
11.102.2 Field Documentation . . . . .	706
11.10CFE_TBL_DumpRegistryCmd_Payload Struct Reference . . . . .	706

11.103.1 Detailed Description . . . . .	707
11.103.2 Field Documentation . . . . .	707
11.104 CFE_TBL_File_Hdr Struct Reference . . . . .	707
11.104.1 Detailed Description . . . . .	708
11.104.2 Field Documentation . . . . .	708
11.105 CFE_TBL_FileDef Struct Reference . . . . .	709
11.105.1 Detailed Description . . . . .	709
11.105.2 Field Documentation . . . . .	709
11.106 CFE_TBL_HousekeepingTlm Struct Reference . . . . .	710
11.106.1 Detailed Description . . . . .	710
11.106.2 Field Documentation . . . . .	711
11.107 CFE_TBL_HousekeepingTlm_Payload Struct Reference . . . . .	711
11.107.1 Detailed Description . . . . .	712
11.107.2 Field Documentation . . . . .	712
11.108 CFE_TBL_Info Struct Reference . . . . .	717
11.108.1 Detailed Description . . . . .	718
11.108.2 Field Documentation . . . . .	718
11.109 CFE_TBL_LoadCmd Struct Reference . . . . .	721
11.109.1 Detailed Description . . . . .	721
11.109.2 Field Documentation . . . . .	721
11.110 CFE_TBL_LoadCmd_Payload Struct Reference . . . . .	722
11.110.1 Detailed Description . . . . .	722
11.110.2 Field Documentation . . . . .	722
11.111 CFE_TBL_NoArgsCmd Struct Reference . . . . .	723
11.111.1 Detailed Description . . . . .	723
11.111.2 Field Documentation . . . . .	723
11.112 CFE_TBL_NotifyCmd Struct Reference . . . . .	723
11.112.1 Detailed Description . . . . .	724

11.112. Field Documentation . . . . .	724
11.113CFE_TBL_NotifyCmd_Payload Struct Reference . . . . .	724
11.113.1 Detailed Description . . . . .	725
11.113.2 Field Documentation . . . . .	725
11.114CFE_TBL_SendRegistryCmd Struct Reference . . . . .	725
11.114.1 Detailed Description . . . . .	726
11.114.2 Field Documentation . . . . .	726
11.115CFE_TBL_SendRegistryCmd_Payload Struct Reference . . . . .	726
11.115.1 Detailed Description . . . . .	727
11.115.2 Field Documentation . . . . .	727
11.116CFE_TBL_TableRegistryTlm Struct Reference . . . . .	727
11.116.1 Detailed Description . . . . .	727
11.116.2 Field Documentation . . . . .	728
11.117CFE_TBL_TblRegPacket_Payload Struct Reference . . . . .	728
11.117.1 Detailed Description . . . . .	729
11.117.2 Field Documentation . . . . .	729
11.118CFE_TBL_ValidateCmd Struct Reference . . . . .	734
11.118.1 Detailed Description . . . . .	734
11.118.2 Field Documentation . . . . .	734
11.119CFE_TBL_ValidateCmd_Payload Struct Reference . . . . .	735
11.119.1 Detailed Description . . . . .	735
11.119.2 Field Documentation . . . . .	735
11.120CFE_TIME_DiagnosticTlm Struct Reference . . . . .	736
11.120.1 Detailed Description . . . . .	736
11.120.2 Field Documentation . . . . .	736
11.121CFE_TIME_DiagnosticTlm_Payload Struct Reference . . . . .	736
11.121.1 Detailed Description . . . . .	738
11.121.2 Field Documentation . . . . .	739

11.12 <del>CFE_TIME_HousekeepingTlm</del> Struct Reference . . . . .	749
11.122.1 Detailed Description . . . . .	749
11.122.2 Field Documentation . . . . .	750
11.12 <del>CFE_TIME_HousekeepingTlm_Payload</del> Struct Reference . . . . .	750
11.123.1 Detailed Description . . . . .	751
11.123.2 Field Documentation . . . . .	751
11.12 <del>CFE_TIME_LeapsCmd_Payload</del> Struct Reference . . . . .	754
11.124.1 Detailed Description . . . . .	755
11.124.2 Field Documentation . . . . .	755
11.12 <del>CFE_TIME_NoArgsCmd</del> Struct Reference . . . . .	755
11.125.1 Detailed Description . . . . .	755
11.125.2 Field Documentation . . . . .	756
11.12 <del>CFE_TIME_OneHzAdjustmentCmd</del> Struct Reference . . . . .	756
11.126.1 Detailed Description . . . . .	756
11.126.2 Field Documentation . . . . .	756
11.12 <del>CFE_TIME_OneHzAdjustmentCmd_Payload</del> Struct Reference . . . . .	757
11.127.1 Detailed Description . . . . .	757
11.127.2 Field Documentation . . . . .	757
11.12 <del>CFE_TIME_SetLeapSecondsCmd</del> Struct Reference . . . . .	758
11.128.1 Detailed Description . . . . .	758
11.128.2 Field Documentation . . . . .	758
11.12 <del>CFE_TIME_SetSignalCmd</del> Struct Reference . . . . .	759
11.129.1 Detailed Description . . . . .	759
11.129.2 Field Documentation . . . . .	759
11.13 <del>CFE_TIME_SetSourceCmd</del> Struct Reference . . . . .	760
11.130.1 Detailed Description . . . . .	760
11.130.2 Field Documentation . . . . .	760
11.13 <del>CFE_TIME_SetStateCmd</del> Struct Reference . . . . .	761

11.131.1. Detailed Description . . . . .	761
11.131.2. Field Documentation . . . . .	761
11.132. CFE_TIME_SignalCmd_Payload Struct Reference . . . . .	762
11.132.1. Detailed Description . . . . .	762
11.132.2. Field Documentation . . . . .	762
11.133. CFE_TIME_SourceCmd_Payload Struct Reference . . . . .	763
11.133.1. Detailed Description . . . . .	763
11.133.2. Field Documentation . . . . .	763
11.134. CFE_TIME_StateCmd_Payload Struct Reference . . . . .	763
11.134.1. Detailed Description . . . . .	764
11.134.2. Field Documentation . . . . .	764
11.135. CFE_TIME_SysTime Struct Reference . . . . .	764
11.135.1. Detailed Description . . . . .	764
11.135.2. Field Documentation . . . . .	765
11.136. CFE_TIME_TimeCmd Struct Reference . . . . .	765
11.136.1. Detailed Description . . . . .	765
11.136.2. Field Documentation . . . . .	766
11.137. CFE_TIME_TimeCmd_Payload Struct Reference . . . . .	766
11.137.1. Detailed Description . . . . .	766
11.137.2. Field Documentation . . . . .	766
11.138. CFE_TIME_ToneDataCmd Struct Reference . . . . .	767
11.138.1. Detailed Description . . . . .	767
11.138.2. Field Documentation . . . . .	767
11.139. CFE_TIME_ToneDataCmd_Payload Struct Reference . . . . .	768
11.139.1. Detailed Description . . . . .	768
11.139.2. Field Documentation . . . . .	769
11.140. DS_AddMidCmd_t Struct Reference . . . . .	770
11.140.1. Detailed Description . . . . .	770

11.140. Field Documentation . . . . .	770
11.14 DS_AppData_t Struct Reference . . . . .	771
11.141. Detailed Description . . . . .	772
11.141. Field Documentation . . . . .	772
11.14 DS_AppFileStatus_t Struct Reference . . . . .	778
11.142. Detailed Description . . . . .	779
11.142. Field Documentation . . . . .	779
11.14 DS_AppStateCmd_t Struct Reference . . . . .	782
11.143. Detailed Description . . . . .	782
11.143. Field Documentation . . . . .	782
11.14 DS_CloseAllCmd_t Struct Reference . . . . .	783
11.144. Detailed Description . . . . .	783
11.144. Field Documentation . . . . .	783
11.14 DS_CloseFileCmd_t Struct Reference . . . . .	784
11.145. Detailed Description . . . . .	784
11.145. Field Documentation . . . . .	784
11.14 DS_DestAgeCmd_t Struct Reference . . . . .	785
11.146. Detailed Description . . . . .	785
11.146. Field Documentation . . . . .	785
11.14 DS_DestBaseCmd_t Struct Reference . . . . .	786
11.147. Detailed Description . . . . .	787
11.147. Field Documentation . . . . .	787
11.14 DS_DestCountCmd_t Struct Reference . . . . .	788
11.148. Detailed Description . . . . .	788
11.148. Field Documentation . . . . .	789
11.14 DS_DestExtCmd_t Struct Reference . . . . .	790
11.149. Detailed Description . . . . .	790
11.149. Field Documentation . . . . .	790

11.150S_DestFileEntry_t Struct Reference . . . . .	791
11.150.1 Detailed Description . . . . .	792
11.150.2 Field Documentation . . . . .	792
11.151DS_DestFileTable_t Struct Reference . . . . .	794
11.151.1 Detailed Description . . . . .	794
11.151.2 Field Documentation . . . . .	795
11.152DS_DestPathCmd_t Struct Reference . . . . .	795
11.152.1 Detailed Description . . . . .	796
11.152.2 Field Documentation . . . . .	796
11.153DS_DestSizeCmd_t Struct Reference . . . . .	797
11.153.1 Detailed Description . . . . .	797
11.153.2 Field Documentation . . . . .	797
11.154DS_DestStateCmd_t Struct Reference . . . . .	798
11.154.1 Detailed Description . . . . .	799
11.154.2 Field Documentation . . . . .	799
11.155DS_DestTypeCmd_t Struct Reference . . . . .	800
11.155.1 Detailed Description . . . . .	800
11.155.2 Field Documentation . . . . .	800
11.156DS_FileCompletePkt_t Struct Reference . . . . .	801
11.156.1 Detailed Description . . . . .	802
11.156.2 Field Documentation . . . . .	802
11.157DS_FileCompletePktBuf_t Union Reference . . . . .	802
11.157.1 Detailed Description . . . . .	803
11.157.2 Field Documentation . . . . .	803
11.158DS_FileHeader_t Struct Reference . . . . .	803
11.158.1 Detailed Description . . . . .	804
11.158.2 Field Documentation . . . . .	804
11.159DS_FileInfo_t Struct Reference . . . . .	805

11.159.1 Detailed Description . . . . .	806
11.159.2 Field Documentation . . . . .	806
11.160 S_FileInfoPkt_t Struct Reference . . . . .	808
11.160.1 Detailed Description . . . . .	808
11.160.2 Field Documentation . . . . .	808
11.161 DS_FilterFileCmd_t Struct Reference . . . . .	809
11.161.1 Detailed Description . . . . .	809
11.161.2 Field Documentation . . . . .	809
11.162 DS_FilterParms_t Struct Reference . . . . .	810
11.162.1 Detailed Description . . . . .	811
11.162.2 Field Documentation . . . . .	811
11.163 DS_FilterParmsCmd_t Struct Reference . . . . .	812
11.163.1 Detailed Description . . . . .	813
11.163.2 Field Documentation . . . . .	813
11.164 DS_FilterTable_t Struct Reference . . . . .	814
11.164.1 Detailed Description . . . . .	815
11.164.2 Field Documentation . . . . .	815
11.165 DS_FilterTypeCmd_t Struct Reference . . . . .	815
11.165.1 Detailed Description . . . . .	816
11.165.2 Field Documentation . . . . .	816
11.166 DS_GetFileInfoCmd_t Struct Reference . . . . .	817
11.166.1 Detailed Description . . . . .	817
11.166.2 Field Documentation . . . . .	818
11.167 DS_HashTag Struct Reference . . . . .	818
11.167.1 Detailed Description . . . . .	818
11.167.2 Field Documentation . . . . .	818
11.168 DS_HkPacket_t Struct Reference . . . . .	819
11.168.1 Detailed Description . . . . .	820

11.168. Field Documentation . . . . .	821
11.169. S_NoopCmd_t Struct Reference . . . . .	825
11.169.1. Detailed Description . . . . .	825
11.169.2. Field Documentation . . . . .	825
11.170. S_PacketEntry_t Struct Reference . . . . .	826
11.170.1. Detailed Description . . . . .	826
11.170.2. Field Documentation . . . . .	826
11.171. DS_ResetCmd_t Struct Reference . . . . .	827
11.171.1. Detailed Description . . . . .	827
11.171.2. Field Documentation . . . . .	827
11.172. S_bin_sem_prop_t Struct Reference . . . . .	828
11.172.1. Detailed Description . . . . .	828
11.172.2. Field Documentation . . . . .	828
11.173. S_count_sem_prop_t Struct Reference . . . . .	829
11.173.1. Detailed Description . . . . .	829
11.173.2. Field Documentation . . . . .	829
11.174. s_dirent_t Struct Reference . . . . .	830
11.174.1. Detailed Description . . . . .	830
11.174.2. Field Documentation . . . . .	830
11.175. S_FdSet Struct Reference . . . . .	830
11.175.1. Detailed Description . . . . .	831
11.175.2. Field Documentation . . . . .	831
11.176. S_file_prop_t Struct Reference . . . . .	831
11.176.1. Detailed Description . . . . .	831
11.176.2. Field Documentation . . . . .	832
11.177. s_fsinfo_t Struct Reference . . . . .	832
11.177.1. Detailed Description . . . . .	833
11.177.2. Field Documentation . . . . .	833

11.178s_fstat_t Struct Reference . . . . .	834
11.178.1 Detailed Description . . . . .	834
11.178.2 Field Documentation . . . . .	834
11.179S_heap_prop_t Struct Reference . . . . .	835
11.179.1 Detailed Description . . . . .	835
11.179.2 Field Documentation . . . . .	835
11.180S_module_address_t Struct Reference . . . . .	836
11.180.1 Detailed Description . . . . .	836
11.180.2 Field Documentation . . . . .	836
11.180S_module_prop_t Struct Reference . . . . .	838
11.181.1 Detailed Description . . . . .	838
11.181.2 Field Documentation . . . . .	838
11.180S_mut_sem_prop_t Struct Reference . . . . .	839
11.182.1 Detailed Description . . . . .	840
11.182.2 Field Documentation . . . . .	840
11.180S_queue_prop_t Struct Reference . . . . .	840
11.183.1 Detailed Description . . . . .	841
11.183.2 Field Documentation . . . . .	841
11.180S_SockAddr_t Struct Reference . . . . .	841
11.184.1 Detailed Description . . . . .	842
11.184.2 Field Documentation . . . . .	842
11.180S_SockAddrData_t Union Reference . . . . .	842
11.185.1 Detailed Description . . . . .	843
11.185.2 Field Documentation . . . . .	843
11.180S_socket_prop_t Struct Reference . . . . .	844
11.186.1 Detailed Description . . . . .	844
11.186.2 Field Documentation . . . . .	844
11.180S_static_symbol_record_t Struct Reference . . . . .	845

11.187.1 Detailed Description . . . . .	845
11.187.2 Field Documentation . . . . .	845
11.188 OS_statvfs_t Struct Reference . . . . .	846
11.188.1 Detailed Description . . . . .	846
11.188.2 Field Documentation . . . . .	846
11.189 OS_task_prop_t Struct Reference . . . . .	847
11.189.1 Detailed Description . . . . .	847
11.189.2 Field Documentation . . . . .	847
11.190 OS_time_t Struct Reference . . . . .	848
11.190.1 Detailed Description . . . . .	848
11.190.2 Field Documentation . . . . .	849
11.191 OS_timebase_prop_t Struct Reference . . . . .	849
11.191.1 Detailed Description . . . . .	849
11.191.2 Field Documentation . . . . .	849
11.192 OS_timer_prop_t Struct Reference . . . . .	850
11.192.1 Detailed Description . . . . .	851
11.192.2 Field Documentation . . . . .	851
<b>12 File Documentation</b>	<b>852</b>
12.1 apps/ds/docs/dox_src/cfs_ds.dox File Reference . . . . .	852
12.2 apps/ds/fsw/mission_inc/ds_perfids.h File Reference . . . . .	852
12.2.1 Detailed Description . . . . .	852
12.3 apps/ds/fsw/platform_inc/ds_msgids.h File Reference . . . . .	852
12.3.1 Detailed Description . . . . .	852
12.4 apps/ds/fsw/platform_inc/ds_platform_cfg.h File Reference . . . . .	853
12.4.1 Detailed Description . . . . .	854
12.5 apps/ds/fsw/src/ds_app.c File Reference . . . . .	854
12.5.1 Detailed Description . . . . .	855

12.5.2 Function Documentation . . . . .	855
12.5.3 Variable Documentation . . . . .	865
12.6 apps/ds/fsw/src/ds_app.h File Reference . . . . .	865
12.6.1 Detailed Description . . . . .	866
12.6.2 Macro Definition Documentation . . . . .	866
12.6.3 Function Documentation . . . . .	867
12.6.4 Variable Documentation . . . . .	877
12.7 apps/ds/fsw/src/ds_appdefs.h File Reference . . . . .	877
12.7.1 Detailed Description . . . . .	878
12.7.2 Macro Definition Documentation . . . . .	878
12.8 apps/ds/fsw/src/ds_cmds.c File Reference . . . . .	882
12.8.1 Detailed Description . . . . .	883
12.8.2 Function Documentation . . . . .	883
12.9 apps/ds/fsw/src/ds_cmds.h File Reference . . . . .	907
12.9.1 Detailed Description . . . . .	908
12.9.2 Function Documentation . . . . .	908
12.10 apps/ds/fsw/src/ds_events.h File Reference . . . . .	932
12.10.1 Detailed Description . . . . .	935
12.11 apps/ds/fsw/src/ds_file.c File Reference . . . . .	935
12.11.1 Detailed Description . . . . .	936
12.11.2 Macro Definition Documentation . . . . .	936
12.11.3 Function Documentation . . . . .	940
12.12 apps/ds/fsw/src/ds_file.h File Reference . . . . .	955
12.12.1 Detailed Description . . . . .	956
12.12.2 Function Documentation . . . . .	956
12.13 apps/ds/fsw/src/ds_msg.h File Reference . . . . .	971
12.13.1 Detailed Description . . . . .	972
12.14 apps/ds/fsw/src/ds_msgdefs.h File Reference . . . . .	972

12.14.1 Detailed Description . . . . .	973
12.15apps/ds/fsw/src/ds_table.c File Reference . . . . .	973
12.15.1 Detailed Description . . . . .	975
12.15.2 Macro Definition Documentation . . . . .	975
12.15.3 Function Documentation . . . . .	975
12.16apps/ds/fsw/src/ds_table.h File Reference . . . . .	999
12.16.1 Detailed Description . . . . .	1001
12.16.2 Macro Definition Documentation . . . . .	1001
12.16.3 Typedef Documentation . . . . .	1002
12.16.4 Function Documentation . . . . .	1002
12.17apps/ds/fsw/src/ds_verify.h File Reference . . . . .	1026
12.17.1 Detailed Description . . . . .	1027
12.18apps/ds/fsw/src/ds_version.h File Reference . . . . .	1027
12.18.1 Detailed Description . . . . .	1027
12.19apps/ds/fsw/tables/ds_file_tbl.c File Reference . . . . .	1027
12.19.1 Detailed Description . . . . .	1028
12.19.2 Macro Definition Documentation . . . . .	1028
12.19.3 Variable Documentation . . . . .	1029
12.20apps/ds/fsw/tables/ds_filter_tbl.c File Reference . . . . .	1029
12.20.1 Detailed Description . . . . .	1030
12.20.2 Macro Definition Documentation . . . . .	1030
12.20.3 Variable Documentation . . . . .	1031
12.21build/docs/osconfig-example.h File Reference . . . . .	1032
12.21.1 Macro Definition Documentation . . . . .	1033
12.22cfecmake/sample_defs/cpu1_msgids.h File Reference . . . . .	1041
12.22.1 Detailed Description . . . . .	1042
12.22.2 Macro Definition Documentation . . . . .	1042
12.23cfecmake/sample_defs/cpu1_platform_cfg.h File Reference . . . . .	1049

12.23.1 Detailed Description . . . . .	1052
12.23.2 Macro Definition Documentation . . . . .	1052
12.24cfe/cmake/sample_defs/sample_mission_cfg.h File Reference . . . . .	1106
12.24.1 Detailed Description . . . . .	1108
12.24.2 Macro Definition Documentation . . . . .	1108
12.25cfe/cmake/sample_defs/sample_perfids.h File Reference . . . . .	1127
12.25.1 Detailed Description . . . . .	1128
12.25.2 Macro Definition Documentation . . . . .	1128
12.26cfe/docs/src/cfe_api.dox File Reference . . . . .	1131
12.27cfe/docs/src/cfe_es.dox File Reference . . . . .	1131
12.28cfe/docs/src/cfe_evs.dox File Reference . . . . .	1131
12.29cfe/docs/src/cfe_frontpage.dox File Reference . . . . .	1131
12.30cfe/docs/src/cfe_glossary.dox File Reference . . . . .	1131
12.31cfe/docs/src/cfe_sb.dox File Reference . . . . .	1131
12.32cfe/docs/src/cfe_tbl.dox File Reference . . . . .	1131
12.33cfe/docs/src/cfe_time.dox File Reference . . . . .	1131
12.34cfe/docs/src/cfe_xref.dox File Reference . . . . .	1131
12.35cfe/docs/src/cfs_versions.dox File Reference . . . . .	1131
12.36cfe/modules/core_api/fsw/inc/cfe.h File Reference . . . . .	1131
12.36.1 Detailed Description . . . . .	1131
12.37cfe/modules/core_api/fsw/inc/cfe_config.h File Reference . . . . .	1132
12.37.1 Detailed Description . . . . .	1132
12.37.2 Function Documentation . . . . .	1132
12.38cfe/modules/core_api/fsw/inc/cfe_config_api_typedefs.h File Reference . . . . .	1136
12.38.1 Detailed Description . . . . .	1137
12.38.2 Macro Definition Documentation . . . . .	1137
12.38.3 Typedef Documentation . . . . .	1137
12.39cfe/modules/core_api/fsw/inc/cfe_endian.h File Reference . . . . .	1138

12.39.1 Detailed Description . . . . .	1138
12.39.2 Macro Definition Documentation . . . . .	1138
12.40cfe/modules/core_api/fsw/inc/cfe_error.h File Reference . . . . .	1138
12.40.1 Detailed Description . . . . .	1145
12.40.2 Macro Definition Documentation . . . . .	1145
12.40.3 Typedef Documentation . . . . .	1148
12.40.4 Function Documentation . . . . .	1148
12.41cfe/modules/core_api/fsw/inc/cfe_es.h File Reference . . . . .	1149
12.41.1 Detailed Description . . . . .	1152
12.41.2 Macro Definition Documentation . . . . .	1152
12.42cfe/modules/core_api/fsw/inc/cfe_es_api_typedefs.h File Reference . . . . .	1153
12.42.1 Detailed Description . . . . .	1154
12.42.2 Macro Definition Documentation . . . . .	1154
12.42.3 Typedef Documentation . . . . .	1158
12.43cfe/modules/core_api/fsw/inc/cfe_es_extern_typedefs.h File Reference . . . . .	1159
12.43.1 Detailed Description . . . . .	1161
12.43.2 Macro Definition Documentation . . . . .	1161
12.43.3 Typedef Documentation . . . . .	1162
12.43.4 Enumeration Type Documentation . . . . .	1168
12.44cfe/modules/core_api/fsw/inc/cfe_evs.h File Reference . . . . .	1171
12.44.1 Detailed Description . . . . .	1171
12.44.2 Macro Definition Documentation . . . . .	1171
12.45cfe/modules/core_api/fsw/inc/cfe_evs_api_typedefs.h File Reference . . . . .	1173
12.45.1 Detailed Description . . . . .	1173
12.45.2 Macro Definition Documentation . . . . .	1174
12.45.3 Typedef Documentation . . . . .	1176
12.46cfe/modules/core_api/fsw/inc/cfe_evs_extern_typedefs.h File Reference . . . . .	1176
12.46.1 Detailed Description . . . . .	1177

12.46.2 Typedef Documentation . . . . .	1177
12.46.3 Enumeration Type Documentation . . . . .	1178
12.47 cfe/modules/core_api/fsw/inc/cfe_fs.h File Reference . . . . .	1181
12.47.1 Detailed Description . . . . .	1182
12.48 cfe/modules/core_api/fsw/inc/cfe_fs_api_typedefs.h File Reference . . . . .	1182
12.48.1 Detailed Description . . . . .	1182
12.48.2 Typedef Documentation . . . . .	1183
12.48.3 Enumeration Type Documentation . . . . .	1184
12.49 cfe/modules/core_api/fsw/inc/cfe_fs_extern_typedefs.h File Reference . . . . .	1185
12.49.1 Detailed Description . . . . .	1186
12.49.2 Macro Definition Documentation . . . . .	1186
12.49.3 Typedef Documentation . . . . .	1186
12.49.4 Enumeration Type Documentation . . . . .	1187
12.50 cfe/modules/core_api/fsw/inc/cfe_msg.h File Reference . . . . .	1188
12.50.1 Detailed Description . . . . .	1190
12.51 cfe/modules/core_api/fsw/inc/cfe_msg_api_typedefs.h File Reference . . . . .	1190
12.51.1 Detailed Description . . . . .	1192
12.51.2 Macro Definition Documentation . . . . .	1192
12.51.3 Typedef Documentation . . . . .	1192
12.51.4 Enumeration Type Documentation . . . . .	1195
12.52 cfe/modules/core_api/fsw/inc/cfe_resourceid.h File Reference . . . . .	1198
12.52.1 Detailed Description . . . . .	1199
12.52.2 Macro Definition Documentation . . . . .	1199
12.52.3 Function Documentation . . . . .	1200
12.53 cfe/modules/core_api/fsw/inc/cfe_resourceid_api_typedefs.h File Reference . . . . .	1205
12.53.1 Detailed Description . . . . .	1206
12.53.2 Macro Definition Documentation . . . . .	1206
12.54 cfe/modules/core_api/fsw/inc/cfe_sb.h File Reference . . . . .	1207

12.54.1 Detailed Description . . . . .	1208
12.54.2 Macro Definition Documentation . . . . .	1208
12.55cfe/modules/core_api/fsw/inc/cfe_sb_api_typedefs.h File Reference . . . . .	1209
12.55.1 Detailed Description . . . . .	1210
12.55.2 Macro Definition Documentation . . . . .	1211
12.55.3 Typedef Documentation . . . . .	1214
12.56cfe/modules/core_api/fsw/inc/cfe_sb_extern_typedefs.h File Reference . . . . .	1214
12.56.1 Detailed Description . . . . .	1215
12.56.2 Macro Definition Documentation . . . . .	1215
12.56.3 Typedef Documentation . . . . .	1216
12.56.4 Enumeration Type Documentation . . . . .	1217
12.57cfe/modules/core_api/fsw/inc/cfe_tbl.h File Reference . . . . .	1218
12.57.1 Detailed Description . . . . .	1219
12.58cfe/modules/core_api/fsw/inc/cfe_tbl_api_typedefs.h File Reference . . . . .	1219
12.58.1 Detailed Description . . . . .	1220
12.58.2 Macro Definition Documentation . . . . .	1221
12.58.3 Typedef Documentation . . . . .	1221
12.58.4 Enumeration Type Documentation . . . . .	1222
12.59cfe/modules/core_api/fsw/inc/cfe_tbl_extern_typedefs.h File Reference . . . . .	1222
12.59.1 Detailed Description . . . . .	1223
12.59.2 Typedef Documentation . . . . .	1223
12.59.3 Enumeration Type Documentation . . . . .	1223
12.60cfe/modules/core_api/fsw/inc/cfe_tbl_filedef.h File Reference . . . . .	1224
12.60.1 Detailed Description . . . . .	1224
12.60.2 Macro Definition Documentation . . . . .	1225
12.60.3 Typedef Documentation . . . . .	1225
12.61cfe/modules/core_api/fsw/inc/cfe_time.h File Reference . . . . .	1226
12.61.1 Detailed Description . . . . .	1227

12.61.2 Macro Definition Documentation . . . . .	1227
12.62cfe/modules/core_api/fsw/inc/cfe_time_api_typedefs.h File Reference . . . . .	1228
12.62.1 Detailed Description . . . . .	1228
12.62.2 Macro Definition Documentation . . . . .	1228
12.62.3 Typedef Documentation . . . . .	1229
12.62.4 Enumeration Type Documentation . . . . .	1229
12.63cfe/modules/core_api/fsw/inc/cfe_time_extern_typedefs.h File Reference . . . . .	1230
12.63.1 Detailed Description . . . . .	1231
12.63.2 Typedef Documentation . . . . .	1231
12.63.3 Enumeration Type Documentation . . . . .	1233
12.64cfe/modules/core_api/fsw/inc/cfe_version.h File Reference . . . . .	1236
12.64.1 Detailed Description . . . . .	1236
12.64.2 Macro Definition Documentation . . . . .	1237
12.65cfe/modules/es/fsw/inc/cfe_es_events.h File Reference . . . . .	1239
12.65.1 Detailed Description . . . . .	1242
12.65.2 Macro Definition Documentation . . . . .	1242
12.66cfe/modules/es/fsw/inc/cfe_es_msg.h File Reference . . . . .	1272
12.66.1 Detailed Description . . . . .	1276
12.66.2 Macro Definition Documentation . . . . .	1276
12.66.3 Typedef Documentation . . . . .	1300
12.67cfe/modules/evs/fsw/inc/cfe_evs_events.h File Reference . . . . .	1308
12.67.1 Detailed Description . . . . .	1309
12.67.2 Macro Definition Documentation . . . . .	1309
12.68cfe/modules/evs/fsw/inc/cfe_evs_msg.h File Reference . . . . .	1323
12.68.1 Detailed Description . . . . .	1326
12.68.2 Macro Definition Documentation . . . . .	1326
12.68.3 Typedef Documentation . . . . .	1348
12.69cfe/modules/msg/fsw/inc/ccsds_hdr.h File Reference . . . . .	1355

12.69.1 Detailed Description . . . . .	1356
12.69.2 Typedef Documentation . . . . .	1356
12.70cfe/modules/resourceid/fsw/inc/cfe_core_resourceid_basevalues.h File Reference . . . . .	1356
12.70.1 Detailed Description . . . . .	1357
12.71cfe/modules/resourceid/fsw/inc/cfe_resourceid_basevalue.h File Reference . . . . .	1357
12.71.1 Detailed Description . . . . .	1358
12.71.2 Macro Definition Documentation . . . . .	1358
12.72cfe/modules/sb/fsw/inc/cfe_sb_events.h File Reference . . . . .	1359
12.72.1 Detailed Description . . . . .	1361
12.72.2 Macro Definition Documentation . . . . .	1361
12.73cfe/modules/sb/fsw/inc/cfe_sb_msg.h File Reference . . . . .	1383
12.73.1 Detailed Description . . . . .	1385
12.73.2 Macro Definition Documentation . . . . .	1385
12.73.3 Typedef Documentation . . . . .	1396
12.74cfe/modules/tbl/fsw/inc/cfe_tbl_events.h File Reference . . . . .	1401
12.74.1 Detailed Description . . . . .	1403
12.74.2 Macro Definition Documentation . . . . .	1403
12.75cfe/modules/tbl/fsw/inc/cfe_tbl_msg.h File Reference . . . . .	1427
12.75.1 Detailed Description . . . . .	1429
12.75.2 Macro Definition Documentation . . . . .	1429
12.75.3 Typedef Documentation . . . . .	1440
12.76cfe/modules/time/fsw/inc/cfe_time_events.h File Reference . . . . .	1444
12.76.1 Detailed Description . . . . .	1445
12.76.2 Macro Definition Documentation . . . . .	1446
12.77cfe/modules/time/fsw/inc/cfe_time_msg.h File Reference . . . . .	1458
12.77.1 Detailed Description . . . . .	1461
12.77.2 Macro Definition Documentation . . . . .	1461
12.77.3 Typedef Documentation . . . . .	1478

12.78osal/docs/src/osal_frontpage.dox File Reference . . . . .	1484
12.79osal/docs/src/osal_fs.dox File Reference . . . . .	1484
12.80osal/docs/src/osal_timer.dox File Reference . . . . .	1484
12.81osal/src/os/inc/common_types.h File Reference . . . . .	1484
12.81.1 Detailed Description . . . . .	1486
12.81.2 Macro Definition Documentation . . . . .	1486
12.81.3 Typedef Documentation . . . . .	1487
12.81.4 Function Documentation . . . . .	1491
12.82osal/src/os/inc/osapi-binsem.h File Reference . . . . .	1492
12.82.1 Detailed Description . . . . .	1493
12.83osal/src/os/inc/osapi-bsp.h File Reference . . . . .	1493
12.83.1 Detailed Description . . . . .	1494
12.84osal/src/os/inc/osapi-clock.h File Reference . . . . .	1494
12.84.1 Detailed Description . . . . .	1495
12.84.2 Enumeration Type Documentation . . . . .	1495
12.85osal/src/os/inc/osapi-common.h File Reference . . . . .	1496
12.85.1 Detailed Description . . . . .	1496
12.85.2 Typedef Documentation . . . . .	1497
12.85.3 Enumeration Type Documentation . . . . .	1498
12.86osal/src/os/inc/osapi-constants.h File Reference . . . . .	1499
12.86.1 Detailed Description . . . . .	1499
12.86.2 Macro Definition Documentation . . . . .	1499
12.87osal/src/os/inc/osapi-countsem.h File Reference . . . . .	1500
12.87.1 Detailed Description . . . . .	1501
12.88osal/src/os/inc/osapi-dir.h File Reference . . . . .	1501
12.88.1 Detailed Description . . . . .	1502
12.88.2 Macro Definition Documentation . . . . .	1502
12.89osal/src/os/inc/osapi-error.h File Reference . . . . .	1502

12.89.1 Detailed Description . . . . .	1505
12.89.2 Macro Definition Documentation . . . . .	1505
12.89.3 Typedef Documentation . . . . .	1505
12.90osal/src/os/inc/osapi-file.h File Reference . . . . .	1506
12.90.1 Detailed Description . . . . .	1508
12.90.2 Macro Definition Documentation . . . . .	1508
12.90.3 Enumeration Type Documentation . . . . .	1509
12.91osal/src/os/inc/osapi-filesystem.h File Reference . . . . .	1510
12.91.1 Detailed Description . . . . .	1511
12.91.2 Macro Definition Documentation . . . . .	1511
12.92osal/src/os/inc/osapi-heap.h File Reference . . . . .	1512
12.92.1 Detailed Description . . . . .	1512
12.93osal/src/os/inc/osapi-idmap.h File Reference . . . . .	1512
12.93.1 Detailed Description . . . . .	1514
12.93.2 Macro Definition Documentation . . . . .	1514
12.94osal/src/os/inc/osapi-macros.h File Reference . . . . .	1514
12.94.1 Detailed Description . . . . .	1515
12.94.2 Macro Definition Documentation . . . . .	1515
12.95osal/src/os/inc/osapi-module.h File Reference . . . . .	1517
12.95.1 Detailed Description . . . . .	1517
12.95.2 Macro Definition Documentation . . . . .	1517
12.96osal/src/os/inc/osapi-mutex.h File Reference . . . . .	1518
12.96.1 Detailed Description . . . . .	1519
12.97osal/src/os/inc/osapi-network.h File Reference . . . . .	1519
12.97.1 Detailed Description . . . . .	1519
12.98osal/src/os/inc/osapi-printf.h File Reference . . . . .	1520
12.98.1 Detailed Description . . . . .	1520
12.99osal/src/os/inc/osapi-queue.h File Reference . . . . .	1520

12.99.1 Detailed Description . . . . .	1521
12.100sal/src/os/inc/osapi-select.h File Reference . . . . .	1521
12.100.1Detailed Description . . . . .	1521
12.100.2Enumeration Type Documentation . . . . .	1521
12.101sal/src/os/inc/osapi-shell.h File Reference . . . . .	1522
12.101.1Detailed Description . . . . .	1522
12.102sal/src/os/inc/osapi-sockets.h File Reference . . . . .	1522
12.102.1Detailed Description . . . . .	1524
12.102.2Macro Definition Documentation . . . . .	1524
12.102.3Enumeration Type Documentation . . . . .	1524
12.103sal/src/os/inc/osapi-task.h File Reference . . . . .	1525
12.103.1Detailed Description . . . . .	1527
12.103.2Macro Definition Documentation . . . . .	1527
12.103.3Typedef Documentation . . . . .	1528
12.103.4Function Documentation . . . . .	1528
12.104sal/src/os/inc/osapi-timebase.h File Reference . . . . .	1529
12.104.1Detailed Description . . . . .	1529
12.104.2Typedef Documentation . . . . .	1530
12.105sal/src/os/inc/osapi-timer.h File Reference . . . . .	1530
12.105.1Detailed Description . . . . .	1531
12.105.2Typedef Documentation . . . . .	1531
12.106sal/src/os/inc/osapi-version.h File Reference . . . . .	1531
12.106.1Detailed Description . . . . .	1532
12.106.2Macro Definition Documentation . . . . .	1532
12.106.3Function Documentation . . . . .	1535
12.107sal/src/os/inc/osapi.h File Reference . . . . .	1536
12.107.1Detailed Description . . . . .	1537
12.108psp/fsw/inc/cfe_psp.h File Reference . . . . .	1537
12.108.1Macro Definition Documentation . . . . .	1539
12.108.2Function Documentation . . . . .	1546
12.109psp/fsw/inc/cfe_psp_error.h File Reference . . . . .	1558
12.109.1Detailed Description . . . . .	1559
12.109.2Macro Definition Documentation . . . . .	1559
12.109.3Typedef Documentation . . . . .	1562
12.109.4Function Documentation . . . . .	1562

## 1 CFS Data Storage (DS) Documentation

- [CFS Data Storage Introduction](#)
- [CFS Data Storage Overview](#)
- [CFS Data Storage Operation](#)
- [CFS Data Storage Commands](#)
- [CFS Data Storage Telemetry](#)
- [CFS Data Storage Events](#)
- [CFS Data Storage Deployment Guide](#)
- [CFS Data Storage Configuration](#)
- [CFS Data Storage Table Definitions](#)
- [CFS Data Storage Operational Constraints](#)
- [CFS Data Storage Frequently Asked Questions](#)

### 1.1 CFS Data Storage Introduction

#### Scope

This document provides a complete specification for the commands and telemetry associated with the CFS Data Storage (DS) application software. The document is intended primarily for users of the software (operations personal, test engineers, and maintenance personnel). The last section of the document, the deployment guide section, is intended for mission developers when deploying and configuring the application software for a mission flight software build environment.

#### CFS Data Storage Version

#### Acronyms

Acronym	Description
DS	CFS Data Storage
API	Application Programming Interface
ATP	Absolute Time Processor
ATS	Absolute Time tagged command Sequence
CCSDS	Consultative Committee for Space Data Systems
C&DH	Command and Data Handling
CFE	Core Flight Executive
CFS	Core Flight System

CI	Command Ingest
Cmd	Command
CPU	Central Processing Unit
EDAC	Error Detection and Correction
FDS	Flight Data System
FM	File Manager
FSW	Flight Software
GN&C	Guidance Navigation & Control
GSFC	Goddard Space Flight Center
HK	Housekeeping
HW, H/W	Hardware
ICD	Interface Control Document
ISR	Interrupt Service Routine
OS	Operating System
OSAL	Operating System Abstraction Layer
Pkts	Packets
RAM	Random-Access Memory
RTOS	Real Time Operating System
RTP	Relative Time Processor
RTS	Relative Time tagged command Sequence
SB	Software Bus Service
SBC	Single Board Computer
SC	Stored Commands task
SW, S/W	Software
TBD	To Be Determined
TBL	Table
TDM	Time Data Multiplex
TLM	Telemetry
UTC	Universal time code

## 1.2 CFS Data Storage Overview

The CFS DS application is responsible for storing messages in files. These files are generally stored on a storage device such as a solid state recorder but they could be stored on any file system. Another application such as CFDP must be used in order to transfer the files created by DS to the ground. The DS software context diagram is shown in Figure DS-1.




Figure 1 Figure DS-1: Software Context Diagram

During initialization, DS subscribes to messages from other applications as defined in the Data Storage Filter Table. The Scheduler application (SCH) sends periodic commands to DS as defined in the SCH Schedule Table which requests housekeeping from DS (note that a mission must define this request in the SCH table). Ground commands come from the Command Ingest task (CI). Messages are routed to DS by the cFE SB application. DS learns of ground updates to the DS tables through the cFE Table Services application.

DS defines two tables:

1. Filter Table - for each message ID, specifies filter scheme, filter parameters and which file or files to write the message to. Note that each message can be written to a maximum of **DS\_FILTERS\_PER\_PACKET** destination files.
2. File Table - specifies information about each destination file.

### 1.3 CFS Data Storage Operation

When DS receives a message that passes the filtering algorithm, the message is stored in a file or files based upon the File Table information for that message ID. Once a message is stored, the DS Housekeeping packet displays information about the open file. Each housekeeping cycle, DS evaluates the open files to determine if their age has been exceeded. If this determination is true, the file is closed by the DS application. Also, each time a message is to be stored, DS determines if the message will fit in the open file. If the determination is false, the open file will be closed and a new file created containing the message. A minimum of one message will be stored each file.

### Filtering

Filtering is based upon message IDs. The Filter Table determines what messages DS will store. The DS application supports two types of filtering:

1. Sequence number based filtering
2. Time based filtering.

Each filtering type relies on three filter factors, N, X, and O where N of X messages will be stored starting at offset O.

#### Sequence based Filtering

This type of filtering uses the packet sequence number to determine if the message should be filtered or not. If X is greater than zero, the message shall be stored if and only if the sequence number modulo X is less than N. For example, N=4, X=6 and O=2 will store 4 of 6 messages starting at offset 2.

#### Time based Filtering

This type of filtering uses the spacecraft time code found in the CCSDS packet secondary header. Fifteen bits out of the 64-bit CCSDS time code field are used. The constructed 15-bit time stamp used for DS filtering consists of the 11 Least Significant Bits (LSB) of the seconds field and the 4 Most Significant Bits (MSB) of the sub-seconds field. Messages will be stored if and only if the constructed 15-bit time stamp modulo X is less than N. This type of filtering is rare in that the N value must be set to the desired 15-bit time stamp which is hard to specify. Testing used simulated values for the spacecraft time code.

## 1.4 CFS Data Storage Commands

[CFS Data Storage Message IDs](#)

[CFS Data Storage Command Structures](#)

[CFS Data Storage Command Codes](#)

## 1.5 CFS Data Storage Telemetry

[CFS Data Storage Message IDs](#)

[CFS Data Storage Telemetry](#)

## 1.6 CFS Data Storage Events

[CFS Data Store Event IDs](#)

## 1.7 CFS Data Storage Deployment Guide

To integrate the DS application, follow the CFS App Integration Guide. Also, be sure to set up the configuration parameters and message IDs for the platform.

### Move File Capability

If the DS\_MOVE\_FILES configuration parameter is set to TRUE, the telemetry database, Destination File table load images and the File Table display page require changes. The Destination File Table rdl file uses the DS\_MOVE\_FILES definition in the [ds\\_platform\\_cfg.h](#) file. However, in order to get the required parameter included in telemetry, this configuration parameter must be set to 1 rather than TRUE. The table images must include this parameter in order to load successfully and the display page must be modified to display this parameter.

## 1.8 CFS Data Storage Configuration

### [CFS Data Storage Mission Configuration](#)

### [CFS Data Storage Platform Configuration](#)

## 1.9 CFS Data Storage Table Definitions

### Destination File Table

The Destination File Table is defined by [DS\\_DestFileTable\\_t](#). This table contains a description and [DS\\_DEST\\_FILE\\_CNT](#) entries. Each entry is defined by [DS\\_DestFileEntry\\_t](#).

### Filter Table

The Filter Table is defined by [DS\\_FilterTable\\_t](#). This table contains a description and [DS\\_PACKETS\\_IN\\_FILTER\\_TABLE](#) entries. Each entry is defined by [DS\\_PacketEntry\\_t](#). Each Packet entry contains the Message ID for DS to store and [DS\\_FILTERS\\_PER\\_PACKET](#) entries defined by [DS\\_FilterParms\\_t](#).

The Data Storage (DS) application attempts to load the File and Filter Tables from [DS\\_DEF\\_DEST\\_FILENAME](#) and [DS\\_DEF\\_FILTER\\_FILENAME](#) upon startup. If the load fails for either of these tables, DS will still start in the mode of operation as defined by the [DS\\_DEF\\_ENABLE\\_STATE](#) configuration parameter. If this configuration parameter is set to ENABLED mode and either the File and/or Filter Table failed to load, DS will not store any messages until both tables are loaded with valid data. This can be accomplished by using the cFE Table Services commands after creating a table load image file and uploading it to the spacecraft's file system. Until both tables are loaded with valid data, DS will increment the [DS\\_HkPacket\\_t.IgnoredPktCounter](#) for each received packet that is discarded.

## 1.10 CFS Data Storage Operational Constraints

DS is dependent on the associated OS/hardware file system and storage constraints.

## 1.11 CFS Data Storage Frequently Asked Questions

### (Q) How do I determine what message IDs are to be stored?

The Message IDs to be stored are specified in the Filter Table. To determine what these are, you must dump the filter table. This can be done by displaying the Filter Table display page and clicking the Refresh button.

### (Q) Where are my files being stored?

The locations of the files are determined by the File Table entry that the message ID is associated with. The Filter table indicates what File index is being used to store that message IDs data. To trace the message ID to the File entry, both tables must be dumped. This can be done by displaying the File and Filter Table display pages and clicking the Refresh buttons on each page.

### (Q) How are my files named?

The files are named as follows:

path + base + [time/seq characters] + extension.

If the file is a Sequence based file, the sequence characters will be based upon the next sequence number. For example, if path = /ram and base = seq and extension = .dat, the file would be named /ram/seq00000100.dat  
If the file is time based, the characters will be in the form YYYYDDDHMMSS. For example if the file was created on day 123 at 14:15:22 using path = /ram, base = tim and extension = .dat, the file would be named /ram/tim2010123141522.dat

The path, base and extension can be determined by looking in the File Table for the appropriate entry. Finally, the entire length of the filename must not exceed the length specified by the [OS\\_MAX\\_PATH\\_LEN](#) configuration parameter.

## 2 Core Flight Executive Documentation

- General Information and Concepts
  - [Background](#)
  - [Applicable Documents](#)
  - [Version Numbers](#)
  - [Dependencies](#)
  - [Acronyms](#)
  - [Glossary of Terms](#)
- Executive Services (ES)
  - [cFE Executive Services Overview](#)
  - [cFE Executive Services Commands](#)
  - [cFE Executive Services Telemetry](#)
  - [ES Event Message Reference](#)
  - [cFE Executive Services Configuration Parameters](#)
- Events Services (EVS)

- [cFE Event Services Overview](#)
- [cFE Event Services Commands](#)
- [cFE Event Services Telemetry](#)
- [EVS Event Message Reference](#)
- [cFE Event Services Configuration Parameters](#)
- Software Bus Services (SB)
  - [cFE Software Bus Overview](#)
  - [cFE Software Bus Commands](#)
  - [cFE Software Bus Telemetry](#)
  - [SB Event Message Reference](#)
  - [cFE Software Bus Configuration Parameters](#)
- Table Services (TBL)
  - [cFE Table Services Overview](#)
  - [cFE Table Services Commands](#)
  - [cFE Table Services Telemetry](#)
  - [TBL Event Message Reference](#)
  - [cFE Table Services Configuration Parameters](#)
- Time Services (TIME)
  - [cFE Time Services Overview](#)
  - [cFE Time Services Commands](#)
  - [cFE Time Services Telemetry](#)
  - [TIME Event Message Reference](#)
  - [cFE Time Services Configuration Parameters](#)
- [cFE Event Message Cross Reference](#)
- [cFE Command Mnemonic Cross Reference](#)
- [cFE Telemetry Mnemonic Cross Reference](#)
- [cFE Application Programmer's Interface \(API\) Reference](#)

## 2.1 Background

The Core Flight Executive (cFE) is an application development and run-time environment. The cFE provides a set of core services including Software Bus (messaging), Time, Event (Alerts), Executive (startup and runtime), and Table services. The cFE defines an application programming interface (API) for each service which serves as the basis for application development.

The cFE Software Bus service provides a publish and subscribe messaging system that allows applications to easily plug and play into the system. Applications subscribe to cFE services at runtime, making system modifications easy. Facilitating rapid prototyping, new applications can be compiled, linked, loaded, and started without requiring the entire system to be rebuilt.

Each service comes complete with a built in application that allows users to interface with each service. To support reuse and project independence, the cFE contains a configurable set of requirements and code. The configurable parameters allow the cFE to be tailored for each environment including desk-top and closed loop simulation environments. This provides the ability to run and test software applications on a developer's desktop and then deploy that same software without changes to the embedded system. In addition the cFE includes the following software development tools:

- Unit Test Framework (UTF) for unit testing applications developed via the cFE
- Software Timing Analyzer that provides visibility into the real-time performance of embedded systems software
- Table Builder
- Command and Telemetry utilities

The cFE is one of the components of the Core Flight System (cFS), a platform and project independent reusable software framework and set of reusable software applications. There are three key aspects to the cFS architecture: a dynamic run-time environment, layered software, and a component based design. The combination of these key aspects along with an implementation targeted to the embedded software domain makes it suitable for reuse on any number of NASA flight projects and/or embedded software systems.

The pivotal design feature, abstracting the software architecture from the hardware and forming the basis of reuse, is component layering. Each layer of the architecture "hides" its implementation and technology details from the other layers by defining and using standard Application Programming Interfaces (APIs). The internals of a layer can be changed without affecting other layers' internals and components.

The layers include an OS Abstraction Layer (OSAL), Platform Support Package (PSP) layer, core Flight Executive (cFE) layer, and an Application layer. The cFE layer runs on top of the PSP and OSAL layers. The cFE comes complete with a build environment, deployment guide, API reference guide, and provides a sample PSP. The OSAL is available open source and once integrated into the cFE build environment, developers will be ready to build and run the system and start developing their mission/project specific applications that easily plug and play into the system.

### Core Flight Executive (cFE) Goals

The main long term goal of the cFE is to form the basis for a platform and project independent reusable software framework. The cFE with the OSAL allow the development of portable embedded system software that is independent of a particular Real Time Operating System and hardware platform. A secondary long term goal is to create a standardized, product-line approach for development of embedded aerospace flight software.

### Functional and Community Goals

The cFE allows embedded system software to be developed and tested on desktop workstations and ported to the target platform without changing a single line of code, providing a shorter development and debug time. The cFE is an enabler of software collaboration amongst all users promoting the growth of the application and library layers where new applications, libraries, tools, and lessons learned can be contributed and shared.

It is important for application developers to realize the long term and functional goals of the cFE. With a standard set of services providing a standard API, all applications developed with the cFE have an opportunity to become useful on future missions through code reuse. In order to achieve this goal, applications must be written with care to ensure that their code does not have dependencies on specific hardware, software or compilers. The cFE and the underlying generic operating system API (OS API) have been designed to insulate the cFE Application developer from hardware and software dependencies. The developer, however, must make the effort to identify the proper methods through the cFE and OS API to satisfy their software requirements and not be tempted to take a "short-cut" and accomplish their goal with a direct hardware or operating system software interface.

## 2.2 Applicable Documents

Document Title	Link
cFE System (L4) Requirements Document	cfe/docs/'cfe requirements.docx'
cFE Functional (L5) Requirements Document	cfe/docs/cFE_FunctionalRequirements.csv
cFE Application Developers Guide	cfe/docs/'cFE Application Developers Guide.md'
cFE User's Guide (includes API)	Autogenerated from code, provided with releases in cFE repository
OS Abstraction Layer (OSAL) API	Autogenerated from code, provided with releases in OSAL repository

## 2.3 Version Numbers

### Version Number Semantics

The version number is a sequence of four numbers, generally separated by dots when written. These are, in order, the Major number, the Minor number, the Revision number, and the Mission Revision number.

It is important to note that version numbers are only updated upon official releases of tagged versions, **NOT** on development builds. We aim to follow the Semantic Versioning v2.0 specification with our versioning.

The MAJOR number is incremented on release to indicate when there is a change to an API that may cause existing, correctly-written cFS components to stop working. It may also be incremented for a release that contains changes deemed to be of similar impact, even if there are no actual changes to the API.

The MINOR number is incremented on release to indicate the addition of features to the API which do not break the existing code. It may also be incremented for a release that contains changes deemed to be of similar impact, even if there are no actual updates to the API.

The REVISION number shall be incremented on changes that benefit from unique identification such as bug fixes or major documentation updates. The Revision number may also be updated if there are other changes contained within a release that make it desirable for applications to distinguish one release from another. **WARNING:** The revision number is set to the number 99 in development builds. To distinguish between development builds refer to the BUILD\_NUMBER and BUILD\_BASELINE detailed in the section "Identifying Development Builds".

The Mission Rev Version number is set to zero in all official releases, and is reserved for the mission use.

### How and Where Defined

The version numbers are provided as simple macros defined in the [cfe\\_version.h](#) header file as part of the API definition; these macros must expand to simple integer values, so that they can be used in simple if directives by the macro preprocessor.

Note the Mission Rev number is provided for missions to be able to identify unique changes they have made to the released software (via clone and own). Specifically, the values 1-254 are reserved for mission use to denote patches/customizations while 0 and 0xFF are reserved for cFS open-source development use (pending resolution of nasa/cFS#440).

### Identifying Development Builds

In order to distinguish between development versions, we also provide a BUILD\_NUMBER.

The BUILD\_NUMBER reflects the number of commits since the BUILD\_BASELINE, a baseline git tag, for each particular component. The BUILD\_NUMBER integer monotonically increases for a given baseline. The BUILD\_BASELINE identifies the current development cycle and is a git tag with format vMAJOR.MINOR.REVISION. The Codename used in the version string also refers to the current development cycle. When a new baseline tag and codename are created, the BUILD\_NUMBER resets to zero and begins increasing from a new baseline.

### Templates for the short and long version string

See [cfe\\_version.h](#) for the standard layout and definition of version information. The apps and repositories follow the same pattern by replacing the CFE\_ prefix with the appropriate name; for example, osal uses OS\_, psp uses CFE\_P←SP\_IMPL, and so on.

Suggested pattern for development:

- CFSCOMPONENT\_SRC\_VERSION: REFERENCE\_GIT\_TAG"+dev"BUILD\_NUMBER
  - Example: "v6.8.0-rc1+dev123"
- CFSCOMPONENT\_VERSION\_STRING: "CFSCOMPONENT DEVELOPMENT BUILD "CFSCOMPONENT\_S←RC\_VERSION" (Codename: CFSCONSTELLATION), Last Official Release: MAJOR.MINOR.REVISION"
  - Example: "cFE DEVELOPMENT BUILD v6.8.0-rc1+dev123 (Codename: Bootes), Last Official Release: cfe v6.7.0"

Suggested pattern for official releases:

- CFSCOMPONENT\_SRC\_VERSION: OFFICIAL\_GIT\_TAG
  - Example: "v7.0.0"
- COMPONENT\_VERSION\_STRING: "CFSCOMPONENT OFFICIAL RELEASE "CFSCOMPONENT\_SRC\_VE←RSION" (Codename: CFSCONSTELLATION)"
  - Example: "cFE OFFICIAL RELEASE v7.0.0 (Codename: Caelum)"

## 2.4 Dependencies

The Core Flight Executive (cFE) is required to be built with the Operating System Abstraction Layer (OSAL) and Platform Support Package (PSP) components of the Core Flight System (cFS). It is always recommended to build with the latest versions of each of the components as backward compatibility may not be supported.

Several internal data structures within the cFE use the "char" data type. This data type is typically 1 byte in storage size with a value range -128 to 127 or 0 to 255. The size of the "char" data type and whether or not the type is signed or unsigned can change across platforms. The cFE assumes use of the "char" data type as an **8-bit type**.

## 2.5 Acronyms

<b>Acronym</b>	<b>Description</b>
AC	Attitude Control
ACE	Attitude Control Electronics
ACS	Attitude Control System
API	Application Programming Interface
APID	CCSDS Application ID
App	Application
CCSDS	Consultative Committee for Space Data Systems
CDH, C&DH	Command and Data Handling
cFE	core Flight Executive
cFS	core Flight System
CM	Configuration Management
CMD	Command
CPU	Central Processing Unit
EDAC	Error Detection and Correction
EEPROM	Electrically Erasable Programmable Read-Only Memory
ES	Executive Services
EVS	Event Services
FC	Function Code
FDC	Failure Detection and Correction
FSW	Flight Software
HW, H/W	Hardware
ICD	Interface Control Document
MET	Mission Elapsed Time
MID	Message ID
OS	Operating System
OSAL	Operating System Abstraction Layer
PID	Pipeline ID
PKT	Packet
PSP	Platform Support Package
RAM	Random-Access Memory
SB	Software Bus
SDO	Solar Dynamics Observatory
ST5	Space Technology Five
STCF	Spacecraft Time Correlation Factor
SW, S/W	Software
TAI	International Atomic Time
TBD	To Be Determined
TBL	Table Services
TID	Task ID
TIME	Time Services
TLM	Telemetry
UTC	Coordinated Universal Time

## 2.6 cFE Executive Services Overview

Executive Services (ES) is one of the five core Flight Executive components. ES is the primary interface to the underlying Operating System, providing a high level interface to system control facilities. The ES component is responsible for starting up and restarting the cFE, starting up, shutting down, and restarting cFE Applications, logging errors and performance data, and providing a persistent memory store for cFE Applications.

The interfaces to the ES task include the Ground Interface (commands and telemetry) and the Application Programmer Interfaces (APIs). The ES task interfaces to the OS through the OS Abstraction Layer (OSAL) and platform through the Platform Support Package (PSP).

The functionality provided by the ES task include Software Reset, Application and Child Task Management, Basic File System, Performance Data Collection, Critical Data Store, Memory Pool, System Log, Shell Command.

For additional detail on Executive Services, see the following sections:

- [Terminology](#)
- [Software Reset](#)
  - [Reset Types and Subtypes](#)
  - [Exception and Reset \(ER\) Log](#)
- [Application and Child Task Management](#)
  - [Starting an Application](#)
  - [Stopping an Application](#)
  - [Restarting an Application](#)
  - [Reloading an Application](#)
  - [Listing Current Applications](#)
  - [Listing Current Tasks](#)
  - [Loading Common Libraries](#)
- [Basic File System](#)
- [Performance Data Collection](#)
- [Critical Data Store](#)

- [Memory Pool](#)
- [System Log](#)
- [Version Identification](#)
- [Executive Services Frequently Asked Questions](#)

### 2.6.1 Terminology

The following sections describe terminology that is very relevant to understanding the Executive Services:

- ["Application" and "cFE Application"](#)
- ["Task"](#)
- ["Startup Script"](#)

Next: ["Application" and "cFE Application"](#)

Up To: [cFE Executive Services Overview](#)

#### 2.6.1.1 "Application" and "cFE Application"

##### **Application**

The term 'Application' as defined in the [Glossary of Terms](#) is *a set of data and functions that is treated as a single entity by the cFE. cFE resources are allocated on a per-Application basis. Applications are made up of a Main Task and zero or more Child Tasks.*

##### **cFE Application**

A 'cFE Application' is an application that is external to the cFE and designed to interface to the cFE through the APIs. It is created through an entry in the ["Startup Script"](#) (with the 'Object Type' field set to CFE\_APP) or by way of the [CFE\\_ES\\_START\\_APP\\_CC](#) ground command.

When referring to one of the five applications internal to the cFE (ES, EVS, SB, TIME or TBL), the term 'Service' or 'Core Application' is typically used.

A listing of cFE applications can be acquired by using the [CFE\\_ES\\_QUERY\\_ALL\\_CC](#) ground command. This listing will include the cFE internal applications as well as cFE applications that are loaded and running.

Next: ["Task"](#)

Up To: [Terminology](#)

### 2.6.1.2 "Task"

A Task is a thread of execution in the operating system, often associated with a cFE Application. Each cFE Application has a Main task providing its CPU context, stack and other OS resources. In addition, each cFE Application can create multiple Child Tasks which are closely associated with the Parent Task and cFE Application.

In a traditional Real Time Operating System such as vxWorks, the cFE Application Main task and child tasks end up being mapped to these OS tasks in the same shared memory space. For example, a Stored Command cFE Application that consists of a cFE Main Task and 10 Relative Time Sequence Child Tasks would have 11 tasks on a vxWorks system. The only association between these tasks exists in the cFE.

In a memory protected process oriented Operating System, the intention is to have a cFE Application implemented as a memory protected process with its own virtual address space. In this Process Model, each cFE Child Task would be a thread in the parent Process, much like a Unix process with multiple threads. In this model, the Stored Command example with a cFE Main Task and 10 Relative Time Sequence Child Tasks would consist of a Unix Process and 10 pthreads, all under the same virtual address space.

Next: ["Startup Script"](#)

Prev: ["Application" and "cFE Application"](#)

Up To: [Terminology](#)

### 2.6.1.3 "Startup Script"

The startup script is a text file, written by the user that contains a list of entries (one entry for each application) and is used by the ES application for automating the startup of applications. For a processor reset, ES checks for the CFE\_PLATFROM\_ES\_VOLATILE\_STARTUP\_FILE first, and if it doesn't exist or for a power on reset ES uses the file passed in to [CFE\\_ES\\_Main](#) (typically CFE\_PLATFORM\_ES\_NONVOL\_STARTUP\_FILE but dependent on the PSP).

The fields in a single entry include:

Object Type	CFE_APP for an Application, or CFE_LIB for a library.
Path/Filename	This is a cFE Virtual filename, not a vxWorks device pathname
Entry Point	This is the name of the "main" function for App.
CFE Name	The cFE name for the APP or Library
Priority	This is the Priority of the App, not used for a Library
Stack Size	This is the Stack size for the App, not used for a Library
Load Address	This is the Optional Load Address for the App or Library. It is currently not implemented so it should always be 0x0.
Exception Action	<p>This is the Action the cFE should take if the Application has an exception.</p> <ul style="list-style-type: none"> <li>• 0 = Do a cFE Processor Reset</li> <li>• Non-Zero = Just restart the Application</li> </ul>

Immediately after the cFE completes its initialization, the ES Application first looks for the volatile startup script. The location in the file system is defined by the cFE platform configuration parameter named [CFE\\_PLATFORM\\_ES\\_VOLATILE\\_STARTUP\\_FILE](#). This configuration parameter contains a path as well as a filename. If the file is found, ES begins to startup the applications that are listed in the file. If ES does not find the file, it attempts to open the [CFE\\_PLATFORM\\_ES\\_NONVOL\\_STARTUP\\_FILE](#).

If ES finds the volatile startup script, the attempt to open the nonvolatile startup script is bypassed.

Any errors encountered in the startup script processing are written to the [System Log](#). The [System Log](#) may also contain positive acknowledge messages regarding the startup script processing.

The startup script delivered with the cFE (`cfe_es_startup.scr`) also has some detailed information about the fields and the settings.

Next: [Software Reset](#)

Prev: [Starting an Application](#)

Up To: [Terminology](#)

### 2.6.2 Software Reset

The ES Software Reset provides a command to [reset the cFE](#) as well as [resetting individual applications](#). Because applications are dependent on the cFE services, it is not possible to reset the cFE without affecting the applications. Therefore, a command to reset the cFE will also reset every application that is running at the time the command is received.

Also include is the Exception and Reset (ER) Log, which has a command for [dumping](#) or [clearing](#) the log and telemetry to show the number of entries in the log. In addition to the ER log, the user may find information about the most recent reset in the ES task housekeeping telemetry.

The ES Software Reset also provides a command to [set the maximum number of processor resets](#) before ES issues a power-on reset. There is a corresponding 'processor resets' counter in ES housekeeping telemetry that may be [reset](#) through another ES command.

Next: [Reset Types and Subtypes](#)

Prev: [Terminology](#)

Up To: [cFE Executive Services Overview](#)

### 2.6.3 Reset Types and Subtypes

The Reset Type is sent to the ground in the ES housekeeping packet and tells how the current running version of the cFE was invoked. The possible Reset Types expected in the telemetry field are `CFE_PSP_RST_TYPE_POWERON` and `CFE_PSP_RST_TYPE_PROCESSOR`. There is a third Reset Type defined in the ES code as `CFE_ES_APP_RESTART` which applies only to restarting an individual application and is covered in more detail in the section titled Application and Child Task.

The Reset Subtype is also sent in the ES housekeeping packet and gives more detail about the type of reset that started the execution of the current running version of the cFE. The possible Reset Subtypes are `CFE_PSP_RST_SUBTYPE_POWER_CYCLE`, `CFE_PSP_RST_SUBTYPE_PUSH_BUTTON`, `CFE_PSP_RST_SUBTYPE_HW_SPECIFIC_COMMAND`, `CFE_PSP_RST_SUBTYPE_HW_WATCHDOG`, `CFE_PSP_RST_SUBTYPE_RESET_COMMAND`, `CFE_PSP_RST_SUBTYPE_EXCEPTION`, `CFE_PSP_RST_SUBTYPE_UNDEFINED_RESET`, `CFE_PSP_RST_SW_BTYPED_HWDBUG_RESET`, `CFE_PSP_RST_SUBTYPE_BANKSWITCH_RESET`.

Next: [Exception and Reset \(ER\) Log](#)

Prev: [Software Reset](#)

Up To: [cFE Executive Services Overview](#)

#### 2.6.4 Exception and Reset (ER) Log

The Exception and Reset Log contains detailed information about past resets and exceptions. To view the information the [CFE\\_ES\\_WRITE\\_ER\\_LOG\\_CC](#) command must be sent. This command will write the log to a binary file. The path and filename may be specified in the command. If the filename command field contains an empty string, the configuration parameter [CFE\\_PLATFORM\\_ES\\_DEFAULT\\_ER\\_LOG\\_FILE](#) is used to specify the path and filename. Use the ground system to get the file and display the contents. There is also a command to clear the ER log, [CFE\\_ES\\_CLEAR\\_ER\\_LOG\\_CC](#).

The size of the ER log is defined by the platform configuration parameter [CFE\\_PLATFORM\\_ES\\_ER\\_LOG\\_ENTRIES](#). This log is preserved after a processor reset and held in the ES reset area.

A count of the number of entries in the log is present in the ES housekeeping telemetry. This count can be used with the configuration parameter [CFE\\_PLATFORM\\_ES\\_ER\\_LOG\\_ENTRIES](#) to calculate the fullness of the log.

The information contained in a single log entry is defined by the structure [CFE\\_ES\\_ERLog\\_t](#).

Next: [Application and Child Task Management](#)

Prev: [Reset Types and Subtypes](#)

Up To: [cFE Executive Services Overview](#)

#### 2.6.5 Application and Child Task Management

The ES Application and Child Task Management provides the user with full control over starting and stopping applications as well as querying information regarding applications, tasks and library routines.

There is no command to start or stop a child task. Child tasks can be controlled (started, stopped or deleted) only by the parent application through an API call.

This provides a way for the user to load a set of library routines, (via the startup script) without starting a corresponding task. See the section related to library routines for more detail.

The ES task maintains a counter for the number of registered applications, number of registered child tasks and the number of registered libraries in the ES housekeeping data.

Next: [Starting an Application](#)

Prev: [Software Reset](#)

Up To: [cFE Executive Services Overview](#)

#### 2.6.6 Starting an Application

There are two ways to start an application, through the ground command [CFE\\_ES\\_START\\_APP\\_CC](#) or through the startup script. In either case, the object file must be loaded on board before the command is sent or before the startup script is executed. The startup script contains a list of applications and library routines to load and start immediately after the cFE finishes its startup sequence. The parameters in the command, match the elements of an entry in the startup script.

The format of the Start Application command, is defined in the structure [CFE\\_ES\\_StartAppCmd\\_t](#). The members of the structure include, application name, entry point, filename, stack size, load address, exception action and priority.

If the command fails for any reason, an error event will be sent stating the reason for the failure. There may be additional information in the system log that can be viewed by sending the ES command to dump the system log.

After starting an application, the ES task sends an informational event message displaying the application name, file-name of the object and the application ID. The new application will then show up in the query list downloaded in response to the [CFE\\_ES\\_QUERY\\_ALL\\_CC](#) command.

Next: [Stopping an Application](#)

Up To: [Application and Child Task Management](#)

### 2.6.7 Stopping an Application

Stopping an application can be done through the ground command [CFE\\_ES\\_STOP\\_APP\\_CC](#). This command will terminate the application execution and all child tasks created by the application, free the system resources that it allocated and delete the corresponding object file.

The process of stopping an application is done in a controlled manner when the application is properly using the return code from the call to the [CFE\\_ES\\_RunLoop](#). When the application properly uses this function, the ES task starts a timer and (via the return code) tells the application to exit at its own convenience. This gives the application time to free its own resources and do any cleanup that may be required before terminating itself by calling [CFE\\_ES\\_ExitApp](#). If the timer expires and the application still exists, then ES must 'kill' the application. When the application is killed, ES attempts to cleanup the applications resources as best it could. In this case there is no guarantee that all the system resources are properly released.

The format of the Stop Application command, is defined in the structure [CFE\\_ES\\_AppNameCmd\\_t](#). The only parameter in the command is an application name.

If the command fails for any reason, an error event will be sent stating the reason for the failure. There may be additional information in the system log that can be viewed by sending the ES command to dump the system log.

After stopping an application, the ES task sends a debug message stating the name of the application. After executing the command, the application (or any resources it allocated) should no longer be listed in any cFE tables or files.

Next: [Restarting an Application](#)

Prev: [Starting an Application](#)

Up To: [Application and Child Task Management](#)

### 2.6.8 Restarting an Application

The [CFE\\_ES\\_RESTART\\_APP\\_CC](#) command is used to restart an application using the same file name as the last start.

This command checks for file existence, the application is running, and the application is not a core app. If valid, the application restart is requested.

When requested, ES stops the application, unloads the object file, loads the object file using the previous file name, and restarts an application using the parameters defined when the application was previously started, either through the startup script or by way of the [CFE\\_ES\\_START\\_APP\\_CC](#) command.

Next: [Reloading an Application](#)

Prev: [Stopping an Application](#)

Up To: [Application and Child Task Management](#)

### 2.6.9 Reloading an Application

The [CFE\\_ES\\_RELOAD\\_APP\\_CC](#) command is used to reload an application using a new file name.

This command performs the same actions as [CFE\\_ES\\_RESTART\\_APP\\_CC](#) only using the new file.

Next: [Listing Current Applications](#)

Prev: [Restarting an Application](#)

Up To: [Application and Child Task Management](#)

### 2.6.10 Listing Current Applications

There are two options for receiving information about applications, the [CFE\\_ES\\_QUERY\\_ONE\\_CC](#) command can be used to get details about a single application. This command takes an application name as its only parameter and the application information is sent as a software bus packet that can be telemetered to the ground.

Or the [CFE\\_ES\\_QUERY\\_ALL\\_CC](#) command can be used to get information about all the applications that are currently registered with ES. This command writes the application data to a file and has one parameter which specifies the path and filename of the output file.

For either command, the following Application information is made available:

- **Application ID** - The Application ID assigned by the cFE to the Application
- **Type Identifier** - Identifies whether the Application is a CORE App or an EXTERNAL App
- **Name** - The Application Name
- **Entry Point** - The symbolic name for the entry point into the Application
- **Filename** - The name of the file the Application was loaded from
- **Stack Size** - The number of bytes allocated for the Application's stack
- **Load Address** - The starting address of memory where the Application was loaded
- **Load Size** - The size, in bytes, of the Application when loaded into memory
- **Start Address** - The physical address that maps to the Entry Point
- **Exception Action** - A flag that identifies whether the Processor should undergo a Restart or whether just the Application should restart upon an exception condition within the Application
- **Priority** - The assigned priority for the Application
- **Main Task ID** - The Task ID assigned to the main task associated with the Application
- **Main Task Name** - The name of the main task associated with the Application
- **Number of Child Tasks** - The number of child tasks spawned by the main task

For a description of the format in which this data is dumped, see [CFE\\_ES\\_AppInfo\\_t](#).

Next: [Listing Current Tasks](#)

Prev: [Reloading an Application](#)

Up To: [Application and Child Task Management](#)

### 2.6.11 Listing Current Tasks

The `CFE_ES_QUERY_ALL_TASKS_CC` command is used to get a list of child tasks that are currently registered with ES. The following information is provided for each registered task:

- **Task ID** - The Task ID associated with the specified task
- **Task Name** - The name of the Task
- **Application ID** - The ID for the Application the Task is associated with
- **Application Name** - The name of the Application the Task is associated with

Next: [Loading Common Libraries](#)

Prev: [Listing Current Applications](#)

Up To: [Application and Child Task Management](#)

### 2.6.12 Loading Common Libraries

Library routines may be loaded only through the startup script. There is an option that allows a library routine initialization function to be executed after the library is loaded. Refer to the cFE Application Developers Guide for more information regarding Library Routines and startup scripts. The startup script delivered with the cFE (`cfe_es_startup.scr`) also has some detailed information about library routines.

Next: [Basic File System](#)

Prev: [Listing Current Tasks](#)

Up To: [Application and Child Task Management](#)

### 2.6.13 Basic File System

ES provides minimal functionality to initialize, read, and write cfe File headers.

Next: [Performance Data Collection](#)

Prev: [Loading Common Libraries](#)

Up To: [Application and Child Task Management](#)

### 2.6.14 Performance Data Collection

The Performance Data Collection provides precise timing information for each software application similar to how a logic analyzer can trigger and filter data.

API calls are inserted by the development team at key points in the code. The basic operation is to start the data collection, wait some amount of time, then send the command to stop the data collection. When the stop command is received, the ES task writes all the data from the buffer to a file. The file can then be imported to analysis tools for viewing. The size of the buffer is configurable through the `CFE_PLATFORM_ES_PERF_DATA_BUFFER_SIZE` platform configuration parameter.

Additional information follows:

- [Performance Data Collection Trigger Masks](#)
- [Starting to Collect Performance Data](#)
- [Stopping the Collection of Performance Data](#)
- [Viewing the Collection of Performance Data](#)

Next: [Performance Data Collection Trigger Masks](#)

Prev: [Basic File System](#)

Up To: [cFE Executive Services Overview](#)

#### 2.6.14.1 Performance Data Collection Trigger Masks

The trigger mask is used to control precisely when to start collecting the data. There is a bit in the trigger mask for every marker used in the code. After a start command is received, the trigger mask is read and dictates when to begin storing data in the buffer.

If the trigger mask is set to all zeros, then the collection will begin immediately after the start command and continue until a stop command is received. In this case the buffer behaves in a 'circular' manner.

Next: [Starting to Collect Performance Data](#)

Prev: [Performance Data Collection](#)

Up To: [Performance Data Collection](#)

#### 2.6.14.2 Starting to Collect Performance Data

The `CFE_ES_START_PERF_DATA_CC` command is used to start the data collection process. The ES task sends a debug event when the command is received. It is not possible to start a collection if the buffer-to-file write is in progress from an earlier collection. There is an ES telemetry point that can be used to ensure there is not a buffer-to-file write in progress. This ES telemetry point is called 'Perf Data to Write' and begins counting down from 'Data Count' to zero. If this counter is zero, it is ok to send the start command. If any errors are encountered when the start command is received, the details will be displayed in an error event message.

Next: [Stopping the Collection of Performance Data](#)

Prev: [Performance Data Collection Trigger Masks](#)

Up To: [Performance Data Collection](#)

#### 2.6.14.3 Stopping the Collection of Performance Data

The [CFE\\_ES\\_STOP\\_PERF\\_DATA\\_CC](#) command is used to stop the data collection process and write the buffer data to a file. The path and filename may be specified in the command. If the filename command field contains an empty string, the configuration parameter [CFE\\_PLATFORM\\_ES\\_DEFAULT\\_PERF\\_DUMP\\_FILENAME](#) is used to specify the path and filename. The number of entries written to the file is determined by the 'data count' variable, which is sent in the ES housekeeping telemetry packet. To ensure cpu hogging does not occur during the write process, ES creates a low priority child task to perform the file write operation. This child task will write a number of entries, then sleep for a short time to give tasks of lower priority a chance to run. The number of entries between delays, and the delay time is displayed in the debug event at the time the stop command is received.

Next: [Viewing the Collection of Performance Data](#)

Prev: [Starting to Collect Performance Data](#)

Up To: [Performance Data Collection](#)

#### 2.6.14.4 Viewing the Collection of Performance Data

To view the performance data, the file created as a result of the stop command must be transferred to the ground and imported into a viewing tool. See <https://github.com/nasa/perfutils-java> as an example.

Next: [Critical Data Store](#)

Prev: [Stopping the Collection of Performance Data](#)

Up To: [Performance Data Collection](#)

### 2.6.15 Critical Data Store

Some missions are required, for health, safety and mission success criteria, to survive Processor Resets. These mission requirements frequently flow down to Attitude Control and/or Command and Data Handling requirements that force an Application developer to design a mechanism for retaining software state information through a Processor Reset. The cFE provides the Critical Data Store to assist the developer in meeting these requirements.

The Critical Data Store is an area of memory that is not cleared during a Processor Reset. In addition, the contents of memory are validated when accessed with a Data Integrity Value that helps to ensure the contents have not been corrupted. Each processor platform, through the design of its Board Support Package, can implement this area of memory in a number of ways to ensure the contents survive a Processor Reset. Applications can allocate a section of this memory for their use in a way similar to the [cFE Table Services Overview](#).

When an Application registers a Critical Data Store (CDS), the Executive Services allocates a section of the Critical Data Store memory for the application's use and assigns the Application specified name to the memory area. The operator can find and learn the characteristics of these Critical Data Stores by using the [Dump CDS Registry Command](#). This command will dump the contents of the CDS Registry maintained by the Executive Services into a file that can be downlinked and examined by the operator.

The CDS Registry dump will identify the following information for each registered CDS:

- **Handle** - the numeric identifier used by an Application to access the contents of the CDS
- **Size** - the number of bytes allocated to the specified CDS

- **Table Flag** - a flag that indicates whether the CDS is associated with a [Critical Tables](#) (when non-zero) or not (when equal to zero).
- **Name** - a processor specific name that uniquely identifies the CDS. The name comes in two parts, "AppName . ← CDSName". AppName identifies which Application registered the CDS. CDSName is the name the Application assigned to the CDS.

The format of the CDS Registry Dump File is a cFE Standard File header (see [CFE\\_FS\\_Header\\_t](#)) followed by one or more CDS Registry Dump File Records (see [CFE\\_ES\\_CDSRegDumpRec\\_t](#)).

Next: [Memory Pool](#)

Prev: [Performance Data Collection](#)

Up To: [cFE Executive Services Overview](#)

#### 2.6.16 Memory Pool

Refer to the cFE Application Developers Guide for additional information.

Applications that are designed for generic missions, frequently have to wait until run-time before allocating memory for buffers, data records, etc.

The cFE provides a memory allocation algorithm that may be used by an application to manage its block of memory. The user provides a pointer to its memory block and a list of block sizes and the cFE provides 'get' and 'put' API's to the user for managing its memory pool.

Run-time memory allocation in an embedded system can be risky because of the potential problem of memory fragmentation. Memory fragmentation is also referred to as External Fragmentation and is defined in the wikipedia as:

External fragmentation is the phenomenon in which free storage becomes divided into many small pieces over time. It is a weakness of certain storage allocation algorithms, occurring when an application allocates and deallocates ("frees") regions of storage of varying sizes, and the allocation algorithm responds by leaving the allocated and deallocated regions interspersed. The result is that, although free storage is available, it is effectively unusable because it is divided into pieces that are too small to satisfy the demands of the application. The term "external" refers to the fact that the unusable storage is outside the allocated regions.

To help prevent this from happening, the cFE has integrated a memory allocation algorithm that is designed to create blocks at run-time, based on the size of the blocks requested. After a reset, there are no blocks created, the memory pool is said to be unconfigured. As requests for memory blocks are made, the memory pool first tries to use blocks that have been created but are no longer in use. If it cannot find an available block, it will create a new one. The created blocks remain until a reset occurs.

This algorithm is recommended when the size of the requests and the peak rate of requests can be pre-determined. It is highly recommended that adequate margin is designed into the pool size. The memory pool should never get close to being fully configured (i.e. not enough memory to create a new block). If the memory does become fully configured, requests for new size blocks will fail, regardless of whether the created blocks are in-use or not. The margin on the memory pool can be monitored by viewing the 'free bytes' member of the memory pool statistics. The memory pool statistics are dumped only when commanded by way of the ES command [CFE\\_ES\\_SEND\\_MEM\\_POOL\\_STATS\\_CC](#).

A user of the ES memory pool begins by tailoring the memory pool for the particular use, by defining a list of block sizes and allocating a block of memory. These block size definitions simply give the memory pool a set of sizes to choose

from. They do not configure the memory pool in any way and they do not affect the size of the pool. The cFE defines a default set of block sizes in the `cfe_platform_cfg.h` file.

If the default block sizes are used, the application will create the pool using the simpler [CFE\\_ES\\_PoolCreate](#) API. This API takes a pointer to the first byte of the memory pool (allocated by the application) and a size parameter. The API returns a handle to be used for the get and put requests.

If the defaults are not sufficient, the user must define the block sizes and use the [CFE\\_ES\\_PoolCreateEx](#) API.

After receiving a positive response from the PoolCreate API, the memory pool is ready to accept requests, but at this point it is completely unconfigured (meaning there are no blocks created). The first valid request (via [CFE\\_ES\\_GetPoolBuf](#) API) after creating the pool will always cause the memory pool to create a block and return a pointer to the new block. The size of the block depends on the size definitions mentioned earlier. If there is not an exact match between the requested and defined sizes, then the memory pool will create and return the smallest block that meets the following criteria: is a defined size and large enough to hold the request.

If another request for that size comes in before the first block was released through the [CFE\\_ES\\_PutPoolBuf](#) API, then the memory pool will create a second block of that size and return a pointer to the second block. If both blocks were then released through the [CFE\\_ES\\_PutPoolBuf](#) API and the memory pool statistics were dumped via the [CFE\\_ES\\_SEND\\_MEM\\_POOL\\_STATS\\_CC](#) command, the number of blocks created would be two. The number of 'free bytes' in the pool would be the size of the pool minus the sum of the following items:

- the size of the two blocks created (even though they are not 'in-use').
- a buffer descriptor for each of the two blocks created ( $2 * 12$  bytes)
- a 168 byte pool descriptor Refer to the cFE Applications Developers Guide for more details.

This allocation algorithm does have its limits. There are certain conditions that can place the memory pool in an undesired state. For instance, if a burst of get requests were received for the same block size, the memory pool may create a large number of blocks of that size. If this is a one-time burst, the memory pool would be configured with this large number of blocks that may no longer be needed. This scenario would use up the 'free bytes' margin in an undesired way. It should be noted that once the blocks are created, they cannot be deleted by any means other than a processor or power-on reset. It is highly recommended that the memory pool statistics be carefully monitored to ensure that the 'free-bytes' margin is sufficient (which is typically dictated by mission requirements).

An operator can obtain information about an Application's Memory Pool by using the [Telemeter Memory Pool Statistics Command](#).

This command will cause Executive Services to extract pertinent statistics from the data used to manage the Memory Pool and telemeter them to the ground in the [Memory Pool Statistics Telemetry Packet](#).

In order to obtain the statistics associated with a memory pool, the operator **MUST** have the correct Memory Handle as reported by the Application who owns the Memory Pool. **It should be noted that an inappropriate Memory Pool Handle can (and likely will) cause the system software to crash!** Within the cFE itself, there are three cFE Core Applications that make use of the Executive Services Memory Pool API. These are Software Bus (SB), Event Services (EVS) and Table Services (TBL). Each of these cFE Core Applications report their memory pool handles in telemetry.

The [Memory Pool Statistics Telemetry Packet](#) contains the following information:

- **Memory Pool Handle** - the handle, as provided by the operator in the [Telemeter Memory Pool Statistics Command](#). This repeating of the handle in telemetry ensures the operator knows which Memory Pool Statistics are being viewed

- **Pool Size** - The total size of the memory pool (in bytes)
- **Number Blocks Requested** - The total number of memory blocks requested for allocation
- **Number of Errors** - The total number of errors encountered when a block was released
- **Number of Free Bytes** - The total number of bytes in the Memory Pool that have never been allocated to a Memory Block
- **Block Statistics** - For each specified size of memory block (of which there are [CFE\\_MISSION\\_ES\\_POOL\\_MAX\\_BUCKETS](#)), the following statistics are kept
  - **Block Size** - The size, in bytes, of all blocks of this type
  - **Number of Blocks Allocated** - The number of this sized block which are currently allocated and in use
  - **Number of Blocks Free** - The number of this size block which have been in use previously but are no longer being used

Next: [System Log](#)

Prev: [Critical Data Store](#)

Up To: [cFE Executive Services Overview](#)

#### 2.6.17 System Log

The System Log is an array of bytes that contains back-to-back printf type messages from applications. The cFE internal applications use this log when errors are encountered during initialization before the Event Manager is fully initialized. To view the information the [CFE\\_ES\\_WRITE\\_SYSLOG\\_CC](#) command must be sent. This command will write the log to a binary file. The path and filename may be specified in the command. If the filename command field contains an empty string, the configuration parameter [CFE\\_PLATFORM\\_ES\\_DEFAULT\\_SYSLOG\\_FILE](#) is used to specify the path and filename. Use the ground system to get the file and display the contents. The [CFE\\_ES\\_CLEAR\\_SYSLOG\\_CC](#) is used to clear the System log.

The size of the System log is defined by the platform configuration parameter [CFE\\_PLATFORM\\_ES\\_SYSTEM\\_LOG\\_SIZE](#). This log is preserved after a processor reset and held in the ES reset area.

A count of the number of entries in the log is present in the ES housekeeping telemetry.

Next: [Version Identification](#)

Prev: [Memory Pool](#)

Up To: [cFE Executive Services Overview](#)

#### 2.6.18 Version Identification

Version information is reported at startup, and upon receipt of a No-op command

Next: [Executive Services Frequently Asked Questions](#)

Prev: [System Log](#)

Up To: [cFE Executive Services Overview](#)

### 2.6.19 Executive Services Frequently Asked Questions

Prev: [Version Identification](#)

Up To: [cFE Executive Services Overview](#)

## 2.7 cFE Executive Services Commands

Upon receipt of any command, the Executive Services application will confirm that the message length embedded within the header (from `CFE_MSG_GetSize()`) matches the expected length of that message, based on the size of the C structure defining that command. If there is any discrepancy between the expected and actual message size, ES will generate the `CFE_ES_LEN_ERR_EID` event, increment the command error counter (`$sc_$cpu_ES_CMDEC`), and the command will *not* be accepted for processing.

The following is a list of commands that are processed by the cFE Executive Services Task.

#### **Global `CFE_ES_CLEAR_ER_LOG_CC`**

Clears the contents of the Exception and Reset Log

#### **Global `CFE_ES_CLEAR_SYSLOG_CC`**

Clear Executive Services System Log

#### **Global `CFE_ES_DELETE_CDS_CC`**

Delete Critical Data Store

#### **Global `CFE_ES_DUMP_CDS_REGISTRY_CC`**

Dump Critical Data Store Registry to a File

#### **Global `CFE_ES_NOOP_CC`**

Executive Services No-Op

#### **Global `CFE_ES_OVER_WRITE_SYSLOG_CC`**

Set Executive Services System Log Mode to Discard/Overwrite

#### **Global `CFE_ES_QUERY_ALL_CC`**

Writes all Executive Services Information on all loaded modules to a File

#### **Global `CFE_ES_QUERY_ALL_TASKS_CC`**

Writes a list of All Executive Services Tasks to a File

#### **Global `CFE_ES_QUERY_ONE_CC`**

Request Executive Services Information on a specified module

#### **Global `CFE_ES_RELOAD_APP_CC`**

Stops, Unloads, Loads from the command specified File and Restarts an Application

#### **Global `CFE_ES_RESET_COUNTERS_CC`**

Executive Services Reset Counters

#### **Global `CFE_ES_RESET_PR_COUNT_CC`**

Resets the Processor Reset Counter to Zero

#### **Global `CFE_ES_RESTART_APP_CC`**

Stops, Unloads, Loads using the previous File name, and Restarts an Application

#### **Global `CFE_ES_RESTART_CC`**

Executive Services Processor / Power-On Reset

**Global CFE\_ES\_SEND\_MEM\_POOL\_STATS\_CC**

Telemeter Memory Pool Statistics

**Global CFE\_ES\_SET\_MAX\_PR\_COUNT\_CC**

Configure the Maximum Number of Processor Resets before a Power-On Reset

**Global CFE\_ES\_SET\_PERF\_FILTER\_MASK\_CC**

Set Performance Analyzer's Filter Masks

**Global CFE\_ES\_SET\_PERF\_TRIGGER\_MASK\_CC**

Set Performance Analyzer's Trigger Masks

**Global CFE\_ES\_START\_APP\_CC**

Load and Start an Application

**Global CFE\_ES\_START\_PERF\_DATA\_CC**

Start Performance Analyzer

**Global CFE\_ES\_STOP\_APP\_CC**

Stop and Unload Application

**Global CFE\_ES\_STOP\_PERF\_DATA\_CC**

Stop Performance Analyzer and write data file

**Global CFE\_ES\_WRITE\_ER\_LOG\_CC**

Writes Exception and Reset Log to a File

**Global CFE\_ES\_WRITE\_SYSLOG\_CC**

Writes contents of Executive Services System Log to a File

## 2.8 cFE Executive Services Telemetry

The following are telemetry packets generated by the cFE Executive Services Task.

**Global CFE\_ES\_HousekeepingTlm\_Payload\_t**

Executive Services Housekeeping Packet

**Global CFE\_ES\_HousekeepingTlm\_Payload\_t**

Executive Services Housekeeping Packet

**Global CFE\_ES\_OneAppTlm\_Payload\_t**

Single Application Information Packet

**Global CFE\_ES\_OneAppTlm\_Payload\_t**

Single Application Information Packet

**Global CFE\_ES\_PoolStatsTlm\_Payload\_t**

Memory Pool Statistics Packet

**Global CFE\_ES\_PoolStatsTlm\_Payload\_t**

Memory Pool Statistics Packet

## 2.9 cFE Executive Services Configuration Parameters

The following are configuration parameters used to configure the cFE Executive Services either for each platform or for a mission as a whole.

### **Global CFE\_MISSION\_ES\_CDS\_MAX\_FULL\_NAME\_LEN**

Maximum Length of Full CDS Name in messages

### **Global CFE\_MISSION\_ES\_CDS\_MAX\_NAME\_LENGTH**

Maximum Length of CDS Name

### **Global CFE\_MISSION\_ES\_DEFAULT\_CRC**

Mission Default CRC algorithm

### **Global CFE\_MISSION\_ES\_MAX\_APPLICATIONS**

Mission Max Apps in a message

### **Global CFE\_MISSION\_ES\_PERF\_MAX\_IDS**

Define Max Number of Performance IDs for messages

### **Global CFE\_MISSION\_ES\_POOL\_MAX\_BUCKETS**

Maximum number of block sizes in pool structures

### **Global CFE\_PLATFORM\_CORE\_MAX\_STARTUP\_MSEC**

CFE core application startup timeout

### **Global CFE\_PLATFORM\_ES\_APP\_KILL\_TIMEOUT**

Define ES Application Kill Timeout

### **Global CFE\_PLATFORM\_ES\_APP\_SCAN\_RATE**

Define ES Application Control Scan Rate

### **Global CFE\_PLATFORM\_ES\_CDS\_MAX\_NUM\_ENTRIES**

Define Maximum Number of Registered CDS Blocks

### **Global CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_01**

Define ES Critical Data Store Memory Pool Block Sizes

### **Global CFE\_PLATFORM\_ES\_CDS\_SIZE**

Define Critical Data Store Size

### **Global CFE\_PLATFORM\_ES\_DEFAULT\_APP\_LOG\_FILE**

Default Application Information Filename

### **Global CFE\_PLATFORM\_ES\_DEFAULT\_CDS\_REG\_DUMP\_FILE**

Default Critical Data Store Registry Filename

### **Global CFE\_PLATFORM\_ES\_DEFAULT\_ER\_LOG\_FILE**

Default Exception and Reset (ER) Log Filename

### **Global CFE\_PLATFORM\_ES\_DEFAULT\_PERF\_DUMP\_FILENAME**

Default Performance Data Filename

### **Global CFE\_PLATFORM\_ES\_DEFAULT\_POR\_SYSLOG\_MODE**

Define Default System Log Mode following Power On Reset

### **Global CFE\_PLATFORM\_ES\_DEFAULT\_PR\_SYSLOG\_MODE**

Define Default System Log Mode following Processor Reset

**Global CFE\_PLATFORM\_ES\_DEFAULT\_STACK\_SIZE**

Define Default Stack Size for an Application

**Global CFE\_PLATFORM\_ES\_DEFAULT\_SYSLOG\_FILE**

Default System Log Filename

**Global CFE\_PLATFORM\_ES\_DEFAULT\_TASK\_LOG\_FILE**

Default Application Information Filename

**Global CFE\_PLATFORM\_ES\_ER\_LOG\_ENTRIES**

Define Max Number of ER (Exception and Reset) log entries

**Global CFE\_PLATFORM\_ES\_ER\_LOG\_MAX\_CONTEXT\_SIZE**

Maximum size of CPU Context in ES Error Log

**Global CFE\_PLATFORM\_ES\_MAX\_APPLICATIONS**

Define Max Number of Applications

**Global CFE\_PLATFORM\_ES\_MAX\_GEN\_COUNTERS**

Define Max Number of Generic Counters

**Global CFE\_PLATFORM\_ES\_MAX\_LIBRARIES**

Define Max Number of Shared libraries

**Global CFE\_PLATFORM\_ES\_MAX\_MEMORY\_POOLS**

Maximum number of memory pools

**Global CFE\_PLATFORM\_ES\_MAX\_PROCESSOR\_RESETS**

Define Number of Processor Resets Before a Power On Reset

**Global CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_01**

Define Default ES Memory Pool Block Sizes

**Global CFE\_PLATFORM\_ES\_MEMPOOL\_ALIGN\_SIZE\_MIN**

Define Memory Pool Alignment Size

**Global CFE\_PLATFORM\_ES\_NONVOL\_DISK\_MOUNT\_STRING**

Default virtual path for persistent storage

**Global CFE\_PLATFORM\_ES\_NONVOL\_STARTUP\_FILE**

ES Nonvolatile Startup Filename

**Global CFE\_PLATFORM\_ES\_OBJECT\_TABLE\_SIZE**

Define Number of entries in the ES Object table

**Global CFE\_PLATFORM\_ES\_PERF\_CHILD\_MS\_DELAY**

Define Performance Analyzer Child Task Delay

**Global CFE\_PLATFORM\_ES\_PERF\_CHILD\_PRIORITY**

Define Performance Analyzer Child Task Priority

**Global CFE\_PLATFORM\_ES\_PERF\_CHILD\_STACK\_SIZE**

Define Performance Analyzer Child Task Stack Size

**Global CFE\_PLATFORM\_ES\_PERF\_DATA\_BUFFER\_SIZE**

Define Max Size of Performance Data Buffer

**Global CFE\_PLATFORM\_ES\_PERF\_ENTRIES\_BTWN\_DLYS**

Define Performance Analyzer Child Task Number of Entries Between Delay

**Global CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_ALL**

Define Filter Mask Setting for Enabling All Performance Entries

**Global CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_INIT**

Define Default Filter Mask Setting for Performance Data Buffer

**Global CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_NONE**

Define Filter Mask Setting for Disabling All Performance Entries

**Global CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_ALL**

Define Filter Trigger Setting for Enabling All Performance Entries

**Global CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_INIT**

Define Default Filter Trigger Setting for Performance Data Buffer

**Global CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_NONE**

Define Default Filter Trigger Setting for Disabling All Performance Entries

**Global CFE\_PLATFORM\_ES\_POOL\_MAX\_BUCKETS**

Maximum number of block sizes in pool structures

**Global CFE\_PLATFORM\_ES\_RAM\_DISK\_MOUNT\_STRING**

Default virtual path for volatile storage

**Global CFE\_PLATFORM\_ES\_RAM\_DISK\_NUM\_SECTORS**

ES Ram Disk Number of Sectors

**Global CFE\_PLATFORM\_ES\_RAM\_DISK\_PERCENT\_RESERVED**

Percentage of Ram Disk Reserved for Decompressing Apps

**Global CFE\_PLATFORM\_ES\_RAM\_DISK\_SECTOR\_SIZE**

ES Ram Disk Sector Size

**Global CFE\_PLATFORM\_ES\_RESET\_AREA\_SIZE**

Define ES Reset Area Size

**Global CFE\_PLATFORM\_ES\_START\_TASK\_PRIORITY**

Define ES Task Priority

**Global CFE\_PLATFORM\_ES\_START\_TASK\_STACK\_SIZE**

Define ES Task Stack Size

**Global CFE\_PLATFORM\_ES\_STARTUP\_SCRIPT\_TIMEOUT\_MSEC**

Startup script timeout

**Global CFE\_PLATFORM\_ES\_STARTUP\_SYNC\_POLL\_MSEC**

Poll timer for startup sync delay

**Global CFE\_PLATFORM\_ES\_SYSTEM\_LOG\_SIZE**

Define Size of the cFE System Log.

**Global CFE\_PLATFORM\_ES\_USER\_RESERVED\_SIZE**

Define User Reserved Memory Size

**Global CFE\_PLATFORM\_ES\_VOLATILE\_STARTUP\_FILE**

ES Volatile Startup Filename

**Global CFE\_PLATFORM\_EVS\_START\_TASK\_PRIORITY**

Define EVS Task Priority

**Global CFE\_PLATFORM\_EVS\_START\_TASK\_STACK\_SIZE**

Define EVS Task Stack Size

**Global CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_01**

Define SB Memory Pool Block Sizes

**Global CFE\_PLATFORM\_SB\_START\_TASK\_PRIORITY**

Define SB Task Priority

**Global CFE\_PLATFORM\_SB\_START\_TASK\_STACK\_SIZE**

Define SB Task Stack Size

**Global CFE\_PLATFORM\_TBL\_START\_TASK\_PRIORITY**

Define TBL Task Priority

**Global CFE\_PLATFORM\_TBL\_START\_TASK\_STACK\_SIZE**

Define TBL Task Stack Size

## 2.10 cFE Event Services Overview

Event Services (EVS) provides centralized control for the processing of event messages originating from the EVS task itself, other cFE core applications (ES, SB, TIME, and TBL), and from cFE applications. Event messages are asynchronous messages that are used to inform the operator of a significant event from within the context of a registered application or core service. EVS provides various ways to filter event messages in order to manage event message generation.

Note for messages outside the context of a registered application (for example early in app initialization or if registration fails) [CFE\\_ES\\_WriteToSysLog](#) can be used for reporting.

For more information on cFE Event Services, see the following sections:

- [Event Message Format](#)
- [Local Event Log](#)
- [Event Message Control](#)
- [Event Message Filtering](#)
- [EVS Registry](#)
- [EVS Counters](#)
- [Resetting EVS Counters](#)
- [Effects of a Processor Reset on EVS](#)
- [EVS squelching of misbehaving apps](#)
- [Frequently Asked Questions about Event Services](#)

### 2.10.1 Event Message Format

Event messages are software bus messages that contain the following fields:

- Timestamp
- Event Type
- Spacecraft ID
- Processor ID
- Application Name
- Event ID
- Message

The *Timestamp* corresponds to when the event was generated, in spacecraft time. The *Event Type* is one of the following: DEBUG, INFO, ERROR or CRITICAL. The *Spacecraft ID* and *Processor ID* identify the spacecraft and processor from which the event was generated. Note that the *Spacecraft ID* is defined in the cfe\_mission\_cfg.h file; The *Processor ID* is defined in the appropriate cfe\_platform\_cfg.h file. The *Application Name* refers to the Application that issued the event message as specified on application startup (either startup script or app start command). The *Event ID* is an Application unique number that identifies the event. The *Message* is an ASCII text string describing the event. Event messages may have parameters associated with the event message. EVS formats the parameters such that they are part of the ASCII text string that make up the event message.

In order to accommodate missions that have limited telemetry bandwidth, EVS can be configured such that the ASCII text string part of the event message is omitted, thus reducing the size of each event message. This is referred to as *Short Format*; Event messages including the ASCII text string are referred to as *Long Format*. The default setting is specified in the cfe\_platform\_cfg.h file. EVS also provides commands in order to set the mode (short or long).

Since the design of the cFE's Software Bus is based on run-time registration, no predetermined message routing is defined, hence it is not truly correct to say that events are generated as telemetry. Technically, EVS generates events in the form of software bus messages. Applications such as Telemetry Output and Data Storage can then subscribe to these messages making them telemetry. For the purposes of this document, any references to telemetry assumes that a telemetry application subscribes to the EVS event software bus message and routes it to the ground as telemetry. Note that short format event messages on the Software Bus have different message lengths than long form messages and do not include any part of the long format message string.

The EVS can be configured via ground command to send event messages out one or more message ports. These message ports may include ports such as debug, console, and UART. Messages sent out of the message ports will be in ASCII text format. This is generally used for lab purposes. Note that the event mode (short or long) does affect the event message content sent out these message ports.

Next: [Local Event Log](#)

Up To: [cFE Event Services Overview](#)

### 2.10.2 Local Event Log

In addition to generating a software bus message, EVS logs the event message to a Local Event Log. Note that this is an optional feature that must be enabled via the `cfe_platform_cfg.h` file. The Local Event Log resides on the same processor as the EVS which is used to store events without relying on an external bus. In multi-processor cFE configurations the Local Event Buffer preserves event messages during non-deterministic processor initialization sequences and during failure scenarios. In order to obtain the contents of the Local Event Log, a command must be sent to write the contents of the buffer to a file which can then be sent to the ground via a file transfer mechanism. Note that event messages stored in the EVS Local Event Log are always long format messages and are not affected by the event mode (short or long).

EVS provides a command in order to [clear the Local Event Log](#).

#### Local Event Log Mode

EVS can be configured to control the Local Event Log to either discard or overwrite the contents of the log when it becomes full. If the mode is set to overwrite, the log is treated like a circular buffer, overwriting the oldest event message contained in the log first. This control is configured by default in the `cfe_platform_cfg.h` file but can be modified by [a command](#).

Next: [Event Message Control](#)

Prev: [Event Message Format](#)

Up To: [cFE Event Services Overview](#)

### 2.10.3 Event Message Control

In order for an application to be serviced by EVS, it must be registered with EVS. EVS provides various commands in order to control the event messages that are generated as software bus messages.

#### Event Message Control - By Type

The highest level of event message control that EVS provides is the ability to enable and disable event message types. As mentioned above, there are four event types. They are:

1. DEBUG

2. INFORMATION

3. ERROR

4. CRITICAL

When commands are sent to `enable` or `disable` a particular type of event message, ALL event messages of the specified type are affected. Typically, event messages of type DEBUG are disabled on-orbit. Note that EVS provides the capability to affect multiple types within one command using a bit mask. Note also that the configuration parameter `CFE_PLATFORM_EVS_DEFAULT_TYPE_FLAG` in the `cfe_platform_cfg.h` file specifies which event message types are enabled/disabled by default.

### Event Message Control - By Application

Commands are available to [enable](#) and [disable](#) the generation of event messages for a particular application. The result is that ALL event messages for the specified Application are affected (i.e. enabled or disabled).

### Event Message Control - By Event Type for an Application

EVS also provides the capability to [enable](#) / [disable](#) an event type for a particular application. Note that EVS provides the capability to affect multiple event types within one command using a bit mask.

### Event Message Control - Individual Events

There are two ways to control the generation of individual events depending on whether the application's event message has been registered with EVS or not.

#### Modifying a registered event message filter

When an application registers with EVS, the application has the option of specifying the events that it wants to register for filtering along with the [Event Message Filtering](#) (only the Binary Filtering Scheme exists currently). Note that applications are limited in the number of events that they can register for filtering (see [CFE\\_PLATFORM\\_EVS\\_MAX\\_EVENT\\_FILTERERS](#) in `cfe_platform_cfg.h` for the mission defined limit). The filtering method uses a mask to determine if the message is forwarded to the software bus, making it available in telemetry (see [Event Message Filtering](#) for a description on filtering). Commands are available to [modify the filter mask](#) for any registered event.

An on-orbit mission, for example, might be experiencing a problem resulting in an application's event message being repeatedly issued, flooding the downlink. If the event message for the application is registered with EVS, then a command can be issued to set the event message filter to the specified value in order to prevent flooding of the downlink.

#### Adding/Removing an event message for filtering

Commands are also available to add filtering for those events that are not registered for filtering. Once an event is [registered for filtering](#), the filter can be modified (see above) or [removed](#).

An on-orbit mission, for example, might be experiencing a problem resulting in an event message being repeatedly issued, flooding the downlink. If the event message was not registered with EVS for filtering then the ground can add (i.e. register) the offending application's event for filtering (much like an application registers the event during initialization).

EVS also supports the ability to [remove](#) (i.e. unregister) an application's event message. Once it is removed, the event will no longer be filtered. Note that commands issued to disable events by event type, by application or by event type for an application are still valid and could affect this particular event.

Next: [Event Message Filtering](#)

Prev: [Local Event Log](#)

Up To: [cFE Event Services Overview](#)

#### 2.10.4 Event Message Filtering

EVS uses a hexadecimal bit mask that controls how often a message is filtered. An event's filter mask is bit-wise ANDed with the event's event counter. There is one event counter for each event ID. If the result of the ANDing is zero then the message is sent.

Filter masks can be set so that one out of 1, 2, 4, 8 events are sent. Some examples of masks that use this pattern are: (0x0000, Every one), (0x0001, One of every 2), (0x0003, One of every 4), and (0x0007, One of every 8).

Filter masks can also be set so that only the first n events are sent. For example, the mask 0xFFFF generates one event message and then stops. Note that when the filter counter is reset to zero by command, this will restart the counting and enable n more events to be sent.

Event messages will be filtered until CFE\_EVS\_MAX\_FILTER\_COUNT events of the filtered event ID from the application have been received. After this, the filtering will become locked (no more of that event will be received by the ground) until the filter is either reset or deleted by ground command. This is to prevent the counter from rolling over, which would cause some filters to behave improperly. An event message will be sent when this maximum count is reached.

The following shows an example of how filtering works using a filter mask of x'0001', resulting in sending every other event:

	<b>packet x</b>	<b>packet X+1</b>	<b>packet X+2</b>	<b>packet X+3</b>	<b>packet X+4</b>	...
<b>Event ID counter</b>	x'0000'	x'0001'	x'0002'	x'0003'	x'0004'	
<b>Event Filter mask</b>	x'0001'	x'0001'	x'0001'	x'0001'	x'0001'	
<b>Bitwise AND results</b>	x'0000'	x'0001'	x'0000'	x'0001'	x'0000'	
<b>Send event?</b>	Yes	No	Yes	No	Yes	

In this example, the ground uses a filter mask of x'FFFE' resulting in the first two events being sent and then no more.

	<b>packet x</b>	<b>packet X+1</b>	<b>packet X+2</b>	<b>packet X+3</b>	<b>packet X+4</b>	...
<b>Event ID counter</b>	x'0000'	x'0001'	x'0002'	x'0003'	x'0004'	
<b>Event Filter mask</b>	x'FFFE'	x'FFFE'	x'FFFE'	x'FFFE'	x'FFFE'	
<b>Bitwise AND results</b>	x'0000'	x'0000'	x'0002'	x'0002'	x'0004'	
<b>Send event?</b>	Yes	Yes	No	No	No	

See [cfe\\_evs.h](#) for predefined macro values which can be used for masks.

Next: [EVS Registry](#)

Prev: [Event Message Control](#)

Up To: [cFE Event Services Overview](#)

#### 2.10.5 EVS Registry

EVS maintains information on each registered application and all events registered for an application.

The registry contains the following information for each Registered Application:

- Active Flag - If equal to FALSE (0), all events from this Application are Filtered

- Event Count - Total number of events issued by this Application. Note that this value stop incrementing at 65535.

The following information for each Filtered Event (up to [CFE\\_PLATFORM\\_EVS\\_MAX\\_EVENT\\_FILTERS](#))  
:

- Event ID - Event ID for event whose filter has been defined
- Mask - Binary Filter mask value (see [Event Message Filtering](#) for an explanation)
- Count - Current number of times this Event ID has been issued by this Application

Next: [EVS Counters](#)

Prev: [Event Message Filtering](#)

Up To: [cFE Event Services Overview](#)

#### 2.10.6 EVS Counters

There are 2 types of counters in EVS housekeeping telemetry:

- Total events sent counter
- Number of events sent for each Application

The difference is that the first one is the sum of all of the event messages sent. Both of these represent events that are actually sent (by EVS to the software bus). If an event message is filtered or disabled, neither counter is incremented.

There are other counters available that show how many event messages were generated by an App, however, these are only available for those events that are registered for filtering hence if you have a message that is not registered for filtering and the message type (e.g. DEBUG) is disabled then you won't know if the event was ever issued by an application. These counters are available by sending a command to [write the EVS Application Data](#) and transferring the file to the ground.

Next: [Resetting EVS Counters](#)

Prev: [EVS Registry](#)

Up To: [cFE Event Services Overview](#)

### 2.10.7 Resetting EVS Counters

As far as reset commands, there are 4 commands available:

1. [Reset the total events sent counter](#)
2. [Reset the events sent counter for a particular Application](#) - e.g. reset the LC application events counter
3. [Reset all of the event counters for a particular registered event for a particular Application](#) - e.g. Reset event counter for Event ID 5 for the LC Application.
4. [Reset all of the event counters for ALL registered events for a particular App](#) - e.g. Reset all registered event counters for LC.

Note that there is currently no way to reset ALL of the events sent counters for all of the Apps with one command.

Next: [Effects of a Processor Reset on EVS](#)

Prev: [EVS Counters](#)

Up To: [cFE Event Services Overview](#)

### 2.10.8 Effects of a Processor Reset on EVS

On a processor reset, the EVS Registry is cleared such that applications must re-register with EVS in order to use EVS services. All counters are also cleared with the exceptions of those listed below.

On a processor reset, the following EVS data is preserved (if the cFE is configured to include an [Local Event Log](#)):

- Local Event Log if the Local Event Log Mode is configured to Discard (1). If the Local Event Log Mode is configured to Overwrite (0), the contents of the log may be overwritten depending on the size and contents of the log prior to the reset.
- Local Event Log Full Flag
- Local Event Log overflow counter

The Local Event Log Mode (overwrite/discard) is set to the configured value specified in the `cfe_platform_cfg.h` file. The default value is Discard (1). Discard mode will guarantee the contents of the event log are preserved over a processor restart.

This provides the ground with the capability to write the Local Event Log to a file and transfer it to the ground in order to help debug a reset.

Next: [EVS squelching of misbehaving apps](#)

Prev: [Resetting EVS Counters](#)

Up To: [cFE Event Services Overview](#)

### 2.10.9 EVS squelching of misbehaving apps

Event squelching is an optional feature for suppressing excessive events from misbehaving apps. It is enabled by setting `CFE_PLATFORM_EVS_MAX_APP_EVENT_BURST` to a nonzero positive value, and `CFE_PLATFORM_EVS_APP_EVENTS_PER_SEC` equal to or less than that value.

`CFE_PLATFORM_EVS_MAX_APP_EVENT_BURST` controls the maximum events that can be sent at a given moment, and `CFE_PLATFORM_EVS_APP_EVENTS_PER_SEC` is the sustained event throughput per second.

The suppression mechanism initializes with `CFE_PLATFORM_EVS_MAX_APP_EVENT_BURST * 1000` credits. Each event costs 1000 credits. Credits are restored at a rate of `CFE_PLATFORM_EVS_APP_EVENTS_PER_SEC * 1000` up to a maximum balance of `CFE_PLATFORM_EVS_MAX_APP_EVENT_BURST * 1000`, and the maximum "debt" is `-CFE_PLATFORM_EVS_MAX_APP_EVENT_BURST * 1000`. When the credit count crosses from positive to negative, a squelched event message is emitted and events are suppressed, until the credit count becomes positive again.

Figure EVS-1 is a notional state diagram of the event squelching mechanism.




Figure 2 Figure EVS-1: EVS Squelching State Diagram

Next: [Frequently Asked Questions about Event Services](#)

Prev: [Effects of a Processor Reset on EVS](#)

Up To: [cFE Event Services Overview](#)

### 2.10.10 Frequently Asked Questions about Event Services

<b>(Q) My telemetry stream is being flooded with the same event message. How do I make it stop?</b>	
	The most direct way to stop an event message from flooding your downlink stream is to send a command to EVS to filter the offending event (see <a href="#">Event Message Control</a> or <a href="#">\$sc_\$cpu_EVS_SetBinFltrMask</a> ). In order to stop the event message from being sent, a bit mask of '0xFFFF' should be used. If the event is not currently registered for filtering, the event message must be added using the command <a href="#">\$sc_\$cpu_EVS_AddEvtFltr</a> .
<b>(Q) I filtered an event message and would now like to see it again. What do I do in order to see those events again?</b>	
	If the event message that you are interested in is registered with EVS for filtering, then you have 2 options:
<ol style="list-style-type: none"> <li>1. You can use the <a href="#">\$sc_\$cpu_EVS_SetBinFltrMask</a> command using a bit mask of '0x0000' which will result in getting all of the events for that Event Id <b>or</b></li> <li>2. You can remove the registration of that event with EVS (see <a href="#">\$sc_\$cpu_EVS_DelEvtFltr</a>). Note that option (1) is the preferred method.</li> </ol>	
<b>(Q) What is the purpose of DEBUG event messages?</b>	
	Event messages of type "DEBUG" are primarily used during flight software development in order to provide information that is most likely not needed on orbit. Some commands send debug event messages as verification that a command request was received. When writing the EVS local event log to a file, for example, an event message of type DEBUG is issued. On orbit, this event message is probably not needed. Instead, the command counter is used for command verification.
<b>(Q) How do I find out which events are registered for filtering?</b>	
	EVS provides a command ( <a href="#">\$sc_\$cpu_EVS_WriteAppData2File</a> ) which generates a file containing all of the applications that have registered with EVS and all of the filters that are registered for each application. Note that EVS merely generates the file. The file must be transferred to the ground in order to view it.
<b>(Q) Why do I see event messages in my console window?</b>	
	By default, the events are configured to transmit out a "port" that shows event messages in the console
<b>(Q) What is the difference between event services and the ES System Log</b>	
	Events are within the context of an App or cFE Service (requires registration with ES). The system log can be written to outside of the Application or cFE Service context, for example during application startup to report errors before registration.

Prev: [Effects of a Processor Reset on EVS](#)

Up To: [cFE Event Services Overview](#)

## 2.11 cFE Event Services Commands

Upon receipt of any command, the Event Services application will confirm that the message length embedded within the header (from [CFE\\_MSG\\_GetSize\(\)](#)) matches the expected length of that message, based on the size of the C structure defining that command. If there is any discrepancy between the expected and actual message size, EVS will generate the [CFE\\_EVS\\_LEN\\_ERR\\_EID](#) event, increment the command error counter ([\\$sc\\_\\$cpu\\_EVS\\_CMDEC](#)), and the command will *not* be accepted for processing.

The following is a list of commands that are processed by the cFE Event Services Task.

**Global CFE\_EVS\_ADD\_EVENT\_FILTER\_CC**

Add Application Event Filter

**Global CFE\_EVS\_CLEAR\_LOG\_CC**

Clear Event Log

**Global CFE\_EVS\_DELETE\_EVENT\_FILTER\_CC**

Delete Application Event Filter

**Global CFE\_EVS\_DISABLE\_APP\_EVENT\_TYPE\_CC**

Disable Application Event Type

**Global CFE\_EVS\_DISABLE\_APP\_EVENTS\_CC**

Disable Event Services for an Application

**Global CFE\_EVS\_DISABLE\_EVENT\_TYPE\_CC**

Disable Event Type

**Global CFE\_EVS\_DISABLE\_PORTS\_CC**

Disable Event Services Output Ports

**Global CFE\_EVS\_ENABLE\_APP\_EVENT\_TYPE\_CC**

Enable Application Event Type

**Global CFE\_EVS\_ENABLE\_APP\_EVENTS\_CC**

Enable Event Services for an Application

**Global CFE\_EVS\_ENABLE\_EVENT\_TYPE\_CC**

Enable Event Type

**Global CFE\_EVS\_ENABLE\_PORTS\_CC**

Enable Event Services Output Ports

**Global CFE\_EVS\_NOOP\_CC**

Event Services No-Op

**Global CFE\_EVS\_RESET\_ALL\_FILTERS\_CC**

Reset All Event Filters for an Application

**Global CFE\_EVS\_RESET\_APP\_COUNTER\_CC**

Reset Application Event Counters

**Global CFE\_EVS\_RESET\_COUNTERS\_CC**

Event Services Reset Counters

**Global CFE\_EVS\_RESET\_FILTER\_CC**

Reset an Event Filter for an Application

**Global CFE\_EVS\_SET\_EVENT\_FORMAT\_MODE\_CC**

Set Event Format Mode

**Global CFE\_EVS\_SET\_FILTER\_CC**

Set Application Event Filter

**Global CFE\_EVS\_SET\_LOG\_MODE\_CC**

Set Logging Mode

**Global CFE\_EVS\_WRITE\_APP\_DATA\_FILE\_CC**

Write Event Services Application Information to File

**Global CFE\_EVS\_WRITE\_LOG\_DATA\_FILE\_CC**

Write Event Log to File

## 2.12 cFE Event Services Telemetry

The following are telemetry packets generated by the cFE Event Services Task.

### Global `CFE_EVS_HousekeepingTlm_Payload_t`

Event Services Housekeeping Telemetry Packet

### Global `CFE_EVS_HousekeepingTlm_Payload_t`

Event Services Housekeeping Telemetry Packet

### Global `CFE_EVS_LongEventTlm_Payload_t`

Event Message Telemetry Packet (Long format)

### Global `CFE_EVS_LongEventTlm_Payload_t`

Event Message Telemetry Packet (Long format)

### Global `CFE_EVS_ShortEventTlm_Payload_t`

Event Message Telemetry Packet (Short format)

### Global `CFE_EVS_ShortEventTlm_Payload_t`

Event Message Telemetry Packet (Short format)

## 2.13 cFE Event Services Configuration Parameters

The following are configuration parameters used to configure the cFE Event Services either for each platform or for a mission as a whole.

### Global `CFE_MISSION_EVS_MAX_MESSAGE_LENGTH`

Maximum Event Message Length

### Global `CFE_PLATFORM_EVS_APP_EVENTS_PER_SEC`

Sustained number of event messages per second per app before squelching

### Global `CFE_PLATFORM_EVS_DEFAULT_APP_DATA_FILE`

Default EVS Application Data Filename

### Global `CFE_PLATFORM_EVS_DEFAULT_LOG_FILE`

Default Event Log Filename

### Global `CFE_PLATFORM_EVS_DEFAULT_LOG_MODE`

Default EVS Local Event Log Mode

### Global `CFE_PLATFORM_EVS_DEFAULT_MSG_FORMAT_MODE`

Default EVS Message Format Mode

### Global `CFE_PLATFORM_EVS_DEFAULT_TYPE_FLAG`

Default EVS Event Type Filter Mask

### Global `CFE_PLATFORM_EVS_LOG_MAX`

Maximum Number of Events in EVS Local Event Log

### Global `CFE_PLATFORM_EVS_MAX_APP_EVENT_BURST`

Maximum number of event before squelching

### Global `CFE_PLATFORM_EVS_MAX_EVENT_FILTERS`

Define Maximum Number of Event Filters per Application

### Global `CFE_PLATFORM_EVS_PORT_DEFAULT`

Default EVS Output Port State

## 2.14 cFE Software Bus Overview

The Software Bus (SB) handles communication between software tasks on a processor. All tasks communicate with each other, with hardware devices, and with the ground by sending command and telemetry messages. The software bus provides an application programming interface (API) to other tasks for sending and receiving messages. This API is independent of the underlying operating system so that tasks can use the same interface regardless of which processor they reside on. Refer to the [cFE Application Programmer's Interface \(API\) Reference](#) for detailed information about the API functions.

The software bus is used internally by the flight software, and normally does not require attention from the ground. However, because of the scalability and the dynamic nature of the software bus, it is strongly recommended that each project carefully review the SB statistics and SB memory pool to be sure adequate margin is met on the configurable items.

The cFE software bus uses a dynamic protocol and builds its routing table at run-time through the SB subscribe API's. Also the cFE software bus pipes are created at run-time through the [CFE\\_SB\\_CreatePipe](#) API. Because the routing is established, and pipes are created at run-time, it is necessary to have a clear view of the routing details on command. The cFE software bus allows the user to dump the routing table, the pipe table, the message map and the statistics packet. Each of these items are described in detail in the corresponding section of this document.

- [Software Bus Terminology](#)
- [Autonomous Actions](#)
- [Operation of the SB Software](#)
- [Frequently Asked Questions about Software Bus](#)

### 2.14.1 Software Bus Terminology

In order to fully understand the Software Bus, it is imperative that the basic terms used to describe its features are also understood. Below are the critical terms that help identify what the Software Bus accomplishes for each Application:

- [Messages](#)
- [Pipes](#)
- [Subscriptions](#)
- [Memory](#)

Next: [Messages](#)

Up To: [cFE Software Bus Overview](#)

### 2.14.1.1 Messages

The sole purpose of the software bus is to provide applications a way to send messages to each other. The term message and the term packet are used interchangeably throughout this document. A message is a combined set of bytes with a predefined format that is used as the basis of communication on a spacecraft. All commands, telemetry, and other data that are passed between the ground and the spacecraft, and between subsystems of the spacecraft, are considered to be messages. The most common message format is CCSDS (Consultative Committee for Space Data Systems) in [CCSDS Space Packet Protocol](#), but can be customized by replacing the message module.

There are two general types of messages - commands (or command packets) and telemetry (or telemetry packets). Command packets are sent to a particular software task from the ground (or another task). Telemetry packets are sent from a particular software task to the ground (or other tasks).

The concept of a message identifier is utilized to provide abstraction from header implementation, often abbreviated as message ID, MsgId, or MID. Header and message identifier values should not be accessed directly to avoid implementation specific dependencies.

Telemetry packets typically contain a timestamp that indicates when the packet was produced. Command packets typically contain a command code that identifies the particular type of command.

The message module provides APIs for 'setting' and 'getting' the fields in the header of the message. The message module was separated from software bus to enable users to customize message headers without requiring clone and own of the entire cfe repository. To customize, remove the built in msg module from the build and replace with custom implementation. See sample target definitions folder for examples.

Following the header is the user defined message data.

Next: [Pipes](#)

Up To: [Software Bus Terminology](#)

### 2.14.1.2 Pipes

The destinations to which messages are sent are called pipes. These are queues that can hold messages until they are read out and processed by a task. Each pipe is created at run-time through the [CFE\\_SB\\_CreatePipe](#) API. The pipe name and the pipe depth are given as arguments in the API. The pipe identifier (or Pipeld) is given back to the caller after the API is executed. Each pipe can be read by only one task, but a task may read more than one pipe. Only the pipe owner is allowed to subscribe to messages on the pipe.

The Pipe IDs are specific to a particular processor (that is, the same ID number may refer to a different pipe on each processor). The pipe information for all pipes that have been created, may be requested at anytime by sending the ['Write Pipe Info' SB command](#). The software bus also provides a set of figures regarding capacity, current utilization and high water marks relevant to pipes. This information may be requested by sending the command to [dump the SB statistics packet](#).

Next: [Subscriptions](#)

Prev: [Messages](#)

Up To: [Software Bus Terminology](#)

### 2.14.1.3 Subscriptions

A subscription is a run-time request for a particular message to be sent to a particular pipe. If the caller of the subscribe API is not the owner of the pipe, the request is rejected and an error event is sent. The application that creates the pipe is considered the owner of the pipe. The pipe specified in the subscription is sometimes referred to as the destination of the message. There are a maximum number of destinations for a particular message. This value is specified by the platform configuration parameter [CFE\\_PLATFORM\\_SB\\_MAX\\_DEST\\_PER\\_PKT](#).

As subscriptions are received, the destinations are added to the head of a linked list. During the sending of a message, the list is traversed beginning at the head of the list. Therefore the message will first be sent to the last subscriber. If an application has timing constraints and needs to receive a message in the shortest possible time, the developer may consider holding off its subscription until other applications have subscribed to the message.

The message limit specifies the maximum number of messages (with the specified Message ID) that are allowed on the specified pipe at any time. This limit is specified by the application at the time of the subscription. If the application uses the [CFE\\_SB\\_Subscribe](#) API, a message limit default value of four is used. If this default value is not sufficient, the caller would use the [CFE\\_SB\\_SubscribeEx](#) API that allows the message limit to be specified.

The software bus also provides the user with an option to unsubscribe to a message. The [unsubscribe API](#) takes two parameters, Message ID and Pipe ID. Only the owner of a pipe may unsubscribe to messages on that pipe.

Next: [Memory](#)

Prev: [Pipes](#)

Up To: [Software Bus Terminology](#)

### 2.14.1.4 Memory

The software bus statically allocates a block of memory for message buffers and subscription blocks. The size of this memory block is defined by the platform configuration parameter [CFE\\_PLATFORM\\_SB\\_BUF\\_MEMORY\\_BYTES](#). The memory is managed by the cFE ES memory pool and is used only by the software bus. The ES memory pool allows an application to define the block sizes for the pool at compile time. These sizes are defined by the platform configuration parameters prefixed with CFE\_SB\_MEM\_BLOCK\_SIZE (for example, [CFE\\_PLATFORM\\_SB\\_MEM\\_BLOCK\\_SIZE\\_01](#)). It is recommended that a project tailor these values for the mission, based on the software bus packet sizes.

At the time a message is sent, two buffers are allocated from the pool. One for a buffer descriptor (CFE\_SB\_BufferD\_t) and one for the size of the packet. Both buffers are returned to the pool when the message has been received by all recipients. More precisely, if there is one recipient for a message, the message buffers will be released on the following call to [CFE\\_SB\\_ReceiveBuffer](#) for the pipe that received the buffer.

Also when subscriptions are received through the subscribe API's, the software bus allocates a subscription block (CFE\_SB\_DestinationD\_t) from the pool. The subscription blocks are returned to the pool if and when the subscription is nullified through a [CFE\\_SB\\_Unsubscribe](#) call.

The software bus provides a set of figures regarding memory capacity, current memory utilization and high water marks relevant to the SB memory pool. This information may be requested by sending the command to dump the SB statistics packet. In addition, the current memory utilization value and the 'unmarked memory' value ([CFE\\_PLATFORM\\_SB\\_BUF\\_MEMORY\\_BYTES](#) minus peak memory in use) are sent in software bus housekeeping telemetry. The unmarked memory value should be monitored regularly to ensure that the value (in bytes) does not continue to decline or approach zero. If this value were to approach zero, there is a possibility that memory requests would fail which may inhibit the sending of a message. The current memory utilization value should also be monitored to ensure the system contains no memory leaks. The value (in bytes) should remain stable under nominal conditions. Refer to the ES users guide for more information regarding the ES Memory Pool.

Next: [Autonomous Actions](#)

Prev: [Subscriptions](#)

Up To: [Software Bus Terminology](#)

### 2.14.2 Autonomous Actions

The software bus is primarily a set of library routines that are called by other software tasks to send and receive packets. The software bus does not perform any operations autonomously, except for sending event messages if errors are detected during the transfer of packets.

As do other tasks, the SB task sends out housekeeping telemetry when requested through the 'Send Housekeeping Data' command.

Next: [Operation of the SB Software](#)

Prev: [Software Bus Terminology](#)

Up To: [cFE Software Bus Overview](#)

### 2.14.3 Operation of the SB Software

- [Initialization](#)
- [All Resets](#)
- [Message Routing](#)
- [Packet Sequence Values](#)
- [Message Limit Error](#)
- [Pipe Overflow Error](#)
- [SB Event Filtering](#)
- [Diagnostic Data](#)
- [Control of Packet Routing](#)
- [Quality of Service](#)
- [Known Problem](#)

Next: [Initialization](#)

Prev: [Autonomous Actions](#)

Up To: [cFE Software Bus Overview](#)

---

### 2.14.3.1 Initialization

No action is required by the ground to initialize the software bus. The software bus initializes internal data structures and tables the same way regardless of the type of reset.

Next: [All Resets](#)

Up To: [Operation of the SB Software](#)

### 2.14.3.2 All Resets

The software bus does not preserve any information across a reset of any kind. The software bus initializes internal data structures and tables the same way regardless of the type of reset. The routing is reestablished as the system initializes. It is normal procedure for each task of the system to create the pipe or pipes it needs and do all of its subscriptions during task initialization.

After any reset the following statements are true:

- The routing table is cleared and does not contain any routes.
- All subscriptions are lost and must be regenerated.
- The pipe table contains no data, all pipes must be recreated.
- Any packets in transit at the time of the reset are lost.
- The sequence counters for telemetry packets will begin again with a value of one.

Next: [Message Routing](#)

Prev: [Initialization](#)

Up To: [Operation of the SB Software](#)

### 2.14.3.3 Message Routing

In the software bus, all messages are processed in a similar way. The software bus uses the Message ID and the packet length fields (contained in the header) for routing the message to the destination pipe. If either of these two fields do not pass validation, the software bus generates an error event and aborts the delivery process. The software bus performs some validation checks by simply checking message header values against mission or platform configuration parameters. Messages originating from various tasks or instruments are routed to one or more pipes, where they wait until read by a task. The routing configuration for each message is established when applications call one of the SB subscribe APIs. The subscribe APIs take a Message ID and a Pipe ID as parameters. The routing for each packet is stored in SB memory and may be requested at any time by sending the 'Send Routing Info' command. The software bus also provides a set of figures regarding capacity, current utilization and high water marks relevant to the routing. This information may be requested by sending the command to dump the SB statistics packet.

Next: [Packet Sequence Values](#)

Prev: [All Resets](#)

Up To: [Operation of the SB Software](#)

#### 2.14.3.4 Packet Sequence Values

The sequence count behavior depends on if the message is a command type or telemetry type.

The sequence counter for command messages is not altered by the software bus.

For a telemetry message, the behavior is controlled via API input parameters when sending. When enabled, the software bus will populate the packet sequence counter using an internal counter that gets initialized upon the first subscription to the message (first message will have a packet sequence counter value of 1). From that point on each send request will increment the counter by one, regardless of the number of destinations or if there is an active subscription.

After a rollover condition the sequence counter will be a value of zero for one instance. The sequence counter is incremented after all the checks have passed prior to the actual sending of the message. This includes the parameter checks and the memory allocation check.

When disabled, the original message will not be altered. This method of message delivery is recommended for situations where the sender did not generate the packet, such as a network interface application passing a packet from a remote system to the local software bus.

Next: [Message Limit Error](#)

Prev: [Message Routing](#)

Up To: [Operation of the SB Software](#)

#### 2.14.3.5 Message Limit Error

Before placing a message on a pipe, the software bus checks the message limit to ensure the maximum number of packets in transit to the destination is not exceeded. If placing the message on the pipe would exceed the message limit, then the action of sending to that pipe is aborted and the 'Message Limit Error' event is sent. This condition will typically occur when an application that receives the packets does not respond quickly enough, or if the sender of the packets produces them too quickly.

This condition occurs often during development and during integration, for example when a remote processor gets reset or a 1553 cable becomes disconnected. Because of the common occurrences, the event may have filtering associated with it. Any filtering for this event would be performed by the cFE Event Services (EVS). Filtering for SB events may be specified in the cFE platform configuration file or may be commanded after the system initializes.

If this error occurs during nominal conditions, it could be an indication that the 'message limit' is not set correctly. The message limit is given at the time of the subscription and given as a parameter in the subscribe API. With the [CFE\\_SB\\_Subscribe](#) API, the SB uses a default message limit value specified by [CFE\\_PLATFORM\\_SB\\_DEFAULT\\_MSG\\_LIMIT](#). This constant is currently set to a value of four. If the default value is insufficient, the message limit value can be specified in the [CFE\\_SB\\_SubscribeEx](#) API.

A related failure is the pipe overflow condition, which can occur if the total number of packets (of all kinds) sent to a particular pipe is too large.

Next: [Pipe Overflow Error](#)

Prev: [Packet Sequence Values](#)

Up To: [Operation of the SB Software](#)

#### 2.14.3.6 Pipe Overflow Error

Another common error that occurs during the send process is the pipe overflow error. This condition occurs if the total number of packets (of all kinds) sent to a particular pipe is too large. If this error occurs too frequently, it may be an indication that the pipe depth is not set correctly. The pipe depth is given at the time the pipe is created as a parameter in the [CFE\\_SB\\_CreatePipe API](#).

Next: [SB Event Filtering](#)

Prev: [Message Limit Error](#)

Up To: [Operation of the SB Software](#)

#### 2.14.3.7 SB Event Filtering

Most filtering for SB events is performed by the cFE Event Services (EVS). Filtering for SB events may be specified in the cFE platform configuration file or may be commanded after the system initializes. There is no SB event log that limits the number of events based on the capacity of the log, as in the heritage software bus.

There is one case in which events are filtered by the software bus instead of event services. This occurs when the software bus needs to suppress events so that a fatal recursive event condition does not transpire. Because error cases encountered when sending a message generate an event, and events cause a message to be sent a calling sequence could cause a stack overflow if the recursion is not properly terminated. The cFE software bus detects this condition and properly terminates the recursion. This is done by using a set of flags (one flag per event in the Send API) which determine whether an API has relinquished its stack. If the software bus needs to send an event that may cause recursion, the flag is set and the event is sent. If sending the event would cause the same event again, the event call will be bypassed, terminating the recursion. The result is that the user will see only one event instead of the many events that would normally occur without the protection. The heritage software bus did not have this condition because it stored events in the software bus event log and another thread would read them out at a later time.

Next: [Diagnostic Data](#)

Prev: [Pipe Overflow Error](#)

Up To: [Operation of the SB Software](#)

#### 2.14.3.8 Diagnostic Data

The cFE software bus provides a set of commands to dump SB diagnostic data to help troubleshoot problems or check configuration settings. These commands allow the user to view the routing table, the pipe table or the message map. The message map is a lookup table used during a send operation to give fast access to the routing table index that corresponds to the message being sent.

The software bus also provides a statistics packet that can be used to tune the configuration parameters. This information is sent to the ground in the form of an SB packet when the corresponding command is received. The cFE limits the number of system pipes, unique Message IDs, buffer memory, messages on a pipe and subscriptions per Message ID. These limits are configurable through cFE platform and mission configuration parameters. The statistics packet was designed to let the project verify that these user settings provide the necessary margin to meet requirements.

The SB statistics information shows 'Currently In Use' figures, 'High Water Mark' figures and 'Max Allowed' figures for the following: buffer memory, messages on each pipe (pipe depth stats), System Pipes, Unique Message IDs and total subscriptions.

Depending on the task-scheduling implementation details of the operating system, it is possible to see the peak messages on a pipe occasionally exceed the depth of the pipe. The "Peak Messages In Use" parameter is included in the SB statistics packet under the pipe depth stats.

Next: [Control of Packet Routing](#)

Prev: [SB Event Filtering](#)

Up To: [Operation of the SB Software](#)

#### 2.14.3.9 Control of Packet Routing

The software bus allows the ground to disable and enable the sending of packets of a specified Message ID to a specified pipe. All destinations that are needed for normal operation are enabled by default. Modifying the routing of packets may be required for the following reasons:

- In flight, one can enable diagnostic packets to see them on the ground.
- During testing, one can disable a destination to simulate an anomaly.

Next: [Quality of Service](#)

Prev: [Diagnostic Data](#)

Up To: [Operation of the SB Software](#)

#### 2.14.3.10 Quality of Service

The software bus has a parameter in the [CFE\\_SB\\_SubscribeEx](#) API named Quality, which means Quality of Service (QOS) for off-board routing and is of the type [CFE\\_SB\\_Qos\\_t](#). This structure has two members named priority and reliability. The Quality parameter is currently unused by the software bus. It is a placeholder to be used with the future software bus capability of inter-processor communication. Although currently the software bus does not implement quality of service.

A default quality of services is provided via the [CFE\\_SB\\_DEFAULT\\_QOS](#) macro.

Next: [Known Problem](#)

Prev: [Control of Packet Routing](#)

Up To: [Operation of the SB Software](#)

#### 2.14.3.11 Known Problem

The software bus may perform unexpectedly under an unlikely corner-case scenario. This scenario was revealed in a stress test. The stress test was designed to deplete the Software Bus memory pool by having a high priority application continuously send 1000 byte packets to a lower priority application until the memory pool code returned an error code and sent the following event. "CFE\_ES:getPoolBuf err:Request won't fit in remaining memory" At this point the higher priority sending application would stop executing. This would allow the lower priority receiving application to begin receiving the 1000 byte packets. After the receiving app processed all of the packets, the memory was restored to the memory pool as expected. The SB memory-in-use telemetry was zero because there were no software bus packets in transit. At this point any attempt to send a new-sized packet on the software bus was be rejected. The ES memory pool stated that the "... Request won't fit in remaining memory" even though there was currently no memory in use.

The simplest way to prevent this behavior is to ensure that there is margin when sizing the SB memory pool. To check the margin, monitor the "Peak Memory in Use" vs. the configuration parameter [CFE\\_PLATFORM\\_SB\\_BUF\\_MEMORY\\_BYTES](#) which indicates the amount allocated.

Next: [Frequently Asked Questions about Software Bus](#)

Prev: [Quality of Service](#)

Up To: [Operation of the SB Software](#)

#### 2.14.4 Frequently Asked Questions about Software Bus

<b>(Q) How is the memory pool handle (sent in SB housekeeping telemetry) intended to be used?</b>	
<p>The memory pool handle is used to analyze the SB memory pool statistics. The cFE ES command (<a href="#">CFE_ES_S_SEND_MEM_POOL_STATS_CC</a>) to dump the memory pool statistics takes the pool handle as a parameter. These statistics tell how the SB memory pool is configured and gives details on margin. An improperly configured SB memory pool may inhibit communication. This may occur if there is not enough margin to create a block of the size needed for a transfer. Refer to the ES memory pool users guide for more details. <a href="#">Memory Pool</a></p>	
<b>(Q) When sending a message, what message header fields are critical for routing the message?</b>	
<p>To route the message properly, the software bus uses only the Message ID and packet length fields from the header of the message. If the packet length field is incorrect, then the buffer allocation for the message will also be incorrect. This may appear to the receiver as a truncated message or a message with unknown data added to the end of the message.</p>	
<b>(Q) How many copies of the message are performed in a typical message delivery?</b>	
<p>There is a single copy of the message performed when sending a message (from the callers memory space) using <code>CFE_SB_TransmitMsg</code>. When transmitting the message, the software bus copies the message from the callers memory space into a buffer in the software bus memory space. There is also the option to request a buffer from SB, write directly to the buffer and send via <code>CFE_SB_TransmitBuffer</code>. This is equivalent to the previous zero copy implementation. The <a href="#">CFE_SB_ReceiveBuffer</a> API gives the user back a pointer to the buffer. When working with the buffers, the additional complexity to be aware of is the buffer is only available to the app from the request to send (on the sending side), or from the receive until the next receive on the same pipe on the receiving side. If the data is required outside that scope, the app needs a local copy.</p>	
<b>(Q) When does the software bus free the buffer during a typical message delivery process? Or how long is the message, and the pointer to the buffer in the <a href="#">CFE_SB_ReceiveBuffer</a> valid?</b>	
<p>After receiving a buffer by calling <a href="#">CFE_SB_ReceiveBuffer</a>, the buffer received is valid until the next call to <a href="#">CFE_SB_ReceiveBuffer</a> with the same Pipe Id. If the caller needs the message longer than the next call to <a href="#">CFE_SB_ReceiveBuffer</a>, the caller must copy the message to its memory space.</p>	
<b>(Q) The first parameter in the <a href="#">CFE_SB_ReceiveBuffer</a> API is a pointer to a pointer which can get confusing. How can I be sure that the correct address is given for this parameter.</b>	
<p>Typically a caller declares a ptr of type <code>CFE_SB_Buffer_t</code> (i.e. <code>CFE_SB_Buffer_t *Ptr</code>) then gives the address of that pointer (<code>&amp;Ptr</code>) as this parameter. After a successful call to <a href="#">CFE_SB_ReceiveBuffer</a>, <code>Ptr</code> will point to the first byte of the software bus buffer. This should be used as a read-only pointer. In systems with an MMU, writes to this pointer may cause a memory protection fault.</p>	
<b>(Q) Why am I not seeing expected Message Limit error events or Pipe Overflow events?</b>	
<p>It is possible the events are being filtered by cFE Event Services. The filtering for this event may be specified in the platform configuration file or it may have been commanded after the system initializes. There is a corresponding counter for each of these conditions. First verify that the condition is happening by viewing the counter in SB HK telemetry. If the condition is happening, you can view the SB filter information through the EVS App Data Main page by clicking the 'go to' button for SB. The event Id for these events can be learned through a previous event or from the <a href="#">cfe_sb_events.h</a> file.</p>	
<b>(Q) Why does the SB provide event filtering through the platform configuration file?</b>	
<p>To give the user the ability to filter events before an EVS command can be sent. During system initialization, there are many conditions occurring that can cause a flood of SB events such as No Subscribers, Pipe Overflow and MsgId to Pipe errors. This gives the user a way to limit these events.</p>	
<b>(Q) Why does SB have so many debug event messages?</b>	
<p>The SB debug messages are positive acknowledgments that an action (like receiving a cmd, creating a pipe or subscribing to a message) has occurred. They are intended to help isolate system problems. For instance, if an expected response to a command is not happening, it may be possible to repeat the scenario with the debug event turned on to verify that the command was successfully received.</p>	
<b>(Q) How is the QOS parameter in the <a href="#">CFE_SB_SubscribeEx</a> used by the software bus?</b>	

	The QOS parameter is currently unused by the software bus. It is a placeholder to be used with the future software bus capability of inter-processor communication. Setting the QOS as <a href="#">CFE_SB_DEFAULT_QOS</a> will ensure seamless integration when the software bus is expanded to support inter-processor communication.
<b>(Q) Can I confirm my software bus buffer was delivered?</b>	
	There is no built in mechanism for confirming delivery (it could span systems). This could be accomplished by generating a response message from the receiver.

Prev: [Operation of the SB Software](#)

Up To: [cFE Software Bus Overview](#)

## 2.15 cFE Software Bus Commands

Upon receipt of any command, the Software Bus application will confirm that the message length embedded within the header (from [CFE\\_MSG\\_GetSize\(\)](#)) matches the expected length of that message, based on the size of the C structure defining that command. If there is any discrepancy between the expected and actual message size, SB will generate the [CFE\\_SB\\_LEN\\_ERR\\_EID](#) event, increment the command error counter (\$sc\_\$cpu\_SB\_CMDEC), and the command will *not* be accepted for processing.

The following is a list of commands that are processed by the cFE Software Bus Task.

### Global [CFE\\_SB\\_DISABLE\\_ROUTE\\_CC](#)

Disable Software Bus Route

### Global [CFE\\_SB\\_DISABLE\\_SUB\\_REPORTING\\_CC](#)

Disable Subscription Reporting Command

### Global [CFE\\_SB\\_ENABLE\\_ROUTE\\_CC](#)

Enable Software Bus Route

### Global [CFE\\_SB\\_ENABLE\\_SUB\\_REPORTING\\_CC](#)

Enable Subscription Reporting Command

### Global [CFE\\_SB\\_NOOP\\_CC](#)

Software Bus No-Op

### Global [CFE\\_SB\\_RESET\\_COUNTERS\\_CC](#)

Software Bus Reset Counters

### Global [CFE\\_SB\\_SEND\\_PREV\\_SUBS\\_CC](#)

Send Previous Subscriptions Command

### Global [CFE\\_SB\\_SEND\\_SB\\_STATS\\_CC](#)

Send Software Bus Statistics

### Global [CFE\\_SB\\_WRITE\\_MAP\\_INFO\\_CC](#)

Write Map Info to a File

### Global [CFE\\_SB\\_WRITE\\_PIPE\\_INFO\\_CC](#)

Write Pipe Info to a File

### Global [CFE\\_SB\\_WRITE\\_ROUTING\\_INFO\\_CC](#)

Write Software Bus Routing Info to a File

## 2.16 cFE Software Bus Telemetry

The following are telemetry packets generated by the cFE Software Bus Task.

### Global `CFE_SB_AllSubscriptionsTlm_Payload_t`

SB Previous Subscriptions Packet

### Global `CFE_SB_AllSubscriptionsTlm_Payload_t`

SB Previous Subscriptions Packet

### Global `CFE_SB_HousekeepingTlm_Payload_t`

Software Bus task housekeeping Packet

### Global `CFE_SB_HousekeepingTlm_Payload_t`

Software Bus task housekeeping Packet

### Global `CFE_SB_SingleSubscriptionTlm_Payload_t`

SB Subscription Report Packet

### Global `CFE_SB_SingleSubscriptionTlm_Payload_t`

SB Subscription Report Packet

### Global `CFE_SB_StatsTlm_Payload_t`

SB Statistics Telemetry Packet

### Global `CFE_SB_StatsTlm_Payload_t`

SB Statistics Telemetry Packet

## 2.17 cFE Software Bus Configuration Parameters

The following are configuration parameters used to configure the cFE Software Bus either for each platform or for a mission as a whole.

### Global `CFE_MISSION_SB_MAX_PIPES`

Maximum Number of pipes that SB command/telemetry messages may hold

### Global `CFE_MISSION_SB_MAX_SB_MSG_SIZE`

Maximum SB Message Size

### Global `CFE_PLATFORM_ENDIAN`

Platform Endian Indicator

### Global `CFE_PLATFORM_SB_BUF_MEMORY_BYTES`

Size of the SB buffer memory pool

### Global `CFE_PLATFORM_SB_DEFAULT_MAP_FILENAME`

Default Message Map Filename

### Global `CFE_PLATFORM_SB_DEFAULT_MSG_LIMIT`

Default Subscription Message Limit

### Global `CFE_PLATFORM_SB_DEFAULT_PIPE_FILENAME`

Default Pipe Information Filename

**Global CFE\_PLATFORM\_SB\_DEFAULT\_ROUTING\_FILENAME**

Default Routing Information Filename

**Global CFE\_PLATFORM\_SB\_FILTERED\_EVENT1**

SB Event Filtering

**Global CFE\_PLATFORM\_SB\_HIGHEST\_VALID\_MSGID**

Highest Valid Message Id

**Global CFE\_PLATFORM\_SB\_MAX\_DEST\_PER\_PKT**

Maximum Number of unique local destinations a single MsgId can have

**Global CFE\_PLATFORM\_SB\_MAX\_MSG\_IDS**

Maximum Number of Unique Message IDs SB Routing Table can hold

**Global CFE\_PLATFORM\_SB\_MAX\_PIPES**

Maximum Number of Unique Pipes SB Routing Table can hold

## 2.18 cFE Table Services Overview

Applications often organize sets of their parameters into logical units called tables. These are typically constant parameters that can change the behavior of a flight software algorithm and are only intended to be modified by operations personnel. Examples of this would be attitude control gains, sensor scalefactors, telemetry filter settings, etc.

Table Services (TBL) provides a centralized control of flight software tables. Operations personnel would interact with TBL in order to dump the contents of current tables, load new table images, verify the contents of a table image and manage Critical tables.

None of the cFE core applications (EVS, SB, ES, TIME, or TBL) use tables, and it is possible to build cFE without Table Services if not needed or an alternative parameter management mechanism is to be utilized.

For additional detail on Tables and how to manage them, see the following sections:

- [Managing Tables](#)
- [cFE Table Types and Table Options](#)
- [Table Registry](#)
- [Table Services Telemetry](#)
- [Effects of Processor Reset on Tables](#)
- [Frequently Asked Questions about Table Services](#)

### 2.18.1 Managing Tables

In order to effectively manage tables, an operator needs to understand how cFE Applications manage tables from their end. There are a number of methods that cFE Applications typically use to manage their tables. Each method is appropriate based upon the nature of the contents of the table.

cFE Applications are required to periodically check to see if their table is to be validated, updated (or in the case of dump-only tables, dumped). Most Applications perform this periodic management at the same time as housekeeping requests are processed. This table management is performed by the cFE Application that "owns" a table (ie - the cFE Application that registered the table with cFE Table Services). It is possible for cFE Applications to "share" a table with other cFE Applications. An Application that shares a table does not typically perform any of the management duties associated with that table.

A table can have one of two different types and a number of different options. These are discussed further in later sections. An operator should understand the chosen type and selected options for a particular table before attempting to modify a table's contents.

To understand the methods of maintaining a table, it is important that the terminology be clear. A table has two images: "Active" and "Inactive". The Active table is the one that a cFE Application is currently accessing when it executes. The Inactive table is a copy of the Active table that an operator (or on-board process such as a stored command processor) can manipulate and change to have a newly desired set of data.

To create an Inactive table image on board, the operator would be required to perform a "Load" to the table. Loads are table images stored in on-board files. The Load can contain either a complete table image or just a part of a table image. If the Load contains just a portion, the Inactive image is first initialized with the contents of the Active image and then the portion identified in the Load file is written on top of the Active image. After the initial Load, an operator can continue to manipulate the Inactive table image with additional partial table load images. This allows the operator to reconfigure the contents of multiple portions of the table before deciding to "Validate" and/or "Activate" it.

Some cFE Applications provide special functions that will examine a table image to determine if the contents are logically sound. This function is referred to as the "Validation Function." When a cFE Application assigns a Validation Function to a table during the table registration process, it is then requiring that a Validation be performed before the table can be Activated. When an operator requests a Validation of a table image, they are sending a request to the owning Application to execute the associated Validation Function on that image. The results of this function are then reported in telemetry. If the Validation is successful, the operator is free to perform a table Activation. If the Validation fails, the operator would be required to make additional changes to the Inactive table image and attempt another Validation before commanding an Activation.

To change an Inactive table image into the Active table image, an operator must Activate a table. When an operator sends the table Activation command, they are notifying the table's owning Application that a new table image is available. It is then up to the Application to determine when is the best time to perform the "Update" of the table. When an Application performs an Update, the contents of the Inactive table image become the Active table image.

Next: [cFE Table Types and Table Options](#)  
Up To: [cFE Table Services Overview](#)

### 2.18.2 cFE Table Types and Table Options

A cFE Application Developer has several choices when creating a cFE Application. There are two basic types of tables: single buffered and double buffered. In addition to these two basic types there are a small variety of options possible with each table. These options control special characteristics of the table such as whether it is dump-only, critical or whether it has an application defined location in memory.

Each choice has its advantages and disadvantages. The developer chooses the appropriate type based upon the requirements of the application. Anyone operating a particular cFE Application must understand the nature of the type and options selected for a particular table before they can successfully understand how to perform updates, validations, etc.

For more information on the different types of tables available, see the following sections:

- Table Types
  - Single Buffered Tables
  - Double Buffered Tables
- Table Options
  - Tables with Validation Functions
  - Critical Tables
  - User Defined Address Tables
  - Dump Only Tables

Next: [Single Buffered Tables](#)

Prev: [Managing Tables](#)

Up To: [cFE Table Services Overview](#)

#### 2.18.2.1 Single Buffered Tables

The default table type for a cFE Application to use is a single buffered table. The principle advantage of a single buffered table is that it can share one of several shared table buffers for uploaded and pending table images. Since many cFE Applications have relatively small tables that are not changed at time critical moments or are not changed very often during a mission, single buffered tables represent the most memory resource efficient method of being managed.

The number of single buffered tables that can have inactive table images being manipulated at one time is specified by a TBL Services configuration parameter ([CFE\\_PLATFORM\\_TBL\\_MAX\\_SIMULTANEOUS\\_LOADS](#)) found in the `cfe_platform_cfg.h` file associated with the processor in question. This parameter identifies the number of shared table buffers that are available.

Since inactive single buffered table images share a common resource, it may not be prudent for an operator to load an image and then delay on the image's activation for an extended period of time.

Single buffered tables are allowed to be critical (see [Critical Tables](#)), dump-only (see [Dump Only Tables](#)) and/or have a user-defined address (see [User Defined Address Tables](#)).

Next: [Double Buffered Tables](#)

Up To: [cFE Table Types and Table Options](#)

### 2.18.2.2 Double Buffered Tables

Under certain conditions, a cFE Application Developer may choose to use a double buffered table type within their application. Double buffered tables retain a dedicated inactive image of the table data. With a dedicated inactive table image available, double buffered tables are then capable of efficiently swapping table contents and/or delaying the activation of a table's contents for an indeterminate amount of time.

Some cFE Applications prefer to delay the Activation of a table until a specified time (e.g. - a Spacecraft Ephemeris). These tables are typically defined as double buffered tables so that the Inactive image can be left sitting untouched for an extended period of time without interfering with shared resources for other tables. Then the Application can perform the Update when the time is right.

Applications which have unusually large tables may decide to conserve memory resources by making them double buffered. This is because the shared buffers used by single buffered tables must be sized to match the largest table. If there is one table that is unusually large, there is little reason to allocate up to `CFE_PLATFORM_TBL_MAX_SIMULTANEOUS_LOADS` number of buffers that size. A double buffered table will only allocate ONE extra buffer of that size.

Performance minded Applications that are required to perform processing with tight timing deadlines may choose to use double buffered tables because the Update for a double buffered table is deterministic and quick.

Next: [Tables with Validation Functions](#)

Prev: [Single Buffered Tables](#)

Up To: [cFE Table Types and Table Options](#)

### 2.18.2.3 Tables with Validation Functions

Applications that associate Validation Functions with their tables when the tables are registered are effectively requiring that the contents of a table be logically Validated before it is Activated. The cFE will refuse to let a table with an associated Validation Function be Activated until a successful Validation on the Inactive table image has occurred.

Tables that are NOT assigned a Validation Function are assumed to be valid regardless of the contents of the table image. These tables do not require a Validation Command prior to Activation.

Next: [Critical Tables](#)

Prev: [Double Buffered Tables](#)

Up To: [cFE Table Types and Table Options](#)

### 2.18.2.4 Critical Tables

Applications that must be able to recover quickly from a Processor Reset may select the "Critical" table option when registering their table. Table Services automatically creates a Critical Data Store for the table and ensures that the contents of the Critical Data Store are updated whenever a Table Activation occurs.

If a Processor Reset happens, when the Application attempts to Register the table again, Table Services automatically locates the associated Critical Data Store and initializes the Table with the saved contents.

Next: [User Defined Address Tables](#)

Prev: [Tables with Validation Functions](#)

Up To: [cFE Table Types and Table Options](#)

### 2.18.2.5 User Defined Address Tables

In order to provide a mechanism for Flight Software Maintenance teams to quickly create a table image for dumping contents of memory that isn't normally loaded by the ground, there is an option to create User-Defined Address tables. These tables, when they are first registered, provide a memory address where the Active image of the table is to be maintained. Normally, the address is specified by Table Services from its memory pool.

By specifying the address, the Flight Software Maintenance team can create a Dump-Only table that contains the contents of a data structure that is not normally accessible via telemetry or table dumps. Then, on command, the Flight Software Maintenance team can periodically dump the data structure's contents to an on-board file(s) that can then be transferred to the ground for later analysis.

Next: [Dump Only Tables](#)

Prev: [Critical Tables](#)

Up To: [cFE Table Types and Table Options](#)

### 2.18.2.6 Dump Only Tables

On occasion, cFE Applications require a segment of memory in which the Application writes data. The typical cFE Table is not normally modified directly by an Application but only via Load and Activate commands from either the Ground or Stored Command Processor. However, for those situations where an Application wishes to modify the contents of a data structure and the Application is limited in its telemetry bandwidth so that the modified data cannot be telemetered, the Application can create a Dump-Only table.

Dump-Only tables are not allowed to be modified via the Load/Validate/Activate process most other tables are. They are only supposed to be modified by onboard Applications. The Operator can still command a Dump which will be processed by the table's owning Application when it manages its tables. By letting the Application perform the dump, the Operator can feel confident that the table contents are a complete snapshot in time and not corrupted by taking a snapshot while the Application was in the process of modifying its contents.

Next: [Table Registry](#)

Prev: [User Defined Address Tables](#)

Up To: [cFE Table Types and Table Options](#)

### 2.18.3 Table Registry

When Applications register tables, Table Services retains pertinent information on the table in the Table Registry. The following information (along with other information that is less important for an operator) is kept for each table:

- The Application ID of the Application that Registered the table
- The full name of the table
- The size, in bytes, of the table
- Pointers to the start addresses of the Table's image buffers, Active and Inactive (if appropriate)
- A pointer to the start address of a Validation Function
- A flag indicating whether a table image has been loaded into an Inactive buffer
- A flag indicating whether the table is Critical and its associated CDS Handle if it is

- A flag indicating whether the table has ever been loaded (initialized)
- A flag indicating whether the table is Dump Only
- A flag indicating whether the table has an Update Pending
- A flag indicating whether the table is double buffered or not
- The System Time when the Table was last Updated
- The filename of the last file loaded into the table
- The File Creation Time for the last file used to load the contents of the table

This information can be obtained by either sending the Dump Registry command which will put all of the information from the Table Registry into an onboard file for later downlink or the operator can send a command to Telemeter the Registry Entry for a single table. This will cause the pertinent registry entry for a single table to be sent via a telemetry packet.

The API function [CFE\\_TBL\\_Register\(\)](#) returns either CFE\_SUCCESS or CFE\_TBL\_INFO\_RECOVERED\_TBL to indicate that the table was successfully registered. The difference is whether the table data was recovered from CDS as part of the registration. There are several error return values that describe why the function failed to register the table but nothing related to why the restoration from CDS might have failed. There is, however, a message written to the System Error Log by Table Services that can be dumped by the ground to get this information. Note that failure to restore a table from CDS is not an expected error and requires some sort of data corruption to occur.

Next: [Table Services Telemetry](#)  
Prev: [cFE Table Types and Table Options](#)  
Up To: [cFE Table Services Overview](#)

#### 2.18.4 Table Services Telemetry

Table Services produces two different telemetry packets. The first packet, referred to as the Table Services Housekeeping Packet, is routinely produced by Table Services upon receipt of the Housekeeping Request message that is typically sent to all Applications by an on board scheduler. The contents and format of this packet are described in detail at [CFE\\_TBL\\_HousekeepingTlm\\_t](#).

Next: [Effects of Processor Reset on Tables](#)  
Prev: [Table Registry](#)  
Up To: [cFE Table Services Overview](#)

#### 2.18.5 Effects of Processor Reset on Tables

When a processor resets, the Table Registry is re-initialized. All Applications must, therefore, re-register and re-initialize their tables. The one exception, however, is if the Application has previously tagged a table as "Critical" during Table Registration, then Table Services will attempt to locate a table image for that table stored in the Critical Data Store. Table Services also attempts to locate the Critical Table Registry which is also maintained in the Critical Data Store.

If Table Services is able to find a valid table image for a Critical table in the Critical Data Store, the contents of the table are automatically loaded into the table and the Application is notified that the table does not require additional initialization.

Next: [Frequently Asked Questions about Table Services](#)  
Prev: [Table Services Telemetry](#)  
Up To: [cFE Table Services Overview](#)

#### 2.18.6 Frequently Asked Questions about Table Services

<b>(Q) Is it an error to load a table image that is smaller than the registered size?</b>	
	<p>Table images that are smaller than the declared size of a table fall into one of two categories. If the starting offset of the table image (as specified in the Table Image secondary file header) is not equal to zero, then the table image is considered to be a "partial" table load. Partial loads are valid as long as a table has been previously loaded with a non-"partial" table image.</p> <p>If the starting offset of the table image is zero and the size is less than the declared size of the table, the image is considered "short" but valid. This feature allows application developers to use variable length tables.</p>
<b>(Q) I tried to validate a table and received the following event message that said the event failed:</b>	
<pre>"MyApp validation failed for Inactive 'MyApp.MyTable', Status=0x####"</pre>	
<b>What happened?</b>	
	<p>The event message indicates the application who owns the table has discovered a problem with the contents of the image. The code number following the 'Status' keyword is defined by the Application. The documentation for the specified Application should be referred to in order to identify the exact nature of the problem.</p>
<b>(Q) What commands do I use to load a table with a new image?</b>	
	<p>There are a number of steps required to load a table.</p> <ol style="list-style-type: none"> <li>1. The operator needs to create a cFE Table Services compatible table image file with the desired data contained in it. This can be accomplished by creating a 'C' source file, compiling it with the appropriate cross compiler for the onboard platform and then running the <code>e1f2cfetbl</code> utility on the resultant object file.</li> <li>2. The file needs to be loaded into the onboard processor's filesystem using whichever file transfer protocol is used for that mission.</li> <li>3. The <a href="#">Load Command</a> is sent next to tell Table Services to load the table image file into the Inactive Table Image Buffer for the table identified in the file.</li> <li>4. The <a href="#">Validate Command</a> is then sent to validate the contents of the inactive table image. This will ensure the file was not corrupted or improperly defined. The results of the validation are reported in Table Services Housekeeping Telemetry. If a table does not have a validation function associated with it, the operator may wish to compare the computed CRC to verify the table contents match what was intended.</li> <li>5. Upon successful validation, the operator then sends the <a href="#">Activate Command</a>. The application owning the table should, within a reasonable amount of time, perform a table update and send an event message.</li> </ol>
<b>(Q) What causes cFE Table Services to generate the following sys log message:</b>	
<p><b><i>CFE_TBL:GetAddressInternal-App(%d) attempt to access unowned Tbl Handle=%d</i></b></p>	
	<p>When an application sharing its table(s) with one or more applications is reloaded, the reloaded application's table handle(s) are released. cFE Table Services sees that the table(s) are shared and keeps a 'shadow' version of the table in the Table Services registry. The registry will show the released, shared tables with no name. When the applications sharing the table attempt to access the table via the 'old', released handle, Table Services will return an error code to the applications and generate the sys log message. The applications may then unregister the 'old' handle(s) in order to remove the released, shared table(s) from the Table Services registry and share the newly loaded application table(s).</p>
<b>(Q) When does the Table Services Abort Table Load command need to be issued?</b>	

The Abort command should be used whenever a table image has been loaded but the application has not yet activated it and the operator no longer wants the table to be loaded.

The purpose of the Abort command is to free a previously allocated table buffer. It should be noted, however, that multiple table loads to the SAME table without an intervening activation or abort, will simply OVERWRITE the previous table load using the SAME buffer.

Therefore, the most likely scenarios that would lead to a needed abort are as follows:

1. Operator loads a table and realizes immediately that the load is not wanted.
2. Operator loads a table and performs a validation on it. Regardless of whether the table passes or fails the validation, if the operator no longer wants to activate the table, the abort command should be issued.
3. A table image was loaded; the image was successfully validated; the command for activation was sent; but the application fails to perform the activation.

The Abort command will free the table buffer and clear the activation request.

This situation can occur when either the application is improperly designed and fails to adequately manage its tables (sometimes seen in the lab during development) or the application is "hung" and not performing as it should.

Prev: [Effects of Processor Reset on Tables](#)

Up To: [cFE Table Services Overview](#)

## 2.19 cFE Table Services Commands

Upon receipt of any command, the Table Services application will confirm that the message length embedded within the header (from `CFE_MSG_GetSize()`) matches the expected length of that message, based on the size of the C structure defining that command. If there is any discrepancy between the expected and actual message size, TBL will generate the `CFE_TBL_LEN_ERR_EID` event, increment the command error counter (`$sc_$cpu_TBL_CMDEC`), and the command will *not* be accepted for processing.

The following is a list of commands that are processed by the cFE Table Services Task.

### **Global `CFE_TBL_ABORT_LOAD_CC`**

Abort Table Load

### **Global `CFE_TBL_ACTIVATE_CC`**

Activate Table

### **Global `CFE_TBL_DELETE_CDS_CC`**

Delete Critical Table from Critical Data Store

### **Global `CFE_TBL_DUMP_CC`**

Dump Table

### **Global `CFE_TBL_DUMP_REGISTRY_CC`**

Dump Table Registry

### **Global `CFE_TBL_LOAD_CC`**

Load Table

**Global CFE\_TBL\_NOOP\_CC**

Table No-Op

**Global CFE\_TBL\_RESET\_COUNTERS\_CC**

Table Reset Counters

**Global CFE\_TBL\_SEND\_REGISTRY\_CC**

Telemeter One Table Registry Entry

**Global CFE\_TBL\_VALIDATE\_CC**

Validate Table

## 2.20 cFE Table Services Telemetry

The following are telemetry packets generated by the cFE Table Services Task.

**Global CFE\_TBL\_HousekeepingTlm\_Payload\_t**

Table Services Housekeeping Packet

**Global CFE\_TBL\_HousekeepingTlm\_Payload\_t**

Table Services Housekeeping Packet

**Global CFE\_TBL\_TblRegPacket\_Payload\_t**

Table Registry Info Packet

**Global CFE\_TBL\_TblRegPacket\_Payload\_t**

Table Registry Info Packet

## 2.21 cFE Table Services Configuration Parameters

The following are configuration parameters used to configure the cFE Table Services either for each platform or for a mission as a whole.

**Global CFE\_MISSION\_TBL\_MAX\_FULL\_NAME\_LEN**

Maximum Length of Full Table Name in messages

**Global CFE\_MISSION\_TBL\_MAX\_NAME\_LENGTH**

Maximum Table Name Length

**Global CFE\_PLATFORM\_TBL\_BUF\_MEMORY\_BYTES**

Size of Table Services Table Memory Pool

**Global CFE\_PLATFORM\_TBL\_DEFAULT\_REG\_DUMP\_FILE**

Default Filename for a Table Registry Dump

**Global CFE\_PLATFORM\_TBL\_MAX\_CRITICAL\_TABLES**

Maximum Number of Critical Tables that can be Registered

**Global CFE\_PLATFORM\_TBL\_MAX\_DBL\_TABLE\_SIZE**

Maximum Size Allowed for a Double Buffered Table

**Global CFE\_PLATFORM\_TBL\_MAX\_NUM\_HANDLES**

Maximum Number of Table Handles

**Global CFE\_PLATFORM\_TBL\_MAX\_NUM\_TABLES**

Maximum Number of Tables Allowed to be Registered

**Global CFE\_PLATFORM\_TBL\_MAX\_NUM\_VALIDATIONS**

Maximum Number of Simultaneous Table Validations

**Global CFE\_PLATFORM\_TBL\_MAX\_SIMULTANEOUS\_LOADS**

Maximum Number of Simultaneous Loads to Support

**Global CFE\_PLATFORM\_TBL\_MAX\_SNGL\_TABLE\_SIZE**

Maximum Size Allowed for a Single Buffered Table

**Global CFE\_PLATFORM\_TBL\_VALID\_PRID\_1**

Processor ID values used for table load validation

**Global CFE\_PLATFORM\_TBL\_VALID\_PRID\_COUNT**

Number of Processor ID's specified for validation

**Global CFE\_PLATFORM\_TBL\_VALID\_SCID\_1**

Spacecraft ID values used for table load validation

**Global CFE\_PLATFORM\_TBL\_VALID\_SCID\_COUNT**

Number of Spacecraft ID's specified for validation

## 2.22 cFE Time Services Overview

The cFE Time Service (TIME) is one of the cFE core services. TIME provides time correlation, distribution and synchronization services. TIME exists in two varieties: a Time Server responsible for maintaining the master time reference for all remote systems, and a Time Client responsible for synchronizing to that master time reference.

Since TIME is a generic implementation aimed to meet the needs of a variety of mission configurations, there are numerous configuration parameters, which dictate the behavior of TIME (see `cfe_mission_cfg.h` and `cfe_platform_cfg.h` for the specific mission configuration).

With the exception of those sections specific to Time Clients and Servers, this document assumes the most common physical environment - one instantiation of cFE installed on a single processor. Therefore, TIME represents cFE Time Services configured as a Time Server.

For additional detail on Time Services and how to manage it, see the following sections:

- [Time Components](#)
- [Time Structure](#)
- [Time Formats](#)
- [Time Configuration](#)
  - [Time Format Selection](#)

- Enabling Fake Tone Signal
  - Selecting Tone and Data Ordering
  - Specifying Tone and Data Window
  - Specifying Time Server/Client
  - Specifying Time Tone Byte Order
  - Virtual MET
  - Specifying Time Source
  - Specifying Time Signal
- Time Services Paradigm(s)
  - Flywheeling
  - Time State
  - Initialization
    - Power-On Reset
    - Processor Reset
  - Initialization
    - Power-On Reset
    - Processor Reset
  - Normal Operation
    - Client
    - Server
      - \* Setting Time
      - \* Adjusting Time

- \* Setting MET
- Frequently Asked Questions

### 2.22.1 Time Components

Time knowledge is stored in several pieces, so that the time information can more easily be manipulated and utilized. These components include:

The **Ground Epoch** is an arbitrary date and time that establishes the zero point for spacecraft time calculations. The selection of the epoch is mission specific, although in the past, it was common to select the same epoch as defined for the Operating System used by the computers hosting the ground system software. Recent mission epoch selections have also included using zero seconds after midnight, Jan 1, 2001.

**Spacecraft Time** is the number of seconds (and fraction of a second) since the ground epoch. Spacecraft time is the sum of **Mission Elapsed Time** (MET) and the **Spacecraft Time Correlation Factor** (STCF). By definition, MET is a measure of time since launch or separation. However, for most missions the MET actually represents the amount of time since powering on the hardware containing the MET timer. The STCF correlates the MET to the ground epoch.

The **Tone** is the signal that MET seconds have incremented. In most hardware configurations, the tone is synonymous with the **1 PPS** signal. The tone signal may be generated by a local hardware timer, or by an external event (G↔PS receiver, spacewire time tick, 1553 bus signal, etc). TIME may also be configured to simulate the tone for lab environments that do not have the necessary hardware to provide a tone signal. Note that MET sub-seconds will be zero at the instant of the tone.

**Time at the Tone** is the spacecraft time at the most recent "valid" tone.

**Time since the Tone** is the amount of time since the tone (usually less than one second). This value is often measured using the local processor clock. Upon detecting the tone signal, TIME stores the contents of the local processor clock to facilitate this measurement.

Thus, **Current Spacecraft Time** is the sum of "time at the tone" and "time since the tone".

**Leap Seconds** occur to keep clocks correlated to astronomical observations. The modern definition of a second (9,192,631,770 oscillations of a cesium-133 atom) is constant while the earth's rotation has been slow by a small fraction of a second per day. The **International Earth Rotation and Reference System Service** (IERS) maintains the count of leap seconds as a signed whole number that is subject to update twice a year. Although it is possible to have a negative leap second count if the earth rotates too fast, it is highly unlikely. The initial count of leap seconds (10) was established in January of 1972 and the first leap second was added to the initial count in June of 1972. The most recent leap seconds are announced by the International Earth Rotation Service (IERS): <https://www.iers.org> in IERS Bulletin C (leap second announcements). Search the IERS site for "Bulletin C" to obtain the latest issue/announcement.

Next: [Time Structure](#)  
Up To: [cFE Time Services Overview](#)

### 2.22.2 Time Structure

The cFE implementation of the **System Time Structure** is a modified version of the CCSDS Unsegmented Time Code (CUC) which includes 4 bytes of seconds, and 4 bytes of subseconds, where a subsecond is equivalent to  $1/(2^{32})$  seconds. The system time structure is used by TIME to store current time, time at the tone, time since the tone, the MET, the STCF and command arguments for time adjustments. Note that typically the 32 bits of seconds and the upper 16 bits of subseconds are used for time stamping Software bus messages, but this is dependent on the underlying definition.

The system time structure is defined as follows:

```
typedef struct {
    uint32    Seconds;      /* Number of seconds */
    uint32    Subseconds;   /* Number of 2^(-32) subseconds */
} CFE_TIME_SysTime_t;
```

Next: [Time Formats](#)

Prev: [Time Components](#)

Up To: [cFE Time Services Overview](#)

### 2.22.3 Time Formats

**International Atomic Time** (TAI) is one of two time formats supported by cFE TIME. TAI is the number of seconds and sub-seconds elapsed since the ground epoch as measured with the atomic clock previously described. TAI has no reference to leap seconds and is calculated using the following equation:

$$\text{TAI} = \text{MET} + \text{STCF}$$

It should be noted that TAI is only "true" TAI when the selected ground epoch is the same as the TAI epoch (zero seconds after midnight, January 1, 1958). However, nothing precludes configuring cFE TIME to calculate time in the TAI format and setting the STCF to correlate to any other epoch definition.

**Coordinated Universal Time** (UTC) is the other time format supported by cFE TIME. UTC differs from TAI in the fact that UTC includes a leap seconds adjustment. TIME computes UTC using the following equation:

$$\text{UTC} = \text{TAI} - \text{Leap Seconds.}$$

The preceding UTC equation might seem to imply that TAI includes leap seconds and UTC does not - which is not the case. In fact, the UTC calculation includes a leap seconds adjustment that subtracts leap seconds from the same time components used to create TAI. Alternatively, it might be less confusing to express the UTC equation as follows:

$$\text{UTC} = \text{MET} + \text{STCF} - \text{Leap Seconds}$$

Next: [Time Configuration](#)

Prev: [Time Components](#)

Up To: [cFE Time Services Overview](#)

#### 2.22.4 Time Configuration

All configurations of TIME require a local processor source for a 1Hz interrupt and access to a local clock with a resolution fine enough that it can be used to measure short periods of elapsed time. The local interrupt is used to wake-up TIME at a regular interval for the purpose of verifying that the tone is being received. The local clock is used to measure time since the tone and to provide coarse verification that the tone is occurring at approximately one second intervals. The presumption is that the tone is the most accurate timer in the system and, within reason, is to be trusted. Note that nothing precludes the use of the MET as the local clock, assuming the MET is both local and provides sub-second data. However, the tone must not be used as the source for the local 1Hz interrupt.

Consider the following brief description of three hypothetical hardware configurations. These sample systems may be used as reference examples to help clarify the descriptions of the various TIME configuration selections.

In the first system, there is no MET timer and therefore no tone signal. The MET is a count of the number of "fake" tones generated by TIME software. There is no validation performed regarding the quality of time data. This hardware configuration is a common lab environment using COTS equipment.

In the second system, the MET timer is a hardware register that is directly accessible by TIME. When MET seconds increment, a processor interrupt signals the tone. Upon detecting the tone, TIME can read the MET to establish the time at the tone. To verify that the tone is valid, TIME need only validate that this tone signal occurred approximately one second after the previous tone signal (as measured with the local clock).

In the third system, the MET is located on hardware connected via spacewire. When MET seconds increment, a spacewire time tick triggers a local processor interrupt to signal the tone. Shortly after announcing the tone, the hardware containing the MET also generates a spacewire data packet containing the MET value corresponding to the tone. TIME must wait until both the tone and data packet have been received before validating the tone. The tone must have occurred approximately one second after the previous tone signal and the data packet must have been received within a specified window in time following the tone.

The hardware design choice for how the tone signal is distributed is not material to TIME configuration. The software detecting the tone need only call the cFE API function announcing the arrival of the tone. This function is designed to be called from interrupt handlers.

For detail on each of the individual configuration settings for cFE Time Services, see the following sections:

- [Time Format Selection](#)
- [Enabling Fake Tone Signal](#)
- [Selecting Tone and Data Ordering](#)
- [Specifying Tone and Data Window](#)
- [Specifying Time Server/Client](#)
- [Specifying Time Tone Byte Order](#)
- [Virtual MET](#)

- [Specifying Time Source](#)
- [Specifying Time Signal](#)

Next: [Time Services Paradigm\(s\)](#)

Prev: [Time Formats](#)

Up To: [cFE Time Services Overview](#)

#### 2.22.4.1 Time Format Selection

Time format is defined in the mission configuration header file.

This selection defines the default time format as TAI or UTC. The API functions to get time in either specific format are still enabled, but the API function to get time in the default format will follow this selection. Enable one, and **only one**, of the following time format definitions:

```
#define CFE_MISSION_TIME_CFG_DEFAULT_TAI  TRUE  
#define CFE_MISSION_TIME_CFG_DEFAULT_UTC  FALSE
```

or

```
#define CFE_MISSION_TIME_CFG_DEFAULT_TAI  FALSE  
#define CFE_MISSION_TIME_CFG_DEFAULT_UTC  TRUE
```

The choice of time format is a mission specific decision and is not directly affected by the hardware configuration.

See also

[CFE\\_MISSION\\_TIME\\_CFG\\_DEFAULT\\_TAI](#), [CFE\\_MISSION\\_TIME\\_CFG\\_DEFAULT\\_UTC](#)

Next: [Enabling Fake Tone Signal](#)

Up To: [Time Configuration](#)

#### 2.22.4.2 Enabling Fake Tone Signal

The fake tone is defined in the mission configuration header file.

If this selection is set to TRUE, TIME will generate a "fake" tone signal by calling the same API function as would be called upon detection of the "real" tone signal. Enable the fake tone only for hardware configurations that do not provide a tone signal.

```
#define CFE_MISSION_TIME_CFG_FAKE_TONE  TRUE
```

Hypothetical hardware configuration number one (described above) would enable the fake tone signal.

See also

[CFE\\_MISSION\\_TIME\\_CFG\\_FAKE\\_TONE](#)

Next: [Selecting Tone and Data Ordering](#)

Prev: [Time Format Selection](#)

Up To: [Time Configuration](#)

#### 2.22.4.3 Selecting Tone and Data Ordering

Tone and data order is defined in the mission configuration header file.

This selection defines which comes first - the tone or the time at the tone data. Does the time data describe the tone that already occurred, or the tone that has not yet occurred? This decision may be driven by the hardware design but can also be arbitrary. Enable one, and only one, of the following:

```
#define CFE_MISSION_TIME_AT_TONE_WAS  
#define CFE_MISSION_TIME_AT_TONE_WILL_BE
```

Hypothetical hardware configuration number three (described [Time Configuration](#) above) would enable "time at the tone was".

##### See also

[CFE\\_MISSION\\_TIME\\_AT\\_TONE\\_WAS](#), [CFE\\_MISSION\\_TIME\\_AT\\_TONE\\_WILL\\_BE](#)

Next: [Specifying Tone and Data Window](#)

Prev: [Enabling Fake Tone Signal](#)

Up To: [Time Configuration](#)

#### 2.22.4.4 Specifying Tone and Data Window

The tone and data window is defined in the mission configuration header file.

In concert with the definition of tone and data order, this selection defines the valid window in time for the second of the pair to follow the first. Both must be defined, units are micro-seconds.

```
#define CFE_MISSION_TIME_MIN_ELAPSED 0  
#define CFE_MISSION_TIME_MAX_ELAPSED 100000
```

Hypothetical hardware configuration number three (described above) might use these values which describe a window that begins immediately after the tone and lasts for one tenth of a second.

##### See also

[CFE\\_MISSION\\_TIME\\_MIN\\_ELAPSED](#), [CFE\\_MISSION\\_TIME\\_MAX\\_ELAPSED](#)

Next: [Specifying Time Server/Client](#)

Prev: [Selecting Tone and Data Ordering](#)

Up To: [Time Configuration](#)

#### 2.22.4.5 Specifying Time Server/Client

Configure TIME as a client only when the target system has multiple processors running separate instantiations of the cFE. One instantiation must be configured as the server and the remainder configured as clients. If the target system has only one processor running the cFE, then TIME must be configured as a server.

Enable one, and only one, of the following definitions in the platform configuration header file:

```
#define CFE_PLATFORM_TIME_CFG_SERVER    TRUE  
#define CFE_PLATFORM_TIME_CFG_CLIENT    FALSE
```

or

```
#define CFE_PLATFORM_TIME_CFG_SERVER    FALSE  
#define CFE_PLATFORM_TIME_CFG_CLIENT    TRUE
```

#### See also

[CFE\\_PLATFORM\\_TIME\\_CFG\\_SERVER](#), [CFE\\_PLATFORM\\_TIME\\_CFG\\_CLIENT](#)

Next: [Specifying Time Tone Byte Order](#)

Prev: [Specifying Tone and Data Window](#)

Up To: [Time Configuration](#)

#### 2.22.4.6 Specifying Time Tone Byte Order

By default, the CFE time tone message is a payload of integers in platform-endian order (containing the tone's timestamp, the leap seconds, and state information.) In some configurations, it may be better to have the payload produced in big-endian order—particularly in mixed-endian environments.

In order to force the tone message to be in big-endian order, you must define the following:

```
#define CFE_PLATFORM_TIME_CFG_BIGENDIAN
```

Next: [Virtual MET](#)

Prev: [Specifying Time Server/Client](#)

Up To: [Time Configuration](#)

#### 2.22.4.7 Virtual MET

This configuration option refers to whether the MET is local to this instantiation of TIME. If the MET is not local then TIME must be configured as using a virtual MET.

Therefore, all TIME clients must be configured as using a virtual MET. If the MET was local to any TIME client, then that instantiation of TIME would have to be the server.

TIME servers must be configured as using a virtual MET

Next: [Specifying Time Source](#)

Prev: [Specifying Time Tone Byte Order](#)

Up To: [Time Configuration](#)

#### 2.22.4.8 Specifying Time Source

TIME configuration provides the ability to specify where the source for time data is originating - either internal or external. In hypothetical system one, the MET is internal. In system two, TIME cannot directly read the MET, therefore time data must be received from an external source.

This selection also enables a command interface to switch between internal and external input. When commanded to use internal time data, TIME will ignore the external data. However, TIME will continue to use the API function as the trigger to generate a "time at the tone" command packet regardless of the internal/external command selection.

Set the following definition to TRUE only for TIME servers using an external time data source.

```
#define CFE_PLATFORM_TIME_CFG_SOURCE TRUE
```

The remainder of this section pertains only to TIME servers configured to accept external time data.

When configured to accept external time data, TIME requires an additional definition for the type of external data (GPS, MET, spacecraft time, etc.). This selection will enable an API function specific to the selected data type. Regardless of how the time data is received, the receiver need only pass the data to the appropriate API function.

TIME servers using an external time data source must set one, and only one, of the following to TRUE, for example:

```
#define CFE_PLATFORM_TIME_CFG_SRC_MET TRUE
#define CFE_PLATFORM_TIME_CFG_SRC_GPS FALSE
#define CFE_PLATFORM_TIME_CFG_SRC_TIME FALSE
```

configuration definitions for the particular source.

If the cfe\_platform\_cfg.h file contains "#define CFE\_PLATFORM\_TIME\_CFG\_SOURCE TRUE" then time is configured to allow switching between internal and external time sources (see [CFE\\_TIME\\_SET\\_SOURCE\\_CC](#)). If this configuration parameter is set to FALSE then the command to set the source will be rejected.

If this configuration parameter is set to TRUE then ONE and ONLY ONE of the following configuration parameters must also be set TRUE in order to specify the external time source, for example:

```
#define CFE_PLATFORM_TIME_CFG_SRC_MET TRUE
#define CFE_PLATFORM_TIME_CFG_SRC_GPS FALSE
#define CFE_PLATFORM_TIME_CFG_SRC_TIME FALSE
```

Note that Internal MET source depends on available hardware. It may be the local count of tone signals, the contents of a hardware register or an OS specific time function.

Note also that when configured to use an external time source, commands to set the time will be overwritten.

#### See also

[CFE\\_PLATFORM\\_TIME\\_CFG\\_SRC\\_MET](#), [CFE\\_PLATFORM\\_TIME\\_CFG\\_SRC\\_GPS](#), [CFE\\_PLATFORM\\_TIME\\_CFG\\_SRC\\_TIME](#)

Next: [Specifying Time Signal](#)

Prev: [Virtual MET](#)

Up To: [Time Configuration](#)

#### 2.22.4.9 Specifying Time Signal

Some hardware configurations support a primary and redundant tone signal selection. Setting the following configuration definition to TRUE will result in enabling a TIME command to select the active tone signal.

```
#define CFE_PLATFORM_TIME_CFG_SIGNAL TRUE
```

Note: this feature requires additional custom software to make the physical signal switch.

#### See also

[CFE\\_PLATFORM\\_TIME\\_CFG\\_SIGNAL](#)

Next: [Time Services Paradigm\(s\)](#)

Prev: [Specifying Time Source](#)

Up To: [Time Configuration](#)

#### 2.22.5 Time Format Selection

Time format is defined in the mission configuration header file.

This selection defines the default time format as TAI or UTC. The API functions to get time in either specific format are still enabled, but the API function to get time in the default format will follow this selection. Enable one, and **only one**, of the following time format definitions:

```
#define CFE_MISSION_TIME_CFG_DEFAULT_TAI TRUE  
#define CFE_MISSION_TIME_CFG_DEFAULT_UTC FALSE
```

or

```
#define CFE_MISSION_TIME_CFG_DEFAULT_TAI FALSE  
#define CFE_MISSION_TIME_CFG_DEFAULT_UTC TRUE
```

The choice of time format is a mission specific decision and is not directly affected by the hardware configuration.

#### See also

[CFE\\_MISSION\\_TIME\\_CFG\\_DEFAULT\\_TAI](#), [CFE\\_MISSION\\_TIME\\_CFG\\_DEFAULT\\_UTC](#)

Next: [Enabling Fake Tone Signal](#)

Up To: [Time Configuration](#)

## 2.22.6 Enabling Fake Tone Signal

The fake tone is defined in the mission configuration header file.

If this selection is set to TRUE, TIME will generate a "fake" tone signal by calling the same API function as would be called upon detection of the "real" tone signal. Enable the fake tone only for hardware configurations that do not provide a tone signal.

```
#define CFE_MISSION_TIME_CFG_FAKE_TONE    TRUE
```

Hypothetical hardware configuration number one (described above) would enable the fake tone signal.

See also

[CFE\\_MISSION\\_TIME\\_CFG\\_FAKE\\_TONE](#)

Next: [Selecting Tone and Data Ordering](#)

Prev: [Time Format Selection](#)

Up To: [Time Configuration](#)

## 2.22.7 Selecting Tone and Data Ordering

Tone and data order is defined in the mission configuration header file.

This selection defines which comes first - the tone or the time at the tone data. Does the time data describe the tone that already occurred, or the tone that has not yet occurred? This decision may be driven by the hardware design but can also be arbitrary. Enable one, and only one, of the following:

```
#define CFE_MISSION_TIME_AT_TONE_WAS  
#define CFE_MISSION_TIME_AT_TONE_WILL_BE
```

Hypothetical hardware configuration number three (described [Time Configuration](#) above) would enable "time at the tone was".

See also

[CFE\\_MISSION\\_TIME\\_AT\\_TONE\\_WAS](#), [CFE\\_MISSION\\_TIME\\_AT\\_TONE\\_WILL\\_BE](#)

Next: [Specifying Tone and Data Window](#)

Prev: [Enabling Fake Tone Signal](#)

Up To: [Time Configuration](#)

### 2.22.8 Specifying Tone and Data Window

The tone and data window is defined in the mission configuration header file.

In concert with the definition of tone and data order, this selection defines the valid window in time for the second of the pair to follow the first. Both must be defined, units are micro-seconds.

```
#define CFE_MISSION_TIME_MIN_ELAPSED 0  
#define CFE_MISSION_TIME_MAX_ELAPSED 100000
```

Hypothetical hardware configuration number three (described above) might use these values which describe a window that begins immediately after the tone and lasts for one tenth of a second.

See also

[CFE\\_MISSION\\_TIME\\_MIN\\_ELAPSED](#), [CFE\\_MISSION\\_TIME\\_MAX\\_ELAPSED](#)

Next: [Specifying Time Server/Client](#)

Prev: [Selecting Tone and Data Ordering](#)

Up To: [Time Configuration](#)

### 2.22.9 Specifying Time Server/Client

Configure TIME as a client only when the target system has multiple processors running separate instantiations of the cFE. One instantiation must be configured as the server and the remainder configured as clients. If the target system has only one processor running the cFE, then TIME must be configured as a server.

Enable one, and only one, of the following definitions in the platform configuration header file:

```
#define CFE_PLATFORM_TIME_CFG_SERVER TRUE  
#define CFE_PLATFORM_TIME_CFG_CLIENT FALSE
```

or

```
#define CFE_PLATFORM_TIME_CFG_SERVER FALSE  
#define CFE_PLATFORM_TIME_CFG_CLIENT TRUE
```

See also

[CFE\\_PLATFORM\\_TIME\\_CFG\\_SERVER](#), [CFE\\_PLATFORM\\_TIME\\_CFG\\_CLIENT](#)

Next: [Specifying Time Tone Byte Order](#)

Prev: [Specifying Tone and Data Window](#)

Up To: [Time Configuration](#)

### 2.22.10 Specifying Time Tone Byte Order

By default, the CFE time tone message is a payload of integers in platform-endian order (containing the tone's timestamp, the leap seconds, and state information.) In some configurations, it may be better to have the payload produced in big-endian order—particularly in mixed-endian environments.

In order to force the tone message to be in big-endian order, you must define the following:

```
#define CFE_PLATFORM_TIME_CFG_BIGENDIAN
```

Next: [Virtual MET](#)

Prev: [Specifying Time Server/Client](#)

Up To: [Time Configuration](#)

### 2.22.11 Virtual MET

This configuration option refers to whether the MET is local to this instantiation of TIME. If the MET is not local then TIME must be configured as using a virtual MET.

Therefore, all TIME clients must be configured as using a virtual MET. If the MET was local to any TIME client, then that instantiation of TIME would have to be the server.

TIME servers must be configured as using a virtual MET

Next: [Specifying Time Source](#)

Prev: [Specifying Time Tone Byte Order](#)

Up To: [Time Configuration](#)

### 2.22.12 Specifying Time Source

TIME configuration provides the ability to specify where the source for time data is originating - either internal or external. In hypothetical system one, the MET is internal. In system two, TIME cannot directly read the MET, therefore time data must be received from an external source.

This selection also enables a command interface to switch between internal and external input. When commanded to use internal time data, TIME will ignore the external data. However, TIME will continue to use the API function as the trigger to generate a "time at the tone" command packet regardless of the internal/external command selection.

Set the following definition to TRUE only for TIME servers using an external time data source.

```
#define CFE_PLATFORM_TIME_CFG_SOURCE TRUE
```

The remainder of this section pertains only to TIME servers configured to accept external time data.

When configured to accept external time data, TIME requires an additional definition for the type of external data (GPS, MET, spacecraft time, etc.). This selection will enable an API function specific to the selected data type. Regardless of how the time data is received, the receiver need only pass the data to the appropriate API function.

TIME servers using an external time data source must set one, and only one, of the following to TRUE, for example:

```
#define CFE_PLATFORM_TIME_CFG_SRC_MET    TRUE
#define CFE_PLATFORM_TIME_CFG_SRC_GPS    FALSE
#define CFE_PLATFORM_TIME_CFG_SRC_TIME   FALSE
```

configuration definitions for the particular source.

If the `cfe_platform_cfg.h` file contains "#define CFE\_PLATFORM\_TIME\_CFG\_SOURCE TRUE" then time is configured to allow switching between internal and external time sources (see [CFE\\_TIME\\_SET\\_SOURCE\\_CC](#)). If this configuration parameter is set to FALSE then the command to set the source will be rejected.

If this configuration parameter is set to TRUE then ONE and ONLY ONE of the following configuration parameters must also be set TRUE in order to specify the external time source, for example:

```
#define CFE_PLATFORM_TIME_CFG_SRC_MET    TRUE
#define CFE_PLATFORM_TIME_CFG_SRC_GPS    FALSE
#define CFE_PLATFORM_TIME_CFG_SRC_TIME   FALSE
```

Note that Internal MET source depends on available hardware. It may be the local count of tone signals, the contents of a hardware register or an OS specific time function.

Note also that when configured to use an external time source, commands to set the time will be overwritten.

#### See also

[CFE\\_PLATFORM\\_TIME\\_CFG\\_SRC\\_MET](#), [CFE\\_PLATFORM\\_TIME\\_CFG\\_SRC\\_GPS](#), [CFE\\_PLATFORM\\_TIME\\_CFG\\_SRC\\_TIME](#)

Next: [Specifying Time Signal](#)

Prev: [Virtual MET](#)

Up To: [Time Configuration](#)

#### 2.22.13 Specifying Time Signal

Some hardware configurations support a primary and redundant tone signal selection. Setting the following configuration definition to TRUE will result in enabling a TIME command to select the active tone signal.

```
#define CFE_PLATFORM_TIME_CFG_SIGNAL  TRUE
```

Note: this feature requires additional custom software to make the physical signal switch.

#### See also

[CFE\\_PLATFORM\\_TIME\\_CFG\\_SIGNAL](#)

Next: [Time Services Paradigm\(s\)](#)

Prev: [Specifying Time Source](#)

Up To: [Time Configuration](#)

#### 2.22.14 Time Services Paradigm(s)

In order for the cFE Time Services to work for a particular mission, the methods of obtaining time, distributing time and translating time must follow some standard paradigms used in previous missions. The following describes this expected context:

Mission dependent hardware provides the Tone. When this Tone message is received, TIME latches the local time based on the local clock. Note that in lab environments, a simulated Tone capability exists which uses an SB message. Mission dependent hardware also provides the "time at the tone" message based on the hardware latched time and the reference times stored by TIME Server. The TIME Client then updates its local reference time based on the local hardware latched time at the Tone and the provided Time-at-Tone message packet when certain checks (such as the Validity bit being set) pass.

When used in an environment that includes multiple processors, each running a separate instantiation of cFE software, the presumption is that TIME will be distributed in a client/server relationship. In this model, one processor will have TIME configured as the server and the other processors as clients. The TIME server will maintain the various time components and publish a "time at the tone" message to provide synchronized time to the TIME clients. Environments that have only a single instance of TIME must be configured as a TIME server.

In all configurations, the final step in calculating the time "right now" for any instantiation of TIME is to use a local processor clock to measure the "time since the tone".

The specific MET hardware properties will determine whether the MET value can be modified. However, the cFE design is such that there should never be a need to purposefully change or reset the MET.

Regardless of the physical hardware implementation for the MET (elapsed seconds, elapsed ticks, etc.), cFE TIME will convert the hardware MET value into a System Time Format structure for time calculations and will report the converted value in telemetry. cFE TIME will also maintain and report the STCF in a System Time Format structure.

cFE TIME has no knowledge of the current epoch; it is up to the user to keep time on the spacecraft correlated to an epoch. An exception might appear to be the epoch definition required in the cFE mission configuration definition file. However, this definition is for use only by the API functions that convert spacecraft time and file system time, and the API function that prints spacecraft time as a date and time text string. The cFE "get time" functions are independent of the ground epoch.

The mission configuration parameters, `CFE_MISSION_TIME_CFG_DEFAULT_TAI` and `CFE_MISSION_TIME_CFG_DEFAULT_UTC` specify the default time format. Applications are encouraged to use the `CFE_TIME_GetTime` API, which returns time in the format specified by this configuration parameter.

Next: [Flywheeling](#)

Prev: [Time Components](#)

Up To: [cFE Time Services Overview](#)

#### 2.22.15 Flywheeling

Flywheeling occurs when TIME is not getting a valid tone signal or external "time at the tone" message. While this has minimal impact on internal operations, it can result in the drifting apart of times being stored by different spacecraft systems.

Flywheeling occurs when at least one of the following conditions is true:

- loss of tone signal
- loss of "time at the tone" data packet
- signal and packet not within valid window
- commanded into fly-wheel mode

If the TIME server is in Flywheel mode then the TIME client is also in flywheel mode.

Next: [Time State](#)

Prev: [Time Services Paradigm\(s\)](#)

Up To: [cFE Time Services Overview](#)

#### 2.22.16 Time State

Clock state is a combination of factors, most significantly whether the spacecraft time has been accurately set and whether Time Service is operating in FLYWHEEL mode. A ground command is provided to set the state to reflect when the ground has determined the spacecraft time is now correct, or that time is no longer correct. This information will be distributed to Time Clients, and in turn, to any interested sub-systems. If time has not been set then TIME services reports the state of time as invalid, regardless of whether time is flywheeling or not. Also, this command may be used to force a Time Server or Time Client into FLYWHEEL mode. Use of FLYWHEEL mode is mainly for debug purposes although, in extreme circumstances, it may be of value to force Time Service not to rely on normal time updates. Note that when commanded into FLYWHEEL mode, the Time Service will remain so until receipt of another "set state" command setting the state into a mode other than FLYWHEEL. Note also that setting the clock state to VALID or INV↔ALID on a Time Client that is currently getting time updates from the Time Server will have very limited effect. As soon as the Time Client receives the next time update, the VALID/INVALID selection will be set to that of the Time Server. However, setting a Time Client to FLYWHEEL cannot be overridden by the Time Server since the Time Client will ignore time updates from the Time Server while in FLYWHEEL mode.

Next: [Initialization](#)

Prev: [Flywheeling](#)

Up To: [cFE Time Services Overview](#)

#### 2.22.17 Initialization

No action is required by the ground to initialize the TIME software; however, time variables in the TIME Server must be set by command to allow correct time to propagate.

For a description of what happens during each type of reset, see below:

- [Power-On Reset](#)
- [Processor Reset](#)

Next: [Power-On Reset](#)

Prev: [Time State](#)

Up To: [cFE Time Services Overview](#)

---

### 2.22.17.1 Power-On Reset

TIME initializes all counters in housekeeping telemetry, sets the Validity state to Invalid, and initializes the STCF, Leap Seconds, and 1 Hz Adjustment to zero.

Next: [Processor Reset](#)

Up To: [Initialization](#)

### 2.22.17.2 Processor Reset

In the event of a processor reset, the following time values are preserved:

- MET
- STCF
- Leap Seconds
- Clock Signal Selection
- Current Time Client Delay (if applicable)

Note that since it is virtually impossible for TIME services to validate the actual data that is saved across a processor reset, a signature pattern is written to the preserved area. On a processor reset, TIME queries that signature to make sure that it matches what is expected. If the signature does not match, then TIME is initialized as if a cFE power-on reset occurred.

Next: [Normal Operation](#)

Prev: [Power-On Reset](#)

Up To: [Initialization](#)

### 2.22.18 Power-On Reset

TIME initializes all counters in housekeeping telemetry, sets the Validity state to Invalid, and initializes the STCF, Leap Seconds, and 1 Hz Adjustment to zero.

Next: [Processor Reset](#)

Up To: [Initialization](#)

### 2.22.19 Processor Reset

In the event of a processor reset, the following time values are preserved:

- MET
- STCF
- Leap Seconds
- Clock Signal Selection
- Current Time Client Delay (if applicable)

Note that since it is virtually impossible for TIME services to validate the actual data that is saved across a processor reset, a signature pattern is written to the preserved area. On a processor reset, TIME queries that signature to make sure that it matches what is expected. If the signature does not match, then TIME is initialized as if a cFE power-on reset occurred.

Next: [Normal Operation](#)

Prev: [Power-On Reset](#)

Up To: [Initialization](#)

### 2.22.20 Initialization

No action is required by the ground to initialize the TIME software; however, time variables in the TIME Server must be set by command to allow correct time to propagate.

For a description of what happens during each type of reset, see below:

- [Power-On Reset](#)
- [Processor Reset](#)

Next: [Power-On Reset](#)

Prev: [Time State](#)

Up To: [cFE Time Services Overview](#)

### 2.22.20.1 Power-On Reset

TIME initializes all counters in housekeeping telemetry, sets the Validity state to Invalid, and initializes the STCF, Leap Seconds, and 1 Hz Adjustment to zero.

Next: [Processor Reset](#)

Up To: [Initialization](#)

### 2.22.20.2 Processor Reset

In the event of a processor reset, the following time values are preserved:

- MET
- STCF
- Leap Seconds
- Clock Signal Selection
- Current Time Client Delay (if applicable)

Note that since it is virtually impossible for TIME services to validate the actual data that is saved across a processor reset, a signature pattern is written to the preserved area. On a processor reset, TIME queries that signature to make sure that it matches what is expected. If the signature does not match, then TIME is initialized as if a cFE power-on reset occurred.

Next: [Normal Operation](#)

Prev: [Power-On Reset](#)

Up To: [Initialization](#)

### 2.22.21 Power-On Reset

TIME initializes all counters in housekeeping telemetry, sets the Validity state to Invalid, and initializes the STCF, Leap Seconds, and 1 Hz Adjustment to zero.

Next: [Processor Reset](#)

Up To: [Initialization](#)

### 2.22.22 Processor Reset

In the event of a processor reset, the following time values are preserved:

- MET
- STCF
- Leap Seconds
- Clock Signal Selection
- Current Time Client Delay (if applicable)

Note that since it is virtually impossible for TIME services to validate the actual data that is saved across a processor reset, a signature pattern is written to the preserved area. On a processor reset, TIME queries that signature to make sure that it matches what is expected. If the signature does not match, then TIME is initialized as if a cFE power-on reset occurred.

Next: [Normal Operation](#)

Prev: [Power-On Reset](#)

Up To: [Initialization](#)

### 2.22.23 Normal Operation

The following sections describe the operator's responsibilities for maintaining time under nominal conditions:

- [Client](#)
- [Server](#)

Next: [Client](#)

Prev: [Initialization](#)

Up To: [cFE Time Services Overview](#)

#### 2.22.23.1 Client

Under normal operation, TIME Client systems do not require any attention from the ground, however TIME clients do provide commands to set the persistent latency between the server and client. Latency can be either added or subtracted to the current TIME client time calculation to account for the latency.

Next: [Server](#)

Up To: [Normal Operation](#)

### 2.22.23.2 Server

TIME Servers require maintenance by the operations team to ensure the spacecraft is maintaining a time that can be successfully correlated to other entities. The following sections describe the commands that the operations team can use to help maintain a proper time reference:

- [Setting Time](#)
- [Adjusting Time](#)
- [Setting MET](#)

Next: [Setting Time](#)

Prev: [Client](#)

Up To: [Normal Operation](#)

#### 2.22.23.2.1 Setting Time

The Time Server provides commands to set time. The new time value represents the desired offset from mission-defined time epoch and takes effect immediately upon execution of this command. Time Service will calculate a new STCF value based on the current MET and the desired new time using one of the following:

If Time Service is configured to compute current time as TAI:

```
STCF = new time - current MET
current time = current MET + STCF
```

If Time Service is configured to compute current time as UTC:

```
STCF = ((new time) - (current MET)) + Leap Seconds
current time = ((current MET) + STCF) - Leap Seconds
```

#### See also

[CFE\\_TIME\\_SET\\_TIME\\_CC](#)

Next: [Adjusting Time](#)

Up To: [Server](#)

### 2.22.23.2.2 Adjusting Time

The TIME Server includes commands to set the STCF, Leap Seconds, and Validity state. The STCF should be set implicitly using the [CFE\\_TIME\\_SET\\_TIME\\_CC](#) or explicitly using [CFE\\_TIME\\_SET\\_STCF\\_CC](#). TIME provides the ability to command a one time adjustment ([CFE\\_TIME\\_ADD\\_ADJUST\\_CC](#) and [CFE\\_TIME\\_SUB\\_ADJUST\\_CC](#)) to the current STCF. In addition there is a 1Hz adjustment ([CFE\\_TIME\\_ADD\\_1HZ\\_ADJUSTMENT\\_CC](#) and [CFE\\_TIME\\_SUB\\_1HZ\\_ADJUSTMENT\\_CC](#)) that can be made to the STCF to compensate for oscillator drift. Mission specific ground correlation should be used to assist in determining the proper values to use. The Leap Seconds should be set to the current TAI-UTC. Note that the International Earth Rotation and Reference Systems Service Bulletin C, which defines the current difference, reports it as UTC-TAI, and thus that value must be negated. **The Leap Seconds value will always be a positive number.** The Validity state does not have to be set to invalid to change the STCF or Leap Seconds, and should be set to valid at any time that the TIME Server time reference should be synchronized to by the other systems.

#### See also

[CFE\\_TIME\\_ADD\\_ADJUST\\_CC](#), [CFE\\_TIME\\_SUB\\_ADJUST\\_CC](#), [CFE\\_TIME\\_SET\\_STCF\\_CC](#), [CFE\\_TIME\\_ADD\\_1HZ\\_ADJUSTMENT\\_CC](#), [CFE\\_TIME\\_SUB\\_1HZ\\_ADJUSTMENT\\_CC](#), [CFE\\_TIME\\_SET\\_LEAP\\_SECOND\\_CC](#)

Next: [Setting MET](#)

Prev: [Setting Time](#)

Up To: [Server](#)

### 2.22.23.2.3 Setting MET

The TIME Server provides the capability to set the MET. Note that the MET (as implemented for cFE Time Service) is a logical representation and not a physical timer. Thus, setting the MET is not dependent on whether the hardware supports a MET register that can be written to. Note also that Time Service "assumes" that during normal operation, the MET is synchronized to the tone signal. Therefore, unless operating in FLYWHEEL mode, the sub-seconds portion of the MET will be set to zero at the next tone signal interrupt. The new MET takes effect immediately upon execution of this command.

#### See also

[CFE\\_TIME\\_SET\\_MET\\_CC](#)

Next: [Frequently Asked Questions](#)

Prev: [Adjusting Time](#)

Up To: [Server](#)

### 2.22.24 Client

Under normal operation, TIME Client systems do not require any attention from the ground, however TIME clients do provide commands to set the persistent latency between the server and client. Latency can be either added or subtracted to the current TIME client time calculation to account for the latency.

Next: [Server](#)

Up To: [Normal Operation](#)

## 2.22.25 Server

TIME Servers require maintenance by the operations team to ensure the spacecraft is maintaining a time that can be successfully correlated to other entities. The following sections describe the commands that the operations team can use to help maintain a proper time reference:

- [Setting Time](#)
- [Adjusting Time](#)
- [Setting MET](#)

Next: [Setting Time](#)

Prev: [Client](#)

Up To: [Normal Operation](#)

### 2.22.25.0.1 Setting Time

The Time Server provides commands to set time. The new time value represents the desired offset from mission-defined time epoch and takes effect immediately upon execution of this command. Time Service will calculate a new STCF value based on the current MET and the desired new time using one of the following:

If Time Service is configured to compute current time as TAI:

```
STCF = new time - current MET
current time = current MET + STCF
```

If Time Service is configured to compute current time as UTC:

```
STCF = ((new time) - (current MET)) + Leap Seconds
current time = ((current MET) + STCF) - Leap Seconds
```

#### See also

[CFE\\_TIME\\_SET\\_TIME\\_CC](#)

Next: [Adjusting Time](#)

Up To: [Server](#)

### 2.22.25.0.2 Adjusting Time

The TIME Server includes commands to set the STCF, Leap Seconds, and Validity state. The STCF should be set implicitly using the [CFE\\_TIME\\_SET\\_TIME\\_CC](#) or explicitly using [CFE\\_TIME\\_SET\\_STCF\\_CC](#). TIME provides the ability to command a one time adjustment ([CFE\\_TIME\\_ADD\\_ADJUST\\_CC](#) and [CFE\\_TIME\\_SUB\\_ADJUST\\_CC](#)) to the current STCF. In addition there is a 1Hz adjustment ([CFE\\_TIME\\_ADD\\_1HZ\\_ADJUSTMENT\\_CC](#) and [CFE\\_TIME\\_SUB\\_1HZ\\_ADJUSTMENT\\_CC](#)) that can be made to the STCF to compensate for oscillator drift. Mission specific ground correlation should be used to assist in determining the proper values to use. The Leap Seconds should be set to the current TAI-UTC. Note that the International Earth Rotation and Reference Systems Service Bulletin C, which defines the current difference, reports it as UTC-TAI, and thus that value must be negated. **The Leap Seconds value will always be a positive number.** The Validity state does not have to be set to invalid to change the STCF or Leap Seconds, and should be set to valid at any time that the TIME Server time reference should be synchronized to by the other systems.

See also

[CFE\\_TIME\\_ADD\\_ADJUST\\_CC](#), [CFE\\_TIME\\_SUB\\_ADJUST\\_CC](#), [CFE\\_TIME\\_SET\\_STCF\\_CC](#), [CFE\\_TIME\\_ADD\\_1HZ\\_ADJUSTMENT\\_CC](#), [CFE\\_TIME\\_SUB\\_1HZ\\_ADJUSTMENT\\_CC](#), [CFE\\_TIME\\_SET\\_LEAP\\_SECOND\\_CC](#)

Next: [Setting MET](#)

Prev: [Setting Time](#)

Up To: [Server](#)

### 2.22.25.0.3 Setting MET

The TIME Server provides the capability to set the MET. Note that the MET (as implemented for cFE Time Service) is a logical representation and not a physical timer. Thus, setting the MET is not dependent on whether the hardware supports a MET register that can be written to. Note also that Time Service "assumes" that during normal operation, the MET is synchronized to the tone signal. Therefore, unless operating in FLYWHEEL mode, the sub-seconds portion of the MET will be set to zero at the next tone signal interrupt. The new MET takes effect immediately upon execution of this command.

See also

[CFE\\_TIME\\_SET\\_MET\\_CC](#)

Next: [Frequently Asked Questions](#)

Prev: [Adjusting Time](#)

Up To: [Server](#)

### 2.22.26 Setting Time

The Time Server provides commands to set time. The new time value represents the desired offset from mission-defined time epoch and takes effect immediately upon execution of this command. Time Service will calculate a new STCF value based on the current MET and the desired new time using one of the following:

If Time Service is configured to compute current time as TAI:

```
STCF = new time - current MET
current time = current MET + STCF
```

If Time Service is configured to compute current time as UTC:

```
STCF = ((new time) - (current MET)) + Leap Seconds
current time = ((current MET) + STCF) - Leap Seconds
```

See also

[CFE\\_TIME\\_SET\\_TIME\\_CC](#)

Next: [Adjusting Time](#)

Up To: [Server](#)

### 2.22.27 Adjusting Time

The TIME Server includes commands to set the STCF, Leap Seconds, and Validity state. The STCF should be set implicitly using the [CFE\\_TIME\\_SET\\_TIME\\_CC](#) or explicitly using [CFE\\_TIME\\_SET\\_STCF\\_CC](#). TIME provides the ability to command a one time adjustment ([CFE\\_TIME\\_ADD\\_ADJUST\\_CC](#) and [CFE\\_TIME\\_SUB\\_ADJUST\\_CC](#)) to the current STCF. In addition there is a 1Hz adjustment ([CFE\\_TIME\\_ADD\\_1HZ\\_ADJUSTMENT\\_CC](#) and [CFE\\_TIME\\_SUB\\_1HZ\\_ADJUSTMENT\\_CC](#)) that can be made to the STCF to compensate for oscillator drift. Mission specific ground correlation should be used to assist in determining the proper values to use. The Leap Seconds should be set to the current TA-I-UTC. Note that the International Earth Rotation and Reference Systems Service Bulletin C, which defines the current difference, reports it as UTC-TAI, and thus that value must be negated. **The Leap Seconds value will always be a positive number.** The Validity state does not have to be set to invalid to change the STCF or Leap Seconds, and should be set to valid at any time that the TIME Server time reference should be synchronized to by the other systems.

See also

[CFE\\_TIME\\_ADD\\_ADJUST\\_CC](#), [CFE\\_TIME\\_SUB\\_ADJUST\\_CC](#), [CFE\\_TIME\\_SET\\_STCF\\_CC](#), [CFE\\_TIME\\_ADD\\_1HZ\\_ADJUSTMENT\\_CC](#), [CFE\\_TIME\\_SUB\\_1HZ\\_ADJUSTMENT\\_CC](#), [CFE\\_TIME\\_SET\\_LEAP\\_SECOND\\_CC](#)

Next: [Setting MET](#)

Prev: [Setting Time](#)

Up To: [Server](#)

### 2.22.28 Setting MET

The TIME Server provides the capability to set the MET. Note that the MET (as implemented for cFE Time Service) is a logical representation and not a physical timer. Thus, setting the MET is not dependent on whether the hardware supports a MET register that can be written to. Note also that Time Service "assumes" that during normal operation, the MET is synchronized to the tone signal. Therefore, unless operating in FLYWHEEL mode, the sub-seconds portion of the MET will be set to zero at the next tone signal interrupt. The new MET takes effect immediately upon execution of this command.

See also

[CFE\\_TIME\\_SET\\_MET\\_CC](#)

Next: [Frequently Asked Questions](#)

Prev: [Adjusting Time](#)

Up To: [Server](#)

### 2.22.29 Frequently Asked Questions

(Q)

Prev: [Normal Operation](#)  
Up To: [cFE Time Services Overview](#)

## 2.23 cFE Time Services Commands

Upon receipt of any command, the Time Services application will confirm that the message length embedded within the header (from `CFE_MSG_GetSize()`) matches the expected length of that message, based on the size of the C structure defining that command. If there is any discrepancy between the expected and actual message size, TIME will generate the `CFE_TIME_LEN_ERR_EID` event, increment the command error counter (`$sc_$cpu_TIME_CMDEC`), and the command will *not* be accepted for processing.

The following is a list of commands that are processed by the cFE Time Services Task.

### Global `CFE_TIME_ADD_1HZ_ADJUSTMENT_CC`

Add Delta to Spacecraft Time Correlation Factor each 1Hz

### Global `CFE_TIME_ADD_ADJUST_CC`

Add Delta to Spacecraft Time Correlation Factor

### Global `CFE_TIME_ADD_DELAY_CC`

Add Time to Tone Time Delay

### Global `CFE_TIME_NOOP_CC`

Time No-Op

### Global `CFE_TIME_RESET_COUNTERS_CC`

Time Reset Counters

### Global `CFE_TIME_SEND_DIAGNOSTIC_TLM_CC`

Request TIME Diagnostic Telemetry

### Global `CFE_TIME_SET_LEAP_SECONDS_CC`

Set Leap Seconds

### Global `CFE_TIME_SET_MET_CC`

Set Mission Elapsed Time

### Global `CFE_TIME_SET_SIGNAL_CC`

Set Tone Signal Source

### Global `CFE_TIME_SET_SOURCE_CC`

Set Time Source

### Global `CFE_TIME_SET_STATE_CC`

Set Time State

### Global `CFE_TIME_SET_STCF_CC`

Set Spacecraft Time Correlation Factor

**Global CFE\_TIME\_SET\_TIME\_CC**

Set Spacecraft Time

**Global CFE\_TIME\_SUB\_1HZ\_ADJUSTMENT\_CC**

Subtract Delta from Spacecraft Time Correlation Factor each 1Hz

**Global CFE\_TIME\_SUB\_ADJUST\_CC**

Subtract Delta from Spacecraft Time Correlation Factor

**Global CFE\_TIME\_SUB\_DELAY\_CC**

Subtract Time from Tone Time Delay

## 2.24 cFE Time Services Telemetry

The following are telemetry packets generated by the cFE Time Services Task.

**Global CFE\_TIME\_DiagnosticTlm\_Payload\_t**

Time Services Diagnostics Packet

**Global CFE\_TIME\_DiagnosticTlm\_Payload\_t**

Time Services Diagnostics Packet

**Global CFE\_TIME\_HousekeepingTlm\_Payload\_t**

Time Services Housekeeping Packet

**Global CFE\_TIME\_HousekeepingTlm\_Payload\_t**

Time Services Housekeeping Packet

## 2.25 cFE Time Services Configuration Parameters

The following are configuration parameters used to configure the cFE Time Services either for each platform or for a mission as a whole.

**Global CFE\_MISSION\_TIME\_AT\_TONE\_WAS**

Default Time and Tone Order

**Global CFE\_MISSION\_TIME\_CFG\_DEFAULT\_TAI**

Default Time Format

**Global CFE\_MISSION\_TIME\_CFG\_FAKE\_TONE**

Default Time Format

**Global CFE\_MISSION\_TIME\_DEF\_MET\_SECS**

Default Time Values

**Global CFE\_MISSION\_TIME\_EPOCH\_YEAR**

Default EPOCH Values

**Global CFE\_MISSION\_TIME\_FS\_FACTOR**

Time File System Factor

**Global CFE\_MISSION\_TIME\_MIN\_ELAPSED**

Min and Max Time Elapsed

**Global CFE\_PLATFORM\_TIME\_CFG\_LATCH\_FLY**

Define Periodic Time to Update Local Clock Tone Latch

**Global CFE\_PLATFORM\_TIME\_CFG\_SERVER**

Time Server or Time Client Selection

**Global CFE\_PLATFORM\_TIME\_CFG\_SIGNAL**

Include or Exclude the Primary/Redundant Tone Selection Cmd

**Global CFE\_PLATFORM\_TIME\_CFG\_SOURCE**

Include or Exclude the Internal/External Time Source Selection Cmd

**Global CFE\_PLATFORM\_TIME\_CFG\_SRC\_MET**

Choose the External Time Source for Server only

**Global CFE\_PLATFORM\_TIME\_CFG\_START\_FLY**

Define Time to Start Flywheel Since Last Tone

**Global CFE\_PLATFORM\_TIME\_CFG\_TONE\_LIMIT**

Define Timing Limits From One Tone To The Next

**Global CFE\_PLATFORM\_TIME\_CFG\_VIRTUAL**

Time Tone In Big-Endian Order

Local MET or Virtual MET Selection for Time Servers

**Global CFE\_PLATFORM\_TIME\_MAX\_DELTA\_SECS**

Define the Max Delta Limits for Time Servers using an Ext Time Source

**Global CFE\_PLATFORM\_TIME\_MAX\_LOCAL\_SECS**

Define the Local Clock Rollover Value in seconds and subseconds

**Global CFE\_PLATFORM\_TIME\_START\_TASK\_PRIORITY**

Define TIME Task Priorities

**Global CFE\_PLATFORM\_TIME\_START\_TASK\_STACK\_SIZE**

Define TIME Task Stack Sizes

## 2.26 cFE Event Message Cross Reference

The following cross reference maps the text associated with each cFE Event Message to its Event Message Identifier. A user can search this page for the text of the message they wish to learn more about and then click on the associated Event Message Identifier to obtain more information.

## 2.27 cFE Command Mnemonic Cross Reference

The following cross reference maps the cFE command codes to Command Mnemonics. To learn about the details of a particular command, click on its associated command code.

**Global CFE\_ES\_CLEAR\_ER\_LOG\_CC**

\$sc\_\$cpu\_ES\_ClearERLog

**Global CFE\_ES\_CLEAR\_SYSLOG\_CC**

\$sc\_\$cpu\_ES\_ClearSysLog

**Global CFE\_ES\_DELETE\_CDS\_CC**

\$sc\_\$cpu\_ES\_DeleteCDS

**Global CFE\_ES\_DUMP\_CDS\_REGISTRY\_CC**

\$sc\_\$cpu\_ES\_WriteCDS2File

**Global CFE\_ES\_NOOP\_CC**

\$sc\_\$cpu\_ES\_NOOP

**Global CFE\_ES\_OVER\_WRITE\_SYSLOG\_CC**

\$sc\_\$cpu\_ES\_OverwriteSysLogMode

**Global CFE\_ES\_QUERY\_ALL\_CC**

\$sc\_\$cpu\_ES\_WriteApplInfo2File

**Global CFE\_ES\_QUERY\_ALL\_TASKS\_CC**

\$sc\_\$cpu\_ES\_WriteTaskInfo2File

**Global CFE\_ES\_QUERY\_ONE\_CC**

\$sc\_\$cpu\_ES\_QueryApp

**Global CFE\_ES\_RELOAD\_APP\_CC**

\$sc\_\$cpu\_ES\_ReloadApp

**Global CFE\_ES\_RESET\_COUNTERS\_CC**

\$sc\_\$cpu\_ES\_ResetCtrs

**Global CFE\_ES\_RESET\_PR\_COUNT\_CC**

\$sc\_\$cpu\_ES\_ResetPRCnt

**Global CFE\_ES\_RESTART\_APP\_CC**

\$sc\_\$cpu\_ES\_ResetApp

**Global CFE\_ES\_RESTART\_CC**

\$sc\_\$cpu\_ES\_ProcessorReset, \$sc\_\$cpu\_ES\_PowerOnReset

**Global CFE\_ES\_SEND\_MEM\_POOL\_STATS\_CC**

\$sc\_\$cpu\_ES\_PoolStats

**Global CFE\_ES\_SET\_MAX\_PR\_COUNT\_CC**

\$sc\_\$cpu\_ES\_SetMaxPRCnt

**Global CFE\_ES\_SET\_PERF\_FILTER\_MASK\_CC**

\$sc\_\$cpu\_ES\_LAFilterMask

**Global CFE\_ES\_SET\_PERF\_TRIGGER\_MASK\_CC**

\$sc\_\$cpu\_ES\_LATriggerMask

**Global CFE\_ES\_START\_APP\_CC**

\$sc\_\$cpu\_ES\_StartApp

**Global CFE\_ES\_START\_PERF\_DATA\_CC**

\$sc\_\$cpu\_ES\_StartLAData

**Global CFE\_ES\_STOP\_APP\_CC**

\$sc\_\$cpu\_ES\_StopApp

**Global CFE\_ES\_STOP\_PERF\_DATA\_CC**

\$sc\_\$cpu\_ES\_StopLAData

**Global CFE\_ES\_WRITE\_ER\_LOG\_CC**

\$sc\_\$cpu\_ES\_WriteERLog2File

**Global CFE\_ES\_WRITE\_SYSLOG\_CC**

\$sc\_\$cpu\_ES\_WriteSysLog2File

**Global CFE\_EVS\_ADD\_EVENT\_FILTER\_CC**

\$sc\_\$cpu\_EVS\_AddEvtFltr

**Global CFE\_EVS\_CLEAR\_LOG\_CC**

\$sc\_\$cpu\_EVS\_ClrLog

**Global CFE\_EVS\_DELETE\_EVENT\_FILTER\_CC**

\$sc\_\$cpu\_EVS\_DelEvtFltr

**Global CFE\_EVS\_DISABLE\_APP\_EVENT\_TYPE\_CC**

\$sc\_\$cpu\_EVS\_DisAppEvtType, \$sc\_\$cpu\_EVS\_DisAppEvtTypeMask

**Global CFE\_EVS\_DISABLE\_APP\_EVENTS\_CC**

\$sc\_\$cpu\_EVS\_DisAppEvGen

**Global CFE\_EVS\_DISABLE\_EVENT\_TYPE\_CC**

\$sc\_\$cpu\_EVS\_DisEventType, \$sc\_\$cpu\_EVS\_DisEventTypeMask

**Global CFE\_EVS\_DISABLE\_PORTS\_CC**

\$sc\_\$cpu\_EVS\_DisPort, \$sc\_\$cpu\_EVS\_DisPortMask

**Global CFE\_EVS\_ENABLE\_APP\_EVENT\_TYPE\_CC**

\$sc\_\$cpu\_EVS\_EnaAppEvtType, \$sc\_\$cpu\_EVS\_EnaAppEvtTypeMask

**Global CFE\_EVS\_ENABLE\_APP\_EVENTS\_CC**

\$sc\_\$cpu\_EVS\_EnaAppEvGen

**Global CFE\_EVS\_ENABLE\_EVENT\_TYPE\_CC**

\$sc\_\$cpu\_EVS\_EnaEventType, \$sc\_\$cpu\_EVS\_EnaEventTypeMask

**Global CFE\_EVS\_ENABLE\_PORTS\_CC**

\$sc\_\$cpu\_EVS\_EnaPort, \$sc\_\$cpu\_EVS\_EnaPortMask

**Global CFE\_EVS\_NOOP\_CC**

\$sc\_\$cpu\_EVS\_NOOP

**Global CFE\_EVS\_RESET\_ALL\_FILTERS\_CC**

\$sc\_\$cpu\_EVS\_RstAllFltrs

**Global CFE\_EVS\_RESET\_APP\_COUNTER\_CC**

\$sc\_\$cpu\_EVS\_RstAppCtrs

**Global CFE\_EVS\_RESET\_COUNTERS\_CC**

\$sc\_\$cpu\_EVS\_ResetCtrs

**Global CFE\_EVS\_RESET\_FILTER\_CC**

\$sc\_\$cpu\_EVS\_RstBinFltrCtr

**Global CFE\_EVS\_SET\_EVENT\_FORMAT\_MODE\_CC**

\$sc\_\$cpu\_EVS\_SetEvtFmt

**Global CFE\_EVS\_SET\_FILTER\_CC**

\$sc\_\$cpu\_EVS\_SetBinFltrMask

**Global CFE\_EVS\_SET\_LOG\_MODE\_CC**

\$sc\_\$cpu\_EVS\_SetLogMode

**Global CFE\_EVS\_WRITE\_APP\_DATA\_FILE\_CC**

\$sc\_\$cpu\_EVS\_WriteAppData2File

**Global CFE\_EVS\_WRITE\_LOG\_DATA\_FILE\_CC**  
\$sc\_\$cpu\_EVS\_WriteLog2File

**Global CFE\_SB\_DISABLE\_ROUTE\_CC**  
\$sc\_\$cpu\_SB\_DisRoute

**Global CFE\_SB\_DISABLE\_SUB\_REPORTING\_CC**  
\$sc\_\$cpu\_SB\_DisSubRptg

**Global CFE\_SB\_ENABLE\_ROUTE\_CC**  
\$sc\_\$cpu\_SB\_EnaRoute

**Global CFE\_SB\_ENABLE\_SUB\_REPORTING\_CC**  
\$sc\_\$cpu\_SB\_EnaSubRptg

**Global CFE\_SB\_NOOP\_CC**  
\$sc\_\$cpu\_SB\_NOOP

**Global CFE\_SB\_RESET\_COUNTERS\_CC**  
\$sc\_\$cpu\_SB\_ResetCtrs

**Global CFE\_SB\_SEND\_PREV\_SUBS\_CC**  
\$sc\_\$cpu\_SB\_SendPrevSubs

**Global CFE\_SB\_SEND\_SB\_STATS\_CC**  
\$sc\_\$cpu\_SB\_DumpStats

**Global CFE\_SB\_WRITE\_MAP\_INFO\_CC**  
\$sc\_\$cpu\_SB\_WriteMap2File

**Global CFE\_SB\_WRITE\_PIPE\_INFO\_CC**  
\$sc\_\$cpu\_SB\_WritePipe2File

**Global CFE\_SB\_WRITE\_ROUTING\_INFO\_CC**  
\$sc\_\$cpu\_SB\_WriteRouting2File

**Global CFE\_TBL\_ABORT\_LOAD\_CC**  
\$sc\_\$cpu\_TBL\_LoadAbort

**Global CFE\_TBL\_ACTIVATE\_CC**  
\$sc\_\$cpu\_TBL\_Activate

**Global CFE\_TBL\_DELETE\_CDS\_CC**  
\$sc\_\$cpu\_TBL\_DeleteCDS

**Global CFE\_TBL\_DUMP\_CC**  
\$sc\_\$cpu\_TBL\_Dump

**Global CFE\_TBL\_DUMP\_REGISTRY\_CC**  
\$sc\_\$cpu\_TBL\_WriteReg2File

**Global CFE\_TBL\_LOAD\_CC**  
\$sc\_\$cpu\_TBL\_Load

**Global CFE\_TBL\_NOOP\_CC**  
\$sc\_\$cpu\_TBL\_Noop

**Global CFE\_TBL\_RESET\_COUNTERS\_CC**  
\$sc\_\$cpu\_TBL\_ResetCtrs

**Global CFE\_TBL\_SEND\_REGISTRY\_CC**  
\$sc\_\$cpu\_TBL\_TLMReg

**Global CFE\_TBL\_VALIDATE\_CC**  
\$sc\_\$cpu\_TBL\_VALIDATE

**Global CFE\_TIME\_ADD\_1HZ\_ADJUSTMENT\_CC**  
\$sc\_\$cpu\_TIME\_Add1HzSTCF

**Global CFE\_TIME\_ADD\_ADJUST\_CC**  
\$sc\_\$cpu\_TIME\_AddSTCFAj

**Global CFE\_TIME\_ADD\_DELAY\_CC**  
\$sc\_\$cpu\_TIME\_AddClockLat

**Global CFE\_TIME\_NOOP\_CC**  
\$sc\_\$cpu\_TIME\_NOOP

**Global CFE\_TIME\_RESET\_COUNTERS\_CC**  
\$sc\_\$cpu\_TIME\_ResetCtrs

**Global CFE\_TIME\_SEND\_DIAGNOSTIC\_TLM\_CC**  
\$sc\_\$cpu\_TIME\_RequestDiag

**Global CFE\_TIME\_SET\_LEAP\_SECONDS\_CC**  
\$sc\_\$cpu\_TIME\_SetClockLeap

**Global CFE\_TIME\_SET\_MET\_CC**  
\$sc\_\$cpu\_TIME\_SetClockMET

**Global CFE\_TIME\_SET\_SIGNAL\_CC**  
\$sc\_\$cpu\_TIME\_SetSignal

**Global CFE\_TIME\_SET\_SOURCE\_CC**  
\$sc\_\$cpu\_TIME\_SetSource

**Global CFE\_TIME\_SET\_STATE\_CC**  
\$sc\_\$cpu\_TIME\_SetState

**Global CFE\_TIME\_SET\_STCF\_CC**  
\$sc\_\$cpu\_TIME\_SetClockSTCF

**Global CFE\_TIME\_SET\_TIME\_CC**  
\$sc\_\$cpu\_TIME\_SetClock

**Global CFE\_TIME\_SUB\_1HZ\_ADJUSTMENT\_CC**  
\$sc\_\$cpu\_TIME\_Sub1HzSTCF

**Global CFE\_TIME\_SUB\_ADJUST\_CC**  
\$sc\_\$cpu\_TIME\_SubSTCFAj

**Global CFE\_TIME\_SUB\_DELAY\_CC**  
\$sc\_\$cpu\_TIME\_SubClockLat

## 2.28 cFE Telemetry Mnemonic Cross Reference

The following cross reference maps the cFE telemetry packet members to their associated ground system telemetry mnemonics.

**Global CFE\_ES\_AppInfo::AddressesAreValid**  
\$sc\_\$cpu\_ES\_AddrsValid

**Global CFE\_ES\_AppInfo::BSSAddress**

\$sc\_\$cpu\_ES\_BSSAddress

**Global CFE\_ES\_AppInfo::BSSSize**

\$sc\_\$cpu\_ES\_BSSSize

**Global CFE\_ES\_AppInfo::CodeAddress**

\$sc\_\$cpu\_ES\_CodeAddress

**Global CFE\_ES\_AppInfo::CodeSize**

\$sc\_\$cpu\_ES\_CodeSize

**Global CFE\_ES\_AppInfo::DataAddress**

\$sc\_\$cpu\_ES\_DataAddress

**Global CFE\_ES\_AppInfo::DataSize**

\$sc\_\$cpu\_ES\_DataSize

**Global CFE\_ES\_AppInfo::EntryPoint [CFE\_MISSION\_MAX\_API\_LEN]**

\$sc\_\$cpu\_ES\_AppEntryPt[OS\_MAX\_API\_NAME]

**Global CFE\_ES\_AppInfo::ExceptionAction**

\$sc\_\$cpu\_ES\_ExceptnActn

**Global CFE\_ES\_AppInfo::ExecutionCounter**

\$sc\_\$cpu\_ES\_ExecutionCtr

**Global CFE\_ES\_AppInfo::FileName [CFE\_MISSION\_MAX\_PATH\_LEN]**

\$sc\_\$cpu\_ES\_AppFilename[OS\_MAX\_PATH\_LEN]

**Global CFE\_ES\_AppInfo::MainTaskId**

\$sc\_\$cpu\_ES\_MainTaskId

**Global CFE\_ES\_AppInfo::MainTaskName [CFE\_MISSION\_MAX\_API\_LEN]**

\$sc\_\$cpu\_ES\_MainTaskName[OS\_MAX\_API\_NAME]

**Global CFE\_ES\_AppInfo::Name [CFE\_MISSION\_MAX\_API\_LEN]**

\$sc\_\$cpu\_ES\_AppName[OS\_MAX\_API\_NAME]

**Global CFE\_ES\_AppInfo::NumOfChildTasks**

\$sc\_\$cpu\_ES\_ChildTasks

**Global CFE\_ES\_AppInfo::Priority**

\$sc\_\$cpu\_ES\_Priority

**Global CFE\_ES\_AppInfo::ResourceID**

\$sc\_\$cpu\_ES\_AppID

**Global CFE\_ES\_AppInfo::StackSize**

\$sc\_\$cpu\_ES\_StackSize

**Global CFE\_ES\_AppInfo::StartAddress**

\$sc\_\$cpu\_ES\_StartAddr

**Global CFE\_ES\_AppInfo::Type**

\$sc\_\$cpu\_ES\_AppType

**Global CFE\_ES\_HousekeepingTlm\_Payload::BootSource**

\$sc\_\$cpu\_ES\_BootSource

**Global CFE\_ES\_HousekeepingTlm\_Payload::CFECoreChecksum**

\$sc\_\$cpu\_ES\_CKSUM

**Global CFE\_ES\_HousekeepingTlm\_Payload::CFEMajorVersion**  
\$sc\_\$cpu\_ES\_CFEMAJORVER

**Global CFE\_ES\_HousekeepingTlm\_Payload::CFEMinorVersion**  
\$sc\_\$cpu\_ES\_CFEMINORVER

**Global CFE\_ES\_HousekeepingTlm\_Payload::CFEMissionRevision**  
\$sc\_\$cpu\_ES\_CFEMISSIONREV

**Global CFE\_ES\_HousekeepingTlm\_Payload::CFERevision**  
\$sc\_\$cpu\_ES\_CFEREVISION

**Global CFE\_ES\_HousekeepingTlm\_Payload::CommandCounter**  
\$sc\_\$cpu\_ES\_CMDPC

**Global CFE\_ES\_HousekeepingTlm\_Payload::CommandErrorCounter**  
\$sc\_\$cpu\_ES\_CMDEC

**Global CFE\_ES\_HousekeepingTlm\_Payload::ERLogEntries**  
\$sc\_\$cpu\_ES\_ERLOGENTRIES

**Global CFE\_ES\_HousekeepingTlm\_Payload::ERLogIndex**  
\$sc\_\$cpu\_ES\_ERLOGINDEX

**Global CFE\_ES\_HousekeepingTlm\_Payload::HeapBlocksFree**  
\$sc\_\$cpu\_ES\_HeapBlocksFree

**Global CFE\_ES\_HousekeepingTlm\_Payload::HeapBytesFree**  
\$sc\_\$cpu\_ES\_HeapBytesFree

**Global CFE\_ES\_HousekeepingTlm\_Payload::HeapMaxBlockSize**  
\$sc\_\$cpu\_ES\_HeapMaxBlkSize

**Global CFE\_ES\_HousekeepingTlm\_Payload::MaxProcessorResets**  
\$sc\_\$cpu\_ES\_MaxProcResets

**Global CFE\_ES\_HousekeepingTlm\_Payload::OSALMajorVersion**  
\$sc\_\$cpu\_ES\_OSMAJORVER

**Global CFE\_ES\_HousekeepingTlm\_Payload::OSALMinorVersion**  
\$sc\_\$cpu\_ES\_OSMINORVER

**Global CFE\_ES\_HousekeepingTlm\_Payload::OSALMissionRevision**  
\$sc\_\$cpu\_ES\_OSMISSIONREV

**Global CFE\_ES\_HousekeepingTlm\_Payload::OSALRevision**  
\$sc\_\$cpu\_ES\_OSREVISION

**Global CFE\_ES\_HousekeepingTlm\_Payload::PerfDataCount**  
\$sc\_\$cpu\_ES\_PerfDataCnt

**Global CFE\_ES\_HousekeepingTlm\_Payload::PerfDataEnd**  
\$sc\_\$cpu\_ES\_PerfDataEnd

**Global CFE\_ES\_HousekeepingTlm\_Payload::PerfDataStart**  
\$sc\_\$cpu\_ES\_PerfDataStart

**Global CFE\_ES\_HousekeepingTlm\_Payload::PerfDataToWrite**  
\$sc\_\$cpu\_ES\_PerfData2Write

**Global CFE\_ES\_HousekeepingTlm\_Payload::PerfFilterMask [CFE\_MISSION\_ES\_PERF\_MAX\_IDS/32]**  
\$sc\_\$cpu\_ES\_PerfFitrMask[MaskCnt]

**Global CFE\_ES\_HousekeepingTlm\_Payload::PerfMode**  
\$sc\_\$cpu\_ES\_PerfMode

**Global CFE\_ES\_HousekeepingTlm\_Payload::PerfState**  
\$sc\_\$cpu\_ES\_PerfState

**Global CFE\_ES\_HousekeepingTlm\_Payload::PerfTriggerCount**  
\$sc\_\$cpu\_ES\_PerfTrigCnt

**Global CFE\_ES\_HousekeepingTlm\_Payload::PerfTriggerMask [CFE\_MISSION\_ES\_PERF\_MAX\_IDS/32]**  
\$sc\_\$cpu\_ES\_PerfTrigMask[MaskCnt]

**Global CFE\_ES\_HousekeepingTlm\_Payload::ProcessorResets**  
\$sc\_\$cpu\_ES\_ProcResetCnt

**Global CFE\_ES\_HousekeepingTlm\_Payload::PSPMajorVersion**  
\$sc\_\$cpu\_ES\_PSPMAJORVER

**Global CFE\_ES\_HousekeepingTlm\_Payload::PSPMinorVersion**  
\$sc\_\$cpu\_ES\_PSPMINORVER

**Global CFE\_ES\_HousekeepingTlm\_Payload::PSPMissionRevision**  
\$sc\_\$cpu\_ES\_PSPMISSIONREV

**Global CFE\_ES\_HousekeepingTlm\_Payload::PSPRevision**  
\$sc\_\$cpu\_ES\_PSPREVISION

**Global CFE\_ES\_HousekeepingTlm\_Payload::RegisteredCoreApps**  
\$sc\_\$cpu\_ES\_RegCoreApps

**Global CFE\_ES\_HousekeepingTlm\_Payload::RegisteredExternalApps**  
\$sc\_\$cpu\_ES\_RegExtApps

**Global CFE\_ES\_HousekeepingTlm\_Payload::RegisteredLibs**  
\$sc\_\$cpu\_ES\_RegLibs

**Global CFE\_ES\_HousekeepingTlm\_Payload::RegisteredTasks**  
\$sc\_\$cpu\_ES\_RegTasks

**Global CFE\_ES\_HousekeepingTlm\_Payload::ResetSubtype**  
\$sc\_\$cpu\_ES\_ResetSubtype

**Global CFE\_ES\_HousekeepingTlm\_Payload::ResetType**  
\$sc\_\$cpu\_ES\_ResetType

**Global CFE\_ES\_HousekeepingTlm\_Payload::SysLogBytesUsed**  
\$sc\_\$cpu\_ES\_SYSLOGBYTEUSED

**Global CFE\_ES\_HousekeepingTlm\_Payload::SysLogEntries**  
\$sc\_\$cpu\_ES\_SYSLOGENTRIES

**Global CFE\_ES\_HousekeepingTlm\_Payload::SysLogMode**  
\$sc\_\$cpu\_ES\_SYSLOGMODE

**Global CFE\_ES\_HousekeepingTlm\_Payload::SysLogSize**  
\$sc\_\$cpu\_ES\_SYSLOGSIZE

**Global CFE\_ES\_MemPoolStats::BlockStats [CFE\_MISSION\_ES\_POOL\_MAX\_BUCKETS]**  
\$sc\_\$cpu\_ES\_BlkStats[BLK\_SIZES]

**Global CFE\_ES\_MemPoolStats::CheckErrCtr**  
\$sc\_\$cpu\_ES\_BlkErrCTR

**Global CFE\_ES\_MemPoolStats::NumBlocksRequested**  
\$sc\_\$cpu\_ES\_BlkReq

**Global CFE\_ES\_MemPoolStats::NumFreeBytes**  
\$sc\_\$cpu\_ES\_FreeBytes

**Global CFE\_ES\_MemPoolStats::PoolSize**  
\$sc\_\$cpu\_ES\_PoolSize

**Global CFE\_ES\_PoolStatsTim\_Payload::PoolHandle**  
\$sc\_\$cpu\_ES\_PoolHandle

**Global CFE\_EVS\_AppTlmData::AppEnableStatus**  
\$sc\_\$cpu\_EVS\_APP[CFE\_PLATFORM\_ES\_MAX\_APPLICATIONS].APPENASTAT

**Global CFE\_EVS\_AppTlmData::AppID**  
\$sc\_\$cpu\_EVS\_APP[CFE\_PLATFORM\_ES\_MAX\_APPLICATIONS].APPID

**Global CFE\_EVS\_AppTlmData::AppMessageSentCounter**  
\$sc\_\$cpu\_EVS\_APP[CFE\_PLATFORM\_ES\_MAX\_APPLICATIONS].APPMGSENTC

**Global CFE\_EVS\_AppTlmData::AppMessageSquelchedCounter**  
\$sc\_\$cpu\_EVS\_APP[CFE\_PLATFORM\_ES\_MAX\_APPLICATIONS].SQUELCHEDC

**Global CFE\_EVS\_HousekeepingTlm\_Payload::AppData [CFE\_MISSION\_ES\_MAX\_APPLICATIONS]**  
\$sc\_\$cpu\_EVS\_APP[CFE\_PLATFORM\_ES\_MAX\_APPLICATIONS]

**Global CFE\_EVS\_HousekeepingTlm\_Payload::CommandCounter**  
\$sc\_\$cpu\_EVS\_CMDPC

**Global CFE\_EVS\_HousekeepingTlm\_Payload::CommandErrorCounter**  
\$sc\_\$cpu\_EVS\_CMDEC

**Global CFE\_EVS\_HousekeepingTlm\_Payload::LogEnabled**  
\$sc\_\$cpu\_EVS\_LOGENABLED

**Global CFE\_EVS\_HousekeepingTlm\_Payload::LogFullFlag**  
\$sc\_\$cpu\_EVS\_LOGFULL

**Global CFE\_EVS\_HousekeepingTlm\_Payload::LogMode**  
\$sc\_\$cpu\_EVS\_LOGMODE

**Global CFE\_EVS\_HousekeepingTlm\_Payload::LogOverflowCounter**  
\$sc\_\$cpu\_EVS\_LOGOVERLOWC

**Global CFE\_EVS\_HousekeepingTlm\_Payload::MessageFormatMode**  
\$sc\_\$cpu\_EVS\_MSGFMTMODE

**Global CFE\_EVS\_HousekeepingTlm\_Payload::MessageSendCounter**  
\$sc\_\$cpu\_EVS\_MSGSENTC

**Global CFE\_EVS\_HousekeepingTlm\_Payload::MessageTruncCounter**  
\$sc\_\$cpu\_EVS\_MSGTRUNC

**Global CFE\_EVS\_HousekeepingTlm\_Payload::OutputPort**  
\$sc\_\$cpu\_EVS\_OUTPUTPORT

**Global CFE\_EVS\_HousekeepingTlm\_Payload::Spare1**  
\$sc\_\$cpu\_EVS\_HK\_SPARE1

**Global CFE\_EVS\_HousekeepingTlm\_Payload::Spare2**  
\$sc\_\$cpu\_EVS\_HK\_SPARE2

**Global CFE\_EVS\_HousekeepingTlm\_Payload::Spare3**  
\$sc\_\$cpu\_EVS\_HK\_SPARE3

**Global CFE\_EVS\_HousekeepingTlm\_Payload::UnregisteredAppCounter**  
\$sc\_\$cpu\_EVS\_UNREGAPPC

**Global CFE\_EVS\_LongEventTlm\_Payload::Message [CFE\_MISSION\_EVS\_MAX\_MESSAGE\_LENGTH]**  
\$sc\_\$cpu\_EVS\_EVENT[CFE\_MISSION\_EVS\_MAX\_MESSAGE\_LENGTH]

**Global CFE\_EVS\_LongEventTlm\_Payload::Spare1**  
\$sc\_\$cpu\_EVS\_SPARE1

**Global CFE\_EVS\_LongEventTlm\_Payload::Spare2**  
\$sc\_\$cpu\_EVS\_SPARE2

**Global CFE\_EVS\_PacketID::AppName [CFE\_MISSION\_MAX\_API\_LEN]**  
\$sc\_\$cpu\_EVS\_APPNAME[OS\_MAX\_API\_NAME]

**Global CFE\_EVS\_PacketID::EventID**  
\$sc\_\$cpu\_EVS\_EVENTID

**Global CFE\_EVS\_PacketID::EventType**  
\$sc\_\$cpu\_EVS\_EVENTTYPE

**Global CFE\_EVS\_PacketID::ProcessorID**  
\$sc\_\$cpu\_EVS\_PROCESSORID

**Global CFE\_EVS\_PacketID::SpacecraftID**  
\$sc\_\$cpu\_EVS\_SCID

**Global CFE\_SB\_HousekeepingTlm\_Payload::CommandCounter**  
\$sc\_\$cpu\_SB\_CMDPC

**Global CFE\_SB\_HousekeepingTlm\_Payload::CommandErrorCounter**  
\$sc\_\$cpu\_SB\_CMDEC

**Global CFE\_SB\_HousekeepingTlm\_Payload::CreatePipeErrorCounter**  
\$sc\_\$cpu\_SB\_NewPipeEC

**Global CFE\_SB\_HousekeepingTlm\_Payload::DuplicateSubscriptionsCounter**  
\$sc\_\$cpu\_SB\_DupSubCnt

**Global CFE\_SB\_HousekeepingTlm\_Payload::GetPipeIDByNameErrorCounter**  
\$sc\_\$cpu\_SB\_GetPipeIDByNameEC

**Global CFE\_SB\_HousekeepingTlm\_Payload::InternalErrorCounter**  
\$sc\_\$cpu\_SB\_InternalEC

**Global CFE\_SB\_HousekeepingTlm\_Payload::MemInUse**  
\$sc\_\$cpu\_SB\_MemInUse

**Global CFE\_SB\_HousekeepingTlm\_Payload::MemPoolHandle**  
\$sc\_\$cpu\_SB\_MemPoolHdl

**Global CFE\_SB\_HousekeepingTlm\_Payload::MsgLimitErrorCounter**  
\$sc\_\$cpu\_SB\_MsgLimEC

**Global CFE\_SB\_HousekeepingTlm\_Payload::MsgReceiveErrorCounter**  
\$sc\_\$cpu\_SB\_MsgRecEC

**Global CFE\_SB\_HousekeepingTlm\_Payload::MsgSendErrorCounter**  
\$sc\_\$cpu\_SB\_MsgSndEC

**Global CFE\_SB\_HousekeepingTlm\_Payload::NoSubscribersCounter**  
\$sc\_\$cpu\_SB\_NoSubEC

**Global CFE\_SB\_HousekeepingTlm\_Payload::PipeOptsErrorCounter**  
\$sc\_\$cpu\_SB\_PipeOptsEC

**Global CFE\_SB\_HousekeepingTlm\_Payload::PipeOverflowErrorCounter**  
\$sc\_\$cpu\_SB\_PipeOvrEC

**Global CFE\_SB\_HousekeepingTlm\_Payload::Spare2Align [1]**  
\$sc\_\$cpu\_SB\_Spare2Align[2]

**Global CFE\_SB\_HousekeepingTlm\_Payload::SubscribeErrorCounter**  
\$sc\_\$cpu\_SB\_SubscrEC

**Global CFE\_SB\_HousekeepingTlm\_Payload::UnmarkedMem**  
\$sc\_\$cpu\_SB\_UnMarkedMem

**Global CFE\_SB\_PipeDepthStats::CurrentQueueDepth**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMPDS[CFE\_PLATFORM\_SB\_MAX\_PIPES].SB\_PDINUSE

**Global CFE\_SB\_PipeDepthStats::MaxQueueDepth**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMPDS[CFE\_PLATFORM\_SB\_MAX\_PIPES].SB\_PDDEPTH

**Global CFE\_SB\_PipeDepthStats::PeakQueueDepth**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMPDS[CFE\_PLATFORM\_SB\_MAX\_PIPES].SB\_PDPKINUSE

**Global CFE\_SB\_PipeDepthStats::PipId**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMPDS[CFE\_PLATFORM\_SB\_MAX\_PIPES].SB\_PDPIPEID

**Global CFE\_SB\_PipeDepthStats::Spare**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMPDS[CFE\_PLATFORM\_SB\_MAX\_PIPES].SB\_PDSPARE

**Global CFE\_SB\_StatsTlm\_Payload::MaxMemAllowed**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMMBMALW

**Global CFE\_SB\_StatsTlm\_Payload::MaxMsgIdsAllowed**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMMMDALW

**Global CFE\_SB\_StatsTlm\_Payload::MaxPipeDepthAllowed**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMMPDALW

**Global CFE\_SB\_StatsTlm\_Payload::MaxPipesAllowed**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMPPALW

**Global CFE\_SB\_StatsTlm\_Payload::MaxSubscriptionsAllowed**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMMMSALW

**Global CFE\_SB\_StatsTlm\_Payload::MemInUse**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMBMIU

**Global CFE\_SB\_StatsTlm\_Payload::MsgIdsInUse**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMMIDIU

**Global CFE\_SB\_StatsTlm\_Payload::PeakMemInUse**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMPBMIU

**Global CFE\_SB\_StatsTlm\_Payload::PeakMsgIdsInUse**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMPMIDIU

**Global CFE\_SB\_StatsTlm\_Payload::PeakPipesInUse**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMPPIU

**Global CFE\_SB\_StatsTlm\_Payload::PeakSBBuffersInUse**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMPSBBIU

**Global CFE\_SB\_StatsTlm\_Payload::PeakSubscriptionsInUse**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMPSIU

**Global CFE\_SB\_StatsTlm\_Payload::PipeDepthStats [CFE\_MISSION\_SB\_MAX\_PIPES]**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMPDS[CFE\_PLATFORM\_SB\_MAX\_PIPES]

**Global CFE\_SB\_StatsTlm\_Payload::PipesInUse**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMPIU

**Global CFE\_SB\_StatsTlm\_Payload::SBBuffersInUse**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMSBBIU

**Global CFE\_SB\_StatsTlm\_Payload::SubscriptionsInUse**  
\$sc\_\$cpu\_SB\_Stat.SB\_SMSIU

**Global CFE\_TBL\_HousekeepingTlm\_Payload::ActiveBuffer**  
\$sc\_\$cpu\_TBL\_LastValBuf

**Global CFE\_TBL\_HousekeepingTlm\_Payload::ByteAlignPad1**  
\$sc\_\$cpu\_TBL\_BytAlignPad1

**Global CFE\_TBL\_HousekeepingTlm\_Payload::CommandCounter**  
\$sc\_\$cpu\_TBL\_CMDPC

**Global CFE\_TBL\_HousekeepingTlm\_Payload::CommandErrorCounter**  
\$sc\_\$cpu\_TBL\_CMDEC

**Global CFE\_TBL\_HousekeepingTlm\_Payload::FailedValCounter**  
\$sc\_\$cpu\_TBL\_ValFailedCtr

**Global CFE\_TBL\_HousekeepingTlm\_Payload::LastFileDumped [CFE\_MISSION\_MAX\_PATH\_LEN]**  
\$sc\_\$cpu\_TBL\_LastFileDumped[OS\_MAX\_PATH\_LEN]

**Global CFE\_TBL\_HousekeepingTlm\_Payload::LastFileLoaded [CFE\_MISSION\_MAX\_PATH\_LEN]**  
\$sc\_\$cpu\_TBL\_LastFileLoaded[OS\_MAX\_PATH\_LEN]

**Global CFE\_TBL\_HousekeepingTlm\_Payload::LastTableLoaded [CFE\_MISSION\_TBL\_MAX\_FULL\_NAME\_LEN]**  
\$sc\_\$cpu\_TBL\_LastTableLoaded[CFE\_TBL\_MAX\_FULL\_NAME\_LEN]

**Global CFE\_TBL\_HousekeepingTlm\_Payload::LastUpdatedTable [CFE\_MISSION\_TBL\_MAX\_FULL\_NAME\_L←EN]**  
\$sc\_\$cpu\_TBL\_LastUpdTblName[CFE\_TB\_MAX\_FULL\_NAME\_LEN]

**Global CFE\_TBL\_HousekeepingTlm\_Payload::LastUpdateTime**  
\$sc\_\$cpu\_TBL\_LastUpdTime, \$sc\_\$cpu\_TBL\_SECONDS, \$sc\_\$cpu\_TBL\_SUBSECONDS

**Global CFE\_TBL\_HousekeepingTlm\_Payload::LastValCrc**  
\$sc\_\$cpu\_TBL\_LastValCRC

**Global CFE\_TBL\_HousekeepingTlm\_Payload::LastValStatus**  
\$sc\_\$cpu\_TBL\_LastVals

**Global CFE\_TBL\_HousekeepingTlm\_Payload::LastValTableName [CFE\_MISSION\_TBL\_MAX\_FULL\_NAME\_L←EN]**  
\$sc\_\$cpu\_TBL\_LastValTblName[CFE\_TB\_MAX\_FULL\_NAME\_LEN]

**Global CFE\_TBL\_HousekeepingTlm\_Payload::MemPoolHandle**  
\$sc\_\$cpu\_TBL\_MemPoolHandle

**Global CFE\_TBL\_HousekeepingTlm\_Payload::NumFreeSharedBufs**  
\$sc\_\$cpu\_TBL\_NumFreeShrBuf

**Global CFE\_TBL\_HousekeepingTlm\_Payload::NumLoadPending**  
\$sc\_\$cpu\_TBL\_NumUpdatesPend

**Global CFE\_TBL\_HousekeepingTlm\_Payload::NumTables**  
\$sc\_\$cpu\_TBL\_NumTables

**Global CFE\_TBL\_HousekeepingTlm\_Payload::NumValRequests**  
\$sc\_\$cpu\_TBL\_ValReqCtr

**Global CFE\_TBL\_HousekeepingTlm\_Payload::SuccessValCounter**  
\$sc\_\$cpu\_TBL\_ValSuccessCtr

**Global CFE\_TBL\_HousekeepingTlm\_Payload::ValidationCounter**  
\$sc\_\$cpu\_TBL\_ValCompltdCtr

**Global CFE\_TBL\_TblRegPacket\_Payload::ActiveBufferAddr**  
\$sc\_\$cpu\_TBL\_ActBufAdd

**Global CFE\_TBL\_TblRegPacket\_Payload::ByteAlign4**  
\$sc\_\$cpu\_TBL\_Spare4

**Global CFE\_TBL\_TblRegPacket\_Payload::Crc**  
\$sc\_\$cpu\_TBL\_CRC

**Global CFE\_TBL\_TblRegPacket\_Payload::Critical**  
\$sc\_\$cpu\_TBL\_Spare3

**Global CFE\_TBL\_TblRegPacket\_Payload::DoubleBuffered**  
\$sc\_\$cpu\_TBL\_DblBuffered

**Global CFE\_TBL\_TblRegPacket\_Payload::DumpOnly**  
\$sc\_\$cpu\_TBL\_DumpOnly

**Global CFE\_TBL\_TblRegPacket\_Payload::FileCreateTimeSecs**  
\$sc\_\$cpu\_TBL\_FILECSECONDS

**Global CFE\_TBL\_TblRegPacket\_Payload::FileCreateTimeSubSecs**  
\$sc\_\$cpu\_TBL\_FILECSUBSECONDS

**Global CFE\_TBL\_TblRegPacket\_Payload::InactiveBufferAddr**  
\$sc\_\$cpu\_TBL\_IActBufAdd

**Global CFE\_TBL\_TblRegPacket\_Payload::LastFileLoaded [CFE\_MISSION\_MAX\_PATH\_LEN]**  
\$sc\_\$cpu\_TBL\_LastFileUpd[OS\_MAX\_PATH\_LEN]

**Global CFE\_TBL\_TblRegPacket\_Payload::LoadPending**  
\$sc\_\$cpu\_TBL\_UpdatePndng

**Global CFE\_TBL\_TblRegPacket\_Payload::Name [CFE\_MISSION\_TBL\_MAX\_FULL\_NAME\_LEN]**  
\$sc\_\$cpu\_TBL\_Name[CFE\_TB\_MAX\_FULL\_NAME\_LEN]

**Global CFE\_TBL\_TblRegPacket\_Payload::OwnerAppName [CFE\_MISSION\_MAX\_API\_LEN]**  
\$sc\_\$cpu\_TBL\_OwnerApp[OS\_MAX\_API\_NAME]

**Global CFE\_TBL\_TblRegPacket\_Payload::Size**  
\$sc\_\$cpu\_TBL\_SIZE

**Global CFE\_TBL\_TblRegPacket\_Payload::TableLoadedOnce**  
\$sc\_\$cpu\_TBL\_LoadedOnce

**Global CFE\_TBL\_TblRegPacket\_Payload::TimeOfLastUpdate**  
\$sc\_\$cpu\_TBL\_TimeLastUpd, \$sc\_\$cpu\_TBL\_TLUSECONDS, \$sc\_\$cpu\_TBL\_TLUSUBSECONDS

**Global CFE\_TBL\_TblRegPacket\_Payload::ValidationFuncPtr**  
\$sc\_\$cpu\_TBL\_ValFuncPtr

**Global CFE\_TIME\_DiagnosticTlm\_Payload::AtToneDelay**  
\$sc\_\$cpu\_TIME\_DLlatentS, \$sc\_\$cpu\_TIME\_DLlatentSs

**Global CFE\_TIME\_DiagnosticTlm\_Payload::AtToneLatch**  
\$sc\_\$cpu\_TIME\_DTVvalidS, \$sc\_\$cpu\_TIME\_DTVvalidSs

**Global CFE\_TIME\_DiagnosticTlm\_Payload::AtToneLeapSeconds**  
\$sc\_\$cpu\_TIME\_DLapS

**Global CFE\_TIME\_DiagnosticTlm\_Payload::AtToneMET**  
\$sc\_\$cpu\_TIME\_DTMETS, \$sc\_\$cpu\_TIME\_DTMETSs

**Global CFE\_TIME\_DiagnosticTlm\_Payload::AtToneSTCF**  
\$sc\_\$cpu\_TIME\_DSTCFS, \$sc\_\$cpu\_TIME\_DSTCFSS

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ClockFlyState**  
\$sc\_\$cpu\_TIME\_DFlywheel

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ClockSetState**  
\$sc\_\$cpu\_TIME\_DValid

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ClockSignal**  
\$sc\_\$cpu\_TIME\_DSignal

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ClockSource**  
\$sc\_\$cpu\_TIME\_DSource

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ClockStateAPI**  
\$sc\_\$cpu\_TIME\_DAPISate

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ClockStateFlags**  
\$sc\_\$cpu\_TIME\_DStateFlags, \$sc\_\$cpu\_TIME\_DFlagSet, \$sc\_\$cpu\_TIME\_DFlagFly, \$sc\_\$cpu\_TIME\_DFlagSrc,  
\$sc\_\$cpu\_TIME\_DFlagPri, \$sc\_\$cpu\_TIME\_DFlagSfly, \$sc\_\$cpu\_TIME\_DFlagCfly, \$sc\_\$cpu\_TIME\_DFlagAdjd,  
\$sc\_\$cpu\_TIME\_DFlag1Hzd, \$sc\_\$cpu\_TIME\_DFlagClat, \$sc\_\$cpu\_TIME\_DFlagSorC, \$sc\_\$cpu\_TIME\_DFlag←  
NIU

**Global CFE\_TIME\_DiagnosticTlm\_Payload::CurrentLatch**  
\$sc\_\$cpu\_TIME\_DLlocalS, \$sc\_\$cpu\_TIME\_DLlocalSs

**Global CFE\_TIME\_DiagnosticTlm\_Payload::CurrentMET**  
\$sc\_\$cpu\_TIME\_DMETS, \$sc\_\$cpu\_TIME\_DMETSs

**Global CFE\_TIME\_DiagnosticTlm\_Payload::CurrentTAI**  
\$sc\_\$cpu\_TIME\_DTAIS, \$sc\_\$cpu\_TIME\_DTAISS

**Global CFE\_TIME\_DiagnosticTlm\_Payload::CurrentUTC**  
\$sc\_\$cpu\_TIME\_DUTCS, \$sc\_\$cpu\_TIME\_DUTCSS

**Global CFE\_TIME\_DiagnosticTlm\_Payload::DataStoreStatus**  
\$sc\_\$cpu\_TIME\_DataStStat

**Global CFE\_TIME\_DiagnosticTlm\_Payload::DelayDirection**  
\$sc\_\$cpu\_TIME\_DLlatentDir

**Global CFE\_TIME\_DiagnosticTlm\_Payload::Forced2Fly**  
\$sc\_\$cpu\_TIME\_DCMD2Fly

**Global CFE\_TIME\_DiagnosticTlm\_Payload::LocalIntCounter**  
\$sc\_\$cpu\_TIME\_D1HzISRCNT

**Global CFE\_TIME\_DiagnosticTlm\_Payload::LocalTaskCounter**  
\$sc\_\$cpu\_TIME\_D1HzTaskCNT

**Global CFE\_TIME\_DiagnosticTlm\_Payload::MaxElapsed**  
\$sc\_\$cpu\_TIME\_DMaxWindow

**Global CFE\_TIME\_DiagnosticTlm\_Payload::MaxLocalClock**  
\$sc\_\$cpu\_TIME\_DWrapS, \$sc\_\$cpu\_TIME\_DWrapSs

**Global CFE\_TIME\_DiagnosticTlm\_Payload::MinElapsed**  
\$sc\_\$cpu\_TIME\_DMinWindow

**Global CFE\_TIME\_DiagnosticTlm\_Payload::OneHzAdjust**  
\$sc\_\$cpu\_TIME\_D1HzAdjS, \$sc\_\$cpu\_TIME\_D1HzAdjSs

**Global CFE\_TIME\_DiagnosticTlm\_Payload::OneHzDirection**  
\$sc\_\$cpu\_TIME\_D1HzAdjDir

**Global CFE\_TIME\_DiagnosticTlm\_Payload::OneTimeAdjust**  
\$sc\_\$cpu\_TIME\_DAdjustS, \$sc\_\$cpu\_TIME\_DAdjustSs

**Global CFE\_TIME\_DiagnosticTlm\_Payload::OneTimeDirection**  
\$sc\_\$cpu\_TIME\_DAdjustDir

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ServerFlyState**  
\$sc\_\$cpu\_TIME\_DSrvFly

**Global CFE\_TIME\_DiagnosticTlm\_Payload::TimeSinceTone**  
\$sc\_\$cpu\_TIME\_DElapsedS, \$sc\_\$cpu\_TIME\_DElapsedSs

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ToneDataCounter**  
\$sc\_\$cpu\_TIME\_DTatTCNT

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ToneDataLatch**  
\$sc\_\$cpu\_TIME\_DTDS, \$sc\_\$cpu\_TIME\_DTDSSs

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ToneIntCounter**  
\$sc\_\$cpu\_TIME\_DTsISRCNT

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ToneIntErrorCounter**  
\$sc\_\$cpu\_TIME\_DTsISRERR

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ToneMatchCounter**  
\$sc\_\$cpu\_TIME\_DVerifyCNT

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ToneMatchErrorCounter**  
\$sc\_\$cpu\_TIME\_DVerifyER

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ToneOverLimit**  
\$sc\_\$cpu\_TIME\_DMaxSs

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ToneSignalCounter**  
\$sc\_\$cpu\_TIME\_DTSDetCNT

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ToneSignalLatch**  
\$sc\_\$cpu\_TIME\_DTTS, \$sc\_\$cpu\_TIME\_DTTSSs

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ToneTaskCounter**  
\$sc\_\$cpu\_TIME\_DTsTaskCNT

**Global CFE\_TIME\_DiagnosticTlm\_Payload::ToneUnderLimit**  
\$sc\_\$cpu\_TIME\_DMinSs

**Global CFE\_TIME\_DiagnosticTlm\_Payload::VersionCounter**  
\$sc\_\$cpu\_TIME\_DVersionCNT

**Global CFE\_TIME\_DiagnosticTlm\_Payload::VirtualMET**  
\$sc\_\$cpu\_TIME\_DLLogicalMET

**Global CFE\_TIME\_HousekeepingTlm\_Payload::ClockStateAPI**  
\$sc\_\$cpu\_TIME\_DAPISate

**Global CFE\_TIME\_HousekeepingTlm\_Payload::ClockStateFlags**  
\$sc\_\$cpu\_TIME\_StateFlg, \$sc\_\$cpu\_TIME\_FlagSet, \$sc\_\$cpu\_TIME\_FlagFly, \$sc\_\$cpu\_TIME\_FlagSrc, \$sc\_\$cpu\_TIME\_FlagPri, \$sc\_\$cpu\_TIME\_FlagSfly, \$sc\_\$cpu\_TIME\_FlagCfly, \$sc\_\$cpu\_TIME\_FlagAdjd, \$sc\_\$cpu\_TIME\_Flag1Hzd, \$sc\_\$cpu\_TIME\_FlagClat, \$sc\_\$cpu\_TIME\_FlagSorC, \$sc\_\$cpu\_TIME\_FlagNIU

**Global CFE\_TIME\_HousekeepingTlm\_Payload::CommandCounter**  
\$sc\_\$cpu\_TIME\_CMDPC

**Global CFE\_TIME\_HousekeepingTlm\_Payload::CommandErrorCounter**  
\$sc\_\$cpu\_TIME\_CMDEC

**Global CFE\_TIME\_HousekeepingTlm\_Payload::LeapSeconds**  
\$sc\_\$cpu\_TIME\_LeapSecs

**Global CFE\_TIME\_HousekeepingTlm\_Payload::Seconds1HzAdj**  
\$sc\_\$cpu\_TIME\_1HzAdjSecs

**Global CFE\_TIME\_HousekeepingTlm\_Payload::SecondsDelay**  
\$sc\_\$cpu\_TIME\_1HzAdjSecs

**Global CFE\_TIME\_HousekeepingTlm\_Payload::SecondsMET**  
\$sc\_\$cpu\_TIME\_METSecs

**Global CFE\_TIME\_HousekeepingTlm\_Payload::SecondsSTCF**  
\$sc\_\$cpu\_TIME\_STCFSecs

**Global CFE\_TIME\_HousekeepingTlm\_Payload::Subsecs1HzAdj**  
\$sc\_\$cpu\_TIME\_1HzAdjSSecs

**Global CFE\_TIME\_HousekeepingTlm\_Payload::SubsecsDelay**  
\$sc\_\$cpu\_TIME\_1HzAdjSSecs

**Global CFE\_TIME\_HousekeepingTlm\_Payload::SubsecsMET**  
\$sc\_\$cpu\_TIME\_METSubsecs

**Global CFE\_TIME\_HousekeepingTlm\_Payload::SubsecsSTCF**  
\$sc\_\$cpu\_TIME\_STCFSubsecs

### 3 Glossary of Terms

Term	Definition
Application (or App)	A set of data and functions that is treated as a single entity by the cFE. cFE resources are allocated on a per-Application basis. Applications are made up of a Main Task and zero or more Child Tasks.
Application ID	A processor unique reference to an Application. <b>NOTE: This is different from a CCSDS Application ID which is referred to as an "APID."</b>
Application Programmer's Interface (API)	A set of routines, protocols, and tools for building software applications
Platform Support Package (PSP)	A collection of user-provided facilities that interface an OS and the cFE with a specific hardware platform. The PSP is responsible for hardware initialization.
Child Task	A separate thread of execution that is spawned by an Application's Main Task.
Command	A Software Bus Message defined by the receiving Application. Commands can originate from other onboard Applications or from the ground.
Core Flight Executive (cFE)	A runtime environment and a set of services for hosting FSW Applications
Critical Data Store (CDS)	A collection of data that is not modified by the OS or cFE following a Processor Reset.
Cyclic Redundancy Check	A polynomial based method for checking that a data set has remained unchanged from one time period to another.
Developer	Anyone who is coding a cFE Application.
Event Data	Data describing an Event that is supplied to the cFE Event Service. The cFE includes this data in an <a href="#">Event Message</a> .
Event Filter	A numeric value (bit mask) used to determine how frequently to output an application Event Message defined by its <a href="#">Event ID</a> .
Event Format Mode	Defines the Event Message Format downlink option: short or long. The short format is used when there is limited telemetry bandwidth and is binary. The long format is in ASCII and is used for logging to a Local Event Log and to an Event Message Port.
Event ID	A numeric literal used to uniquely name an Application event.
Event Type	A numeric literal used to identify the type of an Application event. An event type may be <a href="#">CFE_EVS_EventType_DEBUG</a> , <a href="#">CFE_EVS_EventType_INFORMATION</a> , <a href="#">CFE_EVS_EventType_ERROR</a> , or <a href="#">CFE_EVS_EventType_CRITICAL</a> .
Event Message	A data item used to notify the user and/or an external <a href="#">Application</a> of a significant event. Event Messages include a time-stamp of when the message was generated, a processor unique identifier, an <a href="#">Application ID</a> , the <a href="#">Event Type</a> (DEBUG,INFO,ERROR or CRITICAL), and <a href="#">Event Data</a> . An Event Message can either be real-time or playback from a Local Event Log.

## 4 cFE Application Programmer's Interface (API) Reference

### Executive Services API

- [cFE Entry/Exit APIs](#)

- [CFE\\_ES\\_Main](#) - cFE Main Entry Point used by Board Support Package to start cFE
- [CFE\\_ES\\_ResetCFE](#) - Reset the cFE Core and all cFE Applications.
- [cFE Application Control APIs](#)
  - [CFE\\_ES\\_RestartApp](#) - Restart a single cFE Application.
  - [CFE\\_ES\\_ReloadApp](#) - Reload a single cFE Application.
  - [CFE\\_ES\\_DeleteApp](#) - Delete a cFE Application.
- [cFE Application Behavior APIs](#)
  - [CFE\\_ES\\_RunLoop](#) - Check for Exit, Restart, or Reload commands.
  - [CFE\\_ES\\_WaitForStartupSync](#) - Allow an Application to Wait for the "OPERATIONAL" global system state.
  - [CFE\\_ES\\_WaitForSystemState](#) - Allow an Application to Wait for a minimum global system state.
  - [CFE\\_ES\\_IncrementTaskCounter](#) - Increments the execution counter for the calling task.
  - [CFE\\_ES\\_ExitApp](#) - Exit a cFE Application.
- [cFE Information APIs](#)
  - [CFE\\_ES\\_GetResetType](#) - Return the most recent Reset Type.
  - [CFE\\_ES\\_GetAppID](#) - Get an Application ID for the calling Application.
  - [CFE\\_ES\\_GetTaskID](#) - Get the task ID of the calling context.
  - [CFE\\_ES\\_GetAppIDByName](#) - Get an Application ID associated with a specified Application name.
  - [CFE\\_ES\\_GetLibIDByName](#) - Get a Library ID associated with a specified Library name.
  - [CFE\\_ES\\_GetAppName](#) - Get an Application name for a specified Application ID.
  - [CFE\\_ES\\_GetLibName](#) - Get a Library name for a specified Library ID.
  - [CFE\\_ES\\_GetAppInfo](#) - Get Application Information given a specified App ID.
  - [CFE\\_ES\\_GetTaskInfo](#) - Get Task Information given a specified Task ID.
  - [CFE\\_ES\\_GetLibInfo](#) - Get Library Information given a specified Resource ID.
  - [CFE\\_ES\\_GetModuleInfo](#) - Get Information given a specified Resource ID.
- [cFE Child Task APIs](#)
  - [CFE\\_ES\\_CreateChildTask](#) - Creates a new task under an existing Application.
  - [CFE\\_ES\\_GetTaskIDByName](#) - Get a Task ID associated with a specified Task name.
  - [CFE\\_ES\\_GetTaskName](#) - Get a Task name for a specified Task ID.
  - [CFE\\_ES\\_DeleteChildTask](#) - Deletes a task under an existing Application.
  - [CFE\\_ES\\_ExitChildTask](#) - Exits a child task.
- [cFE Critical Data Store APIs](#)
  - [CFE\\_ES\\_RegisterCDS](#) - Reserve space (or re-obtain previously reserved space) in the Critical Data Store (CDS)
  - [CFE\\_ES\\_GetCDSBlockIDByName](#) - Get a CDS Block ID associated with a specified CDS Block name.
  - [CFE\\_ES\\_GetCDSBlockName](#) - Get a Block name for a specified Block ID.
  - [CFE\\_ES\\_CopyToCDS](#) - Save a block of data in the Critical Data Store (CDS)
  - [CFE\\_ES\\_RestoreFromCDS](#) - Recover a block of data from the Critical Data Store (CDS)
- [cFE Memory Manager APIs](#)

- [CFE\\_ES\\_PoolCreate](#) - Initializes a memory pool created by an application while using a semaphore during processing.
  - [CFE\\_ES\\_PoolCreateEx](#) - Initializes a memory pool created by an application with application specified block sizes.
  - [CFE\\_ES\\_PoolCreateNoSem](#) - Initializes a memory pool created by an application without using a semaphore during processing.
  - [CFE\\_ES\\_PoolDelete](#) - Deletes a memory pool that was previously created.
  - [CFE\\_ES\\_GetPoolBuf](#) - Gets a buffer from the memory pool created by [CFE\\_ES\\_PoolCreate](#) or [CFE\\_ES\\_PoolCreateNoSem](#).
  - [CFE\\_ES\\_PutPoolBuf](#) - Releases a buffer from the memory pool that was previously allocated via [CFE\\_ES\\_GetPoolBuf](#).
  - [CFE\\_ES\\_GetMemPoolStats](#) - Extracts the statistics maintained by the memory pool software.
  - [CFE\\_ES\\_GetPoolBufInfo](#) - Gets info on a buffer previously allocated via [CFE\\_ES\\_GetPoolBuf](#).
- [cFE Performance Monitor APIs](#)
    - [CFE\\_ES\\_PerfLogEntry](#) - Entry marker for use with Software Performance Analysis Tool.
    - [CFE\\_ES\\_PerfLogExit](#) - Exit marker for use with Software Performance Analysis Tool.
    - [CFE\\_ES\\_PerfLogAdd](#) - Adds a new entry to the data buffer.
  - [cFE Generic Counter APIs](#)
    - [CFE\\_ES\\_RegisterGenCounter](#) - Register a generic counter.
    - [CFE\\_ES\\_DeleteGenCounter](#) - Delete a generic counter.
    - [CFE\\_ES\\_IncrementGenCounter](#) - Increments the specified generic counter.
    - [CFE\\_ES\\_SetGenCount](#) - Set the specified generic counter.
    - [CFE\\_ES\\_GetGenCount](#) - Get the specified generic counter count.
    - [CFE\\_ES\\_GetGenCounterIDByName](#) - Get the Id associated with a generic counter name.
    - [CFE\\_ES\\_GetGenCounterName](#) - Get a Counter name for a specified Counter ID.
  - [cFE Miscellaneous APIs](#)
    - [CFE\\_ES\\_BackgroundWakeup](#) - Wakes up the CFE background task.
    - [CFE\\_ES\\_CalculateCRC](#) - Calculate a CRC on a block of memory.
    - [CFE\\_ES\\_WriteToSysLog](#) - Write a string to the cFE System Log.
    - [CFE\\_ES\\_ProcessAsyncEvent](#) - Notification that an asynchronous event was detected by the underlying OS/PSP.
    - [CFE\\_ES\\_StatusToString](#) - Convert status to a string.
  - [cFE Resource ID APIs](#)
    - [CFE\\_ES\\_AppID\\_ToIndex](#) - Obtain an index value correlating to an ES Application ID.
    - [CFE\\_ES\\_LibID\\_ToIndex](#) - Obtain an index value correlating to an ES Library ID.
    - [CFE\\_ES\\_TaskID\\_ToIndex](#) - Obtain an index value correlating to an ES Task ID.
    - [CFE\\_ES\\_CounterID\\_ToIndex](#) - Obtain an index value correlating to an ES Counter ID.

## Events Services API

- cFE Registration APIs
  - [CFE\\_EVS\\_Register](#) - Register an application for receiving event services.
- cFE Send Event APIs
  - [CFE\\_EVS\\_SendEvent](#) - Generate a software event.
  - [CFE\\_EVS\\_SendEventWithAppID](#) - Generate a software event given the specified Application ID.
  - [CFE\\_EVS\\_SendTimedEvent](#) - Generate a software event with a specific time tag.
- cFE Reset Event Filter APIs
  - [CFE\\_EVS\\_ResetFilter](#) - Resets the calling application's event filter for a single event ID.
  - [CFE\\_EVS\\_ResetAllFilters](#) - Resets all of the calling application's event filters.

## File Services API

- cFE File Header Management APIs
  - [CFE\\_FS\\_ReadHeader](#) - Read the contents of the Standard cFE File Header.
  - [CFE\\_FS\\_InitHeader](#) - Initializes the contents of the Standard cFE File Header.
  - [CFE\\_FS\\_WriteHeader](#) - Write the specified Standard cFE File Header to the specified file.
  - [CFE\\_FS\\_SetTimestamp](#) - Modifies the Time Stamp field in the Standard cFE File Header for the specified file.
- cFE File Utility APIs
  - [CFE\\_FS\\_GetDefaultMountPoint](#) - Get the default virtual mount point for a file category.
  - [CFE\\_FS\\_GetDefaultExtension](#) - Get the default filename extension for a file category.
  - [CFE\\_FS\\_ParseInputFileNameEx](#) - Parse a filename input from an input buffer into a local buffer.
  - [CFE\\_FS\\_ParseInputFileName](#) - Parse a filename string from the user into a local buffer.
  - [CFE\\_FS\\_ExtractFilenameFromPath](#) - Extracts the filename from a unix style path and filename string.
  - [CFE\\_FS\\_BackgroundFileDumpRequest](#) - Register a background file dump request.
  - [CFE\\_FS\\_BackgroundFileDumplIsPending](#) - Query if a background file write request is currently pending.

## Message API

- cFE Generic Message APIs
  - [CFE\\_MSG\\_Init](#) - Initialize a message.
- cFE Message Primary Header APIs
  - [CFE\\_MSG\\_GetSize](#) - Gets the total size of a message.
  - [CFE\\_MSG\\_SetSize](#) - Sets the total size of a message.
  - [CFE\\_MSG.GetType](#) - Gets the message type.
  - [CFE\\_MSG\\_SetType](#) - Sets the message type.
  - [CFE\\_MSG\\_GetHeaderVersion](#) - Gets the message header version.
  - [CFE\\_MSG\\_SetHeaderVersion](#) - Sets the message header version.

- [CFE\\_MSG\\_GetHasSecondaryHeader](#) - Gets the message secondary header boolean.
- [CFE\\_MSG\\_SetHasSecondaryHeader](#) - Sets the message secondary header boolean.
- [CFE\\_MSG\\_GetApId](#) - Gets the message application ID.
- [CFE\\_MSG\\_SetApId](#) - Sets the message application ID.
- [CFE\\_MSG\\_GetSegmentationFlag](#) - Gets the message segmentation flag.
- [CFE\\_MSG\\_SetSegmentationFlag](#) - Sets the message segmentation flag.
- [CFE\\_MSG\\_GetSequenceCount](#) - Gets the message sequence count.
- [CFE\\_MSG\\_SetSequenceCount](#) - Sets the message sequence count.
- [CFE\\_MSG\\_GetNextSequenceCount](#) - Gets the next sequence count value (rolls over if appropriate)
- cFE Message Extended Header APIs
  - [CFE\\_MSG\\_GetEDSVersion](#) - Gets the message EDS version.
  - [CFE\\_MSG\\_SetEDSVersion](#) - Sets the message EDS version.
  - [CFE\\_MSG\\_GetEndian](#) - Gets the message endian.
  - [CFE\\_MSG\\_SetEndian](#) - Sets the message endian.
  - [CFE\\_MSG\\_GetPlaybackFlag](#) - Gets the message playback flag.
  - [CFE\\_MSG\\_SetPlaybackFlag](#) - Sets the message playback flag.
  - [CFE\\_MSG\\_GetSubsystem](#) - Gets the message subsystem.
  - [CFE\\_MSG\\_SetSubsystem](#) - Sets the message subsystem.
  - [CFE\\_MSG\\_GetSystem](#) - Gets the message system.
  - [CFE\\_MSG\\_SetSystem](#) - Sets the message system.
- cFE Message Secondary Header APIs
  - [CFE\\_MSG\\_GenerateChecksum](#) - Calculates and sets the checksum of a message.
  - [CFE\\_MSG\\_ValidateChecksum](#) - Validates the checksum of a message.
  - [CFE\\_MSG\\_SetFcnCode](#) - Sets the function code field in a message.
  - [CFE\\_MSG\\_GetFcnCode](#) - Gets the function code field from a message.
  - [CFE\\_MSG\\_GetMsgTime](#) - Gets the time field from a message.
  - [CFE\\_MSG\\_SetMsgTime](#) - Sets the time field in a message.
- cFE Message Id APIs
  - [CFE\\_MSG\\_GetMsgId](#) - Gets the message id from a message.
  - [CFE\\_MSG\\_SetMsgId](#) - Sets the message id bits in a message.
  - [CFE\\_MSG.GetTypeFromMsgId](#) - Gets message type using message ID.

## Resource ID API

- cFE Resource Misc APIs
  - [CFE\\_Resourceld\\_ToInteger](#) - Convert a resource ID to an integer.
  - [CFE\\_Resourceld\\_FromInteger](#) - Convert an integer to a resource ID.
  - [CFE\\_Resourceld\\_Equal](#) - Compare two Resource ID values for equality.
  - [CFE\\_Resourceld\\_IsDefined](#) - Check if a resource ID value is defined.
  - [CFE\\_Resourceld\\_GetBase](#) - Get the Base value (type/category) from a resource ID value.
  - [CFE\\_Resourceld\\_GetSerial](#) - Get the Serial Number (sequential ID) from a resource ID value.
  - [CFE\\_Resourceld\\_FindNext](#) - Locate the next resource ID which does not map to an in-use table entry.
  - [CFE\\_Resourceld\\_ToIndex](#) - Internal routine to aid in converting an ES resource ID to an array index.

## Software Bus Services API

- cFE Pipe Management APIs

- [CFE\\_SB\\_CreatePipe](#) - Creates a new software bus pipe.
- [CFE\\_SB\\_DeletePipe](#) - Delete a software bus pipe.
- [CFE\\_SB\\_Pipeld\\_ToIndex](#) - Obtain an index value correlating to an SB Pipe ID.
- [CFE\\_SB\\_SetPipeOpts](#) - Set options on a pipe.
- [CFE\\_SB\\_GetPipeOpts](#) - Get options on a pipe.
- [CFE\\_SB\\_GetPipeName](#) - Get the pipe name for a given id.
- [CFE\\_SB\\_GetPipeldByName](#) - Get pipe id by pipe name.

- cFE Message Subscription Control APIs

- [CFE\\_SB\\_Subscribe](#) - Subscribe to a message on the software bus with default parameters.
- [CFE\\_SB\\_SubscribeEx](#) - Subscribe to a message on the software bus.
- [CFE\\_SB\\_SubscribeLocal](#) - Subscribe to a message while keeping the request local to a cpu.
- [CFE\\_SB\\_Unsubscribe](#) - Remove a subscription to a message on the software bus.
- [CFE\\_SB\\_UnsubscribeLocal](#) - Remove a subscription to a message on the software bus on the current CPU.

- cFE Send/Receive Message APIs

- [CFE\\_SB\\_TransmitMsg](#) - Transmit a message.
- [CFE\\_SB\\_ReceiveBuffer](#) - Receive a message from a software bus pipe.

- cFE Zero Copy APIs

- [CFE\\_SB\\_AllocateMessageBuffer](#) - Get a buffer pointer to use for "zero copy" SB sends.
- [CFE\\_SB\\_ReleaseMessageBuffer](#) - Release an unused "zero copy" buffer pointer.
- [CFE\\_SB\\_TransmitBuffer](#) - Transmit a buffer.

- cFE Message Characteristics APIs

- [CFE\\_SB\\_SetUserDataLength](#) - Sets the length of user data in a software bus message.
- [CFE\\_SB\\_TimeStampMsg](#) - Sets the time field in a software bus message with the current spacecraft time.
- [CFE\\_SB\\_MessageStringSet](#) - Copies a string into a software bus message.
- [CFE\\_SB\\_GetUserData](#) - Get a pointer to the user data portion of a software bus message.
- [CFE\\_SB\\_GetUserDataLength](#) - Gets the length of user data in a software bus message.
- [CFE\\_SB\\_MessageStringGet](#) - Copies a string out of a software bus message.

- cFE Message ID APIs

- [CFE\\_SB\\_IsValidMsgId](#) - Identifies whether a given [CFE\\_SB\\_MsgId\\_t](#) is valid.
- [CFE\\_SB\\_MsgId\\_Equal](#) - Identifies whether two [CFE\\_SB\\_MsgId\\_t](#) values are equal.
- [CFE\\_SB\\_MsgIdToValue](#) - Converts a [CFE\\_SB\\_MsgId\\_t](#) to a normal integer.
- [CFE\\_SB\\_ValueToMsgId](#) - Converts a normal integer into a [CFE\\_SB\\_MsgId\\_t](#).

## Table Services API

- cFE Registration APIs
  - [CFE\\_TBL\\_Register](#) - Register a table with cFE to obtain Table Management Services.
  - [CFE\\_TBL\\_Share](#) - Obtain handle of table registered by another application.
  - [CFE\\_TBL\\_Unregister](#) - Unregister a table.
- cFE Manage Table Content APIs
  - [CFE\\_TBL\\_Load](#) - Load a specified table with data from specified source.
  - [CFE\\_TBL\\_Update](#) - Update contents of a specified table, if an update is pending.
  - [CFE\\_TBL\\_Validate](#) - Perform steps to validate the contents of a table image.
  - [CFE\\_TBL\\_Manage](#) - Perform standard operations to maintain a table.
  - [CFE\\_TBL\\_DumpToBuffer](#) - Copies the contents of a Dump Only Table to a shared buffer.
  - [CFE\\_TBL\\_Modified](#) - Notify cFE Table Services that table contents have been modified by the Application.
- cFE Access Table Content APIs
  - [CFE\\_TBL\\_GetAddress](#) - Obtain the current address of the contents of the specified table.
  - [CFE\\_TBL\\_GetAddresses](#) - Obtain the current addresses of an array of specified tables.
  - [CFE\\_TBL\\_ReleaseAddress](#) - Release previously obtained pointer to the contents of the specified table.
  - [CFE\\_TBL\\_ReleaseAddresses](#) - Release the addresses of an array of specified tables.
- cFE Get Table Information APIs
  - [CFE\\_TBL\\_GetStatus](#) - Obtain current status of pending actions for a table.
  - [CFE\\_TBL\\_GetInfo](#) - Obtain characteristics/information of/about a specified table.
  - [CFE\\_TBL\\_NotifyByMessage](#) - Instruct cFE Table Services to notify Application via message when table requires management.

## Time Services API

- cFE Get Current Time APIs
  - [CFE\\_TIME\\_GetTime](#) - Get the current spacecraft time.
  - [CFE\\_TIME\\_GetTAI](#) - Get the current TAI (MET + SCTF) time.
  - [CFE\\_TIME\\_GetUTC](#) - Get the current UTC (MET + SCTF - Leap Seconds) time.
  - [CFE\\_TIME\\_GetMET](#) - Get the current value of the Mission Elapsed Time (MET).
  - [CFE\\_TIME\\_GetMETseconds](#) - Get the current seconds count of the mission-elapsed time.
  - [CFE\\_TIME\\_GetMETsubsecs](#) - Get the current sub-seconds count of the mission-elapsed time.
- cFE Get Time Information APIs
  - [CFE\\_TIME\\_GetSTCF](#) - Get the current value of the spacecraft time correction factor (STCF).
  - [CFE\\_TIME\\_GetLeapSeconds](#) - Get the current value of the leap seconds counter.
  - [CFE\\_TIME\\_GetClockState](#) - Get the current state of the spacecraft clock.
  - [CFE\\_TIME\\_GetClockInfo](#) - Provides information about the spacecraft clock.
- cFE Time Arithmetic APIs
  - [CFE\\_TIME\\_Add](#) - Adds two time values.

- [CFE\\_TIME\\_Subtract](#) - Subtracts two time values.
- [CFE\\_TIME\\_Compare](#) - Compares two time values.
- cFE Time Conversion APIs
  - [CFE\\_TIME\\_MET2SCTime](#) - Convert specified MET into Spacecraft Time.
  - [CFE\\_TIME\\_Sub2MicroSecs](#) - Converts a sub-seconds count to an equivalent number of microseconds.
  - [CFE\\_TIME\\_Micro2SubSecs](#) - Converts a number of microseconds to an equivalent sub-seconds count.
- cFE External Time Source APIs
  - [CFE\\_TIME\\_ExternalTone](#) - Provides the 1 Hz signal from an external source.
  - [CFE\\_TIME\\_ExternalMET](#) - Provides the Mission Elapsed Time from an external source.
  - [CFE\\_TIME\\_ExternalGPS](#) - Provide the time from an external source that has data common to GPS receivers.
  - [CFE\\_TIME\\_ExternalTime](#) - Provide the time from an external source that measures time relative to a known epoch.
  - [CFE\\_TIME\\_RegisterSynchCallback](#) - Registers a callback function that is called whenever time synchronization occurs.
  - [CFE\\_TIME\\_UnregisterSynchCallback](#) - Unregisters a callback function that is called whenever time synchronization occurs.
- cFE Miscellaneous Time APIs
  - [CFE\\_TIME\\_Print](#) - Print a time value as a string.
  - [CFE\\_TIME\\_Local1HzISR](#) - This function is called via a timer callback set up at initialization of the TIME service.

## 5 Osal API Documentation

- General Information and Concepts
  - [OSAL Introduction](#)
- Core
  - [OSAL Return Code Defines](#)
  - [OSAL Object Type Defines](#)
  - APIs
    - \* [OSAL Core Operation APIs](#)
    - \* [OSAL Object ID Utility APIs](#)
    - \* [OSAL Task APIs](#)
    - \* [OSAL Message Queue APIs](#)
    - \* [OSAL Heap APIs](#)
    - \* [OSAL Error Info APIs](#)
    - \* [OSAL Select APIs](#)
    - \* [OSAL Printf APIs](#)
    - \* [OSAL BSP low level access APIs](#)
    - \* [OSAL Real Time Clock APIs](#)

- \* OSAL Shell APIs
  - Common Reference
  - Return Code Reference
  - Id Map Reference
  - Clock Reference
  - Task Reference
  - Message Queue Reference
  - Heap Reference
  - Select Reference
  - Printf Reference
  - BSP Reference
  - Shell Reference
- File System
  - File System Overview
  - File Descriptors In Osal
  - OSAL File Access Option Defines
  - OSAL Reference Point For Seek Offset Defines
  - APIs
    - \* OSAL Standard File APIs
    - \* OSAL Directory APIs
    - \* OSAL File System Level APIs
  - File System Reference
  - File Reference
  - Directory Reference
- Object File Loader
  - APIs
    - \* OSAL Dynamic Loader and Symbol APIs
  - File Loader Reference
- Network
  - APIs
    - \* OSAL Network ID APIs
    - \* OSAL Socket Address APIs
    - \* OSAL Socket Management APIs
  - Network Reference
  - Socket Reference
- Timer
  - Timer Overview
  - APIs
    - \* OSAL Time Base APIs
    - \* OSAL Timer APIs

- [Timer Reference](#)
- [Time Base Reference](#)
- Semaphore and Mutex
  - [OSAL Semaphore State Defines](#)
  - APIs
    - \* [OSAL Binary Semaphore APIs](#)
    - \* [OSAL Counting Semaphore APIs](#)
    - \* [OSAL Mutex APIs](#)
  - [Binary Semaphore Reference](#)
  - [Counting Semaphore Reference](#)
  - [Mutex Reference](#)

## 5.1 OSAL Introduction

The goal of this library is to promote the creation of portable and reusable real time embedded system software. Given the necessary OS abstraction layer implementations, the same embedded software should compile and run on a number of platforms ranging from spacecraft computer systems to desktop PCs.

The OS Application Program Interfaces (APIs) are broken up into core, file system, loader, network, and timer APIs. See the related document sections for full descriptions.

### Note

The majority of these APIs should be called from a task running in the context of an OSAL application and in general should not be called from an ISR. There are a few exceptions, such as the ability to give a binary semaphore from an ISR.

## 5.2 File System Overview

The File System API is a thin wrapper around a selection of POSIX file APIs. In addition the File System API presents a common directory structure and volume view regardless of the underlying system type. For example, vxWorks uses MS-DOS style volume names and directories where a vxWorks RAM disk might have the volume “RAM:0”. With this File System API, volumes are represented as Unix-style paths where each volume is mounted on the root file system:

- RAM:0/file1.dat becomes /mnt/ram/file1.dat
- FL:0/file2.dat becomes /mnt/fl/file2.dat

This abstraction allows the applications to use the same paths regardless of the implementation and it also allows file systems to be simulated on a desktop system for testing. On a desktop Linux system, the file system abstraction can be set up to map virtual devices to a regular directory. This is accomplished through the OS\_mkfs call, OS\_mount call, and a BSP specific volume table that maps the virtual devices to real devices or underlying file systems.

In order to make this file system volume abstraction work, a “Volume Table” needs to be provided in the Board Support Package of the application. The table has the following fields:

- Device Name: This is the name of the virtual device that the Application uses. Common names are “ramdisk1”, “flash1”, or “volatile1” etc. But the name can be any unique string.
- Physical Device Name: This is an implementation specific field. For vxWorks it is not needed and can be left blank. For a File system based implementation, it is the “mount point” on the root file system where all of the volume will be mounted. A common place for this on Linux could be a user’s home directory, “/tmp”, or even the current working directory “.”. In the example of “/tmp” all of the directories created for the volumes would be under “/tmp” on the Linux file system. For a real disk device in Linux, such as a RAM disk, this field is the device name “/dev/ram0”.
- Volume Type: This field defines the type of volume. The types are: FS\_BASED which uses the existing file system, RAM\_DISK which uses a RAM\_DISK device in vxWorks, RTEMS, or Linux, FLASH\_DISK\_FORMAT which uses a flash disk that is to be formatted before use, FLASH\_DISK\_INIT which uses a flash disk with an existing format that is just to be initialized before its use, EEPROM which is for an EEPROM or PROM based system.
- Volatile Flag: This flag indicates that the volume or disk is a volatile disk (RAM disk) or a non-volatile disk, that retains its contents when the system is rebooted. This should be set to TRUE or FALSE.
- Free Flag: This is an internal flag that should be set to FALSE or zero.
- Is Mounted Flag: This is an internal flag that should be set to FALSE or zero. Note that a “pre-mounted” FS\_BASED path can be set up by setting this flag to one.
- Volume Name: This is an internal field and should be set to a space character “ ”.
- Mount Point Field: This is an internal field and should be set to a space character “ ”.
- Block Size Field: This is used to record the block size of the device and does not need to be set by the user.

### 5.3 File Descriptors In Osal

The OSAL uses abstracted file descriptors. This means that the file descriptors passed back from the OS\_open and OS\_creat calls will only work with other OSAL OS\_\* calls. The reasoning for this is as follows:

Because the OSAL now keeps track of all file descriptors, OSAL specific information can be associated with a specific file descriptor in an OS independent way. For instance, the path of the file that the file descriptor points to can be easily retrieved. Also, the OSAL task ID of the task that opened the file can also be retrieved easily. Both of these pieces of information are very useful when trying to determine statistics for a task, or the entire system. This information can all be retrieved with a single API, OS\_FDGetInfo.

All of the possible file system calls are not implemented. "Special" files requiring OS specific control/operations are by nature not portable. Abstraction in this case is not possible, so the raw OS calls should be used (including open/close/etc). Mixing with OSAL calls is not supported for such cases. [OS\\_TranslatePath](#) is available to support using open directly by an app and maintain abstraction on the file system.

There are some small drawbacks with the OSAL file descriptors. Because the related information is kept in a table, there is a define called OS\_MAX\_NUM\_OPEN\_FILES that defines the maximum number of file descriptors available. This is a configuration parameter, and can be changed to fit your needs.

Also, if you open or create a file not using the OSAL calls (OS\_open or OS\_creat) then none of the other OS\_\* calls that accept a file descriptor as a parameter will work (the results of doing so are undefined). Therefore, if you open a file with the underlying OS’s open call, you must continue to use the OS’s calls until you close the file descriptor. Be aware that by doing this your software may no longer be OS agnostic.

## 5.4 Timer Overview

The timer API is a generic interface to the OS timer facilities. It is implemented using the POSIX timers on Linux and vxWorks and the native timer API on RTEMS. The number of timers supported is controlled by the configuration parameter OS\_MAX\_TIMERS.

# 6 cFE Mission Configuration Parameters

## Global CFE\_MISSION\_ES\_HK\_TLM\_MSG

cFE Portable Message Numbers for Telemetry

## Global CFE\_MISSION\_EVS\_CMD\_MSG

cFE Portable Message Numbers for Commands

## Global CFE\_MISSION\_MAX\_API\_LEN

cFE Maximum length for API names within data exchange structures

## Global CFE\_MISSION\_MAX\_FILE\_LEN

cFE Maximum length for filenames within data exchange structures

## Global CFE\_MISSION\_MAX\_PATH\_LEN

cFE Maximum length for pathnames within data exchange structures

## Global CFE\_MISSION\_TIME\_DATA\_CMD\_MSG

cFE Portable Message Numbers for Global Messages

# 7 Module Index

## 7.1 Modules

Here is a list of all modules:

CFS Data Storage Mission Configuration	132
CFS Data Storage Message IDs	133
CFS Data Storage Message IDs	134
CFS Data Storage Platform Configuration	135
CFS Data Store Event IDs	148
CFS Data Storage Command Structures	178
CFS Data Storage Telemetry	179
CFS Data Storage Command Codes	180
CFS Data Storage Version	199
cFE Return Code Defines	200

cFE Resource ID APIs	237
cFE Entry/Exit APIs	241
cFE Application Control APIs	243
cFE Application Behavior APIs	246
cFE Information APIs	251
cFE Child Task APIs	261
cFE Miscellaneous APIs	266
cFE Critical Data Store APIs	270
cFE Memory Manager APIs	276
cFE Performance Monitor APIs	284
cFE Generic Counter APIs	287
cFE Registration APIs	295
cFE Send Event APIs	297
cFE Reset Event Filter APIs	302
cFE File Header Management APIs	304
cFE File Utility APIs	309
cFE Generic Message APIs	315
cFE Message Primary Header APIs	316
cFE Message Extended Header APIs	327
cFE Message Secondary Header APIs	334
cFE Message Id APIs	339
cFE Pipe Management APIs	342
cFE Message Subscription Control APIs	349
cFE Send/Receive Message APIs	355
cFE Zero Copy APIs	358
cFE Message Characteristics APIs	361
cFE Message ID APIs	366
cFE SB Pipe options	369
cFE Registration APIs	370
cFE Manage Table Content APIs	376

cFE Access Table Content APIs	383
cFE Get Table Information APIs	388
cFE Table Type Defines	392
cFE Get Current Time APIs	396
cFE Get Time Information APIs	400
cFE Time Arithmetic APIs	403
cFE Time Conversion APIs	406
cFE External Time Source APIs	409
cFE Miscellaneous Time APIs	414
cFE Resource ID base values	416
cFE Clock State Flag Defines	418
OSAL Semaphore State Defines	421
OSAL Binary Semaphore APIs	422
OSAL BSP low level access APIs	428
OSAL Real Time Clock APIs	429
OSAL Core Operation APIs	441
OSAL Counting Semaphore APIs	445
OSAL Directory APIs	451
OSAL Return Code Defines	456
OSAL Error Info APIs	467
OSAL File Access Option Defines	470
OSAL Reference Point For Seek Offset Defines	471
OSAL Standard File APIs	472
OSAL File System Level APIs	485
OSAL Heap APIs	494
OSAL Object Type Defines	495
OSAL Object ID Utility APIs	499
OSAL Dynamic Loader and Symbol APIs	506
OSAL Mutex APIs	511
OSAL Network ID APIs	516

OSAL Printf APIs	518
OSAL Message Queue APIs	520
OSAL Select APIs	525
OSAL Shell APIs	530
OSAL Socket Address APIs	531
OSAL Socket Management APIs	535
OSAL Task APIs	543
OSAL Time Base APIs	550
OSAL Timer APIs	556

## 8 Data Structure Index

### 8.1 Data Structures

Here are the data structures with brief descriptions:

<a href="#"><b>CCSDS_ExtendedHeader</b></a> CCSDS packet extended header	563
<a href="#"><b>CCSDS_PrimaryHeader</b></a> CCSDS packet primary header	564
<a href="#"><b>CFE_ES_AppInfo</b></a> Application Information	565
<a href="#"><b>CFE_ES_AppNameCmd</b></a> Generic application name command	571
<a href="#"><b>CFE_ES_AppNameCmd_Payload</b></a> Generic application name command payload	572
<a href="#"><b>CFE_ES_AppReloadCmd_Payload</b></a> Reload Application Command Payload	573
<a href="#"><b>CFE_ES_BlockStats</b></a> Block statistics	574
<a href="#"><b>CFE_ES_CDSRegDumpRec</b></a> CDS Register Dump Record	575
<a href="#"><b>CFE_ES_DeleteCDSCmd</b></a> Delete Critical Data Store Command	577
<a href="#"><b>CFE_ES_DeleteCDSCmd_Payload</b></a> Delete Critical Data Store Command Payload	578

<a href="#"><b>CFE_ES_DumpCDSRegistryCmd</b></a>	Dump CDS Registry Command	579
<a href="#"><b>CFE_ES_DumpCDSRegistryCmd_Payload</b></a>	Dump CDS Registry Command Payload	580
<a href="#"><b>CFE_ES_FileNameCmd</b></a>	Generic file name command	581
<a href="#"><b>CFE_ES_FileNameCmd_Payload</b></a>	Generic file name command payload	582
<a href="#"><b>CFE_ES_HousekeepingTlm</b></a>		583
<a href="#"><b>CFE_ES_HousekeepingTlm_Payload</b></a>		583
<a href="#"><b>CFE_ES_MemPoolStats</b></a>	Memory Pool Statistics	596
<a href="#"><b>CFE_ES_MemStatsTlm</b></a>		598
<a href="#"><b>CFE_ES_NoArgsCmd</b></a>	Generic "no arguments" command	599
<a href="#"><b>CFE_ES_OneAppTlm</b></a>		600
<a href="#"><b>CFE_ES_OneAppTlm_Payload</b></a>		601
<a href="#"><b>CFE_ES_OverWriteSysLogCmd</b></a>	Overwrite/Discard System Log Configuration Command Payload	602
<a href="#"><b>CFE_ES_OverWriteSysLogCmd_Payload</b></a>	Overwrite/Discard System Log Configuration Command Payload	603
<a href="#"><b>CFE_ES_PoolAlign</b></a>	Pool Alignment	604
<a href="#"><b>CFE_ES_PoolStatsTlm_Payload</b></a>		605
<a href="#"><b>CFE_ES_ReloadAppCmd</b></a>	Reload Application Command	606
<a href="#"><b>CFE_ES_RestartCmd</b></a>	Restart cFE Command	607
<a href="#"><b>CFE_ES_RestartCmd_Payload</b></a>	Restart cFE Command Payload	608
<a href="#"><b>CFE_ES_SendMemPoolStatsCmd</b></a>	Send Memory Pool Statistics Command	609
<a href="#"><b>CFE_ES_SendMemPoolStatsCmd_Payload</b></a>	Send Memory Pool Statistics Command Payload	610
<a href="#"><b>CFE_ES_SetMaxPRCountCmd</b></a>	Set Maximum Processor Reset Count Command	611

<b>CFE_ES_SetMaxPRCountCmd_Payload</b>	Set Maximum Processor Reset Count Command Payload	612
<b>CFE_ES_SetPerfFilterMaskCmd</b>	Set Performance Analyzer Filter Mask Command	612
<b>CFE_ES_SetPerfFilterMaskCmd_Payload</b>	Set Performance Analyzer Filter Mask Command Payload	613
<b>CFE_ES_SetPerfTriggerMaskCmd</b>	Set Performance Analyzer Trigger Mask Command	614
<b>CFE_ES_SetPerfTrigMaskCmd_Payload</b>	Set Performance Analyzer Trigger Mask Command Payload	615
<b>CFE_ES_StartApp</b>	Start Application Command	616
<b>CFE_ES_StartAppCmd_Payload</b>	Start Application Command Payload	617
<b>CFE_ES_StartPerfCmd_Payload</b>	Start Performance Analyzer Command Payload	619
<b>CFE_ES_StartPerfDataCmd</b>	Start Performance Analyzer Command	620
<b>CFE_ES_StopPerfCmd_Payload</b>	Stop Performance Analyzer Command Payload	621
<b>CFE_ES_StopPerfDataCmd</b>	Stop Performance Analyzer Command	622
<b>CFE_ES_TaskInfo</b>	Task Information	623
<b>CFE_EVS_AppDataCmd_Payload</b>	Write Event Services Application Information to File Command Payload	626
<b>CFE_EVS_AppNameBitMaskCmd</b>	Generic App Name and Bitmask Command	626
<b>CFE_EVS_AppNameBitMaskCmd_Payload</b>	Generic App Name and Bitmask Command Payload	627
<b>CFE_EVS_AppNameCmd</b>	Generic App Name Command	629
<b>CFE_EVS_AppNameCmd_Payload</b>	Generic App Name Command Payload	630
<b>CFE_EVS_AppNameEventIDCmd</b>	Generic App Name and Event ID Command	631
<b>CFE_EVS_AppNameEventIDCmd_Payload</b>	Generic App Name and Event ID Command Payload	632

<a href="#">CFE_EVS_AppNameEventIDMaskCmd</a> Generic App Name, Event ID, Mask Command	633
<a href="#">CFE_EVS_AppNameEventIDMaskCmd_Payload</a> Generic App Name, Event ID, Mask Command Payload	634
<a href="#">CFE_EVS_AppTlmData</a>	635
<a href="#">CFE_EVS_BinFilter</a> Event message filter definition structure	636
<a href="#">CFE_EVS_BitMaskCmd</a> Generic Bitmask Command	637
<a href="#">CFE_EVS_BitMaskCmd_Payload</a> Generic Bitmask Command Payload	638
<a href="#">CFE_EVS_HousekeepingTlm</a>	639
<a href="#">CFE_EVS_HousekeepingTlm_Payload</a>	640
<a href="#">CFE_EVS_LogFileCmd_Payload</a> Write Event Log to File Command Payload	645
<a href="#">CFE_EVS_LongEventTlm</a>	646
<a href="#">CFE_EVS_LongEventTlm_Payload</a>	647
<a href="#">CFE_EVS_NoArgsCmd</a> Command with no additional arguments	649
<a href="#">CFE_EVS_PacketID</a>	649
<a href="#">CFE_EVS_SetEventFormatCode_Payload</a> Set Event Format Mode Command Payload	651
<a href="#">CFE_EVS_SetEventFormatModeCmd</a> Set Event Format Mode Command	652
<a href="#">CFE_EVS_SetLogMode_Payload</a> Set Log Mode Command Payload	653
<a href="#">CFE_EVS_SetLogModeCmd</a> Set Log Mode Command	654
<a href="#">CFE_EVS_ShortEventTlm</a>	655
<a href="#">CFE_EVS_ShortEventTlm_Payload</a>	656
<a href="#">CFE_EVS_WriteAppDataFileCmd</a> Write Event Services Application Information to File Command	657
<a href="#">CFE_EVS_WriteLogFileCmd</a> Write Event Log to File Command	658
<a href="#">CFE_FS_FileWriteMetaData</a> External Metadata/State object associated with background file writes	659

<b>CFE_FS_Header</b>	Standard cFE File header structure definition	661
<b>CFE_SB_AllSubscriptionsTlm</b>		663
<b>CFE_SB_AllSubscriptionsTlm_Payload</b>		664
<b>CFE_SB_HousekeepingTlm</b>		666
<b>CFE_SB_HousekeepingTlm_Payload</b>		667
<b>CFE_SB_Msg</b>	Software Bus generic message	672
<b>CFE_SB_MsgId_t</b>	CFE_SB_MsgId_t type definition	673
<b>CFE_SB_MsgMapFileEntry</b>	SB Map File Entry	674
<b>CFE_SB_PipeDepthStats</b>	SB Pipe Depth Statistics	675
<b>CFE_SB_PipeInfoEntry</b>	SB Pipe Information File Entry	677
<b>CFE_SB_Qos_t</b>	Quality Of Service Type Definition	680
<b>CFE_SB_RouteCmd</b>	Enable/Disable Route Command	681
<b>CFE_SB_RouteCmd_Payload</b>	Enable/Disable Route Command Payload	682
<b>CFE_SB_RoutingFileEntry</b>	SB Routing File Entry	684
<b>CFE_SB_SingleSubscriptionTlm</b>		686
<b>CFE_SB_SingleSubscriptionTlm_Payload</b>		686
<b>CFE_SB_StatsTlm</b>		688
<b>CFE_SB_StatsTlm_Payload</b>		689
<b>CFE_SB_SubEntries</b>	SB Previous Subscriptions Entry	694
<b>CFE_SB_WriteFileInfoCmd</b>	Write File Info Command	696
<b>CFE_SB_WriteFileInfoCmd_Payload</b>	Write File Info Command Payload	697
<b>CFE_TBL_AbortLoadCmd</b>	Abort Load Command	697

<b>CFE_TBL_AbortLoadCmd_Payload</b>		
Abort Load Command Payload		698
<b>CFE_TBL_ActivateCmd</b>		
Activate Table Command		699
<b>CFE_TBL_ActivateCmd_Payload</b>		
Activate Table Command Payload		700
<b>CFE_TBL_DeleteCDSCommand_Payload</b>		
Delete Critical Table CDS Command Payload		701
<b>CFE_TBL_DeleteCDSCommand</b>		
Delete Critical Table CDS Command		702
<b>CFE_TBL_DumpCmd</b>		
<b>CFE_TBL_DumpCmd_Payload</b>		
Dump Table Command Payload		704
<b>CFE_TBL_DumpRegistryCmd</b>		
Dump Registry Command		705
<b>CFE_TBL_DumpRegistryCmd_Payload</b>		
Dump Registry Command Payload		706
<b>CFE_TBL_File_Hdr</b>		
The definition of the header fields that are included in CFE Table Data files		707
<b>CFE_TBL_FileDef</b>		
<b>CFE_TBL_HousekeepingTIm</b>		
<b>CFE_TBL_HousekeepingTIm_Payload</b>		
<b>CFE_TBL_Info</b>		
Table Info		717
<b>CFE_TBL_LoadCmd</b>		
Load Table Command		721
<b>CFE_TBL_LoadCmd_Payload</b>		
Load Table Command Payload		722
<b>CFE_TBL_NoArgsCmd</b>		
Generic "no arguments" command		723
<b>CFE_TBL_NotifyCmd</b>		
<b>CFE_TBL_NotifyCmd_Payload</b>		
Table Management Notification Command Payload		724
<b>CFE_TBL_SendRegistryCmd</b>		
Send Table Registry Command		725
<b>CFE_TBL_SendRegistryCmd_Payload</b>		
Send Table Registry Command Payload		726

<b>CFE_TBL_TableRegistryTlm</b>	727
<b>CFE_TBL_TblRegPacket_Payload</b>	728
<b>CFE_TBL_ValidateCmd</b> Validate Table Command	734
<b>CFE_TBL_ValidateCmd_Payload</b> Validate Table Command Payload	735
<b>CFE_TIME_DiagnosticTlm</b>	736
<b>CFE_TIME_DiagnosticTlm_Payload</b>	736
<b>CFE_TIME_HousekeepingTlm</b>	749
<b>CFE_TIME_HousekeepingTlm_Payload</b>	750
<b>CFE_TIME_LeapsCmd_Payload</b> Set leap seconds command payload	754
<b>CFE_TIME_NoArgsCmd</b> Generic no argument command	755
<b>CFE_TIME_OneHzAdjustmentCmd</b> Generic seconds, subseconds adjustment command	756
<b>CFE_TIME_OneHzAdjustmentCmd_Payload</b> Generic seconds, subseconds command payload	757
<b>CFE_TIME_SetLeapSecondsCmd</b> Set leap seconds command	758
<b>CFE_TIME_SetSignalCmd</b> Set tone signal source command	759
<b>CFE_TIME_SetSourceCmd</b> Set time data source command	760
<b>CFE_TIME_SetStateCmd</b> Set clock state command	761
<b>CFE_TIME_SignalCmd_Payload</b> Set tone signal source command payload	762
<b>CFE_TIME_SourceCmd_Payload</b> Set time data source command payload	763
<b>CFE_TIME_StateCmd_Payload</b> Set clock state command payload	763
<b>CFE_TIME_SysTime</b> Data structure used to hold system time values	764
<b>CFE_TIME_TimeCmd</b> Generic seconds, microseconds argument command	765

<b>CFE_TIME_TimeCmd_Payload</b> Generic seconds, microseconds command payload	766
<b>CFE_TIME_ToneDataCmd</b> Time at tone data command	767
<b>CFE_TIME_ToneDataCmd_Payload</b> Time at tone data command payload	768
<b>DS_AddMidCmd_t</b> Add Message ID To Packet Filter Table	770
<b>DS_AppData_t</b> DS global data structure definition	771
<b>DS_AppFileStatus_t</b> Current state of destination files	778
<b>DS_AppStateCmd_t</b> Set Ena/Dis State For DS Application	782
<b>DS_CloseAllCmd_t</b> Close All Destination Files	783
<b>DS_CloseFileCmd_t</b> Close Destination File	784
<b>DS_DestAgeCmd_t</b> Set Max File Age For Destination File Table Entry	785
<b>DS_DestBaseCmd_t</b> Set Base Portion Of Filename For Destination File Table Entry	786
<b>DS_DestCountCmd_t</b> Set Sequence Portion Of Filename For Destination File Table Entry	788
<b>DS_DestExtCmd_t</b> Set Extension Portion Of Filename For Destination File Table Entry	790
<b>DS_DestFileEntry_t</b> DS Destination File Table Entry	791
<b>DS_DestFileTable_t</b> DS Destination File Table	794
<b>DS_DestPathCmd_t</b> Set Path Portion Of Filename For Destination File Table Entry	795
<b>DS_DestSizeCmd_t</b> Set Max File Size For Destination File Table Entry	797
<b>DS_DestStateCmd_t</b> Set Ena/Dis State For Destination File Table Entry	798
<b>DS_DestTypeCmd_t</b> Set Filename Type For Destination File Table Entry	800

<b>DS_FileCompletePkt_t</b>	Single application file info packet	801
<b>DS_FileCompletePktBuf_t</b>	Single application file info packet buffer	802
<b>DS_FileHeader_t</b>	DS File Header (follows cFE file header at start of file)	803
<b>DS_FileInfo_t</b>	Current state of destination files	805
<b>DS_FileInfoPkt_t</b>	Application file info packet	808
<b>DS_FilterFileCmd_t</b>	Set File Selection For Packet Filter Table Entry	809
<b>DS_FilterParms_t</b>	DS Packet Filter Parameters	810
<b>DS_FilterParmsCmd_t</b>	Set Filter Parameters For Packet Filter Table Entry	812
<b>DS_FilterTable_t</b>	DS Filter Table	814
<b>DS_FilterTypeCmd_t</b>	Set Filter Type For Packet Filter Table Entry	815
<b>DS_GetFileInfoCmd_t</b>	Get File Info Command	817
<b>DS_HashTag</b>	DS Hash Table Linked List structure	818
<b>DS_HkPacket_t</b>	Application housekeeping packet	819
<b>DS_NoopCmd_t</b>	No-Operation Command	825
<b>DS_PacketEntry_t</b>	DS Filter Table Packet Entry	826
<b>DS_ResetCmd_t</b>	Reset Housekeeping Telemetry Command	827
<b>OS_bin_sem_prop_t</b>	OSAL binary semaphore properties	828
<b>OS_count_sem_prop_t</b>	OSAL counting semaphore properties	829
<b>os_dirent_t</b>	Directory entry	830

<b>OS_FdSet</b>	An abstract structure capable of holding several OSAL IDs	830
<b>OS_file_prop_t</b>	OSAL file properties	831
<b>os_fsinfo_t</b>	OSAL file system info	832
<b>os_fstat_t</b>	File system status	834
<b>OS_heap_prop_t</b>	OSAL heap properties	835
<b>OS_module_address_t</b>	OSAL module address properties	836
<b>OS_module_prop_t</b>	OSAL module properties	838
<b>OS_mut_sem_prop_t</b>	OSAL mutex properties	839
<b>OS_queue_prop_t</b>	OSAL queue properties	840
<b>OS_SockAddr_t</b>	Encapsulates a generic network address	841
<b>OS_SockAddrData_t</b>	Storage buffer for generic network address	842
<b>OS_socket_prop_t</b>	Encapsulates socket properties	844
<b>OS_static_symbol_record_t</b>	Associates a single symbol name with a memory address	845
<b>OS_statvfs_t</b>		846
<b>OS_task_prop_t</b>	OSAL task properties	847
<b>OS_time_t</b>	OSAL time interval structure	848
<b>OS_timebase_prop_t</b>	Time base properties	849
<b>OS_timer_prop_t</b>	Timer properties	850

---

## 9 File Index

## 9.1 File List

Here is a list of all files with brief descriptions:

<a href="#">apps/ds/fsw/mission_inc/ds_perfids.h</a>	852
<a href="#">apps/ds/fsw/platform_inc/ds_msgids.h</a>	852
<a href="#">apps/ds/fsw/platform_inc/ds_platform_cfg.h</a>	853
<a href="#">apps/ds/fsw/src/ds_app.c</a>	854
<a href="#">apps/ds/fsw/src/ds_app.h</a>	865
<a href="#">apps/ds/fsw/src/ds_appdefs.h</a>	877
<a href="#">apps/ds/fsw/src/ds_cmds.c</a>	882
<a href="#">apps/ds/fsw/src/ds_cmds.h</a>	907
<a href="#">apps/ds/fsw/src/ds_events.h</a>	932
<a href="#">apps/ds/fsw/src/ds_file.c</a>	935
<a href="#">apps/ds/fsw/src/ds_file.h</a>	955
<a href="#">apps/ds/fsw/src/ds_msg.h</a>	971
<a href="#">apps/ds/fsw/src/ds_msgdefs.h</a>	972
<a href="#">apps/ds/fsw/src/ds_table.c</a>	973
<a href="#">apps/ds/fsw/src/ds_table.h</a>	999
<a href="#">apps/ds/fsw/src/ds_verify.h</a>	1026
<a href="#">apps/ds/fsw/src/ds_version.h</a>	1027
<a href="#">apps/ds/fsw/tables/ds_file_tbl.c</a>	1027
<a href="#">apps/ds/fsw/tables/ds_filter_tbl.c</a>	1029
<a href="#">build/docs/osconfig-example.h</a>	1032
<a href="#">cfe/cmake/sample_defs/cpu1_msgids.h</a>	1041
<a href="#">cfe/cmake/sample_defs/cpu1_platform_cfg.h</a>	1049
<a href="#">cfe/cmake/sample_defs/sample_mission_cfg.h</a>	1106
<a href="#">cfe/cmake/sample_defs/sample_perfids.h</a>	1127
<a href="#">cfe/modules/core_api/fsw/inc/cfe.h</a>	1131
<a href="#">cfe/modules/core_api/fsw/inc/cfe_config.h</a>	1132
<a href="#">cfe/modules/core_api/fsw/inc/cfe_config_api_typedefs.h</a>	1136

cfe/modules/core_api/fsw/inc/cfe_endian.h	1138
cfe/modules/core_api/fsw/inc/cfe_error.h	1138
cfe/modules/core_api/fsw/inc/cfe_es.h	1149
cfe/modules/core_api/fsw/inc/cfe_es_api_typedefs.h	1153
cfe/modules/core_api/fsw/inc/cfe_es_extern_typedefs.h	1159
cfe/modules/core_api/fsw/inc/cfe_evs.h	1171
cfe/modules/core_api/fsw/inc/cfe_evs_api_typedefs.h	1173
cfe/modules/core_api/fsw/inc/cfe_evs_extern_typedefs.h	1176
cfe/modules/core_api/fsw/inc/cfe_fs.h	1181
cfe/modules/core_api/fsw/inc/cfe_fs_api_typedefs.h	1182
cfe/modules/core_api/fsw/inc/cfe_fs_extern_typedefs.h	1185
cfe/modules/core_api/fsw/inc/cfe_msg.h	1188
cfe/modules/core_api/fsw/inc/cfe_msg_api_typedefs.h	1190
cfe/modules/core_api/fsw/inc/cfe_resourceid.h	1198
cfe/modules/core_api/fsw/inc/cfe_resourceid_api_typedefs.h	1205
cfe/modules/core_api/fsw/inc/cfe_sb.h	1207
cfe/modules/core_api/fsw/inc/cfe_sb_api_typedefs.h	1209
cfe/modules/core_api/fsw/inc/cfe_sb_extern_typedefs.h	1214
cfe/modules/core_api/fsw/inc/cfe_tbl.h	1218
cfe/modules/core_api/fsw/inc/cfe_tbl_api_typedefs.h	1219
cfe/modules/core_api/fsw/inc/cfe_tbl_extern_typedefs.h	1222
cfe/modules/core_api/fsw/inc/cfe_tbl_filedef.h	1224
cfe/modules/core_api/fsw/inc/cfe_time.h	1226
cfe/modules/core_api/fsw/inc/cfe_time_api_typedefs.h	1228
cfe/modules/core_api/fsw/inc/cfe_time_extern_typedefs.h	1230
cfe/modules/core_api/fsw/inc/cfe_version.h	1236
cfe/modules/es/fsw/inc/cfe_es_events.h	1239
cfe/modules/es/fsw/inc/cfe_es_msg.h	1272
cfe/modules/evs/fsw/inc/cfe_evs_events.h	1308
cfe/modules/evs/fsw/inc/cfe_evs_msg.h	1323

<a href="#">cfe/modules/msg/fsw/inc/ccsds_hdr.h</a>	1355
<a href="#">cfe/modules/resourceid/fsw/inc/cfe_core_resourceid_basevalues.h</a>	1356
<a href="#">cfe/modules/resourceid/fsw/inc/cfe_resourceid_basevalue.h</a>	1357
<a href="#">cfe/modules/sb/fsw/inc/cfe_sb_events.h</a>	1359
<a href="#">cfe/modules/sb/fsw/inc/cfe_sb_msg.h</a>	1383
<a href="#">cfe/modules/tbl/fsw/inc/cfe_tbl_events.h</a>	1401
<a href="#">cfe/modules/tbl/fsw/inc/cfe_tbl_msg.h</a>	1427
<a href="#">cfe/modules/time/fsw/inc/cfe_time_events.h</a>	1444
<a href="#">cfe/modules/time/fsw/inc/cfe_time_msg.h</a>	1458
<a href="#">osal/src/os/inc/common_types.h</a>	1484
<a href="#">osal/src/os/inc/osapi-binsem.h</a>	1492
<a href="#">osal/src/os/inc/osapi-bsp.h</a>	1493
<a href="#">osal/src/os/inc/osapi-clock.h</a>	1494
<a href="#">osal/src/os/inc/osapi-common.h</a>	1496
<a href="#">osal/src/os/inc/osapi-constants.h</a>	1499
<a href="#">osal/src/os/inc/osapi-countsem.h</a>	1500
<a href="#">osal/src/os/inc/osapi-dir.h</a>	1501
<a href="#">osal/src/os/inc/osapi-error.h</a>	1502
<a href="#">osal/src/os/inc/osapi-file.h</a>	1506
<a href="#">osal/src/os/inc/osapi-fs.h</a>	1510
<a href="#">osal/src/os/inc/osapi-heap.h</a>	1512
<a href="#">osal/src/os/inc/osapi-idmap.h</a>	1512
<a href="#">osal/src/os/inc/osapi-macros.h</a>	1514
<a href="#">osal/src/os/inc/osapi-module.h</a>	1517
<a href="#">osal/src/os/inc/osapi-mutex.h</a>	1518
<a href="#">osal/src/os/inc/osapi-network.h</a>	1519
<a href="#">osal/src/os/inc/osapi-printf.h</a>	1520
<a href="#">osal/src/os/inc/osapi-queue.h</a>	1520
<a href="#">osal/src/os/inc/osapi-select.h</a>	1521
<a href="#">osal/src/os/inc/osapi-shell.h</a>	1522

<a href="#">osal/src/os/inc/osapi-sockets.h</a>	1522
<a href="#">osal/src/os/inc/osapi-task.h</a>	1525
<a href="#">osal/src/os/inc/osapi-timebase.h</a>	1529
<a href="#">osal/src/os/inc/osapi-timer.h</a>	1530
<a href="#">osal/src/os/inc/osapi-version.h</a>	1531
<a href="#">osal/src/os/inc/osapi.h</a>	1536
<a href="#">psp/fsw/inc/cfe_psp.h</a>	1537
<a href="#">psp/fsw/inc/cfe_psp_error.h</a>	
CFE PSP Error header	1558

## 10 Module Documentation

### 10.1 CFS Data Storage Mission Configuration

#### Macros

- `#define DS_APPMAIN_PERF_ID 38`  
*Main application performance ID.*

#### 10.1.1 Detailed Description

#### 10.1.2 Macro Definition Documentation

##### 10.1.2.1 DS\_APPMAIN\_PERF\_ID

```
#define DS_APPMAIN_PERF_ID 38
```

Main application performance ID.

Definition at line 32 of file `ds_perfid.h`.

Referenced by `DS_AppMain()`.

## 10.2 CFS Data Storage Message IDs

### Macros

- #define DS\_CMD\_MID 0x18BB  
*DS Ground Commands Message ID.*
- #define DS\_SEND\_HK\_MID 0x18BC  
*DS Send Hk Data Cmd Message ID.*

#### 10.2.1 Detailed Description

#### 10.2.2 Macro Definition Documentation

##### 10.2.2.1 DS\_CMD\_MID

```
#define DS_CMD_MID 0x18BB
```

DS Ground Commands Message ID.

Definition at line 32 of file ds\_msgids.h.

Referenced by DS\_AppInitialize(), DS\_AppProcessCmd(), DS\_AppProcessMsg(), DS\_TableSubscribe(), and DS\_TableUnsubscribe().

##### 10.2.2.2 DS\_SEND\_HK\_MID

```
#define DS_SEND_HK_MID 0x18BC
```

DS Send Hk Data Cmd Message ID.

Definition at line 33 of file ds\_msgids.h.

Referenced by DS\_AppInitialize(), DS\_AppProcessMsg(), DS\_TableSubscribe(), and DS\_TableUnsubscribe().

## 10.3 CFS Data Storage Message IDs

### Macros

- `#define DS_HK_TLM_MID 0x08B8`  
*DS Hk Telemetry Message ID.*
- `#define DS_DIAG_TLM_MID 0x08B9`  
*DS File Info Telemetry Message ID.*
- `#define DS_COMP_TLM_MID 0x08BA`  
*DS Completed File Info Telemetry Message ID.*

### 10.3.1 Detailed Description

### 10.3.2 Macro Definition Documentation

#### 10.3.2.1 DS\_COMP\_TLM\_MID

```
#define DS_COMP_TLM_MID 0x08BA
```

DS Completed File Info Telemetry Message ID.

Definition at line 44 of file ds\_msgids.h.

Referenced by DS\_FileTransmit().

#### 10.3.2.2 DS\_DIAG\_TLM\_MID

```
#define DS_DIAG_TLM_MID 0x08B9
```

DS File Info Telemetry Message ID.

Definition at line 43 of file ds\_msgids.h.

Referenced by DS\_CmdGetFileInfo().

#### 10.3.2.3 DS\_HK\_TLM\_MID

```
#define DS_HK_TLM_MID 0x08B8
```

DS Hk Telemetry Message ID.

Definition at line 42 of file ds\_msgids.h.

Referenced by DS\_AppProcessHK().

## 10.4 CFS Data Storage Platform Configuration

### Macros

- #define DS\_DESTINATION\_TBL\_NAME "FILE\_TBL"  
*Destination File Table – logical table name.*
- #define DS\_DEF\_DEST\_FILENAME "/cf/ds\_file\_tbl.tbl"  
*Destination File Table – default table filename.*
- #define DS\_DEST\_FILE\_CNT 16  
*Destination File Table – number of files.*
- #define DS\_PATHNAME\_BUFSIZE OS\_MAX\_PATH\_LEN  
*Destination File Table – pathname buffer size.*
- #define DS\_BASENAME\_BUFSIZE OS\_MAX\_PATH\_LEN  
*Destination File Table – basename buffer size.*
- #define DS\_EXTENSION\_BUFSIZE 8  
*Destination File Table – extension buffer size.*
- #define DS\_FILTER\_TBL\_NAME "FILTER\_TBL"  
*Packet Filter Table – logical table name.*
- #define DS\_DEF\_FILTER\_FILENAME "/cf/ds\_filter\_tbl.tbl"  
*Packet Filter Table – default table filename.*
- #define DS\_PACKETS\_IN\_FILTER\_TABLE 256  
*Packet Filter Table – number of packets.*
- #define DS\_FILTERS\_PER\_PACKET 4  
*Packet Filter Table – filters per packet.*
- #define DS\_DESCRIPTOR\_BUFSIZE 32  
*Common Table File – descriptor text buffer size.*
- #define DS\_SEQUENCE\_DIGITS 8  
*Filename Sequence Count – number of digits.*
- #define DS\_MAX\_SEQUENCE\_COUNT 99999999  
*Filename Sequence Count – max counter value.*
- #define DS\_TOTAL\_FNAME\_BUFSIZE OS\_MAX\_PATH\_LEN  
*Data Storage File – total filename size.*
- #define DS\_FILE\_HDR\_SUBTYPE 12345  
*Data Storage File – cFE file header sub-type.*
- #define DS\_FILE\_HDR\_DESCRIPTION "DS data storage file"  
*Data Storage File – cFE file header description.*
- #define DS\_FILE\_MIN\_SIZE\_LIMIT 1024  
*Data Storage File – minimum size limit.*
- #define DS\_FILE\_MIN\_AGE\_LIMIT 60  
*Data Storage File – minimum age limit.*
- #define DS\_APP\_PIPE\_NAME "DS\_CMD\_PIPE"  
*Application Pipe Name.*
- #define DS\_APP\_PIPE\_DEPTH 45  
*Application Pipe Depth.*
- #define DS\_MAKE\_TABLES\_CRITICAL 0  
*Make DS Tables Critical.*
- #define DS\_SECS\_PER\_HK\_CYCLE 4

- #define DS\_DEF\_ENABLE\_STATE 1  
*Default DS Packet Processor State.*
- #define DS\_CDS\_ENABLE\_STATE 1  
*Save DS Packet Processor State in Critical Data Store.*
- #define DS\_MISSION\_REV 0  
*Mission specific version number for DS application.*
- #define DS\_FILE\_HEADER\_TYPE 1  
*File Header Type Selection.*
- #define DS\_MOVE\_FILES true  
*Move Files to Downlink Directory After Close Selection.*
- #define DS\_PER\_PACKET\_PIPE\_LIMIT 45  
*Application Per Packet Pipe Limit.*

#### 10.4.1 Detailed Description

#### 10.4.2 Macro Definition Documentation

##### 10.4.2.1 DS\_APP\_PIPE\_DEPTH

```
#define DS_APP_PIPE_DEPTH 45
```

Application Pipe Depth.

##### Description:

This parameter defines the depth of the DS input pipe. The depth should be deep enough to accommodate all of the DS command packets and all of the subscribed telemetry packets that might be generated by applications with a priority higher than the DS application.

##### Limits:

The value must be greater than zero and cannot exceed the definition of [OS\\_QUEUE\\_MAX\\_DEPTH](#)

Definition at line 340 of file ds\_platform\_cfg.h.

Referenced by DS\_AppInitialize().

#### 10.4.2.2 DS\_APP\_PIPE\_NAME

```
#define DS_APP_PIPE_NAME "DS_CMD_PIPE"
```

Application Pipe Name.

##### Description:

This parameter defines a portion of the logical name used during the creation of the DS input pipe. The logical name may also be used as an identifier when accessing status for the pipe via cFE Software Bus Services. The entire logical name is "DS.DS\_CMD\_PIPE".

##### Limits:

The string length (including string terminator) cannot exceed [OS\\_MAX\\_API\\_NAME](#). (limit is not verified)

Definition at line 324 of file ds\_platform\_cfg.h.

Referenced by DS\_AppInitialize().

#### 10.4.2.3 DS\_BASENAME\_BUFSIZE

```
#define DS_BASENAME_BUFSIZE OS_MAX_PATH_LEN
```

Destination File Table – basename buffer size.

##### Description:

This parameter further defines the size of the Destination File Table by setting the size of the basename buffer for each file entry. Note that the buffer must contain both the string and the string terminator - so the max string length is one less than the buffer size.

##### Limits:

The buffer size must be greater than zero and a multiple of four bytes for alignment. The value cannot exceed the maximum filename size allowed by the OS ([OS\\_MAX\\_PATH\\_LEN](#)).

Definition at line 110 of file ds\_platform\_cfg.h.

#### 10.4.2.4 DS\_CDS\_ENABLE\_STATE

```
#define DS_CDS_ENABLE_STATE 1
```

Save DS Packet Processor State in Critical Data Store.

##### Description:

Set this parameter to a value of one and DS will restore the previous Packet Processor enable/disable state after a processor reset. This setting does not affect the Packet Processor enable/disable state set at power-on which is controlled by [DS\\_DEF\\_ENABLE\\_STATE](#). Set the value to zero and DS will set the enable/disable state as described for [DS\\_DEF\\_ENABLE\\_STATE](#) following any reset.

##### Limits

This parameter must be set to zero or one.

Definition at line 399 of file ds\_platform\_cfg.h.

#### 10.4.2.5 DS\_DEF\_DEST\_FILENAME

```
#define DS_DEF_DEST_FILENAME "/cf/ds_file_tbl.tbl"
```

Destination File Table – default table filename.

##### Description:

This parameter defines the default filename for the Destination File Table.

##### Limits:

The string length (including string terminator) cannot exceed [OS\\_MAX\\_PATH\\_LEN](#). (limit is not verified)

Definition at line 59 of file ds\_platform\_cfg.h.

Referenced by DS\_TableInit().

#### 10.4.2.6 DS\_DEF\_ENABLE\_STATE

```
#define DS_DEF_ENABLE_STATE 1
```

Default DS Packet Processor State.

##### Description:

Set this parameter to a value of one and DS will begin to process packets immediately on startup. Set the value to zero and DS will ignore data storage packets until receipt of a valid [DS\\_SET\\_APP\\_STATE\\_CC](#) command to enable.

##### Limits

This parameter must be set to zero or one.

Definition at line 382 of file ds\_platform\_cfg.h.

Referenced by DS\_AppInitialize().

#### 10.4.2.7 DS\_DEF\_FILTER\_FILENAME

```
#define DS_DEF_FILTER_FILENAME "/cf/ds_filter_tbl.tbl"
```

Packet Filter Table – default table filename.

**Description:**

This parameter defines the default filename for the Packet Filter Table.

**Limits:**

The string length (including string terminator) cannot exceed [OS\\_MAX\\_PATH\\_LEN](#). (limit is not verified)

Definition at line 156 of file ds\_platform\_cfg.h.

Referenced by DS\_TableInit().

#### 10.4.2.8 DS\_DESCRIPTOR\_BUFSIZE

```
#define DS_DESCRIPTOR_BUFSIZE 32
```

Common Table File – descriptor text buffer size.

**Description:**

This parameter defines the size of the Descriptor Text fields in both the Destination File Table and the Packet Filter Table. The buffer includes the string terminator.

**Limits:**

The buffer size must be greater than zero and a multiple of four bytes for alignment. There is no upper limit.

Definition at line 204 of file ds\_platform\_cfg.h.

#### 10.4.2.9 DS\_DEST\_FILE\_CNT

```
#define DS_DEST_FILE_CNT 16
```

Destination File Table – number of files.

**Description:**

This parameter defines the size of the DS Destination File Table by setting the number of file entries in the table. The number should be large enough to provide an entry for all the destination files defined for the project. Maintenance will be simplified if file index 'n' always describes the same file - even if that file is not in use at the present time.

**Limits:**

The number must be greater than zero but there is no upper enforced limit for this parameter.

Definition at line 76 of file ds\_platform\_cfg.h.

Referenced by DS\_AppInitialize(), DS\_AppProcessHK(), DS\_CmdCloseAll(), DS\_CmdGetFileInfo(), DS\_FileStorePacket(), DS\_FileTestAge(), DS\_TableCreateCDS(), DS\_TableManageDestFile(), DS\_TableUpdateCDS(), DS\_TableVerifyDestFile(), and DS\_TableVerifyFileIndex().

#### 10.4.2.10 DS\_DESTINATION\_TBL\_NAME

```
#define DS_DESTINATION_TBL_NAME "FILE_TBL"
```

Destination File Table – logical table name.

##### Description:

This parameter defines the name of the DS Destination File Table when referenced via cFE Table Services. Note that this parameter is not a filename, it is the table specific portion of the logical name. The entire logical name for this table is "DS.FILE\_TBL".

##### Limits:

The string length (including string terminator) cannot exceed [CFE\\_MISSION\\_TBL\\_MAX\\_NAME\\_LENGTH](#). (limit is not verified)

Definition at line 46 of file ds\_platform\_cfg.h.

Referenced by DS\_TableInit().

#### 10.4.2.11 DS\_EXTENSION\_BUFSIZE

```
#define DS_EXTENSION_BUFSIZE 8
```

Destination File Table – extension buffer size.

##### Description:

This parameter further defines the size of the Destination File Table by setting the size of the extension buffer for each file entry. Note that the buffer must contain both the string and the string terminator - so the max string length is one less than the buffer size.

##### Limits:

The buffer size must be greater than zero and a multiple of four bytes for alignment. The value cannot exceed the maximum filename size allowed by the OS ([OS\\_MAX\\_PATH\\_LEN](#)).

Definition at line 127 of file ds\_platform\_cfg.h.

#### 10.4.2.12 DS\_FILE\_HDR\_DESCRIPTION

```
#define DS_FILE_HDR_DESCRIPTION "DS data storage file"
```

Data Storage File – cFE file header description.

**Description:**

This parameter defines a mission-specific text string that may be used to identify Data Storage files.

**Limits:**

The string length (including string terminator) cannot exceed [CFE\\_FS\\_HDR\\_DESC\\_MAX\\_LEN](#). (limit is not verified)

Definition at line 276 of file ds\_platform\_cfg.h.

Referenced by DS\_FileWriteHeader().

#### 10.4.2.13 DS\_FILE\_HDR\_SUBTYPE

```
#define DS_FILE_HDR_SUBTYPE 12345
```

Data Storage File – cFE file header sub-type.

**Description:**

This parameter defines a mission-specific value that is used to identify a Data Storage file.

**Limits:**

The file header data type for the value is 32 bits unsigned, thus the value can be anything from zero to 4,294,967,295. (limit is not verified)

Definition at line 263 of file ds\_platform\_cfg.h.

Referenced by DS\_FileWriteHeader().

#### 10.4.2.14 DS\_FILE\_HEADER\_TYPE

```
#define DS_FILE_HEADER_TYPE 1
```

File Header Type Selection.

**Description:**

Set this parameter to select the type of file header that will be the first record written to each Data Storage File.

**Limits**

This parameter must be set to one of the following: 0 = none – set this value to have no file header 1 = CFE – set this value to use CFE file headers

Definition at line 428 of file ds\_platform\_cfg.h.

#### 10.4.2.15 DS\_FILE\_MIN\_AGE\_LIMIT

```
#define DS_FILE_MIN_AGE_LIMIT 60
```

Data Storage File – minimum age limit.

##### Description:

This parameter defines the lower limit for commands and table entries that define the age (in seconds) when a data storage file is automatically closed.

##### Limits:

None – however, the user should be cautioned that a very small value will allow an age limit that closes files too frequently, while a very large value will effectively prevent files from ever being closed due to age.

Definition at line 308 of file ds\_platform\_cfg.h.

Referenced by DS\_TableVerifyAge().

#### 10.4.2.16 DS\_FILE\_MIN\_SIZE\_LIMIT

```
#define DS_FILE_MIN_SIZE_LIMIT 1024
```

Data Storage File – minimum size limit.

##### Description:

This parameter defines the lower limit for commands and table entries that define the size (in bytes) when a data storage file is automatically closed.

##### Limits:

None – however, the user should be cautioned that a very small value will allow an size limit that closes files too frequently, while a very large value will effectively prevent files from ever being closed due to size.

Definition at line 292 of file ds\_platform\_cfg.h.

Referenced by DS\_TableVerifySize().

#### 10.4.2.17 DS\_FILTER\_TBL\_NAME

```
#define DS_FILTER_TBL_NAME "FILTER_TBL"
```

Packet Filter Table – logical table name.

##### Description:

This parameter defines the name of the DS Packet Filter Table when referenced via cFE Table Services. Note that this parameter is not a filename, it is the table specific portion of the logical name. The entire logical name for this table is "DS.FILTER\_TBL".

##### Limits:

The string length (including string terminator) cannot exceed [CFE\\_MISSION\\_TBL\\_MAX\\_NAME\\_LENGTH](#). (limit is not verified)

Definition at line 143 of file ds\_platform\_cfg.h.

Referenced by DS\_AppProcessHK(), and DS\_TableInit().

#### 10.4.2.18 DS\_FILTERS\_PER\_PACKET

```
#define DS_FILTERS_PER_PACKET 4
```

Packet Filter Table – filters per packet.

##### Description:

This parameter further defines the size of the DS Packet Filter Table by setting the number of filters per packet entry. This is the maximum number of destination files to which a single packet can be written (at one time).

##### Limits:

The number of filters per packet must be greater than zero and not greater than [DS\\_DEST\\_FILE\\_CNT](#).

Definition at line 190 of file ds\_platform\_cfg.h.

Referenced by DS\_CmdAddMID(), DS\_CmdSetFilterFile(), DS\_CmdSetFilterParms(), DS\_CmdSetFilterType(), DS\_FileStorePacket(), and DS\_TableVerifyFilterEntry().

#### 10.4.2.19 DS\_MAKE\_TABLES\_CRITICAL

```
#define DS_MAKE_TABLES_CRITICAL 0
```

Make DS Tables Critical.

**Description:**

Set this parameter to a value of one to make the DS tables critical, otherwise set to zero.

**Limits**

This parameter must be set to zero or one.

Definition at line 352 of file ds\_platform\_cfg.h.

#### 10.4.2.20 DS\_MAX\_SEQUENCE\_COUNT

```
#define DS_MAX_SEQUENCE_COUNT 99999999
```

Filename Sequence Count – max counter value.

**Description:**

This parameter defines the maximum value a file sequence count will reach before rollover.

**Limits:**

The value must be greater than zero and should not have more digits than the number of sequence count digits defined for [DS\\_SEQUENCE\\_DIGITS](#), above.

Definition at line 235 of file ds\_platform\_cfg.h.

Referenced by DS\_FileCreateDest(), and DS\_TableVerifyCount().

#### 10.4.2.21 DS\_MISSION\_REV

```
#define DS_MISSION_REV 0
```

Mission specific version number for DS application.

**Description:**

An application version number consists of four parts: major version number, minor version number, revision number and mission specific revision number. The mission specific revision number is defined here and the other parts are defined in "ds\_version.h".

**Limits:**

Must be defined as a numeric value that is greater than or equal to zero.

Definition at line 414 of file ds\_platform\_cfg.h.

Referenced by DS\_AppInitialize(), and DS\_CmdNoop().

#### 10.4.2.22 DS\_MOVE\_FILES

```
#define DS_MOVE_FILES true
```

Move Files to Downlink Directory After Close Selection.

##### Description:

Set this parameter to enable the code and structures to automatically move DS files to another directory after closing the files. The intended use for this setting is to move files from a working directory into a directory from which the files can be downlinked. Note that even after enabling this feature, files will not be moved if the move pathname in the Destination File Table is null.

##### Limits

This parameter must be set to one of the following: true = add move pathname field to Destination File Table false = do not add move pathname to Destination File Table

Definition at line 447 of file ds\_platform\_cfg.h.

#### 10.4.2.23 DS\_PACKETS\_IN\_FILTER\_TABLE

```
#define DS_PACKETS_IN_FILTER_TABLE 256
```

Packet Filter Table – number of packets.

##### Description:

This parameter defines the size of the DS Packet Filter Table by setting the number of packet entries in the table. The number should be large enough to provide an entry for each command and telemetry packet subject to data storage.

##### Limits:

The number must be greater than zero but there is no upper enforced limit for this parameter. However, setting the size equal to the number of packets that might be subject to data storage, rather than the total number of packets defined for this project, will reduce the table file size, possibly significantly.

Definition at line 175 of file ds\_platform\_cfg.h.

Referenced by DS\_TableCreateHash(), DS\_TableSubscribe(), DS\_TableUnsubscribe(), and DS\_TableVerifyFilter().

#### 10.4.2.24 DS\_PATHNAME\_BUFSIZE

```
#define DS_PATHNAME_BUFSIZE OS_MAX_PATH_LEN
```

Destination File Table – pathname buffer size.

##### Description:

This parameter further defines the size of the Destination File Table by setting the size of the pathname buffer for each file entry. Note that the buffer must contain both the string and the string terminator - so the max string length is one less than the buffer size.

##### Limits:

The buffer size must be greater than zero and a multiple of four bytes for alignment. The value cannot exceed the maximum filename size allowed by the OS ([OS\\_MAX\\_PATH\\_LEN](#)).

Definition at line 93 of file `ds_platform_cfg.h`.

#### 10.4.2.25 DS\_PER\_PACKET\_PIPE\_LIMIT

```
#define DS_PER_PACKET_PIPE_LIMIT 45
```

Application Per Packet Pipe Limit.

##### Description:

This parameter defines the per packet pipe limit. This is the max number of packets with the same Message ID that may be in the DS input pipe at any one time. This value should be large enough to accommodate a burst of packets (usually event packets) plus a suitable margin.

##### Limits:

The value must be greater than zero and cannot exceed the definition of [DS\\_APP\\_PIPE\\_DEPTH](#).

Definition at line 463 of file `ds_platform_cfg.h`.

Referenced by `DS_CmdAddMID()`, and `DS_TableSubscribe()`.

#### 10.4.2.26 DS\_SECS\_PER\_HK\_CYCLE

```
#define DS_SECS_PER_HK_CYCLE 4
```

Housekeeping Request Frequency.

##### Description:

Set this parameter equal to the number of seconds between housekeeping request commands. This number is mission specific and must match the frequency used by the source of the command - often the scheduler task. The value is used by the DS application to measure file age and also as a factor in the calculation of file growth rates.

##### Limits

This parameter must be greater than zero.

Definition at line 368 of file ds\_platform\_cfg.h.

Referenced by DS\_AppProcessHK().

#### 10.4.2.27 DS\_SEQUENCE\_DIGITS

```
#define DS_SEQUENCE_DIGITS 8
```

Filename Sequence Count – number of digits.

##### Description:

This parameter defines the number of filename sequence count digits used when the filename type has been set to "count" rather than "time". Sequence counts are padded with leading zero's to create fixed length strings.

##### Limits:

The number of sequence count digits must be greater than zero - even if there is no intention of later setting the filename type to "count". This value should match the definition for [DS\\_MAX\\_SEQUENCE\\_COUNT](#), below.

Definition at line 221 of file ds\_platform\_cfg.h.

Referenced by DS\_FileCreateSequence().

#### 10.4.2.28 DS\_TOTAL\_FNAME\_BUFSIZE

```
#define DS_TOTAL_FNAME_BUFSIZE OS_MAX_PATH_LEN
```

Data Storage File – total filename size.

##### Description:

This parameter defines the maximum size of a filename after combining the pathname, basename, sequence and extension.

##### Limits:

The buffer size must be greater than zero and a multiple of four bytes for alignment. The buffer size (including string terminator) cannot exceed [OS\\_MAX\\_PATH\\_LEN](#).

Definition at line 249 of file ds\_platform\_cfg.h.

Referenced by DS\_FileCloseDest(), and DS\_FileCreateName().

## 10.5 CFS Data Store Event IDs

### Macros

- #define DS\_INIT\_EID 1  
*DS Initialization Event ID.*
- #define DS\_INIT\_ERR\_EID 2  
*DS Initialization Failed Event ID.*
- #define DS\_EXIT\_ERR\_EID 3  
*DS App Termination Event ID.*
- #define DS\_INIT\_CDS\_ERR\_EID 6  
*DS Critical Data Store Initialization Failed Event ID.*
- #define DS\_INIT\_TBL\_CDS\_EID 7  
*DS Critical Data Store Table Restore Event ID.*
- #define DS\_INIT\_TBL\_ERR\_EID 8  
*DS Initialize Table Failed Event ID.*
- #define DS\_FIL\_TBL\_EID 10  
*DS Destination Table Validation Results Event ID.*
- #define DS\_FIL\_TBL\_ERR\_EID 11  
*DS Destination Table Validation Failed Event ID.*
- #define DS\_FLT\_TBL\_EID 12  
*DS Filter Table Validation Results Event ID.*
- #define DS\_FLT\_TBL\_ERR\_EID 13  
*DS Filter Table Validation Failed Event ID.*
- #define DS\_FILE\_NAME\_ERR\_EID 14  
*DS File Name Failed Event ID.*
- #define DS\_CREATE\_FILE\_ERR\_EID 15  
*DS File Create Failed Event ID.*
- #define DS\_WRITE\_FILE\_ERR\_EID 16  
*DS File Write Failed Event ID.*
- #define DS\_CMD\_CODE\_ERR\_EID 21  
*DS Invalid Command Code Event ID.*
- #define DS\_HK\_REQUEST\_ERR\_EID 22  
*DS Housekeeping Request Invalid Length Event ID.*
- #define DS\_NOOP\_CMD\_EID 31  
*DS No-op Command Event ID.*
- #define DS\_NOOP\_CMD\_ERR\_EID 32  
*DS No-op Command Invalid Length Event ID.*
- #define DS\_RESET\_CMD\_EID 33  
*DS Reset Counters Command Event ID.*
- #define DS\_RESET\_CMD\_ERR\_EID 34  
*DS Reset Counters Command Invalid Length Event ID.*
- #define DS\_ENADIS\_CMD\_EID 35  
*DS Application Enable/Disable State Command Event ID.*
- #define DS\_ENADIS\_CMD\_ERR\_EID 36  
*DS Application Enable/Disable State Command Invalid Event ID.*
- #define DS\_FILE\_CMD\_EID 37

- #define DS\_FILE\_CMD\_ERR\_EID 38
  - DS Set Filter File Index Command Event ID.
- #define DS\_FTYPE\_CMD\_EID 39
  - DS Set Filter Type Command Event ID.
- #define DS\_FTYPE\_CMD\_ERR\_EID 40
  - DS Set Filter Type Command Invalid Event ID.
- #define DS\_PARMS\_CMD\_EID 41
  - DS Set Filter Parameters Command Event ID.
- #define DS\_PARMS\_CMD\_ERR\_EID 42
  - DS Set Filter Parameters Command Invalid Event ID.
- #define DS\_NTYPE\_CMD\_EID 43
  - DS Set Filename Type Command Event ID.
- #define DS\_NTYPE\_CMD\_ERR\_EID 44
  - DS Set Filename Type Command Invalid Event ID.
- #define DS\_STATE\_CMD\_EID 45
  - DS Set File Enable/Disable State Command Event ID.
- #define DS\_STATE\_CMD\_ERR\_EID 46
  - DS Set File Enable/Disable State Command Invalid Event ID.
- #define DS\_PATH\_CMD\_EID 47
  - DS Set Filename Path Command Event ID.
- #define DS\_PATH\_CMD\_ERR\_EID 48
  - DS Set Filename Path Command Invalid Event ID.
- #define DS\_BASE\_CMD\_EID 49
  - DS Set File Basename Command Event ID.
- #define DS\_BASE\_CMD\_ERR\_EID 50
  - DS Set File Basename Command Invalid Event ID.
- #define DS\_EXT\_CMD\_EID 51
  - DS Set Filename Extension Command Event ID.
- #define DS\_EXT\_CMD\_ERR\_EID 52
  - DS Set Filename Extension Command Invalid Event ID.
- #define DS\_SIZE\_CMD\_EID 53
  - DS Set Max File Size Command Event ID.
- #define DS\_SIZE\_CMD\_ERR\_EID 54
  - DS Set Max File Size Command Invalid Event ID.
- #define DS\_AGE\_CMD\_EID 55
  - DS Set Max File Age Command Event ID.
- #define DS\_AGE\_CMD\_ERR\_EID 56
  - DS Set Max File Age Command Invalid Event ID.
- #define DS\_SEQ\_CMD\_EID 57
  - DS Set Sequence Count Command Event ID.
- #define DS\_SEQ\_CMD\_ERR\_EID 58
  - DS Set Sequence Count Command Invalid Event ID.
- #define DS\_CLOSE\_CMD\_EID 59
  - DS Close Destination File Command Event ID.
- #define DS\_CLOSE\_CMD\_ERR\_EID 60
  - DS Close Destination File Command Invalid Event ID.

- #define DS\_MOVE\_FILE\_ERR\_EID 61  
*DS File Move Failed Event ID.*
- #define DS\_GET\_FILE\_INFO\_CMD\_EID 62  
*DS Get File Info Command Event ID.*
- #define DS\_GET\_FILE\_INFO\_CMD\_ERR\_EID 63  
*DS Get File Info Command Invalid Event ID.*
- #define DS\_ADD\_MID\_CMD\_EID 64  
*DS Add Message ID to Filter Table Command Event ID.*
- #define DS\_ADD\_MID\_CMD\_ERR\_EID 65  
*DS Add Message ID to Filter Table Command Invalid Event ID.*
- #define DS\_CLOSE\_ALL\_CMD\_EID 66  
*DS Close All Destination Files Command Event ID.*
- #define DS\_CLOSE\_ALL\_CMD\_ERR\_EID 67  
*DS Close All Destination Files Command Invalid Event ID.*
- #define DS\_FILE\_CREATE\_EMPTY\_PATH\_ERR\_EID 68  
*DS File Create Invalid Name Event ID.*
- #define DS\_APPHK\_FILTER\_TBL\_ERR\_EID 69  
*DS Filter Table Name Invalid Event ID.*
- #define DS\_APPHK\_FILTER\_TBL\_PRINT\_ERR\_EID 70  
*DS Filter Table Name Create Failed Event ID.*

#### 10.5.1 Detailed Description

#### 10.5.2 Macro Definition Documentation

##### 10.5.2.1 DS\_ADD\_MID\_CMD\_EID

```
#define DS_ADD_MID_CMD_EID 64
```

DS Add Message ID to Filter Table Command Event ID.

Type: DEBUG

Cause:

This event signals the successful execution of a command to add a new message ID to the Packet Filter Table.

The Packet Filter Table must be loaded and have an unused entry available for adding the new message ID. The new message ID must not be zero and must not already exist in the table.

Definition at line 770 of file ds\_events.h.

Referenced by DS\_CmdAddMID().

### 10.5.2.2 DS\_ADD\_MID\_CMD\_ERR\_EID

```
#define DS_ADD_MID_CMD_ERR_EID 65
```

DS Add Message ID to Filter Table Command Invalid Event ID.

Type: ERROR

Cause:

This event signals the failed execution of a command to add a new message ID to the Packet Filter Table. The cause of the failure may be an invalid command packet length or an invalid message ID.

The failure may also result from not having a Packet Filter Table loaded at the time the command was invoked. The loaded table must have an unused entry available for the new message ID and must not already contain the new message ID.

Definition at line 788 of file ds\_events.h.

Referenced by DS\_CmdAddMID().

### 10.5.2.3 DS\_AGE\_CMD\_EID

```
#define DS_AGE_CMD_EID 55
```

DS Set Max File Age Command Event ID.

Type: DEBUG

Cause:

This event signals the successful execution of a command to set the file age limit for a Destination File Table entry.

Definition at line 638 of file ds\_events.h.

Referenced by DS\_CmdSetDestAge().

#### 10.5.2.4 DS\_AGE\_CMD\_ERR\_EID

```
#define DS_AGE_CMD_ERR_EID 56
```

DS Set Max File Age Command Invalid Event ID.

Type: ERROR

Cause:

This event signals the failed execution of a command to set the file age limit for a Destination File Table entry. The cause of the failure may be an invalid command packet length, an invalid file table index or an invalid file age limit.

The failure may also result from not having a Destination File Table loaded at the time the command was invoked.

Definition at line 655 of file ds\_events.h.

Referenced by DS\_CmdSetDestAge().

#### 10.5.2.5 DS\_APPHK\_FILTER\_TBL\_ERR\_EID

```
#define DS_APPHK_FILTER_TBL_ERR_EID 69
```

DS Filter Table Name Invalid Event ID.

Type: ERROR

Cause:

This event is issued when an invalid filter table name is passed to the CFE\_TBL\_GetInfo.

Definition at line 839 of file ds\_events.h.

Referenced by DS\_AppProcessHK().

#### 10.5.2.6 DS\_APPHK\_FILTER\_TBL\_PRINT\_ERR\_EID

```
#define DS_APPHK_FILTER_TBL_PRINT_ERR_EID 70
```

DS Filter Table Name Create Failed Event ID.

Type: ERROR

Cause:

This event is issued when the filter table name is not successfully created (via snprintf) in the DS\_AppProcessHK function.

Definition at line 851 of file ds\_events.h.

Referenced by DS\_AppProcessHK().

#### 10.5.2.7 DS\_BASE\_CMD\_EID

```
#define DS_BASE_CMD_EID 49
```

DS Set File Basename Command Event ID.

Type: DEBUG

Cause:

This event signals the successful execution of a command to set the basename portion of the filename for a Destination File Table entry.

Definition at line 551 of file ds\_events.h.

Referenced by DS\_CmdSetDestBase().

### 10.5.2.8 DS\_BASE\_CMD\_ERR\_EID

```
#define DS_BASE_CMD_ERR_EID 50
```

DS Set File Basename Command Invalid Event ID.

Type: ERROR

Cause:

This event signals the failed execution of a command to set the base filename text for a Destination File Table entry. The cause of the failure may be an invalid command packet length, an invalid file table index or invalid base filename text.

The failure may also result from not having a Destination File Table loaded at the time the command was invoked.

Definition at line 568 of file ds\_events.h.

Referenced by DS\_CmdSetDestBase().

### 10.5.2.9 DS\_CLOSE\_ALL\_CMD\_EID

```
#define DS_CLOSE_ALL_CMD_EID 66
```

DS Close All Destination Files Command Event ID.

Type: DEBUG

Cause:

This event signals the successful execution of a command to close all open Destination Files.

This command will succeed regardless of whether there was an open file.

Definition at line 802 of file ds\_events.h.

Referenced by DS\_CmdCloseAll().

**10.5.2.10 DS\_CLOSE\_ALL\_CMD\_ERR\_EID**

```
#define DS_CLOSE_ALL_CMD_ERR_EID 67
```

DS Close All Destination Files Command Invalid Event ID.

Type: **ERROR**

Cause:

This event signals the failed execution of a command to close all open Destination Files. The cause of the failure can only be an invalid command packet length.

Definition at line 815 of file ds\_events.h.

Referenced by DS\_CmdCloseAll().

**10.5.2.11 DS\_CLOSE\_CMD\_EID**

```
#define DS_CLOSE_CMD_EID 59
```

DS Close Destination File Command Event ID.

Type: **DEBUG**

Cause:

This event signals the successful execution of a command to close the selected Destination File.

This command will succeed if the file table index is valid, regardless of whether there was an open file.

Definition at line 699 of file ds\_events.h.

Referenced by DS\_CmdCloseFile().

### 10.5.2.12 DS\_CLOSE\_CMD\_ERR\_EID

```
#define DS_CLOSE_CMD_ERR_EID 60
```

DS Close Destination File Command Invalid Event ID.

Type: **ERROR**

Cause:

This event signals the failed execution of a command to close the selected Destination File. The cause of the failure may be an invalid command packet length or an invalid file table index.

Definition at line 712 of file ds\_events.h.

Referenced by DS\_CmdCloseFile().

### 10.5.2.13 DS\_CMD\_CODE\_ERR\_EID

```
#define DS_CMD_CODE_ERR_EID 21
```

DS Invalid Command Code Event ID.

Type: **ERROR**

Cause:

This error occurs when a DS application command is received that has an undefined command code (CC). Ground systems generally prevent these errors so the cause is more likely to result from sending "raw" ground commands or on-board stored commands.

Definition at line 245 of file ds\_events.h.

Referenced by DS\_AppProcessCmd().

**10.5.2.14 DS\_CREATE\_FILE\_ERR\_EID**

```
#define DS_CREATE_FILE_ERR_EID 15
```

DS File Create Failed Event ID.

Type: ERROR

Cause:

This error occurs when an attempt to create a destination file fails. The most common cause of this error is insufficient free space available on the target file system (disk). However, it is possible to specify a filename that is legal but still invalid (i.e. the path string has legal chars but does not exist).

Note that the file create error handler will also disable the destination to prevent the immediate re-occurrence of the error as more packets are written to this destination.

Definition at line 212 of file ds\_events.h.

Referenced by DS\_FileCreateDest().

**10.5.2.15 DS\_ENADIS\_CMD\_EID**

```
#define DS_ENADIS_CMD_EID 35
```

DS Application Enable/Disable State Command Event ID.

Type: DEBUG

Cause:

This event signals the successful execution of a command to set the application enable/disable state for processing data storage packets. The DS application is always enabled to receive and process commands.

Definition at line 321 of file ds\_events.h.

Referenced by DS\_CmdSetAppState().

### 10.5.2.16 DS\_ENADIS\_CMD\_ERR\_EID

```
#define DS_ENADIS_CMD_ERR_EID 36
```

DS Application Enable/Disable State Command Invalid Event ID.

Type: **ERROR**

Cause:

This event signals the failed execution of a command to set the application enable/disable state. The cause of the failure may be an invalid command packet length or an invalid enable/disable state value.

Definition at line 335 of file ds\_events.h.

Referenced by DS\_CmdSetAppState().

### 10.5.2.17 DS\_EXIT\_ERR\_EID

```
#define DS_EXIT_ERR_EID 3
```

DS App Termination Event ID.

Type: **CRITICAL**

Cause:

This event message is issued when the application performs a voluntary termination. The termination may be caused by a cFE command requesting the application be terminated - or, the cause may result from the DS application having received an error when invoking a cFE or O/S function necessary for normal operation.

Definition at line 70 of file ds\_events.h.

Referenced by DS\_AppMain().

**10.5.2.18 DS\_EXT\_CMD\_EID**

```
#define DS_EXT_CMD_EID 51
```

DS Set Filename Extension Command Event ID.

Type: DEBUG

Cause:

This event signals the successful execution of a command to set the extension portion of the filename for a Destination File Table entry.

Definition at line 580 of file ds\_events.h.

Referenced by DS\_CmdSetDestExt().

**10.5.2.19 DS\_EXT\_CMD\_ERR\_EID**

```
#define DS_EXT_CMD_ERR_EID 52
```

DS Set Filename Extension Command Invalid Event ID.

Type: ERROR

Cause:

This event signals the failed execution of a command to set the filename extension text for a Destination File Table entry. The cause of the failure may be an invalid command packet length, an invalid file table index or invalid filename extension text.

The failure may also result from not having a Destination File Table loaded at the time the command was invoked.

Definition at line 597 of file ds\_events.h.

Referenced by DS\_CmdSetDestExt().

### 10.5.2.20 DS\_FIL\_TBL\_EID

```
#define DS_FIL_TBL_EID 10
```

DS Destination Table Validation Results Event ID.

Type: INFORMATION

Cause:

This event describes the results of the Destination File Table validation function. The cFE Table Services Manager will call this function autonomously when the default table is loaded at startup and also whenever a table validate command (that targets this table) is processed.

Definition at line 130 of file ds\_events.h.

Referenced by DS\_TableVerifyDestFile().

### 10.5.2.21 DS\_FIL\_TBL\_ERR\_EID

```
#define DS_FIL_TBL_ERR_EID 11
```

DS Destination Table Validation Failed Event ID.

Type: ERROR

Cause:

These are the errors that the DS application might encounter when verifying the contents of a Destination File Table. Note that only the first error detected for each table file will result in an event being generated. The remaining entries are still tested to establish the result counters but no further error events will be generated during this call to the verify function.

Definition at line 145 of file ds\_events.h.

Referenced by DS\_TableVerifyDestFileEntry().

**10.5.2.22 DS\_FILE\_CMD\_EID**

```
#define DS_FILE_CMD_EID 37
```

DS Set Filter File Index Command Event ID.

Type: DEBUG

Cause:

The Packet Filter Table consists of an array of packet structures, with each element in the array representing one packet message ID.

Each packet structure contains an array of filter structures, and each filter structure contains a destination file selection. Thus, each packet has multiple filters and each filter selects a file.

File selections are expressed as an index into the Destination File Table.

This event signals the successful execution of a command to set the destination file index for a single filter entry in the Packet Filter Table.

Definition at line 358 of file ds\_events.h.

Referenced by DS\_CmdSetFilterFile().

**10.5.2.23 DS\_FILE\_CMD\_ERR\_EID**

```
#define DS_FILE_CMD_ERR_EID 38
```

DS Set Filter File Index Command Invalid Event ID.

Type: ERROR

Cause:

This event signals the failed execution of a command to set the Destination File Table index for a Packet Filter Table entry. The cause of the failure may be an invalid command packet length, an invalid Message ID or an invalid filter parameters index.

The failure may also result from not having a Packet Filter Table loaded at the time the command was invoked or because the message ID was not found in the Packet Filter Table.

Definition at line 376 of file ds\_events.h.

Referenced by DS\_CmdSetFilterFile().

#### 10.5.2.24 DS\_FILE\_CREATE\_EMPTY\_PATH\_ERR\_EID

```
#define DS_FILE_CREATE_EMPTY_PATH_ERR_EID 68
```

DS File Create Invalid Name Event ID.

Type: ERROR

Cause:

This event is generated when DS\_FileCreateName is invoked with an empty path name.

Definition at line 827 of file ds\_events.h.

Referenced by DS\_FileCreateName().

#### 10.5.2.25 DS\_FILE\_NAME\_ERR\_EID

```
#define DS_FILE_NAME_ERR_EID 14
```

DS File Name Failed Event ID.

Type: ERROR

Cause:

This error occurs when an attempt to create a destination filename fails. The expected cause of this error is for the sum of the lengths of each filename element to be invalid, even though each individual element length is valid. Note that each of the individual element strings has been previously verified.

Note that the filename create error handler will also disable the destination to prevent the immediate re-occurrence of the error as more packets are written to this destination.

Definition at line 193 of file ds\_events.h.

Referenced by DS\_FileCreateName().

**10.5.2.26 DS\_FLT\_TBL\_EID**

```
#define DS_FLT_TBL_EID 12
```

DS Filter Table Validation Results Event ID.

Type: INFORMATION

Cause:

This event describes the results of the Packet Filter Table validation function. The cFE Table Services Manager will call this function autonomously when the default table is loaded at startup and also whenever a table validate command (that targets this table) is processed.

Definition at line 159 of file ds\_events.h.

Referenced by DS\_TableVerifyFilter().

**10.5.2.27 DS\_FLT\_TBL\_ERR\_EID**

```
#define DS_FLT_TBL_ERR_EID 13
```

DS Filter Table Validation Failed Event ID.

Type: ERROR

Cause:

These are the errors that the DS application might encounter when verifying the contents of a Packet Filter Table. Note that only the first error detected for each table file will result in an event being generated. The remaining entries are still tested to establish the result counters but no further error events will be generated during this call to the verify function.

Definition at line 174 of file ds\_events.h.

Referenced by DS\_TableVerifyFilterEntry().

### 10.5.2.28 DS\_FTYPE\_CMD\_EID

```
#define DS_FTYPE_CMD_EID 39
```

DS Set Filter Type Command Event ID.

Type: DEBUG

Cause:

The Packet Filter Table consists of an array of packet structures, with each element in the array representing one packet message ID.

Each packet structure contains an array of filter structures, and each filter structure contains a filter type selection. Thus, each packet has multiple filters and each filter selects a filter type.

This event signals the successful execution of a command to set the filter type for a single filter entry in the Packet Filter Table.

Definition at line 395 of file ds\_events.h.

Referenced by DS\_CmdSetFilterType().

### 10.5.2.29 DS\_FTYPE\_CMD\_ERR\_EID

```
#define DS_FTYPE_CMD_ERR_EID 40
```

DS Set Filter Type Command Invalid Event ID.

Type: ERROR

Cause:

This event signals the failed execution of a command to set the filter type for a Packet Filter Table entry. The cause of the failure may be an invalid command packet length, an invalid message ID, an invalid Filter Parameters index or an invalid filter type.

The failure may also result from not having a Packet Filter Table loaded at the time the command was invoked or because the Message ID was not found in the Packet Filter Table.

Definition at line 413 of file ds\_events.h.

Referenced by DS\_CmdSetFilterType().

**10.5.2.30 DS\_GET\_FILE\_INFO\_CMD\_EID**

```
#define DS_GET_FILE_INFO_CMD_EID 62
```

DS Get File Info Command Event ID.

Type: DEBUG

Cause:

This event signals the successful execution of a command to get the file info diagnostic packet.

This command will succeed even if the selected file does not exist.

Definition at line 741 of file ds\_events.h.

Referenced by DS\_CmdGetFileInfo().

**10.5.2.31 DS\_GET\_FILE\_INFO\_CMD\_ERR\_EID**

```
#define DS_GET_FILE_INFO_CMD_ERR_EID 63
```

DS Get File Info Command Invalid Event ID.

Type: ERROR

Cause:

This event signals the failed execution of a command to get the file info diagnostic packet. The cause of the failure is an invalid command packet length.

Definition at line 754 of file ds\_events.h.

Referenced by DS\_CmdGetFileInfo().

### 10.5.2.32 DS\_HK\_REQUEST\_ERR\_EID

```
#define DS_HK_REQUEST_ERR_EID 22
```

DS Housekeeping Request Invalid Length Event ID.

Type: ERROR

Cause:

This event signals the failed execution of a HK request command. The cause of the failure is an invalid command packet length.

Definition at line 257 of file ds\_events.h.

Referenced by DS\_AppProcessMsg().

### 10.5.2.33 DS\_INIT\_CDS\_ERR\_EID

```
#define DS_INIT_CDS_ERR_EID 6
```

DS Critical Data Store Initialization Failed Event ID.

Type: ERROR

Cause:

The DS application stores the current values for Destination Filename sequence counts in the Critical Data Store (CDS). This ensures that DS will not overwrite old data storage files following a processor reset. This event indicates an error at startup as DS is initializing access to the Critical Data Store. Subsequent CDS errors are ignored by DS.

Definition at line 85 of file ds\_events.h.

Referenced by DS\_TableCreateCDS(), and DS\_TableUpdateCDS().

#### 10.5.2.34 DS\_INIT\_EID

```
#define DS_INIT_EID 1
```

DS Initialization Event ID.

Type: INFORMATION

Cause:

This event message is issued if the Data Storage (DS) application successfully completes its initialization.

Definition at line 42 of file ds\_events.h.

Referenced by DS\_AppInitialize().

#### 10.5.2.35 DS\_INIT\_ERR\_EID

```
#define DS_INIT_ERR_EID 2
```

DS Initialization Failed Event ID.

Type: ERROR

Cause:

This event message is issued when the application receives an error while performing cFE initialization. The value displayed is the return code from the function that failed.

Definition at line 55 of file ds\_events.h.

Referenced by DS\_AppInitialize().

### 10.5.2.36 DS\_INIT\_TBL\_CDS\_EID

```
#define DS_INIT_TBL_CDS_EID 7
```

DS Critical Data Store Table Restore Event ID.

Type: DEBUG

Cause:

If configured to make DS tables critical, the DS application will try and recover the table data in use prior to a processor reset. These startup initialization events indicate that the table data has been restored from the Critical Data Store (CDS).

Definition at line 99 of file ds\_events.h.

Referenced by DS\_TableInit().

### 10.5.2.37 DS\_INIT\_TBL\_ERR\_EID

```
#define DS_INIT_TBL_ERR_EID 8
```

DS Initialize Table Failed Event ID.

Type: ERROR

Cause:

At startup, the DS application must create both a packet filter table and a destination file definition table. After creating the tables, DS must then load default table data for each of the files. If DS is unable to create either table then the application will terminate. If DS is able to create both tables and is then unable to load both tables then DS will operate in a reduced function mode - thus allowing table load error recovery via the cFE Table Services command interface.

Definition at line 116 of file ds\_events.h.

Referenced by DS\_TableInit().

**10.5.2.38 DS\_MOVE\_FILE\_ERR\_EID**

```
#define DS_MOVE_FILE_ERR_EID 61
```

DS File Move Failed Event ID.

Type: **ERROR**

Cause:

This event signals the failed attempt to move a Data Storage file from the temporary working directory it was created in, to the directory specified in the file definition table. The cause of the failure may be an invalid combined directory and filename length or the system file move function may have returned an error result.

Definition at line 727 of file ds\_events.h.

Referenced by DS\_FileCloseDest().

**10.5.2.39 DS\_NOOP\_CMD\_EID**

```
#define DS_NOOP_CMD_EID 31
```

DS No-op Command Event ID.

Type: **INFORMATION**

Cause:

This event signals the successful execution of an application NOOP command. The command is used primarily as an indicator that the DS application can receive commands and generate telemetry.

Definition at line 270 of file ds\_events.h.

Referenced by DS\_CmdNoop().

#### 10.5.2.40 DS\_NOOP\_CMD\_ERR\_EID

```
#define DS_NOOP_CMD_ERR_EID 32
```

DS No-op Command Invalid Length Event ID.

Type: **ERROR**

Cause:

This event signals the failed execution of a NOOP command. The cause of the failure is an invalid command packet length.

Definition at line 282 of file ds\_events.h.

Referenced by DS\_CmdNoop().

#### 10.5.2.41 DS\_NTYPE\_CMD\_EID

```
#define DS_NTYPE_CMD_EID 43
```

DS Set Filename Type Command Event ID.

Type: **DEBUG**

Cause:

This event signals the successful execution of a command to set the filename type for a Destination File Table entry.

Definition at line 464 of file ds\_events.h.

Referenced by DS\_CmdSetDestType().

**10.5.2.42 DS\_NTYPE\_CMD\_ERR\_EID**

```
#define DS_NTYPE_CMD_ERR_EID 44
```

DS Set Filename Type Command Invalid Event ID.

Type: **ERROR**

Cause:

This event signals the failed execution of a command to set the filename type for the selected Destination File Table entry. The cause of the failure may be an invalid command packet length, an invalid file table index or an invalid filename type.

The failure may also result from not having a Destination File Table loaded at the time the command was invoked.

Definition at line 481 of file ds\_events.h.

Referenced by DS\_CmdSetDestType().

**10.5.2.43 DS\_PARMS\_CMD\_EID**

```
#define DS_PARMS_CMD_EID 41
```

DS Set Filter Parameters Command Event ID.

Type: **DEBUG**

Cause:

The Packet Filter Table consists of an array of packet structures, with each element in the array representing one packet message ID.

Each packet structure contains an array of filter structures, and each filter structure contains a set of filter parameters. Thus, each packet has multiple filters and each filter has unique filter parameters.

This event signals the successful execution of a command to set the filter parameters for a single filter entry in the Packet Filter Table.

Definition at line 433 of file ds\_events.h.

Referenced by DS\_CmdSetFilterParms().

#### 10.5.2.44 DS\_PARMS\_CMD\_ERR\_EID

```
#define DS_PARMS_CMD_ERR_EID 42
```

DS Set Filter Parameters Command Invalid Event ID.

Type: ERROR

Cause:

This event signals the failed execution of a command to set the filter parameters for a Packet Filter Table entry. The cause of the failure may be an invalid command packet length, an invalid message ID, an invalid filter parameters index or an invalid filter parameters value (N,X,O).

The failure may also result from not having a Packet Filter Table loaded at the time the command was invoked or because the Message ID was not found in the Packet Filter Table.

Definition at line 452 of file ds\_events.h.

Referenced by DS\_CmdSetFilterParms().

#### 10.5.2.45 DS\_PATH\_CMD\_EID

```
#define DS_PATH_CMD_EID 47
```

DS Set Filename Path Command Event ID.

Type: DEBUG

Cause:

This event signals the successful execution of a command to set the path portion of the filename for a Destination File Table entry.

Definition at line 522 of file ds\_events.h.

Referenced by DS\_CmdSetDestPath().

**10.5.2.46 DS\_PATH\_CMD\_ERR\_EID**

```
#define DS_PATH_CMD_ERR_EID 48
```

DS Set Filename Path Command Invalid Event ID.

Type: **ERROR**

Cause:

This event signals the failed execution of a command to set the filename path text for a Destination File Table entry. The cause of the failure may be an invalid command packet length, an invalid file table index or invalid filename path text.

The failure may also result from not having a Destination File Table loaded at the time the command was invoked.

Definition at line 539 of file ds\_events.h.

Referenced by DS\_CmdSetDestPath().

**10.5.2.47 DS\_RESET\_CMD\_EID**

```
#define DS_RESET_CMD_EID 33
```

DS Reset Counters Command Event ID.

Type: **DEBUG**

Cause:

This event signals the successful execution of a RESET housekeeping counters command. The command is used primarily to clear counters that have already been examined.

Definition at line 295 of file ds\_events.h.

Referenced by DS\_CmdReset().

#### 10.5.2.48 DS\_RESET\_CMD\_ERR\_EID

```
#define DS_RESET_CMD_ERR_EID 34
```

DS Reset Counters Command Invalid Length Event ID.

Type: **ERROR**

Cause:

This event signals the failed execution of a RESET command. The cause of the failure is an invalid command packet length.

Definition at line 307 of file ds\_events.h.

Referenced by DS\_CmdReset().

#### 10.5.2.49 DS\_SEQ\_CMD\_EID

```
#define DS_SEQ_CMD_EID 57
```

DS Set Sequence Count Command Event ID.

Type: **DEBUG**

Cause:

This event signals the successful execution of a command to set the sequence count for a Destination File Table entry.

Definition at line 667 of file ds\_events.h.

Referenced by DS\_CmdSetDestCount().

**10.5.2.50 DS\_SEQ\_CMD\_ERR\_EID**

```
#define DS_SEQ_CMD_ERR_EID 58
```

DS Set Sequence Count Command Invalid Event ID.

Type: **ERROR**

Cause:

This event signals the failed execution of a command to set the sequence count for a Destination File Table entry. The cause of the failure may be an invalid command packet length, an invalid file table index or an invalid sequence count.

The failure may also result from not having a Destination File Table loaded at the time the command was invoked.

Definition at line 684 of file ds\_events.h.

Referenced by DS\_CmdSetDestCount().

**10.5.2.51 DS\_SIZE\_CMD\_EID**

```
#define DS_SIZE_CMD_EID 53
```

DS Set Max File Size Command Event ID.

Type: **DEBUG**

Cause:

This event signals the successful execution of a command to set the file size limit for a Destination File Table entry.

Definition at line 609 of file ds\_events.h.

Referenced by DS\_CmdSetDestSize().

### 10.5.2.52 DS\_SIZE\_CMD\_ERR\_EID

```
#define DS_SIZE_CMD_ERR_EID 54
```

DS Set Max File Size Command Invalid Event ID.

Type: **ERROR**

Cause:

This event signals the failed execution of a command to set the file size limit for a Destination File Table entry. The cause of the failure may be an invalid command packet length, an invalid file table index or an invalid file size limit.

The failure may also result from not having a Destination File Table loaded at the time the command was invoked.

Definition at line 626 of file ds\_events.h.

Referenced by DS\_CmdSetDestSize().

### 10.5.2.53 DS\_STATE\_CMD\_EID

```
#define DS_STATE_CMD_EID 45
```

DS Set File Enable/Disable State Command Event ID.

Type: **DEBUG**

Cause:

This event signals the successful execution of a command to set the enable/disable state for a Destination File Table entry.

Definition at line 493 of file ds\_events.h.

Referenced by DS\_CmdSetDestState().

**10.5.2.54 DS\_STATE\_CMD\_ERR\_EID**

```
#define DS_STATE_CMD_ERR_EID 46
```

DS Set File Enable/Disable State Command Invalid Event ID.

**Type:** ERROR

**Cause:**

This event signals the failed execution of a command to set the enable/disable state for the selected Destination File Table entry. The cause of the failure may be an invalid command packet length, an invalid file table index or an invalid state selection.

The failure may also result from not having a Destination File Table loaded at the time the command was invoked.

Definition at line 510 of file ds\_events.h.

Referenced by DS\_CmdSetDestState().

**10.5.2.55 DS\_WRITE\_FILE\_ERR\_EID**

```
#define DS_WRITE_FILE_ERR_EID 16
```

DS File Write Failed Event ID.

**Type:** ERROR

**Cause:**

This error occurs when an attempt to write to a destination file fails. The most common cause of this error is insufficient free space available on the target file system (disk). Other causes for this error imply some sort of operational or file system failure and will require careful analysis.

Note that the file write error handler will also close the file and disable the destination to prevent the immediate re-occurrence of the error as more packets are written to this destination.

Definition at line 231 of file ds\_events.h.

Referenced by DS\_FileWriteError().

## 10.6 CFS Data Storage Command Structures

### Data Structures

- struct **DS\_NoopCmd\_t**  
*No-Operation Command.*
- struct **DS\_ResetCmd\_t**  
*Reset Housekeeping Telemetry Command.*
- struct **DS\_AppStateCmd\_t**  
*Set Ena/Dis State For DS Application.*
- struct **DS\_FilterFileCmd\_t**  
*Set File Selection For Packet Filter Table Entry.*
- struct **DS\_FilterTypeCmd\_t**  
*Set Filter Type For Packet Filter Table Entry.*
- struct **DS\_FilterParmsCmd\_t**  
*Set Filter Parameters For Packet Filter Table Entry.*
- struct **DS\_DestTypeCmd\_t**  
*Set Filename Type For Destination File Table Entry.*
- struct **DS\_DestStateCmd\_t**  
*Set Ena/Dis State For Destination File Table Entry.*
- struct **DS\_DestPathCmd\_t**  
*Set Path Portion Of Filename For Destination File Table Entry.*
- struct **DS\_DestBaseCmd\_t**  
*Set Base Portion Of Filename For Destination File Table Entry.*
- struct **DS\_DestExtCmd\_t**  
*Set Extension Portion Of Filename For Destination File Table Entry.*
- struct **DS\_DestSizeCmd\_t**  
*Set Max File Size For Destination File Table Entry.*
- struct **DS\_DestAgeCmd\_t**  
*Set Max File Age For Destination File Table Entry.*
- struct **DS\_DestCountCmd\_t**  
*Set Sequence Portion Of Filename For Destination File Table Entry.*
- struct **DS\_CloseFileCmd\_t**  
*Close Destination File.*
- struct **DS\_CloseAllCmd\_t**  
*Close All Destination Files.*
- struct **DS\_GetFileInfoCmd\_t**  
*Get File Info Command.*
- struct **DS\_AddMidCmd\_t**  
*Add Message ID To Packet Filter Table.*

### 10.6.1 Detailed Description

## 10.7 CFS Data Storage Telemetry

### Data Structures

- struct [DS\\_HkPacket\\_t](#)  
*Application housekeeping packet.*
- struct [DS\\_FileInfo\\_t](#)  
*Current state of destination files.*
- struct [DS\\_FileInfoPkt\\_t](#)  
*Application file info packet.*
- struct [DS\\_FileCompletePkt\\_t](#)  
*Single application file info packet.*
- union [DS\\_FileCompletePktBuf\\_t](#)  
*Single application file info packet buffer.*

#### 10.7.1 Detailed Description

## 10.8 CFS Data Storage Command Codes

### Macros

- #define DS\_NOOP\_CC 0  
*No-Operation Command.*
- #define DS\_RESET\_CC 1  
*Reset Housekeeping Telemetry Counters Command.*
- #define DS\_SET\_APP\_STATE\_CC 2  
*Set Enable/Disable State For DS Application.*
- #define DS\_SET\_FILTER\_FILE\_CC 3  
*Set Destination File For Packet Filter Table Entry.*
- #define DS\_SET\_FILTER\_TYPE\_CC 4  
*Set Filter Type For Packet Filter Table Entry.*
- #define DS\_SET\_FILTER\_PARMS\_CC 5  
*Set Algorithm Parameters For Packet Filter Table Entry.*
- #define DS\_SET\_DEST\_TYPE\_CC 6  
*Set Filename Type For Destination File Table Entry.*
- #define DS\_SET\_DEST\_STATE\_CC 7  
*Set Ena/Dis State For Destination File Table Entry.*
- #define DS\_SET\_DEST\_PATH\_CC 8  
*Set Pathname For Destination File Table Entry.*
- #define DS\_SET\_DEST\_BASE\_CC 9  
*Set Basename For Destination File Table Entry.*
- #define DS\_SET\_DEST\_EXT\_CC 10  
*Set Extension For Destination File Table Entry.*
- #define DS\_SET\_DEST\_SIZE\_CC 11  
*Set Max File Size For Destination File Table Entry.*
- #define DS\_SET\_DEST\_AGE\_CC 12  
*Set Max File Age For Destination File Table Entry.*
- #define DS\_SET\_DEST\_COUNT\_CC 13  
*Set Sequence Count For Destination File Table Entry.*
- #define DS\_CLOSE\_FILE\_CC 14  
*Close Destination File.*
- #define DS\_GET\_FILE\_INFO\_CC 15  
*Get File Info Packet.*
- #define DS\_ADD\_MID\_CC 16  
*Add Message ID To Packet Filter Table.*
- #define DS\_CLOSE\_ALL\_CC 17  
*Close All Destination Files.*

### 10.8.1 Detailed Description

### 10.8.2 Macro Definition Documentation

### 10.8.2.1 DS\_ADD\_MID\_CC

```
#define DS_ADD_MID_CC 16
```

Add Message ID To Packet Filter Table.

#### Description

This command will change the Message ID selection for an unused Packet Filter Table entry to the indicated value.

#### Command Structure

`DS_AddMidCmd_t`

#### Command Verification

Evidence of success may be found in the following telemetry:

- `DS_HkPacket_t.CmdAcceptedCounter` will increment
- The `DS_ADD_MID_CMD_EID` debug event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length
- Message ID is invalid (can be anything but zero)
- Packet filter table is not currently loaded
- Message ID already exists in packet filter table
- All packet filter table entries are already in use

Evidence of failure may be found in the following telemetry:

- `DS_HkPacket_t.CmdRejectedCounter` will increment
- The `DS_ADD_MID_CMD_ERR_EID` error event message will be sent

#### Criticality

None

Definition at line 550 of file `ds_msgdefs.h`.

Referenced by `DS_AppProcessCmd()`.

### 10.8.2.2 DS\_CLOSE\_ALL\_CC

```
#define DS_CLOSE_ALL_CC 17
```

Close All Destination Files.

#### Description

This command will close all open Destination Files.

- NOTE: Using this command may incur a performance hit based upon the number and size of the files being closed.

#### Command Structure

[DS\\_CloseAllCmd\\_t](#)

#### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will increment
- The [DS\\_CLOSE\\_ALL\\_CMD\\_EID](#) debug event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length
- Destination file table is not currently loaded

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_CLOSE\\_ALL\\_CMD\\_ERR\\_EID](#) error event message will be sent

#### Criticality

None

Definition at line 580 of file `ds_msgdefs.h`.

Referenced by `DS_AppProcessCmd()`.

### 10.8.2.3 DS\_CLOSE\_FILE\_CC

```
#define DS_CLOSE_FILE_CC 14
```

Close Destination File.

#### Description

This command will close the indicated Destination File.

#### Command Structure

[DS\\_CloseFileCmd\\_t](#)

#### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will increment
- The [DS\\_CLOSE\\_CMD\\_EID](#) debug event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length
- Invalid destination file table index
- Destination file table is not currently loaded

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_CLOSE\\_CMD\\_ERR\\_EID](#) error event message will be sent

#### Criticality

None

Definition at line 491 of file `ds_msgdefs.h`.

Referenced by `DS_AppProcessCmd()`.

#### 10.8.2.4 DS\_GET\_FILE\_INFO\_CC

```
#define DS_GET_FILE_INFO_CC 15
```

Get File Info Packet.

##### Description

This command will send the DS File Info Packet.

##### Command Structure

[DS\\_GetFileInfoCmd\\_t](#)

##### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will increment
- The [DS\\_FileInfoPkt\\_t](#) packet will be sent

##### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_GET\\_FILE\\_INFO\\_CMD\\_ERR\\_EID](#) error event message will be sent

##### Criticality

None

Definition at line 518 of file `ds_msgdefs.h`.

Referenced by `DS_AppProcessCmd()`.

### 10.8.2.5 DS\_NOOP\_CC

```
#define DS_NOOP_CC 0
```

No-Operation Command.

#### Description

This command will increment the command execution counter and send an event containing the version number of the application. The command is often used as a general test for application "aliveness".

#### Command Structure

[DS\\_NoopCmd\\_t](#)

#### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will increment
- The [DS\\_NOOP\\_CMD\\_EID](#) informational event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_NOOP\\_CMD\\_ERR\\_EID](#) error event message will be sent

#### Criticality

None

Definition at line 59 of file `ds_msgdefs.h`.

Referenced by `DS_AppProcessCmd()`.

### 10.8.2.6 DS\_RESET\_CC

```
#define DS_RESET_CC 1
```

Reset Housekeeping Telemetry Counters Command.

#### Description

This command will set the housekeeping counters to zero

#### Command Structure

[DS\\_ResetCmd\\_t](#)

#### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will reset to zero
- The [DS\\_RESET\\_CMD\\_EID](#) debug event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_RESET\\_CMD\\_ERR\\_EID](#) error event message will be sent

#### Criticality

None

Definition at line 86 of file [ds\\_msgdefs.h](#).

Referenced by [DS\\_AppProcessCmd\(\)](#).

### 10.8.2.7 DS\_SET\_APP\_STATE\_CC

```
#define DS_SET_APP_STATE_CC 2
```

Set Enable/Disable State For DS Application.

#### Description

This command will modify the Ena/Dis State selection for the DS application. No packets are stored while DS is disabled.

#### Command Structure

[DS\\_AppStateCmd\\_t](#)

#### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will increment
- The [DS\\_ENADIS\\_CMD\\_EID](#) debug event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length
- Invalid enable/disable state selection

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_ENADIS\\_CMD\\_ERR\\_EID](#) error event message will be sent

#### Criticality

None

Definition at line 115 of file `ds_msgdefs.h`.

Referenced by `DS_AppProcessCmd()`.

### 10.8.2.8 DS\_SET\_DEST\_AGE\_CC

```
#define DS_SET_DEST_AGE_CC 12
```

Set Max File Age For Destination File Table Entry.

#### Description

This command will modify the max file age selection for the indicated entry in the Destination File Table.

#### Command Structure

[DS\\_DestAgeCmd\\_t](#)

#### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will increment
- The [DS\\_AGE\\_CMD\\_EID](#) debug event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length
- Invalid destination file table index
- Invalid max file age selection
- Destination file table is not currently loaded

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_AGE\\_CMD\\_ERR\\_EID](#) error event message will be sent

#### Criticality

None

Definition at line 431 of file `ds_msgdefs.h`.

Referenced by `DS_AppProcessCmd()`.

### 10.8.2.9 DS\_SET\_DEST\_BASE\_CC

```
#define DS_SET_DEST_BASE_CC 9
```

Set Basename For Destination File Table Entry.

#### Description

This command will modify the Basename portion of the filename for the indicated entry in the Destination File Table.

#### Command Structure

[DS\\_DestBaseCmd\\_t](#)

#### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will increment
- The [DS\\_BASE\\_CMD\\_EID](#) debug event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length
- Invalid destination file table index
- Invalid basename string (no terminator, bad characters)
- Destination file table is not currently loaded

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_BASE\\_CMD\\_ERR\\_EID](#) error event message will be sent

#### Criticality

None

Definition at line 338 of file ds\_msgdefs.h.

Referenced by [DS\\_AppProcessCmd\(\)](#).

### 10.8.2.10 DS\_SET\_DEST\_COUNT\_CC

```
#define DS_SET_DEST_COUNT_CC 13
```

Set Sequence Count For Destination File Table Entry.

#### Description

This command will modify the sequence count value for the indicated entry in the Destination File Table.

#### Command Structure

[DS\\_DestCountCmd\\_t](#)

#### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will increment
- The [DS\\_SEQ\\_CMD\\_EID](#) debug event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length
- Invalid destination file table index
- Invalid sequence count value
- Destination file table is not currently loaded

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_SEQ\\_CMD\\_ERR\\_EID](#) error event message will be sent

#### Criticality

None

Definition at line 462 of file ds\_msgdefs.h.

Referenced by [DS\\_AppProcessCmd\(\)](#).

### 10.8.2.11 DS\_SET\_DEST\_EXT\_CC

```
#define DS_SET_DEST_EXT_CC 10
```

Set Extension For Destination File Table Entry.

#### Description

This command will modify the Extension portion of the filename for the indicated entry in the Destination File Table.

#### Command Structure

[DS\\_DestExtCmd\\_t](#)

#### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will increment
- The [DS\\_EXT\\_CMD\\_EID](#) debug event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length
- Invalid destination file table index
- Invalid extension string (empty, no terminator, bad characters)
- Destination file table is not currently loaded

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_EXT\\_CMD\\_ERR\\_EID](#) error event message will be sent

#### Criticality

None

Definition at line 369 of file `ds_msgdefs.h`.

Referenced by `DS_AppProcessCmd()`.

### 10.8.2.12 DS\_SET\_DEST\_PATH\_CC

```
#define DS_SET_DEST_PATH_CC 8
```

Set Pathname For Destination File Table Entry.

#### Description

This command will modify the Pathname portion of the filename for the indicated entry in the Destination File Table.

#### Command Structure

[DS\\_DestPathCmd\\_t](#)

#### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will increment
- The [DS\\_PATH\\_CMD\\_EID](#) debug event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length
- Invalid destination file table index
- Invalid pathname string (empty, no terminator, bad characters)
- Destination file table is not currently loaded

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_PATH\\_CMD\\_ERR\\_EID](#) error event message will be sent

#### Criticality

None

Definition at line 307 of file `ds_msgdefs.h`.

Referenced by `DS_AppProcessCmd()`.

### 10.8.2.13 DS\_SET\_DEST\_SIZE\_CC

```
#define DS_SET_DEST_SIZE_CC 11
```

Set Max File Size For Destination File Table Entry.

#### Description

This command will modify the max file size selection for the indicated entry in the Destination File Table.

#### Command Structure

[DS\\_DestSizeCmd\\_t](#)

#### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will increment
- The [DS\\_SIZE\\_CMD\\_EID](#) debug event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length
- Invalid destination file table index
- Invalid max file size selection
- Destination file table is not currently loaded

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_SIZE\\_CMD\\_ERR\\_EID](#) error event message will be sent

#### Criticality

None

Definition at line 400 of file `ds_msgdefs.h`.

Referenced by `DS_AppProcessCmd()`.

### 10.8.2.14 DS\_SET\_DEST\_STATE\_CC

```
#define DS_SET_DEST_STATE_CC 7
```

Set Ena/Dis State For Destination File Table Entry.

#### Description

This command will modify the Ena/Dis State selection for the indicated entry in the Destination File Table.

#### Command Structure

[DS\\_DestStateCmd\\_t](#)

#### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will increment
- The [DS\\_STATE\\_CMD\\_EID](#) debug event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length
- Invalid destination file table index
- Invalid destination state selection
- Destination file table is not currently loaded

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_STATE\\_CMD\\_ERR\\_EID](#) error event message will be sent

#### Criticality

None

Definition at line 276 of file `ds_msgdefs.h`.

Referenced by `DS_AppProcessCmd()`.

### 10.8.2.15 DS\_SET\_DEST\_TYPE\_CC

```
#define DS_SET_DEST_TYPE_CC 6
```

Set Filename Type For Destination File Table Entry.

#### Description

This command will modify the Filename Type selection for the indicated entry in the Destination File Table.

#### Command Structure

[DS\\_DestTypeCmd\\_t](#)

#### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will increment
- The [DS\\_NTYPE\\_CMD\\_EID](#) debug event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length
- Invalid destination file table index
- Invalid filename type selection
- Destination file table is not currently loaded

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_NTYPE\\_CMD\\_ERR\\_EID](#) error event message will be sent

#### Criticality

None

Definition at line 245 of file ds\_msgdefs.h.

Referenced by [DS\\_AppProcessCmd\(\)](#).

### 10.8.2.16 DS\_SET\_FILTER\_FILE\_CC

```
#define DS_SET_FILTER_FILE_CC 3
```

Set Destination File For Packet Filter Table Entry.

#### Description

This command will modify the Destination File selection for the indicated entry in the Packet Filter Table.

#### Command Structure

[DS\\_FilterFileCmd\\_t](#)

#### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will increment
- The [DS\\_FILE\\_CMD\\_EID](#) debug event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length
- Invalid filter table index
- Invalid filter parameters index
- Invalid destination file selection
- Packet filter table is not currently loaded
- Cannot modify unused packet filter table entry

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_FILE\\_CMD\\_ERR\\_EID](#) error event message will be sent

#### Criticality

None

Definition at line 148 of file `ds_msgdefs.h`.

Referenced by `DS_AppProcessCmd()`.

### 10.8.2.17 DS\_SET\_FILTER\_PARMS\_CC

```
#define DS_SET_FILTER_PARMS_CC 5
```

Set Algorithm Parameters For Packet Filter Table Entry.

#### Description

This command will modify the Algorithm Parameters for the indicated entry in the Packet Filter Table.

#### Command Structure

[DS\\_FilterParmsCmd\\_t](#)

#### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will increment
- The [DS\\_PARMS\\_CMD\\_EID](#) debug event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length
- Invalid filter table index
- Invalid filter parameters index
- Algorithm\_N value cannot be greater than Algorithm\_X
- Packet filter table is not currently loaded
- Cannot modify unused packet filter table entry

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_PARMS\\_CMD\\_ERR\\_EID](#) error event message will be sent

#### Criticality

None

Definition at line 214 of file `ds_msgdefs.h`.

Referenced by `DS_AppProcessCmd()`.

### 10.8.2.18 DS\_SET\_FILTER\_TYPE\_CC

```
#define DS_SET_FILTER_TYPE_CC 4
```

Set Filter Type For Packet Filter Table Entry.

#### Description

This command will modify the Filter Type selection for the indicated entry in the Packet Filter Table.

#### Command Structure

[DS\\_FilterTypeCmd\\_t](#)

#### Command Verification

Evidence of success may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdAcceptedCounter](#) will increment
- The [DS\\_FTYPE\\_CMD\\_EID](#) debug event message will be sent

#### Error Conditions

This command can fail for the following reasons:

- Invalid command packet length
- Invalid filter table index
- Invalid filter parameters index
- Invalid filter type selection
- Packet filter table is not currently loaded
- Cannot modify unused packet filter table entry

Evidence of failure may be found in the following telemetry:

- [DS\\_HkPacket\\_t.CmdRejectedCounter](#) will increment
- The [DS\\_FTYPE\\_CMD\\_ERR\\_EID](#) error event message will be sent

#### Criticality

None

Definition at line 181 of file `ds_msgdefs.h`.

Referenced by `DS_AppProcessCmd()`.

## 10.9 CFS Data Storage Version

### Macros

- `#define DS_MAJOR_VERSION 2`  
*Major version number.*
- `#define DS_MINOR_VERSION 6`  
*Minor version number.*
- `#define DS_REVISION 99`  
*Revision number.*

### 10.9.1 Detailed Description

#### Version Numbers

##### 10.9.2 Macro Definition Documentation

###### 10.9.2.1 DS\_MAJOR\_VERSION

```
#define DS_MAJOR_VERSION 2
```

Major version number.

Definition at line 33 of file `ds_version.h`.

Referenced by `DS_AppInitialize()`, and `DS_CmdNoop()`.

###### 10.9.2.2 DS\_MINOR\_VERSION

```
#define DS_MINOR_VERSION 6
```

Minor version number.

Definition at line 34 of file `ds_version.h`.

Referenced by `DS_AppInitialize()`, and `DS_CmdNoop()`.

###### 10.9.2.3 DS\_REVISION

```
#define DS_REVISION 99
```

Revision number.

Definition at line 35 of file `ds_version.h`.

Referenced by `DS_AppInitialize()`, and `DS_CmdNoop()`.

## 10.10 cFE Return Code Defines

### Macros

- #define CFE\_SUCCESS ((CFE\_Status\_t)0)  
*Successful execution.*
- #define CFE\_STATUS\_NO\_COUNTER\_INCREMENT ((CFE\_Status\_t)0x48000001)  
*No Counter Increment.*
- #define CFE\_STATUS\_WRONG\_MSG\_LENGTH ((CFE\_Status\_t)0xc8000002)  
*Wrong Message Length.*
- #define CFE\_STATUS\_UNKNOWN\_MSG\_ID ((CFE\_Status\_t)0xc8000003)  
*Unknown Message ID.*
- #define CFE\_STATUS\_BAD\_COMMAND\_CODE ((CFE\_Status\_t)0xc8000004)  
*Bad Command Code.*
- #define CFE\_STATUS\_EXTERNAL\_RESOURCE\_FAIL ((CFE\_Status\_t)0xc8000005)  
*External failure.*
- #define CFE\_STATUS\_REQUEST\_ALREADY\_PENDING ((int32)0xc8000006)  
*Request already pending.*
- #define CFE\_STATUS\_NOT\_IMPLEMENTED ((CFE\_Status\_t)0xc800ffff)  
*Not Implemented.*
- #define CFE\_EVS\_UNKNOWN\_FILTER ((CFE\_Status\_t)0xc2000001)  
*Unknown Filter.*
- #define CFE\_EVS\_APP\_NOT\_REGISTERED ((CFE\_Status\_t)0xc2000002)  
*Application Not Registered.*
- #define CFE\_EVS\_APP\_ILLEGAL\_APP\_ID ((CFE\_Status\_t)0xc2000003)  
*Illegal Application ID.*
- #define CFE\_EVS\_APP\_FILTER\_OVERLOAD ((CFE\_Status\_t)0xc2000004)  
*Application Filter Overload.*
- #define CFE\_EVS\_RESET\_AREA\_POINTER ((CFE\_Status\_t)0xc2000005)  
*Reset Area Pointer Failure.*
- #define CFE\_EVS\_EVT\_NOT\_REGISTERED ((CFE\_Status\_t)0xc2000006)  
*Event Not Registered.*
- #define CFE\_EVS\_FILE\_WRITE\_ERROR ((CFE\_Status\_t)0xc2000007)  
*File Write Error.*
- #define CFE\_EVS\_INVALID\_PARAMETER ((CFE\_Status\_t)0xc2000008)  
*Invalid Pointer.*
- #define CFE\_EVS\_APP\_SQUELCHED ((CFE\_Status\_t)0xc2000009)  
*Event squelched.*
- #define CFE\_EVS\_NOT\_IMPLEMENTED ((CFE\_Status\_t)0xc200ffff)  
*Not Implemented.*
- #define CFE\_ES\_ERR\_RESOURCEID\_NOT\_VALID ((CFE\_Status\_t)0xc4000001)  
*Resource ID is not valid.*
- #define CFE\_ES\_ERR\_NAME\_NOT\_FOUND ((CFE\_Status\_t)0xc4000002)  
*Resource Name Error.*
- #define CFE\_ES\_ERR\_APP\_CREATE ((CFE\_Status\_t)0xc4000004)  
*Application Create Error.*
- #define CFE\_ES\_ERR\_CHILD\_TASK\_CREATE ((CFE\_Status\_t)0xc4000005)

- Child Task Create Error.*
- #define CFE\_ES\_ERR\_SYS\_LOG\_FULL ((CFE\_Status\_t)0xc4000006)  
*System Log Full.*
  - #define CFE\_ES\_ERR\_MEM\_BLOCK\_SIZE ((CFE\_Status\_t)0xc4000008)  
*Memory Block Size Error.*
  - #define CFE\_ES\_ERR\_LOAD\_LIB ((CFE\_Status\_t)0xc4000009)  
*Load Library Error.*
  - #define CFE\_ES\_BAD\_ARGUMENT ((CFE\_Status\_t)0xc400000a)  
*Bad Argument.*
  - #define CFE\_ES\_ERR\_CHILD\_TASK\_REGISTER ((CFE\_Status\_t)0xc400000b)  
*Child Task Register Error.*
  - #define CFE\_ES\_CDS\_ALREADY\_EXISTS ((CFE\_Status\_t)0x4400000d)  
*CDS Already Exists.*
  - #define CFE\_ES\_CDS\_INSUFFICIENT\_MEMORY ((CFE\_Status\_t)0xc400000e)  
*CDS Insufficient Memory.*
  - #define CFE\_ES\_CDS\_INVALID\_NAME ((CFE\_Status\_t)0xc400000f)  
*CDS Invalid Name.*
  - #define CFE\_ES\_CDS\_INVALID\_SIZE ((CFE\_Status\_t)0xc4000010)  
*CDS Invalid Size.*
  - #define CFE\_ES\_CDS\_INVALID ((CFE\_Status\_t)0xc4000012)  
*CDS Invalid.*
  - #define CFE\_ES\_CDS\_ACCESS\_ERROR ((CFE\_Status\_t)0xc4000013)  
*CDS Access Error.*
  - #define CFE\_ES\_FILE\_IO\_ERR ((CFE\_Status\_t)0xc4000014)  
*File IO Error.*
  - #define CFE\_ES\_RST\_ACCESS\_ERR ((CFE\_Status\_t)0xc4000015)  
*Reset Area Access Error.*
  - #define CFE\_ES\_ERR\_APP\_REGISTER ((CFE\_Status\_t)0xc4000017)  
*Application Register Error.*
  - #define CFE\_ES\_ERR\_CHILD\_TASK\_DELETE ((CFE\_Status\_t)0xc4000018)  
*Child Task Delete Error.*
  - #define CFE\_ES\_ERR\_CHILD\_TASK\_DELETE\_MAIN\_TASK ((CFE\_Status\_t)0xc4000019)  
*Child Task Delete Passed Main Task.*
  - #define CFE\_ES\_CDS\_BLOCK\_CRC\_ERR ((CFE\_Status\_t)0xc400001A)  
*CDS Block CRC Error.*
  - #define CFE\_ES\_MUT\_SEM\_DELETE\_ERR ((CFE\_Status\_t)0xc400001B)  
*Mutex Semaphore Delete Error.*
  - #define CFE\_ES\_BIN\_SEM\_DELETE\_ERR ((CFE\_Status\_t)0xc400001C)  
*Binary Semaphore Delete Error.*
  - #define CFE\_ES\_COUNT\_SEM\_DELETE\_ERR ((CFE\_Status\_t)0xc400001D)  
*Counting Semaphore Delete Error.*
  - #define CFE\_ES\_QUEUE\_DELETE\_ERR ((CFE\_Status\_t)0xc400001E)  
*Queue Delete Error.*
  - #define CFE\_ES\_FILE\_CLOSE\_ERR ((CFE\_Status\_t)0xc400001F)  
*File Close Error.*
  - #define CFE\_ES\_CDS\_WRONG\_TYPE\_ERR ((CFE\_Status\_t)0xc4000020)  
*CDS Wrong Type Error.*

- #define CFE\_ES\_CDS\_OWNER\_ACTIVE\_ERR ((CFE\_Status\_t)0xc4000022)  
*CDS Owner Active Error.*
- #define CFE\_ES\_APP\_CLEANUP\_ERR ((CFE\_Status\_t)0xc4000023)  
*Application Cleanup Error.*
- #define CFE\_ES\_TIMER\_DELETE\_ERR ((CFE\_Status\_t)0xc4000024)  
*Timer Delete Error.*
- #define CFE\_ES\_BUFFER\_NOT\_IN\_POOL ((CFE\_Status\_t)0xc4000025)  
*Buffer Not In Pool.*
- #define CFE\_ES\_TASK\_DELETE\_ERR ((CFE\_Status\_t)0xc4000026)  
*Task Delete Error.*
- #define CFE\_ES\_OPERATION\_TIMED\_OUT ((CFE\_Status\_t)0xc4000027)  
*Operation Timed Out.*
- #define CFE\_ES\_LIB\_ALREADY\_LOADED ((CFE\_Status\_t)0x44000028)  
*Library Already Loaded.*
- #define CFE\_ES\_ERR\_SYS\_LOG\_TRUNCATED ((CFE\_Status\_t)0x44000029)  
*System Log Message Truncated.*
- #define CFE\_ES\_NO\_RESOURCE\_IDS\_AVAILABLE ((CFE\_Status\_t)0xc400002B)  
*Resource ID is not available.*
- #define CFE\_ES\_POOL\_BLOCK\_INVALID ((CFE\_Status\_t)0xc400002C)  
*Invalid pool block.*
- #define CFE\_ES\_ERR\_DUPLICATE\_NAME ((CFE\_Status\_t)0xc400002E)  
*Duplicate Name Error.*
- #define CFE\_ES\_NOT\_IMPLEMENTED ((CFE\_Status\_t)0xc400ffff)  
*Not Implemented.*
- #define CFE\_FS\_BAD\_ARGUMENT ((CFE\_Status\_t)0xc6000001)  
*Bad Argument.*
- #define CFE\_FS\_INVALID\_PATH ((CFE\_Status\_t)0xc6000002)  
*Invalid Path.*
- #define CFE\_FS\_FNAME\_TOO\_LONG ((CFE\_Status\_t)0xc6000003)  
*Filename Too Long.*
- #define CFE\_FS\_NOT\_IMPLEMENTED ((CFE\_Status\_t)0xc600ffff)  
*Not Implemented.*
- #define CFE\_SB\_TIME\_OUT ((CFE\_Status\_t)0xca000001)  
*Time Out.*
- #define CFE\_SB\_NO\_MESSAGE ((CFE\_Status\_t)0xca000002)  
*No Message.*
- #define CFE\_SB\_BAD\_ARGUMENT ((CFE\_Status\_t)0xca000003)  
*Bad Argument.*
- #define CFE\_SB\_MAX\_PIPES\_MET ((CFE\_Status\_t)0xca000004)  
*Max Pipes Met.*
- #define CFE\_SB\_PIPE\_CR\_ERR ((CFE\_Status\_t)0xca000005)  
*Pipe Create Error.*
- #define CFE\_SB\_PIPE\_RD\_ERR ((CFE\_Status\_t)0xca000006)  
*Pipe Read Error.*
- #define CFE\_SB\_MSG\_TOO\_BIG ((CFE\_Status\_t)0xca000007)  
*Message Too Big.*
- #define CFE\_SB\_BUF\_ALOC\_ERR ((CFE\_Status\_t)0xca000008)

- Buffer Allocation Error.*
- #define CFE\_SB\_MAX\_MSGS\_MET ((CFE\_Status\_t)0xca000009)  
*Max Messages Met.*
  - #define CFE\_SB\_MAX\_DESTS\_MET ((CFE\_Status\_t)0xca00000a)  
*Max Destinations Met.*
  - #define CFE\_SB\_INTERNAL\_ERR ((CFE\_Status\_t)0xca00000c)  
*Internal Error.*
  - #define CFE\_SB\_WRONG\_MSG\_TYPE ((CFE\_Status\_t)0xca00000d)  
*Wrong Message Type.*
  - #define CFE\_SB\_BUFFER\_INVALID ((CFE\_Status\_t)0xca00000e)  
*Buffer Invalid.*
  - #define CFE\_SB\_NOT\_IMPLEMENTED ((CFE\_Status\_t)0xca00ffff)  
*Not Implemented.*
  - #define CFE\_TBL\_ERR\_INVALID\_HANDLE ((CFE\_Status\_t)0xcc000001)  
*Invalid Handle.*
  - #define CFE\_TBL\_ERR\_INVALID\_NAME ((CFE\_Status\_t)0xcc000002)  
*Invalid Name.*
  - #define CFE\_TBL\_ERR\_INVALID\_SIZE ((CFE\_Status\_t)0xcc000003)  
*Invalid Size.*
  - #define CFE\_TBL\_INFO\_UPDATE\_PENDING ((CFE\_Status\_t)0x4c000004)  
*Update Pending.*
  - #define CFE\_TBL\_ERR\_NEVER\_LOADED ((CFE\_Status\_t)0xcc000005)  
*Never Loaded.*
  - #define CFE\_TBL\_ERR\_REGISTRY\_FULL ((CFE\_Status\_t)0xcc000006)  
*Registry Full.*
  - #define CFE\_TBL\_WARN\_DUPLICATE ((CFE\_Status\_t)0x4c000007)  
*Duplicate Warning.*
  - #define CFE\_TBL\_ERR\_NO\_ACCESS ((CFE\_Status\_t)0xcc000008)  
*No Access.*
  - #define CFE\_TBL\_ERR\_UNREGISTERED ((CFE\_Status\_t)0xcc000009)  
*Unregistered.*
  - #define CFE\_TBL\_ERR\_HANDLES\_FULL ((CFE\_Status\_t)0xcc00000B)  
*Handles Full.*
  - #define CFE\_TBL\_ERR\_DUPLICATE\_DIFF\_SIZE ((CFE\_Status\_t)0xcc00000C)  
*Duplicate Table With Different Size.*
  - #define CFE\_TBL\_ERR\_DUPLICATE\_NOT\_OWNED ((CFE\_Status\_t)0xcc00000D)  
*Duplicate Table And Not Owned.*
  - #define CFE\_TBL\_INFO\_UPDATED ((CFE\_Status\_t)0x4c00000E)  
*Updated.*
  - #define CFE\_TBL\_ERR\_NO\_BUFFER\_AVAIL ((CFE\_Status\_t)0xcc00000F)  
*No Buffer Available.*
  - #define CFE\_TBL\_ERR\_DUMP\_ONLY ((CFE\_Status\_t)0xcc000010)  
*Dump Only Error.*
  - #define CFE\_TBL\_ERR\_ILLEGAL\_SRC\_TYPE ((CFE\_Status\_t)0xcc000011)  
*Illegal Source Type.*
  - #define CFE\_TBL\_ERR\_LOAD\_IN\_PROGRESS ((CFE\_Status\_t)0xcc000012)  
*Load In Progress.*

- #define CFE\_TBL\_ERR\_FILE\_TOO\_LARGE ((CFE\_Status\_t)0xcc000014)  
*File Too Large.*
- #define CFE\_TBL\_WARN\_SHORT\_FILE ((CFE\_Status\_t)0x4c000015)  
*Short File Warning.*
- #define CFE\_TBL\_ERR\_BAD\_CONTENT\_ID ((CFE\_Status\_t)0xcc000016)  
*Bad Content ID.*
- #define CFE\_TBL\_INFO\_NO\_UPDATE\_PENDING ((CFE\_Status\_t)0x4c000017)  
*No Update Pending.*
- #define CFE\_TBL\_INFO\_TABLE\_LOCKED ((CFE\_Status\_t)0x4c000018)  
*Table Locked.*
- #define CFE\_TBL\_INFO\_VALIDATION\_PENDING ((CFE\_Status\_t)0x4c000019)
- #define CFE\_TBL\_INFO\_NO\_VALIDATION\_PENDING ((CFE\_Status\_t)0x4c00001A)
- #define CFE\_TBL\_ERR\_BAD\_SUBTYPE\_ID ((CFE\_Status\_t)0xcc00001B)  
*Bad Subtype ID.*
- #define CFE\_TBL\_ERR\_FILE\_SIZE\_INCONSISTENT ((CFE\_Status\_t)0xcc00001C)  
*File Size Inconsistent.*
- #define CFE\_TBL\_ERR\_NO\_STD\_HEADER ((CFE\_Status\_t)0xcc00001D)  
*No Standard Header.*
- #define CFE\_TBL\_ERR\_NO\_TBL\_HEADER ((CFE\_Status\_t)0xcc00001E)  
*No Table Header.*
- #define CFE\_TBL\_ERR\_FILENAME\_TOO\_LONG ((CFE\_Status\_t)0xcc00001F)  
*Filename Too Long.*
- #define CFE\_TBL\_ERR\_FILE\_FOR\_WRONG\_TABLE ((CFE\_Status\_t)0xcc000020)  
*File For Wrong Table.*
- #define CFE\_TBL\_ERR\_LOAD\_INCOMPLETE ((CFE\_Status\_t)0xcc000021)  
*Load Incomplete.*
- #define CFE\_TBL\_WARN\_PARTIAL\_LOAD ((CFE\_Status\_t)0x4c000022)  
*Partial Load Warning.*
- #define CFE\_TBL\_ERR\_PARTIAL\_LOAD ((CFE\_Status\_t)0xcc000023)  
*Partial Load Error.*
- #define CFE\_TBL\_INFO\_DUMP\_PENDING ((CFE\_Status\_t)0x4c000024)  
*Dump Pending.*
- #define CFE\_TBL\_ERR\_INVALID\_OPTIONS ((CFE\_Status\_t)0xcc000025)  
*Invalid Options.*
- #define CFE\_TBL\_WARN\_NOT\_CRITICAL ((CFE\_Status\_t)0x4c000026)  
*Not Critical Warning.*
- #define CFE\_TBL\_INFO\_RECOVERED\_TBL ((CFE\_Status\_t)0x4c000027)  
*Recovered Table.*
- #define CFE\_TBL\_ERR\_BAD\_SPACECRAFT\_ID ((CFE\_Status\_t)0xcc000028)  
*Bad Spacecraft ID.*
- #define CFE\_TBL\_ERR\_BAD\_PROCESSOR\_ID ((CFE\_Status\_t)0xcc000029)  
*Bad Processor ID.*
- #define CFE\_TBL\_MESSAGE\_ERROR ((CFE\_Status\_t)0xcc00002a)  
*Message Error.*
- #define CFE\_TBL\_ERR\_SHORT\_FILE ((CFE\_Status\_t)0xcc00002b)
- #define CFE\_TBL\_ERR\_ACCESS ((CFE\_Status\_t)0xcc00002c)
- #define CFE\_TBL\_BAD\_ARGUMENT ((CFE\_Status\_t)0xcc00002d)

*Bad Argument.*

- #define CFE\_TBL\_NOT\_IMPLEMENTED ((CFE\_Status\_t)0xcc00ffff)  
*Not Implemented.*
- #define CFE\_TIME\_NOT\_IMPLEMENTED ((CFE\_Status\_t)0xce00ffff)  
*Not Implemented.*
- #define CFE\_TIME\_INTERNAL\_ONLY ((CFE\_Status\_t)0xce000001)  
*Internal Only.*
- #define CFE\_TIME\_OUT\_OF\_RANGE ((CFE\_Status\_t)0xce000002)  
*Out Of Range.*
- #define CFE\_TIME\_TOO\_MANY\_SYNCH\_CALLBACKS ((CFE\_Status\_t)0xce000003)  
*Too Many Sync Callbacks.*
- #define CFE\_TIME\_CALLBACK\_NOT\_REGISTERED ((CFE\_Status\_t)0xce000004)  
*Callback Not Registered.*
- #define CFE\_TIME\_BAD\_ARGUMENT ((CFE\_Status\_t)0xce000005)  
*Bad Argument.*

#### 10.10.1 Detailed Description

#### 10.10.2 Macro Definition Documentation

##### 10.10.2.1 CFE\_ES\_APP\_CLEANUP\_ERR

```
#define CFE_ES_APP_CLEANUP_ERR ((CFE_Status_t)0xc4000023)
```

Application Cleanup Error.

Occurs when an attempt was made to Clean Up an application which involves calling Table, EVS, and SB cleanup functions, then deleting all ES resources, child tasks, and unloading the object module. The approach here is to keep going even though one of these steps had an error. There will be syslog messages detailing each problem.

Definition at line 564 of file cfe\_error.h.

##### 10.10.2.2 CFE\_ES\_BAD\_ARGUMENT

```
#define CFE_ES_BAD_ARGUMENT ((CFE_Status_t)0xc40000a)
```

Bad Argument.

Bad parameter passed into an ES API.

Definition at line 375 of file cfe\_error.h.

### 10.10.2.3 CFE\_ES\_BIN\_SEM\_DELETE\_ERR

```
#define CFE_ES_BIN_SEM_DELETE_ERR ((CFE_Status_t)0xc400001C)
```

Binary Semaphore Delete Error.

Occurs when trying to delete a Binary Semaphore that belongs to a task that ES is cleaning up.

Definition at line 503 of file cfe\_error.h.

### 10.10.2.4 CFE\_ES\_BUFFER\_NOT\_IN\_POOL

```
#define CFE_ES_BUFFER_NOT_IN_POOL ((CFE_Status_t)0xc4000025)
```

Buffer Not In Pool.

The specified address is not in the memory pool.

Definition at line 581 of file cfe\_error.h.

### 10.10.2.5 CFE\_ES\_CDS\_ACCESS\_ERROR

```
#define CFE_ES_CDS_ACCESS_ERROR ((CFE_Status_t)0xc4000013)
```

CDS Access Error.

The CDS was inaccessible

Definition at line 434 of file cfe\_error.h.

### 10.10.2.6 CFE\_ES\_CDS\_ALREADY\_EXISTS

```
#define CFE_ES_CDS_ALREADY_EXISTS ((CFE_Status_t)0x4400000d)
```

CDS Already Exists.

The Application is receiving the pointer to a CDS that was already present.

Definition at line 391 of file cfe\_error.h.

Referenced by DS\_TableCreateCDS().

#### 10.10.2.7 CFE\_ES\_CDS\_BLOCK\_CRC\_ERR

```
#define CFE_ES_CDS_BLOCK_CRC_ERR ((CFE_Status_t)0xc400001A)
```

CDS Block CRC Error.

Occurs when trying to read a CDS Data block and the CRC of the current data does not match the stored CRC for the data. Either the contents of the CDS Data Block are corrupted or the CDS Control Block is corrupted.

Definition at line 485 of file cfe\_error.h.

#### 10.10.2.8 CFE\_ES\_CDS\_INSUFFICIENT\_MEMORY

```
#define CFE_ES_CDS_INSUFFICIENT_MEMORY ((CFE_Status_t)0xc400000e)
```

CDS Insufficient Memory.

The Application is requesting a CDS Block that is larger than the remaining CDS memory.

Definition at line 400 of file cfe\_error.h.

#### 10.10.2.9 CFE\_ES\_CDS\_INVALID

```
#define CFE_ES_CDS_INVALID ((CFE_Status_t)0xc4000012)
```

CDS Invalid.

The CDS contents are invalid.

Definition at line 426 of file cfe\_error.h.

#### 10.10.2.10 CFE\_ES\_CDS\_INVALID\_NAME

```
#define CFE_ES_CDS_INVALID_NAME ((CFE_Status_t)0xc400000f)
```

CDS Invalid Name.

The Application is requesting a CDS Block with an invalid ASCII string name. Either the name is too long (> [CFE\\_MISSESSION\\_ES\\_CDS\\_MAX\\_NAME\\_LENGTH](#)) or was an empty string.

Definition at line 409 of file cfe\_error.h.

#### 10.10.2.11 CFE\_ES\_CDS\_INVALID\_SIZE

```
#define CFE_ES_CDS_INVALID_SIZE ((CFE_Status_t)0xc4000010)
```

CDS Invalid Size.

The Application is requesting a CDS Block or Pool with a size beyond the applicable limits, either too large or too small/zero.

Definition at line 418 of file cfe\_error.h.

#### 10.10.2.12 CFE\_ES\_CDS\_OWNER\_ACTIVE\_ERR

```
#define CFE_ES_CDS_OWNER_ACTIVE_ERR ((CFE_Status_t)0xc4000022)
```

CDS Owner Active Error.

Occurs when an attempt was made to delete a CDS when an application with the same name associated with the CDS is still present. CDSs can ONLY be deleted when Applications that created them are not present in the system.

Definition at line 551 of file cfe\_error.h.

#### 10.10.2.13 CFE\_ES\_CDS\_WRONG\_TYPE\_ERR

```
#define CFE_ES_CDS_WRONG_TYPE_ERR ((CFE_Status_t)0xc4000020)
```

CDS Wrong Type Error.

Occurs when Table Services is trying to delete a Critical Data Store that is not a Critical Table Image or when Executive Services is trying to delete a Critical Table Image.

Definition at line 540 of file cfe\_error.h.

#### 10.10.2.14 CFE\_ES\_COUNT\_SEM\_DELETE\_ERR

```
#define CFE_ES_COUNT_SEM_DELETE_ERR ((CFE_Status_t)0xc400001D)
```

Counting Semaphore Delete Error.

Occurs when trying to delete a Counting Semaphore that belongs to a task that ES is cleaning up.

Definition at line 512 of file cfe\_error.h.

**10.10.2.15 CFE\_ES\_ERR\_APP\_CREATE**

```
#define CFE_ES_ERR_APP_CREATE ((CFE_Status_t)0xc4000004)
```

Application Create Error.

There was an error loading or creating the App.

Definition at line 334 of file cfe\_error.h.

**10.10.2.16 CFE\_ES\_ERR\_APP\_REGISTER**

```
#define CFE_ES_ERR_APP_REGISTER ((CFE_Status_t)0xc4000017)
```

Application Register Error.

Occurs when a task cannot be registered in ES global tables

Definition at line 458 of file cfe\_error.h.

**10.10.2.17 CFE\_ES\_ERR\_CHILD\_TASK\_CREATE**

```
#define CFE_ES_ERR_CHILD_TASK_CREATE ((CFE_Status_t)0xc4000005)
```

Child Task Create Error.

There was an error creating a child task.

Definition at line 342 of file cfe\_error.h.

**10.10.2.18 CFE\_ES\_ERR\_CHILD\_TASK\_DELETE**

```
#define CFE_ES_ERR_CHILD_TASK_DELETE ((CFE_Status_t)0xc4000018)
```

Child Task Delete Error.

There was an error deleting a child task.

Definition at line 466 of file cfe\_error.h.

#### 10.10.2.19 CFE\_ES\_ERR\_CHILD\_TASK\_DELETE\_MAIN\_TASK

```
#define CFE_ES_ERR_CHILD_TASK_DELETE_MAIN_TASK ((CFE_Status_t)0xc4000019)
```

Child Task Delete Passed Main Task.

There was an attempt to delete a cFE App Main Task with the [CFE\\_ES\\_DeleteChildTask](#) API.

Definition at line 475 of file `cfe_error.h`.

#### 10.10.2.20 CFE\_ES\_ERR\_CHILD\_TASK\_REGISTER

```
#define CFE_ES_ERR_CHILD_TASK_REGISTER ((CFE_Status_t)0xc400000b)
```

Child Task Register Error.

Errors occurred when trying to register a child task.

Definition at line 383 of file `cfe_error.h`.

#### 10.10.2.21 CFE\_ES\_ERR\_DUPLICATE\_NAME

```
#define CFE_ES_ERR_DUPLICATE_NAME ((CFE_Status_t)0xc400002E)
```

Duplicate Name Error.

Resource creation failed due to the name already existing in the system.

Definition at line 644 of file `cfe_error.h`.

#### 10.10.2.22 CFE\_ES\_ERR\_LOAD\_LIB

```
#define CFE_ES_ERR_LOAD_LIB ((CFE_Status_t)0xc4000009)
```

Load Library Error.

Could not load the shared library.

Definition at line 367 of file `cfe_error.h`.

**10.10.2.23 CFE\_ES\_ERR\_MEM\_BLOCK\_SIZE**

```
#define CFE_ES_ERR_MEM_BLOCK_SIZE ((CFE_Status_t)0xc4000008)
```

Memory Block Size Error.

The block size requested is invalid.

Definition at line 359 of file cfe\_error.h.

**10.10.2.24 CFE\_ES\_ERR\_NAME\_NOT\_FOUND**

```
#define CFE_ES_ERR_NAME_NOT_FOUND ((CFE_Status_t)0xc4000002)
```

Resource Name Error.

There is no match in the system for the given name.

Definition at line 326 of file cfe\_error.h.

**10.10.2.25 CFE\_ES\_ERR\_RESOURCEID\_NOT\_VALID**

```
#define CFE_ES_ERR_RESOURCEID_NOT_VALID ((CFE_Status_t)0xc4000001)
```

Resource ID is not valid.

This error indicates that the passed in resource identifier (App ID, Lib ID, Counter ID, etc) did not validate.

Definition at line 318 of file cfe\_error.h.

**10.10.2.26 CFE\_ES\_ERR\_SYS\_LOG\_FULL**

```
#define CFE_ES_ERR_SYS_LOG_FULL ((CFE_Status_t)0xc4000006)
```

System Log Full.

The cFE system Log is full. This error means the message was not logged at all

Definition at line 351 of file cfe\_error.h.

**10.10.2.27 CFE\_ES\_ERR\_SYS\_LOG\_TRUNCATED**

```
#define CFE_ES_ERR_SYS_LOG_TRUNCATED ((CFE_Status_t)0x44000029)
```

System Log Message Truncated.

This information code means the last syslog message was truncated due to insufficient space in the log buffer.

Definition at line 616 of file cfe\_error.h.

**10.10.2.28 CFE\_ES\_FILE\_CLOSE\_ERR**

```
#define CFE_ES_FILE_CLOSE_ERR ((CFE_Status_t)0xc400001F)
```

File Close Error.

Occurs when trying to close a file that belongs to a task that ES is cleaning up.

Definition at line 530 of file cfe\_error.h.

**10.10.2.29 CFE\_ES\_FILE\_IO\_ERR**

```
#define CFE_ES_FILE_IO_ERR ((CFE_Status_t)0xc4000014)
```

File IO Error.

Occurs when a file operation fails

Definition at line 442 of file cfe\_error.h.

**10.10.2.30 CFE\_ES\_LIB\_ALREADY\_LOADED**

```
#define CFE_ES_LIB_ALREADY_LOADED ((CFE_Status_t)0x44000028)
```

Library Already Loaded.

Occurs if CFE\_ES\_LoadLibrary detects that the requested library name is already loaded.

Definition at line 607 of file cfe\_error.h.

**10.10.2.31 CFE\_ES\_MUT\_SEM\_DELETE\_ERR**

```
#define CFE_ES_MUT_SEM_DELETE_ERR ((CFE_Status_t)0xc400001B)
```

Mutex Semaphore Delete Error.

Occurs when trying to delete a Mutex that belongs to a task that ES is cleaning up.

Definition at line 494 of file cfe\_error.h.

**10.10.2.32 CFE\_ES\_NO\_RESOURCE\_IDS\_AVAILABLE**

```
#define CFE_ES_NO_RESOURCE_IDS_AVAILABLE ((CFE_Status_t)0xc400002B)
```

Resource ID is not available.

This error indicates that the maximum resource identifiers (App ID, Lib ID, Counter ID, etc) has already been reached and a new ID cannot be allocated.

Definition at line 626 of file cfe\_error.h.

**10.10.2.33 CFE\_ES\_NOT\_IMPLEMENTED**

```
#define CFE_ES_NOT_IMPLEMENTED ((CFE_Status_t)0xc400ffff)
```

Not Implemented.

Current version of cFE does not have the function or the feature of the function implemented. This could be due to either an early build of the cFE for this platform or the platform does not support the specified feature.

Definition at line 655 of file cfe\_error.h.

**10.10.2.34 CFE\_ES\_OPERATION\_TIMED\_OUT**

```
#define CFE_ES_OPERATION_TIMED_OUT ((CFE_Status_t)0xc4000027)
```

Operation Timed Out.

Occurs if the timeout for a given operation was exceeded

Definition at line 598 of file cfe\_error.h.

**10.10.2.35 CFE\_ES\_POOL\_BLOCK\_INVALID**

```
#define CFE_ES_POOL_BLOCK_INVALID ((CFE_Status_t)0xc400002C)
```

Invalid pool block.

Software attempted to "put" a block back into a pool which does not appear to belong to that pool. This may mean the pool has become unusable due to memory corruption.

Definition at line 636 of file cfe\_error.h.

**10.10.2.36 CFE\_ES\_QUEUE\_DELETE\_ERR**

```
#define CFE_ES_QUEUE_DELETE_ERR ((CFE_Status_t)0xc400001E)
```

Queue Delete Error.

Occurs when trying to delete a Queue that belongs to a task that ES is cleaning up.

Definition at line 521 of file cfe\_error.h.

**10.10.2.37 CFE\_ES\_RST\_ACCESS\_ERR**

```
#define CFE_ES_RST_ACCESS_ERR ((CFE_Status_t)0xc4000015)
```

Reset Area Access Error.

Occurs when the BSP is not successful in returning the reset area address.

Definition at line 450 of file cfe\_error.h.

**10.10.2.38 CFE\_ES\_TASK\_DELETE\_ERR**

```
#define CFE_ES_TASK_DELETE_ERR ((CFE_Status_t)0xc4000026)
```

Task Delete Error.

Occurs when trying to delete a task that ES is cleaning up.

Definition at line 590 of file cfe\_error.h.

**10.10.2.39 CFE\_ES\_TIMER\_DELETE\_ERR**

```
#define CFE_ES_TIMER_DELETE_ERR ((CFE_Status_t)0xc4000024)
```

Timer Delete Error.

Occurs when trying to delete a Timer that belongs to a task that ES is cleaning up.

Definition at line 573 of file cfe\_error.h.

**10.10.2.40 CFE\_EVS\_APP\_FILTER\_OVERLOAD**

```
#define CFE_EVS_APP_FILTER_OVERLOAD ((CFE_Status_t)0xc2000004)
```

Application Filter Overload.

Number of Application event filters input upon registration is greater than [CFE\\_PLATFORM\\_EVS\\_MAX\\_EVENT\\_FILTERS](#)

Definition at line 252 of file cfe\_error.h.

**10.10.2.41 CFE\_EVS\_APP\_ILLEGAL\_APP\_ID**

```
#define CFE_EVS_APP_ILLEGAL_APP_ID ((CFE_Status_t)0xc2000003)
```

Illegal Application ID.

Application ID returned by [CFE\\_ES\\_GetAppIDByName](#) is greater than [CFE\\_PLATFORM\\_ES\\_MAX\\_APPLICATIONS](#)

Definition at line 243 of file cfe\_error.h.

**10.10.2.42 CFE\_EVS\_APP\_NOT\_REGISTERED**

```
#define CFE_EVS_APP_NOT_REGISTERED ((CFE_Status_t)0xc2000002)
```

Application Not Registered.

Calling application never previously called [CFE\\_EVS\\_Register](#)

Definition at line 234 of file cfe\_error.h.

#### 10.10.2.43 CFE\_EVS\_APP\_SQUELCHED

```
#define CFE_EVS_APP_SQUELCHED ((CFE_Status_t)0xc2000009)
```

Event squelched.

Event squelched due to being sent at too high a rate

Definition at line 294 of file cfe\_error.h.

#### 10.10.2.44 CFE\_EVS\_EVT\_NOT\_REGISTERED

```
#define CFE_EVS_EVT_NOT_REGISTERED ((CFE_Status_t)0xc2000006)
```

Event Not Registered.

[CFE\\_EVS\\_ResetFilter](#) EventID argument was not found in any event filter registered by the calling application.

Definition at line 270 of file cfe\_error.h.

#### 10.10.2.45 CFE\_EVS\_FILE\_WRITE\_ERROR

```
#define CFE_EVS_FILE_WRITE_ERROR ((CFE_Status_t)0xc2000007)
```

File Write Error.

A file write error occurred while processing an EVS command

Definition at line 278 of file cfe\_error.h.

#### 10.10.2.46 CFE\_EVS\_INVALID\_PARAMETER

```
#define CFE_EVS_INVALID_PARAMETER ((CFE_Status_t)0xc2000008)
```

Invalid Pointer.

Invalid parameter supplied to EVS command

Definition at line 286 of file cfe\_error.h.

**10.10.2.47 CFE\_EVS\_NOT\_IMPLEMENTED**

```
#define CFE_EVS_NOT_IMPLEMENTED ((CFE_Status_t)0xc200ffff)
```

Not Implemented.

Current version of cFE does not have the function or the feature of the function implemented. This could be due to either an early build of the cFE for this platform or the platform does not support the specified feature.

Definition at line 305 of file cfe\_error.h.

**10.10.2.48 CFE\_EVS\_RESET\_AREA\_POINTER**

```
#define CFE_EVS_RESET_AREA_POINTER ((CFE_Status_t)0xc2000005)
```

Reset Area Pointer Failure.

Could not get pointer to the ES Reset area, so we could not get the pointer to the EVS Log.

Definition at line 261 of file cfe\_error.h.

**10.10.2.49 CFE\_EVS\_UNKNOWN\_FILTER**

```
#define CFE_EVS_UNKNOWN_FILTER ((CFE_Status_t)0xc2000001)
```

Unknown Filter.

**CFE\_EVS\_Register** FilterScheme parameter was illegal

Definition at line 226 of file cfe\_error.h.

**10.10.2.50 CFE\_FS\_BAD\_ARGUMENT**

```
#define CFE_FS_BAD_ARGUMENT ((CFE_Status_t)0xc6000001)
```

Bad Argument.

A parameter given by a caller to a File Services API did not pass validation checks.

Definition at line 668 of file cfe\_error.h.

#### 10.10.2.51 CFE\_FS\_FNAME\_TOO\_LONG

```
#define CFE_FS_FNAME_TOO_LONG ((CFE_Status_t)0xc6000003)
```

Filename Too Long.

FS filename string is too long

Definition at line 684 of file cfe\_error.h.

#### 10.10.2.52 CFE\_FS\_INVALID\_PATH

```
#define CFE_FS_INVALID_PATH ((CFE_Status_t)0xc6000002)
```

Invalid Path.

FS was unable to extract a filename from a path string

Definition at line 676 of file cfe\_error.h.

#### 10.10.2.53 CFE\_FS\_NOT\_IMPLEMENTED

```
#define CFE_FS_NOT_IMPLEMENTED ((CFE_Status_t)0xc600ffff)
```

Not Implemented.

Current version of cFE does not have the function or the feature of the function implemented. This could be due to either an early build of the cFE for this platform or the platform does not support the specified feature.

Definition at line 695 of file cfe\_error.h.

#### 10.10.2.54 CFE\_SB\_BAD\_ARGUMENT

```
#define CFE_SB_BAD_ARGUMENT ((CFE_Status_t)0xca000003)
```

Bad Argument.

A parameter given by a caller to a Software Bus API did not pass validation checks.

Definition at line 726 of file cfe\_error.h.

**10.10.2.55 CFE\_SB\_BUF\_ALOC\_ERR**

```
#define CFE_SB_BUF_ALOC_ERR ((CFE_Status_t)0xca000008)
```

Buffer Allocation Error.

Returned when the memory in the SB message buffer pool has been depleted. The amount of memory in the pool is dictated by the configuration parameter [CFE\\_PLATFORM\\_SB\\_BUF\\_MEMORY\\_BYTES](#) specified in the `cfe_platform_cfg.h` file. Also the memory statistics, including current utilization figures and high water marks for the SB Buffer memory pool can be monitored by sending a Software Bus command to send the SB statistics packet.

Definition at line 784 of file `cfe_error.h`.

**10.10.2.56 CFE\_SB\_BUFFER\_INVALID**

```
#define CFE_SB_BUFFER_INVALID ((CFE_Status_t)0xca00000e)
```

Buffer Invalid.

This error code will be returned when a request to release or send a zero copy buffer is invalid, such as if the handle or buffer is not correct or the buffer was previously released.

Definition at line 835 of file `cfe_error.h`.

**10.10.2.57 CFE\_SB\_INTERNAL\_ERR**

```
#define CFE_SB_INTERNAL_ERR ((CFE_Status_t)0xca00000c)
```

Internal Error.

This error code will be returned by the [CFE\\_SB\\_Subscribe](#) API if the code detects an internal index is out of range. The most likely cause would be a Single Event Upset.

Definition at line 816 of file `cfe_error.h`.

**10.10.2.58 CFE\_SB\_MAX\_DESTS\_MET**

```
#define CFE_SB_MAX_DESTS_MET ((CFE_Status_t)0xca00000a)
```

Max Destinations Met.

Will be returned when calling one of the SB subscription API's if the SB routing table cannot accommodate another destination for a particular the given message ID. This occurs when the number of destinations in use meets the platform configuration parameter [CFE\\_PLATFORM\\_SB\\_MAX\\_DEST\\_PER\\_PKT](#).

Definition at line 806 of file `cfe_error.h`.

#### 10.10.2.59 CFE\_SB\_MAX\_MSGS\_MET

```
#define CFE_SB_MAX_MSGS_MET ((CFE_Status_t)0xca000009)
```

Max Messages Met.

Will be returned when calling one of the SB subscription API's if the SB routing table cannot accommodate another unique message ID because the platform configuration parameter [CFE\\_PLATFORM\\_SB\\_MAX\\_MSG\\_IDS](#) has been met.

Definition at line 794 of file cfe\_error.h.

#### 10.10.2.60 CFE\_SB\_MAX\_PIPES\_MET

```
#define CFE_SB_MAX_PIPES_MET ((CFE_Status_t)0xca000004)
```

Max Pipes Met.

This error code will be returned from [CFE\\_SB\\_CreatePipe](#) when the SB cannot accommodate the request to create a pipe because the maximum number of pipes ([CFE\\_PLATFORM\\_SB\\_MAX\\_PIPES](#)) are in use. This configuration parameter is defined in the cfe\_platform\_cfg.h file.

Definition at line 737 of file cfe\_error.h.

#### 10.10.2.61 CFE\_SB\_MSG\_TOO\_BIG

```
#define CFE_SB_MSG_TOO_BIG ((CFE_Status_t)0xca000007)
```

Message Too Big.

The size field in the message header indicates the message exceeds the max Software Bus message size. The max size is defined by configuration parameter [CFE\\_MISSION\\_SB\\_MAX\\_SB\\_MSG\\_SIZE](#) in cfe\_mission\_cfg.h

Definition at line 771 of file cfe\_error.h.

#### 10.10.2.62 CFE\_SB\_NO\_MESSAGE

```
#define CFE_SB_NO_MESSAGE ((CFE_Status_t)0xca000002)
```

No Message.

When "Polling" a pipe for a message in [CFE\\_SB\\_ReceiveBuffer](#), this return value indicates that there was not a message on the pipe.

Definition at line 717 of file cfe\_error.h.

**10.10.2.63 CFE\_SB\_NOT\_IMPLEMENTED**

```
#define CFE_SB_NOT_IMPLEMENTED ((CFE_Status_t)0xca00ffff)
```

Not Implemented.

Current version of cFE does not have the function or the feature of the function implemented. This could be due to either an early build of the cFE for this platform or the platform does not support the specified feature.

Definition at line 846 of file cfe\_error.h.

**10.10.2.64 CFE\_SB\_PIPE\_CR\_ERR**

```
#define CFE_SB_PIPE_CR_ERR ((CFE_Status_t)0xca000005)
```

Pipe Create Error.

The maximum number of queues([OS\\_MAX\\_QUEUES](#)) are in use. Or possibly a lower level problem with creating the underlying queue has occurred such as a lack of memory. If the latter is the problem, the status code displayed in the event must be tracked.

Definition at line 748 of file cfe\_error.h.

**10.10.2.65 CFE\_SB\_PIPE\_RD\_ERR**

```
#define CFE_SB_PIPE_RD_ERR ((CFE_Status_t)0xca000006)
```

Pipe Read Error.

This return value indicates an error at the Queue read level. This error typically cannot be corrected by the caller. Some possible causes are: queue was not properly initialized or created, the number of bytes read from the queue was not the number of bytes requested in the read. The queue id is invalid. Similar errors regarding the pipe will be caught by higher level code in the Software Bus.

Definition at line 761 of file cfe\_error.h.

**10.10.2.66 CFE\_SB\_TIME\_OUT**

```
#define CFE_SB_TIME_OUT ((CFE_Status_t)0xca000001)
```

Time Out.

In [CFE\\_SB\\_ReceiveBuffer](#), this return value indicates that a packet has not been received in the time given in the "timeout" parameter.

Definition at line 708 of file cfe\_error.h.

Referenced by DS\_AppMain().

#### 10.10.2.67 CFE\_SB\_WRONG\_MSG\_TYPE

```
#define CFE_SB_WRONG_MSG_TYPE ((CFE_Status_t)0xca00000d)
```

Wrong Message Type.

This error code will be returned when a request such as `CFE_MSG_SetMsgTime` is made on a packet that does not include a field for msg time.

Definition at line 825 of file `cfe_error.h`.

#### 10.10.2.68 CFE\_STATUS\_BAD\_COMMAND\_CODE

```
#define CFE_STATUS_BAD_COMMAND_CODE ((CFE_Status_t)0xc8000004)
```

Bad Command Code.

This error code will be returned when a message identification process determined that the command code is does not correspond to any known value

Definition at line 182 of file `cfe_error.h`.

#### 10.10.2.69 CFE\_STATUS\_EXTERNAL\_RESOURCE\_FAIL

```
#define CFE_STATUS_EXTERNAL_RESOURCE_FAIL ((CFE_Status_t)0xc8000005)
```

External failure.

This error indicates that the operation failed for some reason outside the scope of CFE. The real failure may have been in OSAL, PSP, or another dependent library.

Details of the original failure should be written to syslog and/or a system event before returning this error.

Definition at line 194 of file `cfe_error.h`.

#### 10.10.2.70 CFE\_STATUS\_NO\_COUNTER\_INCREMENT

```
#define CFE_STATUS_NO_COUNTER_INCREMENT ((CFE_Status_t)0x48000001)
```

No Counter Increment.

Informational code indicating that a command was processed successfully but that the command counter should *not* be incremented.

Definition at line 155 of file `cfe_error.h`.

**10.10.2.71 CFE\_STATUS\_NOT\_IMPLEMENTED**

```
#define CFE_STATUS_NOT_IMPLEMENTED ((CFE_Status_t)0xc800ffff)
```

Not Implemented.

Current version does not have the function or the feature of the function implemented. This could be due to either an early build for this platform or the platform does not support the specified feature.

Definition at line 214 of file cfe\_error.h.

**10.10.2.72 CFE\_STATUS\_REQUEST\_ALREADY\_PENDING**

```
#define CFE_STATUS_REQUEST_ALREADY_PENDING ((int32)0xc8000006)
```

Request already pending.

Commands or requests are already pending or the pending request limit has been reached. No more requests can be made until the current request(s) complete.

Definition at line 203 of file cfe\_error.h.

**10.10.2.73 CFE\_STATUS\_UNKNOWN\_MSG\_ID**

```
#define CFE_STATUS_UNKNOWN_MSG_ID ((CFE_Status_t)0xc8000003)
```

Unknown Message ID.

This error code will be returned when a message identification process determined that the message ID does not correspond to a known value

Definition at line 173 of file cfe\_error.h.

**10.10.2.74 CFE\_STATUS\_WRONG\_MSG\_LENGTH**

```
#define CFE_STATUS_WRONG_MSG_LENGTH ((CFE_Status_t)0xc8000002)
```

Wrong Message Length.

This error code will be returned when a message validation process determined that the message length is incorrect

Definition at line 164 of file cfe\_error.h.

#### 10.10.2.75 CFE\_SUCCESS

```
#define CFE_SUCCESS ((CFE_Status_t) 0)
```

Successful execution.

Operation was performed successfully

Definition at line 147 of file cfe\_error.h.

Referenced by DS\_AppInitialize(), DS\_AppMain(), DS\_AppProcessHK(), DS\_FileCreateDest(), DS\_FileUpdateHeader(), DS\_FileWriteData(), DS\_FileWriteHeader(), DS\_TableCreateCDS(), DS\_TableInit(), DS\_TableManageDestFile(), DS\_TableManageFilter(), DS\_TableUpdateCDS(), DS\_TableVerifyDestFile(), and DS\_TableVerifyFilter().

#### 10.10.2.76 CFE\_TBL\_BAD\_ARGUMENT

```
#define CFE_TBL_BAD_ARGUMENT ((CFE_Status_t) 0xcc00002d)
```

Bad Argument.

A parameter given by a caller to a Table API did not pass validation checks.

Definition at line 1257 of file cfe\_error.h.

#### 10.10.2.77 CFE\_TBL\_ERR\_ACCESS

```
#define CFE_TBL_ERR_ACCESS ((CFE_Status_t) 0xcc00002c)
```

Error code indicating that the TBL file could not be opened by the OS.

Definition at line 1248 of file cfe\_error.h.

#### 10.10.2.78 CFE\_TBL\_ERR\_BAD\_CONTENT\_ID

```
#define CFE_TBL_ERR_BAD_CONTENT_ID ((CFE_Status_t) 0xcc000016)
```

Bad Content ID.

The calling Application called [CFE\\_TBL\\_Load](#) with a filename that specified a file whose content ID was not that of a table image.

Definition at line 1040 of file cfe\_error.h.

**10.10.2.79 CFE\_TBL\_ERR\_BAD\_PROCESSOR\_ID**

```
#define CFE_TBL_ERR_BAD_PROCESSOR_ID ((CFE_Status_t)0xcc000029)
```

Bad Processor ID.

The selected table file failed validation for Processor ID. The platform configuration file has verification of table files enabled for Processor ID and an attempt was made to load a table with an invalid Processor ID in the table file header.

Definition at line 1228 of file cfe\_error.h.

**10.10.2.80 CFE\_TBL\_ERR\_BAD\_SPACECRAFT\_ID**

```
#define CFE_TBL_ERR_BAD_SPACECRAFT_ID ((CFE_Status_t)0xcc000028)
```

Bad Spacecraft ID.

The selected table file failed validation for Spacecraft ID. The platform configuration file has verification of table files enabled for Spacecraft ID and an attempt was made to load a table with an invalid Spacecraft ID in the table file header.

Definition at line 1217 of file cfe\_error.h.

**10.10.2.81 CFE\_TBL\_ERR\_BAD\_SUBTYPE\_ID**

```
#define CFE_TBL_ERR_BAD_SUBTYPE_ID ((CFE_Status_t)0xcc00001B)
```

Bad Subtype ID.

The calling Application tried to access a table file whose Subtype identifier indicated it was not a table image file.

Definition at line 1081 of file cfe\_error.h.

**10.10.2.82 CFE\_TBL\_ERR\_DUMP\_ONLY**

```
#define CFE_TBL_ERR_DUMP_ONLY ((CFE_Status_t)0xcc000010)
```

Dump Only Error.

The calling Application has attempted to perform a load on a table that was created with "Dump Only" attributes.

Definition at line 992 of file cfe\_error.h.

**10.10.2.83 CFE\_TBL\_ERR\_DUPLICATE\_DIFF\_SIZE**

```
#define CFE_TBL_ERR_DUPLICATE_DIFF_SIZE ((CFE_Status_t)0xcc00000C)
```

Duplicate Table With Different Size.

An application attempted to register a table with the same name as a table that is already in the registry. The size of the new table is different from the size already in the registry.

Definition at line 953 of file cfe\_error.h.

**10.10.2.84 CFE\_TBL\_ERR\_DUPLICATE\_NOT OWNED**

```
#define CFE_TBL_ERR_DUPLICATE_NOT OWNED ((CFE_Status_t)0xcc00000D)
```

Duplicate Table And Not Owned.

An application attempted to register a table with the same name as a table that is already in the registry. The previously registered table is owned by a different application.

Definition at line 963 of file cfe\_error.h.

**10.10.2.85 CFE\_TBL\_ERR\_FILE\_FOR\_WRONG\_TABLE**

```
#define CFE_TBL_ERR_FILE_FOR_WRONG_TABLE ((CFE_Status_t)0xcc000020)
```

File For Wrong Table.

The calling Application tried to load a table using a file whose header indicated that it was for a different table.

Definition at line 1125 of file cfe\_error.h.

**10.10.2.86 CFE\_TBL\_ERR\_FILE\_SIZE\_INCONSISTENT**

```
#define CFE_TBL_ERR_FILE_SIZE_INCONSISTENT ((CFE_Status_t)0xcc00001C)
```

File Size Inconsistent.

The calling Application tried to access a table file whose Subtype identifier indicated it was not a table image file.

Definition at line 1090 of file cfe\_error.h.

**10.10.2.87 CFE\_TBL\_ERR\_FILE\_TOO\_LARGE**

```
#define CFE_TBL_ERR_FILE_TOO_LARGE ((CFE_Status_t)0xcc000014)
```

File Too Large.

The calling Application called [CFE\\_TBL\\_Load](#) with a filename that specified a file that contained more data than the size of the table OR which contained more data than specified in the table header.

Definition at line 1020 of file `cfe_error.h`.

**10.10.2.88 CFE\_TBL\_ERR\_FILENAME\_TOO\_LONG**

```
#define CFE_TBL_ERR_FILENAME_TOO_LONG ((CFE_Status_t)0xcc00001F)
```

Filename Too Long.

The calling Application tried to load a table using a filename that was too long.

Definition at line 1116 of file `cfe_error.h`.

**10.10.2.89 CFE\_TBL\_ERR\_HANDLES\_FULL**

```
#define CFE_TBL_ERR_HANDLES_FULL ((CFE_Status_t)0xcc00000B)
```

Handles Full.

An application attempted to create a table and the Table Handle Array already used all `CFE_PLATFORM_TBL_MAX_NUM_HANDLES` in it.

Definition at line 943 of file `cfe_error.h`.

**10.10.2.90 CFE\_TBL\_ERR\_ILLEGAL\_SRC\_TYPE**

```
#define CFE_TBL_ERR_ILLEGAL_SRC_TYPE ((CFE_Status_t)0xcc000011)
```

Illegal Source Type.

The calling Application called [CFE\\_TBL\\_Load](#) with an illegal value for the second parameter.

Definition at line 1001 of file `cfe_error.h`.

#### 10.10.2.91 CFE\_TBL\_ERR\_INVALID\_HANDLE

```
#define CFE_TBL_ERR_INVALID_HANDLE ((CFE_Status_t)0xcc000001)
```

Invalid Handle.

The calling Application attempted to pass a Table handle that represented too large an index or identified a Table Access Descriptor that was not used.

Definition at line 860 of file cfe\_error.h.

#### 10.10.2.92 CFE\_TBL\_ERR\_INVALID\_NAME

```
#define CFE_TBL_ERR_INVALID_NAME ((CFE_Status_t)0xcc000002)
```

Invalid Name.

The calling Application attempted to register a table whose name length exceeded the platform configuration value of [CFE\\_MISSION\\_TBL\\_MAX\\_NAME\\_LENGTH](#) or was zero characters long.

Definition at line 870 of file cfe\_error.h.

#### 10.10.2.93 CFE\_TBL\_ERR\_INVALID\_OPTIONS

```
#define CFE_TBL_ERR_INVALID_OPTIONS ((CFE_Status_t)0xcc000025)
```

Invalid Options.

The calling Application has used an illegal combination of table options. A summary of the illegal combinations are as follows:

**#CFE\_TBL\_OPT\_USR\_DEF\_ADDR** cannot be combined with any of the following:

1. [CFE\\_TBL\\_OPT\\_DBL\\_BUFFER](#)
2. [CFE\\_TBL\\_OPT\\_LOAD\\_DUMP](#)
3. [CFE\\_TBL\\_OPT\\_CRITICAL](#)

**#CFE\_TBL\_OPT\_DBL\_BUFFER** cannot be combined with the following:

1. [CFE\\_TBL\\_OPT\\_USR\\_DEF\\_ADDR](#)
2. [CFE\\_TBL\\_OPT\\_DUMP\\_ONLY](#)

Definition at line 1182 of file cfe\_error.h.

**10.10.2.94 CFE\_TBL\_ERR\_INVALID\_SIZE**

```
#define CFE_TBL_ERR_INVALID_SIZE ((CFE_Status_t)0xcc000003)
```

Invalid Size.

The calling Application attempted to register a table: a) that was a double buffered table with size greater than `CFE_PLATFORM_TBL_MAX_DBL_TABLE_SIZE` b) that was a single buffered table with size greater than `CFE_PLATFORM_TBL_MAX_SNGL_TABLE_SIZE` c) that had a size of zero

Definition at line 881 of file `cfe_error.h`.

**10.10.2.95 CFE\_TBL\_ERR\_LOAD\_IN\_PROGRESS**

```
#define CFE_TBL_ERR_LOAD_IN_PROGRESS ((CFE_Status_t)0xcc000012)
```

Load In Progress.

The calling Application called `CFE_TBL_Load` when another Application was trying to load the table.

Definition at line 1010 of file `cfe_error.h`.

**10.10.2.96 CFE\_TBL\_ERR\_LOAD\_INCOMPLETE**

```
#define CFE_TBL_ERR_LOAD_INCOMPLETE ((CFE_Status_t)0xcc000021)
```

Load Incomplete.

The calling Application tried to load a table file whose header claimed the load was larger than what was actually read from the file.

Definition at line 1134 of file `cfe_error.h`.

**10.10.2.97 CFE\_TBL\_ERR\_NEVER\_LOADED**

```
#define CFE_TBL_ERR_NEVER_LOADED ((CFE_Status_t)0xcc000005)
```

Never Loaded.

Table has not been loaded with data.

Definition at line 897 of file `cfe_error.h`.

Referenced by `DS_TableManageDestFile()`, and `DS_TableManageFilter()`.

#### 10.10.2.98 CFE\_TBL\_ERR\_NO\_ACCESS

```
#define CFE_TBL_ERR_NO_ACCESS ((CFE_Status_t)0xcc000008)
```

No Access.

The calling application either failed when calling [CFE\\_TBL\\_Register](#), failed when calling [CFE\\_TBL\\_Share](#) or forgot to call either one.

Definition at line 925 of file cfe\_error.h.

#### 10.10.2.99 CFE\_TBL\_ERR\_NO\_BUFFER\_AVAIL

```
#define CFE_TBL_ERR_NO_BUFFER_AVAIL ((CFE_Status_t)0xcc00000F)
```

No Buffer Available.

The calling Application has tried to allocate a working buffer but none were available.

Definition at line 983 of file cfe\_error.h.

#### 10.10.2.100 CFE\_TBL\_ERR\_NO\_STD\_HEADER

```
#define CFE_TBL_ERR_NO_STD_HEADER ((CFE_Status_t)0xcc00001D)
```

No Standard Header.

The calling Application tried to access a table file whose standard cFE File Header was the wrong size, etc.

Definition at line 1098 of file cfe\_error.h.

#### 10.10.2.101 CFE\_TBL\_ERR\_NO\_TBL\_HEADER

```
#define CFE_TBL_ERR_NO_TBL_HEADER ((CFE_Status_t)0xcc00001E)
```

No Table Header.

The calling Application tried to access a table file whose standard cFE Table File Header was the wrong size, etc.

Definition at line 1107 of file cfe\_error.h.

**10.10.2.102 CFE\_TBL\_ERR\_PARTIAL\_LOAD**

```
#define CFE_TBL_ERR_PARTIAL_LOAD ((CFE_Status_t)0xcc000023)
```

Partial Load Error.

The calling Application tried to load a table file whose header claimed the load did not start with the first byte and the table image had NEVER been loaded before. Partial loads are not allowed on uninitialized tables. It should be noted that [CFE\\_TBL\\_WARN\\_SHORT\\_FILE](#) also indicates a partial load.

Definition at line 1156 of file [cfe\\_error.h](#).

**10.10.2.103 CFE\_TBL\_ERR\_REGISTRY\_FULL**

```
#define CFE_TBL_ERR_REGISTRY_FULL ((CFE_Status_t)0xcc000006)
```

Registry Full.

An application attempted to create a table and the Table registry already contained [CFE\\_PLATFORM\\_TBL\\_MAX\\_NUM\\_TABLES](#) in it.

Definition at line 906 of file [cfe\\_error.h](#).

**10.10.2.104 CFE\_TBL\_ERR\_SHORT\_FILE**

```
#define CFE_TBL_ERR_SHORT_FILE ((CFE_Status_t)0xcc00002b)
```

Error code indicating that the TBL file is shorter than indicated in the file header.

Definition at line 1242 of file [cfe\\_error.h](#).

**10.10.2.105 CFE\_TBL\_ERR\_UNREGISTERED**

```
#define CFE_TBL_ERR_UNREGISTERED ((CFE_Status_t)0xcc000009)
```

Unregistered.

The calling application is trying to access a table that has been unregistered.

Definition at line 934 of file [cfe\\_error.h](#).

#### 10.10.2.106 CFE\_TBL\_INFO\_DUMP\_PENDING

```
#define CFE_TBL_INFO_DUMP_PENDING ((CFE_Status_t)0x4c000024)
```

Dump Pending.

The calling Application should call [CFE\\_TBL\\_Manage](#) for the specified table. The ground has requested a dump of the Dump-Only table and needs to synchronize with the owning application.

Definition at line 1166 of file cfe\_error.h.

Referenced by DS\_TableManageDestFile(), and DS\_TableManageFilter().

#### 10.10.2.107 CFE\_TBL\_INFO\_NO\_UPDATE\_PENDING

```
#define CFE_TBL_INFO_NO_UPDATE_PENDING ((CFE_Status_t)0x4c000017)
```

No Update Pending.

The calling Application has attempted to update a table without a pending load.

Definition at line 1048 of file cfe\_error.h.

#### 10.10.2.108 CFE\_TBL\_INFO\_NO\_VALIDATION\_PENDING

```
#define CFE_TBL_INFO_NO_VALIDATION_PENDING ((CFE_Status_t)0x4c00001A)
```

No Validation Pending

The calling Application tried to validate a table that did not have a validation request pending.

Definition at line 1072 of file cfe\_error.h.

#### 10.10.2.109 CFE\_TBL\_INFO\_RECOVERED\_TBL

```
#define CFE_TBL_INFO_RECOVERED_TBL ((CFE_Status_t)0x4c000027)
```

Recovered Table.

The calling Application registered a critical table whose previous contents were discovered in the Critical Data Store. The discovered contents were copied back into the newly registered table as the table's initial contents.

**NOTE:** In this situation, the contents of the table are **NOT** validated using the table's validation function.

Definition at line 1206 of file cfe\_error.h.

Referenced by DS\_TableInit().

**10.10.2.110 CFE\_TBL\_INFO\_TABLE\_LOCKED**

```
#define CFE_TBL_INFO_TABLE_LOCKED ((CFE_Status_t)0x4c000018)
```

Table Locked.

The calling Application tried to update a table that is locked by another user.

Definition at line 1056 of file cfe\_error.h.

**10.10.2.111 CFE\_TBL\_INFO\_UPDATE\_PENDING**

```
#define CFE_TBL_INFO_UPDATE_PENDING ((CFE_Status_t)0x4c000004)
```

Update Pending.

The calling Application has identified a table that has a load pending.

Definition at line 889 of file cfe\_error.h.

Referenced by DS\_TableManageDestFile(), and DS\_TableManageFilter().

**10.10.2.112 CFE\_TBL\_INFO\_UPDATED**

```
#define CFE_TBL_INFO_UPDATED ((CFE_Status_t)0x4c00000E)
```

Updated.

The calling Application has identified a table that has been updated.

**NOTE:** This is a nominal return code informing the calling application that the table identified in the call has had its contents updated since the last time the application obtained its address or status.

Definition at line 974 of file cfe\_error.h.

Referenced by DS\_TableManageDestFile(), and DS\_TableManageFilter().

**10.10.2.113 CFE\_TBL\_INFO\_VALIDATION\_PENDING**

```
#define CFE_TBL_INFO_VALIDATION_PENDING ((CFE_Status_t)0x4c000019)
```

Validation Pending

The calling Application should call [CFE\\_TBL\\_Validate](#) for the specified table.

Definition at line 1064 of file cfe\_error.h.

Referenced by DS\_TableManageDestFile(), and DS\_TableManageFilter().

#### 10.10.2.114 CFE\_TBL\_MESSAGE\_ERROR

```
#define CFE_TBL_MESSAGE_ERROR ((CFE_Status_t)0xcc00002a)
```

Message Error.

Error code indicating that the TBL command was not processed successfully and that the error counter should be incremented.

Definition at line 1236 of file cfe\_error.h.

#### 10.10.2.115 CFE\_TBL\_NOT\_IMPLEMENTED

```
#define CFE_TBL_NOT_IMPLEMENTED ((CFE_Status_t)0xcc00ffff)
```

Not Implemented.

Current version of cFE does not have the function or the feature of the function implemented. This could be due to either an early build of the cFE for this platform or the platform does not support the specified feature.

Definition at line 1268 of file cfe\_error.h.

#### 10.10.2.116 CFE\_TBL\_WARN\_DUPLICATE

```
#define CFE_TBL_WARN_DUPLICATE ((CFE_Status_t)0x4c000007)
```

Duplicate Warning.

This is an error that the registration is trying to replace an existing table with the same name. The previous table stays in place and the new table is rejected.

Definition at line 916 of file cfe\_error.h.

#### 10.10.2.117 CFE\_TBL\_WARN\_NOT\_CRITICAL

```
#define CFE_TBL_WARN_NOT_CRITICAL ((CFE_Status_t)0x4c000026)
```

Not Critical Warning.

The calling Application attempted to register a table as "Critical". Table Services failed to create an appropriate Critical Data Store (See System Log for reason) to save the table contents. The table will be treated as a normal table from now on.

Definition at line 1193 of file cfe\_error.h.

**10.10.2.118 CFE\_TBL\_WARN\_PARTIAL\_LOAD**

```
#define CFE_TBL_WARN_PARTIAL_LOAD ((CFE_Status_t)0x4c000022)
```

Partial Load Warning.

The calling Application tried to load a table file whose header claimed the load did not start with the first byte. It should be noted that [CFE\\_TBL\\_WARN\\_SHORT\\_FILE](#) also indicates a partial load.

Definition at line 1144 of file `cfe_error.h`.

**10.10.2.119 CFE\_TBL\_WARN\_SHORT\_FILE**

```
#define CFE_TBL_WARN_SHORT_FILE ((CFE_Status_t)0x4c000015)
```

Short File Warning.

The calling Application called [CFE\\_TBL\\_Load](#) with a filename that specified a file that started with the first byte of the table but contained less data than the size of the table. It should be noted that [CFE\\_TBL\\_WARN\\_PARTIAL\\_LOAD](#) also indicates a partial load (one that starts at a non-zero offset).

Definition at line 1031 of file `cfe_error.h`.

**10.10.2.120 CFE\_TIME\_BAD\_ARGUMENT**

```
#define CFE_TIME_BAD_ARGUMENT ((CFE_Status_t)0xce000005)
```

Bad Argument.

A parameter given by a caller to a TIME Services API did not pass validation checks.

Definition at line 1340 of file `cfe_error.h`.

**10.10.2.121 CFE\_TIME\_CALLBACK\_NOT\_REGISTERED**

```
#define CFE_TIME_CALLBACK_NOT_REGISTERED ((CFE_Status_t)0xce000004)
```

Callback Not Registered.

An attempt to unregister a cFE Time Services Synchronization callback has failed because the specified callback function was not located in the Synchronization Callback Registry.

Definition at line 1331 of file `cfe_error.h`.

#### 10.10.2.122 CFE\_TIME\_INTERNAL\_ONLY

```
#define CFE_TIME_INTERNAL_ONLY ((CFE_Status_t)0xce000001)
```

Internal Only.

One of the TIME Services API functions to set the time with data from an external time source has been called, but TIME Services has been commanded to not accept external time data. However, the command is still a signal for the Time Server to generate a "time at the tone" command packet using internal data.

Definition at line 1295 of file cfe\_error.h.

#### 10.10.2.123 CFE\_TIME\_NOT\_IMPLEMENTED

```
#define CFE_TIME_NOT_IMPLEMENTED ((CFE_Status_t)0xce00ffff)
```

Not Implemented.

Current version of cFE does not have the function or the feature of the function implemented. This could be due to either an early build of the cFE for this platform or the platform does not support the specified feature.

Definition at line 1283 of file cfe\_error.h.

#### 10.10.2.124 CFE\_TIME\_OUT\_OF\_RANGE

```
#define CFE_TIME_OUT_OF_RANGE ((CFE_Status_t)0xce000002)
```

Out Of Range.

One of the TIME Services API functions to set the time with data from an external time source has been called, but TIME Services has determined that the new time data is invalid. However, the command is still a signal for the Time Server to generate a "time at the tone" command packet using internal data.

Note that the test for invalid time update data only occurs if TIME Services has previously been commanded to set the clock state to "valid".

Definition at line 1310 of file cfe\_error.h.

#### 10.10.2.125 CFE\_TIME\_TOO\_MANY\_SYNCH\_CALLBACKS

```
#define CFE_TIME_TOO_MANY_SYNCH_CALLBACKS ((CFE_Status_t)0xce000003)
```

Too Many Sync Callbacks.

An attempt to register too many cFE Time Services Synchronization callbacks has been made. Only one callback function is allowed per application. It is expected that the application itself will distribute the single callback to child threads as needed.

Definition at line 1321 of file cfe\_error.h.

## 10.11 cFE Resource ID APIs

### Functions

- `CFE_Status_t CFE_ES_AppID_ToIndex (CFE_ES_AppId_t AppID, uint32 *Idx)`  
*Obtain an index value correlating to an ES Application ID.*
- `int32 CFE_ES_LibID_ToIndex (CFE_ES_LibId_t LibId, uint32 *Idx)`  
*Obtain an index value correlating to an ES Library ID.*
- `CFE_Status_t CFE_ES_TaskID_ToIndex (CFE_ES_TaskId_t TaskID, uint32 *Idx)`  
*Obtain an index value correlating to an ES Task ID.*
- `CFE_Status_t CFE_ES_CounterID_ToIndex (CFE_ES_CounterId_t CounterId, uint32 *Idx)`  
*Obtain an index value correlating to an ES Counter ID.*

#### 10.11.1 Detailed Description

#### 10.11.2 Function Documentation

##### 10.11.2.1 CFE\_ES\_AppID\_ToIndex()

```
CFE_Status_t CFE_ES_AppID_ToIndex (
    CFE_ES_AppId_t AppID,
    uint32 * Idx )
```

Obtain an index value correlating to an ES Application ID.

This calculates a zero based integer value that may be used for indexing into a local resource table/array.

Index values are only guaranteed to be unique for resources of the same type. For instance, the indices corresponding to two [valid] application IDs will never overlap, but the index of an application and a library ID may be the same. Furthermore, indices may be reused if a resource is deleted and re-created.

#### Note

There is no inverse of this function - indices cannot be converted back to the original AppID value. The caller should retain the original ID for future use.

#### Parameters

in	<i>AppID</i>	Application ID to convert
out	<i>Idx</i>	Buffer where the calculated index will be stored (must not be null)

#### Returns

Execution status, see [cFE Return Code Defines](#)

### Return values

<code>CFE_SUCCESS</code>	Successful execution.
<code>CFE_ES_ERR_RESOURCEID_NOT_VALID</code>	Resource ID is not valid.

### 10.11.2.2 CFE\_ES\_CounterID\_ToIndex()

```
CFE_Status_t CFE_ES_CounterID_ToIndex (
    CFE_ES_CounterId_t CounterId,
    uint32 * Idx )
```

Obtain an index value correlating to an ES Counter ID.

This calculates a zero based integer value that may be used for indexing into a local resource table/array.

Index values are only guaranteed to be unique for resources of the same type. For instance, the indices corresponding to two [valid] Counter IDs will never overlap, but the index of a Counter and a library ID may be the same. Furthermore, indices may be reused if a resource is deleted and re-created.

### Note

There is no inverse of this function - indices cannot be converted back to the original CounterID value. The caller should retain the original ID for future use.

### Parameters

in	<i>Counter</i> <i>Id</i>	Counter ID to convert
out	<i>Idx</i>	Buffer where the calculated index will be stored (must not be null)

### Returns

Execution status, see [cFE Return Code Defines](#)

### Return values

<code>CFE_SUCCESS</code>	Successful execution.
<code>CFE_ES_ERR_RESOURCEID_NOT_VALID</code>	Resource ID is not valid.

### 10.11.2.3 CFE\_ES\_LibID\_ToIndex()

```
int32 CFE_ES_LibID_ToIndex (
    CFE_ES_LibId_t LibId,
    uint32 * Idx )
```

Obtain an index value correlating to an ES Library ID.

This calculates a zero based integer value that may be used for indexing into a local resource table/array.

Index values are only guaranteed to be unique for resources of the same type. For instance, the indices corresponding to two [valid] Library IDs will never overlap, but the index of an Library and a library ID may be the same. Furthermore, indices may be reused if a resource is deleted and re-created.

#### Note

There is no inverse of this function - indices cannot be converted back to the original LibID value. The caller should retain the original ID for future use.

#### Parameters

in	<i>Lib</i> ↔ <i>Id</i>	Library ID to convert
out	<i>Idx</i>	Buffer where the calculated index will be stored (must not be null)

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_ES_ERR_RESOURCEID_NOT_VALID</i>	Resource ID is not valid.

#### 10.11.2.4 CFE\_ES\_TaskID\_ToIndex()

```
CFE_Status_t CFE_ES_TaskID_ToIndex (
    CFE_ES_TaskId_t TaskID,
    uint32 * Idx )
```

Obtain an index value correlating to an ES Task ID.

This calculates a zero based integer value that may be used for indexing into a local resource table/array.

Index values are only guaranteed to be unique for resources of the same type. For instance, the indices corresponding to two [valid] Task IDs will never overlap, but the index of a Task and a library ID may be the same. Furthermore, indices may be reused if a resource is deleted and re-created.

#### Note

There is no inverse of this function - indices cannot be converted back to the original TaskID value. The caller should retain the original ID for future use.

**Parameters**

in	<i>TaskID</i>	Task ID to convert
out	<i>Idx</i>	Buffer where the calculated index will be stored (must not be null)

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_ES_ERR_RESOURCEID_NOT_VALID</i>	Resource ID is not valid.
<i>CFE_ES_BAD_ARGUMENT</i>	Bad Argument.

## 10.12 cFE Entry/Exit APIs

### Functions

- void [CFE\\_ES\\_Main](#) ([uint32](#) StartType, [uint32](#) StartSubtype, [uint32](#) ModelId, const char \*StartFilePath)  
*cFE Main Entry Point used by Board Support Package to start cFE*
- [CFE\\_Status\\_t CFE\\_ES\\_ResetCFE](#) ([uint32](#) ResetType)  
*Reset the cFE Core and all cFE Applications.*

### 10.12.1 Detailed Description

### 10.12.2 Function Documentation

#### 10.12.2.1 CFE\_ES\_Main()

```
void CFE_ES_Main (
    uint32 StartType,
    uint32 StartSubtype,
    uint32 ModelId,
    const char * StartFilePath )
```

cFE Main Entry Point used by Board Support Package to start cFE

#### Description

cFE main entry point. This is the entry point into the cFE software. It is called only by the Board Support Package software.

#### Assumptions, External Events, and Notes:

None

#### Parameters

in	<i>StartType</i>	Identifies whether this was a <a href="#">CFE_PSP_RST_TYPE_POWERON</a> or <a href="#">CFE_PSP_RST_TYPE_PROCESSOR</a> .
in	<i>StartSubtype</i>	Specifies, in more detail, what caused the <i>StartType</i> identified above. See <a href="#">CFE_PSP_RST_SUBTYPE_POWER_CYCLE</a> for possible examples.
in	<i>ModelId</i>	Identifies the source of the Boot as determined by the BSP.
in	<i>StartFilePath</i>	Identifies the startup file to use to initialize the cFE apps.

#### See also

[CFE\\_ES\\_ResetCFE](#)

### 10.12.2.2 CFE\_ES\_ResetCFE()

```
CFE_Status_t CFE_ES_ResetCFE (
    uint32 ResetType )
```

Reset the cFE Core and all cFE Applications.

#### Description

This API causes an immediate reset of the cFE Kernel and all cFE Applications. The caller can specify whether the reset should clear all memory ([CFE\\_PSP\\_RST\\_TYPE\\_POWERON](#)) or try to retain volatile memory areas ([CFE\\_PSP\\_RST\\_TYPE\\_PROCESSOR](#)).

#### Assumptions, External Events, and Notes:

None

#### Parameters

in	<i>ResetType</i>	Identifies the type of reset desired. Allowable settings are: <ul style="list-style-type: none"><li>• <a href="#">CFE_PSP_RST_TYPE_POWERON</a> - Causes all memory to be cleared</li><li>• <a href="#">CFE_PSP_RST_TYPE_PROCESSOR</a> - Attempts to retain volatile disk, critical data store and user reserved memory.</li></ul>
----	------------------	---

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.
<a href="#">CFE_ES_NOT_IMPLEMENTED</a>	Not Implemented.

#### See also

[CFE\\_ES\\_Main](#)

## 10.13 cFE Application Control APIs

### Functions

- `CFE_Status_t CFE_ES_RestartApp (CFE_ES_AppId_t AppID)`  
*Restart a single cFE Application.*
- `CFE_Status_t CFE_ES_ReloadApp (CFE_ES_AppId_t AppID, const char *AppFileName)`  
*Reload a single cFE Application.*
- `CFE_Status_t CFE_ES_DeleteApp (CFE_ES_AppId_t AppID)`  
*Delete a cFE Application.*

### 10.13.1 Detailed Description

### 10.13.2 Function Documentation

#### 10.13.2.1 `CFE_ES_DeleteApp()`

```
CFE_Status_t CFE_ES_DeleteApp (
    CFE_ES_AppId_t AppID )
```

Delete a cFE Application.

#### Description

This API causes a cFE Application to be stopped deleted.

#### Assumptions, External Events, and Notes:

None

#### Parameters

in	<code>AppID</code>	Identifies the application to be reset.
----	--------------------	---

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<code>CFE_ES_ERR_RESOURCEID_NOT_VALID</code>	Resource ID is not valid.
<code>CFE_SUCCESS</code>	Successful execution.

**See also**

[CFE\\_ES\\_RestartApp](#), [CFE\\_ES\\_ReloadApp](#)

**10.13.2.2 CFE\_ES\_ReloadApp()**

```
CFE_Status_t CFE_ES_ReloadApp (
    CFE_ES_AppId_t AppID,
    const char * AppFileName )
```

Reload a single cFE Application.

**Description**

This API causes a cFE Application to be stopped and restarted from the specified file.

**Assumptions, External Events, and Notes:**

The filename is checked for existence prior to load. A missing file will be reported and the reload operation will be aborted prior to unloading the app.

Goes through the standard CFE\_ES\_CleanUpApp which unloads, then attempts a load using the specified file name.

In the event that an application cannot be reloaded due to a corrupt file, the application may no longer be reloaded when given a valid load file (it has been deleted and no longer exists). To recover, the application may be started by loading the application via the ES\_STARTAPP command ([CFE\\_ES\\_START\\_APP\\_CC](#)).

**Parameters**

in	<i>AppID</i>	Identifies the application to be reset.
in	<i>AppFileName</i>	Identifies the new file to start (must not be null)

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_FILE_IO_ERR</a>	File IO Error.

**See also**

[CFE\\_ES\\_RestartApp](#), [CFE\\_ES\\_DeleteApp](#), [CFE\\_ES\\_START\\_APP\\_CC](#)

### 10.13.2.3 CFE\_ES\_RestartApp()

```
CFE_Status_t CFE_ES_RestartApp (
    CFE_ES_AppId_t AppID )
```

Restart a single cFE Application.

#### Description

This API causes a cFE Application to be unloaded and restarted from the same file name as the last start.

#### Assumptions, External Events, and Notes:

The filename is checked for existence prior to load. A missing file will be reported and the reload operation will be aborted prior to unloading the app.

Goes through the standard CFE\_ES\_CleanUpApp which unloads, then attempts a load using the original file name.

In the event that an application cannot be reloaded due to a missing file or any other load issue, the application may no longer be restarted or reloaded when given a valid load file (the app has been deleted and no longer exists). To recover, the application may be started by loading the application via the ES\_STARTAPP command ([CFE\\_ES\\_START\\_APP\\_CC](#)).

#### Parameters

in	AppID	Identifies the application to be reset.
----	-------	---

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_ES_FILE_IO_ERR</a>	File IO Error.
<a href="#">CFE_SUCCESS</a>	Successful execution.

#### See also

[CFE\\_ES\\_ReloadApp](#), [CFE\\_ES\\_DeleteApp](#)

## 10.14 cFE Application Behavior APIs

### Functions

- void [CFE\\_ES\\_ExitApp](#) (uint32 ExitStatus)  
*Exit a cFE Application.*
- bool [CFE\\_ES\\_RunLoop](#) (uint32 \*RunStatus)  
*Check for Exit, Restart, or Reload commands.*
- [CFE\\_Status\\_t CFE\\_ES\\_WaitForSystemState](#) (uint32 MinSystemState, uint32 TimeOutMilliseconds)  
*Allow an Application to Wait for a minimum global system state.*
- void [CFE\\_ES\\_WaitForStartupSync](#) (uint32 TimeOutMilliseconds)  
*Allow an Application to Wait for the "OPERATIONAL" global system state.*
- void [CFE\\_ES\\_IncrementTaskCounter](#) (void)  
*Increments the execution counter for the calling task.*

### 10.14.1 Detailed Description

### 10.14.2 Function Documentation

#### 10.14.2.1 CFE\_ES\_ExitApp()

```
void CFE_ES_ExitApp (
    uint32 ExitStatus )
```

Exit a cFE Application.

#### Description

This API is the "Exit Point" for the cFE application

#### Assumptions, External Events, and Notes:

None

**Parameters**

in	<i>ExitStatus</i>	Acceptable values are: <ul style="list-style-type: none"><li>• <a href="#">CFE_ES_RunStatus_APP_EXIT</a> - Indicates that the Application wants to exit normally.</li><li>• <a href="#">CFE_ES_RunStatus_APP_ERROR</a> - Indicates that the Application is quitting with an error.</li><li>• <a href="#">CFE_ES_RunStatus_CORE_APP_INIT_ERROR</a> - Indicates that the Core Application could not Init.</li><li>• <a href="#">CFE_ES_RunStatus_CORE_APP_RUNTIME_ERROR</a> - Indicates that the Core Application had a runtime failure.</li></ul>
----	-------------------	--

**See also**[CFE\\_ES\\_RunLoop](#)

Referenced by DS\_AppMain().

**10.14.2.2 CFE\_ES\_IncrementTaskCounter()**

```
void CFE_ES_IncrementTaskCounter (
    void )
```

Increments the execution counter for the calling task.

**Description**

This routine increments the execution counter that is stored for the calling task. It can be called from cFE Application main tasks, child tasks, or cFE Core application main tasks. Normally, the call is not necessary from a cFE Application, since the CFE\_ES\_RunLoop call increments the counter for the Application.

**Assumptions, External Events, and Notes:**

NOTE: This API is not needed for Applications that call the CFE\_ES\_RunLoop call.

**See also**[CFE\\_ES\\_RunLoop](#)

### 10.14.2.3 CFE\_ES\_RunLoop()

```
bool CFE_ES_RunLoop (
    uint32 * RunStatus )
```

Check for Exit, Restart, or Reload commands.

#### Description

This is the API that allows an app to check for exit requests from the system, or request shutdown from the system.

#### Assumptions, External Events, and Notes:

This API updates the internal task counter tracked by ES for the calling task. For ES to report application counters correctly this API should be called from the main app task as part of it's main processing loop.

In the event of a externally initiated app shutdown request (such as the APP\_STOP, APP\_RELOAD, and APP\_RESET commands) or if a system error occurs requiring the app to be shut down administratively, this function returns "false" and optionally sets the "RunStatus" output to further indicate the specific application state.

If "RunStatus" is passed as non-NULL, it should point to a local status variable containing the requested status to ES. Normally, this should be initialized to [CFE\\_ES\\_RunStatus\\_APP\\_RUN](#) during application start up, and should remain as this value during normal operation.

If "RunStatus" is set to [CFE\\_ES\\_RunStatus\\_APP\\_EXIT](#) or [CFE\\_ES\\_RunStatus\\_APP\\_ERROR](#) on input, this acts as a shutdown request - [CFE\\_ES\\_RunLoop\(\)](#) function will return "false", and a shutdown will be initiated similar to if ES had been externally commanded to shut down the app.

If "RunStatus" is not used, it should be passed as NULL. In this mode, only the boolean return value is relevant, which will indicate if an externally-initiated shutdown request is pending.

#### Parameters

<i>in, out</i>	<i>RunStatus</i>	Optional pointer to a variable containing the desired run status
----------------	------------------	--

#### Returns

Boolean indicating application should continue running

#### Return values

<i>true</i>	Application should continue running
<i>false</i>	Application should not continue running

#### See also

[CFE\\_ES\\_ExitApp](#)

Referenced by DS\_AppMain().

#### 10.14.2.4 CFE\_ES\_WaitForStartupSync()

```
void CFE_ES_WaitForStartupSync (
    uint32 TimeOutMilliseconds )
```

Allow an Application to Wait for the "OPERATIONAL" global system state.

##### Description

This is the API that allows an app to wait for the rest of the apps to complete their entire initialization before continuing. It is most useful for applications such as Health and Safety or the Scheduler that need to wait until applications exist and are running before sending out packets to them.

This is a specialized wrapper for CFE\_ES\_WaitForSystemState for compatibility with applications using this API.

##### Assumptions, External Events, and Notes:

This API should only be called as the last item of an Apps initialization. In addition, this API should only be called by an App that is started from the ES Startup file. It should not be used by an App that is started after the system is running. ( Although it will cause no harm )

##### Parameters

in	TimeOutMilliseconds	The timeout value in Milliseconds. This parameter must be at least 1000. Lower values will be rounded up. There is not an option to wait indefinitely to avoid hanging a critical application because a non-critical app did not start.
----	---------------------	---

##### See also

[CFE\\_ES\\_RunLoop](#)

#### 10.14.2.5 CFE\_ES\_WaitForSystemState()

```
CFE_Status_t CFE_ES_WaitForSystemState (
    uint32 MinSystemState,
    uint32 TimeOutMilliseconds )
```

Allow an Application to Wait for a minimum global system state.

##### Description

This is the API that allows an app to wait for the rest of the apps to complete a given stage of initialization before continuing.

This gives finer grained control than [CFE\\_ES\\_WaitForStartupSync](#)

**Assumptions, External Events, and Notes:**

This API assumes that the caller has also been initialized sufficiently to satisfy the global system state it is waiting for, and the apps own state will be updated accordingly.

**Parameters**

in	<i>MinSystemState</i>	Determine the state of the App
in	<i>TimeOutMilliseconds</i>	The timeout value in Milliseconds. There is not an option to wait indefinitely to avoid hanging a critical application because a non-critical app did not start.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	State successfully achieved
<a href="#">CFE_ES_OPERATION_TIMED_OUT</a>	(return value only verified in coverage test) Timeout was reached

**See also**

[CFE\\_ES\\_RunLoop](#)

## 10.15 cFE Information APIs

### Functions

- `int32 CFE_ES_GetResetType (uint32 *ResetSubtypePtr)`  
*Return the most recent Reset Type.*
- `CFE_Status_t CFE_ES_GetAppID (CFE_ES_AppId_t *AppIdPtr)`  
*Get an Application ID for the calling Application.*
- `CFE_Status_t CFE_ES_GetTaskID (CFE_ES_TaskId_t *TaskIdPtr)`  
*Get the task ID of the calling context.*
- `CFE_Status_t CFE_ES_GetAppIDByName (CFE_ES_AppId_t *AppIdPtr, const char *AppName)`  
*Get an Application ID associated with a specified Application name.*
- `CFE_Status_t CFE_ES_GetLibIDByName (CFE_ES_LibId_t *LibIdPtr, const char *LibName)`  
*Get a Library ID associated with a specified Library name.*
- `CFE_Status_t CFE_ES_GetAppName (char *AppName, CFE_ES_AppId_t AppId, size_t BufferLength)`  
*Get an Application name for a specified Application ID.*
- `CFE_Status_t CFE_ES_GetLibName (char *LibName, CFE_ES_LibId_t LibId, size_t BufferLength)`  
*Get a Library name for a specified Library ID.*
- `CFE_Status_t CFE_ES_GetAppInfo (CFE_ES_AppInfo_t *AppInfo, CFE_ES_AppId_t AppId)`  
*Get Application Information given a specified App ID.*
- `CFE_Status_t CFE_ES_GetTaskInfo (CFE_ES_TaskInfo_t *TaskInfo, CFE_ES_TaskId_t TaskId)`  
*Get Task Information given a specified Task ID.*
- `int32 CFE_ES_GetLibInfo (CFE_ES_AppInfo_t *LibInfo, CFE_ES_LibId_t LibId)`  
*Get Library Information given a specified Resource ID.*
- `int32 CFE_ES_GetModuleInfo (CFE_ES_AppInfo_t *ModuleInfo, CFE_Resourceld_t Resourceld)`  
*Get Information given a specified Resource ID.*

### 10.15.1 Detailed Description

### 10.15.2 Function Documentation

#### 10.15.2.1 CFE\_ES\_GetAppID()

```
CFE_Status_t CFE_ES_GetAppID (
    CFE_ES_AppId_t * AppIdPtr )
```

Get an Application ID for the calling Application.

##### Description

This routine retrieves the cFE Application ID for the calling Application.

##### Assumptions, External Events, and Notes:

NOTE: **All** tasks associated with the Application would return the same Application ID.

**Parameters**

<b>out</b>	<i>AppIdPtr</i>	Pointer to variable that is to receive the Application's ID (must not be null). *AppIdPtr will be set to the application ID of the calling Application.
------------	-----------------	---

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_ES_ERR_RESOURCEID_NOT_VALID</i>	Resource ID is not valid.
<i>CFE_ES_BAD_ARGUMENT</i>	Bad Argument.

**See also**

[CFE\\_ES\\_GetResetType](#), [CFE\\_ES\\_GetAppIDByName](#), [CFE\\_ES\\_GetAppName](#), [CFE\\_ES\\_GetTaskInfo](#)

**10.15.2.2 CFE\_ES\_GetAppIDByName()**

```
CFE_Status_t CFE_ES_GetAppIDByName (
    CFE_ES_AppId_t * AppIdPtr,
    const char * AppName )
```

Get an Application ID associated with a specified Application name.

**Description**

This routine retrieves the cFE Application ID associated with a specified Application name.

**Assumptions, External Events, and Notes:**

None

**Parameters**

<b>out</b>	<i>AppIdPtr</i>	Pointer to variable that is to receive the Application's ID (must not be null).
<b>in</b>	<i>AppName</i>	Pointer to null terminated character string containing an Application name (must not be null).

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#"><i>CFE_SUCCESS</i></a>	Successful execution.
<a href="#"><i>CFE_ES_ERR_NAME_NOT_FOUND</i></a>	Resource Name Error.
<a href="#"><i>CFE_ES_BAD_ARGUMENT</i></a>	Bad Argument.

**See also**

[CFE\\_ES\\_GetAppID](#), [CFE\\_ES\\_GetAppName](#), [CFE\\_ES\\_GetAppInfo](#)

**10.15.2.3 CFE\_ES\_GetAppInfo()**

```
CFE_Status_t CFE_ES_GetAppInfo (
    CFE_ES_AppInfo_t * AppInfo,
    CFE_ES_AppId_t AppId )
```

Get Application Information given a specified App ID.

**Description**

This routine retrieves the information about an App associated with a specified App ID. The information includes all of the information ES maintains for an application ( documented in the `CFE_ES_AppInfo_t` type )

**Assumptions, External Events, and Notes:**

None

**Parameters**

<code>out</code>	<code>AppInfo</code>	Pointer to a structure (must not be null) that will be filled with resource name and memory addresses information.
<code>in</code>	<code>AppId</code>	ID of application to obtain information about

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#"><i>CFE_SUCCESS</i></a>	Successful execution.
<a href="#"><i>CFE_ES_ERR_RESOURCEID_NOT_VALID</i></a>	Resource ID is not valid.
<a href="#"><i>CFE_ES_BAD_ARGUMENT</i></a>	Bad Argument.

**See also**

[CFE\\_ES\\_GetAppID](#), [CFE\\_ES\\_GetAppIDByName](#), [CFE\\_ES\\_GetAppName](#)

**10.15.2.4 CFE\_ES\_GetAppName()**

```
CFE_Status_t CFE_ES_GetAppName (
    char * AppName,
    CFE_ES_AppId_t AppId,
    size_t BufferLength )
```

Get an Application name for a specified Application ID.

**Description**

This routine retrieves the cFE Application name associated with a specified Application ID.

**Assumptions, External Events, and Notes:**

In the case of a failure ([CFE\\_ES\\_ERR\\_RESOURCEID\\_NOT\\_VALID](#)), an empty string is returned.

**Parameters**

out	<i>AppName</i>	Pointer to a character array (must not be null) of at least <i>BufferLength</i> in size that will be filled with the appropriate Application name.
in	<i>AppId</i>	Application ID of Application whose name is being requested.
in	<i>BufferLength</i>	The maximum number of characters, including the null terminator, that can be put into the <i>AppName</i> buffer. This routine will truncate the name to this length, if necessary.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.

**See also**

[CFE\\_ES\\_GetAppID](#), [CFE\\_ES\\_GetAppIDByName](#), [CFE\\_ES\\_GetAppInfo](#)

### 10.15.2.5 CFE\_ES\_GetLibIDByName()

```
CFE_Status_t CFE_ES_GetLibIDByName (
    CFE_ES_LibId_t * LibIdPtr,
    const char * LibName )
```

Get a Library ID associated with a specified Library name.

#### Description

This routine retrieves the cFE Library ID associated with a specified Library name.

#### Assumptions, External Events, and Notes:

None

#### Parameters

out	<i>LibIdPtr</i>	Pointer to variable that is to receive the Library's ID (must not be null).
in	<i>LibName</i>	Pointer to null terminated character string containing a Library name (must not be null).

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_ERR_NAME_NOT_FOUND</a>	Resource Name Error.
<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.

#### See also

[CFE\\_ES\\_GetLibName](#)

### 10.15.2.6 CFE\_ES\_GetLibInfo()

```
int32 CFE_ES_GetLibInfo (
    CFE_ES_AppInfo_t * LibInfo,
    CFE_ES_LibId_t LibId )
```

Get Library Information given a specified Resource ID.

#### Description

This routine retrieves the information about a Library associated with a specified ID. The information includes all of the information ES maintains for this resource type ( documented in the CFE\_ES\_AppInfo\_t type ).

This shares the same output structure as CFE\_ES\_GetAppInfo, such that informational commands can be executed against either applications or libraries. When applied to a library, the task information in the structure will be omitted, as libraries do not have tasks associated.

#### Assumptions, External Events, and Notes:

None

#### Parameters

<code>out</code>	<code>LibInfo</code>	Pointer to a structure (must not be null) that will be filled with resource name and memory addresses information.
<code>in</code>	<code>LibId</code>	ID of application to obtain information about

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<code>CFE_SUCCESS</code>	Successful execution.
<code>CFE_ES_ERR_RESOURCEID_NOT_VALID</code>	Resource ID is not valid.
<code>CFE_ES_BAD_ARGUMENT</code>	Bad Argument.

#### See also

[CFE\\_ES\\_GetLibIDByName](#), [CFE\\_ES\\_GetLibName](#)

#### 10.15.2.7 CFE\_ES\_GetLibName()

```
CFE_Status_t CFE_ES_GetLibName (
    char * LibName,
    CFE_ES_LibId_t LibId,
    size_t BufferLength )
```

Get a Library name for a specified Library ID.

#### Description

This routine retrieves the cFE Library name associated with a specified Library ID.

#### Assumptions, External Events, and Notes:

In the case of a failure ([CFE\\_ES\\_ERR\\_RESOURCEID\\_NOT\\_VALID](#)), an empty string is returned.

**Parameters**

<i>out</i>	<i>LibName</i>	Pointer to a character array (must not be null) of at least <i>BufferLength</i> in size that will be filled with the Library name.
<i>in</i>	<i>LibId</i>	Library ID of Library whose name is being requested.
<i>in</i>	<i>BufferLength</i>	The maximum number of characters (must not be zero), including the null terminator, that can be put into the <i>LibName</i> buffer. This routine will truncate the name to this length, if necessary.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_ES_ERR_RESOURCEID_NOT_VALID</i>	Resource ID is not valid.
<i>CFE_ES_BAD_ARGUMENT</i>	Bad Argument.

**See also**

[CFE\\_ES\\_GetLibIDByName](#)

**10.15.2.8 CFE\_ES\_GetModuleInfo()**

```
int32 CFE_ES_GetModuleInfo (
    CFE_ES_AppInfo_t * ModuleInfo,
    CFE_ResourceId_t ResourceId )
```

Get Information given a specified Resource ID.

**Description**

This routine retrieves the information about an Application or Library associated with a specified ID.

This is a wrapper API that in turn calls either CFE\_ES\_GetAppInfo or CFE\_ES\_GetLibInfo if passed an AppId or LibId, respectively.

This allows commands originally targeted to operate on AppIDs to be easily ported to operate on either Libraries or Applications, where relevant.

**Assumptions, External Events, and Notes:**

None

**Parameters**

<b>out</b>	<i>ModuleInfo</i>	Pointer to a structure (must not be null) that will be filled with resource name and memory addresses information.
<b>in</b>	<i>Resource← Id</i>	ID of application or library to obtain information about

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_ES_ERR_RESOURCEID_NOT_VALID</i>	Resource ID is not valid.
<i>CFE_ES_BAD_ARGUMENT</i>	Bad Argument.

**See also**

[CFE\\_ES\\_GetLibInfo](#), [CFE\\_ES\\_GetApplInfo](#)

**10.15.2.9 CFE\_ES\_GetResetType()**

```
int32 CFE_ES_GetResetType (
    uint32 * ResetSubtypePtr )
```

Return the most recent Reset Type.

**Description**

Provides the caller with codes that identifies the type of Reset the processor most recently underwent. The caller can also obtain information on what caused the reset by supplying a pointer to a variable that will be filled with the Reset Sub-Type.

**Assumptions, External Events, and Notes:**

None

**Parameters**

<b>in, out</b>	<i>ResetSubtypePtr</i>	Pointer to <code>uint32</code> type variable in which the Reset Sub-Type will be stored. The caller can set this pointer to NULL if the Sub-Type is of no interest. <i>ResetSubtypePtr</i> If the provided pointer was not NULL, the Reset Sub-Type is stored at the given address. For a list of possible Sub-Type values, see " <a href="#">Reset Sub-Types</a> ".
----------------	------------------------	---

**Returns**

Processor reset type

**Return values**

<code>CFE_PSP_RST_TYPE_POWERON</code>	
<code>CFE_PSP_RST_TYPE_PROCESSOR</code>	

**See also**

[CFE\\_ES\\_GetAppID](#), [CFE\\_ES\\_GetAppIDByName](#), [CFE\\_ES\\_GetAppName](#), [CFE\\_ES\\_GetTaskInfo](#)

### 10.15.2.10 CFE\_ES\_GetTaskID()

```
CFE_Status_t CFE_ES_GetTaskID (
    CFE_ES_TaskId_t * TaskIdPtr )
```

Get the task ID of the calling context.

**Description**

This retrieves the current task context from OSAL

**Assumptions, External Events, and Notes:**

Applications which desire to call other CFE ES services such as `CFE_ES_TaskGetInfo()` should use this API rather than getting the ID from OSAL directly via `OS_TaskGetId()`.

**Parameters**

<code>out</code>	<code>TaskIdPtr</code>	Pointer to variable that is to receive the ID (must not be null). Will be set to the ID of the calling task.
------------------	------------------------	--

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<code>CFE_SUCCESS</code>	Successful execution.
<code>CFE_ES_ERR_RESOURCEID_NOT_VALID</code>	Resource ID is not valid.
<code>CFE_ES_BAD_ARGUMENT</code>	Bad Argument.

### 10.15.2.11 CFE\_ES\_GetTaskInfo()

```
CFE_Status_t CFE_ES_GetTaskInfo (
    CFE_ES_TaskInfo_t * TaskInfo,
    CFE_ES_TaskId_t TaskId )
```

Get Task Information given a specified Task ID.

#### Description

This routine retrieves the information about a Task associated with a specified Task ID. The information includes Task Name, and Parent/Creator Application ID.

#### Assumptions, External Events, and Notes:

None

#### Parameters

out	<i>TaskInfo</i>	Pointer to a <code>CFE_ES_TaskInfo_t</code> structure (must not be null) that holds the specific task information. <code>*TaskInfo</code> is the filled out <code>CFE_ES_TaskInfo_t</code> structure containing the Task Name, Parent App Name, Parent App ID among other fields.
in	<i>TaskId</i>	Application ID of Application whose name is being requested.

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<code>CFE_SUCCESS</code>	Successful execution.
<code>CFE_ES_ERR_RESOURCEID_NOT_VALID</code>	Resource ID is not valid.
<code>CFE_ES_BAD_ARGUMENT</code>	Bad Argument.

#### See also

[CFE\\_ES\\_GetTaskID](#), [CFE\\_ES\\_GetTaskIDByName](#), [CFE\\_ES\\_GetTaskName](#)

## 10.16 cFE Child Task APIs

### Functions

- `CFE_Status_t CFE_ES_CreateChildTask (CFE_ES_TaskId_t *TaskIdPtr, const char *TaskName, CFE_ES_ChildTaskMainFuncPtr_t FunctionPtr, CFE_ES_StackPointer_t StackPtr, size_t StackSize, CFE_ES_TaskPriority_Atom_t Priority, uint32 Flags)`  
*Creates a new task under an existing Application.*
- `CFE_Status_t CFE_ES_GetTaskIDByName (CFE_ES_TaskId_t *TaskIdPtr, const char *TaskName)`  
*Get a Task ID associated with a specified Task name.*
- `CFE_Status_t CFE_ES_GetTaskName (char *TaskName, CFE_ES_TaskId_t TaskId, size_t BufferLength)`  
*Get a Task name for a specified Task ID.*
- `CFE_Status_t CFE_ES_DeleteChildTask (CFE_ES_TaskId_t TaskId)`  
*Deletes a task under an existing Application.*
- `void CFE_ES_ExitChildTask (void)`  
*Exits a child task.*

### 10.16.1 Detailed Description

### 10.16.2 Function Documentation

#### 10.16.2.1 CFE\_ES\_CreateChildTask()

```
CFE_Status_t CFE_ES_CreateChildTask (
    CFE_ES_TaskId_t * TaskIdPtr,
    const char * TaskName,
    CFE_ES_ChildTaskMainFuncPtr_t FunctionPtr,
    CFE_ES_StackPointer_t StackPtr,
    size_t StackSize,
    CFE_ES_TaskPriority_Atom_t Priority,
    uint32 Flags )
```

Creates a new task under an existing Application.

#### Description

This routine creates a new task (a separate execution thread) owned by the calling Application.

#### Assumptions, External Events, and Notes:

None

## Parameters

out	<i>TaskIdPtr</i>	A pointer to a variable that will be filled in with the new task's ID (must not be null). TaskIdPtr is the Task ID of the newly created child task.
in	<i>TaskName</i>	A pointer to a string containing the desired name of the new task (must not be null). This can be up to <a href="#">OS_MAX_API_NAME</a> characters, including the trailing null.
in	<i>FunctionPtr</i>	A pointer to the function that will be spawned as a new task (must not be null).
in	<i>StackPtr</i>	A pointer to the location where the child task's stack pointer should start. NOTE: Not all underlying operating systems support this parameter. The <a href="#">CFE_ES_TASK_STACK_ALLOCATE</a> constant may be passed to indicate that the stack should be dynamically allocated.
in	<i>StackSize</i>	The number of bytes to allocate for the new task's stack (must not be zero).
in	<i>Priority</i>	The priority for the new task. Lower numbers are higher priority, with 0 being the highest priority.
in	<i>Flags</i>	Reserved for future expansion.

## Returns

Execution status, see [cFE Return Code Defines](#)

## Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_ERR_CHILD_TASK_CREATE</a>	Child Task Create Error.
<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.

## See also

[CFE\\_ES\\_DeleteChildTask](#), [CFE\\_ES\\_ExitChildTask](#)

### 10.16.2.2 CFE\_ES\_DeleteChildTask()

```
CFE_Status_t CFE_ES_DeleteChildTask (
    CFE_ES_TaskId_t TaskId )
```

Deletes a task under an existing Application.

## Description

This routine deletes a task under an Application specified by the TaskId obtained when the child task was created using the [CFE\\_ES\\_CreateChildTask](#) API.

## Assumptions, External Events, and Notes:

None

**Parameters**

in	<i>Task</i> ↔ <i>Id</i>	The task ID previously obtained when the Child Task was created with the <a href="#">CFE_ES_CreateChildTask</a> API.
----	-------------------------------	--

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_ES_ERR_CHILD_TASK_DELETE</i>	(return value only verified in coverage test) Child Task Delete Error.
<i>CFE_ES_ERR_CHILD_TASK_DELETE_MAIN_TASK</i>	Child Task Delete Passed Main Task.
<i>CFE_ES_ERR_RESOURCEID_NOT_VALID</i>	Resource ID is not valid.

**See also**

[CFE\\_ES\\_CreateChildTask](#), [CFE\\_ES\\_ExitChildTask](#)

**10.16.2.3 CFE\_ES\_ExitChildTask()**

```
void CFE_ES_ExitChildTask (
    void )
```

Exits a child task.

**Description**

This routine allows the current executing child task to exit and be deleted by ES.

**Assumptions, External Events, and Notes:**

This function cannot be called from an Application's Main Task.

**Note**

This function does not return a value, but if it does return at all, it is assumed that the Task was either unregistered or this function was called from a cFE Application's main task.

**See also**

[CFE\\_ES\\_CreateChildTask](#), [CFE\\_ES\\_DeleteChildTask](#)

#### 10.16.2.4 CFE\_ES\_GetTaskIDByName()

```
CFE_Status_t CFE_ES_GetTaskIDByName (
    CFE_ES_TaskId_t * TaskIdPtr,
    const char * TaskName )
```

Get a Task ID associated with a specified Task name.

##### Description

This routine retrieves the cFE Task ID associated with a specified Task name.

##### Assumptions, External Events, and Notes:

None

##### Parameters

out	<i>TaskIdPtr</i>	Pointer to variable that is to receive the Task's ID (must not be null).
in	<i>TaskName</i>	Pointer to null terminated character string containing a Task name (must not be null).

##### Returns

Execution status, see [cFE Return Code Defines](#)

##### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_ERR_NAME_NOT_FOUND</a>	Resource Name Error.
<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.

##### See also

[CFE\\_ES\\_GetTaskName](#)

#### 10.16.2.5 CFE\_ES\_GetTaskName()

```
CFE_Status_t CFE_ES_GetTaskName (
    char * TaskName,
    CFE_ES_TaskId_t TaskId,
    size_t BufferLength )
```

Get a Task name for a specified Task ID.

### Description

This routine retrieves the cFE Task name associated with a specified Task ID.

### Assumptions, External Events, and Notes:

In the case of a failure ([CFE\\_ES\\_ERR\\_RESOURCEID\\_NOT\\_VALID](#)), an empty string is returned.

### Parameters

out	<i>TaskName</i>	Pointer to a character array (must not be null) of at least <i>BufferLength</i> in size that will be filled with the Task name.
in	<i>TaskId</i>	Task ID of Task whose name is being requested.
in	<i>BufferLength</i>	The maximum number of characters, including the null terminator, that can be put into the <i>TaskName</i> buffer. This routine will truncate the name to this length, if necessary.

### Returns

Execution status, see [cFE Return Code Defines](#)

### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.

### See also

[CFE\\_ES\\_GetTaskIDByName](#)

## 10.17 cFE Miscellaneous APIs

### Functions

- void [CFE\\_ES\\_BackgroundWakeup](#) (void)  
*Wakes up the CFE background task.*
- [CFE\\_Status\\_t CFE\\_ES\\_WriteToSysLog](#) (const char \*SpecStringPtr,...) [OS\\_PRINTF](#)(1)  
*Write a string to the cFE System Log.*
- [CFE\\_Status\\_t uint32 CFE\\_ES\\_CalculateCRC](#) (const void \*DataPtr, size\_t DataLength, [uint32](#) InputCRC, [uint32](#) TypeCRC)  
*Calculate a CRC on a block of memory.*
- void [CFE\\_ES\\_ProcessAsyncEvent](#) (void)  
*Notification that an asynchronous event was detected by the underlying OS/PSP.*

### 10.17.1 Detailed Description

### 10.17.2 Function Documentation

#### 10.17.2.1 [CFE\\_ES\\_BackgroundWakeup\(\)](#)

```
void CFE_ES_BackgroundWakeup (
    void )
```

Wakes up the CFE background task.

#### Description

Normally the ES background task wakes up at a periodic interval. Whenever new background work is added, this can be used to wake the task early, which may reduce the delay between adding the job and the job getting processed.

#### Assumptions, External Events, and Notes:

Note the amount of work that the background task will perform is pro-rated based on the amount of time elapsed since the last wakeup. Waking the task early will not cause the background task to do more work than it otherwise would - it just reduces the delay before work starts initially.

### 10.17.2.2 CFE\_ES\_CalculateCRC()

```
CFE_Status_t uint32 CFE_ES_CalculateCRC (
    const void * DataPtr,
    size_t DataLength,
    uint32 InputCRC,
    uint32 TypeCRC )
```

Calculate a CRC on a block of memory.

#### Description

This routine calculates a cyclic redundancy check (CRC) on a block of memory. The CRC algorithm used is determined by the last parameter.

#### Assumptions, External Events, and Notes:

None

**Parameters**

in	<i>DataPtr</i>	Pointer to the base of the memory block.
in	<i>DataLength</i>	The number of bytes in the memory block.
in	<i>InputCRC</i>	A starting value for use in the CRC calculation. This parameter allows the user to calculate the CRC of non-contiguous blocks as a single value. Nominally, the user should set this value to zero.
in	<i>TypeCRC</i>	One of the following CRC algorithm selections: <ul style="list-style-type: none"> <li>• CFE_MISSION_ES_CRC_8 - (Not currently implemented)</li> <li>• CFE_MISSION_ES_CRC_16 - CRC-16/ARC Polynomial: 0x8005 Initialization: 0x0000 Reflect Input/Output: true XorOut: 0x0000</li> <li>• CFE_MISSION_ES_CRC_32 - (not currently implemented)</li> </ul>

**Returns**

The result of the CRC calculation on the specified memory block. If the TypeCRC is unimplemented will return 0. If DataPtr is null or DataLength is 0, will return InputCRC

**10.17.2.3 CFE\_ES\_ProcessAsyncEvent()**

```
void CFE_ES_ProcessAsyncEvent (
    void )
```

Notification that an asynchronous event was detected by the underlying OS/PSP.

**Description**

This hook routine is called from the PSP when an exception or other asynchronous system event occurs

**Assumptions, External Events, and Notes:**

The PSP must guarantee that this function is only invoked from a context which may use OSAL primitives. In general this means that it shouldn't be *directly* invoked from an ISR/signal context.

#### 10.17.2.4 CFE\_ES\_WriteToSysLog()

```
CFE_Status_t CFE_ES_WriteToSysLog (
    const char * SpecStringPtr,
    ...
)
```

Write a string to the cFE System Log.

##### Description

This routine writes a formatted string to the cFE system log. This can be used to record very low-level errors that can't be reported using the Event Services. This function is used in place of printf for flight software. It should be used for significant startup events, critical errors, and conditionally compiled debug software.

##### Assumptions, External Events, and Notes:

None

##### Parameters

in	SpecStringPtr	The format string for the log message (must not be null). This is similar to the format string for a printf() call.
----	---------------	---

##### Returns

Execution status, see [cFE Return Code Defines](#)

##### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_ERR_SYS_LOG_FULL</a>	System Log Full.
<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.

Referenced by DS\_AppMain().

## 10.18 cFE Critical Data Store APIs

### Functions

- [`CFE\_Status\_t CFE\_ES\_RegisterCDS \(CFE\_ES\_CDSHandle\_t \*CDSHandlePtr, size\_t BlockSize, const char \*Name\)`](#)  
*Reserve space (or re-obtain previously reserved space) in the Critical Data Store (CDS)*
- [`CFE\_Status\_t CFE\_ES\_GetCDSBlockIDByName \(CFE\_ES\_CDSHandle\_t \*BlockIdPtr, const char \*BlockName\)`](#)  
*Get a CDS Block ID associated with a specified CDS Block name.*
- [`CFE\_Status\_t CFE\_ES\_GetCDSBlockName \(char \*BlockName, CFE\_ES\_CDSHandle\_t BlockId, size\_t BufferLength\)`](#)  
*Get a Block name for a specified Block ID.*
- [`CFE\_Status\_t CFE\_ES\_CopyToCDS \(CFE\_ES\_CDSHandle\_t Handle, const void \*DataToCopy\)`](#)  
*Save a block of data in the Critical Data Store (CDS)*
- [`CFE\_Status\_t CFE\_ES\_RestoreFromCDS \(void \*RestoreToMemory, CFE\_ES\_CDSHandle\_t Handle\)`](#)  
*Recover a block of data from the Critical Data Store (CDS)*

#### 10.18.1 Detailed Description

#### 10.18.2 Function Documentation

##### 10.18.2.1 `CFE_ES_CopyToCDS()`

```
CFE_Status_t CFE_ES_CopyToCDS (
    CFE_ES_CDSHandle_t Handle,
    const void * DataToCopy )
```

Save a block of data in the Critical Data Store (CDS)

#### Description

This routine copies a specified block of memory into the Critical Data Store that had been previously registered via [CFE\\_ES\\_RegisterCDS](#). The block of memory to be copied must be at least as big as the size specified when registering the CDS.

#### Assumptions, External Events, and Notes:

None

#### Parameters

in	<code>Handle</code>	The handle of the CDS block that was previously obtained from <a href="#">CFE_ES_RegisterCDS</a> .
in	<code>DataToCopy</code>	A Pointer to the block of memory to be copied into the CDS (must not be null).

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_ES_ERR_RESOURCEID_NOT_VALID</i>	Resource ID is not valid.
<i>CFE_ES_BAD_ARGUMENT</i>	Bad Argument.

**See also**

[CFE\\_ES\\_RegisterCDS](#), [CFE\\_ES\\_RestoreFromCDS](#)

Referenced by DS\_TableCreateCDS(), and DS\_TableUpdateCDS().

### 10.18.2.2 CFE\_ES\_GetCDSBlockIDByName()

```
CFE_Status_t CFE_ES_GetCDSBlockIDByName (
    CFE_ES_CDSHandle_t * BlockIdPtr,
    const char * BlockName )
```

Get a CDS Block ID associated with a specified CDS Block name.

**Description**

This routine retrieves the CDS Block ID associated with a specified CDS Block name.

**Assumptions, External Events, and Notes:**

None

**Parameters**

<i>out</i>	<i>BlockIdPtr</i>	Pointer to variable that is to receive the CDS Block ID (must not be null).
<i>in</i>	<i>BlockName</i>	Pointer to null terminated character string containing a CDS Block name (must not be null).

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_ES_ERR_NAME_NOT_FOUND</i>	Resource Name Error.

### Return values

<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.
<a href="#">CFE_ES_NOT_IMPLEMENTED</a>	The processor does not support a Critical Data Store.

### See also

[CFE\\_ES\\_GetCDSBlockName](#)

#### 10.18.2.3 CFE\_ES\_GetCDSBlockName()

```
CFE_Status_t CFE_ES_GetCDSBlockName (
    char * BlockName,
    CFE_ES_CDSHandle_t BlockId,
    size_t BufferLength )
```

Get a Block name for a specified Block ID.

### Description

This routine retrieves the cFE Block name associated with a specified Block ID.

### Assumptions, External Events, and Notes:

In the case of a failure ([CFE\\_ES\\_ERR\\_RESOURCEID\\_NOT\\_VALID](#)), an empty string is returned.

### Parameters

out	<i>BlockName</i>	Pointer to a character array (must not be null) of at least <i>BufferLength</i> in size that will be filled with the CDS Block name.
in	<i>BlockId</i>	Block ID/Handle of CDS registry entry whose name is being requested.
in	<i>BufferLength</i>	The maximum number of characters, including the null terminator, that can be put into the <i>BlockName</i> buffer. This routine will truncate the name to this length, if necessary.

### Returns

Execution status, see [cFE Return Code Defines](#)

### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.
<a href="#">CFE_ES_NOT_IMPLEMENTED</a>	The processor does not support a Critical Data Store.

**See also**

[CFE\\_ES\\_GetCDSBlockIDByName](#)

**10.18.2.4 CFE\_ES\_RegisterCDS()**

```
CFE_Status_t CFE_ES_RegisterCDS (
    CFE_ES_CDSHandle_t * CDSHandlePtr,
    size_t BlockSize,
    const char * Name )
```

Reserve space (or re-obtain previously reserved space) in the Critical Data Store (CDS)

**Description**

This routine allocates a block of memory in the Critical Data Store and associates it with the calling Application. The memory can survive an Application restart as well as a Processor Reset.

**Assumptions, External Events, and Notes:**

This function does *not* clear or otherwise initialize/modify the data within the CDS block. If this function returns [CFE\\_ES\\_CDS\\_ALREADY\\_EXISTS](#) the block may already have valid data in it.

If a new CDS block is reserved (either because the name did not exist, or existed as a different size) it is the responsibility of the calling application to fill the CDS block with valid data. This is indicated by a [CFE\\_SUCCESS](#) return code, and in this case the calling application should ensure that it also calls [CFE\\_ES\\_CopyToCDS\(\)](#) to fill the block with valid data.

**Parameters**

out	<i>CDSHandlePtr</i>	Pointer Application's variable that will contain the CDS Memory Block Handle (must not be null). HandlePtr is the handle of the CDS block that can be used in <a href="#">CFE_ES_CopyToCDS</a> and <a href="#">CFE_ES_RestoreFromCDS</a> .
in	<i>BlockSize</i>	The number of bytes needed in the CDS (must not be zero).
in	<i>Name</i>	A pointer to a character string (must not be null) containing an application unique name of <a href="#">CFE_MISSION_ES_CDS_MAX_NAME_LENGTH</a> characters or less.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	The memory block was successfully created in the CDS.
<a href="#">CFE_ES_NOT_IMPLEMENTED</a>	The processor does not support a Critical Data Store.
<a href="#">CFE_ES_CDS_ALREADY_EXISTS</a>	CDS Already Exists.
<a href="#">CFE_ES_CDS_INVALID_SIZE</a>	CDS Invalid Size.
<a href="#">CFE_ES_CDS_INVALID_NAME</a>	CDS Invalid Name.

**Return values**

<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.
<a href="#">CFE_ES_CDS_INVALID</a>	(return value only verified in coverage test) CDS Invalid.

**See also**

[CFE\\_ES\\_CopyToCDS](#), [CFE\\_ES\\_RestoreFromCDS](#)

Referenced by DS\_TableCreateCDS().

**10.18.2.5 CFE\_ES\_RestoreFromCDS()**

```
CFE_Status_t CFE_ES_RestoreFromCDS (
    void * RestoreToMemory,
    CFE_ES_CDSHandle_t Handle )
```

Recover a block of data from the Critical Data Store (CDS)

**Description**

This routine copies data from the Critical Data Store identified with the Handle into the area of memory pointed to by the *RestoreToMemory* pointer. The area of memory to be copied into must be at least as big as the size specified when registering the CDS. The recovery will indicate an error if the data integrity check maintained by the CDS indicates the contents of the CDS have changed. However, the contents will still be copied into the specified area of memory.

**Assumptions, External Events, and Notes:**

None

**Parameters**

in	<i>Handle</i>	The handle of the CDS block that was previously obtained from <a href="#">CFE_ES_RegisterCDS</a> .
out	<i>RestoreToMemory</i>	A Pointer to the block of memory (must not be null) that is to be restored with the contents of the CDS. <i>*RestoreToMemory</i> is the contents of the specified CDS.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
-----------------------------	-----------------------

**Return values**

<a href="#"><i>CFE_ES_ERR_RESOURCEID_NOT_VALID</i></a>	Resource ID is not valid.
<a href="#"><i>CFE_ES_CDS_BLOCK_CRC_ERR</i></a>	(return value only verified in coverage test) CDS Block CRC Error.
<a href="#"><i>CFE_ES_BAD_ARGUMENT</i></a>	Bad Argument.

**See also**

[CFE\\_ES\\_RegisterCDS](#), [CFE\\_ES\\_CopyToCDS](#)

Referenced by `DS_TableCreateCDS()`.

## 10.19 cFE Memory Manager APIs

### Functions

- `CFE_Status_t CFE_ES_PoolCreateNoSem (CFE_ES_MemHandle_t *PoolID, void *MemPtr, size_t Size)`  
*Initializes a memory pool created by an application without using a semaphore during processing.*
- `CFE_Status_t CFE_ES_PoolCreate (CFE_ES_MemHandle_t *PoolID, void *MemPtr, size_t Size)`  
*Initializes a memory pool created by an application while using a semaphore during processing.*
- `CFE_Status_t CFE_ES_PoolCreateEx (CFE_ES_MemHandle_t *PoolID, void *MemPtr, size_t Size, uint16 NumBlockSizes, const size_t *BlockSizes, bool UseMutex)`  
*Initializes a memory pool created by an application with application specified block sizes.*
- `int32 CFE_ES_PoolDelete (CFE_ES_MemHandle_t PoolID)`  
*Deletes a memory pool that was previously created.*
- `int32 CFE_ES_GetPoolBuf (CFE_ES_MemPoolBuf_t *BufPtr, CFE_ES_MemHandle_t Handle, size_t Size)`  
*Gets a buffer from the memory pool created by `CFE_ES_PoolCreate` or `CFE_ES_PoolCreateNoSem`.*
- `CFE_Status_t CFE_ES_GetPoolBufInfo (CFE_ES_MemHandle_t Handle, CFE_ES_MemPoolBuf_t BufPtr)`  
*Gets info on a buffer previously allocated via `CFE_ES_GetPoolBuf`.*
- `int32 CFE_ES_PutPoolBuf (CFE_ES_MemHandle_t Handle, CFE_ES_MemPoolBuf_t BufPtr)`  
*Releases a buffer from the memory pool that was previously allocated via `CFE_ES_GetPoolBuf`.*
- `CFE_Status_t CFE_ES_GetMemPoolStats (CFE_ES_MemPoolStats_t *BufPtr, CFE_ES_MemHandle_t Handle)`  
*Extracts the statistics maintained by the memory pool software.*

### 10.19.1 Detailed Description

### 10.19.2 Function Documentation

#### 10.19.2.1 `CFE_ES_GetMemPoolStats()`

```
CFE_Status_t CFE_ES_GetMemPoolStats (
    CFE_ES_MemPoolStats_t * BufPtr,
    CFE_ES_MemHandle_t Handle )
```

Extracts the statistics maintained by the memory pool software.

#### Description

This routine fills the `CFE_ES_MemPoolStats_t` data structure with the statistics maintained by the memory pool software. These statistics can then be telemetered by the calling Application.

#### Assumptions, External Events, and Notes:

None

**Parameters**

<i>out</i>	<i>BufPtr</i>	Pointer to <a href="#">CFE_ES_MemPoolStats_t</a> data structure (must not be null) to be filled with memory statistics. *BufPtr is the Memory Pool Statistics stored in given data structure.
<i>in</i>	<i>Handle</i>	The handle to the memory pool whose statistics are desired.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.

**See also**

[CFE\\_ES\\_PoolCreate](#), [CFE\\_ES\\_PoolCreateNoSem](#), [CFE\\_ES\\_PoolCreateEx](#), [CFE\\_ES\\_GetPoolBuf](#), [CFE\\_ES\\_PutPoolBuf](#)

**10.19.2.2 CFE\_ES\_GetPoolBuf()**

```
int32 CFE_ES_GetPoolBuf (
    CFE_ES_MemPoolBuf_t * BufPtr,
    CFE_ES_MemHandle_t Handle,
    size_t Size )
```

Gets a buffer from the memory pool created by [CFE\\_ES\\_PoolCreate](#) or [CFE\\_ES\\_PoolCreateNoSem](#).

**Description**

This routine obtains a block of memory from the memory pool supplied by the calling application.

**Assumptions, External Events, and Notes:**

1. The size allocated from the memory pool is, at a minimum, 12 bytes more than requested.

**Parameters**

<i>out</i>	<i>BufPtr</i>	A pointer to the Application's pointer (must not be null) in which will be stored the address of the allocated memory buffer. *BufPtr is the address of the requested buffer.
<i>in</i>	<i>Handle</i>	The handle to the memory pool as returned by <a href="#">CFE_ES_PoolCreate</a> or <a href="#">CFE_ES_PoolCreateNoSem</a> .
<i>in</i>	<i>Size</i>	The size of the buffer requested. NOTE: The size allocated may be larger.

**Returns**

Bytes Allocated, or error code [cFE Return Code Defines](#)

**Return values**

<a href="#"><code>CFE_ES_ERR_RESOURCEID_NOT_VALID</code></a>	Resource ID is not valid.
<a href="#"><code>CFE_ES_ERR_MEM_BLOCK_SIZE</code></a>	Memory Block Size Error.
<a href="#"><code>CFE_ES_BAD_ARGUMENT</code></a>	Bad Argument.

**See also**

[CFE\\_ES\\_PoolCreate](#), [CFE\\_ES\\_PoolCreateNoSem](#), [CFE\\_ES\\_PoolCreateEx](#), [CFE\\_ES\\_PutPoolBuf](#), [CFE\\_ES\\_GetMemPoolStats](#), [CFE\\_ES\\_GetPoolBufInfo](#)

**10.19.2.3 CFE\_ES\_GetPoolBufInfo()**

```
CFE_Status_t CFE_ES_GetPoolBufInfo (
    CFE_ES_MemHandle_t Handle,
    CFE_ES_MemPoolBuf_t BufPtr )
```

Gets info on a buffer previously allocated via [CFE\\_ES\\_GetPoolBuf](#).

**Description**

This routine gets info on a buffer in the memory pool.

**Assumptions, External Events, and Notes:**

None

**Parameters**

in	<i>Handle</i>	The handle to the memory pool as returned by <a href="#">CFE_ES_PoolCreate</a> or <a href="#">CFE_ES_PoolCreateNoSem</a> .
in	<i>BufPtr</i>	A pointer to the memory buffer to provide status for (must not be null).

**Returns**

Size of the buffer if successful, or status code if not successful, see [cFE Return Code Defines](#)

**Return values**

<a href="#"><code>CFE_ES_ERR_RESOURCEID_NOT_VALID</code></a>	Resource ID is not valid.
<a href="#"><code>CFE_ES_BUFFER_NOT_IN_POOL</code></a>	Buffer Not In Pool.
<a href="#"><code>CFE_ES_BAD_ARGUMENT</code></a>	Bad Argument.

**See also**

[CFE\\_ES\\_PoolCreate](#), [CFE\\_ES\\_PoolCreateNoSem](#), [CFE\\_ES\\_PoolCreateEx](#), [CFE\\_ES\\_GetPoolBuf](#), [CFE\\_ES\\_GetMemPoolStats](#), [CFE\\_ES\\_PutPoolBuf](#)

**10.19.2.4 CFE\_ES\_PoolCreate()**

```
CFE_Status_t CFE_ES_PoolCreate (
    CFE_ES_MemHandle_t * PoolID,
    void * MemPtr,
    size_t Size )
```

Initializes a memory pool created by an application while using a semaphore during processing.

**Description**

This routine initializes a pool of memory supplied by the calling application. When a memory pool created by this routine is processed, mutex handling will be performed.

**Assumptions, External Events, and Notes:**

1. The size of the pool must be an integral number of 32-bit words
2. The start address of the pool must be 32-bit aligned
3. 168 bytes are used for internal bookkeeping, therefore, they will not be available for allocation.

**Parameters**

out	<i>PoolID</i>	A pointer to the variable the caller wishes to have the memory pool handle kept in (must not be null). PoolID is the memory pool handle.
in	<i>MemPtr</i>	A Pointer to the pool of memory created by the calling application (must not be null). This address must be aligned suitably for the processor architecture. The <a href="#">CFE_ES_STATIC_POOL_TYPE</a> macro may be used to assist in creating properly aligned memory pools.
in	<i>Size</i>	The size of the pool of memory (must not be zero). Note that this must be an integral multiple of the memory alignment of the processor architecture.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.

**See also**

[CFE\\_ES\\_PoolCreateNoSem](#), [CFE\\_ES\\_PoolCreateEx](#), [CFE\\_ES\\_GetPoolBuf](#), [CFE\\_ES\\_PutPoolBuf](#), [CFE\\_ES\\_GetMemPoolStats](#)

**10.19.2.5 CFE\_ES\_PoolCreateEx()**

```
CFE_Status_t CFE_ES_PoolCreateEx (
    CFE_ES_MemHandle_t * PoolID,
    void * MemPtr,
    size_t Size,
    uint16 NumBlockSizes,
    const size_t * BlockSizes,
    bool UseMutex )
```

Initializes a memory pool created by an application with application specified block sizes.

**Description**

This routine initializes a pool of memory supplied by the calling application.

**Assumptions, External Events, and Notes:**

1. The size of the pool must be an integral number of 32-bit words
2. The start address of the pool must be 32-bit aligned
3. 168 bytes are used for internal bookkeeping, therefore, they will not be available for allocation.

**Parameters**

out	<i>PoolID</i>	A pointer to the variable the caller wishes to have the memory pool handle kept in (must not be null). PoolID is the memory pool handle.
in	<i>MemPtr</i>	A Pointer to the pool of memory created by the calling application (must not be null). This address must be aligned suitably for the processor architecture. The <a href="#">CFE_ES_STATIC_POOL_TYPE</a> macro may be used to assist in creating properly aligned memory pools.
in	<i>Size</i>	The size of the pool of memory (must not be zero). Note that this must be an integral multiple of the memory alignment of the processor architecture.
in	<i>NumBlockSizes</i>	The number of different block sizes specified in the <i>BlockSizes</i> array. If set larger than <a href="#">CFE_PLATFORM_ES_POOL_MAX_BUCKETS</a> , <a href="#">CFE_ES_BAD_ARGUMENT</a> will be returned. If BlockSizes is null and NumBlockSizes is 0, NubBlockSizes will be set to <a href="#">CFE_PLATFORM_ES_POOL_MAX_BUCKETS</a> .
in	<i>BlockSizes</i>	Pointer to an array of sizes to be used instead of the default block sizes specified by <a href="#">CFE_PLATFORM_ES_MEM_BLOCK_SIZE_01</a> through <a href="#">CFE_PLATFORM_ES_MAX_BLOCK_SIZE</a> . If the pointer is equal to NULL, the default block sizes are used.
in	<i>UseMutex</i>	Flag indicating whether the new memory pool will be processing with mutex handling or not. Valid parameter values are <a href="#">CFE_ES_USE_MUTEX</a> and <a href="#">CFE_ES_NO_MUTEX</a>

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#"><i>CFE_SUCCESS</i></a>	Successful execution.
<a href="#"><i>CFE_ES_BAD_ARGUMENT</i></a>	Bad Argument.
<a href="#"><i>CFE_ES_NO_RESOURCE_IDS_AVAILABLE</i></a>	Resource ID is not available.
<a href="#"><i>CFE_STATUS_EXTERNAL_RESOURCE_FAILURE</i></a>	(return value only verified in coverage test) External failure.

**See also**

[\*CFE\\_ES\\_PoolCreate\*](#), [\*CFE\\_ES\\_PoolCreateNoSem\*](#), [\*CFE\\_ES\\_GetPoolBuf\*](#), [\*CFE\\_ES\\_PutPoolBuf\*](#), [\*CFE\\_ES\\_GetMemPoolStats\*](#)

**10.19.2.6 CFE\_ES\_PoolCreateNoSem()**

```
CFE_Status_t CFE_ES_PoolCreateNoSem (
    CFE_ES_MemHandle_t * PoolID,
    void * MemPtr,
    size_t Size )
```

Initializes a memory pool created by an application without using a semaphore during processing.

**Description**

This routine initializes a pool of memory supplied by the calling application. When a memory pool created by this routine is processed, no mutex handling is performed.

**Assumptions, External Events, and Notes:**

1. The size of the pool must be an integral number of 32-bit words
2. The start address of the pool must be 32-bit aligned
3. 168 bytes are used for internal bookkeeping, therefore, they will not be available for allocation.

**Parameters**

<i>out</i>	<i>PoolID</i>	A pointer to the variable the caller wishes to have the memory pool handle kept in (must not be null). PoolID is the memory pool handle.
<i>in</i>	<i>MemPtr</i>	A Pointer to the pool of memory created by the calling application (must not be null). This address must be aligned suitably for the processor architecture. The <a href="#"><i>CFE_ES_STATIC_POOL_TYPE</i></a> macro may be used to assist in creating properly aligned memory pools.
<i>in</i>	<i>Size</i>	The size of the pool of memory (must not be zero). Note that this must be an integral multiple of the memory alignment of the processor architecture.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.

**See also**

[CFE\\_ES\\_PoolCreate](#), [CFE\\_ES\\_PoolCreateEx](#), [CFE\\_ES\\_GetPoolBuf](#), [CFE\\_ES\\_PutPoolBuf](#), [CFE\\_ES\\_GetMemPoolStats](#)

**10.19.2.7 CFE\_ES\_PoolDelete()**

```
int32 CFE_ES_PoolDelete (
    CFE_ES_MemHandle_t PoolID )
```

Deletes a memory pool that was previously created.

**Description**

This routine removes the pool ID and frees the global table entry for future re-use.

**Assumptions, External Events, and Notes:**

All buffers associated with the pool become invalid after this call. The application should ensure that buffers/references to the pool are returned before deleting the pool.

**Parameters**

in	<i>PoolID</i>	The ID of the pool to delete
----	---------------	------------------------------

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.

**See also**

[CFE\\_ES\\_PoolCreate](#), [CFE\\_ES\\_PoolCreateNoSem](#), [CFE\\_ES\\_GetPoolBuf](#), [CFE\\_ES\\_PutPoolBuf](#), [CFE\\_ES\\_GetMemPoolStats](#)

**10.19.2.8 CFE\_ES\_PutPoolBuf()**

```
int32 CFE_ES_PutPoolBuf (
    CFE_ES_MemHandle_t Handle,
    CFE_ES_MemPoolBuf_t BufPtr )
```

Releases a buffer from the memory pool that was previously allocated via [CFE\\_ES\\_GetPoolBuf](#).

**Description**

This routine releases a buffer back into the memory pool.

**Assumptions, External Events, and Notes:**

None

**Parameters**

in	<i>Handle</i>	The handle to the memory pool as returned by <a href="#">CFE_ES_PoolCreate</a> or <a href="#">CFE_ES_PoolCreateNoSem</a> .
in	<i>BufPtr</i>	A pointer to the memory buffer to be released (must not be null).

**Returns**

Bytes released, or error code cFE Return Code Defines

**Return values**

<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.
<a href="#">CFE_ES_BUFFER_NOT_IN_POOL</a>	Buffer Not In Pool.
<a href="#">CFE_ES_POOL_BLOCK_INVALID</a>	Invalid pool block.

**See also**

[CFE\\_ES\\_PoolCreate](#), [CFE\\_ES\\_PoolCreateNoSem](#), [CFE\\_ES\\_PoolCreateEx](#), [CFE\\_ES\\_GetPoolBuf](#), [CFE\\_ES\\_GetMemPoolStats](#), [CFE\\_ES\\_GetPoolBufInfo](#)

## 10.20 cFE Performance Monitor APIs

### Macros

- #define CFE\_ES\_PerfLogEntry(id) (CFE\_ES\_PerfLogAdd(id, 0))  
*Entry marker for use with Software Performance Analysis Tool.*
- #define CFE\_ES\_PerfLogExit(id) (CFE\_ES\_PerfLogAdd(id, 1))  
*Exit marker for use with Software Performance Analysis Tool.*

### Functions

- void CFE\_ES\_PerfLogAdd (uint32 Marker, uint32 EntryExit)  
*Adds a new entry to the data buffer.*

#### 10.20.1 Detailed Description

#### 10.20.2 Macro Definition Documentation

##### 10.20.2.1 CFE\_ES\_PerfLogEntry

```
#define CFE_ES_PerfLogEntry(  
    id ) (CFE_ES_PerfLogAdd(id, 0))
```

Entry marker for use with Software Performance Analysis Tool.

#### Description

This macro logs the entry or start event/marker for the specified entry `id`. This macro, in conjunction with the [CFE\\_ES\\_PerfLogExit](#), is used by the Software Performance Analysis tool (see section 5.15).

#### Assumptions, External Events, and Notes:

None

#### Parameters

in	<code>id</code>	Identifier of the specific event or marker.
----	-----------------	---

#### See also

[CFE\\_ES\\_PerfLogExit](#), [CFE\\_ES\\_PerfLogAdd](#)

Definition at line 1471 of file `cfe_es.h`.

Referenced by DS\_AppMain().

### 10.20.2.2 CFE\_ES\_PerfLogExit

```
#define CFE_ES_PerfLogExit( id ) (CFE_ES_PerfLogAdd(id, 1))
```

Exit marker for use with Software Performance Analysis Tool.

#### Description

This macro logs the exit or end event/marker for the specified entry `id`. This macro, in conjunction with the [CFE\\_ES\\_PerfLogEntry](#), is used by the Software Performance Analysis tool (see section 5.15).

#### Assumptions, External Events, and Notes:

None

#### Parameters

in	<i>id</i>	Identifier of the specific event or marker.
----	-----------	---

#### See also

[CFE\\_ES\\_PerfLogEntry](#), [CFE\\_ES\\_PerfLogAdd](#)

Definition at line 1490 of file `cfe_es.h`.

Referenced by DS\_AppMain().

### 10.20.3 Function Documentation

#### 10.20.3.1 CFE\_ES\_PerfLogAdd()

```
void CFE_ES_PerfLogAdd ( uint32 Marker, uint32 EntryExit )
```

Adds a new entry to the data buffer.

Function called by [CFE\\_ES\\_PerfLogEntry](#) and [CFE\\_ES\\_PerfLogExit](#) macros

**Description**

This function logs the entry and exit marker for the specified `id`. This function is used by the Software Performance Analysis tool (see section 5.15).

**Assumptions, External Events, and Notes:**

This function implements a circular buffer using an array. `DataStart` points to first stored entry `DataEnd` points to next available entry if `DataStart == DataEnd` then the buffer is either empty or full depending on the value of the `DataCount`

Time is stored as 2 32 bit integers, (`TimerLower32`, `TimerUpper32`): `TimerLower32` is the current value of the hardware timer register. `TimerUpper32` is the number of times the timer has rolled over.

**Parameters**

in	<i>Marker</i>	Identifier of the specific event or marker.
in	<i>EntryExit</i>	Used to specify Entry(0) or Exit(1)

**See also**

[CFE\\_ES\\_PerfLogEntry](#), [CFE\\_ES\\_PerfLogExit](#)

## 10.21 cFE Generic Counter APIs

### Functions

- [CFE\\_Status\\_t CFE\\_ES\\_RegisterGenCounter \(CFE\\_ES\\_CounterId\\_t \\*CounterIdPtr, const char \\*CounterName\)](#)  
*Register a generic counter.*
- [CFE\\_Status\\_t CFE\\_ES\\_DeleteGenCounter \(CFE\\_ES\\_CounterId\\_t CounterId\)](#)  
*Delete a generic counter.*
- [CFE\\_Status\\_t CFE\\_ES\\_IncrementGenCounter \(CFE\\_ES\\_CounterId\\_t CounterId\)](#)  
*Increments the specified generic counter.*
- [CFE\\_Status\\_t CFE\\_ES\\_SetGenCount \(CFE\\_ES\\_CounterId\\_t CounterId, uint32 Count\)](#)  
*Set the specified generic counter.*
- [CFE\\_Status\\_t CFE\\_ES\\_GetGenCount \(CFE\\_ES\\_CounterId\\_t CounterId, uint32 \\*Count\)](#)  
*Get the specified generic counter count.*
- [CFE\\_Status\\_t CFE\\_ES\\_GetGenCounterIDByName \(CFE\\_ES\\_CounterId\\_t \\*CounterIdPtr, const char \\*CounterName\)](#)  
*Get the Id associated with a generic counter name.*
- [CFE\\_Status\\_t CFE\\_ES\\_GetGenCounterName \(char \\*CounterName, CFE\\_ES\\_CounterId\\_t CounterId, size\\_t BufferLength\)](#)  
*Get a Counter name for a specified Counter ID.*

#### 10.21.1 Detailed Description

#### 10.21.2 Function Documentation

##### 10.21.2.1 CFE\_ES\_DeleteGenCounter()

```
CFE_Status_t CFE_ES_DeleteGenCounter (
    CFE_ES_CounterId_t CounterId )
```

Delete a generic counter.

#### Description

This routine deletes a previously registered generic counter.

#### Assumptions, External Events, and Notes:

None.

#### Parameters

in	CounterId	The Counter Id of the newly created counter.
----	-----------	--

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#"><i>CFE_SUCCESS</i></a>	Successful execution.
<a href="#"><i>CFE_ES_BAD_ARGUMENT</i></a>	Bad Argument.

**See also**

[\*CFE\\_ES\\_IncrementGenCounter\*](#), [\*CFE\\_ES\\_RegisterGenCounter\*](#), [\*CFE\\_ES\\_SetGenCount\*](#), [\*CFE\\_ES\\_GetGenCount\*](#), [\*CFE\\_ES\\_GetGenCounterIDByName\*](#)

**10.21.2.2 CFE\_ES\_GetGenCount()**

```
CFE_Status_t CFE_ES_GetGenCount (
    CFE_ES_CounterId_t CounterId,
    uint32 * Count )
```

Get the specified generic counter count.

**Description**

This routine gets the value of a generic counter.

**Assumptions, External Events, and Notes:**

None.

**Parameters**

<i>in</i>	<i>CounterId</i>	The Counter to get the value from.
<i>out</i>	<i>Count</i>	Buffer to store value of the Counter (must not be null).

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#"><i>CFE_SUCCESS</i></a>	Successful execution.
<a href="#"><i>CFE_ES_BAD_ARGUMENT</i></a>	Bad Argument.

**See also**

[CFE\\_ES\\_RegisterGenCounter](#), [CFE\\_ES\\_DeleteGenCounter](#), [CFE\\_ES\\_SetGenCount](#), [CFE\\_ES\\_IncrementGenCounter](#), [CFE\\_ES\\_GetGenCounterIDByName](#)

**10.21.2.3 CFE\_ES\_GetGenCounterIDByName()**

```
CFE_Status_t CFE_ES_GetGenCounterIDByName (
    CFE_ES_CounterId_t * CounterIdPtr,
    const char * CounterName )
```

Get the Id associated with a generic counter name.

**Description**

This routine gets the Counter Id for a generic counter specified by name.

**Assumptions, External Events, and Notes:**

None.

**Parameters**

out	<i>CounterIdPtr</i>	Pointer to variable that is to receive the Counter's ID (must not be null).
in	<i>CounterName</i>	Pointer to null terminated character string containing a Counter name (must not be null).

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_ERR_NAME_NOT_FOUND</a>	Resource Name Error.
<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.

**See also**

[CFE\\_ES\\_GetGenCounterName](#)

**10.21.2.4 CFE\_ES\_GetGenCounterName()**

```
CFE_Status_t CFE_ES_GetGenCounterName (
    char * CounterName,
```

```
CFE_ES_CounterId_t CounterId,
size_t BufferLength )
```

Get a Counter name for a specified Counter ID.

#### Description

This routine retrieves the cFE Counter name associated with a specified Counter ID.

#### Assumptions, External Events, and Notes:

In the case of a failure ([CFE\\_ES\\_ERR\\_RESOURCEID\\_NOT\\_VALID](#)), an empty string is returned.

#### Parameters

out	<i>CounterName</i>	Pointer to a character array (must not be null) of at least <i>BufferLength</i> in size that will be filled with the Counter name.
in	<i>CounterId</i>	ID of Counter whose name is being requested.
in	<i>BufferLength</i>	The maximum number of characters, including the null terminator (must not be zero), that can be put into the <i>CounterName</i> buffer. This routine will truncate the name to this length, if necessary.

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.

#### See also

[CFE\\_ES\\_GetGenCounterIDByName](#)

#### 10.21.2.5 CFE\_ES\_IncrementGenCounter()

```
CFE_Status_t CFE_ES_IncrementGenCounter (
    CFE_ES_CounterId_t CounterId )
```

Increments the specified generic counter.

#### Description

This routine increments the specified generic counter.

**Assumptions, External Events, and Notes:**

None.

**Parameters**

in	<i>CounterId</i>	The Counter to be incremented.
----	------------------	--------------------------------

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.

**See also**

[CFE\\_ES\\_RegisterGenCounter](#), [CFE\\_ES\\_DeleteGenCounter](#), [CFE\\_ES\\_SetGenCount](#), [CFE\\_ES\\_GetGenCount](#), [CFE\\_ES\\_GetGenCounterIDByName](#)

**10.21.2.6 CFE\_ES\_RegisterGenCounter()**

```
CFE_Status_t CFE_ES_RegisterGenCounter (
    CFE_ES_CounterId_t * CounterIdPtr,
    const char * CounterName )
```

Register a generic counter.

**Description**

This routine registers a generic thread-safe counter which can be used for inter-task management.

**Assumptions, External Events, and Notes:**

The initial value of all newly registered counters is 0.

**Parameters**

out	<i>CounterIdPtr</i>	Buffer to store the Counter Id of the newly created counter (must not be null).
in	<i>CounterName</i>	The Name of the generic counter (must not be null).

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_ES_BAD_ARGUMENT</i>	Bad Argument.
<i>CFE_ES_ERR_DUPLICATE_NAME</i>	Duplicate Name Error.
<i>CFE_ES_NO_RESOURCE_IDS_AVAILABLE</i>	Resource ID is not available.

**See also**

[CFE\\_ES\\_IncrementGenCounter](#), [CFE\\_ES\\_DeleteGenCounter](#), [CFE\\_ES\\_SetGenCount](#), [CFE\\_ES\\_GetGenCount](#), [CFE\\_ES\\_GetGenCounterIDByName](#)

**10.21.2.7 CFE\_ES\_SetGenCount()**

```
CFE_Status_t CFE_ES_SetGenCount (
    CFE_ES_CounterId_t CounterId,
    uint32 Count )
```

Set the specified generic counter.

**Description**

This routine sets the specified generic counter to the specified value.

**Assumptions, External Events, and Notes:**

None.

**Parameters**

in	<i>CounterId</i>	The Counter to be set.
in	<i>Count</i>	The new value of the Counter.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_ES_BAD_ARGUMENT</i>	Bad Argument.

**See also**

[CFE\\_ES\\_RegisterGenCounter](#), [CFE\\_ES\\_DeleteGenCounter](#), [CFE\\_ES\\_IncrementGenCounter](#), [CFE\\_ES\\_Get←GenCount](#), [CFE\\_ES\\_GetGenCounterIDByName](#)

## 10.22 cFE Registration APIs

### Functions

- [CFE\\_Status\\_t CFE\\_EVS\\_Register](#) (const void \*Filters, uint16 NumEventFilters, uint16 FilterScheme)  
*Register an application for receiving event services.*

#### 10.22.1 Detailed Description

#### 10.22.2 Function Documentation

##### 10.22.2.1 CFE\_EVS\_Register()

```
CFE_Status_t CFE_EVS_Register (
    const void * Filters,
    uint16 NumEventFilters,
    uint16 FilterScheme )
```

Register an application for receiving event services.

#### Description

This routine registers an application with event services and allocates/initializes the internal data structures used to support this application's events. An application may not send events unless it has called this routine. The routine also accepts a filter array structure for applications requiring event filtering. In the current implementation of the EVS, only the binary filtering scheme is supported. See section TBD of the cFE Application Programmer's Guide for a description of the behavior of binary filters. Applications may call [CFE\\_EVS\\_Register](#) more than once, but each call will wipe out all filters registered by previous calls (filter registration is NOT cumulative).

#### Assumptions, External Events, and Notes:

Note: Event filters can be added, deleted or modified by ground commands. All filtering schemes include a default setting that results in no filtering (such as [CFE\\_EVS\\_NO\\_FILTER](#) for binary filters).

**Filter Scheme:** Binary

**Code:** CFE\_EVS\_EventFilter\_BINARY

**Filter Structure:**

```
typedef struct CFE_EVS_BinFilter {
    uint16 EventID,
    uint16 Mask ;
} CFE_EVS_BinFilter_t;
```

### Parameters

in	<i>Filters</i>	Pointer to an array of event message filters, or NULL if no filtering is desired. The structure of an event message filter depends on the FilterScheme selected. (see Filter Schemes mentioned above)
in	<i>NumEventFilters</i>	The number of event message filters included in this call. This must be less than or equal to the maximum number of events allowed per application ( <a href="#">CFE_PLATFORM_EVS_MAX_EVENT_FILTERS</a> ).
in	<i>FilterScheme</i>	The event filtering scheme that this application will use. For the first implementation of the event services, only filter type <a href="#">CFE_EVS_EventFilter_BINARY</a> will be supported.

### Returns

Execution status below or from [CFE\\_ES\\_GetAppID](#), see [cFE Return Code Defines](#)

### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_EVS_APP_FILTER_OVERLOAD</a>	Application Filter Overload.
<a href="#">CFE_EVS_UNKNOWN_FILTER</a>	Unknown Filter.
<a href="#">CFE_EVS_APP_ILLEGAL_APP_ID</a>	Illegal Application ID.
<a href="#">CFE_ES_BAD_ARGUMENT</a>	Bad Argument.

Referenced by DS\_AppInitialize().

## 10.23 cFE Send Event APIs

### Functions

- `CFE_Status_t CFE_EVS_SendEvent (uint16 EventID, uint16 EventType, const char *Spec,...) OS_PRINTF(3  
Generate a software event.`
- `CFE_Status_t CFE_Status_t CFE_EVS_SendEventWithApplID (uint16 EventID, uint16 EventType, CFE_ES_←  
ApplId_t ApplID, const char *Spec,...) OS_PRINTF(4  
Generate a software event given the specified Application ID.`
- `CFE_Status_t CFE_Status_t CFE_Status_t CFE_EVS_SendTimedEvent (CFE_TIME_SysTime_t Time, uint16  
EventID, uint16 EventType, const char *Spec,...) OS_PRINTF(4  
Generate a software event with a specific time tag.`

### 10.23.1 Detailed Description

### 10.23.2 Function Documentation

#### 10.23.2.1 CFE\_EVS\_SendEvent()

```
CFE_Status_t CFE_EVS_SendEvent (
    uint16 EventID,
    uint16 EventType,
    const char * Spec,
    ... )
```

Generate a software event.

#### Description

This routine generates a software event message. If the EventID is not filtered, the event will be sent as a software bus message, optionally logged in the local event log, and optionally sent as an ASCII text string out the enabled output port(s).

#### Assumptions, External Events, and Notes:

This API only works within the context of a registered application or core service. For messages outside the context of a registered application (for example early in app initialization or if registration fails) `CFE_ES_WriteToSysLog` can be used for reporting.

#### Parameters

in	<i>EventID</i>	A numeric literal used to uniquely identify an application event. The Event ID is defined and supplied by the application sending the event.
----	----------------	--

## Parameters

in	<i>EventType</i>	A numeric literal used to classify an event, one of: <ul style="list-style-type: none"><li>• <a href="#">CFE_EVS_EventType_DEBUG</a></li><li>• <a href="#">CFE_EVS_EventType_INFORMATION</a></li><li>• <a href="#">CFE_EVS_EventType_ERROR</a></li><li>• <a href="#">CFE_EVS_EventType_CRITICAL</a></li></ul>
in	<i>Spec</i>	A pointer to a null terminated text string (must not be null) describing the output format for the event. This is the same type of format string used for the ANSI <code>printf</code> function. Nominally the post-conversion string is limited to 80 characters, but this limit is configurable through the parameter <a href="#">CFE_MISSION_EVS_MAX_MESSAGE_LENGTH</a> . Characters beyond the limit will be truncated. Do not use floating point conversions (f, e, E, g, and G) in the format string unless your application will be running in a system that supports floating point arithmetic. Do not use non-printable characters (\t, \n, etc.) in the format string; they will mess up the formatting when the events are displayed on the ground system.

## Returns

Execution status, see [cFE Return Code Defines](#)

## Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_EVS_APP_NOT_REGISTERED</a>	Application Not Registered.
<a href="#">CFE_EVS_APP_ILLEGAL_APP_ID</a>	Illegal Application ID.
<a href="#">CFE_EVS_INVALID_PARAMETER</a>	Invalid Pointer.

## See also

[CFE\\_EVS\\_SendEventWithAppID](#), [CFE\\_EVS\\_SendTimedEvent](#)

Referenced by `DS_AppInitialize()`, `DS_AppMain()`, `DS_AppProcessCmd()`, `DS_AppProcessHK()`, `DS_AppProcessMsg()`, `DS_CmdAddMID()`, `DS_CmdCloseAll()`, `DS_CmdCloseFile()`, `DS_CmdGetFileInfo()`, `DS_CmdNoop()`, `DS_CmdReset()`, `DS_CmdSetAppState()`, `DS_CmdSetDestAge()`, `DS_CmdSetDestBase()`, `DS_CmdSetDestCount()`, `DS_CmdSetDestExt()`, `DS_CmdSetDestPath()`, `DS_CmdSetDestSize()`, `DS_CmdSetDestState()`, `DS_CmdSetDestType()`, `DS_CmdSetFilterFile()`, `DS_CmdSetFilterParms()`, `DS_CmdSetFilterType()`, `DS_FileCloseDest()`, `DS_FileCreateDest()`, `DS_FileCreateName()`, `DS_FileWriteError()`, `DS_TableCreateCDS()`, `DS_TableInit()`, `DS_TableUpdateCDS()`, `DS_TableVerifyDestFile()`, `DS_TableVerifyDestFileEntry()`, `DS_TableVerifyFilter()`, and `DS_TableVerifyFilterEntry()`.

## 10.23.2.2 CFE\_EVS\_SendEventWithAppID()

```
CFE_Status_t CFE_Status_t CFE_EVS_SendEventWithAppID (
    uint16 EventID,
```

```
    uint16 EventType,
    CFE_ES_AppId_t AppID,
    const char * Spec,
    ...
)
```

Generate a software event given the specified Application ID.

#### Description

This routine generates a software event message. If the EventID is not filtered, the event will be sent as a software bus message, optionally logged in the local event log, and optionally sent as an ASCII text string out the enabled output port(s). Note that this function should really only be used from within an API in order to preserve the context of an Application's event. In general, [CFE\\_EVS\\_SendEvent](#) should be used.

#### Assumptions, External Events, and Notes:

The Application ID must correspond to a registered application or core service. For messages outside the context of a registered application (for example early in app initialization or if registration fails) [CFE\\_ES\\_WriteToSysLog](#) can be used for reporting.

#### Parameters

in	<i>EventID</i>	A numeric literal used to uniquely identify an application event. The Event ID is defined and supplied by the application sending the event.
in	<i>EventType</i>	A numeric literal used to classify an event, one of: <ul style="list-style-type: none"> <li>• <a href="#">CFE_EVS_EventType_DEBUG</a></li> <li>• <a href="#">CFE_EVS_EventType_INFORMATION</a></li> <li>• <a href="#">CFE_EVS_EventType_ERROR</a></li> <li>• <a href="#">CFE_EVS_EventType_CRITICAL</a></li> </ul>
in	<i>AppID</i>	The Application ID from which the event message should appear.
in	<i>Spec</i>	A pointer to a null terminated text string (must not be null) describing the output format for the event. This is the same type of format string used for the ANSI <code>printf</code> function. Nominally the post-conversion string is limited to 80 characters, but this limit is configurable through the parameter <a href="#">CFE_MISSION_EVS_MAX_MESSAGE_LENGTH</a> . Characters beyond the limit will be truncated. Do not use floating point conversions (f, e, E, g, and G) in the format string unless your application will be running in a system that supports floating point arithmetic. Do not use non-printable characters (\t, \n, etc.) in the format string; they will mess up the formatting when the events are displayed on the ground system.

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_EVS_APP_NOT_REGISTERED</a>	Application Not Registered.

### Return values

<a href="#">CFE_EVS_APP_ILLEGAL_APP_ID</a>	Illegal Application ID.
<a href="#">CFE_EVS_INVALID_PARAMETER</a>	Invalid Pointer.

### See also

[CFE\\_EVS\\_SendEvent](#), [CFE\\_EVS\\_SendTimedEvent](#)

### 10.23.2.3 CFE\_EVS\_SendTimedEvent()

```
CFE_Status_t CFE_Status_t CFE_Status_t CFE_EVS_SendTimedEvent (
    CFE_TIME_SysTime_t Time,
    uint16 EventID,
    uint16 EventType,
    const char * Spec,
    ...
)
```

Generate a software event with a specific time tag.

#### Description

This routine is the same as [CFE\\_EVS\\_SendEvent](#) except that the caller specifies the event time instead of having the EVS use the current spacecraft time. This routine should be used in situations where an error condition is detected at one time, but the event message is reported at a later time.

#### Assumptions, External Events, and Notes:

This API only works within the context of a registered application or core service. For messages outside the context of a registered application (for example early in app initialization or if registration fails) [CFE\\_ES\\_WriteToSysLog](#) can be used for reporting.

#### Parameters

in	<i>Time</i>	The time to include in the event. This will usually be a time returned by the function <a href="#">CFE_TIME_GetTime</a> .
in	<i>EventID</i>	A numeric literal used to uniquely identify an application event. The <i>Event ID</i> is defined and supplied by the application sending the event.
in	<i>EventType</i>	A numeric literal used to classify an event, one of: <ul style="list-style-type: none"> <li>• <a href="#">CFE_EVS_EventType_DEBUG</a></li> <li>• <a href="#">CFE_EVS_EventType_INFORMATION</a></li> <li>• <a href="#">CFE_EVS_EventType_ERROR</a></li> <li>• <a href="#">CFE_EVS_EventType_CRITICAL</a></li> </ul>
in	<i>Spec</i>	A pointer to a null terminated text string (must not be null) describing the output format for the event. This is the same type of format string used for the ANSI <code>printf</code> function. Nominally the post-conversion string is limited to 80 characters, but this limit is configurable through the parameter <a href="#">CFE_MISSION_EVS_MAX_MESSAGE_LENGTH</a> . Characters beyond the limit will be truncated. Do not use floating point conversions (f, e, E, g, and G) in the format string unless your application will be running in a system that supports floating point arithmetic. Do not use non-printable characters (\t, \n, etc.) in the format string; they will mess up the formatting when

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#"><i>CFE_SUCCESS</i></a>	Successful execution.
<a href="#"><i>CFE_EVS_APP_NOT_REGISTERED</i></a>	Application Not Registered.
<a href="#"><i>CFE_EVS_APP_ILLEGAL_APP_ID</i></a>	Illegal Application ID.
<a href="#"><i>CFE_EVS_INVALID_PARAMETER</i></a>	Invalid Pointer.

**See also**

[CFE\\_EVS\\_SendEvent](#), [CFE\\_EVS\\_SendEventWithAppID](#)

## 10.24 cFE Reset Event Filter APIs

### Functions

- [CFE\\_Status\\_t CFE\\_EVS\\_ResetFilter \(uint16 EventID\)](#)  
*Resets the calling application's event filter for a single event ID.*
- [CFE\\_Status\\_t CFE\\_EVS\\_ResetAllFilters \(void\)](#)  
*Resets all of the calling application's event filters.*

#### 10.24.1 Detailed Description

#### 10.24.2 Function Documentation

##### 10.24.2.1 CFE\_EVS\_ResetAllFilters()

```
CFE_Status_t CFE_EVS_ResetAllFilters (
    void )
```

Resets all of the calling application's event filters.

#### Description

This routine resets all the calling application's event filter counters to zero, providing a quick and convenient method for resetting event filters.

#### Assumptions, External Events, and Notes:

None

#### Returns

Execution status below or from [CFE\\_ES\\_GetAppID](#), see [cFE Return Code Defines](#)

#### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_EVS_APP_NOT_REGISTERED</a>	Application Not Registered.
<a href="#">CFE_EVS_APP_ILLEGAL_APP_ID</a>	Illegal Application ID.

#### See also

[CFE\\_EVS\\_ResetFilter](#)

### 10.24.2.2 CFE\_EVS\_ResetFilter()

```
CFE_Status_t CFE_EVS_ResetFilter (
    uint16 EventID )
```

Resets the calling application's event filter for a single event ID.

#### Description

Resets the filter such that the next event is treated like the first. For example, if the filter was set to only send the first event, the next event following the reset would be sent.

#### Assumptions, External Events, and Notes:

None

#### Parameters

in	<i>EventID</i>	A numeric literal used to uniquely identify an application event. The <i>Event ID</i> is defined and supplied by the application sending the event.
----	----------------	---

#### Returns

Execution status below or from [CFE\\_ES\\_GetAppID](#), see [cFE Return Code Defines](#)

#### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_EVS_APP_NOT_REGISTERED</a>	Application Not Registered.
<a href="#">CFE_EVS_APP_ILLEGAL_APP_ID</a>	Illegal Application ID.
<a href="#">CFE_EVS_EVT_NOT_REGISTERED</a>	Event Not Registered.

#### See also

[CFE\\_EVS\\_ResetAllFilters](#)

## 10.25 cFE File Header Management APIs

### Functions

- [CFE\\_Status\\_t CFE\\_FS\\_ReadHeader \(CFE\\_FS\\_Header\\_t \\*Hdr, osal\\_id\\_t FileDes\)](#)  
*Read the contents of the Standard cFE File Header.*
- [void CFE\\_FS\\_InitHeader \(CFE\\_FS\\_Header\\_t \\*Hdr, const char \\*Description, uint32 SubType\)](#)  
*Initializes the contents of the Standard cFE File Header.*
- [CFE\\_Status\\_t CFE\\_FS\\_WriteHeader \(osal\\_id\\_t FileDes, CFE\\_FS\\_Header\\_t \\*Hdr\)](#)  
*Write the specified Standard cFE File Header to the specified file.*
- [CFE\\_Status\\_t CFE\\_FS\\_SetTimestamp \(osal\\_id\\_t FileDes, CFE\\_TIME\\_SysTime\\_t NewTimestamp\)](#)  
*Modifies the Time Stamp field in the Standard cFE File Header for the specified file.*

### 10.25.1 Detailed Description

### 10.25.2 Function Documentation

#### 10.25.2.1 CFE\_FS\_InitHeader()

```
void CFE_FS_InitHeader (
    CFE_FS_Header_t * Hdr,
    const char * Description,
    uint32 SubType )
```

Initializes the contents of the Standard cFE File Header.

#### Description

This API will clear the specified [CFE\\_FS\\_Header\\_t](#) variable and initialize the description field with the specified value

#### Parameters

in	<i>Hdr</i>	Pointer to a variable of type <a href="#">CFE_FS_Header_t</a> that will be cleared and initialized
in	<i>Description</i>	Initializes Header's Description (must not be null)
in	<i>SubType</i>	Initializes Header's SubType

#### See also

[CFE\\_FS\\_WriteHeader](#)

### 10.25.2.2 CFE\_FS\_ReadHeader()

```
CFE_Status_t CFE_FS_ReadHeader (
    CFE_FS_Header_t * Hdr,
    osal_id_t FileDes )
```

Read the contents of the Standard cFE File Header.

#### Description

This API will fill the specified [CFE\\_FS\\_Header\\_t](#) variable with the contents of the Standard cFE File Header of the file identified by the given File Descriptor.

#### Assumptions, External Events, and Notes:

1. The File has already been successfully opened using [OS\\_OpenCreate](#) and the caller has a legitimate File Descriptor.
2. File offset behavior: Agnostic on entry since it will move the offset to the start of the file, on success the offset will be at the end of the header, undefined offset behavior for error cases.

#### Parameters

out	<i>Hdr</i>	Pointer to a variable of type <a href="#">CFE_FS_Header_t</a> (must not be null) that will be filled with the contents of the Standard cFE File Header. *Hdr is the contents of the Standard cFE File Header for the specified file.
in	<i>FileDes</i>	File Descriptor obtained from a previous call to <a href="#">OS_OpenCreate</a> that is associated with the file whose header is to be read.

#### Returns

Bytes read or error status from OSAL

#### Return values

<a href="#">CFE_FS_BAD_ARGUMENT</a>	Bad Argument.
-------------------------------------	---------------

#### Note

This function invokes OSAL API routines and the current implementation may return OSAL error codes to the caller if failure occurs. In a future version of CFE, the status codes will be converted to a value in [cFE Return Code Defines](#).

#### See also

[CFE\\_FS\\_WriteHeader](#)

### 10.25.2.3 CFE\_FS\_SetTimestamp()

```
CFE_Status_t CFE_FS_SetTimestamp (
    osal_id_t FileDes,
    CFE_TIME_SysTime_t NewTimestamp )
```

Modifies the Time Stamp field in the Standard cFE File Header for the specified file.

#### Description

This API will modify the [timestamp](#) found in the Standard cFE File Header of the specified file. The timestamp will be replaced with the time specified by the caller.

#### Assumptions, External Events, and Notes:

1. The File has already been successfully opened using [OS\\_OpenCreate](#) and the caller has a legitimate File Descriptor.
2. The NewTimestamp field has been filled appropriately by the Application.
3. File offset behavior: Agnostic on entry since it will move the offset, on success the offset will be at the end of the time stamp, undefined offset behavior for error cases.

#### Parameters

in	<i>FileDes</i>	File Descriptor obtained from a previous call to <a href="#">OS_OpenCreate</a> that is associated with the file whose header is to be read.
in	<i>NewTimestamp</i>	A <a href="#">CFE_TIME_SysTime_t</a> data structure containing the desired time to be put into the file's Standard cFE File Header.

#### Returns

Execution status, see [cFE Return Code Defines](#), or OSAL status

#### Return values

<a href="#">CFE_STATUS_EXTERNAL_RESOURCE_FAILURE</a>	(return value only verified in coverage test) External failure.
<a href="#">CFE_SUCCESS</a>	Successful execution.

#### Note

This function invokes OSAL API routines and the current implementation may return OSAL error codes to the caller if failure occurs. In a future version of CFE, the status codes will be converted to a value in [cFE Return Code Defines](#).

#### 10.25.2.4 CFE\_FS\_WriteHeader()

```
CFE_Status_t CFE_FS_WriteHeader (
    osal_id_t FileDes,
    CFE_FS_Header_t * Hdr )
```

Write the specified Standard cFE File Header to the specified file.

#### Description

This API will output the specified [CFE\\_FS\\_Header\\_t](#) variable, with some fields automatically updated, to the specified file as the Standard cFE File Header. This API will automatically populate the following fields in the specified [CFE\\_FS\\_Header\\_t](#):

1. [ContentType](#) - Filled with 0x63464531 ('cFE1')
2. [Length](#) - Filled with the sizeof(CFE\_FS\_Header\_t)
3. [SpacecraftID](#) - Filled with the Spacecraft ID
4. [ProcessorID](#) - Filled with the Processor ID
5. [ApplicationID](#) - Filled with the Application ID
6. [TimeSeconds](#) - Filled with the Time, in seconds, as obtained by [CFE\\_TIME\\_GetTime](#)
7. [TimeSubSeconds](#) - Filled with the Time, subseconds, as obtained by [CFE\\_TIME\\_GetTime](#)

#### Assumptions, External Events, and Notes:

1. The File has already been successfully opened using [OS\\_OpenCreate](#) and the caller has a legitimate File Descriptor.
2. The SubType field has been filled appropriately by the Application.
3. The Description field has been filled appropriately by the Application.
4. File offset behavior: Agnostic on entry since it will move the offset to the start of the file, on success the offset will be at the end of the header, undefined offset behavior for error cases.

#### Parameters

in	<i>FileDes</i>	File Descriptor obtained from a previous call to <a href="#">OS_OpenCreate</a> that is associated with the file whose header is to be read.
out	<i>Hdr</i>	Pointer to a variable of type <a href="#">CFE_FS_Header_t</a> (must not be null) that will be filled with the contents of the Standard cFE File Header. *Hdr is the contents of the Standard cFE File Header for the specified file.

#### Returns

Bytes read or error status from OSAL

**Return values**

<a href="#"><i>CFE_FS_BAD_ARGUMENT</i></a>	Bad Argument.
--	---------------

**Note**

This function invokes OSAL API routines and the current implementation may return OSAL error codes to the caller if failure occurs. In a future version of CFE, the status codes will be converted to a value in [cFE Return Code Defines](#).

**See also**

[CFE\\_FS\\_ReadHeader](#)

Referenced by [DS\\_FileWriteHeader\(\)](#).

## 10.26 cFE File Utility APIs

### Functions

- `const char * CFE_FS_GetDefaultMountPoint (CFE_FS_FileCategory_t FileCategory)`  
*Get the default virtual mount point for a file category.*
- `const char * CFE_FS_GetDefaultExtension (CFE_FS_FileCategory_t FileCategory)`  
*Get the default filename extension for a file category.*
- `int32 CFE_FS_ParseInputFileNameEx (char *OutputBuffer, const char *InputBuffer, size_t OutputBufSize, size_t InputBufSize, const char *DefaultInput, const char *DefaultPath, const char *DefaultExtension)`  
*Parse a filename input from an input buffer into a local buffer.*
- `int32 CFE_FS_ParseInputFileName (char *OutputBuffer, const char *InputName, size_t OutputBufSize, CFE_FS_FileCategory_t FileCategory)`  
*Parse a filename string from the user into a local buffer.*
- `CFE_Status_t CFE_FS_ExtractFilenameFromPath (const char *OriginalPath, char *FileNameOnly)`  
*Extracts the filename from a unix style path and filename string.*
- `int32 CFE_FS_BackgroundFileDumpRequest (CFE_FS_FileWriteMetaData_t *Meta)`  
*Register a background file dump request.*
- `bool CFE_FS_BackgroundFileDumpIsPending (const CFE_FS_FileWriteMetaData_t *Meta)`  
*Query if a background file write request is currently pending.*

### 10.26.1 Detailed Description

### 10.26.2 Function Documentation

#### 10.26.2.1 CFE\_FS\_BackgroundFileDumpIsPending()

```
bool CFE_FS_BackgroundFileDumpIsPending (
    const CFE_FS_FileWriteMetaData_t * Meta )
```

Query if a background file write request is currently pending.

#### Description

This returns "true" while the request is on the background work queue. This returns "false" once the request is complete and removed from the queue.

#### Assumptions, External Events, and Notes:

None

#### Parameters

<code>in, out</code>	<code>Meta</code>	The background file write persistent state object (must not be null)
----------------------	-------------------	--

**Returns**

boolean value indicating if request is already pending

**Return values**

<i>true</i>	if request is pending
<i>false</i>	if request is not pending

**10.26.2.2 CFE\_FS\_BackgroundFileDumpRequest()**

```
int32 CFE_FS_BackgroundFileDumpRequest (
    CFE_FS_FileWriteMetaData_t * Meta )
```

Register a background file dump request.

**Description**

Puts the previously-initialized metadata into the pending request queue

**Assumptions, External Events, and Notes:**

Metadata structure should be stored in a persistent memory area (not on stack) as it must remain accessible by the file writer task throughout the asynchronous job operation.

**Parameters**

<i>in, out</i>	<i>Meta</i>	The background file write persistent state object (must not be null)
----------------	-------------	--

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_FS_BAD_ARGUMENT</i>	Bad Argument.
<i>CFE_FS_INVALID_PATH</i>	Invalid Path.
<i>CFE_STATUS_REQUEST_ALREADY_PENDING</i>	Request already pending.
<i>CFE_SUCCESS</i>	Successful execution.

**10.26.2.3 CFE\_FS\_ExtractFilenameFromPath()**

```
CFE_Status_t CFE_FS_ExtractFilenameFromPath (
```

```
const char * OriginalPath,
char * FileNameOnly )
```

Extracts the filename from a unix style path and filename string.

#### Description

This API will take the original unix path/filename combination and extract the base filename. Example: Given the path/filename : "/cf/apps/myapp.o.gz" this function will return the filename: "myapp.o.gz".

#### Assumptions, External Events, and Notes:

1. The paths and filenames used here are the standard unix style filenames separated by "/" characters.
2. The extracted filename (including terminator) is no longer than [OS\\_MAX\\_PATH\\_LEN](#)

#### Parameters

in	<i>OriginalPath</i>	The original path (must not be null)
out	<i>FileNameOnly</i>	The filename that is extracted from the path (must not be null)

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<a href="#">CFE_FS_BAD_ARGUMENT</a>	Bad Argument.
<a href="#">CFE_FS_FNAME_TOO_LONG</a>	Filename Too Long.
<a href="#">CFE_FS_INVALID_PATH</a>	Invalid Path.
<a href="#">CFE_SUCCESS</a>	Successful execution.

#### 10.26.2.4 CFE\_FS\_GetDefaultExtension()

```
const char* CFE_FS_GetDefaultExtension (
    CFE_FS_FileCategory_t FileCategory )
```

Get the default filename extension for a file category.

Certain file types may have an extension that varies from system to system. This is primarily an issue for application modules which are ".so" on Linux systems, ".dll" on Windows, ".o" on VxWorks, ".obj" on RTEMS, and so on.

This uses a combination of compile-time configuration and hints from the build environment to get the default/expected extension for a given file category.

#### Returns

String containing the extension

**Return values**

<code>NULL</code>	if no default extension is known for the given file category
-------------------	--

**10.26.2.5 CFE\_FS\_GetDefaultMountPoint()**

```
const char* CFE_FS_GetDefaultMountPoint (
    CFE_FS_FileCategory_t FileCategory )
```

Get the default virtual mount point for a file category.

Certain classes of files generally reside in a common directory, mainly either the persistent storage (/cf typically) or ram disk (/ram typically).

Ephemeral status files are generally in the ram disk while application modules and scripts are generally in the persistent storage.

This returns the expected directory for a given class of files in the form of a virtual OSAL mount point string.

**Returns**

String containing the mount point

**Return values**

<code>NULL</code>	if no mount point is known for the given file category
-------------------	--

**10.26.2.6 CFE\_FS\_ParseInputFileName()**

```
int32 CFE_FS_ParseInputFileName (
    char * OutputBuffer,
    const char * InputName,
    size_t OutputBufSize,
    CFE_FS_FileCategory_t FileCategory )
```

Parse a filename string from the user into a local buffer.

**Description**

Simplified API for [CFE\\_FS\\_ParseInputFileNameEx\(\)](#) where input is always known to be a non-empty, null terminated string and the fixed-length input buffer not needed. For instance this may be used where the input is a fixed string from cfe\_platform\_cfg.h or similar.

**Assumptions, External Events, and Notes:**

The parameters are organized such that this is basically like strncpy() with an extra argument, and existing file name accesses which use a direct copy can easily change to use this instead.

**See also**[CFE\\_FS\\_ParseInputFileNameEx\(\)](#)**Parameters**

<i>out</i>	<i>OutputBuffer</i>	Buffer to store result (must not be null).
<i>in</i>	<i>InputName</i>	A null terminated input string (must not be null).
<i>in</i>	<i>OutputBufSize</i>	Maximum Size of output buffer (must not be zero).
<i>in</i>	<i>FileCategory</i>	The generalized category of file (implies default path/extension)

**Returns**Execution status, see [cFE Return Code Defines](#)**10.26.2.7 CFE\_FS\_ParseInputFileNameEx()**

```
int32 CFE_FS_ParseInputFileNameEx (
    char * OutputBuffer,
    const char * InputBuffer,
    size_t OutputBufSize,
    size_t InputBufSize,
    const char * DefaultInput,
    const char * DefaultPath,
    const char * DefaultExtension )
```

Parse a filename input from an input buffer into a local buffer.

**Description**

This provides a more user friendly way to specify file names, using default values for the path and extension, which can vary from system to system.

If InputBuffer is null or its length is zero, then DefaultInput is used as if it was the content of the input buffer.

If either the pathname or extension is missing from the input, it will be added from defaults, with the complete fully-qualified filename stored in the output buffer.

**Assumptions, External Events, and Notes:**

1. The paths and filenames used here are the standard unix style filenames separated by "/" (path) and "." (extension) characters.
2. Input Buffer has a fixed max length. Parsing will not exceed InputBufSize, and does not need to be null terminated. However parsing will stop at the first null char, when the input is shorter than the maximum.

**Parameters**

out	<i>OutputBuffer</i>	Buffer to store result (must not be null).
in	<i>InputBuffer</i>	A input buffer that may contain a file name (e.g. from command) (must not be null).
in	<i>OutputBufSize</i>	Maximum Size of output buffer (must not be zero).
in	<i>InputBufSize</i>	Maximum Size of input buffer.
in	<i>DefaultInput</i>	Default value to use for input if InputBfffer is empty
in	<i>DefaultPath</i>	Default value to use for pathname if omitted from input
in	<i>DefaultExtension</i>	Default value to use for extension if omitted from input

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_FS_BAD_ARGUMENT</a>	Bad Argument.
<a href="#">CFE_FS_FNAME_TOO_LONG</a>	Filename Too Long.
<a href="#">CFE_FS_INVALID_PATH</a>	Invalid Path.
<a href="#">CFE_SUCCESS</a>	Successful execution.

## 10.27 cFE Generic Message APIs

### Functions

- `CFE_Status_t CFE_MSG_Init (CFE_MSG_Message_t *MsgPtr, CFE_SB_MsgId_t MsgId, CFE_MSG_Size_t Size)`

*Initialize a message.*

#### 10.27.1 Detailed Description

#### 10.27.2 Function Documentation

##### 10.27.2.1 CFE\_MSG\_Init()

```
CFE_Status_t CFE_MSG_Init (
    CFE_MSG_Message_t * MsgPtr,
    CFE_SB_MsgId_t MsgId,
    CFE_MSG_Size_t Size )
```

Initialize a message.

#### Description

This routine initialize a message. The entire message is set to zero (based on size), defaults are set, then the size and bits from MsgId are set.

#### Parameters

out	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
in	<i>MsgId</i>	MsgId that corresponds to message
in	<i>Size</i>	Total size of the message (used to set length field)

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<code>CFE_SUCCESS</code>	Successful execution.
<code>CFE_MSG_BAD_ARGUMENT</code>	Error - bad argument.

Referenced by DS\_AppProcessHK(), DS\_CmdGetFileInfo(), and DS\_FileTransmit().

## 10.28 cFE Message Primary Header APIs

### Functions

- `CFE_Status_t CFE_MSG_GetSize (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_Size_t *Size)`  
*Gets the total size of a message.*
- `CFE_Status_t CFE_MSG_SetSize (CFE_MSG_Message_t *MsgPtr, CFE_MSG_Size_t Size)`  
*Sets the total size of a message.*
- `CFE_Status_t CFE_MSG.GetType (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_Type_t *Type)`  
*Gets the message type.*
- `CFE_Status_t CFE_MSG_SetType (CFE_MSG_Message_t *MsgPtr, CFE_MSG_Type_t Type)`  
*Sets the message type.*
- `CFE_Status_t CFE_MSG_GetHeaderVersion (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_HeaderVersion_t *Version)`  
*Gets the message header version.*
- `CFE_Status_t CFE_MSG_SetHeaderVersion (CFE_MSG_Message_t *MsgPtr, CFE_MSG_HeaderVersion_t Version)`  
*Sets the message header version.*
- `CFE_Status_t CFE_MSG_GetHasSecondaryHeader (const CFE_MSG_Message_t *MsgPtr, bool *HasSecondary)`  
*Gets the message secondary header boolean.*
- `CFE_Status_t CFE_MSG_SetHasSecondaryHeader (CFE_MSG_Message_t *MsgPtr, bool HasSecondary)`  
*Sets the message secondary header boolean.*
- `CFE_Status_t CFE_MSG_GetApld (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_Apld_t *Apld)`  
*Gets the message application ID.*
- `CFE_Status_t CFE_MSG_SetApld (CFE_MSG_Message_t *MsgPtr, CFE_MSG_Apld_t Apld)`  
*Sets the message application ID.*
- `CFE_Status_t CFE_MSG_GetSegmentationFlag (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_SegmentationFlag_t *SegFlag)`  
*Gets the message segmentation flag.*
- `CFE_Status_t CFE_MSG_SetSegmentationFlag (CFE_MSG_Message_t *MsgPtr, CFE_MSG_SegmentationFlag_t SegFlag)`  
*Sets the message segmentation flag.*
- `CFE_Status_t CFE_MSG_GetSequenceCount (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_SequenceCount_t *SeqCnt)`  
*Gets the message sequence count.*
- `CFE_Status_t CFE_MSG_SetSequenceCount (CFE_MSG_Message_t *MsgPtr, CFE_MSG_SequenceCount_t SeqCnt)`  
*Sets the message sequence count.*
- `CFE_MSG_SequenceCount_t CFE_MSG_GetNextSequenceCount (CFE_MSG_SequenceCount_t SeqCnt)`  
*Gets the next sequence count value (rolls over if appropriate)*

#### 10.28.1 Detailed Description

#### 10.28.2 Function Documentation

### 10.28.2.1 CFE\_MSG\_GetApId()

```
CFE_Status_t CFE_MSG_GetApId (
    const CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_ApId_t * ApId )
```

Gets the message application ID.

#### Description

This routine gets the message application ID.

#### Parameters

in	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
out	<i>ApId</i>	Application ID (must not be null)

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_MSG_BAD_ARGUMENT</i>	Error - bad argument.

### 10.28.2.2 CFE\_MSG\_GetHasSecondaryHeader()

```
CFE_Status_t CFE_MSG_GetHasSecondaryHeader (
    const CFE_MSG_Message_t * MsgPtr,
    bool * HasSecondary )
```

Gets the message secondary header boolean.

#### Description

This routine gets the message secondary header boolean.

#### Parameters

in	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
out	<i>HasSecondary</i>	Has secondary header flag (must not be null)

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_MSG_BAD_ARGUMENT</i>	Error - bad argument.

**10.28.2.3 CFE\_MSG\_GetHeaderVersion()**

```
CFE_Status_t CFE_MSG_GetHeaderVersion (
    const CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_HeaderVersion_t * Version )
```

Gets the message header version.

**Description**

This routine gets the message header version.

**Parameters**

<i>in</i>	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
<i>out</i>	<i>Version</i>	Header version (must not be null)

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_MSG_BAD_ARGUMENT</i>	Error - bad argument.

**10.28.2.4 CFE\_MSG\_GetNextSequenceCount()**

```
CFE_MSG_SequenceCount_t CFE_MSG_GetNextSequenceCount (
    CFE_MSG_SequenceCount_t SeqCnt )
```

Gets the next sequence count value (rolls over if appropriate)

**Description**

Abstract method to get the next valid sequence count value. Will roll over to zero for any input value greater than or equal to the maximum possible sequence count value given the field in the header.

**Parameters**

in	<i>SeqCnt</i>	Sequence count
----	---------------	----------------

**Returns**

The next valid sequence count value

**10.28.2.5 CFE\_MSG\_GetSegmentationFlag()**

```
CFE_Status_t CFE_MSG_GetSegmentationFlag (
    const CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_SegmentationFlag_t * SegFlag )
```

Gets the message segmentation flag.

**Description**

This routine gets the message segmentation flag

**Parameters**

in	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
out	<i>SegFlag</i>	Segmentation flag (must not be null)

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_MSG_BAD_ARGUMENT</a>	Error - bad argument.

**10.28.2.6 CFE\_MSG\_GetSequenceCount()**

```
CFE_Status_t CFE_MSG_GetSequenceCount (
```

```
const CFE_MSG_Message_t * MsgPtr,
CFE_MSG_SequenceCount_t * SeqCnt )
```

Gets the message sequence count.

#### Description

This routine gets the message sequence count.

#### Parameters

in	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
out	<i>SeqCnt</i>	Sequence count (must not be null)

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_MSG_BAD_ARGUMENT</i>	Error - bad argument.

Referenced by DS\_IsPacketFiltered().

### 10.28.2.7 CFE\_MSG\_GetSize()

```
CFE_Status_t CFE_MSG_GetSize (
    const CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_Size_t * Size )
```

Gets the total size of a message.

#### Description

This routine gets the total size of the message.

#### Parameters

in	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
out	<i>Size</i>	Total message size (must not be null)

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_MSG_BAD_ARGUMENT</a>	Error - bad argument.

Referenced by DS\_AppProcessMsg(), DS\_CmdAddMID(), DS\_CmdCloseAll(), DS\_CmdCloseFile(), DS\_CmdGetFileInfo(), DS\_CmdNoop(), DS\_CmdReset(), DS\_CmdSetAppState(), DS\_CmdSetDestAge(), DS\_CmdSetDestBase(), DS\_CmdSetDestCount(), DS\_CmdSetDestExt(), DS\_CmdSetDestPath(), DS\_CmdSetDestSize(), DS\_CmdSetDestState(), DS\_CmdSetDestType(), DS\_CmdSetFilterFile(), DS\_CmdSetFilterParms(), DS\_CmdSetFilterType(), and DS\_FileSetupWrite().

**10.28.2.8 CFE\_MSG\_GetType()**

```
CFE_Status_t CFE_MSG_GetType (
    const CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_Type_t * Type )
```

Gets the message type.

**Description**

This routine gets the message type.

**Parameters**

in	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
out	<i>Type</i>	Message type (must not be null)

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_MSG_BAD_ARGUMENT</a>	Error - bad argument.

**10.28.2.9 CFE\_MSG\_SetApId()**

```
CFE_Status_t CFE_MSG_SetApId (
```

```
CFE_MSG_Message_t * MsgPtr,
CFE_MSG_ApId_t ApId )
```

Sets the message application ID.

#### Description

This routine sets the message application ID. Typically set at initialization using the MsgId, but API available to set bits that may not be included in MsgId.

#### Parameters

in, out	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
in	<i>ApId</i>	Application ID

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_MSG_BAD_ARGUMENT</i>	Error - bad argument.

### 10.28.2.10 CFE\_MSG\_SetHasSecondaryHeader()

```
CFE_Status_t CFE_MSG_SetHasSecondaryHeader (
    CFE_MSG_Message_t * MsgPtr,
    bool HasSecondary )
```

Sets the message secondary header boolean.

#### Description

This routine sets the message secondary header boolean. Typically only set within message initialization and not used by APPs.

#### Parameters

in, out	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
in	<i>HasSecondary</i>	Has secondary header flag

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_MSG_BAD_ARGUMENT</a>	Error - bad argument.

**10.28.2.11 CFE\_MSG\_SetHeaderVersion()**

```
CFE_Status_t CFE_MSG_SetHeaderVersion (
    CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_HeaderVersion_t Version )
```

Sets the message header version.

**Description**

This routine sets the message header version. Typically only set within message initialization and not used by APPs.

**Parameters**

<i>in, out</i>	<i>MsgPtr</i>	A pointer to the buffer that contains the message.
<i>in</i>	<i>Version</i>	Header version

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_MSG_BAD_ARGUMENT</a>	Error - bad argument.

**10.28.2.12 CFE\_MSG\_SetSegmentationFlag()**

```
CFE_Status_t CFE_MSG_SetSegmentationFlag (
    CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_SegmentationFlag_t SegFlag )
```

Sets the message segmentation flag.

**Description**

This routine sets the message segmentation flag.

**Parameters**

<i>in, out</i>	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
<i>in</i>	<i>SegFlag</i>	Segmentation flag

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#"><i>CFE_SUCCESS</i></a>	Successful execution.
<a href="#"><i>CFE_MSG_BAD_ARGUMENT</i></a>	Error - bad argument.

**10.28.2.13 CFE\_MSG\_SetSequenceCount()**

```
CFE_Status_t CFE_MSG_SetSequenceCount (
    CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_SequenceCount_t SeqCnt )
```

Sets the message sequence count.

**Description**

This routine sets the message sequence count.

**Parameters**

<i>in, out</i>	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
<i>in</i>	<i>SeqCnt</i>	Sequence count

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#"><i>CFE_SUCCESS</i></a>	Successful execution.
<a href="#"><i>CFE_MSG_BAD_ARGUMENT</i></a>	Error - bad argument.

### 10.28.2.14 CFE\_MSG\_SetSize()

```
CFE_Status_t CFE_MSG_SetSize (
    CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_Size_t Size )
```

Sets the total size of a message.

#### Description

This routine sets the total size of the message.

#### Parameters

in, out	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
in	<i>Size</i>	Total message size

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_MSG_BAD_ARGUMENT</i>	Error - bad argument.

### 10.28.2.15 CFE\_MSG\_SetType()

```
CFE_Status_t CFE_MSG_SetType (
    CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_Type_t Type )
```

Sets the message type.

#### Description

This routine sets the message type.

#### Parameters

in, out	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
in	<i>Type</i>	Message type

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#"><i>CFE_SUCCESS</i></a>	Successful execution.
<a href="#"><i>CFE_MSG_BAD_ARGUMENT</i></a>	Error - bad argument.

## 10.29 cFE Message Extended Header APIs

### Functions

- `CFE_Status_t CFE_MSG_GetEDSVersion (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_EDSVersion_t *Version)`  
*Gets the message EDS version.*
- `CFE_Status_t CFE_MSG_SetEDSVersion (CFE_MSG_Message_t *MsgPtr, CFE_MSG_EDSVersion_t Version)`  
*Sets the message EDS version.*
- `CFE_Status_t CFE_MSG_GetEndian (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_Endian_t *Endian)`  
*Gets the message endian.*
- `CFE_Status_t CFE_MSG_SetEndian (CFE_MSG_Message_t *MsgPtr, CFE_MSG_Endian_t Endian)`  
*Sets the message endian.*
- `CFE_Status_t CFE_MSG_GetPlaybackFlag (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_PlaybackFlag_t *PlayFlag)`  
*Gets the message playback flag.*
- `CFE_Status_t CFE_MSG_SetPlaybackFlag (CFE_MSG_Message_t *MsgPtr, CFE_MSG_PlaybackFlag_t PlayFlag)`  
*Sets the message playback flag.*
- `CFE_Status_t CFE_MSG_GetSubsystem (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_Subsystem_t *Subsystem)`  
*Gets the message subsystem.*
- `CFE_Status_t CFE_MSG_SetSubsystem (CFE_MSG_Message_t *MsgPtr, CFE_MSG_Subsystem_t Subsystem)`  
*Sets the message subsystem.*
- `CFE_Status_t CFE_MSG_GetSystem (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_System_t *System)`  
*Gets the message system.*
- `CFE_Status_t CFE_MSG_SetSystem (CFE_MSG_Message_t *MsgPtr, CFE_MSG_System_t System)`  
*Sets the message system.*

### 10.29.1 Detailed Description

### 10.29.2 Function Documentation

#### 10.29.2.1 CFE\_MSG\_GetEDSVersion()

```
CFE_Status_t CFE_MSG_GetEDSVersion (
    const CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_EDSVersion_t * Version )
```

Gets the message EDS version.

#### Description

This routine gets the message EDS version.

**Parameters**

in	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
out	<i>Version</i>	EDS Version (must not be null)

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_MSG_BAD_ARGUMENT</i>	Error - bad argument.

**10.29.2.2 CFE\_MSG\_GetEndian()**

```
CFE_Status_t CFE_MSG_GetEndian (
    const CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_Endian_t * Endian )
```

Gets the message endian.

**Description**

This routine gets the message endian.

**Parameters**

in	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
out	<i>Endian</i>	Endian (must not be null)

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_MSG_BAD_ARGUMENT</i>	Error - bad argument.

### 10.29.2.3 CFE\_MSG\_GetPlaybackFlag()

```
CFE_Status_t CFE_MSG_GetPlaybackFlag (
    const CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_PlaybackFlag_t * PlayFlag )
```

Gets the message playback flag.

#### Description

This routine gets the message playback flag.

#### Parameters

in	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
out	<i>PlayFlag</i>	Playback Flag (must not be null)

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_MSG_BAD_ARGUMENT</i>	Error - bad argument.

### 10.29.2.4 CFE\_MSG\_GetSubsystem()

```
CFE_Status_t CFE_MSG_GetSubsystem (
    const CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_Subsystem_t * Subsystem )
```

Gets the message subsystem.

#### Description

This routine gets the message subsystem

#### Parameters

in	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
out	<i>Subsystem</i>	Subsystem (must not be null)

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#"><i>CFE_SUCCESS</i></a>	Successful execution.
<a href="#"><i>CFE_MSG_BAD_ARGUMENT</i></a>	Error - bad argument.

**10.29.2.5 CFE\_MSG\_GetSystem()**

```
CFE_Status_t CFE_MSG_GetSystem (
    const CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_System_t * System )
```

Gets the message system.

**Description**

This routine gets the message system id

**Parameters**

<i>in</i>	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
<i>out</i>	<i>System</i>	System (must not be null)

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#"><i>CFE_SUCCESS</i></a>	Successful execution.
<a href="#"><i>CFE_MSG_BAD_ARGUMENT</i></a>	Error - bad argument.

**10.29.2.6 CFE\_MSG\_SetEDSVersion()**

```
CFE_Status_t CFE_MSG_SetEDSVersion (
    CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_EDSVersion_t Version )
```

Sets the message EDS version.

**Description**

This routine sets the message EDS version.

**Parameters**

in, out	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
in	<i>Version</i>	EDS Version

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_MSG_BAD_ARGUMENT</i>	Error - bad argument.

**10.29.2.7 CFE\_MSG\_SetEndian()**

```
CFE_Status_t CFE_MSG_SetEndian (
    CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_Endian_t Endian )
```

Sets the message endian.

**Description**

This routine sets the message endian. Invalid endian selection will set big endian.

**Parameters**

in, out	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
in	<i>Endian</i>	Endian

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_MSG_BAD_ARGUMENT</i>	Error - bad argument.

### 10.29.2.8 CFE\_MSG\_SetPlaybackFlag()

```
CFE_Status_t CFE_MSG_SetPlaybackFlag (
    CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_PlaybackFlag_t PlayFlag )
```

Sets the message playback flag.

#### Description

This routine sets the message playback flag.

#### Parameters

<i>in, out</i>	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
<i>in</i>	<i>PlayFlag</i>	Playback Flag

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<a href="#"><i>CFE_SUCCESS</i></a>	Successful execution.
<a href="#"><i>CFE_MSG_BAD_ARGUMENT</i></a>	Error - bad argument.

### 10.29.2.9 CFE\_MSG\_SetSubsystem()

```
CFE_Status_t CFE_MSG_SetSubsystem (
    CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_Subsystem_t Subsystem )
```

Sets the message subsystem.

#### Description

This routine sets the message subsystem. Some bits may be set at initialization using the MsgId, but API available to set bits that may not be included in MsgId.

#### Parameters

<i>in, out</i>	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
<i>in</i>	<i>Subsystem</i>	Subsystem

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_MSG_BAD_ARGUMENT</a>	Error - bad argument.

**10.29.2.10 CFE\_MSG\_SetSystem()**

```
CFE_Status_t CFE_MSG_SetSystem (
    CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_System_t System )
```

Sets the message system.

**Description**

This routine sets the message system id. Some bits may be set at initialization using the MsgId, but API available to set bits that may not be included in MsgId.

**Parameters**

in, out	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
in	<i>System</i>	System

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_MSG_BAD_ARGUMENT</a>	Error - bad argument.

## 10.30 cFE Message Secondary Header APIs

### Functions

- [CFE\\_Status\\_t CFE\\_MSG\\_GenerateChecksum \(CFE\\_MSG\\_Message\\_t \\*MsgPtr\)](#)  
*Calculates and sets the checksum of a message.*
- [CFE\\_Status\\_t CFE\\_MSG\\_ValidateChecksum \(const CFE\\_MSG\\_Message\\_t \\*MsgPtr, bool \\*isValid\)](#)  
*Validates the checksum of a message.*
- [CFE\\_Status\\_t CFE\\_MSG\\_SetFcnCode \(CFE\\_MSG\\_Message\\_t \\*MsgPtr, CFE\\_MSG\\_FcnCode\\_t FcnCode\)](#)  
*Sets the function code field in a message.*
- [CFE\\_Status\\_t CFE\\_MSG\\_GetFcnCode \(const CFE\\_MSG\\_Message\\_t \\*MsgPtr, CFE\\_MSG\\_FcnCode\\_t \\*FcnCode\)](#)  
*Gets the function code field from a message.*
- [CFE\\_Status\\_t CFE\\_MSG\\_GetMsgTime \(const CFE\\_MSG\\_Message\\_t \\*MsgPtr, CFE\\_TIME\\_SysTime\\_t \\*Time\)](#)  
*Gets the time field from a message.*
- [CFE\\_Status\\_t CFE\\_MSG\\_SetMsgTime \(CFE\\_MSG\\_Message\\_t \\*MsgPtr, CFE\\_TIME\\_SysTime\\_t NewTime\)](#)  
*Sets the time field in a message.*

### 10.30.1 Detailed Description

### 10.30.2 Function Documentation

#### 10.30.2.1 CFE\_MSG\_GenerateChecksum()

```
CFE_Status_t CFE_MSG_GenerateChecksum (
    CFE_MSG_Message_t * MsgPtr )
```

Calculates and sets the checksum of a message.

#### Description

This routine calculates the checksum of a message according to an implementation-defined algorithm. Then, it sets the checksum field in the message with the calculated value. The contents and location of this field will depend on the underlying implementation of messages. It may be a checksum, a CRC, or some other algorithm.

#### Assumptions, External Events, and Notes:

- If the underlying implementation of messages does not include a checksum field, then this routine will return [CFE\\_MSG\\_WRONG\\_MSG\\_TYPE](#)

#### Parameters

in, out	MsgPtr	A pointer to the buffer that contains the message (must not be null).
---------	--------	---

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_MSG_BAD_ARGUMENT</i>	Error - bad argument.
<i>CFE_MSG_WRONG_MSG_TYPE</i>	Error - wrong type.

**10.30.2.2 CFE\_MSG\_GetFcnCode()**

```
CFE_Status_t CFE_MSG_GetFcnCode (
    const CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_FcnCode_t * FcnCode )
```

Gets the function code field from a message.

**Description**

This routine gets the function code from a message.

**Assumptions, External Events, and Notes:**

- If the underlying implementation of messages does not include a function code field, then this routine will set FcnCode to zero and return [CFE\\_MSG\\_WRONG\\_MSG\\_TYPE](#)

**Parameters**

in	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
out	<i>FcnCode</i>	The function code from the message (must not be null)

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_MSG_BAD_ARGUMENT</i>	Error - bad argument.
<i>CFE_MSG_WRONG_MSG_TYPE</i>	Error - wrong type.

Referenced by DS\_AppProcessCmd().

### 10.30.2.3 CFE\_MSG\_GetMsgTime()

```
CFE_Status_t CFE_MSG_GetMsgTime (
    const CFE_MSG_Message_t * MsgPtr,
    CFE_TIME_SysTime_t * Time )
```

Gets the time field from a message.

#### Description

This routine gets the time from a message.

#### Assumptions, External Events, and Notes:

- If the underlying implementation of messages does not include a time field, then this routine will set Time to zero and return [CFE\\_MSG\\_WRONG\\_MSG\\_TYPE](#)
- Note default implementation of command messages do not have a time field.

#### Parameters

in	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
out	<i>Time</i>	Time from the message (must not be null)

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_MSG_BAD_ARGUMENT</a>	Error - bad argument.
<a href="#">CFE_MSG_WRONG_MSG_TYPE</a>	Error - wrong type.

Referenced by DS\_IsPacketFiltered().

### 10.30.2.4 CFE\_MSG\_SetFcnCode()

```
CFE_Status_t CFE_MSG_SetFcnCode (
    CFE_MSG_Message_t * MsgPtr,
    CFE_MSG_FcnCode_t FcnCode )
```

Sets the function code field in a message.

#### Description

This routine sets the function code of a message.

**Assumptions, External Events, and Notes:**

- If the underlying implementation of messages does not include a function code field, then this routine will do nothing to the message contents and will return [CFE\\_MSG\\_WRONG\\_MSG\\_TYPE](#).

**Parameters**

<i>in, out</i>	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
<i>in</i>	<i>FcnCode</i>	The function code to include in the message.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_MSG_BAD_ARGUMENT</a>	Error - bad argument.
<a href="#">CFE_MSG_WRONG_MSG_TYPE</a>	Error - wrong type.

**10.30.2.5 CFE\_MSG\_SetMsgTime()**

```
CFE_Status_t CFE_MSG_SetMsgTime (
    CFE_MSG_Message_t * MsgPtr,
    CFE_TIME_SysTime_t NewTime )
```

Sets the time field in a message.

**Description**

This routine sets the time of a message. Most applications will want to use [CFE\\_SB\\_TimeStampMsg](#) instead of this function. But, when needed, this API can be used to set multiple messages with identical time stamps.

**Assumptions, External Events, and Notes:**

- If the underlying implementation of messages does not include a time field, then this routine will do nothing to the message contents and will return [CFE\\_MSG\\_WRONG\\_MSG\\_TYPE](#).
- Note default implementation of command messages do not have a time field.

**Parameters**

<i>in, out</i>	<i>MsgPtr</i>	A pointer to the message (must not be null).
<i>in</i>	<i>NewTime</i>	The time to include in the message. This will usually be a time from <a href="#">CFE_TIME_GetTime</a> .

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_MSG_BAD_ARGUMENT</i>	Error - bad argument.
<i>CFE_MSG_WRONG_MSG_TYPE</i>	Error - wrong type.

**10.30.2.6 CFE\_MSG\_ValidateChecksum()**

```
CFE_Status_t CFE_MSG_ValidateChecksum (
    const CFE_MSG_Message_t * MsgPtr,
    bool * IsValid )
```

Validates the checksum of a message.

**Description**

This routine validates the checksum of a message according to an implementation-defined algorithm.

**Assumptions, External Events, and Notes:**

- If the underlying implementation of messages does not include a checksum field, then this routine will return *CFE\_MSG\_WRONG\_MSG\_TYPE* and set the *IsValid* parameter false.

**Parameters**

in	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null). This must point to the first byte of the message header.
out	<i>IsValid</i>	Checksum validation result (must not be null) <ul style="list-style-type: none"> <li>• true - valid</li> <li>• false - invalid or not supported/implemented</li> </ul>

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_MSG_BAD_ARGUMENT</i>	Error - bad argument.
<i>CFE_MSG_WRONG_MSG_TYPE</i>	Error - wrong type.

## 10.31 cFE Message Id APIs

### Functions

- `CFE_Status_t CFE_MSG_GetMsgId (const CFE_MSG_Message_t *MsgPtr, CFE_SB_MsgId_t *MsgId)`  
*Gets the message id from a message.*
- `CFE_Status_t CFE_MSG_SetMsgId (CFE_MSG_Message_t *MsgPtr, CFE_SB_MsgId_t MsgId)`  
*Sets the message id bits in a message.*
- `CFE_Status_t CFE_MSG_GetTypeFromMsgId (CFE_SB_MsgId_t MsgId, CFE_MSG_Type_t *Type)`  
*Gets message type using message ID.*

### 10.31.1 Detailed Description

### 10.31.2 Function Documentation

#### 10.31.2.1 CFE\_MSG\_GetMsgId()

```
CFE_Status_t CFE_MSG_GetMsgId (
    const CFE_MSG_Message_t * MsgPtr,
    CFE_SB_MsgId_t * MsgId )
```

Gets the message id from a message.

#### Description

This routine gets the message id from a message. The message id is a hash of bits in the message header, used by the software bus for routing. Message id needs to be unique for each endpoint in the system.

#### Parameters

in	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
out	<i>MsgId</i>	Message id (must not be null)

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<code>CFE_SUCCESS</code>	Successful execution.
<code>CFE_MSG_BAD_ARGUMENT</code>	Error - bad argument.

Referenced by DS\_AppProcessMsg().

### 10.31.2.2 CFE\_MSG\_GetTypeFromMsgId()

```
CFE_Status_t CFE_MSG_GetTypeFromMsgId (
    CFE_SB_MsgId_t MsgId,
    CFE_MSG_Type_t * Type )
```

Gets message type using message ID.

#### Description

This routine gets the message type using the message ID

#### Parameters

in	<i>MsgId</i>	Message id
out	<i>Type</i>	Message type (must not be null)

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_MSG_BAD_ARGUMENT</a>	Error - bad argument.

### 10.31.2.3 CFE\_MSG\_SetMsgId()

```
CFE_Status_t CFE_MSG_SetMsgId (
    CFE_MSG_Message_t * MsgPtr,
    CFE_SB_MsgId_t MsgId )
```

Sets the message id bits in a message.

#### Description

This routine sets the message id bits in a message. The message id is a hash of bits in the message header, used by the software bus for routing. Message id needs to be unique for each endpoint in the system.

#### Note

This API only sets the bits in the header that make up the message ID. No other values in the header are modified.

The user should ensure that this function is only called with a valid MsgId parameter value. If called with an invalid value, the results are implementation-defined. The implementation may or may not return the error code [CFE\\_MSG\\_BAD\\_ARGUMENT](#) in this case.

**Parameters**

in, out	<i>MsgPtr</i>	A pointer to the buffer that contains the message (must not be null).
in	<i>MsgId</i>	Message id

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#"><i>CFE_SUCCESS</i></a>	Successful execution.
<a href="#"><i>CFE_MSG_BAD_ARGUMENT</i></a>	Error - bad argument.

## 10.32 cFE Pipe Management APIs

### Functions

- [CFE\\_Status\\_t CFE\\_SB\\_CreatePipe \(CFE\\_SB\\_Pipeld\\_t \\*PipeldPtr, uint16 Depth, const char \\*PipeName\)](#)  
*Creates a new software bus pipe.*
- [CFE\\_Status\\_t CFE\\_SB\\_DeletePipe \(CFE\\_SB\\_Pipeld\\_t Pipeld\)](#)  
*Delete a software bus pipe.*
- [CFE\\_Status\\_t CFE\\_SB\\_Pipeld\\_ToIndex \(CFE\\_SB\\_Pipeld\\_t PipeID, uint32 \\*Idx\)](#)  
*Obtain an index value correlating to an SB Pipe ID.*
- [CFE\\_Status\\_t CFE\\_SB\\_SetPipeOpts \(CFE\\_SB\\_Pipeld\\_t Pipeld, uint8 Opts\)](#)  
*Set options on a pipe.*
- [CFE\\_Status\\_t CFE\\_SB\\_GetPipeOpts \(CFE\\_SB\\_Pipeld\\_t Pipeld, uint8 \\*OptsPtr\)](#)  
*Get options on a pipe.*
- [CFE\\_Status\\_t CFE\\_SB\\_GetPipeName \(char \\*PipeNameBuf, size\\_t PipeNameSize, CFE\\_SB\\_Pipeld\\_t Pipeld\)](#)  
*Get the pipe name for a given id.*
- [CFE\\_Status\\_t CFE\\_SB\\_GetPipeldByName \(CFE\\_SB\\_Pipeld\\_t \\*PipeldPtr, const char \\*PipeName\)](#)  
*Get pipe id by pipe name.*

### 10.32.1 Detailed Description

### 10.32.2 Function Documentation

#### 10.32.2.1 CFE\_SB\_CreatePipe()

```
CFE_Status_t CFE_SB_CreatePipe (
    CFE_SB_Pipeld_t * PipeIdPtr,
    uint16 Depth,
    const char * PipeName )
```

Creates a new software bus pipe.

#### Description

This routine creates and initializes an input pipe that the calling application can use to receive software bus messages. By default, no messages are routed to the new pipe. So, the application must use [CFE\\_SB\\_Subscribe](#) to specify which messages it wants to receive on this pipe.

#### Assumptions, External Events, and Notes:

None

**Parameters**

<i>out</i>	<i>PipeIdPtr</i>	A pointer to a variable of type <a href="#">CFE_SB_PipeId_t</a> (must not be null), which will be filled in with the pipe ID information by the <a href="#">CFE_SB_CreatePipe</a> routine. *PipeIdPtr is the identifier for the created pipe.
<i>in</i>	<i>Depth</i>	The maximum number of messages that will be allowed on this pipe at one time.
<i>in</i>	<i>PipeName</i>	A string (must not be null) to be used to identify this pipe in error messages and routing information telemetry. The string must be no longer than <a href="#">OS_MAX_API_NAME</a> (including terminator). Longer strings will be truncated.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_SB_BAD_ARGUMENT</a>	Bad Argument.
<a href="#">CFE_SB_MAX_PIPES_MET</a>	Max Pipes Met.
<a href="#">CFE_SB_PIPE_CR_ERR</a>	Pipe Create Error.

**See also**

[CFE\\_SB\\_DeletePipe](#) [CFE\\_SB\\_GetPipeOpts](#) [CFE\\_SB\\_SetPipeOpts](#) [CFE\\_SB\\_GetPipeIdByName](#)

Referenced by `DS_AppInitialize()`.

**10.32.2.2 CFE\_SB\_DeletePipe()**

```
CFE_Status_t CFE_SB_DeletePipe (
    CFE_SB_PipeId_t PipeId )
```

Delete a software bus pipe.

**Description**

This routine deletes an input pipe and cleans up all data structures associated with the pipe. All subscriptions made for this pipe by calls to [CFE\\_SB\\_Subscribe](#) will be automatically removed from the SB routing tables. Any messages in the pipe will be discarded.

Applications should not call this routine for all of their SB pipes as part of their orderly shutdown process, as the pipe will be deleted by the support framework at the appropriate time.

**Assumptions, External Events, and Notes:**

None

**Parameters**

in	<i>PipeId</i>	The pipe ID (obtained previously from <a href="#">CFE_SB_CreatePipe</a> ) of the pipe to be deleted.
----	---------------	--

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_SB_BAD_ARGUMENT</a>	Bad Argument.

**See also**

[CFE\\_SB\\_CreatePipe](#) [CFE\\_SB\\_GetPipeOpts](#) [CFE\\_SB\\_SetPipeOpts](#) [CFE\\_SB\\_GetPipeldByName](#)

**10.32.2.3 CFE\_SB\_GetPipeldByName()**

```
CFE_Status_t CFE_SB_GetPipeldByName (
    CFE_SB_Pipeld_t * PipeldPtr,
    const char * PipeName )
```

Get pipe id by pipe name.

**Description**

This routine finds the pipe id for a pipe name.

**Parameters**

in	<i>PipeName</i>	The name of the pipe (must not be null).
out	<i>PipeldPtr</i>	The Pipeld for that name (must not be null).

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_SB_BAD_ARGUMENT</a>	Bad Argument.

**See also**

[CFE\\_SB\\_CreatePipe](#) [CFE\\_SB\\_DeletePipe](#) [CFE\\_SB\\_SetPipeOpts](#) [CFE\\_SB\\_PIPEOPTS\\_IGNOREMINE](#)

**10.32.2.4 CFE\_SB\_GetPipeName()**

```
CFE_Status_t CFE_SB_GetPipeName (
    char * PipeNameBuf,
    size_t PipeNameSize,
    CFE_SB_PipeId_t PipeId )
```

Get the pipe name for a given id.

**Description**

This routine finds the pipe name for a pipe id.

**Parameters**

out	<i>PipeNameBuf</i>	The buffer to receive the pipe name (must not be null).
in	<i>PipeNameSize</i>	The size (in chars) of the PipeName buffer (must not be zero).
in	<i>PipeId</i>	The PipeId for that name.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_SB_BAD_ARGUMENT</a>	Bad Argument.

**See also**

[CFE\\_SB\\_CreatePipe](#) [CFE\\_SB\\_DeletePipe](#) [CFE\\_SB\\_SetPipeOpts](#) [CFE\\_SB\\_GetPipeIdByName](#)

**10.32.2.5 CFE\_SB\_GetPipeOpts()**

```
CFE_Status_t CFE_SB_GetPipeOpts (
    CFE_SB_PipeId_t PipeId,
    uint8 * OptsPtr )
```

Get options on a pipe.

**Description**

This routine gets the current options on a pipe.

**Parameters**

in	<i>PipeId</i>	The pipe ID of the pipe to get options from.
out	<i>OptsPtr</i>	A bit field of options: <a href="#">cFE SB Pipe options</a> (must not be null)

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_SB_BAD_ARGUMENT</a>	Bad Argument.

**See also**

[CFE\\_SB\\_CreatePipe](#) [CFE\\_SB\\_DeletePipe](#) [CFE\\_SB\\_SetPipeOpts](#) [CFE\\_SB\\_GetPipeIDByName](#) [CFE\\_SB\\_PIP←EOPTS\\_IGNOREMINE](#)

**10.32.2.6 CFE\_SB\_PipeID\_ToIndex()**

```
CFE_Status_t CFE_SB_PipeID_ToIndex (
    CFE_SB_PipeID_t PipeID,
    uint32 * Idx )
```

Obtain an index value correlating to an SB Pipe ID.

This calculates a zero based integer value that may be used for indexing into a local resource table/array.

Index values are only guaranteed to be unique for resources of the same type. For instance, the indices corresponding to two [valid] application IDs will never overlap, but the index of a pipe ID and an app ID may be the same. Furthermore, indices may be reused if a resource is deleted and re-created.

**Note**

There is no inverse of this function - indices cannot be converted back to the original PipeID value. The caller should retain the original ID for future use.

**Parameters**

in	<i>PipeID</i>	Pipe ID to convert
out	<i>Idx</i>	Buffer where the calculated index will be stored (must not be null)

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_ES_ERR_RESOURCEID_NOT_VALID</i>	Resource ID is not valid.

**10.32.2.7 CFE\_SB\_SetPipeOpts()**

```
CFE_Status_t CFE_SB_SetPipeOpts (
    CFE_SB_PipeId_t PipeId,
    uint8 Opts )
```

Set options on a pipe.

**Description**

This routine sets (or clears) options to alter the pipe's behavior. Options are (re)set every call to this routine.

**Parameters**

in	<i>PipeId</i>	The pipe ID of the pipe to set options on.
in	<i>Opts</i>	A bit field of options: <a href="#">cFE SB Pipe options</a>

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_SB_BAD_ARGUMENT</i>	Bad Argument.

**See also**

[CFE\\_SB\\_CreatePipe](#) [CFE\\_SB\\_DeletePipe](#) [CFE\\_SB\\_GetPipeOpts](#) [CFE\\_SB\\_GetPipeIdByName](#) [CFE\\_SB\\_PIPE\\_OPTS\\_IGNOREMINE](#)

## 10.33 cFE Message Subscription Control APIs

### Functions

- [`CFE\_Status\_t CFE\_SB\_SubscribeEx \(CFE\_SB\_MsgId\_t MsgId, CFE\_SB\_PipeId\_t PipeId, CFE\_SB\_Qos\_t Quality, uint16 MsgLim\)`](#)  
*Subscribe to a message on the software bus.*
- [`CFE\_Status\_t CFE\_SB\_Subscribe \(CFE\_SB\_MsgId\_t MsgId, CFE\_SB\_PipeId\_t PipeId\)`](#)  
*Subscribe to a message on the software bus with default parameters.*
- [`CFE\_Status\_t CFE\_SB\_SubscribeLocal \(CFE\_SB\_MsgId\_t MsgId, CFE\_SB\_PipeId\_t PipeId, uint16 MsgLim\)`](#)  
*Subscribe to a message while keeping the request local to a cpu.*
- [`CFE\_Status\_t CFE\_SB\_Unsubscribe \(CFE\_SB\_MsgId\_t MsgId, CFE\_SB\_PipeId\_t PipeId\)`](#)  
*Remove a subscription to a message on the software bus.*
- [`CFE\_Status\_t CFE\_SB\_UnsubscribeLocal \(CFE\_SB\_MsgId\_t MsgId, CFE\_SB\_PipeId\_t PipeId\)`](#)  
*Remove a subscription to a message on the software bus on the current CPU.*

#### 10.33.1 Detailed Description

#### 10.33.2 Function Documentation

##### 10.33.2.1 CFE\_SB\_Subscribe()

```
CFE_Status_t CFE_SB_Subscribe (
    CFE_SB_MsgId_t MsgId,
    CFE_SB_PipeId_t PipeId )
```

Subscribe to a message on the software bus with default parameters.

#### Description

This routine adds the specified pipe to the destination list for the specified message ID. This is the same as [CFE\\_SB\\_SubscribeEx](#) with the Quality field set to [CFE\\_SB\\_DEFAULT\\_QOS](#) and MsgLim set to [CFE\\_PLATFORM\\_SB\\_DEFAULT\\_MSG\\_LIMIT](#) (4).

#### Assumptions, External Events, and Notes:

Note: As subscriptions are received, the destinations are added to the head of a linked list. During the sending of a message, the list is traversed beginning at the head of the list. Therefore the message will first be sent to the last subscriber. If an application has timing constraints and needs to receive a message in the shortest possible time, the developer may consider holding off its subscription until other applications have subscribed to the message.

#### Parameters

in	<code>MsgId</code>	The message ID of the message to be subscribed to.
in	<code>PipeId</code>	The pipe ID of the pipe the subscribed message should be sent to.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#"><i>CFE_SUCCESS</i></a>	Successful execution.
<a href="#"><i>CFE_SB_MAX_MSGS_MET</i></a>	(return value only verified in coverage test) Max Messages Met.
<a href="#"><i>CFE_SB_MAX_DESTS_MET</i></a>	Max Destinations Met.
<a href="#"><i>CFE_SB_BAD_ARGUMENT</i></a>	Bad Argument.
<a href="#"><i>CFE_SB_BUF_ALOC_ERR</i></a>	(return value only verified in coverage test) Buffer Allocation Error.

**See also**

[CFE\\_SB\\_SubscribeEx](#), [CFE\\_SB\\_SubscribeLocal](#), [CFE\\_SB\\_Unsubscribe](#), [CFE\\_SB\\_UnsubscribeLocal](#)

Referenced by `DS_AppInitialize()`.

**10.33.2.2 CFE\_SB\_SubscribeEx()**

```
CFE_Status_t CFE_SB_SubscribeEx (
    CFE_SB_MsgId_t MsgId,
    CFE_SB_PipeId_t PipeId,
    CFE_SB_Qos_t Quality,
    uint16 MsgLim )
```

Subscribe to a message on the software bus.

**Description**

This routine adds the specified pipe to the destination list associated with the specified message ID.

**Assumptions, External Events, and Notes:**

Note: As subscriptions are received, the destinations are added to the head of a linked list. During the sending of a message, the list is traversed beginning at the head of the list. Therefore the message will first be sent to the last subscriber. If an application has timing constraints and needs to receive a message in the shortest possible time, the developer may consider holding off its subscription until other applications have subscribed to the message.

**Parameters**

in	<i>MsgId</i>	The message ID of the message to be subscribed to.
in	<i>PipeId</i>	The pipe ID of the pipe the subscribed message should be sent to.
in	<i>Quality</i>	The requested Quality of Service (QoS) required of the messages. Most callers will use <a href="#"><i>CFE_SB_DEFAULT_QOS</i></a> for this parameter.
in	<i>MsgLim</i>	The maximum number of messages with this Message ID to allow in this pipe at the same time.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#"><i>CFE_SUCCESS</i></a>	Successful execution.
<a href="#"><i>CFE_SB_MAX_MSGS_MET</i></a>	(return value only verified in coverage test) Max Messages Met.
<a href="#"><i>CFE_SB_MAX_DESTS_MET</i></a>	Max Destinations Met.
<a href="#"><i>CFE_SB_BAD_ARGUMENT</i></a>	Bad Argument.
<a href="#"><i>CFE_SB_BUF_ALOC_ERR</i></a>	(return value only verified in coverage test) Buffer Allocation Error.

**See also**

[CFE\\_SB\\_Subscribe](#), [CFE\\_SB\\_SubscribeLocal](#), [CFE\\_SB\\_Unsubscribe](#), [CFE\\_SB\\_UnsubscribeLocal](#)

Referenced by [DS\\_CmdAddMID\(\)](#), and [DS\\_TableSubscribe\(\)](#).

**10.33.2.3 CFE\_SB\_SubscribeLocal()**

```
CFE_Status_t CFE_SB_SubscribeLocal (
    CFE_SB_MsgId_t MsgId,
    CFE_SB_PipeId_t PipeId,
    uint16 MsgLim )
```

Subscribe to a message while keeping the request local to a cpu.

**Description**

This routine adds the specified pipe to the destination list for the specified message ID. This is similar to [CFE\\_SB\\_SubscribeEx](#) with the Quality field set to [\*CFE\\_SB\\_DEFAULT\\_QOS\*](#) and MsgLim set to [\*CFE\\_PLATFORM\\_SB\\_DEFAULT\\_MSG\\_LIMIT\*](#), but will not report the subscription.

Software Bus Network (SBN) application is an example use case, where local subscriptions should not be reported to peers.

**Assumptions, External Events, and Notes:**

- This API is typically only used by Software Bus Network (SBN) Application

**Parameters**

in	<i>MsgId</i>	The message ID of the message to be subscribed to.
in	<i>PipeId</i>	The pipe ID of the pipe the subscribed message should be sent to.
in	<i>MsgLim</i>	The maximum number of messages with this Message ID to allow in this pipe at the same time.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#"><i>CFE_SUCCESS</i></a>	Successful execution.
<a href="#"><i>CFE_SB_MAX_MSGS_MET</i></a>	(return value only verified in coverage test) Max Messages Met.
<a href="#"><i>CFE_SB_MAX_DESTS_MET</i></a>	Max Destinations Met.
<a href="#"><i>CFE_SB_BAD_ARGUMENT</i></a>	Bad Argument.
<a href="#"><i>CFE_SB_BUF_ALOC_ERR</i></a>	(return value only verified in coverage test) Buffer Allocation Error.

**See also**

[CFE\\_SB\\_Subscribe](#), [CFE\\_SB\\_SubscribeEx](#), [CFE\\_SB\\_Unsubscribe](#), [CFE\\_SB\\_UnsubscribeLocal](#)

**10.33.2.4 CFE\_SB\_Unsubscribe()**

```
CFE_Status_t CFE_SB_Unsubscribe (
    CFE_SB_MsgId_t MsgId,
    CFE_SB_PipeId_t PipeId )
```

Remove a subscription to a message on the software bus.

**Description**

This routine removes the specified pipe from the destination list for the specified message ID.

**Assumptions, External Events, and Notes:**

If the Pipe is not subscribed to MsgId, the [CFE\\_SB\\_UNSUB\\_NO\\_SUBS\\_EID](#) event will be generated and [\*CFE\\_SUCCESS\*](#) will be returned

**Parameters**

in	<i>MsgId</i>	The message ID of the message to be unsubscribed.
in	<i>PipeId</i>	The pipe ID of the pipe the subscribed message should no longer be sent to.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_SB_BAD_ARGUMENT</a>	Bad Argument.

**See also**

[CFE\\_SB\\_Subscribe](#), [CFE\\_SB\\_SubscribeEx](#), [CFE\\_SB\\_SubscribeLocal](#), [CFE\\_SB\\_UnsubscribeLocal](#)

Referenced by [DS\\_TableUnsubscribe\(\)](#).

**10.33.2.5 CFE\_SB\_UnsubscribeLocal()**

```
CFE_Status_t CFE_SB_UnsubscribeLocal (
    CFE_SB_MsgId_t MsgId,
    CFE_SB_PipeId_t PipeId )
```

Remove a subscription to a message on the software bus on the current CPU.

**Description**

This routine removes the specified pipe from the destination list for the specified message ID on the current CPU.

**Assumptions, External Events, and Notes:**

This API is typically only used by Software Bus Network (SBN) Application. If the Pipe is not subscribed to MsgId, the [CFE\\_SB\\_UNSUB\\_NO\\_SUBS\\_EID](#) event will be generated and [CFE\\_SUCCESS](#) will be returned

**Parameters**

in	<i>MsgId</i>	The message ID of the message to be unsubscribed.
in	<i>PipeId</i>	The pipe ID of the pipe the subscribed message should no longer be sent to.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_SB_BAD_ARGUMENT</a>	Bad Argument.

**See also**

[CFE\\_SB\\_Subscribe](#), [CFE\\_SB\\_SubscribeEx](#), [CFE\\_SB\\_SubscribeLocal](#), [CFE\\_SB\\_Unsubscribe](#)

## 10.34 cFE Send/Receive Message APIs

### Functions

- `CFE_Status_t CFE_SB_TransmitMsg (const CFE_MSG_Message_t *MsgPtr, bool IncrementSequenceCount)`  
*Transmit a message.*
- `CFE_Status_t CFE_SB_ReceiveBuffer (CFE_SB_Buffer_t **BufPtr, CFE_SB_PipeId_t PipeId, int32 TimeOut)`  
*Receive a message from a software bus pipe.*

#### 10.34.1 Detailed Description

#### 10.34.2 Function Documentation

##### 10.34.2.1 CFE\_SB\_ReceiveBuffer()

```
CFE_Status_t CFE_SB_ReceiveBuffer (
    CFE_SB_Buffer_t ** BufPtr,
    CFE_SB_PipeId_t PipeId,
    int32 TimeOut )
```

Receive a message from a software bus pipe.

#### Description

This routine retrieves the next message from the specified pipe. If the pipe is empty, this routine will block until either a new message comes in or the timeout value is reached.

#### Assumptions, External Events, and Notes:

Note - If an error occurs in this API, the \*BufPtr value may be NULL or random. Therefore, it is recommended that the return code be tested for CFE\_SUCCESS before processing the message.

#### Parameters

in,out	<i>BufPtr</i>	A pointer to the software bus buffer to receive to (must not be null). Typically a caller declares a ptr of type CFE_SB_Buffer_t (i.e. CFE_SB_Buffer_t *Ptr) then gives the address of that pointer (&Ptr) as this parameter. After a successful receipt of a message, *BufPtr will point to the first byte of the software bus buffer. This should be used as a read-only pointer (in systems with an MMU, writes to this pointer may cause a memory protection fault). The *BufPtr is valid only until the next call to CFE_SB_ReceiveBuffer for the same pipe.
in	<i>PipeId</i>	The pipe ID of the pipe containing the message to be obtained.
in	<i>TimeOut</i>	The number of milliseconds to wait for a new message if the pipe is empty at the time of the call. This can also be set to <a href="#">CFE_SB_POLL</a> for a non-blocking receive or <a href="#">CFE_SB_PEND_FOREVER</a> to wait forever for a message to arrive.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_SB_BAD_ARGUMENT</i>	Bad Argument.
<i>CFE_SB_TIME_OUT</i>	Time Out.
<i>CFE_SB_PIPE_RD_ERR</i>	(return value only verified in coverage test) Pipe Read Error.
<i>CFE_SB_NO_MESSAGE</i>	No Message.

Referenced by DS\_AppMain().

**10.34.2.2 CFE\_SB\_TransmitMsg()**

```
CFE_Status_t CFE_SB_TransmitMsg (
    const CFE_MSG_Message_t * MsgPtr,
    bool IncrementSequenceCount )
```

Transmit a message.

**Description**

This routine copies the specified message into a software bus buffer which is then transmitted to all subscribers. The software bus will read the message ID from the message header to determine which pipes should receive the message.

**Assumptions, External Events, and Notes:**

- This routine will not normally wait for the receiver tasks to process the message before returning control to the caller's task.
- However, if a higher priority task is pending and subscribed to this message, that task may get to run before returning control to the caller.

**Parameters**

in	<i>MsgPtr</i>	A pointer to the message to be sent (must not be null). This must point to the first byte of the message header.
in	<i>IncrementSequenceCount</i>	Boolean to increment the internally tracked sequence count and update the message if the buffer contains a telemetry message

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_SB_BAD_ARGUMENT</i>	Bad Argument.
<i>CFE_SB_MSG_TOO_BIG</i>	Message Too Big.
<i>CFE_SB_BUF_ALOC_ERR</i>	(return value only verified in coverage test) Buffer Allocation Error.

Referenced by DS\_AppProcessHK(), and DS\_CmdGetFileInfo().

## 10.35 cFE Zero Copy APIs

### Functions

- [CFE\\_SB\\_Buffer\\_t \\* CFE\\_SB\\_AllocateMessageBuffer \(size\\_t MsgSize\)](#)  
*Get a buffer pointer to use for "zero copy" SB sends.*
- [CFE\\_Status\\_t CFE\\_SB\\_ReleaseMessageBuffer \(CFE\\_SB\\_Buffer\\_t \\*BufPtr\)](#)  
*Release an unused "zero copy" buffer pointer.*
- [CFE\\_Status\\_t CFE\\_SB\\_TransmitBuffer \(CFE\\_SB\\_Buffer\\_t \\*BufPtr, bool IncrementSequenceCount\)](#)  
*Transmit a buffer.*

### 10.35.1 Detailed Description

### 10.35.2 Function Documentation

#### 10.35.2.1 CFE\_SB\_AllocateMessageBuffer()

```
CFE_SB_Buffer_t* CFE_SB_AllocateMessageBuffer (
    size_t MsgSize )
```

Get a buffer pointer to use for "zero copy" SB sends.

#### Description

This routine can be used to get a pointer to one of the software bus' internal memory buffers that are used for sending messages. The caller can use this memory buffer to build an SB message, then send it using the [CFE\\_SB\\_TransmitBuffer\(\)](#) function. This interface avoids an extra copy of the message from the user's memory buffer to the software bus internal buffer.

#### Assumptions, External Events, and Notes:

1. The pointer returned by [CFE\\_SB\\_AllocateMessageBuffer\(\)](#) is only good for one call to [CFE\\_SB\\_TransmitBuffer\(\)](#).
2. Once a buffer has been successfully transmitted (as indicated by a successful return from [CFE\\_SB\\_TransmitBuffer\(\)](#)) the buffer becomes owned by the SB application. It will automatically be freed by SB once all recipients have finished reading it.
3. Applications must not de-reference the message pointer (for reading or writing) after the call to [CFE\\_SB\\_TransmitBuffer\(\)](#).
4. If [CFE\\_SB\\_ReleaseMessageBuffer](#) should be used only if a message is not transmitted

#### Parameters

in	MsgSize	The size of the SB message buffer the caller wants (including the SB message header).
----	---------	---

**Returns**

A pointer to a memory buffer that message data can be written to for use with [CFE\\_SB\\_TransmitBuffer\(\)](#).

Referenced by [DS\\_FileTransmit\(\)](#).

### 10.35.2.2 CFE\_SB\_ReleaseMessageBuffer()

```
CFE_Status_t CFE_SB_ReleaseMessageBuffer (
    CFE_SB_Buffer_t * BufPtr )
```

Release an unused "zero copy" buffer pointer.

**Description**

This routine can be used to release a pointer to one of the software bus' internal memory buffers.

**Assumptions, External Events, and Notes:**

1. This function is not needed for normal "zero copy" transfers. It is needed only for cleanup when an application gets a pointer using [CFE\\_SB\\_AllocateMessageBuffer\(\)](#), but (due to some error condition) never uses that pointer in a call to [CFE\\_SB\\_TransmitBuffer\(\)](#).

**Parameters**

in	BufPtr	A pointer to the SB internal buffer (must not be null). This must be a pointer returned by a call to <a href="#">CFE_SB_AllocateMessageBuffer()</a> , but never used in a call to <a href="#">CFE_SB_TransmitBuffer()</a> .
----	--------	---

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_SB_BUFFER_INVALID</a>	Buffer Invalid.

### 10.35.2.3 CFE\_SB\_TransmitBuffer()

```
CFE_Status_t CFE_SB_TransmitBuffer (
    CFE_SB_Buffer_t * BufPtr,
    bool IncrementSequenceCount )
```

Transmit a buffer.

## Description

This routine sends a message that has been created directly in an internal SB message buffer by an application (after a call to [CFE\\_SB\\_AllocateMessageBuffer](#)). This interface is more complicated than the normal [CFE\\_SB↔TransmitMsg](#) interface, but it avoids an extra copy of the message from the user's memory buffer to the software bus internal buffer. The "zero copy" interface can be used to improve performance in high-rate, high-volume software bus traffic.

## Assumptions, External Events, and Notes:

1. A handle returned by [CFE\\_SB\\_AllocateMessageBuffer](#) is "consumed" by a *successful* call to [CFE\\_SB↔TransmitBuffer](#).
2. If this function returns [CFE\\_SUCCESS](#), this indicates the zero copy handle is now owned by software bus, and is no longer owned by the calling application, and should not be re-used.
3. However if this function fails (returns any error status) it does not change the state of the buffer at all, meaning the calling application still owns it. (a failure means the buffer is left in the same state it was before the call).
4. Applications should be written as if [CFE\\_SB\\_AllocateMessageBuffer](#) is equivalent to a `malloc()` and a successful call to [CFE\\_SB\\_TransmitBuffer](#) is equivalent to a `free()`.
5. Applications must not de-reference the message pointer (for reading or writing) after a successful call to [CFE\\_SB\\_TransmitBuffer](#).
6. This function will increment and apply the internally tracked sequence counter if set to do so.

## Parameters

<code>in</code>	<code>BufPtr</code>	A pointer to the buffer to be sent (must not be null).
<code>in</code>	<code>IncrementSequenceCount</code>	Boolean to increment the internally tracked sequence count and update the message if the buffer contains a telemetry message

## Returns

Execution status, see [cFE Return Code Defines](#)

## Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_SB_BAD_ARGUMENT</a>	Bad Argument.
<a href="#">CFE_SB_MSG_TOO_BIG</a>	Message Too Big.

Referenced by `DS_FileTransmit()`.

## 10.36 cFE Message Characteristics APIs

### Functions

- void [CFE\\_SB\\_SetUserDataLength](#) ([CFE\\_MSG\\_Message\\_t](#) \*MsgPtr, size\_t DataLength)  
*Sets the length of user data in a software bus message.*
- void [CFE\\_SB\\_TimeStampMsg](#) ([CFE\\_MSG\\_Message\\_t](#) \*MsgPtr)  
*Sets the time field in a software bus message with the current spacecraft time.*
- int32 [CFE\\_SB\\_MessageStringSet](#) (char \*DestStringPtr, const char \*SourceStringPtr, size\_t DestMaxSize, size\_t SourceMaxSize)  
*Copies a string into a software bus message.*
- void \* [CFE\\_SB\\_GetUserData](#) ([CFE\\_MSG\\_Message\\_t](#) \*MsgPtr)  
*Get a pointer to the user data portion of a software bus message.*
- size\_t [CFE\\_SB\\_GetUserDataLength](#) (const [CFE\\_MSG\\_Message\\_t](#) \*MsgPtr)  
*Gets the length of user data in a software bus message.*
- int32 [CFE\\_SB\\_MessageStringGet](#) (char \*DestStringPtr, const char \*SourceStringPtr, const char \*DefaultString, size\_t DestMaxSize, size\_t SourceMaxSize)  
*Copies a string out of a software bus message.*

### 10.36.1 Detailed Description

### 10.36.2 Function Documentation

#### 10.36.2.1 CFE\_SB\_GetUserData()

```
void* CFE_SB_GetUserData (
    CFE_MSG_Message_t * MsgPtr )
```

Get a pointer to the user data portion of a software bus message.

#### Description

This routine returns a pointer to the user data portion of a software bus message. SB message header formats can be different for each deployment of the cFE. So, applications should use this function and avoid hard coding offsets into their SB message buffers.

#### Assumptions, External Events, and Notes:

None

#### Parameters

in	MsgPtr	A pointer to the buffer that contains the software bus message (must not be null).
----	--------	--

**Returns**

A pointer to the first byte of user data within the software bus message.

**10.36.2.2 CFE\_SB\_GetUserDataLength()**

```
size_t CFE_SB_GetUserDataLength (
    const CFE_MSG_Message_t * MsgPtr )
```

Gets the length of user data in a software bus message.

**Description**

This routine returns the size of the user data in a software bus message.

**Assumptions, External Events, and Notes:**

None

**Parameters**

in	<i>MsgPtr</i>	A pointer to the buffer that contains the software bus message (must not be null). This must point to the first byte of the message header.
----	---------------	---

**Returns**

The size (in bytes) of the user data in the software bus message.

**Return values**

<i>0</i>	if an error occurs, such as if the <i>MsgPtr</i> argument is not valid.
----------	---

**10.36.2.3 CFE\_SB\_MessageStringGet()**

```
int32 CFE_SB_MessageStringGet (
    char * DestStringPtr,
    const char * SourceStringPtr,
    const char * DefaultString,
    size_t DestMaxSize,
    size_t SourceMaxSize )
```

Copies a string out of a software bus message.

### Description

Strings within software bus messages have a defined/fixed maximum length, and may not necessarily be null terminated within the message. This presents a possible issue when using the C library functions to copy strings out of a message.

This function should replace use of C library functions such as strcpy/strncpy when copying strings out of software bus messages to local storage buffers.

Up to [SourceMaxSize] or [DestMaxSize-1] (whichever is smaller) characters will be copied from the source buffer to the destination buffer, and a NUL termination character will be written to the destination buffer as the last character.

If the DefaultString pointer is non-NULL, it will be used in place of the source string if the source is an empty string. This is typically a string constant that comes from the platform configuration, allowing default values to be assumed for fields that are unspecified.

**IMPORTANT** - the default string, if specified, must be null terminated. This will be the case if a string literal is passed in (the typical/expected use case).

If the default is NULL, then only the source string will be copied, and the result will be an empty string if the source was empty.

If the destination buffer is too small to store the entire string, it will be truncated, but it will still be null terminated.

### Parameters

out	<i>DestStringPtr</i>	Pointer to destination buffer (must not be null)
in	<i>SourceStringPtr</i>	Pointer to source buffer (component of SB message definition)
in	<i>DefaultString</i>	Default string to use if source is empty
in	<i>DestMaxSize</i>	Size of destination storage buffer (must not be zero)
in	<i>SourceMaxSize</i>	Size of source buffer as defined by the message definition

### Returns

Number of characters copied or error code, see [cFE Return Code Defines](#)

### Return values

<a href="#">CFE_SB_BAD_ARGUMENT</a>	Bad Argument.
-------------------------------------	---------------

### 10.36.2.4 CFE\_SB\_MessageStringSet()

```
int32 CFE_SB_MessageStringSet (
    char * DestStringPtr,
    const char * SourceStringPtr,
    size_t DestMaxSize,
    size_t SourceMaxSize )
```

Copies a string into a software bus message.

#### Description

Strings within software bus messages have a defined/fixed maximum length, and may not necessarily be null terminated within the message. This presents a possible issue when using the C library functions to copy strings out of a message.

This performs a very similar function to "strncpy()" except that the sizes of *both* buffers are passed in. Neither buffer is required to be null-terminated, but copying will stop after the first termination character is encountered.

If the destination buffer is not completely filled by the source data (such as if the supplied string was shorter than the allotted length) the destination buffer will be padded with NUL characters up to the size of the buffer, similar to what strncpy() does. This ensures that the entire destination buffer is set.

#### Note

If the source string buffer is already guaranteed to be null terminated, then there is no difference between the C library "strncpy()" function and this implementation. It is only necessary to use this when termination of the source buffer is not guaranteed.

#### Parameters

<i>out</i>	<i>DestStringPtr</i>	Pointer to destination buffer (component of SB message definition) (must not be null)
<i>in</i>	<i>SourceStringPtr</i>	Pointer to source buffer (must not be null)
<i>in</i>	<i>DestMaxSize</i>	Size of destination buffer as defined by the message definition
<i>in</i>	<i>SourceMaxSize</i>	Size of source buffer

#### Returns

Number of characters copied or error code, see [cFE Return Code Defines](#)

#### Return values

<a href="#">CFE_SB_BAD_ARGUMENT</a>	Bad Argument.
-------------------------------------	---------------

#### 10.36.2.5 CFE\_SB\_SetUserDataLength()

```
void CFE_SB_SetUserDataLength (
    CFE_MSG_Message_t * MsgPtr,
    size_t DataLength )
```

Sets the length of user data in a software bus message.

### Description

This routine sets the field in the SB message header that determines the size of the user data in a software bus message. SB message header formats can be different for each deployment of the cFE. So, applications should use this function rather than trying to poke a length value directly into their SB message buffers.

### Assumptions, External Events, and Notes:

- You must set a valid message ID in the SB message header before calling this function.

### Parameters

in	<i>MsgPtr</i>	A pointer to the buffer that contains the software bus message (must not be null). This must point to the first byte of the message header.
in	<i>DataLength</i>	The length to set (size of the user data, in bytes).

### 10.36.2.6 CFE\_SB\_TimeStampMsg()

```
void CFE_SB_TimeStampMsg (
    CFE_MSG_Message_t * MsgPtr )
```

Sets the time field in a software bus message with the current spacecraft time.

### Description

This routine sets the time of a software bus message with the current spacecraft time. This will be the same time that is returned by the function [CFE\\_TIME\\_GetTime](#).

### Assumptions, External Events, and Notes:

- If the underlying implementation of software bus messages does not include a time field, then this routine will do nothing.

### Parameters

in	<i>MsgPtr</i>	A pointer to the buffer that contains the software bus message (must not be null). This must point to the first byte of the message header.
----	---------------	---

Referenced by [DS\\_AppProcessHK\(\)](#), [DS\\_CmdGetFileInfo\(\)](#), and [DS\\_FileTransmit\(\)](#).

## 10.37 cFE Message ID APIs

### Functions

- bool [CFE\\_SB\\_IsValidMsgId](#) ([CFE\\_SB\\_MsgId\\_t](#) MsgId)  
*Identifies whether a given [CFE\\_SB\\_MsgId\\_t](#) is valid.*
- static bool [CFE\\_SB\\_MsgId\\_Equal](#) ([CFE\\_SB\\_MsgId\\_t](#) MsgId1, [CFE\\_SB\\_MsgId\\_t](#) MsgId2)  
*Identifies whether two [CFE\\_SB\\_MsgId\\_t](#) values are equal.*
- static [CFE\\_SB\\_MsgId\\_Atom\\_t](#) [CFE\\_SB\\_MsgIdToValue](#) ([CFE\\_SB\\_MsgId\\_t](#) MsgId)  
*Converts a [CFE\\_SB\\_MsgId\\_t](#) to a normal integer.*
- static [CFE\\_SB\\_MsgId\\_t](#) [CFE\\_SB\\_ValueToMsgId](#) ([CFE\\_SB\\_MsgId\\_Atom\\_t](#) MsgIdValue)  
*Converts a normal integer into a [CFE\\_SB\\_MsgId\\_t](#).*

### 10.37.1 Detailed Description

### 10.37.2 Function Documentation

#### 10.37.2.1 [CFE\\_SB\\_IsValidMsgId\(\)](#)

```
bool CFE_SB_IsValidMsgId (
    CFE_SB_MsgId_t MsgId )
```

Identifies whether a given [CFE\\_SB\\_MsgId\\_t](#) is valid.

#### Description

Implements a basic sanity check on the value provided

#### Returns

Boolean message ID validity indicator

#### Return values

<i>true</i>	Message ID is within the valid range
<i>false</i>	Message ID is not within the valid range

Referenced by [DS\\_CmdAddMID\(\)](#), [DS\\_CmdSetFilterFile\(\)](#), [DS\\_CmdSetFilterParms\(\)](#), [DS\\_CmdSetFilterType\(\)](#), [DS\\_TableSubscribe\(\)](#), [DS\\_TableUnsubscribe\(\)](#), and [DS\\_TableVerifyFilter\(\)](#).

### 10.37.2.2 CFE\_SB\_MsgId\_Equal()

```
static bool CFE_SB_MsgId_Equal (
    CFE_SB_MsgId_t MsgId1,
    CFE_SB_MsgId_t MsgId2 ) [inline], [static]
```

Identifies whether two [CFE\\_SB\\_MsgId\\_t](#) values are equal.

#### Description

In cases where the [CFE\\_SB\\_MsgId\\_t](#) type is not a simple integer type, it may not be possible to do a direct equality check. This inline function provides an abstraction for the equality check between two [CFE\\_SB\\_MsgId\\_t](#) values.

Applications should transition to using this function to compare MsgId values for equality to remain compatible with future versions of cFE.

#### Returns

Boolean message ID equality indicator

#### Return values

<i>true</i>	Message IDs are Equal
<i>false</i>	Message IDs are not Equal

Definition at line 766 of file cfe\_sb.h.

References CFE\_SB\_MSGID\_UNWRAP\_VALUE.

### 10.37.2.3 CFE\_SB\_MsgIdToValue()

```
static CFE_SB_MsgId_Atom_t CFE_SB_MsgIdToValue (
    CFE_SB_MsgId_t MsgId ) [inline], [static]
```

Converts a [CFE\\_SB\\_MsgId\\_t](#) to a normal integer.

#### Description

In cases where the [CFE\\_SB\\_MsgId\\_t](#) type is not a simple integer type, it is not possible to directly display the value in a printf-style statement, use it in a switch() statement, or other similar use cases.

This inline function provides the ability to map a [CFE\\_SB\\_MsgId\\_t](#) type back into a simple integer value.

Applications should transition to using this function wherever a [CFE\\_SB\\_MsgId\\_t](#) type needs to be used as an integer.

#### Assumptions and Notes:

This negates the type safety that was gained by using a non-integer type for the [CFE\\_SB\\_MsgId\\_t](#) value. This should only be used in specific cases such as UI display (printf, events, etc) where the value is being sent externally.

Any internal API calls should be updated to use the [CFE\\_SB\\_MsgId\\_t](#) type directly, rather than an integer type.

**Returns**

Integer representation of the [CFE\\_SB\\_MsgId\\_t](#)

Definition at line 797 of file cfe\_sb.h.

References [CFE\\_SB\\_MSGID\\_UNWRAP\\_VALUE](#).

Referenced by [DS\\_AppProcessMsg\(\)](#), [DS\\_CmdAddMID\(\)](#), [DS\\_CmdSetFilterFile\(\)](#), [DS\\_CmdSetFilterParms\(\)](#), [DS\\_CmdSetFilterType\(\)](#), [DS\\_TableFindMsgID\(\)](#), [DS\\_TableHashFunction\(\)](#), [DS\\_TableSubscribe\(\)](#), [DS\\_TableUnsubscribe\(\)](#), and [DS\\_TableVerifyFilterEntry\(\)](#).

#### 10.37.2.4 CFE\_SB\_ValueToMsgId()

```
static CFE\_SB\_MsgId\_t CFE_SB_ValueToMsgId (
    CFE\_SB\_MsgId\_Atom\_t MsgIdValue ) [inline], [static]
```

Converts a normal integer into a [CFE\\_SB\\_MsgId\\_t](#).

**Description**

In cases where the [CFE\\_SB\\_MsgId\\_t](#) type is not a simple integer type, it is not possible to directly use an integer value supplied via a define or similar method.

This inline function provides the ability to map an integer value into a corresponding [CFE\\_SB\\_MsgId\\_t](#) value.

Applications should transition to using this function wherever an integer needs to be used for a [CFE\\_SB\\_MsgId\\_t](#).

**Assumptions and Notes:**

This negates the type safety that was gained by using a non-integer type for the [CFE\\_SB\\_MsgId\\_t](#) value. This should only be used in specific cases where the value is coming from an external source. Any internal API calls should be updated to return the [CFE\\_SB\\_MsgId\\_t](#) type directly, rather than an integer type.

**Returns**

[CFE\\_SB\\_MsgId\\_t](#) representation of the integer

Definition at line 826 of file cfe\_sb.h.

References [CFE\\_SB\\_MSGID\\_C](#).

Referenced by [DS\\_AppInitialize\(\)](#), [DS\\_AppProcessHK\(\)](#), [DS\\_CmdGetFileInfo\(\)](#), and [DS\\_FileTransmit\(\)](#).

## 10.38 cFE SB Pipe options

### Macros

- #define CFE\_SB\_PIPEOPTS\_IGNOREMINE 0x00000001

*Messages sent by the app that owns this pipe will not be sent to this pipe.*

#### 10.38.1 Detailed Description

#### 10.38.2 Macro Definition Documentation

##### 10.38.2.1 CFE\_SB\_PIPEOPTS\_IGNOREMINE

```
#define CFE_SB_PIPEOPTS_IGNOREMINE 0x00000001
```

Messages sent by the app that owns this pipe will not be sent to this pipe.

Definition at line 131 of file cfe\_sb\_api\_typedefs.h.

## 10.39 cFE Registration APIs

### Functions

- `CFE_Status_t CFE_TBL_Register (CFE_TBL_Handle_t *TblHandlePtr, const char *Name, size_t Size, uint16 TblOptionFlags, CFE_TBL_CallbackFuncPtr_t TblValidationFuncPtr)`  
*Register a table with cFE to obtain Table Management Services.*
- `CFE_Status_t CFE_TBL_Share (CFE_TBL_Handle_t *TblHandlePtr, const char *TblName)`  
*Obtain handle of table registered by another application.*
- `CFE_Status_t CFE_TBL_Unregister (CFE_TBL_Handle_t TblHandle)`  
*Unregister a table.*

### 10.39.1 Detailed Description

### 10.39.2 Function Documentation

#### 10.39.2.1 CFE\_TBL\_Register()

```
CFE_Status_t CFE_TBL_Register (
    CFE_TBL_Handle_t * TblHandlePtr,
    const char * Name,
    size_t Size,
    uint16 TblOptionFlags,
    CFE_TBL_CallbackFuncPtr_t TblValidationFuncPtr )
```

Register a table with cFE to obtain Table Management Services.

#### Description

When an application is created and initialized, it is responsible for creating its table images via the TBL API. The application must inform the Table Service of the table name, table size and selection of optional table features.

#### Assumptions, External Events, and Notes:

Note: This function call can block. Therefore, interrupt service routines should NOT create their own tables. An application should create any table(s) and provide the handle(s) to the interrupt service routine.

#### Parameters

out	<code>TblHandlePtr</code>	a pointer to a <code>CFE_TBL_Handle_t</code> type variable (must not be null) that will be assigned the table's handle. The table handle is required for other API calls when accessing the data contained in the table. <code>*TblHandlePtr</code> is the handle used to identify table to cFE when performing Table operations. This value is returned at address specified by <code>TblHandlePtr</code> .
in	<code>Name</code>	The raw table name. This name will be combined with the name of the application to produce a name of the form "AppName.RawTableName". This application specific name will be used in commands for modifying or viewing the contents of the table.

**Parameters**

in	<i>Size</i>	The size, in bytes, of the table to be created (must not be zero). This is the size that will be allocated as a shared memory resource between the Table Management Service and the calling application.
----	-------------	--

## Parameters

in	<i>TblOptionFlags</i>	<p>Flag bits indicating selected options for table. A bitwise OR of the following option flags:</p> <ul style="list-style-type: none"> <li>• <a href="#">CFE_TBL_OPT_DEFAULT</a> - The default setting for table options is a combination of <a href="#">CFE_TBL_OPT_SNGL_BUFFER</a> and <a href="#">CFE_TBL_OPT_LOAD_DUMP</a>. See below for a description of these two options. This option is mutually exclusive with the <a href="#">CFE_TBL_OPT_DBL_BUFFER</a>, <a href="#">CFE_TBL_OPT_DUMP_ONLY</a> and <a href="#">CFE_TBL_OPT_USR_DEF_ADDR</a> options.</li> <li>• <a href="#">CFE_TBL_OPT_SNGL_BUFFER</a> - When this option is selected, the table will use a shared session table for performing table modifications and a memory copy from the session table to the "active" table buffer will occur when the table is updated. This is the preferred option since it will minimize memory usage. This option is mutually exclusive with the <a href="#">CFE_TBL_OPT_DBL_BUFFER</a> option</li> <li>• <a href="#">CFE_TBL_OPT_DBL_BUFFER</a> - When this option is selected, two instances of the table are created. One is considered the "active" table and the other the "inactive" table. Whenever table modifications occur, they do not require the use of a common session table. Modifications occur in the "inactive" buffer. Then, when it is time to update the table, the pointer to the "active" table is changed to point to the "inactive" buffer thus making it the new "active" buffer. This feature is most useful for time critical applications (ie - interrupt service routines, etc). This option is mutually exclusive with the <a href="#">CFE_TBL_OPT_SNGL_BUFFER</a> and <a href="#">CFE_TBL_OPT_DEFAULT</a> option.</li> <li>• <a href="#">CFE_TBL_OPT_LOAD_DUMP</a> - When this option is selected, the Table Service is allowed to perform all operations on the specified table. This option is mutually exclusive with the <a href="#">CFE_TBL_OPT_DUMP_ONLY</a> option.</li> <li>• <a href="#">CFE_TBL_OPT_DUMP_ONLY</a> - When this option is selected, the Table Service will not perform table loads to this table. This does not prevent, however, a task from writing to the table via an address obtained with the <a href="#">CFE_TBL_GetAddress</a> API function. This option is mutually exclusive with the <a href="#">CFE_TBL_OPT_LOAD_DUMP</a> and <a href="#">CFE_TBL_OPT_DEFAULT</a> options. If the Application wishes to specify their own block of memory as the Dump Only table, they need to also include the <a href="#">CFE_TBL_OPT_USR_DEF_ADDR</a> option explained below.</li> <li>• <a href="#">CFE_TBL_OPT_NOT_USR_DEF</a> - When this option is selected, Table Services allocates memory for the table and, in the case of a double buffered table, it allocates the same amount of memory again for the second buffer. This option is mutually exclusive with the <a href="#">CFE_TBL_OPT_USR_DEF_ADDR</a> option.</li> <li>• <a href="#">CFE_TBL_OPT_USR_DEF_ADDR</a> - When this option is selected, the Table Service will not allocate memory for the table. Table Services will require the Application to identify the location of the active table buffer via the <a href="#">CFE_TBL_Load</a> function. This option implies the <a href="#">CFE_TBL_OPT_DUMP_ONLY</a> and the <a href="#">CFE_TBL_OPT_SNGL_BUFFER</a> options and is mutually exclusive of the <a href="#">CFE_TBL_OPT_DBL_BUFFER</a> option.</li> <li>• <a href="#">CFE_TBL_OPT_CRITICAL</a> - When this option is selected, the Table Service will automatically allocate space in the Critical Data Store (CDS) for the table and ensure that the contents in the CDS are the same as the contents of the currently active buffer for the table. This option is mutually exclusive of the <a href="#">CFE_TBL_OPT_USR_DEF_ADDR</a> and <a href="#">CFE_TBL_OPT_DUMP_ONLY</a> options. It should also be noted that the use of this option with double buffered tables will prevent the update of the double buffered table from being quick and it could be blocked. Therefore, critical tables should not be updated.</li> </ul>

### Parameters

in	<i>TblValidationFuncPtr</i>	<p>is a pointer to a function that will be executed in the context of the Table Management Service when the contents of a table need to be validated. If set to NULL, then the Table Management Service will assume any data is valid. If the value is not NULL, it must be a pointer to a function with the following prototype:</p> <pre><b>int32 CallbackFunc(void *TblPtr);</b></pre> <p>where</p> <p><b>TblPtr</b> will be a pointer to the table data that is to be verified. When the function returns <b>CFE_SUCCESS</b>, the data is considered valid and ready for a commit. When the function returns a negative value, the data is considered invalid and an Event Message will be issued containing the returned value. If the function should return a positive number, the table is considered invalid and the return code is considered invalid. Validation functions <b>must</b> return either <b>CFE_SUCCESS</b> or a negative number (whose value is at the developer's discretion). The validation function will be executed in the Application's context so that Event Messages describing the validation failure are possible from within the function.</p>
----	-----------------------------	---

### Returns

Execution status, see [cFE Return Code Defines](#)

### Return values

<b>CFE_SUCCESS</b>	Successful execution.
<b>CFE_TBL_INFO_RECOVERED_TBL</b>	Recovered Table.
<b>CFE_TBL_ERR_DUPLICATE_DIFF_SIZE</b>	Duplicate Table With Different Size.
<b>CFE_TBL_ERR_DUPLICATE_NOT_OWNED</b>	Duplicate Table And Not Owned.
<b>CFE_TBL_ERR_REGISTRY_FULL</b>	Registry Full.
<b>CFE_TBL_ERR_HANDLES_FULL</b>	Handles Full.
<b>CFE_TBL_ERR_INVALID_SIZE</b>	Invalid Size.
<b>CFE_TBL_ERR_INVALID_NAME</b>	Invalid Name.
<b>CFE_ES_ERR_RESOURCEID_NOT_VALID</b>	Resource ID is not valid.
<b>CFE_TBL_BAD_ARGUMENT</b>	Bad Argument.
<b>CFE_TBL_ERR_INVALID_OPTIONS</b>	Invalid Options.
<b>CFE_TBL_WARN_DUPLICATE</b>	Duplicate Warning.
<b>CFE_TBL_WARN_NOT_CRITICAL</b>	Not Critical Warning.

### See also

[CFE\\_TBL\\_Unregister](#), [CFE\\_TBL\\_Share](#)

Referenced by [DS\\_TableInit\(\)](#).

### 10.39.2.2 CFE\_TBL\_Share()

```
CFE_Status_t CFE_TBL_Share (
    CFE_TBL_Handle_t * TblHandlePtr,
    const char * TblName )
```

Obtain handle of table registered by another application.

#### Description

After a table has been created, other applications can gain access to that table via the table handle. In order for two or more applications to share a table, the applications that do not create the table must obtain the handle using this function.

#### Assumptions, External Events, and Notes:

None

#### Parameters

<b>out</b>	<i>TblHandlePtr</i>	A pointer to a <a href="#">CFE_TBL_Handle_t</a> type variable (must not be null) that will be assigned the table's handle. The table handle is required for other API calls when accessing the data contained in the table. *TblHandlePtr is the handle used to identify table to cFE when performing Table operations. This value is returned at the address specified by TblHandlePtr.
<b>in</b>	<i>TblName</i>	The application specific name of the table of the form "AppName.RawTableName", where RawTableName is the name specified in the <a href="#">CFE_TBL_Register</a> API call. Example: "ACS.TamParams" for a table called "TamParams" that was registered by the application called "ACS".

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_TBL_ERR_HANDLES_FULL</a>	Handles Full.
<a href="#">CFE_TBL_ERR_INVALID_NAME</a>	Invalid Name.
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_TBL_BAD_ARGUMENT</a>	Bad Argument.

#### See also

[CFE\\_TBL\\_Unregister](#), [CFE\\_TBL\\_Register](#)

### 10.39.2.3 CFE\_TBL\_Unregister()

```
CFE_Status_t CFE_TBL_Unregister (
    CFE_TBL_Handle_t TblHandle )
```

Unregister a table.

#### Description

When an application is being removed from the system, ES will clean up/free all the application related resources including tables so apps are not required to call this function.

A valid use-case for this API is to unregister a shared table if access is no longer needed or the owning application was removed from the system (CS app is an example).

Typically apps should only register tables during initialization and registration/unregistration by the owning application during operation should be avoided. If unavoidable, special care needs to be taken (especially for shared tables) to avoid race conditions due to competing requests from multiple tasks.

Note the table will not be removed from memory until all table access links have been removed (registration and all shared access).

#### Assumptions, External Events, and Notes:

None

#### Parameters

in	<i>TblHandle</i>	Handle, previously obtained from <a href="#">CFE_TBL_Register</a> or <a href="#">CFE_TBL_Share</a> , that identifies the Table to be unregistered.
----	------------------	--

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_TBL_ERR_NO_ACCESS</a>	No Access.
<a href="#">CFE_TBL_ERR_INVALID_HANDLE</a>	Invalid Handle.

#### See also

[CFE\\_TBL\\_Share](#), [CFE\\_TBL\\_Register](#)

## 10.40 cFE Manage Table Content APIs

### Functions

- `CFE_Status_t CFE_TBL_Load (CFE_TBL_Handle_t TblHandle, CFE_TBL_SrcEnum_t SrcType, const void *SrcDataPtr)`  
*Load a specified table with data from specified source.*
- `CFE_Status_t CFE_TBL_Update (CFE_TBL_Handle_t TblHandle)`  
*Update contents of a specified table, if an update is pending.*
- `CFE_Status_t CFE_TBL_Validate (CFE_TBL_Handle_t TblHandle)`  
*Perform steps to validate the contents of a table image.*
- `CFE_Status_t CFE_TBL_Manage (CFE_TBL_Handle_t TblHandle)`  
*Perform standard operations to maintain a table.*
- `CFE_Status_t CFE_TBL_DumpToBuffer (CFE_TBL_Handle_t TblHandle)`  
*Copies the contents of a Dump Only Table to a shared buffer.*
- `CFE_Status_t CFE_TBL_Modified (CFE_TBL_Handle_t TblHandle)`  
*Notify cFE Table Services that table contents have been modified by the Application.*

### 10.40.1 Detailed Description

### 10.40.2 Function Documentation

#### 10.40.2.1 CFE\_TBL\_DumpToBuffer()

```
CFE_Status_t CFE_TBL_DumpToBuffer (
    CFE_TBL_Handle_t TblHandle )
```

Copies the contents of a Dump Only Table to a shared buffer.

#### Description

Typically, apps should just call `CFE_TBL_Manage` as part of routine processing which will perform validation, update, or dump if pending. This API is provided for the case where just a dump should be performed.

#### Assumptions, External Events, and Notes:

If the table does not have a dump pending status, nothing will occur (no error, no dump)

#### Parameters

in	<code>TblHandle</code>	Handle of Table to be dumped.
----	------------------------	-------------------------------

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_ES_ERR_RESOURCEID_NOT_VALID</i>	Resource ID is not valid.
<i>CFE_TBL_ERR_NO_ACCESS</i>	No Access.
<i>CFE_TBL_ERR_INVALID_HANDLE</i>	Invalid Handle.
<i>CFE_TBL_INFO_DUMP_PENDING</i>	Dump Pending.

**See also**

[CFE\\_TBL\\_Manage](#)

Referenced by `DS_TableManageDestFile()`, and `DS_TableManageFilter()`.

#### 10.40.2.2 CFE\_TBL\_Load()

```
CFE_Status_t CFE_TBL_Load (
    CFE_TBL_Handle_t TblHandle,
    CFE_TBL_SrcEnum_t SrcType,
    const void * SrcDataPtr )
```

Load a specified table with data from specified source.

**Description**

Once an application has created a table ([CFE\\_TBL\\_Register](#)), it must provide the values that initialize the contents of that table. The application accomplishes this with one of two different TBL API calls. This function call initializes the table with values that are held in a data structure.

**Assumptions, External Events, and Notes:**

This function call can block. Therefore, interrupt service routines should NOT initialize their own tables. An application should initialize any table(s) prior to providing the handle(s) to the interrupt service routine.

**Parameters**

in	<i>TblHandle</i>	Handle, previously obtained from <a href="#">CFE_TBL_Register</a> or <a href="#">CFE_TBL_Share</a> , that identifies the Table to be loaded.
----	------------------	--

### Parameters

in	<i>SrcType</i>	Flag indicating the nature of the given <i>SrcDataPtr</i> below. This value can be any one of the following: <ul style="list-style-type: none"> <li>• <a href="#">CFE_TBL_SRC_FILE</a> - File source When this option is selected, the <i>SrcDataPtr</i> will be interpreted as a pointer to a null terminated character string. The string should specify the full path and filename of the file containing the initial data contents of the table.</li> <li>• <a href="#">CFE_TBL_SRC_ADDRESS</a> - Address source When this option is selected, the <i>SrcDataPtr</i> will be interpreted as a pointer to a memory location that is the beginning of the initialization data for loading the table OR, in the case of a "user defined" dump only table, the address of the active table itself. The block of memory is assumed to be of the same size specified in the <a href="#">CFE_TBL_Register</a> function Size parameter.</li> </ul>
in	<i>SrcDataPtr</i>	Pointer (must not be null) to either a character string specifying a filename or a memory address of a block of binary data to be loaded into a table or, if the table was registered with the <a href="#">CFE_TBL_OPT_USR_DEF_ADDR</a> option, the address of the active table buffer.

### Returns

Execution status, see [cFE Return Code Defines](#)

### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_TBL_ERR_NO_ACCESS</a>	No Access.
<a href="#">CFE_TBL_ERR_INVALID_HANDLE</a>	Invalid Handle.
<a href="#">CFE_TBL_ERR_DUMP_ONLY</a>	Dump Only Error.
<a href="#">CFE_TBL_ERR_ILLEGAL_SRC_TYPE</a>	Illegal Source Type.
<a href="#">CFE_TBL_ERR_LOAD_IN_PROGRESS</a>	Load In Progress.
<a href="#">CFE_TBL_ERR_LOAD_INCOMPLETE</a>	Load Incomplete.
<a href="#">CFE_TBL_ERR_NO_BUFFER_AVAIL</a>	No Buffer Available.
<a href="#">CFE_TBL_ERR_ACCESS</a>	
<a href="#">CFE_TBL_ERR_FILE_TOO_LARGE</a>	File Too Large.
<a href="#">CFE_TBL_ERR_BAD_CONTENT_ID</a>	Bad Content ID.
<a href="#">CFE_TBL_ERR_BAD_SUBTYPE_ID</a>	Bad Subtype ID.
<a href="#">CFE_TBL_ERR_NO_STD_HEADER</a>	No Standard Header.
<a href="#">CFE_TBL_ERR_NO_TBL_HEADER</a>	No Table Header.
<a href="#">CFE_TBL_ERR_PARTIAL_LOAD</a>	Partial Load Error.
<a href="#">CFE_TBL_BAD_ARGUMENT</a>	Bad Argument.

### See also

[CFE\\_TBL\\_Update](#), [CFE\\_TBL\\_Validate](#), [CFE\\_TBL\\_Manage](#)

Referenced by `DS_TableInit()`.

### 10.40.2.3 CFE\_TBL\_Manage()

```
CFE_Status_t CFE_TBL_Manage (
    CFE_TBL_Handle_t TblHandle )
```

Perform standard operations to maintain a table.

#### Description

Applications should call this API periodically to process pending requests for update, validation, or dump to buffer. Typically, the application that created the table would call this function at the start or conclusion of any routine processing cycle.

#### Assumptions, External Events, and Notes:

None

#### Parameters

in	<i>TblHandle</i>	Handle, previously obtained from <a href="#">CFE_TBL_Register</a> or <a href="#">CFE_TBL_Share</a> , that identifies the Table to be managed.
----	------------------	---

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_TBL_INFO_UPDATED</a>	Updated.
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_TBL_ERR_NO_ACCESS</a>	No Access.
<a href="#">CFE_TBL_ERR_INVALID_HANDLE</a>	Invalid Handle.
<a href="#">CFE_TBL_INFO_DUMP_PENDING</a>	Dump Pending.
<a href="#">CFE_TBL_INFO_UPDATE_PENDING</a>	Update Pending.
<a href="#">CFE_TBL_INFO_VALIDATION_PENDING</a>	

#### See also

[CFE\\_TBL\\_Update](#), [CFE\\_TBL\\_Validate](#), [CFE\\_TBL\\_Load](#), [CFE\\_TBL\\_DumpToBuffer](#)

Referenced by [DS\\_TableManageDestFile\(\)](#), and [DS\\_TableManageFilter\(\)](#).

#### 10.40.2.4 CFE\_TBL\_Modified()

```
CFE_Status_t CFE_TBL_Modified (
    CFE_TBL_Handle_t TblHandle )
```

Notify cFE Table Services that table contents have been modified by the Application.

##### Description

This API notifies Table Services that the contents of the specified table has been modified by the Application. This notification is important when a table has been registered as "Critical" because Table Services can then update the contents of the table kept in the Critical Data Store.

##### Assumptions, External Events, and Notes:

None

##### Parameters

in	<i>TblHandle</i>	Handle of Table that was modified.
----	------------------	------------------------------------

##### Returns

Execution status, see [cFE Return Code Defines](#)

##### Return values

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_ES_ERR_RESOURCEID_NOT_VALID</i>	Resource ID is not valid.
<i>CFE_TBL_ERR_NO_ACCESS</i>	No Access.
<i>CFE_TBL_ERR_INVALID_HANDLE</i>	Invalid Handle.

##### See also

[CFE\\_TBL\\_Manage](#)

Referenced by `DS_CmdAddMID()`, `DS_CmdSetDestAge()`, `DS_CmdSetDestBase()`, `DS_CmdSetDestCount()`, `DS_CmdSetDestExt()`, `DS_CmdSetDestPath()`, `DS_CmdSetDestSize()`, `DS_CmdSetDestState()`, `DS_CmdSetDestType()`, `DS_CmdSetFilterFile()`, `DS_CmdSetFilterParms()`, and `DS_CmdSetFilterType()`.

#### 10.40.2.5 CFE\_TBL\_Update()

```
CFE_Status_t CFE_TBL_Update (
    CFE_TBL_Handle_t TblHandle )
```

Update contents of a specified table, if an update is pending.

### Description

Typically, apps should just call [CFE\\_TBL\\_Manage](#) as part of routine processing which will perform validation, update, or dump if pending. This API is provided for the case where just an update should be performed.

### Assumptions, External Events, and Notes:

None

### Parameters

in	TblHandle	Handle, previously obtained from <a href="#">CFE_TBL_Register</a> or <a href="#">CFE_TBL_Share</a> , that identifies the Table to be updated.
----	-----------	---

### Returns

Execution status, see [cFE Return Code Defines](#)

### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_TBL_INFO_NO_UPDATE_PENDING</a>	No Update Pending.
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_TBL_ERR_NO_ACCESS</a>	No Access.
<a href="#">CFE_TBL_ERR_INVALID_HANDLE</a>	Invalid Handle.

### See also

[CFE\\_TBL\\_Load](#), [CFE\\_TBL\\_Validate](#), [CFE\\_TBL\\_Manage](#)

Referenced by `DS_TableManageDestFile()`, and `DS_TableManageFilter()`.

### 10.40.2.6 CFE\_TBL\_Validate()

```
CFE_Status_t CFE_TBL_Validate (
    CFE_TBL_Handle_t TblHandle )
```

Perform steps to validate the contents of a table image.

### Description

Typically, apps should just call [CFE\\_TBL\\_Manage](#) as part of routine processing which will perform validation, update, or dump if pending. This API is provided for the case where just a validation should be performed.

### Assumptions, External Events, and Notes:

None

**Parameters**

in	<i>TblHandle</i>	Handle, previously obtained from <a href="#">CFE_TBL_Register</a> or <a href="#">CFE_TBL_Share</a> , that identifies the Table to be managed.
----	------------------	---

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_TBL_INFO_NO_VALIDATION_PENDING</a>	
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_TBL_ERR_NO_ACCESS</a>	No Access.
<a href="#">CFE_TBL_ERR_INVALID_HANDLE</a>	Invalid Handle.

**See also**

[CFE\\_TBL\\_Update](#), [CFE\\_TBL\\_Manage](#), [CFE\\_TBL\\_Load](#)

Referenced by `DS_TableManageDestFile()`, and `DS_TableManageFilter()`.

## 10.41 cFE Access Table Content APIs

### Functions

- **CFE\_Status\_t CFE\_TBL\_GetAddress** (void \*\*TblPtr, **CFE\_TBL\_Handle\_t** TblHandle)  
*Obtain the current address of the contents of the specified table.*
- **CFE\_Status\_t CFE\_TBL\_ReleaseAddress** (**CFE\_TBL\_Handle\_t** TblHandle)  
*Release previously obtained pointer to the contents of the specified table.*
- **CFE\_Status\_t CFE\_TBL\_GetAddresses** (void \*\*TblPtrs[], **uint16** NumTables, const **CFE\_TBL\_Handle\_t** TblHandles[])  
*Obtain the current addresses of an array of specified tables.*
- **CFE\_Status\_t CFE\_TBL\_ReleaseAddresses** (**uint16** NumTables, const **CFE\_TBL\_Handle\_t** TblHandles[])  
*Release the addresses of an array of specified tables.*

### 10.41.1 Detailed Description

### 10.41.2 Function Documentation

#### 10.41.2.1 CFE\_TBL\_GetAddress()

```
CFE_Status_t CFE_TBL_GetAddress (
    void ** TblPtr,
    CFE_TBL_Handle_t TblHandle )
```

Obtain the current address of the contents of the specified table.

#### Description

When a table has been created and initialized, it is available to any application that can identify it with its unique handle. In order to view the data contained in the table, an application must call this function or [CFE\\_TBL\\_GetAddresses](#).

#### Assumptions, External Events, and Notes:

1. This call can be a blocking call when the table is not double buffered and is shared with another application of lower priority that just happens to be in the middle of a table update of the specific table. If this occurs, the application performing the table update will automatically have its priority elevated in order to release the resource as soon as possible.
2. An application must always release the returned table address using the [CFE\\_TBL\\_ReleaseAddress](#) or [CFE\\_TBL\\_ReleaseAddresses](#) function prior to either a [CFE\\_TBL\\_Update](#) call or any blocking call (e.g. - pending on software bus message, etc). Table updates cannot occur while table addresses have not been released.
3. [CFE\\_TBL\\_ERR\\_NEVER\\_LOADED](#) will be returned if the table has never been loaded (either from file or from a block of memory), but the function will still return a valid table pointer to a table with all zero content. This pointer must be released with the [CFE\\_TBL\\_ReleaseAddress](#) API before the table can be loaded with data.

**Parameters**

<b>out</b>	<i>TblPtr</i>	The address of a pointer (must not be null) that will be loaded with the address of the first byte of the table. This pointer can then be typecast by the calling application to the appropriate table data structure. *TblPtr is the address of the first byte of data associated with the specified table.
<b>in</b>	<i>TblHandle</i>	Handle, previously obtained from <a href="#">CFE_TBL_Register</a> or <a href="#">CFE_TBL_Share</a> , that identifies the Table whose address is to be returned.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_TBL_INFO_UPDATED</a>	Updated.
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_TBL_ERR_NO_ACCESS</a>	No Access.
<a href="#">CFE_TBL_ERR_INVALID_HANDLE</a>	Invalid Handle.
<a href="#">CFE_TBL_ERR_UNREGISTERED</a>	Unregistered.
<a href="#">CFE_TBL_ERR_NEVER_LOADED</a>	Never Loaded.
<a href="#">CFE_TBL_BAD_ARGUMENT</a>	Bad Argument.

**See also**

[CFE\\_TBL\\_ReleaseAddress](#), [CFE\\_TBL\\_GetAddresses](#), [CFE\\_TBL\\_ReleaseAddresses](#)

Referenced by [DS\\_TableManageDestFile\(\)](#), and [DS\\_TableManageFilter\(\)](#).

**10.41.2.2 CFE\_TBL\_GetAddresses()**

```
CFE_Status_t CFE_TBL_GetAddresses (
    void ** TblPtrs[],
    uint16 NumTables,
    const CFE_TBL_Handle_t TblHandles[] )
```

Obtain the current addresses of an array of specified tables.

**Description**

When a table has been created and initialized, it is available to any application that can identify it with its unique handle. In order to view the data contained in the table, an application must call this function or [CFE\\_TBL\\_GetAddress](#).

## Assumptions, External Events, and Notes:

1. This call can be a blocking call when the table is not double buffered and is shared with another application of lower priority that just happens to be in the middle of a table update of the specific table. If this occurs, the application performing the table update will automatically have its priority elevated in order to release the resource as soon as possible.
2. An application must always release the returned table address using the [CFE\\_TBL\\_ReleaseAddress](#) or [CFE\\_TBL\\_ReleaseAddresses](#) function prior to either a [CFE\\_TBL\\_Update](#) call or any blocking call (e.g. - pending on software bus message, etc). Table updates cannot occur while table addresses have not been released.
3. [CFE\\_TBL\\_ERR\\_NEVER\\_LOADED](#) will be returned if the table has never been loaded (either from file or from a block of memory), but the function will still return a valid table pointer to a table with all zero content. This pointer must be released with the [CFE\\_TBL\\_ReleaseAddress](#) API before the table can be loaded with data.

## Parameters

<i>out</i>	<i>TblPtrs</i>	Array of Pointers (must not be null) to variables that calling Application wishes to hold the start addresses of the Tables. *TblPtrs is an array of addresses of the first byte of data associated with the specified tables.
<i>in</i>	<i>NumTables</i>	Size of TblPtrs and TblHandles arrays.
<i>in</i>	<i>TblHandles</i>	Array of Table Handles, previously obtained from <a href="#">CFE_TBL_Register</a> or <a href="#">CFE_TBL_Share</a> , of those tables whose start addresses are to be obtained.

## Returns

Execution status, see [cFE Return Code Defines](#)

## Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_TBL_INFO_UPDATED</a>	Updated.
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_TBL_ERR_NO_ACCESS</a>	No Access.
<a href="#">CFE_TBL_ERR_INVALID_HANDLE</a>	Invalid Handle.
<a href="#">CFE_TBL_ERR_UNREGISTERED</a>	Unregistered.
<a href="#">CFE_TBL_ERR_NEVER_LOADED</a>	Never Loaded.
<a href="#">CFE_TBL_BAD_ARGUMENT</a>	Bad Argument.

## See also

[CFE\\_TBL\\_GetAddress](#), [CFE\\_TBL\\_ReleaseAddress](#), [CFE\\_TBL\\_ReleaseAddresses](#)

10.41.2.3 [CFE\\_TBL\\_ReleaseAddress\(\)](#)

```
CFE_Status_t CFE_TBL_ReleaseAddress (
    CFE_TBL_Handle_t TblHandle )
```

Release previously obtained pointer to the contents of the specified table.

## Description

Each application is **required** to release a table address obtained through the [CFE\\_TBL\\_GetAddress](#) function.

## Assumptions, External Events, and Notes:

An application must always release the returned table address using the [CFE\\_TBL\\_ReleaseAddress](#) function prior to either a [CFE\\_TBL\\_Update](#) call or any blocking call (e.g. - pending on software bus message, etc). Table updates cannot occur while table addresses have not been released.

## Parameters

in	<i>TblHandle</i>	Handle, previously obtained from <a href="#">CFE_TBL_Register</a> or <a href="#">CFE_TBL_Share</a> , that identifies the Table whose address is to be released.
----	------------------	---

## Returns

Execution status, see [cFE Return Code Defines](#)

## Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_TBL_INFO_UPDATED</a>	Updated.
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_TBL_ERR_NO_ACCESS</a>	No Access.
<a href="#">CFE_TBL_ERR_INVALID_HANDLE</a>	Invalid Handle.
<a href="#">CFE_TBL_ERR_NEVER_LOADED</a>	Never Loaded.

## See also

[CFE\\_TBL\\_GetAddress](#), [CFE\\_TBL\\_GetAddresses](#), [CFE\\_TBL\\_ReleaseAddresses](#)

Referenced by `DS_TableManageDestFile()`, and `DS_TableManageFilter()`.

## 10.41.2.4 CFE\_TBL\_ReleaseAddresses()

```
CFE_Status_t CFE_TBL_ReleaseAddresses (
    uint16 NumTables,
    const CFE_TBL_Handle_t TblHandles[] )
```

Release the addresses of an array of specified tables.

## Description

Each application is **required** to release a table address obtained through the [CFE\\_TBL\\_GetAddress](#) function.

## Assumptions, External Events, and Notes:

An application must always release the returned table address using the [CFE\\_TBL\\_ReleaseAddress](#) function prior to either a [CFE\\_TBL\\_Update](#) call or any blocking call (e.g. - pending on software bus message, etc). Table updates cannot occur while table addresses have not been released.

**Parameters**

in	<i>NumTables</i>	Size of TblHandles array.
in	<i>TblHandles</i>	Array of Table Handles (must not be null), previously obtained from <a href="#">CFE_TBL_Register</a> or <a href="#">CFE_TBL_Share</a> , of those tables whose start addresses are to be released.

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_TBL_INFO_UPDATED</a>	Updated.
<a href="#">CFE_ES_ERR_RESOURCEID_NOT_VALID</a>	Resource ID is not valid.
<a href="#">CFE_TBL_ERR_NO_ACCESS</a>	No Access.
<a href="#">CFE_TBL_ERR_INVALID_HANDLE</a>	Invalid Handle.
<a href="#">CFE_TBL_ERR_NEVER_LOADED</a>	Never Loaded.
<a href="#">CFE_TBL_BAD_ARGUMENT</a>	Bad Argument.

**See also**

[CFE\\_TBL\\_GetAddress](#), [CFE\\_TBL\\_ReleaseAddress](#), [CFE\\_TBL\\_GetAddresses](#)

## 10.42 cFE Get Table Information APIs

### Functions

- [CFE\\_Status\\_t CFE\\_TBL\\_GetStatus \(CFE\\_TBL\\_Handle\\_t TblHandle\)](#)  
*Obtain current status of pending actions for a table.*
- [CFE\\_Status\\_t CFE\\_TBL\\_GetInfo \(CFE\\_TBL\\_Info\\_t \\*TblInfoPtr, const char \\*TblName\)](#)  
*Obtain characteristics/information of/about a specified table.*
- [CFE\\_Status\\_t CFE\\_TBL\\_NotifyByMessage \(CFE\\_TBL\\_Handle\\_t TblHandle, CFE\\_SB\\_MsgId\\_t MsgId, CFE\\_MSG\\_FcnCode\\_t CommandCode, uint32 Parameter\)](#)  
*Instruct cFE Table Services to notify Application via message when table requires management.*

### 10.42.1 Detailed Description

### 10.42.2 Function Documentation

#### 10.42.2.1 CFE\_TBL\_GetInfo()

```
CFE_Status_t CFE_TBL_GetInfo (
    CFE_TBL_Info_t * TblInfoPtr,
    const char * TblName )
```

Obtain characteristics/information of/about a specified table.

#### Description

This API provides the registry information associated with the specified table. The function fills the given data structure with the data found in the Table Registry.

#### Assumptions, External Events, and Notes:

None

#### Parameters

out	<i>TblInfoPtr</i>	A pointer to a CFE_TBL_Info_t data structure (must not be null) that is to be populated with table characteristics and information. *TblInfoPtr is the description of the tables characteristics and registry information stored in the <a href="#">CFE_TBL_Info_t</a> data structure format.
in	<i>TblName</i>	The application specific name (must not be null) of the table of the form "AppName.RawTableName", where RawTableName is the name specified in the <a href="#">CFE_TBL_Register</a> API call. Example: "ACS.TamParams" for a table called "TamParams" that was registered by the application called "ACS".

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
<a href="#">CFE_TBL_ERR_INVALID_NAME</a>	Invalid Name.
<a href="#">CFE_TBL_BAD_ARGUMENT</a>	Bad Argument.

**See also**

[CFE\\_TBL\\_GetStatus](#)

Referenced by DS\_AppProcessHK().

#### 10.42.2.2 CFE\_TBL\_GetStatus()

```
CFE_Status_t CFE_TBL_GetStatus (
    CFE_TBL_Handle_t TblHandle )
```

Obtain current status of pending actions for a table.

**Description**

An application is **required** to perform a periodic check for an update or a validation request for all the tables that it creates. Typically, the application that created the table would call this function at the start or conclusion of any routine processing cycle. If a table update or validation request is pending, the Application should follow up with a call to [CFE\\_TBL\\_Update](#) or [CFE\\_TBL\\_Validate](#) respectively.

**Assumptions, External Events, and Notes:**

None

**Parameters**

in	<i>TblHandle</i>	Handle, previously obtained from <a href="#">CFE_TBL_Register</a> or <a href="#">CFE_TBL_Share</a> , that identifies the Table to be managed.
----	------------------	---

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<a href="#">CFE_SUCCESS</a>	Successful execution.
-----------------------------	-----------------------

### Return values

<code>CFE_TBL_INFO_UPDATE_PENDING</code>	Update Pending.
<code>CFE_TBL_INFO_VALIDATION_PENDING</code>	
<code>CFE_TBL_INFO_DUMP_PENDING</code>	Dump Pending.
<code>CFE_ES_ERR_RESOURCEID_NOT_VALID</code>	Resource ID is not valid.
<code>CFE_TBL_ERR_NO_ACCESS</code>	No Access.
<code>CFE_TBL_ERR_INVALID_HANDLE</code>	Invalid Handle.

### Note

Some status return codes are "success" while being non-zero. This behavior will change in the future.

### See also

[CFE\\_TBL\\_Manage](#), [CFE\\_TBL\\_Update](#), [CFE\\_TBL\\_Validate](#), [CFE\\_TBL\\_GetInfo](#)

Referenced by `DS_TableManageDestFile()`, and `DS_TableManageFilter()`.

### 10.42.2.3 CFE\_TBL\_NotifyByMessage()

```
CFE_Status_t CFE_TBL_NotifyByMessage (
    CFE_TBL_Handle_t TblHandle,
    CFE_SB_MsgId_t MsgId,
    CFE_MSG_FcnCode_t CommandCode,
    uint32 Parameter )
```

Instruct cFE Table Services to notify Application via message when table requires management.

### Description

This API instructs Table Services to send a message to the calling Application whenever the specified table requires management by the application. This feature allows applications to avoid polling table services via the [CFE\\_TBL\\_Manage](#) call to determine whether a table requires updates, validation, etc. This API should be called following the [CFE\\_TBL\\_Register](#) API whenever the owning application requires this feature.

### Assumptions, External Events, and Notes:

- Only the application that owns the table is allowed to register a notification message
- Recommend **NOT** using the ground command MID which typically impacts command counters. The typical approach is to use a unique MID for inter-task communications similar to how schedulers typically trigger application housekeeping messages.

### Parameters

in	<code>TblHandle</code>	Handle of Table with which the message should be associated.
in	<code>MsgId</code>	Message ID to be used in notification message sent by Table Services.
in	<code>CommandCode</code>	Command Code value to be placed in secondary header of message sent by Table Services.
in	<code>Parameter</code>	Application defined value to be passed as a parameter in the message sent by Table Services. Suggested use includes an application's table index that allows the same MsgId

**Returns**

Execution status, see [cFE Return Code Defines](#)

**Return values**

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_ES_ERR_RESOURCEID_NOT_VALID</i>	Resource ID is not valid.
<i>CFE_TBL_ERR_NO_ACCESS</i>	No Access.
<i>CFE_TBL_ERR_INVALID_HANDLE</i>	Invalid Handle.

**See also**

[CFE\\_TBL\\_Register](#)

## 10.43 cFE Table Type Defines

### Macros

- #define CFE\_TBL\_OPT\_BUFFER\_MSK (0x0001)  
*Table buffer mask.*
- #define CFE\_TBL\_OPT\_SNGL\_BUFFER (0x0000)  
*Single buffer table.*
- #define CFE\_TBL\_OPT\_DBL\_BUFFER (0x0001)  
*Double buffer table.*
- #define CFE\_TBL\_OPT\_LD\_DMP\_MSK (0x0002)  
*Table load/dump mask.*
- #define CFE\_TBL\_OPT\_LOAD\_DUMP (0x0000)  
*Load/Dump table.*
- #define CFE\_TBL\_OPT\_DUMP\_ONLY (0x0002)  
*Dump only table.*
- #define CFE\_TBL\_OPT\_USR\_DEF\_MSK (0x0004)  
*Table user defined mask.*
- #define CFE\_TBL\_OPT\_NOT\_USR\_DEF (0x0000)  
*Not user defined table.*
- #define CFE\_TBL\_OPT\_USR\_DEF\_ADDR (0x0006)  
*User Defined table.,*
- #define CFE\_TBL\_OPT\_CRITICAL\_MSK (0x0008)  
*Table critical mask.*
- #define CFE\_TBL\_OPT\_NOT\_CRITICAL (0x0000)  
*Not critical table.*
- #define CFE\_TBL\_OPT\_CRITICAL (0x0008)  
*Critical table.*
- #define CFE\_TBL\_OPT\_DEFAULT (CFE\_TBL\_OPT\_SNGL\_BUFFER | CFE\_TBL\_OPT\_LOAD\_DUMP)  
*Default table options.*

### 10.43.1 Detailed Description

### 10.43.2 Macro Definition Documentation

#### 10.43.2.1 CFE\_TBL\_OPT\_BUFFER\_MSK

```
#define CFE_TBL_OPT_BUFFER_MSK (0x0001)
```

Table buffer mask.

Definition at line 48 of file `cfe_tbl_api_typedefs.h`.

#### 10.43.2.2 CFE\_TBL\_OPT\_CRITICAL

```
#define CFE_TBL_OPT_CRITICAL (0x0008)
```

Critical table.

Definition at line 63 of file `cfe_tbl_api_typedefs.h`.

Referenced by `DS_TableInit()`.

#### 10.43.2.3 CFE\_TBL\_OPT\_CRITICAL\_MSK

```
#define CFE_TBL_OPT_CRITICAL_MSK (0x0008)
```

Table critical mask.

Definition at line 61 of file `cfe_tbl_api_typedefs.h`.

#### 10.43.2.4 CFE\_TBL\_OPT\_DBL\_BUFFER

```
#define CFE_TBL_OPT_DBL_BUFFER (0x0001)
```

Double buffer table.

Definition at line 50 of file `cfe_tbl_api_typedefs.h`.

#### 10.43.2.5 CFE\_TBL\_OPT\_DEFAULT

```
#define CFE_TBL_OPT_DEFAULT (CFE_TBL_OPT_SNGL_BUFFER | CFE_TBL_OPT_LOAD_DUMP)
```

Default table options.

Definition at line 66 of file `cfe_tbl_api_typedefs.h`.

#### 10.43.2.6 CFE\_TBL\_OPT\_DUMP\_ONLY

```
#define CFE_TBL_OPT_DUMP_ONLY (0x0002)
```

Dump only table.

Definition at line 54 of file `cfe_tbl_api_typedefs.h`.

#### 10.43.2.7 CFE\_TBL\_OPT\_LD\_DMP\_MSK

```
#define CFE_TBL_OPT_LD_DMP_MSK (0x0002)
```

Table load/dump mask.

Definition at line 52 of file cfe\_tbl\_api\_typedefs.h.

#### 10.43.2.8 CFE\_TBL\_OPT\_LOAD\_DUMP

```
#define CFE_TBL_OPT_LOAD_DUMP (0x0000)
```

Load/Dump table.

Definition at line 53 of file cfe\_tbl\_api\_typedefs.h.

Referenced by DS\_TableInit().

#### 10.43.2.9 CFE\_TBL\_OPT\_NOT\_CRITICAL

```
#define CFE_TBL_OPT_NOT_CRITICAL (0x0000)
```

Not critical table.

Definition at line 62 of file cfe\_tbl\_api\_typedefs.h.

#### 10.43.2.10 CFE\_TBL\_OPT\_NOT\_USR\_DEF

```
#define CFE_TBL_OPT_NOT_USR_DEF (0x0000)
```

Not user defined table.

Definition at line 57 of file cfe\_tbl\_api\_typedefs.h.

#### 10.43.2.11 CFE\_TBL\_OPT\_SNGL\_BUFFER

```
#define CFE_TBL_OPT_SNGL_BUFFER (0x0000)
```

Single buffer table.

Definition at line 49 of file cfe\_tbl\_api\_typedefs.h.

Referenced by DS\_TableInit().

#### 10.43.2.12 CFE\_TBL\_OPT\_USR\_DEF\_ADDR

```
#define CFE_TBL_OPT_USR_DEF_ADDR (0x0006)
```

User Defined table,.

##### Note

Automatically includes [CFE\\_TBL\\_OPT\\_DUMP\\_ONLY](#) option

Definition at line 58 of file `cfe_tbl_api_typedefs.h`.

#### 10.43.2.13 CFE\_TBL\_OPT\_USR\_DEF\_MSK

```
#define CFE_TBL_OPT_USR_DEF_MSK (0x0004)
```

Table user defined mask.

Definition at line 56 of file `cfe_tbl_api_typedefs.h`.

## 10.44 cFE Get Current Time APIs

### Functions

- [CFE\\_TIME\\_SysTime\\_t CFE\\_TIME\\_GetTime \(void\)](#)  
*Get the current spacecraft time.*
- [CFE\\_TIME\\_SysTime\\_t CFE\\_TIME\\_GetTAI \(void\)](#)  
*Get the current TAI (MET + SCTF) time.*
- [CFE\\_TIME\\_SysTime\\_t CFE\\_TIME\\_GetUTC \(void\)](#)  
*Get the current UTC (MET + SCTF - Leap Seconds) time.*
- [CFE\\_TIME\\_SysTime\\_t CFE\\_TIME\\_GetMET \(void\)](#)  
*Get the current value of the Mission Elapsed Time (MET).*
- [uint32 CFE\\_TIME\\_GetMETseconds \(void\)](#)  
*Get the current seconds count of the mission-elapsed time.*
- [uint32 CFE\\_TIME\\_GetMETsubsecs \(void\)](#)  
*Get the current sub-seconds count of the mission-elapsed time.*

### 10.44.1 Detailed Description

### 10.44.2 Function Documentation

#### 10.44.2.1 CFE\_TIME\_GetMET()

```
CFE_TIME_SysTime_t CFE_TIME_GetMET (
    void )
```

Get the current value of the Mission Elapsed Time (MET).

#### Description

This routine returns the current mission-elapsed time (MET). MET is usually derived from a hardware-based clock that is not adjusted during normal operations. Callers of this routine should not assume that the MET return value has any specific relationship to any ground-based time standard.

#### Assumptions, External Events, and Notes:

None

#### Returns

The current MET

#### See also

[CFE\\_TIME\\_GetTime](#), [CFE\\_TIME\\_GetTAI](#), [CFE\\_TIME\\_GetUTC](#), [CFE\\_TIME\\_GetMETseconds](#), [CFE\\_TIME\\_GetMETsubsecs](#), [CFE\\_TIME\\_MET2SCTime](#)

### 10.44.2.2 CFE\_TIME\_GetMETseconds()

```
uint32 CFE_TIME_GetMETseconds (
    void )
```

Get the current seconds count of the mission-elapsed time.

#### Description

This routine is the same as [CFE\\_TIME\\_GetMET](#), except that it returns only the integer seconds portion of the MET time.

#### Assumptions, External Events, and Notes:

None

#### Returns

The current MET seconds

#### See also

[CFE\\_TIME\\_GetTime](#), [CFE\\_TIME\\_GetTAI](#), [CFE\\_TIME\\_GetUTC](#), [CFE\\_TIME\\_GetMET](#), [CFE\\_TIME\\_GetMETsubsecs](#), [CFE\\_TIME\\_MET2SCTime](#)

### 10.44.2.3 CFE\_TIME\_GetMETsubsecs()

```
uint32 CFE_TIME_GetMETsubsecs (
    void )
```

Get the current sub-seconds count of the mission-elapsed time.

#### Description

This routine is the same as [CFE\\_TIME\\_GetMET](#), except that it returns only the integer sub-seconds portion of the MET time. Each count is equal to  $2^{-32}$  seconds.

#### Assumptions, External Events, and Notes:

None

#### Returns

The current MET sub-seconds

#### See also

[CFE\\_TIME\\_GetTime](#), [CFE\\_TIME\\_GetTAI](#), [CFE\\_TIME\\_GetUTC](#), [CFE\\_TIME\\_GetMET](#), [CFE\\_TIME\\_GetMETsubsecs](#), [CFE\\_TIME\\_MET2SCTime](#)

#### 10.44.2.4 CFE\_TIME\_GetTAI()

```
CFE_TIME_SysTime_t CFE_TIME_GetTAI (
    void    )
```

Get the current TAI (MET + SCTF) time.

##### Description

This routine returns the current TAI time to the caller. TAI is an international time standard that does not include leap seconds. This routine should only be used in situations where TAI is absolutely required. Applications that call [CFE\\_TIME\\_GetTAI](#) may not be portable to all missions. Maintenance of correct TAI in flight is not guaranteed under all mission operations scenarios. To maintain re-usability across missions, most applications should be using [CFE\\_TIME\\_GetTime](#), rather than the specific routines for getting UTC/TAI directly.

##### Assumptions, External Events, and Notes:

1. The "TAI" time returned is referenced to the mission-defined time epoch, which may or may not be the same as the standard TAI epoch.
2. Even though TAI does not include leap seconds, the time returned by this function can still jump forward or backward without warning when the spacecraft clock is set or adjusted by operators. Applications using this function must be able to handle these time discontinuities gracefully.

##### Returns

The current spacecraft time in TAI

##### See also

[CFE\\_TIME\\_GetTime](#), [CFE\\_TIME\\_GetUTC](#), [CFE\\_TIME\\_GetMET](#), [CFE\\_TIME\\_GetMETseconds](#), [CFE\\_TIME\\_GetMETsubsecs](#)

#### 10.44.2.5 CFE\_TIME\_GetTime()

```
CFE_TIME_SysTime_t CFE_TIME_GetTime (
    void    )
```

Get the current spacecraft time.

##### Description

This routine returns the current spacecraft time, which is the amount of time elapsed since the epoch as set in mission configuration. The time returned is either TAI (no leap seconds) or UTC (including leap seconds). This choice is made in the mission configuration file by defining either [CFE\\_MISSION\\_TIME\\_CFG\\_DEFAULT\\_TAI](#) or [CFE\\_MISSION\\_TIME\\_CFG\\_DEFAULT\\_UTC](#) as true at compile time. To maintain re-usability across missions, most applications should be using this function rather than the specific routines for getting UTC/TAI directly.

##### Assumptions, External Events, and Notes:

None

**Returns**

The current spacecraft time in default format

**See also**

[CFE\\_TIME\\_GetTAI](#), [CFE\\_TIME\\_GetUTC](#), [CFE\\_TIME\\_GetMET](#), [CFE\\_TIME\\_GetMETseconds](#), [CFE\\_TIME\\_GetMETsubsecs](#)

Referenced by `DS_FileCreateSequence()`, and `DS_FileUpdateHeader()`.

#### 10.44.2.6 [CFE\\_TIME\\_GetUTC\(\)](#)

```
CFE_TIME_SysTime_t CFE_TIME_GetUTC (
    void )
```

Get the current UTC (MET + SCTF - Leap Seconds) time.

**Description**

This routine returns the current UTC time to the caller. This routine should only be used in situations where UTC is absolutely required. Applications that call [CFE\\_TIME\\_GetUTC](#) may not be portable to all missions. Maintenance of correct UTC in flight is not guaranteed under all mission operations scenarios. If UTC is maintained in flight, it will jump backwards occasionally due to leap second adjustments. To maintain re-usability across missions, most applications should be using [CFE\\_TIME\\_GetTime](#), rather than the specific routines for getting UTC/TAI directly.

**Assumptions, External Events, and Notes:**

Note: The "UTC" time returned is referenced to the mission-defined time epoch, which may or may not be the same as the standard UTC epoch.

**Returns**

The current spacecraft time in UTC

**See also**

[CFE\\_TIME\\_GetTime](#), [CFE\\_TIME\\_GetTAI](#), [CFE\\_TIME\\_GetMET](#), [CFE\\_TIME\\_GetMETseconds](#), [CFE\\_TIME\\_GetMETsubsecs](#)

## 10.45 cFE Get Time Information APIs

### Functions

- [CFE\\_TIME\\_SysTime\\_t CFE\\_TIME\\_GetSTCF \(void\)](#)  
*Get the current value of the spacecraft time correction factor (STCF).*
- [int16 CFE\\_TIME\\_GetLeapSeconds \(void\)](#)  
*Get the current value of the leap seconds counter.*
- [CFE\\_TIME\\_ClockState\\_Enum\\_t CFE\\_TIME\\_GetClockState \(void\)](#)  
*Get the current state of the spacecraft clock.*
- [uint16 CFE\\_TIME\\_GetClockInfo \(void\)](#)  
*Provides information about the spacecraft clock.*

### 10.45.1 Detailed Description

### 10.45.2 Function Documentation

#### 10.45.2.1 CFE\_TIME\_GetClockInfo()

```
uint16 CFE_TIME_GetClockInfo (
    void )
```

Provides information about the spacecraft clock.

#### Description

This routine returns information on the spacecraft clock in a bit mask.

#### Assumptions, External Events, and Notes:

None

#### Returns

Spacecraft clock information, [cFE Clock State Flag Defines](#). To extract the information from the returned value, the flags can be used as in the following:

```
if ((ReturnValue & CFE_TIME_FLAG_xxxxxxx) == CFE_TIME_FLAG_xxxxxxx) then the following definition of the CFE_TIME_FLAG_xxxxxxx is true.
```

#### See also

[CFE\\_TIME\\_GetSTCF](#), [CFE\\_TIME\\_GetLeapSeconds](#), [CFE\\_TIME\\_GetClockState](#)

### 10.45.2.2 CFE\_TIME\_GetClockState()

```
CFE_TIME_ClockState_Enum_t CFE_TIME_GetClockState (
    void )
```

Get the current state of the spacecraft clock.

#### Description

This routine returns the spacecraft clock state. Applications that are highly dependent on valid time may want to call this routine before taking actions based on the times returned by the various clock routines

#### Assumptions, External Events, and Notes:

None

#### Returns

The current spacecraft clock state

#### See also

[CFE\\_TIME\\_GetSTCF](#), [CFE\\_TIME\\_GetLeapSeconds](#), [CFE\\_TIME\\_GetClockInfo](#)

### 10.45.2.3 CFE\_TIME\_GetLeapSeconds()

```
int16 CFE_TIME_GetLeapSeconds (
    void )
```

Get the current value of the leap seconds counter.

#### Description

This routine returns the current value of the leap seconds counter. This is the delta seconds between international atomic time (TAI) and universal coordinated time (UTC). There is no API provided to set or adjust leap seconds or SCTF, those actions should be done by command only. This API is provided for applications to be able to include leap seconds in their data products to aid in time correlation during downstream science data processing. Note that some mission operations teams do not maintain the leap seconds count, preferring to adjust the STCF instead. Users of this function should check with their mission ops team to see how they are planning to handle leap seconds.

#### Assumptions, External Events, and Notes:

None

#### Returns

The current spacecraft leap seconds.

#### See also

[CFE\\_TIME\\_GetSTCF](#), [CFE\\_TIME\\_GetClockState](#), [CFE\\_TIME\\_GetClockInfo](#)

#### 10.45.2.4 CFE\_TIME\_GetSTCF()

```
CFE_TIME_SysTime_t CFE_TIME_GetSTCF (
    void    )
```

Get the current value of the spacecraft time correction factor (STCF).

##### Description

This routine returns the current value of the spacecraft time correction factor. This is the delta time between the MET and the TAI time. There is no API provided to set or adjust leap seconds or SCTF, those actions should be done by command only. This API is provided for applications to be able to include STCF in their data products to aid in time correlation during downstream science data processing.

##### Assumptions, External Events, and Notes:

Does not include leap seconds

##### Returns

The current SCTF

##### See also

[CFE\\_TIME\\_GetLeapSeconds](#), [CFE\\_TIME\\_GetClockState](#), [CFE\\_TIME\\_GetClockInfo](#)

## 10.46 cFE Time Arithmetic APIs

### Functions

- `CFE_TIME_SysTime_t CFE_TIME_Add (CFE_TIME_SysTime_t Time1, CFE_TIME_SysTime_t Time2)`  
*Adds two time values.*
- `CFE_TIME_SysTime_t CFE_TIME_Subtract (CFE_TIME_SysTime_t Time1, CFE_TIME_SysTime_t Time2)`  
*Subtracts two time values.*
- `CFE_TIME_Compare_t CFE_TIME_Compare (CFE_TIME_SysTime_t TimeA, CFE_TIME_SysTime_t TimeB)`  
*Compares two time values.*

### 10.46.1 Detailed Description

### 10.46.2 Function Documentation

#### 10.46.2.1 CFE\_TIME\_Add()

```
CFE_TIME_SysTime_t CFE_TIME_Add (
    CFE_TIME_SysTime_t Time1,
    CFE_TIME_SysTime_t Time2 )
```

Adds two time values.

#### Description

This routine adds the two specified times and returns the result. Normally, at least one of the input times should be a value representing a delta time. Adding two absolute times together will not cause an error, but the result will probably be meaningless.

#### Assumptions, External Events, and Notes:

None

#### Parameters

in	<code>Time1</code>	The first time to be added.
in	<code>Time2</code>	The second time to be added.

#### Returns

The sum of the two times. If the sum is greater than the maximum value that can be stored in a `CFE_TIME_SysTime_t`, the result will roll over (this is not considered an error).

**See also**

[CFE\\_TIME\\_Subtract](#), [CFE\\_TIME\\_Compare](#)

**10.46.2.2 CFE\_TIME\_Compare()**

```
CFE_TIME_Compare_t CFE_TIME_Compare (
    CFE_TIME_SysTime_t TimeA,
    CFE_TIME_SysTime_t TimeB )
```

Compares two time values.

**Description**

This routine compares two time values to see which is "greater". It is important that applications use this function rather than trying to directly compare the component pieces of times. This function will handle roll-over cases seamlessly, which may not be intuitively obvious. The cFE's internal representation of time "rolls over" when the 32 bit seconds count reaches 0xFFFFFFFF. Also, subtracting a delta time from an absolute time close to the epoch could result in "roll under". The strange cases that result from these situations can be handled by defining the comparison function for times as follows: Plot the two times on the circumference of a circle where 0 is at the top and 0x80000000 is at the bottom. If the shortest arc from time A to time B runs clockwise around the circle, then time A is less than time B. If the shortest arc from A to B runs counter-clockwise, then time A is greater than time B.

**Assumptions, External Events, and Notes:**

None

**Parameters**

in	TimeA	The first time to compare.
in	TimeB	The second time to compare.

**Returns**

The result of comparing the two times.

**Return values**

<a href="#">CFE_TIME_EQUAL</a>	The two specified times are considered to be equal.
<a href="#">CFE_TIME_A_GT↔_B</a>	The first specified time is considered to be after the second specified time.
<a href="#">CFE_TIME_A_LT↔_B</a>	The first specified time is considered to be before the second specified time.

**See also**

[CFE\\_TIME\\_Add](#), [CFE\\_TIME\\_Subtract](#)

### 10.46.2.3 CFE\_TIME\_Subtract()

```
CFE_TIME_SysTime_t CFE_TIME_Subtract (
    CFE_TIME_SysTime_t Time1,
    CFE_TIME_SysTime_t Time2 )
```

Subtracts two time values.

**Description**

This routine subtracts time2 from time1 and returns the result. The time values can represent either absolute or delta times, but not all combinations make sense.

- AbsTime - AbsTime = DeltaTime
- AbsTime - DeltaTime = AbsTime
- DeltaTime - DeltaTime = DeltaTime
- DeltaTime - AbsTime = garbage

**Assumptions, External Events, and Notes:**

None

**Parameters**

in	Time1	The base time.
in	Time2	The time to be subtracted from the base time.

**Returns**

The result of subtracting the two times. If the subtraction results in an underflow, the result will roll over (this is not considered an error).

**See also**

[CFE\\_TIME\\_Add](#), [CFE\\_TIME\\_Compare](#)

## 10.47 cFE Time Conversion APIs

### Functions

- [CFE\\_TIME\\_SysTime\\_t CFE\\_TIME\\_MET2SCTime \(CFE\\_TIME\\_SysTime\\_t METTime\)](#)  
*Convert specified MET into Spacecraft Time.*
- [uint32 CFE\\_TIME\\_Sub2MicroSecs \(uint32 SubSeconds\)](#)  
*Converts a sub-seconds count to an equivalent number of microseconds.*
- [uint32 CFE\\_TIME\\_Micro2SubSecs \(uint32 MicroSeconds\)](#)  
*Converts a number of microseconds to an equivalent sub-seconds count.*

### 10.47.1 Detailed Description

### 10.47.2 Function Documentation

#### 10.47.2.1 CFE\_TIME\_MET2SCTime()

```
CFE_TIME_SysTime_t CFE_TIME_MET2SCTime (
    CFE_TIME_SysTime_t METTime )
```

Convert specified MET into Spacecraft Time.

#### Description

This function returns Spacecraft Time given MET. Note that Spacecraft Time is returned as either UTC or TAI depending on whether the mission configuration parameter [CFE\\_MISSION\\_TIME\\_CFG\\_DEFAULT\\_UTC](#) or [CFE\\_MISSION\\_TIME\\_CFG\\_DEFAULT\\_TAI](#) was set to true at compile time.

#### Assumptions, External Events, and Notes:

None

#### Parameters

in	METTime	The MET to be converted.
----	---------	--------------------------

#### Returns

Spacecraft Time (UTC or TAI) corresponding to the specified MET

#### See also

[CFE\\_TIME\\_GetMET](#), [CFE\\_TIME\\_GetMETseconds](#), [CFE\\_TIME\\_GetMETsubsecs](#), [CFE\\_TIME\\_Sub2MicroSecs](#), [CFE\\_TIME\\_Micro2SubSecs](#)

### 10.47.2.2 CFE\_TIME\_Micro2SubSecs()

```
uint32 CFE_TIME_Micro2SubSecs (
    uint32 MicroSeconds )
```

Converts a number of microseconds to an equivalent sub-seconds count.

#### Description

This routine converts from microseconds (each tick is 1e-06 seconds) to a subseconds count (each tick is  $1 / 2^{32}$  seconds).

#### Assumptions, External Events, and Notes:

None

#### Parameters

in	MicroSeconds	The sub-seconds count to convert.
----	--------------	-----------------------------------

#### Returns

The equivalent number of subseconds. If the number of microseconds passed in is greater than one second, (i.e. > 999,999), the return value is equal to 0xffffffff.

#### See also

[CFE\\_TIME\\_MET2SCTime](#), [CFE\\_TIME\\_Sub2MicroSecs](#),

### 10.47.2.3 CFE\_TIME\_Sub2MicroSecs()

```
uint32 CFE_TIME_Sub2MicroSecs (
    uint32 SubSeconds )
```

Converts a sub-seconds count to an equivalent number of microseconds.

#### Description

This routine converts from a sub-seconds count (each tick is  $1 / 2^{32}$  seconds) to microseconds (each tick is 1e-06 seconds).

#### Assumptions, External Events, and Notes:

None

**Parameters**

in	<i>SubSeconds</i>	The sub-seconds count to convert.
----	-------------------	-----------------------------------

**Returns**

The equivalent number of microseconds.

**See also**

[CFE\\_TIME\\_MET2SCTime](#), [CFE\\_TIME\\_Micro2SubSecs](#),

## 10.48 cFE External Time Source APIs

### Functions

- void [CFE\\_TIME\\_ExternalTone](#) (void)  
*Provides the 1 Hz signal from an external source.*
- void [CFE\\_TIME\\_ExternalMET](#) ([CFE\\_TIME\\_SysTime\\_t](#) NewMET)  
*Provides the Mission Elapsed Time from an external source.*
- void [CFE\\_TIME\\_ExternalGPS](#) ([CFE\\_TIME\\_SysTime\\_t](#) NewTime, [int16](#) NewLeaps)  
*Provide the time from an external source that has data common to GPS receivers.*
- void [CFE\\_TIME\\_ExternalTime](#) ([CFE\\_TIME\\_SysTime\\_t](#) NewTime)  
*Provide the time from an external source that measures time relative to a known epoch.*
- [CFE\\_Status\\_t CFE\\_TIME\\_RegisterSynchCallback](#) ([CFE\\_TIME\\_SynchCallbackPtr\\_t](#) CallbackFuncPtr)  
*Registers a callback function that is called whenever time synchronization occurs.*
- [CFE\\_Status\\_t CFE\\_TIME\\_UnregisterSynchCallback](#) ([CFE\\_TIME\\_SynchCallbackPtr\\_t](#) CallbackFuncPtr)  
*Unregisters a callback function that is called whenever time synchronization occurs.*

#### 10.48.1 Detailed Description

#### 10.48.2 Function Documentation

##### 10.48.2.1 [CFE\\_TIME\\_ExternalGPS\(\)](#)

```
void CFE_TIME_ExternalGPS (
    CFE\_TIME\_SysTime\_t NewTime,
    int16 NewLeaps )
```

Provide the time from an external source that has data common to GPS receivers.

#### Description

This routine provides a method to provide cFE TIME with current time data acquired from an external source. There is a presumption that this function will be called at the appropriate time (relative to the tone) such that this call may be used by cFE TIME as the signal to generate the "time at the tone" data command. The "time at the tone" data command must arrive within the configuration parameter specified window for tone signal and data packet verification.

Internally, cFE TIME will calculate a new STCF as the difference between this new time value and the space-craft MET value at the tone. This allows cFE TIME to always calculate time as the sum of MET and STCF. The value of STCF will change only as much as the drift factor between spacecraft MET and the external time source.

#### Assumptions, External Events, and Notes:

- This routine is included in the API only when 3 specific configuration parameters are set to true. The first is [CFE\\_PLATFORM\\_TIME\\_CFG\\_SERVER](#) which defines this instantiation of cFE TIME as a time server (not a client). The second required configuration parameter is [CFE\\_PLATFORM\\_TIME\\_CFG\\_SOURCE](#) which enables time source selection commands to the cFE TIME task, and further enables configuration definitions for the selected type of external time data. The third configuration parameter required for this routine is [CFE\\_PLATFORM\\_TIME\\_CFG\\_SRC\\_GPS](#), which indicates that the external time data consists of a time value relative to a known epoch, plus a leap seconds value.

## Parameters

in	<i>NewTime</i>	The MET value at the next (or previous) 1 Hz tone signal.
in	<i>NewLeaps</i>	The Leap Seconds value used to calculate time as UTC.

## See also

[CFE\\_TIME\\_ExternalTone](#), [CFE\\_TIME\\_ExternalMET](#), [CFE\\_TIME\\_ExternalTime](#)

### 10.48.2.2 CFE\_TIME\_ExternalMET()

```
void CFE_TIME_ExternalMET (
    CFE_TIME_SysTime_t NewMET )
```

Provides the Mission Elapsed Time from an external source.

## Description

This routine provides a method to provide cFE TIME with MET acquired from an external source. There is a presumption that this function will be called at the appropriate time (relative to the tone) such that this call may be used by cFE TIME as the signal to generate the "time at the tone" data command. The "time at the tone" data command must arrive within the configuration parameter specified window for tone signal and data packet verification.

The MET value at the tone "should" have zero subseconds. Although the interface accepts non-zero values for sub-seconds, it may be harmful to other applications that expect zero subseconds at the moment of the tone. Any decision to use non-zero subseconds should be carefully considered.

## Assumptions, External Events, and Notes:

- This routine is included in the API only when 3 specific configuration parameters are set to true. The first is [CFE\\_PLATFORM\\_TIME\\_CFG\\_SERVER](#) which defines this instantiation of cFE TIME as a time server (not a client). The second required configuration parameter is [CFE\\_PLATFORM\\_TIME\\_CFG\\_SOURCE](#) which enables time source selection commands to the cFE TIME task, and further enables configuration definitions for the selected type of external time data. The third configuration parameter required for this routine is [CFE\\_PLATFORM\\_TIME\\_CFG\\_SRC\\_MET](#), which indicates that the external time data consists of MET.

## Parameters

in	<i>NewMET</i>	The MET value at the next (or previous) 1 Hz tone signal.
----	---------------	---

## See also

[CFE\\_TIME\\_ExternalTone](#), [CFE\\_TIME\\_ExternalGPS](#), [CFE\\_TIME\\_ExternalTime](#)

#### 10.48.2.3 CFE\_TIME\_ExternalTime()

```
void CFE_TIME_ExternalTime (
    CFE_TIME_SysTime_t NewTime )
```

Provide the time from an external source that measures time relative to a known epoch.

##### Description

This routine provides a method to provide cFE TIME with current time data acquired from an external source. There is a presumption that this function will be called at the appropriate time (relative to the tone) such that this call may be used by cFE TIME as the signal to generate the "time at the tone" data command. The "time at the tone" data command must arrive within the configuration specified window for tone signal and data packet verification.

Internally, cFE TIME will calculate a new STCF as the difference between this new time value and the space-craft MET value at the tone. This allows cFE TIME to always calculate time as the sum of MET and STCF. The value of STCF will change only as much as the drift factor between spacecraft MET and the external time source.

##### Assumptions, External Events, and Notes:

- This routine is included in the API only when 3 specific configuration parameters are set to true. The first is [CFE\\_PLATFORM\\_TIME\\_CFG\\_SERVER](#) which defines this instantiation of cFE TIME as a time server (not a client). The second required configuration parameter is [CFE\\_PLATFORM\\_TIME\\_CFG\\_SOURCE](#) which enables time source selection commands to the cFE TIME task, and further enables configuration definitions for the selected type of external time data. The third configuration parameter required for this routine is [CFE\\_PLATFORM\\_TIME\\_CFG\\_SRC\\_TIME](#), which indicates that the external time data consists of a time value relative to a known epoch.

##### Parameters

in	<i>NewTime</i>	The MET value at the next (or previous) 1 Hz tone signal.
----	----------------	---

##### See also

[CFE\\_TIME\\_ExternalTone](#), [CFE\\_TIME\\_ExternalMET](#), [CFE\\_TIME\\_ExternalGPS](#)

#### 10.48.2.4 CFE\_TIME\_ExternalTone()

```
void CFE_TIME_ExternalTone (
    void )
```

Provides the 1 Hz signal from an external source.

##### Description

This routine provides a method for cFE TIME software to be notified of the occurrence of the 1Hz tone signal without knowledge of the specific hardware design. Regardless of the source of the tone, this routine should be called as soon as possible after detection to allow cFE TIME software the opportunity to latch the local clock as close as possible to the instant of the tone.

#### Assumptions, External Events, and Notes:

- This routine may be called directly from within the context of an interrupt handler.

#### See also

[CFE\\_TIME\\_ExternalMET](#), [CFE\\_TIME\\_ExternalGPS](#), [CFE\\_TIME\\_ExternalTime](#)

#### 10.48.2.5 CFE\_TIME\_RegisterSynchCallback()

```
CFE_Status_t CFE_TIME_RegisterSynchCallback (
    CFE_TIME_SynchCallbackPtr_t CallbackFuncPtr )
```

Registers a callback function that is called whenever time synchronization occurs.

#### Description

This routine passes a callback function pointer for an Application that wishes to be notified whenever a legitimate time synchronization signal (typically a 1 Hz) is received.

#### Assumptions, External Events, and Notes:

Only a single callback per application is supported, and this function should only be called from a single thread within each application (typically the apps main thread). If an application requires triggering multiple child tasks at 1Hz, it should distribute the timing signal internally, rather than registering for multiple callbacks.

#### Parameters

in	<i>CallbackFuncPtr</i>	Function to call at synchronization interval (must not be null)
----	------------------------	---

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_TIME_TOO_MANY_SYNCH_CALLBACKS</i>	Too Many Sync Callbacks.
<i>CFE_TIME_BAD_ARGUMENT</i>	Bad Argument.

#### See also

[CFE\\_TIME\\_UnregisterSynchCallback](#)

#### 10.48.2.6 CFE\_TIME\_UnregisterSynchCallback()

```
CFE_Status_t CFE_TIME_UnregisterSynchCallback (
    CFE_TIME_SynchCallbackPtr_t CallbackFuncPtr )
```

Unregisters a callback function that is called whenever time synchronization occurs.

##### Description

This routine removes the specified callback function pointer from the list of Callback functions that are called whenever a time synchronization (typically the 1Hz signal) is received.

##### Assumptions, External Events, and Notes:

Only a single callback per application is supported, and this function should only be called from a single thread within each application (typically the apps main thread).

##### Parameters

in	<i>CallbackFuncPtr</i>	Function to remove from synchronization call list (must not be null)
----	------------------------	--

##### Returns

Execution status, see [cFE Return Code Defines](#)

##### Return values

<i>CFE_SUCCESS</i>	Successful execution.
<i>CFE_TIME_CALLBACK_NOT_REGISTERED</i>	Callback Not Registered.
<i>CFE_TIME_BAD_ARGUMENT</i>	Bad Argument.

##### See also

[CFE\\_TIME\\_RegisterSynchCallback](#)

## 10.49 cFE Miscellaneous Time APIs

### Functions

- void [CFE\\_TIME\\_Print](#) (char \*PrintBuffer, [CFE\\_TIME\\_SysTime\\_t](#) TimeToPrint)  
*Print a time value as a string.*
- void [CFE\\_TIME\\_Local1HzISR](#) (void)  
*This function is called via a timer callback set up at initialization of the TIME service.*

#### 10.49.1 Detailed Description

#### 10.49.2 Function Documentation

##### 10.49.2.1 CFE\_TIME\_Local1HzISR()

```
void CFE_TIME_Local1HzISR (
    void )
```

This function is called via a timer callback set up at initialization of the TIME service.

#### Description

Drives the time processing logic from the system PSP layer. This must be called once per second based on a hardware interrupt or OS kernel signal.

#### Assumptions, External Events, and Notes:

This will update the global data structures accordingly, incrementing each by the 1Hz amount.

##### 10.49.2.2 CFE\_TIME\_Print()

```
void CFE_TIME_Print (
    char * PrintBuffer,
    CFE\_TIME\_SysTime\_t TimeToPrint )
```

Print a time value as a string.

#### Description

This routine prints the specified time to the specified string buffer in the following format:

yyyy-ddd-hh:mm:ss.xxxxx\0

where:

- `YYYY` = year
- `ddd` = Julian day of the year
- `hh` = hour of the day (0 to 23)
- `mm` = minute (0 to 59)
- `ss` = second (0 to 59)
- `xxxxx` = subsecond formatted as a decimal fraction (1/4 second = 0.25000)
- `\0` = trailing null

**Assumptions, External Events, and Notes:**

- The value of the time argument is simply added to the configuration definitions for the ground epoch and converted into a fixed length string in the buffer provided by the caller.
- A loss of data during the string conversion will occur if the computed year exceeds 9999. However, a year that large would require an unrealistic definition for the ground epoch since the maximum amount of time represented by a [CFE\\_TIME\\_SysTime](#) structure is approximately 136 years.

**Parameters**

out	<i>PrintBuffer</i>	Pointer to a character array (must not be null) of at least <a href="#">CFE_TIME_PRINTED_STRING_SIZE</a> characters in length. *PrintBuffer is the time as a character string as described above.
in	<i>TimeToPrint</i>	The time to print into the character array.

Referenced by DS\_FileCreateSequence().

## 10.50 cFE Resource ID base values

### Enumerations

- enum {
   
**CFE\_RESOURCEID\_ES\_TASKID\_BASE\_OFFSET** = OS\_OBJECT\_TYPE\_OS\_TASK, **CFE\_RESOURCEID\_ES\_APPID\_BASE\_OFFSET** = OS\_OBJECT\_TYPE\_USER + 1, **CFE\_RESOURCEID\_ES\_LIBID\_BASE\_OFFSET** = OS\_OBJECT\_TYPE\_USER + 2, **CFE\_RESOURCEID\_ES\_COUNTID\_BASE\_OFFSET** = OS\_OBJECT\_TYPE\_USER + 3,
   
**CFE\_RESOURCEID\_ES\_POOLID\_BASE\_OFFSET** = OS\_OBJECT\_TYPE\_USER + 4, **CFE\_RESOURCEID\_ES\_CDSBLOCKID\_BASE\_OFFSET** = OS\_OBJECT\_TYPE\_USER + 5, **CFE\_RESOURCEID\_SB\_PIPEID\_RESOURCE\_BASE\_OFFSET** = OS\_OBJECT\_TYPE\_USER + 6, **CFE\_RESOURCEID\_CONFIGID\_BASE\_OFFSET** = OS\_OBJECT\_TYPE\_USER + 7 }
- enum {
   
**CFE\_ES\_TASKID\_BASE** = CFE\_RESOURCEID\_MAKE\_BASE(CFE\_RESOURCEID\_ES\_TASKID\_BASE\_OFFSET), **CFE\_ES\_APPID\_BASE** = CFE\_RESOURCEID\_MAKE\_BASE(CFE\_RESOURCEID\_ES\_APPID\_BASE\_OFFSET), **CFE\_ES\_LIBID\_BASE** = CFE\_RESOURCEID\_MAKE\_BASE(CFE\_RESOURCEID\_ES\_LIBID\_BASE\_OFFSET), **CFE\_ES\_COUNTID\_BASE** = CFE\_RESOURCEID\_MAKE\_BASE(CFE\_RESOURCEID\_ES\_COUNTID\_BASE\_OFFSET),
   
**CFE\_ES\_POOLID\_BASE** = CFE\_RESOURCEID\_MAKE\_BASE(CFE\_RESOURCEID\_ES\_POOLID\_BASE\_OFFSET), **CFE\_ES\_CDSBLOCKID\_BASE** = CFE\_RESOURCEID\_MAKE\_BASE(CFE\_RESOURCEID\_ES\_CDSBLOCKID\_BASE\_OFFSET), **CFE\_SB\_PIPEID\_BASE** = CFE\_RESOURCEID\_MAKE\_BASE(CFE\_RESOURCEID\_SB\_PIPEID\_RESOURCE\_BASE\_OFFSET), **CFE\_CONFIGID\_BASE** = CFE\_RESOURCEID\_MAKE\_BASE(CFE\_RESOURCEID\_CONFIGID\_BASE\_OFFSET) }

### 10.50.1 Detailed Description

### 10.50.2 Enumeration Type Documentation

#### 10.50.2.1 anonymous enum

anonymous enum

##### Enumerator

<b>CFE_RESOURCEID_ES_TASKID_BASE_OFFSET</b>	
<b>CFE_RESOURCEID_ES_APPID_BASE_OFFSET</b>	
<b>CFE_RESOURCEID_ES_LIBID_BASE_OFFSET</b>	
<b>CFE_RESOURCEID_ES_COUNTID_BASE_OFFSET</b>	
<b>CFE_RESOURCEID_ES_POOLID_BASE_OFFSET</b>	
<b>CFE_RESOURCEID_ES_CDSBLOCKID_BASE_OFFSET</b>	
<b>CFE_RESOURCEID_SB_PIPEID_RESOURCE_BASE_OFFSET</b>	
<b>CFE_RESOURCEID_CONFIGID_BASE_OFFSET</b>	

Definition at line 48 of file `cfe_core_resourceid_basevalues.h`.

### 10.50.2.2 anonymous enum

anonymous enum

Enumerator

CFE_ES_TASKID_BASE	
CFE_ES_APPID_BASE	
CFE_ES_LIBID_BASE	
CFE_ES_COUNTID_BASE	
CFE_ES_POOLID_BASE	
CFE_ES_CDSBLOCKID_BASE	
CFE_SB_PIPEID_BASE	
CFE_CONFIGID_BASE	

Definition at line 81 of file cfe\_core\_resourceid\_basevalues.h.

## 10.51 cFE Clock State Flag Defines

### Macros

- #define CFE\_TIME\_FLAG\_CLKSET 0x8000  
*The spacecraft time has been set.*
- #define CFE\_TIME\_FLAG\_FLYING 0x4000  
*This instance of Time Services is flywheeling.*
- #define CFE\_TIME\_FLAG\_SRCINT 0x2000  
*The clock source is set to "internal".*
- #define CFE\_TIME\_FLAG\_SIGPRI 0x1000  
*The clock signal is set to "primary".*
- #define CFE\_TIME\_FLAG\_SRVFLY 0x0800  
*The Time Server is in flywheel mode.*
- #define CFE\_TIME\_FLAG\_CMDFLY 0x0400  
*This instance of Time Services was commanded into flywheel mode.*
- #define CFE\_TIME\_FLAG\_ADDADJ 0x0200  
*One time STCF Adjustment is to be done in positive direction.*
- #define CFE\_TIME\_FLAG\_ADD1HZ 0x0100  
*1 Hz STCF Adjustment is to be done in a positive direction*
- #define CFE\_TIME\_FLAG\_ADDTCL 0x0080  
*Time Client Latency is applied in a positive direction.*
- #define CFE\_TIME\_FLAG\_SERVER 0x0040  
*This instance of Time Services is a Time Server.*
- #define CFE\_TIME\_FLAG\_GDTONE 0x0020  
*The tone received is good compared to the last tone received.*
- #define CFE\_TIME\_FLAG\_REFERR 0x0010  
*GetReference read error, will be set if unable to get a consistent ref value.*
- #define CFE\_TIME\_FLAG\_UNUSED 0x000F  
*Reserved flags - should be zero.*

### 10.51.1 Detailed Description

### 10.51.2 Macro Definition Documentation

#### 10.51.2.1 CFE\_TIME\_FLAG\_ADD1HZ

```
#define CFE_TIME_FLAG_ADD1HZ 0x0100
```

1 Hz STCF Adjustment is to be done in a positive direction

Definition at line 715 of file cfe\_time\_msg.h.

### 10.51.2.2 CFE\_TIME\_FLAG\_ADDADJ

```
#define CFE_TIME_FLAG_ADDADJ 0x0200
```

One time STCF Adjustment is to be done in positive direction.

Definition at line 714 of file cfe\_time\_msg.h.

### 10.51.2.3 CFE\_TIME\_FLAG\_ADDTCL

```
#define CFE_TIME_FLAG_ADDTCL 0x0080
```

Time Client Latency is applied in a positive direction.

Definition at line 716 of file cfe\_time\_msg.h.

### 10.51.2.4 CFE\_TIME\_FLAG\_CLKSET

```
#define CFE_TIME_FLAG_CLKSET 0x8000
```

The spacecraft time has been set.

Definition at line 708 of file cfe\_time\_msg.h.

### 10.51.2.5 CFE\_TIME\_FLAG\_CMDFLY

```
#define CFE_TIME_FLAG_CMDFLY 0x0400
```

This instance of Time Services was commanded into flywheel mode.

Definition at line 713 of file cfe\_time\_msg.h.

### 10.51.2.6 CFE\_TIME\_FLAG\_FLYING

```
#define CFE_TIME_FLAG_FLYING 0x4000
```

This instance of Time Services is flywheeling.

Definition at line 709 of file cfe\_time\_msg.h.

### 10.51.2.7 CFE\_TIME\_FLAG\_GDTONE

```
#define CFE_TIME_FLAG_GDTONE 0x0020
```

The tone received is good compared to the last tone received.

Definition at line 718 of file cfe\_time\_msg.h.

### 10.51.2.8 CFE\_TIME\_FLAG\_REFERR

```
#define CFE_TIME_FLAG_REFERR 0x0010
```

GetReference read error, will be set if unable to get a consistent ref value.

Definition at line 719 of file cfe\_time\_msg.h.

### 10.51.2.9 CFE\_TIME\_FLAG\_SERVER

```
#define CFE_TIME_FLAG_SERVER 0x0040
```

This instance of Time Services is a Time Server.

Definition at line 717 of file cfe\_time\_msg.h.

### 10.51.2.10 CFE\_TIME\_FLAG\_SIGPRI

```
#define CFE_TIME_FLAG_SIGPRI 0x1000
```

The clock signal is set to "primary".

Definition at line 711 of file cfe\_time\_msg.h.

### 10.51.2.11 CFE\_TIME\_FLAG\_SRCINT

```
#define CFE_TIME_FLAG_SRCINT 0x2000
```

The clock source is set to "internal".

Definition at line 710 of file cfe\_time\_msg.h.

### 10.51.2.12 CFE\_TIME\_FLAG\_SRVFLY

```
#define CFE_TIME_FLAG_SRVFLY 0x0800
```

The Time Server is in flywheel mode.

Definition at line 712 of file cfe\_time\_msg.h.

### 10.51.2.13 CFE\_TIME\_FLAG\_UNUSED

```
#define CFE_TIME_FLAG_UNUSED 0x000F
```

Reserved flags - should be zero.

Definition at line 721 of file cfe\_time\_msg.h.

## 10.52 OSAL Semaphore State Defines

### Macros

- `#define OS_SEM_FULL 1`  
*Semaphore full state.*
- `#define OS_SEM_EMPTY 0`  
*Semaphore empty state.*

#### 10.52.1 Detailed Description

#### 10.52.2 Macro Definition Documentation

##### 10.52.2.1 OS\_SEM\_EMPTY

```
#define OS_SEM_EMPTY 0
```

Semaphore empty state.

Definition at line 35 of file osapi-binsem.h.

##### 10.52.2.2 OS\_SEM\_FULL

```
#define OS_SEM_FULL 1
```

Semaphore full state.

Definition at line 34 of file osapi-binsem.h.

## 10.53 OSAL Binary Semaphore APIs

### Functions

- `int32 OS_BinSemCreate (osal_id_t *sem_id, const char *sem_name, uint32 sem_initial_value, uint32 options)`  
*Creates a binary semaphore.*
- `int32 OS_BinSemFlush (osal_id_t sem_id)`  
*Unblock all tasks pending on the specified semaphore.*
- `int32 OS_BinSemGive (osal_id_t sem_id)`  
*Increment the semaphore value.*
- `int32 OS_BinSemTake (osal_id_t sem_id)`  
*Decrement the semaphore value.*
- `int32 OS_BinSemTimedWait (osal_id_t sem_id, uint32 msecs)`  
*Decrement the semaphore value with a timeout.*
- `int32 OS_BinSemDelete (osal_id_t sem_id)`  
*Deletes the specified Binary Semaphore.*
- `int32 OS_BinSemGetIdByName (osal_id_t *sem_id, const char *sem_name)`  
*Find an existing semaphore ID by name.*
- `int32 OS_BinSemGetInfo (osal_id_t sem_id, OS_bin_sem_prop_t *bin_prop)`  
*Fill a property object buffer with details regarding the resource.*

#### 10.53.1 Detailed Description

#### 10.53.2 Function Documentation

##### 10.53.2.1 OS\_BinSemCreate()

```
int32 OS_BinSemCreate (
    osal_id_t * sem_id,
    const char * sem_name,
    uint32 sem_initial_value,
    uint32 options )
```

Creates a binary semaphore.

Creates a binary semaphore with initial value specified by `sem_initial_value` and name specified by `sem_name`. `sem_id` will be returned to the caller

#### Parameters

<code>out</code>	<code>sem_id</code>	will be set to the non-zero ID of the newly-created resource (must not be null)
<code>in</code>	<code>sem_name</code>	the name of the new resource to create (must not be null)
<code>in</code>	<code>sem_initial_value</code>	the initial value of the binary semaphore
<code>in</code>	<code>options</code>	Reserved for future use, should be passed as 0.

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if sen name or sem_id are NULL
<i>OS_ERR_NAME_TOO_LONG</i>	name length including null terminator greater than <i>OS_MAX_API_NAME</i>
<i>OS_ERR_NO_FREE_IDS</i>	if all of the semaphore ids are taken
<i>OS_ERR_NAME_TAKEN</i>	if this is already the name of a binary semaphore
<i>OS_SEM_FAILURE</i>	if the OS call failed (return value only verified in coverage test)

**10.53.2.2 OS\_BinSemDelete()**

```
int32 OS_BinSemDelete (
    osal_id_t sem_id )
```

Deletes the specified Binary Semaphore.

This is the function used to delete a binary semaphore in the operating system. This also frees the respective sem\_id to be used again when another semaphore is created.

**Parameters**

in	<i>sem_id</i>	The object ID to delete
----	---------------	-------------------------

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the id passed in is not a valid binary semaphore
<i>OS_SEM_FAILURE</i>	if an unspecified failure occurs (return value only verified in coverage test)

**10.53.2.3 OS\_BinSemFlush()**

```
int32 OS_BinSemFlush (
    osal_id_t sem_id )
```

Unblock all tasks pending on the specified semaphore.

The function unblocks all tasks pending on the specified semaphore. However, this function does not change the state of the semaphore.

#### Parameters

in	<i>sem_id</i>	The object ID to operate on
----	---------------	-----------------------------

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_ERR_INVALID_ID</a>	if the id passed in is not a binary semaphore
<a href="#">OS_SEM_FAILURE</a>	if an unspecified failure occurs (return value only verified in coverage test)

### 10.53.2.4 OS\_BinSemGetIdByName()

```
int32 OS_BinSemGetIdByName (
    osal_id_t * sem_id,
    const char * sem_name )
```

Find an existing semaphore ID by name.

This function tries to find a binary sem Id given the name of a bin\_sem. The id is returned through sem\_id

#### Parameters

out	<i>sem_id</i>	will be set to the ID of the existing resource
in	<i>sem_name</i>	the name of the existing resource to find (must not be null)

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_INVALID_POINTER</a>	is semid or sem_name are NULL pointers
<a href="#">OS_ERR_NAME_TOO_LONG</a>	name length including null terminator greater than <a href="#">OS_MAX_API_NAME</a>
<a href="#">OS_ERR_NAME_NOT_FOUND</a>	if the name was not found in the table

### 10.53.2.5 OS\_BinSemGetInfo()

```
int32 OS_BinSemGetInfo (
    osal_id_t sem_id,
    OS_bin_sem_prop_t * bin_prop )
```

Fill a property object buffer with details regarding the resource.

This function will pass back a pointer to structure that contains all of the relevant info( name and creator) about the specified binary semaphore.

#### Parameters

in	<i>sem_id</i>	The object ID to operate on
out	<i>bin_prop</i>	The property object buffer to fill (must not be null)

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the id passed in is not a valid semaphore
<i>OS_INVALID_POINTER</i>	if the bin_prop pointer is null

### 10.53.2.6 OS\_BinSemGive()

```
int32 OS_BinSemGive (
    osal_id_t sem_id )
```

Increment the semaphore value.

The function unlocks the semaphore referenced by *sem\_id* by performing a semaphore unlock operation on that semaphore. If the semaphore value resulting from this operation is positive, then no threads were blocked waiting for the semaphore to become unlocked; the semaphore value is simply incremented for this semaphore.

#### Parameters

in	<i>sem_id</i>	The object ID to operate on
----	---------------	-----------------------------

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the id passed in is not a binary semaphore
<i>OS_SEM_FAILURE</i>	if an unspecified failure occurs (return value only verified in coverage test)

**10.53.2.7 OS\_BinSemTake()**

```
int32 OS_BinSemTake (
    osal_id_t sem_id )
```

Decrement the semaphore value.

The locks the semaphore referenced by *sem\_id* by performing a semaphore lock operation on that semaphore. If the semaphore value is currently zero, then the calling thread shall not return from the call until it either locks the semaphore or the call is interrupted.

**Parameters**

in	<i>sem_id</i>	The object ID to operate on
----	---------------	-----------------------------

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	the Id passed in is not a valid binary semaphore
<i>OS_SEM_FAILURE</i>	if an unspecified failure occurs (return value only verified in coverage test)

**10.53.2.8 OS\_BinSemTimedWait()**

```
int32 OS_BinSemTimedWait (
    osal_id_t sem_id,
    uint32 msecs )
```

Decrement the semaphore value with a timeout.

The function locks the semaphore referenced by `sem_id`. However, if the semaphore cannot be locked without waiting for another process or thread to unlock the semaphore, this wait shall be terminated when the specified timeout, `msecs`, expires.

#### Parameters

in	<code>sem_id</code>	The object ID to operate on
in	<code>msecs</code>	The maximum amount of time to block, in milliseconds

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<code>OS_SUCCESS</code>	Successful execution.
<code>OS_SEM_TIMEOUT</code>	if semaphore was not relinquished in time
<code>OS_ERR_INVALID_ID</code>	if the ID passed in is not a valid semaphore ID
<code>OS_SEM_FAILURE</code>	if an unspecified failure occurs (return value only verified in coverage test)

## 10.54 OSAL BSP low level access APIs

### Functions

- void `OS_BSP_SetResourceTypeConfig (uint32 ResourceType, uint32 ConfigOptionValue)`
- `uint32 OS_BSP_GetResourceTypeConfig (uint32 ResourceType)`
- `uint32 OS_BSP_GetArgC (void)`
- `char *const * OS_BSP_GetArgV (void)`
- void `OS_BSP_SetExitCode (int32 code)`

#### 10.54.1 Detailed Description

These are for OSAL internal BSP information access to pass any BSP-specific boot/command line/startup arguments through to the application, and return a status code back to the OS after exit.

Not intended for user application use

#### 10.54.2 Function Documentation

##### 10.54.2.1 OS\_BSP\_GetArgC()

```
uint32 OS_BSP_GetArgC (
    void )
```

##### 10.54.2.2 OS\_BSP\_GetArgV()

```
char* const* OS_BSP_GetArgV (
    void )
```

##### 10.54.2.3 OS\_BSP\_SetResourceTypeConfig()

```
uint32 OS_BSP_SetResourceTypeConfig (
    uint32 ResourceType )
```

##### 10.54.2.4 OS\_BSP\_SetExitCode()

```
void OS_BSP_SetExitCode (
    int32 code )
```

##### 10.54.2.5 OS\_BSP\_SetResourceTypeConfig()

```
void OS_BSP_SetResourceTypeConfig (
    uint32 ResourceType,
    uint32 ConfigOptionValue )
```

## 10.55 OSAL Real Time Clock APIs

### Functions

- `int32 OS_GetLocalTime (OS_time_t *time_struct)`  
*Get the local time.*
- `int32 OS_SetLocalTime (const OS_time_t *time_struct)`  
*Set the local time.*
- static `int64 OS_TimeGetTotalSeconds (OS_time_t tm)`  
*Get interval from an `OS_time_t` object normalized to whole number of seconds.*
- static `int64 OS_TimeGetTotalMilliseconds (OS_time_t tm)`  
*Get interval from an `OS_time_t` object normalized to millisecond units.*
- static `int64 OS_TimeGetTotalMicroseconds (OS_time_t tm)`  
*Get interval from an `OS_time_t` object normalized to microsecond units.*
- static `int64 OS_TimeGetTotalNanoseconds (OS_time_t tm)`  
*Get interval from an `OS_time_t` object normalized to nanosecond units.*
- static `int64 OS_TimeGetFractionalPart (OS_time_t tm)`  
*Get subseconds portion (fractional part only) from an `OS_time_t` object.*
- static `uint32 OS_TimeGetSubsecondsPart (OS_time_t tm)`  
*Get 32-bit normalized subseconds (fractional part only) from an `OS_time_t` object.*
- static `uint32 OS_TimeGetMillisecondsPart (OS_time_t tm)`  
*Get milliseconds portion (fractional part only) from an `OS_time_t` object.*
- static `uint32 OS_TimeGetMicrosecondsPart (OS_time_t tm)`  
*Get microseconds portion (fractional part only) from an `OS_time_t` object.*
- static `uint32 OS_TimeGetNanosecondsPart (OS_time_t tm)`  
*Get nanoseconds portion (fractional part only) from an `OS_time_t` object.*
- static `OS_time_t OS_TimeAssembleFromNanoseconds (int64 seconds, uint32 nanoseconds)`  
*Assemble/Convert a number of seconds + nanoseconds into an `OS_time_t` interval.*
- static `OS_time_t OS_TimeAssembleFromMicroseconds (int64 seconds, uint32 microseconds)`  
*Assemble/Convert a number of seconds + microseconds into an `OS_time_t` interval.*
- static `OS_time_t OS_TimeAssembleFromMilliseconds (int64 seconds, uint32 milliseconds)`  
*Assemble/Convert a number of seconds + milliseconds into an `OS_time_t` interval.*
- static `OS_time_t OS_TimeAssembleFromSubseconds (int64 seconds, uint32 subseconds)`  
*Assemble/Convert a number of seconds + subseconds into an `OS_time_t` interval.*
- static `OS_time_t OS_TimeAdd (OS_time_t time1, OS_time_t time2)`  
*Computes the sum of two time intervals.*
- static `OS_time_t OS_TimeSubtract (OS_time_t time1, OS_time_t time2)`  
*Computes the difference between two time intervals.*

### 10.55.1 Detailed Description

### 10.55.2 Function Documentation

### 10.55.2.1 OS\_GetLocalTime()

```
int32 OS_GetLocalTime (
    OS_time_t * time_struct )
```

Get the local time.

This function gets the local time from the underlying OS.

#### Note

Mission time management typically uses the cFE Time Service

#### Parameters

out	time_struct	An <a href="#">OS_time_t</a> that will be set to the current time (must not be null)
-----	-------------	--

#### Returns

Get local time status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_INVALID_POINTER</a>	if time_struct is null

### 10.55.2.2 OS\_SetLocalTime()

```
int32 OS_SetLocalTime (
    const OS_time_t * time_struct )
```

Set the local time.

This function sets the local time on the underlying OS.

#### Note

Mission time management typically uses the cFE Time Services

#### Parameters

in	time_struct	An <a href="#">OS_time_t</a> containing the current time (must not be null)
----	-------------	---

**Returns**

Set local time status, see [OSAL Return Code Defines](#)

**Return values**

<code>OS_SUCCESS</code>	Successful execution.
<code>OS_INVALID_POINTER</code>	if time_struct is null

**10.55.2.3 OS\_TimeAdd()**

```
static OS_time_t OS_TimeAdd (
    OS_time_t time1,
    OS_time_t time2 ) [inline], [static]
```

Computes the sum of two time intervals.

**Parameters**

in	<code>time1</code>	The first interval
in	<code>time2</code>	The second interval

**Returns**

The sum of the two intervals (time1 + time2)

Definition at line 388 of file osapi-clock.h.

References OS\_time\_t::ticks.

**10.55.2.4 OS\_TimeAssembleFromMicroseconds()**

```
static OS_time_t OS_TimeAssembleFromMicroseconds (
    int64 seconds,
    uint32 microseconds ) [inline], [static]
```

Assemble/Convert a number of seconds + microseconds into an `OS_time_t` interval.

This creates an `OS_time_t` value using a whole number of seconds and a fractional part in units of microseconds. This is the inverse of `OS_TimeGetTotalSeconds()` and `OS_TimeGetMicrosecondsPart()`, and should recreate the original `OS_time_t` value from these separate values (aside from any potential conversion losses due to limited resolution of the data types/units).

**See also**

[OS\\_TimeGetTotalSeconds\(\)](#), [OS\\_TimeGetMicrosecondsPart\(\)](#)

**Parameters**

in	<i>seconds</i>	Whole number of seconds
in	<i>microseconds</i>	Number of microseconds (fractional part only)

**Returns**

The input arguments represented as an [OS\\_time\\_t](#) interval

Definition at line 323 of file osapi-clock.h.

References OS\_TIME\_TICKS\_PER\_SECOND, OS\_TIME\_TICKS\_PER\_USEC, and OS\_time\_t::ticks.

**10.55.2.5 OS\_TimeAssembleFromMilliseconds()**

```
static OS\_time\_t OS_TimeAssembleFromMilliseconds (
    int64 seconds,
    uint32 milliseconds ) [inline], [static]
```

Assemble/Convert a number of seconds + milliseconds into an [OS\\_time\\_t](#) interval.

This creates an [OS\\_time\\_t](#) value using a whole number of seconds and a fractional part in units of milliseconds. This is the inverse of [OS\\_TimeGetTotalSeconds\(\)](#) and [OS\\_TimeGetMillisecondsPart\(\)](#), and should recreate the original [OS\\_time\\_t](#) value from these separate values (aside from any potential conversion losses due to limited resolution of the data types/units).

**See also**

[OS\\_TimeGetTotalSeconds\(\)](#), [OS\\_TimeGetMillisecondsPart\(\)](#)

**Parameters**

in	<i>seconds</i>	Whole number of seconds
in	<i>milliseconds</i>	Number of milliseconds (fractional part only)

**Returns**

The input arguments represented as an [OS\\_time\\_t](#) interval

Definition at line 347 of file osapi-clock.h.

References OS\_TIME\_TICKS\_PER\_MSEC, OS\_TIME\_TICKS\_PER\_SECOND, and OS\_time\_t::ticks.

### 10.55.2.6 OS\_TimeAssembleFromNanoseconds()

```
static OS_time_t OS_TimeAssembleFromNanoseconds (
    int64 seconds,
    uint32 nanoseconds ) [inline], [static]
```

Assemble/Convert a number of seconds + nanoseconds into an [OS\\_time\\_t](#) interval.

This creates an [OS\\_time\\_t](#) value using a whole number of seconds and a fractional part in units of nanoseconds. This is the inverse of [OS\\_TimeGetTotalSeconds\(\)](#) and [OS\\_TimeGetNanosecondsPart\(\)](#), and should recreate the original [OS\\_time\\_t](#) value from these separate values (aside from any potential conversion losses due to limited resolution of the data types/units).

#### See also

[OS\\_TimeGetTotalSeconds\(\)](#), [OS\\_TimeGetNanosecondsPart\(\)](#)

#### Parameters

in	seconds	Whole number of seconds
in	nanoseconds	Number of nanoseconds (fractional part only)

#### Returns

The input arguments represented as an [OS\\_time\\_t](#) interval

Definition at line 299 of file osapi-clock.h.

References [OS\\_TIME\\_TICK\\_RESOLUTION\\_NS](#), [OS\\_TIME\\_TICKS\\_PER\\_SECOND](#), and [OS\\_time\\_t::ticks](#).

### 10.55.2.7 OS\_TimeAssembleFromSubseconds()

```
static OS_time_t OS_TimeAssembleFromSubseconds (
    int64 seconds,
    uint32 subseconds ) [inline], [static]
```

Assemble/Convert a number of seconds + subseconds into an [OS\\_time\\_t](#) interval.

This creates an [OS\\_time\\_t](#) value using a whole number of seconds and a fractional part in units of sub-seconds ( $1/2^{32}$ ). This is the inverse of [OS\\_TimeGetTotalSeconds\(\)](#) and [OS\\_TimeGetSubsecondsPart\(\)](#), and should recreate the original [OS\\_time\\_t](#) value from these separate values (aside from any potential conversion losses due to limited resolution of the data types/units).

#### See also

[OS\\_TimeGetTotalSeconds\(\)](#), [OS\\_TimeGetNanosecondsPart\(\)](#)

**Parameters**

in	<i>seconds</i>	Whole number of seconds
in	<i>subseconds</i>	Number of subseconds (32 bit fixed point fractional part)

**Returns**

The input arguments represented as an [OS\\_time\\_t](#) interval

Definition at line 370 of file osapi-clock.h.

References OS\_TIME\_TICKS\_PER\_SECOND, and OS\_time\_t::ticks.

**10.55.2.8 OS\_TimeGetFractionalPart()**

```
static int64 OS_TimeGetFractionalPart (
    OS_time_t tm ) [inline], [static]
```

Get subseconds portion (fractional part only) from an [OS\\_time\\_t](#) object.

Extracts the fractional part from a given [OS\\_time\\_t](#) object. Units returned are in ticks, not normalized to any standard time unit.

**Parameters**

in	<i>tm</i>	Time interval value
----	-----------	---------------------

**Returns**

Fractional/subsecond portion of time interval in ticks

Definition at line 191 of file osapi-clock.h.

References OS\_TIME\_TICKS\_PER\_SECOND, and OS\_time\_t::ticks.

Referenced by OS\_TimeGetMicrosecondsPart(), OS\_TimeGetMillisecondsPart(), OS\_TimeGetNanosecondsPart(), and OS\_TimeGetSubsecondsPart().

**10.55.2.9 OS\_TimeGetMicrosecondsPart()**

```
static uint32 OS_TimeGetMicrosecondsPart (
    OS_time_t tm ) [inline], [static]
```

Get microseconds portion (fractional part only) from an [OS\\_time\\_t](#) object.

Extracts the fractional part from a given [OS\\_time\\_t](#) object normalized to units of microseconds.

This function may be used to adapt applications initially implemented using an older OSAL version where [OS\\_time\\_t](#) was a structure containing a "seconds" and "microsecs" field.

This function will obtain a value that is compatible with the "microsecs" field of [OS\\_time\\_t](#) as it was defined in previous versions of OSAL, as well as the "tv\_usecs" field of POSIX-style "struct timeval" values.

See also

[OS\\_TimeGetTotalSeconds\(\)](#)

Parameters

in	<i>tm</i>	Time interval value
----	-----------	---------------------


Returns

Number of microseconds in time interval

Definition at line 259 of file osapi-clock.h.

References OS\_TIME\_TICKS\_PER\_USEC, and [OS\\_TimeGetFractionalPart\(\)](#).

Here is the call graph for this function:



### 10.55.2.10 OS\_TimeGetMillisecondsPart()

```
static uint32 OS_TimeGetMillisecondsPart (
    OS_time_t tm ) [inline], [static]
```

Get milliseconds portion (fractional part only) from an [OS\\_time\\_t](#) object.

Extracts the fractional part from a given [OS\\_time\\_t](#) object normalized to units of milliseconds.

See also

[OS\\_TimeGetTotalSeconds\(\)](#)

Parameters

in	<i>tm</i>	Time interval value
----	-----------	---------------------

**Returns**

Number of milliseconds in time interval

Definition at line 234 of file osapi-clock.h.

References OS\_TIME\_TICKS\_PER\_MSEC, and OS\_TimeGetFractionalPart().

Here is the call graph for this function:



### 10.55.2.11 OS\_TimeGetNanosecondsPart()

```
static uint32 OS_TimeGetNanosecondsPart (
    OS_time_t tm ) [inline], [static]
```

Get nanoseconds portion (fractional part only) from an [OS\\_time\\_t](#) object.

Extracts the only number of nanoseconds from a given [OS\\_time\\_t](#) object.

This function will obtain a value that is compatible with the "tv\_nsec" field of POSIX-style "struct timespec" values.

**See also**

[OS\\_TimeGetTotalSeconds\(\)](#)

**Parameters**

in	tm	Time interval value
----	----	---------------------

**Returns**

Number of nanoseconds in time interval

Definition at line 278 of file osapi-clock.h.

References OS\_TIME\_TICK\_RESOLUTION\_NS, and OS\_TimeGetFractionalPart().

Here is the call graph for this function:



#### 10.55.2.12 OS\_TimeGetSubsecondsPart()

```
static uint32 OS_TimeGetSubsecondsPart (
    OS_time_t tm ) [inline], [static]
```

Get 32-bit normalized subseconds (fractional part only) from an [OS\\_time\\_t](#) object.

Extracts the fractional part from a given [OS\\_time\\_t](#) object in maximum precision, with units of  $2^{-32}$  sec. This is a base-2 fixed-point fractional value with the point left-justified in the 32-bit value (i.e. left of MSB).

This is (mostly) compatible with the CFE "subseconds" value, where 0x80000000 represents exactly one half second, and 0 represents a full second.

##### Parameters

in	tm	Time interval value
----	----	---------------------

##### Returns

Fractional/subsecond portion of time interval as 32-bit fixed point value

Definition at line 210 of file osapi-clock.h.

References OS\_TIME\_TICKS\_PER\_SECOND, and [OS\\_TimeGetFractionalPart\(\)](#).

Here is the call graph for this function:



### 10.55.2.13 OS\_TimeGetTotalMicroseconds()

```
static int64 OS_TimeGetTotalMicroseconds (
    OS_time_t tm ) [inline], [static]
```

Get interval from an [OS\\_time\\_t](#) object normalized to microsecond units.

Note this refers to the complete interval, not just the fractional part.

#### Parameters

in	tm	Time interval value
----	----	---------------------

#### Returns

Whole number of microseconds in time interval

Definition at line 158 of file osapi-clock.h.

References OS\_TIME\_TICKS\_PER\_USEC, and OS\_time\_t::ticks.

### 10.55.2.14 OS\_TimeGetTotalMilliseconds()

```
static int64 OS_TimeGetTotalMilliseconds (
    OS_time_t tm ) [inline], [static]
```

Get interval from an [OS\\_time\\_t](#) object normalized to millisecond units.

Note this refers to the complete interval, not just the fractional part.

#### Parameters

in	tm	Time interval value
----	----	---------------------

#### Returns

Whole number of milliseconds in time interval

Definition at line 144 of file osapi-clock.h.

References OS\_TIME\_TICKS\_PER\_MSEC, and OS\_time\_t::ticks.

### 10.55.2.15 OS\_TimeGetTotalNanoseconds()

```
static int64 OS_TimeGetTotalNanoseconds (
    OS_time_t tm ) [inline], [static]
```

Get interval from an [OS\\_time\\_t](#) object normalized to nanosecond units.

Note this refers to the complete interval, not just the fractional part.

#### Note

There is no protection against overflow of the 64-bit return value. Applications must use caution to ensure that the interval does not exceed the representable range of a signed 64 bit integer - approximately 140 years.

#### Parameters

in	tm	Time interval value
----	----	---------------------

#### Returns

Whole number of microseconds in time interval

Definition at line 176 of file osapi-clock.h.

References OS\_TIME\_TICK\_RESOLUTION\_NS, and OS\_time\_t::ticks.

### 10.55.2.16 OS\_TimeGetTotalSeconds()

```
static int64 OS_TimeGetTotalSeconds (
    OS_time_t tm ) [inline], [static]
```

Get interval from an [OS\\_time\\_t](#) object normalized to whole number of seconds.

Extracts the number of whole seconds from a given [OS\\_time\\_t](#) object, discarding any fractional component.

This may also replace a direct read of the "seconds" field from the [OS\\_time\\_t](#) object from previous versions of OSAL, where the structure was defined with separate seconds/microseconds fields.

#### See also

[OS\\_TimeGetMicrosecondsPart\(\)](#)

#### Parameters

in	tm	Time interval value
----	----	---------------------

**Returns**

Whole number of seconds in time interval

Definition at line 130 of file osapi-clock.h.

References OS\_TIME\_TICKS\_PER\_SECOND, and OS\_time\_t::ticks.

**10.55.2.17 OS\_TimeSubtract()**

```
static OS_time_t OS_TimeSubtract (
    OS_time_t time1,
    OS_time_t time2 ) [inline], [static]
```

Computes the difference between two time intervals.

**Parameters**

in	time1	The first interval
in	time2	The second interval

**Returns**

The difference of the two intervals (time1 - time2)

Definition at line 402 of file osapi-clock.h.

References OS\_time\_t::ticks.

## 10.56 OSAL Core Operation APIs

### Functions

- void [OS\\_Application\\_Startup](#) (void)  
*Application startup.*
- void [OS\\_Application\\_Run](#) (void)  
*Application run.*
- int32 [OS\\_API\\_Init](#) (void)  
*Initialization of API.*
- void [OS\\_API\\_Teardown](#) (void)  
*Teardown/de-initialization of OSAL API.*
- void [OS\\_IdleLoop](#) (void)  
*Background thread implementation - waits forever for events to occur.*
- void [OS\\_DeleteAllObjects](#) (void)  
*delete all resources created in OSAL.*
- void [OS\\_ApplicationShutdown](#) (uint8 flag)  
*Initiate orderly shutdown.*
- void [OS\\_ApplicationExit](#) (int32 Status)  
*Exit/Abort the application.*
- int32 [OS\\_RegisterEventHandler](#) (OS\_EventHandler\_t handler)  
*Callback routine registration.*

### 10.56.1 Detailed Description

These are for OSAL core operations for startup/initialization, running, and shutdown. Typically only used in bsp's, unit tests, psp's, etc.

Not intended for user application use

### 10.56.2 Function Documentation

#### 10.56.2.1 [OS\\_API\\_Init\(\)](#)

```
int32 OS_API_Init (
    void )
```

Initialization of API.

This function returns initializes the internal data structures of the OS Abstraction Layer. It must be called in the application startup code before calling any other OS routines.

#### Returns

Execution status, see [OSAL Return Code Defines](#). Any error code (negative) means the OSAL can not be initialized. Typical platform specific response is to abort since additional OSAL calls will have undefined behavior.

## Return values

<code>OS_SUCCESS</code>	Successful execution.
<code>OS_ERROR</code>	Failed execution. (return value only verified in coverage test)

### 10.56.2.2 OS\_API\_Teardown()

```
void OS_API_Teardown (
    void )
```

Teardown/de-initialization of OSAL API.

This is the inverse of [OS\\_API\\_Init\(\)](#). It will release all OS resources and return the system to a state similar to what it was prior to invoking [OS\\_API\\_Init\(\)](#) initially.

Normally for embedded applications, the OSAL is initialized after boot and will remain initialized in memory until the processor is rebooted. However for testing and development purposes, it is potentially useful to reset back to initial conditions.

For testing purposes, this API is designed/intended to be compatible with the `UtTest_AddTeardown()` routine provided by the UT-Assert subsystem.

#### Note

This is a "best-effort" routine and it may not always be possible/guaranteed to recover all resources, particularly in the case of off-nominal conditions, or if a resource is used outside of OSAL.

For example, while this will attempt to unload all dynamically-loaded modules, doing so may not be possible and/or may induce undefined behavior if resources are in use by tasks/functions outside of OSAL.

### 10.56.2.3 OS\_Application\_Run()

```
void OS_Application_Run (
    void )
```

Application run.

Run abstraction such that the same BSP can be used for operations and testing.

### 10.56.2.4 OS\_Application\_Startup()

```
void OS_Application_Startup (
    void )
```

Application startup.

Startup abstraction such that the same BSP can be used for operations and testing.

### 10.56.2.5 OS\_ApplicationExit()

```
void OS_ApplicationExit (
    int32 Status )
```

Exit/Abort the application.

Indicates that the OSAL application should exit and return control to the OS. This is intended for e.g. scripted unit testing where the test needs to end without user intervention.

This function does not return. Production code typically should not ever call this.

#### Note

This exits the entire process including tasks that have been created.

### 10.56.2.6 OS\_ApplicationShutdown()

```
void OS_ApplicationShutdown (
    uint8 flag )
```

Initiate orderly shutdown.

Indicates that the OSAL application should perform an orderly shutdown of ALL tasks, clean up all resources, and exit the application.

This allows the task currently blocked in [OS\\_IdleLoop\(\)](#) to wake up, and for that function to return to its caller.

This is preferred over e.g. [OS\\_ApplicationExit\(\)](#) which exits immediately and does not provide for any means to clean up first.

#### Parameters

in	<i>flag</i>	set to true to initiate shutdown, false to cancel
----	-------------	---

### 10.56.2.7 OS\_DeleteAllObjects()

```
void OS_DeleteAllObjects (
    void )
```

delete all resources created in OSAL.

provides a means to clean up all resources allocated by this instance of OSAL. It would typically be used during an orderly shutdown but may also be helpful for testing purposes.

### 10.56.2.8 OS\_IdleLoop()

```
void OS_IdleLoop (
    void )
```

Background thread implementation - waits forever for events to occur.

This should be called from the BSP main routine or initial thread after all other board and application initialization has taken place and all other tasks are running.

Typically just waits forever until "OS\_shutdown" flag becomes true.

### 10.56.2.9 OS\_RegisterEventHandler()

```
int32 OS_RegisterEventHandler (
    OS_EventHandler_t handler )
```

Callback routine registration.

This hook enables the application code to perform extra platform-specific operations on various system events such as resource creation/deletion.

#### Note

Some events are invoked while the resource is "locked" and therefore application-defined handlers for these events should not block or attempt to access other OSAL resources.

#### Parameters

in	<i>handler</i>	The application-provided event handler (must not be null)
----	----------------	---

#### Returns

Execution status, see [OSAL Return Code Defines](#).

#### Return values

<a href="#"><i>OS_SUCCESS</i></a>	Successful execution.
<a href="#"><i>OS_INVALID_POINTER</i></a>	if handler is NULL

## 10.57 OSAL Counting Semaphore APIs

### Functions

- `int32 OS_CountSemCreate (osal_id_t *sem_id, const char *sem_name, uint32 sem_initial_value, uint32 options)`  
*Creates a counting semaphore.*
- `int32 OS_CountSemGive (osal_id_t sem_id)`  
*Increment the semaphore value.*
- `int32 OS_CountSemTake (osal_id_t sem_id)`  
*Decrement the semaphore value.*
- `int32 OS_CountSemTimedWait (osal_id_t sem_id, uint32 msecs)`  
*Decrement the semaphore value with timeout.*
- `int32 OS_CountSemDelete (osal_id_t sem_id)`  
*Deletes the specified counting Semaphore.*
- `int32 OS_CountSemGetIdByName (osal_id_t *sem_id, const char *sem_name)`  
*Find an existing semaphore ID by name.*
- `int32 OS_CountSemGetInfo (osal_id_t sem_id, OS_count_sem_prop_t *count_prop)`  
*Fill a property object buffer with details regarding the resource.*

### 10.57.1 Detailed Description

### 10.57.2 Function Documentation

#### 10.57.2.1 OS\_CountSemCreate()

```
int32 OS_CountSemCreate (
    osal_id_t * sem_id,
    const char * sem_name,
    uint32 sem_initial_value,
    uint32 options )
```

Creates a counting semaphore.

Creates a counting semaphore with initial value specified by `sem_initial_value` and name specified by `sem_name`. `sem_id` will be returned to the caller.

#### Note

Underlying RTOS implementations may or may not impose a specific upper limit to the value of a counting semaphore. If the OS has a specific limit and the `sem_initial_value` exceeds this limit, then `OS_INVALID_SEM_VALUE` is returned. On other implementations, any 32-bit integer value may be acceptable. For maximum portability, it is recommended to keep counting semaphore values within the range of a "short int" (i.e. between 0 and 32767). Many platforms do accept larger values, but may not be guaranteed.

**Parameters**

out	<i>sem_id</i>	will be set to the non-zero ID of the newly-created resource (must not be null)
in	<i>sem_name</i>	the name of the new resource to create (must not be null)
in	<i>sem_initial_value</i>	the initial value of the counting semaphore
in	<i>options</i>	Reserved for future use, should be passed as 0.

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if sem name or sem_id are NULL
<i>OS_ERR_NAME_TOO_LONG</i>	name length including null terminator greater than <a href="#">OS_MAX_API_NAME</a>
<i>OS_ERR_NO_FREE_IDS</i>	if all of the semaphore ids are taken
<i>OS_ERR_NAME_TAKEN</i>	if this is already the name of a counting semaphore
<i>OS_INVALID_SEM_VALUE</i>	if the semaphore value is too high (return value only verified in coverage test)
<i>OS_SEM_FAILURE</i>	if an unspecified implementation error occurs (return value only verified in coverage test)

**10.57.2.2 OS\_CountSemDelete()**

```
int32 OS_CountSemDelete (
    osal_id_t sem_id )
```

Deletes the specified counting Semaphore.

**Parameters**

in	<i>sem_id</i>	The object ID to delete
----	---------------	-------------------------

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the id passed in is not a valid counting semaphore
<i>OS_SEM_FAILURE</i>	if an unspecified implementation error occurs (return value only verified in coverage test)

### 10.57.2.3 OS\_CountSemGetIdByName()

```
int32 OS_CountSemGetIdByName (
    osal_id_t * sem_id,
    const char * sem_name )
```

Find an existing semaphore ID by name.

This function tries to find a counting sem Id given the name of a count\_sem. The id is returned through sem\_id

#### Parameters

out	<i>sem_id</i>	will be set to the ID of the existing resource
in	<i>sem_name</i>	the name of the existing resource to find (must not be null)

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	is semid or sem_name are NULL pointers
<i>OS_ERR_NAME_TOO_LONG</i>	name length including null terminator greater than <i>OS_MAX_API_NAME</i>
<i>OS_ERR_NAME_NOT_FOUND</i>	if the name was not found in the table

### 10.57.2.4 OS\_CountSemGetInfo()

```
int32 OS_CountSemGetInfo (
    osal_id_t sem_id,
    OS_count_sem_prop_t * count_prop )
```

Fill a property object buffer with details regarding the resource.

This function will pass back a pointer to structure that contains all of the relevant info( name and creator) about the specified counting semaphore.

#### Parameters

in	<i>sem_id</i>	The object ID to operate on
out	<i>count_prop</i>	The property object buffer to fill (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the id passed in is not a valid semaphore
<i>OS_INVALID_POINTER</i>	if the count_prop pointer is null

**10.57.2.5 OS\_CountSemGive()**

```
int32 OS_CountSemGive (
    osal_id_t sem_id )
```

Increment the semaphore value.

The function unlocks the semaphore referenced by *sem\_id* by performing a semaphore unlock operation on that semaphore. If the semaphore value resulting from this operation is positive, then no threads were blocked waiting for the semaphore to become unlocked; the semaphore value is simply incremented for this semaphore.

**Parameters**

<i>in</i>	<i>sem_id</i>	The object ID to operate on
-----------	---------------	-----------------------------

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the id passed in is not a counting semaphore
<i>OS_SEM_FAILURE</i>	if an unspecified implementation error occurs (return value only verified in coverage test)

**10.57.2.6 OS\_CountSemTake()**

```
int32 OS_CountSemTake (
    osal_id_t sem_id )
```

Decrement the semaphore value.

The locks the semaphore referenced by `sem_id` by performing a semaphore lock operation on that semaphore. If the semaphore value is currently zero, then the calling thread shall not return from the call until it either locks the semaphore or the call is interrupted.

**Parameters**

in	<i>sem_id</i>	The object ID to operate on
----	---------------	-----------------------------

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	the Id passed in is not a valid counting semaphore
<i>OS_SEM_FAILURE</i>	if an unspecified implementation error occurs (return value only verified in coverage test)

**10.57.2.7 OS\_CountSemTimedWait()**

```
int32 OS_CountSemTimedWait (
    osal_id_t sem_id,
    uint32 msecs )
```

Decrement the semaphore value with timeout.

The function locks the semaphore referenced by *sem\_id*. However, if the semaphore cannot be locked without waiting for another process or thread to unlock the semaphore, this wait shall be terminated when the specified timeout, *msecs*, expires.

**Parameters**

in	<i>sem_id</i>	The object ID to operate on
in	<i>msecs</i>	The maximum amount of time to block, in milliseconds

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_SEM_TIMEOUT</i>	if semaphore was not relinquished in time
<i>OS_ERR_INVALID_ID</i>	if the ID passed in is not a valid semaphore ID
<i>OS_SEM_FAILURE</i>	if an unspecified implementation error occurs (return value only verified in coverage test)

## 10.58 OSAL Directory APIs

### Functions

- `int32 OS_DirectoryOpen (osal_id_t *dir_id, const char *path)`  
*Opens a directory.*
- `int32 OS_DirectoryClose (osal_id_t dir_id)`  
*Closes an open directory.*
- `int32 OS_DirectoryRewind (osal_id_t dir_id)`  
*Rewinds an open directory.*
- `int32 OS_DirectoryRead (osal_id_t dir_id, os_dirent_t *dirent)`  
*Reads the next name in the directory.*
- `int32 OS_mkdir (const char *path, uint32 access)`  
*Makes a new directory.*
- `int32 OS_rmdir (const char *path)`  
*Removes a directory from the file system.*

### 10.58.1 Detailed Description

### 10.58.2 Function Documentation

#### 10.58.2.1 OS\_DirectoryClose()

```
int32 OS_DirectoryClose (
    osal_id_t dir_id )
```

Closes an open directory.

The directory referred to by `dir_id` will be closed

#### Parameters

in	<code>dir_id</code>	The handle ID of the directory
----	---------------------	--------------------------------

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<code>OS_SUCCESS</code>	Successful execution.
<code>OS_ERR_INVALID_ID</code>	if the directory handle is invalid

### 10.58.2.2 OS\_DirectoryOpen()

```
int32 OS_DirectoryOpen (
    osal_id_t * dir_id,
    const char * path )
```

Opens a directory.

Prepares for reading the files within a directory

#### Parameters

out	<i>dir_id</i>	Location to store handle ID of the directory (must not be null)
in	<i>path</i>	The directory to open (must not be null)

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if dir_id or path is NULL
<i>OS_FS_ERR_PATH_TOO_LONG</i>	if the path argument exceeds the maximum length
<i>OS_FS_ERR_PATH_INVALID</i>	if the path argument is not valid
<i>OS_ERROR</i>	if the directory could not be opened

### 10.58.2.3 OS\_DirectoryRead()

```
int32 OS_DirectoryRead (
    osal_id_t dir_id,
    os_dirent_t * dirent )
```

Reads the next name in the directory.

Obtains directory entry data for the next file from an open directory

#### Parameters

in	<i>dir_id</i>	The handle ID of the directory
out	<i>dirent</i>	Buffer to store directory entry information (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if dirent argument is NULL
<i>OS_ERR_INVALID_ID</i>	if the directory handle is invalid
<i>OS_ERROR</i>	at the end of the directory or if the OS call otherwise fails

**10.58.2.4 OS\_DirectoryRewind()**

```
int32 OS_DirectoryRewind (
    osal_id_t dir_id )
```

Rewinds an open directory.

Resets a directory read handle back to the first file.

**Parameters**

in	<i>dir_id</i>	The handle ID of the directory
----	---------------	--------------------------------

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the directory handle is invalid

**10.58.2.5 OS\_mkdir()**

```
int32 OS_mkdir (
    const char * path,
    uint32 access )
```

Makes a new directory.

Makes a directory specified by path.

**Parameters**

in	<i>path</i>	The new directory name (must not be null)
in	<i>access</i>	The permissions for the directory (reserved for future use)

**Note**

Current implementations do not utilize the "access" parameter. Applications should still pass the intended value ([OS\\_READ\\_WRITE](#) or [OS\\_READ\\_ONLY](#)) to be compatible with future implementations.

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_INVALID_POINTER</a>	if path is NULL
<a href="#">OS_FS_ERR_PATH_TOO_LONG</a>	if the path is too long to be stored locally
<a href="#">OS_FS_ERR_PATH_INVALID</a>	if path cannot be parsed
<a href="#">OS_ERROR</a>	if the OS call fails (return value only verified in coverage test)

**10.58.2.6 OS\_rmdir()**

```
int32 OS_rmdir (
    const char * path )
```

Removes a directory from the file system.

Removes a directory from the structure. The directory must be empty prior to this operation.

**Parameters**

in	<i>path</i>	The directory to remove
----	-------------	-------------------------

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_INVALID_POINTER</a>	if path is NULL
<a href="#">OS_FS_ERR_PATH_INVALID</a>	if path cannot be parsed

**Return values**

<i>OS_FS_ERR_PATH_TOO_LONG</i>	
<i>OS_ERROR</i>	if the directory remove operation failed (return value only verified in coverage test)

## 10.59 OSAL Return Code Defines

### Macros

- #define **OS\_SUCCESS** (0)  
*Successful execution.*
- #define **OS\_ERROR** (-1)  
*Failed execution.*
- #define **OS\_INVALID\_POINTER** (-2)  
*Invalid pointer.*
- #define **OS\_ERROR\_ADDRESS\_MISALIGNED** (-3)  
*Address misalignment.*
- #define **OS\_ERROR\_TIMEOUT** (-4)  
*Error timeout.*
- #define **OS\_INVALID\_INT\_NUM** (-5)  
*Invalid interrupt number.*
- #define **OS\_SEM\_FAILURE** (-6)  
*Semaphore failure.*
- #define **OS\_SEM\_TIMEOUT** (-7)  
*Semaphore timeout.*
- #define **OS\_QUEUE\_EMPTY** (-8)  
*Queue empty.*
- #define **OS\_QUEUE\_FULL** (-9)  
*Queue full.*
- #define **OS\_QUEUE\_TIMEOUT** (-10)  
*Queue timeout.*
- #define **OS\_QUEUE\_INVALID\_SIZE** (-11)  
*Queue invalid size.*
- #define **OS\_QUEUE\_ID\_ERROR** (-12)  
*Queue ID error.*
- #define **OS\_ERR\_NAME\_TOO\_LONG** (-13)  
*Name length including null terminator greater than `OS_MAX_API_NAME`.*
- #define **OS\_ERR\_NO\_FREE\_IDS** (-14)  
*No free IDs.*
- #define **OS\_ERR\_NAME\_TAKEN** (-15)  
*Name taken.*
- #define **OS\_ERR\_INVALID\_ID** (-16)  
*Invalid ID.*
- #define **OS\_ERR\_NAME\_NOT\_FOUND** (-17)  
*Name not found.*
- #define **OS\_ERR\_SEM\_NOT\_FULL** (-18)  
*Semaphore not full.*
- #define **OS\_ERR\_INVALID\_PRIORITY** (-19)  
*Invalid priority.*
- #define **OS\_INVALID\_SEM\_VALUE** (-20)  
*Invalid semaphore value.*
- #define **OS\_ERR\_FILE** (-27)

- `#define OS_ERR_NOT_IMPLEMENTED (-28)`  
*Not implemented.*
- `#define OS_TIMER_ERR_INVALID_ARGS (-29)`  
*Timer invalid arguments.*
- `#define OS_TIMER_ERR_TIMER_ID (-30)`  
*Timer ID error.*
- `#define OS_TIMER_ERR_UNAVAILABLE (-31)`  
*Timer unavailable.*
- `#define OS_TIMER_ERR_INTERNAL (-32)`  
*Timer internal error.*
- `#define OS_ERR_OBJECT_IN_USE (-33)`  
*Object in use.*
- `#define OS_ERR_BAD_ADDRESS (-34)`  
*Bad address.*
- `#define OS_ERR_INCORRECT_OBJ_STATE (-35)`  
*Incorrect object state.*
- `#define OS_ERR_INCORRECT_OBJ_TYPE (-36)`  
*Incorrect object type.*
- `#define OS_ERR_STREAM_DISCONNECTED (-37)`  
*Stream disconnected.*
- `#define OS_ERR_OPERATION_NOT_SUPPORTED (-38)`  
*Requested operation not support on supplied object(s)*
- `#define OS_ERR_INVALID_SIZE (-40)`  
*Invalid Size.*
- `#define OS_ERR_OUTPUT_TOO_LARGE (-41)`  
*Size of output exceeds limit.*
- `#define OS_ERR_INVALID_ARGUMENT (-42)`  
*Invalid argument value (other than ID or size)*
- `#define OS_FS_ERR_PATH_TOO_LONG (-103)`  
*FS path too long.*
- `#define OS_FS_ERR_NAME_TOO_LONG (-104)`  
*FS name too long.*
- `#define OS_FS_ERR_DRIVE_NOT_CREATED (-106)`  
*FS drive not created.*
- `#define OS_FS_ERR_DEVICE_NOT_FREE (-107)`  
*FS device not free.*
- `#define OS_FS_ERR_PATH_INVALID (-108)`  
*FS path invalid.*

#### 10.59.1 Detailed Description

The specific status/return code definitions listed in this section may be extended or refined in future versions of OSAL.

**Note**

Application developers should assume that any OSAL API may return any status value listed here. While the documentation of each OSAL API function indicates the return/status values that function may directly generate, functions may also pass through other status codes from related functions, so that list should not be considered absolute/exhaustive.

The `int32` data type should be used to store an OSAL status code. Negative values will always represent errors, while non-negative values indicate success. Most APIs specifically return `OS_SUCCESS` (0) upon successful execution, but some return a nonzero value, such as data size.

Ideally, in order to more easily adapt to future OSAL versions and status code extensions/refinements, applications should typically check for errors as follows:

```
int32 status;
status = OS_TaskCreate(...);  (or any other API)
if (status < OS_SUCCESS)
{
    handle or report error....
    may also check for specific codes here.
}
else
{
    handle normal/successful status...
}
```

## 10.59.2 Macro Definition Documentation

### 10.59.2.1 OS\_ERR\_BAD\_ADDRESS

```
#define OS_ERR_BAD_ADDRESS (-34)
```

Bad address.

Definition at line 124 of file osapi-error.h.

### 10.59.2.2 OS\_ERR\_FILE

```
#define OS_ERR_FILE (-27)
```

File error.

Definition at line 117 of file osapi-error.h.

**10.59.2.3 OS\_ERR\_INCORRECT\_OBJ\_STATE**

```
#define OS_ERR_INCORRECT_OBJ_STATE (-35)
```

Incorrect object state.

Definition at line 125 of file osapi-error.h.

**10.59.2.4 OS\_ERR\_INCORRECT\_OBJ\_TYPE**

```
#define OS_ERR_INCORRECT_OBJ_TYPE (-36)
```

Incorrect object type.

Definition at line 126 of file osapi-error.h.

**10.59.2.5 OS\_ERR\_INVALID\_ARGUMENT**

```
#define OS_ERR_INVALID_ARGUMENT (-42)
```

Invalid argument value (other than ID or size)

Definition at line 131 of file osapi-error.h.

**10.59.2.6 OS\_ERR\_INVALID\_ID**

```
#define OS_ERR_INVALID_ID (-16)
```

Invalid ID.

Definition at line 112 of file osapi-error.h.

**10.59.2.7 OS\_ERR\_INVALID\_PRIORITY**

```
#define OS_ERR_INVALID_PRIORITY (-19)
```

Invalid priority.

Definition at line 115 of file osapi-error.h.

### 10.59.2.8 OS\_ERR\_INVALID\_SIZE

```
#define OS_ERR_INVALID_SIZE (-40)
```

Invalid Size.

Definition at line 129 of file osapi-error.h.

### 10.59.2.9 OS\_ERR\_NAME\_NOT\_FOUND

```
#define OS_ERR_NAME_NOT_FOUND (-17)
```

Name not found.

Definition at line 113 of file osapi-error.h.

### 10.59.2.10 OS\_ERR\_NAME\_TAKEN

```
#define OS_ERR_NAME_TAKEN (-15)
```

Name taken.

Definition at line 111 of file osapi-error.h.

### 10.59.2.11 OS\_ERR\_NAME\_TOO\_LONG

```
#define OS_ERR_NAME_TOO_LONG (-13)
```

name length including null terminator greater than [OS\\_MAX\\_API\\_NAME](#)

Definition at line 109 of file osapi-error.h.

### 10.59.2.12 OS\_ERR\_NO\_FREE\_IDS

```
#define OS_ERR_NO_FREE_IDS (-14)
```

No free IDs.

Definition at line 110 of file osapi-error.h.

**10.59.2.13 OS\_ERR\_NOT\_IMPLEMENTED**

```
#define OS_ERR_NOT_IMPLEMENTED (-28)
```

Not implemented.

Definition at line 118 of file osapi-error.h.

**10.59.2.14 OS\_ERR\_OBJECT\_IN\_USE**

```
#define OS_ERR_OBJECT_IN_USE (-33)
```

Object in use.

Definition at line 123 of file osapi-error.h.

**10.59.2.15 OS\_ERR\_OPERATION\_NOT\_SUPPORTED**

```
#define OS_ERR_OPERATION_NOT_SUPPORTED (-38)
```

Requested operation not support on supplied object(s)

Definition at line 128 of file osapi-error.h.

**10.59.2.16 OS\_ERR\_OUTPUT\_TOO\_LARGE**

```
#define OS_ERR_OUTPUT_TOO_LARGE (-41)
```

Size of output exceeds limit.

Definition at line 130 of file osapi-error.h.

**10.59.2.17 OS\_ERR\_SEM\_NOT\_FULL**

```
#define OS_ERR_SEM_NOT_FULL (-18)
```

Semaphore not full.

Definition at line 114 of file osapi-error.h.

**10.59.2.18 OS\_ERR\_STREAM\_DISCONNECTED**

```
#define OS_ERR_STREAM_DISCONNECTED (-37)
```

Stream disconnected.

Definition at line 127 of file osapi-error.h.

**10.59.2.19 OS\_ERROR**

```
#define OS_ERROR (-1)
```

Failed execution.

Definition at line 97 of file osapi-error.h.

**10.59.2.20 OS\_ERROR\_ADDRESS\_MISALIGNED**

```
#define OS_ERROR_ADDRESS_MISALIGNED (-3)
```

Address misalignment.

Definition at line 99 of file osapi-error.h.

**10.59.2.21 OS\_ERROR\_TIMEOUT**

```
#define OS_ERROR_TIMEOUT (-4)
```

Error timeout.

Definition at line 100 of file osapi-error.h.

**10.59.2.22 OS\_FS\_ERR\_DEVICE\_NOT\_FREE**

```
#define OS_FS_ERR_DEVICE_NOT_FREE (-107)
```

FS device not free.

Definition at line 144 of file osapi-error.h.

**10.59.2.23 OS\_FS\_ERR\_DRIVE\_NOT\_CREATED**

```
#define OS_FS_ERR_DRIVE_NOT_CREATED (-106)
```

FS drive not created.

Definition at line 143 of file osapi-error.h.

**10.59.2.24 OS\_FS\_ERR\_NAME\_TOO\_LONG**

```
#define OS_FS_ERR_NAME_TOO_LONG (-104)
```

FS name too long.

Definition at line 142 of file osapi-error.h.

**10.59.2.25 OS\_FS\_ERR\_PATH\_INVALID**

```
#define OS_FS_ERR_PATH_INVALID (-108)
```

FS path invalid.

Definition at line 145 of file osapi-error.h.

**10.59.2.26 OS\_FS\_ERR\_PATH\_TOO\_LONG**

```
#define OS_FS_ERR_PATH_TOO_LONG (-103)
```

FS path too long.

Definition at line 141 of file osapi-error.h.

**10.59.2.27 OS\_INVALID\_INT\_NUM**

```
#define OS_INVALID_INT_NUM (-5)
```

Invalid Interrupt number.

Definition at line 101 of file osapi-error.h.

**10.59.2.28 OS\_INVALID\_POINTER**

```
#define OS_INVALID_POINTER (-2)
```

Invalid pointer.

Definition at line 98 of file osapi-error.h.

**10.59.2.29 OS\_INVALID\_SEM\_VALUE**

```
#define OS_INVALID_SEM_VALUE (-20)
```

Invalid semaphore value.

Definition at line 116 of file osapi-error.h.

**10.59.2.30 OS\_QUEUE\_EMPTY**

```
#define OS_QUEUE_EMPTY (-8)
```

Queue empty.

Definition at line 104 of file osapi-error.h.

**10.59.2.31 OS\_QUEUE\_FULL**

```
#define OS_QUEUE_FULL (-9)
```

Queue full.

Definition at line 105 of file osapi-error.h.

**10.59.2.32 OS\_QUEUE\_ID\_ERROR**

```
#define OS_QUEUE_ID_ERROR (-12)
```

Queue ID error.

Definition at line 108 of file osapi-error.h.

**10.59.2.33 OS\_QUEUE\_INVALID\_SIZE**

```
#define OS_QUEUE_INVALID_SIZE (-11)
```

Queue invalid size.

Definition at line 107 of file osapi-error.h.

**10.59.2.34 OS\_QUEUE\_TIMEOUT**

```
#define OS_QUEUE_TIMEOUT (-10)
```

Queue timeout.

Definition at line 106 of file osapi-error.h.

**10.59.2.35 OS\_SEM\_FAILURE**

```
#define OS_SEM_FAILURE (-6)
```

Semaphore failure.

Definition at line 102 of file osapi-error.h.

**10.59.2.36 OS\_SEM\_TIMEOUT**

```
#define OS_SEM_TIMEOUT (-7)
```

Semaphore timeout.

Definition at line 103 of file osapi-error.h.

**10.59.2.37 OS\_SUCCESS**

```
#define OS_SUCCESS (0)
```

Successful execution.

Definition at line 96 of file osapi-error.h.

Referenced by DS\_FileCloseDest(), and DS\_FileCreateDest().

**10.59.2.38 OS\_TIMER\_ERR\_INTERNAL**

```
#define OS_TIMER_ERR_INTERNAL (-32)
```

Timer internal error.

Definition at line 122 of file osapi-error.h.

**10.59.2.39 OS\_TIMER\_ERR\_INVALID\_ARGS**

```
#define OS_TIMER_ERR_INVALID_ARGS (-29)
```

Timer invalid arguments.

Definition at line 119 of file osapi-error.h.

**10.59.2.40 OS\_TIMER\_ERR\_TIMER\_ID**

```
#define OS_TIMER_ERR_TIMER_ID (-30)
```

Timer ID error.

Definition at line 120 of file osapi-error.h.

**10.59.2.41 OS\_TIMER\_ERR\_UNAVAILABLE**

```
#define OS_TIMER_ERR_UNAVAILABLE (-31)
```

Timer unavailable.

Definition at line 121 of file osapi-error.h.

## 10.60 OSAL Error Info APIs

### Functions

- static long `OS_StatusToInteger (osal_status_t Status)`  
*Convert a status code to a native "long" type.*
- `int32 OS_GetErrorName (int32 error_num, os_err_name_t *err_name)`  
*Convert an error number to a string.*
- `char * OS_StatusToString (osal_status_t status, os_status_string_t *status_string)`  
*Convert status to a string.*

### 10.60.1 Detailed Description

### 10.60.2 Function Documentation

#### 10.60.2.1 `OS_GetErrorName()`

```
int32 OS_GetErrorName (
    int32 error_num,
    os_err_name_t * err_name )
```

Convert an error number to a string.

#### Parameters

in	<code>error_num</code>	Error number to convert
out	<code>err_name</code>	Buffer to store error string

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<code>OS_SUCCESS</code>	if successfully converted to a string
<code>OS_INVALID_POINTER</code>	if <code>err_name</code> is NULL
<code>OS_ERROR</code>	if error could not be converted

Referenced by `OS_StatusToInteger()`.

### 10.60.2.2 OS\_StatusToInteger()

```
static long OS_StatusToInteger (
    osal_status_t Status ) [inline], [static]
```

Convert a status code to a native "long" type.

For printing or logging purposes, this converts the given status code to a "long" (signed integer) value. It should be used in conjunction with the "%ld" conversion specifier in printf-style statements.

#### Parameters

in	Status	Execution status, see <a href="#">OSAL Return Code Defines</a>
----	--------	--


#### Returns

Same status value converted to the "long" data type

Definition at line 164 of file osapi-error.h.

References OS\_GetErrorName(), and OS\_StatusToString().

Here is the call graph for this function:



### 10.60.2.3 OS\_StatusToString()

```
char* OS_StatusToString (
    osal_status_t status,
    os_status_string_t * status_string )
```

Convert status to a string.

**Parameters**

in	<i>status</i>	Status value to convert
out	<i>status_string</i>	Buffer to store status converted to string

**Returns**

Passed in string pointer

Referenced by OS\_StatusToInteger().

## 10.61 OSAL File Access Option Defines

### Macros

- #define OS\_READ\_ONLY 0
- #define OS\_WRITE\_ONLY 1
- #define OS\_READ\_WRITE 2

#### 10.61.1 Detailed Description

#### 10.61.2 Macro Definition Documentation

##### 10.61.2.1 OS\_READ\_ONLY

```
#define OS_READ_ONLY 0
```

Read only file access

Definition at line 35 of file osapi-file.h.

##### 10.61.2.2 OS\_READ\_WRITE

```
#define OS_READ_WRITE 2
```

Read write file access

Definition at line 37 of file osapi-file.h.

Referenced by DS\_FileCreateDest().

##### 10.61.2.3 OS\_WRITE\_ONLY

```
#define OS_WRITE_ONLY 1
```

Write only file access

Definition at line 36 of file osapi-file.h.

## 10.62 OSAL Reference Point For Seek Offset Defines

### Macros

- #define OS\_SEEK\_SET 0
- #define OS\_SEEK\_CUR 1
- #define OS\_SEEK\_END 2

#### 10.62.1 Detailed Description

#### 10.62.2 Macro Definition Documentation

##### 10.62.2.1 OS\_SEEK\_CUR

```
#define OS_SEEK_CUR 1
```

Seek offset current

Definition at line 44 of file osapi-file.h.

##### 10.62.2.2 OS\_SEEK\_END

```
#define OS_SEEK_END 2
```

Seek offset end

Definition at line 45 of file osapi-file.h.

##### 10.62.2.3 OS\_SEEK\_SET

```
#define OS_SEEK_SET 0
```

Seek offset set

Definition at line 43 of file osapi-file.h.

Referenced by DS\_FileUpdateHeader().

## 10.63 OSAL Standard File APIs

### Functions

- `int32 OS_OpenCreate (osal_id_t *filedes, const char *path, int32 flags, int32 access_mode)`  
*Open or create a file.*
- `int32 OS_close (osal_id_t filedes)`  
*Closes an open file handle.*
- `int32 OS_read (osal_id_t filedes, void *buffer, size_t nbytes)`  
*Read from a file handle.*
- `int32 OS_write (osal_id_t filedes, const void *buffer, size_t nbytes)`  
*Write to a file handle.*
- `int32 OS_TimedRead (osal_id_t filedes, void *buffer, size_t nbytes, int32 timeout)`  
*File/Stream input read with a timeout.*
- `int32 OS_TimedWrite (osal_id_t filedes, const void *buffer, size_t nbytes, int32 timeout)`  
*File/Stream output write with a timeout.*
- `int32 OS_chmod (const char *path, uint32 access_mode)`  
*Changes the permissions of a file.*
- `int32 OS_stat (const char *path, os_fstat_t *filestats)`  
*Obtain information about a file or directory.*
- `int32 OS_lseek (osal_id_t filedes, int32 offset, uint32 whence)`  
*Seeks to the specified position of an open file.*
- `int32 OS_remove (const char *path)`  
*Removes a file from the file system.*
- `int32 OS_rename (const char *old_filename, const char *new_filename)`  
*Renames a file.*
- `int32 OS_cp (const char *src, const char *dest)`  
*Copies a single file from src to dest.*
- `int32 OS_mv (const char *src, const char *dest)`  
*Move a single file from src to dest.*
- `int32 OS_FDGetInfo (osal_id_t filedes, OS_file_prop_t *fd_prop)`  
*Obtain information about an open file.*
- `int32 OS_FileOpenCheck (const char *Filename)`  
*Checks to see if a file is open.*
- `int32 OS_CloseAllFiles (void)`  
*Close all open files.*
- `int32 OS_CloseFileByName (const char *Filename)`  
*Close a file by filename.*

### 10.63.1 Detailed Description

### 10.63.2 Function Documentation

#### 10.63.2.1 OS\_chmod()

```
int32 OS_chmod (
    const char * path,
    uint32 access_mode )
```

Changes the permissions of a file.

**Parameters**

in	<i>path</i>	File to change (must not be null)
in	<i>access_mode</i>	Desired access mode - see <a href="#">OSAL File Access Option Defines</a>

**Note**

Some file systems do not implement permissions. If the underlying OS does not support this operation, then [OS\\_ERR\\_NOT\\_IMPLEMENTED](#) is returned.

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<a href="#">OS_SUCCESS</a>	Successful execution. (return value only verified in coverage test)
<a href="#">OS_ERR_NOT_IMPLEMENTED</a>	if the filesystem does not support this call
<a href="#">OS_INVALID_POINTER</a>	if the path argument is NULL

**10.63.2.2 OS\_close()**

```
int32 OS_close (
    osal_id_t filedes )
```

Closes an open file handle.

This closes regular file handles and any other file-like resource, such as network streams or pipes.

**Parameters**

in	<i>filedes</i>	The handle ID to operate on
----	----------------	-----------------------------

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_ERR_INVALID_ID</a>	if the file descriptor passed in is invalid
<a href="#">OS_ERROR</a>	if an unexpected/unhandled error occurs (return value only verified in coverage test)

Referenced by DS\_FileCloseDest().

### 10.63.2.3 OS\_CloseAllFiles()

```
int32 OS_CloseAllFiles (
    void )
```

Close all open files.

Closes All open files that were opened through the OSAL

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_ERROR</a>	if one or more file close returned an error (return value only verified in coverage test)

### 10.63.2.4 OS\_CloseFileByName()

```
int32 OS_CloseFileByName (
    const char * Filename )
```

Close a file by filename.

Allows a file to be closed by name. This will only work if the name passed in is the same name used to open the file.

#### Parameters

in	<i>Filename</i>	The file to close (must not be null)
----	-----------------	--------------------------------------

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_FS_ERR_PATH_INVALID</a>	if the file is not found
<a href="#">OS_ERROR</a>	if the file close returned an error (return value only verified in coverage test)
<a href="#">OS_INVALID_POINTER</a>	if the filename argument is NULL

### 10.63.2.5 OS\_cp()

```
int32 OS_cp (
    const char * src,
    const char * dest )
```

Copies a single file from src to dest.

#### Note

The behavior of this API on an open file is not defined at the OSAL level due to dependencies on the underlying OS which may or may not allow the related operation based on a variety of potential configurations. For portability, it is recommended that applications ensure the file is closed prior to removal.

#### Parameters

in	<i>src</i>	The source file to operate on (must not be null)
in	<i>dest</i>	The destination file (must not be null)

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERROR</i>	if the file could not be accessed
<i>OS_INVALID_POINTER</i>	if src or dest are NULL
<i>OS_FS_ERR_PATH_INVALID</i>	if path cannot be parsed
<i>OS_FS_ERR_PATH_TOO_LONG</i>	if the paths given are too long to be stored locally
<i>OS_FS_ERR_NAME_TOO_LONG</i>	if the dest name is too long to be stored locally

### 10.63.2.6 OS\_FDGetInfo()

```
int32 OS_FDGetInfo (
    osal_id_t filedes,
    OS_file_prop_t * fd_prop )
```

Obtain information about an open file.

Copies the information of the given file descriptor into a structure passed in

**Parameters**

in	<i>filedes</i>	The handle ID to operate on
out	<i>fd_prop</i>	Storage buffer for file information (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the file descriptor passed in is invalid
<i>OS_INVALID_POINTER</i>	if the fd_prop argument is NULL

**10.63.2.7 OS\_FileOpenCheck()**

```
int32 OS_FileOpenCheck (
    const char * Filename )
```

Checks to see if a file is open.

This function takes a filename and determines if the file is open. The function will return success if the file is open.

**Parameters**

in	<i>Filename</i>	The file to operate on (must not be null)
----	-----------------	---

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	if the file is open
<i>OS_ERROR</i>	if the file is not open
<i>OS_INVALID_POINTER</i>	if the filename argument is NULL

**10.63.2.8 OS\_lseek()**

```
int32 OS_lseek (
    osal_id_t filedes,
```

```
int32 offset,
uint32 whence )
```

Seeks to the specified position of an open file.

Sets the read/write pointer to a specific offset in a specific file.

#### Parameters

in	<i>filedes</i>	The handle ID to operate on
in	<i>offset</i>	The file offset to seek to
in	<i>whence</i>	The reference point for offset, see <a href="#">OSAL Reference Point For Seek Offset Defines</a>

#### Returns

Byte offset from the beginning of the file or appropriate error code, see [OSAL Return Code Defines](#)

#### Return values

<a href="#"><i>OS_ERR_INVALID_ID</i></a>	if the file descriptor passed in is invalid
<a href="#"><i>OS_ERROR</i></a>	if OS call failed (return value only verified in coverage test)

Referenced by DS\_FileUpdateHeader().

### 10.63.2.9 OS\_mv()

```
int32 OS_mv (
    const char * src,
    const char * dest )
```

Move a single file from src to dest.

This first attempts to rename the file, which is faster if the source and destination reside on the same file system.

If this fails, it falls back to copying the file and removing the original.

#### Note

The behavior of this API on an open file is not defined at the OSAL level due to dependencies on the underlying OS which may or may not allow the related operation based on a variety of potential configurations. For portability, it is recommended that applications ensure the file is closed prior to removal.

#### Parameters

in	<i>src</i>	The source file to operate on (must not be null)
in	<i>dest</i>	The destination file (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_ERROR</a>	if the file could not be renamed.
<a href="#">OS_INVALID_POINTER</a>	if src or dest are NULL
<a href="#">OS_FS_ERR_PATH_INVALID</a>	if path cannot be parsed
<a href="#">OS_FS_ERR_PATH_TOO_LONG</a>	if the paths given are too long to be stored locally
<a href="#">OS_FS_ERR_NAME_TOO_LONG</a>	if the dest name is too long to be stored locally

Referenced by DS\_FileCloseDest().

**10.63.2.10 OS\_OpenCreate()**

```
int32 OS_OpenCreate (
    osal_id_t * filedes,
    const char * path,
    int32 flags,
    int32 access_mode )
```

Open or create a file.

Implements the same as OS\_open/OS\_creat but follows the OSAL paradigm of outputting the ID/descriptor separately from the return value, rather than relying on the user to convert it back.

**Parameters**

out	<i>filedes</i>	The handle ID (OS_OBJECT_ID_UNDEFINED on failure) (must not be null)
in	<i>path</i>	File name to create or open (must not be null)
in	<i>flags</i>	The file permissions - see <a href="#">OS_file_flag_t</a>
in	<i>access_mode</i>	Intended access mode - see <a href="#">OSAL File Access Option Defines</a>

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_ERROR</a>	if the command was not executed properly
<a href="#">OS_INVALID_POINTER</a>	if pointer argument was NULL
<a href="#">OS_ERR_NO_FREE_IDS</a>	if all available file handles are in use
<a href="#">OS_FS_ERR_NAME_TOO_LONG</a>	if the filename portion of the path exceeds OS_MAX_FILE_NAME

**Return values**

<code>OS_FS_ERR_PATH_INVALID</code>	if the path argument is not valid
<code>OS_FS_ERR_PATH_TOO_LONG</code>	if the path argument exceeds OS_MAX_PATH_LEN

Referenced by DS\_FileCreateDest().

**10.63.2.11 OS\_read()**

```
int32 OS_read (
    osal_id_t filedes,
    void * buffer,
    size_t nbytes )
```

Read from a file handle.

Reads up to nbytes from a file, and puts them into buffer.

If the file position is at the end of file (or beyond, if the OS allows) then this function will return 0.

**Parameters**

in	<i>filedes</i>	The handle ID to operate on
out	<i>buffer</i>	Storage location for file data (must not be null)
in	<i>nbytes</i>	Maximum number of bytes to read (must not be zero)

**Note**

All OSAL error codes are negative int32 values. Failure of this call can be checked by testing if the result is less than 0.

**Returns**

A non-negative byte count or appropriate error code, see [OSAL Return Code Defines](#)

**Return values**

<code>OS_INVALID_POINTER</code>	if buffer is a null pointer
<code>OS_ERR_INVALID_SIZE</code>	if the passed-in size is not valid
<code>OS_ERROR</code>	if OS call failed (return value only verified in coverage test)
<code>OS_ERR_INVALID_ID</code>	if the file descriptor passed in is invalid
<code>0</code>	if at end of file/stream data

### 10.63.2.12 OS\_remove()

```
int32 OS_remove (
    const char * path )
```

Removes a file from the file system.

Removes a given filename from the drive

#### Note

The behavior of this API on an open file is not defined at the OSAL level due to dependencies on the underlying OS which may or may not allow the related operation based on a variety of potential configurations. For portability, it is recommended that applications ensure the file is closed prior to removal.

#### Parameters

in	<i>path</i>	The file to operate on (must not be null)
----	-------------	---

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERROR</i>	if there is no device or the driver returns error
<i>OS_INVALID_POINTER</i>	if path is NULL
<i>OS_FS_ERR_PATH_TOO_LONG</i>	if path is too long to be stored locally
<i>OS_FS_ERR_PATH_INVALID</i>	if path cannot be parsed
<i>OS_FS_ERR_NAME_TOO_LONG</i>	if the name of the file to remove is too long

### 10.63.2.13 OS\_rename()

```
int32 OS_rename (
    const char * old_filename,
    const char * new_filename )
```

Renames a file.

Changes the name of a file, where the source and destination reside on the same file system.

#### Note

The behavior of this API on an open file is not defined at the OSAL level due to dependencies on the underlying OS which may or may not allow the related operation based on a variety of potential configurations. For portability, it is recommended that applications ensure the file is closed prior to removal.

**Parameters**

in	<i>old_filename</i>	The original filename (must not be null)
in	<i>new_filename</i>	The desired filename (must not be null)

**Returns**Execution status, see [OSAL Return Code Defines](#)**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERROR</i>	if the file could not be opened or renamed.
<i>OS_INVALID_POINTER</i>	if old or new are NULL
<i>OS_FS_ERR_PATH_INVALID</i>	if path cannot be parsed
<i>OS_FS_ERR_PATH_TOO_LONG</i>	if the paths given are too long to be stored locally
<i>OS_FS_ERR_NAME_TOO_LONG</i>	if the new name is too long to be stored locally

**10.63.2.14 OS\_stat()**

```
int32 OS_stat (
    const char * path,
    os_fstat_t * filestats )
```

Obtain information about a file or directory.

Returns information about a file or directory in an [os\\_fstat\\_t](#) structure**Parameters**

in	<i>path</i>	The file to operate on (must not be null)
out	<i>filestats</i>	Buffer to store file information (must not be null)

**Returns**Execution status, see [OSAL Return Code Defines](#)**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if path or filestats is NULL
<i>OS_FS_ERR_PATH_TOO_LONG</i>	if the path is too long to be stored locally
<i>OS_FS_ERR_NAME_TOO_LONG</i>	if the name of the file is too long to be stored
<i>OS_FS_ERR_PATH_INVALID</i>	if path cannot be parsed
<i>OS_ERROR</i>	if the OS call failed

### 10.63.2.15 OS\_TimedRead()

```
int32 OS_TimedRead (
    osal_id_t filedes,
    void * buffer,
    size_t nbytes,
    int32 timeout )
```

File/Stream input read with a timeout.

This implements a time-limited read and is primarily intended for use with sockets but may also work with any other stream-like resource that the underlying OS supports, such as pipes or special devices.

If data is immediately available on the file/socket, this will return that data along with the actual number of bytes that were immediately available. It will not block.

If the file position is at the end of file or end of stream data (e.g. if the remote end has closed the connection), then this function will immediately return 0 without blocking for the timeout period.

If no data is immediately available, but the underlying resource/stream is still connected to a peer, this will wait up to the given timeout for additional data to appear. If no data appears within the timeout period, then this returns the [OS\\_ERROR\\_TIMEOUT](#) status code. This allows the caller to differentiate an open (but idle) socket connection from a connection which has been closed by the remote peer.

In all cases this will return successfully as soon as at least 1 byte of actual data is available. It will not attempt to read the entire input buffer.

If an EOF condition occurs prior to timeout, this function returns zero.

#### Parameters

in	<i>filedes</i>	The handle ID to operate on
out	<i>buffer</i>	Storage location for file data (must not be null)
in	<i>nbytes</i>	Maximum number of bytes to read (must not be zero)
in	<i>timeout</i>	Maximum time to wait, in milliseconds (OS_PEND = forever)

#### Returns

Byte count on success or appropriate error code, see [OSAL Return Code Defines](#)

#### Return values

<a href="#">OS_ERROR_TIMEOUT</a>	if no data became available during timeout period
<a href="#">OS_ERR_INVALID_ID</a>	if the file descriptor passed in is invalid
<a href="#">OS_ERR_INVALID_SIZE</a>	if the passed-in size is not valid
<a href="#">OS_INVALID_POINTER</a>	if the passed-in buffer is not valid
0	if at end of file/stream data

### 10.63.2.16 OS\_TimedWrite()

```
int32 OS_TimedWrite (
    osal_id_t filedes,
    const void * buffer,
    size_t nbytes,
    int32 timeout )
```

File/Stream output write with a timeout.

This implements a time-limited write and is primarily intended for use with sockets but may also work with any other stream-like resource that the underlying OS supports.

If output buffer space is immediately available on the file/socket, this will place data into the buffer and return the actual number of bytes that were queued for output. It will not block.

If no output buffer space is immediately available, this will wait up to the given timeout for space to become available. If no space becomes available within the timeout period, then this returns an error code (not zero).

In all cases this will return successfully as soon as at least 1 byte of actual data is output. It will *not* attempt to write the entire output buffer.

If an EOF condition occurs prior to timeout, this function returns zero.

#### Parameters

in	<i>filedes</i>	The handle ID to operate on
in	<i>buffer</i>	Source location for file data (must not be null)
in	<i>nbytes</i>	Maximum number of bytes to read (must not be zero)
in	<i>timeout</i>	Maximum time to wait, in milliseconds (OS_PEND = forever)

#### Returns

A non-negative byte count or appropriate error code, see [OSAL Return Code Defines](#)

#### Return values

<a href="#"><i>OS_ERROR_TIMEOUT</i></a>	if no data became available during timeout period
<a href="#"><i>OS_ERR_INVALID_ID</i></a>	if the file descriptor passed in is invalid
<a href="#"><i>OS_ERR_INVALID_SIZE</i></a>	if the passed-in size is not valid
<a href="#"><i>OS_INVALID_POINTER</i></a>	if the passed-in buffer is not valid
0	if file/stream cannot accept any more data

### 10.63.2.17 OS\_write()

```
int32 OS_write (
    osal_id_t filedes,
    const void * buffer,
    size_t nbytes )
```

Write to a file handle.

Writes to a file. copies up to a maximum of nbytes of buffer to the file described in filedes

#### Parameters

in	<i>filedes</i>	The handle ID to operate on
in	<i>buffer</i>	Source location for file data (must not be null)
in	<i>nbytes</i>	Maximum number of bytes to read (must not be zero)

#### Note

All OSAL error codes are negative int32 values. Failure of this call can be checked by testing if the result is less than 0.

#### Returns

A non-negative byte count or appropriate error code, see [OSAL Return Code Defines](#)

#### Return values

<a href="#"><i>OS_INVALID_POINTER</i></a>	if buffer is NULL
<a href="#"><i>OS_ERR_INVALID_SIZE</i></a>	if the passed-in size is not valid
<a href="#"><i>OS_ERROR</i></a>	if OS call failed (return value only verified in coverage test)
<a href="#"><i>OS_ERR_INVALID_ID</i></a>	if the file descriptor passed in is invalid
<i>0</i>	if file/stream cannot accept any more data

Referenced by DS\_FileUpdateHeader(), DS\_FileWriteData(), and DS\_FileWriteHeader().

## 10.64 OSAL File System Level APIs

### Functions

- `int32 OS_FileSysAddFixedMap (osal_id_t *filesystem_id, const char *phys_path, const char *virt_path)`  
*Create a fixed mapping between an existing directory and a virtual OSAL mount point.*
- `int32 OS_mkfs (char *address, const char *devname, const char *volname, size_t blocksize, osal_blockcount_t numblocks)`  
*Makes a file system on the target.*
- `int32 OS_mount (const char *devname, const char *mountpoint)`  
*Mounts a file system.*
- `int32 OS_initfs (char *address, const char *devname, const char *volname, size_t blocksize, osal_blockcount_t numblocks)`  
*Initializes an existing file system.*
- `int32 OS_rmfs (const char *devname)`  
*Removes a file system.*
- `int32 OS_unmount (const char *mountpoint)`  
*Unmounts a mounted file system.*
- `int32 OS_FileSysStatVolume (const char *name, OS_statvfs_t *statbuf)`  
*Obtains information about size and free space in a volume.*
- `int32 OS_chkfs (const char *name, bool repair)`  
*Checks the health of a file system and repairs it if necessary.*
- `int32 OS_FS_GetPhysDriveName (char *PhysDriveName, const char *MountPoint)`  
*Obtains the physical drive name associated with a mount point.*
- `int32 OS_TranslatePath (const char *VirtualPath, char *LocalPath)`  
*Translates an OSAL Virtual file system path to a host Local path.*
- `int32 OS_GetFsInfo (os_fsinfo_t *filesystem_info)`  
*Returns information about the file system.*

### 10.64.1 Detailed Description

### 10.64.2 Function Documentation

#### 10.64.2.1 OS\_chkfs()

```
int32 OS_chkfs (
    const char * name,
    bool repair )
```

Checks the health of a file system and repairs it if necessary.

Checks the drives for inconsistencies and optionally also repairs it

#### Note

not all operating systems implement this function. If the underlying OS does not provide a facility to check the volume, then OS\_ERR\_NOT\_IMPLEMENTED will be returned.

**Parameters**

in	<i>name</i>	The device/path to operate on (must not be null)
in	<i>repair</i>	Whether to also repair inconsistencies

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution. (return value only verified in coverage test)
<i>OS_INVALID_POINTER</i>	Name is NULL
<i>OS_ERR_NOT_IMPLEMENTED</i>	Not implemented.
<i>OS_FS_ERR_PATH_TOO_LONG</i>	if the name is too long
<i>OS_ERROR</i>	Failed execution. (return value only verified in coverage test)

**10.64.2.2 OS\_FileSysAddFixedMap()**

```
int32 OS_FileSysAddFixedMap (
    osal_id_t * filesys_id,
    const char * phys_path,
    const char * virt_path )
```

Create a fixed mapping between an existing directory and a virtual OSAL mount point.

This mimics the behavior of a "FS\_BASED" entry in the VolumeTable but is registered at runtime. It is intended to be called by the PSP/BSP prior to starting the application.

**Note**

OSAL virtual mount points are required to be a single, non-empty top-level directory name. Virtual path names always follow the form /<virt\_mount\_point>/<relative\_path>/<file>. Only the relative path may be omitted/empty (i.e. /<virt\_mount\_point>/<file>) but the virtual mount point must be present and not an empty string. In particular this means it is not possible to directly refer to files in the "root" of the native file system from OSAL. However it is possible to create a virtual map to the root, such as by calling:

```
OS_FileSysAddFixedMap (&fs_id, "/", "/root");
```

**Parameters**

out	<i>filesys_id</i>	A buffer to store the ID of the file system mapping (must not be null)
in	<i>phys_path</i>	The native system directory (an existing mount point) (must not be null)
in	<i>virt_path</i>	The virtual mount point of this filesystem (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_FS_ERR_PATH_TOO_LONG</i>	if the overall phys_path is too long
<i>OS_ERR_NAME_TOO_LONG</i>	if the phys_path basename (filesystem name) is too long
<i>OS_INVALID_POINTER</i>	if any argument is NULL

**10.64.2.3 OS\_FileSysStatVolume()**

```
int32 OS_FileSysStatVolume (
    const char * name,
    OS_statvfs_t * statbuf )
```

Obtains information about size and free space in a volume.

Populates the supplied *OS\_statvfs\_t* structure, which includes the block size and total/free blocks in a file system volume.

This replaces two older OSAL calls:

*OS\_fsBlocksFree()* is determined by reading the *blocks\_free* output struct member *OS\_fsBytesFree()* is determined by multiplying *blocks\_free* by the *block\_size* member

**Parameters**

<i>in</i>	<i>name</i>	The device/path to operate on (must not be null)
<i>out</i>	<i>statbuf</i>	Output structure to populate (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if name or statbuf is NULL
<i>OS_FS_ERR_PATH_TOO_LONG</i>	if the name is too long
<i>OS_ERROR</i>	if an unexpected/unhandled OS error occurs (return value only verified in coverage test)

#### 10.64.2.4 OS\_FS\_GetPhysDriveName()

```
int32 OS_FS_GetPhysDriveName (
    char * PhysDriveName,
    const char * MountPoint )
```

Obtains the physical drive name associated with a mount point.

Returns the name of the physical volume associated with the drive, when given the OSAL mount point of the drive

##### Parameters

out	<i>PhysDriveName</i>	Buffer to store physical drive name (must not be null)
in	<i>MountPoint</i>	OSAL mount point (must not be null)

##### Returns

Execution status, see [OSAL Return Code Defines](#)

##### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if either parameter is NULL
<i>OS_ERR_NAME_NOT_FOUND</i>	if the MountPoint is not mounted in OSAL
<i>OS_FS_ERR_PATH_TOO_LONG</i>	if the MountPoint is too long

#### 10.64.2.5 OS\_GetFsInfo()

```
int32 OS_GetFsInfo (
    os_fsinfo_t * filesys_info )
```

Returns information about the file system.

Returns information about the file system in an [\*os\\_fsinfo\\_t\*](#). This includes the number of open files and file systems

##### Parameters

out	<i>filesys_info</i>	Buffer to store filesystem information (must not be null)
-----	---------------------	---

##### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<code>OS_SUCCESS</code>	Successful execution.
<code>OS_INVALID_POINTER</code>	if <code>filesys_info</code> is NULL

#### 10.64.2.6 OS\_initfs()

```
int32 OS_initfs (
    char * address,
    const char * devname,
    const char * volname,
    size_t blocksize,
    osal_blockcount_t numblocks )
```

Initializes an existing file system.

Initializes a file system on the target.

#### Note

The "volname" parameter of RAM disks should always begin with the string "RAM", e.g. "RAMDISK" or "RA←M0","RAM1", etc if multiple devices are created. The underlying implementation uses this to select the correct filesystem type/format, and this may also be used to differentiate between RAM disks and real physical disks.

#### Parameters

in	<code>address</code>	The address at which to start the new disk. If <code>address == 0</code> , then space will be allocated by the OS
in	<code>devname</code>	The underlying kernel device to use, if applicable. (must not be null)
in	<code>volname</code>	The name of the volume (see note) (must not be null)
in	<code>blocksize</code>	The size of a single block on the drive
in	<code>numblocks</code>	The number of blocks to allocate for the drive

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<code>OS_SUCCESS</code>	Successful execution.
<code>OS_INVALID_POINTER</code>	if <code>devname</code> or <code>volname</code> are NULL
<code>OS_FS_ERR_PATH_TOO_LONG</code>	if the name is too long
<code>OS_FS_ERR_DEVICE_NOT_FREE</code>	if the volume table is full
<code>OS_FS_ERR_DRIVE_NOT_CREATED</code>	if an unexpected/unhandled OS error occurs (return value only verified in coverage test)

### 10.64.2.7 OS\_mkfs()

```
int32 OS_mkfs (
    char * address,
    const char * devname,
    const char * volname,
    size_t blocksize,
    osal_blockcount_t numblocks )
```

Makes a file system on the target.

Makes a file system on the target. Highly dependent on underlying OS and dependent on OS volume table definition.

#### Note

The "volname" parameter of RAM disks should always begin with the string "RAM", e.g. "RAMDISK" or "RA←M0","RAM1", etc if multiple devices are created. The underlying implementation uses this to select the correct filesystem type/format, and this may also be used to differentiate between RAM disks and real physical disks.

#### Parameters

in	<i>address</i>	The address at which to start the new disk. If address == 0 space will be allocated by the OS.
in	<i>devname</i>	The underlying kernel device to use, if applicable. (must not be null)
in	<i>volname</i>	The name of the volume (see note) (must not be null)
in	<i>blocksize</i>	The size of a single block on the drive
in	<i>numblocks</i>	The number of blocks to allocate for the drive

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#"><b>OS_SUCCESS</b></a>	Successful execution.
<a href="#"><b>OS_INVALID_POINTER</b></a>	if devname or volname is NULL
<a href="#"><b>OS_FS_ERR_PATH_TOO_LONG</b></a>	if the overall devname or volname is too long
<a href="#"><b>OS_FS_ERR_DEVICE_NOT_FREE</b></a>	if the volume table is full
<a href="#"><b>OS_FS_ERR_DRIVE_NOT_CREATED</b></a>	if an unexpected/unhandled OS error occurs (return value only verified in coverage test)

### 10.64.2.8 OS\_mount()

```
int32 OS_mount (
```

```
const char * devname,
const char * mountpoint )
```

Mounts a file system.

Mounts a file system / block device at the given mount point.

#### Parameters

in	<i>devname</i>	The name of the drive to mount. <i>devname</i> is the same from <a href="#">OS_mkfs</a> (must not be null)
in	<i>mountpoint</i>	The name to call this disk from now on (must not be null)

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_ERR_NAME_NOT_FOUND</a>	if the device name does not exist in OSAL
<a href="#">OS_FS_ERR_PATH_TOO_LONG</a>	if the mount point string is too long
<a href="#">OS_INVALID_POINTER</a>	if any argument is NULL
<a href="#">OS_ERROR</a>	if an unexpected/unhandled OS error occurs (return value only verified in coverage test)

### 10.64.2.9 OS\_rmfs()

```
int32 OS_rmfs (
    const char * devname )
```

Removes a file system.

This function will remove or un-map the target file system. Note that this is not the same as un-mounting the file system.

#### Parameters

in	<i>devname</i>	The name of the "generic" drive (must not be null)
----	----------------	--

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#">OS_SUCCESS</a>	Successful execution.
----------------------------	-----------------------

### Return values

<i>OS_INVALID_POINTER</i>	if devname is NULL
<i>OS_FS_ERR_PATH_TOO_LONG</i>	if the devname is too long
<i>OS_ERR_NAME_NOT_FOUND</i>	if the devname does not exist in OSAL
<i>OS_ERROR</i>	if an unexpected/unhandled OS error occurs (return value only verified in coverage test)

### 10.64.2.10 OS\_TranslatePath()

```
int32 OS_TranslatePath (
    const char * VirtualPath,
    char * LocalPath )
```

Translates an OSAL Virtual file system path to a host Local path.

Translates a virtual path to an actual system path name

#### Note

The buffer provided in the LocalPath argument is required to be at least OS\_MAX\_PATH\_LEN characters in length.

#### Parameters

in	<i>VirtualPath</i>	OSAL virtual path name (must not be null)
out	<i>LocalPath</i>	Buffer to store native/translated path name (must not be null)

#### Returns

Execution status, see [OSAL Return Code Defines](#)

### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if either parameter is NULL
<i>OS_FS_ERR_NAME_TOO_LONG</i>	if the filename component is too long
<i>OS_FS_ERR_PATH_INVALID</i>	if either parameter cannot be interpreted as a path
<i>OS_FS_ERR_PATH_TOO_LONG</i>	if either input or output pathnames are too long

### 10.64.2.11 OS\_unmount()

```
int32 OS_unmount (
    const char * mountpoint )
```

Unmounts a mounted file system.

This function will unmount a drive from the file system and make all open file descriptors useless.

#### Note

Any open file descriptors referencing this file system should be closed prior to unmounting a drive

#### Parameters

in	<i>mountpoint</i>	The mount point to remove from <a href="#">OS_mount</a> (must not be null)
----	-------------------	--

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_INVALID_POINTER</a>	if name is NULL
<a href="#">OS_FS_ERR_PATH_TOO_LONG</a>	if the absolute path given is too long
<a href="#">OS_ERR_NAME_NOT_FOUND</a>	if the mountpoint is not mounted in OSAL
<a href="#">OS_ERROR</a>	if an unexpected/unhandled OS error occurs (return value only verified in coverage test)

## 10.65 OSAL Heap APIs

### Functions

- `int32 OS_HeapGetInfo (OS_heap_prop_t *heap_prop)`

*Return current info on the heap.*

#### 10.65.1 Detailed Description

#### 10.65.2 Function Documentation

##### 10.65.2.1 OS\_HeapGetInfo()

```
int32 OS_HeapGetInfo (
    OS_heap_prop_t * heap_prop )
```

Return current info on the heap.

#### Parameters

<code>out</code>	<code>heap_prop</code>	Storage buffer for heap info
------------------	------------------------	------------------------------

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<code>OS_SUCCESS</code>	Successful execution.
<code>OS_INVALID_POINTER</code>	if the <code>heap_prop</code> argument is NULL

## 10.66 OSAL Object Type Defines

### Macros

- #define **OS\_OBJECT\_TYPE\_UNDEFINED** 0x00  
*Object type undefined.*
- #define **OS\_OBJECT\_TYPE\_OS\_TASK** 0x01  
*Object task type.*
- #define **OS\_OBJECT\_TYPE\_OS\_QUEUE** 0x02  
*Object queue type.*
- #define **OS\_OBJECT\_TYPE\_OS\_COUNTSEM** 0x03  
*Object counting semaphore type.*
- #define **OS\_OBJECT\_TYPE\_OS\_BINSEM** 0x04  
*Object binary semaphore type.*
- #define **OS\_OBJECT\_TYPE\_OS\_MUTEX** 0x05  
*Object mutex type.*
- #define **OS\_OBJECT\_TYPE\_OS\_STREAM** 0x06  
*Object stream type.*
- #define **OS\_OBJECT\_TYPE\_OS\_DIR** 0x07  
*Object directory type.*
- #define **OS\_OBJECT\_TYPE\_OS\_TIMEBASE** 0x08  
*Object timebase type.*
- #define **OS\_OBJECT\_TYPE\_OS\_TIMECB** 0x09  
*Object timer callback type.*
- #define **OS\_OBJECT\_TYPE\_OS\_MODULE** 0x0A  
*Object module type.*
- #define **OS\_OBJECT\_TYPE\_OS\_FILESYS** 0x0B  
*Object file system type.*
- #define **OS\_OBJECT\_TYPE\_OS\_CONSOLE** 0x0C  
*Object console type.*
- #define **OS\_OBJECT\_TYPE\_USER** 0x10  
*Object user type.*

### 10.66.1 Detailed Description

### 10.66.2 Macro Definition Documentation

#### 10.66.2.1 **OS\_OBJECT\_TYPE\_OS\_BINSEM**

```
#define OS_OBJECT_TYPE_OS_BINSEM 0x04
```

Object binary semaphore type.

Definition at line 42 of file osapi-idmap.h.

### 10.66.2.2 OS\_OBJECT\_TYPE\_OS\_CONSOLE

```
#define OS_OBJECT_TYPE_OS_CONSOLE 0x0C
```

Object console type.

Definition at line 50 of file osapi-idmap.h.

### 10.66.2.3 OS\_OBJECT\_TYPE\_OS\_COUNTSEM

```
#define OS_OBJECT_TYPE_OS_COUNTSEM 0x03
```

Object counting semaphore type.

Definition at line 41 of file osapi-idmap.h.

### 10.66.2.4 OS\_OBJECT\_TYPE\_OS\_DIR

```
#define OS_OBJECT_TYPE_OS_DIR 0x07
```

Object directory type.

Definition at line 45 of file osapi-idmap.h.

### 10.66.2.5 OS\_OBJECT\_TYPE\_OS\_FILESYS

```
#define OS_OBJECT_TYPE_OS_FILESYS 0x0B
```

Object file system type.

Definition at line 49 of file osapi-idmap.h.

### 10.66.2.6 OS\_OBJECT\_TYPE\_OS\_MODULE

```
#define OS_OBJECT_TYPE_OS_MODULE 0x0A
```

Object module type.

Definition at line 48 of file osapi-idmap.h.

**10.66.2.7 OS\_OBJECT\_TYPE\_OS\_MUTEX**

```
#define OS_OBJECT_TYPE_OS_MUTEX 0x05
```

Object mutex type.

Definition at line 43 of file osapi-idmap.h.

**10.66.2.8 OS\_OBJECT\_TYPE\_OS\_QUEUE**

```
#define OS_OBJECT_TYPE_OS_QUEUE 0x02
```

Object queue type.

Definition at line 40 of file osapi-idmap.h.

**10.66.2.9 OS\_OBJECT\_TYPE\_OS\_STREAM**

```
#define OS_OBJECT_TYPE_OS_STREAM 0x06
```

Object stream type.

Definition at line 44 of file osapi-idmap.h.

**10.66.2.10 OS\_OBJECT\_TYPE\_OS\_TASK**

```
#define OS_OBJECT_TYPE_OS_TASK 0x01
```

Object task type.

Definition at line 39 of file osapi-idmap.h.

**10.66.2.11 OS\_OBJECT\_TYPE\_OS\_TIMEBASE**

```
#define OS_OBJECT_TYPE_OS_TIMEBASE 0x08
```

Object timebase type.

Definition at line 46 of file osapi-idmap.h.

**10.66.2.12 OS\_OBJECT\_TYPE\_OS\_TIMECB**

```
#define OS_OBJECT_TYPE_OS_TIMECB 0x09
```

Object timer callback type.

Definition at line 47 of file osapi-idmap.h.

**10.66.2.13 OS\_OBJECT\_TYPE\_UNDEFINED**

```
#define OS_OBJECT_TYPE_UNDEFINED 0x00
```

Object type undefined.

Definition at line 38 of file osapi-idmap.h.

**10.66.2.14 OS\_OBJECT\_TYPE\_USER**

```
#define OS_OBJECT_TYPE_USER 0x10
```

Object user type.

Definition at line 51 of file osapi-idmap.h.

## 10.67 OSAL Object ID Utility APIs

### Functions

- static unsigned long [OS\\_ObjectIdToInteger \(osal\\_id\\_t object\\_id\)](#)  
*Obtain an integer value corresponding to an object ID.*
- static [osal\\_id\\_t OS\\_ObjectIdFromInteger \(unsigned long value\)](#)  
*Obtain an osal ID corresponding to an integer value.*
- static bool [OS\\_ObjectIdEqual \(osal\\_id\\_t object\\_id1, osal\\_id\\_t object\\_id2\)](#)  
*Check two OSAL object ID values for equality.*
- static bool [OS\\_ObjectIdDefined \(osal\\_id\\_t object\\_id\)](#)  
*Check if an object ID is defined.*
- [int32 OS\\_GetResourceName \(osal\\_id\\_t object\\_id, char \\*buffer, size\\_t buffer\\_size\)](#)  
*Obtain the name of an object given an arbitrary object ID.*
- [osal\\_objtype\\_t OS\\_IdentifyObject \(osal\\_id\\_t object\\_id\)](#)  
*Obtain the type of an object given an arbitrary object ID.*
- [int32 OS\\_ConvertToArrayIndex \(osal\\_id\\_t object\\_id, osal\\_index\\_t \\*ArrayIndex\)](#)  
*Converts an abstract ID into a number suitable for use as an array index.*
- [int32 OS\\_ObjectIdToArrayIndex \(osal\\_objtype\\_t idtype, osal\\_id\\_t object\\_id, osal\\_index\\_t \\*ArrayIndex\)](#)  
*Converts an abstract ID into a number suitable for use as an array index.*
- void [OS\\_ForEachObject \(osal\\_id\\_t creator\\_id, OS\\_ArgCallback\\_t callback\\_ptr, void \\*callback\\_arg\)](#)  
*call the supplied callback function for all valid object IDs*
- void [OS\\_ForEachObjectType \(osal\\_objtype\\_t objtype, osal\\_id\\_t creator\\_id, OS\\_ArgCallback\\_t callback\\_ptr, void \\*callback\\_arg\)](#)  
*call the supplied callback function for valid object IDs of a specific type*

### 10.67.1 Detailed Description

### 10.67.2 Function Documentation

#### 10.67.2.1 OS\_ConvertToArrayIndex()

```
int32 OS_ConvertToArrayIndex (
    osal_id_t object_id,
    osal_index_t * ArrayIndex )
```

Converts an abstract ID into a number suitable for use as an array index.

This will return a unique zero-based integer number in the range of [0,MAX) for any valid object ID. This may be used by application code as an array index for indexing into local tables.

#### Note

This does NOT verify the validity of the ID, that is left to the caller. This is only the conversion logic.

This routine accepts any object type, and returns a value based on the maximum number of objects for that type. This is equivalent to invoking [OS\\_ObjectIdToArrayIndex\(\)](#) with the idtype set to [OS\\_OBJECT\\_TYPE\\_UNDEFINED](#).

#### See also

[OS\\_ObjectIdToArrayIndex](#)

**Parameters**

in	<i>object_id</i>	The object ID to operate on
out	* <i>ArrayIndex</i>	The Index to return (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the object_id argument is not valid
<i>OS_INVALID_POINTER</i>	if the ArrayIndex is NULL

Referenced by OS\_ObjectIdDefined().

**10.67.2.2 OS\_ForEachObject()**

```
void OS_ForEachObject (
    osal_id_t creator_id,
    OS_ArgCallback_t callback_ptr,
    void * callback_arg )
```

call the supplied callback function for all valid object IDs

Loops through all defined OSAL objects of all types and calls callback\_ptr on each one If creator\_id is nonzero then only objects with matching creator id are processed.

**Parameters**

in	<i>creator_id</i>	Filter objects to those created by a specific task This may be passed as OS_OBJECT_CREATOR_ANY to return all objects
in	<i>callback_ptr</i>	Function to invoke for each matching object ID
in	<i>callback_arg</i>	Opaque Argument to pass to callback function (may be NULL)

Referenced by OS\_ObjectIdDefined().

**10.67.2.3 OS\_ForEachObjectType()**

```
void OS_ForEachObjectType (
    osal_objtype_t objtype,
```

```
    osal_id_t creator_id,
    OS_ArgCallback_t callback_ptr,
    void * callback_arg )
```

call the supplied callback function for valid object IDs of a specific type

Loops through all defined OSAL objects of a specific type and calls callback\_ptr on each one If creator\_id is nonzero then only objects with matching creator id are processed.

#### Parameters

in	<i>objtype</i>	The type of objects to iterate
in	<i>creator_id</i>	Filter objects to those created by a specific task This may be passed as OS_OBJECT_CREATOR_ANY to return all objects
in	<i>callback_ptr</i>	Function to invoke for each matching object ID
in	<i>callback_arg</i>	Opaque Argument to pass to callback function (may be NULL)

Referenced by OS\_ObjectIdDefined().

#### 10.67.2.4 OS\_GetResourceName()

```
int32 OS_GetResourceName (
    osal_id_t object_id,
    char * buffer,
    size_t buffer_size )
```

Obtain the name of an object given an arbitrary object ID.

All OSAL resources generally have a name associated with them. This allows application code to retrieve the name of any valid OSAL object ID.

#### Parameters

in	<i>object_id</i>	The object ID to operate on
out	<i>buffer</i>	Buffer in which to store the name (must not be null)
in	<i>buffer_size</i>	Size of the output storage buffer (must not be zero)

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#"><i>OS_SUCCESS</i></a>	Successful execution.
<a href="#"><i>OS_ERR_INVALID_ID</i></a>	if the passed-in ID is not a valid OSAL ID
<a href="#"><i>OS_INVALID_POINTER</i></a>	if the passed-in buffer is invalid
<a href="#"><i>OS_ERR_NAME_TOO_LONG</i></a>	if the name will not fit in the buffer provided

Referenced by OS\_ObjectIdDefined().

#### 10.67.2.5 OS\_IdentifyObject()

```
osal_objtype_t OS_IdentifyObject (
    osal_id_t object_id )
```

Obtain the type of an object given an arbitrary object ID.

Given an arbitrary object ID, get the type of the object

##### Parameters

in	<i>object_id</i>	The object ID to operate on
----	------------------	-----------------------------

##### Returns

The object type portion of the object\_id, see [OSAL Object Type Defines](#) for expected values

Referenced by OS\_ObjectIdDefined().

#### 10.67.2.6 OS\_ObjectIdDefined()

```
static bool OS_ObjectIdDefined (
    osal_id_t object_id ) [inline], [static]
```

Check if an object ID is defined.

The OSAL ID values should be treated as abstract values by applications, and not directly manipulated using standard C operators.

This returns false if the ID is NOT a defined resource (i.e. free/empty/invalid).

##### Note

OS\_ObjectIdDefined(OS\_OBJECT\_ID\_UNDEFINED) is always guaranteed to be false.

##### Parameters

in	<i>object_id</i>	The first object ID
----	------------------	---------------------

Definition at line 147 of file osapi-idmap.h.

References OS\_ConvertToArrayIndex(), OS\_ForEachObject(), OS\_ForEachObjectType(), OS\_GetResourceName(), OS\_IdentifyObject(), OS\_ObjectIdToInteger(), and OS\_ObjectIdToInteger().

Referenced by DS\_CmdCloseAll(), DS\_CmdCloseFile(), DS\_CmdGetFileInfo(), DS\_FileCreateDest(), DS\_FileSetupWrite(), and DS\_FileTestAge().

#### 10.67.2.7 OS\_ObjectIdEqual()

```
static bool OS_ObjectIdEqual (
    osal_id_t object_id1,
    osal_id_t object_id2 ) [inline], [static]
```

Check two OSAL object ID values for equality.

The OSAL ID values should be treated as abstract values by applications, and not directly manipulated using standard C operators.

This checks two values for equality, replacing the "==" operator.

##### Parameters

in	<i>object_id1</i>	The first object ID
in	<i>object_id2</i>	The second object ID

##### Returns

true if the object IDs are equal

Definition at line 126 of file osapi-idmap.h.

References OS\_ObjectIdToInteger().

#### 10.67.2.8 OS\_ObjectIdFromInteger()

```
static osal_id_t OS_ObjectIdFromInteger (
    unsigned long value ) [inline], [static]
```

Obtain an osal ID corresponding to an integer value.

Provides the inverse of [OS\\_ObjectIdToInteger\(\)](#). Reconstitutes the original osal\_id\_t type from an integer representation.

##### Parameters

in	<i>value</i>	The integer representation of an OSAL ID
----	--------------	--

**Returns**

The ID value converted to an osal\_id\_t

Definition at line 101 of file osapi-idmap.h.

**10.67.2.9 OS\_ObjectIdToArrayIndex()**

```
int32 OS_ObjectIdToArrayIndex (
    osal_objtype_t idtype,
    osal_id_t object_id,
    osal_index_t * ArrayIndex )
```

Converts an abstract ID into a number suitable for use as an array index.

This will return a unique zero-based integer number in the range of [0,MAX) for any valid object ID. This may be used by application code as an array index for indexing into local tables.

This routine operates on a specific object type, and returns a value based on the maximum number of objects for that type.

If the idtype is passed as [OS\\_OBJECT\\_TYPE\\_UNDEFINED](#), then object type verification is skipped and any object ID will be accepted and converted to an index. In this mode, the range of the output depends on the actual passed-in object type.

If the idtype is passed as any other value, the passed-in ID value is first confirmed to be the correct type. This check will guarantee that the output is within an expected range; for instance, if the type is passed as [OS\\_OBJECT\\_TYPE\\_OS\\_TASK](#), then the output index is guaranteed to be between 0 and [OS\\_MAX\\_TASKS](#)-1 after successful conversion.

**Parameters**

in	<i>idtype</i>	The object type to convert
in	<i>object_id</i>	The object ID to operate on
out	<i>*ArrayIndex</i>	The Index to return (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_ERR_INVALID_ID</a>	if the object_id argument is not valid
<a href="#">OS_INVALID_POINTER</a>	if the ArrayIndex is NULL

Referenced by [OS\\_ObjectIdDefined\(\)](#).

### 10.67.2.10 OS\_ObjectIdToInteger()

```
static unsigned long OS_ObjectIdToInteger (
    osal_id_t object_id ) [inline], [static]
```

Obtain an integer value corresponding to an object ID.

Obtains an integer representation of an object id, generally for the purpose of printing to the console or system logs.

The returned value is of the type "unsigned long" for direct use with printf-style functions. It is recommended to use the "%lx" conversion specifier as the hexadecimal encoding clearly delineates the internal fields.

#### Note

This provides the raw integer value and is *not* suitable for use as an array index, as the result is not zero-based.  
See the [OS\\_ConvertToArrayIndex\(\)](#) to obtain a zero-based index value.

#### Parameters

in	<i>object_id</i>	The object ID
----	------------------	---------------

#### Returns

integer value representation of object ID

Definition at line 79 of file osapi-idmap.h.

Referenced by [OS\\_ObjectIdDefined\(\)](#), and [OS\\_ObjectIdEqual\(\)](#).

## 10.68 OSAL Dynamic Loader and Symbol APIs

### Functions

- `int32 OS_SymbolLookup (cpuaddr *symbol_address, const char *symbol_name)`  
*Find the Address of a Symbol.*
- `int32 OS_ModuleSymbolLookup (osal_id_t module_id, cpuaddr *symbol_address, const char *symbol_name)`  
*Find the Address of a Symbol within a module.*
- `int32 OS_SymbolTableDump (const char *filename, size_t size_limit)`  
*Dumps the system symbol table to a file.*
- `int32 OS_ModuleLoad (osal_id_t *module_id, const char *module_name, const char *filename, uint32 flags)`  
*Loads an object file.*
- `int32 OS_ModuleUnload (osal_id_t module_id)`  
*Unloads the module file.*
- `int32 OS_ModuleInfo (osal_id_t module_id, OS_module_prop_t *module_info)`  
*Obtain information about a module.*

### 10.68.1 Detailed Description

### 10.68.2 Function Documentation

#### 10.68.2.1 OS\_ModuleInfo()

```
int32 OS_ModuleInfo (
    osal_id_t module_id,
    OS_module_prop_t * module_info )
```

Obtain information about a module.

Returns information about the loadable module

#### Parameters

in	<code>module_id</code>	OSAL ID of the previously the loaded module
out	<code>module_info</code>	Buffer to store module information (must not be null)

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<code>OS_SUCCESS</code>	Successful execution.
<code>OS_ERR_INVALID_ID</code>	if the module id invalid

**Return values**

<i>OS_INVALID_POINTER</i>	if the pointer to the ModuleInfo structure is invalid
<i>OS_ERROR</i>	if an other/unspecified error occurs (return value only verified in coverage test)

**10.68.2.2 OS\_ModuleLoad()**

```
int32 OS_ModuleLoad (
    osal_id_t * module_id,
    const char * module_name,
    const char * filename,
    uint32 flags )
```

Loads an object file.

Loads an object file into the running operating system

The "flags" parameter may influence how the loaded module symbols are made available for use in the application. See [OS\\_MODULE\\_FLAG\\_LOCAL\\_SYMBOLS](#) and [OS\\_MODULE\\_FLAG\\_GLOBAL\\_SYMBOLS](#) for descriptions.

**Parameters**

<i>out</i>	<i>module_id</i>	Non-zero OSAL ID corresponding to the loaded module
<i>in</i>	<i>module_name</i>	Name of module (must not be null)
<i>in</i>	<i>filename</i>	File containing the object code to load (must not be null)
<i>in</i>	<i>flags</i>	Options for the loaded module

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if one of the parameters is NULL
<i>OS_ERR_NO_FREE_IDS</i>	if the module table is full
<i>OS_ERR_NAME_TAKEN</i>	if the name is in use
<i>OS_ERR_NAME_TOO_LONG</i>	if the module_name is too long
<i>OS_FS_ERR_PATH_INVALID</i>	if the filename argument is not valid
<i>OS_ERROR</i>	if an other/unspecified error occurs (return value only verified in coverage test)

### 10.68.2.3 OS\_ModuleSymbolLookup()

```
int32 OS_ModuleSymbolLookup (
    osal_id_t module_id,
    cpuaddr * symbol_address,
    const char * symbol_name )
```

Find the Address of a Symbol within a module.

This is similar to [OS\\_SymbolLookup\(\)](#) but for a specific module ID. This should be used to look up a symbol in a module that has been loaded with the [OS\\_MODULE\\_FLAG\\_LOCAL\\_SYMBOLS](#) flag.

#### Parameters

in	<i>module_id</i>	Module ID that should contain the symbol
out	<i>symbol_address</i>	Set to the address of the symbol (must not be null)
in	<i>symbol_name</i>	Name of the symbol to look up (must not be null)

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_ERROR</a>	if the symbol could not be found
<a href="#">OS_INVALID_POINTER</a>	if one of the pointers passed in are NULL

### 10.68.2.4 OS\_ModuleUnload()

```
int32 OS_ModuleUnload (
    osal_id_t module_id )
```

Unloads the module file.

Unloads the module file from the running operating system

#### Parameters

in	<i>module_id</i>	OSAL ID of the previously the loaded module
----	------------------	---

#### Returns

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the module id invalid
<i>OS_ERROR</i>	if an other/unspecified error occurs (return value only verified in coverage test)

**10.68.2.5 OS\_SymbolLookup()**

```
int32 OS_SymbolLookup (
    cpuaddr * symbol_address,
    const char * symbol_name )
```

Find the Address of a Symbol.

This calls to the OS dynamic symbol lookup implementation, and/or checks a static symbol table for a matching symbol name.

The static table is intended to support embedded targets that do not have module loading capability or have it disabled.

**Parameters**

<i>out</i>	<i>symbol_address</i>	Set to the address of the symbol (must not be null)
<i>in</i>	<i>symbol_name</i>	Name of the symbol to look up (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERROR</i>	if the symbol could not be found
<i>OS_INVALID_POINTER</i>	if one of the pointers passed in are NULL

**10.68.2.6 OS\_SymbolTableDump()**

```
int32 OS_SymbolTableDump (
    const char * filename,
    size_t size_limit )
```

Dumps the system symbol table to a file.

Dumps the system symbol table to the specified filename

**Note**

Not all RTOS implementations support this API. If the underlying module subsystem does not provide a facility to iterate through the symbol table, then the [OS\\_ERR\\_NOT\\_IMPLEMENTED](#) status code is returned.

**Parameters**

in	<i>filename</i>	File to write to (must not be null)
in	<i>size_limit</i>	Maximum number of bytes to write

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_ERR_NOT_IMPLEMENTED</a>	Not implemented.
<a href="#">OS_INVALID_POINTER</a>	if the filename argument is NULL
<a href="#">OS_FS_ERR_PATH_INVALID</a>	if the filename argument is not valid
<a href="#">OS_ERR_NAME_TOO_LONG</a>	if any of the symbol names are too long (return value only verified in coverage test)
<a href="#">OS_ERR_OUTPUT_TOO_LARGE</a>	if the size_limit was reached before completing all symbols (return value only verified in coverage test)
<a href="#">OS_ERROR</a>	if an other/unspecified error occurs (return value only verified in coverage test)

## 10.69 OSAL Mutex APIs

### Functions

- `int32 OS_MutSemCreate (osal_id_t *sem_id, const char *sem_name, uint32 options)`  
*Creates a mutex semaphore.*
- `int32 OS_MutSemGive (osal_id_t sem_id)`  
*Releases the mutex object referenced by `sem_id`.*
- `int32 OS_MutSemTake (osal_id_t sem_id)`  
*Acquire the mutex object referenced by `sem_id`.*
- `int32 OS_MutSemDelete (osal_id_t sem_id)`  
*Deletes the specified Mutex Semaphore.*
- `int32 OS_MutSemGetIdByName (osal_id_t *sem_id, const char *sem_name)`  
*Find an existing mutex ID by name.*
- `int32 OS_MutSemGetInfo (osal_id_t sem_id, OS_mut_sem_prop_t *mut_prop)`  
*Fill a property object buffer with details regarding the resource.*

### 10.69.1 Detailed Description

### 10.69.2 Function Documentation

#### 10.69.2.1 OS\_MutSemCreate()

```
int32 OS_MutSemCreate (
    osal_id_t * sem_id,
    const char * sem_name,
    uint32 options )
```

Creates a mutex semaphore.

Mutex semaphores are always created in the unlocked (full) state.

#### Parameters

out	<code>sem_id</code>	will be set to the non-zero ID of the newly-created resource (must not be null)
in	<code>sem_name</code>	the name of the new resource to create (must not be null)
in	<code>options</code>	reserved for future use. Should be passed as 0.

#### Returns

Execution status, see [OSAL Return Code Defines](#)

## Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if sem_id or sem_name are NULL
<i>OS_ERR_NAME_TOO_LONG</i>	name length including null terminator greater than <i>OS_MAX_API_NAME</i>
<i>OS_ERR_NO_FREE_IDS</i>	if there are no more free mutex Ids
<i>OS_ERR_NAME_TAKEN</i>	if there is already a mutex with the same name
<i>OS_SEM_FAILURE</i>	if the OS call failed (return value only verified in coverage test)

## 10.69.2.2 OS\_MutSemDelete()

```
int32 OS_MutSemDelete (
    osal_id_t sem_id )
```

Deletes the specified Mutex Semaphore.

Delete the semaphore. This also frees the respective sem\_id such that it can be used again when another is created.

## Parameters

in	<i>sem_id</i>	The object ID to delete
----	---------------	-------------------------

## Returns

Execution status, see [OSAL Return Code Defines](#)

## Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the id passed in is not a valid mutex
<i>OS_SEM_FAILURE</i>	if an unspecified error occurs (return value only verified in coverage test)

## 10.69.2.3 OS\_MutSemGetIdByName()

```
int32 OS_MutSemGetIdByName (
    osal_id_t * sem_id,
    const char * sem_name )
```

Find an existing mutex ID by name.

This function tries to find a mutex sem\_id given the name of a mut\_sem. The id is returned through sem\_id

**Parameters**

out	<i>sem_id</i>	will be set to the ID of the existing resource
in	<i>sem_name</i>	the name of the existing resource to find (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if semid or sem_name are NULL pointers
<i>OS_ERR_NAME_TOO_LONG</i>	name length including null terminator greater than <i>OS_MAX_API_NAME</i>
<i>OS_ERR_NAME_NOT_FOUND</i>	if the name was not found in the table

**10.69.2.4 OS\_MutSemGetInfo()**

```
int32 OS_MutSemGetInfo (
    osal_id_t sem_id,
    OS_mut_sem_prop_t * mut_prop )
```

Fill a property object buffer with details regarding the resource.

This function will pass back a pointer to structure that contains all of the relevant info( name and creator) about the specified mutex semaphore.

**Parameters**

in	<i>sem_id</i>	The object ID to operate on
out	<i>mut_prop</i>	The property object buffer to fill (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the id passed in is not a valid semaphore
<i>OS_INVALID_POINTER</i>	if the mut_prop pointer is null

### 10.69.2.5 OS\_MutSemGive()

```
int32 OS_MutSemGive (
    osal_id_t sem_id )
```

Releases the mutex object referenced by `sem_id`.

If there are threads blocked on the mutex object referenced by `mutex` when this function is called, resulting in the mutex becoming available, the scheduling policy shall determine which thread shall acquire the mutex.

#### Parameters

in	<code>sem_id</code>	The object ID to operate on
----	---------------------	-----------------------------

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<code>OS_SUCCESS</code>	Successful execution.
<code>OS_ERR_INVALID_ID</code>	if the id passed in is not a valid mutex
<code>OS_SEM_FAILURE</code>	if an unspecified error occurs (return value only verified in coverage test)

### 10.69.2.6 OS\_MutSemTake()

```
int32 OS_MutSemTake (
    osal_id_t sem_id )
```

Acquire the mutex object referenced by `sem_id`.

If the mutex is already locked, the calling thread shall block until the mutex becomes available. This operation shall return with the mutex object referenced by `mutex` in the locked state with the calling thread as its owner.

#### Parameters

in	<code>sem_id</code>	The object ID to operate on
----	---------------------	-----------------------------

#### Returns

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	the id passed in is not a valid mutex
<i>OS_SEM_FAILURE</i>	if an unspecified error occurs (return value only verified in coverage test)

## 10.70 OSAL Network ID APIs

### Functions

- [int32 OS\\_NetworkGetID \(void\)](#)  
*Gets the network ID of the local machine.*
- [int32 OS\\_NetworkGetHostName \(char \\*host\\_name, size\\_t name\\_len\)](#)  
*Gets the local machine network host name.*

### 10.70.1 Detailed Description

Provides some basic methods to query a network host name and ID

### 10.70.2 Function Documentation

#### 10.70.2.1 OS\_NetworkGetHostName()

```
int32 OS_NetworkGetHostName (
    char * host_name,
    size_t name_len )
```

Gets the local machine network host name.

If configured in the underlying network stack, this function retrieves the local hostname of the system.

#### Parameters

out	<i>host_name</i>	Buffer to hold name information (must not be null)
in	<i>name_len</i>	Maximum length of host name buffer (must not be zero)

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_ERR_INVALID_SIZE</a>	if the name_len is zero
<a href="#">OS_INVALID_POINTER</a>	if the host_name is NULL

### 10.70.2.2 OS\_NetworkGetID()

```
int32 OS_NetworkGetID (
    void )
```

Gets the network ID of the local machine.

The ID is an implementation-defined value and may not be consistent in meaning across different platform types.

#### Note

This API may be removed in a future version of OSAL due to inconsistencies between platforms.

#### Returns

The ID or fixed value of -1 if the host id could not be found. Note it is not possible to differentiate between error codes and valid network IDs here. It is assumed, however, that -1 is never a valid ID.

## 10.71 OSAL Printf APIs

### Functions

- void [OS\\_printf](#) (const char \*string,...) [OS\\_PRINTF\(1\)](#)  
*Abstraction for the system printf() call.*
- void void [OS\\_printf\\_disable](#) (void)  
*This function disables the output from OS\_printf.*
- void [OS\\_printf\\_enable](#) (void)  
*This function enables the output from OS\_printf.*

### 10.71.1 Detailed Description

### 10.71.2 Function Documentation

#### 10.71.2.1 [OS\\_printf\(\)](#)

```
void OS_printf (
    const char * string,
    ...
)
```

Abstraction for the system printf() call.

This function abstracts out the printf type statements. This is useful for using OS- specific thots that will allow non-polled print statements for the real time systems.

Operates in a manner similar to the printf() call defined by the standard C library and takes all the parameters and formatting options of printf. This abstraction may implement additional buffering, if necessary, to improve the real-time performance of the call.

Strings (including terminator) longer than [OS\\_BUFFER\\_SIZE](#) will be truncated.

The output of this routine also may be dynamically enabled or disabled by the [OS\\_printf\\_enable\(\)](#) and [OS\\_printf\\_disable\(\)](#) calls, respectively.

#### Parameters

in	string	Format string, followed by additional arguments
----	--------	---

#### 10.71.2.2 [OS\\_printf\\_disable\(\)](#)

```
void void OS_printf_disable (
    void
)
```

This function disables the output from OS\_printf.

#### 10.71.2.3 OS\_printf\_enable()

```
void OS_printf_enable (
    void )
```

This function enables the output from OS\_printf.

## 10.72 OSAL Message Queue APIs

### Functions

- `int32 OS_QueueCreate (osal_id_t *queue_id, const char *queue_name, osal_blockcount_t queue_depth, size_t data_size, uint32 flags)`

*Create a message queue.*
- `int32 OS_QueueDelete (osal_id_t queue_id)`

*Deletes the specified message queue.*
- `int32 OS_QueueGet (osal_id_t queue_id, void *data, size_t size, size_t *size_copied, int32 timeout)`

*Receive a message on a message queue.*
- `int32 OS_QueuePut (osal_id_t queue_id, const void *data, size_t size, uint32 flags)`

*Put a message on a message queue.*
- `int32 OS_QueueGetIdByName (osal_id_t *queue_id, const char *queue_name)`

*Find an existing queue ID by name.*
- `int32 OS_QueueGetInfo (osal_id_t queue_id, OS_queue_prop_t *queue_prop)`

*Fill a property object buffer with details regarding the resource.*

### 10.72.1 Detailed Description

### 10.72.2 Function Documentation

#### 10.72.2.1 OS\_QueueCreate()

```
int32 OS_QueueCreate (
    osal_id_t * queue_id,
    const char * queue_name,
    osal_blockcount_t queue_depth,
    size_t data_size,
    uint32 flags )
```

Create a message queue.

This is the function used to create a queue in the operating system. Depending on the underlying operating system, the memory for the queue will be allocated automatically or allocated by the code that sets up the queue. Queue names must be unique; if the name already exists this function fails. Names cannot be NULL.

### Parameters

out	<code>queue_id</code>	will be set to the non-zero ID of the newly-created resource (must not be null)
in	<code>queue_name</code>	the name of the new resource to create (must not be null)
in	<code>queue_depth</code>	the maximum depth of the queue
in	<code>data_size</code>	the size of each entry in the queue (must not be zero)
in	<code>flags</code>	options for the queue (reserved for future use, pass as 0)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if a pointer passed in is NULL
<i>OS_ERR_NAME_TOO_LONG</i>	name length including null terminator greater than <i>OS_MAX_API_NAME</i>
<i>OS_ERR_NO_FREE_IDS</i>	if there are already the max queues created
<i>OS_ERR_NAME_TAKEN</i>	if the name is already being used on another queue
<i>OS_ERR_INVALID_SIZE</i>	if data_size is 0
<i>OS_QUEUE_INVALID_SIZE</i>	if the queue depth exceeds the limit
<i>OS_ERROR</i>	if the OS create call fails

**10.72.2.2 OS\_QueueDelete()**

```
int32 OS_QueueDelete (
    osal_id_t queue_id )
```

Deletes the specified message queue.

This is the function used to delete a queue in the operating system. This also frees the respective queue\_id to be used again when another queue is created.

**Note**

If There are messages on the queue, they will be lost and any subsequent calls to QueueGet or QueuePut to this queue will result in errors

**Parameters**

in	<i>queue_id</i>	The object ID to delete
----	-----------------	-------------------------

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the id passed in does not exist
<i>OS_ERROR</i>	if the OS call returns an unexpected error (return value only verified in coverage test)

### 10.72.2.3 OS\_QueueGet()

```
int32 OS_QueueGet (
    osal_id_t queue_id,
    void * data,
    size_t size,
    size_t * size_copied,
    int32 timeout )
```

Receive a message on a message queue.

If a message is pending, it is returned immediately. Otherwise the calling task will block until a message arrives or the timeout expires.

#### Parameters

in	<i>queue_id</i>	The object ID to operate on
out	<i>data</i>	The buffer to store the received message (must not be null)
in	<i>size</i>	The size of the data buffer (must not be zero)
out	<i>size_copied</i>	Set to the actual size of the message (must not be null)
in	<i>timeout</i>	The maximum amount of time to block, or OS_PEND to wait forever

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#"><i>OS_SUCCESS</i></a>	Successful execution.
<a href="#"><i>OS_ERR_INVALID_ID</i></a>	if the given ID does not exist
<a href="#"><i>OS_INVALID_POINTER</i></a>	if a pointer passed in is NULL
<a href="#"><i>OS_QUEUE_EMPTY</i></a>	if the Queue has no messages on it to be received
<a href="#"><i>OS_QUEUE_TIMEOUT</i></a>	if the timeout was OS_PEND and the time expired
<a href="#"><i>OS_QUEUE_INVALID_SIZE</i></a>	if the size copied from the queue was not correct
<a href="#"><i>OS_ERROR</i></a>	if the OS call returns an unexpected error (return value only verified in coverage test)

### 10.72.2.4 OS\_QueueGetIdByName()

```
int32 OS_QueueGetIdByName (
    osal_id_t * queue_id,
    const char * queue_name )
```

Find an existing queue ID by name.

This function tries to find a queue Id given the name of the queue. The id of the queue is passed back in *queue\_id*.

**Parameters**

<i>out</i>	<i>queue_id</i>	will be set to the ID of the existing resource
<i>in</i>	<i>queue_name</i>	the name of the existing resource to find (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<a href="#"><i>OS_SUCCESS</i></a>	Successful execution.
<a href="#"><i>OS_INVALID_POINTER</i></a>	if the name or id pointers are NULL
<a href="#"><i>OS_ERR_NAME_TOO_LONG</i></a>	name length including null terminator greater than <a href="#"><i>OS_MAX_API_NAME</i></a>
<a href="#"><i>OS_ERR_NAME_NOT_FOUND</i></a>	the name was not found in the table

**10.72.2.5 OS\_QueueGetInfo()**

```
int32 OS_QueueGetInfo (
    osal_id_t queue_id,
    OS_queue_prop_t * queue_prop )
```

Fill a property object buffer with details regarding the resource.

This function will pass back a pointer to structure that contains all of the relevant info (name and creator) about the specified queue.

**Parameters**

<i>in</i>	<i>queue_id</i>	The object ID to operate on
<i>out</i>	<i>queue_prop</i>	The property object buffer to fill (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<a href="#"><i>OS_SUCCESS</i></a>	Successful execution.
<a href="#"><i>OS_INVALID_POINTER</i></a>	if queue_prop is NULL
<a href="#"><i>OS_ERR_INVALID_ID</i></a>	if the ID given is not a valid queue

### 10.72.2.6 OS\_QueuePut()

```
int32 OS_QueuePut (
    osal_id_t queue_id,
    const void * data,
    size_t size,
    uint32 flags )
```

Put a message on a message queue.

#### Parameters

in	<i>queue_id</i>	The object ID to operate on
in	<i>data</i>	The buffer containing the message to put (must not be null)
in	<i>size</i>	The size of the data buffer (must not be zero)
in	<i>flags</i>	Currently reserved/unused, should be passed as 0

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#"><i>OS_SUCCESS</i></a>	Successful execution.
<a href="#"><i>OS_ERR_INVALID_ID</i></a>	if the queue id passed in is not a valid queue
<a href="#"><i>OS_INVALID_POINTER</i></a>	if the data pointer is NULL
<a href="#"><i>OS_QUEUE_INVALID_SIZE</i></a>	if the data message is too large for the queue
<a href="#"><i>OS_QUEUE_FULL</i></a>	if the queue cannot accept another message
<a href="#"><i>OS_ERROR</i></a>	if the OS call returns an unexpected error (return value only verified in coverage test)

## 10.73 OSAL Select APIs

### Functions

- `int32 OS_SelectMultiple (OS_FdSet *ReadSet, OS_FdSet *WriteSet, int32 msecs)`  
*Wait for events across multiple file handles.*
- `int32 OS_SelectSingle (osal_id_t objid, uint32 *StateFlags, int32 msecs)`  
*Wait for events on a single file handle.*
- `int32 OS_SelectFdZero (OS_FdSet *Set)`  
*Clear a FdSet structure.*
- `int32 OS_SelectFdAdd (OS_FdSet *Set, osal_id_t objid)`  
*Add an ID to an FdSet structure.*
- `int32 OS_SelectFdClear (OS_FdSet *Set, osal_id_t objid)`  
*Clear an ID from an FdSet structure.*
- `bool OS_SelectFdIsSet (const OS_FdSet *Set, osal_id_t objid)`  
*Check if an FdSet structure contains a given ID.*

### 10.73.1 Detailed Description

### 10.73.2 Function Documentation

#### 10.73.2.1 OS\_SelectFdAdd()

```
int32 OS_SelectFdAdd (
    OS_FdSet * Set,
    osal_id_t objid )
```

Add an ID to an FdSet structure.

After this call the set will contain the given OSAL ID

#### Parameters

in, out	<code>Set</code>	Pointer to <code>OS_FdSet</code> object to operate on (must not be null)
in	<code>objid</code>	The handle ID to add to the set

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<code>OS_SUCCESS</code>	Successful execution.
<code>OS_INVALID_POINTER</code>	if argument is NULL
<code>OS_ERR_INVALID_ID</code>	if the objid is not a valid handle

### 10.73.2.2 OS\_SelectFdClear()

```
int32 OS_SelectFdClear (
    OS_FdSet * Set,
    osal_id_t objid )
```

Clear an ID from an FdSet structure.

After this call the set will no longer contain the given OSAL ID

#### Parameters

in, out	<i>Set</i>	Pointer to <a href="#">OS_FdSet</a> object to operate on (must not be null)
in	<i>objid</i>	The handle ID to remove from the set

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_INVALID_POINTER</a>	if argument is NULL
<a href="#">OS_ERR_INVALID_ID</a>	if the objid is not a valid handle

### 10.73.2.3 OS\_SelectFdIsSet()

```
bool OS_SelectFdIsSet (
    const OS_FdSet * Set,
    osal_id_t objid )
```

Check if an FdSet structure contains a given ID.

#### Parameters

in	<i>Set</i>	Pointer to <a href="#">OS_FdSet</a> object to operate on (must not be null)
in	<i>objid</i>	The handle ID to check for in the set

#### Returns

Boolean set status

**Return values**

<i>true</i>	FdSet structure contains ID
<i>false</i>	FDSet structure does not contain ID

**10.73.2.4 OS\_SelectFdZero()**

```
int32 OS_SelectFdZero (
    OS_FdSet * Set )
```

Clear a FdSet structure.

After this call the set will contain no OSAL IDs

**Parameters**

<i>out</i>	<i>Set</i>	Pointer to <a href="#">OS_FdSet</a> object to clear (must not be null)
------------	------------	--

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_INVALID_POINTER</a>	if argument is NULL

**10.73.2.5 OS\_SelectMultiple()**

```
int32 OS_SelectMultiple (
    OS_FdSet * ReadSet,
    OS_FdSet * WriteSet,
    int32 msec )
```

Wait for events across multiple file handles.

Wait for any of the given sets of IDs to become readable or writable

This function will block until any of the following occurs:

- At least one OSAL ID in the ReadSet is readable
- At least one OSAL ID in the WriteSet is writable

- The timeout has elapsed

The sets are input/output parameters. On entry, these indicate the file handle(s) to wait for. On exit, these are set to the actual file handle(s) that have activity.

If the timeout occurs this returns an error code and all output sets should be empty.

#### Note

This does not lock or otherwise protect the file handles in the given sets. If a filehandle supplied via one of the FdSet arguments is closed or modified by another while this function is in progress, the results are undefined. Because of this limitation, it is recommended to use [OS\\_SelectSingle\(\)](#) whenever possible.

#### Parameters

<i>in, out</i>	<i>ReadSet</i>	Set of handles to check/wait to become readable
<i>in, out</i>	<i>WriteSet</i>	Set of handles to check/wait to become writable
<i>in</i>	<i>msecs</i>	Indicates the timeout. Positive values will wait up to that many milliseconds. Zero will not wait (poll). Negative values will wait forever (pend)

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#">OS_SUCCESS</a>	If any handle in the ReadSet or WriteSet is readable or writable, respectively
<a href="#">OS_ERROR_TIMEOUT</a>	If no handles in the ReadSet or WriteSet became readable or writable within the timeout
<a href="#">OS_ERR_OPERATION_NOT_SUPPORTED</a>	if a specified handle does not support select
<a href="#">OS_ERR_INVALID_ID</a>	if no valid handles were contained in the ReadSet/WriteSet

#### 10.73.2.6 OS\_SelectSingle()

```
int32 OS_SelectSingle (
    osal_id_t objid,
    uint32 * StateFlags,
    int32 msecs )
```

Wait for events on a single file handle.

Wait for a single OSAL filehandle to change state

This function can be used to wait for a single OSAL stream ID to become readable or writable. On entry, the "StateFlags" parameter should be set to the desired state (OS\_STREAM\_STATE\_READABLE and/or OS\_STREAM\_STATE\_WRITABLE) and upon return the flags will be set to the state actually detected.

As this operates on a single ID, the filehandle is protected during this call, such that another thread accessing the same handle will return an error. However, it is important to note that once the call returns then other threads may then also read/write and affect the state before the current thread can service it.

To mitigate this risk the application may prefer to use the OS\_TimedRead/OS\_TimedWrite calls.

#### Parameters

in	<i>objid</i>	The handle ID to select on
in, out	<i>StateFlags</i>	State flag(s) (readable or writable) (must not be null)
in	<i>msecs</i>	Indicates the timeout. Positive values will wait up to that many milliseconds. Zero will not wait (poll). Negative values will wait forever (pend)

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#"><i>OS_SUCCESS</i></a>	If the handle is readable and/or writable, as requested
<a href="#"><i>OS_ERROR_TIMEOUT</i></a>	If the handle did not become readable or writable within the timeout
<a href="#"><i>OS_INVALID_POINTER</i></a>	if argument is NULL
<a href="#"><i>OS_ERR_INVALID_ID</i></a>	if the objid is not a valid handle

## 10.74 OSAL Shell APIs

### Functions

- `int32 OS_ShellOutputToFile (const char *Cmd, osal_id_t filedes)`

*Executes the command and sends output to a file.*

#### 10.74.1 Detailed Description

#### 10.74.2 Function Documentation

##### 10.74.2.1 OS\_ShellOutputToFile()

```
int32 OS_ShellOutputToFile (
    const char * Cmd,
    osal_id_t filedes )
```

Executes the command and sends output to a file.

Takes a shell command in and writes the output of that command to the specified file. The output file must be opened previously with write access (OS\_WRITE\_ONLY or OS\_READ\_WRITE).

#### Parameters

in	<i>Cmd</i>	Command to pass to shell (must not be null)
in	<i>filedes</i>	File to send output to.

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<code>OS_SUCCESS</code>	Successful execution.
<code>OS_ERROR</code>	if the command was not executed properly
<code>OS_INVALID_POINTER</code>	if Cmd argument is NULL
<code>OS_ERR_INVALID_ID</code>	if the file descriptor passed in is invalid

## 10.75 OSAL Socket Address APIs

### Functions

- `int32 OS_SocketAddrInit (OS_SockAddr_t *Addr, OS_SocketDomain_t Domain)`  
*Initialize a socket address structure to hold an address of the given family.*
- `int32 OS_SocketAddrToString (char *buffer, size_t buflen, const OS_SockAddr_t *Addr)`  
*Get a string representation of a network host address.*
- `int32 OS_SocketAddrFromString (OS_SockAddr_t *Addr, const char *string)`  
*Set a network host address from a string representation.*
- `int32 OS_SocketAddrGetPort (uint16 *PortNum, const OS_SockAddr_t *Addr)`  
*Get the port number of a network address.*
- `int32 OS_SocketAddrSetPort (OS_SockAddr_t *Addr, uint16 PortNum)`  
*Set the port number of a network address.*

### 10.75.1 Detailed Description

These functions provide a means to manipulate network addresses in a manner that is (mostly) agnostic to the actual network address type.

Every network address should be representable as a string (i.e. dotted decimal IP, etc). This can serve as the "common denominator" to all address types.

### 10.75.2 Function Documentation

#### 10.75.2.1 OS\_SocketAddrFromString()

```
int32 OS_SocketAddrFromString (
    OS_SockAddr_t * Addr,
    const char * string )
```

Set a network host address from a string representation.

The specific format of the output string depends on the address family.

The address structure should have been previously initialized using `OS_SocketAddrInit()` to set the address family type.

#### Note

For IPv4, this would typically be the dotted-decimal format (X.X.X.X). It is up to the discretion of the underlying implementation whether to accept hostnames, as this depends on the availability of DNS services. Since many embedded deployments do not have name services, this should not be relied upon.

**Parameters**

<i>out</i>	<i>Addr</i>	The address buffer to initialize (must not be null)
<i>in</i>	<i>string</i>	The string to initialize the address from (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if argument is NULL
<i>OS_ERROR</i>	if the string cannot be converted to an address

**10.75.2.2 OS\_SocketAddrGetPort()**

```
int32 OS_SocketAddrGetPort (
    uint16 * PortNum,
    const OS_SockAddr_t * Addr )
```

Get the port number of a network address.

For network protocols that have the concept of a port number (such as TCP/IP and UDP/IP) this function gets the port number from the address structure.

**Parameters**

<i>out</i>	<i>PortNum</i>	Buffer to store the port number (must not be null)
<i>in</i>	<i>Addr</i>	The network address buffer (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if argument is NULL
<i>OS_ERR_BAD_ADDRESS</i>	if the address domain is not compatible

### 10.75.2.3 OS\_SocketAddrInit()

```
int32 OS_SocketAddrInit (
    OS_SockAddr_t * Addr,
    OS_SocketDomain_t Domain )
```

Initialize a socket address structure to hold an address of the given family.

The address is set to a suitable default value for the family.

#### Parameters

out	<i>Addr</i>	The address buffer to initialize (must not be null)
in	<i>Domain</i>	The address family

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if Addr argument is NULL
<i>OS_ERR_NOT_IMPLEMENTED</i>	if the system does not implement the requested domain

### 10.75.2.4 OS\_SocketAddrSetPort()

```
int32 OS_SocketAddrSetPort (
    OS_SockAddr_t * Addr,
    uint16 PortNum )
```

Set the port number of a network address.

For network protocols that have the concept of a port number (such as TCP/IP and UDP/IP) this function sets the port number from the address structure.

#### Parameters

out	<i>Addr</i>	The network address buffer (must not be null)
in	<i>PortNum</i>	The port number to set

#### Returns

Execution status, see [OSAL Return Code Defines](#)

### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if argument is NULL
<i>OS_ERR_BAD_ADDRESS</i>	if the address domain is not compatible

### 10.75.2.5 OS\_SocketAddrToString()

```
int32 OS_SocketAddrToString (
    char * buffer,
    size_t buflen,
    const OS_SockAddr_t * Addr )
```

Get a string representation of a network host address.

The specific format of the output string depends on the address family.

This string should be suitable to pass back into [OS\\_SocketAddrFromString\(\)](#) which should recreate the same network address, and it should also be meaningful to a user of printed or logged as a C string.

#### Note

For IPv4, this would typically be the dotted-decimal format (X.X.X.X).

### Parameters

out	<i>buffer</i>	Buffer to hold the output string (must not be null)
in	<i>buflen</i>	Maximum length of the output string (must not be zero)
in	<i>Addr</i>	The network address buffer to convert (must not be null)

### Returns

Execution status, see [OSAL Return Code Defines](#)

### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if argument is NULL
<i>OS_ERR_INVALID_SIZE</i>	if passed-in buflen is not valid
<i>OS_ERROR</i>	if the address cannot be converted to string, or string buffer too small

## 10.76 OSAL Socket Management APIs

### Functions

- `int32 OS_SocketOpen (osal_id_t *sock_id, OS_SocketDomain_t Domain, OS_SocketType_t Type)`  
*Opens a socket.*
- `int32 OS_SocketBind (osal_id_t sock_id, const OS_SockAddr_t *Addr)`  
*Binds a socket to a given local address.*
- `int32 OS_SocketConnect (osal_id_t sock_id, const OS_SockAddr_t *Addr, int32 timeout)`  
*Connects a socket to a given remote address.*
- `int32 OS_SocketShutdown (osal_id_t sock_id, OS_SocketShutdownMode_t Mode)`  
*Implement graceful shutdown of a stream socket.*
- `int32 OS_SocketAccept (osal_id_t sock_id, osal_id_t *connsock_id, OS_SockAddr_t *Addr, int32 timeout)`  
*Waits for and accept the next incoming connection on the given socket.*
- `int32 OS_SocketRecvFrom (osal_id_t sock_id, void *buffer, size_t buflen, OS_SockAddr_t *RemoteAddr, int32 timeout)`  
*Reads data from a message-oriented (datagram) socket.*
- `int32 OS_SocketSendTo (osal_id_t sock_id, const void *buffer, size_t buflen, const OS_SockAddr_t *RemoteAddr)`  
*Sends data to a message-oriented (datagram) socket.*
- `int32 OS_SocketGetIdByName (osal_id_t *sock_id, const char *sock_name)`  
*Gets an OSAL ID from a given name.*
- `int32 OS_SocketGetInfo (osal_id_t sock_id, OS_socket_prop_t *sock_prop)`  
*Gets information about an OSAL Socket ID.*

### 10.76.1 Detailed Description

These functions are loosely related to the BSD Sockets API but made to be more consistent with other OSAL API functions. That is, they operate on OSAL IDs (32-bit opaque number values) and return an OSAL error code.

OSAL Socket IDs are very closely related to File IDs and share the same ID number space. Additionally, the file `OS←read() / OS_write() / OS_close()` calls also work on sockets.

Note that all of functions may return `OS_ERR_NOT_IMPLEMENTED` if network support is not configured at compile time.

### 10.76.2 Function Documentation

### 10.76.2.1 OS\_SocketAccept()

```
int32 OS_SocketAccept (
    osal_id_t sock_id,
    osal_id_t * connsock_id,
    OS_SockAddr_t * Addr,
    int32 timeout )
```

Waits for and accept the next incoming connection on the given socket.

This is used for sockets operating in a "server" role. The socket must be a stream type (connection-oriented) and previously bound to a local address using [OS\\_SocketBind\(\)](#). This will block the caller up to the given timeout or until an incoming connection request occurs, whichever happens first.

The new stream connection is then returned to the caller and the original server socket ID can be reused for the next connection.

**Parameters**

in	<i>sock_id</i>	The server socket ID, previously bound using <a href="#">OS_SocketBind()</a>
out	<i>connsock_id</i>	The connection socket, a new ID that can be read/written (must not be null)
in	<i>Addr</i>	The remote address of the incoming connection (must not be null)
in	<i>timeout</i>	The maximum amount of time to wait, or OS_PEND to wait forever

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_INVALID_POINTER</a>	if argument is NULL
<a href="#">OS_ERR_INVALID_ID</a>	if the <i>sock_id</i> parameter is not valid
<a href="#">OS_ERR_INCORRECT_OBJ_TYPE</a>	if the handle is not a socket
<a href="#">OS_ERR_INCORRECT_OBJ_STATE</a>	if the socket is not bound or already connected

**10.76.2.2 OS\_SocketBind()**

```
int32 OS_SocketBind (
    osal_id_t sock_id,
    const OS_SockAddr_t * Addr )
```

Binds a socket to a given local address.

The specified socket will be bound to the local address and port, if available.

If the socket is connectionless, then it only binds to the local address.

If the socket is connection-oriented (stream), then this will also put the socket into a listening state for incoming connections at the local address.

**Parameters**

in	<i>sock_id</i>	The socket ID
in	<i>Addr</i>	The local address to bind to (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the <i>sock_id</i> parameter is not valid
<i>OS_INVALID_POINTER</i>	if argument is NULL
<i>OS_ERR_INCORRECT_OBJ_STATE</i>	if the socket is already bound
<i>OS_ERR_INCORRECT_OBJ_TYPE</i>	if the handle is not a socket

### 10.76.2.3 OS\_SocketConnect()

```
int32 OS_SocketConnect (
    osal_id_t sock_id,
    const OS_SockAddr_t * Addr,
    int32 timeout )
```

Connects a socket to a given remote address.

The socket will be connected to the remote address and port, if available. This only applies to stream-oriented sockets. Calling this on a datagram socket will return an error (these sockets should use SendTo/RecvFrom).

### Parameters

in	<i>sock_id</i>	The socket ID
in	<i>Addr</i>	The remote address to connect to (must not be null)
in	<i>timeout</i>	The maximum amount of time to wait, or OS_PEND to wait forever

### Returns

Execution status, see [OSAL Return Code Defines](#)

### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INCORRECT_OBJ_STATE</i>	if the socket is already connected
<i>OS_ERR_INVALID_ID</i>	if the <i>sock_id</i> parameter is not valid
<i>OS_ERR_INCORRECT_OBJ_TYPE</i>	if the handle is not a socket
<i>OS_INVALID_POINTER</i>	if <i>Addr</i> argument is NULL

### 10.76.2.4 OS\_SocketGetIdByName()

```
int32 OS_SocketGetIdByName (
    osal_id_t * sock_id,
    const char * sock_name )
```

Gets an OSAL ID from a given name.

#### Note

OSAL Sockets use generated names according to the address and type.

#### See also

[OS\\_SocketGetInfo\(\)](#)

#### Parameters

out	<i>sock_id</i>	Buffer to hold result (must not be null)
in	<i>sock_name</i>	Name of socket to find (must not be null)

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	is id or name are NULL pointers
<i>OS_ERR_NAME_TOO_LONG</i>	name length including null terminator greater than <a href="#">OS_MAX_API_NAME</a>
<i>OS_ERR_NAME_NOT_FOUND</i>	if the name was not found in the table

### 10.76.2.5 OS\_SocketGetInfo()

```
int32 OS_SocketGetInfo (
    osal_id_t sock_id,
    OS_socket_prop_t * sock_prop )
```

Gets information about an OSAL Socket ID.

OSAL Sockets use generated names according to the address and type. This allows applications to find the name of a given socket.

#### Parameters

in	<i>sock_id</i>	The socket ID
out	<i>sock_prop</i>	Buffer to hold socket information (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the id passed in is not a valid semaphore
<i>OS_INVALID_POINTER</i>	if the count_prop pointer is null

**10.76.2.6 OS\_SocketOpen()**

```
int32 OS_SocketOpen (
    osal_id_t * sock_id,
    OS_SocketDomain_t Domain,
    OS_SocketType_t Type )
```

Opens a socket.

A new, unconnected and unbound socket is allocated of the given domain and type.

**Parameters**

out	<i>sock_id</i>	Buffer to hold the non-zero OSAL ID (must not be null)
in	<i>Domain</i>	The domain / address family of the socket (INET or INET6, etc)
in	<i>Type</i>	The type of the socket (STREAM or DATAGRAM)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if argument is NULL
<i>OS_ERR_NOT_IMPLEMENTED</i>	if the system does not implement the requested socket/address domain

**10.76.2.7 OS\_SocketRecvFrom()**

```
int32 OS_SocketRecvFrom (
    osal_id_t sock_id,
```

```
void * buffer,
size_t buflen,
OS_SockAddr_t * RemoteAddr,
int32 timeout )
```

Reads data from a message-oriented (datagram) socket.

If a message is already available on the socket, this should immediately return that data without blocking. Otherwise, it may block up to the given timeout.

#### Parameters

in	<i>sock_id</i>	The socket ID, previously bound using <a href="#">OS_SocketBind()</a>
out	<i>buffer</i>	Pointer to message data receive buffer (must not be null)
in	<i>buflen</i>	The maximum length of the message data to receive (must not be zero)
out	<i>RemoteAddr</i>	Buffer to store the remote network address (may be NULL)
in	<i>timeout</i>	The maximum amount of time to wait, or OS_PEND to wait forever

#### Returns

Count of actual bytes received or error status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#"><i>OS_INVALID_POINTER</i></a>	if argument is NULL
<a href="#"><i>OS_ERR_INVALID_SIZE</i></a>	if passed-in buflen is not valid
<a href="#"><i>OS_ERR_INVALID_ID</i></a>	if the <i>sock_id</i> parameter is not valid
<a href="#"><i>OS_ERR_INCORRECT_OBJ_TYPE</i></a>	if the handle is not a socket

#### 10.76.2.8 OS\_SocketSendTo()

```
int32 OS_SocketSendTo (
    osal_id_t sock_id,
    const void * buffer,
    size_t buflen,
    const OS_SockAddr_t * RemoteAddr )
```

Sends data to a message-oriented (datagram) socket.

This sends data in a non-blocking mode. If the socket is not currently able to queue the message, such as if its outbound buffer is full, then this returns an error code.

#### Parameters

in	<i>sock_id</i>	The socket ID, which must be of the datagram type
in	<i>buffer</i>	Pointer to message data to send (must not be null)
in	<i>buflen</i>	The length of the message data to send (must not be zero)
in	<i>RemoteAddr</i>	Buffer containing the remote network address to send to

**Returns**

Count of actual bytes sent or error status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_INVALID_POINTER</i>	if argument is NULL
<i>OS_ERR_INVALID_SIZE</i>	if passed-in buflen is not valid
<i>OS_ERR_INVALID_ID</i>	if the sock_id parameter is not valid
<i>OS_ERR_INCORRECT_OBJ_TYPE</i>	if the handle is not a socket

**10.76.2.9 OS\_SocketShutdown()**

```
int32 OS_SocketShutdown (
    osal_id_t sock_id,
    OS_SocketShutdownMode_t Mode )
```

Implement graceful shutdown of a stream socket.

This can be utilized to indicate the end of data stream without immediately closing the socket, giving the remote side an indication that the data transfer is complete.

**Parameters**

in	<i>sock_id</i>	The socket ID
in	<i>Mode</i>	Whether to shutdown reading, writing, or both.

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the sock_id parameter is not valid
<i>OS_ERR_INVALID_ARGUMENT</i>	if the Mode argument is not one of the valid options
<i>OS_ERR_INCORRECT_OBJ_TYPE</i>	if the handle is not a socket
<i>OS_ERR_INCORRECT_OBJ_STATE</i>	if the socket is not connected

## 10.77 OSAL Task APIs

### Functions

- `int32 OS_TaskCreate (osal_id_t *task_id, const char *task_name, osal_task_entry function_pointer, osal_stackptr_t stack_pointer, size_t stack_size, osal_priority_t priority, uint32 flags)`  
*Creates a task and starts running it.*
- `int32 OS_TaskDelete (osal_id_t task_id)`  
*Deletes the specified Task.*
- `void OS_TaskExit (void)`  
*Exits the calling task.*
- `int32 OS_TaskInstallDeleteHandler (osal_task_entry function_pointer)`  
*Installs a handler for when the task is deleted.*
- `int32 OS_TaskDelay (uint32 millisecond)`  
*Delay a task for specified amount of milliseconds.*
- `int32 OS_TaskSetPriority (osal_id_t task_id, osal_priority_t new_priority)`  
*Sets the given task to a new priority.*
- `osal_id_t OS_TaskGetId (void)`  
*Obtain the task id of the calling task.*
- `int32 OS_TaskGetIdByName (osal_id_t *task_id, const char *task_name)`  
*Find an existing task ID by name.*
- `int32 OS_TaskGetInfo (osal_id_t task_id, OS_task_prop_t *task_prop)`  
*Fill a property object buffer with details regarding the resource.*
- `int32 OS_TaskFindIdBySystemData (osal_id_t *task_id, const void *sysdata, size_t sysdata_size)`  
*Reverse-lookup the OSAL task ID from an operating system ID.*

### 10.77.1 Detailed Description

### 10.77.2 Function Documentation

#### 10.77.2.1 OS\_TaskCreate()

```
int32 OS_TaskCreate (
    osal_id_t * task_id,
    const char * task_name,
    osal_task_entry function_pointer,
    osal_stackptr_t stack_pointer,
    size_t stack_size,
    osal_priority_t priority,
    uint32 flags )
```

Creates a task and starts running it.

Creates a task and passes back the id of the task created. Task names must be unique; if the name already exists this function fails. Names cannot be NULL.

Portable applications should always specify the actual stack size in the stack\_size parameter, not 0. This size value is not enforced/checked by OSAL, but is simply passed through to the RTOS for stack creation. Some RTOS implementations may assume 0 means a default stack size while others may actually create a task with no stack.

Unlike stack\_size, the stack\_pointer is optional and can be specified as NULL. In that case, a stack of the requested size will be dynamically allocated from the system heap.

**Parameters**

out	<i>task_id</i>	will be set to the non-zero ID of the newly-created resource (must not be null)
in	<i>task_name</i>	the name of the new resource to create (must not be null)
in	<i>function_pointer</i>	the entry point of the new task (must not be null)
in	<i>stack_pointer</i>	pointer to the stack for the task, or NULL to allocate a stack from the system memory heap
in	<i>stack_size</i>	the size of the stack (must not be zero)
in	<i>priority</i>	initial priority of the new task
in	<i>flags</i>	initial options for the new task

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_INVALID_POINTER</a>	if any of the necessary pointers are NULL
<a href="#">OS_ERR_INVALID_SIZE</a>	if the stack_size argument is zero
<a href="#">OS_ERR_NAME_TOO_LONG</a>	name length including null terminator greater than <a href="#">OS_MAX_API_NAME</a>
<a href="#">OS_ERR_INVALID_PRIORITY</a>	if the priority is bad (return value only verified in coverage test)
<a href="#">OS_ERR_NO_FREE_IDS</a>	if there can be no more tasks created
<a href="#">OS_ERR_NAME_TAKEN</a>	if the name specified is already used by a task
<a href="#">OS_ERROR</a>	if an unspecified/other error occurs (return value only verified in coverage test)

**10.77.2.2 OS\_TaskDelay()**

```
int32 OS_TaskDelay (
    uint32 millisecond )
```

Delay a task for specified amount of milliseconds.

Causes the current thread to be suspended from execution for the period of millisecond. This is a scheduled wait (clock\_nanosleep/rtems\_task\_wake\_after/taskDelay), not a "busy" wait.

**Parameters**

in	<i>millisecond</i>	Amount of time to delay
----	--------------------	-------------------------

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERROR</i>	if an unspecified/other error occurs (return value only verified in coverage test)

**10.77.2.3 OS\_TaskDelete()**

```
int32 OS_TaskDelete (
    osal_id_t task_id )
```

Deletes the specified Task.

The task will be removed from the local tables. and the OS will be configured to stop executing the task at the next opportunity.

**Parameters**

in	<i>task_id</i>	The object ID to operate on
----	----------------	-----------------------------

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the ID given to it is invalid
<i>OS_ERROR</i>	if the OS delete call fails (return value only verified in coverage test)

**10.77.2.4 OS\_TaskExit()**

```
void OS_TaskExit (
    void )
```

Exits the calling task.

The calling thread is terminated. This function does not return.

### 10.77.2.5 OS\_TaskFindIdBySystemData()

```
int32 OS_TaskFindIdBySystemData (
    osal_id_t * task_id,
    const void * sysdata,
    size_t sysdata_size )
```

Reverse-lookup the OSAL task ID from an operating system ID.

This provides a method by which an external entity may find the OSAL task ID corresponding to a system-defined identifier (e.g. TASK\_ID, pthread\_t, rtems\_id, etc).

Normally OSAL does not expose the underlying OS-specific values to the application, but in some circumstances, such as exception handling, the OS may provide this information directly to a BSP handler outside of the normal OSAL API.

#### Parameters

out	<i>task_id</i>	The buffer where the task id output is stored (must not be null)
in	<i>sysdata</i>	Pointer to the system-provided identification data
in	<i>sysdata_size</i>	Size of the system-provided identification data

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#"><i>OS_SUCCESS</i></a>	Successful execution. (return value only verified in coverage test)
<a href="#"><i>OS_INVALID_POINTER</i></a>	if a pointer argument is NULL

### 10.77.2.6 OS\_TaskGetId()

```
osal_id_t OS_TaskGetId (
    void )
```

Obtain the task id of the calling task.

This function returns the task id of the calling task

#### Returns

Task ID, or zero if the operation failed (zero is never a valid task ID)

### 10.77.2.7 OS\_TaskGetIdByName()

```
int32 OS_TaskGetIdByName (
    osal_id_t * task_id,
    const char * task_name )
```

Find an existing task ID by name.

This function tries to find a task Id given the name of a task

#### Parameters

out	<i>task_id</i>	will be set to the ID of the existing resource
in	<i>task_name</i>	the name of the existing resource to find (must not be null)

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if the pointers passed in are NULL
<i>OS_ERR_NAME_TOO_LONG</i>	name length including null terminator greater than <i>OS_MAX_API_NAME</i>
<i>OS_ERR_NAME_NOT_FOUND</i>	if the name wasn't found in the table

### 10.77.2.8 OS\_TaskGetInfo()

```
int32 OS_TaskGetInfo (
    osal_id_t task_id,
    OS_task_prop_t * task_prop )
```

Fill a property object buffer with details regarding the resource.

This function will pass back a pointer to structure that contains all of the relevant info (creator, stack size, priority, name) about the specified task.

#### Parameters

in	<i>task_id</i>	The object ID to operate on
out	<i>task_prop</i>	The property object buffer to fill (must not be null)

#### Returns

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the ID passed to it is invalid
<i>OS_INVALID_POINTER</i>	if the task_prop pointer is NULL

**10.77.2.9 OS\_TaskInstallDeleteHandler()**

```
int32 OS_TaskInstallDeleteHandler (
    osal_task_entry function_pointer )
```

Installs a handler for when the task is deleted.

This function is used to install a callback that is called when the task is deleted. The callback is called when OS\_TaskDelete is called with the task ID. A task delete handler is useful for cleaning up resources that a task creates, before the task is removed from the system.

**Parameters**

in	<i>function_pointer</i>	function to be called when task exits
----	-------------------------	---------------------------------------

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_ERR_INVALID_ID</i>	if the calling context is not an OSAL task
--------------------------	--

**10.77.2.10 OS\_TaskSetPriority()**

```
int32 OS_TaskSetPriority (
    osal_id_t task_id,
    osal_priority_t new_priority )
```

Sets the given task to a new priority.

**Parameters**

in	<i>task_id</i>	The object ID to operate on
in	<i>new_priority</i>	Set the new priority

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the ID passed to it is invalid
<i>OS_ERR_INVALID_PRIORITY</i>	if the priority is greater than the max allowed (return value only verified in coverage test)
<i>OS_ERROR</i>	if an unspecified/other error occurs (return value only verified in coverage test)

## 10.78 OSAL Time Base APIs

### Functions

- `int32 OS_TimeBaseCreate (osal_id_t *timebase_id, const char *timebase_name, OS_TimerSync_t external_sync)`  
*Create an abstract Time Base resource.*
- `int32 OS_TimeBaseSet (osal_id_t timebase_id, uint32 start_time, uint32 interval_time)`  
*Sets the tick period for simulated time base objects.*
- `int32 OS_TimeBaseDelete (osal_id_t timebase_id)`  
*Deletes a time base object.*
- `int32 OS_TimeBaseGetIdByName (osal_id_t *timebase_id, const char *timebase_name)`  
*Find the ID of an existing time base resource.*
- `int32 OS_TimeBaseGetInfo (osal_id_t timebase_id, OS_timebase_prop_t *timebase_prop)`  
*Obtain information about a timebase resource.*
- `int32 OS_TimeBaseGetFreeRun (osal_id_t timebase_id, uint32 *freerun_val)`  
*Read the value of the timebase free run counter.*

### 10.78.1 Detailed Description

### 10.78.2 Function Documentation

#### 10.78.2.1 OS\_TimeBaseCreate()

```
int32 OS_TimeBaseCreate (
    osal_id_t * timebase_id,
    const char * timebase_name,
    OS_TimerSync_t external_sync )
```

Create an abstract Time Base resource.

An OSAL time base is an abstraction of a "timer tick" that can, in turn, be used for measurement of elapsed time between events.

Time bases can be simulated by the operating system using the OS kernel-provided timing facilities, or based on a hardware timing source if provided by the BSP.

A time base object has a servicing task associated with it, that runs at elevated priority and will thereby interrupt user-level tasks when timing ticks occur.

If the `external_sync` function is passed as `NULL`, the operating system kernel timing resources will be utilized for a simulated timer tick.

If the `external_sync` function is not `NULL`, this should point to a BSP-provided function that will block the calling task until the next tick occurs. This can be used for synchronizing with hardware events.

#### Note

When provisioning a tunable RTOS kernel, such as RTEMS, the kernel should be configured to support at least `(OS_MAX_TASKS + OS_MAX_TIMEBASES)` threads, to account for the helper threads associated with time base objects.

This configuration API must not be used from the context of a timer callback. Timers should only be configured from the context of normal OSAL tasks.

**Parameters**

out	<i>timebase_id</i>	will be set to the non-zero ID of the newly-created resource (must not be null)
in	<i>timebase_name</i>	The name of the time base (must not be null)
in	<i>external_sync</i>	A synchronization function for BSP hardware-based timer ticks

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_NAME_TAKEN</i>	if the name specified is already used
<i>OS_ERR_NO_FREE_IDS</i>	if there can be no more timebase resources created
<i>OS_ERR_INCORRECT_OBJ_STATE</i>	if called from timer/timebase context
<i>OS_ERR_NAME_TOO_LONG</i>	if the timebase_name is too long
<i>OS_INVALID_POINTER</i>	if a pointer argument is NULL

**10.78.2.2 OS\_TimeBaseDelete()**

```
int32 OS_TimeBaseDelete (
    osal_id_t timebase_id )
```

Deletes a time base object.

The helper task and any other resources associated with the time base abstraction will be freed.

**Note**

This configuration API must not be used from the context of a timer callback. Timers should only be configured from the context of normal OSAL tasks.

**Parameters**

in	<i>timebase_id</i>	The timebase resource to delete
----	--------------------	---------------------------------

**Returns**

Execution status, see [OSAL Return Code Defines](#)

### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the id passed in is not a valid timebase
<i>OS_ERR_INCORRECT_OBJ_STATE</i>	if called from timer/timebase context

### 10.78.2.3 OS\_TimeBaseGetFreeRun()

```
int32 OS_TimeBaseGetFreeRun (
    osal_id_t timebase_id,
    uint32 * freerun_val )
```

Read the value of the timebase free run counter.

Poll the timer free-running time counter in a lightweight fashion.

The free run count is a monotonically increasing value reflecting the total time elapsed since the timebase inception. Units are the same as the timebase itself, usually microseconds.

Applications may quickly and efficiently calculate relative time differences by polling this value and subtracting the previous counter value.

The absolute value of this counter is not relevant, because it will "roll over" after  $2^{32}$  units of time. For a timebase with microsecond units, this occurs approximately every 4294 seconds, or about 1.2 hours.

### Note

To ensure consistency of results, the application should sample the value at a minimum of two times the roll over frequency, and calculate the difference between the consecutive samples.

### Parameters

in	<i>timebase_id</i>	The timebase to operate on
out	<i>freerun_val</i>	Buffer to store the free run counter (must not be null)

### Returns

Execution status, see [OSAL Return Code Defines](#)

### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the id passed in is not a valid timebase
<i>OS_INVALID_POINTER</i>	if pointer argument is NULL

#### 10.78.2.4 OS\_TimeBaseGetIdByName()

```
int32 OS_TimeBaseGetIdByName (
    osal_id_t * timebase_id,
    const char * timebase_name )
```

Find the ID of an existing time base resource.

Given a time base name, find and output the ID associated with it.

##### Note

This configuration API must not be used from the context of a timer callback. Timers should only be configured from the context of normal OSAL tasks.

##### Parameters

out	<i>timebase_id</i>	will be set to the non-zero ID of the matching resource (must not be null)
in	<i>timebase_name</i>	The name of the timebase resource to find (must not be null)

##### Returns

Execution status, see [OSAL Return Code Defines](#)

##### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_INVALID_POINTER</i>	if timebase_id or timebase_name are NULL pointers
<i>OS_ERR_NAME_TOO_LONG</i>	name length including null terminator greater than <a href="#">OS_MAX_API_NAME</a>
<i>OS_ERR_NAME_NOT_FOUND</i>	if the name was not found in the table
<i>OS_ERR_INCORRECT_OBJ_STATE</i>	if called from timer/timebase context

#### 10.78.2.5 OS\_TimeBaseGetInfo()

```
int32 OS_TimeBaseGetInfo (
    osal_id_t timebase_id,
    OS_timebase_prop_t * timebase_prop )
```

Obtain information about a timebase resource.

Fills the buffer referred to by the timebase\_prop parameter with relevant information about the time base resource.

This function will pass back a pointer to structure that contains all of the relevant info( name and creator) about the specified timebase.

**Note**

This configuration API must not be used from the context of a timer callback. Timers should only be configured from the context of normal OSAL tasks.

**Parameters**

in	<i>timebase_id</i>	The timebase resource ID
out	<i>timebase_prop</i>	Buffer to store timebase properties (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the id passed in is not a valid timebase
<i>OS_INVALID_POINTER</i>	if the timebase_prop pointer is null
<i>OS_ERR_INCORRECT_OBJ_STATE</i>	if called from timer/timebase context

**10.78.2.6 OS\_TimeBaseSet()**

```
int32 OS_TimeBaseSet (
    osal_id_t timebase_id,
    uint32 start_time,
    uint32 interval_time )
```

Sets the tick period for simulated time base objects.

This sets the actual tick period for timing ticks that are simulated by the RTOS kernel (i.e. the "external\_sync" parameter on the call to [OS\\_TimeBaseCreate\(\)](#) is NULL).

The RTOS will be configured to wake up the helper thread at the requested interval.

This function has no effect for time bases that are using a BSP-provided external\_sync function.

**Note**

This configuration API must not be used from the context of a timer callback. Timers should only be configured from the context of normal OSAL tasks.

**Parameters**

in	<i>timebase_id</i>	The timebase resource to configure
in	<i>start_time</i>	The amount of delay for the first tick, in microseconds.
in	<i>interval_time</i>	The amount of delay between ticks, in microseconds.

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the id passed in is not a valid timebase
<i>OS_ERR_INCORRECT_OBJ_STATE</i>	if called from timer/timebase context
<i>OS_TIMER_ERR_INVALID_ARGS</i>	if start_time or interval_time are out of range

## 10.79 OSAL Timer APIs

### Functions

- `int32 OS_TimerCreate (osal_id_t *timer_id, const char *timer_name, uint32 *clock_accuracy, OS_TimerCallback_t callback_ptr)`  
*Create a timer object.*
- `int32 OS_TimerAdd (osal_id_t *timer_id, const char *timer_name, osal_id_t timebase_id, OS_ArgCallback_t callback_ptr, void *callback_arg)`  
*Add a timer object based on an existing TimeBase resource.*
- `int32 OS_TimerSet (osal_id_t timer_id, uint32 start_time, uint32 interval_time)`  
*Configures a periodic or one shot timer.*
- `int32 OS_TimerDelete (osal_id_t timer_id)`  
*Deletes a timer resource.*
- `int32 OS_TimerGetIdByName (osal_id_t *timer_id, const char *timer_name)`  
*Locate an existing timer resource by name.*
- `int32 OS_TimerGetInfo (osal_id_t timer_id, OS_timer_prop_t *timer_prop)`  
*Gets information about an existing timer.*

### 10.79.1 Detailed Description

### 10.79.2 Function Documentation

#### 10.79.2.1 OS\_TimerAdd()

```
int32 OS_TimerAdd (
    osal_id_t * timer_id,
    const char * timer_name,
    osal_id_t timebase_id,
    OS_ArgCallback_t callback_ptr,
    void * callback_arg )
```

Add a timer object based on an existing TimeBase resource.

A timer object is a resource that invokes the specified application-provided function upon timer expiration. Timers may be one-shot or periodic in nature.

This function uses an existing time base object to service this timer, which must exist prior to adding the timer. The precision of the timer is the same as that of the underlying time base object. Multiple timer objects can be created referring to a single time base object.

This routine also uses a different callback function prototype from [OS\\_TimerCreate\(\)](#), allowing a single opaque argument to be passed to the callback routine. The OSAL implementation does not use this parameter, and may be set NULL.

The callback function for this method should be declared according to the OS\_ArgCallback\_t function pointer type. The timer\_id is passed in to the function by the OSAL, and the arg parameter is passed through from the callback\_arg argument on this call.

**Note**

This configuration API must not be used from the context of a timer callback. Timers should only be configured from the context of normal OSAL tasks.

**See also**

[OS\\_ArgCallback\\_t](#)

### Parameters

out	<i>timer_id</i>	Will be set to the non-zero resource ID of the timer object (must not be null)
in	<i>timer_name</i>	Name of the timer object (must not be null)
in	<i>timebase_id</i>	The time base resource to use as a reference
in	<i>callback_ptr</i>	Application-provided function to invoke (must not be null)
in	<i>callback_arg</i>	Opaque argument to pass to callback function, may be NULL

### Returns

Execution status, see [OSAL Return Code Defines](#)

### Return values

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_INVALID_POINTER</a>	if any parameters are NULL
<a href="#">OS_ERR_INVALID_ID</a>	if the timebase_id parameter is not valid
<a href="#">OS_ERR_NAME_TOO_LONG</a>	name length including null terminator greater than <a href="#">OS_MAX_API_NAME</a>
<a href="#">OS_ERR_NAME_TAKEN</a>	if the name is already in use by another timer.
<a href="#">OS_ERR_NO_FREE_IDS</a>	if all of the timers are already allocated.
<a href="#">OS_ERR_INCORRECT_OBJ_STATE</a>	if invoked from a timer context
<a href="#">OS_TIMER_ERR_INTERNAL</a>	if there was an error programming the OS timer (return value only verified in coverage test)

### 10.79.2.2 OS\_TimerCreate()

```
int32 OS_TimerCreate (
    osal_id_t * timer_id,
    const char * timer_name,
    uint32 * clock_accuracy,
    OS_TimerCallback_t callback_ptr )
```

Create a timer object.

A timer object is a resource that invokes the specified application-provided function upon timer expiration. Timers may be one-shot or periodic in nature.

This function creates a dedicated (hidden) time base object to service this timer, which is created and deleted with the timer object itself. The internal time base is configured for an OS simulated timer tick at the same interval as the timer.

The callback function should be declared according to the OS\_TimerCallback\_t function pointer type. The timer\_id value is passed to the callback function.

**Note**

`clock_accuracy` comes from the underlying OS tick value. The nearest integer microsecond value is returned, so may not be exact.

This configuration API must not be used from the context of a timer callback. Timers should only be configured from the context of normal OSAL tasks.

**See also**

[OS\\_TimerCallback\\_t](#)

**Parameters**

<code>out</code>	<code>timer_id</code>	Will be set to the non-zero resource ID of the timer object (must not be null)
<code>in</code>	<code>timer_name</code>	Name of the timer object (must not be null)
<code>out</code>	<code>clock_accuracy</code>	Expected precision of the timer, in microseconds. This is the underlying tick value rounded to the nearest microsecond integer. (must not be null)
<code>in</code>	<code>callback_ptr</code>	The function pointer of the timer callback (must not be null).

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<a href="#">OS_SUCCESS</a>	Successful execution.
<a href="#">OS_INVALID_POINTER</a>	if any parameters are NULL
<a href="#">OS_ERR_NAME_TOO_LONG</a>	name length including null terminator greater than <a href="#">OS_MAX_API_NAME</a>
<a href="#">OS_ERR_NAME_TAKEN</a>	if the name is already in use by another timer.
<a href="#">OS_ERR_NO_FREE_IDS</a>	if all of the timers are already allocated.
<a href="#">OS_ERR_INCORRECT_OBJ_STATE</a>	if invoked from a timer context
<a href="#">OS_TIMER_ERR_INTERNAL</a>	if there was an error programming the OS timer (return value only verified in coverage test)

**10.79.2.3 OS\_TimerDelete()**

```
int32 OS_TimerDelete (
    osal_id_t timer_id )
```

Deletes a timer resource.

The application callback associated with the timer will be stopped, and the resources freed for future use.

**Note**

This configuration API must not be used from the context of a timer callback. Timers should only be configured from the context of normal OSAL tasks.

**Parameters**

in	<i>timer_id</i>	The timer ID to operate on
----	-----------------	----------------------------

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the timer_id is invalid.
<i>OS_TIMER_ERR_INTERNAL</i>	if there was a problem deleting the timer in the host OS (return value only verified in coverage test)
<i>OS_ERR_INCORRECT_OBJ_STATE</i>	if called from timer/timebase context

**10.79.2.4 OS\_TimerGetIdByName()**

```
int32 OS_TimerGetIdByName (
    osal_id_t * timer_id,
    const char * timer_name )
```

Locate an existing timer resource by name.

Outputs the ID associated with the given timer, if it exists.

**Note**

This configuration API must not be used from the context of a timer callback. Timers should only be configured from the context of normal OSAL tasks.

**Parameters**

out	<i>timer_id</i>	Will be set to the timer ID corresponding to the name (must not be null)
in	<i>timer_name</i>	The timer name to find (must not be null)

**Returns**

Execution status, see [OSAL Return Code Defines](#)

**Return values**

<i>OS_SUCCESS</i>	Successful execution.
-------------------	-----------------------

#### Return values

<i>OS_INVALID_POINTER</i>	if timer_id or timer_name are NULL pointers
<i>OS_ERR_NAME_TOO_LONG</i>	name length including null terminator greater than <i>OS_MAX_API_NAME</i>
<i>OS_ERR_NAME_NOT_FOUND</i>	if the name was not found in the table
<i>OS_ERR_INCORRECT_OBJ_STATE</i>	if called from timer/timebase context

#### 10.79.2.5 OS\_TimerGetInfo()

```
int32 OS_TimerGetInfo (
    osal_id_t timer_id,
    OS_timer_prop_t *timer_prop )
```

Gets information about an existing timer.

This function takes timer\_id, and looks it up in the OS table. It puts all of the information known about that timer into a structure pointer to by timer\_prop.

#### Note

This configuration API must not be used from the context of a timer callback. Timers should only be configured from the context of normal OSAL tasks.

#### Parameters

in	<i>timer_id</i>	The timer ID to operate on
out	<i>timer_prop</i>	<p>Buffer containing timer properties (must not be null)</p> <ul style="list-style-type: none"> <li>• creator: the OS task ID of the task that created this timer</li> <li>• name: the string name of the timer</li> <li>• start_time: the start time in microseconds, if any</li> <li>• interval_time: the interval time in microseconds, if any</li> <li>• accuracy: the accuracy of the timer in microseconds</li> </ul>

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<i>OS_SUCCESS</i>	Successful execution.
<i>OS_ERR_INVALID_ID</i>	if the id passed in is not a valid timer
<i>OS_INVALID_POINTER</i>	if the timer_prop pointer is null
<i>OS_ERR_INCORRECT_OBJ_STATE</i>	if called from timer/timebase context

### 10.79.2.6 OS\_TimerSet()

```
int32 OS_TimerSet (
    osal_id_t timer_id,
    uint32 start_time,
    uint32 interval_time )
```

Configures a periodic or one shot timer.

This function programs the timer with a start time and an optional interval time. The start time is the time in microseconds when the user callback function will be called. If the interval time is non-zero, the timer will be reprogrammed with that interval in microseconds to call the user callback function periodically. If the start time and interval time are zero, the function will return an error.

For a "one-shot" timer, the start\_time configures the expiration time, and the interval\_time should be passed as zero to indicate the timer is not to be automatically reset.

#### Note

The resolution of the times specified is limited to the clock accuracy returned in the OS\_TimerCreate call. If the times specified in the start\_msec or interval\_msec parameters are less than the accuracy, they will be rounded up to the accuracy of the timer.

This configuration API must not be used from the context of a timer callback. Timers should only be configured from the context of normal OSAL tasks.

#### Parameters

in	<i>timer_id</i>	The timer ID to operate on
in	<i>start_time</i>	Time in microseconds to the first expiration
in	<i>interval_time</i>	Time in microseconds between subsequent intervals, value of zero will only call the user callback function once after the start_msec time.

#### Returns

Execution status, see [OSAL Return Code Defines](#)

#### Return values

<a href="#"><i>OS_SUCCESS</i></a>	Successful execution.
<a href="#"><i>OS_ERR_INVALID_ID</i></a>	if the timer_id is not valid.
<a href="#"><i>OS_TIMER_ERR_INTERNAL</i></a>	if there was an error programming the OS timer (return value only verified in coverage test)
<a href="#"><i>OS_ERR_INCORRECT_OBJ_STATE</i></a>	if called from timer/timebase context
<a href="#"><i>OS_TIMER_ERR_INVALID_ARGS</i></a>	if the start_time or interval_time is out of range, or both 0

## 11 Data Structure Documentation

### 11.1 CCSDS\_ExtendedHeader Struct Reference

CCSDS packet extended header.

```
#include <ccsds_hdr.h>
```

#### Data Fields

- `uint8 Subsystem [2]`  
*subsystem qualifier*
- `uint8 SystemId [2]`  
*system qualifier*

#### 11.1.1 Detailed Description

CCSDS packet extended header.

Definition at line 75 of file ccsds\_hdr.h.

#### 11.1.2 Field Documentation

##### 11.1.2.1 Subsystem

```
uint8 CCSDS_ExtendedHeader::Subsystem[2]
```

subsystem qualifier

Definition at line 78 of file ccsds\_hdr.h.

##### 11.1.2.2 SystemId

```
uint8 CCSDS_ExtendedHeader::SystemId[2]
```

system qualifier

Definition at line 85 of file ccsds\_hdr.h.

The documentation for this struct was generated from the following file:

- cfe/modules/msg/fsw/inc/[ccsds\\_hdr.h](#)

## 11.2 CCSDS\_PrimaryHeader Struct Reference

CCSDS packet primary header.

```
#include <ccsds_hdr.h>
```

### Data Fields

- `uint8 StreamId [2]`  
*packet identifier word (stream ID)*
- `uint8 Sequence [2]`  
*packet sequence word*
- `uint8 Length [2]`  
*packet length word*

### 11.2.1 Detailed Description

CCSDS packet primary header.

Definition at line 51 of file ccsds\_hdr.h.

### 11.2.2 Field Documentation

#### 11.2.2.1 Length

```
uint8 CCSDS_PrimaryHeader::Length [2]
```

packet length word

Definition at line 66 of file ccsds\_hdr.h.

#### 11.2.2.2 Sequence

```
uint8 CCSDS_PrimaryHeader::Sequence [2]
```

packet sequence word

Definition at line 61 of file ccsds\_hdr.h.

### 11.2.2.3 StreamId

```
uint8 CCSDS_PrimaryHeader::StreamId[2]
```

packet identifier word (stream ID)

Definition at line 54 of file ccsds\_hdr.h.

The documentation for this struct was generated from the following file:

- cfe/modules/msg/fsw/inc/[ccsds\\_hdr.h](#)

## 11.3 CFE\_ES\_AppInfo Struct Reference

Application Information.

```
#include <cfe_es_extern_typedefs.h>
```

### Data Fields

- **CFE\_Resourceld\_t Resourceld**  
*Application or Library ID for this resource.*
- **uint32 Type**  
*The type of App: CORE or EXTERNAL.*
- **char Name [CFE\_MISSION\_MAX\_API\_LEN]**  
*The Registered Name of the Application.*
- **char EntryPoint [CFE\_MISSION\_MAX\_API\_LEN]**  
*The Entry Point label for the Application.*
- **char FileName [CFE\_MISSION\_MAX\_PATH\_LEN]**  
*The Filename of the file containing the Application.*
- **CFE\_ES\_MemOffset\_t StackSize**  
*The Stack Size of the Application.*
- **uint32 AddressesAreValid**  
*Indicates that the Code, Data, and BSS addresses/sizes are valid.*
- **CFE\_ES\_MemAddress\_t CodeAddress**  
*The Address of the Application Code Segment.*
- **CFE\_ES\_MemOffset\_t CodeSize**  
*The Code Size of the Application.*
- **CFE\_ES\_MemAddress\_t DataAddress**  
*The Address of the Application Data Segment.*
- **CFE\_ES\_MemOffset\_t DataSize**  
*The Data Size of the Application.*
- **CFE\_ES\_MemAddress\_t BSSAddress**  
*The Address of the Application BSS Segment.*
- **CFE\_ES\_MemOffset\_t BSSSize**  
*The BSS Size of the Application.*

- [CFE\\_ES\\_MemAddress\\_t StartAddress](#)  
*The Start Address of the Application.*
- [CFE\\_ES\\_ExceptionAction\\_Enum\\_t ExceptionAction](#)  
*What should occur if Application has an exception (Restart Application OR Restart Processor)*
- [CFE\\_ES\\_TaskPriority\\_Atom\\_t Priority](#)  
*The Priority of the Application.*
- [CFE\\_ES\\_TaskId\\_t MainTaskId](#)  
*The Application's Main Task ID.*
- [uint32 ExecutionCounter](#)  
*The Application's Main Task Execution Counter.*
- char [MainTaskName \[CFE\\_MISSION\\_MAX\\_API\\_LEN\]](#)  
*The Application's Main Task ID.*
- [uint32 NumOfChildTasks](#)  
*Number of Child tasks for an App.*

### 11.3.1 Detailed Description

Application Information.

Structure that is used to provide information about an app. It is primarily used for the QueryOne and QueryAll Commands.

While this structure is primarily intended for Application info, it can also represent Library information where only a subset of the information applies.

Definition at line 442 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2 Field Documentation

#### 11.3.2.1 AddressesAreValid

[uint32 CFE\\_ES\\_AppInfo::AddressesAreValid](#)

Indicates that the Code, Data, and BSS addresses/sizes are valid.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_AddrsValid

Definition at line 458 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.2 BSSAddress

`CFE_ES_MemAddress_t CFE_ES_AppInfo::BSSAddress`

The Address of the Application BSS Segment.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_BSSAddress

Definition at line 468 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.3 BSSSize

`CFE_ES_MemOffset_t CFE_ES_AppInfo::BSSSize`

The BSS Size of the Application.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_BSSSize

Definition at line 470 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.4 CodeAddress

`CFE_ES_MemAddress_t CFE_ES_AppInfo::CodeAddress`

The Address of the Application Code Segment.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_CodeAddress

Definition at line 460 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.5 CodeSize

`CFE_ES_MemOffset_t CFE_ES_AppInfo::CodeSize`

The Code Size of the Application.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_CodeSize

Definition at line 462 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.6 DataAddress

`CFE_ES_MemAddress_t CFE_ES_AppInfo::DataAddress`

The Address of the Application Data Segment.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_DataAddress

Definition at line 464 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.7 DataSize

`CFE_ES_MemOffset_t CFE_ES_AppInfo::DataSize`

The Data Size of the Application.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_DataSize

Definition at line 466 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.8 EntryPoint

`char CFE_ES_AppInfo::EntryPoint[CFE_MISSION_MAX_API_LEN]`

The Entry Point label for the Application.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_AppEntryPt[OS\_MAX\_API\_NAME]

Definition at line 451 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.9 ExceptionAction

`CFE_ES_ExceptionAction_Enum_t CFE_ES_AppInfo::ExceptionAction`

What should occur if Application has an exception (Restart Application OR Restart Processor)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_ExceptnActn

Definition at line 474 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.10 ExecutionCounter

```
uint32 CFE_ES_AppInfo::ExecutionCounter
```

The Application's Main Task Execution Counter.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_ExecutionCtr

Definition at line 481 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.11 FileName

```
char CFE_ES_AppInfo::FileName[CFE_MISSION_MAX_PATH_LEN]
```

The Filename of the file containing the Application.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_AppFilename[OS\_MAX\_PATH\_LEN]

Definition at line 453 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.12 MainTaskId

```
CFE_ES_TaskId_t CFE_ES_AppInfo::MainTaskId
```

The Application's Main Task ID.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_MainTaskId

Definition at line 479 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.13 MainTaskName

```
char CFE_ES_AppInfo::MainTaskName[CFE_MISSION_MAX_API_LEN]
```

The Application's Main Task ID.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_MainTaskName[OS\_MAX\_API\_NAME]

Definition at line 483 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.14 Name

```
char CFE_ES_AppInfo::Name[CFE_MISSION_MAX_API_LEN]
```

The Registered Name of the Application.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_AppName[OS\_MAX\_API\_NAME]

Definition at line 449 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.15 NumOfChildTasks

```
uint32 CFE_ES_AppInfo::NumOfChildTasks
```

Number of Child tasks for an App.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_ChildTasks

Definition at line 485 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.16 Priority

```
CFE_ES_TaskPriority_Atom_t CFE_ES_AppInfo::Priority
```

The Priority of the Application.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_Priority

Definition at line 477 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.17 ResourceId

```
CFE_ResourceId_t CFE_ES_AppInfo::ResourceId
```

Application or Library ID for this resource.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_AppID

Definition at line 444 of file cfe\_es\_extern\_typedefs.h.

### 11.3.2.18 StackSize

`CFE_ES_MemOffset_t CFE_ES_AppInfo::StackSize`

The Stack Size of the Application.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_StackSize

Definition at line 456 of file `cfe_es_extern_typedefs.h`.

### 11.3.2.19 StartAddress

`CFE_ES_MemAddress_t CFE_ES_AppInfo::StartAddress`

The Start Address of the Application.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_StartAddr

Definition at line 472 of file `cfe_es_extern_typedefs.h`.

### 11.3.2.20 Type

`uint32 CFE_ES_AppInfo::Type`

The type of App: CORE or EXTERNAL.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_AppType

Definition at line 446 of file `cfe_es_extern_typedefs.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/core_api/fsw/inc/cfe_es_extern_typedefs.h`

## 11.4 CFE\_ES\_AppNameCmd Struct Reference

Generic application name command.

```
#include <cfe_es_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) CommandHeader  
*Command header.*
- [CFE\\_ES\\_AppNameCmd\\_Payload\\_t](#) Payload  
*Command payload.*

### 11.4.1 Detailed Description

Generic application name command.

Definition at line 1198 of file cfe\_es\_msg.h.

### 11.4.2 Field Documentation

#### 11.4.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_ES\_AppNameCmd::CommandHeader

Command header.

Definition at line 1200 of file cfe\_es\_msg.h.

#### 11.4.2.2 Payload

[CFE\\_ES\\_AppNameCmd\\_Payload\\_t](#) CFE\_ES\_AppNameCmd::Payload

Command payload.

Definition at line 1201 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfe\\_es\\_msg.h](#)

## 11.5 CFE\_ES\_AppNameCmd\_Payload Struct Reference

Generic application name command payload.

```
#include <cfe_es_msg.h>
```

## Data Fields

- char [Application \[CFE\\_MISSION\\_MAX\\_API\\_LEN\]](#)  
*ASCII text string containing Application or Library Name.*

### 11.5.1 Detailed Description

Generic application name command payload.

For command details, see [CFE\\_ES\\_STOP\\_APP\\_CC](#), [CFE\\_ES\\_RESTART\\_APP\\_CC](#), [CFE\\_ES\\_QUERY\\_ONE\\_CC](#)

Definition at line 1190 of file cfe\_es\_msg.h.

### 11.5.2 Field Documentation

#### 11.5.2.1 Application

```
char CFE_ES_AppNameCmd_Payload::Application[CFE_MISSION_MAX_API_LEN]
```

ASCII text string containing Application or Library Name.

Definition at line 1192 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfe\\_es\\_msg.h](#)

## 11.6 CFE\_ES\_AppReloadCmd\_Payload Struct Reference

Reload Application Command Payload.

```
#include <cfe_es_msg.h>
```

## Data Fields

- char [Application \[CFE\\_MISSION\\_MAX\\_API\\_LEN\]](#)  
*ASCII text string containing Application Name.*
- char [AppFileName \[CFE\\_MISSION\\_MAX\\_PATH\\_LEN\]](#)  
*Full path and filename of Application's executable image.*

### 11.6.1 Detailed Description

Reload Application Command Payload.

For command details, see [CFE\\_ES\\_RELOAD\\_APP\\_CC](#)

Definition at line 1219 of file cfe\_es\_msg.h.

### 11.6.2 Field Documentation

#### 11.6.2.1 AppFileName

```
char CFE_ES_AppReloadCmd_Payload::AppFileName[CFE\_MISSION\_MAX\_PATH\_LEN]
```

Full path and filename of Application's executable image.

Definition at line 1222 of file cfe\_es\_msg.h.

#### 11.6.2.2 Application

```
char CFE_ES_AppReloadCmd_Payload::Application[CFE\_MISSION\_MAX\_API\_LEN]
```

ASCII text string containing Application Name.

Definition at line 1221 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfe\\_es\\_msg.h](#)

## 11.7 CFE\_ES\_BlockStats Struct Reference

Block statistics.

```
#include <cfe_es_extern_typedefs.h>
```

### Data Fields

- [CFE\\_ES\\_MemOffset\\_t BlockSize](#)  
*Number of bytes in each of these blocks.*
- [uint32 NumCreated](#)  
*Number of Memory Blocks of this size created.*
- [uint32 NumFree](#)  
*Number of Memory Blocks of this size that are free.*

### 11.7.1 Detailed Description

Block statistics.

Sub-Structure that is used to provide information about a specific block size/bucket within a memory pool.

Definition at line 540 of file `cfe_es_extern_typedefs.h`.

### 11.7.2 Field Documentation

#### 11.7.2.1 BlockSize

`CFE_ES_MemOffset_t` `CFE_ES_BlockStats::BlockSize`

Number of bytes in each of these blocks.

Definition at line 542 of file `cfe_es_extern_typedefs.h`.

#### 11.7.2.2 NumCreated

`uint32` `CFE_ES_BlockStats::NumCreated`

Number of Memory Blocks of this size created.

Definition at line 543 of file `cfe_es_extern_typedefs.h`.

#### 11.7.2.3 NumFree

`uint32` `CFE_ES_BlockStats::NumFree`

Number of Memory Blocks of this size that are free.

Definition at line 544 of file `cfe_es_extern_typedefs.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/core_api/fsw/inc/cfe_es_extern_typedefs.h`

## 11.8 CFE\_ES\_CDSRegDumpRec Struct Reference

CDS Register Dump Record.

```
#include <cfe_es_extern_typedefs.h>
```

## Data Fields

- **`CFE_ES_CDSHandle_t Handle`**  
*Handle of CDS.*
- **`CFE_ES_MemOffset_t Size`**  
*Size, in bytes, of the CDS memory block.*
- **`bool Table`**  
*Flag that indicates whether CDS contains a Critical Table.*
- **`char Name [CFE_MISSION_ES_CDS_MAX_FULL_NAME_LEN]`**  
*Processor Unique Name of CDS.*
- **`uint8 ByteAlignSpare [3]`**  
*Spare bytes to ensure structure size is multiple of 4 bytes.*

### 11.8.1 Detailed Description

CDS Register Dump Record.

Structure that is used to provide information about a critical data store. It is primarily used for the Dump CDS registry ([CFE\\_ES\\_DUMP\\_CDS\\_REGISTRY\\_CC](#)) command.

#### Note

There is not currently a telemetry message directly containing this data structure, but it does define the format of the data file generated by the Dump CDS registry command. Therefore it should be considered part of the overall telemetry interface.

Definition at line 525 of file `cfe_es_extern_typedefs.h`.

### 11.8.2 Field Documentation

#### 11.8.2.1 ByteAlignSpare

`uint8 CFE_ES_CDSRegDumpRec::ByteAlignSpare [3]`

Spare bytes to ensure structure size is multiple of 4 bytes.

Definition at line 531 of file `cfe_es_extern_typedefs.h`.

#### 11.8.2.2 Handle

`CFE_ES_CDSHandle_t CFE_ES_CDSRegDumpRec::Handle`

Handle of CDS.

Definition at line 527 of file `cfe_es_extern_typedefs.h`.

### 11.8.2.3 Name

```
char CFE_ES_CDSRegDumpRec::Name[CFE_MISSION_ES_CDS_MAX_FULL_NAME_LEN]
```

Processor Unique Name of CDS.

Definition at line 530 of file cfe\_es\_extern\_typedefs.h.

### 11.8.2.4 Size

```
CFE_ES_MemOffset_t CFE_ES_CDSRegDumpRec::Size
```

Size, in bytes, of the CDS memory block.

Definition at line 528 of file cfe\_es\_extern\_typedefs.h.

### 11.8.2.5 Table

```
bool CFE_ES_CDSRegDumpRec::Table
```

Flag that indicates whether CDS contains a Critical Table.

Definition at line 529 of file cfe\_es\_extern\_typedefs.h.

The documentation for this struct was generated from the following file:

- cfe/modules/core\_api/fsw/inc/cfe\_es\_extern\_typedefs.h

## 11.9 CFE\_ES\_DeleteCDSCmd Struct Reference

Delete Critical Data Store Command.

```
#include <cfe_es_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) CommandHeader  
*Command header.*
- [CFE\\_ES\\_DeleteCDSCmd\\_Payload\\_t](#) Payload  
*Command payload.*

### 11.9.1 Detailed Description

Delete Critical Data Store Command.

Definition at line 1272 of file `cfe_es_msg.h`.

### 11.9.2 Field Documentation

#### 11.9.2.1 CommandHeader

`CFE_MSG_CommandHeader_t CFE_ES_DeleteCDSCmd::CommandHeader`

Command header.

Definition at line 1274 of file `cfe_es_msg.h`.

#### 11.9.2.2 Payload

`CFE_ES_DeleteCDSCmd_Payload_t CFE_ES_DeleteCDSCmd::Payload`

Command payload.

Definition at line 1275 of file `cfe_es_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/es/fsw/inc/cfe_es_msg.h`

## 11.10 CFE\_ES\_DeleteCDSCmd\_Payload Struct Reference

Delete Critical Data Store Command Payload.

```
#include <cfe_es_msg.h>
```

### Data Fields

- char `CdsName [CFE_MISSION_ES_CDS_MAX_FULL_NAME_LEN]`

*ASCII text string containing name of CDS to delete.*

### 11.10.1 Detailed Description

Delete Critical Data Store Command Payload.

For command details, see [CFE\\_ES\\_DELETE\\_CDS\\_CC](#)

Definition at line 1262 of file cfe\_es\_msg.h.

### 11.10.2 Field Documentation

#### 11.10.2.1 CdsName

```
char CFE_ES_DeleteCDSCmd_Payload::CdsName[CFE\_MISSION\_ES\_CDS\_MAX\_FULL\_NAME\_LEN]
```

ASCII text string containing name of CDS to delete.

Definition at line 1265 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfe\\_es\\_msg.h](#)

## 11.11 CFE\_ES\_DumpCDSRegistryCmd Struct Reference

Dump CDS Registry Command.

```
#include <cfe_es_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) CommandHeader  
*Command header.*
- [CFE\\_ES\\_DumpCDSRegistryCmd\\_Payload\\_t](#) Payload  
*Command payload.*

### 11.11.1 Detailed Description

Dump CDS Registry Command.

Definition at line 1400 of file cfe\_es\_msg.h.

## 11.11.2 Field Documentation

### 11.11.2.1 CommandHeader

`CFE_MSG_CommandHeader_t` `CFE_ES_DumpCDSRegistryCmd::CommandHeader`

Command header.

Definition at line 1402 of file `cfe_es_msg.h`.

### 11.11.2.2 Payload

`CFE_ES_DumpCDSRegistryCmd_Payload_t` `CFE_ES_DumpCDSRegistryCmd::Payload`

Command payload.

Definition at line 1403 of file `cfe_es_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/es/fsw/inc/cfe_es_msg.h`

## 11.12 CFE\_ES\_DumpCDSRegistryCmd\_Payload Struct Reference

Dump CDS Registry Command Payload.

```
#include <cfe_es_msg.h>
```

### Data Fields

- `char DumpFilename [CFE_MISSION_MAX_PATH_LEN]`  
*ASCII text string of full path and filename of file CDS Registry is to be written.*

### 11.12.1 Detailed Description

Dump CDS Registry Command Payload.

For command details, see [CFE\\_ES\\_DUMP\\_CDS\\_REGISTRY\\_CC](#)

Definition at line 1391 of file `cfe_es_msg.h`.

## 11.12.2 Field Documentation

### 11.12.2.1 DumpFilename

char CFE\_ES\_DumpCDSRegistryCmd\_Payload::DumpFilename [CFE\_MISSION\_MAX\_PATH\_LEN]

ASCII text string of full path and filename of file CDS Registry is to be written.

Definition at line 1393 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/cfe\_es\_msg.h

## 11.13 CFE\_ES\_FileNameCmd Struct Reference

Generic file name command.

```
#include <cfe_es_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) CommandHeader  
*Command header.*
- [CFE\\_ES\\_FileNameCmd\\_Payload\\_t](#) Payload  
*Command payload.*

### 11.13.1 Detailed Description

Generic file name command.

Definition at line 1115 of file cfe\_es\_msg.h.

## 11.13.2 Field Documentation

### 11.13.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_ES\_FileNameCmd::CommandHeader

Command header.

Definition at line 1117 of file cfe\_es\_msg.h.

### 11.13.2.2 Payload

`CFE_ES_FileNameCmd_Payload_t` `CFE_ES_FileNameCmd::Payload`

Command payload.

Definition at line 1118 of file `cfe_es_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/es/fsw/inc/cfe_es_msg.h`

## 11.14 CFE\_ES\_FileNameCmd\_Payload Struct Reference

Generic file name command payload.

```
#include <cfe_es_msg.h>
```

### Data Fields

- `char FileName [CFE_MISSION_MAX_PATH_LEN]`

*ASCII text string containing full path and filename of file in which Application data is to be dumped.*

### 11.14.1 Detailed Description

Generic file name command payload.

This format is shared by several executive services commands. For command details, see `CFE_ES_QUERY_ALL_CC`, `CFE_ES_QUERY_ALL_TASKS_CC`, `CFE_ES_WRITE_SYSLOG_CC`, and `CFE_ES_WRITE_ER_LOG_CC`

Definition at line 1106 of file `cfe_es_msg.h`.

### 11.14.2 Field Documentation

#### 11.14.2.1 FileName

`char CFE_ES_FileNameCmd_Payload::FileName [CFE_MISSION_MAX_PATH_LEN]`

ASCII text string containing full path and filename of file in which Application data is to be dumped.

Definition at line 1108 of file `cfe_es_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/es/fsw/inc/cfe_es_msg.h`

## 11.15 CFE\_ES\_HousekeepingTlm Struct Reference

```
#include <cfes_es_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_TelemetryHeader\\_t TelemetryHeader](#)  
*Telemetry header.*
- [CFE\\_ES\\_HousekeepingTlm\\_Payload\\_t Payload](#)  
*Telemetry payload.*

### 11.15.1 Detailed Description

Definition at line 1548 of file cfe\_es\_msg.h.

### 11.15.2 Field Documentation

#### 11.15.2.1 Payload

[CFE\\_ES\\_HousekeepingTlm\\_Payload\\_t](#) CFE\_ES\_HousekeepingTlm::Payload

Telemetry payload.

Definition at line 1551 of file cfe\_es\_msg.h.

#### 11.15.2.2 TelemetryHeader

[CFE\\_MSG\\_TelemetryHeader\\_t](#) CFE\_ES\_HousekeepingTlm::TelemetryHeader

Telemetry header.

Definition at line 1550 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfes\\_es\\_msg.h](#)

## 11.16 CFE\_ES\_HousekeepingTlm\_Payload Struct Reference

```
#include <cfes_es_msg.h>
```

## Data Fields

- **uint8 CommandCounter**  
*The ES Application Command Counter.*
- **uint8 CommandErrorCounter**  
*The ES Application Command Error Counter.*
- **uint16 CFECOREChecksum**  
*Checksum of cFE Core Code.*
- **uint8 CFEMajorVersion**  
*Major Version Number of cFE.*
- **uint8 CFEMinorVersion**  
*Minor Version Number of cFE.*
- **uint8 CFERevision**  
*Sub-Minor Version Number of cFE.*
- **uint8 CFEMissionRevision**  
*Mission Version Number of cFE.*
- **uint8 OSALMajorVersion**  
*OS Abstraction Layer Major Version Number.*
- **uint8 OSALMinorVersion**  
*OS Abstraction Layer Minor Version Number.*
- **uint8 OSALRevision**  
*OS Abstraction Layer Revision Number.*
- **uint8 OSALMissionRevision**  
*OS Abstraction Layer MissionRevision Number.*
- **uint8 PSPMajorVersion**  
*Platform Support Package Major Version Number.*
- **uint8 PSPMinorVersion**  
*Platform Support Package Minor Version Number.*
- **uint8 PSPRevision**  
*Platform Support Package Revision Number.*
- **uint8 PSPMissionRevision**  
*Platform Support Package MissionRevision Number.*
- **CFE\_ES\_MemOffset\_t SysLogBytesUsed**  
*Total number of bytes used in system log.*
- **CFE\_ES\_MemOffset\_t SysLogSize**  
*Total size of the system log.*
- **uint32 SysLogEntries**  
*Number of entries in the system log.*
- **uint32 SysLogMode**  
*Write/Overwrite Mode.*
- **uint32 ERLogIndex**  
*Current index of the ER Log (wraps around)*
- **uint32 ERLogEntries**  
*Number of entries made in the ER Log since the power on.*
- **uint32 RegisteredCoreApps**  
*Number of Applications registered with ES.*
- **uint32 RegisteredExternalApps**

- **uint32 RegisteredTasks**  
*Number of Applications registered with ES.*
- **uint32 RegisteredLibs**  
*Number of Libraries registered with ES.*
- **uint32 ResetType**  
*Reset type ( PROCESSOR or POWERON )*
- **uint32 ResetSubtype**  
*Reset Sub Type.*
- **uint32 ProcessorResets**  
*Number of processor resets since last power on.*
- **uint32 MaxProcessorResets**  
*Max processor resets before a power on is done.*
- **uint32 BootSource**  
*Boot source ( as provided from BSP )*
- **uint32 PerfState**  
*Current state of Performance Analyzer.*
- **uint32 PerfMode**  
*Current mode of Performance Analyzer.*
- **uint32 PerfTriggerCount**  
*Number of Times Performance Analyzer has Triggered.*
- **uint32 PerfFilterMask [CFE\_MISSION\_ES\_PERF\_MAX\_IDS/32]**  
*Current Setting of Performance Analyzer Filter Masks.*
- **uint32 PerfTriggerMask [CFE\_MISSION\_ES\_PERF\_MAX\_IDS/32]**  
*Current Setting of Performance Analyzer Trigger Masks.*
- **uint32 PerfDataStart**  
*Identifies First Stored Entry in Performance Analyzer Log.*
- **uint32 PerfDataEnd**  
*Identifies Last Stored Entry in Performance Analyzer Log.*
- **uint32 PerfDataCount**  
*Number of Entries Put Into the Performance Analyzer Log.*
- **uint32 PerfDataToWrite**  
*Number of Performance Analyzer Log Entries Left to be Written to Log Dump File.*
- **CFE\_ES\_MemOffset\_t HeapBytesFree**  
*Number of free bytes remaining in the OS heap.*
- **CFE\_ES\_MemOffset\_t HeapBlocksFree**  
*Number of free blocks remaining in the OS heap.*
- **CFE\_ES\_MemOffset\_t HeapMaxBlockSize**  
*Number of bytes in the largest free block.*

#### 11.16.1 Detailed Description

**Name** Executive Services Housekeeping Packet

Definition at line 1451 of file cfe\_es\_msg.h.

## 11.16.2 Field Documentation

### 11.16.2.1 BootSource

`uint32 CFE_ES_HousekeepingTlm_Payload::BootSource`

Boot source ( as provided from BSP )

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_BootSource

Definition at line 1517 of file cfe\_es\_msg.h.

### 11.16.2.2 CFECOREChecksum

`uint16 CFE_ES_HousekeepingTlm_Payload::CFECOREChecksum`

Checksum of cFE Core Code.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_CKSUM

Definition at line 1458 of file cfe\_es\_msg.h.

### 11.16.2.3 CFEMajorVersion

`uint8 CFE_ES_HousekeepingTlm_Payload::CFEMajorVersion`

Major Version Number of cFE.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_CFEMAJORVER

Definition at line 1460 of file cfe\_es\_msg.h.

### 11.16.2.4 CFEMinorVersion

`uint8 CFE_ES_HousekeepingTlm_Payload::CFEMinorVersion`

Minor Version Number of cFE.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_CFEMINORVER

Definition at line 1462 of file cfe\_es\_msg.h.

#### 11.16.2.5 CFEMissionRevision

```
uint8 CFE_ES_HousekeepingTlm_Payload::CFEMissionRevision
```

Mission Version Number of cFE.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_CFEMISSIONREV

Definition at line 1466 of file cfe\_es\_msg.h.

#### 11.16.2.6 CFERevision

```
uint8 CFE_ES_HousekeepingTlm_Payload::CFERevision
```

Sub-Minor Version Number of cFE.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_CFEREVISION

Definition at line 1464 of file cfe\_es\_msg.h.

#### 11.16.2.7 CommandCounter

```
uint8 CFE_ES_HousekeepingTlm_Payload::CommandCounter
```

The ES Application Command Counter.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_CMDPC

Definition at line 1453 of file cfe\_es\_msg.h.

#### 11.16.2.8 CommandErrorCounter

```
uint8 CFE_ES_HousekeepingTlm_Payload::CommandErrorCounter
```

The ES Application Command Error Counter.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_CMDEC

Definition at line 1455 of file cfe\_es\_msg.h.

### 11.16.2.9 ERLogEntries

`uint32 CFE_ES_HousekeepingTlm_Payload::ERLogEntries`

Number of entries made in the ER Log since the power on.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_ERLOGENTRIES

Definition at line 1497 of file cfe\_es\_msg.h.

### 11.16.2.10 ERLogIndex

`uint32 CFE_ES_HousekeepingTlm_Payload::ERLogIndex`

Current index of the ER Log (wraps around)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_ERLOGINDEX

Definition at line 1495 of file cfe\_es\_msg.h.

### 11.16.2.11 HeapBlocksFree

`CFE_ES_MemOffset_t CFE_ES_HousekeepingTlm_Payload::HeapBlocksFree`

Number of free blocks remaining in the OS heap.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_HeapBlocksFree

Definition at line 1542 of file cfe\_es\_msg.h.

### 11.16.2.12 HeapBytesFree

`CFE_ES_MemOffset_t CFE_ES_HousekeepingTlm_Payload::HeapBytesFree`

Number of free bytes remaining in the OS heap.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_HeapBytesFree

Definition at line 1540 of file cfe\_es\_msg.h.

### 11.16.2.13 HeapMaxBlockSize

`CFE_ES_MemOffset_t CFE_ES_HousekeepingTlm_Payload::HeapMaxBlockSize`

Number of bytes in the largest free block.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_HeapMaxBlkSize

Definition at line 1544 of file cfe\_es\_msg.h.

### 11.16.2.14 MaxProcessorResets

`uint32 CFE_ES_HousekeepingTlm_Payload::MaxProcessorResets`

Max processor resets before a power on is done.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_MaxProcResets

Definition at line 1515 of file cfe\_es\_msg.h.

### 11.16.2.15 OSALMajorVersion

`uint8 CFE_ES_HousekeepingTlm_Payload::OSALMajorVersion`

OS Abstraction Layer Major Version Number.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_OSMajorVer

Definition at line 1468 of file cfe\_es\_msg.h.

### 11.16.2.16 OSALMinorVersion

`uint8 CFE_ES_HousekeepingTlm_Payload::OSALMinorVersion`

OS Abstraction Layer Minor Version Number.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_OsminorVer

Definition at line 1470 of file cfe\_es\_msg.h.

### 11.16.2.17 OSALMissionRevision

`uint8 CFE_ES_HousekeepingTlm_Payload::OSALMissionRevision`

OS Abstraction Layer MissionRevision Number.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_OSMISSIONREV

Definition at line 1474 of file cfe\_es\_msg.h.

### 11.16.2.18 OSALRevision

`uint8 CFE_ES_HousekeepingTlm_Payload::OSALRevision`

OS Abstraction Layer Revision Number.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_OSREVISION

Definition at line 1472 of file cfe\_es\_msg.h.

### 11.16.2.19 PerfDataCount

`uint32 CFE_ES_HousekeepingTlm_Payload::PerfDataCount`

Number of Entries Put Into the Performance Analyzer Log.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_PerfDataCnt

Definition at line 1535 of file cfe\_es\_msg.h.

### 11.16.2.20 PerfDataEnd

`uint32 CFE_ES_HousekeepingTlm_Payload::PerfDataEnd`

Identifies Last Stored Entry in Performance Analyzer Log.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_PerfDataEnd

Definition at line 1533 of file cfe\_es\_msg.h.

### 11.16.2.21 PerfDataStart

```
uint32 CFE_ES_HousekeepingTlm_Payload::PerfDataStart
```

Identifies First Stored Entry in Performance Analyzer Log.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_PerfDataStart

Definition at line 1531 of file cfe\_es\_msg.h.

### 11.16.2.22 PerfDataToWrite

```
uint32 CFE_ES_HousekeepingTlm_Payload::PerfDataToWrite
```

Number of Performance Analyzer Log Entries Left to be Written to Log Dump File.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_PerfData2Write

Definition at line 1538 of file cfe\_es\_msg.h.

### 11.16.2.23 PerfFilterMask

```
uint32 CFE_ES_HousekeepingTlm_Payload::PerfFilterMask[CFE_MISSION_ES_PERF_MAX_IDS/32]
```

Current Setting of Performance Analyzer Filter Masks.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_PerfFltrMask[MaskCnt]

Definition at line 1526 of file cfe\_es\_msg.h.

### 11.16.2.24 PerfMode

```
uint32 CFE_ES_HousekeepingTlm_Payload::PerfMode
```

Current mode of Performance Analyzer.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_PerfMode

Definition at line 1522 of file cfe\_es\_msg.h.

### 11.16.2.25 PerfState

```
uint32 CFE_ES_HousekeepingTlm_Payload::PerfState
```

Current state of Performance Analyzer.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_PerfState

Definition at line 1520 of file cfe\_es\_msg.h.

### 11.16.2.26 PerfTriggerCount

```
uint32 CFE_ES_HousekeepingTlm_Payload::PerfTriggerCount
```

Number of Times Performance Analyzer has Triggered.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_PerfTrigCnt

Definition at line 1524 of file cfe\_es\_msg.h.

### 11.16.2.27 PerfTriggerMask

```
uint32 CFE_ES_HousekeepingTlm_Payload::PerfTriggerMask[CFE_MISSION_ES_PERF_MAX_IDS/32]
```

Current Setting of Performance Analyzer Trigger Masks.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_PerfTrigMask[MaskCnt]

Definition at line 1529 of file cfe\_es\_msg.h.

### 11.16.2.28 ProcessorResets

```
uint32 CFE_ES_HousekeepingTlm_Payload::ProcessorResets
```

Number of processor resets since last power on.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_ProcResetCnt

Definition at line 1513 of file cfe\_es\_msg.h.

### 11.16.2.29 PSPMajorVersion

```
uint8 CFE_ES_HousekeepingTlm_Payload::PSPMajorVersion
```

Platform Support Package Major Version Number.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_PSPMAJORVER

Definition at line 1477 of file cfe\_es\_msg.h.

### 11.16.2.30 PSPMinorVersion

```
uint8 CFE_ES_HousekeepingTlm_Payload::PSPMinorVersion
```

Platform Support Package Minor Version Number.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_PSPMINORVER

Definition at line 1479 of file cfe\_es\_msg.h.

### 11.16.2.31 PSPMissionRevision

```
uint8 CFE_ES_HousekeepingTlm_Payload::PSPMissionRevision
```

Platform Support Package MissionRevision Number.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_PSPMISSIONREV

Definition at line 1483 of file cfe\_es\_msg.h.

### 11.16.2.32 PSPRevision

```
uint8 CFE_ES_HousekeepingTlm_Payload::PSPRevision
```

Platform Support Package Revision Number.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_PSPREVISION

Definition at line 1481 of file cfe\_es\_msg.h.

### 11.16.2.33 RegisteredCoreApps

```
uint32 CFE_ES_HousekeepingTlm_Payload::RegisteredCoreApps
```

Number of Applications registered with ES.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_RegCoreApps

Definition at line 1500 of file cfe\_es\_msg.h.

### 11.16.2.34 RegisteredExternalApps

```
uint32 CFE_ES_HousekeepingTlm_Payload::RegisteredExternalApps
```

Number of Applications registered with ES.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_RegExtApps

Definition at line 1502 of file cfe\_es\_msg.h.

### 11.16.2.35 RegisteredLibs

```
uint32 CFE_ES_HousekeepingTlm_Payload::RegisteredLibs
```

Number of Libraries registered with ES.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_RegLibs

Definition at line 1506 of file cfe\_es\_msg.h.

### 11.16.2.36 RegisteredTasks

```
uint32 CFE_ES_HousekeepingTlm_Payload::RegisteredTasks
```

Number of Tasks ( main AND child tasks ) registered with ES.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_RegTasks

Definition at line 1504 of file cfe\_es\_msg.h.

### 11.16.2.37 ResetSubtype

```
uint32 CFE_ES_HousekeepingTlm_Payload::ResetSubtype
```

Reset Sub Type.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_ResetSubtype

Definition at line 1511 of file cfe\_es\_msg.h.

### 11.16.2.38 ResetType

```
uint32 CFE_ES_HousekeepingTlm_Payload::ResetType
```

Reset type ( PROCESSOR or POWERON )

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_ResetType

Definition at line 1509 of file cfe\_es\_msg.h.

### 11.16.2.39 SysLogBytesUsed

```
CFE_ES_MemOffset_t CFE_ES_HousekeepingTlm_Payload::SysLogBytesUsed
```

Total number of bytes used in system log.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_SYSLOGBYTEUSED

Definition at line 1486 of file cfe\_es\_msg.h.

### 11.16.2.40 SysLogEntries

```
uint32 CFE_ES_HousekeepingTlm_Payload::SysLogEntries
```

Number of entries in the system log.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_SYSLOGENTRIES

Definition at line 1490 of file cfe\_es\_msg.h.

#### 11.16.2.41 SysLogMode

`uint32 CFE_ES_HousekeepingTlm_Payload::SysLogMode`

Write/Overwrite Mode.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_SYSLOGMODE

Definition at line 1492 of file cfe\_es\_msg.h.

#### 11.16.2.42 SysLogSize

`CFE_ES_MemOffset_t CFE_ES_HousekeepingTlm_Payload::SysLogSize`

Total size of the system log.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_SYSLOGSIZE

Definition at line 1488 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/cfe\_es\_msg.h

### 11.17 CFE\_ES\_MemPoolStats Struct Reference

Memory Pool Statistics.

```
#include <cfe_es_extern_typedefs.h>
```

#### Data Fields

- **CFE\_ES\_MemOffset\_t PoolSize**  
*Size of Memory Pool (in bytes)*
- **uint32 NumBlocksRequested**  
*Number of times a memory block has been allocated.*
- **uint32 CheckErrCtr**  
*Number of errors detected when freeing a memory block.*
- **CFE\_ES\_MemOffset\_t NumFreeBytes**  
*Number of bytes never allocated to a block.*
- **CFE\_ES\_BlockStats\_t BlockStats [CFE\_MISSION\_ES\_POOL\_MAX\_BUCKETS]**  
*Contains stats on each block size.*

### 11.17.1 Detailed Description

Memory Pool Statistics.

Structure that is used to provide information about a memory pool. Used by the Memory Pool Stats telemetry message.

#### See also

[CFE\\_ES\\_SEND\\_MEM\\_POOL\\_STATS\\_CC](#)

Definition at line 555 of file `cfe_es_extern_typedefs.h`.

### 11.17.2 Field Documentation

#### 11.17.2.1 BlockStats

`CFE_ES_BlockStats_t` `CFE_ES_MemPoolStats::BlockStats[CFE_MISSION_ES_POOL_MAX_BUCKETS]`

Contains stats on each block size.

**Telemetry Mnemonic(s)** `$sc_$cpu_ES_BlkStats[BLK_SIZES]`

Definition at line 565 of file `cfe_es_extern_typedefs.h`.

#### 11.17.2.2 CheckErrCtr

`uint32` `CFE_ES_MemPoolStats::CheckErrCtr`

Number of errors detected when freeing a memory block.

**Telemetry Mnemonic(s)** `$sc_$cpu_ES_BlkErrCTR`

Definition at line 561 of file `cfe_es_extern_typedefs.h`.

### 11.17.2.3 NumBlocksRequested

`uint32 CFE_ES_MemPoolStats::NumBlocksRequested`

Number of times a memory block has been allocated.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_BlkREQ

Definition at line 559 of file cfe\_es\_extern\_typedefs.h.

### 11.17.2.4 NumFreeBytes

`CFE_ES_MemOffset_t CFE_ES_MemPoolStats::NumFreeBytes`

Number of bytes never allocated to a block.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_FreeBytes

Definition at line 563 of file cfe\_es\_extern\_typedefs.h.

### 11.17.2.5 PoolSize

`CFE_ES_MemOffset_t CFE_ES_MemPoolStats::PoolSize`

Size of Memory Pool (in bytes)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_PoolSize

Definition at line 557 of file cfe\_es\_extern\_typedefs.h.

The documentation for this struct was generated from the following file:

- cfe/modules/core\_api/fsw/inc/cfe\_es\_extern\_typedefs.h

## 11.18 CFE\_ES\_MemStatsTlm Struct Reference

```
#include <cfe_es_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_TelemetryHeader\\_t TelemetryHeader](#)  
*Telemetry header.*
- [CFE\\_ES\\_PoolStatsTlm\\_Payload\\_t Payload](#)  
*Telemetry payload.*

### 11.18.1 Detailed Description

Definition at line 1440 of file `cfe_es_msg.h`.

### 11.18.2 Field Documentation

#### 11.18.2.1 Payload

[CFE\\_ES\\_PoolStatsTlm\\_Payload\\_t CFE\\_ES\\_MemStatsTlm::Payload](#)

Telemetry payload.

Definition at line 1443 of file `cfe_es_msg.h`.

#### 11.18.2.2 TelemetryHeader

[CFE\\_MSG\\_TelemetryHeader\\_t CFE\\_ES\\_MemStatsTlm::TelemetryHeader](#)

Telemetry header.

Definition at line 1442 of file `cfe_es_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/es/fsw/inc/cfe_es_msg.h`

## 11.19 CFE\_ES\_NoArgsCmd Struct Reference

Generic "no arguments" command.

```
#include <cfe_es_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) CommandHeader

*Command header.*

### 11.19.1 Detailed Description

Generic "no arguments" command.

This command structure is used for commands that do not have any parameters. This includes:

1. The Housekeeping Request Message
2. The No-Op Command (For details, see [CFE\\_ES\\_NOOP\\_CC](#))
3. The Reset Counters Command (For details, see [CFE\\_ES\\_RESET\\_COUNTERS\\_CC](#))

Definition at line 1059 of file cfe\_es\_msg.h.

### 11.19.2 Field Documentation

#### 11.19.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_ES\_NoArgsCmd::CommandHeader

Command header.

Definition at line 1061 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfe\\_es\\_msg.h](#)

## 11.20 CFE\_ES\_OneAppTlm Struct Reference

```
#include <cfe_es_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_TelemetryHeader\\_t](#) TelemetryHeader

*Telemetry header.*

- [CFE\\_ES\\_OneAppTlm\\_Payload\\_t](#) Payload

*Telemetry payload.*

### 11.20.1 Detailed Description

Definition at line 1424 of file cfe\_es\_msg.h.

### 11.20.2 Field Documentation

#### 11.20.2.1 Payload

[`CFE\_ES\_OneAppTlm\_Payload\_t`](#) `CFE_ES_OneAppTlm::Payload`

Telemetry payload.

Definition at line 1427 of file cfe\_es\_msg.h.

#### 11.20.2.2 TelemetryHeader

[`CFE\_MSG\_TelemetryHeader\_t`](#) `CFE_ES_OneAppTlm::TelemetryHeader`

Telemetry header.

Definition at line 1426 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfe\\_es\\_msg.h](#)

## 11.21 CFE\_ES\_OneAppTlm\_Payload Struct Reference

```
#include <cfe_es_msg.h>
```

### Data Fields

- [`CFE\_ES\_AppInfo\_t`](#) `ApplInfo`

*For more information, see [CFE\\_ES\\_AppInfo\\_t](#).*

### 11.21.1 Detailed Description

**Name** Single Application Information Packet

Definition at line 1418 of file cfe\_es\_msg.h.

## 11.21.2 Field Documentation

### 11.21.2.1 AppInfo

[`CFE\_ES\_AppInfo\_t`](#) `CFE_ES_OneAppTlm_Payload::AppInfo`

For more information, see [`CFE\_ES\_AppInfo\_t`](#).

Definition at line 1420 of file `cfe_es_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/es/fsw/inc/cfe_es_msg.h`

## 11.22 CFE\_ES\_OverWriteSysLogCmd Struct Reference

Overwrite/Discard System Log Configuration Command Payload.

```
#include <cfe_es_msg.h>
```

### Data Fields

- [`CFE\_MSG\_CommandHeader\_t`](#) `CommandHeader`  
*Command header.*
- [`CFE\_ES\_OverWriteSysLogCmd\_Payload\_t`](#) `Payload`  
*Command payload.*

### 11.22.1 Detailed Description

Overwrite/Discard System Log Configuration Command Payload.

Definition at line 1146 of file `cfe_es_msg.h`.

### 11.22.2 Field Documentation

#### 11.22.2.1 CommandHeader

[`CFE\_MSG\_CommandHeader\_t`](#) `CFE_ES_OverWriteSysLogCmd::CommandHeader`

Command header.

Definition at line 1148 of file `cfe_es_msg.h`.

### 11.22.2.2 Payload

`CFE_ES_OverWriteSysLogCmd_Payload_t` `CFE_ES_OverWriteSysLogCmd::Payload`

Command payload.

Definition at line 1149 of file `cfe_es_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/es/fsw/inc/cfe_es_msg.h`

## 11.23 CFE\_ES\_OverWriteSysLogCmd\_Payload Struct Reference

Overwrite/Discard System Log Configuration Command Payload.

```
#include <cfe_es_msg.h>
```

### Data Fields

- `uint32 Mode`

`CFE_ES_LogMode_DISCARD`=Throw away most recent messages, `CFE_ES_LogMode_OVERWRITE`=Overwrite oldest with most recent

### 11.23.1 Detailed Description

Overwrite/Discard System Log Configuration Command Payload.

For command details, see [CFE\\_ES\\_OVER\\_WRITE\\_SYSLOG\\_CC](#)

Definition at line 1136 of file `cfe_es_msg.h`.

### 11.23.2 Field Documentation

#### 11.23.2.1 Mode

`uint32 CFE_ES_OverWriteSysLogCmd::Mode`

`CFE_ES_LogMode_DISCARD`=Throw away most recent messages, `CFE_ES_LogMode_OVERWRITE`=Overwrite oldest with most recent

Definition at line 1138 of file `cfe_es_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/es/fsw/inc/cfe_es_msg.h`

## 11.24 CFE\_ES\_PoolAlign Union Reference

Pool Alignment.

```
#include <cfes_api_typedefs.h>
```

### Data Fields

- void \* **Ptr**  
*Aligned pointer.*
- long long int **LongInt**  
*Aligned Long Integer.*
- long double **LongDouble**  
*Aligned Long Double.*

### 11.24.1 Detailed Description

Pool Alignment.

Union that can be used for minimum memory alignment of ES memory pools on the target. It contains the longest native data types such that the alignment of this structure should reflect the largest possible alignment requirements for any data on this processor.

Definition at line 93 of file cfe\_es\_api\_typedefs.h.

### 11.24.2 Field Documentation

#### 11.24.2.1 LongDouble

```
long double CFE_ES_PoolAlign::LongDouble
```

Aligned Long Double.

Definition at line 98 of file cfe\_es\_api\_typedefs.h.

#### 11.24.2.2 LongInt

```
long long int CFE_ES_PoolAlign::LongInt
```

Aligned Long Integer.

Definition at line 97 of file cfe\_es\_api\_typedefs.h.

### 11.24.2.3 Ptr

```
void* CFE_ES_PoolAlign::Ptr
```

Aligned pointer.

Definition at line 95 of file cfe\_es\_api\_typedefs.h.

The documentation for this union was generated from the following file:

- [cfe/modules/core\\_api/fsw/inc/cfe\\_es\\_api\\_typedefs.h](#)

## 11.25 CFE\_ES\_PoolStatsTlm\_Payload Struct Reference

```
#include <cfe_es_msg.h>
```

### Data Fields

- [CFE\\_ES\\_MemHandle\\_t PoolHandle](#)  
*Handle of memory pool whose stats are being telemetered.*
- [CFE\\_ES\\_MemPoolStats\\_t PoolStats](#)  
*For more info, see [CFE\\_ES\\_MemPoolStats\\_t](#).*

### 11.25.1 Detailed Description

**Name** Memory Pool Statistics Packet

Definition at line 1433 of file cfe\_es\_msg.h.

### 11.25.2 Field Documentation

#### 11.25.2.1 PoolHandle

```
CFE_ES_MemHandle_t CFE_ES_PoolStatsTlm_Payload::PoolHandle
```

Handle of memory pool whose stats are being telemetered.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_ES\_PoolHandle

Definition at line 1435 of file cfe\_es\_msg.h.

### 11.25.2.2 PoolStats

`CFE_ES_MemPoolStats_t` `CFE_ES_PoolStatsTlm_Payload::PoolStats`

For more info, see [CFE\\_ES\\_MemPoolStats\\_t](#).

Definition at line 1437 of file `cfe_es_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/es/fsw/inc/cfe_es_msg.h`

## 11.26 CFE\_ES\_ReloadAppCmd Struct Reference

Reload Application Command.

```
#include <cfe_es_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) `CommandHeader`  
*Command header.*
- [CFE\\_ES\\_AppReloadCmd\\_Payload\\_t](#) `Payload`  
*Command payload.*

### 11.26.1 Detailed Description

Reload Application Command.

Definition at line 1229 of file `cfe_es_msg.h`.

### 11.26.2 Field Documentation

#### 11.26.2.1 CommandHeader

`CFE_MSG_CommandHeader_t` `CFE_ES_ReloadAppCmd::CommandHeader`

Command header.

Definition at line 1231 of file `cfe_es_msg.h`.

### 11.26.2.2 Payload

`CFE_ES_AppReloadCmd_Payload_t CFE_ES_ReloadAppCmd::Payload`

Command payload.

Definition at line 1232 of file `cfe_es_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/es/fsw/inc/cfe_es_msg.h`

## 11.27 CFE\_ES\_RestartCmd Struct Reference

Restart cFE Command.

```
#include <cfe_es_msg.h>
```

### Data Fields

- `CFE_MSG_CommandHeader_t CommandHeader`  
*Command header.*
- `CFE_ES_RestartCmd_Payload_t Payload`  
*Command payload.*

### 11.27.1 Detailed Description

Restart cFE Command.

Definition at line 1092 of file `cfe_es_msg.h`.

### 11.27.2 Field Documentation

#### 11.27.2.1 CommandHeader

`CFE_MSG_CommandHeader_t CFE_ES_RestartCmd::CommandHeader`

Command header.

Definition at line 1094 of file `cfe_es_msg.h`.

### 11.27.2.2 Payload

```
CFE_ES_RestartCmd_Payload_t CFE_ES_RestartCmd::Payload
```

Command payload.

Definition at line 1095 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/cfe\_es\_msg.h

## 11.28 CFE\_ES\_RestartCmd\_Payload Struct Reference

Restart cFE Command Payload.

```
#include <cfe_es_msg.h>
```

### Data Fields

- `uint16 RestartType`  
`CFE_PSP_RST_TYPE_PROCESSOR`=Processor Reset or `CFE_PSP_RST_TYPE_POWERON`=Power-On Reset

### 11.28.1 Detailed Description

Restart cFE Command Payload.

For command details, see [CFE\\_ES\\_RESTART\\_CC](#)

Definition at line 1083 of file cfe\_es\_msg.h.

### 11.28.2 Field Documentation

#### 11.28.2.1 RestartType

```
uint16 CFE_ES_RestartCmd_Payload::RestartType
```

`CFE_PSP_RST_TYPE_PROCESSOR`=Processor Reset or `CFE_PSP_RST_TYPE_POWERON`=Power-On Reset

Definition at line 1085 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/cfe\_es\_msg.h

## 11.29 CFE\_ES\_SendMemPoolStatsCmd Struct Reference

Send Memory Pool Statistics Command.

```
#include <cfes_es_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) **CommandHeader**  
*Command header.*
- [CFE\\_ES\\_SendMemPoolStatsCmd\\_Payload\\_t](#) **Payload**  
*Command payload.*

### 11.29.1 Detailed Description

Send Memory Pool Statistics Command.

Definition at line 1379 of file cfe\_es\_msg.h.

### 11.29.2 Field Documentation

#### 11.29.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_ES\_SendMemPoolStatsCmd::CommandHeader

Command header.

Definition at line 1381 of file cfe\_es\_msg.h.

#### 11.29.2.2 Payload

[CFE\\_ES\\_SendMemPoolStatsCmd\\_Payload\\_t](#) CFE\_ES\_SendMemPoolStatsCmd::Payload

Command payload.

Definition at line 1382 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfes\\_es\\_msg.h](#)

## 11.30 CFE\_ES\_SendMemPoolStatsCmd\_Payload Struct Reference

Send Memory Pool Statistics Command Payload.

```
#include <cfes_es_msg.h>
```

### Data Fields

- char [Application \[CFE\\_MISSION\\_MAX\\_API\\_LEN\]](#)
  - *RESERVED - should be all zeroes*
- [CFE\\_ES\\_MemHandle\\_t PoolHandle](#)  
*Handle of Pool whose statistics are to be telemetered.*

### 11.30.1 Detailed Description

Send Memory Pool Statistics Command Payload.

For command details, see [CFE\\_ES\\_SEND\\_MEM\\_POOL\\_STATS\\_CC](#)

Definition at line 1369 of file cfe\_es\_msg.h.

### 11.30.2 Field Documentation

#### 11.30.2.1 Application

```
char CFE_ES_SendMemPoolStatsCmd_Payload::Application[CFE_MISSION_MAX_API_LEN]
```

- RESERVED - should be all zeroes

Definition at line 1371 of file cfe\_es\_msg.h.

#### 11.30.2.2 PoolHandle

```
CFE_ES_MemHandle_t CFE_ES_SendMemPoolStatsCmd_Payload::PoolHandle
```

Handle of Pool whose statistics are to be telemetered.

Definition at line 1372 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfes\\_es\\_msg.h](#)

## 11.31 CFE\_ES\_SetMaxPRCountCmd Struct Reference

Set Maximum Processor Reset Count Command.

```
#include <cfes_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) **CommandHeader**  
*Command header.*
- [CFE\\_ES\\_SetMaxPRCountCmd\\_Payload\\_t](#) **Payload**  
*Command payload.*

#### 11.31.1 Detailed Description

Set Maximum Processor Reset Count Command.

Definition at line 1250 of file cfe\_es\_msg.h.

#### 11.31.2 Field Documentation

##### 11.31.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) **CFE\_ES\_SetMaxPRCountCmd::CommandHeader**

Command header.

Definition at line 1252 of file cfe\_es\_msg.h.

##### 11.31.2.2 Payload

[CFE\\_ES\\_SetMaxPRCountCmd\\_Payload\\_t](#) **CFE\_ES\_SetMaxPRCountCmd::Payload**

Command payload.

Definition at line 1253 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfes\\_msg.h](#)

## 11.32 CFE\_ES\_SetMaxPRCountCmd\_Payload Struct Reference

Set Maximum Processor Reset Count Command Payload.

```
#include <cfes_es_msg.h>
```

### Data Fields

- `uint16 MaxPRCount`

*New maximum number of Processor Resets before an automatic Power-On Reset is performed.*

### 11.32.1 Detailed Description

Set Maximum Processor Reset Count Command Payload.

For command details, see [CFE\\_ES\\_SET\\_MAX\\_PR\\_COUNT\\_CC](#)

Definition at line 1241 of file cfe\_es\_msg.h.

### 11.32.2 Field Documentation

#### 11.32.2.1 MaxPRCount

```
uint16 CFE_ES_SetMaxPRCountCmd_Payload::MaxPRCount
```

New maximum number of Processor Resets before an automatic Power-On Reset is performed.

Definition at line 1243 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfes\\_es\\_msg.h](#)

## 11.33 CFE\_ES\_SetPerfFilterMaskCmd Struct Reference

Set Performance Analyzer Filter Mask Command.

```
#include <cfes_es_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) CommandHeader  
*Command header.*
- [CFE\\_ES\\_SetPerfFilterMaskCmd\\_Payload\\_t](#) Payload  
*Command payload.*

### 11.33.1 Detailed Description

Set Performance Analyzer Filter Mask Command.

Definition at line 1335 of file cfe\_es\_msg.h.

### 11.33.2 Field Documentation

#### 11.33.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_ES\_SetPerfFilterMaskCmd::CommandHeader

Command header.

Definition at line 1337 of file cfe\_es\_msg.h.

#### 11.33.2.2 Payload

[CFE\\_ES\\_SetPerfFilterMaskCmd\\_Payload\\_t](#) CFE\_ES\_SetPerfFilterMaskCmd::Payload

Command payload.

Definition at line 1338 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfe\\_es\\_msg.h](#)

## 11.34 CFE\_ES\_SetPerfFilterMaskCmd\_Payload Struct Reference

Set Performance Analyzer Filter Mask Command Payload.

```
#include <cfe_es_msg.h>
```

## Data Fields

- `uint32 FilterMaskNum`  
*Index into array of Filter Masks.*
- `uint32 FilterMask`  
*New Mask for specified entry in array of Filter Masks.*

### 11.34.1 Detailed Description

Set Performance Analyzer Filter Mask Command Payload.

For command details, see [CFE\\_ES\\_SET\\_PERF\\_FILTER\\_MASK\\_CC](#)

Definition at line 1325 of file cfe\_es\_msg.h.

### 11.34.2 Field Documentation

#### 11.34.2.1 FilterMask

`uint32 CFE_ES_SetPerfFilterMaskCmd_Payload::FilterMask`

New Mask for specified entry in array of Filter Masks.

Definition at line 1328 of file cfe\_es\_msg.h.

#### 11.34.2.2 FilterMaskNum

`uint32 CFE_ES_SetPerfFilterMaskCmd_Payload::FilterMaskNum`

Index into array of Filter Masks.

Definition at line 1327 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfe\\_es\\_msg.h](#)

## 11.35 CFE\_ES\_SetPerfTriggerMaskCmd Struct Reference

Set Performance Analyzer Trigger Mask Command.

```
#include <cfe_es_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) CommandHeader  
*Command header.*
- [CFE\\_ES\\_SetPerfTrigMaskCmd\\_Payload\\_t](#) Payload  
*Command payload.*

### 11.35.1 Detailed Description

Set Performance Analyzer Trigger Mask Command.

Definition at line 1357 of file cfe\_es\_msg.h.

### 11.35.2 Field Documentation

#### 11.35.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_ES\_SetPerfTriggerMaskCmd::CommandHeader

Command header.

Definition at line 1359 of file cfe\_es\_msg.h.

#### 11.35.2.2 Payload

[CFE\\_ES\\_SetPerfTrigMaskCmd\\_Payload\\_t](#) CFE\_ES\_SetPerfTriggerMaskCmd::Payload

Command payload.

Definition at line 1360 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfe\\_es\\_msg.h](#)

## 11.36 CFE\_ES\_SetPerfTrigMaskCmd\_Payload Struct Reference

Set Performance Analyzer Trigger Mask Command Payload.

```
#include <cfe_es_msg.h>
```

## Data Fields

- `uint32 TriggerMaskNum`  
*Index into array of Trigger Masks.*
- `uint32 TriggerMask`  
*New Mask for specified entry in array of Trigger Masks.*

### 11.36.1 Detailed Description

Set Performance Analyzer Trigger Mask Command Payload.

For command details, see [CFE\\_ES\\_SET\\_PERF\\_TRIGGER\\_MASK\\_CC](#)

Definition at line 1347 of file `cfe_es_msg.h`.

### 11.36.2 Field Documentation

#### 11.36.2.1 TriggerMask

`uint32 CFE_ES_SetPerfTrigMaskCmd_Payload::TriggerMask`

New Mask for specified entry in array of Trigger Masks.

Definition at line 1350 of file `cfe_es_msg.h`.

#### 11.36.2.2 TriggerMaskNum

`uint32 CFE_ES_SetPerfTrigMaskCmd_Payload::TriggerMaskNum`

Index into array of Trigger Masks.

Definition at line 1349 of file `cfe_es_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/es/fsw/inc/cfe_es_msg.h`

## 11.37 CFE\_ES\_StartApp Struct Reference

Start Application Command.

```
#include <cfe_es_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) CommandHeader  
*Command header.*
- [CFE\\_ES\\_StartAppCmd\\_Payload\\_t](#) Payload  
*Command payload.*

### 11.37.1 Detailed Description

Start Application Command.

Definition at line 1178 of file cfe\_es\_msg.h.

### 11.37.2 Field Documentation

#### 11.37.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_ES\_StartApp::CommandHeader

Command header.

Definition at line 1180 of file cfe\_es\_msg.h.

#### 11.37.2.2 Payload

[CFE\\_ES\\_StartAppCmd\\_Payload\\_t](#) CFE\_ES\_StartApp::Payload

Command payload.

Definition at line 1181 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfe\\_es\\_msg.h](#)

## 11.38 CFE\_ES\_StartAppCmd\_Payload Struct Reference

Start Application Command Payload.

```
#include <cfe_es_msg.h>
```

## Data Fields

- char [Application](#) [CFE\_MISSION\_MAX\_API\_LEN]  
*Name of Application to be started.*
- char [AppEntryPoint](#) [CFE\_MISSION\_MAX\_API\_LEN]  
*Symbolic name of Application's entry point.*
- char [AppFileName](#) [CFE\_MISSION\_MAX\_PATH\_LEN]  
*Full path and filename of Application's executable image.*
- [CFE\\_ES\\_MemOffset\\_t](#) [StackSize](#)  
*Desired stack size for the new application.*
- [CFE\\_ES\\_ExceptionAction\\_Enum\\_t](#) [ExceptionAction](#)  
*CFE\_ES\_ExceptionAction\_RESTART\_APP=On exception, restart Application, CFE\_ES\_ExceptionAction\_PROC\_RESET=On exception, perform a Processor Reset*
- [CFE\\_ES\\_TaskPriority\\_Atom\\_t](#) [Priority](#)  
*The new Applications runtime priority.*

### 11.38.1 Detailed Description

Start Application Command Payload.

For command details, see [CFE\\_ES\\_START\\_APP\\_CC](#)

Definition at line 1158 of file cfe\_es\_msg.h.

### 11.38.2 Field Documentation

#### 11.38.2.1 AppEntryPoint

```
char CFE_ES_StartAppCmd_Payload::AppEntryPoint[CFE_MISSION_MAX_API_LEN]
```

Symbolic name of Application's entry point.

Definition at line 1161 of file cfe\_es\_msg.h.

#### 11.38.2.2 AppFileName

```
char CFE_ES_StartAppCmd_Payload::AppFileName[CFE_MISSION_MAX_PATH_LEN]
```

Full path and filename of Application's executable image.

Definition at line 1162 of file cfe\_es\_msg.h.

### 11.38.2.3 Application

```
char CFE_ES_StartAppCmd_Payload::Application[CFE_MISSION_MAX_API_LEN]
```

Name of Application to be started.

Definition at line 1160 of file cfe\_es\_msg.h.

### 11.38.2.4 ExceptionAction

```
CFE_ES_ExceptionAction_Enum_t CFE_ES_StartAppCmd_Payload::ExceptionAction
```

**CFE\_ES\_ExceptionAction\_RESTART\_APP**=On exception, restart Application, **CFE\_ES\_ExceptionAction\_PROC\_RESET**=On exception, perform a Processor Reset

Definition at line 1167 of file cfe\_es\_msg.h.

### 11.38.2.5 Priority

```
CFE_ES_TaskPriority_Atom_t CFE_ES_StartAppCmd_Payload::Priority
```

The new Applications runtime priority.

Definition at line 1171 of file cfe\_es\_msg.h.

### 11.38.2.6 StackSize

```
CFE_ES_MemOffset_t CFE_ES_StartAppCmd_Payload::StackSize
```

Desired stack size for the new application.

Definition at line 1165 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/cfe\_es\_msg.h

## 11.39 CFE\_ES\_StartPerfCmd\_Payload Struct Reference

Start Performance Analyzer Command Payload.

```
#include <cfe_es_msg.h>
```

## Data Fields

- [uint32 TriggerMode](#)

*Desired trigger position (Start, Center, End)*

### 11.39.1 Detailed Description

Start Performance Analyzer Command Payload.

For command details, see [CFE\\_ES\\_START\\_PERF\\_DATA\\_CC](#)

Definition at line 1284 of file cfe\_es\_msg.h.

### 11.39.2 Field Documentation

#### 11.39.2.1 TriggerMode

`uint32 CFE_ES_StartPerfCmd_Payload::TriggerMode`

Desired trigger position (Start, Center, End)

Definition at line 1286 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfe\\_es\\_msg.h](#)

## 11.40 CFE\_ES\_StartPerfDataCmd Struct Reference

Start Performance Analyzer Command.

```
#include <cfe_es_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CommandHeader](#)

*Command header.*

- [CFE\\_ES\\_StartPerfCmd\\_Payload\\_t Payload](#)

*Command payload.*

### 11.40.1 Detailed Description

Start Performance Analyzer Command.

Definition at line 1292 of file cfe\_es\_msg.h.

### 11.40.2 Field Documentation

#### 11.40.2.1 CommandHeader

`CFE_MSG_CommandHeader_t` `CFE_ES_StartPerfDataCmd::CommandHeader`

Command header.

Definition at line 1294 of file cfe\_es\_msg.h.

#### 11.40.2.2 Payload

`CFE_ES_StartPerfCmd_Payload_t` `CFE_ES_StartPerfDataCmd::Payload`

Command payload.

Definition at line 1295 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- `cfe/modules/es/fsw/inc/cfe_es_msg.h`

## 11.41 CFE\_ES\_StopPerfCmd\_Payload Struct Reference

Stop Performance Analyzer Command Payload.

```
#include <cfe_es_msg.h>
```

### Data Fields

- char `DataFileName` [`CFE_MISSION_MAX_PATH_LEN`]

*ASCII text string of full path and filename of file Performance Analyzer data is to be written.*

### 11.41.1 Detailed Description

Stop Performance Analyzer Command Payload.

For command details, see [CFE\\_ES\\_STOP\\_PERF\\_DATA\\_CC](#)

Definition at line 1304 of file cfe\_es\_msg.h.

### 11.41.2 Field Documentation

#### 11.41.2.1 DataFileName

```
char CFE_ES_StopPerfCmd_Payload::DataFileName[CFE\_MISSION\_MAX\_PATH\_LEN]
```

ASCII text string of full path and filename of file Performance Analyzer data is to be written.

Definition at line 1306 of file cfe\_es\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/es/fsw/inc/[cfe\\_es\\_msg.h](#)

## 11.42 CFE\_ES\_StopPerfDataCmd Struct Reference

Stop Performance Analyzer Command.

```
#include <cfe_es_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) CommandHeader  
*Command header.*
- [CFE\\_ES\\_StopPerfCmd\\_Payload\\_t](#) Payload  
*Command payload.*

### 11.42.1 Detailed Description

Stop Performance Analyzer Command.

Definition at line 1313 of file cfe\_es\_msg.h.

### 11.42.2 Field Documentation

#### 11.42.2.1 CommandHeader

`CFE_MSG_CommandHeader_t` `CFE_ES_StopPerfDataCmd::CommandHeader`

Command header.

Definition at line 1315 of file `cfe_es_msg.h`.

#### 11.42.2.2 Payload

`CFE_ES_StopPerfCmd_Payload_t` `CFE_ES_StopPerfDataCmd::Payload`

Command payload.

Definition at line 1316 of file `cfe_es_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/es/fsw/inc/cfe_es_msg.h`

## 11.43 CFE\_ES\_TaskInfo Struct Reference

Task Information.

```
#include <cfe_es_extern_typedefs.h>
```

### Data Fields

- `CFE_ES_TaskId_t TaskId`  
*Task Id.*
- `uint32 ExecutionCounter`  
*Task Execution Counter.*
- `char TaskName [CFE_MISSION_MAX_API_LEN]`  
*Task Name.*
- `CFE_ES_AppId_t Appld`  
*Parent Application ID.*
- `charAppName [CFE_MISSION_MAX_API_LEN]`  
*Parent Application Name.*
- `CFE_ES_MemOffset_t StackSize`
- `CFE_ES_TaskPriority_Atom_t Priority`
- `uint8 Spare [2]`

### 11.43.1 Detailed Description

Task Information.

Structure that is used to provide information about a task. It is primarily used for the Query All Tasks ([CFE\\_ES\\_QUERY\\_ALL\\_TASKS\\_CC](#)) command.

#### Note

There is not currently a telemetry message directly containing this data structure, but it does define the format of the data file generated by the Query All Tasks command. Therefore it should be considered part of the overall telemetry interface.

Definition at line 501 of file `cfe_es_extern_typedefs.h`.

### 11.43.2 Field Documentation

#### 11.43.2.1 AppId

`CFE_ES_AppId_t` `CFE_ES_TaskInfo::AppId`

Parent Application ID.

Definition at line 506 of file `cfe_es_extern_typedefs.h`.

#### 11.43.2.2 AppName

`char` `CFE_ES_TaskInfo::AppName[CFE_MISSION_MAX_API_LEN]`

Parent Application Name.

Definition at line 507 of file `cfe_es_extern_typedefs.h`.

#### 11.43.2.3 ExecutionCounter

`uint32` `CFE_ES_TaskInfo::ExecutionCounter`

Task Execution Counter.

Definition at line 504 of file `cfe_es_extern_typedefs.h`.

#### 11.43.2.4 Priority

`CFE_ES_TaskPriority_Atom_t CFE_ES_TaskInfo::Priority`

Priority of task

Definition at line 509 of file `cfe_es_extern_typedefs.h`.

#### 11.43.2.5 Spare

`uint8 CFE_ES_TaskInfo::Spare[2]`

Spare bytes for alignment

Definition at line 510 of file `cfe_es_extern_typedefs.h`.

#### 11.43.2.6 StackSize

`CFE_ES_MemOffset_t CFE_ES_TaskInfo::StackSize`

Size of task stack

Definition at line 508 of file `cfe_es_extern_typedefs.h`.

#### 11.43.2.7 TaskId

`CFE_ES_TaskId_t CFE_ES_TaskInfo::TaskId`

Task Id.

Definition at line 503 of file `cfe_es_extern_typedefs.h`.

#### 11.43.2.8 TaskName

`char CFE_ES_TaskInfo::TaskName[CFE_MISSION_MAX_API_LEN]`

Task Name.

Definition at line 505 of file `cfe_es_extern_typedefs.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/core_api/fsw/inc/cfe_es_extern_typedefs.h`

## 11.44 CFE\_EVS\_AppDataCmd\_Payload Struct Reference

Write Event Services Application Information to File Command Payload.

```
#include <cfе_evs_msg.h>
```

### Data Fields

- char AppDataFilename [CFE\_MISSION\_MAX\_PATH\_LEN]

*Filename where application data is to be written.*

### 11.44.1 Detailed Description

Write Event Services Application Information to File Command Payload.

For command details, see [CFE\\_EVS\\_WRITE\\_APP\\_DATA\\_FILE\\_CC](#)

Definition at line 945 of file cfe\_evs\_msg.h.

### 11.44.2 Field Documentation

#### 11.44.2.1 AppDataFilename

```
char CFE_EVS_AppDataCmd_Payload::AppDataFilename [CFE_MISSION_MAX_PATH_LEN]
```

Filename where application data is to be written.

Definition at line 947 of file cfe\_evs\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/evs/fsw/inc/[cfe\\_evs\\_msg.h](#)

## 11.45 CFE\_EVS\_AppNameBitMaskCmd Struct Reference

Generic App Name and Bitmask Command.

```
#include <cfе_evs_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) CommandHeader  
*Command header.*
- [CFE\\_EVS\\_AppNameBitMaskCmd\\_Payload\\_t](#) Payload  
*Command payload.*

### 11.45.1 Detailed Description

Generic App Name and Bitmask Command.

Definition at line 1109 of file cfe\_evs\_msg.h.

### 11.45.2 Field Documentation

#### 11.45.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_EVS\_AppNameBitMaskCmd::CommandHeader

Command header.

Definition at line 1111 of file cfe\_evs\_msg.h.

#### 11.45.2.2 Payload

[CFE\\_EVS\\_AppNameBitMaskCmd\\_Payload\\_t](#) CFE\_EVS\_AppNameBitMaskCmd::Payload

Command payload.

Definition at line 1112 of file cfe\_evs\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/evs/fsw/inc/[cfe\\_evs\\_msg.h](#)

## 11.46 CFE\_EVS\_AppNameBitMaskCmd\_Payload Struct Reference

Generic App Name and Bitmask Command Payload.

```
#include <cfe_evs_msg.h>
```

## Data Fields

- char `AppName [CFE_MISSION_MAX_API_LEN]`  
*Application name to use in the command.*
- `uint8 BitMask`  
*BitMask to use in the command.*
- `uint8 Spare`  
*Pad to even byte.*

### 11.46.1 Detailed Description

Generic App Name and Bitmask Command Payload.

For command details, see `CFE_EVS_ENABLE_APP_EVENT_TYPE_CC` and/or `CFE_EVS_DISABLE_APP_EVENT_TYPE_CC`

Definition at line 1099 of file `cfe_evs_msg.h`.

### 11.46.2 Field Documentation

#### 11.46.2.1 AppName

```
char CFE_EVS_AppNameBitMaskCmd_Payload::AppName [CFE_MISSION_MAX_API_LEN]
```

Application name to use in the command.

Definition at line 1101 of file `cfe_evs_msg.h`.

#### 11.46.2.2 BitMask

```
uint8 CFE_EVS_AppNameBitMaskCmd_Payload::BitMask
```

BitMask to use in the command.

Definition at line 1102 of file `cfe_evs_msg.h`.

### 11.46.2.3 Spare

```
uint8 CFE_EVS_AppNameBitMaskCmd_Payload::Spare
```

Pad to even byte.

Definition at line 1103 of file cfe\_evs\_msg.h.

The documentation for this struct was generated from the following file:

- [cfe/modules/evs/fsw/inc/cfe\\_evs\\_msg.h](#)

## 11.47 CFE\_EVS\_AppNameCmd Struct Reference

Generic App Name Command.

```
#include <cfe_evs_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CommandHeader](#)  
*Command header.*
- [CFE\\_EVS\\_AppNameCmd\\_Payload\\_t Payload](#)  
*Command payload.*

### 11.47.1 Detailed Description

Generic App Name Command.

Definition at line 1048 of file cfe\_evs\_msg.h.

### 11.47.2 Field Documentation

#### 11.47.2.1 CommandHeader

```
CFE_MSG_CommandHeader_t CFE_EVS_AppNameCmd::CommandHeader
```

Command header.

Definition at line 1050 of file cfe\_evs\_msg.h.

### 11.47.2.2 Payload

`CFE_EVS_AppNameCmd_Payload_t` `CFE_EVS_AppNameCmd::Payload`

Command payload.

Definition at line 1051 of file `cfe_evs_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/evs/fsw/inc/cfe_evs_msg.h`

## 11.48 CFE\_EVS\_AppNameCmd\_Payload Struct Reference

Generic App Name Command Payload.

```
#include <cfe_evs_msg.h>
```

### Data Fields

- `char AppName [CFE_MISSION_MAX_API_LEN]`  
*Application name to use in the command.*

### 11.48.1 Detailed Description

Generic App Name Command Payload.

For command details, see `CFE_EVS_ENABLE_APP_EVENTS_CC`, `CFE_EVS_DISABLE_APP_EVENTS_CC`, `CFE_EVS_RESET_APP_COUNTER_CC` and/or `CFE_EVS_RESET_ALL_FILTERS_CC`

Definition at line 1040 of file `cfe_evs_msg.h`.

### 11.48.2 Field Documentation

#### 11.48.2.1 AppName

`char CFE_EVS_AppNameCmd_Payload::AppName [CFE_MISSION_MAX_API_LEN]`

Application name to use in the command.

Definition at line 1042 of file `cfe_evs_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/evs/fsw/inc/cfe_evs_msg.h`

## 11.49 CFE\_EVS\_AppNameEventIDCmd Struct Reference

Generic App Name and Event ID Command.

```
#include <cfе_evs_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) `CommandHeader`  
*Command header.*
- [CFE\\_EVS\\_AppNameEventIDCmd\\_Payload\\_t](#) `Payload`  
*Command payload.*

#### 11.49.1 Detailed Description

Generic App Name and Event ID Command.

Definition at line 1079 of file `cfе_evs_msg.h`.

#### 11.49.2 Field Documentation

##### 11.49.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) `CFE_EVS_AppNameEventIDCmd::CommandHeader`

Command header.

Definition at line 1081 of file `cfе_evs_msg.h`.

##### 11.49.2.2 Payload

[CFE\\_EVS\\_AppNameEventIDCmd\\_Payload\\_t](#) `CFE_EVS_AppNameEventIDCmd::Payload`

Command payload.

Definition at line 1082 of file `cfе_evs_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/evs/fsw/inc/cfe_evs_msg.h`

## 11.50 CFE\_EVS\_AppNameEventIDCmd\_Payload Struct Reference

Generic App Name and Event ID Command Payload.

```
#include <cfе_evs_msg.h>
```

### Data Fields

- char [AppName \[CFE\\_MISSION\\_MAX\\_API\\_LEN\]](#)  
*Application name to use in the command.*
- [uint16 EventID](#)  
*Event ID to use in the command.*

### 11.50.1 Detailed Description

Generic App Name and Event ID Command Payload.

For command details, see [CFE\\_EVS\\_RESET\\_FILTER\\_CC](#) and [CFE\\_EVS\\_DELETE\\_EVENT\\_FILTER\\_CC](#)

Definition at line 1070 of file cfe\_evs\_msg.h.

### 11.50.2 Field Documentation

#### 11.50.2.1 AppName

```
char CFE_EVS_AppNameEventIDCmd_Payload::AppName[CFE_MISSION_MAX_API_LEN]
```

Application name to use in the command.

Definition at line 1072 of file cfe\_evs\_msg.h.

#### 11.50.2.2 EventID

```
uint16 CFE_EVS_AppNameEventIDCmd_Payload::EventID
```

Event ID to use in the command.

Definition at line 1073 of file cfe\_evs\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/evs/fsw/inc/[cfе\\_evs\\_msg.h](#)

## 11.51 CFE\_EVS\_AppNameEventIDMaskCmd Struct Reference

Generic App Name, Event ID, Mask Command.

```
#include <cfе_evs_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) `CommandHeader`  
*Command header.*
- [CFE\\_EVS\\_AppNameEventIDMaskCmd\\_Payload\\_t](#) `Payload`  
*Command payload.*

#### 11.51.1 Detailed Description

Generic App Name, Event ID, Mask Command.

Definition at line 1140 of file `cfе_evs_msg.h`.

#### 11.51.2 Field Documentation

##### 11.51.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) `CFE_EVS_AppNameEventIDMaskCmd::CommandHeader`

Command header.

Definition at line 1142 of file `cfе_evs_msg.h`.

##### 11.51.2.2 Payload

[CFE\\_EVS\\_AppNameEventIDMaskCmd\\_Payload\\_t](#) `CFE_EVS_AppNameEventIDMaskCmd::Payload`

Command payload.

Definition at line 1143 of file `cfе_evs_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/evs/fsw/inc/cfe_evs_msg.h`

## 11.52 CFE\_EVS\_AppNameEventIDMaskCmd\_Payload Struct Reference

Generic App Name, Event ID, Mask Command Payload.

```
#include <cfе_evs_msg.h>
```

### Data Fields

- char [AppName \[CFE\\_MISSION\\_MAX\\_API\\_LEN\]](#)  
*Application name to use in the command.*
- [uint16 EventID](#)  
*Event ID to use in the command.*
- [uint16 Mask](#)  
*Mask to use in the command.*

### 11.52.1 Detailed Description

Generic App Name, Event ID, Mask Command Payload.

For command details, see [CFE\\_EVS\\_SET\\_FILTER\\_CC](#), [CFE\\_EVS\\_ADD\\_EVENT\\_FILTER\\_CC](#) and/or [CFE\\_EVS\\_DELETE\\_EVENT\\_FILTER\\_CC](#)

Definition at line 1130 of file cfe\_evs\_msg.h.

### 11.52.2 Field Documentation

#### 11.52.2.1 AppName

```
char CFE_EVS_AppNameEventIDMaskCmd_Payload::AppName [CFE_MISSION_MAX_API_LEN]
```

Application name to use in the command.

Definition at line 1132 of file cfe\_evs\_msg.h.

#### 11.52.2.2 EventID

```
uint16 CFE_EVS_AppNameEventIDMaskCmd_Payload::EventID
```

Event ID to use in the command.

Definition at line 1133 of file cfe\_evs\_msg.h.

### 11.52.2.3 Mask

```
uint16 CFE_EVS_AppNameEventIDMaskCmd_Payload::Mask
```

Mask to use in the command.

Definition at line 1134 of file cfe\_evs\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/evs/fsw/inc/cfe\_evs\_msg.h

## 11.53 CFE\_EVS\_AppTlmData Struct Reference

```
#include <cfe_evs_msg.h>
```

### Data Fields

- [CFE\\_ES\\_AppId\\_t AppID](#)  
*Numerical application identifier.*
- [uint16 AppMessageSentCounter](#)  
*Application message sent counter.*
- [uint8 AppEnableStatus](#)  
*Application event service enable status.*
- [uint8 AppMessageSquelchedCounter](#)  
*Number of events squelched.*

### 11.53.1 Detailed Description

Definition at line 1158 of file cfe\_evs\_msg.h.

### 11.53.2 Field Documentation

#### 11.53.2.1 AppEnableStatus

```
uint8 CFE_EVS_AppTlmData::AppEnableStatus
```

Application event service enable status.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_APP[CFE\_PLATFORM\_ES\_MAX\_APPLICATIONS].APPENASTAT

Definition at line 1164 of file cfe\_evs\_msg.h.

### 11.53.2.2 AppID

`CFE_ES_AppId_t` `CFE_EVS_AppTlmData::AppID`

Numerical application identifier.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_APP[CFE\_PLATFORM\_ES\_MAX\_APPLICATIONS].APPID

Definition at line 1160 of file `cfe_evs_msg.h`.

### 11.53.2.3 AppMessageSentCounter

`uint16` `CFE_EVS_AppTlmData::AppMessageSentCounter`

Application message sent counter.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_APP[CFE\_PLATFORM\_ES\_MAX\_APPLICATIONS].APPMMSGSENTC

Definition at line 1162 of file `cfe_evs_msg.h`.

### 11.53.2.4 AppMessageSquelchedCounter

`uint8` `CFE_EVS_AppTlmData::AppMessageSquelchedCounter`

Number of events squelched.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_APP[CFE\_PLATFORM\_ES\_MAX\_APPLICATIONS].SQUELCHEDC

Definition at line 1166 of file `cfe_evs_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/evs/fsw/inc/cfe_evs_msg.h`

## 11.54 CFE\_EVS\_BinFilter Struct Reference

Event message filter definition structure.

```
#include <cfe_evs_api_typedefs.h>
```

## Data Fields

- `uint16 EventID`  
*Numerical event identifier.*
- `uint16 Mask`  
*Binary filter mask value.*

### 11.54.1 Detailed Description

Event message filter definition structure.

Definition at line 60 of file `cfe_evs_api_typedefs.h`.

### 11.54.2 Field Documentation

#### 11.54.2.1 EventID

`uint16 CFE_EVS_BinFilter::EventID`

Numerical event identifier.

Definition at line 62 of file `cfe_evs_api_typedefs.h`.

#### 11.54.2.2 Mask

`uint16 CFE_EVS_BinFilter::Mask`

Binary filter mask value.

Definition at line 63 of file `cfe_evs_api_typedefs.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/core_api/fsw/inc/cfe_evs_api_typedefs.h`

## 11.55 CFE\_EVS\_BitMaskCmd Struct Reference

Generic Bitmask Command.

```
#include <cfe_evs_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) CommandHeader  
*Command header.*
- [CFE\\_EVS\\_BitMaskCmd\\_Payload\\_t](#) Payload  
*Command payload.*

### 11.55.1 Detailed Description

Generic Bitmask Command.

Definition at line 1017 of file cfe\_evs\_msg.h.

### 11.55.2 Field Documentation

#### 11.55.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_EVS\_BitMaskCmd::CommandHeader

Command header.

Definition at line 1019 of file cfe\_evs\_msg.h.

#### 11.55.2.2 Payload

[CFE\\_EVS\\_BitMaskCmd\\_Payload\\_t](#) CFE\_EVS\_BitMaskCmd::Payload

Command payload.

Definition at line 1020 of file cfe\_evs\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/evs/fsw/inc/[cfe\\_evs\\_msg.h](#)

## 11.56 CFE\_EVS\_BitMaskCmd\_Payload Struct Reference

Generic Bitmask Command Payload.

```
#include <cfe_evs_msg.h>
```

## Data Fields

- `uint8 BitMask`  
*BitMask to use in the command.*
- `uint8 Spare`  
*Pad to even byte.*

### 11.56.1 Detailed Description

Generic Bitmask Command Payload.

For command details, see [CFE\\_EVS\\_ENABLE\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_DISABLE\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_ENABLE\\_PORTS\\_CC](#) and/or [CFE\\_EVS\\_DISABLE\\_PORTS\\_CC](#)

Definition at line 1008 of file `cfe_evs_msg.h`.

### 11.56.2 Field Documentation

#### 11.56.2.1 BitMask

`uint8 CFE_EVS_BitMaskCmd_Payload::BitMask`

BitMask to use in the command.

Definition at line 1010 of file `cfe_evs_msg.h`.

#### 11.56.2.2 Spare

`uint8 CFE_EVS_BitMaskCmd_Payload::Spare`

Pad to even byte.

Definition at line 1011 of file `cfe_evs_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/evs/fsw/inc/cfe_evs_msg.h`

## 11.57 CFE\_EVS\_HousekeepingTim Struct Reference

```
#include <cfe_evs_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_TelemetryHeader\\_t](#) TelemetryHeader  
*Telemetry header.*
- [CFE\\_EVS\\_HousekeepingTlm\\_Payload\\_t](#) Payload  
*Telemetry payload.*

### 11.57.1 Detailed Description

Definition at line 1213 of file cfe\_evs\_msg.h.

### 11.57.2 Field Documentation

#### 11.57.2.1 Payload

[CFE\\_EVS\\_HousekeepingTlm\\_Payload\\_t](#) CFE\_EVS\_HousekeepingTlm::Payload

Telemetry payload.

Definition at line 1216 of file cfe\_evs\_msg.h.

#### 11.57.2.2 TelemetryHeader

[CFE\\_MSG\\_TelemetryHeader\\_t](#) CFE\_EVS\_HousekeepingTlm::TelemetryHeader

Telemetry header.

Definition at line 1215 of file cfe\_evs\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/evs/fsw/inc/[cfe\\_evs\\_msg.h](#)

## 11.58 CFE\_EVS\_HousekeepingTlm\_Payload Struct Reference

```
#include <cfe_evs_msg.h>
```

## Data Fields

- `uint8 CommandCounter`  
*EVS Command Counter.*
- `uint8 CommandErrorCounter`  
*EVS Command Error Counter.*
- `uint8 MessageFormatMode`  
*Event message format mode (short/long)*
- `uint8 MessageTruncCounter`  
*Event message truncation counter.*
- `uint8 UnregisteredAppCounter`  
*Unregistered application message send counter.*
- `uint8 OutputPort`  
*Output port mask.*
- `uint8 LogFullFlag`  
*Local event log full flag.*
- `uint8 LogMode`  
*Local event logging mode (overwrite/discard)*
- `uint16 MessageSendCounter`  
*Event message send counter.*
- `uint16 LogOverflowCounter`  
*Local event log overflow counter.*
- `uint8 LogEnabled`  
*Current event log enable/disable state.*
- `uint8 Spare1`  
*Padding for 32 bit boundary.*
- `uint8 Spare2`  
*Padding for 32 bit boundary.*
- `uint8 Spare3`  
*Padding for 32 bit boundary.*
- `CFE_EVS_AppTlmData_t AppData [CFE_MISSION_ES_MAX_APPLICATIONS]`  
*Array of registered application table data.*

### 11.58.1 Detailed Description

**Name** Event Services Housekeeping Telemetry Packet

Definition at line 1174 of file cfe\_evs\_msg.h.

### 11.58.2 Field Documentation

### 11.58.2.1 AppData

`CFE_EVS_AppTlmData_t CFE_EVS_HousekeepingTlm_Payload::AppData[CFE_MISSION_ES_MAX_APPLICATIONS]`

Array of registered application table data.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_APP[CFE\_PLATFORM\_ES\_MAX\_APPLICATIONS]

Definition at line 1208 of file cfe\_evs\_msg.h.

### 11.58.2.2 CommandCounter

`uint8 CFE_EVS_HousekeepingTlm_Payload::CommandCounter`

EVS Command Counter.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_CMDPC

Definition at line 1176 of file cfe\_evs\_msg.h.

### 11.58.2.3 CommandErrorCounter

`uint8 CFE_EVS_HousekeepingTlm_Payload::CommandErrorCounter`

EVS Command Error Counter.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_CMDEC

Definition at line 1178 of file cfe\_evs\_msg.h.

### 11.58.2.4 LogEnabled

`uint8 CFE_EVS_HousekeepingTlm_Payload::LogEnabled`

Current event log enable/disable state.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_LOGENABLED

Definition at line 1199 of file cfe\_evs\_msg.h.

### 11.58.2.5 LogFullFlag

```
uint8 CFE_EVS_HousekeepingTlm_Payload::LogFullFlag
```

Local event log full flag.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_LOGFULL

Definition at line 1189 of file cfe\_evs\_msg.h.

### 11.58.2.6 LogMode

```
uint8 CFE_EVS_HousekeepingTlm_Payload::LogMode
```

Local event logging mode (overwrite/discard)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_LOGMODE

Definition at line 1191 of file cfe\_evs\_msg.h.

### 11.58.2.7 LogOverflowCounter

```
uint16 CFE_EVS_HousekeepingTlm_Payload::LogOverflowCounter
```

Local event log overflow counter.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_LOGOVERFLOWC

Definition at line 1196 of file cfe\_evs\_msg.h.

### 11.58.2.8 MessageFormatMode

```
uint8 CFE_EVS_HousekeepingTlm_Payload::MessageFormatMode
```

Event message format mode (short/long)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_MSGFMTMODE

Definition at line 1180 of file cfe\_evs\_msg.h.

### 11.58.2.9 MessageSendCounter

```
uint16 CFE_EVS_HousekeepingTlm_Payload::MessageSendCounter
```

Event message send counter.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_MSGSENTC

Definition at line 1194 of file cfe\_evs\_msg.h.

### 11.58.2.10 MessageTruncCounter

```
uint8 CFE_EVS_HousekeepingTlm_Payload::MessageTruncCounter
```

Event message truncation counter.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_MSGTRUNC

Definition at line 1182 of file cfe\_evs\_msg.h.

### 11.58.2.11 OutputPort

```
uint8 CFE_EVS_HousekeepingTlm_Payload::OutputPort
```

Output port mask.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_OUTPUTPORT

Definition at line 1187 of file cfe\_evs\_msg.h.

### 11.58.2.12 Spare1

```
uint8 CFE_EVS_HousekeepingTlm_Payload::Spare1
```

Padding for 32 bit boundary.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_HK\_SPARE1

Definition at line 1201 of file cfe\_evs\_msg.h.

### 11.58.2.13 Spare2

```
uint8 CFE_EVS_HousekeepingTlm_Payload::Spare2
```

Padding for 32 bit boundary.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_HK\_SPARE2

Definition at line 1203 of file cfe\_evs\_msg.h.

### 11.58.2.14 Spare3

```
uint8 CFE_EVS_HousekeepingTlm_Payload::Spare3
```

Padding for 32 bit boundary.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_HK\_SPARE3

Definition at line 1205 of file cfe\_evs\_msg.h.

### 11.58.2.15 UnregisteredAppCounter

```
uint8 CFE_EVS_HousekeepingTlm_Payload::UnregisteredAppCounter
```

Unregistered application message send counter.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_UNREGAPPC

Definition at line 1185 of file cfe\_evs\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/evs/fsw/inc/cfe\_evs\_msg.h

## 11.59 CFE\_EVS\_LogFileCmd\_Payload Struct Reference

Write Event Log to File Command Payload.

```
#include <cfe_evs_msg.h>
```

## Data Fields

- char [LogFilename \[CFE\\_MISSION\\_MAX\\_PATH\\_LEN\]](#)

*Filename where log data is to be written.*

### 11.59.1 Detailed Description

Write Event Log to File Command Payload.

For command details, see [CFE\\_EVS\\_WRITE\\_LOG\\_DATA\\_FILE\\_CC](#)

Definition at line 925 of file cfe\_evs\_msg.h.

### 11.59.2 Field Documentation

#### 11.59.2.1 LogFilename

```
char CFE_EVS_LogFileCmd_Payload::LogFilename[CFE_MISSION_MAX_PATH_LEN]
```

Filename where log data is to be written.

Definition at line 927 of file cfe\_evs\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/evs/fsw/inc/[cfe\\_evs\\_msg.h](#)

## 11.60 CFE\_EVS\_LongEventTlm Struct Reference

```
#include <cfe_evs_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_TelemetryHeader\\_t TelemetryHeader](#)  
*Telemetry header.*
- [CFE\\_EVS\\_LongEventTlm\\_Payload\\_t Payload](#)  
*Telemetry payload.*

### 11.60.1 Detailed Description

Definition at line 1259 of file cfe\_evs\_msg.h.

## 11.60.2 Field Documentation

### 11.60.2.1 Payload

`CFE_EVS_LongEventTlm_Payload_t CFE_EVS_LongEventTlm::Payload`

Telemetry payload.

Definition at line 1262 of file `cfe_evs_msg.h`.

### 11.60.2.2 TelemetryHeader

`CFE_MSG_TelemetryHeader_t CFE_EVS_LongEventTlm::TelemetryHeader`

Telemetry header.

Definition at line 1261 of file `cfe_evs_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/evs/fsw/inc/cfe_evs_msg.h`

## 11.61 CFE\_EVS\_LongEventTlm\_Payload Struct Reference

```
#include <cfe_evs_msg.h>
```

### Data Fields

- `CFE_EVS_PacketID_t PacketID`  
*Event packet information.*
- `char Message [CFE_MISSION_EVS_MAX_MESSAGE_LENGTH]`  
*Event message string.*
- `uint8 Spare1`  
*Structure padding.*
- `uint8 Spare2`  
*Structure padding.*

### 11.61.1 Detailed Description

**Name** Event Message Telemetry Packet (Long format)

Definition at line 1239 of file `cfe_evs_msg.h`.

## 11.61.2 Field Documentation

### 11.61.2.1 Message

```
char CFE_EVS_LongEventTlm_Payload::Message[CFE_MISSION_EVS_MAX_MESSAGE_LENGTH]
```

Event message string.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_EVENT[CFE\_MISSION\_EVS\_MAX\_MESSAGE\_LENGTH]

Definition at line 1242 of file cfe\_evs\_msg.h.

### 11.61.2.2 PacketID

```
CFE_EVS_PacketID_t CFE_EVS_LongEventTlm_Payload::PacketID
```

Event packet information.

Definition at line 1241 of file cfe\_evs\_msg.h.

### 11.61.2.3 Spare1

```
uint8 CFE_EVS_LongEventTlm_Payload::Spare1
```

Structure padding.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_SPARE1

Definition at line 1244 of file cfe\_evs\_msg.h.

### 11.61.2.4 Spare2

```
uint8 CFE_EVS_LongEventTlm_Payload::Spare2
```

Structure padding.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_SPARE2

Definition at line 1246 of file cfe\_evs\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/evs/fsw/inc/cfe\_evs\_msg.h

## 11.62 CFE\_EVS\_NoArgsCmd Struct Reference

Command with no additional arguments.

```
#include <cfе_evs_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CommandHeader](#)  
*Command header.*

#### 11.62.1 Detailed Description

Command with no additional arguments.

Definition at line 905 of file cfe\_evs\_msg.h.

#### 11.62.2 Field Documentation

##### 11.62.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_EVS\_NoArgsCmd::CommandHeader

Command header.

Definition at line 907 of file cfe\_evs\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/evs/fsw/inc/[cfе\\_evs\\_msg.h](#)

## 11.63 CFE\_EVS\_PacketID Struct Reference

```
#include <cfе_evs_msg.h>
```

### Data Fields

- char [AppName \[CFE\\_MISSION\\_MAX\\_API\\_LEN\]](#)  
*Application name.*
- [uint16 EventID](#)  
*Numerical event identifier.*
- [uint16 EventType](#)  
*Numerical event type identifier.*
- [uint32 SpacecraftID](#)  
*Spacecraft identifier.*
- [uint32 ProcessorID](#)  
*Numerical processor identifier.*

### 11.63.1 Detailed Description

Telemetry packet structures

Definition at line 1221 of file cfe\_evs\_msg.h.

### 11.63.2 Field Documentation

#### 11.63.2.1 AppName

```
char CFE_EVS_PacketID::AppName[CFE_MISSION_MAX_API_LEN]
```

Application name.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_APPNAME[OS\_MAX\_API\_NAME]

Definition at line 1223 of file cfe\_evs\_msg.h.

#### 11.63.2.2 EventID

```
uint16 CFE_EVS_PacketID::EventID
```

Numerical event identifier.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_EVENTID

Definition at line 1225 of file cfe\_evs\_msg.h.

#### 11.63.2.3 EventType

```
uint16 CFE_EVS_PacketID::EventType
```

Numerical event type identifier.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_EVENTTYPE

Definition at line 1227 of file cfe\_evs\_msg.h.

### 11.63.2.4 ProcessorID

```
uint32 CFE_EVS_PacketID::ProcessorID
```

Numerical processor identifier.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_PROCESSORID

Definition at line 1231 of file cfe\_evs\_msg.h.

### 11.63.2.5 SpacecraftID

```
uint32 CFE_EVS_PacketID::SpacecraftID
```

Spacecraft identifier.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_EVS\_SCID

Definition at line 1229 of file cfe\_evs\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/evs/fsw/inc/cfe\_evs\_msg.h

## 11.64 CFE\_EVS\_SetEventFormatCode\_Payload Struct Reference

Set Event Format Mode Command Payload.

```
#include <cfe_evs_msg.h>
```

### Data Fields

- **CFE\_EVS\_MsgFormat\_Enum\_t MsgFormat**  
*Mode to use in the command.*
- **uint8 Spare**  
*Pad to even byte.*

### 11.64.1 Detailed Description

Set Event Format Mode Command Payload.

For command details, see [CFE\\_EVS\\_SET\\_EVENT\\_FORMAT\\_MODE\\_CC](#)

Definition at line 986 of file cfe\_evs\_msg.h.

## 11.64.2 Field Documentation

### 11.64.2.1 MsgFormat

`CFE_EVS_MsgFormat_Enum_t CFE_EVS_SetEventFormatCode_Payload::MsgFormat`

Mode to use in the command.

Definition at line 988 of file `cfe_evs_msg.h`.

### 11.64.2.2 Spare

`uint8 CFE_EVS_SetEventFormatCode_Payload::Spare`

Pad to even byte.

Definition at line 989 of file `cfe_evs_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/evs/fsw/inc/cfe_evs_msg.h`

## 11.65 CFE\_EVS\_SetEventFormatModeCmd Struct Reference

Set Event Format Mode Command.

```
#include <cfe_evs_msg.h>
```

### Data Fields

- `CFE_MSG_CommandHeader_t CommandHeader`  
*Command header.*
- `CFE_EVS_SetEventFormatMode_Payload_t Payload`  
*Command payload.*

### 11.65.1 Detailed Description

Set Event Format Mode Command.

Definition at line 995 of file `cfe_evs_msg.h`.

## 11.65.2 Field Documentation

### 11.65.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_EVS\_SetEventFormatModeCmd::CommandHeader

Command header.

Definition at line 997 of file cfe\_evs\_msg.h.

### 11.65.2.2 Payload

[CFE\\_EVS\\_SetEventFormatMode\\_Payload\\_t](#) CFE\_EVS\_SetEventFormatModeCmd::Payload

Command payload.

Definition at line 998 of file cfe\_evs\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/evs/fsw/inc/[cfe\\_evs\\_msg.h](#)

## 11.66 CFE\_EVS\_SetLogMode\_Payload Struct Reference

Set Log Mode Command Payload.

```
#include <cfe_evs_msg.h>
```

### Data Fields

- [CFE\\_EVS\\_LogMode\\_Enum\\_t LogMode](#)  
*Mode to use in the command.*
- [uint8 Spare](#)  
*Pad to even byte.*

### 11.66.1 Detailed Description

Set Log Mode Command Payload.

For command details, see [CFE\\_EVS\\_SET\\_LOG\\_MODE\\_CC](#)

Definition at line 965 of file cfe\_evs\_msg.h.

## 11.66.2 Field Documentation

### 11.66.2.1 LogMode

`CFE_EVS_LogMode_Enum_t` `CFE_EVS_SetLogMode_Payload::LogMode`

Mode to use in the command.

Definition at line 967 of file `cfe_evs_msg.h`.

### 11.66.2.2 Spare

`uint8` `CFE_EVS_SetLogMode_Payload::Spare`

Pad to even byte.

Definition at line 968 of file `cfe_evs_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/evs/fsw/inc/cfe_evs_msg.h`

## 11.67 CFE\_EVS\_SetLogModeCmd Struct Reference

Set Log Mode Command.

```
#include <cfe_evs_msg.h>
```

### Data Fields

- `CFE_MSG_CommandHeader_t` `CommandHeader`  
*Command header.*
- `CFE_EVS_SetLogMode_Payload_t` `Payload`  
*Command payload.*

### 11.67.1 Detailed Description

Set Log Mode Command.

Definition at line 974 of file `cfe_evs_msg.h`.

## 11.67.2 Field Documentation

### 11.67.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_EVS\_SetLogModeCmd::CommandHeader

Command header.

Definition at line 976 of file cfe\_evs\_msg.h.

### 11.67.2.2 Payload

[CFE\\_EVS\\_SetLogMode\\_Payload\\_t](#) CFE\_EVS\_SetLogModeCmd::Payload

Command payload.

Definition at line 977 of file cfe\_evs\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/evs/fsw/inc/[cfe\\_evs\\_msg.h](#)

## 11.68 CFE\_EVS\_ShortEventTlm Struct Reference

```
#include <cfe_evs_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_TelemetryHeader\\_t](#) TelemetryHeader  
*Telemetry header.*
- [CFE\\_EVS\\_ShortEventTlm\\_Payload\\_t](#) Payload  
*Telemetry payload.*

### 11.68.1 Detailed Description

Definition at line 1266 of file cfe\_evs\_msg.h.

### 11.68.2 Field Documentation

### 11.68.2.1 Payload

`CFE_EVS_ShortEventTlm_Payload_t` `CFE_EVS_ShortEventTlm::Payload`

Telemetry payload.

Definition at line 1269 of file `cfe_evs_msg.h`.

### 11.68.2.2 TelemetryHeader

`CFE_MSG_TelemetryHeader_t` `CFE_EVS_ShortEventTlm::TelemetryHeader`

Telemetry header.

Definition at line 1268 of file `cfe_evs_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/evs/fsw/inc/cfe_evs_msg.h`

## 11.69 CFE\_EVS\_ShortEventTlm\_Payload Struct Reference

```
#include <cfe_evs_msg.h>
```

### Data Fields

- `CFE_EVS_PacketID_t PacketID`

*Event packet information.*

### 11.69.1 Detailed Description

**Name** Event Message Telemetry Packet (Short format)

Definition at line 1253 of file `cfe_evs_msg.h`.

### 11.69.2 Field Documentation

### 11.69.2.1 PacketID

`CFE_EVS_PacketID_t CFE_EVS_ShortEventTlm_Payload::PacketID`

Event packet information.

Definition at line 1255 of file `cfe_evs_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/evs/fsw/inc/cfe_evs_msg.h`

## 11.70 CFE\_EVS\_WriteAppDataFileCmd Struct Reference

Write Event Services Application Information to File Command.

```
#include <cfe_evs_msg.h>
```

### Data Fields

- `CFE_MSG_CommandHeader_t CommandHeader`  
*Command header.*
- `CFE_EVS_AppDataCmd_Payload_t Payload`  
*Command payload.*

### 11.70.1 Detailed Description

Write Event Services Application Information to File Command.

Definition at line 953 of file `cfe_evs_msg.h`.

### 11.70.2 Field Documentation

#### 11.70.2.1 CommandHeader

`CFE_MSG_CommandHeader_t CFE_EVS_WriteAppDataFileCmd::CommandHeader`

Command header.

Definition at line 955 of file `cfe_evs_msg.h`.

### 11.70.2.2 Payload

`CFE_EVS_AppDataCmd_Payload_t CFE_EVS_WriteAppDataFileCmd::Payload`

Command payload.

Definition at line 956 of file `cfe_evs_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/evs/fsw/inc/cfe_evs_msg.h`

## 11.71 CFE\_EVS\_WriteLogFileCmd Struct Reference

Write Event Log to File Command.

```
#include <cfe_evs_msg.h>
```

### Data Fields

- `CFE_MSG_CommandHeader_t CommandHeader`  
*Command header.*
- `CFE_EVS_LogFileCmd_Payload_t Payload`  
*Command payload.*

### 11.71.1 Detailed Description

Write Event Log to File Command.

Definition at line 933 of file `cfe_evs_msg.h`.

### 11.71.2 Field Documentation

#### 11.71.2.1 CommandHeader

`CFE_MSG_CommandHeader_t CFE_EVS_WriteLogFileCmd::CommandHeader`

Command header.

Definition at line 935 of file `cfe_evs_msg.h`.

### 11.71.2.2 Payload

`CFE_EVS_LogFileCmd_Payload_t` `CFE_EVS_WriteLogFileCmd::Payload`

Command payload.

Definition at line 936 of file `cfe_evs_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/evs/fsw/inc/cfe_evs_msg.h`

## 11.72 CFE\_FS\_FileWriteMetaData Struct Reference

External Metadata/State object associated with background file writes.

```
#include <cfe_fs_api_typedefs.h>
```

### Data Fields

- volatile bool `IsPending`
- char `FileName` [`OS_MAX_PATH_LEN`]
- `uint32 FileSubType`
- char `Description` [`CFE_FS_HDR_DESC_MAX_LEN`]
- `CFE_FS_FileWriteGetData_t GetData`
- `CFE_FS_FileWriteOnEvent_t OnEvent`

### 11.72.1 Detailed Description

External Metadata/State object associated with background file writes.

Applications intending to schedule background file write jobs should instantiate this object in static/global data memory. This keeps track of the state of the file write request(s).

Definition at line 124 of file `cfe_fs_api_typedefs.h`.

### 11.72.2 Field Documentation

#### 11.72.2.1 Description

```
char CFE_FS_FileWriteMetaData::Description[CFE_FS_HDR_DESC_MAX_LEN]
```

Description of file (for FS header)

Definition at line 132 of file `cfe_fs_api_typedefs.h`.

### 11.72.2.2 FileName

```
char CFE_FS_FileWriteMetaData::FileName[OS_MAX_PATH_LEN]
```

Name of file to write

Definition at line 128 of file cfe\_fs\_api\_typedefs.h.

### 11.72.2.3 FileSubType

```
uint32 CFE_FS_FileWriteMetaData::FileSubType
```

Type of file to write (for FS header)

Definition at line 131 of file cfe\_fs\_api\_typedefs.h.

### 11.72.2.4 GetData

```
CFE_FS_FileWriteGetData_t CFE_FS_FileWriteMetaData::GetData
```

Application callback to get a data record

Definition at line 134 of file cfe\_fs\_api\_typedefs.h.

### 11.72.2.5 IsPending

```
volatile bool CFE_FS_FileWriteMetaData::IsPending
```

Whether request is pending (volatile as it may be checked outside lock)

Definition at line 126 of file cfe\_fs\_api\_typedefs.h.

### 11.72.2.6 OnEvent

```
CFE_FS_FileWriteOnEvent_t CFE_FS_FileWriteMetaData::OnEvent
```

Application callback for abstract event processing

Definition at line 135 of file cfe\_fs\_api\_typedefs.h.

The documentation for this struct was generated from the following file:

- cfe/modules/core\_api/fsw/inc/cfe\_fs\_api\_typedefs.h

## 11.73 CFE\_FS\_Header Struct Reference

Standard cFE File header structure definition.

```
#include <cfef_s_extern_typedefs.h>
```

### Data Fields

- **uint32 ContentType**  
*Identifies the content type (=‘cFE1’=0x63464531)*
- **uint32 SubType**  
*Type of ContentType, if necessary.*
- **uint32 Length**  
*Length of this header to support external processing.*
- **uint32 SpacecraftID**  
*Spacecraft that generated the file.*
- **uint32 ProcessorID**  
*Processor that generated the file.*
- **uint32 ApplicationID**  
*Application that generated the file.*
- **uint32 TimeSeconds**  
*File creation timestamp (seconds)*
- **uint32 TimeSubSeconds**  
*File creation timestamp (sub-seconds)*
- **char Description [CFE\_FS\_HDR\_DESC\_MAX\_LEN]**  
*File description.*

### 11.73.1 Detailed Description

Standard cFE File header structure definition.

Definition at line 204 of file cfe\_fs\_extern\_typedefs.h.

### 11.73.2 Field Documentation

#### 11.73.2.1 ApplicationID

```
uint32 CFE_FS_Header::ApplicationID
```

Application that generated the file.

Definition at line 213 of file cfe\_fs\_extern\_typedefs.h.

### 11.73.2.2 ContentType

```
uint32 CFE_FS_Header::ContentType
```

Identifies the content type ('cFE1'=0x63464531)

Definition at line 206 of file cfe\_fs\_extern\_typedefs.h.

### 11.73.2.3 Description

```
char CFE_FS_Header::Description[CFE_FS_HDR_DESC_MAX_LEN]
```

File description.

Definition at line 218 of file cfe\_fs\_extern\_typedefs.h.

Referenced by DS\_FileWriteHeader().

### 11.73.2.4 Length

```
uint32 CFE_FS_Header::Length
```

Length of this header to support external processing.

Definition at line 210 of file cfe\_fs\_extern\_typedefs.h.

### 11.73.2.5 ProcessorID

```
uint32 CFE_FS_Header::ProcessorID
```

Processor that generated the file.

Definition at line 212 of file cfe\_fs\_extern\_typedefs.h.

### 11.73.2.6 SpacecraftID

```
uint32 CFE_FS_Header::SpacecraftID
```

Spacecraft that generated the file.

Definition at line 211 of file cfe\_fs\_extern\_typedefs.h.

### 11.73.2.7 SubType

`uint32 CFE_FS_Header::SubType`

Type of `ContentType`, if necessary.

Standard `SubType` definitions can be found [here](#)

Definition at line 207 of file `cfe_fs_extern_typedefs.h`.

Referenced by `DS_FileWriteHeader()`.

### 11.73.2.8 TimeSeconds

`uint32 CFE_FS_Header::TimeSeconds`

File creation timestamp (seconds)

Definition at line 215 of file `cfe_fs_extern_typedefs.h`.

### 11.73.2.9 TimeSubSeconds

`uint32 CFE_FS_Header::TimeSubSeconds`

File creation timestamp (sub-seconds)

Definition at line 216 of file `cfe_fs_extern_typedefs.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/core_api/fsw/inc/cfe_fs_extern_typedefs.h`

## 11.74 CFE\_SB\_AllSubscriptionsTlm Struct Reference

```
#include <cfe_sb_msg.h>
```

### Data Fields

- `CFE_MSG_TelemetryHeader_t TelemetryHeader`  
*Telemetry header.*
- `CFE_SB_AllSubscriptionsTlm_Payload_t Payload`  
*Telemetry payload.*

### 11.74.1 Detailed Description

Definition at line 797 of file cfe\_sb\_msg.h.

### 11.74.2 Field Documentation

#### 11.74.2.1 Payload

`CFE_SB_AllSubscriptionsTlm_Payload_t` CFE\_SB\_AllSubscriptionsTlm::Payload

Telemetry payload.

Definition at line 800 of file cfe\_sb\_msg.h.

#### 11.74.2.2 TelemetryHeader

`CFE_MSG_TelemetryHeader_t` CFE\_SB\_AllSubscriptionsTlm::TelemetryHeader

Telemetry header.

Definition at line 799 of file cfe\_sb\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/sb/fsw/inc/cfe\_sb\_msg.h

## 11.75 CFE\_SB\_AllSubscriptionsTlm\_Payload Struct Reference

```
#include <cfe_sb_msg.h>
```

### Data Fields

- `uint32 PktSegment`  
*Pkt number(starts at 1) in the series.*
- `uint32 TotalSegments`  
*Total number of pkts needed to complete the request.*
- `uint32 Entries`  
*Number of entries in the pkt.*
- `CFE_SB_SubEntries_t Entry [CFE_SB_SUB_ENTRIES_PER_PKT]`  
*Array of `CFE_SB_SubEntries_t` entries.*

### 11.75.1 Detailed Description

**Name** SB Previous Subscriptions Packet

This structure defines the pkt(s) sent by SB that contains a list of all current subscriptions. This pkt is generated on cmd and intended to be used primarily by the Software Bus Networking Application (SBN). Typically, when the cmd is received there are more subscriptions than can fit in one pkt. The complete list of subscriptions is sent via a series of segmented pkts.

Definition at line 788 of file cfe\_sb\_msg.h.

### 11.75.2 Field Documentation

#### 11.75.2.1 Entries

```
uint32 CFE_SB_AllSubscriptionsTlm_Payload::Entries
```

Number of entries in the pkt.

Definition at line 793 of file cfe\_sb\_msg.h.

#### 11.75.2.2 Entry

```
CFE_SB_SubEntries_t CFE_SB_AllSubscriptionsTlm_Payload::Entry[CFE_SB_SUB_ENTRIES_PER_PKT]
```

Array of [CFE\\_SB\\_SubEntries\\_t](#) entries.

Definition at line 794 of file cfe\_sb\_msg.h.

#### 11.75.2.3 PktSegment

```
uint32 CFE_SB_AllSubscriptionsTlm_Payload::PktSegment
```

Pkt number(starts at 1) in the series.

Definition at line 791 of file cfe\_sb\_msg.h.

#### 11.75.2.4 TotalSegments

```
uint32 CFE_SB_AllSubscriptionsTlm_Payload::TotalSegments
```

Total number of pkts needed to complete the request.

Definition at line 792 of file cfe\_sb\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/sb/fsw/inc/cfe\_sb\_msg.h

### 11.76 CFE\_SB\_HousekeepingTlm Struct Reference

```
#include <cfe_sb_msg.h>
```

#### Data Fields

- **CFE\_MSG\_TelemetryHeader\_t TelemetryHeader**  
*Telemetry header.*
- **CFE\_SB\_HousekeepingTlm\_Payload\_t Payload**  
*Telemetry payload.*

#### 11.76.1 Detailed Description

Definition at line 598 of file cfe\_sb\_msg.h.

#### 11.76.2 Field Documentation

##### 11.76.2.1 Payload

```
CFE_SB_HousekeepingTlm_Payload_t CFE_SB_HousekeepingTlm::Payload
```

Telemetry payload.

Definition at line 601 of file cfe\_sb\_msg.h.

### 11.76.2.2 TelemetryHeader

`CFE_MSG_TelemetryHeader_t` CFE\_SB\_HousekeepingTlm::TelemetryHeader

Telemetry header.

Definition at line 600 of file cfe\_sb\_msg.h.

The documentation for this struct was generated from the following file:

- [cfe/modules/sb/fsw/inc/cfe\\_sb\\_msg.h](#)

## 11.77 CFE\_SB\_HousekeepingTlm\_Payload Struct Reference

```
#include <cfe_sb_msg.h>
```

### Data Fields

- **uint8 CommandCounter**  
*Count of valid commands received.*
- **uint8 CommandErrorCounter**  
*Count of invalid commands received.*
- **uint8 NoSubscribersCounter**  
*Count pkts sent with no subscribers.*
- **uint8 MsgSendErrorCounter**  
*Count of message send errors.*
- **uint8 MsgReceiveErrorCounter**  
*Count of message receive errors.*
- **uint8 InternalErrorCounter**  
*Count of queue read or write errors.*
- **uint8 CreatePipeErrorCounter**  
*Count of errors in create pipe API.*
- **uint8 SubscribeErrorCounter**  
*Count of errors in subscribe API.*
- **uint8 PipeOptsErrorCounter**  
*Count of errors in set/get pipe options API.*
- **uint8 DuplicateSubscriptionsCounter**  
*Count of duplicate subscriptions.*
- **uint8 GetPipeldByNameErrorCounter**  
*Count of errors in get pipe id by name API.*
- **uint8 Spare2Align [1]**  
*Spare bytes to ensure alignment.*
- **uint16 PipeOverflowErrorCounter**  
*Count of pipe overflow errors.*
- **uint16 MsgLimitErrorCounter**  
*Count of msg id to pipe errors.*
- **CFE\_ES\_MemHandle\_t MemPoolHandle**  
*Handle to SB's Memory Pool.*
- **uint32 MemInUse**  
*Memory in use.*
- **uint32 UnmarkedMem**  
*cfg param CFE\_PLATFORM\_SB\_BUF\_MEMORY\_BYTES minus Peak Memory in use*

### 11.77.1 Detailed Description

**Name** Software Bus task housekeeping Packet

Definition at line 554 of file cfe\_sb\_msg.h.

### 11.77.2 Field Documentation

#### 11.77.2.1 CommandCounter

`uint8 CFE_SB_HousekeepingTlm_Payload::CommandCounter`

Count of valid commands received.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_CMDPC

Definition at line 557 of file cfe\_sb\_msg.h.

#### 11.77.2.2 CommandErrorCounter

`uint8 CFE_SB_HousekeepingTlm_Payload::CommandErrorCounter`

Count of invalid commands received.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_CMDEC

Definition at line 559 of file cfe\_sb\_msg.h.

#### 11.77.2.3 CreatePipeErrorCounter

`uint8 CFE_SB_HousekeepingTlm_Payload::CreatePipeErrorCounter`

Count of errors in create pipe API.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_NewPipeEC

Definition at line 570 of file cfe\_sb\_msg.h.

#### 11.77.2.4 DuplicateSubscriptionsCounter

```
uint8 CFE_SB_HousekeepingTlm_Payload::DuplicateSubscriptionsCounter
```

Count of duplicate subscriptions.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_DupSubCnt

Definition at line 576 of file cfe\_sb\_msg.h.

#### 11.77.2.5 GetPipeIdByNameErrorCounter

```
uint8 CFE_SB_HousekeepingTlm_Payload::GetPipeIdByNameErrorCounter
```

Count of errors in get pipe id by name API.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_GetPipeIDByNameEC

Definition at line 578 of file cfe\_sb\_msg.h.

#### 11.77.2.6 InternalErrorCounter

```
uint8 CFE_SB_HousekeepingTlm_Payload::InternalErrorCounter
```

Count of queue read or write errors.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_InternalEC

Definition at line 568 of file cfe\_sb\_msg.h.

#### 11.77.2.7 MemInUse

```
uint32 CFE_SB_HousekeepingTlm_Payload::MemInUse
```

Memory in use.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_MemInUse

Definition at line 591 of file cfe\_sb\_msg.h.

### 11.77.2.8 MemPoolHandle

`CFE_ES_MemHandle_t CFE_SB_HousekeepingTlm_Payload::MemPoolHandle`

Handle to SB's Memory Pool.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_MemPoolHdl

Definition at line 588 of file cfe\_sb\_msg.h.

### 11.77.2.9 MsgLimitErrorCounter

`uint16 CFE_SB_HousekeepingTlm_Payload::MsgLimitErrorCounter`

Count of msg id to pipe errors.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_MsgLimEC

Definition at line 585 of file cfe\_sb\_msg.h.

### 11.77.2.10 MsgReceiveErrorCounter

`uint8 CFE_SB_HousekeepingTlm_Payload::MsgReceiveErrorCounter`

Count of message receive errors.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_MsgRecEC

Definition at line 566 of file cfe\_sb\_msg.h.

### 11.77.2.11 MsgSendErrorCounter

`uint8 CFE_SB_HousekeepingTlm_Payload::MsgSendErrorCounter`

Count of message send errors.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_MsgSndEC

Definition at line 563 of file cfe\_sb\_msg.h.

#### 11.77.2.12 NoSubscribersCounter

```
uint8 CFE_SB_HousekeepingTlm_Payload::NoSubscribersCounter
```

Count pkts sent with no subscribers.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_NoSubEC

Definition at line 561 of file cfe\_sb\_msg.h.

#### 11.77.2.13 PipeOptsErrorCounter

```
uint8 CFE_SB_HousekeepingTlm_Payload::PipeOptsErrorCounter
```

Count of errors in set/get pipe options API.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_PipeOptsEC

Definition at line 574 of file cfe\_sb\_msg.h.

#### 11.77.2.14 PipeOverflowErrorCounter

```
uint16 CFE_SB_HousekeepingTlm_Payload::PipeOverflowErrorCounter
```

Count of pipe overflow errors.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_PipeOvrEC

Definition at line 583 of file cfe\_sb\_msg.h.

#### 11.77.2.15 Spare2Align

```
uint8 CFE_SB_HousekeepingTlm_Payload::Spare2Align[1]
```

Spare bytes to ensure alignment.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Spare2Align[2]

Definition at line 580 of file cfe\_sb\_msg.h.

### 11.77.2.16 SubscribeErrorCounter

```
uint8 CFE_SB_HousekeepingTlm_Payload::SubscribeErrorCounter
```

Count of errors in subscribe API.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_SubscrEC

Definition at line 572 of file cfe\_sb\_msg.h.

### 11.77.2.17 UnmarkedMem

```
uint32 CFE_SB_HousekeepingTlm_Payload::UnmarkedMem
```

cfg param CFE\_PLATFORM\_SB\_BUF\_MEMORY\_BYTES minus Peak Memory in use

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_UnMarkedMem

Definition at line 594 of file cfe\_sb\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/sb/fsw/inc/cfe\_sb\_msg.h

## 11.78 CFE\_SB\_Msg Union Reference

Software Bus generic message.

```
#include <cfe_sb_api_typedefs.h>
```

### Data Fields

- **CFE\_MSG\_Message\_t Msg**  
*Base message type without enforced alignment.*
- long long int **LongInt**  
*Align to support Long Integer.*
- long double **LongDouble**  
*Align to support Long Double.*

### 11.78.1 Detailed Description

Software Bus generic message.

Definition at line 142 of file cfe\_sb\_api\_typedefs.h.

### 11.78.2 Field Documentation

#### 11.78.2.1 LongDouble

```
long double CFE_SB_Msg::LongDouble
```

Align to support Long Double.

Definition at line 146 of file cfe\_sb\_api\_typedefs.h.

#### 11.78.2.2 LongInt

```
long long int CFE_SB_Msg::LongInt
```

Align to support Long Integer.

Definition at line 145 of file cfe\_sb\_api\_typedefs.h.

#### 11.78.2.3 Msg

```
CFE_MSG_Message_t CFE_SB_Msg::Msg
```

Base message type without enforced alignment.

Definition at line 144 of file cfe\_sb\_api\_typedefs.h.

Referenced by DS\_AppProcessCmd(), DS\_AppProcessMsg(), DS\_CmdAddMID(), DS\_CmdCloseAll(), DS\_CmdCloseFile(), DS\_CmdGetFileInfo(), DS\_CmdNoop(), DS\_CmdReset(), DS\_CmdSetAppState(), DS\_CmdSetDestAge(), DS\_CmdSetDestBase(), DS\_CmdSetDestCount(), DS\_CmdSetDestExt(), DS\_CmdSetDestPath(), DS\_CmdSetDestSize(), DS\_CmdSetDestState(), DS\_CmdSetDestType(), DS\_CmdSetFilterFile(), DS\_CmdSetFilterParms(), DS\_CmdSetFilterType(), and DS\_FileSetupWrite().

The documentation for this union was generated from the following file:

- cfe/modules/core\_api/fsw/inc/cfe\_sb\_api\_typedefs.h

## 11.79 CFE\_SB\_MsgId\_t Struct Reference

[CFE\\_SB\\_MsgId\\_t](#) type definition.

```
#include <cfe_sb_extern_typedefs.h>
```

**Data Fields**

- [CFE\\_SB\\_MsgId\\_Atom\\_t Value](#)

**11.79.1 Detailed Description**

[CFE\\_SB\\_MsgId\\_t](#) type definition.

Software Bus message identifier used in many SB APIs

Currently this is directly mapped to the underlying holding type (not wrapped) for compatibility with existing usage semantics in apps (mainly switch/case statements)

**Note**

In a future version it could become a type-safe wrapper similar to the route index, to avoid message IDs getting mixed between other integer values.

Definition at line 116 of file [cfe\\_sb\\_extern\\_typedefs.h](#).

**11.79.2 Field Documentation****11.79.2.1 Value**

[CFE\\_SB\\_MsgId\\_Atom\\_t CFE\\_SB\\_MsgId\\_t::Value](#)

Definition at line 118 of file [cfe\\_sb\\_extern\\_typedefs.h](#).

The documentation for this struct was generated from the following file:

- [cfe/modules/core\\_api/fsw/inc/cfe\\_sb\\_extern\\_typedefs.h](#)

**11.80 CFE\_SB\_MsgMapFileEntry Struct Reference**

SB Map File Entry.

```
#include <cfe_sb_msg.h>
```

**Data Fields**

- [CFE\\_SB\\_MsgId\\_t MsgId](#)

*Message Id which has been subscribed to.*

- [CFE\\_SB\\_Routeld\\_Atom\\_t Index](#)

*Routing raw index value (0 based, not Route ID)*

### 11.80.1 Detailed Description

SB Map File Entry.

Structure of one element of the map information in response to [CFE\\_SB\\_WRITE\\_MAP\\_INFO\\_CC](#)

Definition at line 730 of file cfe\_sb\_msg.h.

### 11.80.2 Field Documentation

#### 11.80.2.1 Index

[CFE\\_SB\\_RouteId\\_Atom\\_t](#) CFE\_SB\_MsgMapFileEntry::Index

Routing raw index value (0 based, not Route ID)

Definition at line 733 of file cfe\_sb\_msg.h.

#### 11.80.2.2 MsgId

[CFE\\_SB\\_MsgId\\_t](#) CFE\_SB\_MsgMapFileEntry::MsgId

Message Id which has been subscribed to.

Definition at line 732 of file cfe\_sb\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/sb/fsw/inc/[cfe\\_sb\\_msg.h](#)

## 11.81 CFE\_SB\_PipeDepthStats Struct Reference

SB Pipe Depth Statistics.

```
#include <cfe_sb_msg.h>
```

## Data Fields

- **CFE\_SB\_PipeId\_t PipeId**  
*Pipe Id associated with the stats below.*
- **uint16 MaxQueueDepth**  
*Number of messages the pipe can hold.*
- **uint16 CurrentQueueDepth**  
*Number of messages currently on the pipe.*
- **uint16 PeakQueueDepth**  
*Peak number of messages that have been on the pipe.*
- **uint16 Spare**  
*Spare word to ensure alignment.*

### 11.81.1 Detailed Description

SB Pipe Depth Statistics.

Used in SB Statistics Telemetry Packet [CFE\\_SB\\_StatsTlm\\_t](#)

Definition at line 609 of file `cfe_sb_msg.h`.

### 11.81.2 Field Documentation

#### 11.81.2.1 CurrentQueueDepth

`uint16 CFE_SB_PipeDepthStats::CurrentQueueDepth`

Number of messages currently on the pipe.

**Telemetry Mnemonic(s)** `$sc_$cpu_SB_Stat.SB_SMPDS[CFE_PLATFORM_SB_MAX_PIPES].SB_PDINUSE`

Definition at line 616 of file `cfe_sb_msg.h`.

#### 11.81.2.2 MaxQueueDepth

`uint16 CFE_SB_PipeDepthStats::MaxQueueDepth`

Number of messages the pipe can hold.

**Telemetry Mnemonic(s)** `$sc_$cpu_SB_Stat.SB_SMPDS[CFE_PLATFORM_SB_MAX_PIPES].SB_PDDEPTH`

Definition at line 614 of file `cfe_sb_msg.h`.

### 11.81.2.3 PeakQueueDepth

`uint16 CFE_SB_PipeDepthStats::PeakQueueDepth`

Peak number of messages that have been on the pipe.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMPDS[CFE\_PLATFORM\_SB\_MAX\_PIPES].SB\_PDPKINUSE

Definition at line 618 of file cfe\_sb\_msg.h.

### 11.81.2.4 PipeId

`CFE_SB_PipeId_t CFE_SB_PipeDepthStats::PipeId`

Pipe Id associated with the stats below.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMPDS[CFE\_PLATFORM\_SB\_MAX\_PIPES].SB\_PDPipeID

Definition at line 612 of file cfe\_sb\_msg.h.

### 11.81.2.5 Spare

`uint16 CFE_SB_PipeDepthStats::Spare`

Spare word to ensure alignment.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMPDS[CFE\_PLATFORM\_SB\_MAX\_PIPES].SB\_PDSpare

Definition at line 620 of file cfe\_sb\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/sb/fsw/inc/cfe\_sb\_msg.h

## 11.82 CFE\_SB\_PipeInfoEntry Struct Reference

SB Pipe Information File Entry.

```
#include <cfe_sb_msg.h>
```

## Data Fields

- `CFE_SB_PipeId_t PipeId`
- `CFE_ES_AppId_t AppId`
- `char PipeName [CFE_MISSION_MAX_API_LEN]`
- `charAppName [CFE_MISSION_MAX_API_LEN]`
- `uint16 MaxQueueDepth`
- `uint16 CurrentQueueDepth`
- `uint16 PeakQueueDepth`
- `uint16 SendErrors`
- `uint8 Opts`
- `uint8 Spare [3]`

### 11.82.1 Detailed Description

SB Pipe Information File Entry.

This statistics structure is output as part of the CFE SB "Send Pipe Info" command (CFE\_SB\_SEND\_PIPE\_INFO\_CC).

Previous versions of CFE simply wrote the internal CFE\_SB\_PipeD\_t object to the file, but this also contains information such as pointers which are not relevant outside the running CFE process.

By defining the pipe info structure separately, it also provides some independence, such that the internal CFE\_SB\_PipeD\_t definition can evolve without changing the binary format of the information file.

Definition at line 640 of file cfe\_sb\_msg.h.

### 11.82.2 Field Documentation

#### 11.82.2.1 AppId

`CFE_ES_AppId_t CFE_SB_PipeInfoEntry::AppId`

The runtime ID of the application that owns the pipe

Definition at line 643 of file cfe\_sb\_msg.h.

#### 11.82.2.2 AppName

`char CFE_SB_PipeInfoEntry::AppName [CFE_MISSION_MAX_API_LEN]`

The Name of the application that owns the pipe

Definition at line 645 of file cfe\_sb\_msg.h.

### 11.82.2.3 CurrentQueueDepth

```
uint16 CFE_SB_PipeInfoEntry::CurrentQueueDepth
```

The current depth of the pipe

Definition at line 647 of file cfe\_sb\_msg.h.

### 11.82.2.4 MaxQueueDepth

```
uint16 CFE_SB_PipeInfoEntry::MaxQueueDepth
```

The allocated depth of the pipe (max capacity)

Definition at line 646 of file cfe\_sb\_msg.h.

### 11.82.2.5 Opts

```
uint8 CFE_SB_PipeInfoEntry::Opts
```

Pipe options set (bitmask)

Definition at line 650 of file cfe\_sb\_msg.h.

### 11.82.2.6 PeakQueueDepth

```
uint16 CFE_SB_PipeInfoEntry::PeakQueueDepth
```

The peak depth of the pipe (high watermark)

Definition at line 648 of file cfe\_sb\_msg.h.

### 11.82.2.7 Pipelid

```
CFE_SB_PipeId_t CFE_SB_PipeInfoEntry::Pipelid
```

The runtime ID of the pipe

Definition at line 642 of file cfe\_sb\_msg.h.

### 11.82.2.8 PipeName

```
char CFE_SB_PipeInfoEntry::PipeName[CFE_MISSION_MAX_API_LEN]
```

The Name of the pipe

Definition at line 644 of file cfe\_sb\_msg.h.

### 11.82.2.9 SendErrors

```
uint16 CFE_SB_PipeInfoEntry::SendErrors
```

Number of errors when writing to this pipe

Definition at line 649 of file cfe\_sb\_msg.h.

### 11.82.2.10 Spare

```
uint8 CFE_SB_PipeInfoEntry::Spare[3]
```

Padding to make this structure a multiple of 4 bytes

Definition at line 651 of file cfe\_sb\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/sb/fsw/inc/cfe\_sb\_msg.h

## 11.83 CFE\_SB\_Qos\_t Struct Reference

Quality Of Service Type Definition.

```
#include <cfe_sb_extern_typedefs.h>
```

### Data Fields

- **uint8 Priority**

*Specify high(1) or low(0) message priority for off-board routing, currently unused.*

- **uint8 Reliability**

*Specify high(1) or low(0) message transfer reliability for off-board routing, currently unused.*

### 11.83.1 Detailed Description

Quality Of Service Type Definition.

Currently an unused parameter in [CFE\\_SB\\_SubscribeEx](#) Intended to be used for interprocessor communication only

Definition at line 133 of file cfe\_sb\_extern\_typedefs.h.

### 11.83.2 Field Documentation

#### 11.83.2.1 Priority

```
uint8 CFE_SB_Qos_t::Priority
```

Specify high(1) or low(0) message priority for off-board routing, currently unused.

Definition at line 135 of file cfe\_sb\_extern\_typedefs.h.

#### 11.83.2.2 Reliability

```
uint8 CFE_SB_Qos_t::Reliability
```

Specify high(1) or low(0) message transfer reliability for off-board routing, currently unused.

Definition at line 136 of file cfe\_sb\_extern\_typedefs.h.

The documentation for this struct was generated from the following file:

- [cfe/modules/core\\_api/fsw/inc/cfe\\_sb\\_extern\\_typedefs.h](#)

## 11.84 CFE\_SB\_RouteCmd Struct Reference

Enable/Disable Route Command.

```
#include <cfe_sb_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CommandHeader](#)  
*Command header.*
- [CFE\\_SB\\_RouteCmd\\_Payload\\_t Payload](#)  
*Command payload.*

### 11.84.1 Detailed Description

Enable/Disable Route Command.

Definition at line 535 of file cfe\_sb\_msg.h.

### 11.84.2 Field Documentation

#### 11.84.2.1 CommandHeader

`CFE_MSG_CommandHeader_t` CFE\_SB\_RouteCmd::CommandHeader

Command header.

Definition at line 537 of file cfe\_sb\_msg.h.

#### 11.84.2.2 Payload

`CFE_SB_RouteCmd_Payload_t` CFE\_SB\_RouteCmd::Payload

Command payload.

Definition at line 538 of file cfe\_sb\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/sb/fsw/inc/cfe\_sb\_msg.h

## 11.85 CFE\_SB\_RouteCmd\_Payload Struct Reference

Enable/Disable Route Command Payload.

```
#include <cfe_sb_msg.h>
```

### Data Fields

- `CFE_SB_MsgId_t MsgId`  
*Message ID of route to be enabled or disabled `CFE_SB_MsgId_t`.*
- `CFE_SB_Pipeld_t Pipe`  
*Pipe ID of route to be enabled or disabled `CFE_SB_Pipeld_t`.*
- `uint8 Spare`  
*Spare byte to make command even number of bytes.*

### 11.85.1 Detailed Description

Enable/Disable Route Command Payload.

This structure contains a definition used by two SB commands, 'Enable Route' [CFE\\_SB\\_ENABLE\\_ROUTE\\_CC](#) and 'Disable Route' [CFE\\_SB\\_DISABLE\\_ROUTE\\_CC](#). A route is the destination pipe for a particular message and is therefore defined as a MsgId and PipeId combination.

Definition at line 524 of file `cfe_sb_msg.h`.

### 11.85.2 Field Documentation

#### 11.85.2.1 MsgId

`CFE_SB_MsgId_t` `CFE_SB_RouteCmd_Payload::MsgId`

Message ID of route to be enabled or disabled [CFE\\_SB\\_MsgId\\_t](#).

Definition at line 527 of file `cfe_sb_msg.h`.

#### 11.85.2.2 Pipe

`CFE_SB_PipeId_t` `CFE_SB_RouteCmd_Payload::Pipe`

Pipe ID of route to be enabled or disabled [CFE\\_SB\\_PipeId\\_t](#).

Definition at line 528 of file `cfe_sb_msg.h`.

#### 11.85.2.3 Spare

`uint8` `CFE_SB_RouteCmd_Payload::Spare`

Spare byte to make command even number of bytes.

Definition at line 529 of file `cfe_sb_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/sb/fsw/inc/cfe_sb_msg.h`

## 11.86 CFE\_SB\_RoutingFileEntry Struct Reference

SB Routing File Entry.

```
#include <cfе_sb_msg.h>
```

### Data Fields

- **CFE\_SB\_MsgId\_t MsgId**  
*Message Id portion of the route.*
- **CFE\_SB\_Pipeld\_t Pipeld**  
*Pipe Id portion of the route.*
- **uint8 State**  
*Route Enabled or Disabled.*
- **uint16 MsgCnt**  
*Number of msgs with this MsgId sent to this Pipeld.*
- **char AppName [CFE\_MISSION\_MAX\_API\_LEN]**  
*Pipe Depth Statistics.*
- **char PipeName [CFE\_MISSION\_MAX\_API\_LEN]**  
*Pipe Depth Statistics.*

### 11.86.1 Detailed Description

SB Routing File Entry.

Structure of one element of the routing information in response to [CFE\\_SB\\_WRITE\\_ROUTING\\_INFO\\_CC](#)

Definition at line 715 of file cfe\_sb\_msg.h.

### 11.86.2 Field Documentation

#### 11.86.2.1 AppName

```
char CFE_SB_RoutingFileEntry::AppName[CFE_MISSION_MAX_API_LEN]
```

Pipe Depth Statistics.

Definition at line 721 of file cfe\_sb\_msg.h.

### 11.86.2.2 MsgCnt

```
uint16 CFE_SB_RoutingFileEntry::MsgCnt
```

Number of msgs with this MsgId sent to this PipeId.

Definition at line 720 of file [cfe\\_sb\\_msg.h](#).

### 11.86.2.3 MsgId

```
CFE_SB_MsgId_t CFE_SB_RoutingFileEntry::MsgId
```

Message Id portion of the route.

Definition at line 717 of file [cfe\\_sb\\_msg.h](#).

### 11.86.2.4 PipeId

```
CFE_SB_PipeId_t CFE_SB_RoutingFileEntry::PipeId
```

Pipe Id portion of the route.

Definition at line 718 of file [cfe\\_sb\\_msg.h](#).

### 11.86.2.5 PipeName

```
char CFE_SB_RoutingFileEntry::PipeName[CFE_MISSION_MAX_API_LEN]
```

Pipe Depth Statistics.

Definition at line 722 of file [cfe\\_sb\\_msg.h](#).

### 11.86.2.6 State

```
uint8 CFE_SB_RoutingFileEntry::State
```

Route Enabled or Disabled.

Definition at line 719 of file [cfe\\_sb\\_msg.h](#).

The documentation for this struct was generated from the following file:

- [cfe/modules/sb/fsw/inc/cfe\\_sb\\_msg.h](#)

## 11.87 CFE\_SB\_SingleSubscriptionTlm Struct Reference

```
#include <cfе_sb_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_TelemetryHeader\\_t TelemetryHeader](#)  
*Telemetry header.*
- [CFE\\_SB\\_SingleSubscriptionTlm\\_Payload\\_t Payload](#)  
*Telemetry payload.*

### 11.87.1 Detailed Description

Definition at line 756 of file cfe\_sb\_msg.h.

### 11.87.2 Field Documentation

#### 11.87.2.1 Payload

[CFE\\_SB\\_SingleSubscriptionTlm\\_Payload\\_t](#) CFE\_SB\_SingleSubscriptionTlm::Payload

Telemetry payload.

Definition at line 759 of file cfe\_sb\_msg.h.

#### 11.87.2.2 TelemetryHeader

[CFE\\_MSG\\_TelemetryHeader\\_t](#) CFE\_SB\_SingleSubscriptionTlm::TelemetryHeader

Telemetry header.

Definition at line 758 of file cfe\_sb\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/sb/fsw/inc/[cfe\\_sb\\_msg.h](#)

## 11.88 CFE\_SB\_SingleSubscriptionTlm\_Payload Struct Reference

```
#include <cfе_sb_msg.h>
```

## Data Fields

- [uint8 SubType](#)  
*Subscription or Unsubscription.*
- [CFE\\_SB\\_MsgId\\_t MsgId](#)  
*MsgId subscribed or unsubscribe to.*
- [CFE\\_SB\\_Qos\\_t Qos](#)  
*Quality of Service, used only for interprocessor communication.*
- [CFE\\_SB\\_PipeId\\_t Pipe](#)  
*Destination pipe id to send above msg id.*

### 11.88.1 Detailed Description

**Name** SB Subscription Report Packet

This structure defines the pkt sent by SB when a subscription or a request to unsubscribe is received while subscription reporting is enabled. By default subscription reporting is disabled. This feature is intended to be used primarily by Software Bus Networking Application (SBN)

#### See also

[CFE\\_SB\\_ENABLE\\_SUB\\_REPORTING\\_CC](#), [CFE\\_SB\\_DISABLE\\_SUB\\_REPORTING\\_CC](#)

Definition at line 746 of file cfe\_sb\_msg.h.

### 11.88.2 Field Documentation

#### 11.88.2.1 MsgId

[CFE\\_SB\\_MsgId\\_t](#) CFE\_SB\_SingleSubscriptionTlm\_Payload::MsgId

MsgId subscribed or unsubscribe to.

Definition at line 750 of file cfe\_sb\_msg.h.

#### 11.88.2.2 Pipe

[CFE\\_SB\\_PipeId\\_t](#) CFE\_SB\_SingleSubscriptionTlm\_Payload::Pipe

Destination pipe id to send above msg id.

Definition at line 752 of file cfe\_sb\_msg.h.

### 11.88.2.3 Qos

`CFE_SB_Qos_t CFE_SB_SingleSubscriptionTlm_Payload::Qos`

Quality of Service, used only for interprocessor communication.

Definition at line 751 of file `cfe_sb_msg.h`.

### 11.88.2.4 SubType

`uint8 CFE_SB_SingleSubscriptionTlm_Payload::SubType`

Subscription or Unsubscription.

Definition at line 749 of file `cfe_sb_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/sb/fsw/inc/cfe_sb_msg.h`

## 11.89 CFE\_SB\_StatsTlm Struct Reference

`#include <cfe_sb_msg.h>`

### Data Fields

- `CFE_MSG_TelemetryHeader_t TelemetryHeader`  
*Telemetry header.*
- `CFE_SB_StatsTlm_Payload_t Payload`  
*Telemetry payload.*

### 11.89.1 Detailed Description

Definition at line 704 of file `cfe_sb_msg.h`.

### 11.89.2 Field Documentation

### 11.89.2.1 Payload

`CFE_SB_StatsTlm_Payload_t` `CFE_SB_StatsTlm::Payload`

Telemetry payload.

Definition at line 707 of file `cfe_sb_msg.h`.

### 11.89.2.2 TelemetryHeader

`CFE_MSG_TelemetryHeader_t` `CFE_SB_StatsTlm::TelemetryHeader`

Telemetry header.

Definition at line 706 of file `cfe_sb_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/sb/fsw/inc/cfe_sb_msg.h`

## 11.90 CFE\_SB\_StatsTlm\_Payload Struct Reference

```
#include <cfe_sb_msg.h>
```

### Data Fields

- `uint32 MsgIdsInUse`  
*Current number of MsgIds with a destination.*
- `uint32 PeakMsgIdsInUse`  
*Peak number of MsgIds with a destination.*
- `uint32 MaxMsgIdsAllowed`  
*cFE Cfg Param `CFE_PLATFORM_SB_MAX_MSG_IDS`*
- `uint32 PipesInUse`  
*Number of pipes currently in use.*
- `uint32 PeakPipesInUse`  
*Peak number of pipes since last reboot.*
- `uint32 MaxPipesAllowed`  
*cFE Cfg Param `CFE_PLATFORM_SB_MAX_PIPES`*
- `uint32 MemInUse`  
*Memory bytes currently in use for SB msg transfers.*
- `uint32 PeakMemInUse`  
*Peak memory bytes in use for SB msg transfers.*
- `uint32 MaxMemAllowed`  
*cFE Cfg Param `CFE_PLATFORM_SB_BUF_MEMORY_BYTES`*
- `uint32 SubscriptionsInUse`

- **uint32 PeakSubscriptionsInUse**  
*Number of current subscriptions.*
- **uint32 MaxSubscriptionsAllowed**  
*Peak number of subscriptions.*  
*product of [CFE\\_PLATFORM\\_SB\\_MAX\\_MSG\\_IDS](#) and [CFE\\_PLATFORM\\_SB\\_MAX\\_DEST\\_PER\\_PKT](#)*
- **uint32 SBBuffersInUse**  
*Number of SB message buffers currently in use.*
- **uint32 PeakSBBuffersInUse**  
*Max number of SB message buffers in use.*
- **uint32 MaxPipeDepthAllowed**  
*Maximum allowed pipe depth.*
- **CFE\_SB\_PipeDepthStats\_t PipeDepthStats [CFE\_MISSION\_SB\_MAX\_PIPES]**  
*Pipe Depth Statistics [CFE\\_SB\\_PipeDepthStats\\_t](#).*

### 11.90.1 Detailed Description

**Name** SB Statistics Telemetry Packet

SB Statistics packet sent in response to [CFE\\_SB\\_SEND\\_SB\\_STATS\\_CC](#)

Definition at line 660 of file cfe\_sb\_msg.h.

### 11.90.2 Field Documentation

#### 11.90.2.1 MaxMemAllowed

`uint32 CFE_SB_StatsTlm_Payload::MaxMemAllowed`

cFE Cfg Param [CFE\\_PLATFORM\\_SB\\_BUF\\_MEMORY\\_BYTES](#)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMMBMALW

Definition at line 681 of file cfe\_sb\_msg.h.

#### 11.90.2.2 MaxMsgIdsAllowed

`uint32 CFE_SB_StatsTlm_Payload::MaxMsgIdsAllowed`

cFE Cfg Param [CFE\\_PLATFORM\\_SB\\_MAX\\_MSG\\_IDS](#)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMMMIDALW

Definition at line 667 of file cfe\_sb\_msg.h.

#### 11.90.2.3 MaxPipeDepthAllowed

```
uint32 CFE_SB_StatsTlm_Payload::MaxPipeDepthAllowed
```

Maximum allowed pipe depth.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMMPDALW

Definition at line 697 of file cfe\_sb\_msg.h.

#### 11.90.2.4 MaxPipesAllowed

```
uint32 CFE_SB_StatsTlm_Payload::MaxPipesAllowed
```

cFE Cfg Param [CFE\\_PLATFORM\\_SB\\_MAX\\_PIPES](#)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMMPALW

Definition at line 674 of file cfe\_sb\_msg.h.

#### 11.90.2.5 MaxSubscriptionsAllowed

```
uint32 CFE_SB_StatsTlm_Payload::MaxSubscriptionsAllowed
```

product of [CFE\\_PLATFORM\\_SB\\_MAX\\_MSG\\_IDS](#) and [CFE\\_PLATFORM\\_SB\\_MAX\\_DEST\\_PER\\_PKT](#)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMMSALW

Definition at line 688 of file cfe\_sb\_msg.h.

#### 11.90.2.6 MemInUse

```
uint32 CFE_SB_StatsTlm_Payload::MemInUse
```

Memory bytes currently in use for SB msg transfers.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMBMIU

Definition at line 677 of file cfe\_sb\_msg.h.

### 11.90.2.7 MsgIdsInUse

```
uint32 CFE_SB_StatsTlm_Payload::MsgIdsInUse
```

Current number of MsgIds with a destination.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMMIDIU

Definition at line 663 of file cfe\_sb\_msg.h.

### 11.90.2.8 PeakMemInUse

```
uint32 CFE_SB_StatsTlm_Payload::PeakMemInUse
```

Peak memory bytes in use for SB msg transfers.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMPBMIU

Definition at line 679 of file cfe\_sb\_msg.h.

### 11.90.2.9 PeakMsgIdsInUse

```
uint32 CFE_SB_StatsTlm_Payload::PeakMsgIdsInUse
```

Peak number of MsgIds with a destination.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMPMIDIU

Definition at line 665 of file cfe\_sb\_msg.h.

### 11.90.2.10 PeakPipesInUse

```
uint32 CFE_SB_StatsTlm_Payload::PeakPipesInUse
```

Peak number of pipes since last reboot.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMPIIU

Definition at line 672 of file cfe\_sb\_msg.h.

#### 11.90.2.11 PeakSBBuffersInUse

```
uint32 CFE_SB_StatsTlm_Payload::PeakSBBuffersInUse
```

Max number of SB message buffers in use.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMPSBBIU

Definition at line 694 of file cfe\_sb\_msg.h.

#### 11.90.2.12 PeakSubscriptionsInUse

```
uint32 CFE_SB_StatsTlm_Payload::PeakSubscriptionsInUse
```

Peak number of subscriptions.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMPSIU

Definition at line 686 of file cfe\_sb\_msg.h.

#### 11.90.2.13 PipeDepthStats

```
CFE_SB_PipeDepthStats_t CFE_SB_StatsTlm_Payload::PipeDepthStats[CFE_MISSION_SB_MAX_PIPES]
```

Pipe Depth Statistics [CFE\\_SB\\_PipeDepthStats\\_t](#).

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMPDS[CFE\_PLATFORM\_SB\_MAX\_PIPES]

Definition at line 700 of file cfe\_sb\_msg.h.

#### 11.90.2.14 PipesInUse

```
uint32 CFE_SB_StatsTlm_Payload::PipesInUse
```

Number of pipes currently in use.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMPIU

Definition at line 670 of file cfe\_sb\_msg.h.

### 11.90.2.15 SBBuffersInUse

```
uint32 CFE_SB_StatsTlm_Payload::SBBuffersInUse
```

Number of SB message buffers currently in use.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMSBBIU

Definition at line 692 of file cfe\_sb\_msg.h.

### 11.90.2.16 SubscriptionsInUse

```
uint32 CFE_SB_StatsTlm_Payload::SubscriptionsInUse
```

Number of current subscriptions.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_SB\_Stat.SB\_SMSIU

Definition at line 684 of file cfe\_sb\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/sb/fsw/inc/cfe\_sb\_msg.h

## 11.91 CFE\_SB\_SubEntries Struct Reference

SB Previous Subscriptions Entry.

```
#include <cfe_sb_msg.h>
```

### Data Fields

- **CFE\_SB\_MsgId\_t MsgId**  
*MsgId portion of the subscription.*
- **CFE\_SB\_Qos\_t Qos**  
*Qos portion of the subscription.*
- **CFE\_SB\_PipeId\_t Pipe**  
*PipeId portion of the subscription.*

### 11.91.1 Detailed Description

SB Previous Subscriptions Entry.

This structure defines an entry used in the CFE\_SB\_PrevSubsPkt\_t Intended to be used primarily by Software Bus Networking Application (SBN)

Used in structure definition [CFE\\_SB\\_AllSubscriptionsTim\\_t](#)

Definition at line 770 of file cfe\_sb\_msg.h.

### 11.91.2 Field Documentation

#### 11.91.2.1 MsgId

[CFE\\_SB\\_MsgId\\_t](#) CFE\_SB\_SubEntries::MsgId

MsgId portion of the subscription.

Definition at line 773 of file cfe\_sb\_msg.h.

#### 11.91.2.2 Pipe

[CFE\\_SB\\_PipeId\\_t](#) CFE\_SB\_SubEntries::Pipe

Pipeld portion of the subscription.

Definition at line 775 of file cfe\_sb\_msg.h.

#### 11.91.2.3 Qos

[CFE\\_SB\\_Qos\\_t](#) CFE\_SB\_SubEntries::Qos

Qos portion of the subscription.

Definition at line 774 of file cfe\_sb\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/sb/fsw/inc/[cfe\\_sb\\_msg.h](#)

## 11.92 CFE\_SB\_WriteFileInfoCmd Struct Reference

Write File Info Command.

```
#include <cfef_sb_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) `CommandHeader`  
*Command header.*
- [CFE\\_SB\\_WriteFileInfoCmd\\_Payload\\_t](#) `Payload`  
*Command payload.*

### 11.92.1 Detailed Description

Write File Info Command.

Definition at line 503 of file cfe\_sb\_msg.h.

### 11.92.2 Field Documentation

#### 11.92.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) `CFE_SB_WriteFileInfoCmd::CommandHeader`

Command header.

Definition at line 505 of file cfe\_sb\_msg.h.

#### 11.92.2.2 Payload

[CFE\\_SB\\_WriteFileInfoCmd\\_Payload\\_t](#) `CFE_SB_WriteFileInfoCmd::Payload`

Command payload.

Definition at line 506 of file cfe\_sb\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/sb/fsw/inc/[cfef\\_sb\\_msg.h](#)

## 11.93 CFE\_SB\_WriteFileInfoCmd\_Payload Struct Reference

Write File Info Command Payload.

```
#include <cfе_sb_msg.h>
```

### Data Fields

- char [Filename \[CFE\\_MISSION\\_MAX\\_PATH\\_LEN\]](#)

*Path and Filename of data to be loaded.*

#### 11.93.1 Detailed Description

Write File Info Command Payload.

This structure contains a generic definition used by SB commands that write to a file

Definition at line 495 of file cfe\_sb\_msg.h.

#### 11.93.2 Field Documentation

##### 11.93.2.1 Filename

```
char CFE_SB_WriteFileInfoCmd_Payload::Filename[CFE_MISSION_MAX_PATH_LEN]
```

Path and Filename of data to be loaded.

Definition at line 497 of file cfe\_sb\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/sb/fsw/inc/[cfе\\_sb\\_msg.h](#)

## 11.94 CFE\_TBL\_AbortLoadCmd Struct Reference

Abort Load Command.

```
#include <cfе_tbl_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) CommandHeader  
*Command header.*
- [CFE\\_TBL\\_AbortLoadCmd\\_Payload\\_t](#) Payload  
*Command payload.*

### 11.94.1 Detailed Description

Abort Load Command.

Definition at line 684 of file cfe\_tbl\_msg.h.

### 11.94.2 Field Documentation

#### 11.94.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_TBL\_AbortLoadCmd::CommandHeader

Command header.

Definition at line 686 of file cfe\_tbl\_msg.h.

#### 11.94.2.2 Payload

[CFE\\_TBL\\_AbortLoadCmd\\_Payload\\_t](#) CFE\_TBL\_AbortLoadCmd::Payload

Command payload.

Definition at line 687 of file cfe\_tbl\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/tbl/fsw/inc/[cfe\\_tbl\\_msg.h](#)

## 11.95 CFE\_TBL\_AbortLoadCmd\_Payload Struct Reference

Abort Load Command Payload.

```
#include <cfe_tbl_msg.h>
```

## Data Fields

- char [TableName \[CFE\\_MISSION\\_TBL\\_MAX\\_FULL\\_NAME\\_LEN\]](#)

*Full Name of Table whose load is to be aborted.*

### 11.95.1 Detailed Description

Abort Load Command Payload.

For command details, see [CFE\\_TBL\\_ABORT\\_LOAD\\_CC](#)

Definition at line 674 of file cfe\_tbl\_msg.h.

### 11.95.2 Field Documentation

#### 11.95.2.1 TableName

```
char CFE_TBL_AbortLoadCmd_Payload::TableName[CFE_MISSION_TBL_MAX_FULL_NAME_LEN]
```

Full Name of Table whose load is to be aborted.

ASCII string containing full table name identifier of a table whose load is to be aborted

Definition at line 676 of file cfe\_tbl\_msg.h.

The documentation for this struct was generated from the following file:

- [cfe/modules/tbl/fsw/inc/cfe\\_tbl\\_msg.h](#)

## 11.96 CFE\_TBL\_ActivateCmd Struct Reference

Activate Table Command.

```
#include <cfe_tbl_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CommandHeader](#)  
*Command header.*
- [CFE\\_TBL\\_ActivateCmd\\_Payload\\_t Payload](#)  
*Command payload.*

### 11.96.1 Detailed Description

Activate Table Command.

Definition at line 595 of file `cfe_tbl_msg.h`.

### 11.96.2 Field Documentation

#### 11.96.2.1 CommandHeader

`CFE_MSG_CommandHeader_t` `CFE_TBL_ActivateCmd::CommandHeader`

Command header.

Definition at line 597 of file `cfe_tbl_msg.h`.

#### 11.96.2.2 Payload

`CFE_TBL_ActivateCmd_Payload_t` `CFE_TBL_ActivateCmd::Payload`

Command payload.

Definition at line 598 of file `cfe_tbl_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/tbl/fsw/inc/cfe_tbl_msg.h`

## 11.97 CFE\_TBL\_ActivateCmd\_Payload Struct Reference

Activate Table Command Payload.

```
#include <cfe_tbl_msg.h>
```

### Data Fields

- `char TableName [CFE_MISSION_TBL_MAX_FULL_NAME_LEN]`

*Full Name of Table to be activated.*

### 11.97.1 Detailed Description

Activate Table Command Payload.

For command details, see [CFE\\_TBL\\_ACTIVATE\\_CC](#)

Definition at line 585 of file cfe\_tbl\_msg.h.

### 11.97.2 Field Documentation

#### 11.97.2.1 TableName

```
char CFE_TBL_ActivateCmd_Payload::TableName[CFE\_MISSION\_TBL\_MAX\_FULL\_NAME\_LEN]
```

Full Name of Table to be activated.

ASCII string containing full table name identifier of table to be activated

Definition at line 587 of file cfe\_tbl\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/tbl/fsw/inc/[cfe\\_tbl\\_msg.h](#)

## 11.98 CFE\_TBL\_DelCDSCmd\_Payload Struct Reference

Delete Critical Table CDS Command Payload.

```
#include <cfe_tbl_msg.h>
```

### Data Fields

- char [TableName \[CFE\\_MISSION\\_TBL\\_MAX\\_FULL\\_NAME\\_LEN\]](#)  
*Full Name of Table whose CDS is to be deleted.*

### 11.98.1 Detailed Description

Delete Critical Table CDS Command Payload.

For command details, see [CFE\\_TBL\\_DELETE\\_CDS\\_CC](#)

Definition at line 651 of file cfe\_tbl\_msg.h.

## 11.98.2 Field Documentation

### 11.98.2.1 TableName

```
char CFE_TBL_DelCDSCmd_Payload::TableName[CFE\_MISSION\_TBL\_MAX\_FULL\_NAME\_LEN]
```

Full Name of Table whose CDS is to be deleted.

ASCII string containing full table name identifier of a critical table whose CDS is to be deleted

Definition at line 653 of file `cfe_tbl_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/tbl/fsw/inc/cfe_tbl_msg.h`

## 11.99 CFE\_TBL\_DeleteCDSCmd Struct Reference

Delete Critical Table CDS Command.

```
#include <cfe_tbl_msg.h>
```

### Data Fields

- `CFE_MSG_CommandHeader_t CommandHeader`  
*Command header.*
- `CFE_TBL_DelCDSCmd_Payload_t Payload`  
*Command payload.*

### 11.99.1 Detailed Description

Delete Critical Table CDS Command.

Definition at line 663 of file `cfe_tbl_msg.h`.

### 11.99.2 Field Documentation

### 11.99.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_TBL\_DeleteCDSCmd::CommandHeader

Command header.

Definition at line 665 of file cfe\_tbl\_msg.h.

### 11.99.2.2 Payload

[CFE\\_TBL\\_DelCDSCmd\\_Payload\\_t](#) CFE\_TBL\_DeleteCDSCmd::Payload

Command payload.

Definition at line 666 of file cfe\_tbl\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/tbl/fsw/inc/[cfe\\_tbl\\_msg.h](#)

## 11.100 CFE\_TBL\_DumpCmd Struct Reference

```
#include <cfe_tbl_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) CommandHeader  
*Command header.*
- [CFE\\_TBL\\_DumpCmd\\_Payload\\_t](#) Payload  
*Command payload.*

### 11.100.1 Detailed Description

/brief Dump Table Command

Definition at line 547 of file cfe\_tbl\_msg.h.

### 11.100.2 Field Documentation

### 11.100.2.1 CommandHeader

`CFE_MSG_CommandHeader_t` `CFE_TBL_DumpCmd::CommandHeader`

Command header.

Definition at line 549 of file `cfe_tbl_msg.h`.

### 11.100.2.2 Payload

`CFE_TBL_DumpCmd_Payload_t` `CFE_TBL_DumpCmd::Payload`

Command payload.

Definition at line 550 of file `cfe_tbl_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/tbl/fsw/inc/cfe_tbl_msg.h`

## 11.101 CFE\_TBL\_DumpCmd\_Payload Struct Reference

Dump Table Command Payload.

```
#include <cfe_tbl_msg.h>
```

### Data Fields

- `uint16 ActiveTableFlag`  
*CFE\_TBL\_BufferSelect\_INACTIVE=Inactive Table, CFE\_TBL\_BufferSelect\_ACTIVE=Active Table*
- `char TableName [CFE_MISSION_TBL_MAX_FULL_NAME_LEN]`  
*Full name of table to be dumped.*
- `char DumpFilename [CFE_MISSION_MAX_PATH_LEN]`  
*Full Filename where data is to be written.*

### 11.101.1 Detailed Description

Dump Table Command Payload.

For command details, see [CFE\\_TBL\\_DUMP\\_CC](#)

Definition at line 528 of file `cfe_tbl_msg.h`.

### 11.101.2 Field Documentation

#### 11.101.2.1 ActiveTableFlag

`uint16 CFE_TBL_DumpCmd_Payload::ActiveTableFlag`

`CFE_TBL_BufferSelect_INACTIVE`=Inactive Table, `CFE_TBL_BufferSelect_ACTIVE`=Active Table

Selects either the "Inactive" (`CFE_TBL_BufferSelect_INACTIVE`) buffer or the "Active" (`CFE_TBL_BufferSelect_ACTIVE`) buffer to be dumped

Definition at line 530 of file `cfe_tbl_msg.h`.

#### 11.101.2.2 DumpFilename

`char CFE_TBL_DumpCmd_Payload::DumpFilename[CFE_MISSION_MAX_PATH_LEN]`

Full Filename where data is to be written.

ASCII string containing full path of filename where data is to be dumped

Definition at line 539 of file `cfe_tbl_msg.h`.

#### 11.101.2.3 TableName

`char CFE_TBL_DumpCmd_Payload::TableName[CFE_MISSION_TBL_MAX_FULL_NAME_LEN]`

Full name of table to be dumped.

ASCII string containing full table name identifier of table to be dumped

Definition at line 536 of file `cfe_tbl_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/tbl/fsw/inc/cfe_tbl_msg.h`

## 11.102 CFE\_TBL\_DumpRegistryCmd Struct Reference

Dump Registry Command.

```
#include <cfe_tbl_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) CommandHeader  
*Command header.*
- [CFE\\_TBL\\_DumpRegistryCmd\\_Payload\\_t](#) Payload  
*Command payload.*

### 11.102.1 Detailed Description

Dump Registry Command.

Definition at line 617 of file cfe\_tbl\_msg.h.

### 11.102.2 Field Documentation

#### 11.102.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_TBL\_DumpRegistryCmd::CommandHeader

Command header.

Definition at line 619 of file cfe\_tbl\_msg.h.

#### 11.102.2.2 Payload

[CFE\\_TBL\\_DumpRegistryCmd\\_Payload\\_t](#) CFE\_TBL\_DumpRegistryCmd::Payload

Command payload.

Definition at line 620 of file cfe\_tbl\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/tbl/fsw/inc/[cfe\\_tbl\\_msg.h](#)

### 11.103 CFE\_TBL\_DumpRegistryCmd\_Payload Struct Reference

Dump Registry Command Payload.

```
#include <cfe_tbl_msg.h>
```

## Data Fields

- char [DumpFilename \[CFE\\_MISSION\\_MAX\\_PATH\\_LEN\]](#)

*Full Filename where dumped data is to be written.*

### 11.103.1 Detailed Description

Dump Registry Command Payload.

For command details, see [CFE\\_TBL\\_DUMP\\_REGISTRY\\_CC](#)

Definition at line 606 of file cfe\_tbl\_msg.h.

### 11.103.2 Field Documentation

#### 11.103.2.1 DumpFilename

```
char CFE_TBL_DumpRegistryCmd_Payload::DumpFilename[CFE_MISSION_MAX_PATH_LEN]
```

Full Filename where dumped data is to be written.

ASCII string containing full path of filename where registry is to be dumped

Definition at line 608 of file cfe\_tbl\_msg.h.

The documentation for this struct was generated from the following file:

- [cfe/modules/tbl/fsw/inc/cfe\\_tbl\\_msg.h](#)

## 11.104 CFE\_TBL\_File\_Hdr Struct Reference

The definition of the header fields that are included in CFE Table Data files.

```
#include <cfe_tbl_extern_typedefs.h>
```

## Data Fields

- [uint32 Reserved](#)
- [CFE\\_ES\\_MemOffset\\_t Offset](#)
- [CFE\\_ES\\_MemOffset\\_t NumBytes](#)
- char [TableName \[CFE\\_MISSION\\_TBL\\_MAX\\_FULL\\_NAME\\_LEN\]](#)

### 11.104.1 Detailed Description

The definition of the header fields that are included in CFE Table Data files.

This header follows the CFE\_FS header and precedes the actual table data.

Definition at line 71 of file `cfe_tbl_extern_typedefs.h`.

### 11.104.2 Field Documentation

#### 11.104.2.1 NumBytes

`CFE_ES_MemOffset_t` `CFE_TBL_File_Hdr::NumBytes`

Number of bytes to load into table

Definition at line 75 of file `cfe_tbl_extern_typedefs.h`.

#### 11.104.2.2 Offset

`CFE_ES_MemOffset_t` `CFE_TBL_File_Hdr::Offset`

Byte Offset at which load should commence

Definition at line 74 of file `cfe_tbl_extern_typedefs.h`.

#### 11.104.2.3 Reserved

`uint32` `CFE_TBL_File_Hdr::Reserved`

Future Use: NumTblSegments in File?

Definition at line 73 of file `cfe_tbl_extern_typedefs.h`.

#### 11.104.2.4 TableName

`char` `CFE_TBL_File_Hdr::TableName[CFE_MISSION_TBL_MAX_FULL_NAME_LEN]`

Fully qualified name of table to load

Definition at line 76 of file `cfe_tbl_extern_typedefs.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/core_api/fsw/inc/cfe_tbl_extern_typedefs.h`

## 11.105 CFE\_TBL\_FileDef Struct Reference

```
#include <cfef_tbl_filedef.h>
```

### Data Fields

- char [ObjectName](#) [64]  
*Name of instantiated variable that contains desired table image.*
- char [TableName](#) [[CFE\\_MISSION\\_TBL\\_MAX\\_FULL\\_NAME\\_LEN](#)]  
*Name of Table as defined onboard.*
- char [Description](#) [[CFE\\_FS\\_HDR\\_DESC\\_MAX\\_LEN](#)]  
*Description of table image that is included in cFE File Header.*
- char [TgtFilename](#) [[CFE\\_MISSION\\_MAX\\_FILE\\_LEN](#)]  
*Default filename to be used for output of elf2cfetbl utility.*
- [uint32 ObjectSize](#)  
*Size, in bytes, of instantiated object.*

### 11.105.1 Detailed Description

Definition at line 56 of file `cfef_tbl_filedef.h`.

### 11.105.2 Field Documentation

#### 11.105.2.1 Description

```
char CFE_TBL_FileDef::Description[CFE\_FS\_HDR\_DESC\_MAX\_LEN]
```

Description of table image that is included in cFE File Header.

Definition at line 60 of file `cfef_tbl_filedef.h`.

#### 11.105.2.2 ObjectName

```
char CFE_TBL_FileDef::ObjectName[ 64 ]
```

Name of instantiated variable that contains desired table image.

Definition at line 58 of file `cfef_tbl_filedef.h`.

### 11.105.2.3 ObjectSize

```
uint32 CFE_TBL_FileDef::ObjectSize
```

Size, in bytes, of instantiated object.

Definition at line 64 of file `cfe_tbl_filedef.h`.

### 11.105.2.4 TableName

```
char CFE_TBL_FileDef::TableName[CFE_MISSION_TBL_MAX_FULL_NAME_LEN]
```

Name of Table as defined onboard.

Definition at line 59 of file `cfe_tbl_filedef.h`.

### 11.105.2.5 TgtFilename

```
char CFE_TBL_FileDef::TgtFilename[CFE_MISSION_MAX_FILE_LEN]
```

Default filename to be used for output of `elf2cfetbl` utility.

Definition at line 62 of file `cfe_tbl_filedef.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/core_api/fsw/inc/cfe_tbl_filedef.h`

## 11.106 CFE\_TBL\_HousekeepingTlm Struct Reference

```
#include <cfe_tbl_msg.h>
```

### Data Fields

- `CFE_MSG_TelemetryHeader_t TelemetryHeader`  
*Telemetry header.*
- `CFE_TBL_HousekeepingTlm_Payload_t Payload`  
*Telemetry payload.*

### 11.106.1 Detailed Description

Definition at line 783 of file `cfe_tbl_msg.h`.

## 11.106.2 Field Documentation

### 11.106.2.1 Payload

`CFE_TBL_HousekeepingTlm_Payload_t` CFE\_TBL\_HousekeepingTlm::Payload

Telemetry payload.

Definition at line 786 of file `cfe_tbl_msg.h`.

### 11.106.2.2 TelemetryHeader

`CFE_MSG_TelemetryHeader_t` CFE\_TBL\_HousekeepingTlm::TelemetryHeader

Telemetry header.

Definition at line 785 of file `cfe_tbl_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/tbl/fsw/inc/cfe_tbl_msg.h`

## 11.107 CFE\_TBL\_HousekeepingTlm\_Payload Struct Reference

```
#include <cfe_tbl_msg.h>
```

### Data Fields

- `uint8 CommandCounter`  
*Count of valid commands received.*
- `uint8 CommandErrorCounter`  
*Count of invalid commands received.*
- `uint16 NumTables`  
*Number of Tables Registered.*
- `uint16 NumLoadPending`  
*Number of Tables pending on Applications for their update.*
- `uint16 ValidationCounter`  
*Number of completed table validations.*
- `uint32 LastValCrc`  
*Data Integrity Value computed for last table validated.*
- `int32 LastValStatus`  
*Returned status from validation function for last table validated.*
- `bool ActiveBuffer`

- **char LastValTableName [CFE\_MISSION\_TBL\_MAX\_FULL\_NAME\_LEN]**  
*Name of last table validated.*
- **uint8 SuccessValCounter**  
*Total number of successful table validations.*
- **uint8 FailedValCounter**  
*Total number of unsuccessful table validations.*
- **uint8 NumValRequests**  
*Number of times Table Services has requested validations from Apps.*
- **uint8 NumFreeSharedBufs**  
*Number of free Shared Working Buffers.*
- **uint8 ByteAlignPad1**  
*Spare byte to ensure longword alignment.*
- **CFE\_ES\_MemHandle\_t MemPoolHandle**  
*Handle to TBL's memory pool.*
- **CFE\_TIME\_SysTime\_t LastUpdateTime**  
*Time of last table update.*
- **char LastUpdatedTable [CFE\_MISSION\_TBL\_MAX\_FULL\_NAME\_LEN]**  
*Name of the last table updated.*
- **char LastFileLoaded [CFE\_MISSION\_MAX\_PATH\_LEN]**  
*Path and Name of last table image file loaded.*
- **char LastFileDumped [CFE\_MISSION\_MAX\_PATH\_LEN]**  
*Path and Name of last file dumped to.*
- **char LastTableLoaded [CFE\_MISSION\_TBL\_MAX\_FULL\_NAME\_LEN]**  
*Name of the last table loaded.*

### 11.107.1 Detailed Description

**Name** Table Services Housekeeping Packet

Definition at line 724 of file cfe\_tbl\_msg.h.

### 11.107.2 Field Documentation

#### 11.107.2.1 ActiveBuffer

```
bool CFE_TBL_HousekeepingTlm_Payload::ActiveBuffer
```

Indicator of whether table buffer validated was 0=Inactive, 1=Active.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_LastValBuf

Definition at line 751 of file cfe\_tbl\_msg.h.

### 11.107.2.2 ByteAlignPad1

```
uint8 CFE_TBL_HousekeepingTlm_Payload::ByteAlignPad1
```

Spare byte to ensure longword alignment.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_ByteAlignPad1

Definition at line 767 of file cfe\_tbl\_msg.h.

### 11.107.2.3 CommandCounter

```
uint8 CFE_TBL_HousekeepingTlm_Payload::CommandCounter
```

Count of valid commands received.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_CMDPC

Definition at line 729 of file cfe\_tbl\_msg.h.

### 11.107.2.4 CommandErrorCounter

```
uint8 CFE_TBL_HousekeepingTlm_Payload::CommandErrorCounter
```

Count of invalid commands received.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_CMDEC

Definition at line 731 of file cfe\_tbl\_msg.h.

### 11.107.2.5 FailedValCounter

```
uint8 CFE_TBL_HousekeepingTlm_Payload::FailedValCounter
```

Total number of unsuccessful table validations.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_ValFailedCtr

Definition at line 757 of file cfe\_tbl\_msg.h.

### 11.107.2.6 LastFileDumped

```
char CFE_TBL_HousekeepingTlm_Payload::LastFileDumped[CFE_MISSION_MAX_PATH_LEN]
```

Path and Name of last file dumped to.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_LastFileDumped[OS\_MAX\_PATH\_LEN]

Definition at line 777 of file cfe\_tbl\_msg.h.

### 11.107.2.7 LastFileLoaded

```
char CFE_TBL_HousekeepingTlm_Payload::LastFileLoaded[CFE_MISSION_MAX_PATH_LEN]
```

Path and Name of last table image file loaded.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_LastFileLoaded[OS\_MAX\_PATH\_LEN]

Definition at line 775 of file cfe\_tbl\_msg.h.

### 11.107.2.8 LastTableLoaded

```
char CFE_TBL_HousekeepingTlm_Payload::LastTableLoaded[CFE_MISSION_TBL_MAX_FULL_NAME_LEN]
```

Name of the last table loaded.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_LastTableLoaded[CFE\_TBL\_MAX\_FULL\_NAME\_LEN]

Definition at line 779 of file cfe\_tbl\_msg.h.

### 11.107.2.9 LastUpdatedTable

```
char CFE_TBL_HousekeepingTlm_Payload::LastUpdatedTable[CFE_MISSION_TBL_MAX_FULL_NAME_LEN]
```

Name of the last table updated.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_LastUpdTblName[CFE\_TB\_MAX\_FULL\_NAME\_LEN]

Definition at line 773 of file cfe\_tbl\_msg.h.

### 11.107.2.10 LastUpdateTime

`CFE_TIME_SysTime_t` `CFE_TBL_HousekeepingTlm_Payload::LastUpdateTime`

Time of last table update.

**Telemetry Mnemonic(s)** `$sc_$cpu_TBL_LastUpdTime`, `$sc_$cpu_TBL_SECONDS`, `$sc_$cpu_TBL_SUBSECONDS`

Definition at line 771 of file `cfe_tbl_msg.h`.

### 11.107.2.11 LastValCrc

`uint32` `CFE_TBL_HousekeepingTlm_Payload::LastValCrc`

Data Integrity Value computed for last table validated.

**Telemetry Mnemonic(s)** `$sc_$cpu_TBL_LastValCRC`

Definition at line 747 of file `cfe_tbl_msg.h`.

### 11.107.2.12 LastValStatus

`int32` `CFE_TBL_HousekeepingTlm_Payload::LastValStatus`

Returned status from validation function for last table validated.

**Telemetry Mnemonic(s)** `$sc_$cpu_TBL_LastVals`

Definition at line 749 of file `cfe_tbl_msg.h`.

### 11.107.2.13 LastValTableName

`char` `CFE_TBL_HousekeepingTlm_Payload::LastValTableName[CFE_MISSION_TBL_MAX_FULL_NAME_LEN]`

Name of last table validated.

**Telemetry Mnemonic(s)** `$sc_$cpu_TBL_LastValTblName[CFE_TB_MAX_FULL_NAME_LEN]`

Definition at line 753 of file `cfe_tbl_msg.h`.

#### 11.107.2.14 MemPoolHandle

`CFE_ES_MemHandle_t CFE_TBL_HousekeepingTlm_Payload::MemPoolHandle`

Handle to TBL's memory pool.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_MemPoolHandle

Definition at line 769 of file cfe\_tbl\_msg.h.

#### 11.107.2.15 NumFreeSharedBufs

`uint8 CFE_TBL_HousekeepingTlm_Payload::NumFreeSharedBufs`

Number of free Shared Working Buffers.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_NumFreeShrBuf

Definition at line 765 of file cfe\_tbl\_msg.h.

#### 11.107.2.16 NumLoadPending

`uint16 CFE_TBL_HousekeepingTlm_Payload::NumLoadPending`

Number of Tables pending on Applications for their update.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_NumUpdatesPend

Definition at line 739 of file cfe\_tbl\_msg.h.

#### 11.107.2.17 NumTables

`uint16 CFE_TBL_HousekeepingTlm_Payload::NumTables`

Number of Tables Registered.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_NumTables

Definition at line 737 of file cfe\_tbl\_msg.h.

**11.107.2.18 NumValRequests**

```
uint8 CFE_TBL_HousekeepingTlm_Payload::NumValRequests
```

Number of times Table Services has requested validations from Apps.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_ValReqCtr

Definition at line 759 of file cfe\_tbl\_msg.h.

**11.107.2.19 SuccessValCounter**

```
uint8 CFE_TBL_HousekeepingTlm_Payload::SuccessValCounter
```

Total number of successful table validations.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_ValSuccessCtr

Definition at line 755 of file cfe\_tbl\_msg.h.

**11.107.2.20 ValidationCounter**

```
uint16 CFE_TBL_HousekeepingTlm_Payload::ValidationCounter
```

Number of completed table validations.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_ValCompltdCtr

Definition at line 745 of file cfe\_tbl\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/tbl/fsw/inc/cfe\_tbl\_msg.h

**11.108 CFE\_TBL\_Info Struct Reference**

Table Info.

```
#include <cfe_tbl_api_typedefs.h>
```

## Data Fields

- **size\_t Size**  
*Size, in bytes, of Table.*
- **uint32 NumUsers**  
*Number of Apps with access to the table.*
- **uint32 FileCreateTimeSecs**  
*File creation time from last file loaded into table.*
- **uint32 FileCreateTimeSubSecs**  
*File creation time from last file loaded into table.*
- **uint32 Crc**  
*Most recently calculated CRC by TBL services on table contents.*
- **CFE\_TIME\_SysTime\_t TimeOfLastUpdate**  
*Time when Table was last updated.*
- **bool TableLoadedOnce**  
*Flag indicating whether table has been loaded once or not.*
- **bool DumpOnly**  
*Flag indicating Table is NOT to be loaded.*
- **bool DoubleBuffered**  
*Flag indicating Table has a dedicated inactive buffer.*
- **bool UserDefAddr**  
*Flag indicating Table address was defined by Owner Application.*
- **bool Critical**  
*Flag indicating Table contents are maintained in a CDS.*
- **char LastFileLoaded [CFE\_MISSION\_MAX\_PATH\_LEN]**  
*Filename of last file loaded into table.*

### 11.108.1 Detailed Description

Table Info.

Definition at line 109 of file cfe\_tbl\_api\_typedefs.h.

### 11.108.2 Field Documentation

#### 11.108.2.1 Crc

`uint32 CFE_TBL_Info::Crc`

Most recently calculated CRC by TBL services on table contents.

Definition at line 115 of file cfe\_tbl\_api\_typedefs.h.

### 11.108.2.2 Critical

```
bool CFE_TBL_Info::Critical
```

Flag indicating Table contents are maintained in a CDS.

Definition at line 121 of file cfe\_tbl\_api\_typedefs.h.

### 11.108.2.3 DoubleBuffered

```
bool CFE_TBL_Info::DoubleBuffered
```

Flag indicating Table has a dedicated inactive buffer.

Definition at line 119 of file cfe\_tbl\_api\_typedefs.h.

### 11.108.2.4 DumpOnly

```
bool CFE_TBL_Info::DumpOnly
```

Flag indicating Table is NOT to be loaded.

Definition at line 118 of file cfe\_tbl\_api\_typedefs.h.

### 11.108.2.5 FileCreateTimeSecs

```
uint32 CFE_TBL_Info::FileCreateTimeSecs
```

File creation time from last file loaded into table.

Definition at line 113 of file cfe\_tbl\_api\_typedefs.h.

### 11.108.2.6 FileCreateTimeSubSecs

```
uint32 CFE_TBL_Info::FileCreateTimeSubSecs
```

File creation time from last file loaded into table.

Definition at line 114 of file cfe\_tbl\_api\_typedefs.h.

**11.108.2.7 LastFileLoaded**

```
char CFE_TBL_Info::LastFileLoaded[CFE_MISSION_MAX_PATH_LEN]
```

Filename of last file loaded into table.

Definition at line 122 of file cfe\_tbl\_api\_typedefs.h.

Referenced by DS\_AppProcessHK().

**11.108.2.8 NumUsers**

```
uint32 CFE_TBL_Info::NumUsers
```

Number of Apps with access to the table.

Definition at line 112 of file cfe\_tbl\_api\_typedefs.h.

**11.108.2.9 Size**

```
size_t CFE_TBL_Info::Size
```

Size, in bytes, of Table.

Definition at line 111 of file cfe\_tbl\_api\_typedefs.h.

**11.108.2.10 TableLoadedOnce**

```
bool CFE_TBL_Info::TableLoadedOnce
```

Flag indicating whether table has been loaded once or not.

Definition at line 117 of file cfe\_tbl\_api\_typedefs.h.

**11.108.2.11 TimeOfLastUpdate**

```
CFE_TIME_SysTime_t CFE_TBL_Info::TimeOfLastUpdate
```

Time when Table was last updated.

Definition at line 116 of file cfe\_tbl\_api\_typedefs.h.

### 11.108.2.12 UserDefAddr

```
bool CFE_TBL_Info::UserDefAddr
```

Flag indicating Table address was defined by Owner Application.

Definition at line 120 of file `cfe_tbl_api_typedefs.h`.

The documentation for this struct was generated from the following file:

- [cfe/modules/core\\_api/fsw/inc/cfe\\_tbl\\_api\\_typedefs.h](#)

## 11.109 CFE\_TBL\_LoadCmd Struct Reference

Load Table Command.

```
#include <cfe_tbl_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CommandHeader](#)  
*Command header.*
- [CFE\\_TBL\\_LoadCmd\\_Payload\\_t Payload](#)  
*Command payload.*

### 11.109.1 Detailed Description

Load Table Command.

Definition at line 517 of file `cfe_tbl_msg.h`.

### 11.109.2 Field Documentation

#### 11.109.2.1 CommandHeader

```
CFE\_MSG\_CommandHeader\_t CFE_TBL_LoadCmd::CommandHeader
```

Command header.

Definition at line 519 of file `cfe_tbl_msg.h`.

### 11.109.2.2 Payload

`CFE_TBL_LoadCmd_Payload_t` `CFE_TBL_LoadCmd::Payload`

Command payload.

Definition at line 520 of file `cfe_tbl_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/tbl/fsw/inc/cfe_tbl_msg.h`

## 11.110 CFE\_TBL\_LoadCmd\_Payload Struct Reference

Load Table Command Payload.

```
#include <cfe_tbl_msg.h>
```

### Data Fields

- `char LoadFilename [CFE_MISSION_MAX_PATH_LEN]`  
*Filename (and path) of data to be loaded.*

### 11.110.1 Detailed Description

Load Table Command Payload.

For command details, see [CFE\\_TBL\\_LOAD\\_CC](#)

Definition at line 509 of file `cfe_tbl_msg.h`.

### 11.110.2 Field Documentation

#### 11.110.2.1 LoadFilename

`char CFE_TBL_LoadCmd_Payload::LoadFilename [CFE_MISSION_MAX_PATH_LEN]`

Filename (and path) of data to be loaded.

Definition at line 511 of file `cfe_tbl_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/tbl/fsw/inc/cfe_tbl_msg.h`

## 11.111 CFE\_TBL\_NoArgsCmd Struct Reference

Generic "no arguments" command.

```
#include <cfef_tbl_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CommandHeader](#)  
*Command header.*

#### 11.111.1 Detailed Description

Generic "no arguments" command.

This command structure is used for commands that do not have any parameters. This includes:

1. The Housekeeping Request Message
2. The No-Op Command (For details, see [CFE\\_TBL\\_NOOP\\_CC](#))
3. The Reset Counters Command (For details, see [CFE\\_TBL\\_RESET\\_COUNTERS\\_CC](#))

Definition at line 490 of file cfe\_tbl\_msg.h.

#### 11.111.2 Field Documentation

##### 11.111.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_TBL\_NoArgsCmd::CommandHeader

Command header.

Definition at line 492 of file cfe\_tbl\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/tbl/fsw/inc/[cfe\\_tbl\\_msg.h](#)

## 11.112 CFE\_TBL\_NotifyCmd Struct Reference

```
#include <cfef_tbl_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) CommandHeader  
*Command header.*
- [CFE\\_TBL\\_NotifyCmd\\_Payload\\_t](#) Payload  
*Command payload.*

### 11.112.1 Detailed Description

/brief Table Management Notification Command

Definition at line 711 of file cfe\_tbl\_msg.h.

### 11.112.2 Field Documentation

#### 11.112.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_TBL\_NotifyCmd::CommandHeader

Command header.

Definition at line 713 of file cfe\_tbl\_msg.h.

#### 11.112.2.2 Payload

[CFE\\_TBL\\_NotifyCmd\\_Payload\\_t](#) CFE\_TBL\_NotifyCmd::Payload

Command payload.

Definition at line 714 of file cfe\_tbl\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/tbl/fsw/inc/[cfe\\_tbl\\_msg.h](#)

### 11.113 CFE\_TBL\_NotifyCmd\_Payload Struct Reference

Table Management Notification Command Payload.

```
#include <cfe_tbl_msg.h>
```

## Data Fields

- [uint32 Parameter](#)

*Application specified command parameter.*

### 11.113.1 Detailed Description

Table Management Notification Command Payload.

#### Description

Whenever an application that owns a table calls the [CFE\\_TBL\\_NotifyByMessage](#) API following the table registration, Table services will generate the following command message with the application specified message ID, command code and parameter whenever the table requires management (e.g. - loads and validations).

Definition at line 703 of file cfe\_tbl\_msg.h.

### 11.113.2 Field Documentation

#### 11.113.2.1 Parameter

`uint32 CFE_TBL_NotifyCmd_Payload::Parameter`

Application specified command parameter.

Definition at line 705 of file cfe\_tbl\_msg.h.

The documentation for this struct was generated from the following file:

- [cfe/modules/tbl/fsw/inc/cfe\\_tbl\\_msg.h](#)

## 11.114 CFE\_TBL\_SendRegistryCmd Struct Reference

Send Table Registry Command.

```
#include <cfe_tbl_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CommandHeader](#)  
*Command header.*
- [CFE\\_TBL\\_SendRegistryCmd\\_Payload\\_t Payload](#)  
*Command payload.*

### 11.114.1 Detailed Description

Send Table Registry Command.

Definition at line 640 of file `cfe_tbl_msg.h`.

### 11.114.2 Field Documentation

#### 11.114.2.1 CommandHeader

`CFE_MSG_CommandHeader_t` `CFE_TBL_SendRegistryCmd::CommandHeader`

Command header.

Definition at line 642 of file `cfe_tbl_msg.h`.

#### 11.114.2.2 Payload

`CFE_TBL_SendRegistryCmd_Payload_t` `CFE_TBL_SendRegistryCmd::Payload`

Command payload.

Definition at line 643 of file `cfe_tbl_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/tbl/fsw/inc/cfe_tbl_msg.h`

## 11.115 CFE\_TBL\_SendRegistryCmd\_Payload Struct Reference

Send Table Registry Command Payload.

```
#include <cfe_tbl_msg.h>
```

### Data Fields

- char `TableName` [`CFE_MISSION_TBL_MAX_FULL_NAME_LEN`]

*Full Name of Table whose registry entry is to be telemetered.*

### 11.115.1 Detailed Description

Send Table Registry Command Payload.

For command details, see [CFE\\_TBL\\_SEND\\_REGISTRY\\_CC](#)

Definition at line 628 of file cfe\_tbl\_msg.h.

### 11.115.2 Field Documentation

#### 11.115.2.1 TableName

```
char CFE_TBL_SendRegistryCmd_Payload::TableName[CFE\_MISSION\_TBL\_MAX\_FULL\_NAME\_LEN]
```

Full Name of Table whose registry entry is to be telemetered.

ASCII string containing full table name identifier of table whose registry entry is to be telemetered via [CFE\\_TBL\\_TableRegistryTlm\\_t](#)

Definition at line 630 of file cfe\_tbl\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/tbl/fsw/inc/[cfe\\_tbl\\_msg.h](#)

## 11.116 CFE\_TBL\_TableRegistryTlm Struct Reference

```
#include <cfe_tbl_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_TelemetryHeader\\_t TelemetryHeader](#)  
*Telemetry header.*
- [CFE\\_TBL\\_TblRegPacket\\_Payload\\_t Payload](#)  
*Telemetry payload.*

### 11.116.1 Detailed Description

Definition at line 830 of file cfe\_tbl\_msg.h.

## 11.116.2 Field Documentation

### 11.116.2.1 Payload

`CFE_TBL_TblRegPacket_Payload_t` `CFE_TBL_TableRegistryTlm::Payload`

Telemetry payload.

Definition at line 833 of file `cfe_tbl_msg.h`.

### 11.116.2.2 TelemetryHeader

`CFE_MSG_TelemetryHeader_t` `CFE_TBL_TableRegistryTlm::TelemetryHeader`

Telemetry header.

Definition at line 832 of file `cfe_tbl_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/tbl/fsw/inc/cfe_tbl_msg.h`

## 11.117 CFE\_TBL\_TblRegPacket\_Payload Struct Reference

```
#include <cfe_tbl_msg.h>
```

### Data Fields

- `CFE_ES_MemOffset_t` `Size`  
*Size, in bytes, of Table.*
- `uint32` `Crc`  
*Most recently calculated CRC of Table.*
- `CFE_ES_MemAddress_t` `ActiveBufferAddr`  
*Address of Active Buffer.*
- `CFE_ES_MemAddress_t` `InactiveBufferAddr`  
*Address of Inactive Buffer.*
- `CFE_ES_MemAddress_t` `ValidationFuncPtr`  
*Ptr to Owner App's function that validates tbl contents.*
- `CFE_TIME_SysTime_t` `TimeOfLastUpdate`  
*Time when Table was last updated.*
- `uint32` `FileCreateTimeSecs`  
*File creation time from last file loaded into table.*
- `uint32` `FileCreateTimeSubSecs`

*File creation time from last file loaded into table.*

- bool [TableLoadedOnce](#)

*Flag indicating whether table has been loaded once or not.*

- bool [LoadPending](#)

*Flag indicating an inactive buffer is ready to be copied.*

- bool [DumpOnly](#)

*Flag indicating Table is NOT to be loaded.*

- bool [DoubleBuffered](#)

*Flag indicating Table has a dedicated inactive buffer.*

- char [Name \[CFE\\_MISSION\\_TBL\\_MAX\\_FULL\\_NAME\\_LEN\]](#)

*Processor specific table name.*

- char [LastFileLoaded \[CFE\\_MISSION\\_MAX\\_PATH\\_LEN\]](#)

*Filename of last file loaded into table.*

- char [OwnerAppName \[CFE\\_MISSION\\_MAX\\_API\\_LEN\]](#)

*Name of owning application.*

- bool [Critical](#)

*Indicates whether table is Critical or not.*

- uint8 [ByteAlign4](#)

*Spare byte to maintain byte alignment.*

### 11.117.1 Detailed Description

#### Name Table Registry Info Packet

Definition at line 792 of file cfe\_tbl\_msg.h.

### 11.117.2 Field Documentation

#### 11.117.2.1 ActiveBufferAddr

[CFE\\_ES\\_MemAddress\\_t](#) [CFE\\_TBL\\_TblRegPacket\\_Payload::ActiveBufferAddr](#)

Address of Active Buffer.

#### Telemetry Mnemonic(s) \$sc\_\$cpu\_TBL\_ActBufAdd

Definition at line 798 of file cfe\_tbl\_msg.h.

### 11.117.2.2 ByteAlign4

```
uint8 CFE_TBL_TblRegPacket_Payload::ByteAlign4
```

Spare byte to maintain byte alignment.

#### **Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_Spare4

Definition at line 826 of file cfe\_tbl\_msg.h.

### 11.117.2.3 Crc

```
uint32 CFE_TBL_TblRegPacket_Payload::Crc
```

Most recently calculated CRC of Table.

#### **Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_CRC

Definition at line 796 of file cfe\_tbl\_msg.h.

### 11.117.2.4 Critical

```
bool CFE_TBL_TblRegPacket_Payload::Critical
```

Indicates whether table is Critical or not.

#### **Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_Spare3

Definition at line 824 of file cfe\_tbl\_msg.h.

### 11.117.2.5 DoubleBuffered

```
bool CFE_TBL_TblRegPacket_Payload::DoubleBuffered
```

Flag indicating Table has a dedicated inactive buffer.

#### **Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_DblBuffered

Definition at line 816 of file cfe\_tbl\_msg.h.

### 11.117.2.6 DumpOnly

```
bool CFE_TBL_TblRegPacket_Payload::DumpOnly
```

Flag indicating Table is NOT to be loaded.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_DumpOnly

Definition at line 814 of file cfe\_tbl\_msg.h.

### 11.117.2.7 FileCreateTimeSecs

```
uint32 CFE_TBL_TblRegPacket_Payload::FileCreateTimeSecs
```

File creation time from last file loaded into table.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_FILECSECONDS

Definition at line 806 of file cfe\_tbl\_msg.h.

### 11.117.2.8 FileCreateTimeSubSecs

```
uint32 CFE_TBL_TblRegPacket_Payload::FileCreateTimeSubSecs
```

File creation time from last file loaded into table.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_FILECSUBSECONDS

Definition at line 808 of file cfe\_tbl\_msg.h.

### 11.117.2.9 InactiveBufferAddr

```
CFE_ES_MemAddress_t CFE_TBL_TblRegPacket_Payload::InactiveBufferAddr
```

Address of Inactive Buffer.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_IActBufAdd

Definition at line 800 of file cfe\_tbl\_msg.h.

### 11.117.2.10 LastFileLoaded

```
char CFE_TBL_TblRegPacket_Payload::LastFileLoaded[CFE_MISSION_MAX_PATH_LEN]
```

Filename of last file loaded into table.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_LastFileUpd[OS\_MAX\_PATH\_LEN]

Definition at line 820 of file cfe\_tbl\_msg.h.

### 11.117.2.11 LoadPending

```
bool CFE_TBL_TblRegPacket_Payload::LoadPending
```

Flag indicating an inactive buffer is ready to be copied.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_UpdatePndng

Definition at line 812 of file cfe\_tbl\_msg.h.

### 11.117.2.12 Name

```
char CFE_TBL_TblRegPacket_Payload::Name[CFE_MISSION_TBL_MAX_FULL_NAME_LEN]
```

Processor specific table name.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_Name[CFE\_TB\_MAX\_FULL\_NAME\_LEN]

Definition at line 818 of file cfe\_tbl\_msg.h.

### 11.117.2.13 OwnerAppName

```
char CFE_TBL_TblRegPacket_Payload::OwnerAppName[CFE_MISSION_MAX_API_LEN]
```

Name of owning application.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_OwnerApp[OS\_MAX\_API\_NAME]

Definition at line 822 of file cfe\_tbl\_msg.h.

## 11.117.2.14 Size

```
CFE_ES_MemOffset_t CFE_TBL_TblRegPacket_Payload::Size
```

Size, in bytes, of Table.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_SIZE

Definition at line 794 of file cfe\_tbl\_msg.h.

## 11.117.2.15 TableLoadedOnce

```
bool CFE_TBL_TblRegPacket_Payload::TableLoadedOnce
```

Flag indicating whether table has been loaded once or not.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_LoadedOnce

Definition at line 810 of file cfe\_tbl\_msg.h.

## 11.117.2.16 TimeOfLastUpdate

```
CFE_TIME_SysTime_t CFE_TBL_TblRegPacket_Payload::TimeOfLastUpdate
```

Time when Table was last updated.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_TimeLastUpd, \$sc\_\$cpu\_TBL\_TLUSECONDS, \$sc\_\$cpu\_TBL\_TLUSUB←  
SECONDS

Definition at line 804 of file cfe\_tbl\_msg.h.

## 11.117.2.17 ValidationFuncPtr

```
CFE_ES_MemAddress_t CFE_TBL_TblRegPacket_Payload::ValidationFuncPtr
```

Ptr to Owner App's function that validates tbl contents.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TBL\_ValFuncPtr

Definition at line 802 of file cfe\_tbl\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/tbl/fsw/inc/cfe\_tbl\_msg.h

## 11.118 CFE\_TBL\_ValidateCmd Struct Reference

Validate Table Command.

```
#include <cfef_tbl_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t](#) CommandHeader  
*Command header.*
- [CFE\\_TBL\\_ValidateCmd\\_Payload\\_t](#) Payload  
*Command payload.*

#### 11.118.1 Detailed Description

Validate Table Command.

Definition at line 574 of file cfe\_tbl\_msg.h.

#### 11.118.2 Field Documentation

##### 11.118.2.1 CommandHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) CFE\_TBL\_ValidateCmd::CommandHeader

Command header.

Definition at line 576 of file cfe\_tbl\_msg.h.

##### 11.118.2.2 Payload

[CFE\\_TBL\\_ValidateCmd\\_Payload\\_t](#) CFE\_TBL\_ValidateCmd::Payload

Command payload.

Definition at line 577 of file cfe\_tbl\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/tbl/fsw/inc/[cfef\\_tbl\\_msg.h](#)

## 11.119 CFE\_TBL\_ValidateCmd\_Payload Struct Reference

Validate Table Command Payload.

```
#include <cfef_tbl_msg.h>
```

### Data Fields

- `uint16 ActiveTableFlag`  
*CFE\_TBL\_BufferSelect\_INACTIVE=Inactive Table, CFE\_TBL\_BufferSelect\_ACTIVE=Active Table*
- `char TableName [CFE_MISSION_TBL_MAX_FULL_NAME_LEN]`  
*Full Name of Table to be validated.*

#### 11.119.1 Detailed Description

Validate Table Command Payload.

For command details, see [CFE\\_TBL\\_VALIDATE\\_CC](#)

Definition at line 558 of file cfe\_tbl\_msg.h.

#### 11.119.2 Field Documentation

##### 11.119.2.1 ActiveTableFlag

```
uint16 CFE_TBL_ValidateCmd_Payload::ActiveTableFlag
```

`CFE_TBL_BufferSelect_INACTIVE`=Inactive Table, `CFE_TBL_BufferSelect_ACTIVE`=Active Table

Selects either the "Inactive" (`CFE_TBL_BufferSelect_INACTIVE`) buffer or the "Active" (`CFE_TBL_BufferSelect_ACTIVE`) buffer to be validated

Definition at line 560 of file cfe\_tbl\_msg.h.

##### 11.119.2.2 TableName

```
char CFE_TBL_ValidateCmd_Payload::TableName [CFE_MISSION_TBL_MAX_FULL_NAME_LEN]
```

Full Name of Table to be validated.

ASCII string containing full table name identifier of table to be validated

Definition at line 566 of file cfe\_tbl\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/tbl/fsw/inc/[cfe\\_tbl\\_msg.h](#)

## 11.120 CFE\_TIME\_DiagnosticTlm Struct Reference

```
#include <cfе_time_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_TelemetryHeader\\_t TelemetryHeader](#)  
*Telemetry header.*
- [CFE\\_TIME\\_DiagnosticTlm\\_Payload\\_t Payload](#)  
*Telemetry payload.*

### 11.120.1 Detailed Description

Definition at line 1122 of file cfe\_time\_msg.h.

### 11.120.2 Field Documentation

#### 11.120.2.1 Payload

[CFE\\_TIME\\_DiagnosticTlm\\_Payload\\_t](#) CFE\_TIME\_DiagnosticTlm::Payload

Telemetry payload.

Definition at line 1125 of file cfe\_time\_msg.h.

#### 11.120.2.2 TelemetryHeader

[CFE\\_MSG\\_TelemetryHeader\\_t](#) CFE\_TIME\_DiagnosticTlm::TelemetryHeader

Telemetry header.

Definition at line 1124 of file cfe\_time\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/time/fsw/inc/[cfе\\_time\\_msg.h](#)

## 11.121 CFE\_TIME\_DiagnosticTlm\_Payload Struct Reference

```
#include <cfе_time_msg.h>
```

## Data Fields

- **CFE\_TIME\_SysTime\_t AtToneMET**  
*MET at time of tone.*
- **CFE\_TIME\_SysTime\_t AtToneSTCF**  
*STCF at time of tone.*
- **CFE\_TIME\_SysTime\_t AtToneDelay**  
*Adjustment for slow tone detection.*
- **CFE\_TIME\_SysTime\_t AtToneLatch**  
*Local clock latched at time of tone.*
- **int16 AtToneLeapSeconds**  
*Leap Seconds at time of tone.*
- **CFE\_TIME\_ClockState\_Enum\_t ClockStateAPI**  
*Clock state as per API.*
- **CFE\_TIME\_SysTime\_t TimeSinceTone**  
*Time elapsed since the tone.*
- **CFE\_TIME\_SysTime\_t CurrentLatch**  
*Local clock latched just "now".*
- **CFE\_TIME\_SysTime\_t CurrentMET**  
*MET at this instant.*
- **CFE\_TIME\_SysTime\_t CurrentTAI**  
*TAI at this instant.*
- **CFE\_TIME\_SysTime\_t CurrentUTC**  
*UTC at this instant.*
- **int16 ClockSetState**  
*Time has been "set".*
- **int16 ClockFlyState**  
*Current fly-wheel state.*
- **int16 ClockSource**  
*Internal vs external, etc.*
- **int16 ClockSignal**  
*Primary vs redundant, etc.*
- **int16 ServerFlyState**  
*Used by clients only.*
- **int16 Forced2Fly**  
*Commanded into fly-wheel.*
- **uint16 ClockStateFlags**  
*Clock State Flags.*
- **int16 OneTimeDirection**  
*One time STCF adjustment direction (Add = 1, Sub = 2)*
- **int16 OneHzDirection**  
*1Hz STCF adjustment direction*
- **int16 DelayDirection**  
*Client latency adjustment direction.*
- **CFE\_TIME\_SysTime\_t OneTimeAdjust**  
*Previous one-time STCF adjustment.*
- **CFE\_TIME\_SysTime\_t OneHzAdjust**

- *Current 1Hz STCF adjustment.*
- **CFE\_TIME\_SysTime\_t ToneSignalLatch**
  - Local Clock latched at most recent tone signal.*
- **CFE\_TIME\_SysTime\_t ToneDataLatch**
  - Local Clock latched at arrival of tone data.*
- **uint32 ToneMatchCounter**
  - Tone signal / data verification count.*
- **uint32 ToneMatchErrorCounter**
  - Tone signal / data verification error count.*
- **uint32 ToneSignalCounter**
  - Tone signal detected SB message count.*
- **uint32 ToneDataCounter**
  - Time at the tone data SB message count.*
- **uint32 ToneIntCounter**
  - Tone signal ISR execution count.*
- **uint32 ToneIntErrorCounter**
  - Tone signal ISR error count.*
- **uint32 ToneTaskCounter**
  - Tone task execution count.*
- **uint32 VersionCounter**
  - Count of mods to time at tone reference data (version)*
- **uint32 LocalIntCounter**
  - Local 1Hz ISR execution count.*
- **uint32 LocalTaskCounter**
  - Local 1Hz task execution count.*
- **uint32 VirtualMET**
  - Software MET.*
- **uint32 MinElapsed**
  - Min tone signal / data pkt arrival window (Sub-seconds)*
- **uint32 MaxElapsed**
  - Max tone signal / data pkt arrival window (Sub-seconds)*
- **CFE\_TIME\_SysTime\_t MaxLocalClock**
  - Max local clock value before rollover.*
- **uint32 ToneOverLimit**
  - Max between tone signal interrupts.*
- **uint32 ToneUnderLimit**
  - Min between tone signal interrupts.*
- **uint32 DataStoreStatus**
  - Data Store status (preserved across processor reset)*

#### 11.121.1 Detailed Description

**Name** Time Services Diagnostics Packet

Definition at line 976 of file cfe\_time\_msg.h.

## 11.121.2 Field Documentation

### 11.121.2.1 AtToneDelay

`CFE_TIME_SysTime_t` `CFE_TIME_DiagnosticTlm_Payload::AtToneDelay`

Adjustment for slow tone detection.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DLlatentS, \$sc\_\$cpu\_TIME\_DLlatentSs

Definition at line 985 of file cfe\_time\_msg.h.

### 11.121.2.2 AtToneLatch

`CFE_TIME_SysTime_t` `CFE_TIME_DiagnosticTlm_Payload::AtToneLatch`

Local clock latched at time of tone.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DTVlaidS, \$sc\_\$cpu\_TIME\_DTVlaidSs

Definition at line 987 of file cfe\_time\_msg.h.

### 11.121.2.3 AtToneLeapSeconds

`int16` `CFE_TIME_DiagnosticTlm_Payload::AtToneLeapSeconds`

Leap Seconds at time of tone.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DLepS

Definition at line 990 of file cfe\_time\_msg.h.

### 11.121.2.4 AtToneMET

`CFE_TIME_SysTime_t` `CFE_TIME_DiagnosticTlm_Payload::AtToneMET`

MET at time of tone.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DTMETS, \$sc\_\$cpu\_TIME\_DTMETSs

Definition at line 981 of file cfe\_time\_msg.h.

### 11.121.2.5 AtToneSTCF

`CFE_TIME_SysTime_t` `CFE_TIME_DiagnosticTlm_Payload::AtToneSTCF`

STCF at time of tone.

**Telemetry Mnemonic(s)** `$sc_$cpu_TIME_DSTCFS`, `$sc_$cpu_TIME_DSTCFSS`

Definition at line 983 of file `cfe_time_msg.h`.

### 11.121.2.6 ClockFlyState

`int16` `CFE_TIME_DiagnosticTlm_Payload::ClockFlyState`

Current fly-wheel state.

**Telemetry Mnemonic(s)** `$sc_$cpu_TIME_DFlywheel`

Definition at line 1014 of file `cfe_time_msg.h`.

### 11.121.2.7 ClockSetState

`int16` `CFE_TIME_DiagnosticTlm_Payload::ClockSetState`

Time has been "set".

**Telemetry Mnemonic(s)** `$sc_$cpu_TIME_DValid`

Definition at line 1012 of file `cfe_time_msg.h`.

### 11.121.2.8 ClockSignal

`int16` `CFE_TIME_DiagnosticTlm_Payload::ClockSignal`

Primary vs redundant, etc.

**Telemetry Mnemonic(s)** `$sc_$cpu_TIME_DSignal`

Definition at line 1018 of file `cfe_time_msg.h`.

### 11.121.2.9 ClockSource

```
int16 CFE_TIME_DiagnosticTlm_Payload::ClockSource
```

Internal vs external, etc.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DSource

Definition at line 1016 of file cfe\_time\_msg.h.

### 11.121.2.10 ClockStateAPI

```
CFE_TIME_ClockState_Enum_t CFE_TIME_DiagnosticTlm_Payload::ClockStateAPI
```

Clock state as per API.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DAPIState

Definition at line 992 of file cfe\_time\_msg.h.

### 11.121.2.11 ClockStateFlags

```
uint16 CFE_TIME_DiagnosticTlm_Payload::ClockStateFlags
```

Clock State Flags.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DStateFlags, \$sc\_\$cpu\_TIME\_DFlagSet, \$sc\_\$cpu\_TIME\_DFlagFly,  
\$sc\_\$cpu\_TIME\_DFlagSrc, \$sc\_\$cpu\_TIME\_DFlagPri, \$sc\_\$cpu\_TIME\_DFlagSfly, \$sc\_↔  
\$cpu\_TIME\_DFlagCfly, \$sc\_\$cpu\_TIME\_DFlagAdj, \$sc\_\$cpu\_TIME\_DFlag1Hzd, \$sc\_↔  
\$cpu\_TIME\_DFlagClat, \$sc\_\$cpu\_TIME\_DFlagSorC, \$sc\_\$cpu\_TIME\_DFlagNIU

Definition at line 1028 of file cfe\_time\_msg.h.

### 11.121.2.12 CurrentLatch

```
CFE_TIME_SysTime_t CFE_TIME_DiagnosticTlm_Payload::CurrentLatch
```

Local clock latched just "now".

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DLocalS, \$sc\_\$cpu\_TIME\_DLocalSs

Definition at line 1000 of file cfe\_time\_msg.h.

### 11.121.2.13 CurrentMET

`CFE_TIME_SysTime_t` `CFE_TIME_DiagnosticTlm_Payload::CurrentMET`

MET at this instant.

**Telemetry Mnemonic(s)** `$sc_$cpu_TIME_DMETS`, `$sc_$cpu_TIME_DMETSS`

Definition at line 1002 of file `cfe_time_msg.h`.

### 11.121.2.14 CurrentTAI

`CFE_TIME_SysTime_t` `CFE_TIME_DiagnosticTlm_Payload::CurrentTAI`

TAI at this instant.

**Telemetry Mnemonic(s)** `$sc_$cpu_TIME_DTAIS`, `$sc_$cpu_TIME_DTAISS`

Definition at line 1004 of file `cfe_time_msg.h`.

### 11.121.2.15 CurrentUTC

`CFE_TIME_SysTime_t` `CFE_TIME_DiagnosticTlm_Payload::CurrentUTC`

UTC at this instant.

**Telemetry Mnemonic(s)** `$sc_$cpu_TIME_DUTCS`, `$sc_$cpu_TIME_DUTCSS`

Definition at line 1006 of file `cfe_time_msg.h`.

### 11.121.2.16 DataStoreStatus

`uint32` `CFE_TIME_DiagnosticTlm_Payload::DataStoreStatus`

Data Store status (preserved across processor reset)

**Telemetry Mnemonic(s)** `$sc_$cpu_TIME_DataStStat`

Definition at line 1118 of file `cfe_time_msg.h`.

### 11.121.2.17 DelayDirection

```
int16 CFE_TIME_DiagnosticTlm_Payload::DelayDirection
```

Client latency adjustment direction.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DLlatentDir

Definition at line 1038 of file cfe\_time\_msg.h.

### 11.121.2.18 Forced2Fly

```
int16 CFE_TIME_DiagnosticTlm_Payload::Forced2Fly
```

Commanded into fly-wheel.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DCMD2Fly

Definition at line 1022 of file cfe\_time\_msg.h.

### 11.121.2.19 LocalIntCounter

```
uint32 CFE_TIME_DiagnosticTlm_Payload::LocalIntCounter
```

Local 1Hz ISR execution count.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_D1HzISRCNT

Definition at line 1076 of file cfe\_time\_msg.h.

### 11.121.2.20 LocalTaskCounter

```
uint32 CFE_TIME_DiagnosticTlm_Payload::LocalTaskCounter
```

Local 1Hz task execution count.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_D1HzTaskCNT

Definition at line 1078 of file cfe\_time\_msg.h.

### 11.121.2.21 MaxElapsed

`uint32 CFE_TIME_DiagnosticTlm_Payload::MaxElapsed`

Max tone signal / data pkt arrival window (Sub-seconds)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DMaxWindow

Definition at line 1098 of file cfe\_time\_msg.h.

### 11.121.2.22 MaxLocalClock

`CFE_TIME_SysTime_t CFE_TIME_DiagnosticTlm_Payload::MaxLocalClock`

Max local clock value before rollover.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DWrapS, \$sc\_\$cpu\_TIME\_DWrapSs

Definition at line 1104 of file cfe\_time\_msg.h.

### 11.121.2.23 MinElapsed

`uint32 CFE_TIME_DiagnosticTlm_Payload::MinElapsed`

Min tone signal / data pkt arrival window (Sub-seconds)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DMinWindow

Definition at line 1096 of file cfe\_time\_msg.h.

### 11.121.2.24 OneHzAdjust

`CFE_TIME_SysTime_t CFE_TIME_DiagnosticTlm_Payload::OneHzAdjust`

Current 1Hz STCF adjustment.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_D1HzAdjS, \$sc\_\$cpu\_TIME\_D1HzAdjSs

Definition at line 1046 of file cfe\_time\_msg.h.

### 11.121.2.25 OneHzDirection

`int16 CFE_TIME_DiagnosticTlm_Payload::OneHzDirection`

1Hz STCF adjustment direction

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_D1HzAdjDir

Definition at line 1036 of file cfe\_time\_msg.h.

### 11.121.2.26 OneTimeAdjust

`CFE_TIME_SysTime_t CFE_TIME_DiagnosticTlm_Payload::OneTimeAdjust`

Previous one-time STCF adjustment.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DAdjustS, \$sc\_\$cpu\_TIME\_DAdjustSs

Definition at line 1044 of file cfe\_time\_msg.h.

### 11.121.2.27 OneTimeDirection

`int16 CFE_TIME_DiagnosticTlm_Payload::OneTimeDirection`

One time STCF adjustment direction (Add = 1, Sub = 2)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DAdjustDir

Definition at line 1034 of file cfe\_time\_msg.h.

### 11.121.2.28 ServerFlyState

`int16 CFE_TIME_DiagnosticTlm_Payload::ServerFlyState`

Used by clients only.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DSrvFly

Definition at line 1020 of file cfe\_time\_msg.h.

**11.121.2.29 TimeSinceTone**

```
CFE_TIME_SysTime_t CFE_TIME_DiagnosticTlm_Payload::TimeSinceTone
```

Time elapsed since the tone.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DElapsedS, \$sc\_\$cpu\_TIME\_DElapsedSs

Definition at line 998 of file cfe\_time\_msg.h.

**11.121.2.30 ToneDataCounter**

```
uint32 CFE_TIME_DiagnosticTlm_Payload::ToneDataCounter
```

Time at the tone data SB message count.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DTatTCNT

Definition at line 1066 of file cfe\_time\_msg.h.

**11.121.2.31 ToneDataLatch**

```
CFE_TIME_SysTime_t CFE_TIME_DiagnosticTlm_Payload::ToneDataLatch
```

Local Clock latched at arrival of tone data.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DTDS, \$sc\_\$cpu\_TIME\_DTDSs

Definition at line 1054 of file cfe\_time\_msg.h.

**11.121.2.32 ToneIntCounter**

```
uint32 CFE_TIME_DiagnosticTlm_Payload::ToneIntCounter
```

Tone signal ISR execution count.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DTsISRCNT

Definition at line 1068 of file cfe\_time\_msg.h.

### 11.121.2.33 ToneIntErrorCounter

```
uint32 CFE_TIME_DiagnosticTlm_Payload::ToneIntErrorCounter
```

Tone signal ISR error count.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DTslSRERR

Definition at line 1070 of file cfe\_time\_msg.h.

### 11.121.2.34 ToneMatchCounter

```
uint32 CFE_TIME_DiagnosticTlm_Payload::ToneMatchCounter
```

Tone signal / data verification count.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DVerifyCNT

Definition at line 1060 of file cfe\_time\_msg.h.

### 11.121.2.35 ToneMatchErrorCounter

```
uint32 CFE_TIME_DiagnosticTlm_Payload::ToneMatchErrorCounter
```

Tone signal / data verification error count.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DVerifyER

Definition at line 1062 of file cfe\_time\_msg.h.

### 11.121.2.36 ToneOverLimit

```
uint32 CFE_TIME_DiagnosticTlm_Payload::ToneOverLimit
```

Max between tone signal interrupts.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DMaxSs

Definition at line 1110 of file cfe\_time\_msg.h.

### 11.121.2.37 ToneSignalCounter

`uint32 CFE_TIME_DiagnosticTlm_Payload::ToneSignalCounter`

Tone signal detected SB message count.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DTSDetCNT

Definition at line 1064 of file cfe\_time\_msg.h.

### 11.121.2.38 ToneSignalLatch

`CFE_TIME_SysTime_t CFE_TIME_DiagnosticTlm_Payload::ToneSignalLatch`

Local Clock latched at most recent tone signal.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DTTS, \$sc\_\$cpu\_TIME\_DTTSS

Definition at line 1052 of file cfe\_time\_msg.h.

### 11.121.2.39 ToneTaskCounter

`uint32 CFE_TIME_DiagnosticTlm_Payload::ToneTaskCounter`

Tone task execution count.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DTsTaskCNT

Definition at line 1072 of file cfe\_time\_msg.h.

### 11.121.2.40 ToneUnderLimit

`uint32 CFE_TIME_DiagnosticTlm_Payload::ToneUnderLimit`

Min between tone signal interrupts.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DMinSs

Definition at line 1112 of file cfe\_time\_msg.h.

## 11.121.2.41 VersionCounter

```
uint32 CFE_TIME_DiagnosticTlm_Payload::VersionCounter
```

Count of mods to time at tone reference data (version)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DVersionCNT

Definition at line 1074 of file cfe\_time\_msg.h.

## 11.121.2.42 VirtualMET

```
uint32 CFE_TIME_DiagnosticTlm_Payload::VirtualMET
```

Software MET.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DLLogicalMET

Definition at line 1084 of file cfe\_time\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/time/fsw/inc/cfe\_time\_msg.h

## 11.122 CFE\_TIME\_HousekeepingTlm Struct Reference

```
#include <cfe_time_msg.h>
```

## Data Fields

- **CFE\_MSG\_TelemetryHeader\_t TelemetryHeader**  
*Telemetry header.*
- **CFE\_TIME\_HousekeepingTlm\_Payload\_t Payload**  
*Telemetry payload.*

## 11.122.1 Detailed Description

Definition at line 965 of file cfe\_time\_msg.h.

## 11.122.2 Field Documentation

### 11.122.2.1 Payload

`CFE_TIME_HousekeepingTlm_Payload_t` `CFE_TIME_HousekeepingTlm::Payload`

Telemetry payload.

Definition at line 968 of file `cfe_time_msg.h`.

### 11.122.2.2 TelemetryHeader

`CFE_MSG_TelemetryHeader_t` `CFE_TIME_HousekeepingTlm::TelemetryHeader`

Telemetry header.

Definition at line 967 of file `cfe_time_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/time/fsw/inc/cfe_time_msg.h`

## 11.123 CFE\_TIME\_HousekeepingTlm\_Payload Struct Reference

```
#include <cfe_time_msg.h>
```

### Data Fields

- `uint8 CommandCounter`  
*Time Command Execution Counter.*
- `uint8 CommandErrorCounter`  
*Time Command Error Counter.*
- `uint16 ClockStateFlags`  
*State Flags.*
- `CFE_TIME_ClockState_Enum_t ClockStateAPI`  
*API State.*
- `int16 LeapSeconds`  
*Current Leaps Seconds.*
- `uint32 SecondsMET`  
*Current MET (seconds)*
- `uint32 SubsecsMET`  
*Current MET (sub-seconds)*
- `uint32 SecondsSTCF`

- `uint32 SubsecsSTCF`  
*Current STCF (seconds)*
- `uint32 Seconds1HzAdj`  
*Current 1 Hz SCTF adjustment (sub-seconds)*
- `uint32 Subsecs1HzAdj`  
*Current 1 Hz SCTF adjustment (sub-seconds)*
- `uint32 SecondsDelay`  
*Current 1 Hz SCTF Delay (seconds)*
- `uint32 SubsecsDelay`  
*Current 1 Hz SCTF Delay (sub-seconds)*

### 11.123.1 Detailed Description

**Name** Time Services Housekeeping Packet

Definition at line 906 of file cfe\_time\_msg.h.

### 11.123.2 Field Documentation

#### 11.123.2.1 ClockStateAPI

`CFE_TIME_ClockState_Enum_t` `CFE_TIME_HousekeepingTlm_Payload::ClockStateAPI`

API State.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_DAPIStrate

Definition at line 921 of file cfe\_time\_msg.h.

#### 11.123.2.2 ClockStateFlags

`uint16` `CFE_TIME_HousekeepingTlm_Payload::ClockStateFlags`

State Flags.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_StateFlg, \$sc\_\$cpu\_TIME\_FlagSet, \$sc\_\$cpu\_TIME\_FlagFly, \$sc\_\$cpu←\_TIME\_FlagSrc, \$sc\_\$cpu\_TIME\_FlagPri, \$sc\_\$cpu\_TIME\_FlagSfly, \$sc\_\$cpu\_TIME←FlagCfly, \$sc\_\$cpu\_TIME\_FlagAdjd, \$sc\_\$cpu\_TIME\_Flag1Hzd, \$sc\_\$cpu\_TIME\_FlagClat, \$sc\_\$cpu\_TIME\_FlagSorC, \$sc\_\$cpu\_TIME\_FlagNIU

Definition at line 919 of file cfe\_time\_msg.h.

### 11.123.2.3 CommandCounter

```
uint8 CFE_TIME_HousekeepingTlm_Payload::CommandCounter
```

Time Command Execution Counter.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_CMDPC

Definition at line 911 of file cfe\_time\_msg.h.

### 11.123.2.4 CommandErrorCounter

```
uint8 CFE_TIME_HousekeepingTlm_Payload::CommandErrorCounter
```

Time Command Error Counter.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_CMDEC

Definition at line 913 of file cfe\_time\_msg.h.

### 11.123.2.5 LeapSeconds

```
int16 CFE_TIME_HousekeepingTlm_Payload::LeapSeconds
```

Current Leaps Seconds.

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_LeapSecs

Definition at line 927 of file cfe\_time\_msg.h.

### 11.123.2.6 Seconds1HzAdj

```
uint32 CFE_TIME_HousekeepingTlm_Payload::Seconds1HzAdj
```

Current 1 Hz SCTF adjustment (seconds)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_1HzAdjSecs

Definition at line 947 of file cfe\_time\_msg.h.

### 11.123.2.7 SecondsDelay

```
uint32 CFE_TIME_HousekeepingTlm_Payload::SecondsDelay
```

Current 1 Hz SCTF Delay (seconds)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_1HzAdjSecs

Definition at line 957 of file cfe\_time\_msg.h.

### 11.123.2.8 SecondsMET

```
uint32 CFE_TIME_HousekeepingTlm_Payload::SecondsMET
```

Current MET (seconds)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_METSecs

Definition at line 933 of file cfe\_time\_msg.h.

### 11.123.2.9 SecondsSTCF

```
uint32 CFE_TIME_HousekeepingTlm_Payload::SecondsSTCF
```

Current STCF (seconds)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_STCFSecs

Definition at line 938 of file cfe\_time\_msg.h.

### 11.123.2.10 Subsecs1HzAdj

```
uint32 CFE_TIME_HousekeepingTlm_Payload::Subsecs1HzAdj
```

Current 1 Hz SCTF adjustment (sub-seconds)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_1HzAdjSSecs

Definition at line 949 of file cfe\_time\_msg.h.

### 11.123.2.11 SubsecsDelay

`uint32 CFE_TIME_HousekeepingTlm_Payload::SubsecsDelay`

Current 1 Hz SCTF Delay (sub-seconds)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_1HzAdjSSecs

Definition at line 959 of file cfe\_time\_msg.h.

### 11.123.2.12 SubsecsMET

`uint32 CFE_TIME_HousekeepingTlm_Payload::SubsecsMET`

Current MET (sub-seconds)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_METSubsecs

Definition at line 935 of file cfe\_time\_msg.h.

### 11.123.2.13 SubsecsSTCF

`uint32 CFE_TIME_HousekeepingTlm_Payload::SubsecsSTCF`

Current STCF (sub-seconds)

**Telemetry Mnemonic(s)** \$sc\_\$cpu\_TIME\_STCFSubsecs

Definition at line 940 of file cfe\_time\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/time/fsw/inc/[cfe\\_time\\_msg.h](#)

## 11.124 CFE\_TIME\_LeapsCmd\_Payload Struct Reference

Set leap seconds command payload.

```
#include <cfe_time_msg.h>
```

## Data Fields

- `int16 LeapSeconds`

### 11.124.1 Detailed Description

Set leap seconds command payload.

Definition at line 750 of file `cfe_time_msg.h`.

### 11.124.2 Field Documentation

#### 11.124.2.1 LeapSeconds

`int16 CFE_TIME_LeapsCmd_Payload::LeapSeconds`

Definition at line 752 of file `cfe_time_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/time/fsw/inc/cfe_time_msg.h`

## 11.125 CFE\_TIME\_NoArgsCmd Struct Reference

Generic no argument command.

```
#include <cfe_time_msg.h>
```

## Data Fields

- `CFE_MSG_CommandHeader_t CommandHeader`  
*Command header.*

### 11.125.1 Detailed Description

Generic no argument command.

Definition at line 729 of file `cfe_time_msg.h`.

## 11.125.2 Field Documentation

### 11.125.2.1 CommandHeader

`CFE_MSG_CommandHeader_t CFE_TIME_NoArgsCmd::CommandHeader`

Command header.

Definition at line 731 of file cfe\_time\_msg.h.

The documentation for this struct was generated from the following file:

- `cfe/modules/time/fsw/inc/cfe_time_msg.h`

## 11.126 CFE\_TIME\_OneHzAdjustmentCmd Struct Reference

Generic seconds, subseconds adjustment command.

```
#include <cfe_time_msg.h>
```

### Data Fields

- `CFE_MSG_CommandHeader_t CommandHeader`  
*Command header.*
- `CFE_TIME_OneHzAdjustmentCmd_Payload_t Payload`  
*Command payload.*

### 11.126.1 Detailed Description

Generic seconds, subseconds adjustment command.

Definition at line 867 of file cfe\_time\_msg.h.

### 11.126.2 Field Documentation

#### 11.126.2.1 CommandHeader

`CFE_MSG_CommandHeader_t CFE_TIME_OneHzAdjustmentCmd::CommandHeader`

Command header.

Definition at line 869 of file cfe\_time\_msg.h.

### 11.126.2.2 Payload

`CFE_TIME_OneHzAdjustmentCmd_Payload_t CFE_TIME_OneHzAdjustmentCmd::Payload`

Command payload.

Definition at line 870 of file `cfe_time_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/time/fsw/inc/cfe_time_msg.h`

## 11.127 CFE\_TIME\_OneHzAdjustmentCmd\_Payload Struct Reference

Generic seconds, subseconds command payload.

```
#include <cfe_time_msg.h>
```

### Data Fields

- `uint32 Seconds`
- `uint32 Subseconds`

### 11.127.1 Detailed Description

Generic seconds, subseconds command payload.

Definition at line 857 of file `cfe_time_msg.h`.

### 11.127.2 Field Documentation

#### 11.127.2.1 Seconds

`uint32 CFE_TIME_OneHzAdjustmentCmd_Payload::Seconds`

Definition at line 859 of file `cfe_time_msg.h`.

### 11.127.2.2 Subseconds

`uint32 CFE_TIME_OneHzAdjustmentCmd_Payload::Subseconds`

Definition at line 860 of file `cfe_time_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/time/fsw/inc/cfe_time_msg.h`

## 11.128 CFE\_TIME\_SetLeapSecondsCmd Struct Reference

Set leap seconds command.

```
#include <cfe_time_msg.h>
```

### Data Fields

- `CFE_MSG_CommandHeader_t CommandHeader`  
*Command header.*
- `CFE_TIME_LeapsCmd_Payload_t Payload`  
*Command payload.*

### 11.128.1 Detailed Description

Set leap seconds command.

Definition at line 758 of file `cfe_time_msg.h`.

### 11.128.2 Field Documentation

#### 11.128.2.1 CommandHeader

`CFE_MSG_CommandHeader_t CFE_TIME_SetLeapSecondsCmd::CommandHeader`

Command header.

Definition at line 760 of file `cfe_time_msg.h`.

### 11.128.2.2 Payload

`CFE_TIME_LeapsCmd_Payload_t CFE_TIME_SetLeapSecondsCmd::Payload`

Command payload.

Definition at line 761 of file `cfe_time_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/time/fsw/inc/cfe_time_msg.h`

## 11.129 CFE\_TIME\_SetSignalCmd Struct Reference

Set tone signal source command.

```
#include <cfe_time_msg.h>
```

### Data Fields

- `CFE_MSG_CommandHeader_t CommandHeader`  
*Command header.*
- `CFE_TIME_SignalCmd_Payload_t Payload`  
*Command payload.*

### 11.129.1 Detailed Description

Set tone signal source command.

Definition at line 817 of file `cfe_time_msg.h`.

### 11.129.2 Field Documentation

#### 11.129.2.1 CommandHeader

`CFE_MSG_CommandHeader_t CFE_TIME_SetSignalCmd::CommandHeader`

Command header.

Definition at line 819 of file `cfe_time_msg.h`.

### 11.129.2.2 Payload

`CFE_TIME_SignalCmd_Payload_t CFE_TIME_SetSignalCmd::Payload`

Command payload.

Definition at line 820 of file `cfe_time_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/time/fsw/inc/cfe_time_msg.h`

## 11.130 CFE\_TIME\_SetSourceCmd Struct Reference

Set time data source command.

```
#include <cfe_time_msg.h>
```

### Data Fields

- `CFE_MSG_CommandHeader_t CommandHeader`  
*Command header.*
- `CFE_TIME_SourceCmd_Payload_t Payload`  
*Command payload.*

### 11.130.1 Detailed Description

Set time data source command.

Definition at line 798 of file `cfe_time_msg.h`.

### 11.130.2 Field Documentation

#### 11.130.2.1 CommandHeader

`CFE_MSG_CommandHeader_t CFE_TIME_SetSourceCmd::CommandHeader`

Command header.

Definition at line 800 of file `cfe_time_msg.h`.

### 11.130.2.2 Payload

`CFE_TIME_SourceCmd_Payload_t CFE_TIME_SetSourceCmd::Payload`

Command payload.

Definition at line 801 of file `cfe_time_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/time/fsw/inc/cfe_time_msg.h`

## 11.131 CFE\_TIME\_SetStateCmd Struct Reference

Set clock state command.

```
#include <cfe_time_msg.h>
```

### Data Fields

- `CFE_MSG_CommandHeader_t CommandHeader`  
*Command header.*
- `CFE_TIME_StateCmd_Payload_t Payload`  
*Command payload.*

### 11.131.1 Detailed Description

Set clock state command.

Definition at line 779 of file `cfe_time_msg.h`.

### 11.131.2 Field Documentation

#### 11.131.2.1 CommandHeader

`CFE_MSG_CommandHeader_t CFE_TIME_SetStateCmd::CommandHeader`

Command header.

Definition at line 781 of file `cfe_time_msg.h`.

### 11.131.2.2 Payload

`CFE_TIME_StateCmd_Payload_t` `CFE_TIME_SetStateCmd::Payload`

Command payload.

Definition at line 782 of file `cfe_time_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/time/fsw/inc/cfe_time_msg.h`

## 11.132 CFE\_TIME\_SignalCmd\_Payload Struct Reference

Set tone signal source command payload.

```
#include <cfe_time_msg.h>
```

### Data Fields

- `int16 ToneSource`  
`CFE_TIME_ToneSignalSelect_PRIMARY`=Primary Source, `CFE_TIME_ToneSignalSelect_REDUNDANT`=Redundant Source

### 11.132.1 Detailed Description

Set tone signal source command payload.

Definition at line 807 of file `cfe_time_msg.h`.

### 11.132.2 Field Documentation

#### 11.132.2.1 ToneSource

`int16 CFE_TIME_SignalCmd_Payload::ToneSource`

`CFE_TIME_ToneSignalSelect_PRIMARY`=Primary Source, `CFE_TIME_ToneSignalSelect_REDUNDANT`=Redundant Source

Selects either the "Primary" or "Redundant" tone signal source

Definition at line 809 of file `cfe_time_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/time/fsw/inc/cfe_time_msg.h`

## 11.133 CFE\_TIME\_SourceCmd\_Payload Struct Reference

Set time data source command payload.

```
#include <cfе_time_msg.h>
```

### Data Fields

- `int16 TimeSource`  
*CFE\_TIME\_SourceSelect\_INTERNAL=Internal Source, CFE\_TIME\_SourceSelect\_EXTERNAL=External Source*

#### 11.133.1 Detailed Description

Set time data source command payload.

Definition at line 788 of file cfe\_time\_msg.h.

#### 11.133.2 Field Documentation

##### 11.133.2.1 TimeSource

```
int16 CFE_TIME_SourceCmd_Payload::TimeSource
```

*CFE\_TIME\_SourceSelect\_INTERNAL=Internal Source, CFE\_TIME\_SourceSelect\_EXTERNAL=External Source*

Selects either the "Internal" and "External" clock source

Definition at line 790 of file cfe\_time\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/time/fsw/inc/cfe\_time\_msg.h

## 11.134 CFE\_TIME\_StateCmd\_Payload Struct Reference

Set clock state command payload.

```
#include <cfе_time_msg.h>
```

### Data Fields

- `CFE_TIME_ClockState_Enum_t ClockState`  
*CFE\_TIME\_ClockState\_INVALID=Spacecraft time has not been accurately set, CFE\_TIME\_ClockState\_VAL←ID=Spacecraft clock has been accurately set, CFE\_TIME\_ClockState\_FLYWHEEL=Force into FLYWHEEL mode*

### 11.134.1 Detailed Description

Set clock state command payload.

Definition at line 767 of file cfe\_time\_msg.h.

### 11.134.2 Field Documentation

#### 11.134.2.1 ClockState

`CFE_TIME_ClockState_Enum_t CFE_TIME_StateCmd_Payload::ClockState`

`CFE_TIME_ClockState_INVALID`=Spacecraft time has not been accurately set, `CFE_TIME_ClockState_VALID`=Spacecraft clock has been accurately set, `CFE_TIME_ClockState_FLYWHEEL`=Force into FLYWHEEL mode

Selects the current clock state

Definition at line 769 of file cfe\_time\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/time/fsw/inc/cfe\_time\_msg.h

## 11.135 CFE\_TIME\_SysTime Struct Reference

Data structure used to hold system time values.

```
#include <cfe_time_extern_typedefs.h>
```

### Data Fields

- `uint32 Seconds`  
*Number of seconds since epoch.*
- `uint32 Subseconds`  
*Number of subseconds since epoch (LSB =  $2^{-32}$  seconds)*

### 11.135.1 Detailed Description

Data structure used to hold system time values.

#### Description

The `CFE_TIME_SysTime_t` data structure is used to hold time values. Time is referred to as the elapsed time (in seconds and subseconds) since a specified epoch time. The subseconds field contains the number of  $2^{-32}$  second intervals that have elapsed since the epoch.

Definition at line 51 of file cfe\_time\_extern\_typedefs.h.

### 11.135.2 Field Documentation

#### 11.135.2.1 Seconds

`uint32 CFE_TIME_SysTime::Seconds`

Number of seconds since epoch.

Definition at line 53 of file `cfe_time_extern_typedefs.h`.

Referenced by `DS_IsPacketFiltered()`.

#### 11.135.2.2 Subseconds

`uint32 CFE_TIME_SysTime::Subseconds`

Number of subseconds since epoch (LSB =  $2^{-32}$  seconds)

Definition at line 54 of file `cfe_time_extern_typedefs.h`.

Referenced by `DS_IsPacketFiltered()`.

The documentation for this struct was generated from the following file:

- [cfe/modules/core\\_api/fsw/inc/cfe\\_time\\_extern\\_typedefs.h](#)

## 11.136 CFE\_TIME\_TimeCmd Struct Reference

Generic seconds, microseconds argument command.

```
#include <cfe_time_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CommandHeader](#)  
*Command header.*
- [CFE\\_TIME\\_TimeCmd\\_Payload\\_t Payload](#)  
*Command payload.*

#### 11.136.1 Detailed Description

Generic seconds, microseconds argument command.

Definition at line 835 of file `cfe_time_msg.h`.

## 11.136.2 Field Documentation

### 11.136.2.1 CommandHeader

`CFE_MSG_CommandHeader_t` `CFE_TIME_TimeCmd::CommandHeader`

Command header.

Definition at line 837 of file `cfe_time_msg.h`.

### 11.136.2.2 Payload

`CFE_TIME_TimeCmd_Payload_t` `CFE_TIME_TimeCmd::Payload`

Command payload.

Definition at line 838 of file `cfe_time_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/time/fsw/inc/cfe_time_msg.h`

## 11.137 CFE\_TIME\_TimeCmd\_Payload Struct Reference

Generic seconds, microseconds command payload.

```
#include <cfe_time_msg.h>
```

### Data Fields

- `uint32 Seconds`
- `uint32 MicroSeconds`

### 11.137.1 Detailed Description

Generic seconds, microseconds command payload.

Definition at line 826 of file `cfe_time_msg.h`.

### 11.137.2 Field Documentation

### 11.137.2.1 MicroSeconds

```
uint32 CFE_TIME_TimeCmd_Payload::MicroSeconds
```

Definition at line 829 of file cfe\_time\_msg.h.

### 11.137.2.2 Seconds

```
uint32 CFE_TIME_TimeCmd_Payload::Seconds
```

Definition at line 828 of file cfe\_time\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/time/fsw/inc/cfe\_time\_msg.h

## 11.138 CFE\_TIME\_ToneDataCmd Struct Reference

Time at tone data command.

```
#include <cfe_time_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CommandHeader](#)  
*Command header.*
- [CFE\\_TIME\\_ToneDataCmd\\_Payload\\_t Payload](#)  
*Command payload.*

### 11.138.1 Detailed Description

Time at tone data command.

Definition at line 895 of file cfe\_time\_msg.h.

### 11.138.2 Field Documentation

### 11.138.2.1 CommandHeader

`CFE_MSG_CommandHeader_t` `CFE_TIME_ToneDataCmd::CommandHeader`

Command header.

Definition at line 897 of file `cfe_time_msg.h`.

### 11.138.2.2 Payload

`CFE_TIME_ToneDataCmd_Payload_t` `CFE_TIME_ToneDataCmd::Payload`

Command payload.

Definition at line 898 of file `cfe_time_msg.h`.

The documentation for this struct was generated from the following file:

- `cfe/modules/time/fsw/inc/cfe_time_msg.h`

## 11.139 CFE\_TIME\_ToneDataCmd\_Payload Struct Reference

Time at tone data command payload.

```
#include <cfe_time_msg.h>
```

### Data Fields

- `CFE_TIME_SysTime_t AtToneMET`  
*MET at time of tone.*
- `CFE_TIME_SysTime_t AtToneSTCF`  
*STCF at time of tone.*
- `int16 AtToneLeapSeconds`  
*Leap Seconds at time of tone.*
- `CFE_TIME_ClockState_Enum_t AtToneState`  
*Clock state at time of tone.*

### 11.139.1 Detailed Description

Time at tone data command payload.

Definition at line 884 of file `cfe_time_msg.h`.

## 11.139.2 Field Documentation

### 11.139.2.1 AtToneLeapSeconds

```
int16 CFE_TIME_ToneDataCmd_Payload::AtToneLeapSeconds
```

Leap Seconds at time of tone.

Definition at line 888 of file cfe\_time\_msg.h.

### 11.139.2.2 AtToneMET

```
CFE_TIME_SysTime_t CFE_TIME_ToneDataCmd_Payload::AtToneMET
```

MET at time of tone.

Definition at line 886 of file cfe\_time\_msg.h.

### 11.139.2.3 AtToneState

```
CFE_TIME_ClockState_Enum_t CFE_TIME_ToneDataCmd_Payload::AtToneState
```

Clock state at time of tone.

Definition at line 889 of file cfe\_time\_msg.h.

### 11.139.2.4 AtToneSTCF

```
CFE_TIME_SysTime_t CFE_TIME_ToneDataCmd_Payload::AtToneSTCF
```

STCF at time of tone.

Definition at line 887 of file cfe\_time\_msg.h.

The documentation for this struct was generated from the following file:

- cfe/modules/time/fsw/inc/[cfe\\_time\\_msg.h](#)

## 11.140 DS\_AddMidCmd\_t Struct Reference

Add Message ID To Packet Filter Table.

```
#include <ds_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CmdHeader](#)  
*cFE Software Bus command message header*
- [CFE\\_SB\\_MsgId\\_t MessageID](#)  
*Message ID to add to Packet Filter Table.*

### 11.140.1 Detailed Description

Add Message ID To Packet Filter Table.

For command details see [DS\\_ADD\\_MID\\_CC](#)

Definition at line 288 of file ds\_msg.h.

### 11.140.2 Field Documentation

#### 11.140.2.1 CmdHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) DS\_AddMidCmd\_t::CmdHeader

cFE Software Bus command message header

Definition at line 290 of file ds\_msg.h.

#### 11.140.2.2 MessageID

[CFE\\_SB\\_MsgId\\_t](#) DS\_AddMidCmd\_t::MessageID

Message ID to add to Packet Filter Table.

Definition at line 292 of file ds\_msg.h.

Referenced by DS\_CmdAddMID().

The documentation for this struct was generated from the following file:

- [apps/ds/fsw/src/ds\\_msg.h](#)

## 11.141 DS\_AppData\_t Struct Reference

DS global data structure definition.

```
#include <ds_app.h>
```

### Data Fields

- **CFE\_SB\_PipeId\_t InputPipe**  
*Pipe Id for DS command pipe.*
- **CFE\_ES\_CDSHandle\_t DataStoreHandle**  
*Critical Data Store (CDS) handle.*
- **CFE\_TBL\_Handle\_t FilterTblHandle**  
*Packet filter table handle.*
- **CFE\_TBL\_Handle\_t DestFileTblHandle**  
*Destination file table handle.*
- **DS\_FilterTable\_t \* FilterTblPtr**  
*Packet filter table data pointer.*
- **DS\_DestFileTable\_t \* DestFileTblPtr**  
*Destination file table data pointer.*
- **uint8 CmdAcceptedCounter**  
*Count of valid commands received.*
- **uint8 CmdRejectedCounter**  
*Count of invalid commands received.*
- **uint8 DestTblLoadCounter**  
*Count of destination file table loads.*
- **uint8 DestTblErrCounter**  
*Count of failed attempts to get table data pointer.*
- **uint8 FilterTblLoadCounter**  
*Count of packet filter table loads.*
- **uint8 FilterTblErrCounter**  
*Count of failed attempts to get table data pointer.*
- **uint8 AppEnableState**  
*Application enable/disable state.*
- **uint8 Spare8**  
*Structure alignment padding.*
- **uint16 FileWriteCounter**  
*Count of good destination file writes.*
- **uint16 FileWriteErrCounter**  
*Count of bad destination file writes.*
- **uint16 FileUpdateCounter**  
*Count of good updates to secondary header.*
- **uint16 FileUpdateErrCounter**  
*Count of bad updates to secondary header.*
- **uint32 DisabledPktCounter**  
*Count of packets discarded (DS app disabled)*
- **uint32 IgnoredPktCounter**

- Count of packets discarded (pkt has no filter)*
- **uint32 FilteredPktCounter**
- Count of packets discarded (failed filter test)*
- **uint32 PassedPktCounter**
- Count of packets that passed filter test.*
- **DS\_AppFileStatus\_t FileStatus [DS\_DEST\_FILE\_CNT]**
- Current state of destination files.*
- **DS\_HashLink\_t HashLinks [DS\_PACKETS\_IN\_FILTER\_TABLE]**
- Hash table linked list elements.*
- **DS\_HashLink\_t \* HashTable [DS\_HASH\_TABLE\_ENTRIES]**
- Each hash table entry is a linked list.*

#### 11.141.1 Detailed Description

DS global data structure definition.

Definition at line 71 of file `ds_app.h`.

#### 11.141.2 Field Documentation

##### 11.141.2.1 AppEnableState

```
uint8 DS_AppData_t::AppEnableState
```

Application enable/disable state.

Definition at line 89 of file `ds_app.h`.

Referenced by `DS_AppInitialize()`, `DS_AppProcessHK()`, `DS_AppStorePacket()`, `DS_CmdSetAppState()`, `DS_TableCreateCDS()`, and `DS_TableUpdateCDS()`.

##### 11.141.2.2 CmdAcceptedCounter

```
uint8 DS_AppData_t::CmdAcceptedCounter
```

Count of valid commands received.

Definition at line 83 of file `ds_app.h`.

Referenced by `DS_AppProcessHK()`, `DS_CmdAddMID()`, `DS_CmdCloseAll()`, `DS_CmdCloseFile()`, `DS_CmdGetFileInfo()`, `DS_CmdNoop()`, `DS_CmdReset()`, `DS_CmdSetAppState()`, `DS_CmdSetDestAge()`, `DS_CmdSetDestBase()`, `D_S_CmdSetDestCount()`, `DS_CmdSetDestExt()`, `DS_CmdSetDestPath()`, `DS_CmdSetDestSize()`, `DS_CmdSetDestState()`, `DS_CmdSetDestType()`, `DS_CmdSetFilterFile()`, `DS_CmdSetFilterParms()`, and `DS_CmdSetFilterType()`.

#### 11.141.2.3 CmdRejectedCounter

```
uint8 DS_AppData_t::CmdRejectedCounter
```

Count of invalid commands received.

Definition at line 84 of file ds\_app.h.

Referenced by DS\_AppProcessCmd(), DS\_AppProcessHK(), DS\_CmdAddMID(), DS\_CmdCloseAll(), DS\_CmdCloseFile(), DS\_CmdGetFileInfo(), DS\_CmdNoop(), DS\_CmdReset(), DS\_CmdSetAppState(), DS\_CmdSetDestAge(), DS\_CmdSetDestBase(), DS\_CmdSetDestCount(), DS\_CmdSetDestExt(), DS\_CmdSetDestPath(), DS\_CmdSetDestSize(), DS\_CmdSetDestState(), DS\_CmdSetDestType(), DS\_CmdSetFilterFile(), DS\_CmdSetFilterParms(), and DS\_CmdSetFilterType().

#### 11.141.2.4 DataStoreHandle

```
CFE_ES_CDSHandle_t DS_AppData_t::DataStoreHandle
```

Critical Data Store (CDS) handle.

Definition at line 75 of file ds\_app.h.

Referenced by DS\_TableCreateCDS(), and DS\_TableUpdateCDS().

#### 11.141.2.5 DestFileTblHandle

```
CFE_TBL_Handle_t DS_AppData_t::DestFileTblHandle
```

Destination file table handle.

Definition at line 78 of file ds\_app.h.

Referenced by DS\_CmdSetDestAge(), DS\_CmdSetDestBase(), DS\_CmdSetDestCount(), DS\_CmdSetDestExt(), DS\_CmdSetDestPath(), DS\_CmdSetDestSize(), DS\_CmdSetDestState(), DS\_CmdSetDestType(), DS\_TableInit(), and DS\_TableManageDestFile().

#### 11.141.2.6 DestFileTblPtr

```
DS_DestFileTable_t* DS_AppData_t::DestFileTblPtr
```

Destination file table data pointer.

Definition at line 81 of file ds\_app.h.

Referenced by DS\_AppStorePacket(), DS\_CmdGetFileInfo(), DS\_CmdSetDestAge(), DS\_CmdSetDestBase(), DS\_CmdSetDestCount(), DS\_CmdSetDestExt(), DS\_CmdSetDestPath(), DS\_CmdSetDestSize(), DS\_CmdSetDestState(), DS\_CmdSetDestType(), DS\_FileCloseDest(), DS\_FileCreateDest(), DS\_FileCreateName(), DS\_FileSetupWrite(), DS\_FileTestAge(), DS\_FileWriteHeader(), and DS\_TableManageDestFile().

### 11.141.2.7 DestTblErrCounter

```
uint8 DS_AppData_t::DestTblErrCounter
```

Count of failed attempts to get table data pointer.

Definition at line 86 of file ds\_app.h.

Referenced by DS\_AppProcessHK(), DS\_CmdReset(), and DS\_TableManageDestFile().

### 11.141.2.8 DestTblLoadCounter

```
uint8 DS_AppData_t::DestTblLoadCounter
```

Count of destination file table loads.

Definition at line 85 of file ds\_app.h.

Referenced by DS\_AppProcessHK(), DS\_CmdReset(), and DS\_TableManageDestFile().

### 11.141.2.9 DisabledPktCounter

```
uint32 DS_AppData_t::DisabledPktCounter
```

Count of packets discarded (DS app disabled)

Definition at line 97 of file ds\_app.h.

Referenced by DS\_AppProcessHK(), DS\_AppStorePacket(), and DS\_CmdReset().

### 11.141.2.10 FileStatus

```
DS_AppFileStatus_t DS_AppData_t::FileStatus[DS_DEST_FILE_CNT]
```

Current state of destination files.

Definition at line 102 of file ds\_app.h.

Referenced by DS\_AppInitialize(), DS\_AppProcessHK(), DS\_CmdCloseAll(), DS\_CmdCloseFile(), DS\_CmdGetFileInfo(), DS\_CmdSetDestCount(), DS\_CmdSetDestState(), DS\_FileCloseDest(), DS\_FileCreateDest(), DS\_FileCreateName(), DS\_FileSetupWrite(), DS\_FileStorePacket(), DS\_FileTestAge(), DS\_FileUpdateHeader(), DS\_FileWriteData(), DS\_FileWriteError(), DS\_FileWriteHeader(), DS\_TableCreateCDS(), DS\_TableManageDestFile(), and DS\_TableUpdateCDS().

### 11.141.2.11 FileUpdateCounter

```
uint16 DS_AppData_t::FileUpdateCounter
```

Count of good updates to secondary header.

Definition at line 94 of file ds\_app.h.

Referenced by DS\_AppProcessHK(), DS\_CmdReset(), and DS\_FileUpdateHeader().

### 11.141.2.12 FileUpdateErrCounter

```
uint16 DS_AppData_t::FileUpdateErrCounter
```

Count of bad updates to secondary header.

Definition at line 95 of file ds\_app.h.

Referenced by DS\_AppProcessHK(), DS\_CmdReset(), and DS\_FileUpdateHeader().

### 11.141.2.13 FileWriteCounter

```
uint16 DS_AppData_t::FileWriteCounter
```

Count of good destination file writes.

Definition at line 92 of file ds\_app.h.

Referenced by DS\_AppProcessHK(), DS\_CmdReset(), DS\_FileCreateDest(), DS\_FileWriteData(), and DS\_FileWriteHeader().

### 11.141.2.14 FileWriteErrCounter

```
uint16 DS_AppData_t::FileWriteErrCounter
```

Count of bad destination file writes.

Definition at line 93 of file ds\_app.h.

Referenced by DS\_AppProcessHK(), DS\_CmdReset(), DS\_FileCreateDest(), and DS\_FileWriteError().

### 11.141.2.15 FilteredPktCounter

`uint32 DS_AppData_t::FilteredPktCounter`

Count of packets discarded (failed filter test)

Definition at line 99 of file `ds_app.h`.

Referenced by `DS_AppProcessHK()`, `DS_CmdReset()`, and `DS_FileStorePacket()`.

### 11.141.2.16 FilterTblErrCounter

`uint8 DS_AppData_t::FilterTblErrCounter`

Count of failed attempts to get table data pointer.

Definition at line 88 of file `ds_app.h`.

Referenced by `DS_AppProcessHK()`, `DS_CmdReset()`, and `DS_TableManageFilter()`.

### 11.141.2.17 FilterTblHandle

`CFE_TBL_Handle_t DS_AppData_t::FilterTblHandle`

Packet filter table handle.

Definition at line 77 of file `ds_app.h`.

Referenced by `DS_CmdAddMID()`, `DS_CmdSetFilterFile()`, `DS_CmdSetFilterParms()`, `DS_CmdSetFilterType()`, `DS_TableInit()`, and `DS_TableManageFilter()`.

### 11.141.2.18 FilterTblLoadCounter

`uint8 DS_AppData_t::FilterTblLoadCounter`

Count of packet filter table loads.

Definition at line 87 of file `ds_app.h`.

Referenced by `DS_AppProcessHK()`, `DS_CmdReset()`, and `DS_TableManageFilter()`.

**11.141.2.19 FilterTblPtr**

```
DS_FilterTable_t* DS_AppData_t::FilterTblPtr
```

Packet filter table data pointer.

Definition at line 80 of file ds\_app.h.

Referenced by DS\_AppStorePacket(), DS\_CmdAddMID(), DS\_CmdSetFilterFile(), DS\_CmdSetFilterParms(), DS\_CmdSetFilterType(), DS\_FileStorePacket(), DS\_TableCreateHash(), DS\_TableFindMsgID(), DS\_TableManageFilter(), DS\_TableSubscribe(), and DS\_TableUnsubscribe().

**11.141.2.20 HashLinks**

```
DS_HashLink_t DS_AppData_t::HashLinks[DS_PACKETS_IN_FILTER_TABLE]
```

Hash table linked list elements.

Definition at line 104 of file ds\_app.h.

Referenced by DS\_TableAddMsgID(), and DS\_TableCreateHash().

**11.141.2.21 HashTable**

```
DS_HashLink_t* DS_AppData_t::HashTable[DS_HASH_TABLE_ENTRIES]
```

Each hash table entry is a linked list.

Definition at line 105 of file ds\_app.h.

Referenced by DS\_TableAddMsgID(), DS\_TableCreateHash(), and DS\_TableFindMsgID().

**11.141.2.22 IgnoredPktCounter**

```
uint32 DS_AppData_t::IgnoredPktCounter
```

Count of packets discarded (pkt has no filter)

Definition at line 98 of file ds\_app.h.

Referenced by DS\_AppProcessHK(), DS\_AppStorePacket(), DS\_CmdReset(), and DS\_FileStorePacket().

### 11.141.2.23 InputPipe

`CFE_SB_PipeId_t DS_AppData_t::InputPipe`

Pipe Id for DS command pipe.

Definition at line 73 of file `ds_app.h`.

Referenced by `DS_AppInitialize()`, `DS_AppMain()`, `DS_CmdAddMID()`, `DS_TableSubscribe()`, and `DS_TableUnsubscribe()`.

### 11.141.2.24 PassedPktCounter

`uint32 DS_AppData_t::PassedPktCounter`

Count of packets that passed filter test.

Definition at line 100 of file `ds_app.h`.

Referenced by `DS_AppProcessHK()`, `DS_CmdReset()`, and `DS_FileStorePacket()`.

### 11.141.2.25 Spare8

`uint8 DS_AppData_t::Spare8`

Structure alignment padding.

Definition at line 90 of file `ds_app.h`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds\_app.h`

## 11.142 DS\_AppFileStatus\_t Struct Reference

Current state of destination files.

```
#include <ds_app.h>
```

## Data Fields

- `osal_id_t FileHandle`  
*Current file handle.*
- `uint32 FileAge`  
*Current file age in seconds.*
- `uint32 FileSize`  
*Current file size in bytes.*
- `uint32 FileGrowth`  
*Current file growth in bytes (since HK)*
- `uint32 FileRate`  
*File growth rate in bytes (at last HK)*
- `uint32 FileCount`  
*Current file sequence count.*
- `uint16 FileState`  
*Current file enable/disable state.*
- `uint16 Unused`  
*Unused - structure padding.*
- `char FileName [DS_TOTAL_FNAME_BUFSIZE]`  
*Current filename (path+base+seq+ext)*

### 11.142.1 Detailed Description

Current state of destination files.

Definition at line 54 of file ds\_app.h.

### 11.142.2 Field Documentation

#### 11.142.2.1 FileAge

`uint32 DS_AppFileStatus_t::FileAge`

Current file age in seconds.

Definition at line 57 of file ds\_app.h.

Referenced by `DS_CmdGetFileInfo()`, `DS_FileCloseDest()`, `DS_FileTestAge()`, and `DS_FileTransmit()`.

### 11.142.2.2 FileCount

```
uint32 DS_AppFileStatus_t::FileCount
```

Current file sequence count.

Definition at line 61 of file ds\_app.h.

Referenced by DS\_CmdGetFileInfo(), DS\_CmdSetDestCount(), DS\_FileCreateDest(), DS\_FileCreateName(), DS\_FileTransmit(), DS\_TableCreateCDS(), DS\_TableManageDestFile(), and DS\_TableUpdateCDS().

### 11.142.2.3 FileGrowth

```
uint32 DS_AppFileStatus_t::FileGrowth
```

Current file growth in bytes (since HK)

Definition at line 59 of file ds\_app.h.

Referenced by DS\_AppProcessHK(), DS\_FileWriteData(), and DS\_FileWriteHeader().

### 11.142.2.4 FileHandle

```
osal_id_t DS_AppFileStatus_t::FileHandle
```

Current file handle.

Definition at line 56 of file ds\_app.h.

Referenced by DS\_AppInitialize(), DS\_CmdCloseAll(), DS\_CmdCloseFile(), DS\_CmdGetFileInfo(), DS\_FileCloseDest(), DS\_FileCreateDest(), DS\_FileSetupWrite(), DS\_FileTestAge(), DS\_FileUpdateHeader(), DS\_FileWriteData(), and DS\_FileWriteHeader().

### 11.142.2.5 FileName

```
char DS_AppFileStatus_t::FileName[DS_TOTAL_FNAME_BUFSIZE]
```

Current filename (path+base+seq+ext)

Definition at line 64 of file ds\_app.h.

Referenced by DS\_CmdGetFileInfo(), DS\_FileCloseDest(), DS\_FileCreateDest(), DS\_FileCreateName(), DS\_FileTransmit(), DS\_FileWriteError(), and DS\_FileWriteHeader().

### 11.142.2.6 FileRate

```
uint32 DS_AppFileStatus_t::FileRate
```

File growth rate in bytes (at last HK)

Definition at line 60 of file `ds_app.h`.

Referenced by `DS_AppProcessHK()`, `DS_CmdGetFileInfo()`, and `DS_FileTransmit()`.

### 11.142.2.7 FileSize

```
uint32 DS_AppFileStatus_t::FileSize
```

Current file size in bytes.

Definition at line 58 of file `ds_app.h`.

Referenced by `DS_CmdGetFileInfo()`, `DS_FileCloseDest()`, `DS_FileSetupWrite()`, `DS_FileTransmit()`, `DS_FileWriteData()`, and `DS_FileWriteHeader()`.

### 11.142.2.8 FileState

```
uint16 DS_AppFileStatus_t::FileState
```

Current file enable/disable state.

Definition at line 62 of file `ds_app.h`.

Referenced by `DS_CmdGetFileInfo()`, `DS_CmdSetDestState()`, `DS_FileCreateDest()`, `DS_FileCreateName()`, `DS_FileStorePacket()`, `DS_FileTransmit()`, `DS_FileWriteError()`, and `DS_TableManageDestFile()`.

### 11.142.2.9 Unused

```
uint16 DS_AppFileStatus_t::Unused
```

Unused - structure padding.

Definition at line 63 of file `ds_app.h`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds\_app.h`

## 11.143 DS\_AppStateCmd\_t Struct Reference

Set Ena/Dis State For DS Application.

```
#include <ds_msg.h>
```

### Data Fields

- **CFE\_MSG\_CommandHeader\_t CmdHeader**  
*cFE Software Bus command message header*
- **uint16 EnableState**  
*Application enable/disable state.*
- **uint16 Padding**  
*Structure Padding on 32-bit boundaries.*

### 11.143.1 Detailed Description

Set Ena/Dis State For DS Application.

For command details see [DS\\_SET\\_APP\\_STATE\\_CC](#)

Definition at line 63 of file ds\_msg.h.

### 11.143.2 Field Documentation

#### 11.143.2.1 CmdHeader

```
CFE_MSG_CommandHeader_t DS_AppStateCmd_t::CmdHeader
```

cFE Software Bus command message header

Definition at line 65 of file ds\_msg.h.

#### 11.143.2.2 EnableState

```
uint16 DS_AppStateCmd_t::EnableState
```

Application enable/disable state.

Definition at line 67 of file ds\_msg.h.

Referenced by [DS\\_CmdSetAppState\(\)](#).

### 11.143.2.3 Padding

```
uint16 DS_AppStateCmd_t::Padding
```

Structure Padding on 32-bit boundaries.

Definition at line 68 of file ds\_msg.h.

The documentation for this struct was generated from the following file:

- [apps/ds/fsw/src/ds\\_msg.h](#)

## 11.144 DS\_CloseAllCmd\_t Struct Reference

Close All Destination Files.

```
#include <ds_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CmdHeader](#)  
*cFE Software Bus command message header*

### 11.144.1 Detailed Description

Close All Destination Files.

For command details see [DS\\_CLOSE\\_ALL\\_CC](#)

Definition at line 264 of file ds\_msg.h.

### 11.144.2 Field Documentation

#### 11.144.2.1 CmdHeader

```
CFE_MSG_CommandHeader_t DS_CloseAllCmd_t::CmdHeader
```

cFE Software Bus command message header

Definition at line 267 of file ds\_msg.h.

The documentation for this struct was generated from the following file:

- [apps/ds/fsw/src/ds\\_msg.h](#)

## 11.145 DS\_CloseFileCmd\_t Struct Reference

Close Destination File.

```
#include <ds_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CmdHeader](#)  
*cFE Software Bus command message header*
- [uint16 FileTableIndex](#)  
*Index into Destination File Table.*
- [uint16 Padding](#)  
*Structure Padding on 32-bit boundaries.*

### 11.145.1 Detailed Description

Close Destination File.

For command details see [DS\\_CLOSE\\_FILE\\_CC](#)

Definition at line 250 of file ds\_msg.h.

### 11.145.2 Field Documentation

#### 11.145.2.1 CmdHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) DS\_CloseFileCmd\_t::CmdHeader

cFE Software Bus command message header

Definition at line 252 of file ds\_msg.h.

#### 11.145.2.2 FileTableIndex

[uint16](#) DS\_CloseFileCmd\_t::FileTableIndex

Index into Destination File Table.

Definition at line 254 of file ds\_msg.h.

Referenced by DS\_CmdCloseFile().

### 11.145.2.3 Padding

```
uint16 DS_CloseFileCmd_t::Padding
```

Structure Padding on 32-bit boundaries.

Definition at line 255 of file ds\_msg.h.

The documentation for this struct was generated from the following file:

- [apps/ds/fsw/src/ds\\_msg.h](#)

## 11.146 DS\_DestAgeCmd\_t Struct Reference

Set Max File Age For Destination File Table Entry.

```
#include <ds_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CmdHeader](#)  
*cFE Software Bus command message header*
- [uint16 FileTableIndex](#)  
*Index into Destination File Table.*
- [uint16 Padding](#)  
*Structure Padding on 32-bit boundaries.*
- [uint32 MaxFileAge](#)  
*Max file age (seconds)*

### 11.146.1 Detailed Description

Set Max File Age For Destination File Table Entry.

For command details see [DS\\_SET\\_DEST\\_AGE\\_CC](#)

Definition at line 218 of file ds\_msg.h.

### 11.146.2 Field Documentation

### 11.146.2.1 CmdHeader

`CFE_MSG_CommandHeader_t DS_DestAgeCmd_t::CmdHeader`

cFE Software Bus command message header

Definition at line 220 of file `ds_msg.h`.

### 11.146.2.2 FileTableIndex

`uint16 DS_DestAgeCmd_t::FileTableIndex`

Index into Destination File Table.

Definition at line 222 of file `ds_msg.h`.

Referenced by `DS_CmdSetDestAge()`.

### 11.146.2.3 MaxFileAge

`uint32 DS_DestAgeCmd_t::MaxFileAge`

Max file age (seconds)

Definition at line 225 of file `ds_msg.h`.

Referenced by `DS_CmdSetDestAge()`.

### 11.146.2.4 Padding

`uint16 DS_DestAgeCmd_t::Padding`

Structure Padding on 32-bit boundaries.

Definition at line 223 of file `ds_msg.h`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds_msg.h`

## 11.147 DS\_DestBaseCmd\_t Struct Reference

Set Base Portion Of Filename For Destination File Table Entry.

```
#include <ds_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CmdHeader](#)  
*cFE Software Bus command message header*
- [uint16 FileTableIndex](#)  
*Index into Destination File Table.*
- [uint16 Padding](#)  
*Structure Padding on 32-bit boundaries.*
- [char Basename \[DS\\_BASENAME\\_BUFSIZE\]](#)  
*Base portion of filename.*

### 11.147.1 Detailed Description

Set Base Portion Of Filename For Destination File Table Entry.

For command details see [DS\\_SET\\_DEST\\_BASE\\_CC](#)

Definition at line 172 of file ds\_msg.h.

### 11.147.2 Field Documentation

#### 11.147.2.1 Basename

```
char DS_DestBaseCmd_t::Basename[DS_BASENAME_BUFSIZE]
```

Base portion of filename.

Definition at line 179 of file ds\_msg.h.

Referenced by [DS\\_CmdSetDestBase\(\)](#).

#### 11.147.2.2 CmdHeader

```
CFE_MSG_CommandHeader_t DS_DestBaseCmd_t::CmdHeader
```

cFE Software Bus command message header

Definition at line 175 of file ds\_msg.h.

### 11.147.2.3 FileTableIndex

`uint16 DS_DestBaseCmd_t::FileTableIndex`

Index into Destination File Table.

Definition at line 177 of file `ds_msg.h`.

Referenced by `DS_CmdSetDestBase()`.

### 11.147.2.4 Padding

`uint16 DS_DestBaseCmd_t::Padding`

Structure Padding on 32-bit boundaries.

Definition at line 178 of file `ds_msg.h`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds\_msg.h`

## 11.148 DS\_DestCountCmd\_t Struct Reference

Set Sequence Portion Of Filename For Destination File Table Entry.

```
#include <ds_msg.h>
```

### Data Fields

- `CFE_MSG_CommandHeader_t CmdHeader`  
*cFE Software Bus command message header*
- `uint16 FileTableIndex`  
*Index into Destination File Table.*
- `uint16 Padding`  
*Structure Padding on 32-bit boundaries.*
- `uint32 SequenceCount`  
*Sequence count portion of filename.*

### 11.148.1 Detailed Description

Set Sequence Portion Of Filename For Destination File Table Entry.

For command details see [DS\\_SET\\_DEST\\_COUNT\\_CC](#)

Definition at line 234 of file `ds_msg.h`.

### 11.148.2 Field Documentation

#### 11.148.2.1 CmdHeader

`CFE_MSG_CommandHeader_t` DS\_DestCountCmd\_t::CmdHeader

cFE Software Bus command message header

Definition at line 236 of file ds\_msg.h.

#### 11.148.2.2 FileTableIndex

`uint16` DS\_DestCountCmd\_t::FileTableIndex

Index into Destination File Table.

Definition at line 238 of file ds\_msg.h.

Referenced by DS\_CmdSetDestCount().

#### 11.148.2.3 Padding

`uint16` DS\_DestCountCmd\_t::Padding

Structure Padding on 32-bit boundaries.

Definition at line 239 of file ds\_msg.h.

#### 11.148.2.4 SequenceCount

`uint32` DS\_DestCountCmd\_t::SequenceCount

Sequence count portion of filename.

Definition at line 241 of file ds\_msg.h.

Referenced by DS\_CmdSetDestCount().

The documentation for this struct was generated from the following file:

- apps/ds/fsw/src/[ds\\_msg.h](#)

## 11.149 DS\_DestExtCmd\_t Struct Reference

Set Extension Portion Of Filename For Destination File Table Entry.

```
#include <ds_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CmdHeader](#)  
*cFE Software Bus command message header*
- [uint16 FileTableIndex](#)  
*Index into Destination File Table.*
- [uint16 Padding](#)  
*Structure Padding on 32-bit boundaries.*
- [char Extension \[DS\\_EXTENSION\\_BUFSIZE\]](#)  
*Extension portion of filename.*

### 11.149.1 Detailed Description

Set Extension Portion Of Filename For Destination File Table Entry.

For command details see [DS\\_SET\\_DEST\\_EXT\\_CC](#)

Definition at line 188 of file ds\_msg.h.

### 11.149.2 Field Documentation

#### 11.149.2.1 CmdHeader

```
CFE_MSG_CommandHeader_t DS_DestExtCmd_t::CmdHeader
```

cFE Software Bus command message header

Definition at line 190 of file ds\_msg.h.

#### 11.149.2.2 Extension

```
char DS_DestExtCmd_t::Extension[DS_EXTENSION_BUFSIZE]
```

Extension portion of filename.

Definition at line 194 of file ds\_msg.h.

Referenced by DS\_CmdSetDestExt().

### 11.149.2.3 FileTableIndex

`uint16 DS_DestExtCmd_t::FileTableIndex`

Index into Destination File Table.

Definition at line 192 of file `ds_msg.h`.

Referenced by `DS_CmdSetDestExt()`.

### 11.149.2.4 Padding

`uint16 DS_DestExtCmd_t::Padding`

Structure Padding on 32-bit boundaries.

Definition at line 193 of file `ds_msg.h`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds_msg.h`

## 11.150 DS\_DestFileEntry\_t Struct Reference

DS Destination File Table Entry.

```
#include <ds_table.h>
```

### Data Fields

- `char Movename [DS_PATHNAME_BUFSIZE]`  
*Move files to this dir after close.*
- `char Pathname [DS_PATHNAME_BUFSIZE]`  
*Path portion of filename.*
- `char Basename [DS_BASENAME_BUFSIZE]`  
*Base portion of filename.*
- `char Extension [DS_EXTENSION_BUFSIZE]`  
*Extension portion of filename.*
- `uint16 FileNameType`  
*Filename type - count vs time.*
- `uint16 EnableState`  
*File enable/disable state.*
- `uint32 MaxFileSize`  
*Max file size (bytes)*
- `uint32 MaxFileAge`  
*Max file age (seconds)*
- `uint32 SequenceCount`  
*Sequence count portion of filename.*

### 11.150.1 Detailed Description

DS Destination File Table Entry.

Note that the sum of the string buffer sizes exceeds the max for a qualified filename (OS\_MAX\_PATH\_LEN). This allows a variable definition of how many characters may be used in the pathname versus the filename. The qualified filename length will be verified at run-time as each filename is created.

Definition at line 92 of file ds\_table.h.

### 11.150.2 Field Documentation

#### 11.150.2.1 Basename

```
char DS_DestFileEntry_t::Basename[DS\_BASENAME\_BUFSIZE]
```

Base portion of filename.

Definition at line 98 of file ds\_table.h.

Referenced by DS\_CmdSetDestBase(), and DS\_FileCreateName().

#### 11.150.2.2 EnableState

```
uint16 DS_DestFileEntry_t::EnableState
```

File enable/disable state.

Definition at line 102 of file ds\_table.h.

Referenced by DS\_CmdSetDestState(), DS\_TableManageDestFile(), and DS\_TableVerifyDestFileEntry().

#### 11.150.2.3 Extension

```
char DS_DestFileEntry_t::Extension[DS\_EXTENSION\_BUFSIZE]
```

Extension portion of filename.

Definition at line 99 of file ds\_table.h.

Referenced by DS\_CmdSetDestExt(), and DS\_FileCreateName().

#### 11.150.2.4 FileNameType

```
uint16 DS_DestFileEntry_t::FileNameType
```

Filename type - count vs time.

Definition at line 101 of file ds\_table.h.

Referenced by DS\_CmdSetDestType(), DS\_FileCreateDest(), DS\_FileCreateName(), DS\_FileWriteHeader(), and DS\_TableVerifyDestFileEntry().

#### 11.150.2.5 MaxFileAge

```
uint32 DS_DestFileEntry_t::MaxFileAge
```

Max file age (seconds)

Definition at line 105 of file ds\_table.h.

Referenced by DS\_CmdSetDestAge(), DS\_FileTestAge(), and DS\_TableVerifyDestFileEntry().

#### 11.150.2.6 MaxFileSize

```
uint32 DS_DestFileEntry_t::MaxFileSize
```

Max file size (bytes)

Definition at line 104 of file ds\_table.h.

Referenced by DS\_CmdSetDestSize(), DS\_FileSetupWrite(), and DS\_TableVerifyDestFileEntry().

#### 11.150.2.7 Movename

```
char DS_DestFileEntry_t::Movename[DS_PATHNAME_BUFSIZE]
```

Move files to this dir after close.

Definition at line 95 of file ds\_table.h.

Referenced by DS\_FileCloseDest().

### 11.150.2.8 Pathname

```
char DS_DestFileEntry_t::Pathname[DS_PATHNAME_BUFSIZE]
```

Path portion of filename.

Definition at line 97 of file `ds_table.h`.

Referenced by `DS_CmdSetDestPath()`, and `DS_FileCreateName()`.

### 11.150.2.9 SequenceCount

```
uint32 DS_DestFileEntry_t::SequenceCount
```

Sequence count portion of filename.

Definition at line 107 of file `ds_table.h`.

Referenced by `DS_CmdSetDestCount()`, `DS_FileCreateDest()`, `DS_TableManageDestFile()`, and `DS_TableVerifyDestFileEntry()`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds_table.h`

## 11.151 DS\_DestFileDialog\_t Struct Reference

DS Destination File Table.

```
#include <ds_table.h>
```

### Data Fields

- `char Descriptor [DS_DESCRIPTOR_BUFSIZE]`  
*Description such as "HK Telemetry File".*
- `DS_DestFileEntry_t File [DS_DEST_FILE_CNT]`  
*One entry for each destination data file.*

### 11.151.1 Detailed Description

DS Destination File Table.

Definition at line 112 of file `ds_table.h`.

### 11.151.2 Field Documentation

#### 11.151.2.1 Descriptor

char DS\_DestFileTable\_t::Descriptor[[DS\\_DESCRIPTOR\\_BUFSIZE](#)]

Description such as "HK Telemetry File".

Definition at line 114 of file [ds\\_table.h](#).

#### 11.151.2.2 File

[DS\\_DestFileEntry\\_t](#) DS\_DestFileTable\_t::File[[DS\\_DEST\\_FILE\\_CNT](#)]

One entry for each destination data file.

Definition at line 115 of file [ds\\_table.h](#).

Referenced by DS\_CmdSetDestAge(), DS\_CmdSetDestBase(), DS\_CmdSetDestCount(), DS\_CmdSetDestExt(), D←S\_CmdSetDestPath(), DS\_CmdSetDestSize(), DS\_CmdSetDestState(), DS\_CmdSetDestType(), DS\_FileCloseDest(), DS\_FileCreateDest(), DS\_FileCreateName(), DS\_FileSetupWrite(), DS\_FileTestAge(), DS\_FileWriteHeader(), DS←TableManageDestFile(), and DS\_TableVerifyDestFile().

The documentation for this struct was generated from the following file:

- [apps/ds/fsw/src/ds\\_table.h](#)

## 11.152 DS\_DestPathCmd\_t Struct Reference

Set Path Portion Of Filename For Destination File Table Entry.

```
#include <ds_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CmdHeader](#)  
*cFE Software Bus command message header*
- [uint16 FileTableIndex](#)  
*Index into Destination File Table.*
- [uint16 Padding](#)  
*Structure Padding on 32-bit boundaries.*
- [char Pathname \[\[DS\\\_PATHNAME\\\_BUFSIZE\]\(#\)\]](#)  
*Path portion of filename.*

### 11.152.1 Detailed Description

Set Path Portion Of Filename For Destination File Table Entry.

For command details see [DS\\_SET\\_DEST\\_PATH\\_CC](#)

Definition at line 156 of file ds\_msg.h.

### 11.152.2 Field Documentation

#### 11.152.2.1 CmdHeader

`CFE_MSG_CommandHeader_t DS_DestPathCmd_t::CmdHeader`

cFE Software Bus command message header

Definition at line 159 of file ds\_msg.h.

#### 11.152.2.2 FileTableIndex

`uint16 DS_DestPathCmd_t::FileTableIndex`

Index into Destination File Table.

Definition at line 161 of file ds\_msg.h.

Referenced by `DS_CmdSetDestPath()`.

#### 11.152.2.3 Padding

`uint16 DS_DestPathCmd_t::Padding`

Structure Padding on 32-bit boundaries.

Definition at line 162 of file ds\_msg.h.

#### 11.152.2.4 Pathname

```
char DS_DestPathCmd_t::Pathname[DS_PATHNAME_BUFSIZE]
```

Path portion of filename.

Definition at line 163 of file ds\_msg.h.

Referenced by DS\_CmdSetDestPath().

The documentation for this struct was generated from the following file:

- [apps/ds/fsw/src/ds\\_msg.h](#)

## 11.153 DS\_DestSizeCmd\_t Struct Reference

Set Max File Size For Destination File Table Entry.

```
#include <ds_msg.h>
```

#### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CmdHeader](#)  
*cFE Software Bus command message header*
- [uint16 FileTableIndex](#)  
*Index into Destination File Table.*
- [uint16 Padding](#)  
*Structure Padding on 32-bit boundaries.*
- [uint32 MaxFileSize](#)  
*Max file size (bytes) before re-open.*

#### 11.153.1 Detailed Description

Set Max File Size For Destination File Table Entry.

For command details see [DS\\_SET\\_DEST\\_SIZE\\_CC](#)

Definition at line 203 of file ds\_msg.h.

#### 11.153.2 Field Documentation

### 11.153.2.1 CmdHeader

`CFE_MSG_CommandHeader_t DS_DestSizeCmd_t::CmdHeader`

cFE Software Bus command message header

Definition at line 205 of file `ds_msg.h`.

### 11.153.2.2 FileTableIndex

`uint16 DS_DestSizeCmd_t::FileTableIndex`

Index into Destination File Table.

Definition at line 207 of file `ds_msg.h`.

Referenced by `DS_CmdSetDestSize()`.

### 11.153.2.3 MaxFileSize

`uint32 DS_DestSizeCmd_t::MaxFileSize`

Max file size (bytes) before re-open.

Definition at line 209 of file `ds_msg.h`.

Referenced by `DS_CmdSetDestSize()`.

### 11.153.2.4 Padding

`uint16 DS_DestSizeCmd_t::Padding`

Structure Padding on 32-bit boundaries.

Definition at line 208 of file `ds_msg.h`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds_msg.h`

## 11.154 DS\_DestStateCmd\_t Struct Reference

Set Ena/Dis State For Destination File Table Entry.

```
#include <ds_msg.h>
```

## Data Fields

- `CFE_MSG_CommandHeader_t CmdHeader`  
*cFE Software Bus command message header*
- `uint16 FileTableIndex`  
*Index into Destination File Table.*
- `uint16 EnableState`  
*File enable/disable state.*

### 11.154.1 Detailed Description

Set Ena/Dis State For Destination File Table Entry.

For command details see [DS\\_SET\\_DEST\\_STATE\\_CC](#)

Definition at line 142 of file ds\_msg.h.

### 11.154.2 Field Documentation

#### 11.154.2.1 CmdHeader

`CFE_MSG_CommandHeader_t DS_DestStateCmd_t::CmdHeader`

cFE Software Bus command message header

Definition at line 144 of file ds\_msg.h.

#### 11.154.2.2 EnableState

`uint16 DS_DestStateCmd_t::EnableState`

File enable/disable state.

Definition at line 147 of file ds\_msg.h.

Referenced by `DS_CmdSetDestState()`.

### 11.154.2.3 FileTableIndex

`uint16 DS_DestStateCmd_t::FileTableIndex`

Index into Destination File Table.

Definition at line 146 of file `ds_msg.h`.

Referenced by `DS_CmdSetDestState()`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds\_msg.h`

## 11.155 DS\_DestTypeCmd\_t Struct Reference

Set Filename Type For Destination File Table Entry.

```
#include <ds_msg.h>
```

### Data Fields

- `CFE_MSG_CommandHeader_t CmdHeader`  
*cFE Software Bus command message header*
- `uint16 FileTableIndex`  
*Index into Destination File Table.*
- `uint16 FileNameType`  
*Filename type - count vs time.*

### 11.155.1 Detailed Description

Set Filename Type For Destination File Table Entry.

For command details see [`DS\_SET\_DEST\_TYPE\_CC`](#)

Definition at line 128 of file `ds_msg.h`.

### 11.155.2 Field Documentation

### 11.155.2.1 CmdHeader

`CFE_MSG_CommandHeader_t` DS\_DestTypeCmd\_t ::CmdHeader

cFE Software Bus command message header

Definition at line 130 of file ds\_msg.h.

### 11.155.2.2 FileNameType

`uint16` DS\_DestTypeCmd\_t ::FileNameType

Filename type - count vs time.

Definition at line 133 of file ds\_msg.h.

Referenced by DS\_CmdSetDestType().

### 11.155.2.3 FileTableIndex

`uint16` DS\_DestTypeCmd\_t ::FileTableIndex

Index into Destination File Table.

Definition at line 132 of file ds\_msg.h.

Referenced by DS\_CmdSetDestType().

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds_msg.h`

## 11.156 DS\_FileCompletePkt\_t Struct Reference

Single application file info packet.

```
#include <ds_msg.h>
```

### Data Fields

- `CFE_MSG_TelemetryHeader_t TlmHeader`  
*cFE Software Bus telemetry message header*
- `DS_FileInfo_t FileInfo`  
*Current state of destination file.*

### 11.156.1 Detailed Description

Single application file info packet.

Definition at line 362 of file `ds_msg.h`.

### 11.156.2 Field Documentation

#### 11.156.2.1 FileInfo

`DS_FileInfo_t` `DS_FileCompletePkt_t::FileInfo`

Current state of destination file.

Definition at line 366 of file `ds_msg.h`.

Referenced by `DS_FileTransmit()`.

#### 11.156.2.2 TlmHeader

`CFE_MSG_TelemetryHeader_t` `DS_FileCompletePkt_t::TlmHeader`

cFE Software Bus telemetry message header

Definition at line 364 of file `ds_msg.h`.

Referenced by `DS_FileTransmit()`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds\_msg.h`

## 11.157 DS\_FileCompletePktBuf\_t Union Reference

Single application file info packet buffer.

```
#include <ds_msg.h>
```

### Data Fields

- `CFE_SB_Buffer_t SBBuf`  
*Message buffer for alignment.*
- `DS_FileCompletePkt_t Pkt`  
*Single application file info packet.*

### 11.157.1 Detailed Description

Single application file info packet buffer.

This typedef supports CFE\_SB\_AllocateMessageBuffer use with a [DS\\_FileCompletePkt\\_t](#) that compiles with the alignment constraints of a CFE\_SB\_Buffer\_t

Definition at line 375 of file ds\_msg.h.

### 11.157.2 Field Documentation

#### 11.157.2.1 Pkt

[DS\\_FileCompletePkt\\_t](#) DS\_FileCompletePktBuf\_t::Pkt

Single application file info packet.

Definition at line 378 of file ds\_msg.h.

Referenced by [DS\\_FileTransmit\(\)](#).

#### 11.157.2.2 SBBuf

[CFE\\_SB\\_Buffer\\_t](#) DS\_FileCompletePktBuf\_t::SBBuf

Message buffer for alignment.

Definition at line 377 of file ds\_msg.h.

Referenced by [DS\\_FileTransmit\(\)](#).

The documentation for this union was generated from the following file:

- apps/ds/fsw/src/[ds\\_msg.h](#)

## 11.158 DS\_FileHeader\_t Struct Reference

DS File Header (follows cFE file header at start of file)

```
#include <ds_file.h>
```

## Data Fields

- `uint32 CloseSeconds`  
*Time when file was closed.*
- `uint32 CloseSubsecs`
- `uint16 FileTableIndex`  
*Destination file table index.*
- `uint16 FileNameType`  
*Filename type - count vs time.*
- `char FileName [DS_TOTAL_FNAME_BUFSIZE]`  
*On-board filename.*

### 11.158.1 Detailed Description

DS File Header (follows cFE file header at start of file)

Definition at line 41 of file `ds_file.h`.

### 11.158.2 Field Documentation

#### 11.158.2.1 CloseSeconds

`uint32 DS_FileHeader_t::CloseSeconds`

Time when file was closed.

Definition at line 43 of file `ds_file.h`.

#### 11.158.2.2 CloseSubsecs

`uint32 DS_FileHeader_t::CloseSubsecs`

Definition at line 44 of file `ds_file.h`.

#### 11.158.2.3 FileName

`char DS_FileHeader_t::FileName [DS_TOTAL_FNAME_BUFSIZE]`

On-board filename.

Definition at line 49 of file `ds_file.h`.

Referenced by `DS_FileWriteHeader()`.

#### 11.158.2.4 FileNameType

`uint16 DS_FileHeader_t::FileNameType`

Filename type - count vs time.

Definition at line 47 of file `ds_file.h`.

Referenced by `DS_FileWriteHeader()`.

#### 11.158.2.5 FileTableIndex

`uint16 DS_FileHeader_t::FileTableIndex`

Destination file table index.

Definition at line 46 of file `ds_file.h`.

Referenced by `DS_FileWriteHeader()`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds_file.h`

## 11.159 DS\_FileInfo\_t Struct Reference

Current state of destination files.

```
#include <ds_msg.h>
```

### Data Fields

- `uint32 FileAge`  
*Current file age in seconds.*
- `uint32 FileSize`  
*Current file size in bytes.*
- `uint32 FileRate`  
*Current file data rate (avg since HK)*
- `uint32 SequenceCount`  
*Sequence count portion of filename.*
- `uint16 EnableState`  
*Current file enable/disable state.*
- `uint16 OpenState`  
*Current file open/close state.*
- `char FileName [DS_TOTAL_FNAME_BUFSIZE]`  
*Current filename (path+base+seq+ext)*

### 11.159.1 Detailed Description

Current state of destination files.

Definition at line 338 of file ds\_msg.h.

### 11.159.2 Field Documentation

#### 11.159.2.1 EnableState

```
uint16 DS_FileInfo_t::EnableState
```

Current file enable/disable state.

Definition at line 344 of file ds\_msg.h.

Referenced by DS\_CmdGetFileInfo(), and DS\_FileTransmit().

#### 11.159.2.2 FileAge

```
uint32 DS_FileInfo_t::FileAge
```

Current file age in seconds.

Definition at line 340 of file ds\_msg.h.

Referenced by DS\_CmdGetFileInfo(), and DS\_FileTransmit().

#### 11.159.2.3 FileName

```
char DS_FileInfo_t::FileName[DS_TOTAL_FNAME_BUFSIZE]
```

Current filename (path+base+seq+ext)

Definition at line 346 of file ds\_msg.h.

Referenced by DS\_CmdGetFileInfo(), and DS\_FileTransmit().

#### 11.159.2.4 FileRate

`uint32 DS_FileInfo_t::FileRate`

Current file data rate (avg since HK)

Definition at line 342 of file `ds_msg.h`.

Referenced by `DS_CmdGetFileInfo()`, and `DS_FileTransmit()`.

#### 11.159.2.5 FileSize

`uint32 DS_FileInfo_t::FileSize`

Current file size in bytes.

Definition at line 341 of file `ds_msg.h`.

Referenced by `DS_CmdGetFileInfo()`, and `DS_FileTransmit()`.

#### 11.159.2.6 OpenState

`uint16 DS_FileInfo_t::OpenState`

Current file open/close state.

Definition at line 345 of file `ds_msg.h`.

Referenced by `DS_CmdGetFileInfo()`, and `DS_FileTransmit()`.

#### 11.159.2.7 SequenceCount

`uint32 DS_FileInfo_t::SequenceCount`

Sequence count portion of filename.

Definition at line 343 of file `ds_msg.h`.

Referenced by `DS_CmdGetFileInfo()`, and `DS_FileTransmit()`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds\_msg.h`

## 11.160 DS\_FileInfoPkt\_t Struct Reference

Application file info packet.

```
#include <ds_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_TelemetryHeader\\_t TlmHeader](#)  
*cFE Software Bus telemetry message header*
- [DS\\_FileInfo\\_t FileInfo \[DS\\_DEST\\_FILE\\_CNT\]](#)  
*Current state of destination files.*

### 11.160.1 Detailed Description

Application file info packet.

Definition at line 352 of file ds\_msg.h.

### 11.160.2 Field Documentation

#### 11.160.2.1 FileInfo

```
DS_FileInfo_t DS_FileInfoPkt_t::FileInfo[DS_DEST_FILE_CNT]
```

Current state of destination files.

Definition at line 356 of file ds\_msg.h.

Referenced by DS\_CmdGetFileInfo().

#### 11.160.2.2 TlmHeader

```
CFE_MSG_TelemetryHeader_t DS_FileInfoPkt_t::TlmHeader
```

cFE Software Bus telemetry message header

Definition at line 354 of file ds\_msg.h.

Referenced by DS\_CmdGetFileInfo().

The documentation for this struct was generated from the following file:

- [apps/ds/fsw/src/ds\\_msg.h](#)

## 11.161 DS\_FilterFileCmd\_t Struct Reference

Set File Selection For Packet Filter Table Entry.

```
#include <ds_msg.h>
```

### Data Fields

- **CFE\_MSG\_CommandHeader\_t CmdHeader**  
*cFE Software Bus command message header*
- **CFE\_SB\_MsgId\_t MessageID**  
*Message ID of existing entry in Packet Filter Table.*
- **uint16 FilterParmsIndex**  
*Index into Filter Params Array.*
- **uint16 FileTableIndex**  
*Index into Destination File Table.*

### 11.161.1 Detailed Description

Set File Selection For Packet Filter Table Entry.

For command details see [DS\\_SET\\_FILTER\\_FILE\\_CC](#)

Definition at line 77 of file ds\_msg.h.

### 11.161.2 Field Documentation

#### 11.161.2.1 CmdHeader

```
CFE_MSG_CommandHeader_t DS_FilterFileCmd_t::CmdHeader
```

cFE Software Bus command message header

Definition at line 79 of file ds\_msg.h.

#### 11.161.2.2 FileTableIndex

```
uint16 DS_FilterFileCmd_t::FileTableIndex
```

Index into Destination File Table.

Definition at line 84 of file ds\_msg.h.

Referenced by DS\_CmdSetFilterFile().

### 11.161.2.3 FilterParmsIndex

`uint16 DS_FilterFileCmd_t::FilterParmsIndex`

Index into Filter Params Array.

Definition at line 83 of file `ds_msg.h`.

Referenced by `DS_CmdSetFilterFile()`.

### 11.161.2.4 MessageID

`CFE_SB_MsgId_t DS_FilterFileCmd_t::MessageID`

Message ID of existing entry in Packet Filter Table.

DS defines Message ID zero to be unused

Definition at line 81 of file `ds_msg.h`.

Referenced by `DS_CmdSetFilterFile()`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds_msg.h`

## 11.162 DS\_FilterParms\_t Struct Reference

DS Packet Filter Parameters.

```
#include <ds_table.h>
```

### Data Fields

- `uint8 FileTableIndex`  
*Index into Destination File Table.*
- `uint8 FilterType`  
*Filter type (packet count or time)*
- `uint16 Algorithm_N`  
*Algorithm value N (pass this many)*
- `uint16 Algorithm_X`  
*Algorithm value X (out of this many)*
- `uint16 Algorithm_O`  
*Algorithm value O (at this offset)*

### 11.162.1 Detailed Description

DS Packet Filter Parameters.

Definition at line 57 of file ds\_table.h.

### 11.162.2 Field Documentation

#### 11.162.2.1 Algorithm\_N

```
uint16 DS_FilterParms_t::Algorithm_N
```

Algorithm value N (pass this many)

Definition at line 62 of file ds\_table.h.

Referenced by DS\_CmdAddMID(), DS\_CmdSetFilterParms(), DS\_FileStorePacket(), and DS\_TableVerifyFilterEntry().

#### 11.162.2.2 Algorithm\_O

```
uint16 DS_FilterParms_t::Algorithm_O
```

Algorithm value O (at this offset)

Definition at line 64 of file ds\_table.h.

Referenced by DS\_CmdAddMID(), DS\_CmdSetFilterParms(), DS\_FileStorePacket(), and DS\_TableVerifyFilterEntry().

#### 11.162.2.3 Algorithm\_X

```
uint16 DS_FilterParms_t::Algorithm_X
```

Algorithm value X (out of this many)

Definition at line 63 of file ds\_table.h.

Referenced by DS\_CmdAddMID(), DS\_CmdSetFilterParms(), DS\_FileStorePacket(), and DS\_TableVerifyFilterEntry().

### 11.162.2.4 FileTableIndex

`uint8 DS_FilterParms_t::FileTableIndex`

Index into Destination File Table.

Definition at line 59 of file `ds_table.h`.

Referenced by `DS_CmdAddMID()`, `DS_CmdSetFilterFile()`, `DS_FileStorePacket()`, and `DS_TableVerifyFilterEntry()`.

### 11.162.2.5 FilterType

`uint8 DS_FilterParms_t::FilterType`

Filter type (packet count or time)

Definition at line 60 of file `ds_table.h`.

Referenced by `DS_CmdAddMID()`, `DS_CmdSetFilterType()`, `DS_FileStorePacket()`, and `DS_TableVerifyFilterEntry()`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds_table.h`

## 11.163 DS\_FilterParmsCmd\_t Struct Reference

Set Filter Parameters For Packet Filter Table Entry.

```
#include <ds_msg.h>
```

### Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CmdHeader](#)  
*cFE Software Bus command message header*
- [CFE\\_SB\\_MsgId\\_t MessageID](#)  
*Message ID of existing entry in Packet Filter Table.*
- `uint16 FilterParmsIndex`  
*Index into Filter Params Array.*
- `uint16 Algorithm_N`  
*Algorithm value N (pass this many)*
- `uint16 Algorithm_X`  
*Algorithm value X (out of this many)*
- `uint16 Algorithm_O`  
*Algorithm value O (at this offset)*

### 11.163.1 Detailed Description

Set Filter Parameters For Packet Filter Table Entry.

For command details see [DS\\_SET\\_FILTER\\_PARMS\\_CC](#)

Definition at line 110 of file ds\_msg.h.

### 11.163.2 Field Documentation

#### 11.163.2.1 Algorithm\_N

```
uint16 DS_FilterParmsCmd_t::Algorithm_N
```

Algorithm value N (pass this many)

Definition at line 117 of file ds\_msg.h.

Referenced by [DS\\_CmdSetFilterParms\(\)](#).

#### 11.163.2.2 Algorithm\_O

```
uint16 DS_FilterParmsCmd_t::Algorithm_O
```

Algorithm value O (at this offset)

Definition at line 119 of file ds\_msg.h.

Referenced by [DS\\_CmdSetFilterParms\(\)](#).

#### 11.163.2.3 Algorithm\_X

```
uint16 DS_FilterParmsCmd_t::Algorithm_X
```

Algorithm value X (out of this many)

Definition at line 118 of file ds\_msg.h.

Referenced by [DS\\_CmdSetFilterParms\(\)](#).

#### 11.163.2.4 CmdHeader

`CFE_MSG_CommandHeader_t DS_FilterParmsCmd_t::CmdHeader`

cFE Software Bus command message header

Definition at line 112 of file `ds_msg.h`.

#### 11.163.2.5 FilterParmsIndex

`uint16 DS_FilterParmsCmd_t::FilterParmsIndex`

Index into Filter Params Array.

Definition at line 116 of file `ds_msg.h`.

Referenced by `DS_CmdSetFilterParms()`.

#### 11.163.2.6 MessageID

`CFE_SB_MsgId_t DS_FilterParmsCmd_t::MessageID`

Message ID of existing entry in Packet Filter Table.

DS defines Message ID zero to be unused

Definition at line 114 of file `ds_msg.h`.

Referenced by `DS_CmdSetFilterParms()`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds\_msg.h`

### 11.164 DS\_FilterTable\_t Struct Reference

DS Filter Table.

```
#include <ds_table.h>
```

#### Data Fields

- `char Descriptor [DS_DESCRIPTOR_BUFSIZE]`  
*Description such as "Safehold Filter Table".*
- `DS_PacketEntry_t Packet [DS_PACKETS_IN_FILTER_TABLE]`  
*One entry for each filtered packet.*

### 11.164.1 Detailed Description

DS Filter Table.

Definition at line 78 of file `ds_table.h`.

### 11.164.2 Field Documentation

#### 11.164.2.1 Descriptor

`char DS_FilterTable_t::Descriptor[DS_DESCRIPTOR_BUFSIZE]`

Description such as "Safehold Filter Table".

Definition at line 80 of file `ds_table.h`.

#### 11.164.2.2 Packet

`DS_PacketEntry_t DS_FilterTable_t::Packet[DS_PACKETS_IN_FILTER_TABLE]`

One entry for each filtered packet.

Definition at line 81 of file `ds_table.h`.

Referenced by `DS_CmdAddMID()`, `DS_CmdSetFilterFile()`, `DS_CmdSetFilterParms()`, `DS_CmdSetFilterType()`, `DS_FileStorePacket()`, `DS_TableCreateHash()`, `DS_TableFindMsgID()`, `DS_TableSubscribe()`, `DS_TableUnsubscribe()`, and `DS_TableVerifyFilter()`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds_table.h`

## 11.165 DS\_FilterTypeCmd\_t Struct Reference

Set Filter Type For Packet Filter Table Entry.

```
#include <ds_msg.h>
```

## Data Fields

- [CFE\\_MSG\\_CommandHeader\\_t CmdHeader](#)  
*cFE Software Bus command message header*
- [CFE\\_SB\\_MsgId\\_t MessageID](#)  
*Message ID of existing entry in Packet Filter Table.*
- [uint16 FilterParmsIndex](#)  
*Index into Filter Params Array.*
- [uint16 FilterType](#)  
*Filter type (packet count or time)*

### 11.165.1 Detailed Description

Set Filter Type For Packet Filter Table Entry.

For command details see [DS\\_SET\\_FILTER\\_TYPE\\_CC](#)

Definition at line 93 of file ds\_msg.h.

### 11.165.2 Field Documentation

#### 11.165.2.1 CmdHeader

[CFE\\_MSG\\_CommandHeader\\_t](#) DS\_FilterTypeCmd\_t::CmdHeader

cFE Software Bus command message header

Definition at line 96 of file ds\_msg.h.

#### 11.165.2.2 FilterParmsIndex

[uint16](#) DS\_FilterTypeCmd\_t::FilterParmsIndex

Index into Filter Params Array.

Definition at line 100 of file ds\_msg.h.

Referenced by DS\_CmdSetFilterType().

### 11.165.2.3 FilterType

`uint16 DS_FilterTypeCmd_t::FilterType`

Filter type (packet count or time)

Definition at line 101 of file `ds_msg.h`.

Referenced by `DS_CmdSetFilterType()`.

### 11.165.2.4 MessageID

`CFE_SB_MsgId_t DS_FilterTypeCmd_t::MessageID`

Message ID of existing entry in Packet Filter Table.

DS defines Message ID zero to be unused

Definition at line 98 of file `ds_msg.h`.

Referenced by `DS_CmdSetFilterType()`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds_msg.h`

## 11.166 DS\_GetFileInfoCmd\_t Struct Reference

Get File Info Command.

```
#include <ds_msg.h>
```

### Data Fields

- `CFE_MSG_CommandHeader_t CmdHeader`  
*cFE Software Bus command message header*

### 11.166.1 Detailed Description

Get File Info Command.

For command details see [DS\\_GET\\_FILE\\_INFO\\_CC](#)

Definition at line 276 of file `ds_msg.h`.

## 11.166.2 Field Documentation

### 11.166.2.1 CmdHeader

`CFE_MSG_CommandHeader_t DS_GetFileInfoCmd_t::CmdHeader`

cFE Software Bus command message header

Definition at line 279 of file `ds_msg.h`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds_msg.h`

## 11.167 DS\_HashTag Struct Reference

DS Hash Table Linked List structure.

```
#include <ds_table.h>
```

### Data Fields

- `CFE_SB_MsgId_t MessageID`  
*DS filter table entry MessageID.*
- `uint16 Index`  
*DS filter table entry index.*
- struct `DS_HashTag *` `Next`  
*Next hash table linked list element.*

### 11.167.1 Detailed Description

DS Hash Table Linked List structure.

Definition at line 41 of file `ds_table.h`.

### 11.167.2 Field Documentation

### 11.167.2.1 Index

`uint16 DS_HashTag::Index`

DS filter table entry index.

Definition at line 44 of file `ds_table.h`.

Referenced by `DS_TableAddMsgID()`, and `DS_TableFindMsgID()`.

### 11.167.2.2 MessageID

`CFE_SB_MsgId_t DS_HashTag::MessageID`

DS filter table entry MessageID.

Definition at line 43 of file `ds_table.h`.

Referenced by `DS_TableAddMsgID()`.

### 11.167.2.3 Next

`struct DS_HashTag* DS_HashTag::Next`

Next hash table linked list element.

Definition at line 46 of file `ds_table.h`.

Referenced by `DS_TableAddMsgID()`, and `DS_TableFindMsgID()`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds_table.h`

## 11.168 DS\_HkPacket\_t Struct Reference

Application housekeeping packet.

```
#include <ds_msg.h>
```

## Data Fields

- **CFE\_MSG\_TelemetryHeader\_t TlmHeader**  
*cFE Software Bus telemetry message header*
- **uint8 CmdAcceptedCounter**  
*Count of valid commands received.*
- **uint8 CmdRejectedCounter**  
*Count of invalid commands received.*
- **uint8 DestTblLoadCounter**  
*Count of destination file table loads.*
- **uint8 DestTblErrCounter**  
*Count of failed attempts to get table data pointer.*
- **uint8 FilterTblLoadCounter**  
*Count of packet filter table loads.*
- **uint8 FilterTblErrCounter**  
*Count of failed attempts to get table data pointer.*
- **uint8 AppEnableState**  
*Application enable/disable state.*
- **uint8 Spare8**  
*Structure alignment padding.*
- **uint16 FileWriteCounter**  
*Count of good destination file writes.*
- **uint16 FileWriteErrCounter**  
*Count of bad destination file writes.*
- **uint16 FileUpdateCounter**  
*Count of good updates to secondary header.*
- **uint16 FileUpdateErrCounter**  
*Count of bad updates to secondary header.*
- **uint32 DisabledPktCounter**  
*Count of packets discarded (DS was disabled)*
- **uint32 IgnoredPktCounter**  
*Count of packets discarded.*
- **uint32 FilteredPktCounter**  
*Count of packets discarded (failed filter test)*
- **uint32 PassedPktCounter**  
*Count of packets that passed filter test.*
- **char FilterTblFilename [OS\_MAX\_PATH\_LEN]**  
*Name of filter table file.*

### 11.168.1 Detailed Description

Application housekeeping packet.

Definition at line 306 of file ds\_msg.h.

## 11.168.2 Field Documentation

### 11.168.2.1 AppEnableState

```
uint8 DS_HkPacket_t::AppEnableState
```

Application enable/disable state.

Definition at line 316 of file ds\_msg.h.

Referenced by DS\_AppProcessHK().

### 11.168.2.2 CmdAcceptedCounter

```
uint8 DS_HkPacket_t::CmdAcceptedCounter
```

Count of valid commands received.

Definition at line 310 of file ds\_msg.h.

Referenced by DS\_AppProcessHK().

### 11.168.2.3 CmdRejectedCounter

```
uint8 DS_HkPacket_t::CmdRejectedCounter
```

Count of invalid commands received.

Definition at line 311 of file ds\_msg.h.

Referenced by DS\_AppProcessHK().

### 11.168.2.4 DestTblErrCounter

```
uint8 DS_HkPacket_t::DestTblErrCounter
```

Count of failed attempts to get table data pointer.

Definition at line 313 of file ds\_msg.h.

Referenced by DS\_AppProcessHK().

### 11.168.2.5 DestTblLoadCounter

`uint8 DS_HkPacket_t::DestTblLoadCounter`

Count of destination file table loads.

Definition at line 312 of file `ds_msg.h`.

Referenced by `DS_AppProcessHK()`.

### 11.168.2.6 DisabledPktCounter

`uint32 DS_HkPacket_t::DisabledPktCounter`

Count of packets discarded (DS was disabled)

Definition at line 322 of file `ds_msg.h`.

Referenced by `DS_AppProcessHK()`.

### 11.168.2.7 FileUpdateCounter

`uint16 DS_HkPacket_t::FileUpdateCounter`

Count of good updates to secondary header.

Definition at line 320 of file `ds_msg.h`.

Referenced by `DS_AppProcessHK()`.

### 11.168.2.8 FileUpdateErrCounter

`uint16 DS_HkPacket_t::FileUpdateErrCounter`

Count of bad updates to secondary header.

Definition at line 321 of file `ds_msg.h`.

Referenced by `DS_AppProcessHK()`.

**11.168.2.9 FileWriteCounter**

```
uint16 DS_HkPacket_t::FileWriteCounter
```

Count of good destination file writes.

Definition at line 318 of file ds\_msg.h.

Referenced by DS\_AppProcessHK().

**11.168.2.10 FileWriteErrCounter**

```
uint16 DS_HkPacket_t::FileWriteErrCounter
```

Count of bad destination file writes.

Definition at line 319 of file ds\_msg.h.

Referenced by DS\_AppProcessHK().

**11.168.2.11 FilteredPktCounter**

```
uint32 DS_HkPacket_t::FilteredPktCounter
```

Count of packets discarded (failed filter test)

Definition at line 330 of file ds\_msg.h.

Referenced by DS\_AppProcessHK().

**11.168.2.12 FilterTblErrCounter**

```
uint8 DS_HkPacket_t::FilterTblErrCounter
```

Count of failed attempts to get table data pointer.

Definition at line 315 of file ds\_msg.h.

Referenced by DS\_AppProcessHK().

### 11.168.2.13 FilterTblFilename

`char DS_HkPacket_t::FilterTblFilename[OS_MAX_PATH_LEN]`

Name of filter table file.

Definition at line 332 of file `ds_msg.h`.

Referenced by `DS_AppProcessHK()`.

### 11.168.2.14 FilterTblLoadCounter

`uint8 DS_HkPacket_t::FilterTblLoadCounter`

Count of packet filter table loads.

Definition at line 314 of file `ds_msg.h`.

Referenced by `DS_AppProcessHK()`.

### 11.168.2.15 IgnoredPktCounter

`uint32 DS_HkPacket_t::IgnoredPktCounter`

Count of packets discarded.

Incoming packets will be discarded when:

- The File and/or Filter Table has failed to load
- A packet (that is not a DS HK or command packet) has been received that is not listed in the Filter Table

Definition at line 323 of file `ds_msg.h`.

Referenced by `DS_AppProcessHK()`.

### 11.168.2.16 PassedPktCounter

`uint32 DS_HkPacket_t::PassedPktCounter`

Count of packets that passed filter test.

Definition at line 331 of file `ds_msg.h`.

Referenced by `DS_AppProcessHK()`.

### 11.168.2.17 Spare8

`uint8 DS_HkPacket_t::Spare8`

Structure alignment padding.

Definition at line 317 of file `ds_msg.h`.

### 11.168.2.18 TlmHeader

`CFE_MSG_TelemetryHeader_t DS_HkPacket_t::TlmHeader`

cFE Software Bus telemetry message header

Definition at line 308 of file `ds_msg.h`.

Referenced by `DS_AppProcessHK()`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds_msg.h`

## 11.169 DS\_NoopCmd\_t Struct Reference

No-Operation Command.

`#include <ds_msg.h>`

### Data Fields

- `CFE_MSG_CommandHeader_t CmdHeader`  
*cFE Software Bus command message header*

### 11.169.1 Detailed Description

No-Operation Command.

For command details see [DS\\_NOOP\\_CC](#)

Definition at line 40 of file `ds_msg.h`.

### 11.169.2 Field Documentation

### 11.169.2.1 CmdHeader

`CFE_MSG_CommandHeader_t DS_NoopCmd_t::CmdHeader`

cFE Software Bus command message header

Definition at line 42 of file `ds_msg.h`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds_msg.h`

## 11.170 DS\_PacketEntry\_t Struct Reference

DS Filter Table Packet Entry.

```
#include <ds_table.h>
```

### Data Fields

- `CFE_SB_MsgId_t MessageID`  
*Packet MessageID (may be cmd or tlm)*
- `DS_FilterParms_t Filter [DS_FILTERS_PER_PACKET]`  
*One entry for each packet destination.*

### 11.170.1 Detailed Description

DS Filter Table Packet Entry.

Definition at line 69 of file `ds_table.h`.

### 11.170.2 Field Documentation

#### 11.170.2.1 Filter

`DS_FilterParms_t DS_PacketEntry_t::Filter[DS_FILTERS_PER_PACKET]`

One entry for each packet destination.

Definition at line 73 of file `ds_table.h`.

Referenced by `DS_CmdAddMID()`, `DS_CmdSetFilterFile()`, `DS_CmdSetFilterParms()`, `DS_CmdSetFilterType()`, `DS_FileStorePacket()`, and `DS_TableVerifyFilterEntry()`.

### 11.170.2.2 MessageID

`CFE_SB_MsgId_t DS_PacketEntry_t::MessageID`

Packet MessageID (may be cmd or tlm)

Definition at line 71 of file `ds_table.h`.

Referenced by `DS_CmdAddMID()`, `DS_TableCreateHash()`, `DS_TableFindMsgID()`, `DS_TableSubscribe()`, `DS_TableUnsubscribe()`, `DS_TableVerifyFilter()`, and `DS_TableVerifyFilterEntry()`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds_table.h`

## 11.171 DS\_ResetCmd\_t Struct Reference

Reset Housekeeping Telemetry Command.

```
#include <ds_msg.h>
```

### Data Fields

- `CFE_MSG_CommandHeader_t CmdHeader`  
*cFE Software Bus command message header*

### 11.171.1 Detailed Description

Reset Housekeeping Telemetry Command.

For command details see [DS\\_RESET\\_CC](#)

Definition at line 51 of file `ds_msg.h`.

### 11.171.2 Field Documentation

#### 11.171.2.1 CmdHeader

`CFE_MSG_CommandHeader_t DS_ResetCmd_t::CmdHeader`

cFE Software Bus command message header

Definition at line 54 of file `ds_msg.h`.

The documentation for this struct was generated from the following file:

- `apps/ds/fsw/src/ds_msg.h`

## 11.172 OS\_bin\_sem\_prop\_t Struct Reference

OSAL binary semaphore properties.

```
#include <osapi-binsem.h>
```

### Data Fields

- char name [OS\_MAX\_API\_NAME]
- osal\_id\_t creator
- int32 value

#### 11.172.1 Detailed Description

OSAL binary semaphore properties.

Definition at line 39 of file osapi-binsem.h.

#### 11.172.2 Field Documentation

##### 11.172.2.1 creator

```
osal_id_t OS_bin_sem_prop_t::creator
```

Definition at line 42 of file osapi-binsem.h.

##### 11.172.2.2 name

```
char OS_bin_sem_prop_t::name [OS_MAX_API_NAME]
```

Definition at line 41 of file osapi-binsem.h.

##### 11.172.2.3 value

```
int32 OS_bin_sem_prop_t::value
```

Definition at line 43 of file osapi-binsem.h.

The documentation for this struct was generated from the following file:

- osal/src/os/inc/[osapi-binsem.h](#)

## 11.173 OS\_count\_sem\_prop\_t Struct Reference

OSAL counting semaphore properties.

```
#include <osapi-countsem.h>
```

### Data Fields

- char name [OS\_MAX\_API\_NAME]
- osal\_id\_t creator
- int32 value

#### 11.173.1 Detailed Description

OSAL counting semaphore properties.

Definition at line 32 of file osapi-countsem.h.

#### 11.173.2 Field Documentation

##### 11.173.2.1 creator

```
osal_id_t OS_count_sem_prop_t::creator
```

Definition at line 35 of file osapi-countsem.h.

##### 11.173.2.2 name

```
char OS_count_sem_prop_t::name [OS_MAX_API_NAME]
```

Definition at line 34 of file osapi-countsem.h.

##### 11.173.2.3 value

```
int32 OS_count_sem_prop_t::value
```

Definition at line 36 of file osapi-countsem.h.

The documentation for this struct was generated from the following file:

- osal/src/os/inc/[osapi-countsem.h](#)

## 11.174 os\_dirent\_t Struct Reference

Directory entry.

```
#include <osapi-dir.h>
```

### Data Fields

- char [FileName \[OS\\_MAX\\_FILE\\_NAME\]](#)

#### 11.174.1 Detailed Description

Directory entry.

Definition at line 32 of file osapi-dir.h.

#### 11.174.2 Field Documentation

##### 11.174.2.1 FileName

```
char os_dirent_t::FileName[OS_MAX_FILE_NAME]
```

Definition at line 34 of file osapi-dir.h.

The documentation for this struct was generated from the following file:

- [osal/src/os/inc/osapi-dir.h](#)

## 11.175 OS\_FdSet Struct Reference

An abstract structure capable of holding several OSAL IDs.

```
#include <osapi-select.h>
```

### Data Fields

- [uint8 object\\_ids \[\(OS\\_MAX\\_NUM\\_OPEN\\_FILES+7\)/8\]](#)

### 11.175.1 Detailed Description

An abstract structure capable of holding several OSAL IDs.

This is part of the select API and is manipulated using the related API calls. It should not be modified directly by applications.

Note: Math is to determine uint8 array size needed to represent single bit OS\_MAX\_NUM\_OPEN\_FILES objects, + 7 rounds up and 8 is the size of uint8.

#### See also

[OS\\_SelectFdZero\(\)](#), [OS\\_SelectFdAdd\(\)](#), [OS\\_SelectFdClear\(\)](#), [OS\\_SelectFdIsSet\(\)](#)

Definition at line 43 of file osapi-select.h.

### 11.175.2 Field Documentation

#### 11.175.2.1 object\_ids

```
uint8 OS_FdSet::object_ids[ (OS_MAX_NUM_OPEN_FILES+7) / 8 ]
```

Definition at line 45 of file osapi-select.h.

The documentation for this struct was generated from the following file:

- [osal/src/os/inc/osapi-select.h](#)

## 11.176 OS\_file\_prop\_t Struct Reference

OSAL file properties.

```
#include <osapi-file.h>
```

#### Data Fields

- [char Path \[OS\\_MAX\\_PATH\\_LEN\]](#)
- [osal\\_id\\_t User](#)
- [uint8 IsValid](#)

### 11.176.1 Detailed Description

OSAL file properties.

Definition at line 49 of file osapi-file.h.

## 11.176.2 Field Documentation

### 11.176.2.1 IsValid

```
uint8 OS_file_prop_t::IsValid
```

Definition at line 53 of file osapi-file.h.

### 11.176.2.2 Path

```
char OS_file_prop_t::Path[OS_MAX_PATH_LEN]
```

Definition at line 51 of file osapi-file.h.

### 11.176.2.3 User

```
osal_id_t OS_file_prop_t::User
```

Definition at line 52 of file osapi-file.h.

The documentation for this struct was generated from the following file:

- [osal/src/os/inc/osapi-file.h](#)

## 11.177 os\_fsinfo\_t Struct Reference

OSAL file system info.

```
#include <osapi-fsinfo.h>
```

### Data Fields

- **uint32 MaxFds**  
*Total number of file descriptors.*
- **uint32 FreeFds**  
*Total number that are free.*
- **uint32 MaxVolumes**  
*Maximum number of volumes.*
- **uint32 FreeVolumes**  
*Total number of volumes free.*

### 11.177.1 Detailed Description

OSAL file system info.

Definition at line 35 of file osapi-filesystems.h.

### 11.177.2 Field Documentation

#### 11.177.2.1 FreeFds

```
uint32 os_fsinfo_t::FreeFds
```

Total number that are free.

Definition at line 38 of file osapi-filesystems.h.

#### 11.177.2.2 FreeVolumes

```
uint32 os_fsinfo_t::FreeVolumes
```

Total number of volumes free.

Definition at line 40 of file osapi-filesystems.h.

#### 11.177.2.3 MaxFds

```
uint32 os_fsinfo_t::MaxFds
```

Total number of file descriptors.

Definition at line 37 of file osapi-filesystems.h.

#### 11.177.2.4 MaxVolumes

```
uint32 os_fsinfo_t::MaxVolumes
```

Maximum number of volumes.

Definition at line 39 of file osapi-filesystems.h.

The documentation for this struct was generated from the following file:

- [osal/src/os/inc/osapi-filesystems.h](#)

## 11.178 os\_fstat\_t Struct Reference

File system status.

```
#include <osapi-file.h>
```

### Data Fields

- `uint32 FileModeBits`
- `OS_time_t FileTime`
- `size_t FileSize`

#### 11.178.1 Detailed Description

File system status.

#### Note

This used to be directly typedef'ed to the "struct stat" from the C library

Some C libraries (glibc in particular) actually define member names to reference into sub-structures, so attempting to reuse a name like "st\_mtime" might not work.

Definition at line 64 of file osapi-file.h.

#### 11.178.2 Field Documentation

##### 11.178.2.1 FileModeBits

```
uint32 os_fstat_t::FileModeBits
```

Definition at line 66 of file osapi-file.h.

##### 11.178.2.2 FileSize

```
size_t os_fstat_t::FileSize
```

Definition at line 68 of file osapi-file.h.

### 11.178.2.3 FileTime

`OS_time_t os_fstat_t::FileTime`

Definition at line 67 of file osapi-file.h.

The documentation for this struct was generated from the following file:

- [osal/src/os/inc/osapi-file.h](#)

## 11.179 OS\_heap\_prop\_t Struct Reference

OSAL heap properties.

```
#include <osapi-heap.h>
```

### Data Fields

- `size_t free_bytes`
- `osal_blockcount_t free_blocks`
- `size_t largest_free_block`

### 11.179.1 Detailed Description

OSAL heap properties.

#### See also

[OS\\_HeapGetInfo\(\)](#)

Definition at line 36 of file osapi-heap.h.

### 11.179.2 Field Documentation

#### 11.179.2.1 free\_blocks

`osal_blockcount_t OS_heap_prop_t::free_blocks`

Definition at line 39 of file osapi-heap.h.

### 11.179.2.2 free\_bytes

```
size_t OS_heap_prop_t::free_bytes
```

Definition at line 38 of file osapi-heap.h.

### 11.179.2.3 largest\_free\_block

```
size_t OS_heap_prop_t::largest_free_block
```

Definition at line 40 of file osapi-heap.h.

The documentation for this struct was generated from the following file:

- [osal/src/os/inc/osapi-heap.h](#)

## 11.180 OS\_module\_address\_t Struct Reference

OSAL module address properties.

```
#include <osapi-module.h>
```

### Data Fields

- [uint32 valid](#)
- [uint32 flags](#)
- [cpuaddr code\\_address](#)
- [cpuaddr code\\_size](#)
- [cpuaddr data\\_address](#)
- [cpuaddr data\\_size](#)
- [cpuaddr bss\\_address](#)
- [cpuaddr bss\\_size](#)

### 11.180.1 Detailed Description

OSAL module address properties.

Definition at line 78 of file osapi-module.h.

### 11.180.2 Field Documentation

**11.180.2.1 bss\_address**

`cpuaddr OS_module_address_t::bss_address`

Definition at line 86 of file osapi-module.h.

**11.180.2.2 bss\_size**

`cpuaddr OS_module_address_t::bss_size`

Definition at line 87 of file osapi-module.h.

**11.180.2.3 code\_address**

`cpuaddr OS_module_address_t::code_address`

Definition at line 82 of file osapi-module.h.

**11.180.2.4 code\_size**

`cpuaddr OS_module_address_t::code_size`

Definition at line 83 of file osapi-module.h.

**11.180.2.5 data\_address**

`cpuaddr OS_module_address_t::data_address`

Definition at line 84 of file osapi-module.h.

**11.180.2.6 data\_size**

`cpuaddr OS_module_address_t::data_size`

Definition at line 85 of file osapi-module.h.

### 11.180.2.7 flags

`uint32 OS_module_address_t::flags`

Definition at line 81 of file osapi-module.h.

### 11.180.2.8 valid

`uint32 OS_module_address_t::valid`

Definition at line 80 of file osapi-module.h.

The documentation for this struct was generated from the following file:

- `osal/src/os/inc/osapi-module.h`

## 11.181 OS\_module\_prop\_t Struct Reference

OSAL module properties.

```
#include <osapi-module.h>
```

### Data Fields

- `cpuaddr entry_point`
- `cpuaddr host_module_id`
- `char filename [OS_MAX_PATH_LEN]`
- `char name [OS_MAX_API_NAME]`
- `OS_module_address_t addr`

### 11.181.1 Detailed Description

OSAL module properties.

Definition at line 91 of file osapi-module.h.

### 11.181.2 Field Documentation

### 11.181.2.1 addr

```
OS_module_address_t OS_module_prop_t::addr
```

Definition at line 97 of file osapi-module.h.

### 11.181.2.2 entry\_point

```
cpuaddr OS_module_prop_t::entry_point
```

Definition at line 93 of file osapi-module.h.

### 11.181.2.3 filename

```
char OS_module_prop_t::filename[OS_MAX_PATH_LEN]
```

Definition at line 95 of file osapi-module.h.

### 11.181.2.4 host\_module\_id

```
cpuaddr OS_module_prop_t::host_module_id
```

Definition at line 94 of file osapi-module.h.

### 11.181.2.5 name

```
char OS_module_prop_t::name[OS_MAX_API_NAME]
```

Definition at line 96 of file osapi-module.h.

The documentation for this struct was generated from the following file:

- osal/src/os/inc/[osapi-module.h](#)

## 11.182 OS\_mut\_sem\_prop\_t Struct Reference

OSAL mutex properties.

```
#include <osapi-mutex.h>
```

**Data Fields**

- char [name \[OS\\_MAX\\_API\\_NAME\]](#)
- [osal\\_id\\_t creator](#)

**11.182.1 Detailed Description**

OSAL mutex properties.

Definition at line 32 of file osapi-mutex.h.

**11.182.2 Field Documentation****11.182.2.1 creator**

[osal\\_id\\_t OS\\_mut\\_sem\\_prop\\_t::creator](#)

Definition at line 35 of file osapi-mutex.h.

**11.182.2.2 name**

char [OS\\_mut\\_sem\\_prop\\_t::name \[OS\\_MAX\\_API\\_NAME\]](#)

Definition at line 34 of file osapi-mutex.h.

The documentation for this struct was generated from the following file:

- [osal/src/os/inc/osapi-mutex.h](#)

**11.183 OS\_queue\_prop\_t Struct Reference**

OSAL queue properties.

```
#include <osapi-queue.h>
```

**Data Fields**

- char [name \[OS\\_MAX\\_API\\_NAME\]](#)
- [osal\\_id\\_t creator](#)

### 11.183.1 Detailed Description

OSAL queue properties.

Definition at line 32 of file osapi-queue.h.

### 11.183.2 Field Documentation

#### 11.183.2.1 creator

`osal_id_t OS_queue_prop_t::creator`

Definition at line 35 of file osapi-queue.h.

#### 11.183.2.2 name

`char OS_queue_prop_t::name[OS_MAX_API_NAME]`

Definition at line 34 of file osapi-queue.h.

The documentation for this struct was generated from the following file:

- `osal/src/os/inc/osapi-queue.h`

## 11.184 OS\_SockAddr\_t Struct Reference

Encapsulates a generic network address.

```
#include <osapi-sockets.h>
```

### Data Fields

- `size_t ActualLength`  
*Length of the actual address data.*
- `OS_SockAddrData_t AddrData`  
*Abstract Address data.*

### 11.184.1 Detailed Description

Encapsulates a generic network address.

This is just an abstract buffer type that holds a network address. It is allocated for the worst-case size defined by OS\_SOCKADDR\_MAX\_LEN, and the real size is stored within.

Definition at line 109 of file osapi-sockets.h.

### 11.184.2 Field Documentation

#### 11.184.2.1 ActualLength

`size_t OS_SockAddr_t::ActualLength`

Length of the actual address data.

Definition at line 111 of file osapi-sockets.h.

#### 11.184.2.2 AddrData

`OS_SockAddrData_t OS_SockAddr_t::AddrData`

Abstract Address data.

Definition at line 112 of file osapi-sockets.h.

The documentation for this struct was generated from the following file:

- `osal/src/os/inc/osapi-sockets.h`

## 11.185 OS\_SockAddrData\_t Union Reference

Storage buffer for generic network address.

```
#include <osapi-sockets.h>
```

### Data Fields

- `uint8 Buffer [OS_SOCKADDR_MAX_LEN]`  
*Ensures length of at least OS\_SOCKADDR\_MAX\_LEN.*
- `uint32 AlignU32`  
*Ensures uint32 alignment.*
- `void * AlignPtr`  
*Ensures pointer alignment.*

### 11.185.1 Detailed Description

Storage buffer for generic network address.

This is a union type that helps to ensure a minimum alignment value for the data storage, such that it can be cast to the system-specific type without increasing alignment requirements.

Definition at line 95 of file osapi-sockets.h.

### 11.185.2 Field Documentation

#### 11.185.2.1 AlignPtr

```
void* OS_SockAddrData_t::AlignPtr
```

Ensures pointer alignment.

Definition at line 99 of file osapi-sockets.h.

#### 11.185.2.2 AlignU32

```
uint32 OS_SockAddrData_t::AlignU32
```

Ensures uint32 alignment.

Definition at line 98 of file osapi-sockets.h.

#### 11.185.2.3 Buffer

```
uint8 OS_SockAddrData_t::Buffer[OS SOCKADDR_MAX_LEN]
```

Ensures length of at least OS SOCKADDR\_MAX\_LEN.

Definition at line 97 of file osapi-sockets.h.

The documentation for this union was generated from the following file:

- [osal/src/os/inc/osapi-sockets.h](#)

## 11.186 OS\_socket\_prop\_t Struct Reference

Encapsulates socket properties.

```
#include <osapi-sockets.h>
```

### Data Fields

- char [name \[OS\\_MAX\\_API\\_NAME\]](#)  
*Name of the socket.*
- [osal\\_id\\_t creator](#)  
*OSAL TaskID which opened the socket.*

#### 11.186.1 Detailed Description

Encapsulates socket properties.

This is for consistency with other OSAL resource types. Currently no extra properties are exposed here but this could change in a future revision of OSAL as needed.

Definition at line 122 of file osapi-sockets.h.

#### 11.186.2 Field Documentation

##### 11.186.2.1 creator

```
osal_id_t OS_socket_prop_t::creator
```

OSAL TaskID which opened the socket.

Definition at line 125 of file osapi-sockets.h.

##### 11.186.2.2 name

```
char OS_socket_prop_t::name[OS_MAX_API_NAME]
```

Name of the socket.

Definition at line 124 of file osapi-sockets.h.

The documentation for this struct was generated from the following file:

- [osal/src/os/inc/osapi-sockets.h](#)

## 11.187 OS\_static\_symbol\_record\_t Struct Reference

Associates a single symbol name with a memory address.

```
#include <osapi-module.h>
```

### Data Fields

- const char \* [Name](#)
- void(\* [Address](#) )(void)
- const char \* [Module](#)

#### 11.187.1 Detailed Description

Associates a single symbol name with a memory address.

If the OS\_STATIC\_SYMBOL\_TABLE feature is enabled, then an array of these structures should be provided by the application. When the application needs to find a symbol address, the static table will be checked in addition to (or instead of) the OS/library-provided lookup function.

This static symbol allows systems that do not implement dynamic module loading to maintain the same semantics as dynamically loaded modules.

Definition at line 113 of file osapi-module.h.

#### 11.187.2 Field Documentation

##### 11.187.2.1 Address

```
void(* OS_static_symbol_record_t::Address) (void)
```

Definition at line 116 of file osapi-module.h.

##### 11.187.2.2 Module

```
const char* OS_static_symbol_record_t::Module
```

Definition at line 117 of file osapi-module.h.

### 11.187.2.3 Name

```
const char* OS_static_symbol_record_t::Name
```

Definition at line 115 of file osapi-module.h.

The documentation for this struct was generated from the following file:

- [osal/src/os/inc/osapi-module.h](#)

## 11.188 OS\_statvfs\_t Struct Reference

```
#include <osapi-filesystem.h>
```

### Data Fields

- `size_t block_size`
- `osal_blockcount_t total_blocks`
- `osal_blockcount_t blocks_free`

### 11.188.1 Detailed Description

Definition at line 49 of file osapi-filesystem.h.

### 11.188.2 Field Documentation

#### 11.188.2.1 block\_size

```
size_t OS_statvfs_t::block_size
```

Block size of underlying FS

Definition at line 51 of file osapi-filesystem.h.

#### 11.188.2.2 blocks\_free

```
osal_blockcount_t OS_statvfs_t::blocks_free
```

Available blocks in underlying FS

Definition at line 53 of file osapi-filesystem.h.

### 11.188.2.3 total\_blocks

```
osal_blockcount_t OS_statvfs_t::total_blocks
```

Total blocks in underlying FS

Definition at line 52 of file osapi-filesystems.h.

The documentation for this struct was generated from the following file:

- [osal/src/os/inc/osapi-filesystems.h](#)

## 11.189 OS\_task\_prop\_t Struct Reference

OSAL task properties.

```
#include <osapi-task.h>
```

### Data Fields

- [char name \[OS\\_MAX\\_API\\_NAME\]](#)
- [osal\\_id\\_t creator](#)
- [size\\_t stack\\_size](#)
- [osal\\_priority\\_t priority](#)

### 11.189.1 Detailed Description

OSAL task properties.

Definition at line 57 of file osapi-task.h.

### 11.189.2 Field Documentation

#### 11.189.2.1 creator

```
osal_id_t OS_task_prop_t::creator
```

Definition at line 60 of file osapi-task.h.

### 11.189.2.2 name

```
char OS_task_prop_t::name[OS_MAX_API_NAME]
```

Definition at line 59 of file osapi-task.h.

### 11.189.2.3 priority

```
osal_priority_t OS_task_prop_t::priority
```

Definition at line 62 of file osapi-task.h.

### 11.189.2.4 stack\_size

```
size_t OS_task_prop_t::stack_size
```

Definition at line 61 of file osapi-task.h.

The documentation for this struct was generated from the following file:

- [osal/src/os/inc/osapi-task.h](#)

## 11.190 OS\_time\_t Struct Reference

OSAL time interval structure.

```
#include <osapi-clock.h>
```

### Data Fields

- [int64 ticks](#)

### 11.190.1 Detailed Description

OSAL time interval structure.

This is used to represent a basic time interval.

When used with OS\_GetLocalTime/OS\_SetLocalTime, this represents the interval from the OS's epoch point, typically 01 Jan 1970 00:00:00 UTC on systems that have a persistent real time clock (RTC), or the system boot time if there is no RTC available.

Applications should not directly access fields within this structure, as the definition may change in future versions of OSAL. Instead, applications should use the accessor/conversion methods defined below.

Definition at line 45 of file osapi-clock.h.

## 11.190.2 Field Documentation

## 11.190.2.1 ticks

```
int64 OS_time_t::ticks
```

Ticks elapsed since reference point

Definition at line 47 of file osapi-clock.h.

Referenced by OS\_TimeAdd(), OS\_TimeAssembleFromMicroseconds(), OS\_TimeAssembleFromMilliseconds(), OS\_TimeAssembleFromNanoseconds(), OS\_TimeAssembleFromSubseconds(), OS\_TimeGetFractionalPart(), OS\_TimeGetTotalMicroseconds(), OS\_TimeGetTotalMilliseconds(), OS\_TimeGetTotalNanoseconds(), OS\_TimeGetTotalSeconds(), and OS\_TimeSubtract().

The documentation for this struct was generated from the following file:

- [osal/src/os/inc/osapi-clock.h](#)

## 11.191 OS\_timebase\_prop\_t Struct Reference

Time base properties.

```
#include <osapi-timebase.h>
```

## Data Fields

- `char name [OS_MAX_API_NAME]`
- `osal_id_t creator`
- `uint32 nominal_interval_time`
- `uint32 freerun_time`
- `uint32 accuracy`

## 11.191.1 Detailed Description

Time base properties.

Definition at line 37 of file osapi-timebase.h.

## 11.191.2 Field Documentation

### 11.191.2.1 accuracy

```
uint32 OS_timebase_prop_t::accuracy
```

Definition at line 43 of file osapi-timebase.h.

### 11.191.2.2 creator

```
osal_id_t OS_timebase_prop_t::creator
```

Definition at line 40 of file osapi-timebase.h.

### 11.191.2.3 freerun\_time

```
uint32 OS_timebase_prop_t::freerun_time
```

Definition at line 42 of file osapi-timebase.h.

### 11.191.2.4 name

```
char OS_timebase_prop_t::name[OS_MAX_API_NAME]
```

Definition at line 39 of file osapi-timebase.h.

### 11.191.2.5 nominal\_interval\_time

```
uint32 OS_timebase_prop_t::nominal_interval_time
```

Definition at line 41 of file osapi-timebase.h.

The documentation for this struct was generated from the following file:

- osal/src/os/inc/[osapi-timebase.h](#)

## 11.192 OS\_timer\_prop\_t Struct Reference

Timer properties.

```
#include <osapi-timer.h>
```

## Data Fields

- `char name [OS_MAX_API_NAME]`
- `osal_id_t creator`
- `uint32 start_time`
- `uint32 interval_time`
- `uint32 accuracy`

### 11.192.1 Detailed Description

Timer properties.

Definition at line 37 of file osapi-timer.h.

### 11.192.2 Field Documentation

#### 11.192.2.1 accuracy

`uint32 OS_timer_prop_t::accuracy`

Definition at line 43 of file osapi-timer.h.

#### 11.192.2.2 creator

`osal_id_t OS_timer_prop_t::creator`

Definition at line 40 of file osapi-timer.h.

#### 11.192.2.3 interval\_time

`uint32 OS_timer_prop_t::interval_time`

Definition at line 42 of file osapi-timer.h.

#### 11.192.2.4 name

`char OS_timer_prop_t::name [OS_MAX_API_NAME]`

Definition at line 39 of file osapi-timer.h.

### 11.192.2.5 start\_time

```
uint32 OS_timer_prop_t::start_time
```

Definition at line 41 of file osapi-timer.h.

The documentation for this struct was generated from the following file:

- [osal/src/os/inc/osapi-timer.h](#)

## 12 File Documentation

### 12.1 [apps/ds/docs/dox\\_src/cfs\\_ds.dox](#) File Reference

### 12.2 [apps/ds/fsw/mission\\_inc/ds\\_perfids.h](#) File Reference

#### Macros

- `#define DS_APPMAIN_PERF_ID 38`

*Main application performance ID.*

#### 12.2.1 Detailed Description

Define DS Performance IDs

### 12.3 [apps/ds/fsw/platform\\_inc/ds\\_msgids.h](#) File Reference

#### Macros

- `#define DS_CMD_MID 0x18BB`  
*DS Ground Commands Message ID.*
- `#define DS_SEND_HK_MID 0x18BC`  
*DS Send Hk Data Cmd Message ID.*
- `#define DS_HK_TLM_MID 0x08B8`  
*DS Hk Telemetry Message ID.*
- `#define DS_DIAG_TLM_MID 0x08B9`  
*DS File Info Telemetry Message ID.*
- `#define DS_COMP_TLM_MID 0x08BA`  
*DS Completed File Info Telemetry Message ID.*

#### 12.3.1 Detailed Description

The CFS Data Storage (DS) Application Message IDs header file

## 12.4 apps/ds/fsw/platform\_inc/ds\_platform\_cfg.h File Reference

### Macros

- #define DS\_DESTINATION\_TBL\_NAME "FILE\_TBL"  
*Destination File Table – logical table name.*
- #define DS\_DEF\_DEST\_FILENAME "/cf/ds\_file\_tbl.tbl"  
*Destination File Table – default table filename.*
- #define DS\_DEST\_FILE\_CNT 16  
*Destination File Table – number of files.*
- #define DS\_PATHNAME\_BUFSIZE OS\_MAX\_PATH\_LEN  
*Destination File Table – pathname buffer size.*
- #define DS\_BASENAME\_BUFSIZE OS\_MAX\_PATH\_LEN  
*Destination File Table – basename buffer size.*
- #define DS\_EXTENSION\_BUFSIZE 8  
*Destination File Table – extension buffer size.*
- #define DS\_FILTER\_TBL\_NAME "FILTER\_TBL"  
*Packet Filter Table – logical table name.*
- #define DS\_DEF\_FILTER\_FILENAME "/cf/ds\_filter\_tbl.tbl"  
*Packet Filter Table – default table filename.*
- #define DS\_PACKETS\_IN\_FILTER\_TABLE 256  
*Packet Filter Table – number of packets.*
- #define DS\_FILTERS\_PER\_PACKET 4  
*Packet Filter Table – filters per packet.*
- #define DS\_DESCRIPTOR\_BUFSIZE 32  
*Common Table File – descriptor text buffer size.*
- #define DS\_SEQUENCE\_DIGITS 8  
*Filenname Sequence Count – number of digits.*
- #define DS\_MAX\_SEQUENCE\_COUNT 99999999  
*Filenname Sequence Count – max counter value.*
- #define DS\_TOTAL\_FNAME\_BUFSIZE OS\_MAX\_PATH\_LEN  
*Data Storage File – total filename size.*
- #define DS\_FILE\_HDR\_SUBTYPE 12345  
*Data Storage File – cFE file header sub-type.*
- #define DS\_FILE\_HDR\_DESCRIPTION "DS data storage file"  
*Data Storage File – cFE file header description.*
- #define DS\_FILE\_MIN\_SIZE\_LIMIT 1024  
*Data Storage File – minimum size limit.*
- #define DS\_FILE\_MIN\_AGE\_LIMIT 60  
*Data Storage File – minimum age limit.*
- #define DS\_APP\_PIPE\_NAME "DS\_CMD\_PIPE"  
*Application Pipe Name.*
- #define DS\_APP\_PIPE\_DEPTH 45  
*Application Pipe Depth.*
- #define DS\_MAKE\_TABLES\_CRITICAL 0  
*Make DS Tables Critical.*
- #define DS\_SECS\_PER\_HK\_CYCLE 4

- `#define DS_DEF_ENABLE_STATE 1`  
*Default DS Packet Processor State.*
- `#define DS_CDS_ENABLE_STATE 1`  
*Save DS Packet Processor State in Critical Data Store.*
- `#define DS_MISSION_REV 0`  
*Mission specific version number for DS application.*
- `#define DS_FILE_HEADER_TYPE 1`  
*File Header Type Selection.*
- `#define DS_MOVE_FILES true`  
*Move Files to Downlink Directory After Close Selection.*
- `#define DS_PER_PACKET_PIPE_LIMIT 45`  
*Application Per Packet Pipe Limit.*

#### 12.4.1 Detailed Description

The CFS Data Storage (DS) Application platform configuration header file

### 12.5 apps/ds/fsw/src/ds\_app.c File Reference

```
#include "cfe.h"
#include "ds_perfids.h"
#include "ds_msgids.h"
#include "ds_platform_cfg.h"
#include "ds_verify.h"
#include "ds_appdefs.h"
#include "ds_msg.h"
#include "ds_app.h"
#include "ds_cmds.h"
#include "ds_file.h"
#include "ds_table.h"
#include "ds_events.h"
#include "ds_msgdefs.h"
#include "ds_version.h"
#include <stdio.h>
```

#### Functions

- `void DS_AppMain (void)`  
*CFS Data Storage (DS) application entry point.*
- `int32 DS_AppInitialize (void)`  
*Application initialization function.*
- `void DS_AppProcessMsg (const CFE_SB_Buffer_t *BufPtr)`  
*Software Bus message handler.*
- `void DS_AppProcessCmd (const CFE_SB_Buffer_t *BufPtr)`  
*Application ground command handler.*
- `void DS_AppProcessHK (void)`  
*Application housekeeping request command handler.*
- `void DS_AppStorePacket (CFE_SB_MsgId_t MessageID, const CFE_SB_Buffer_t *BufPtr)`  
*Application packet storage pre-processor.*

## Variables

- [DS\\_AppData\\_t DS\\_AppData](#)  
*DS global data structure reference.*

### 12.5.1 Detailed Description

The CFS Data Storage (DS) Application file containing the application initialization routines, the main routine and the command interface.

### 12.5.2 Function Documentation

#### 12.5.2.1 DS\_AppInitialize()

```
int32 DS_AppInitialize (
    void )
```

Application initialization function.

##### Description

Performs the following startup initialization:

- register DS application for cFE Event Services
- create a cFE Software Bus message pipe
- subscribe to DS commands via message pipe
- register DS filter and file destination tables
- load default filter and file destination tables
- subscribe to packets referenced in DS filter table
- generate startup initialization event message

##### Assumptions, External Events, and Notes:

(none)

##### Returns

Execution status, see [cFE Return Code Defines](#)

##### Return values


<a href="#">CFE_SUCCESS</a>	Successful execution.
-----------------------------	-----------------------

Definition at line 178 of file ds\_app.c.

References DS\_AppData\_t::AppEnableState, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_EventType\_INFORMATION, CFE\_EVS\_Register(), CFE\_EVS\_SendEvent(), CFE\_SB\_CreatePipe(), CFE\_SB\_Subscribe(), CFE\_SB\_ValueToMsgId(), CFE\_SUCCESS, DS\_APP\_PIPE\_DEPTH, DS\_APP\_PIPE\_NAME, DS\_CMD\_MID, DS\_DEF\_ENABLE\_STATE, DS\_DEST\_FILE\_CNT, DS\_INIT\_EID, DS\_INIT\_ERR\_EID, DS\_MAJOR\_VERSION, DS\_MINOR\_VERSION, DS\_MISSION\_REV, DS\_REVISION, DS\_SEND\_HK\_MID, DS\_TableCreateCDS(), DS\_TableInit(), DS\_AppFileStatus\_t::FileHandle, DS\_AppData\_t::FileStatus, DS\_AppData\_t::InputPipe, and OS\_OBJECT\_ID\_UNDEFINED.

Referenced by DS\_AppMain().

Here is the call graph for this function:



### 12.5.2.2 DS\_AppMain()

```
void DS_AppMain (
    void )
```

CFS Data Storage (DS) application entry point.

#### Description

DS application entry point and main process loop.


#### Assumptions, External Events, and Notes:

None

Definition at line 61 of file ds\_app.c.

References CFE\_ES\_ExitApp(), CFE\_ES\_PerfLogEntry, CFE\_ES\_PerfLogExit, CFE\_ES\_RunLoop(), CFE\_ES\_RunStatus\_APP\_ERROR, CFE\_ES\_RunStatus\_APP\_RUN, CFE\_ES\_WriteToSysLog(), CFE\_EVS\_EventType\_CRITICAL, CFE\_EVS\_SendEvent(), CFE\_SB\_ReceiveBuffer(), CFE\_SB\_TIME\_OUT, CFE\_SUCCESS, DS\_AppInitialize(), DS\_APPMAIN\_PERF\_ID, DS\_AppProcessMsg(), DS\_EXIT\_ERR\_EID, DS\_FileTestAge(), DS\_SB\_TIMEOUT, DS\_SECS\_PER\_TIMEOUT, DS\_TableManageDestFile(), DS\_TableManageFilter(), and DS\_AppData\_t::InputPipe.

Here is the call graph for this function:



### 12.5.2.3 DS\_AppProcessCmd()

```
void DS_AppProcessCmd (
    const CFE_SB_Buffer_t * BufPtr )
```

Application ground command handler.

#### Description

Call command code specific DS command handler function Generate command error event for unknown command codes

#### Assumptions, External Events, and Notes:

(none)

#### Parameters


in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

Definition at line 348 of file ds\_app.c.

References CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetFcnCode(), DS\_AppData\_t::CmdRejectedCounter, DS\_ADD\_MID\_CC, DS\_CLOSE\_ALL\_CC, DS\_CLOSE\_FILE\_CC, DS\_CMD\_CODE\_ERR\_EID, DS\_CMD\_MID, DS\_CmdAddMID(), DS\_CmdCloseAll(), DS\_CmdCloseFile(), DS\_CmdGetFileInfo(), DS\_CmdNoop(), DS\_CmdReset(), DS\_CmdSetAppState(), DS\_CmdSetDestAge(), DS\_CmdSetDestBase(), DS\_CmdSetDestCount(), DS\_CmdSetDestExt(), DS\_CmdSetDestPath(), DS\_CmdSetDestSize(), DS\_CmdSetDestState(), DS\_CmdSetDestType(), DS\_CmdSetFilterFile(), DS\_CmdSetFilterParms(), DS\_CmdSetFilterType(), DS\_GET\_FILE\_INFO\_CC, DS\_N\_OOP\_CC, DS\_RESET\_CC, DS\_SET\_APP\_STATE\_CC, DS\_SET\_DEST AGE\_CC, DS\_SET\_DEST\_BASE\_CC, DS\_SET\_DEST\_COUNT\_CC, DS\_SET\_DEST\_EXT\_CC, DS\_SET\_DEST\_PATH\_CC, DS\_SET\_DEST\_SIZE\_CC, DS\_SET\_DEST\_STATE\_CC, DS\_SET\_DEST\_TYPE\_CC, DS\_SET\_FILTER\_FILE\_CC, DS\_SET\_FILTER\_PARMS\_CC, DS\_SET\_FILTER\_TYPE\_CC, and CFE\_SB\_Msg::Msg.

Referenced by DS\_AppProcessMsg().

Here is the call graph for this function:



#### 12.5.2.4 DS\_AppProcessHK()

```
void DS_AppProcessHK (
```

```
    void  )
```

Application housekeeping request command handler.

#### Description

Check with cFE Table Services for table updates Generate application housekeeping telemetry packet

#### Assumptions, External Events, and Notes:

(none)

#### See also


[DS\\_HkPacket\\_t](#)

Definition at line 503 of file ds\_app.c.

References DS\_AppData\_t::AppEnableState, DS\_HkPacket\_t::AppEnableState, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MISSION\_TBL\_MAX\_NAME\_LENGTH, CFE\_MSG\_Init(), CFE\_SB\_TimeStampMsg(), CFE\_SB\_TransmitMsg(), CFE\_SB\_ValueToMsgId(), CFE\_SUCCESS, CFE\_TBL\_GetInfo(), DS\_AppData\_t::CmdAcceptedCounter, DS\_HkPacket\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_HkPacket\_t::CmdRejectedCounter, DS\_AppData\_t::DestTblErrCounter, DS\_HkPacket\_t::DestTblErrCounter, DS\_AppData\_t::DestTblLoadCounter, DS\_HkPacket\_t::DestTblLoadCounter, DS\_AppData\_t::DisabledPktCounter, DS\_HkPacket\_t::DisabledPktCounter, DS\_APPHK\_FILTER\_TBL\_ERR\_EID, DS\_APPHK\_FILTER\_TBL\_PRINT\_ERR\_EID, DS\_DEST\_FILE\_CNT, DS\_FileTestAge(), DS\_FILTER\_TBL\_NAME, DS\_HK\_TLM\_MID, DS\_SECS\_PER\_HK\_CYCLE, DS\_TableManageDestFile(), DS\_TableManageFilter(), DS\_AppFileStatus\_t::FileGrowth, DS\_AppFileStatus\_t::FileRate, DS\_AppData\_t::FileStatus, DS\_AppData\_t::FileUpdateCounter, DS\_HkPacket\_t::FileUpdateCounter, DS\_AppData\_t::FileUpdateErrCounter, DS\_HkPacket\_t::FileUpdateErrCounter, DS\_AppData\_t::FileWriteCounter, DS\_HkPacket\_t::FileWriteCounter, DS\_AppData\_t::FileWriteErrCounter, DS\_HkPacket\_t::FileWriteErrCounter, DS\_AppData\_t::FilteredPktCounter, DS\_HkPacket\_t::FilteredPktCounter, DS\_AppData\_t::FilterTblErrCounter, DS\_HkPacket\_t::FilterTblErrCounter, DS\_HkPacket\_t::FilterTblFilename, DS\_AppData\_t::FilterTblLoadCounter, DS\_HkPacket\_t::FilterTblLoadCounter, DS\_AppData\_t::IgnoredPktCounter, DS\_HkPacket\_t::IgnoredPktCounter, CFE\_TBL\_Info::LastFileLoaded, OS\_MAX\_PATH\_LEN, DS\_AppData\_t::PassedPktCounter, DS\_HkPacket\_t::PassedPktCounter, and DS\_HkPacket\_t::TlmHeader.

Referenced by DS\_AppProcessMsg().

Here is the call graph for this function:



### 12.5.2.5 DS\_AppProcessMsg()

```
void DS_AppProcessMsg (
    const CFE_SB_Buffer_t * BufPtr )
```

Software Bus message handler.

#### Description

Process packets received via Software Bus message pipe

- may call application housekeeping request command handler
- may call 1Hz wakeup command handler (if enabled)
- may call application ground command handler All packets are processed for possible data storage

#### Assumptions, External Events, and Notes:

(none)

**Parameters**


in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

Definition at line 286 of file ds\_app.c.

References CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetMsgId(), CFE\_MSG\_GetSize(), CFE\_SB\_INVALID\_MSG\_ID, CFE\_SB\_MsgIdToValue(), DS\_AppProcessCmd(), DS\_AppProcessHK(), DS\_AppStorePacket(), DS\_CMD\_MID, DS\_HK\_REQUEST\_ERR\_EID, DS\_INDEX\_NONE, DS\_SEND\_HK\_MID, DS\_TableFindMsgID(), and CFE\_SB\_Msg::Msg.

Referenced by DS\_AppMain().

Here is the call graph for this function:



### 12.5.2.6 DS\_AppStorePacket()

```
void DS_AppStorePacket (
```

```
CFE_SB_MsgId_t MessageID,  
const CFE_SB_Buffer_t * BufPtr )
```

## Application packet storage pre-processor.

## Description

This function verifies that DS storage is enabled and that both DS tables (filter and file) are loaded before calling the file storage function ([DS\\_FileStorePacket](#)).

## **Assumptions, External Events, and Notes:**

(none)

## Parameters

in	<i>MessageID</i>	Message ID
in	<i>BufPtr</i>	Software Bus message pointer

#### See also


## CFE\_SB\_Buffer\_t\*

Definition at line 620 of file ds\_app.c.

References DS\_AppData\_t::AppEnableState, DS\_AppData\_t::DestFileTblPtr, DS\_AppData\_t::DisabledPktCounter, DS\_DISABLED, DS\_FileStorePacket(), DS\_AppData\_t::FilterTblPtr, and DS\_AppData\_t::IgnoredPktCounter.

Referenced by DS\_AppProcessMsg().

Here is the call graph for this function:



### 12.5.3 Variable Documentation

#### 12.5.3.1 DS\_AppData

`DS_AppData_t DS_AppData`

DS global data structure reference.

Definition at line 53 of file `ds_app.c`.

Referenced by `DS_CmdAddMID()`, `DS_CmdCloseAll()`, `DS_CmdCloseFile()`, `DS_CmdGetFileInfo()`, `DS_CmdNoop()`, `DS_CmdReset()`, `DS_CmdSetAppState()`, `DS_CmdSetDestAge()`, `DS_CmdSetDestBase()`, `DS_CmdSetDestCount()`, `DS_CmdSetDestExt()`, `DS_CmdSetDestPath()`, `DS_CmdSetDestSize()`, `DS_CmdSetDestState()`, `DS_CmdSetDestType()`, `DS_CmdSetFilterFile()`, `DS_CmdSetFilterParms()`, `DS_CmdSetFilterType()`, `DS_FileCloseDest()`, `DS_FileCreateDest()`, `DS_FileCreateName()`, `DS_FileSetupWrite()`, `DS_FileStorePacket()`, `DS_FileTestAge()`, `DS_FileUpdateHeader()`, `DS_FileWriteData()`, `DS_FileWriteError()`, `DS_FileWriteHeader()`, `DS_TableAddMsgID()`, `DS_TableCreateCDS()`, `DS_TableCreateHash()`, `DS_TableFindMsgID()`, `DS_TableInit()`, `DS_TableManageDestFile()`, `DS_TableManageFilter()`, `DS_TableSubscribe()`, `DS_TableUnsubscribe()`, and `DS_TableUpdateCDS()`.

## 12.6 apps/ds/fsw/src/ds\_app.h File Reference

```
#include "cfe.h"
#include "ds_appdefs.h"
#include "ds_platform_cfg.h"
#include "ds_table.h"
```

### Data Structures

- struct `DS_AppFileStatus_t`  
*Current state of destination files.*
- struct `DS_AppData_t`  
*DS global data structure definition.*

### Macros

- `#define DS_SB_TIMEOUT 1000`  
*Wakeup for DS.*
- `#define DS_SECS_PER_TIMEOUT (DS_SB_TIMEOUT / 1000)`

## Functions

- void [DS\\_AppMain](#) (void)  
*CFS Data Storage (DS) application entry point.*
- int32 [DS\\_ApplInitialize](#) (void)  
*Application initialization function.*
- void [DS\\_AppProcessMsg](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)  
*Software Bus message handler.*
- void [DS\\_AppProcessCmd](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)  
*Application ground command handler.*
- void [DS\\_AppProcessHK](#) (void)  
*Application housekeeping request command handler.*
- void [DS\\_AppStorePacket](#) ([CFE\\_SB\\_MsgId\\_t](#) MessageID, const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)  
*Application packet storage pre-processor.*

## Variables

- [DS\\_AppData\\_t DS\\_AppData](#)  
*DS global data structure reference.*

### 12.6.1 Detailed Description

The CFS Data Storage (DS) Application header file

### 12.6.2 Macro Definition Documentation

#### 12.6.2.1 [DS\\_SB\\_TIMEOUT](#)

```
#define DS_SB_TIMEOUT 1000
```

Wakeup for DS.

#### Description

Wakes up DS every 1 second for routine maintenance whether a message was received or not.

Definition at line 48 of file `ds_app.h`.

Referenced by `DS_AppMain()`.

### 12.6.2.2 DS\_SECS\_PER\_TIMEOUT

```
#define DS_SECS_PER_TIMEOUT (DS_SB_TIMEOUT / 1000)
```

Definition at line 49 of file ds\_app.h.

Referenced by DS\_AppMain().

### 12.6.3 Function Documentation

#### 12.6.3.1 DS\_AppInitialize()

```
int32 DS_AppInitialize (
    void )
```

Application initialization function.

##### Description

Performs the following startup initialization:

- register DS application for cFE Event Services
- create a cFE Software Bus message pipe
- subscribe to DS commands via message pipe
- register DS filter and file destination tables
- load default filter and file destination tables
- subscribe to packets referenced in DS filter table
- generate startup initialization event message

##### Assumptions, External Events, and Notes:

(none)

##### Returns

Execution status, see [cFE Return Code Defines](#)

##### Return values

<a href="#">CFE_SUCCESS</a>	Successful execution.
-----------------------------	-----------------------


Definition at line 178 of file ds\_app.c.

References DS\_AppData\_t::AppEnableState, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_EventType\_INFORMATION, CFE\_EVS\_Register(), CFE\_EVS\_SendEvent(), CFE\_SB\_CreatePipe(), CFE\_SB\_Subscribe(), CFE\_SB\_Value

ToMsgd(), CFE\_SUCCESS, DS\_APP\_PIPE\_DEPTH, DS\_APP\_PIPE\_NAME, DS\_CMD\_MID, DS\_DEF\_ENABLE\_STATE, DS\_DEST\_FILE\_CNT, DS\_INIT\_EID, DS\_INIT\_ERR\_EID, DS\_MAJOR\_VERSION, DS\_MINOR\_VERSION, DS\_MISSION\_REV, DS\_REVISION, DS\_SEND\_HK\_MID, DS\_TableCreateCDS(), DS\_TableInit(), DS\_AppFileStatus\_t::FileHandle, DS\_AppData\_t::FileStatus, DS\_AppData\_t::InputPipe, and OS\_OBJECT\_ID\_UNDEFINED.

Referenced by DS\_AppMain().

Here is the call graph for this function:



### 12.6.3.2 DS\_AppMain()

```
void DS_AppMain ( void )
```

## CFS Data Storage (DS) application entry point.

## Description

DS application entry point and main process loop.


### **Assumptions, External Events, and Notes:**

None

Definition at line 61 of file ds\_app.c.

References CFE\_ES\_ExitApp(), CFE\_ES\_PerfLogEntry, CFE\_ES\_PerfLogExit, CFE\_ES\_RunLoop(), CFE\_ES\_RunStatus\_APP\_ERROR, CFE\_ES\_RunStatus\_APP\_RUN, CFE\_ES\_WriteToSysLog(), CFE\_EVS\_EventType\_CRITICAL, CFE\_EVS\_SendEvent(), CFE\_SB\_ReceiveBuffer(), CFE\_SB\_TIME\_OUT, CFE\_SUCCESS, DS\_AppInitialize(), DS\_APPMAIN\_PERF\_ID, DS\_AppProcessMsg(), DS\_EXIT\_ERR\_EID, DS\_FileTestAge(), DS\_SB\_TIMEOUT, DS\_SECS\_PER\_TIMEOUT, DS\_TableManageDestFile(), DS\_TableManageFilter(), and DS\_AppData\_t::InputPipe.

Here is the call graph for this function:



### 12.6.3.3 DS\_AppProcessCmd()

```
void DS_AppProcessCmd (
    const CFE_SB_Buffer_t * BufPtr )
```

Application ground command handler.

#### Description

Call command code specific DS command handler function Generate command error event for unknown command codes

#### Assumptions, External Events, and Notes:

(none)

#### Parameters


in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

Definition at line 348 of file ds\_app.c.

References CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetFcnCode(), DS\_AppData\_t::CmdRejectedCounter, DS\_ADD\_MID\_CC, DS\_CLOSE\_ALL\_CC, DS\_CLOSE\_FILE\_CC, DS\_CMD\_CODE\_ERR\_EID, DS\_CMD\_MID, DS\_CmdAddMID(), DS\_CmdCloseAll(), DS\_CmdCloseFile(), DS\_CmdGetFileInfo(), DS\_CmdNoop(), DS\_CmdReset(), DS\_CmdSetAppState(), DS\_CmdSetDestAge(), DS\_CmdSetDestBase(), DS\_CmdSetDestCount(), DS\_CmdSetDestExt(), DS\_CmdSetDestPath(), DS\_CmdSetDestSize(), DS\_CmdSetDestState(), DS\_CmdSetDestType(), DS\_CmdSetFilterFile(), DS\_CmdSetFilterParms(), DS\_CmdSetFilterType(), DS\_GET\_FILE\_INFO\_CC, DS\_N\_OOP\_CC, DS\_RESET\_CC, DS\_SET\_APP\_STATE\_CC, DS\_SET\_DEST AGE\_CC, DS\_SET\_DEST\_BASE\_CC, DS\_SET\_DEST\_COUNT\_CC, DS\_SET\_DEST\_EXT\_CC, DS\_SET\_DEST\_PATH\_CC, DS\_SET\_DEST\_SIZE\_CC, DS\_SET\_DEST\_STATE\_CC, DS\_SET\_DEST\_TYPE\_CC, DS\_SET\_FILTER\_FILE\_CC, DS\_SET\_FILTER\_PARMS\_CC, DS\_SET\_FILTER\_TYPE\_CC, and CFE\_SB\_Msg::Msg.

Referenced by DS\_AppProcessMsg().

Here is the call graph for this function:



#### 12.6.3.4 DS\_AppProcessHK()

```
void DS_AppProcessHK (
```

```
    void  )
```

Application housekeeping request command handler.

#### Description

Check with cFE Table Services for table updates Generate application housekeeping telemetry packet

#### Assumptions, External Events, and Notes:

(none)

#### See also


[DS\\_HkPacket\\_t](#)

Definition at line 503 of file `ds_app.c`.

References DS\_AppData\_t::AppEnableState, DS\_HkPacket\_t::AppEnableState, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MISSION\_TBL\_MAX\_NAME\_LENGTH, CFE\_MSG\_Init(), CFE\_SB\_TimeStampMsg(), CFE\_SB\_TransmitMsg(), CFE\_SB\_ValueToMsgId(), CFE\_SUCCESS, CFE\_TBL\_GetInfo(), DS\_AppData\_t::CmdAcceptedCounter, DS\_HkPacket\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_HkPacket\_t::CmdRejectedCounter, DS\_AppData\_t::DestTblErrCounter, DS\_HkPacket\_t::DestTblErrCounter, DS\_AppData\_t::DestTblLoadCounter, DS\_HkPacket\_t::DestTblLoadCounter, DS\_AppData\_t::DisabledPktCounter, DS\_HkPacket\_t::DisabledPktCounter, DS\_APPHK\_FILTER\_TBL\_ERR\_EID, DS\_APPHK\_FILTER\_TBL\_PRINT\_ERR\_EID, DS\_DEST\_FILE\_CNT, DS\_FileTestAge(), DS\_FILTER\_TBL\_NAME, DS\_HK\_TLM\_MID, DS\_SECS\_PER\_HK\_CYCLE, DS\_TableManageDestFile(), DS\_TableManageFilter(), DS\_AppFileStatus\_t::FileGrowth, DS\_AppFileStatus\_t::FileRate, DS\_AppData\_t::FileStatus, DS\_AppData\_t::FileUpdateCounter, DS\_HkPacket\_t::FileUpdateCounter, DS\_AppData\_t::FileUpdateErrCounter, DS\_HkPacket\_t::FileUpdateErrCounter, DS\_AppData\_t::FileWriteCounter, DS\_HkPacket\_t::FileWriteCounter, DS\_AppData\_t::FileWriteErrCounter, DS\_HkPacket\_t::FileWriteErrCounter, DS\_AppData\_t::FilteredPktCounter, DS\_HkPacket\_t::FilteredPktCounter, DS\_AppData\_t::FilterTblErrCounter, DS\_HkPacket\_t::FilterTblErrCounter, DS\_HkPacket\_t::FilterTblFilename, DS\_AppData\_t::FilterTblLoadCounter, DS\_HkPacket\_t::FilterTblLoadCounter, DS\_AppData\_t::IgnoredPktCounter, DS\_HkPacket\_t::IgnoredPktCounter, CFE\_TBL\_Info::LastFileLoaded, OS\_MAX\_PATH\_LEN, DS\_AppData\_t::PassedPktCounter, DS\_HkPacket\_t::PassedPktCounter, and DS\_HkPacket\_t::TlmHeader.

Referenced by DS\_AppProcessMsg().

Here is the call graph for this function:



### 12.6.3.5 DS\_AppProcessMsg()

```
void DS_AppProcessMsg (
    const CFE_SB_Buffer_t * BufPtr )
```

Software Bus message handler.

#### Description

Process packets received via Software Bus message pipe

- may call application housekeeping request command handler
- may call 1Hz wakeup command handler (if enabled)
- may call application ground command handler All packets are processed for possible data storage

#### Assumptions, External Events, and Notes:

(none)

**Parameters**


in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

Definition at line 286 of file ds\_app.c.

References CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetMsgId(), CFE\_MSG\_GetSize(), CFE\_SB\_INVALID\_MSG\_ID, CFE\_SB\_MsgIdToValue(), DS\_AppProcessCmd(), DS\_AppProcessHK(), DS\_AppStorePacket(), DS\_CMD\_MID, DS\_HK\_REQUEST\_ERR\_EID, DS\_INDEX\_NONE, DS\_SEND\_HK\_MID, DS\_TableFindMsgID(), and CFE\_SB\_Msg::Msg.

Referenced by DS\_AppMain().

Here is the call graph for this function:



### 12.6.3.6 DS\_AppStorePacket()

```
void DS_AppStorePacket (
```

```
CFE_SB_MsgId_t MessageID,  
const CFE_SB_Buffer_t * BufPtr )
```

## Application packet storage pre-processor.

## Description

This function verifies that DS storage is enabled and that both DS tables (filter and file) are loaded before calling the file storage function ([DS\\_FileStorePacket](#)).

## **Assumptions, External Events, and Notes:**

(none)

## Parameters

in	<i>MessageID</i>	Message ID
in	<i>BufPtr</i>	Software Bus message pointer

#### See also


## CFE\_SB\_Buffer\_t\*

Definition at line 620 of file ds\_app.c.

References DS\_AppData\_t::AppEnableState, DS\_AppData\_t::DestFileTblPtr, DS\_AppData\_t::DisabledPktCounter, DS\_DISABLED, DS\_FileStorePacket(), DS\_AppData\_t::FilterTblPtr, and DS\_AppData\_t::IgnoredPktCounter.

Referenced by DS\_AppProcessMsg().

Here is the call graph for this function:



## 12.6.4 Variable Documentation

### 12.6.4.1 DS\_AppData

`DS_AppData_t DS_AppData`

DS global data structure reference.

Definition at line 53 of file `ds_app.c`.

Referenced by `DS_CmdAddMID()`, `DS_CmdCloseAll()`, `DS_CmdCloseFile()`, `DS_CmdGetFileInfo()`, `DS_CmdNoop()`, `DS_CmdReset()`, `DS_CmdSetAppState()`, `DS_CmdSetDestAge()`, `DS_CmdSetDestBase()`, `DS_CmdSetDestCount()`, `DS_CmdSetDestExt()`, `DS_CmdSetDestPath()`, `DS_CmdSetDestSize()`, `DS_CmdSetDestState()`, `DS_CmdSetDestType()`, `DS_CmdSetFilterFile()`, `DS_CmdSetFilterParms()`, `DS_CmdSetFilterType()`, `DS_FileCloseDest()`, `DS_FileCreateDest()`, `DS_FileCreateName()`, `DS_FileSetupWrite()`, `DS_FileStorePacket()`, `DS_FileTestAge()`, `DS_FileUpdateHeader()`, `DS_FileWriteData()`, `DS_FileWriteError()`, `DS_FileWriteHeader()`, `DS_TableAddMsgID()`, `DS_TableCreateCDS()`, `DS_TableCreateHash()`, `DS_TableFindMsgID()`, `DS_TableInit()`, `DS_TableManageDestFile()`, `DS_TableManageFilter()`, `DS_TableSubscribe()`, `DS_TableUnsubscribe()`, and `DS_TableUpdateCDS()`.

## 12.7 apps/ds/fsw/src/ds\_appdefs.h File Reference

### Macros

- `#define DS_UNUSED 0`  
*Unused entries in DS tables.*
- `#define DS_DISABLED 0`  
*Enable/disable state selection.*
- `#define DS_ENABLED 1`  
*Enable/disable state selection.*
- `#define DS_CLOSED 0`  
*File is closed.*
- `#define DS_OPEN 1`  
*File is open.*
- `#define DS_BY_COUNT 1`  
*Action is based on packet sequence count.*
- `#define DS_BY_TIME 2`  
*Action is based on packet timestamp.*
- `#define DS_STRING_REQUIRED true`  
*String text is required.*
- `#define DS_STRING_OPTIONAL false`  
*String text is optional.*
- `#define DS_FILENAME_TEXT true`  
*String text is part of a filename.*
- `#define DS DESCRIPTIVE_TEXT false`  
*String text is not part of a filename.*
- `#define DS_INDEX_NONE -1`

- `#define DS_PATH_SEPARATOR '/'`  
*File system path separator.*
- `#define DS_EMPTY_STRING ""`  
*Empty string buffer entries in DS tables.*
- `#define DS_STRING_TERMINATOR '\0'`  
*ASCIIZ string terminator character.*
- `#define DS_TABLE_VERIFY_ERR 0xFFFFFFFF`  
*Table verification error return value.*
- `#define DS_FILE_HEADER_NONE 0`  
*File header type is NONE.*
- `#define DS_FILE_HEADER_CFE 1`  
*File header type is CFE.*

### 12.7.1 Detailed Description

The CFS Data Storage (DS) Application header file

### 12.7.2 Macro Definition Documentation

#### 12.7.2.1 DS\_BY\_COUNT

```
#define DS_BY_COUNT 1
```

Action is based on packet sequence count.

Definition at line 41 of file ds\_appdefs.h.

Referenced by DS\_CmdAddMID(), DS\_FileCreateDest(), DS\_FileCreateSequence(), and DS\_TableVerifyType().

#### 12.7.2.2 DS\_BY\_TIME

```
#define DS_BY_TIME 2
```

Action is based on packet timestamp.

Definition at line 42 of file ds\_appdefs.h.

Referenced by DS\_FileCreateSequence(), and DS\_TableVerifyType().

### 12.7.2.3 DS\_CLOSED

```
#define DS_CLOSED 0
```

File is closed.

Definition at line 38 of file ds\_appdefs.h.

Referenced by DS\_CmdGetFileInfo(), and DS\_FileTransmit().

### 12.7.2.4 DS DESCRIPTIVE TEXT

```
#define DS DESCRIPTIVE TEXT false
```

String text is not part of a filename.

Definition at line 48 of file ds\_appdefs.h.

### 12.7.2.5 DS DISABLED

```
#define DS DISABLED 0
```

Enable/disable state selection.

Definition at line 35 of file ds\_appdefs.h.

Referenced by DS\_AppStorePacket(), DS\_CmdGetFileInfo(), DS\_FileCreateDest(), DS\_FileCreateName(), DS\_FileWriteError(), and DS\_TableVerifyState().

### 12.7.2.6 DS EMPTY STRING

```
#define DS EMPTY STRING ""
```

Empty string buffer entries in DS tables.

Definition at line 53 of file ds\_appdefs.h.

### 12.7.2.7 DS ENABLED

```
#define DS ENABLED 1
```

Enable/disable state selection.

Definition at line 36 of file ds\_appdefs.h.

Referenced by DS\_FileStorePacket(), and DS\_TableVerifyState().

### 12.7.2.8 DS\_FILE\_HEADER\_CFE

```
#define DS_FILE_HEADER_CFE 1
```

File header type is CFE.

Definition at line 59 of file ds\_appdefs.h.

### 12.7.2.9 DS\_FILE\_HEADER\_NONE

```
#define DS_FILE_HEADER_NONE 0
```

File header type is NONE.

Definition at line 58 of file ds\_appdefs.h.

### 12.7.2.10 DS\_FILENAME\_TEXT

```
#define DS_FILENAME_TEXT true
```

String text is part of a filename.

Definition at line 47 of file ds\_appdefs.h.

### 12.7.2.11 DS\_INDEX\_NONE

```
#define DS_INDEX_NONE -1
```

Packet filter table look-up = not found.

Definition at line 50 of file ds\_appdefs.h.

Referenced by DS\_AppProcessMsg(), DS\_CmdAddMID(), DS\_CmdSetFilterFile(), DS\_CmdSetFilterParms(), DS\_CmdSetFilterType(), DS\_FileStorePacket(), and DS\_TableFindMsgID().

### 12.7.2.12 DS\_OPEN

```
#define DS_OPEN 1
```

File is open.

Definition at line 39 of file ds\_appdefs.h.

Referenced by DS\_CmdGetFileInfo().

### 12.7.2.13 DS\_PATH\_SEPARATOR

```
#define DS_PATH_SEPARATOR '/'
```

File system path separator.

Definition at line 52 of file `ds_appdefs.h`.

Referenced by `DS_FileCreateName()`.

### 12.7.2.14 DS\_STRING\_OPTIONAL

```
#define DS_STRING_OPTIONAL false
```

String text is optional.

Definition at line 45 of file `ds_appdefs.h`.

### 12.7.2.15 DS\_STRING\_REQUIRED

```
#define DS_STRING_REQUIRED true
```

String text is required.

Definition at line 44 of file `ds_appdefs.h`.

### 12.7.2.16 DS\_STRING\_TERMINATOR

```
#define DS_STRING_TERMINATOR '\0'
```

ASCIIZ string terminator character.

Definition at line 54 of file `ds_appdefs.h`.

Referenced by `DS_FileCreateDest()`, `DS_FileCreateName()`, and `DS_FileCreateSequence()`.

### 12.7.2.17 DS\_TABLE\_VERIFY\_ERR

```
#define DS_TABLE_VERIFY_ERR 0xFFFFFFFF
```

Table verification error return value.

Definition at line 56 of file `ds_appdefs.h`.

Referenced by `DS_TableVerifyDestFile()`, and `DS_TableVerifyFilter()`.

### 12.7.2.18 DS\_UNUSED

```
#define DS_UNUSED 0
```

Unused entries in DS tables.

Definition at line 33 of file ds\_appdefs.h.

Referenced by DS\_FileStorePacket(), and DS\_TableEntryUnused().

## 12.8 apps/ds/fsw/src/ds\_cmds.c File Reference

```
#include "cfe.h"
#include "ds_platform_cfg.h"
#include "ds_verify.h"
#include "ds_appdefs.h"
#include "ds_msgids.h"
#include "ds_msg.h"
#include "ds_app.h"
#include "ds_cmds.h"
#include "ds_file.h"
#include "ds_table.h"
#include "ds_events.h"
#include "ds_version.h"
#include <stdio.h>
```

### Functions

- void [DS\\_CmdNoop](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)  
*NOOP command handler.*
- void [DS\\_CmdReset](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)  
*RESET command handler.*
- void [DS\\_CmdSetAppState](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)  
*Set application enable/disable state command handler.*
- void [DS\\_CmdSetFilterFile](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)  
*Set file index for filter table entry command handler.*
- void [DS\\_CmdSetFilterType](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)  
*Set filter type for filter table entry command handler.*
- void [DS\\_CmdSetFilterParms](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)  
*Set filter parameters for filter table entry command handler.*
- void [DS\\_CmdSetDestType](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)  
*Set data storage filename type command handler.*
- void [DS\\_CmdSetDestState](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)  
*Set data storage enable/disable state command handler.*
- void [DS\\_CmdSetDestPath](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)  
*Set data storage file pathname command handler.*
- void [DS\\_CmdSetDestBase](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)

- void `DS_CmdSetDestExt` (const `CFE_SB_Buffer_t` \*BufPtr)  
*Set data storage file basename command handler.*
- void `DS_CmdSetDestSize` (const `CFE_SB_Buffer_t` \*BufPtr)  
*Set data storage file size limit command handler.*
- void `DS_CmdSetDestAge` (const `CFE_SB_Buffer_t` \*BufPtr)  
*Set data storage file age limit command handler.*
- void `DS_CmdSetDestCount` (const `CFE_SB_Buffer_t` \*BufPtr)  
*Set data storage filename sequence count command handler.*
- void `DS_CmdCloseFile` (const `CFE_SB_Buffer_t` \*BufPtr)  
*Close data storage file command handler.*
- void `DS_CmdCloseAll` (const `CFE_SB_Buffer_t` \*BufPtr)  
*Close all data storage files command handler.*
- void `DS_CmdGetFileInfo` (const `CFE_SB_Buffer_t` \*BufPtr)  
*Get file information telemetry packet command handler.*
- void `DS_CmdAddMID` (const `CFE_SB_Buffer_t` \*BufPtr)  
*Add Message ID to Packet Filter Table.*

### 12.8.1 Detailed Description

CFS Data Storage (DS) command handler functions

### 12.8.2 Function Documentation

#### 12.8.2.1 DS\_CmdAddMID()

```
void DS_CmdAddMID (
    const CFE_SB_Buffer_t * BufPtr )
```

Add Message ID to Packet Filter Table.

##### Description

Set MID selection for unused packet filter table entry Reject invalid commands

- generate error event if invalid command packet length
- generate error event if MID argument is invalid (cannot be zero)
- generate error event if packet filter table is not loaded
- generate error event if MID is already in packet filter table
- generate error event if no unused packet filter table entries Accept valid commands
- generate success event (event type = debug)

##### Assumptions, External Events, and Notes:

(none)

## Parameters

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

## See also


[DS\\_ADD\\_MID\\_CC](#), [DS\\_AddMidCmd\\_t](#)

Definition at line 1390 of file ds\_cmds.c.

References DS\_FilterParms\_t::Algorithm\_N, DS\_FilterParms\_t::Algorithm\_O, DS\_FilterParms\_t::Algorithm\_X, CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_SB\_DEFAULT\_QOS, CFE\_SB\_INVALID\_MSG\_ID, CFE\_SB\_IsValidMsgId(), CFE\_SB\_MsgIdToValue(), CFE\_SB\_SubscribeEx(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_ADD\_MID\_CMD\_EID, DS\_ADD\_MID\_CMD\_ERR\_EID, DS\_AppData, DS\_BY\_COUNT, DS\_FILTERS\_PER\_PACKET, DS\_INDEX\_NONE, DS\_PER\_PACKET\_PIPE\_LIMIT, DS\_TableAddMsgID(), DS\_TableFindMsgID(), DS\_FilterParms\_t::FileTableIndex, DS\_PacketEntry\_t::Filter, DS\_AppData\_t::FilterTblHandle, DS\_AppData\_t::FilterTblPtr, DS\_FilterParms\_t::FilterType, DS\_AppData\_t::InputPipe, DS\_PacketEntry\_t::MessageID, DS\_AddMidCmd\_t::MessageID, CFE\_SB\_Msg::Msg, and DS\_FilterTable\_t::Packet.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



## 12.8.2.2 DS\_CmdCloseAll()

```
void DS_CmdCloseAll (
    const CFE_SB_Buffer_t * BufPtr )
```

Close all data storage files command handler.

## Description

Close all open data storage files. If any open destination file is still enabled, another file will be opened upon receipt of the next packet which passes the filter algorithm. Reject invalid command packets

- generate error event if invalid command packet length Accept valid command packets
- close all open destination files
- generate success event (event type = debug)

## Assumptions, External Events, and Notes:

(none)

## Parameters

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

## See also


[DS\\_CLOSE\\_ALL\\_CC](#), [DS\\_CloseAllCmd\\_t](#)

Definition at line 1240 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MS\_G.GetSize(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData, DS\_CLOSE\_ALL\_CMD\_EID, DS\_CLOSE\_ALL\_CMD\_ERR\_EID, DS\_DEST\_FILE\_CNT, DS\_FileCloseDest(), DS\_FileUpdateHeader(), DS\_AppFileStatus\_t::FileHandle, DS\_AppData\_t::FileStatus, CFE\_SB\_Msg::Msg, and OS\_ObjectIdDefined().

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



### 12.8.2.3 DS\_CmdCloseFile()

```
void DS_CmdCloseFile (
    const CFE_SB_Buffer_t * BufPtr )
```

Close data storage file command handler.

#### Description

Close the selected data storage file. If this destination is still enabled, another file will be opened upon receipt of the next packet which passes the filter algorithm. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid destination file index Accept valid command packets
- close the selected destination file
- generate success event (event type = debug)

#### Assumptions, External Events, and Notes:

(none)

### Parameters

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

### See also


[DS\\_CLOSE\\_FILE\\_CC](#), [DS\\_CloseFileCmd\\_t](#)

Definition at line 1183 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG::GetSize(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData, DS\_CLOS::E\_CMD\_EID, DS\_CLOSE\_CMD\_ERR\_EID, DS\_FileCloseDest(), DS\_FileUpdateHeader(), DS\_TableVerifyFileIndex(), DS\_AppFileStatus\_t::FileHandle, DS\_AppData\_t::FileStatus, DS\_CloseFileCmd\_t::FileTableIndex, CFE\_SB\_Msg::Msg, and OS\_ObjectIdDefined().

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



#### 12.8.2.4 DS\_CmdGetFileInfo()

```
void DS_CmdGetFileInfo (
    const CFE_SB_Buffer_t * BufPtr )
```

Get file information telemetry packet command handler.

##### Description

Create and send a telemetry packet containing the current status for all destination files. Reject invalid command packets

- generate error event if invalid command packet length Accept valid command packets
- generate file info telemetry packet
- generate success event (event type = debug)

##### Assumptions, External Events, and Notes:

(none)

##### Parameters

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

##### See also


[DS\\_GET\\_FILE\\_INFO\\_CC](#), [DS\\_GetFileInfoCmd\\_t](#), [DS\\_FileInfoPkt\\_t](#)

Definition at line 1288 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_MSG\_Init(), CFE\_SB\_TimeStampMsg(), CFE\_SB\_TransmitMsg(), CFE\_SB\_ValueToMsgId(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_CLOSED, DS\_DEST\_FILE\_CNT, DS\_DIAG\_TLM\_MID, DS\_DISABLED, DS\_GET\_FILE\_INFO\_CMD\_EID, DS\_GET\_FILE\_INFO\_CMD\_ERR\_EID, DS\_OPEN, DS\_FileInfo\_t::EnableState, DS\_AppFileStatus\_t::FileAge, DS\_FileInfo\_t::FileAge, DS\_AppFileStatus\_t::FileCount, DS\_AppFileStatus\_t::FileHandle, DS\_FileInfoPkt\_t::FileInfo, DS\_AppFileStatus\_t::FileName, DS\_FileInfo\_t::FileName, DS\_AppFileStatus\_t::FileRate, DS\_FileInfo\_t::FileRate, DS\_AppFileStatus\_t::FileSize, DS\_FileInfo\_t::FileSize, DS\_AppFileStatus\_t::FileState, DS\_AppData\_t::FileStatus, CFE\_SB\_Msg::Msg, DS\_FileInfo\_t::OpenState, OS\_ObjectIdDefined(), DS\_FileInfo\_t::SequenceCount, and DS\_FileInfoPkt\_t::TlmHeader.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



#### 12.8.2.5 DS\_CmdNoop()

```
void DS_CmdNoop (
```

NOOP command handler.

## Description

The NOOP command performs no specific function (no operation) Validate command packet

- generate error event if invalid command packet length Process valid command packets
  - generate success event (event type = informational)

## **Assumptions, External Events, and Notes:**

(none)

## Parameters

in *BufPtr* Software Bus message pointer

**See also**


[DS\\_NOOP\\_CC](#), [DS\\_NoopCmd\\_t](#)

Definition at line 49 of file `ds_cmds.c`.

References `CFE_EVS_EventType_ERROR`, `CFE_EVS_EventType_INFORMATION`, `CFE_EVS_SendEvent()`, `CFE_MSG_GetSize()`, `DS_AppData_t::CmdAcceptedCounter`, `DS_AppData_t::CmdRejectedCounter`, `DS_AppData`, `DS_MAJOR_VERSION`, `DS_MINOR_VERSION`, `DS_MISSION_REV`, `DS_NOOP_CMD_EID`, `DS_NOOP_CMD_ERR_EID`, `DS_REVISION`, and `CFE_SB_Msg::Msg`.

Referenced by `DS_AppProcessCmd()`.

Here is the call graph for this function:



#### 12.8.2.6 DS\_CmdReset()

```
void DS_CmdReset (
    const CFE_SB_Buffer_t * BufPtr )
```

RESET command handler.

##### Description

Reset housekeeping telemetry counters command Validate command packet

- generate error event if invalid command packet length Process valid command packets
- set selected housekeeping telemetry counters to zero
- generate success event (event type = debug)

##### Assumptions, External Events, and Notes:

(none)

**Parameters**

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

**See also**


[DS\\_RESET\\_CC](#), [DS\\_ResetCmd\\_t](#)

Definition at line 88 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData\_t::DestTblErrCounter, DS\_AppData\_t::DestTblLoadCounter, DS\_AppData\_t::DisabledPktCounter, DS\_AppData, DS\_RESET\_CMD\_EID, DS\_RESET\_CMD\_ERR\_EID, DS\_AppData\_t::FileUpdateCounter, DS\_AppData\_t::FileUpdateErrCounter, DS\_AppData\_t::FileWriteCounter, DS\_AppData\_t::FileWriteErrCounter, DS\_AppData\_t::FilteredPktCounter, DS\_AppData\_t::FilterTblErrCounter, DS\_AppData\_t::FilterTblLoadCounter, DS\_AppData\_t::IgnoredPktCounter, CFE\_SB\_Msg::Msg, and DS\_AppData\_t::PassedPktCounter.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:

**12.8.2.7 DS\_CmdSetAppState()**

```
void DS_CmdSetAppState (
    const CFE_SB_Buffer_t * BufPtr )
```

Set application enable/disable state command handler.

**Description**

Set application enable/disable state command Validate command packet

- generate error event if invalid command packet length
- generate error event if invalid enable/disable state Process valid command packets
- update application enable/disable state
- generate success event (event type = debug)

**Assumptions, External Events, and Notes:**

(none)

### Parameters

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

### See also


[DS\\_SET\\_APP\\_STATE\\_CC](#), [DS\\_AppStateCmd\\_t](#)

Definition at line 151 of file `ds_cmds.c`.

References `DS_AppData_t::AppEnableState`, `CFE_EVS_EventType_DEBUG`, `CFE_EVS_EventType_ERROR`, `CFE_EVS_SendEvent()`, `CFE_MSG_GetSize()`, `DS_AppData_t::CmdAcceptedCounter`, `DS_AppData_t::CmdRejectedCounter`, `DS_AppData`, `DS_ENADIS_CMD_EID`, `DS_ENADIS_CMD_ERR_EID`, `DS_TableUpdateCDS()`, `DS_TableVerifyState()`, `DS_AppStateCmd_t::EnableState`, and `CFE_SB_Msg::Msg`.

Referenced by `DS_AppProcessCmd()`.

Here is the call graph for this function:



### 12.8.2.8 DS\_CmdSetDestAge()

```
void DS_CmdSetDestAge (
    const CFE_SB_Buffer_t * BufPtr )
```

Set data storage file age limit command handler.

#### Description

Modify the max file age limit for the selected entry in the destination file definitions table. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid file table index
- generate error event if invalid file size limit
- generate error event if file table is not loaded Accept valid command packets
- update max age limit for selected file table entry
- generate success event (event type = debug)

#### Assumptions, External Events, and Notes:

(none)

**Parameters**

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

**See also**


[DS\\_SET\\_DEST\\_AGE\\_CC](#), [DS\\_DestAgeCmd\\_t](#)

Definition at line 1010 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData\_t::DestFileTblHandle, DS\_AppData\_t::DestFileTblPtr, DS\_AGE\_CMD\_EID, DS\_AGE\_CMD\_ERR\_EID, DS\_AppData, DS\_TableVerifyAge(), DS\_TableVerifyFileIndex(), DS\_DestFileTable\_t::File, DS\_DestAgeCmd\_t::FileTableIndex, DS\_DestFileEntry\_t::MaxFileAge, DS\_DestAgeCmd\_t::MaxFileAge, and CFE\_SB\_Msg::Msg.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:

**12.8.2.9 DS\_CmdSetDestBase()**

```
void DS_CmdSetDestBase (
    const CFE_SB_Buffer_t * BufPtr )
```

Set data storage file basename command handler.

**Description**

Modify the base portion of the filename for the selected entry in the destination file definitions table. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid file table index
- generate error event if invalid basename characters
- generate error event if file table is not loaded Accept valid command packets
- update file basename for selected file table entry
- generate success event (event type = debug)

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

**See also**


[DS\\_SET\\_DEST\\_BASE\\_CC](#), [DS\\_DestBaseCmd\\_t](#)

Definition at line 790 of file `ds_cmds.c`.

References `DS_DestFileEntry_t::Basename`, `DS_DestBaseCmd_t::Basename`, `CFE_EVS_EventType_DEBUG`, `CFE_EVS_EventType_ERROR`, `CFE_EVS_SendEvent()`, `CFE_MSG_GetSize()`, `CFE_TBL_Modified()`, `DS_AppData_t::CmdAcceptedCounter`, `DS_AppData_t::CmdRejectedCounter`, `DS_AppData_t::DestFileTblHandle`, `DS_AppData_t::DestFileTblPtr`, `DS_AppData`, `DS_BASE_CMD_EID`, `DS_BASE_CMD_ERR_EID`, `DS_TableVerifyFileIndex()`, `DS_DestFileTable_t::File`, `DS_DestBaseCmd_t::FileTableIndex`, and `CFE_SB_Msg::Msg`.

Referenced by `DS_AppProcessCmd()`.

Here is the call graph for this function:



### 12.8.2.10 DS\_CmdSetDestCount()

```
void DS_CmdSetDestCount (
    const CFE_SB_Buffer_t * BufPtr )
```

Set data storage filename sequence count command handler.

#### Description

Modify the filename sequence count for the selected entry in the destination file definitions table. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid file table index
- generate error event if invalid filename sequence count
- generate error event if file table is not loaded Accept valid command packets
- update filename sequence count for selected file table entry
- generate success event (event type = debug)

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	BufPtr	Software Bus message pointer
----	--------	------------------------------

#### See also


[DS\\_SET\\_DEST\\_COUNT\\_CC](#), [DS\\_DestCountCmd\\_t](#)

Definition at line 1090 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData\_t::DestFileTblHandle, DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_SEQ\_CMD\_EID, DS\_SEQ\_CMD\_ERR\_EID, DS\_TableUpdateCDS(), DS\_TableVerifyCount(), DS\_TableVerifyFileIndex(), DS\_DestFileTable\_t::File, DS\_AppFileStatus\_t::FileCount, DS\_AppData\_t::FileStatus, DS\_DestCountCmd\_t::FileTableIndex, CFE\_SB\_Msg::Msg, DS\_DestFileEntry\_t::SequenceCount, and DS\_DestCountCmd\_t::SequenceCount.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



### 12.8.2.11 DS\_CmdSetDestExt()

```
void DS_CmdSetDestExt (
    const CFE_SB_Buffer_t * BufPtr )
```

Set data storage file extension command handler.

#### Description

Modify the extension portion of the filename for the selected entry in the destination file definitions table. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid file table index
- generate error event if invalid extension characters
- generate error event if file table is not loaded Accept valid command packets
- update file extension for selected file table entry
- generate success event (event type = debug)

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

## See also


[DS\\_SET\\_DEST\\_EXT\\_CC](#), [DS\\_DestExtCmd\\_t](#)

Definition at line 860 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData\_t::DestFileTblHandle, DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_EXT\_CMD\_EID, DS\_EXT\_CMD\_ERR\_EID, DS\_TableVerifyFileIndex(), DS\_DestFileEntry\_t::Extension, DS\_DestExtCmd\_t::Extension, DS\_DestFileTable\_t::File, DS\_DestExtCmd\_t::FileTableIndex, and CFE\_SB\_Msg::Msg.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



### 12.8.2.12 DS\_CmdSetDestPath()

```
void DS_CmdSetDestPath (
    const CFE_SB_Buffer_t * BufPtr )
```

Set data storage file pathname command handler.

#### Description

Modify the path portion of the filename for the selected entry in the destination file definitions table. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid file table index
- generate error event if invalid pathname characters

- generate error event if file table is not loaded Accept valid command packets
- update file pathname for selected file table entry
- generate success event (event type = debug)

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

**See also**


[DS\\_SET\\_DEST\\_PATH\\_CC](#), [DS\\_DestPathCmd\\_t](#)

Definition at line 720 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData\_t::DestFileTblHandle, DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_PATH\_CMD\_EID, DS\_PATH\_CMD\_ERR\_EID, DS\_TableVerifyFileIndex(), DS\_DestFileTable\_t::File, DS\_DestPathCmd\_t::FileTableIndex, CFE\_SB\_Msg::Msg, DS\_DestFileEntry\_t::Pathname, and DS\_DestPathCmd\_t::Pathname.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:

**12.8.2.13 DS\_CmdSetDestSize()**

```
void DS_CmdSetDestSize (
    const CFE_SB_Buffer_t * BufPtr )
```

Set data storage file size limit command handler.

**Description**

Modify the max file size limit for the selected entry in the destination file definitions table. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid file table index
- generate error event if invalid file size limit
- generate error event if file table is not loaded Accept valid command packets
- update max size limit for selected file table entry
- generate success event (event type = debug)

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	BufPtr	Software Bus message pointer
----	--------	------------------------------

**See also**


[DS\\_SET\\_DEST\\_SIZE\\_CC](#), [DS\\_DestSizeCmd\\_t](#)

Definition at line 930 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData\_t::DestFileTblHandle, DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_SIZE\_CMD\_EID, DS\_SIZE\_CM\_D\_ERR\_EID, DS\_TableVerifyFileIndex(), DS\_TableVerifySize(), DS\_DestFileTable\_t::File, DS\_DestSizeCmd\_t::FileTableIndex, DS\_DestFileEntry\_t::MaxFileSize, DS\_DestSizeCmd\_t::MaxFileSize, and CFE\_SB\_Msg::Msg.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



### 12.8.2.14 DS\_CmdSetDestState()

```
void DS_CmdSetDestState (
    const CFE_SB_Buffer_t * BufPtr )
```

Set data storage enable/disable state command handler.

#### Description

Modify the enable/disable state for the selected entry in the destination file definitions table. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid file table index
- generate error event if invalid enable/disable state
- generate error event if file table is not loaded Accept valid command packets
- update enable/disable state for selected file table entry
- generate success event (event type = debug)

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	BufPtr	Software Bus message pointer
----	--------	------------------------------

#### See also


[DS\\_SET\\_DEST\\_STATE\\_CC](#), [DS\\_DestStateCmd\\_t](#)

Definition at line 641 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData\_t::DestFileTblHandle, DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_STATE\_CMD\_EID, DS\_STATE\_CMD\_ERR\_EID, DS\_TableVerifyFileIndex(), DS\_TableVerifyState(), DS\_DestFileEntry\_t::EnableState, DS\_DestStateCmd\_t::EnableState, DS\_DestFileTable\_t::File, DS\_AppFileStatus\_t::FileState, DS\_AppData\_t::FileStatus, DS\_DestStateCmd\_t::FileTableIndex, and CFE\_SB\_Msg::Msg.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



#### 12.8.2.15 DS\_CmdSetDestType()

```
void DS_CmdSetDestType (
    const CFE_SB_Buffer_t * BufPtr )
```

Set data storage filename type command handler.

##### Description

Modify the filename type for the selected entry in the destination file definitions table. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid file table index
- generate error event if invalid filename type
- generate error event if file table is not loaded Accept valid command packets
- update filename type for selected file table entry
- generate success event (event type = debug)

##### Assumptions, External Events, and Notes:

(none)

**Parameters**

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

**See also**


[DS\\_SET\\_DEST\\_TYPE\\_CC](#), [DS\\_DestTypeCmd\\_t](#)

Definition at line 561 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData\_t::DestFileTblHandle, DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_NTYPEDCMD\_EID, DS\_NTYPEDCMD\_ERR\_EID, DS\_TableVerifyFileIndex(), DS\_TableVerifyType(), DS\_DestFileTable\_t::File, DS\_DestFileEntry\_t::FileNameType, DS\_DestTypeCmd\_t::FileNameType, DS\_DestTypeCmd\_t::FileTableIndex, and CFE\_SB\_Msg::Msg.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:

**12.8.2.16 DS\_CmdSetFilterFile()**

```
void DS_CmdSetFilterFile (
    const CFE_SB_Buffer_t * BufPtr )
```

Set file index for filter table entry command handler.

## Description

Set destination file index for filter table entry command Validate command packet

- generate error event if invalid command packet length
- generate error event if invalid filter parameters index
- generate error event if invalid file table index
- generate error event if packet filter table is not loaded
- generate error event if message ID is not in filter table Process valid command packets
- update file index for selected filter table entry
- generate success event (event type = debug)

## Assumptions, External Events, and Notes:

(none)

## Parameters

in	<i>BuPtr</i>	Software Bus message pointer
----	--------------	------------------------------

## See also


[DS\\_SET\\_FILTER\\_FILE\\_CC](#), [DS\\_FilterFileCmd\\_t](#)

Definition at line 208 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_SB\_IsValidMsgId(), CFE\_SB\_MsgIdToValue(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData, DS\_FILE\_CMD\_EID, DS\_FILE\_CMD\_ERR\_EID, DS\_FILTERS\_PER\_PACKET, DS\_INDEX\_NONE, DS\_TableFindMsgID(), DS\_TableVerifyFileIndex(), DS\_FilterParms\_t::FileTableIndex, DS\_FilterFileCmd\_t::FileTableIndex, DS\_PacketEntry\_t::Filter, DS\_FilterFileCmd\_t::FilterParmsIndex, DS\_AppData\_t::FilterTblHandle, DS\_AppData\_t::FilterTblPtr, DS\_FilterFileCmd\_t::MessageID, CFE\_SB\_Msg::Msg, and DS\_FilterTable\_t::Packet.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



### 12.8.2.17 DS\_CmdSetFilterParms()

```
void DS_CmdSetFilterParms (
    const CFE_SB_Buffer_t * BufPtr )
```

Set filter parameters for filter table entry command handler.

#### Description

Set filter parameters for filter table entry command Validate command packet

- generate error event if invalid command packet length
- generate error event if invalid filter parameters index
- generate error event if invalid filter parameters
- generate error event if packet filter table is not loaded
- generate error event if message ID is not in filter table Process valid command packets
- update filter parameters for selected filter table entry
- generate success event (event type = debug)

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	BufPtr	Software Bus message pointer
----	--------	------------------------------

#### See also


[DS\\_SET\\_FILTER\\_PARMS\\_CC](#), [DS\\_FilterParmsCmd\\_t](#)

Definition at line 440 of file ds\_cmds.c.

References DS\_FilterParms\_t::Algorithm\_N, DS\_FilterParmsCmd\_t::Algorithm\_N, DS\_FilterParms\_t::Algorithm\_O, DS\_FilterParmsCmd\_t::Algorithm\_O, DS\_FilterParms\_t::Algorithm\_X, DS\_FilterParmsCmd\_t::Algorithm\_X, CFE\_EVT\_S\_EventType\_DEBUG, CFE\_EVT\_EventType\_ERROR, CFE\_EVT\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_SB\_IsValidMsgId(), CFE\_SB\_MsgIdToValue(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData, DS\_FILTERS\_PER\_PACKET, DS\_INDEX\_NONE, DS\_PARMS\_CMD\_EID, DS\_PARMS\_CMD\_ERR\_EID, DS\_TableFindMsgID(), DS\_TableVerifyParms(), DS\_PacketEntry\_t::Filter, DS\_FilterParmsCmd\_t::FilterParmsIndex, DS\_AppData\_t::FilterTblHandle, DS\_AppData\_t::FilterTblPtr, DS\_FilterParmsCmd\_t::MessageID, CFE\_SB\_Msg::Msg, and DS\_FilterTable\_t::Packet.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



### 12.8.2.18 DS\_CmdSetFilterType()

```
void DS_CmdSetFilterType (
    const CFE_SB_Buffer_t * BufPtr )
```

Set filter type for filter table entry command handler.

#### Description

Set filter type for filter table entry command Validate command packet

- generate error event if invalid command packet length
- generate error event if invalid filter parameters index
- generate error event if invalid filter type
- generate error event if packet filter table is not loaded
- generate error event if message ID is not in filter table Process valid command packets
- update filter type for selected filter table entry
- generate success event (event type = debug)

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

See also


[DS\\_SET\\_FILTER\\_TYPE\\_CC](#), [DS\\_FilterTypeCmd\\_t](#)

Definition at line 324 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_SB\_IsValidMsgId(), CFE\_SB\_MsgIdToValue(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData, DS\_FILTERS\_PER\_PACKET, DS\_FTYPE\_CMD\_EID, DS\_FTYPE\_CMD\_ERR\_EID, DS\_INDEX\_NONE, DS\_TableFindMsgId(), DS\_TableVerifyType(), DS\_PacketEntry\_t::Filter, DS\_FilterTypeCmd\_t::FilterParmsIndex, DS\_AppData\_t::FilterTblHandle, DS\_AppData\_t::FilterTblPtr, DS\_FilterParms\_t::FilterType, DS\_FilterTypeCmd\_t::FilterType, DS\_FilterTypeCmd\_t::MessageID, CFE\_SB\_Msg::Msg, and DS\_FilterTable\_t::Packet.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



## 12.9 apps/ds/fsw/src/ds\_cmds.h File Reference

```
#include "cfe.h"
```

### Functions

- void [DS\\_CmdNoop](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)  
*NOOP command handler.*
- void [DS\\_CmdReset](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)  
*RESET command handler.*
- void [DS\\_CmdSetAppState](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)  
*Set application enable/disable state command handler.*
- void [DS\\_CmdSetFilterFile](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)  
*Set file index for filter table entry command handler.*
- void [DS\\_CmdSetFilterType](#) (const [CFE\\_SB\\_Buffer\\_t](#) \*BufPtr)

- void `DS_CmdSetFilterParms` (const `CFE_SB_Buffer_t` \*BufPtr)
 

*Set filter type for filter table entry command handler.*
- void `DS_CmdSetDestType` (const `CFE_SB_Buffer_t` \*BufPtr)
 

*Set data storage filename type command handler.*
- void `DS_CmdSetDestState` (const `CFE_SB_Buffer_t` \*BufPtr)
 

*Set data storage enable/disable state command handler.*
- void `DS_CmdSetDestPath` (const `CFE_SB_Buffer_t` \*BufPtr)
 

*Set data storage file pathname command handler.*
- void `DS_CmdSetDestBase` (const `CFE_SB_Buffer_t` \*BufPtr)
 

*Set data storage file basename command handler.*
- void `DS_CmdSetDestExt` (const `CFE_SB_Buffer_t` \*BufPtr)
 

*Set data storage file extension command handler.*
- void `DS_CmdSetDestSize` (const `CFE_SB_Buffer_t` \*BufPtr)
 

*Set data storage file size limit command handler.*
- void `DS_CmdSetDestAge` (const `CFE_SB_Buffer_t` \*BufPtr)
 

*Set data storage file age limit command handler.*
- void `DS_CmdSetDestCount` (const `CFE_SB_Buffer_t` \*BufPtr)
 

*Set data storage filename sequence count command handler.*
- void `DS_CmdCloseFile` (const `CFE_SB_Buffer_t` \*BufPtr)
 

*Close data storage file command handler.*
- void `DS_CmdCloseAll` (const `CFE_SB_Buffer_t` \*BufPtr)
 

*Close all data storage files command handler.*
- void `DS_CmdGetFileInfo` (const `CFE_SB_Buffer_t` \*BufPtr)
 

*Get file information telemetry packet command handler.*
- void `DS_CmdAddMID` (const `CFE_SB_Buffer_t` \*BufPtr)
 

*Add Message ID to Packet Filter Table.*

### 12.9.1 Detailed Description

CFS Data Storage (DS) command handler header file

### 12.9.2 Function Documentation

#### 12.9.2.1 DS\_CmdAddMID()

```
void DS_CmdAddMID (
    const CFE_SB_Buffer_t * BufPtr )
```

Add Message ID to Packet Filter Table.

#### Description

Set MID selection for unused packet filter table entry Reject invalid commands

- generate error event if invalid command packet length
- generate error event if MID argument is invalid (cannot be zero)
- generate error event if packet filter table is not loaded
- generate error event if MID is already in packet filter table
- generate error event if no unused packet filter table entries Accept valid commands
- generate success event (event type = debug)

**Assumptions, External Events, and Notes:**

(none)

#### Parameters

in	BufPtr	Software Bus message pointer
----	--------	------------------------------

#### See also


[DS\\_ADD\\_MID\\_CC](#), [DS\\_AddMidCmd\\_t](#)

Definition at line 1390 of file ds\_cmds.c.

References DS\_FilterParms\_t::Algorithm\_N, DS\_FilterParms\_t::Algorithm\_O, DS\_FilterParms\_t::Algorithm\_X, CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_SB\_DEFAULT\_QOS, CFE\_SB\_INVALID\_MSG\_ID, CFE\_SB\_IsValidMsgId(), CFE\_SB\_MsgIdToValue(), CFE\_SB\_SubscribeEx(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_ADD\_MID\_CMD\_EID, DS\_ADD\_MID\_CMD\_ERR\_EID, DS\_AppData, DS\_BY\_COUNT, DS\_FILTERS\_PER\_PACKET, DS\_INDEX\_NONE, DS\_PER\_PACKET\_PIPE\_LIMIT, DS\_TableAddMsgID(), DS\_TableFindMsgID(), DS\_FilterParms\_t::FileTableIndex, DS\_PacketEntry\_t::Filter, DS\_AppData\_t::FilterTblHandle, DS\_AppData\_t::FilterTblPtr, DS\_FilterParms\_t::FilterType, DS\_AppData\_t::InputPipe, DS\_PacketEntry\_t::MessageID, DS\_AddMidCmd\_t::MessageID, CFE\_SB\_Msg::Msg, and DS\_FilterTable\_t::Packet.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



### 12.9.2.2 DS\_CmdCloseAll()

```
void DS_CmdCloseAll (
    const CFE_SB_Buffer_t * BufPtr )
```

Close all data storage files command handler.

#### Description

Close all open data storage files. If any open destination file is still enabled, another file will be opened upon receipt of the next packet which passes the filter algorithm. Reject invalid command packets

- generate error event if invalid command packet length Accept valid command packets
- close all open destination files
- generate success event (event type = debug)

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	BufPtr	Software Bus message pointer
----	--------	------------------------------

#### See also


[DS\\_CLOSE\\_ALL\\_CC](#), [DS\\_CloseAllCmd\\_t](#)

Definition at line 1240 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MS\_G\_GetSize(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData, DS\_CLOSE\_ALL\_CMD\_EID, DS\_CLOSE\_ALL\_CMD\_ERR\_EID, DS\_DEST\_FILE\_CNT, DS\_FileCloseDest(), DS\_FileUpdateHeader(), DS\_AppFileStatus\_t::FileHandle, DS\_AppData\_t::FileStatus, CFE\_SB\_Msg::Msg, and OS\_ObjectIdDefined().

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



### 12.9.2.3 DS\_CmdCloseFile()

```
void DS_CmdCloseFile (
    const CFE_SB_Buffer_t * BufPtr )
```

Close data storage file command handler.

#### Description

Close the selected data storage file. If this destination is still enabled, another file will be opened upon receipt of the next packet which passes the filter algorithm. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid destination file index Accept valid command packets
- close the selected destination file
- generate success event (event type = debug)

#### Assumptions, External Events, and Notes:

(none)

## Parameters

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

## See also


[DS\\_CLOSE\\_FILE\\_CC](#), [DS\\_CloseFileCmd\\_t](#)

Definition at line 1183 of file `ds_cmds.c`.

References `CFE_EVS_EventType_DEBUG`, `CFE_EVS_EventType_ERROR`, `CFE_EVS_SendEvent()`, `CFE_MSG_GetSize()`, `DS_AppData_t::CmdAcceptedCounter`, `DS_AppData_t::CmdRejectedCounter`, `DS_AppData`, `DS_CLOSE_CMD_EID`, `DS_CLOSE_CMD_ERR_EID`, `DS_FileCloseDest()`, `DS_FileUpdateHeader()`, `DS_TableVerifyFileIndex()`, `DS_AppFileStatus_t::FileHandle`, `DS_AppData_t::FileStatus`, `DS_CloseFileCmd_t::FileTableIndex`, `CFE_SB_Msg::Msg`, and `OS_ObjectIdDefined()`.

Referenced by `DS_AppProcessCmd()`.

Here is the call graph for this function:



#### 12.9.2.4 DS\_CmdGetFileInfo()

```
void DS_CmdGetFileInfo (
    const CFE_SB_Buffer_t * BufPtr )
```

Get file information telemetry packet command handler.

#### Description

Create and send a telemetry packet containing the current status for all destination files. Reject invalid command packets

- generate error event if invalid command packet length Accept valid command packets
- generate file info telemetry packet
- generate success event (event type = debug)

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	BufPtr	Software Bus message pointer
----	--------	------------------------------

#### See also


[DS\\_GET\\_FILE\\_INFO\\_CC](#), [DS\\_GetFileInfoCmd\\_t](#), [DS\\_FileInfoPkt\\_t](#)

Definition at line 1288 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_MSG\_Init(), CFE\_SB\_TimeStampMsg(), CFE\_SB\_TransmitMsg(), CFE\_SB\_ValueToMsgId(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_CLOSED, DS\_DEST\_FILE\_CNT, DS\_DIAG\_TLM\_MID, DS\_DISABLED, DS\_GET\_FILE\_INFO\_CMD\_EID, DS\_GET\_FILE\_INFO\_CMD\_ERR\_EID, DS\_OPEN, DS\_FileInfo\_t::EnableState, DS\_AppFileStatus\_t::FileAge, DS\_FileInfo\_t::FileAge, DS\_AppFileStatus\_t::FileCount, DS\_AppFileStatus\_t::FileHandle, DS\_FileInfoPkt\_t::FileInfo, DS\_AppFileStatus\_t::FileName, DS\_FileInfo\_t::FileName, DS\_AppFileStatus\_t::FileRate, DS\_FileInfo\_t::FileRate, DS\_AppFileStatus\_t::FileSize, DS\_FileInfo\_t::FileSize, DS\_AppFileStatus\_t::FileState, DS\_AppData\_t::FileStatus, CFE\_SB\_Msg::Msg, DS\_FileInfo\_t::OpenState, OS\_ObjectIdDefined(), DS\_FileInfo\_t::SequenceCount, and DS\_FileInfoPkt\_t::TlmHeader.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



### 12.9.2.5 DS\_CmdNoop()

```
void DS_CmdNoop (
```

NOOP command handler.

## Description

The NOOP command performs no specific function (no operation) Validate command packet

- generate error event if invalid command packet length Process valid command packets
  - generate success event (event type = informational)

## **Assumptions, External Events, and Notes:**

(none)

## Parameters

in *BufPtr* Software Bus message pointer

**See also**


[DS\\_NOOP\\_CC](#), [DS\\_NoopCmd\\_t](#)

Definition at line 49 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_EventType\_INFORMATION, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData, DS\_MAJOR\_VERSION, DS\_MINOR\_VERSION, DS\_MISSION\_REV, DS\_NOOP\_CMD\_EID, DS\_NOOP\_CMD\_ERR\_EID, DS\_REVISION, and CFE\_SB\_Msg::Msg.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



#### 12.9.2.6 DS\_CmdReset()

```
void DS_CmdReset (
    const CFE_SB_Buffer_t * BufPtr )
```

RESET command handler.

**Description**

Reset housekeeping telemetry counters command Validate command packet

- generate error event if invalid command packet length Process valid command packets
- set selected housekeeping telemetry counters to zero
- generate success event (event type = debug)

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

**See also**


[DS\\_RESET\\_CC](#), [DS\\_ResetCmd\\_t](#)

Definition at line 88 of file `ds_cmds.c`.

References `CFE_EVS_EventType_DEBUG`, `CFE_EVS_EventType_ERROR`, `CFE_EVS_SendEvent()`, `CFE_MSG_GetSize()`, `DS_AppData_t::CmdAcceptedCounter`, `DS_AppData_t::CmdRejectedCounter`, `DS_AppData_t::DestTblErrCounter`, `DS_AppData_t::DestTblLoadCounter`, `DS_AppData_t::DisabledPktCounter`, `DS_AppData`, `DS_RESET_CMD_EID`, `DS_RESET_CMD_ERR_EID`, `DS_AppData_t::FileUpdateCounter`, `DS_AppData_t::FileUpdateErrCounter`, `DS_AppData_t::FileWriteCounter`, `DS_AppData_t::FileWriteErrCounter`, `DS_AppData_t::FilteredPktCounter`, `DS_AppData_t::FilterTblErrCounter`, `DS_AppData_t::FilterTblLoadCounter`, `DS_AppData_t::IgnoredPktCounter`, `CFE_SB_Msg::Msg`, and `DS_AppData_t::PassedPktCounter`.

Referenced by `DS_AppProcessCmd()`.

Here is the call graph for this function:



### 12.9.2.7 DS\_CmdSetAppState()

```
void DS_CmdSetAppState (
    const CFE_SB_Buffer_t * BufPtr )
```

Set application enable/disable state command handler.

**Description**

Set application enable/disable state command Validate command packet

- generate error event if invalid command packet length
- generate error event if invalid enable/disable state Process valid command packets
- update application enable/disable state
- generate success event (event type = debug)

**Assumptions, External Events, and Notes:**

(none)

### Parameters

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

### See also


[DS\\_SET\\_APP\\_STATE\\_CC](#), [DS\\_AppStateCmd\\_t](#)

Definition at line 151 of file `ds_cmds.c`.

References `DS_AppData_t::AppEnableState`, `CFE_EVS_EventType_DEBUG`, `CFE_EVS_EventType_ERROR`, `CFE_EVS_SendEvent()`, `CFE_MSG_GetSize()`, `DS_AppData_t::CmdAcceptedCounter`, `DS_AppData_t::CmdRejectedCounter`, `DS_AppData`, `DS_ENADIS_CMD_EID`, `DS_ENADIS_CMD_ERR_EID`, `DS_TableUpdateCDS()`, `DS_TableVerifyState()`, `DS_AppStateCmd_t::EnableState`, and `CFE_SB_Msg::Msg`.

Referenced by `DS_AppProcessCmd()`.

Here is the call graph for this function:



### 12.9.2.8 DS\_CmdSetDestAge()

```
void DS_CmdSetDestAge (
    const CFE_SB_Buffer_t * BufPtr )
```

Set data storage file age limit command handler.

### Description

Modify the max file age limit for the selected entry in the destination file definitions table. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid file table index
- generate error event if invalid file size limit
- generate error event if file table is not loaded Accept valid command packets
- update max age limit for selected file table entry
- generate success event (event type = debug)

### Assumptions, External Events, and Notes:

(none)

**Parameters**

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

**See also**


[DS\\_SET\\_DEST\\_AGE\\_CC](#), [DS\\_DestAgeCmd\\_t](#)

Definition at line 1010 of file `ds_cmds.c`.

References `CFE_EVS_EventType_DEBUG`, `CFE_EVS_EventType_ERROR`, `CFE_EVS_SendEvent()`, `CFE_MSG_GetSize()`, `CFE_TBL_Modified()`, `DS_AppData_t::CmdAcceptedCounter`, `DS_AppData_t::CmdRejectedCounter`, `DS_AppData_t::DestFileTblHandle`, `DS_AppData_t::DestFileTblPtr`, `DS_AGE_CMD_EID`, `DS_AGE_CMD_ERR_EID`, `DS_AppData`, `DS_TableVerifyAge()`, `DS_TableVerifyFileIndex()`, `DS_DestFileTable_t::File`, `DS_DestAgeCmd_t::FileTableIndex`, `DS_DestFileEntry_t::MaxFileAge`, `DS_DestAgeCmd_t::MaxFileAge`, and `CFE_SB_Msg::Msg`.

Referenced by `DS_AppProcessCmd()`.

Here is the call graph for this function:



### 12.9.2.9 DS\_CmdSetDestBase()

```
void DS_CmdSetDestBase (
    const CFE_SB_Buffer_t * BufPtr )
```

Set data storage file basename command handler.

## Description

Modify the base portion of the filename for the selected entry in the destination file definitions table. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid file table index
- generate error event if invalid basename characters
- generate error event if file table is not loaded Accept valid command packets
- update file basename for selected file table entry
- generate success event (event type = debug)

## Assumptions, External Events, and Notes:

(none)

## Parameters

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

## See also


[DS\\_SET\\_DEST\\_BASE\\_CC](#), [DS\\_DestBaseCmd\\_t](#)

Definition at line 790 of file ds\_cmds.c.

References DS\_DestFileEntry\_t::Basename, DS\_DestBaseCmd\_t::Basename, CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData\_t::DestFileTblHandle, DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_BASE\_CMD\_EID, DS\_BASE\_CMD\_ERR\_EID, DS\_TableVerifyFileIndex(), DS\_DestFileTable\_t::File, DS\_DestBaseCmd\_t::FileTableIndex, and CFE\_SB\_Msg::Msg.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



### 12.9.2.10 DS\_CmdSetDestCount()

```
void DS_CmdSetDestCount (
    const CFE_SB_Buffer_t * BufPtr )
```

Set data storage filename sequence count command handler.

#### Description

Modify the filename sequence count for the selected entry in the destination file definitions table. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid file table index
- generate error event if invalid filename sequence count
- generate error event if file table is not loaded Accept valid command packets
- update filename sequence count for selected file table entry
- generate success event (event type = debug)

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	BufPtr	Software Bus message pointer
----	--------	------------------------------

#### See also


[DS\\_SET\\_DEST\\_COUNT\\_CC](#), [DS\\_DestCountCmd\\_t](#)

Definition at line 1090 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_←GetSize(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_←\_AppData\_t::DestFileTblHandle, DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_SEQ\_CMD\_EID, DS\_SEQ\_CMD\_←\_ERR\_EID, DS\_TableUpdateCDS(), DS\_TableVerifyCount(), DS\_TableVerifyFileIndex(), DS\_DestFileTable\_t::File, D\_←S\_AppFileStatus\_t::FileCount, DS\_AppData\_t::FileStatus, DS\_DestCountCmd\_t::FileTableIndex, CFE\_SB\_Msg::Msg, DS\_DestFileEntry\_t::SequenceCount, and DS\_DestCountCmd\_t::SequenceCount.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



### 12.9.2.11 DS\_CmdSetDestExt()

```
void DS_CmdSetDestExt (
    const CFE_SB_Buffer_t * BufPtr )
```

Set data storage file extension command handler.

#### Description

Modify the extension portion of the filename for the selected entry in the destination file definitions table. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid file table index
- generate error event if invalid extension characters
- generate error event if file table is not loaded Accept valid command packets
- update file extension for selected file table entry
- generate success event (event type = debug)

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

## See also


[DS\\_SET\\_DEST\\_EXT\\_CC](#), [DS\\_DestExtCmd\\_t](#)

Definition at line 860 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData\_t::DestFileTblHandle, DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_EXT\_CMD\_EID, DS\_EXT\_CMD\_ERR\_EID, DS\_TableVerifyFileIndex(), DS\_DestFileEntry\_t::Extension, DS\_DestExtCmd\_t::Extension, DS\_DestFileTable\_t::File, DS\_DestExtCmd\_t::FileTableIndex, and CFE\_SB\_Msg::Msg.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



### 12.9.2.12 DS\_CmdSetDestPath()

```
void DS_CmdSetDestPath (
    const CFE_SB_Buffer_t * BufPtr )
```

Set data storage file pathname command handler.

#### Description

Modify the path portion of the filename for the selected entry in the destination file definitions table. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid file table index
- generate error event if invalid pathname characters

- generate error event if file table is not loaded Accept valid command packets
- update file pathname for selected file table entry
- generate success event (event type = debug)

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

**See also**


[DS\\_SET\\_DEST\\_PATH\\_CC](#), [DS\\_DestPathCmd\\_t](#)

Definition at line 720 of file `ds_cmds.c`.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData\_t::DestFileTblHandle, DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_PATH\_CMD\_EID, DS\_PATH\_CMD\_ERR\_EID, DS\_TableVerifyFileIndex(), DS\_DestFileTable\_t::File, DS\_DestPathCmd\_t::FileTableIndex, CFE\_SB\_Msg::Msg, DS\_DestFileEntry\_t::Pathname, and DS\_DestPathCmd\_t::Pathname.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:

**12.9.2.13 DS\_CmdSetDestSize()**

```
void DS_CmdSetDestSize (
    const CFE_SB_Buffer_t * BufPtr )
```

Set data storage file size limit command handler.

**Description**

Modify the max file size limit for the selected entry in the destination file definitions table. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid file table index
- generate error event if invalid file size limit
- generate error event if file table is not loaded Accept valid command packets
- update max size limit for selected file table entry
- generate success event (event type = debug)

**Assumptions, External Events, and Notes:**

(none)

#### Parameters

in	BufPtr	Software Bus message pointer
----	--------	------------------------------

#### See also


[DS\\_SET\\_DEST\\_SIZE\\_CC](#), [DS\\_DestSizeCmd\\_t](#)

Definition at line 930 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData\_t::DestFileTblHandle, DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_SIZE\_CMD\_EID, DS\_SIZE\_CM\_D\_ERR\_EID, DS\_TableVerifyFileIndex(), DS\_TableVerifySize(), DS\_DestFileTable\_t::File, DS\_DestSizeCmd\_t::FileTableIndex, DS\_DestFileEntry\_t::MaxFileSize, DS\_DestSizeCmd\_t::MaxFileSize, and CFE\_SB\_Msg::Msg.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



### 12.9.2.14 DS\_CmdSetDestState()

```
void DS_CmdSetDestState (
    const CFE_SB_Buffer_t * BufPtr )
```

Set data storage enable/disable state command handler.

#### Description

Modify the enable/disable state for the selected entry in the destination file definitions table. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid file table index
- generate error event if invalid enable/disable state
- generate error event if file table is not loaded Accept valid command packets
- update enable/disable state for selected file table entry
- generate success event (event type = debug)

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

#### See also


[DS\\_SET\\_DEST\\_STATE\\_CC](#), [DS\\_DestStateCmd\\_t](#)

Definition at line 641 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData\_t::DestFileTblHandle, DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_STATE\_CMD\_EID, DS\_STATE\_CMD\_ERR\_EID, DS\_TableVerifyFileIndex(), DS\_TableVerifyState(), DS\_DestFileEntry\_t::EnableState, DS\_DestStateCmd\_t::EnableState, DS\_DestFileTable\_t::File, DS\_AppFileStatus\_t::FileState, DS\_AppData\_t::FileStatus, DS\_DestStateCmd\_t::FileTableIndex, and CFE\_SB\_Msg::Msg.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



#### 12.9.2.15 DS\_CmdSetDestType()

```
void DS_CmdSetDestType (
    const CFE_SB_Buffer_t * BufPtr )
```

Set data storage filename type command handler.

##### Description

Modify the filename type for the selected entry in the destination file definitions table. Reject invalid command packets

- generate error event if invalid command packet length
- generate error event if invalid file table index
- generate error event if invalid filename type
- generate error event if file table is not loaded Accept valid command packets
- update filename type for selected file table entry
- generate success event (event type = debug)

##### Assumptions, External Events, and Notes:

(none)

**Parameters**

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

**See also**


[DS\\_SET\\_DEST\\_TYPE\\_CC](#), [DS\\_DestTypeCmd\\_t](#)

Definition at line 561 of file `ds_cmds.c`.

References `CFE_EVS_EventType_DEBUG`, `CFE_EVS_EventType_ERROR`, `CFE_EVS_SendEvent()`, `CFE_MSG_GetSize()`, `CFE_TBL_Modified()`, `DS_AppData_t::CmdAcceptedCounter`, `DS_AppData_t::CmdRejectedCounter`, `DS_AppData_t::DestFileTblHandle`, `DS_AppData_t::DestFileTblPtr`, `DS_AppData`, `DS_NTTYPE_CMD_EID`, `DS_NTTYPE_CMD_ERR_EID`, `DS_TableVerifyFileIndex()`, `DS_TableVerifyType()`, `DS_DestFileTable_t::File`, `DS_DestFileEntry_t::FileNameType`, `DS_DestTypeCmd_t::FileNameType`, `DS_DestTypeCmd_t::FileTableIndex`, and `CFE_SB_Msg::Msg`.

Referenced by `DS_AppProcessCmd()`.

Here is the call graph for this function:

**12.9.2.16 DS\_CmdSetFilterFile()**

```
void DS_CmdSetFilterFile (
    const CFE_SB_Buffer_t * BufPtr )
```

Set file index for filter table entry command handler.

## Description

Set destination file index for filter table entry command Validate command packet

- generate error event if invalid command packet length
- generate error event if invalid filter parameters index
- generate error event if invalid file table index
- generate error event if packet filter table is not loaded
- generate error event if message ID is not in filter table Process valid command packets
- update file index for selected filter table entry
- generate success event (event type = debug)

## Assumptions, External Events, and Notes:

(none)

## Parameters

in	<i>BuPtr</i>	Software Bus message pointer
----	--------------	------------------------------

## See also


[DS\\_SET\\_FILTER\\_FILE\\_CC](#), [DS\\_FilterFileCmd\\_t](#)

Definition at line 208 of file ds\_cmds.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_SB\_IsValidMsgId(), CFE\_SB\_MsgIdToValue(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData, DS\_FILE\_CMD\_EID, DS\_FILE\_CMD\_ERR\_EID, DS\_FILTERS\_PER\_PACKET, DS\_INDEX\_NONE, DS\_TableFindMsgID(), DS\_TableVerifyFileIndex(), DS\_FilterParms\_t::FileTableIndex, DS\_FilterFileCmd\_t::FileTableIndex, DS\_PacketEntry\_t::Filter, DS\_FilterFileCmd\_t::FilterParmsIndex, DS\_AppData\_t::FilterTblHandle, DS\_AppData\_t::FilterTblPtr, DS\_FilterFileCmd\_t::MessageID, CFE\_SB\_Msg::Msg, and DS\_FilterTable\_t::Packet.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



### 12.9.2.17 DS\_CmdSetFilterParms()

```
void DS_CmdSetFilterParms (
    const CFE_SB_Buffer_t * BufPtr )
```

Set filter parameters for filter table entry command handler.

#### Description

Set filter parameters for filter table entry command Validate command packet

- generate error event if invalid command packet length
- generate error event if invalid filter parameters index
- generate error event if invalid filter parameters
- generate error event if packet filter table is not loaded
- generate error event if message ID is not in filter table Process valid command packets
- update filter parameters for selected filter table entry
- generate success event (event type = debug)

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

#### See also


[DS\\_SET\\_FILTER\\_PARMS\\_CC](#), [DS\\_FilterParmsCmd\\_t](#)

Definition at line 440 of file ds\_cmds.c.

References DS\_FilterParms\_t::Algorithm\_N, DS\_FilterParmsCmd\_t::Algorithm\_N, DS\_FilterParms\_t::Algorithm\_O, DS\_FilterParmsCmd\_t::Algorithm\_O, DS\_FilterParms\_t::Algorithm\_X, DS\_FilterParmsCmd\_t::Algorithm\_X, CFE\_EVT\_S\_EventType\_DEBUG, CFE\_EVT\_EventType\_ERROR, CFE\_EVT\_SendEvent(), CFE\_MSG\_GetSize(), CFE\_SB\_IsValidMsgId(), CFE\_SB\_MsgIdToValue(), CFE\_TBL\_Modified(), DS\_AppData\_t::CmdAcceptedCounter, DS\_AppData\_t::CmdRejectedCounter, DS\_AppData, DS\_FILTERS\_PER\_PACKET, DS\_INDEX\_NONE, DS\_PARMS\_CMD\_EID, DS\_PARMS\_CMD\_ERR\_EID, DS\_TableFindMsgID(), DS\_TableVerifyParms(), DS\_PacketEntry\_t::Filter, DS\_FilterParmsCmd\_t::FilterParmsIndex, DS\_AppData\_t::FilterTblHandle, DS\_AppData\_t::FilterTblPtr, DS\_FilterParmsCmd\_t::MessageID, CFE\_SB\_Msg::Msg, and DS\_FilterTable\_t::Packet.

Referenced by DS\_AppProcessCmd().

Here is the call graph for this function:



#### 12.9.2.18 DS\_CmdSetFilterType()

```
void DS_CmdSetFilterType (
    const CFE_SB_Buffer_t * BufPtr )
```

Set filter type for filter table entry command handler.

##### Description

Set filter type for filter table entry command Validate command packet

- generate error event if invalid command packet length
- generate error event if invalid filter parameters index
- generate error event if invalid filter type
- generate error event if packet filter table is not loaded
- generate error event if message ID is not in filter table Process valid command packets
- update filter type for selected filter table entry
- generate success event (event type = debug)

##### Assumptions, External Events, and Notes:

(none)

##### Parameters

in	<i>BufPtr</i>	Software Bus message pointer
----	---------------	------------------------------

## See also


[DS\\_SET\\_FILTER\\_TYPE\\_CC](#), [DS\\_FilterTypeCmd\\_t](#)

Definition at line 324 of file `ds_cmds.c`.

References `CFE_EVS_EventType_DEBUG`, `CFE_EVS_EventType_ERROR`, `CFE_EVS_SendEvent()`, `CFE_MSG_GetSize()`, `CFE_SB_IsValidMsgId()`, `CFE_SB_MsgIdToValue()`, `CFE_TBL_Modified()`, `DS_AppData_t::CmdAcceptedCounter`, `DS_AppData_t::CmdRejectedCounter`, `DS_AppData`, `DS_FILTERS_PER_PACKET`, `DS_FTYPING_CMD_EID`, `DS_FTYPING_CMD_ERR_EID`, `DS_INDEX_NONE`, `DS_TableFindMsgID()`, `DS_TableVerifyType()`, `DS_PacketEntry_t::Filter`, `DS_FilterTypeCmd_t::FilterParmsIndex`, `DS_AppData_t::FilterTblHandle`, `DS_AppData_t::FilterTblPtr`, `DS_FilterParms_t::FilterType`, `DS_FilterTypeCmd_t::FilterType`, `DS_FilterTypeCmd_t::MessageID`, `CFE_SB_Msg::Msg`, and `DS_FilterTable_t::Packet`.

Referenced by `DS_AppProcessCmd()`.

Here is the call graph for this function:



## 12.10 apps/ds/fsw/src/ds\_events.h File Reference

## Macros

- `#define DS_INIT_EID 1`  
`DS Initialization Event ID.`
- `#define DS_INIT_ERR_EID 2`  
`DS Initialization Failed Event ID.`
- `#define DS_EXIT_ERR_EID 3`  
`DS App Termination Event ID.`
- `#define DS_INIT_CDS_ERR_EID 6`  
`DS Critical Data Store Initialization Failed Event ID.`
- `#define DS_INIT_TBL_CDS_EID 7`  
`DS Critical Data Store Table Restore Event ID.`
- `#define DS_INIT_TBL_ERR_EID 8`  
`DS Initialize Table Failed Event ID.`

- #define **DS\_FIL\_TBL\_EID** 10  
*DS Destination Table Validation Results Event ID.*
- #define **DS\_FIL\_TBL\_ERR\_EID** 11  
*DS Destination Table Validation Failed Event ID.*
- #define **DS\_FLT\_TBL\_EID** 12  
*DS Filter Table Validation Results Event ID.*
- #define **DS\_FLT\_TBL\_ERR\_EID** 13  
*DS Filter Table Validation Failed Event ID.*
- #define **DS\_FILE\_NAME\_ERR\_EID** 14  
*DS File Name Failed Event ID.*
- #define **DS\_CREATE\_FILE\_ERR\_EID** 15  
*DS File Create Failed Event ID.*
- #define **DS\_WRITE\_FILE\_ERR\_EID** 16  
*DS File Write Failed Event ID.*
- #define **DS\_CMD\_CODE\_ERR\_EID** 21  
*DS Invalid Command Code Event ID.*
- #define **DS\_HK\_REQUEST\_ERR\_EID** 22  
*DS Housekeeping Request Invalid Length Event ID.*
- #define **DS\_NOOP\_CMD\_EID** 31  
*DS No-op Command Event ID.*
- #define **DS\_NOOP\_CMD\_ERR\_EID** 32  
*DS No-op Command Invalid Length Event ID.*
- #define **DS\_RESET\_CMD\_EID** 33  
*DS Reset Counters Command Event ID.*
- #define **DS\_RESET\_CMD\_ERR\_EID** 34  
*DS Reset Counters Command Invalid Length Event ID.*
- #define **DS\_ENADIS\_CMD\_EID** 35  
*DS Application Enable/Disable State Command Event ID.*
- #define **DS\_ENADIS\_CMD\_ERR\_EID** 36  
*DS Application Enable/Disable State Command Invalid Event ID.*
- #define **DS\_FILE\_CMD\_EID** 37  
*DS Set Filter File Index Command Event ID.*
- #define **DS\_FILE\_CMD\_ERR\_EID** 38  
*DS Set Filter File Index Command Invalid Event ID.*
- #define **DS\_FTYPE\_CMD\_EID** 39  
*DS Set Filter Type Command Event ID.*
- #define **DS\_FTYPE\_CMD\_ERR\_EID** 40  
*DS Set Filter Type Command Invalid Event ID.*
- #define **DS\_PARMS\_CMD\_EID** 41  
*DS Set Filter Parameters Command Event ID.*
- #define **DS\_PARMS\_CMD\_ERR\_EID** 42  
*DS Set Filter Parameters Command Invalid Event ID.*
- #define **DS\_NTYPE\_CMD\_EID** 43  
*DS Set Filename Type Command Event ID.*
- #define **DS\_NTYPE\_CMD\_ERR\_EID** 44  
*DS Set Filename Type Command Invalid Event ID.*
- #define **DS\_STATE\_CMD\_EID** 45

- #define DS\_STATE\_CMD\_ERR\_EID 46
  - DS Set File Enable/Disable State Command Event ID.
- #define DS\_PATH\_CMD\_EID 47
  - DS Set File Enable/Disable State Command Invalid Event ID.
- #define DS\_PATH\_CMD\_ERR\_EID 48
  - DS Set Filename Path Command Event ID.
- #define DS\_BASE\_CMD\_EID 49
  - DS Set Filename Path Command Invalid Event ID.
- #define DS\_BASE\_CMD\_ERR\_EID 50
  - DS Set File Basename Command Event ID.
- #define DS\_EXT\_CMD\_EID 51
  - DS Set File Basename Command Invalid Event ID.
- #define DS\_EXT\_CMD\_ERR\_EID 52
  - DS Set Filename Extension Command Event ID.
- #define DS\_SIZE\_CMD\_EID 53
  - DS Set Max File Size Command Event ID.
- #define DS\_SIZE\_CMD\_ERR\_EID 54
  - DS Set Max File Size Command Invalid Event ID.
- #define DS\_AGE\_CMD\_EID 55
  - DS Set Max File Age Command Event ID.
- #define DS\_AGE\_CMD\_ERR\_EID 56
  - DS Set Max File Age Command Invalid Event ID.
- #define DS\_SEQ\_CMD\_EID 57
  - DS Set Sequence Count Command Event ID.
- #define DS\_SEQ\_CMD\_ERR\_EID 58
  - DS Set Sequence Count Command Invalid Event ID.
- #define DS\_CLOSE\_CMD\_EID 59
  - DS Close Destination File Command Event ID.
- #define DS\_CLOSE\_CMD\_ERR\_EID 60
  - DS Close Destination File Command Invalid Event ID.
- #define DS\_MOVE\_FILE\_ERR\_EID 61
  - DS File Move Failed Event ID.
- #define DS\_GET\_FILE\_INFO\_CMD\_EID 62
  - DS Get File Info Command Event ID.
- #define DS\_GET\_FILE\_INFO\_CMD\_ERR\_EID 63
  - DS Get File Info Command Invalid Event ID.
- #define DS\_ADD\_MID\_CMD\_EID 64
  - DS Add Message ID to Filter Table Command Event ID.
- #define DS\_ADD\_MID\_CMD\_ERR\_EID 65
  - DS Add Message ID to Filter Table Command Invalid Event ID.
- #define DS\_CLOSE\_ALL\_CMD\_EID 66
  - DS Close All Destination Files Command Event ID.
- #define DS\_CLOSE\_ALL\_CMD\_ERR\_EID 67
  - DS Close All Destination Files Command Invalid Event ID.
- #define DS\_FILE\_CREATE\_EMPTY\_PATH\_ERR\_EID 68
  - DS File Create Invalid Name Event ID.

- #define DS\_APPHK\_FILTER\_TBL\_ERR\_EID 69  
*DS Filter Table Name Invalid Event ID.*
- #define DS\_APPHK\_FILTER\_TBL\_PRINT\_ERR\_EID 70  
*DS Filter Table Name Create Failed Event ID.*

#### 12.10.1 Detailed Description

The CFS Data Storage (DS) Application event id header file

#### 12.11 apps/ds/fsw/src/ds\_file.c File Reference

```
#include "cfe.h"
#include "cfe_fs.h"
#include "ds_platform_cfg.h"
#include "ds_verify.h"
#include "ds_appdefs.h"
#include "ds_msgids.h"
#include "ds_msg.h"
#include "ds_app.h"
#include "ds_file.h"
#include "ds_table.h"
#include "ds_events.h"
#include <stdio.h>
```

#### Macros

- #define DS\_PKT\_SEQUENCE\_BASED\_FILTER\_TYPE 1
- #define DS\_PKT\_TIME\_BASED\_FILTER\_TYPE 2
- #define DS\_16\_MSB\_SUBSECS\_SHIFT 16
- #define DS\_11\_LSB\_SECONDS\_MASK 0x07FF
- #define DS\_11\_LSB\_SECONDS\_SHIFT 4
- #define DS\_4\_MSB\_SUBSECS\_MASK 0xF000
- #define DS\_4\_MSB\_SUBSECS\_SHIFT 12
- #define CFE\_YYYY\_INDEX 0
- #define CFE\_DDD\_INDEX 5
- #define CFE\_HH\_INDEX 9
- #define CFE\_MM\_INDEX 12
- #define CFE\_SS\_INDEX 15
- #define CFE\_ssss\_INDEX 18
- #define DS\_YYYY\_INDEX 0
- #define DS\_DDD\_INDEX 4
- #define DS\_HH\_INDEX 7
- #define DS\_MM\_INDEX 9
- #define DS\_SS\_INDEX 11
- #define DS\_TERM\_INDEX 13

## Functions

- bool `DS_IsPacketFiltered (CFE_MSG_Message_t *MessagePtr, uint16 FilterType, uint16 Algorithm_N, uint16 Algorithm_X, uint16 Algorithm_O)`  
*Determine whether Software Bus message packet is filtered.*
- void `DS_FileStorePacket (CFE_SB_MsgId_t MessageID, const CFE_SB_Buffer_t *BufPtr)`  
*Data Storage packet processor.*
- void `DS_FileSetupWrite (int32 FileIndex, const CFE_SB_Buffer_t *BufPtr)`  
*Prepare to write to a data storage destination file.*
- void `DS_FileWriteData (int32 FileIndex, const void *FileData, uint32 DataLength)`  
*Write data (packet) to file.*
- void `DS_FileWriteHeader (int32 FileIndex)`  
*Write data storage file header.*
- void `DS_FileWriteError (uint32 FileIndex, uint32 DataLength, int32 WriteResult)`  
*File write error handler.*
- void `DS_FileCreateDest (uint32 FileIndex)`  
*Create a new data storage destination file.*
- void `DS_FileCreateName (uint32 FileIndex)`  
*Construct the next filename for a destination file.*
- void `DS_FileCreateSequence (char *Buffer, uint32 Type, uint32 Count)`  
*Construct the sequence portion of a filename.*
- void `DS_FileUpdateHeader (int32 FileIndex)`  
*Update destination file header (prior to closing)*
- void `DS_FileCloseDest (int32 FileIndex)`  
*Close selected destination file.*
- void `DS_FileTestAge (uint32 ElapsedSeconds)`  
*File age processor.*
- void `DS_FileTransmit (DS_AppFileStatus_t *FileStatus)`  
*Transmit file information telemetry handler.*

### 12.11.1 Detailed Description

CFS Data Storage (DS) file functions

### 12.11.2 Macro Definition Documentation

#### 12.11.2.1 CFE\_DDD\_INDEX

```
#define CFE_DDD_INDEX 5
```

Referenced by DS\_FileCreateSequence().

**12.11.2.2 CFE\_HH\_INDEX**

```
#define CFE_HH_INDEX 9
```

Referenced by DS\_FileCreateSequence().

**12.11.2.3 CFE\_MM\_INDEX**

```
#define CFE_MM_INDEX 12
```

Referenced by DS\_FileCreateSequence().

**12.11.2.4 CFE\_SS\_INDEX**

```
#define CFE_SS_INDEX 15
```

Referenced by DS\_FileCreateSequence().

**12.11.2.5 CFE\_ssss\_INDEX**

```
#define CFE_ssss_INDEX 18
```

**12.11.2.6 CFE\_YYYY\_INDEX**

```
#define CFE_YYYY_INDEX 0
```

**12.11.2.7 DS\_11\_LSB\_SECONDS\_MASK**

```
#define DS_11_LSB_SECONDS_MASK 0x07FF
```

Definition at line 46 of file ds\_file.c.

Referenced by DS\_IsPacketFiltered().

**12.11.2.8 DS\_11\_LSB\_SECONDS\_SHIFT**

```
#define DS_11_LSB_SECONDS_SHIFT 4
```

Definition at line 47 of file ds\_file.c.

Referenced by DS\_IsPacketFiltered().

**12.11.2.9 DS\_16\_MSB\_SUBSECS\_SHIFT**

```
#define DS_16_MSB_SUBSECS_SHIFT 16
```

Definition at line 45 of file ds\_file.c.

Referenced by DS\_IsPacketFiltered().

**12.11.2.10 DS\_4\_MSB\_SUBSECS\_MASK**

```
#define DS_4_MSB_SUBSECS_MASK 0xF000
```

Definition at line 48 of file ds\_file.c.

Referenced by DS\_IsPacketFiltered().

**12.11.2.11 DS\_4\_MSB\_SUBSECS\_SHIFT**

```
#define DS_4_MSB_SUBSECS_SHIFT 12
```

Definition at line 49 of file ds\_file.c.

Referenced by DS\_IsPacketFiltered().

**12.11.2.12 DS\_DDD\_INDEX**

```
#define DS_DDD_INDEX 4
```

Referenced by DS\_FileCreateSequence().

**12.11.2.13 DS\_HH\_INDEX**

```
#define DS_HH_INDEX 7
```

Referenced by DS\_FileCreateSequence().

**12.11.2.14 DS\_MM\_INDEX**

```
#define DS_MM_INDEX 9
```

Referenced by DS\_FileCreateSequence().

**12.11.2.15 DS\_PKT\_SEQUENCE\_BASED\_FILTER\_TYPE**

```
#define DS_PKT_SEQUENCE_BASED_FILTER_TYPE 1
```

Definition at line 42 of file ds\_file.c.

Referenced by DS\_IsPacketFiltered().

**12.11.2.16 DS\_PKT\_TIME\_BASED\_FILTER\_TYPE**

```
#define DS_PKT_TIME_BASED_FILTER_TYPE 2
```

Definition at line 43 of file ds\_file.c.

Referenced by DS\_IsPacketFiltered().

**12.11.2.17 DS\_SS\_INDEX**

```
#define DS_SS_INDEX 11
```

Referenced by DS\_FileCreateSequence().

**12.11.2.18 DS\_TERM\_INDEX**

```
#define DS_TERM_INDEX 13
```

Referenced by DS\_FileCreateSequence().

### 12.11.2.19 DS\_YYYY\_INDEX

```
#define DS_YYYY_INDEX 0
```

### 12.11.3 Function Documentation

#### 12.11.3.1 DS\_FileCloseDest()

```
void DS_FileCloseDest (
    int32 FileIndex )
```

Close selected destination file.

##### Description

This function may be called from the DS Close File command handler, from the file age processor, from the file size processor and from the file write error handler. The function closes the selected destination file and updates the file status data to indicate that the file handle is not in use and that the file age, size and name fields are reset.

##### Assumptions, External Events, and Notes:

(none)

##### Parameters


in	<i>FileIndex</i>	Destination file index
----	------------------	------------------------

Definition at line 880 of file ds\_file.c.

References CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_FileTransmit(), DS\_MOVE\_FILE\_ERR\_EID, DS\_TOTAL\_FNAME\_BUFSIZE, DS\_DestFileTable\_t::File, DS\_App←FileStatus\_t::FileAge, DS\_AppFileStatus\_t::FileHandle, DS\_AppFileStatus\_t::FileName, DS\_AppFileStatus\_t::FileSize, DS\_AppData\_t::FileStatus, DS\_DestFileEntry\_t::Movename, OS\_close(), OS\_mv(), OS\_OBJECT\_ID\_UNDEFINED, and OS\_SUCCESS.

Referenced by DS\_CmdCloseAll(), DS\_CmdCloseFile(), DS\_FileSetupWrite(), DS\_FileTestAge(), and DS\_FileWrite←Error().

Here is the call graph for this function:



### 12.11.3.2 DS\_FileCreateDest()

```
void DS_FileCreateDest (
    uint32 FileIndex )
```

Create a new data storage destination file.

#### Description

This function is called when a packet has passed the filter test and the destination file does not exist. The file may not yet have been created - if this is the first packet for this destination to pass the filter test - or the previous file may have been closed by command or file size/age test. Note that destination files are not created until there is a packet ready to be written.

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>FileIndex</i>	Destination file index
----	------------------	------------------------


Definition at line 492 of file `ds_file.c`.

References `CFE_EVS_EventType_ERROR`, `CFE_EVS_SendEvent()`, `CFE_SUCCESS`, `DS_AppData_t::DestFileTbl` ↵ `Ptr`, `DS_AppData`, `DS_BY_COUNT`, `DS_CREATE_FILE_ERR_EID`, `DS_DISABLED`, `DS_FileCreateName()`, `DS_File` ↵ `WriteHeader()`, `DS_MAX_SEQUENCE_COUNT`, `DS_STRING_TERMINATOR`, `DS_TableUpdateCDS()`, `DS_DestFile` ↵ `Table_t::File`, `DS_AppFileStatus_t::FileCount`, `DS_AppFileStatus_t::FileHandle`, `DS_AppFileStatus_t::FileName`, `D` ↵ `S_DestFileEntry_t::FileNameType`, `DS_AppFileStatus_t::FileState`, `DS_AppData_t::FileStatus`, `DS_AppData_t::File` ↵ `WriteCounter`, `DS_AppData_t::FileWriteErrCounter`, `OS_FILE_FLAG_CREATE`, `OS_FILE_FLAG_TRUNCATE`, `OS` ↵

OBJECT\_ID\_UNDEFINED, OS\_ObjectIdDefined(), OS\_OpenCreate(), OS\_READ\_WRITE, OS\_SUCCESS, and DS\_DestFileEntry\_t::SequenceCount.

Referenced by DS\_FileSetupWrite().

Here is the call graph for this function:



### 12.11.3.3 DS\_FileCreateName()

```
void DS_FileCreateName (
    uint32 FileIndex )
```

Construct the next filename for a destination file.

#### Description

The filename is constructed using data from the Destination File Table. First, the pathname and basename fields from the table are combined. Then, based on the filename type from the table, a sequence string is created and appended to the filename. Finally, the file extension from the table is appended to complete the filename.

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>FileIndex</i>	Destination file index
----	------------------	------------------------

## See also


[DS\\_DestFileEntry\\_t](#)

Definition at line 572 of file ds\_file.c.

References DS\_DestFileEntry\_t::Basename, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_DISABLED, DS\_FILE\_CREATE\_EMPTY\_PATH\_ERR\_EID, DS\_FILE\_NAME\_ERR\_EID, DS\_FileCreateSequence(), DS\_PATH\_SEPARATOR, DS\_STRING\_TERMINATOR, DS\_TOTAL\_FNAM\_E\_BUFSIZE, DS\_DestFileEntry\_t::Extension, DS\_DestFileTable\_t::File, DS\_AppFileStatus\_t::FileCount, DS\_AppFileStatus\_t::FileName, DS\_DestFileEntry\_t::FileNameType, DS\_AppFileStatus\_t::FileState, DS\_AppData\_t::FileStatus, and DS\_DestFileEntry\_t::Pathname.

Referenced by DS\_FileCreateDest().

Here is the call graph for this function:



#### 12.11.3.4 DS\_FileCreateSequence()

```
void DS_FileCreateSequence (
    char * Buffer,
    uint32 Type,
    uint32 Count )
```

Construct the sequence portion of a filename.

##### Description

The filename sequence string will be constructed to contain either the current date and time, or a file sequence count value. If the filename type is "time" then the sequence string will have the format "YYYYDDDHHMMSS". Or, if the filename type is "count" then the sequence string will be a fixed number of text digits, where the string length is a platform defined value.

##### Assumptions, External Events, and Notes:

(none)

## Parameters

in	<i>Buffer</i>	Pointer to buffer for sequence portion of filename
in	<i>Type</i>	Filename type (date and time vs sequence count)
in	<i>Count</i>	Sequence counter (used only if type is sequence)

## See also


[DS\\_DestFileEntry\\_t](#)

Definition at line 706 of file ds\_file.c.

References CFE\_DDD\_INDEX, CFE\_HH\_INDEX, CFE\_MM\_INDEX, CFE\_SS\_INDEX, CFE\_TIME\_GetTime(), CFE←\_TIME\_Print(), DS\_BY\_COUNT, DS\_BY\_TIME, DS\_DDD\_INDEX, DS\_HH\_INDEX, DS\_MM\_INDEX, DS\_SEQUEN←CE\_DIGITS, DS\_SS\_INDEX, DS\_STRING\_TERMINATOR, and DS\_TERM\_INDEX.

Referenced by DS\_FileCreateName().

Here is the call graph for this function:



## 12.11.3.5 DS\_FileSetupWrite()

```
void DS_FileSetupWrite (
    int32 FileIndex,
    const CFE_SB_Buffer_t * BufPtr )
```

Prepare to write to a data storage destination file.

### Description

This function is called for packets that have passed the common CFS filter algorithm. The function first queries the packet length and determines whether writing the packet to an existing data storage file would exceed the max file size limit. If so, the existing destination file header is updated and the file is closed. Then the function determines whether a new file needs to be opened and if so, creates the file. Files may be closed due to size or by command, and files may have not yet been created because this is the first packet destined for that file. Next step: write data to file.

### Assumptions, External Events, and Notes:

(none)

## Parameters

in	<i>FileIndex</i>	Destination file index
in	<i>BufPtr</i>	Software Bus message pointer

#### See also


`DS_AppFileStatus_t`, `DS_DestFileEntry_t`

Definition at line 274 of file `ds_file.c`.

References CFE\_MSG\_GetSize(), DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_FileCloseDest(), DS\_FileCreateDest(), DS\_FileUpdateHeader(), DS\_FileWriteData(), DS\_DestFileTable\_t::File, DS\_AppFileStatus\_t::FileHandle, DS\_AppFileStatus\_t::FileSize, DS\_AppData\_t::FileStatus, DS\_DestFileEntry\_t::MaxFileSize, CFE\_SB\_Msg\_t::Msg, and OS\_ObjectIdDefined().

Referenced by DS\_FileStorePacket().

Here is the call graph for this function:



### 12.11.3.6 DS\_FileStorePacket()

```
void DS_FileStorePacket (
    CFE_SB_MsgId_t MessageID,
    const CFE_SB_Buffer_t * BufPtr )
```

Data Storage packet processor.

#### Description

This function searches for a packet filter table entry that matches the input argument Message ID. If no matching packet filter table entry is found, the packet referenced via the Message Pointer is discarded (filtered). When a matching packet table entry is found, each of the multiple filters defined for the packet are tested by applying the common CFS filter algorithm to the table defined filter parameters. Packets that are passed by any filter continue with the write process. Next step: prepare to write data to a file.

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>MessageID</i>	Message ID
in	<i>BufPtr</i>	Software Bus message pointer

#### See also


[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 188 of file `ds_file.c`.

References `DS_FilterParms_t::Algorithm_N`, `DS_FilterParms_t::Algorithm_O`, `DS_FilterParms_t::Algorithm_X`, `DS_AppData`, `DS_DEST_FILE_CNT`, `DS_ENABLED`, `DS_FileSetupWrite()`, `DS_FILTERS_PER_PACKET`, `DS_INDEX_NONE`, `DS_IsPacketFiltered()`, `DS_TableFindMsgID()`, `DS_UNUSED`, `DS_AppFileStatus_t::FileState`, `DS_AppData_t::FileStatus`, `DS_FilterParms_t::FileTableIndex`, `DS_PacketEntry_t::Filter`, `DS_AppData_t::FilteredPktCounter`, `DS_AppData_t::FilterTblPtr`, `DS_FilterParms_t::FilterType`, `DS_AppData_t::IgnoredPktCounter`, `DS_FilterTable_t::Packet`, and `DS_AppData_t::PassedPktCounter`.

Referenced by `DS_AppStorePacket()`.

Here is the call graph for this function:



### 12.11.3.7 DS\_FileTestAge()

```
void DS_FileTestAge (
```

## File age processor.

## Description

This function is called upon receipt of the DS 1Hz command (if defined) or upon receipt of the DS housekeeping request command (if the 1Hz cmd is not defined). The function increments the elapsed file age for all open data storage files by the amount specified. Files that exceed the age limit set in the destination file definition table will be closed. If this destination remains enabled, another file will be opened when the next packet is written to this destination.

## Assumptions, External Events, and Notes:

(none)

## Parameters


in	<i>ElapsedSeconds</i>	Elapsed seconds since previous call
----	-----------------------	-------------------------------------

Definition at line 1002 of file ds\_file.c.

References DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_DEST\_FILE\_CNT, DS\_FileCloseDest(), DS\_FileUpdateHeader(), DS\_DestFileTable\_t::File, DS\_AppFileStatus\_t::FileAge, DS\_AppFileStatus\_t::FileHandle, DS\_AppData\_t::FileStatus, DS\_DestFileEntry\_t::MaxFileAge, and OS\_ObjectIdDefined().

Referenced by DS\_AppMain(), and DS\_AppProcessHK().

Here is the call graph for this function:



### 12.11.3.8 DS\_FileTransmit()

```
void DS_FileTransmit (
    DS_AppFileStatus_t * FileStatus )
```

Transmit file information telemetry handler.

#### Description

Create and send a telemetry packet containing the current status for a closed destination file.

#### Assumptions, External Events, and Notes:

(none)

**Parameters**

in	<i>FileStatus</i>	Current state of destination file
----	-------------------	-----------------------------------

**See also**


[DS\\_FileCompletePktBuf\\_t](#)

Definition at line 1045 of file ds\_file.c.

References CFE\_MSG\_Init(), CFE\_SB\_AllocateMessageBuffer(), CFE\_SB\_TimeStampMsg(), CFE\_SB\_TransmitBuffer(), CFE\_SB\_ValueToMsgId(), DS\_CLOSED, DS\_COMP\_TLM\_MID, DS\_FileInfo\_t::EnableState, DS\_AppFileStatus\_t::FileAge, DS\_FileInfo\_t::FileAge, DS\_AppFileStatus\_t::FileCount, DS\_FileCompletePkt\_t::FileInfo, DS\_AppFileStatus\_t::FileName, DS\_FileInfo\_t::FileName, DS\_AppFileStatus\_t::FileRate, DS\_FileInfo\_t::FileRate, DS\_AppFileStatus\_t::FileSize, DS\_FileInfo\_t::FileSize, DS\_AppFileStatus\_t::FileState, DS\_FileInfo\_t::OpenState, DS\_FileCompletePktBuf\_t::Pkt, DS\_FileCompletePktBuf\_t::SBBuf, DS\_FileInfo\_t::SequenceCount, and DS\_FileCompletePkt\_t::TlmHeader.

Referenced by DS\_FileCloseDest().

Here is the call graph for this function:



### 12.11.3.9 DS\_FileUpdateHeader()

```
void DS_FileUpdateHeader (
    int32 FileIndex )
```

Update destination file header (prior to closing)

#### Description

This function is called just before closing a data storage destination file. The purpose of the function is to update portions of the file header that cannot be known in advance, such as the file size or the file close time. During the update process, seek and write errors are counted but otherwise ignored as the file is about to be closed.

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>FileIndex</i>	Destination file index
----	------------------	------------------------

#### See also


[DS\\_FileWriteHeader](#)

Definition at line 840 of file ds\_file.c.

References CFE\_SUCCESS, CFE\_TIME\_GetTime(), DS\_AppData, DS\_AppFileStatus\_t::FileHandle, DS\_AppData\_t::FileStatus, DS\_AppData\_t::FileUpdateCounter, DS\_AppData\_t::FileUpdateErrCounter, OS\_Iseek(), OS\_SEEK\_SET, and OS\_write().

Referenced by DS\_CmdCloseAll(), DS\_CmdCloseFile(), DS\_FileSetupWrite(), and DS\_FileTestAge().

Here is the call graph for this function:



### 12.11.3.10 DS\_FileWriteData()

```
void DS_FileWriteData (
    int32 FileIndex,
    const void * FileData,
    uint32 DataLength )
```

Write data (packet) to file.

#### Description

This function writes data to an existing data storage destination file and updates the associated data rate counters. If necessary, the function will invoke a file write error handler.

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>FileIndex</i>	Destination file index
in	<i>FileData</i>	Pointer to packet data
in	<i>DataLength</i>	Length of packet data

#### See also


[DS\\_AppFileStatus\\_t](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 349 of file ds\_file.c.

References CFE\_SUCCESS, DS\_AppData, DS\_FileWriteError(), DS\_AppFileStatus\_t::FileGrowth, DS\_AppFileStatus\_t::FileHandle, DS\_AppFileStatus\_t::FileSize, DS\_AppData\_t::FileStatus, DS\_AppData\_t::FileWriteCounter, and OS\_write().

Referenced by DS\_FileSetupWrite().

Here is the call graph for this function:



### 12.11.3.11 DS\_FileWriteError()

```
void DS_FileWriteError (
    uint32 FileIndex,
    uint32 DataLength,
    int32 WriteResult )
```

File write error handler.

#### Description

This function is called upon detection of a file I/O error that occurred while writing to a data storage destination file. The function sends an event describing the error, closes the file and disables the destination. If DS tables have been defined as "critical", the version of the table in the Critical Data Store (CDS) will be updated to reflect the change in enable/disable state for the destination.

#### Assumptions, External Events, and Notes:

(none)

#### Parameters


in	<i>FileIndex</i>	Destination file index
in	<i>DataLength</i>	Length of data being written to file
in	<i>WriteResult</i>	Result of file write

Definition at line 466 of file ds\_file.c.

References CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), DS\_AppData, DS\_DISABLED, DS\_FileCloseDest(), DS\_WRITE\_FILE\_ERR\_EID, DS\_AppFileStatus\_t::FileName, DS\_AppFileStatus\_t::FileState, DS\_AppData\_t::FileStatus, and DS\_AppData\_t::FileWriteErrCounter.

Referenced by DS\_FileWriteData(), and DS\_FileWriteHeader().

Here is the call graph for this function:



### 12.11.3.12 DS\_FileWriteHeader()

```
void DS_FileWriteHeader (
    int32 FileIndex )
```

Write data storage file header.

#### Description

This function is called just after opening a new data storage destination file. The purpose of the function is to write a file header and initialize those elements in the file header that can be known in advance, such as the filename or file type. Any seek or write errors will result in the execution of the common file write error handler.

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>FileIndex</i>	Destination file index
----	------------------	------------------------

#### See also


[DS\\_FileUpdateHeader](#)

Definition at line 386 of file ds\_file.c.

References CFE\_FS\_WriteHeader(), CFE\_SUCCESS, CFE\_FS\_Header::Description, DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_FILE\_HDR\_DESCRIPTION, DS\_FILE\_HDR\_SUBTYPE, DS\_FileWriteError(), DS\_DestFileTable<\_t::File, DS\_AppFileStatus\_t::FileGrowth, DS\_AppFileStatus\_t::FileHandle, DS\_FileHeader\_t::FileName, DS\_AppFileStatus\_t::FileName, DS\_FileHeader\_t::FileNameType, DS\_DestFileEntry\_t::FileNameType, DS\_AppFileStatus\_t::FileSize, DS\_AppData\_t::FileStatus, DS\_FileHeader\_t::FileTableIndex, DS\_AppData\_t::FileWriteCounter, OS\_write(), and CFE\_FS\_Header::SubType.

Referenced by DS\_FileCreateDest().

Here is the call graph for this function:



### 12.11.3.13 DS\_IsPacketFiltered()

```
bool DS_IsPacketFiltered (
    CFE_MSG_Message_t * MessagePtr,
    uint16 FilterType,
    uint16 Algorithm_N,
    uint16 Algorithm_X,
    uint16 Algorithm_O )
```

Determine whether Software Bus message packet is filtered.

#### Description

This routine will apply the DS filter algorithm to the packet to determine whether the packet should be filtered.

#### Assumptions, External Events, and Notes:

None

#### Parameters

in	<i>MessagePtr</i>	Pointer to a Software Bus message packet
in	<i>FilterType</i>	Packet sequence count (1) or timestamp (2)
in	<i>Algorithm_N</i>	Algorithm parameter N "pass this many"
in	<i>Algorithm_X</i>	Algorithm parameter X "out of this many"
in	<i>Algorithm_O</i>	Algorithm parameter O "at this offset"

#### Returns

Boolean packet filtered response

#### Return values


<i>true</i>	The packet should be filtered (not used)
<i>false</i>	The packet should not be filtered (used)

Definition at line 56 of file ds\_file.c.

References CFE\_MSG\_GetMsgTime(), CFE\_MSG\_GetSequenceCount(), DS\_11 LSB\_SECONDS\_MASK, DS\_11 LSB\_SECONDS\_SHIFT, DS\_16 MSB\_SUBSECS\_SHIFT, DS\_4 MSB\_SUBSECS\_MASK, DS\_4 MSB\_SUBSECS SHIFT, DS\_PKT\_SEQUENCE\_BASED\_FILTER\_TYPE, DS\_PKT\_TIME\_BASED\_FILTER\_TYPE, CFE\_TIME\_SysTime::Seconds, and CFE\_TIME\_SysTime::Subseconds.

Referenced by DS\_FileStorePacket().

Here is the call graph for this function:



## 12.12 apps/ds/fsw/src/ds\_file.h File Reference

```
#include "cfe.h"
#include "ds_platform_cfg.h"
```

### Data Structures

- struct `DS_FileHeader_t`  
*DS File Header (follows cFE file header at start of file)*

### Functions

- void `DS_FileStorePacket` (`CFE_SB_MsgId_t` MessageID, const `CFE_SB_Buffer_t` \*BufPtr)  
*Data Storage packet processor.*
- void `DS_FileSetupWrite` (`int32` FileIndex, const `CFE_SB_Buffer_t` \*BufPtr)  
*Prepare to write to a data storage destination file.*
- void `DS_FileWriteData` (`int32` FileIndex, const `void` \*FileData, `uint32` DataLength)  
*Write data (packet) to file.*
- void `DS_FileWriteHeader` (`int32` FileIndex)  
*Write data storage file header.*
- void `DS_FileWriteError` (`uint32` FileIndex, `uint32` DataLength, `int32` WriteResult)  
*File write error handler.*
- void `DS_FileCreateDest` (`uint32` FileIndex)  
*Create a new data storage destination file.*
- void `DS_FileCreateName` (`uint32` FileIndex)  
*Construct the next filename for a destination file.*
- void `DS_FileCreateSequence` (`char` \*Buffer, `uint32` Type, `uint32` Count)  
*Construct the sequence portion of a filename.*
- void `DS_FileUpdateHeader` (`int32` FileIndex)  
*Update destination file header (prior to closing)*
- void `DS_FileCloseDest` (`int32` FileIndex)

- Close selected destination file.*
- void [DS\\_FileTestAge](#) (uint32 ElapsedSeconds)

*File age processor.*

  - void [DS\\_FileTransmit](#) (DS\_AppFileStatus\_t \*FileStatus)

*Transmit file information telemetry handler.*

  - bool [DS\\_IsPacketFiltered](#) (CFE\_MSG\_Message\_t \*MessagePtr, uint16 FilterType, uint16 Algorithm\_N, uint16 Algorithm\_X, uint16 Algorithm\_O)

*Determine whether Software Bus message packet is filtered.*

### 12.12.1 Detailed Description

CFS Data Storage (DS) file storage header file

### 12.12.2 Function Documentation

#### 12.12.2.1 DS\_FileCloseDest()

```
void DS_FileCloseDest (
    int32 FileIndex )
```

Close selected destination file.

##### Description

This function may be called from the DS Close File command handler, from the file age processor, from the file size processor and from the file write error handler. The function closes the selected destination file and updates the file status data to indicate that the file handle is not in use and that the file age, size and name fields are reset.

##### Assumptions, External Events, and Notes:

(none)

##### Parameters


in	<i>FileIndex</i>	Destination file index
----	------------------	------------------------

Definition at line 880 of file ds\_file.c.

References CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_FileTransmit(), DS\_MOVE\_FILE\_ERR\_EID, DS\_TOTAL\_FNAME\_BUFSIZE, DS\_DestFileTable\_t::File, DS\_AppFileStatus\_t::FileAge, DS\_AppFileStatus\_t::FileHandle, DS\_AppFileStatus\_t::FileName, DS\_AppFileStatus\_t::FileSize, DS\_AppData\_t::FileStatus, DS\_DestFileEntry\_t::Movename, OS\_close(), OS\_mv(), OS\_OBJECT\_ID\_UNDEFINED, and OS\_SUCCESS.

Referenced by DS\_CmdCloseAll(), DS\_CmdCloseFile(), DS\_FileSetupWrite(), DS\_FileTestAge(), and DS\_FileWriteError().

Here is the call graph for this function:



### 12.12.2.2 DS\_FileCreateDest()

```
void DS_FileCreateDest (
    uint32 FileIndex )
```

Create a new data storage destination file.

#### Description

This function is called when a packet has passed the filter test and the destination file does not exist. The file may not yet have been created - if this is the first packet for this destination to pass the filter test - or the previous file may have been closed by command or file size/age test. Note that destination files are not created until there is a packet ready to be written.

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>FileIndex</i>	Destination file index
----	------------------	------------------------


Definition at line 492 of file ds\_file.c.

References CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_SUCCESS, DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_BY\_COUNT, DS\_CREATE\_FILE\_ERR\_EID, DS\_DISABLED, DS\_FileCreateName(), DS\_FileWriteHeader(), DS\_MAX\_SEQUENCE\_COUNT, DS\_STRING\_TERMINATOR, DS\_TableUpdateCDS(), DS\_DestFile

Table\_t::File, DS\_AppFileStatus\_t::FileCount, DS\_AppFileStatus\_t::FileHandle, DS\_AppFileStatus\_t::FileName, D\_S\_DestFileEntry\_t::FileNameType, DS\_AppFileStatus\_t::FileState, DS\_AppData\_t::FileStatus, DS\_AppData\_t::FileWriteCounter, DS\_AppData\_t::FileWriteErrCounter, OS\_FILE\_FLAG\_CREATE, OS\_FILE\_FLAG\_TRUNCATE, OS\_OBJECT\_ID\_UNDEFINED, OS\_ObjectIdDefined(), OS\_OpenCreate(), OS\_READ\_WRITE, OS\_SUCCESS, and DS\_DestFileEntry\_t::SequenceCount.

Referenced by DS\_FileSetupWrite().

Here is the call graph for this function:



### 12.12.2.3 DS\_FileCreateName()

```
void DS_FileCreateName (
```

Construct the next filename for a destination file.

## Description

The filename is constructed using data from the Destination File Table. First, the pathname and basename fields from the table are combined. Then, based on the filename type from the table, a sequence string is created and appended to the filename. Finally, the file extension from the table is appended to complete the filename.

### **Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>FileIndex</i>	Destination file index
----	------------------	------------------------

**See also**


[DS\\_DestFileEntry\\_t](#)

Definition at line 572 of file ds\_file.c.

References DS\_DestFileEntry\_t::Basename, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_DISABLED, DS\_FILE\_CREATE\_EMPTY\_PATH\_ERR\_EID, DS\_FILE\_NAME\_ERR\_EID, DS\_FileCreateSequence(), DS\_PATH\_SEPARATOR, DS\_STRING\_TERMINATOR, DS\_TOTAL\_FNAM\_E\_BUFSIZE, DS\_DestFileEntry\_t::Extension, DS\_DestFileTable\_t::File, DS\_AppFileStatus\_t::FileCount, DS\_AppFileStatus\_t::FileName, DS\_DestFileEntry\_t::FileNameType, DS\_AppFileStatus\_t::FileState, DS\_AppData\_t::FileStatus, and DS\_DestFileEntry\_t::Pathname.

Referenced by DS\_FileCreateDest().

Here is the call graph for this function:

**12.12.2.4 DS\_FileCreateSequence()**

```
void DS_FileCreateSequence (
    char * Buffer,
    uint32 Type,
    uint32 Count )
```

Construct the sequence portion of a filename.

**Description**

The filename sequence string will be constructed to contain either the current date and time, or a file sequence count value. If the filename type is "time" then the sequence string will have the format "YYYYDDDHHMMSS". Or, if the filename type is "count" then the sequence string will be a fixed number of text digits, where the string length is a platform defined value.

**Assumptions, External Events, and Notes:**

(none)

## Parameters

in	<i>Buffer</i>	Pointer to buffer for sequence portion of filename
in	<i>Type</i>	Filename type (date and time vs sequence count)
in	<i>Count</i>	Sequence counter (used only if type is sequence)

## See also


[DS\\_DestFileEntry\\_t](#)

Definition at line 706 of file ds\_file.c.

References CFE\_DDD\_INDEX, CFE\_HH\_INDEX, CFE\_MM\_INDEX, CFE\_SS\_INDEX, CFE\_TIME\_GetTime(), CFE←\_TIME\_Print(), DS\_BY\_COUNT, DS\_BY\_TIME, DS\_DDD\_INDEX, DS\_HH\_INDEX, DS\_MM\_INDEX, DS\_SEQUEN←CE\_DIGITS, DS\_SS\_INDEX, DS\_STRING\_TERMINATOR, and DS\_TERM\_INDEX.

Referenced by DS\_FileCreateName().

Here is the call graph for this function:



## 12.12.2.5 DS\_FileSetupWrite()

```
void DS_FileSetupWrite (
    int32 FileIndex,
    const CFE_SB_Buffer_t * BufPtr )
```

Prepare to write to a data storage destination file.

### Description

This function is called for packets that have passed the common CFS filter algorithm. The function first queries the packet length and determines whether writing the packet to an existing data storage file would exceed the max file size limit. If so, the existing destination file header is updated and the file is closed. Then the function determines whether a new file needs to be opened and if so, creates the file. Files may be closed due to size or by command, and files may have not yet been created because this is the first packet destined for that file. Next step: write data to file.

### Assumptions, External Events, and Notes:

(none)

## Parameters

in	<i>FileIndex</i>	Destination file index
in	<i>BufPtr</i>	Software Bus message pointer

### See also


`DS_AppFileStatus_t`, `DS_DestFileEntry_t`

Definition at line 274 of file `ds_file.c`.

References CFE\_MSG\_GetSize(), DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_FileCloseDest(), DS\_FileCreateDest(), DS\_FileUpdateHeader(), DS\_FileWriteData(), DS\_DestFileTable\_t::File, DS\_AppFileStatus\_t::FileHandle, DS\_AppFileStatus\_t::FileSize, DS\_AppData\_t::FileStatus, DS\_DestFileEntry\_t::MaxFileSize, CFE\_SB\_Msg\_t::Msg, and OS\_ObjectIdDefined().

Referenced by DS\_FileStorePacket().

Here is the call graph for this function:



### 12.12.2.6 DS\_FileStorePacket()

```
void DS_FileStorePacket (
    CFE_SB_MsgId_t MessageID,
    const CFE_SB_Buffer_t * BufPtr )
```

Data Storage packet processor.

#### Description

This function searches for a packet filter table entry that matches the input argument Message ID. If no matching packet filter table entry is found, the packet referenced via the Message Pointer is discarded (filtered). When a matching packet table entry is found, each of the multiple filters defined for the packet are tested by applying the common CFS filter algorithm to the table defined filter parameters. Packets that are passed by any filter continue with the write process. Next step: prepare to write data to a file.

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>MessageID</i>	Message ID
in	<i>BufPtr</i>	Software Bus message pointer

#### See also


[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 188 of file ds\_file.c.

References DS\_FilterParms\_t::Algorithm\_N, DS\_FilterParms\_t::Algorithm\_O, DS\_FilterParms\_t::Algorithm\_X, DS\_AppData, DS\_DEST\_FILE\_CNT, DS\_ENABLED, DS\_FileSetupWrite(), DS\_FILTERS\_PER\_PACKET, DS\_INDEX\_NONE, DS\_IsPacketFiltered(), DS\_TableFindMsgID(), DS\_UNUSED, DS\_AppFileStatus\_t::FileState, DS\_AppData\_t::FileStatus, DS\_FilterParms\_t::FileTableIndex, DS\_PacketEntry\_t::Filter, DS\_AppData\_t::FilteredPktCounter, DS\_AppData\_t::FilterTblPtr, DS\_FilterParms\_t::FilterType, DS\_AppData\_t::IgnoredPktCounter, DS\_FilterTable\_t::Packet, and DS\_AppData\_t::PassedPktCounter.

Referenced by DS\_AppStorePacket().

Here is the call graph for this function:



### 12.12.2.7 DS\_FileTestAge()

```
void DS_FileTestAge (
    uint32 ElapsedSeconds )
```

File age processor.

#### Description

This function is called upon receipt of the DS 1Hz command (if defined) or upon receipt of the DS housekeeping request command (if the 1Hz cmd is not defined). The function increments the elapsed file age for all open data storage files by the amount specified. Files that exceed the age limit set in the destination file definition table will be closed. If this destination remains enabled, another file will be opened when the next packet is written to this destination.

#### Assumptions, External Events, and Notes:

(none)

#### Parameters


in	<i>ElapsedSeconds</i>	Elapsed seconds since previous call
----	-----------------------	-------------------------------------

Definition at line 1002 of file ds\_file.c.

References DS\_AppData\_t::DestFileTblPtr, DS\_AppData, DS\_DEST\_FILE\_CNT, DS\_FileCloseDest(), DS\_FileUpdateHeader(), DS\_DestFileTable\_t::File, DS\_AppFileStatus\_t::FileAge, DS\_AppFileStatus\_t::FileHandle, DS\_AppData\_t::FileStatus, DS\_DestFileEntry\_t::MaxFileAge, and OS\_ObjectIdDefined().

Referenced by DS\_AppMain(), and DS\_AppProcessHK().

Here is the call graph for this function:



#### 12.12.2.8 DS\_FileTransmit()

```
void DS_FileTransmit (
    DS_AppFileStatus_t * FileStatus )
```

Transmit file information telemetry handler.

##### Description

Create and send a telemetry packet containing the current status for a closed destination file.

##### Assumptions, External Events, and Notes:

(none)

**Parameters**

in	<i>FileStatus</i>	Current state of destination file
----	-------------------	-----------------------------------

**See also**


[DS\\_FileCompletePktBuf\\_t](#)

Definition at line 1045 of file ds\_file.c.

References CFE\_MSG\_Init(), CFE\_SB\_AllocateMessageBuffer(), CFE\_SB\_TimeStampMsg(), CFE\_SB\_TransmitBuffer(), CFE\_SB\_ValueToMsgId(), DS\_CLOSED, DS\_COMP\_TLM\_MID, DS\_FileInfo\_t::EnableState, DS\_AppFileStatus\_t::FileAge, DS\_FileInfo\_t::FileAge, DS\_AppFileStatus\_t::FileCount, DS\_FileCompletePkt\_t::FileInfo, DS\_AppFileStatus\_t::FileName, DS\_FileInfo\_t::FileName, DS\_AppFileStatus\_t::FileRate, DS\_FileInfo\_t::FileRate, DS\_AppFileStatus\_t::FileSize, DS\_FileInfo\_t::FileSize, DS\_AppFileStatus\_t::FileState, DS\_FileInfo\_t::OpenState, DS\_FileCompletePktBuf\_t::Pkt, DS\_FileCompletePktBuf\_t::SBBuf, DS\_FileInfo\_t::SequenceCount, and DS\_FileCompletePkt\_t::TlmHeader.

Referenced by DS\_FileCloseDest().

Here is the call graph for this function:



### 12.12.2.9 DS\_FileUpdateHeader()

```
void DS_FileUpdateHeader (
    int32 FileIndex )
```

Update destination file header (prior to closing)

#### Description

This function is called just before closing a data storage destination file. The purpose of the function is to update portions of the file header that cannot be known in advance, such as the file size or the file close time. During the update process, seek and write errors are counted but otherwise ignored as the file is about to be closed.

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>FileIndex</i>	Destination file index
----	------------------	------------------------

#### See also


[DS\\_FileWriteHeader](#)

Definition at line 840 of file ds\_file.c.

References CFE\_SUCCESS, CFE\_TIME\_GetTime(), DS\_AppData, DS\_AppFileStatus\_t::FileHandle, DS\_AppData\_t::FileStatus, DS\_AppData\_t::FileUpdateCounter, DS\_AppData\_t::FileUpdateErrCounter, OS\_Iseek(), OS\_SEEK\_SET, and OS\_write().

Referenced by DS\_CmdCloseAll(), DS\_CmdCloseFile(), DS\_FileSetupWrite(), and DS\_FileTestAge().

Here is the call graph for this function:



### 12.12.2.10 DS\_FileWriteData()

```
void DS_FileWriteData (
    int32 FileIndex,
    const void * FileData,
    uint32 DataLength )
```

Write data (packet) to file.

#### Description

This function writes data to an existing data storage destination file and updates the associated data rate counters. If necessary, the function will invoke a file write error handler.

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>FileIndex</i>	Destination file index
in	<i>FileData</i>	Pointer to packet data
in	<i>DataLength</i>	Length of packet data

#### See also


[DS\\_AppFileStatus\\_t](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 349 of file ds\_file.c.

References CFE\_SUCCESS, DS\_AppData, DS\_FileWriteError(), DS\_AppFileStatus\_t::FileGrowth, DS\_AppFileStatus\_t::FileHandle, DS\_AppFileStatus\_t::FileSize, DS\_AppData\_t::FileStatus, DS\_AppData\_t::FileWriteCounter, and OS\_write().

Referenced by DS\_FileSetupWrite().

Here is the call graph for this function:



### 12.12.2.11 DS\_FileWriteError()

```
void DS_FileWriteError (
    uint32 FileIndex,
    uint32 DataLength,
    int32 WriteResult )
```

File write error handler.

#### Description

This function is called upon detection of a file I/O error that occurred while writing to a data storage destination file. The function sends an event describing the error, closes the file and disables the destination. If DS tables have been defined as "critical", the version of the table in the Critical Data Store (CDS) will be updated to reflect the change in enable/disable state for the destination.

#### Assumptions, External Events, and Notes:

(none)

#### Parameters


in	<i>FileIndex</i>	Destination file index
in	<i>DataLength</i>	Length of data being written to file
in	<i>WriteResult</i>	Result of file write

Definition at line 466 of file ds\_file.c.

References CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), DS\_AppData, DS\_DISABLED, DS\_FileCloseDest(), DS\_WRITE\_FILE\_ERR\_EID, DS\_AppFileStatus\_t::FileName, DS\_AppFileStatus\_t::FileState, DS\_AppData\_t::FileStatus, and DS\_AppData\_t::FileWriteErrCounter.

Referenced by DS\_FileWriteData(), and DS\_FileWriteHeader().

Here is the call graph for this function:



### 12.12.2.12 DS\_FileWriteHeader()

```
void DS_FileWriteHeader (
    int32 FileIndex )
```

Write data storage file header.

#### Description

This function is called just after opening a new data storage destination file. The purpose of the function is to write a file header and initialize those elements in the file header that can be known in advance, such as the filename or file type. Any seek or write errors will result in the execution of the common file write error handler.

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>FileIndex</i>	Destination file index
----	------------------	------------------------

#### See also


[DS\\_FileUpdateHeader](#)

Definition at line 386 of file `ds_file.c`.

References `CFE_FS_WriteHeader()`, `CFE_SUCCESS`, `CFE_FS_Header::Description`, `DS_AppData_t::DestFileTblPtr`, `DS_AppData`, `DS_FILE_HDR_DESCRIPTION`, `DS_FILE_HDR_SUBTYPE`, `DS_FileWriteError()`, `DS_DestFileTable<_t::File`, `DS_AppFileStatus_t::FileGrowth`, `DS_AppFileStatus_t::FileHandle`, `DS_FileHeader_t::FileName`, `DS_AppFileStatus_t::FileName`, `DS_FileHeader_t::FileNameType`, `DS_DestFileEntry_t::FileNameType`, `DS_AppFileStatus_t::FileSize`, `DS_AppData_t::FileStatus`, `DS_FileHeader_t::FileTableIndex`, `DS_AppData_t::FileWriteCounter`, `OS_write()`, and `CFE_FS_Header::SubType`.

Referenced by `DS_FileCreateDest()`.

Here is the call graph for this function:



### 12.12.2.13 DS\_IsPacketFiltered()

```
bool DS_IsPacketFiltered (
    CFE_MSG_Message_t * MessagePtr,
    uint16 FilterType,
    uint16 Algorithm_N,
    uint16 Algorithm_X,
    uint16 Algorithm_O )
```

Determine whether Software Bus message packet is filtered.

#### Description

This routine will apply the DS filter algorithm to the packet to determine whether the packet should be filtered.

#### Assumptions, External Events, and Notes:

None

#### Parameters

in	<i>MessagePtr</i>	Pointer to a Software Bus message packet
in	<i>FilterType</i>	Packet sequence count (1) or timestamp (2)
in	<i>Algorithm_N</i>	Algorithm parameter N "pass this many"
in	<i>Algorithm_X</i>	Algorithm parameter X "out of this many"
in	<i>Algorithm_O</i>	Algorithm parameter O "at this offset"

#### Returns

Boolean packet filtered response

#### Return values


<i>true</i>	The packet should be filtered (not used)
<i>false</i>	The packet should not be filtered (used)

Definition at line 56 of file ds\_file.c.

References CFE\_MSG\_GetMsgTime(), CFE\_MSG\_GetSequenceCount(), DS\_11 LSB\_SECONDS\_MASK, DS\_11 ← LSB\_SECONDS\_SHIFT, DS\_16\_MSB\_SUBSECS\_SHIFT, DS\_4\_MSB\_SUBSECS\_MASK, DS\_4\_MSB\_SUBSECS←\_SHIFT, DS\_PKT\_SEQUENCE\_BASED\_FILTER\_TYPE, DS\_PKT\_TIME\_BASED\_FILTER\_TYPE, CFE\_TIME\_Sys←Time::Seconds, and CFE\_TIME\_SysTime::Subseconds.

Referenced by DS\_FileStorePacket().

Here is the call graph for this function:



## 12.13 apps/ds/fsw/src/ds\_msg.h File Reference

```
#include "cfe.h"
#include "ds_platform_cfg.h"
```

### Data Structures

- struct `DS_NoopCmd_t`  
*No-Operation Command.*
- struct `DS_ResetCmd_t`  
*Reset Housekeeping Telemetry Command.*
- struct `DS_AppStateCmd_t`  
*Set Ena/Dis State For DS Application.*
- struct `DS_FilterFileCmd_t`  
*Set File Selection For Packet Filter Table Entry.*
- struct `DS_FilterTypeCmd_t`  
*Set Filter Type For Packet Filter Table Entry.*
- struct `DS_FilterParmsCmd_t`  
*Set Filter Parameters For Packet Filter Table Entry.*
- struct `DS_DestTypeCmd_t`  
*Set Filename Type For Destination File Table Entry.*
- struct `DS_DestStateCmd_t`  
*Set Ena/Dis State For Destination File Table Entry.*
- struct `DS_DestPathCmd_t`  
*Set Path Portion Of Filename For Destination File Table Entry.*
- struct `DS_DestBaseCmd_t`  
*Set Base Portion Of Filename For Destination File Table Entry.*
- struct `DS_DestExtCmd_t`  
*Set Extension Portion Of Filename For Destination File Table Entry.*
- struct `DS_DestSizeCmd_t`  
*Set Max File Size For Destination File Table Entry.*
- struct `DS_DestAgeCmd_t`

- struct **DS\_DestCountCmd\_t**  
*Set Max File Age For Destination File Table Entry.*
- struct **DS\_CloseFileCmd\_t**  
*Set Sequence Portion Of Filename For Destination File Table Entry.*
- struct **DS\_CloseAllCmd\_t**  
*Close Destination File.*
- struct **DS\_GetFileInfoCmd\_t**  
*Close All Destination Files.*
- struct **DS\_AddMidCmd\_t**  
*Get File Info Command.*
- struct **DS\_HkPacket\_t**  
*Add Message ID To Packet Filter Table.*
- struct **DS\_FileInfo\_t**  
*Application housekeeping packet.*
- struct **DS\_FileInfoPkt\_t**  
*Current state of destination files.*
- struct **DS\_FileCompletePkt\_t**  
*Application file info packet.*
- union **DS\_FileCompletePktBuf\_t**  
*Single application file info packet buffer.*

### 12.13.1 Detailed Description

The CFS Data Storage (DS) Message Definitions

## 12.14 apps/ds/fsw/src/ds\_msgdefs.h File Reference

### Macros

- #define **DS\_NOOP\_CC** 0  
*No-Operation Command.*
- #define **DS\_RESET\_CC** 1  
*Reset Housekeeping Telemetry Counters Command.*
- #define **DS\_SET\_APP\_STATE\_CC** 2  
*Set Enable/Disable State For DS Application.*
- #define **DS\_SET\_FILTER\_FILE\_CC** 3  
*Set Destination File For Packet Filter Table Entry.*
- #define **DS\_SET\_FILTER\_TYPE\_CC** 4  
*Set Filter Type For Packet Filter Table Entry.*
- #define **DS\_SET\_FILTER\_PARMS\_CC** 5  
*Set Algorithm Parameters For Packet Filter Table Entry.*
- #define **DS\_SET\_DEST\_TYPE\_CC** 6  
*Set Filename Type For Destination File Table Entry.*
- #define **DS\_SET\_DEST\_STATE\_CC** 7

- #define DS\_SET\_DEST\_PATH\_CC 8  
*Set Pathname For Destination File Table Entry.*
- #define DS\_SET\_DEST\_BASE\_CC 9  
*Set Basename For Destination File Table Entry.*
- #define DS\_SET\_DEST\_EXT\_CC 10  
*Set Extension For Destination File Table Entry.*
- #define DS\_SET\_DEST\_SIZE\_CC 11  
*Set Max File Size For Destination File Table Entry.*
- #define DS\_SET\_DEST\_AGE\_CC 12  
*Set Max File Age For Destination File Table Entry.*
- #define DS\_SET\_DEST\_COUNT\_CC 13  
*Set Sequence Count For Destination File Table Entry.*
- #define DS\_CLOSE\_FILE\_CC 14  
*Close Destination File.*
- #define DS\_GET\_FILE\_INFO\_CC 15  
*Get File Info Packet.*
- #define DS\_ADD\_MID\_CC 16  
*Add Message ID To Packet Filter Table.*
- #define DS\_CLOSE\_ALL\_CC 17  
*Close All Destination Files.*

#### 12.14.1 Detailed Description

The CFS Data Storage (DS) command codes header file

## 12.15 apps/ds/fsw/src/ds\_table.c File Reference

```
#include "cfe.h"
#include "ds_msgids.h"
#include "ds_platform_cfg.h"
#include "ds_verify.h"
#include "ds_appdefs.h"
#include "ds_app.h"
#include "ds_table.h"
#include "ds_msg.h"
#include "ds_events.h"
```

#### Macros

- #define DS\_CDS\_NAME "DS\_CDS"

## Functions

- **int32 DS\_TableInit (void)**  
*Startup table initialization function.*
- **void DS\_TableManageDestFile (void)**  
*Manage destination file table loads, dumps, etc.*
- **void DS\_TableManageFilter (void)**  
*Manage packet filter table loads, dumps, etc.*
- **int32 DS\_TableVerifyDestFile (const void \*TableData)**  
*Verify destination file table data.*
- **bool DS\_TableVerifyDestFileEntry (DS\_DestFileEntry\_t \*DestFileEntry, uint8 TableIndex, int32 ErrorCount)**  
*Verify destination file table entry.*
- **int32 DS\_TableVerifyFilter (const void \*TableData)**  
*Verify packet filter table data.*
- **bool DS\_TableVerifyFilterEntry (DS\_PacketEntry\_t \*PacketEntry, int32 TableIndex, int32 ErrorCount)**  
*Verify packet filter table entry.*
- **bool DS\_TableEntryUnused (const void \*TableEntry, int32 BufferSize)**  
*Test for unused table entry.*
- **bool DS\_TableVerifyFileIndex (uint16 FileTableIndex)**  
*Verify destination file index.*
- **bool DS\_TableVerifyParms (uint16 Algorithm\_N, uint16 Algorithm\_X, uint16 Algorithm\_O)**  
*Verify packet filter parameters.*
- **bool DS\_TableVerifyType (uint16 TimeVsCount)**  
*Verify packet filter type or filename type.*
- **bool DS\_TableVerifyState (uint16 EnableState)**  
*Verify application or destination file enable/disable state.*
- **bool DS\_TableVerifySize (uint32 MaxFileSize)**  
*Verify destination file max size limit.*
- **bool DS\_TableVerifyAge (uint32 MaxFileAge)**  
*Verify destination file max age limit.*
- **bool DS\_TableVerifyCount (uint32 SequenceCount)**  
*Verify destination file sequence count.*
- **void DS\_TableSubscribe (void)**  
*Subscribe to packet filter table packets.*
- **void DS\_TableUnsubscribe (void)**  
*Unsubscribe to packet filter table packets.*
- **int32 DS\_TableCreateCDS (void)**  
*Create local area within the Critical Data Store (CDS)*
- **void DS\_TableUpdateCDS (void)**  
*Update CDS with current filename sequence count values.*
- **uint32 DS\_TableHashFunction (CFE\_SB\_MsgId\_t MessageID)**  
*Hash table function.*
- **void DS\_TableCreateHash (void)**  
*Create hash table function.*
- **int32 DS\_TableAddMsgID (CFE\_SB\_MsgId\_t MessageID, int32 FilterIndex)**  
*Adds a message ID to the hash table.*
- **int32 DS\_TableFindMsgID (CFE\_SB\_MsgId\_t MessageID)**  
*Search packet filter table for message ID.*

### 12.15.1 Detailed Description

CFS Data Storage (DS) table management functions

### 12.15.2 Macro Definition Documentation

#### 12.15.2.1 DS\_CDS\_NAME

```
#define DS_CDS_NAME "DS_CDS"
```

Definition at line 39 of file ds\_table.c.

Referenced by DS\_TableCreateCDS().

### 12.15.3 Function Documentation

#### 12.15.3.1 DS\_TableAddMsgID()

```
int32 DS_TableAddMsgID (
    CFE_SB_MsgId_t MessageID,
    int32 FilterIndex )
```

Adds a message ID to the hash table.

##### Description

This function populates the hash table with a new message ID

##### Called From:

- Creation of Hash Table
- Command to add a MID

##### Assumptions, External Events, and Notes:

(none)

##### Parameters

in	MessageID	Message ID
in	FilterIndex	Filter table index for message ID

**Returns**

Hash table index for message ID

**See also**

[DS\\_HashLink\\_t](#), [DS\\_TableHashFunction](#), [DS\\_TableFindMsgID](#)

Definition at line 1090 of file `ds_table.c`.

References `DS_AppData`, `DS_TableHashFunction()`, `DS_AppData_t::HashLinks`, `DS_AppData_t::HashTable`, `DS_HashTag::Index`, `DS_HashTag::MessageID`, and `DS_HashTag::Next`.

Referenced by `DS_CmdAddMID()`, and `DS_TableCreateHash()`.

Here is the call graph for this function:

**12.15.3.2 DS\_TableCreateCDS()**

```
int32 DS_TableCreateCDS (
    void )
```

Create local area within the Critical Data Store (CDS)

**Description**

This function creates a new CDS area or gets access to a CDS area created prior to a processor reset. The CDS area will be used to store the current values for destination filename sequence counts.

**Called From:**

- Application initialization function

**Assumptions, External Events, and Notes:**

(none)

## See also


[DS\\_DestFileEntry\\_t](#)

Definition at line 898 of file ds\_table.c.

References DS\_AppData\_t::AppEnableState, CFE\_ES\_CDS\_ALREADY\_EXISTS, CFE\_ES\_CDS\_BAD\_HANDLE, CFE\_ES\_CopyToCDS(), CFE\_ES\_RegisterCDS(), CFE\_ES\_RestoreFromCDS(), CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_SUCCESS, DS\_AppData\_t::DataStoreHandle, DS\_AppData, DS\_CDS\_NAME, DS\_DEST\_FILE\_CNT, DS\_INIT\_CDS\_ERR\_EID, DS\_AppFileStatus\_t::FileCount, and DS\_AppData\_t::FileStatus.

Referenced by DS\_AppInitialize().

Here is the call graph for this function:



### 12.15.3.3 DS\_TableCreateHash()

```
void DS_TableCreateHash (
    void )
```

Create hash table function.

#### Description

This function populates the hash table following a new load of the packet filter table. Because there may be more message ID's than hash table entries, the hash table function may translate multiple message ID's into each hash table index. Each hash table entry is a linked list containing a link for each message ID that translates to the same hash table index.

#### Called From:

- Filter table manage updates function (after table load)

#### Assumptions, External Events, and Notes:

(none)

**See also**


[DS\\_HashLink\\_t](#), [DS\\_TableHashFunction](#), [DS\\_TableFindMsgID](#)

Definition at line 1065 of file ds\_table.c.

References DS\_AppData, DS\_PACKETS\_IN\_FILTER\_TABLE, DS\_TableAddMsgID(), DS\_AppData\_t::FilterTblPtr, D←S\_AppData\_t::HashLinks, DS\_AppData\_t::HashTable, DS\_PacketEntry\_t::MessageID, and DS\_FilterTable\_t::Packet.

Referenced by DS\_TableManageFilter().

Here is the call graph for this function:

**12.15.3.4 DS\_TableEntryUnused()**

```
bool DS_TableEntryUnused (
    const void * TableEntry,
    int32 BufferSize )
```

Test for unused table entry.

**Description**

This function returns true if a table entry is unused. Unused is defined as containing nothing but zero's.

**Called From:**

- Packet Filter Table validation function
- Destination File Table validation function

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>TableEntry</i>	Pointer to the table entry data
in	<i>BufferSize</i>	Length of the table entry data

**See also**

[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 654 of file ds\_table.c.

References DS\_UNUSED.

Referenced by DS\_TableVerifyDestFile(), and DS\_TableVerifyFilterEntry().

#### 12.15.3.5 DS\_TableFindMsgID()

```
int32 DS_TableFindMsgID (
    CFE_SB_MsgId_t MessageID )
```

Search packet filter table for message ID.

**Description**

This function searches for a packet filter table entry that matches the input argument message ID.

**Called From:**

- Data storage packet processor
- Command handler (set file index)
- Command handler (set filter type)
- Command handler (set filter parms)
- Command handler (add messageID to filter table)

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	MessageID	Message ID
----	-----------	------------

**Returns**

Filter table index for message ID

**See also**

[DS\\_HashLink\\_t](#), [DS\\_TableHashFunction](#), [DS\\_TableCreateHash](#)

Definition at line 1136 of file ds\_table.c.

References CFE\_SB\_MsgIdToValue(), DS\_AppData, DS\_INDEX\_NONE, DS\_TableHashFunction(), DS\_AppData\_t::FilterTblPtr, DS\_AppData\_t::HashTable, DS\_HashTag::Index, DS\_PacketEntry\_t::MessageID, DS\_HashTag::Next, and DS\_FilterTable\_t::Packet.

Referenced by DS\_AppProcessMsg(), DS\_CmdAddMID(), DS\_CmdSetFilterFile(), DS\_CmdSetFilterParms(), DS\_CmdSetFilterType(), and DS\_FileStorePacket().

Here is the call graph for this function:



### 12.15.3.6 DS\_TableHashFunction()

```
uint32 DS_TableHashFunction (
    CFE_SB_MsgId_t MessageID )
```

Hash table function.

#### Description

This function converts a cFE MessageID into an index into the hash table. The indexed hash table entry contains a linked list where each link identifies a single entry in the packet filter table. Thus, the scope of searching the Packet Filter Table for a specific MessageID has been reduced from searching the total number of entries in the filter table by a factor equal to the size of the hash table.

#### Called From:

- Hash table creation function (after load filter table)
- Find messageID in filter table function

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	MessageID	Message ID
----	-----------	------------

**Returns**

Index of hash table entry for input message ID

**See also**

[DS\\_HashLink\\_t](#), [DS\\_TableCreateHash](#), [DS\\_TableFindMsgID](#)

Definition at line 1022 of file ds\_table.c.

References [CFE\\_SB\\_MsgIdToValue\(\)](#), and [DS\\_HASH\\_TABLE\\_MASK](#).

Referenced by [DS\\_TableAddMsgID\(\)](#), and [DS\\_TableFindMsgID\(\)](#).

Here is the call graph for this function:



### 12.15.3.7 DS\_TableInit()

```
int32 DS_TableInit (
    void )
```

Startup table initialization function.

**Description**

This function creates the Packet Filter and Destination File tables. The function then tries to load default table data for each table. If the Packet Filter Table load is successful, then the function will subscribe to all of the packets referenced by the table.

**Called From:**

- DS startup initialization function

**Assumptions, External Events, and Notes:**

(none)

## See also


`DS_PacketEntry_t`, `DS_FilterParms_t`, `DS_DestFileEntry_t`

Definition at line 47 of file `ds_table.c`.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_SUCCE-  
SS, CFE\_TBL\_INFO\_RECOVERED\_TBL, CFE\_TBL\_Load(), CFE\_TBL\_OPT\_CRITICAL, CFE\_TBL\_OPT\_LOAD\_<  
DUMP, CFE\_TBL\_OPT\_SNGL\_BUFFER, CFE\_TBL\_Register(), CFE\_TBL\_SRC\_FILE, DS\_AppData\_t::DestFileTbl<  
Handle, DS\_AppData, DS\_DEF\_DEST\_FILENAME, DS\_DEF\_FILTER\_FILENAME, DS\_DESTINATION\_TBL\_NA-  
ME, DS\_FILTER\_TBL\_NAME, DS\_INIT\_TBL\_CDS\_EID, DS\_INIT\_TBL\_ERR\_EID, DS\_TableManageDestFile(), DS-<  
\_TableManageFilter(), DS\_TableVerifyDestFile(), DS\_TableVerifyFilter(), and DS\_AppData\_t::FilterTblHandle.

Referenced by DS\_AppInitialize().

Here is the call graph for this function:



#### 12.15.3.8 DS\_TableManageDestFile()

```
void DS_TableManageDestFile (
```

Manage destination file table loads, dumps, etc.

## Description

This function will provide cFE Table Services with an opportunity to make updates to the Destination File Table while in the context of the DS application. There is no special handling necessary if a new version of this table is loaded.

### Called From:

- DS table initialization function
- DS housekeeping request command processor

### Assumptions, External Events, and Notes:

(none)

### See also


[DS\\_DestFileEntry\\_t](#), [DS\\_TableVerifyDestFile](#)

Definition at line 186 of file ds\_table.c.

References CFE\_SUCCESS, CFE\_TBL\_DumpToBuffer(), CFE\_TBL\_ERR\_NEVER\_LOADED, CFE\_TBL\_GetAddress(), CFE\_TBL\_GetStatus(), CFE\_TBL\_INFO\_DUMP\_PENDING, CFE\_TBL\_INFO\_UPDATE\_PENDING, CFE\_TBL\_INFO\_UPDATED, CFE\_TBL\_INFO\_VALIDATION\_PENDING, CFE\_TBL\_Manage(), CFE\_TBL\_ReleaseAddress(), CFE\_TBL\_Update(), CFE\_TBL\_Validate(), DS\_AppData\_t::DestFileTblHandle, DS\_AppData\_t::DestFileTblPtr, DS\_AppData\_t::DestTblErrCounter, DS\_AppData\_t::DestTblLoadCounter, DS\_AppData, DS\_DEST\_FILE\_CNT, DS\_TableUpdateCDS(), DS\_DestFileEntry\_t::EnableState, DS\_DestFileTable\_t::File, DS\_AppFileStatus\_t::FileCount, DS\_AppFileStatus\_t::FileState, DS\_AppData\_t::FileStatus, and DS\_DestFileEntry\_t::SequenceCount.

Referenced by DS\_AppMain(), DS\_AppProcessHK(), and DS\_TableInit().

Here is the call graph for this function:



### 12.15.3.9 DS\_TableManageFilter()

```
void DS_TableManageFilter (
    void )
```

Manage packet filter table loads, dumps, etc.

#### Description

This function will provide cFE Table Services with an opportunity to make updates to the Packet Filter Table while in the context of the DS application. If a new version of the filter table gets loaded, the function will first unsubscribe to any packets referenced by the previous version of the table, and then subscribe to all packets referenced by the new version of the table.

#### Called From:

- DS table initialization function
- DS housekeeping request command processor

#### Assumptions, External Events, and Notes:

(none)

#### See also


[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_TableVerifyFilter](#)

Definition at line 296 of file ds\_table.c.

References CFE\_SUCCESS, CFE\_TBL\_DumpToBuffer(), CFE\_TBL\_ERR\_NEVER\_LOADED, CFE\_TBL\_GetAddress(), CFE\_TBL\_GetStatus(), CFE\_TBL\_INFO\_DUMP\_PENDING, CFE\_TBL\_INFO\_UPDATE\_PENDING, CFE\_TBL\_INFO\_UPDATED, CFE\_TBL\_INFO\_VALIDATION\_PENDING, CFE\_TBL\_Manage(), CFE\_TBL\_ReleaseAddress(), CFE\_TBL\_Update(), CFE\_TBL\_Validate(), DS\_AppData, DS\_TableCreateHash(), DS\_TableSubscribe(), DS\_TableUnsubscribe(), DS\_AppData\_t::FilterTblErrCounter, DS\_AppData\_t::FilterTblHandle, DS\_AppData\_t::FilterTblLoadCounter, and DS\_AppData\_t::FilterTblPtr.

Referenced by DS\_AppMain(), DS\_AppProcessHK(), and DS\_TableInit().

Here is the call graph for this function:



### 12.15.3.10 DS\_TableSubscribe()

```
void DS_TableSubscribe ( void )
```

Subscribe to packet filter table packets.

#### Description

A new Packet Filter Table is available for use. This function is called to subscribe to packets referenced by the new filter table.

#### Called From:

- Packet Filter Table manage function

#### Assumptions, External Events, and Notes:

Caller has determined that the new filter table exists.

#### See also


[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_TableUnsubscribe](#)

Definition at line 828 of file ds\_table.c.

References CFE\_SB\_DEFAULT\_QOS, CFE\_SB\_INVALID\_MSG\_ID, CFE\_SB\_IsValidMsgId(), CFE\_SB\_MsgIdToValue(), CFE\_SB\_SubscribeEx(), DS\_AppData, DS\_CMD\_MID, DS\_PACKETS\_IN\_FILTER\_TABLE, DS\_PER\_PACKET\_PIPE\_LIMIT, DS\_SEND\_HK\_MID, DS\_AppData\_t::FilterTblPtr, DS\_AppData\_t::InputPipe, DS\_PacketEntry\_t::MessageID, and DS\_FilterTable\_t::Packet.

Referenced by DS\_TableManageFilter().

Here is the call graph for this function:



### 12.15.3.11 DS\_TableUnsubscribe()

```
void DS_TableUnsubscribe (
    void )
```

Unsubscribe to packet filter table packets.

#### Description

A new Packet Filter Table is available for use. Prior to subscribing to the packets referenced by the new filter table, this function is called to unsubscribe to packets referenced by the old filter table.

#### Called From:

- Packet Filter Table manage function

#### Assumptions, External Events, and Notes:

Caller has determined that the old filter table exists.

#### See also


[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_TableSubscribe](#)

Definition at line 863 of file ds\_table.c.

References CFE\_SB\_INVALID\_MSG\_ID, CFE\_SB\_IsValidMsgId(), CFE\_SB\_MsgIdToValue(), CFE\_SB\_Unsubscribe(), DS\_AppData, DS\_CMD\_MID, DS\_PACKETS\_IN\_FILTER\_TABLE, DS\_SEND\_HK\_MID, DS\_AppData\_t::FilterTblPtr, DS\_AppData\_t::InputPipe, DS\_PacketEntry\_t::MessageID, and DS\_FilterTable\_t::Packet.

Referenced by DS\_TableManageFilter().

Here is the call graph for this function:



### 12.15.3.12 DS\_TableUpdateCDS()

```
void DS_TableUpdateCDS (
    void )
```

Update CDS with current filename sequence count values.

#### Description

This function writes the current filename sequence count values to the Critical Data Store. The function is called each time the sequence count values are modified.

#### Called From:

- Destination table data update handler
- Destination file creation function
- Command handler (set sequence count)

#### Assumptions, External Events, and Notes:

(none)

#### See also


[DS\\_DestFileEntry\\_t](#)

Definition at line 970 of file ds\_table.c.

References DS\_AppData\_t::AppEnableState, CFE\_ES\_CDS\_BAD\_HANDLE, CFE\_ES\_CopyToCDS(), CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_RESOURCEID\_TEST\_EQUAL, CFE\_SUCCESS, DS\_AppData\_t::DataStoreHandle, DS\_AppData, DS\_DEST\_FILE\_CNT, DS\_INIT\_CDS\_ERR\_EID, DS\_AppFileStatus\_t::FileCount, and DS\_AppData\_t::FileStatus.

Referenced by DS\_CmdSetAppState(), DS\_CmdSetDestCount(), DS\_FileCreateDest(), and DS\_TableManageDestFile().

Here is the call graph for this function:



### 12.15.3.13 DS\_TableVerifyAge()

```
bool DS_TableVerifyAge (
    uint32 MaxFileAge )
```

Verify destination file max age limit.

#### Description

This function verifies that the indicated destination file max age limit is within bounds - as defined by platform configuration parameters.

#### Called From:

- Command handler (set file max age limit)
- Destination File Table entry validation function

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	MaxFileAge	Maximum Age Limit value
----	------------	-------------------------

#### See also

[DS\\_TableVerifySize](#), [DS\\_TableVerifyCount](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 790 of file ds\_table.c.

References DS\_FILE\_MIN\_AGE\_LIMIT.

Referenced by DS\_CmdSetDestAge(), and DS\_TableVerifyDestFileEntry().

### 12.15.3.14 DS\_TableVerifyCount()

```
bool DS_TableVerifyCount (
    uint32 SequenceCount )
```

Verify destination file sequence count.

#### Description

This function verifies that the indicated destination file sequence count is within bounds - as defined by platform configuration parameters.

**Called From:**

- Command handler (set file sequence count)
- Destination File Table entry validation function

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>SequenceCount</i>	Sequence Count value
----	----------------------	----------------------

**See also**

[DS\\_TableVerifySize](#), [DS\\_TableVerifyAge](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 809 of file `ds_table.c`.

References `DS_MAX_SEQUENCE_COUNT`.

Referenced by `DS_CmdSetDestCount()`, and `DS_TableVerifyDestFileEntry()`.

### 12.15.3.15 DS\_TableVerifyDestFile()

```
int32 DS_TableVerifyDestFile (
    const void * TableData )
```

Verify destination file table data.

**Description**

This function is called by cFE Table Services to verify the contents of a candidate Destination File Table. This will occur while cFE Table Services is processing another call from the DS application to manage the table. Thus, this verification function will be executed from within the context of the DS application.

**Called From:**

- cFE Table Services

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>TableData</i>	Pointer to Destination File Table data
----	------------------	--

**See also**


[DS\\_DestFileEntry\\_t](#), [DS\\_TableVerifyDestFileEntry](#)

Definition at line 403 of file `ds_table.c`.

References CFE\_EVS\_EventType\_INFORMATION, CFE\_EVS\_SendEvent(), CFE\_SUCCESS, DS\_DEST\_FILE\_CNT, DS\_FIL\_TBL\_EID, DS\_TABLE\_VERIFY\_ERR, DS\_TableEntryUnused(), DS\_TableVerifyDestFileEntry(), and DS\_DestFileTable\_t::File.

Referenced by DS\_TableInit().

Here is the call graph for this function:



#### 12.15.3.16 DS\_TableVerifyDestFileEntry()

```

bool DS_TableVerifyDestFileEntry (
    DS_DestFileEntry_t * DestFileEntry,
    uint8 TableIndex,
    int32 ErrorCount )
  
```

Verify destination file table entry.

##### Description

This function is called from the Destination File Table verification function to verify a single table entry. This function, in turn, calls common utility functions to verify each field within the selected table entry.

##### Called From:

- Destination File Table validation function

##### Assumptions, External Events, and Notes:

(none)

**Parameters**

in	<i>DestFileEntry</i>	Pointer to selected Destination File Table entry
in	<i>TableIndex</i>	Index of selected Destination File Table entry
in	<i>ErrorCount</i>	Number of errors already encountered

**See also**


[DS\\_DestFileEntry\\_t](#), [DS\\_TableVerifyDestFile](#)

Definition at line 451 of file ds\_table.c.

References CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), DS\_FIL\_TBL\_ERR\_EID, DS\_TableVerifyAge(), DS\_TableVerifyCount(), DS\_TableVerifySize(), DS\_TableVerifyState(), DS\_TableVerifyType(), DS\_DestFileEntry\_t::EnableState, DS\_DestFileEntry\_t::FileNameType, DS\_DestFileEntry\_t::MaxFileAge, DS\_DestFileEntry\_t::MaxFileSize, and DS\_DestFileEntry\_t::SequenceCount.

Referenced by DS\_TableVerifyDestFile().

Here is the call graph for this function:



### 12.15.3.17 DS\_TableVerifyFileIndex()

```
bool DS_TableVerifyFileIndex (
    uint16 FileTableIndex )
```

Verify destination file index.

#### Description

This function verifies that the indicated packet filter table file table index is within bounds - as defined by platform configuration parameters. Note that the utility functions are also called from the ground command handlers to verify command arguments that modify the table data.

#### Called From:

- Command handler (set file table index)
- Command handler (set filename type)
- Command handler (set file enable/disable state)
- Command handler (set pathname)
- Command handler (set basename)
- Command handler (set extension)
- Command handler (set max file size limit)
- Command handler (set max file age limit)
- Command handler (set file sequence count)
- Command handler (close file)
- Packet Filter Table entry validation function

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	FileTableIndex	Destination File Table Index value
----	----------------	------------------------------------

#### See also

[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 679 of file ds\_table.c.

References DS\_DEST\_FILE\_CNT.

Referenced by DS\_CmdCloseFile(), DS\_CmdSetDestAge(), DS\_CmdSetDestBase(), DS\_CmdSetDestCount(), DS\_CmdSetDestExt(), DS\_CmdSetDestPath(), DS\_CmdSetDestSize(), DS\_CmdSetDestState(), DS\_CmdSetDestType(), DS\_CmdSetFilterFile(), and DS\_TableVerifyFilterEntry().

### 12.15.3.18 DS\_TableVerifyFilter()

```
int32 DS_TableVerifyFilter (
    const void * TableData )
```

Verify packet filter table data.

#### Description

This function is called by cFE Table Services to verify the contents of a candidate Packet Filter Table. This will occur while cFE Table Services is processing another call from the DS application to manage the table. Thus, this verification function will be executed from within the context of the DS application.

#### Called From:

- cFE Table Services

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	TableData	Pointer to Packet Filter Table data
----	-----------	-------------------------------------

#### See also


[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_TableVerifyFilterEntry](#)

Definition at line 522 of file `ds_table.c`.

References CFE\_EVS\_EventType\_INFORMATION, CFE\_EVS\_SendEvent(), CFE\_SB\_IsValidMsgId(), CFE\_SUCC↔ESS, DS\_FLT\_TBL\_EID, DS\_PACKETS\_IN\_FILTER\_TABLE, DS\_TABLE\_VERIFY\_ERR, DS\_TableVerifyFilterEntry(), DS\_PacketEntry\_t::MessageID, and DS\_FilterTable\_t::Packet.

Referenced by DS\_TableInit().

Here is the call graph for this function:



#### 12.15.3.19 DS\_TableVerifyFilterEntry()

```
bool DS_TableVerifyFilterEntry (
    DS_PacketEntry_t * PacketEntry,
    int32 TableIndex,
    int32 ErrorCount )
```

Verify packet filter table entry.

##### Description

This function is called from the Packet Filter Table verification function to verify a single table entry. This function, in turn, calls common utility functions to verify each field within the selected table entry.

##### Called From:

- Packet Filter Table validation function

##### Assumptions, External Events, and Notes:

(none)

##### Parameters

in	<code>PacketEntry</code>	Pointer to a Packet Filter Table entry
in	<code>TableIndex</code>	Index of selected Packet Filter Table entry
in	<code>ErrorCount</code>	Number of errors already encountered

## See also


[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_TableVerifyFilter](#)

Definition at line 576 of file `ds_table.c`.

References `DS_FilterParms_t::Algorithm_N`, `DS_FilterParms_t::Algorithm_O`, `DS_FilterParms_t::Algorithm_X`, `CFE_EVS_EventType_ERROR`, `CFE_EVS_SendEvent()`, `CFE_SB_MsgIdToValue()`, `DS_FILTERS_PER_PACKET`, `DS_FLT_TBL_ERR_EID`, `DS_TableEntryUnused()`, `DS_TableVerifyFileIndex()`, `DS_TableVerifyParms()`, `DS_TableVerifyType()`, `DS_FilterParms_t::FileTableIndex`, `DS_PacketEntry_t::Filter`, `DS_FilterParms_t::FilterType`, and `DS_PacketEntry_t::MessageID`.

Referenced by `DS_TableVerifyFilter()`.

Here is the call graph for this function:



#### 12.15.3.20 DS\_TableVerifyParms()

```
bool DS_TableVerifyParms (
    uint16 Algorithm_N,
    uint16 Algorithm_X,
    uint16 Algorithm_O )
```

Verify packet filter parameters.

**Description**

This function verifies that the indicated packet filter table filter parameters are within bounds. Algorithm N must be  $\leq$  Algorithm X Algorithm O must be  $<$  Algorithm X

**Called From:**

- Command handler (set filter parms)
- Packet Filter Table entry validation function

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>Algorithm_N</i>	Filter Algorithm N value
in	<i>Algorithm_X</i>	Filter Algorithm X value
in	<i>Algorithm_O</i>	Filter Algorithm O value

**See also**

[DS\\_TableVerifyType](#), [DS\\_TableVerifyState](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 698 of file ds\_table.c.

Referenced by [DS\\_CmdSetFilterParms\(\)](#), and [DS\\_TableVerifyFilterEntry\(\)](#).

**12.15.3.21 DS\_TableVerifySize()**

```
bool DS_TableVerifySize (
    uint32 MaxFileSize )
```

Verify destination file max size limit.

**Description**

This function verifies that the indicated destination file max size limit is within bounds - as defined by platform configuration parameters.

**Called From:**

- Command handler (set file max size limit)
- Destination File Table entry validation function

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>MaxFileSize</i>	Maximum Size Limit value
----	--------------------	--------------------------

**See also**

[DS\\_TableVerifyAge](#), [DS\\_TableVerifyCount](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 771 of file ds\_table.c.

References DS\_FILE\_MIN\_SIZE\_LIMIT.

Referenced by DS\_CmdSetDestSize(), and DS\_TableVerifyDestFileEntry().

**12.15.3.22 DS\_TableVerifyState()**

```
bool DS_TableVerifyState (
    uint16 EnableState )
```

Verify application or destination file enable/disable state.

**Description**

This function verifies that the indicated destination file enable/disable state is within bounds. Must be DS\_ENABLED or DS\_DISABLED.

**Called From:**

- Command handler (set application enable/disable state)
- Command handler (set file enable/disable state)
- Destination File Table entry validation function

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>EnableState</i>	Enable/Disable State value
----	--------------------	----------------------------

**See also**

[DS\\_TableVerifySize](#), [DS\\_TableVerifyAge](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 752 of file ds\_table.c.

References DS\_DISABLED, and DS\_ENABLED.

Referenced by DS\_CmdSetAppState(), DS\_CmdSetDestState(), and DS\_TableVerifyDestFileEntry().

#### 12.15.3.23 DS\_TableVerifyType()

```
bool DS_TableVerifyType (
    uint16 TimeVsCount )
```

Verify packet filter type or filename type.

##### Description

This common function verifies that the indicated packet filter table filter type, or destination file table filename type is within bounds. Must be DS\_BY\_COUNT or DS\_BY\_TIME.

##### Called From:

- Command handler (set filter type)
- Command handler (set filename type)
- Packet Filter Table entry validation function
- Destination File Table entry validation function

##### Assumptions, External Events, and Notes:

(none)

##### Parameters

in	TimeVsCount	Filter Type or Filename Type value <a href="#">DS_BY_COUNT</a> or <a href="#">DS_BY_TIME</a>
----	-------------	--

##### See also

[DS\\_TableVerifyState](#), [DS\\_TableVerifySize](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 733 of file ds\_table.c.

References DS\_BY\_COUNT, and DS\_BY\_TIME.

Referenced by DS\_CmdSetDestType(), DS\_CmdSetFilterType(), DS\_TableVerifyDestFileEntry(), and DS\_TableVerifyFilterEntry().

## 12.16 apps/ds/fsw/src/ds\_table.h File Reference

```
#include "cfe.h"
#include "ds_platform_cfg.h"
```

## Data Structures

- struct [DS\\_HashTag](#)  
*DS Hash Table Linked List structure.*
- struct [DS\\_FilterParms\\_t](#)  
*DS Packet Filter Parameters.*
- struct [DS\\_PacketEntry\\_t](#)  
*DS Filter Table Packet Entry.*
- struct [DS\\_FilterTable\\_t](#)  
*DS Filter Table.*
- struct [DS\\_DestFileEntry\\_t](#)  
*DS Destination File Table Entry.*
- struct [DS\\_DestFileTable\\_t](#)  
*DS Destination File Table.*

## Macros

- #define [DS\\_HASH\\_TABLE\\_ENTRIES](#) 256
- #define [DS\\_HASH\\_TABLE\\_MASK](#) 0x00FF

## Typedefs

- typedef struct [DS\\_HashTag](#) [DS\\_HashLink\\_t](#)  
*DS Hash Table Linked List structure.*

## Functions

- int32 [DS\\_TableInit](#) (void)  
*Startup table initialization function.*
- void [DS\\_TableManageDestFile](#) (void)  
*Manage destination file table loads, dumps, etc.*
- void [DS\\_TableManageFilter](#) (void)  
*Manage packet filter table loads, dumps, etc.*
- int32 [DS\\_TableVerifyDestFile](#) (const void \*TableData)  
*Verify destination file table data.*
- bool [DS\\_TableVerifyDestFileEntry](#) ([DS\\_DestFileEntry\\_t](#) \*DestFileEntry, uint8 TableIndex, int32 ErrorCount)  
*Verify destination file table entry.*
- int32 [DS\\_TableVerifyFilter](#) (const void \*TableData)  
*Verify packet filter table data.*
- bool [DS\\_TableVerifyFilterEntry](#) ([DS\\_PacketEntry\\_t](#) \*PacketEntry, int32 TableIndex, int32 ErrorCount)  
*Verify packet filter table entry.*
- bool [DS\\_TableEntryUnused](#) (const void \*TableEntry, int32 BufferSize)  
*Test for unused table entry.*
- bool [DS\\_TableVerifyFileIndex](#) (uint16 FileTableIndex)  
*Verify destination file index.*
- bool [DS\\_TableVerifyParms](#) (uint16 Algorithm\_N, uint16 Algorithm\_X, uint16 Algorithm\_O)

- `bool DS_TableVerifyType (uint16 TimeVsCount)`  
*Verify packet filter type or filename type.*
- `bool DS_TableVerifyState (uint16 EnableState)`  
*Verify application or destination file enable/disable state.*
- `bool DS_TableVerifySize (uint32 MaxFileSize)`  
*Verify destination file max size limit.*
- `bool DS_TableVerifyAge (uint32 MaxFileAge)`  
*Verify destination file max age limit.*
- `bool DS_TableVerifyCount (uint32 SequenceCount)`  
*Verify destination file sequence count.*
- `void DS_TableSubscribe (void)`  
*Subscribe to packet filter table packets.*
- `void DS_TableUnsubscribe (void)`  
*Unsubscribe to packet filter table packets.*
- `int32 DS_TableCreateCDS (void)`  
*Create local area within the Critical Data Store (CDS)*
- `void DS_TableUpdateCDS (void)`  
*Update CDS with current filename sequence count values.*
- `uint32 DS_TableHashFunction (CFE_SB_MsgId_t MessageID)`  
*Hash table function.*
- `void DS_TableCreateHash (void)`  
*Create hash table function.*
- `int32 DS_TableAddMsgID (CFE_SB_MsgId_t MessageID, int32 FilterIndex)`  
*Adds a message ID to the hash table.*
- `int32 DS_TableFindMsgID (CFE_SB_MsgId_t MessageID)`  
*Search packet filter table for message ID.*

### 12.16.1 Detailed Description

CFS Data Storage (DS) table definitions

### 12.16.2 Macro Definition Documentation

#### 12.16.2.1 DS\_HASH\_TABLE\_ENTRIES

```
#define DS_HASH_TABLE_ENTRIES 256
```

Definition at line 37 of file ds\_table.h.

**12.16.2.2 DS\_HASH\_TABLE\_MASK**

```
#define DS_HASH_TABLE_MASK 0x00FF
```

Definition at line 38 of file `ds_table.h`.

Referenced by `DS_TableHashFunction()`.

**12.16.3 Typedef Documentation****12.16.3.1 DS\_HashLink\_t**

```
typedef struct DS_HashTag DS_HashLink_t
```

DS Hash Table Linked List structure.

**12.16.4 Function Documentation****12.16.4.1 DS\_TableAddMsgID()**

```
int32 DS_TableAddMsgID (
    CFE_SB_MsgId_t MessageID,
    int32 FilterIndex )
```

Adds a message ID to the hash table.

**Description**

This function populates the hash table with a new message ID

**Called From:**

- Creation of Hash Table
- Command to add a MID

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>MessageID</i>	Message ID
in	<i>FilterIndex</i>	Filter table index for message ID

**Returns**

Hash table index for message ID

**See also**

[DS\\_HashLink\\_t](#), [DS\\_TableHashFunction](#), [DS\\_TableFindMsgID](#)

Definition at line 1090 of file ds\_table.c.

References DS\_AppData, DS\_TableHashFunction(), DS\_AppData\_t::HashLinks, DS\_AppData\_t::HashTable, DS\_↔ HashTag::Index, DS\_HashTag::MessageID, and DS\_HashTag::Next.

Referenced by DS\_CmdAddMID(), and DS\_TableCreateHash().

Here is the call graph for this function:



#### 12.16.4.2 DS\_TableCreateCDS()

```
int32 DS_TableCreateCDS (
    void )
```

Create local area within the Critical Data Store (CDS)

**Description**

This function creates a new CDS area or gets access to a CDS area created prior to a processor reset. The CDS area will be used to store the current values for destination filename sequence counts.

**Called From:**

- Application initialization function

**Assumptions, External Events, and Notes:**

(none)

**See also**


[DS\\_DestFileEntry\\_t](#)

Definition at line 898 of file ds\_table.c.

References DS\_AppData\_t::AppEnableState, CFE\_ES\_CDS\_ALREADY\_EXISTS, CFE\_ES\_CDS\_BAD\_HANDLE, CFE\_ES\_CopyToCDS(), CFE\_ES\_RegisterCDS(), CFE\_ES\_RestoreFromCDS(), CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_SUCCESS, DS\_AppData\_t::DataStoreHandle, DS\_AppData, DS\_CDS\_NAME, DS\_DEST\_FILE\_CNT, DS\_INIT\_CDS\_ERR\_EID, DS\_AppFileStatus\_t::FileCount, and DS\_AppData\_t::FileStatus.

Referenced by DS\_AppInitialize().

Here is the call graph for this function:



#### 12.16.4.3 DS\_TableCreateHash()

```
void DS_TableCreateHash (
    void )
```

Create hash table function.

##### Description

This function populates the hash table following a new load of the packet filter table. Because there may be more message ID's than hash table entries, the hash table function may translate multiple message ID's into each hash table index. Each hash table entry is a linked list containing a link for each message ID that translates to the same hash table index.

##### Called From:

- Filter table manage updates function (after table load)

##### Assumptions, External Events, and Notes:

(none)

**See also**


[DS\\_HashLink\\_t](#), [DS\\_TableHashFunction](#), [DS\\_TableFindMsgID](#)

Definition at line 1065 of file ds\_table.c.

References DS\_AppData, DS\_PACKETS\_IN\_FILTER\_TABLE, DS\_TableAddMsgID(), DS\_AppData\_t::FilterTblPtr, D←S\_AppData\_t::HashLinks, DS\_AppData\_t::HashTable, DS\_PacketEntry\_t::MessageID, and DS\_FilterTable\_t::Packet.

Referenced by DS\_TableManageFilter().

Here is the call graph for this function:

**12.16.4.4 DS\_TableEntryUnused()**

```
bool DS_TableEntryUnused (
    const void * TableEntry,
    int32 BufferSize )
```

Test for unused table entry.

**Description**

This function returns true if a table entry is unused. Unused is defined as containing nothing but zero's.

**Called From:**

- Packet Filter Table validation function
- Destination File Table validation function

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>TableEntry</i>	Pointer to the table entry data
in	<i>BufferSize</i>	Length of the table entry data

**See also**

[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 654 of file `ds_table.c`.

References `DS_UNUSED`.

Referenced by `DS_TableVerifyDestFile()`, and `DS_TableVerifyFilterEntry()`.

#### 12.16.4.5 DS\_TableFindMsgID()

```
int32 DS_TableFindMsgID (
    CFE_SB_MsgId_t MessageID )
```

Search packet filter table for message ID.

**Description**

This function searches for a packet filter table entry that matches the input argument message ID.

**Called From:**

- Data storage packet processor
- Command handler (set file index)
- Command handler (set filter type)
- Command handler (set filter parms)
- Command handler (add messageID to filter table)

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>MessageID</i>	Message ID
----	------------------	------------

**Returns**

Filter table index for message ID

**See also**

[DS\\_HashLink\\_t](#), [DS\\_TableHashFunction](#), [DS\\_TableCreateHash](#)

Definition at line 1136 of file ds\_table.c.

References CFE\_SB\_MsgIdToValue(), DS\_AppData, DS\_INDEX\_NONE, DS\_TableHashFunction(), DS\_AppData\_t::FilterTblPtr, DS\_AppData\_t::HashTable, DS\_HashTag::Index, DS\_PacketEntry\_t::MessageID, DS\_HashTag::Next, and DS\_FilterTable\_t::Packet.

Referenced by DS\_AppProcessMsg(), DS\_CmdAddMID(), DS\_CmdSetFilterFile(), DS\_CmdSetFilterParms(), DS\_CmdSetFilterType(), and DS\_FileStorePacket().

Here is the call graph for this function:



#### 12.16.4.6 DS\_TableHashFunction()

```
uint32 DS_TableHashFunction (
    CFE_SB_MsgId_t MessageID )
```

Hash table function.

##### Description

This function converts a cFE MessageID into an index into the hash table. The indexed hash table entry contains a linked list where each link identifies a single entry in the packet filter table. Thus, the scope of searching the Packet Filter Table for a specific MessageID has been reduced from searching the total number of entries in the filter table by a factor equal to the size of the hash table.

##### Called From:

- Hash table creation function (after load filter table)
- Find messageID in filter table function

##### Assumptions, External Events, and Notes:

(none)

##### Parameters

in	MessageID	Message ID
----	-----------	------------

**Returns**

Index of hash table entry for input message ID

**See also**

[DS\\_HashLink\\_t](#), [DS\\_TableCreateHash](#), [DS\\_TableFindMsgID](#)

Definition at line 1022 of file `ds_table.c`.

References `CFE_SB_MsgIdToValue()`, and `DS_HASH_TABLE_MASK`.

Referenced by `DS_TableAddMsgID()`, and `DS_TableFindMsgID()`.

Here is the call graph for this function:



#### 12.16.4.7 DS\_TableInit()

```
int32 DS_TableInit (
    void )
```

Startup table initialization function.

**Description**

This function creates the Packet Filter and Destination File tables. The function then tries to load default table data for each table. If the Packet Filter Table load is successful, then the function will subscribe to all of the packets referenced by the table.

**Called From:**

- DS startup initialization function

**Assumptions, External Events, and Notes:**

(none)

## See also


[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 47 of file ds\_table.c.

References CFE\_EVS\_EventType\_DEBUG, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_SUCCESS, CFE\_TBL\_INFO\_RECOVERED\_TBL, CFE\_TBL\_Load(), CFE\_TBL\_OPT\_CRITICAL, CFE\_TBL\_OPT\_LOAD\_DUMP, CFE\_TBL\_OPT\_SNGL\_BUFFER, CFE\_TBL\_Register(), CFE\_TBL\_SRC\_FILE, DS\_AppData\_t::DestFileTblHandle, DS\_AppData, DS\_DEF\_DEST\_FILENAME, DS\_DEF\_FILTER\_FILENAME, DS\_DESTINATION\_TBL\_NAME, DS\_FILTER\_TBL\_NAME, DS\_INIT\_TBL\_CDS\_EID, DS\_INIT\_TBL\_ERR\_EID, DS\_TableManageDestFile(), DS\_TableManageFilter(), DS\_TableVerifyDestFile(), and DS\_AppData\_t::FilterTblHandle.

Referenced by DS\_AppInitialize().

Here is the call graph for this function:



#### 12.16.4.8 DS\_TableManageDestFile()

```
void DS_TableManageDestFile (
    void )
```

Manage destination file table loads, dumps, etc.

**Description**

This function will provide cFE Table Services with an opportunity to make updates to the Destination File Table while in the context of the DS application. There is no special handling necessary if a new version of this table is loaded.

**Called From:**

- DS table initialization function
- DS housekeeping request command processor

**Assumptions, External Events, and Notes:**

(none)

**See also**


[DS\\_DestFileEntry\\_t](#), [DS\\_TableVerifyDestFile](#)

Definition at line 186 of file ds\_table.c.

References CFE\_SUCCESS, CFE\_TBL\_DumpToBuffer(), CFE\_TBL\_ERR\_NEVER\_LOADED, CFE\_TBL\_GetAddress(), CFE\_TBL\_GetStatus(), CFE\_TBL\_INFO\_DUMP\_PENDING, CFE\_TBL\_INFO\_UPDATE\_PENDING, CFE\_TBL\_INFO\_UPDATED, CFE\_TBL\_INFO\_VALIDATION\_PENDING, CFE\_TBL\_Manage(), CFE\_TBL\_ReleaseAddress(), CFE\_TBL\_Update(), CFE\_TBL\_Validate(), DS\_AppData\_t::DestFileTblHandle, DS\_AppData\_t::DestFileTblPtr, DS\_AppData\_t::DestTblErrCounter, DS\_AppData\_t::DestTblLoadCounter, DS\_AppData, DS\_DEST\_FILE\_CNT, DS\_TableUpdateCDS(), DS\_DestFileEntry\_t::EnableState, DS\_DestFileTable\_t::File, DS\_AppFileStatus\_t::FileCount, DS\_AppFileStatus\_t::FileState, DS\_AppData\_t::FileStatus, and DS\_DestFileEntry\_t::SequenceCount.

Referenced by DS\_AppMain(), DS\_AppProcessHK(), and DS\_TableInit().

Here is the call graph for this function:



#### 12.16.4.9 DS\_TableManageFilter()

```
void DS_TableManageFilter (
    void )
```

Manage packet filter table loads, dumps, etc.

##### Description

This function will provide cFE Table Services with an opportunity to make updates to the Packet Filter Table while in the context of the DS application. If a new version of the filter table gets loaded, the function will first unsubscribe to any packets referenced by the previous version of the table, and then subscribe to all packets referenced by the new version of the table.

##### Called From:

- DS table initialization function
- DS housekeeping request command processor

##### Assumptions, External Events, and Notes:

(none)

##### See also


[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_TableVerifyFilter](#)

Definition at line 296 of file ds\_table.c.

References CFE\_SUCCESS, CFE\_TBL\_DumpToBuffer(), CFE\_TBL\_ERR\_NEVER\_LOADED, CFE\_TBL\_GetAddress(), CFE\_TBL\_GetStatus(), CFE\_TBL\_INFO\_DUMP\_PENDING, CFE\_TBL\_INFO\_UPDATE\_PENDING, CFE\_TBL\_INFO\_UPDATED, CFE\_TBL\_INFO\_VALIDATION\_PENDING, CFE\_TBL\_Manage(), CFE\_TBL\_ReleaseAddress(), CFE\_TBL\_Update(), CFE\_TBL\_Validate(), DS\_AppData, DS\_TableCreateHash(), DS\_TableSubscribe(), DS\_TableUnsubscribe(), DS\_AppData\_t::FilterTblErrCounter, DS\_AppData\_t::FilterTblHandle, DS\_AppData\_t::FilterTblLoadCounter, and DS\_AppData\_t::FilterTblPtr.

Referenced by DS\_AppMain(), DS\_AppProcessHK(), and DS\_TableInit().

Here is the call graph for this function:



#### 12.16.4.10 DS\_TableSubscribe()

```
void DS_TableSubscribe (
    void )
```

Subscribe to packet filter table packets.

##### Description

A new Packet Filter Table is available for use. This function is called to subscribe to packets referenced by the new filter table.

##### Called From:

- Packet Filter Table manage function

##### Assumptions, External Events, and Notes:

Caller has determined that the new filter table exists.

##### See also


[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_TableUnsubscribe](#)

Definition at line 828 of file ds\_table.c.

References CFE\_SB\_DEFAULT\_QOS, CFE\_SB\_INVALID\_MSG\_ID, CFE\_SB\_IsValidMsgId(), CFE\_SB\_MsgIdToValue(), CFE\_SB\_SubscribeEx(), DS\_AppData, DS\_CMD\_MID, DS\_PACKETS\_IN\_FILTER\_TABLE, DS\_PER\_PACKET\_PIPE\_LIMIT, DS\_SEND\_HK\_MID, DS\_AppData\_t::FilterTblPtr, DS\_AppData\_t::InputPipe, DS\_PacketEntry\_t::MessageID, and DS\_FilterTable\_t::Packet.

Referenced by DS\_TableManageFilter().

Here is the call graph for this function:



#### 12.16.4.11 DS\_TableUnsubscribe()

```
void DS_TableUnsubscribe (
    void )
```

Unsubscribe to packet filter table packets.

##### Description

A new Packet Filter Table is available for use. Prior to subscribing to the packets referenced by the new filter table, this function is called to unsubscribe to packets referenced by the old filter table.

##### Called From:

- Packet Filter Table manage function

##### Assumptions, External Events, and Notes:

Caller has determined that the old filter table exists.

##### See also


[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_TableSubscribe](#)

Definition at line 863 of file ds\_table.c.

References CFE\_SB\_INVALID\_MSG\_ID, CFE\_SB\_IsValidMsgId(), CFE\_SB\_MsgIdToValue(), CFE\_SB\_Unsubscribe(), DS\_AppData, DS\_CMD\_MID, DS\_PACKETS\_IN\_FILTER\_TABLE, DS\_SEND\_HK\_MID, DS\_AppData\_t::FilterTblPtr, DS\_AppData\_t::InputPipe, DS\_PacketEntry\_t::MessageID, and DS\_FilterTable\_t::Packet.

Referenced by DS\_TableManageFilter().

Here is the call graph for this function:



#### 12.16.4.12 DS\_TableUpdateCDS()

```
void DS_TableUpdateCDS (
    void )
```

Update CDS with current filename sequence count values.

##### Description

This function writes the current filename sequence count values to the Critical Data Store. The function is called each time the sequence count values are modified.

##### Called From:

- Destination table data update handler
- Destination file creation function
- Command handler (set sequence count)

##### Assumptions, External Events, and Notes:

(none)

##### See also


[DS\\_DestFileEntry\\_t](#)

Definition at line 970 of file ds\_table.c.

References DS\_AppData\_t::AppEnableState, CFE\_ES\_CDS\_BAD\_HANDLE, CFE\_ES\_CopyToCDS(), CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_RESOURCEID\_TEST\_EQUAL, CFE\_SUCCESS, DS\_AppData\_t::DataStoreHandle, DS\_AppData, DS\_DEST\_FILE\_CNT, DS\_INIT\_CDS\_ERR\_EID, DS\_AppFileStatus\_t::FileCount, and DS\_AppData\_t::FileStatus.

Referenced by DS\_CmdSetAppState(), DS\_CmdSetDestCount(), DS\_FileCreateDest(), and DS\_TableManageDestFile().

Here is the call graph for this function:



#### 12.16.4.13 DS\_TableVerifyAge()

```
bool DS_TableVerifyAge (
    uint32 MaxFileAge )
```

Verify destination file max age limit.

##### Description

This function verifies that the indicated destination file max age limit is within bounds - as defined by platform configuration parameters.

##### Called From:

- Command handler (set file max age limit)
- Destination File Table entry validation function

##### Assumptions, External Events, and Notes:

(none)

##### Parameters

in	MaxFileAge	Maximum Age Limit value
----	------------	-------------------------

##### See also

[DS\\_TableVerifySize](#), [DS\\_TableVerifyCount](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 790 of file ds\_table.c.

References DS\_FILE\_MIN\_AGE\_LIMIT.

Referenced by DS\_CmdSetDestAge(), and DS\_TableVerifyDestFileEntry().

#### 12.16.4.14 DS\_TableVerifyCount()

```
bool DS_TableVerifyCount (
    uint32 SequenceCount )
```

Verify destination file sequence count.

##### Description

This function verifies that the indicated destination file sequence count is within bounds - as defined by platform configuration parameters.

**Called From:**

- Command handler (set file sequence count)
- Destination File Table entry validation function

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>SequenceCount</i>	Sequence Count value
----	----------------------	----------------------

**See also**

[DS\\_TableVerifySize](#), [DS\\_TableVerifyAge](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 809 of file ds\_table.c.

References DS\_MAX\_SEQUENCE\_COUNT.

Referenced by DS\_CmdSetDestCount(), and DS\_TableVerifyDestFileEntry().

#### 12.16.4.15 DS\_TableVerifyDestFile()

```
int32 DS_TableVerifyDestFile (
    const void * TableData )
```

Verify destination file table data.

**Description**

This function is called by cFE Table Services to verify the contents of a candidate Destination File Table. This will occur while cFE Table Services is processing another call from the DS application to manage the table. Thus, this verification function will be executed from within the context of the DS application.

**Called From:**

- cFE Table Services

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>TableData</i>	Pointer to Destination File Table data
----	------------------	--

**See also**


[DS\\_DestFileEntry\\_t](#), [DS\\_TableVerifyDestFileEntry](#)

Definition at line 403 of file ds\_table.c.

References CFE\_EVS\_EventType\_INFORMATION, CFE\_EVS\_SendEvent(), CFE\_SUCCESS, DS\_DEST\_FILE\_CNT, DS\_FIL\_TBL\_EID, DS\_TABLE\_VERIFY\_ERR, DS\_TableEntryUnused(), DS\_TableVerifyDestFileEntry(), and DS\_DestFileTable\_t::File.

Referenced by DS\_TableInit().

Here is the call graph for this function:



#### 12.16.4.16 DS\_TableVerifyDestFileEntry()

```

bool DS_TableVerifyDestFileEntry (
    DS_DestFileEntry_t * DestFileEntry,
    uint8 TableIndex,
    int32 ErrorCount )
  
```

Verify destination file table entry.

##### Description

This function is called from the Destination File Table verification function to verify a single table entry. This function, in turn, calls common utility functions to verify each field within the selected table entry.

##### Called From:

- Destination File Table validation function

##### Assumptions, External Events, and Notes:

(none)

### Parameters

in	<i>DestFileEntry</i>	Pointer to selected Destination File Table entry
in	<i>TableIndex</i>	Index of selected Destination File Table entry
in	<i>ErrorCount</i>	Number of errors already encountered

### See also


[DS\\_DestFileEntry\\_t](#), [DS\\_TableVerifyDestFile](#)

Definition at line 451 of file ds\_table.c.

References CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), DS\_FIL\_TBL\_ERR\_EID, DS\_TableVerifyAge(), DS\_TableVerifyCount(), DS\_TableVerifySize(), DS\_TableVerifyState(), DS\_TableVerifyType(), DS\_DestFileEntry\_t::EnableState, DS\_DestFileEntry\_t::FileNameType, DS\_DestFileEntry\_t::MaxFileAge, DS\_DestFileEntry\_t::MaxFileSize, and DS\_DestFileEntry\_t::SequenceCount.

Referenced by DS\_TableVerifyDestFile().

Here is the call graph for this function:



#### 12.16.4.17 DS\_TableVerifyFileIndex()

```
bool DS_TableVerifyFileIndex (
    uint16 FileTableIndex )
```

Verify destination file index.

#### Description

This function verifies that the indicated packet filter table file table index is within bounds - as defined by platform configuration parameters. Note that the utility functions are also called from the ground command handlers to verify command arguments that modify the table data.

#### Called From:

- Command handler (set file table index)
- Command handler (set filename type)
- Command handler (set file enable/disable state)
- Command handler (set pathname)
- Command handler (set basename)
- Command handler (set extension)
- Command handler (set max file size limit)
- Command handler (set max file age limit)
- Command handler (set file sequence count)
- Command handler (close file)
- Packet Filter Table entry validation function

#### Assumptions, External Events, and Notes:

(none)

#### Parameters

in	<i>FileTableIndex</i>	Destination File Table Index value
----	-----------------------	------------------------------------

#### See also

[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 679 of file ds\_table.c.

References DS\_DEST\_FILE\_CNT.

Referenced by DS\_CmdCloseFile(), DS\_CmdSetDestAge(), DS\_CmdSetDestBase(), DS\_CmdSetDestCount(), DS\_CmdSetDestExt(), DS\_CmdSetDestPath(), DS\_CmdSetDestSize(), DS\_CmdSetDestState(), DS\_CmdSetDestType(), DS\_CmdSetFilterFile(), and DS\_TableVerifyFilterEntry().

#### 12.16.4.18 DS\_TableVerifyFilter()

```
int32 DS_TableVerifyFilter (
    const void * TableData )
```

Verify packet filter table data.

##### Description

This function is called by cFE Table Services to verify the contents of a candidate Packet Filter Table. This will occur while cFE Table Services is processing another call from the DS application to manage the table. Thus, this verification function will be executed from within the context of the DS application.

##### Called From:

- cFE Table Services

##### Assumptions, External Events, and Notes:

(none)

##### Parameters

in	TableData	Pointer to Packet Filter Table data
----	-----------	-------------------------------------

##### See also


[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_TableVerifyFilterEntry](#)

Definition at line 522 of file ds\_table.c.

References CFE\_EVS\_EventType\_INFORMATION, CFE\_EVS\_SendEvent(), CFE\_SB\_IsValidMsgId(), CFE\_SUCC↔ESS, DSFLT\_TBL\_EID, DS\_PACKETS\_IN\_FILTER\_TABLE, DS\_TABLE\_VERIFY\_ERR, DS\_TableVerifyFilterEntry(), DS\_PacketEntry\_t::MessageID, and DS\_FilterTable\_t::Packet.

Referenced by DS\_TableInit().

Here is the call graph for this function:



#### 12.16.4.19 DS\_TableVerifyFilterEntry()

```

bool DS_TableVerifyFilterEntry (
    DS_PacketEntry_t * PacketEntry,
    int32 TableIndex,
    int32 ErrorCount )
  
```

Verify packet filter table entry.

##### Description

This function is called from the Packet Filter Table verification function to verify a single table entry. This function, in turn, calls common utility functions to verify each field within the selected table entry.

##### Called From:

- Packet Filter Table validation function

##### Assumptions, External Events, and Notes:

(none)

##### Parameters

in	<code>PacketEntry</code>	Pointer to a Packet Filter Table entry
in	<code>TableIndex</code>	Index of selected Packet Filter Table entry
in	<code>ErrorCount</code>	Number of errors already encountered

**See also**


[DS\\_PacketEntry\\_t](#), [DS\\_FilterParms\\_t](#), [DS\\_TableVerifyFilter](#)

Definition at line 576 of file ds\_table.c.

References DS\_FilterParms\_t::Algorithm\_N, DS\_FilterParms\_t::Algorithm\_O, DS\_FilterParms\_t::Algorithm\_X, CFE\_EVS\_EventType\_ERROR, CFE\_EVS\_SendEvent(), CFE\_SB\_MsgIdToValue(), DS\_FILTERS\_PER\_PACKET, DSFLT\_TBL\_ERR\_EID, DS\_TableEntryUnused(), DS\_TableVerifyFileIndex(), DS\_TableVerifyParms(), DS\_TableVerifyType(), DS\_FilterParms\_t::FileTableIndex, DS\_PacketEntry\_t::Filter, DS\_FilterParms\_t::FilterType, and DS\_PacketEntry\_t::MessageID.

Referenced by DS\_TableVerifyFilter().

Here is the call graph for this function:



#### 12.16.4.20 DS\_TableVerifyParms()

```
bool DS_TableVerifyParms (
    uint16 Algorithm_N,
    uint16 Algorithm_X,
    uint16 Algorithm_O )
```

Verify packet filter parameters.

**Description**

This function verifies that the indicated packet filter table filter parameters are within bounds. Algorithm N must be  $\leq$  Algorithm X Algorithm O must be  $<$  Algorithm X

**Called From:**

- Command handler (set filter parms)
- Packet Filter Table entry validation function

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>Algorithm_N</i>	Filter Algorithm N value
in	<i>Algorithm_X</i>	Filter Algorithm X value
in	<i>Algorithm_O</i>	Filter Algorithm O value

**See also**

[DS\\_TableVerifyType](#), [DS\\_TableVerifyState](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 698 of file ds\_table.c.

Referenced by [DS\\_CmdSetFilterParms\(\)](#), and [DS\\_TableVerifyFilterEntry\(\)](#).

**12.16.4.21 DS\_TableVerifySize()**

```
bool DS_TableVerifySize (
    uint32 MaxFileSize )
```

Verify destination file max size limit.

**Description**

This function verifies that the indicated destination file max size limit is within bounds - as defined by platform configuration parameters.

**Called From:**

- Command handler (set file max size limit)
- Destination File Table entry validation function

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>MaxFileSize</i>	Maximum Size Limit value
----	--------------------	--------------------------

**See also**

[DS\\_TableVerifyAge](#), [DS\\_TableVerifyCount](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 771 of file ds\_table.c.

References DS\_FILE\_MIN\_SIZE\_LIMIT.

Referenced by DS\_CmdSetDestSize(), and DS\_TableVerifyDestFileEntry().

**12.16.4.22 DS\_TableVerifyState()**

```
bool DS_TableVerifyState (
    uint16 EnableState )
```

Verify application or destination file enable/disable state.

**Description**

This function verifies that the indicated destination file enable/disable state is within bounds. Must be DS\_ENABLED or DS\_DISABLED.

**Called From:**

- Command handler (set application enable/disable state)
- Command handler (set file enable/disable state)
- Destination File Table entry validation function

**Assumptions, External Events, and Notes:**

(none)

**Parameters**

in	<i>EnableState</i>	Enable/Disable State value
----	--------------------	----------------------------

**See also**

[DS\\_TableVerifySize](#), [DS\\_TableVerifyAge](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 752 of file ds\_table.c.

References DS\_DISABLED, and DS\_ENABLED.

Referenced by DS\_CmdSetAppState(), DS\_CmdSetDestState(), and DS\_TableVerifyDestFileEntry().

#### 12.16.4.23 DS\_TableVerifyType()

```
bool DS_TableVerifyType (
    uint16 TimeVsCount )
```

Verify packet filter type or filename type.

##### Description

This common function verifies that the indicated packet filter table filter type, or destination file table filename type is within bounds. Must be DS\_BY\_COUNT or DS\_BY\_TIME.

##### Called From:

- Command handler (set filter type)
- Command handler (set filename type)
- Packet Filter Table entry validation function
- Destination File Table entry validation function

##### Assumptions, External Events, and Notes:

(none)

##### Parameters

in	TimeVsCount	Filter Type or Filename Type value <a href="#">DS_BY_COUNT</a> or <a href="#">DS_BY_TIME</a>
----	-------------	--

##### See also

[DS\\_TableVerifyState](#), [DS\\_TableVerifySize](#), [DS\\_DestFileEntry\\_t](#)

Definition at line 733 of file ds\_table.c.

References DS\_BY\_COUNT, and DS\_BY\_TIME.

Referenced by DS\_CmdSetDestType(), DS\_CmdSetFilterType(), DS\_TableVerifyDestFileEntry(), and DS\_TableVerifyFilterEntry().

#### 12.17 apps/ds/fsw/src/ds\_verify.h File Reference

```
#include "cfe.h"
#include "ds_platform_cfg.h"
```

### 12.17.1 Detailed Description

Define the CFS Data Storage (DS) Application compile-time checks

## 12.18 apps/ds/fsw/src/ds\_version.h File Reference

### Macros

- `#define DS_MAJOR_VERSION 2`  
*Major version number.*
- `#define DS_MINOR_VERSION 6`  
*Minor version number.*
- `#define DS_REVISION 99`  
*Revision number.*

### 12.18.1 Detailed Description

The CFS Data Storage (DS) Application header file containing version number

## 12.19 apps/ds/fsw/tables/ds\_file\_tbl.c File Reference

```
#include "cfe.h"
#include "cfe_tbl_filedef.h"
#include "ds_platform_cfg.h"
#include "ds_appdefs.h"
#include "ds_app.h"
#include "ds_msg.h"
```

### Macros

- `#define FILE_ALL_EVENTS 0`
- `#define FILE_ALL_APP_HK_PKTS 1`
- `#define FILE_ALL_APP_TLM_PKTS 2`
- `#define FILE_ALL_HW_TLM_PKTS 3`
- `#define FILE_CFE_APP_HK_PKTS 4`
- `#define FILE_CFE_APP_TLM_PKTS 5`

### Variables

- `DS_DestFileTable_t DS_DestFileTable`

### 12.19.1 Detailed Description

CFS Data Storage (DS) sample destination file table

#### Note

This source file creates a sample table that defines several data storage destination files using a variety of the options available. None of the file system details (name, size, etc.) are known at this time for the target platform. Therefore, the file pathnames are set to "set\_by\_cmd\_b4\_enable" which indicates that pathnames must be set by command before trying to enable any of the destination files. Max file size values should also be modified via command before using this table.

Obviously, a better solution is to replace this sample table and the sample packet filter table (which references this table) with mission specific versions that define the data storage behavior appropriate for the platform.

But, as long as the target platform has a file system, the sample data storage tables may be used to demonstrate data storage.

### 12.19.2 Macro Definition Documentation

#### 12.19.2.1 FILE\_ALL\_APP\_HK\_PKTS

```
#define FILE_ALL_APP_HK_PKTS 1
```

Definition at line 61 of file ds\_file\_tbl.c.

#### 12.19.2.2 FILE\_ALL\_APP\_TLM\_PKTS

```
#define FILE_ALL_APP_TLM_PKTS 2
```

Definition at line 62 of file ds\_file\_tbl.c.

#### 12.19.2.3 FILE\_ALL\_EVENTS

```
#define FILE_ALL_EVENTS 0
```

Definition at line 59 of file ds\_file\_tbl.c.

#### 12.19.2.4 FILE\_ALL\_HW\_TLM\_PKTS

```
#define FILE_ALL_HW_TLM_PKTS 3
```

Definition at line 64 of file ds\_file\_tbl.c.

#### 12.19.2.5 FILE\_CFE\_APP\_HK\_PKTS

```
#define FILE_CFE_APP_HK_PKTS 4
```

Definition at line 66 of file ds\_file\_tbl.c.

#### 12.19.2.6 FILE\_CFE\_APP\_TLM\_PKTS

```
#define FILE_CFE_APP_TLM_PKTS 5
```

Definition at line 67 of file ds\_file\_tbl.c.

### 12.19.3 Variable Documentation

#### 12.19.3.1 DS\_DestFileTable

[DS\\_DestFileTable\\_t](#) DS\_DestFileTable

Definition at line 72 of file ds\_file\_tbl.c.

## 12.20 apps/ds/fsw/tables/ds\_filter\_tbl.c File Reference

```
#include "cfe.h"
#include "cfe_tbl_filedef.h"
#include "ds_platform_cfg.h"
#include "ds_appdefs.h"
#include "ds_app.h"
#include "ds_msg.h"
#include "cfe_msgids.h"
#include "ds_msgids.h"
```

## Macros

- #define FILE\_ALL\_EVENTS 0
- #define FILE\_ALL\_APP\_HK\_PKTS 1
- #define FILE\_ALL\_APP\_TLM\_PKTS 2
- #define FILE\_ALL\_HW\_TLM\_PKTS 3
- #define FILE\_CFE\_APP\_HK\_PKTS 4
- #define FILE\_CFE\_APP\_TLM\_PKTS 5

## Variables

- DS\_FilterTable\_t DS\_FilterTable

### 12.20.1 Detailed Description

CFS Data Storage (DS) sample packet filter table

#### Note

This source file creates a sample table that stores packets using several different destination storage files. Some packets have one filter that is set to store every packet in one file and another filter that will store every other packet in a second file. Also, some filters are disabled and thus will not store any packets. There is no real purpose to this particular set of filters other than to provide an example of how various fields in the table might be used.

### 12.20.2 Macro Definition Documentation

#### 12.20.2.1 FILE\_ALL\_APP\_HK\_PKTS

```
#define FILE_ALL_APP_HK_PKTS 1
```

Definition at line 73 of file ds\_filter\_tbl.c.

#### 12.20.2.2 FILE\_ALL\_APP\_TLM\_PKTS

```
#define FILE_ALL_APP_TLM_PKTS 2
```

Definition at line 74 of file ds\_filter\_tbl.c.

### 12.20.2.3 FILE\_ALL\_EVENTS

```
#define FILE_ALL_EVENTS 0
```

Definition at line 71 of file ds\_filter\_tbl.c.

### 12.20.2.4 FILE\_ALL\_HW\_TLM\_PKTS

```
#define FILE_ALL_HW_TLM_PKTS 3
```

Definition at line 76 of file ds\_filter\_tbl.c.

### 12.20.2.5 FILE\_CFE\_APP\_HK\_PKTS

```
#define FILE_CFE_APP_HK_PKTS 4
```

Definition at line 78 of file ds\_filter\_tbl.c.

### 12.20.2.6 FILE\_CFE\_APP\_TLM\_PKTS

```
#define FILE_CFE_APP_TLM_PKTS 5
```

Definition at line 79 of file ds\_filter\_tbl.c.

## 12.20.3 Variable Documentation

### 12.20.3.1 DS\_FilterTable

```
DS_FilterTable_t DS_FilterTable
```

Definition at line 84 of file ds\_filter\_tbl.c.

## 12.21 build/docs/osconfig-example.h File Reference

### Macros

- `#define OS_MAX_TASKS`  
*Configuration file Operating System Abstraction Layer.*
- `#define OS_MAX_QUEUES`  
*The maximum number of queues to support.*
- `#define OS_MAX_COUNT_SEMAPHORES`  
*The maximum number of counting semaphores to support.*
- `#define OS_MAX_BIN_SEMAPHORES`  
*The maximum number of binary semaphores to support.*
- `#define OS_MAX_MUTEXES`  
*The maximum number of mutexes to support.*
- `#define OS_MAX_MODULES`  
*The maximum number of modules to support.*
- `#define OS_MAX_TIMEBASES`  
*The maximum number of timebases to support.*
- `#define OS_MAX_TIMERS`  
*The maximum number of timer callbacks to support.*
- `#define OS_MAX_NUM_OPEN_FILES`  
*The maximum number of concurrently open files to support.*
- `#define OS_MAX_NUM_OPEN_DIRS`  
*The maximum number of concurrently open directories to support.*
- `#define OS_MAX_FILE_SYSTEMS`  
*The maximum number of file systems to support.*
- `#define OS_MAX_SYM_LEN`  
*The maximum length of symbols.*
- `#define OS_MAX_FILE_NAME`  
*The maximum length of OSAL file names.*
- `#define OS_MAX_PATH_LEN`  
*The maximum length of OSAL path names.*
- `#define OS_MAX_API_NAME`  
*The maximum length of OSAL resource names.*
- `#define OS_SOCKADDR_MAX_LEN`  
*The maximum size of the socket address structure.*
- `#define OS_BUFFER_SIZE`  
*The maximum size of output produced by a single `OS_printf()`.*
- `#define OS_BUFFER_MSG_DEPTH`  
*The maximum number of `OS_printf()` output strings to buffer.*
- `#define OS.UtilityTask_PRIORITY`  
*Priority level of the background utility task.*
- `#define OS.UtilityTask_STACK_SIZE`  
*The stack size of the background utility task.*
- `#define OS_MAX_CMD_LEN`  
*The maximum size of a shell command.*
- `#define OS_QUEUE_MAX_DEPTH`

- `#define OS_SHELL_CMD_INPUT_FILE_NAME ""`  
*The name of the temporary file used to store shell commands.*
- `#define OS_PRINTF_CONSOLE_NAME ""`  
*The name of the primary console device.*
- `#define OS_MAX_CONSOLES 1`  
*The maximum number of console devices to support.*
- `#define OS_MODULE_FILE_EXTENSION ".so"`  
*The system-specific file extension used on loadable module files.*
- `#define OS_FS_DEV_NAME_LEN 32`
- `#define OS_FS_PHYS_NAME_LEN 64`
- `#define OS_FS_VOL_NAME_LEN 32`

### 12.21.1 Macro Definition Documentation

#### 12.21.1.1 OS\_BUFFER\_MSG\_DEPTH

```
#define OS_BUFFER_MSG_DEPTH
```

The maximum number of [OS\\_printf\(\)](#) output strings to buffer.

Based on the OSAL\_CONFIG\_PRINTF\_BUFFER\_DEPTH configuration option

Definition at line 180 of file osconfig-example.h.

#### 12.21.1.2 OS\_BUFFER\_SIZE

```
#define OS_BUFFER_SIZE
```

The maximum size of output produced by a single [OS\\_printf\(\)](#)

Based on the OSAL\_CONFIG\_PRINTF\_BUFFER\_SIZE configuration option

Definition at line 173 of file osconfig-example.h.

#### 12.21.1.3 OS\_FS\_DEV\_NAME\_LEN

```
#define OS_FS_DEV_NAME_LEN 32
```

Device name length

Definition at line 265 of file osconfig-example.h.

#### 12.21.1.4 OS\_FS\_PHYS\_NAME\_LEN

```
#define OS_FS_PHYS_NAME_LEN 64
```

Physical drive name length

Definition at line 266 of file osconfig-example.h.

#### 12.21.1.5 OS\_FS\_VOL\_NAME\_LEN

```
#define OS_FS_VOL_NAME_LEN 32
```

Volume name length

Definition at line 267 of file osconfig-example.h.

#### 12.21.1.6 OS\_MAX\_API\_NAME

```
#define OS_MAX_API_NAME
```

The maximum length of OSAL resource names.

Based on the OSAL\_CONFIG\_MAX\_API\_NAME configuration option

##### Note

This value must include a terminating NUL character

Definition at line 156 of file osconfig-example.h.

#### 12.21.1.7 OS\_MAX\_BIN\_SEMAPHORES

```
#define OS_MAX_BIN_SEMAPHORES
```

The maximum number of binary semaphores to support.

Based on the OSAL\_CONFIG\_MAX\_BIN\_SEMAPHORES configuration option

Definition at line 65 of file osconfig-example.h.

### 12.21.1.8 OS\_MAX\_CMD\_LEN

```
#define OS_MAX_CMD_LEN
```

The maximum size of a shell command.

This limit is only applicable if shell support is enabled.

Based on the OSAL\_CONFIG\_MAX\_CMD\_LEN configuration option

#### Note

This value must include a terminating NUL character

Definition at line 211 of file osconfig-example.h.

### 12.21.1.9 OS\_MAX\_CONSOLES

```
#define OS_MAX_CONSOLES 1
```

The maximum number of console devices to support.

Fixed value based on current OSAL implementation, not user configurable.

Definition at line 253 of file osconfig-example.h.

### 12.21.1.10 OS\_MAX\_COUNT\_SEMAPHORES

```
#define OS_MAX_COUNT_SEMAPHORES
```

The maximum number of counting semaphores to support.

Based on the OSAL\_CONFIG\_MAX\_COUNT\_SEMAPHORES configuration option

Definition at line 58 of file osconfig-example.h.

### 12.21.1.11 OS\_MAX\_FILE\_NAME

```
#define OS_MAX_FILE_NAME
```

The maximum length of OSAL file names.

This limit applies specifically to the file name portion, not the directory portion, of a path name.

Based on the OSAL\_CONFIG\_MAX\_FILE\_NAME configuration option

#### Note

This value must include a terminating NUL character

Definition at line 135 of file osconfig-example.h.

### 12.21.1.12 OS\_MAX\_FILE\_SYSTEMS

```
#define OS_MAX_FILE_SYSTEMS
```

The maximum number of file systems to support.

Based on the OSAL\_CONFIG\_MAX\_FILE\_SYSTEMS configuration option

Definition at line 114 of file osconfig-example.h.

### 12.21.1.13 OS\_MAX\_MODULES

```
#define OS_MAX_MODULES
```

The maximum number of modules to support.

Based on the OSAL\_CONFIG\_MAX\_MODULES configuration option

Definition at line 79 of file osconfig-example.h.

### 12.21.1.14 OS\_MAX\_MUTEXES

```
#define OS_MAX_MUTEXES
```

The maximum number of mutexes to support.

Based on the OSAL\_CONFIG\_MAX\_MUTEXES configuration option

Definition at line 72 of file osconfig-example.h.

### 12.21.1.15 OS\_MAX\_NUM\_OPEN\_DIRS

```
#define OS_MAX_NUM_OPEN_DIRS
```

The maximum number of concurrently open directories to support.

Based on the OSAL\_CONFIG\_MAX\_NUM\_OPEN\_DIRS configuration option

Definition at line 107 of file osconfig-example.h.

### 12.21.1.16 OS\_MAX\_NUM\_OPEN\_FILES

```
#define OS_MAX_NUM_OPEN_FILES
```

The maximum number of concurrently open files to support.

Based on the OSAL\_CONFIG\_MAX\_NUM\_OPEN\_FILES configuration option

Definition at line 100 of file osconfig-example.h.

### 12.21.1.17 OS\_MAX\_PATH\_LEN

```
#define OS_MAX_PATH_LEN
```

The maximum length of OSAL path names.

This limit applies to the overall length of a path name, including the file name and directory portions.

Based on the OSAL\_CONFIG\_MAX\_PATH\_LEN configuration option

#### Note

This value must include a terminating NUL character

Definition at line 147 of file osconfig-example.h.

Referenced by DS\_AppProcessHK().

### 12.21.1.18 OS\_MAX\_QUEUES

```
#define OS_MAX_QUEUES
```

The maximum number of queues to support.

Based on the OSAL\_CONFIG\_MAX\_QUEUES configuration option

Definition at line 51 of file osconfig-example.h.

### 12.21.1.19 OS\_MAX\_SYM\_LEN

```
#define OS_MAX_SYM_LEN
```

The maximum length of symbols.

Based on the OSAL\_CONFIG\_MAX\_SYM\_LEN configuration option

#### Note

This value must include a terminating NUL character

Definition at line 123 of file osconfig-example.h.

### 12.21.1.20 OS\_MAX\_TASKS

```
#define OS_MAX_TASKS
```

Configuration file Operating System Abstraction Layer.

The specific definitions in this file may only be modified by setting the respective OSAL configuration options in the CMake build.

Any direct modifications to the generated copy will be overwritten each time CMake executes.

#### Note

This file was automatically generated by CMake from /home/runner/work/DS/DS/cfe/default\_config.cmake. The maximum number of tasks to support

Based on the OSAL\_CONFIG\_MAX\_TASKS configuration option

Definition at line 44 of file osconfig-example.h.

### 12.21.1.21 OS\_MAX\_TIMEBASES

```
#define OS_MAX_TIMEBASES
```

The maximum number of timebases to support.

Based on the OSAL\_CONFIG\_MAX\_TIMEBASES configuration option

Definition at line 86 of file osconfig-example.h.

### 12.21.1.22 OS\_MAX\_TIMERS

```
#define OS_MAX_TIMERS
```

The maximum number of timer callbacks to support.

Based on the OSAL\_CONFIG\_MAX\_TIMERS configuration option

Definition at line 93 of file osconfig-example.h.

### 12.21.1.23 OS\_MODULE\_FILE\_EXTENSION

```
#define OS_MODULE_FILE_EXTENSION ".so"
```

The system-specific file extension used on loadable module files.

Fixed value based on system selection, not user configurable.

Definition at line 260 of file osconfig-example.h.

### 12.21.1.24 OS\_PRINTF\_CONSOLE\_NAME

```
#define OS_PRINTF_CONSOLE_NAME ""
```

The name of the primary console device.

This is the device to which [OS\\_printf\(\)](#) output is written. The output may be configured to tag each line with this prefix for identification.

Based on the OSAL\_CONFIG\_PRINTF\_CONSOLE\_NAME configuration option

Definition at line 238 of file osconfig-example.h.

### 12.21.1.25 OS\_QUEUE\_MAX\_DEPTH

```
#define OS_QUEUE_MAX_DEPTH
```

The maximum depth of OSAL queues.

Based on the OSAL\_CONFIG\_QUEUE\_MAX\_DEPTH configuration option

Definition at line 218 of file osconfig-example.h.

**12.21.1.26 OS\_SHELL\_CMD\_INPUT\_FILE\_NAME**

```
#define OS_SHELL_CMD_INPUT_FILE_NAME ""
```

The name of the temporary file used to store shell commands.

This configuration is only applicable if shell support is enabled, and only necessary/relevant on some OS implementations.

Based on the OSAL\_CONFIG\_SHELL\_CMD\_INPUT\_FILE\_NAME configuration option

Definition at line 228 of file osconfig-example.h.

**12.21.1.27 OS SOCKADDR\_MAX\_LEN**

```
#define OS_SOCKADDR_MAX_LEN
```

The maximum size of the socket address structure.

This is part of the Socket API, and should be set large enough to hold the largest address type in use on the target system.

Based on the OSAL\_CONFIG\_SOCKADDR\_MAX\_LEN configuration option

Definition at line 166 of file osconfig-example.h.

**12.21.1.28 OS\_UTILITYTASK\_PRIORITY**

```
#define OS_UTILITYTASK_PRIORITY
```

Priority level of the background utility task.

This task is responsible for writing buffered output of OS\_printf to the actual console device, and any other future maintenance task.

Based on the OSAL\_CONFIG\_UTILITYTASK\_PRIORITY configuration option

Definition at line 190 of file osconfig-example.h.

**12.21.1.29 OS\_UTILITYTASK\_STACK\_SIZE**

```
#define OS_UTILITYTASK_STACK_SIZE
```

The stack size of the background utility task.

This task is responsible for writing buffered output of OS\_printf to the actual console device, and any other future maintenance task.

Based on the OSAL\_CONFIG\_UTILITYTASK\_STACK\_SIZE configuration option

Definition at line 200 of file osconfig-example.h.

## 12.22 cfe/cmake/sample\_defs/cpu1\_msgids.h File Reference

```
#include "cfe_mission_cfg.h"
```

### Macros

- #define CFE\_PLATFORM\_CMD\_MID\_BASE 0x1800  
*Platform command message ID base offset.*
- #define CFE\_PLATFORM\_TLM\_MID\_BASE 0x0800  
*Platform telemetry message ID base offset.*
- #define CFE\_PLATFORM\_CMD\_MID\_BASE\_GLOB 0x1860  
*"Global" command message ID base offset*
- #define CFE\_EVS\_CMD\_MID CFE\_PLATFORM\_CMD\_MID\_BASE + CFE\_MISSION\_EVS\_CMD\_MSG /\* 0x1801 \*/
- #define CFE\_TEST\_CMD\_MID CFE\_PLATFORM\_CMD\_MID\_BASE + CFE\_MISSION\_TEST\_CMD\_MSG /\* 0x1802 \*/
- #define CFE\_SB\_CMD\_MID CFE\_PLATFORM\_CMD\_MID\_BASE + CFE\_MISSION\_SB\_CMD\_MSG /\* 0x1803 \*/
- #define CFE\_TBL\_CMD\_MID CFE\_PLATFORM\_CMD\_MID\_BASE + CFE\_MISSION\_TBL\_CMD\_MSG /\* 0x1804 \*/
- #define CFE\_TIME\_CMD\_MID CFE\_PLATFORM\_CMD\_MID\_BASE + CFE\_MISSION\_TIME\_CMD\_MSG /\* 0x1805 \*/
- #define CFE\_ES\_CMD\_MID CFE\_PLATFORM\_CMD\_MID\_BASE + CFE\_MISSION\_ES\_CMD\_MSG /\* 0x1806 \*/
- #define CFE\_ES\_SEND\_HK\_MID CFE\_PLATFORM\_CMD\_MID\_BASE + CFE\_MISSION\_ES\_SEND\_HK\_MSG /\* 0x1808 \*/
- #define CFE\_EVS\_SEND\_HK\_MID CFE\_PLATFORM\_CMD\_MID\_BASE + CFE\_MISSION\_EVS\_SEND\_HK\_MSG /\* 0x1809 \*/
- #define CFE\_SB\_SEND\_HK\_MID CFE\_PLATFORM\_CMD\_MID\_BASE + CFE\_MISSION\_SB\_SEND\_HK\_MSG /\* 0x180B \*/
- #define CFE\_TBL\_SEND\_HK\_MID CFE\_PLATFORM\_CMD\_MID\_BASE + CFE\_MISSION\_TBL\_SEND\_HK\_MSG /\* 0x180C \*/
- #define CFE\_TIME\_SEND\_HK\_MID CFE\_PLATFORM\_CMD\_MID\_BASE + CFE\_MISSION\_TIME\_SEND\_HK\_MSG /\* 0x180D \*/
- #define CFE\_SB\_SUB\_RPT\_CTRL\_MID CFE\_PLATFORM\_CMD\_MID\_BASE + CFE\_MISSION\_SB\_SUB\_RPT\_CTRL\_MSG /\* 0x180E \*/
- #define CFE\_TIME\_TONE\_CMD\_MID CFE\_PLATFORM\_CMD\_MID\_BASE + CFE\_MISSION\_TIME\_TONE\_CMD\_MSG /\* 0x1810 \*/
- #define CFE\_TIME\_1HZ\_CMD\_MID CFE\_PLATFORM\_CMD\_MID\_BASE + CFE\_MISSION\_TIME\_1HZ\_CMD\_MSG /\* 0x1811 \*/
- #define CFE\_TIME\_DATA\_CMD\_MID CFE\_PLATFORM\_CMD\_MID\_BASE\_GLOB + CFE\_MISSION\_TIME\_DATA\_CMD\_MSG /\* 0x1860 \*/
- #define CFE\_TIME\_SEND\_CMD\_MID CFE\_PLATFORM\_CMD\_MID\_BASE\_GLOB + CFE\_MISSION\_TIME\_SEND\_CMD\_MSG /\* 0x1862 \*/
- #define CFE\_ES\_HK\_TLM\_MID CFE\_PLATFORM\_TLM\_MID\_BASE + CFE\_MISSION\_ES\_HK\_TLM\_MSG /\* 0x0800 \*/
- #define CFE\_EVS\_HK\_TLM\_MID CFE\_PLATFORM\_TLM\_MID\_BASE + CFE\_MISSION\_EVS\_HK\_TLM\_MSG /\* 0x0801 \*/

- #define CFE\_TEST\_HK\_TLM\_MID CFE\_PLATFORM\_TLM\_MID\_BASE + CFE\_MISSION\_TEST\_HK\_TLM\_MSG /\* 0x0802 \*/
- #define CFE\_SB\_HK\_TLM\_MID CFE\_PLATFORM\_TLM\_MID\_BASE + CFE\_MISSION\_SB\_HK\_TLM\_MSG /\* 0x0803 \*/
- #define CFE\_TBL\_HK\_TLM\_MID CFE\_PLATFORM\_TLM\_MID\_BASE + CFE\_MISSION\_TBL\_HK\_TLM\_MSG /\* 0x0804 \*/
- #define CFE\_TIME\_HK\_TLM\_MID CFE\_PLATFORM\_TLM\_MID\_BASE + CFE\_MISSION\_TIME\_HK\_TLM\_MSG /\* 0x0805 \*/
- #define CFE\_TIME\_DIAG\_TLM\_MID CFE\_PLATFORM\_TLM\_MID\_BASE + CFE\_MISSION\_TIME\_DIAG\_TLM\_MSG /\* 0x0806 \*/
- #define CFE\_EVS\_LONG\_EVENT\_MSG\_MID CFE\_PLATFORM\_TLM\_MID\_BASE + CFE\_MISSION\_EVS\_LONG\_EVENT\_MSG\_MSG /\* 0x0808 \*/
- #define CFE\_EVS\_SHORT\_EVENT\_MSG\_MID CFE\_PLATFORM\_TLM\_MID\_BASE + CFE\_MISSION\_EVS\_SHORT\_EVENT\_MSG\_MSG /\* 0x0809 \*/
- #define CFE\_SB\_STATS\_TLM\_MID CFE\_PLATFORM\_TLM\_MID\_BASE + CFE\_MISSION\_SB\_STATS\_TLM\_MSG /\* 0x080A \*/
- #define CFE\_ES\_APP\_TLM\_MID CFE\_PLATFORM\_TLM\_MID\_BASE + CFE\_MISSION\_ES\_APP\_TLM\_MSG /\* 0x080B \*/
- #define CFE\_TBL\_REG\_TLM\_MID CFE\_PLATFORM\_TLM\_MID\_BASE + CFE\_MISSION\_TBL\_REG\_TLM\_MSG /\* 0x080C \*/
- #define CFE\_SB\_ALLSUBS\_TLM\_MID CFE\_PLATFORM\_TLM\_MID\_BASE + CFE\_MISSION\_SB\_ALLSUBS\_TLM\_MSG /\* 0x080D \*/
- #define CFE\_SB\_ONESUB\_TLM\_MID CFE\_PLATFORM\_TLM\_MID\_BASE + CFE\_MISSION\_SB\_ONESUB\_TLM\_MSG /\* 0x080E \*/
- #define CFE\_ES\_MEMSTATS\_TLM\_MID CFE\_PLATFORM\_TLM\_MID\_BASE + CFE\_MISSION\_ES\_MEMSTATS\_TLM\_MSG /\* 0x0810 \*/

### 12.22.1 Detailed Description

Purpose: This header file contains the Message Id's for messages used by the cFE core.

Author: R.McGraw/SSI

Notes: This file should not contain messages defined by cFE external applications.

### 12.22.2 Macro Definition Documentation

#### 12.22.2.1 CFE\_ES\_APP\_TLM\_MID

```
#define CFE_ES_APP_TLM_MID CFE_PLATFORM_TLM_MID_BASE + CFE_MISSION_ES_APP_TLM_MSG /* 0x080B */
```

Definition at line 125 of file cpu1\_msgids.h.

### 12.22.2.2 CFE\_ES\_CMD\_MID

```
#define CFE_ES_CMD_MID CFE_PLATFORM_CMD_MID_BASE + CFE_MISSION_ES_CMD_MSG /* 0x1806 */
```

Definition at line 92 of file cpu1\_msgids.h.

### 12.22.2.3 CFE\_ES\_HK\_TLM\_MID

```
#define CFE_ES_HK_TLM_MID CFE_PLATFORM_TLM_MID_BASE + CFE_MISSION_ES_HK_TLM_MSG /* 0x0800 */
```

Definition at line 115 of file cpu1\_msgids.h.

### 12.22.2.4 CFE\_ES\_MEMSTATS\_TLM\_MID

```
#define CFE_ES_MEMSTATS_TLM_MID CFE_PLATFORM_TLM_MID_BASE + CFE_MISSION_ES_MEMSTATS_TLM_MSG /* 0x0810 */
```

Definition at line 129 of file cpu1\_msgids.h.

### 12.22.2.5 CFE\_ES\_SEND\_HK\_MID

```
#define CFE_ES_SEND_HK_MID CFE_PLATFORM_CMD_MID_BASE + CFE_MISSION_ES_SEND_HK_MSG /* 0x1808 */
```

Definition at line 94 of file cpu1\_msgids.h.

### 12.22.2.6 CFE\_EVS\_CMD\_MID

```
#define CFE_EVS_CMD_MID CFE_PLATFORM_CMD_MID_BASE + CFE_MISSION_EVS_CMD_MSG /* 0x1801 */
```

Definition at line 87 of file cpu1\_msgids.h.

### 12.22.2.7 CFE\_EVS\_HK\_TLM\_MID

```
#define CFE_EVS_HK_TLM_MID CFE_PLATFORM_TLM_MID_BASE + CFE_MISSION_EVS_HK_TLM_MSG /* 0x0801 */
```

Definition at line 116 of file cpu1\_msgids.h.

### 12.22.2.8 CFE\_EVS\_LONG\_EVENT\_MSG\_MID

```
#define CFE_EVS_LONG_EVENT_MSG_MID CFE_PLATFORM_TLM_MID_BASE + CFE_MISSION_EVS_LONG_EVENT_MSG_MSG  
/* 0x0808 */
```

Definition at line 122 of file cpu1\_msgids.h.

### 12.22.2.9 CFE\_EVS\_SEND\_HK\_MID

```
#define CFE_EVS_SEND_HK_MID CFE_PLATFORM_CMD_MID_BASE + CFE_MISSION_EVS_SEND_HK_MSG /* 0x1809 */
```

Definition at line 95 of file cpu1\_msgids.h.

### 12.22.2.10 CFE\_EVS\_SHORT\_EVENT\_MSG\_MID

```
#define CFE_EVS_SHORT_EVENT_MSG_MID CFE_PLATFORM_TLM_MID_BASE + CFE_MISSION_EVS_SHORT_EVENT_MSG_MSG /* 0x0809 */
```

Definition at line 123 of file cpu1\_msgids.h.

### 12.22.2.11 CFE\_PLATFORM\_CMD\_MID\_BASE

```
#define CFE_PLATFORM_CMD_MID_BASE 0x1800
```

Platform command message ID base offset.

Example mechanism for setting default command bits and deconflicting MIDs across multiple platforms in a mission. For any sufficiently complex mission this method is typically replaced by a centralized message ID management scheme.

0x1800 - Nominal value for default message ID implementation (V1). This sets the command field and the secondary header present field. Typical V1 command MID range is 0x1800-1FFF. Additional cpus can deconflict message IDs by incrementing this value to provide sub-allocations (0x1900 for example). 0x0080 - Command bit for MISSION\_MSGI\_D\_V2 message ID implementation (V2). Although this can be used for the value below due to the relatively small set of MIDs in the framework it will not scale so an alternative method of deconfliction is recommended.

Definition at line 59 of file cpu1\_msgids.h.

### 12.22.2.12 CFE\_PLATFORM\_CMD\_MID\_BASE\_GLOB

```
#define CFE_PLATFORM_CMD_MID_BASE_GLOB 0x1860
```

"Global" command message ID base offset

0x1860 - Nominal value for message ID V1 0x00E0 - Potential value for MISSION\_MSGID\_V2, note command bit is 0x0080. Works in limited cases only, alternative method of deconfliction is recommended. See [CFE\\_PLATFORM\\_CMD\\_MID\\_BASE](#) for more information

Definition at line 82 of file cpu1\_msgids.h.

### 12.22.2.13 CFE\_PLATFORM\_TLM\_MID\_BASE

```
#define CFE_PLATFORM_TLM_MID_BASE 0x0800
```

Platform telemetry message ID base offset.

0x0800 - Nominal for message ID V1 0x0000 - Potential value for MISSION\_MSGID\_V2, but limited to a range of 0x0000-0x007F since the command bit is 0x0080. Alternative method of deconfliction is recommended.

See [CFE\\_PLATFORM\\_CMD\\_MID\\_BASE](#) for more information

Definition at line 71 of file cpu1\_msgids.h.

### 12.22.2.14 CFE\_SB\_ALLSUBS\_TLM\_MID

```
#define CFE_SB_ALLSUBS_TLM_MID CFE_PLATFORM_TLM_MID_BASE + CFE_MISSION_SB_ALLSUBS_TLM_MSG /* 0x0800 */
```

Definition at line 127 of file cpu1\_msgids.h.

### 12.22.2.15 CFE\_SB\_CMD\_MID

```
#define CFE_SB_CMD_MID CFE_PLATFORM_CMD_MID_BASE + CFE_MISSION_SB_CMD_MSG /* 0x1803 */
```

Definition at line 89 of file cpu1\_msgids.h.

### 12.22.2.16 CFE\_SB\_HK\_TLM\_MID

```
#define CFE_SB_HK_TLM_MID CFE_PLATFORM_TLM_MID_BASE + CFE_MISSION_SB_HK_TLM_MSG /* 0x0803 */
```

Definition at line 118 of file cpu1\_msgids.h.

**12.22.2.17 CFE\_SB\_ONESUB\_TLM\_MID**

```
#define CFE_SB_ONESUB_TLM_MID CFE_PLATFORM_TLM_MID_BASE + CFE_MISSION_SB_ONESUB_TLM_MSG /* 0x080E */
```

Definition at line 128 of file cpu1\_msgids.h.

**12.22.2.18 CFE\_SB\_SEND\_HK\_MID**

```
#define CFE_SB_SEND_HK_MID CFE_PLATFORM_CMD_MID_BASE + CFE_MISSION_SB_SEND_HK_MSG /* 0x180B */
```

Definition at line 97 of file cpu1\_msgids.h.

**12.22.2.19 CFE\_SB\_STATS\_TLM\_MID**

```
#define CFE_SB_STATS_TLM_MID CFE_PLATFORM_TLM_MID_BASE + CFE_MISSION_SB_STATS_TLM_MSG /* 0x080A */
```

Definition at line 124 of file cpu1\_msgids.h.

**12.22.2.20 CFE\_SB\_SUB\_RPT\_CTRL\_MID**

```
#define CFE_SB_SUB_RPT_CTRL_MID CFE_PLATFORM_CMD_MID_BASE + CFE_MISSION_SB_SUB_RPT_CTRL_MSG /* 0x180E */
```

Definition at line 101 of file cpu1\_msgids.h.

**12.22.2.21 CFE\_TBL\_CMD\_MID**

```
#define CFE_TBL_CMD_MID CFE_PLATFORM_CMD_MID_BASE + CFE_MISSION_TBL_CMD_MSG /* 0x1804 */
```

Definition at line 90 of file cpu1\_msgids.h.

**12.22.2.22 CFE\_TBL\_HK\_TLM\_MID**

```
#define CFE_TBL_HK_TLM_MID CFE_PLATFORM_TLM_MID_BASE + CFE_MISSION_TBL_HK_TLM_MSG /* 0x0804 */
```

Definition at line 119 of file cpu1\_msgids.h.

**12.22.2.23 CFE\_TBL\_REG\_TLM\_MID**

```
#define CFE_TBL_REG_TLM_MID CFE_PLATFORM_TLM_MID_BASE + CFE_MISSION_TBL_REG_TLM_MSG /* 0x080C */
```

Definition at line 126 of file cpu1\_msgids.h.

**12.22.2.24 CFE\_TBL\_SEND\_HK\_MID**

```
#define CFE_TBL_SEND_HK_MID CFE_PLATFORM_CMD_MID_BASE + CFE_MISSION_TBL_SEND_HK_MSG /* 0x180C */
```

Definition at line 98 of file cpu1\_msgids.h.

**12.22.2.25 CFE\_TEST\_CMD\_MID**

```
#define CFE_TEST_CMD_MID CFE_PLATFORM_CMD_MID_BASE + CFE_MISSION_TEST_CMD_MSG /* 0x1802 */
```

Definition at line 88 of file cpu1\_msgids.h.

**12.22.2.26 CFE\_TEST\_HK\_TLM\_MID**

```
#define CFE_TEST_HK_TLM_MID CFE_PLATFORM_TLM_MID_BASE + CFE_MISSION_TEST_HK_TLM_MSG /* 0x0802 */
```

Definition at line 117 of file cpu1\_msgids.h.

**12.22.2.27 CFE\_TIME\_1HZ\_CMD\_MID**

```
#define CFE_TIME_1HZ_CMD_MID CFE_PLATFORM_CMD_MID_BASE + CFE_MISSION_TIME_1HZ_CMD_MSG /* 0x1811 */
```

Definition at line 104 of file cpu1\_msgids.h.

**12.22.2.28 CFE\_TIME\_CMD\_MID**

```
#define CFE_TIME_CMD_MID CFE_PLATFORM_CMD_MID_BASE + CFE_MISSION_TIME_CMD_MSG /* 0x1805 */
```

Definition at line 91 of file cpu1\_msgids.h.

**12.22.2.29 CFE\_TIME\_DATA\_CMD\_MID**

```
#define CFE_TIME_DATA_CMD_MID CFE_PLATFORM_CMD_MID_BASE_GLOB + CFE_MISSION_TIME_DATA_CMD_MSG /*  
0x1860 */
```

Definition at line 109 of file cpu1\_msgids.h.

**12.22.2.30 CFE\_TIME\_DIAG\_TLM\_MID**

```
#define CFE_TIME_DIAG_TLM_MID CFE_PLATFORM_TLM_MID_BASE + CFE_MISSION_TIME_DIAG_TLM_MSG /* 0x0806 */
```

Definition at line 121 of file cpu1\_msgids.h.

**12.22.2.31 CFE\_TIME\_HK\_TLM\_MID**

```
#define CFE_TIME_HK_TLM_MID CFE_PLATFORM_TLM_MID_BASE + CFE_MISSION_TIME_HK_TLM_MSG /* 0x0805 */
```

Definition at line 120 of file cpu1\_msgids.h.

**12.22.2.32 CFE\_TIME\_SEND\_CMD\_MID**

```
#define CFE_TIME_SEND_CMD_MID CFE_PLATFORM_CMD_MID_BASE_GLOB + CFE_MISSION_TIME_SEND_CMD_MSG /*  
0x1862 */
```

Definition at line 110 of file cpu1\_msgids.h.

**12.22.2.33 CFE\_TIME\_SEND\_HK\_MID**

```
#define CFE_TIME_SEND_HK_MID CFE_PLATFORM_CMD_MID_BASE + CFE_MISSION_TIME_SEND_HK_MSG /* 0x180D */
```

Definition at line 99 of file cpu1\_msgids.h.

**12.22.2.34 CFE\_TIME\_TONE\_CMD\_MID**

```
#define CFE_TIME_TONE_CMD_MID CFE_PLATFORM_CMD_MID_BASE + CFE_MISSION_TIME_TONE_CMD_MSG /* 0x1810 */
```

Definition at line 103 of file cpu1\_msgids.h.

## 12.23 cfe/cmake/sample\_defs/cpu1\_platform\_cfg.h File Reference

### Macros

- #define CFE\_PLATFORM\_ES\_NONVOL\_DISK\_MOUNT\_STRING "/cf"
- #define CFE\_PLATFORM\_ES\_RAM\_DISK\_MOUNT\_STRING "/ram"
- #define CFE\_PLATFORM\_SB\_MAX\_MSG\_IDS 256
- #define CFE\_PLATFORM\_SB\_MAX\_PIPES 64
- #define CFE\_PLATFORM\_SB\_MAX\_DEST\_PER\_PKT 16
- #define CFE\_PLATFORM\_SB\_DEFAULT\_MSG\_LIMIT 4
- #define CFE\_PLATFORM\_SB\_BUF\_MEMORY\_BYTES 524288
- #define CFE\_PLATFORM\_SB\_HIGHEST\_VALID\_MSGID 0x1FFF
- #define CFE\_PLATFORM\_ENDIAN CCSDS\_LITTLE\_ENDIAN
- #define CFE\_PLATFORM\_SB\_DEFAULT\_ROUTING\_FILENAME "/ram/cfe\_sb\_route.dat"
- #define CFE\_PLATFORM\_SB\_DEFAULT\_PIPE\_FILENAME "/ram/cfe\_sb\_pipe.dat"
- #define CFE\_PLATFORM\_SB\_DEFAULT\_MAP\_FILENAME "/ram/cfe\_sb\_msgmap.dat"
- #define CFE\_PLATFORM\_SB\_FILTERED\_EVENT1 CFE\_SB\_SEND\_NO\_SUBS\_EID
- #define CFE\_PLATFORM\_SB\_FILTER\_MASK1 CFE\_EVS\_FIRST\_4\_STOP
- #define CFE\_PLATFORM\_SB\_FILTERED\_EVENT2 CFE\_SB\_DUP\_SUBSCRIP\_EID
- #define CFE\_PLATFORM\_SB\_FILTER\_MASK2 CFE\_EVS\_FIRST\_4\_STOP
- #define CFE\_PLATFORM\_SB\_FILTERED\_EVENT3 CFE\_SB\_MSGID\_LIM\_ERR\_EID
- #define CFE\_PLATFORM\_SB\_FILTER\_MASK3 CFE\_EVS\_FIRST\_16\_STOP
- #define CFE\_PLATFORM\_SB\_FILTERED\_EVENT4 CFE\_SB\_Q\_FULL\_ERR\_EID
- #define CFE\_PLATFORM\_SB\_FILTER\_MASK4 CFE\_EVS\_FIRST\_16\_STOP
- #define CFE\_PLATFORM\_SB\_FILTERED\_EVENT5 0
- #define CFE\_PLATFORM\_SB\_FILTER\_MASK5 CFE\_EVS\_NO\_FILTER
- #define CFE\_PLATFORM\_SB\_FILTERED\_EVENT6 0
- #define CFE\_PLATFORM\_SB\_FILTER\_MASK6 CFE\_EVS\_NO\_FILTER
- #define CFE\_PLATFORM\_SB\_FILTERED\_EVENT7 0
- #define CFE\_PLATFORM\_SB\_FILTER\_MASK7 CFE\_EVS\_NO\_FILTER
- #define CFE\_PLATFORM\_SB\_FILTERED\_EVENT8 0
- #define CFE\_PLATFORM\_SB\_FILTER\_MASK8 CFE\_EVS\_NO\_FILTER
- #define CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_01 8
- #define CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_02 16
- #define CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_03 20
- #define CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_04 36
- #define CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_05 64
- #define CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_06 96
- #define CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_07 128
- #define CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_08 160
- #define CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_09 256
- #define CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_10 512
- #define CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_11 1024
- #define CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_12 2048
- #define CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_13 4096
- #define CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_14 8192
- #define CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_15 16384
- #define CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_16 32768
- #define CFE\_PLATFORM\_SB\_MAX\_BLOCK\_SIZE (CFE\_MISSION\_SB\_MAX\_SB\_MSG\_SIZE + 128)
- #define CFE\_PLATFORM\_TIME\_CFG\_SERVER true

- #define CFE\_PLATFORM\_TIME\_CFG\_CLIENT false
- #define CFE\_PLATFORM\_TIME\_CFG\_VIRTUAL true
- #define CFE\_PLATFORM\_TIME\_CFG\_SIGNAL false
- #define CFE\_PLATFORM\_TIME\_CFG\_SOURCE false
- #define CFE\_PLATFORM\_TIME\_CFG\_SRC\_MET false
- #define CFE\_PLATFORM\_TIME\_CFG\_SRC\_GPS false
- #define CFE\_PLATFORM\_TIME\_CFG\_SRC\_TIME false
- #define CFE\_PLATFORM\_TIME\_MAX\_DELTA\_SECS 0
- #define CFE\_PLATFORM\_TIME\_MAX\_DELTA\_SUBS 500000
- #define CFE\_PLATFORM\_TIME\_MAX\_LOCAL\_SECS 27
- #define CFE\_PLATFORM\_TIME\_MAX\_LOCAL\_SUBS 0
- #define CFE\_PLATFORM\_TIME\_CFG\_TONE\_LIMIT 20000
- #define CFE\_PLATFORM\_TIME\_CFG\_START\_FLY 2
- #define CFE\_PLATFORM\_TIME\_CFG\_LATCH\_FLY 8
- #define CFE\_PLATFORM\_ES\_MAX\_APPLICATIONS 32
- #define CFE\_PLATFORM\_ES\_MAX\_LIBRARIES 10
- #define CFE\_PLATFORM\_ES\_ER\_LOG\_ENTRIES 20
- #define CFE\_PLATFORM\_ES\_ER\_LOG\_MAX\_CONTEXT\_SIZE 256
- #define CFE\_PLATFORM\_ES\_SYSTEM\_LOG\_SIZE 3072
- #define CFE\_PLATFORM\_ES\_OBJECT\_TABLE\_SIZE 30
- #define CFE\_PLATFORM\_ES\_MAX\_GEN\_COUNTERS 8
- #define CFE\_PLATFORM\_ES\_APP\_SCAN\_RATE 1000
- #define CFE\_PLATFORM\_ES\_APP\_KILL\_TIMEOUT 5
- #define CFE\_PLATFORM\_ES\_RAM\_DISK\_SECTOR\_SIZE 512
- #define CFE\_PLATFORM\_ES\_RAM\_DISK\_NUM\_SECTORS 4096
- #define CFE\_PLATFORM\_ES\_RAM\_DISK\_PERCENT\_RESERVED 30
- #define CFE\_PLATFORM\_ES\_CDS\_SIZE (128 \* 1024)
- #define CFE\_PLATFORM\_ES\_USER\_RESERVED\_SIZE (1024 \* 1024)
- #define CFE\_PLATFORM\_ES\_RESET\_AREA\_SIZE (170 \* 1024)
- #define CFE\_PLATFORM\_ES\_MEMPOOL\_ALIGN\_SIZE\_MIN 4
- #define CFE\_PLATFORM\_ES\_NONVOL\_STARTUP\_FILE "/cf/cfe\_es\_startup.scr"
- #define CFE\_PLATFORM\_ES\_VOLATILE\_STARTUP\_FILE "/ram/cfe\_es\_startup.scr"
- #define CFE\_PLATFORM\_ES\_DEFAULT\_APP\_LOG\_FILE "/ram/cfe\_es\_app\_info.log"
- #define CFE\_PLATFORM\_ES\_DEFAULT\_TASK\_LOG\_FILE "/ram/cfe\_es\_taskinfo.log"
- #define CFE\_PLATFORM\_ES\_DEFAULT\_SYSLOG\_FILE "/ram/cfe\_es\_syslog.log"
- #define CFE\_PLATFORM\_ES\_DEFAULT\_ER\_LOG\_FILE "/ram/cfe\_erlog.log"
- #define CFE\_PLATFORM\_ES\_DEFAULT\_PERF\_DUMP\_FILENAME "/ram/cfe\_es\_perf.dat"
- #define CFE\_PLATFORM\_ES\_DEFAULT\_CDS\_REG\_DUMP\_FILE "/ram/cfe\_cds\_reg.log"
- #define CFE\_PLATFORM\_ES\_DEFAULT\_POR\_SYSLOG\_MODE 0
- #define CFE\_PLATFORM\_ES\_DEFAULT\_PR\_SYSLOG\_MODE 1
- #define CFE\_PLATFORM\_ES\_PERF\_DATA\_BUFFER\_SIZE 10000
- #define CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_NONE 0
- #define CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_ALL ~CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_NONE
- #define CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_INIT CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_ALL
- #define CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_NONE 0
- #define CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_ALL ~CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_NONE
- #define CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_INIT CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_NONE
- #define CFE\_PLATFORM\_ES\_PERF\_CHILD\_PRIORITY 200
- #define CFE\_PLATFORM\_ES\_PERF\_CHILD\_STACK\_SIZE 4096
- #define CFE\_PLATFORM\_ES\_PERF\_CHILD\_MS\_DELAY 20
- #define CFE\_PLATFORM\_ES\_PERF\_ENTRIES\_BTWN\_DLYS 50

- #define CFE\_PLATFORM\_ES\_DEFAULT\_STACK\_SIZE 8192
- #define CFE\_PLATFORM\_EVS\_START\_TASK\_PRIORITY 61
- #define CFE\_PLATFORM\_EVS\_START\_TASK\_STACK\_SIZE CFE\_PLATFORM\_ES\_DEFAULT\_STACK\_SIZE
- #define CFE\_PLATFORM\_SB\_START\_TASK\_PRIORITY 64
- #define CFE\_PLATFORM\_SB\_START\_TASK\_STACK\_SIZE CFE\_PLATFORM\_ES\_DEFAULT\_STACK\_SIZE
- #define CFE\_PLATFORM\_ES\_START\_TASK\_PRIORITY 68
- #define CFE\_PLATFORM\_ES\_START\_TASK\_STACK\_SIZE CFE\_PLATFORM\_ES\_DEFAULT\_STACK\_SIZE
- #define CFE\_PLATFORM\_TIME\_START\_TASK\_PRIORITY 60
- #define CFE\_PLATFORM\_TIME\_TONE\_TASK\_PRIORITY 25
- #define CFE\_PLATFORM\_TIME\_1HZ\_TASK\_PRIORITY 25
- #define CFE\_PLATFORM\_TIME\_START\_TASK\_STACK\_SIZE CFE\_PLATFORM\_ES\_DEFAULT\_STACK\_SIZE
- #define CFE\_PLATFORM\_TIME\_TONE\_TASK\_STACK\_SIZE 4096
- #define CFE\_PLATFORM\_TIME\_1HZ\_TASK\_STACK\_SIZE 8192
- #define CFE\_PLATFORM\_TBL\_START\_TASK\_PRIORITY 70
- #define CFE\_PLATFORM\_TBL\_START\_TASK\_STACK\_SIZE CFE\_PLATFORM\_ES\_DEFAULT\_STACK\_SIZE
- #define CFE\_PLATFORM\_ES\_CDS\_MAX\_NUM\_ENTRIES 512
- #define CFE\_PLATFORM\_ES\_MAX\_PROCESSOR\_RESETS 2
- #define CFE\_PLATFORM\_ES\_POOL\_MAX\_BUCKETS 17
- #define CFE\_PLATFORM\_ES\_MAX\_MEMORY\_POOLS 10
- #define CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_01 8
- #define CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_02 16
- #define CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_03 32
- #define CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_04 48
- #define CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_05 64
- #define CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_06 96
- #define CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_07 128
- #define CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_08 160
- #define CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_09 256
- #define CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_10 512
- #define CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_11 1024
- #define CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_12 2048
- #define CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_13 4096
- #define CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_14 8192
- #define CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_15 16384
- #define CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_16 32768
- #define CFE\_PLATFORM\_ES\_MAX\_BLOCK\_SIZE 80000
- #define CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_01 8
- #define CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_02 16
- #define CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_03 32
- #define CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_04 48
- #define CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_05 64
- #define CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_06 96
- #define CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_07 128
- #define CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_08 160
- #define CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_09 256
- #define CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_10 512
- #define CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_11 1024
- #define CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_12 2048
- #define CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_13 4096
- #define CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_14 8192

- #define CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_15 16384
- #define CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_16 32768
- #define CFE\_PLATFORM\_ES\_CDS\_MAX\_BLOCK\_SIZE 80000
- #define CFE\_PLATFORM\_EVS\_MAX\_EVENT\_FILTERS 8
- #define CFE\_PLATFORM\_EVS\_MAX\_APP\_EVENT\_BURST 32
- #define CFE\_PLATFORM\_EVS\_APP\_EVENTS\_PER\_SEC 8
- #define CFE\_PLATFORM\_EVS\_DEFAULT\_LOG\_FILE "/ram/cfe\_evs.log"
- #define CFE\_PLATFORM\_EVS\_LOG\_MAX 20
- #define CFE\_PLATFORM\_EVS\_DEFAULT\_APP\_DATA\_FILE "/ram/cfe\_evs\_app.dat"
- #define CFE\_PLATFORM\_EVS\_PORT\_DEFAULT 0x0001
- #define CFE\_PLATFORM\_EVS\_DEFAULT\_TYPE\_FLAG 0xE
- #define CFE\_PLATFORM\_EVS\_DEFAULT\_LOG\_MODE 1
- #define CFE\_PLATFORM\_EVS\_DEFAULT\_MSG\_FORMAT\_MODE CFE\_EVS\_MsgFormat\_LONG
- #define CFE\_PLATFORM\_TBL\_BUF\_MEMORY\_BYTES 524288
- #define CFE\_PLATFORM\_TBL\_MAX\_DBL\_TABLE\_SIZE 16384
- #define CFE\_PLATFORM\_TBL\_MAX\_SNGL\_TABLE\_SIZE 16384
- #define CFE\_PLATFORM\_TBL\_MAX\_NUM\_TABLES 128
- #define CFE\_PLATFORM\_TBL\_MAX\_CRITICAL\_TABLES 32
- #define CFE\_PLATFORM\_TBL\_MAX\_NUM\_HANDLES 256
- #define CFE\_PLATFORM\_TBL\_MAX\_SIMULTANEOUS\_LOADS 4
- #define CFE\_PLATFORM\_TBL\_MAX\_NUM\_VALIDATIONS 10
- #define CFE\_PLATFORM\_TBL\_DEFAULT\_REG\_DUMP\_FILE "/ram/cfe\_tbl\_reg.log"
- #define CFE\_PLATFORM\_TBL\_VALID\_SCID\_COUNT 0
- #define CFE\_PLATFORM\_TBL\_U32FROM4CHARS(\_C1, \_C2, \_C3, \_C4) ((uint32)(\_C1) << 24 | (uint32)(\_C2) << 16 | (uint32)(\_C3) << 8 | (uint32)(\_C4))
- #define CFE\_PLATFORM\_TBL\_VALID\_SCID\_1 (0x42)
- #define CFE\_PLATFORM\_TBL\_VALID\_SCID\_2 (CFE\_PLATFORM\_TBL\_U32FROM4CHARS('a', 'b', 'c', 'd'))
- #define CFE\_PLATFORM\_TBL\_VALID\_PRID\_COUNT 0
- #define CFE\_PLATFORM\_TBL\_VALID\_PRID\_1 (1)
- #define CFE\_PLATFORM\_TBL\_VALID\_PRID\_2 (CFE\_PLATFORM\_TBL\_U32FROM4CHARS('a', 'b', 'c', 'd'))
- #define CFE\_PLATFORM\_TBL\_VALID\_PRID\_3 0
- #define CFE\_PLATFORM\_TBL\_VALID\_PRID\_4 0
- #define CFE\_PLATFORM\_ES\_STARTUP\_SYNC\_POLL\_MSEC 50
- #define CFE\_PLATFORM\_CORE\_MAX\_STARTUP\_MSEC 30000
- #define CFE\_PLATFORM\_ES\_STARTUP\_SCRIPT\_TIMEOUT\_MSEC 1000

### 12.23.1 Detailed Description

Purpose: This header file contains the platform configuration parameters.

Notes: The impact of changing these configurations from their default value is not yet documented. Changing these values may impact the performance and functionality of the system.

Author: R.McGraw/SSI

### 12.23.2 Macro Definition Documentation

### 12.23.2.1 CFE\_PLATFORM\_CORE\_MAX\_STARTUP\_MSEC

```
#define CFE_PLATFORM_CORE_MAX_STARTUP_MSEC 30000
```

**Purpose** CFE core application startup timeout

**Description:**

The upper limit for the amount of time that the cFE core applications (ES, SB, EVS, TIME, TBL) are each allotted to reach their respective "ready" states.

The CFE "main" thread starts individual tasks for each of the core applications (except FS). Each of these must perform some initialization work before the next core application can be started, so the main thread waits to ensure that the application has reached the "ready" state before starting the next application.

If any core application fails to start, then it indicates a major problem with the system and startup is aborted.

Units are in milliseconds

**Limits:**

Must be defined as an integer value that is greater than or equal to zero.

Definition at line 1713 of file cpu1\_platform\_cfg.h.

### 12.23.2.2 CFE\_PLATFORM\_ENDIAN

```
#define CFE_PLATFORM_ENDIAN CCSDS_LITTLE_ENDIAN
```

**Purpose** Platform Endian Indicator

**Description:**

The value of this constant indicates the endianess of the target system

**Limits**

This parameter has a lower limit of 0 and an upper limit of 1.

Definition at line 190 of file cpu1\_platform\_cfg.h.

### 12.23.2.3 CFE\_PLATFORM\_ES\_APP\_KILL\_TIMEOUT

```
#define CFE_PLATFORM_ES_APP_KILL_TIMEOUT 5
```

**Purpose** Define ES Application Kill Timeout

#### Description:

ES Application Kill Timeout. This parameter controls the number of "scan periods" that ES will wait for an application to Exit after getting the signal Delete, Reload or Restart. The sequence works as follows:

1. ES will set the control request for an App to Delete/Restart/Reload and set this kill timer to the value in this parameter.
2. If the App is responding and Calls it's RunLoop function, it will drop out of it's main loop and call CFE\_ES\_ExitApp. Once it calls Exit App, then ES can delete, restart, or reload the app the next time it scans the app table.
3. If the App is not responding, the ES App will decrement this Kill Timeout value each time it runs. If the timeout value reaches zero, ES will kill the app.

The Kill timeout value depends on the [CFE\\_PLATFORM\\_ES\\_APP\\_SCAN\\_RATE](#). If the Scan Rate is 1000, or 1 second, and this [CFE\\_PLATFORM\\_ES\\_APP\\_KILL\\_TIMEOUT](#) is set to 5, then it will take 5 seconds to kill a non-responding App. If the Scan Rate is 250, or 1/4 second, and the [CFE\\_PLATFORM\\_ES\\_APP\\_KILL\\_TIMEOUT](#) is set to 2, then it will take 1/2 second to time out.

#### Limits

There is a lower limit of 1 and an upper limit of 100 on this configuration parameter. Units are number of [CFE\\_PLATFORM\\_ES\\_APP\\_SCAN\\_RATE](#) cycles.

Definition at line 620 of file cpu1\_platform\_cfg.h.

### 12.23.2.4 CFE\_PLATFORM\_ES\_APP\_SCAN\_RATE

```
#define CFE_PLATFORM_ES_APP_SCAN_RATE 1000
```

**Purpose** Define ES Application Control Scan Rate

#### Description:

ES Application Control Scan Rate. This parameter controls the speed that ES scans the Application Table looking for App Delete/Restart/Reload requests. All Applications are deleted, restarted, or reloaded by the ES Application. ES will periodically scan for control requests to process. The scan rate is controlled by this parameter, which is given in milliseconds. A value of 1000 means that ES will scan the Application Table once per second. Be careful not to set the value of this too low, because ES will use more CPU cycles scanning the table.

#### Limits

There is a lower limit of 100 and an upper limit of 20000 on this configuration parameter. millisecond units.

Definition at line 591 of file cpu1\_platform\_cfg.h.

#### 12.23.2.5 CFE\_PLATFORM\_ES\_CDS\_MAX\_BLOCK\_SIZE

```
#define CFE_PLATFORM_ES_CDS_MAX_BLOCK_SIZE 80000
```

Definition at line 1325 of file cpu1\_platform\_cfg.h.

#### 12.23.2.6 CFE\_PLATFORM\_ES\_CDS\_MAX\_NUM\_ENTRIES

```
#define CFE_PLATFORM_ES_CDS_MAX_NUM_ENTRIES 512
```

**Purpose** Define Maximum Number of Registered CDS Blocks

**Description:**

Maximum number of registered CDS Blocks

**Limits**

There is a lower limit of 8. There are no restrictions on the upper limit however, the maximum number of CDS entries is system dependent and should be verified.

Definition at line 1215 of file cpu1\_platform\_cfg.h.

#### 12.23.2.7 CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_01

```
#define CFE_PLATFORM_ES_CDS_MEM_BLOCK_SIZE_01 8
```

**Purpose** Define ES Critical Data Store Memory Pool Block Sizes

**Description:**

Intermediate ES Critical Data Store Memory Pool Block Sizes

**Limits**

These sizes MUST be increasing and MUST be an integral multiple of 4.

Definition at line 1309 of file cpu1\_platform\_cfg.h.

**12.23.2.8 CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_02**

```
#define CFE_PLATFORM_ES_CDS_MEM_BLOCK_SIZE_02 16
```

Definition at line 1310 of file cpu1\_platform\_cfg.h.

**12.23.2.9 CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_03**

```
#define CFE_PLATFORM_ES_CDS_MEM_BLOCK_SIZE_03 32
```

Definition at line 1311 of file cpu1\_platform\_cfg.h.

**12.23.2.10 CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_04**

```
#define CFE_PLATFORM_ES_CDS_MEM_BLOCK_SIZE_04 48
```

Definition at line 1312 of file cpu1\_platform\_cfg.h.

**12.23.2.11 CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_05**

```
#define CFE_PLATFORM_ES_CDS_MEM_BLOCK_SIZE_05 64
```

Definition at line 1313 of file cpu1\_platform\_cfg.h.

**12.23.2.12 CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_06**

```
#define CFE_PLATFORM_ES_CDS_MEM_BLOCK_SIZE_06 96
```

Definition at line 1314 of file cpu1\_platform\_cfg.h.

**12.23.2.13 CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_07**

```
#define CFE_PLATFORM_ES_CDS_MEM_BLOCK_SIZE_07 128
```

Definition at line 1315 of file cpu1\_platform\_cfg.h.

**12.23.2.14 CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_08**

```
#define CFE_PLATFORM_ES_CDS_MEM_BLOCK_SIZE_08 160
```

Definition at line 1316 of file cpu1\_platform\_cfg.h.

**12.23.2.15 CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_09**

```
#define CFE_PLATFORM_ES_CDS_MEM_BLOCK_SIZE_09 256
```

Definition at line 1317 of file cpu1\_platform\_cfg.h.

**12.23.2.16 CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_10**

```
#define CFE_PLATFORM_ES_CDS_MEM_BLOCK_SIZE_10 512
```

Definition at line 1318 of file cpu1\_platform\_cfg.h.

**12.23.2.17 CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_11**

```
#define CFE_PLATFORM_ES_CDS_MEM_BLOCK_SIZE_11 1024
```

Definition at line 1319 of file cpu1\_platform\_cfg.h.

**12.23.2.18 CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_12**

```
#define CFE_PLATFORM_ES_CDS_MEM_BLOCK_SIZE_12 2048
```

Definition at line 1320 of file cpu1\_platform\_cfg.h.

**12.23.2.19 CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_13**

```
#define CFE_PLATFORM_ES_CDS_MEM_BLOCK_SIZE_13 4096
```

Definition at line 1321 of file cpu1\_platform\_cfg.h.

### 12.23.2.20 CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_14

```
#define CFE_PLATFORM_ES_CDS_MEM_BLOCK_SIZE_14 8192
```

Definition at line 1322 of file cpu1\_platform\_cfg.h.

### 12.23.2.21 CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_15

```
#define CFE_PLATFORM_ES_CDS_MEM_BLOCK_SIZE_15 16384
```

Definition at line 1323 of file cpu1\_platform\_cfg.h.

### 12.23.2.22 CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_16

```
#define CFE_PLATFORM_ES_CDS_MEM_BLOCK_SIZE_16 32768
```

Definition at line 1324 of file cpu1\_platform\_cfg.h.

### 12.23.2.23 CFE\_PLATFORM\_ES\_CDS\_SIZE

```
#define CFE_PLATFORM_ES_CDS_SIZE (128 * 1024)
```

**Purpose** Define Critical Data Store Size

#### Description:

Defines the Critical Data Store (CDS) area size in bytes size. The CDS is one of four memory areas that are preserved during a processor reset. NOTE: Changing this value changes memory allocation, and may require changes to platform specific values (in CFE\_PSP) such as USER\_RESERVED\_MEM in VxWorks depending on the memory areas being used for preserved data and on OS specific behavior.

#### Limits

There is a lower limit of 8192 and an upper limit of `UINT_MAX` (4 Gigabytes) on this configuration parameter.

Definition at line 697 of file cpu1\_platform\_cfg.h.

### 12.23.2.24 CFE\_PLATFORM\_ES\_DEFAULT\_APP\_LOG\_FILE

```
#define CFE_PLATFORM_ES_DEFAULT_APP_LOG_FILE "/ram/cfe_es_app_info.log"
```

**Purpose** Default Application Information Filename

**Description:**

The value of this constant defines the filename used to store information pertaining to all of the Applications that are registered with Executive Services. This filename is used only when no filename is specified in the command to query all system apps.

**Limits**

The length of each string, including the NULL terminator cannot exceed the [OS\\_MAX\\_PATH\\_LEN](#) value.

Definition at line 802 of file cpu1\_platform\_cfg.h.

### 12.23.2.25 CFE\_PLATFORM\_ES\_DEFAULT\_CDS\_REG\_DUMP\_FILE

```
#define CFE_PLATFORM_ES_DEFAULT_CDS_REG_DUMP_FILE "/ram/cfe_cds_reg.log"
```

**Purpose** Default Critical Data Store Registry Filename

**Description:**

The value of this constant defines the filename used to store the Critical Data Store Registry. This filename is used only when no filename is specified in the command to stop performance data collecting.

**Limits**

The length of each string, including the NULL terminator cannot exceed the [OS\\_MAX\\_PATH\\_LEN](#) value.

Definition at line 876 of file cpu1\_platform\_cfg.h.

### 12.23.2.26 CFE\_PLATFORM\_ES\_DEFAULT\_ER\_LOG\_FILE

```
#define CFE_PLATFORM_ES_DEFAULT_ER_LOG_FILE "/ram/cfe_erlog.log"
```

**Purpose** Default Exception and Reset (ER) Log Filename

**Description:**

The value of this constant defines the filename used to store the Exception and Reset (ER) Log. This filename is used only when no filename is specified in the command to dump the ER log. No file specified in the cmd means the first character in the cmd filename is a NULL terminator (zero).

**Limits**

The length of each string, including the NULL terminator cannot exceed the [OS\\_MAX\\_PATH\\_LEN](#) value.

Definition at line 848 of file cpu1\_platform\_cfg.h.

### 12.23.2.27 CFE\_PLATFORM\_ES\_DEFAULT\_PERF\_DUMP\_FILENAME

```
#define CFE_PLATFORM_ES_DEFAULT_PERF_DUMP_FILENAME "/ram/cfe_es_perf.dat"
```

**Purpose** Default Performance Data Filename

#### Description:

The value of this constant defines the filename used to store the Performance Data. This filename is used only when no filename is specified in the command to stop performance data collecting.

#### Limits

The length of each string, including the NULL terminator cannot exceed the [OS\\_MAX\\_PATH\\_LEN](#) value.

Definition at line 862 of file cpu1\_platform\_cfg.h.

### 12.23.2.28 CFE\_PLATFORM\_ES\_DEFAULT\_POR\_SYSLOG\_MODE

```
#define CFE_PLATFORM_ES_DEFAULT_POR_SYSLOG_MODE 0
```

**Purpose** Define Default System Log Mode following Power On Reset

#### Description:

Defines the default mode for the operation of the ES System log following a power on reset. The log may operate in either Overwrite mode = 0, where once the log becomes full the oldest message in the log will be overwritten, or Discard mode = 1, where once the log becomes full the contents of the log are preserved and the new event is discarded. This constant may hold a value of either 0 or 1 depending on the desired default. Overwrite Mode = 0, Discard Mode = 1.

#### Limits

There is a lower limit of 0 and an upper limit of 1 on this configuration parameter.

Definition at line 894 of file cpu1\_platform\_cfg.h.

**12.23.2.29 CFE\_PLATFORM\_ES\_DEFAULT\_PR\_SYSLOG\_MODE**

```
#define CFE_PLATFORM_ES_DEFAULT_PR_SYSLOG_MODE 1
```

**Purpose** Define Default System Log Mode following Processor Reset

**Description:**

Defines the default mode for the operation of the ES System log following a processor reset. The log may operate in either Overwrite mode = 0, where once the log becomes full the oldest message in the log will be overwritten, or Discard mode = 1, where once the log becomes full the contents of the log are preserved and the new event is discarded. This constant may hold a value of either 0 or 1 depending on the desired default. Overwrite Mode = 0, Discard Mode = 1.

**Limits**

There is a lower limit of 0 and an upper limit of 1 on this configuration parameter.

Definition at line 912 of file cpu1\_platform\_cfg.h.

**12.23.2.30 CFE\_PLATFORM\_ES\_DEFAULT\_STACK\_SIZE**

```
#define CFE_PLATFORM_ES_DEFAULT_STACK_SIZE 8192
```

**Purpose** Define Default Stack Size for an Application

**Description:**

This parameter defines a default stack size. This parameter is used by the cFE Core Applications.

**Limits**

There is a lower limit of 2048. There are no restrictions on the upper limit however, the maximum stack size is system dependent and should be verified. Most operating systems provide tools for measuring the amount of stack used by a task during operation. It is always a good idea to verify that no more than 1/2 of the stack is used.

Definition at line 1062 of file cpu1\_platform\_cfg.h.

### 12.23.2.31 CFE\_PLATFORM\_ES\_DEFAULT\_SYSLOG\_FILE

```
#define CFE_PLATFORM_ES_DEFAULT_SYSLOG_FILE "/ram/cfe_es_syslog.log"
```

**Purpose** Default System Log Filename

#### Description:

The value of this constant defines the filename used to store important information (as ASCII text strings) that might not be able to be sent in an Event Message. This filename is used only when no filename is specified in the command to dump the system log. No file specified in the cmd means the first character in the cmd filename is a NULL terminator (zero).

#### Limits

The length of each string, including the NULL terminator cannot exceed the [OS\\_MAX\\_PATH\\_LEN](#) value.

Definition at line 833 of file `cpu1_platform_cfg.h`.

### 12.23.2.32 CFE\_PLATFORM\_ES\_DEFAULT\_TASK\_LOG\_FILE

```
#define CFE_PLATFORM_ES_DEFAULT_TASK_LOG_FILE "/ram/cfe_es_taskinfo.log"
```

**Purpose** Default Application Information Filename

#### Description:

The value of this constant defines the filename used to store information pertaining to all of the Applications that are registered with Executive Services. This filename is used only when no filename is specified in the the command to query all system tasks.

#### Limits

The length of each string, including the NULL terminator cannot exceed the [OS\\_MAX\\_PATH\\_LEN](#) value.

Definition at line 817 of file `cpu1_platform_cfg.h`.

### 12.23.2.33 CFE\_PLATFORM\_ES\_ER\_LOG\_ENTRIES

```
#define CFE_PLATFORM_ES_ER_LOG_ENTRIES 20
```

**Purpose** Define Max Number of ER (Exception and Reset) log entries

**Description:**

Defines the maximum number of ER (Exception and Reset) log entries

**Limits**

There is a lower limit of 1. There are no restrictions on the upper limit however, the maximum number of log entries is system dependent and should be verified.

Definition at line 518 of file cpu1\_platform\_cfg.h.

### 12.23.2.34 CFE\_PLATFORM\_ES\_ER\_LOG\_MAX\_CONTEXT\_SIZE

```
#define CFE_PLATFORM_ES_ER_LOG_MAX_CONTEXT_SIZE 256
```

**Purpose** Maximum size of CPU Context in ES Error Log

**Description:**

This should be large enough to accommodate the CPU context information supplied by the PSP on the given platform.

**Limits:**

Must be greater than zero and a multiple of sizeof(uint32). Limited only by the available memory and the number of entries in the error log. Any context information beyond this size will be truncated.

Definition at line 532 of file cpu1\_platform\_cfg.h.

### 12.23.2.35 CFE\_PLATFORM\_ES\_MAX\_APPLICATIONS

```
#define CFE_PLATFORM_ES_MAX_APPLICATIONS 32
```

**Purpose** Define Max Number of Applications

**Description:**

Defines the maximum number of applications that can be loaded into the system. This number does not include child tasks.

**Limits**

There is a lower limit of 6. The lower limit corresponds to the cFE internal applications. There are no restrictions on the upper limit however, the maximum number of applications is system dependent and should be verified. AppIDs that are checked against this configuration are defined by a 32 bit data word.

Definition at line 491 of file cpu1\_platform\_cfg.h.

**12.23.2.36 CFE\_PLATFORM\_ES\_MAX\_BLOCK\_SIZE**

```
#define CFE_PLATFORM_ES_MAX_BLOCK_SIZE 80000
```

Definition at line 1298 of file cpu1\_platform\_cfg.h.

**12.23.2.37 CFE\_PLATFORM\_ES\_MAX\_GEN\_COUNTERS**

```
#define CFE_PLATFORM_ES_MAX_GEN_COUNTERS 8
```

**Purpose** Define Max Number of Generic Counters

**Description:**

Defines the maximum number of Generic Counters that can be registered.

**Limits**

This parameter has a lower limit of 1 and an upper limit of 65535.

Definition at line 572 of file cpu1\_platform\_cfg.h.

**12.23.2.38 CFE\_PLATFORM\_ES\_MAX\_LIBRARIES**

```
#define CFE_PLATFORM_ES_MAX_LIBRARIES 10
```

**Purpose** Define Max Number of Shared libraries

**Description:**

Defines the maximum number of cFE Shared libraries that can be loaded into the system.

**Limits**

There is a lower limit of 1. There are no restrictions on the upper limit however, the maximum number of libraries is system dependent and should be verified.

Definition at line 505 of file cpu1\_platform\_cfg.h.

### 12.23.2.39 CFE\_PLATFORM\_ES\_MAX\_MEMORY\_POOLS

```
#define CFE_PLATFORM_ES_MAX_MEMORY_POOLS 10
```

**Purpose** Maximum number of memory pools

#### Description:

The upper limit for the number of memory pools that can concurrently exist within the system.

The CFE\_SB and CFE\_TBL core subsystems each define a memory pool.

Individual applications may also create memory pools, so this value should be set sufficiently high enough to support the applications being used on this platform.

#### Limits:

Must be at least 2 to support CFE core - SB and TBL pools. No specific upper limit.

Definition at line 1263 of file cpu1\_platform\_cfg.h.

### 12.23.2.40 CFE\_PLATFORM\_ES\_MAX\_PROCESSOR\_RESETS

```
#define CFE_PLATFORM_ES_MAX_PROCESSOR_RESETS 2
```

**Purpose** Define Number of Processor Resets Before a Power On Reset

#### Description:

Number of Processor Resets before a Power On Reset is called. If set to 2, then 2 processor resets will occur, and the 3rd processor reset will be a power on reset instead.

#### Limits

There is a lower limit of 0. There are no restrictions on the upper limit however, the maximum number of processor resets may be system dependent and should be verified.

Definition at line 1230 of file cpu1\_platform\_cfg.h.

#### 12.23.2.41 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_01

```
#define CFE_PLATFORM_ES_MEM_BLOCK_SIZE_01 8
```

**Purpose** Define Default ES Memory Pool Block Sizes

Description:

Default Intermediate ES Memory Pool Block Sizes. If an application is using the CFE\_ES Memory Pool APIs ([CFE\\_ES\\_PoolCreate](#), [CFE\\_ES\\_PoolCreateNoSem](#), [CFE\\_ES\\_GetPoolBuf](#) and [CFE\\_ES\\_PutPoolBuf](#)) but finds these sizes inappropriate for their use, they may wish to use the [CFE\\_ES\\_PoolCreateEx](#) API to specify their own intermediate block sizes

Limits

These sizes MUST be increasing and MUST be an integral multiple of 4. Also, CFE\_PLATFORM\_ES\_MAX\_BLOCK\_SIZE must be larger than CFE\_MISSION\_SB\_MAX\_SB\_MSG\_SIZE and both CFE\_PLATFORM\_TB\_L\_MAX\_SNGL\_TABLE\_SIZE and CFE\_PLATFORM\_TBL\_MAX\_DBL\_TABLE\_SIZE. Note that if Table Services have been removed from the CFE, the table size limits are still enforced although the table size definitions may be reduced.

Definition at line 1282 of file cpu1\_platform\_cfg.h.

#### 12.23.2.42 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_02

```
#define CFE_PLATFORM_ES_MEM_BLOCK_SIZE_02 16
```

Definition at line 1283 of file cpu1\_platform\_cfg.h.

#### 12.23.2.43 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_03

```
#define CFE_PLATFORM_ES_MEM_BLOCK_SIZE_03 32
```

Definition at line 1284 of file cpu1\_platform\_cfg.h.

#### 12.23.2.44 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_04

```
#define CFE_PLATFORM_ES_MEM_BLOCK_SIZE_04 48
```

Definition at line 1285 of file cpu1\_platform\_cfg.h.

**12.23.2.45 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_05**

```
#define CFE_PLATFORM_ES_MEM_BLOCK_SIZE_05 64
```

Definition at line 1286 of file cpu1\_platform\_cfg.h.

**12.23.2.46 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_06**

```
#define CFE_PLATFORM_ES_MEM_BLOCK_SIZE_06 96
```

Definition at line 1287 of file cpu1\_platform\_cfg.h.

**12.23.2.47 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_07**

```
#define CFE_PLATFORM_ES_MEM_BLOCK_SIZE_07 128
```

Definition at line 1288 of file cpu1\_platform\_cfg.h.

**12.23.2.48 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_08**

```
#define CFE_PLATFORM_ES_MEM_BLOCK_SIZE_08 160
```

Definition at line 1289 of file cpu1\_platform\_cfg.h.

**12.23.2.49 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_09**

```
#define CFE_PLATFORM_ES_MEM_BLOCK_SIZE_09 256
```

Definition at line 1290 of file cpu1\_platform\_cfg.h.

**12.23.2.50 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_10**

```
#define CFE_PLATFORM_ES_MEM_BLOCK_SIZE_10 512
```

Definition at line 1291 of file cpu1\_platform\_cfg.h.

**12.23.2.51 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_11**

```
#define CFE_PLATFORM_ES_MEM_BLOCK_SIZE_11 1024
```

Definition at line 1292 of file cpu1\_platform\_cfg.h.

**12.23.2.52 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_12**

```
#define CFE_PLATFORM_ES_MEM_BLOCK_SIZE_12 2048
```

Definition at line 1293 of file cpu1\_platform\_cfg.h.

**12.23.2.53 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_13**

```
#define CFE_PLATFORM_ES_MEM_BLOCK_SIZE_13 4096
```

Definition at line 1294 of file cpu1\_platform\_cfg.h.

**12.23.2.54 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_14**

```
#define CFE_PLATFORM_ES_MEM_BLOCK_SIZE_14 8192
```

Definition at line 1295 of file cpu1\_platform\_cfg.h.

**12.23.2.55 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_15**

```
#define CFE_PLATFORM_ES_MEM_BLOCK_SIZE_15 16384
```

Definition at line 1296 of file cpu1\_platform\_cfg.h.

**12.23.2.56 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_16**

```
#define CFE_PLATFORM_ES_MEM_BLOCK_SIZE_16 32768
```

Definition at line 1297 of file cpu1\_platform\_cfg.h.

**12.23.2.57 CFE\_PLATFORM\_ES\_MEMPOOL\_ALIGN\_SIZE\_MIN**

```
#define CFE_PLATFORM_ES_MEMPOOL_ALIGN_SIZE_MIN 4
```

**Purpose** Define Memory Pool Alignment Size

**Description:**

Ensures that buffers obtained from a memory pool are aligned to a certain minimum block size. Note the allocator will always align to the minimum required by the CPU architecture. This may be set greater than the CPU requirement as desired for optimal performance.

For some architectures/applications it may be beneficial to set this to the cache line size of the target CPU, or to use special SIMD instructions that require a more stringent memory alignment.

**Limits**

This must always be a power of 2, as it is used as a binary address mask.

Definition at line 759 of file cpu1\_platform\_cfg.h.

**12.23.2.58 CFE\_PLATFORM\_ES\_NONVOL\_DISK\_MOUNT\_STRING**

```
#define CFE_PLATFORM_ES_NONVOL_DISK_MOUNT_STRING "/cf"
```

**Purpose** Default virtual path for persistent storage

**Description:**

This configures the default location in the virtual file system for persistent/non-volatile storage. Files such as the startup script, app/library dynamic modules, and configuration tables are expected to be stored in this directory.

Definition at line 47 of file cpu1\_platform\_cfg.h.

**12.23.2.59 CFE\_PLATFORM\_ES\_NONVOL\_STARTUP\_FILE**

```
#define CFE_PLATFORM_ES_NONVOL_STARTUP_FILE "/cf/cfe_es_startup.scr"
```

**Purpose** ES Nonvolatile Startup Filename

**Description:**

The value of this constant defines the path and name of the file that contains a list of modules that will be loaded and started by the cFE after the cFE finishes its startup sequence.

**Limits**

The length of each string, including the NULL terminator cannot exceed the [OS\\_MAX\\_PATH\\_LEN](#) value.

Definition at line 773 of file cpu1\_platform\_cfg.h.

**12.23.2.60 CFE\_PLATFORM\_ES\_OBJECT\_TABLE\_SIZE**

```
#define CFE_PLATFORM_ES_OBJECT_TABLE_SIZE 30
```

**Purpose** Define Number of entries in the ES Object table

**Description:**

Defines the number of entries in the ES Object table. This table controls the core cFE startup.

**Limits**

There is a lower limit of 15. There are no restrictions on the upper limit however, the maximum object table size is system dependent and should be verified.

Definition at line 561 of file cpu1\_platform\_cfg.h.

**12.23.2.61 CFE\_PLATFORM\_ES\_PERF\_CHILD\_MS\_DELAY**

```
#define CFE_PLATFORM_ES_PERF_CHILD_MS_DELAY 20
```

**Purpose** Define Performance Analyzer Child Task Delay

**Description:**

This parameter defines the delay time (in milliseconds) between performance data file writes performed by the Executive Services Performance Analyzer Child Task.

**Limits**

It is recommended this parameter be greater than or equal to 20ms. This parameter is limited by the maximum value allowed by the data type. In this case, the data type is an unsigned 32-bit integer, so the valid range is 0 to 0xFFFFFFFF.

Definition at line 1036 of file cpu1\_platform\_cfg.h.

**12.23.2.62 CFE\_PLATFORM\_ES\_PERF\_CHILD\_PRIORITY**

```
#define CFE_PLATFORM_ES_PERF_CHILD_PRIORITY 200
```

**Purpose** Define Performance Analyzer Child Task Priority

**Description:**

This parameter defines the priority of the child task spawned by the Executive Services to write performance data to a file. Lower numbers are higher priority, with 1 being the highest priority in the case of a child task.

**Limits**

Valid range for a child task is 1 to 255 however, the priority cannot be higher (lower number) than the ES parent application priority.

Definition at line 1007 of file cpu1\_platform\_cfg.h.

**12.23.2.63 CFE\_PLATFORM\_ES\_PERF\_CHILD\_STACK\_SIZE**

```
#define CFE_PLATFORM_ES_PERF_CHILD_STACK_SIZE 4096
```

**Purpose** Define Performance Analyzer Child Task Stack Size

**Description:**

This parameter defines the stack size of the child task spawned by the Executive Services to write performance data to a file.

**Limits**

It is recommended this parameter be greater than or equal to 4KB. This parameter is limited by the maximum value allowed by the data type. In this case, the data type is an unsigned 32-bit integer, so the valid range is 0 to 0xFFFFFFFF.

Definition at line 1021 of file cpu1\_platform\_cfg.h.

**12.23.2.64 CFE\_PLATFORM\_ES\_PERF\_DATA\_BUFFER\_SIZE**

```
#define CFE_PLATFORM_ES_PERF_DATA_BUFFER_SIZE 10000
```

**Purpose** Define Max Size of Performance Data Buffer

**Description:**

Defines the maximum size of the performance data buffer. Units are number of performance data entries. An entry is defined by a 32 bit data word followed by a 64 bit time stamp.

**Limits**

There is a lower limit of 1025. There are no restrictions on the upper limit however, the maximum buffer size is system dependent and should be verified. The units are number of entries. An entry is defined by a 32 bit data word followed by a 64 bit time stamp.

Definition at line 928 of file cpu1\_platform\_cfg.h.

**12.23.2.65 CFE\_PLATFORM\_ES\_PERF\_ENTRIES\_BTWN\_DLYS**

```
#define CFE_PLATFORM_ES_PERF_ENTRIES_BTWN_DLYS 50
```

**Purpose** Define Performance Analyzer Child Task Number of Entries Between Delay

**Description:**

This parameter defines the number of performance analyzer entries the Performance Analyzer Child Task will write to the file between delays.

Definition at line 1046 of file cpu1\_platform\_cfg.h.

**12.23.2.66 CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_ALL**

```
#define CFE_PLATFORM_ES_PERF_FILTMASK_ALL ~CFE_PLATFORM_ES_PERF_FILTMASK_NONE
```

**Purpose** Define Filter Mask Setting for Enabling All Performance Entries

**Description:**

Defines the filter mask for enabling all performance entries. The value is a bit mask. For each bit, 0 means the corresponding entry is disabled and 1 means it is enabled.

Definition at line 948 of file cpu1\_platform\_cfg.h.

**12.23.2.67 CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_INIT**

```
#define CFE_PLATFORM_ES_PERF_FILTMASK_INIT CFE_PLATFORM_ES_PERF_FILTMASK_ALL
```

**Purpose** Define Default Filter Mask Setting for Performance Data Buffer

**Description:**

Defines the default filter mask for the performance data buffer. The value is a bit mask. For each bit, 0 means the corresponding entry is disabled and 1 means it is enabled.

Definition at line 959 of file cpu1\_platform\_cfg.h.

**12.23.2.68 CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_NONE**

```
#define CFE_PLATFORM_ES_PERF_FILTMASK_NONE 0
```

**Purpose** Define Filter Mask Setting for Disabling All Performance Entries

**Description:**

Defines the filter mask for disabling all performance entries. The value is a bit mask. For each bit, 0 means the corresponding entry is disabled and 1 means it is enabled.

Definition at line 938 of file cpu1\_platform\_cfg.h.

**12.23.2.69 CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_ALL**

```
#define CFE_PLATFORM_ES_PERF_TRIGMASK_ALL ~CFE_PLATFORM_ES_PERF_TRIGMASK_NONE
```

**Purpose** Define Filter Trigger Setting for Enabling All Performance Entries

**Description:**

Defines the trigger mask for enabling all performance data entries. The value is a bit mask. For each bit, 0 means the trigger for the corresponding entry is disabled and 1 means it is enabled.

Definition at line 981 of file cpu1\_platform\_cfg.h.

**12.23.2.70 CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_INIT**

```
#define CFE_PLATFORM_ES_PERF_TRIGMASK_INIT CFE_PLATFORM_ES_PERF_TRIGMASK_NONE
```

**Purpose** Define Default Filter Trigger Setting for Performance Data Buffer

**Description:**

Defines the default trigger mask for the performance data buffer. The value is a 32-bit mask. For each bit, 0 means the trigger for the corresponding entry is disabled and 1 means it is enabled.

Definition at line 992 of file cpu1\_platform\_cfg.h.

**12.23.2.71 CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_NONE**

```
#define CFE_PLATFORM_ES_PERF_TRIGMASK_NONE 0
```

**Purpose** Define Default Filter Trigger Setting for Disabling All Performance Entries

**Description:**

Defines the default trigger mask for disabling all performance data entries. The value is a bit mask. For each bit, 0 means the trigger for the corresponding entry is disabled and 1 means it is enabled.

Definition at line 970 of file cpu1\_platform\_cfg.h.

### 12.23.2.72 CFE\_PLATFORM\_ES\_POOL\_MAX\_BUCKETS

```
#define CFE_PLATFORM_ES_POOL_MAX_BUCKETS 17
```

**Purpose** Maximum number of block sizes in pool structures

**Description:**

The upper limit for the number of block sizes supported in the generic pool implementation, which in turn implements the memory pools and CDS.

**Limits:**

Must be at least one. No specific upper limit, but the number is anticipated to be reasonably small (i.e. tens, not hundreds). Large values have not been tested.

The ES and CDS block size lists must correlate with this value

Definition at line 1245 of file cpu1\_platform\_cfg.h.

### 12.23.2.73 CFE\_PLATFORM\_ES\_RAM\_DISK\_MOUNT\_STRING

```
#define CFE_PLATFORM_ES_RAM_DISK_MOUNT_STRING "/ram"
```

**Purpose** Default virtual path for volatile storage

**Description:**

The `CFE_PLATFORM_ES_RAM_DISK_MOUNT_STRING` parameter is used to set the cFE mount path for the CFE RAM disk. This is a parameter for missions that do not want to use the default value of "/ram", or for missions that need to have a different value for different CPUs or Spacecraft. Note that the vxWorks OSAL cannot currently handle names that have more than one path separator in it. The names "/ram", "/ramdisk", "/disk123" will all work, but "/disks/ram" will not. Multiple separators can be used with the posix or RTEMS ports.

Definition at line 63 of file cpu1\_platform\_cfg.h.

### 12.23.2.74 CFE\_PLATFORM\_ES\_RAM\_DISK\_NUM\_SECTORS

```
#define CFE_PLATFORM_ES_RAM_DISK_NUM_SECTORS 4096
```

**Purpose** ES Ram Disk Number of Sectors

**Description:**

Defines the ram disk number of sectors. The ram disk is one of four memory areas that are preserved on a processor reset. NOTE: Changing this value changes memory allocation, and may require changes to platform specific values (in CFE\_PSP) such as `USER_RESERVED_MEM` in VxWorks depending on the memory areas being used for preserved data and on OS specific behavior.

**Limits**

There is a lower limit of 128. There are no restrictions on the upper limit however, the maximum number of RAM sectors is system dependent and should be verified.

Definition at line 656 of file cpu1\_platform\_cfg.h.

### 12.23.2.75 CFE\_PLATFORM\_ES\_RAM\_DISK\_PERCENT\_RESERVED

```
#define CFE_PLATFORM_ES_RAM_DISK_PERCENT_RESERVED 30
```

**Purpose** Percentage of Ram Disk Reserved for Decompressing Apps

#### Description:

The `CFE_PLATFORM_ES_RAM_DISK_PERCENT_RESERVED` parameter is used to make sure that the Volatile ( RAM ) Disk has a defined amount of free space during a processor reset. The cFE uses the Volatile disk to decompress cFE applications during system startup. If this Volatile disk happens to get filled with logs and misc files, then a processor reset may not work, because there will be no room to decompress cFE apps. To solve that problem, this parameter sets the "Low Water Mark" for disk space on a Processor reset. It should be set to allow the largest cFE Application to be decompressed. During a Processor reset, if there is not sufficient space left on the disk, it will be re-formatted in order to clear up some space.

This feature can be turned OFF by setting the parameter to 0.

#### Limits

There is a lower limit of 0 and an upper limit of 75 on this configuration parameter. Units are percentage. A setting of zero will turn this feature off.

Definition at line 680 of file `cpu1_platform_cfg.h`.

### 12.23.2.76 CFE\_PLATFORM\_ES\_RAM\_DISK\_SECTOR\_SIZE

```
#define CFE_PLATFORM_ES_RAM_DISK_SECTOR_SIZE 512
```

**Purpose** ES Ram Disk Sector Size

#### Description:

Defines the ram disk sector size. The ram disk is 1 of 4 memory areas that are preserved on a processor reset.  
NOTE: Changing this value changes memory allocation, and may require changes to platform specific values (in C↔FE\_PSP) such as `USER_RESERVED_MEM` in VxWorks depending on the memory areas being used for preserved data and on OS specific behavior.

#### Limits

There is a lower limit of 128. There are no restrictions on the upper limit however, the maximum RAM disk sector size is system dependent and should be verified.

Definition at line 638 of file `cpu1_platform_cfg.h`.

### 12.23.2.77 CFE\_PLATFORM\_ES\_RESET\_AREA\_SIZE

```
#define CFE_PLATFORM_ES_RESET_AREA_SIZE (170 * 1024)
```

**Purpose** Define ES Reset Area Size

#### Description:

The ES Reset Area Size. This is the size in bytes of the cFE Reset variable and log area. This is a block of memory used by the cFE to store the system log ER Log and critical reset variables. This is 4 of 4 of the memory areas that are preserved during a processor reset. Note: This area must be sized large enough to hold all of the data structures. It should be automatically sized based on the CFE\_ES\_ResetData\_t type, but circular dependencies in the headers prevent it from being defined this way. NOTE: Changing this value changes memory allocation, and may require changes to platform specific values (in CFE\_PSP) such as USER\_RESERVED\_MEM in VxWorks depending on the memory areas being used for preserved data and on OS specific behavior.

#### Limits

There is a lower limit of 153600 (150KBytes) and an upper limit of UINT\_MAX (4 Gigabytes) on this configuration parameter.

Definition at line 740 of file cpu1\_platform\_cfg.h.

### 12.23.2.78 CFE\_PLATFORM\_ES\_START\_TASK\_PRIORITY

```
#define CFE_PLATFORM_ES_START_TASK_PRIORITY 68
```

**Purpose** Define ES Task Priority

#### Description:

Defines the cFE\_ES Task priority.

#### Limits

Not Applicable

Definition at line 1125 of file cpu1\_platform\_cfg.h.

### 12.23.2.79 CFE\_PLATFORM\_ES\_START\_TASK\_STACK\_SIZE

```
#define CFE_PLATFORM_ES_START_TASK_STACK_SIZE CFE_PLATFORM_ES_DEFAULT_STACK_SIZE
```

**Purpose** Define ES Task Stack Size

**Description:**

Defines the cFE\_ES Task Stack Size

**Limits**

There is a lower limit of 2048 on this configuration parameter. There are no restrictions on the upper limit however, the maximum stack size is system dependent and should be verified. Most operating systems provide tools for measuring the amount of stack used by a task during operation. It is always a good idea to verify that no more than 1/2 of the stack is used.

Definition at line 1140 of file cpu1\_platform\_cfg.h.

### 12.23.2.80 CFE\_PLATFORM\_ES\_STARTUP\_SCRIPT\_TIMEOUT\_MSEC

```
#define CFE_PLATFORM_ES_STARTUP_SCRIPT_TIMEOUT_MSEC 1000
```

**Purpose** Startup script timeout

**Description:**

The upper limit for the total amount of time that all apps listed in the CFE ES startup script may take to all become ready.

Unlike the "core" app timeout, this is a soft limit; if the allotted time is exceeded, it probably indicates an issue with one of the apps, but does not cause CFE ES to take any additional action other than logging the event to the syslog.

Units are in milliseconds

**Limits:**

Must be defined as an integer value that is greater than or equal to zero.

Definition at line 1731 of file cpu1\_platform\_cfg.h.

### 12.23.2.81 CFE\_PLATFORM\_ES\_STARTUP\_SYNC\_POLL\_MSEC

```
#define CFE_PLATFORM_ES_STARTUP_SYNC_POLL_MSEC 50
```

**Purpose** Poll timer for startup sync delay

Description:

During startup, some tasks may need to synchronize their own initialization with the initialization of other applications in the system.

CFE ES implements an API to accomplish this, that performs a task delay (sleep) while polling the overall system state until other tasks are ready.

This value controls the amount of time that the CFE\_ES\_ApplicationSyncDelay will sleep between each check of the system state. This should be large enough to allow other tasks to run, but not so large as to noticeably delay the startup completion.

Units are in milliseconds

Limits:

Must be defined as an integer value that is greater than or equal to zero.

Definition at line 1689 of file cpu1\_platform\_cfg.h.

### 12.23.2.82 CFE\_PLATFORM\_ES\_SYSTEM\_LOG\_SIZE

```
#define CFE_PLATFORM_ES_SYSTEM_LOG_SIZE 3072
```

**Purpose** Define Size of the cFE System Log.

Description:

Defines the size in bytes of the cFE system log. The system log holds variable length strings that are terminated by a linefeed and null character.

Limits

There is a lower limit of 512. There are no restrictions on the upper limit however, the maximum system log size is system dependent and should be verified.

Definition at line 547 of file cpu1\_platform\_cfg.h.

### 12.23.2.83 CFE\_PLATFORM\_ES\_USER\_RESERVED\_SIZE

```
#define CFE_PLATFORM_ES_USER_RESERVED_SIZE (1024 * 1024)
```

**Purpose** Define User Reserved Memory Size

#### Description:

User Reserved Memory Size. This is the size in bytes of the cFE User reserved Memory area. This is a block of memory that is available for cFE application use. The address is obtained by calling [CFE\\_PSP\\_GetUserReservedArea](#). The User Reserved Memory is one of four memory areas that are preserved during a processor reset. NOTE: Changing this value changes memory allocation, and may require changes to platform specific values (in CFE\_PSP) such as USER\_RESERVED\_MEM in VxWorks depending on the memory areas being used for preserved data and on OS specific behavior.

#### Limits

There is a lower limit of 1024 and an upper limit of `UINT_MAX` (4 Gigabytes) on this configuration parameter.

Definition at line 717 of file `cpu1_platform_cfg.h`.

### 12.23.2.84 CFE\_PLATFORM\_ES\_VOLATILE\_STARTUP\_FILE

```
#define CFE_PLATFORM_ES_VOLATILE_STARTUP_FILE "/ram/cfe_es_startup.scr"
```

**Purpose** ES Volatile Startup Filename

#### Description:

The value of this constant defines the path and name of the file that contains a list of modules that will be loaded and started by the cFE after the cFE finishes its startup sequence.

#### Limits

The length of each string, including the NULL terminator cannot exceed the [OS\\_MAX\\_PATH\\_LEN](#) value.

Definition at line 787 of file `cpu1_platform_cfg.h`.

**12.23.2.85 CFE\_PLATFORM\_EVS\_APP\_EVENTS\_PER\_SEC**

```
#define CFE_PLATFORM_EVS_APP_EVENTS_PER_SEC 8
```

**Purpose** Sustained number of event messages per second per app before squelching

**Description:**

Sustained number of events that may be emitted per app per second.

**Limits**

This number must be less than or equal to [CFE\\_PLATFORM\\_EVS\\_MAX\\_APP\\_EVENT\\_BURST](#). Values lower than 8 may cause functional and unit test failures.

Definition at line 1362 of file `cpu1_platform_cfg.h`.

**12.23.2.86 CFE\_PLATFORM\_EVS\_DEFAULT\_APP\_DATA\_FILE**

```
#define CFE_PLATFORM_EVS_DEFAULT_APP_DATA_FILE "/ram/cfe_evs_app.dat"
```

**Purpose** Default EVS Application Data Filename

**Description:**

The value of this constant defines the filename used to store the EVS Application Data(event counts/filtering information). This filename is used only when no filename is specified in the command to dump the event log.

**Limits**

The length of each string, including the NULL terminator cannot exceed the [OS\\_MAX\\_PATH\\_LEN](#) value.

Definition at line 1403 of file `cpu1_platform_cfg.h`.

**12.23.2.87 CFE\_PLATFORM\_EVS\_DEFAULT\_LOG\_FILE**

```
#define CFE_PLATFORM_EVS_DEFAULT_LOG_FILE "/ram/cfe_evs.log"
```

**Purpose** Default Event Log Filename

**Description:**

The value of this constant defines the filename used to store the Event Services local event log. This filename is used only when no filename is specified in the command to dump the event log.

**Limits**

The length of each string, including the NULL terminator cannot exceed the [OS\\_MAX\\_PATH\\_LEN](#) value.

Definition at line 1376 of file `cpu1_platform_cfg.h`.

#### 12.23.2.88 CFE\_PLATFORM\_EVS\_DEFAULT\_LOG\_MODE

```
#define CFE_PLATFORM_EVS_DEFAULT_LOG_MODE 1
```

**Purpose** Default EVS Local Event Log Mode

**Description:**

Defines a state of overwrite(0) or discard(1) for the operation of the EVS local event log. The log may operate in either Overwrite mode = 0, where once the log becomes full the oldest event in the log will be overwritten, or Discard mode = 1, where once the log becomes full the contents of the log are preserved and the new event is discarded. Overwrite Mode = 0, Discard Mode = 1.

**Limits**

The valid settings are 0 or 1

Definition at line 1450 of file cpu1\_platform\_cfg.h.

#### 12.23.2.89 CFE\_PLATFORM\_EVS\_DEFAULT\_MSG\_FORMAT\_MODE

```
#define CFE_PLATFORM_EVS_DEFAULT_MSG_FORMAT_MODE CFE_EVS_MsgFormat_LONG
```

**Purpose** Default EVS Message Format Mode

**Description:**

Defines the default message format (long or short) for event messages being sent to the ground. Choose between [CFE\\_EVS\\_MsgFormat\\_LONG](#) or [CFE\\_EVS\\_MsgFormat\\_SHORT](#).

**Limits**

The valid settings are [CFE\\_EVS\\_MsgFormat\\_LONG](#) or [CFE\\_EVS\\_MsgFormat\\_SHORT](#)

Definition at line 1463 of file cpu1\_platform\_cfg.h.

#### 12.23.2.90 CFE\_PLATFORM\_EVS\_DEFAULT\_TYPE\_FLAG

```
#define CFE_PLATFORM_EVS_DEFAULT_TYPE_FLAG 0xE
```

**Purpose** Default EVS Event Type Filter Mask

**Description:**

Defines a state of on or off for all four event types. The term event 'type' refers to the criticality level and may be Debug, Informational, Error or Critical. Each event type has a bit position. (bit 0 = Debug, bit 1 = Info, bit 2 = Error, bit 3 = Critical). This is a global setting, meaning it applies to all applications. To filter an event type, set its bit to zero. For example, 0xE means Debug = OFF, Info = ON, Error = ON, Critical = ON

**Limits**

The valid settings are 0x0 to 0xF.

Definition at line 1434 of file cpu1\_platform\_cfg.h.

**12.23.2.91 CFE\_PLATFORM\_EVS\_LOG\_MAX**

```
#define CFE_PLATFORM_EVS_LOG_MAX 20
```

**Purpose** Maximum Number of Events in EVS Local Event Log

Description:

Dictates the EVS local event log capacity. Units are the number of events.

Limits

There are no restrictions on the lower and upper limits however, the maximum log size is system dependent and should be verified.

Definition at line 1388 of file cpu1\_platform\_cfg.h.

**12.23.2.92 CFE\_PLATFORM\_EVS\_MAX\_APP\_EVENT\_BURST**

```
#define CFE_PLATFORM_EVS_MAX_APP_EVENT_BURST 32
```

**Purpose** Maximum number of event before squelching

Description:

Maximum number of events that may be emitted per app per second. Setting this to 0 will cause events to be unrestricted.

Limits

This number must be less than or equal to INT\_MAX/1000

Definition at line 1350 of file cpu1\_platform\_cfg.h.

**12.23.2.93 CFE\_PLATFORM\_EVS\_MAX\_EVENT\_FILTERS**

```
#define CFE_PLATFORM_EVS_MAX_EVENT_FILTERS 8
```

**Purpose** Define Maximum Number of Event Filters per Application

Description:

Maximum number of events that may be filtered per application.

Limits

There are no restrictions on the lower and upper limits however, the maximum number of event filters is system dependent and should be verified.

Definition at line 1338 of file cpu1\_platform\_cfg.h.

**12.23.2.94 CFE\_PLATFORM\_EVS\_PORT\_DEFAULT**

```
#define CFE_PLATFORM_EVS_PORT_DEFAULT 0x0001
```

**Purpose** Default EVS Output Port State

**Description:**

Defines the default port state (enabled or disabled) for the four output ports defined within the Event Service. Port 1 is usually the uart output terminal. To enable a port, set the proper bit to a 1. Bit 0 is port 1, bit 1 is port2 etc.

**Limits**

The valid settings are 0x0 to 0xF.

Definition at line 1417 of file cpu1\_platform\_cfg.h.

**12.23.2.95 CFE\_PLATFORM\_EVS\_START\_TASK\_PRIORITY**

```
#define CFE_PLATFORM_EVS_START_TASK_PRIORITY 61
```

**Purpose** Define EVS Task Priority

**Description:**

Defines the cFE\_EVS Task priority.

**Limits**

Not Applicable

Definition at line 1073 of file cpu1\_platform\_cfg.h.

**12.23.2.96 CFE\_PLATFORM\_EVS\_START\_TASK\_STACK\_SIZE**

```
#define CFE_PLATFORM_EVS_START_TASK_STACK_SIZE CFE_PLATFORM_ES_DEFAULT_STACK_SIZE
```

**Purpose** Define EVS Task Stack Size

**Description:**

Defines the cFE\_EVS Task Stack Size

**Limits**

There is a lower limit of 2048 on this configuration parameter. There are no restrictions on the upper limit however, the maximum stack size is system dependent and should be verified. Most operating systems provide tools for measuring the amount of stack used by a task during operation. It is always a good idea to verify that no more than 1/2 of the stack is used.

Definition at line 1088 of file cpu1\_platform\_cfg.h.

### 12.23.2.97 CFE\_PLATFORM\_SB\_BUF\_MEMORY\_BYTES

```
#define CFE_PLATFORM_SB_BUF_MEMORY_BYTES 524288
```

**Purpose** Size of the SB buffer memory pool

#### Description:

Dictates the size of the SB memory pool. For each message the SB sends, the SB dynamically allocates from this memory pool, the memory needed to process the message. The memory needed to process each message is msg size + msg descriptor(CFE\_SB\_BufferD\_t). This memory pool is also used to allocate destination descriptors (CFE\_SB\_DestinationD\_t) during the subscription process. To see the run-time, high-water mark and the current utilization figures regarding this parameter, send an SB command to 'Send Statistics Pkt'. Some memory statistics have been added to the SB housekeeping packet. NOTE: It is important to monitor these statistics to ensure the desired memory margin is met.

#### Limits

This parameter has a lower limit of 512 and an upper limit of `UINT_MAX` (4 Gigabytes).

Definition at line 153 of file `cpu1_platform_cfg.h`.

### 12.23.2.98 CFE\_PLATFORM\_SB\_DEFAULT\_MAP\_FILENAME

```
#define CFE_PLATFORM_SB_DEFAULT_MAP_FILENAME "/ram/cfe_sb_msgmap.dat"
```

**Purpose** Default Message Map Filename

#### Description:

The value of this constant defines the filename used to store the software bus message map information. This filename is used only when no filename is specified in the command. The message map is a lookup table (array of 16bit words) that has an element for each possible MsgId value and holds the routing table index for that MsgId. The Msg Map provides fast access to the destinations of a message.

#### Limits

The length of each string, including the NULL terminator cannot exceed the `OS_MAX_PATH_LEN` value.

Definition at line 235 of file `cpu1_platform_cfg.h`.

**12.23.2.99 CFE\_PLATFORM\_SB\_DEFAULT\_MSG\_LIMIT**

```
#define CFE_PLATFORM_SB_DEFAULT_MSG_LIMIT 4
```

**Purpose** Default Subscription Message Limit

**Description:**

Dictates the default Message Limit when using the [CFE\\_SB\\_Subscribe](#) API. This will limit the number of messages with a specific message ID that can be received through a subscription. This only changes the default; other message limits can be set on a per subscription basis using [CFE\\_SB\\_SubscribeEx](#).

**Limits**

This parameter has a lower limit of 4 and an upper limit of 65535.

Definition at line 131 of file cpu1\_platform\_cfg.h.

**12.23.2.100 CFE\_PLATFORM\_SB\_DEFAULT\_PIPE\_FILENAME**

```
#define CFE_PLATFORM_SB_DEFAULT_PIPE_FILENAME "/ram/cfe_sb_pipe.dat"
```

**Purpose** Default Pipe Information Filename

**Description:**

The value of this constant defines the filename used to store the software bus pipe information. This filename is used only when no filename is specified in the command.

**Limits**

The length of each string, including the NULL terminator cannot exceed the [OS\\_MAX\\_PATH\\_LEN](#) value.

Definition at line 218 of file cpu1\_platform\_cfg.h.

**12.23.2.101 CFE\_PLATFORM\_SB\_DEFAULT\_ROUTING\_FILENAME**

```
#define CFE_PLATFORM_SB_DEFAULT_ROUTING_FILENAME "/ram/cfe_sb_route.dat"
```

**Purpose** Default Routing Information Filename

**Description:**

The value of this constant defines the filename used to store the software bus routing information. This filename is used only when no filename is specified in the command.

**Limits**

The length of each string, including the NULL terminator cannot exceed the [OS\\_MAX\\_PATH\\_LEN](#) value.

Definition at line 204 of file cpu1\_platform\_cfg.h.

**12.23.2.102 CFE\_PLATFORM\_SB\_FILTER\_MASK1**

```
#define CFE_PLATFORM_SB_FILTER_MASK1 CFE_EVS_FIRST_4_STOP
```

Definition at line 253 of file cpu1\_platform\_cfg.h.

**12.23.2.103 CFE\_PLATFORM\_SB\_FILTER\_MASK2**

```
#define CFE_PLATFORM_SB_FILTER_MASK2 CFE_EVS_FIRST_4_STOP
```

Definition at line 256 of file cpu1\_platform\_cfg.h.

**12.23.2.104 CFE\_PLATFORM\_SB\_FILTER\_MASK3**

```
#define CFE_PLATFORM_SB_FILTER_MASK3 CFE_EVS_FIRST_16_STOP
```

Definition at line 259 of file cpu1\_platform\_cfg.h.

**12.23.2.105 CFE\_PLATFORM\_SB\_FILTER\_MASK4**

```
#define CFE_PLATFORM_SB_FILTER_MASK4 CFE_EVS_FIRST_16_STOP
```

Definition at line 262 of file cpu1\_platform\_cfg.h.

**12.23.2.106 CFE\_PLATFORM\_SB\_FILTER\_MASK5**

```
#define CFE_PLATFORM_SB_FILTER_MASK5 CFE_EVS_NO_FILTER
```

Definition at line 265 of file cpu1\_platform\_cfg.h.

**12.23.2.107 CFE\_PLATFORM\_SB\_FILTER\_MASK6**

```
#define CFE_PLATFORM_SB_FILTER_MASK6 CFE_EVS_NO_FILTER
```

Definition at line 268 of file cpu1\_platform\_cfg.h.

**12.23.2.108 CFE\_PLATFORM\_SB\_FILTER\_MASK7**

```
#define CFE_PLATFORM_SB_FILTER_MASK7 CFE_EVS_NO_FILTER
```

Definition at line 271 of file cpu1\_platform\_cfg.h.

**12.23.2.109 CFE\_PLATFORM\_SB\_FILTER\_MASK8**

```
#define CFE_PLATFORM_SB_FILTER_MASK8 CFE_EVS_NO_FILTER
```

Definition at line 274 of file cpu1\_platform\_cfg.h.

**12.23.2.110 CFE\_PLATFORM\_SB\_FILTERED\_EVENT1**

```
#define CFE_PLATFORM_SB_FILTERED_EVENT1 CFE_SB_SEND_NO_SUBS_EID
```

**Purpose** SB Event Filtering**Description:**

This group of configuration parameters dictates what SB events will be filtered through EVS. The filtering will begin after the SB task initializes and stay in effect until a cmd to EVS changes it. This allows the operator to set limits on the number of event messages that are sent during system initialization. NOTE: Set all unused event values and mask values to zero

**Limits**

This filtering applies only to SB events. These parameters have a lower limit of 0 and an upper limit of 65535.

Definition at line 252 of file cpu1\_platform\_cfg.h.

**12.23.2.111 CFE\_PLATFORM\_SB\_FILTERED\_EVENT2**

```
#define CFE_PLATFORM_SB_FILTERED_EVENT2 CFE_SB_DUP_SUBSCRIP_EID
```

Definition at line 255 of file cpu1\_platform\_cfg.h.

**12.23.2.112 CFE\_PLATFORM\_SB\_FILTERED\_EVENT3**

```
#define CFE_PLATFORM_SB_FILTERED_EVENT3 CFE_SB_MSGID_LIM_ERR_EID
```

Definition at line 258 of file cpu1\_platform\_cfg.h.

**12.23.2.113 CFE\_PLATFORM\_SB\_FILTERED\_EVENT4**

```
#define CFE_PLATFORM_SB_FILTERED_EVENT4 CFE_SB_Q_FULL_ERR_EID
```

Definition at line 261 of file cpu1\_platform\_cfg.h.

**12.23.2.114 CFE\_PLATFORM\_SB\_FILTERED\_EVENT5**

```
#define CFE_PLATFORM_SB_FILTERED_EVENT5 0
```

Definition at line 264 of file cpu1\_platform\_cfg.h.

**12.23.2.115 CFE\_PLATFORM\_SB\_FILTERED\_EVENT6**

```
#define CFE_PLATFORM_SB_FILTERED_EVENT6 0
```

Definition at line 267 of file cpu1\_platform\_cfg.h.

**12.23.2.116 CFE\_PLATFORM\_SB\_FILTERED\_EVENT7**

```
#define CFE_PLATFORM_SB_FILTERED_EVENT7 0
```

Definition at line 270 of file cpu1\_platform\_cfg.h.

**12.23.2.117 CFE\_PLATFORM\_SB\_FILTERED\_EVENT8**

```
#define CFE_PLATFORM_SB_FILTERED_EVENT8 0
```

Definition at line 273 of file cpu1\_platform\_cfg.h.

### 12.23.2.118 CFE\_PLATFORM\_SB\_HIGHEST\_VALID\_MSGID

```
#define CFE_PLATFORM_SB_HIGHEST_VALID_MSGID 0xFFFF
```

**Purpose** Highest Valid Message Id

#### Description:

The value of this constant dictates the range of valid message ID's, from 0 to CFE\_PLATFORM\_SB\_HIGHEST\_VALID\_MSGID (inclusive).

Although this can be defined differently across platforms, each platform can only publish/subscribe to message ids within their allowable range. Typically this value is set the same across all mission platforms to avoid this complexity.

#### Limits

CFE\_SB\_INVALID\_MSG is set to the maximum representable number of type [CFE\\_SB\\_MsgId\\_t](#). CFE\_PLATFORM\_SB\_HIGHEST\_VALID\_MSGID lower limit is 1, up to CFE\_SB\_INVALID\_MSG\_ID - 1.

When using the direct message map implementation for software bus routing, this value is used to size the map where a value of 0xFFFF results in a 16 KBytes map and 0xFFFF is 128 KBytes.

When using the hash implementation for software bus routing, a multiple of the CFE\_PLATFORM\_SB\_MAX\_MSG\_IDS is used to size the message map. In that case the range selected here does not impact message map memory use, so it's reasonable to use up to the full range supported by the message ID implementation.

Definition at line 179 of file cpu1\_platform\_cfg.h.

### 12.23.2.119 CFE\_PLATFORM\_SB\_MAX\_BLOCK\_SIZE

```
#define CFE_PLATFORM_SB_MAX_BLOCK_SIZE (CFE_MISSION_SB_MAX_SB_MSG_SIZE + 128)
```

Definition at line 303 of file cpu1\_platform\_cfg.h.

### 12.23.2.120 CFE\_PLATFORM\_SB\_MAX\_DEST\_PER\_PKT

```
#define CFE_PLATFORM_SB_MAX_DEST_PER_PKT 16
```

**Purpose** Maximum Number of unique local destinations a single MsgId can have

#### Description:

Dictates the maximum number of unique local destinations a single MsgId can have.

#### Limits

This parameter has a lower limit of 1. There are no restrictions on the upper limit however, the maximum number of destinations per packet is system dependent and should be verified. Destination number values that are checked against this configuration are defined by a 16 bit data word.

Definition at line 116 of file cpu1\_platform\_cfg.h.

### 12.23.2.121 CFE\_PLATFORM\_SB\_MAX\_MSG\_IDS

```
#define CFE_PLATFORM_SB_MAX_MSG_IDS 256
```

**Purpose** Maximum Number of Unique Message IDs SB Routing Table can hold

#### Description:

Dictates the maximum number of unique MsgIds the SB routing table will hold. This constant has a direct effect on the size of SB's tables and arrays. Keeping this count as low as possible will save memory. To see the run-time, high-water mark and the current utilization figures regarding this parameter, send an SB command to 'Send Statistics Pkt'.

#### Limits

This must be a power of two if software bus message routing hash implementation is being used. Lower than 64 will cause unit test failures, and telemetry reporting is impacted below 32. There is no hard upper limit, but impacts memory footprint. For software bus message routing search implementation the number of msg ids subscribed to impacts performance.

Definition at line 83 of file cpu1\_platform\_cfg.h.

### 12.23.2.122 CFE\_PLATFORM\_SB\_MAX\_PIPES

```
#define CFE_PLATFORM_SB_MAX_PIPES 64
```

**Purpose** Maximum Number of Unique Pipes SB Routing Table can hold

#### Description:

Dictates the maximum number of unique Pipes the SB routing table will hold. This constant has a direct effect on the size of SB's tables and arrays. Keeping this count as low as possible will save memory. To see the run-time, high-water mark and the current utilization figures regarding this parameter, send an SB command to 'Send Statistics Pkt'.

#### Limits

This parameter has a lower limit of 1. This parameter must also be less than or equal to OS\_MAX\_QUEUES.

Definition at line 100 of file cpu1\_platform\_cfg.h.

**12.23.2.123 CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_01**

```
#define CFE_PLATFORM_SB_MEM_BLOCK_SIZE_01 8
```

**Purpose** Define SB Memory Pool Block Sizes

**Description:**

Software Bus Memory Pool Block Sizes

**Limits**

These sizes MUST be increasing and MUST be an integral multiple of 4. The number of block sizes defined cannot exceed [CFE\\_PLATFORM\\_ES\\_POOL\\_MAX\\_BUCKETS](#)

Definition at line 287 of file cpu1\_platform\_cfg.h.

**12.23.2.124 CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_02**

```
#define CFE_PLATFORM_SB_MEM_BLOCK_SIZE_02 16
```

Definition at line 288 of file cpu1\_platform\_cfg.h.

**12.23.2.125 CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_03**

```
#define CFE_PLATFORM_SB_MEM_BLOCK_SIZE_03 20
```

Definition at line 289 of file cpu1\_platform\_cfg.h.

**12.23.2.126 CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_04**

```
#define CFE_PLATFORM_SB_MEM_BLOCK_SIZE_04 36
```

Definition at line 290 of file cpu1\_platform\_cfg.h.

**12.23.2.127 CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_05**

```
#define CFE_PLATFORM_SB_MEM_BLOCK_SIZE_05 64
```

Definition at line 291 of file cpu1\_platform\_cfg.h.

**12.23.2.128 CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_06**

```
#define CFE_PLATFORM_SB_MEM_BLOCK_SIZE_06 96
```

Definition at line 292 of file cpu1\_platform\_cfg.h.

**12.23.2.129 CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_07**

```
#define CFE_PLATFORM_SB_MEM_BLOCK_SIZE_07 128
```

Definition at line 293 of file cpu1\_platform\_cfg.h.

**12.23.2.130 CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_08**

```
#define CFE_PLATFORM_SB_MEM_BLOCK_SIZE_08 160
```

Definition at line 294 of file cpu1\_platform\_cfg.h.

**12.23.2.131 CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_09**

```
#define CFE_PLATFORM_SB_MEM_BLOCK_SIZE_09 256
```

Definition at line 295 of file cpu1\_platform\_cfg.h.

**12.23.2.132 CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_10**

```
#define CFE_PLATFORM_SB_MEM_BLOCK_SIZE_10 512
```

Definition at line 296 of file cpu1\_platform\_cfg.h.

**12.23.2.133 CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_11**

```
#define CFE_PLATFORM_SB_MEM_BLOCK_SIZE_11 1024
```

Definition at line 297 of file cpu1\_platform\_cfg.h.

**12.23.2.134 CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_12**

```
#define CFE_PLATFORM_SB_MEM_BLOCK_SIZE_12 2048
```

Definition at line 298 of file cpu1\_platform\_cfg.h.

**12.23.2.135 CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_13**

```
#define CFE_PLATFORM_SB_MEM_BLOCK_SIZE_13 4096
```

Definition at line 299 of file cpu1\_platform\_cfg.h.

**12.23.2.136 CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_14**

```
#define CFE_PLATFORM_SB_MEM_BLOCK_SIZE_14 8192
```

Definition at line 300 of file cpu1\_platform\_cfg.h.

**12.23.2.137 CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_15**

```
#define CFE_PLATFORM_SB_MEM_BLOCK_SIZE_15 16384
```

Definition at line 301 of file cpu1\_platform\_cfg.h.

**12.23.2.138 CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_16**

```
#define CFE_PLATFORM_SB_MEM_BLOCK_SIZE_16 32768
```

Definition at line 302 of file cpu1\_platform\_cfg.h.

**12.23.2.139 CFE\_PLATFORM\_SB\_START\_TASK\_PRIORITY**

```
#define CFE_PLATFORM_SB_START_TASK_PRIORITY 64
```

**Purpose** Define SB Task Priority

**Description:**

Defines the cFE\_SB Task priority.

**Limits**

Not Applicable

Definition at line 1099 of file cpu1\_platform\_cfg.h.

**12.23.2.140 CFE\_PLATFORM\_SB\_START\_TASK\_STACK\_SIZE**

```
#define CFE_PLATFORM_SB_START_TASK_STACK_SIZE CFE_PLATFORM_ES_DEFAULT_STACK_SIZE
```

**Purpose** Define SB Task Stack Size**Description:**

Defines the cFE\_SB Task Stack Size

**Limits**

There is a lower limit of 2048 on this configuration parameter. There are no restrictions on the upper limit however, the maximum stack size is system dependent and should be verified. Most operating systems provide tools for measuring the amount of stack used by a task during operation. It is always a good idea to verify that no more than 1/2 of the stack is used.

Definition at line 1114 of file cpu1\_platform\_cfg.h.

**12.23.2.141 CFE\_PLATFORM\_TBL\_BUF\_MEMORY\_BYTES**

```
#define CFE_PLATFORM_TBL_BUF_MEMORY_BYTES 524288
```

**Purpose** Size of Table Services Table Memory Pool**Description:**

Defines the TOTAL size of the memory pool that cFE Table Services allocates from the system. The size must be large enough to provide memory for each registered table, the inactive buffers for double buffered tables and for the shared inactive buffers for single buffered tables.

**Limits**

The cFE does not place a limit on the size of this parameter.

Definition at line 1479 of file cpu1\_platform\_cfg.h.

**12.23.2.142 CFE\_PLATFORM\_TBL\_DEFAULT\_REG\_DUMP\_FILE**

```
#define CFE_PLATFORM_TBL_DEFAULT_REG_DUMP_FILE "/ram/cfe_tbl_reg.log"
```

**Purpose** Default Filename for a Table Registry Dump**Description:**

Defines the file name used to store the table registry when no filename is specified in the dump registry command.

**Limits**

The length of each string, including the NULL terminator cannot exceed the [OS\\_MAX\\_PATH\\_LEN](#) value.

Definition at line 1593 of file cpu1\_platform\_cfg.h.

### 12.23.2.143 CFE\_PLATFORM\_TBL\_MAX\_CRITICAL\_TABLES

```
#define CFE_PLATFORM_TBL_MAX_CRITICAL_TABLES 32
```

**Purpose** Maximum Number of Critical Tables that can be Registered

**Description:**

Defines the maximum number of critical tables supported by this processor's Table Services.

**Limits**

This number must be less than 32767. It should be recognized that this parameter determines the size of the Critical Table Registry which is maintained in the Critical Data Store. An excessively high number will waste Critical Data Store memory. Therefore, this number must not exceed the value defined in CFE\_ES\_CDS\_MAX\_CRITICAL\_TABLES.

Definition at line 1534 of file cpu1\_platform\_cfg.h.

### 12.23.2.144 CFE\_PLATFORM\_TBL\_MAX\_DBL\_TABLE\_SIZE

```
#define CFE_PLATFORM_TBL_MAX_DBL_TABLE_SIZE 16384
```

**Purpose** Maximum Size Allowed for a Double Buffered Table

**Description:**

Defines the maximum allowed size (in bytes) of a double buffered table.

**Limits**

The cFE does not place a limit on the size of this parameter but it must be less than half of [CFE\\_PLATFORM\\_TBL\\_BUF\\_MEMORY\\_BYTES](#).

Definition at line 1491 of file cpu1\_platform\_cfg.h.

### 12.23.2.145 CFE\_PLATFORM\_TBL\_MAX\_NUM\_HANDLES

```
#define CFE_PLATFORM_TBL_MAX_NUM_HANDLES 256
```

**Purpose** Maximum Number of Table Handles

**Description:**

Defines the maximum number of Table Handles.

**Limits**

This number must be less than 32767. This number must be at least as big as the number of tables ([CFE\\_PLATFORM\\_TBL\\_MAX\\_NUM\\_TABLES](#)) and should be set higher if tables are shared between applications.

Definition at line 1547 of file cpu1\_platform\_cfg.h.

**12.23.2.146 CFE\_PLATFORM\_TBL\_MAX\_NUM\_TABLES**

```
#define CFE_PLATFORM_TBL_MAX_NUM_TABLES 128
```

**Purpose** Maximum Number of Tables Allowed to be Registered

**Description:**

Defines the maximum number of tables supported by this processor's Table Services.

**Limits**

This number must be less than 32767. It should be recognized that this parameter determines the size of the Table Registry. An excessively high number will waste memory.

Definition at line 1520 of file cpu1\_platform\_cfg.h.

**12.23.2.147 CFE\_PLATFORM\_TBL\_MAX\_NUM\_VALIDATIONS**

```
#define CFE_PLATFORM_TBL_MAX_NUM_VALIDATIONS 10
```

**Purpose** Maximum Number of Simultaneous Table Validations

**Description:**

Defines the maximum number of pending validations that the Table Services can handle at any one time. When a table has a validation function, a validation request is made of the application to perform that validation. This number determines how many of those requests can be outstanding at any one time.

**Limits**

This number must be less than 32767. An excessively high number will degrade system performance and waste memory. A number less than 20 is suggested but not required.

Definition at line 1580 of file cpu1\_platform\_cfg.h.

**12.23.2.148 CFE\_PLATFORM\_TBL\_MAX\_SIMULTANEOUS\_LOADS**

```
#define CFE_PLATFORM_TBL_MAX_SIMULTANEOUS_LOADS 4
```

**Purpose** Maximum Number of Simultaneous Loads to Support

**Description:**

Defines the maximum number of single buffered tables that can be loaded simultaneously. This number is used to determine the number of shared buffers to allocate.

**Limits**

This number must be less than 32767. An excessively high number will degrade system performance and waste memory. A number less than 5 is suggested but not required.

Definition at line 1562 of file cpu1\_platform\_cfg.h.

**12.23.2.149 CFE\_PLATFORM\_TBL\_MAX\_SNGL\_TABLE\_SIZE**

```
#define CFE_PLATFORM_TBL_MAX_SNGL_TABLE_SIZE 16384
```

**Purpose** Maximum Size Allowed for a Single Buffered Table

**Description:**

Defines the maximum allowed size (in bytes) of a single buffered table. **NOTE:** This size determines the size of all shared table buffers. Therefore, this size will be multiplied by [CFE\\_PLATFORM\\_TBL\\_MAX\\_SIMULTANEOUS\\_LOADS](#) below when allocating memory for shared tables.

**Limits**

The cFE does not place a limit on the size of this parameter but it must be small enough to allow for [CFE\\_PLATFORM\\_TBL\\_MAX\\_SIMULTANEOUS\\_LOADS](#) number of tables to fit into [CFE\\_PLATFORM\\_TBL\\_BUF\\_MEMORY\\_BYTES](#).

Definition at line 1507 of file cpu1\_platform\_cfg.h.

**12.23.2.150 CFE\_PLATFORM\_TBL\_START\_TASK\_PRIORITY**

```
#define CFE_PLATFORM_TBL_START_TASK_PRIORITY 70
```

**Purpose** Define TBL Task Priority

**Description:**

Defines the cFE\_TBL Task priority.

**Limits**

Not Applicable

Definition at line 1187 of file cpu1\_platform\_cfg.h.

**12.23.2.151 CFE\_PLATFORM\_TBL\_START\_TASK\_STACK\_SIZE**

```
#define CFE_PLATFORM_TBL_START_TASK_STACK_SIZE CFE_PLATFORM_ES_DEFAULT_STACK_SIZE
```

**Purpose** Define TBL Task Stack Size

**Description:**

Defines the cFE\_TBL Task Stack Size

**Limits**

There is a lower limit of 2048 on this configuration parameter. There are no restrictions on the upper limit however, the maximum stack size is system dependent and should be verified. Most operating systems provide tools for measuring the amount of stack used by a task during operation. It is always a good idea to verify that no more than 1/2 of the stack is used.

Definition at line 1202 of file cpu1\_platform\_cfg.h.

**12.23.2.152 CFE\_PLATFORM\_TBL\_U32FROM4CHARS**

```
#define CFE_PLATFORM_TBL_U32FROM4CHARS ( _C1, _C2, _C3, _C4 ) ((uint32) (_C1) << 24 | (uint32) (_C2) << 16 | (uint32) (_C3) << 8 | (uint32) (_C4))
```

Definition at line 1615 of file cpu1\_platform\_cfg.h.

**12.23.2.153 CFE\_PLATFORM\_TBL\_VALID\_PRID\_1**

```
#define CFE_PLATFORM_TBL_VALID_PRID_1 (1)
```

**Purpose** Processor ID values used for table load validation

**Description:**

Defines the processor ID values used for validating the processor ID field in the table file header. To be valid, the spacecraft ID specified in the table file header must match one of the values defined here.

**Limits**

This value can be any 32 bit unsigned integer.

Definition at line 1664 of file cpu1\_platform\_cfg.h.

**12.23.2.154 CFE\_PLATFORM\_TBL\_VALID\_PRID\_2**

```
#define CFE_PLATFORM_TBL_VALID_PRID_2 (CFE_PLATFORM_TBL_U32FROM4CHARS('a', 'b', 'c', 'd'))
```

Definition at line 1665 of file cpu1\_platform\_cfg.h.

**12.23.2.155 CFE\_PLATFORM\_TBL\_VALID\_PRID\_3**

```
#define CFE_PLATFORM_TBL_VALID_PRID_3 0
```

Definition at line 1666 of file cpu1\_platform\_cfg.h.

**12.23.2.156 CFE\_PLATFORM\_TBL\_VALID\_PRID\_4**

```
#define CFE_PLATFORM_TBL_VALID_PRID_4 0
```

Definition at line 1667 of file cpu1\_platform\_cfg.h.

**12.23.2.157 CFE\_PLATFORM\_TBL\_VALID\_PRID\_COUNT**

```
#define CFE_PLATFORM_TBL_VALID_PRID_COUNT 0
```

**Purpose** Number of Processor ID's specified for validation

**Description:**

Defines the number of specified processor ID values that are verified during table loads. If the number is zero then no validation of the processor ID field in the table file header is performed when tables are loaded. Non-zero values indicate how many values from the list of processor ID's defined below are compared to the processor ID field in the table file header. The ELF2CFETBL tool may be used to create table files with specified processor ID values.

**Limits**

This number must be greater than or equal to zero and less than or equal to 4.

Definition at line 1650 of file cpu1\_platform\_cfg.h.

**12.23.2.158 CFE\_PLATFORM\_TBL\_VALID\_SCID\_1**

```
#define CFE_PLATFORM_TBL_VALID_SCID_1 (0x42)
```

**Purpose** Spacecraft ID values used for table load validation

**Description:**

Defines the spacecraft ID values used for validating the spacecraft ID field in the table file header. To be valid, the spacecraft ID specified in the table file header must match one of the values defined here.

**Limits**

This value can be any 32 bit unsigned integer.

Definition at line 1630 of file cpu1\_platform\_cfg.h.

**12.23.2.159 CFE\_PLATFORM\_TBL\_VALID\_SCID\_2**

```
#define CFE_PLATFORM_TBL_VALID_SCID_2 (CFE_PLATFORM_TBL_U32FROM4CHARS('a', 'b', 'c', 'd'))
```

Definition at line 1631 of file cpu1\_platform\_cfg.h.

**12.23.2.160 CFE\_PLATFORM\_TBL\_VALID\_SCID\_COUNT**

```
#define CFE_PLATFORM_TBL_VALID_SCID_COUNT 0
```

**Purpose** Number of Spacecraft ID's specified for validation

**Description:**

Defines the number of specified spacecraft ID values that are verified during table loads. If the number is zero then no validation of the spacecraft ID field in the table file header is performed when tables are loaded. Non-zero values indicate how many values from the list of spacecraft ID's defined below are compared to the spacecraft ID field in the table file header. The ELF2CFETBL tool may be used to create table files with specified spacecraft ID values.

**Limits**

This number must be greater than or equal to zero and less than or equal to 2.

Definition at line 1612 of file cpu1\_platform\_cfg.h.

**12.23.2.161 CFE\_PLATFORM\_TIME\_1HZ\_TASK\_PRIORITY**

```
#define CFE_PLATFORM_TIME_1HZ_TASK_PRIORITY 25
```

Definition at line 1157 of file cpu1\_platform\_cfg.h.

**12.23.2.162 CFE\_PLATFORM\_TIME\_1HZ\_TASK\_STACK\_SIZE**

```
#define CFE_PLATFORM_TIME_1HZ_TASK_STACK_SIZE 8192
```

Definition at line 1176 of file cpu1\_platform\_cfg.h.

**12.23.2.163 CFE\_PLATFORM\_TIME\_CFG\_CLIENT**

```
#define CFE_PLATFORM_TIME_CFG_CLIENT false
```

Definition at line 318 of file cpu1\_platform\_cfg.h.

**12.23.2.164 CFE\_PLATFORM\_TIME\_CFG\_LATCH\_FLY**

```
#define CFE_PLATFORM_TIME_CFG_LATCH_FLY 8
```

**Purpose** Define Periodic Time to Update Local Clock Tone Latch

**Description:**

Define Periodic Time to Update Local Clock Tone Latch. Applies only when in flywheel mode. This define dictates the period at which the simulated 'last tone' time is updated. Units are seconds.

**Limits**

Not Applicable

Definition at line 475 of file cpu1\_platform\_cfg.h.

**12.23.2.165 CFE\_PLATFORM\_TIME\_CFG\_SERVER**

```
#define CFE_PLATFORM_TIME_CFG_SERVER true
```

**Purpose** Time Server or Time Client Selection

**Description:**

This configuration parameter selects whether the Time task functions as a time "server" or "client". A time server generates the "time at the tone" packet which is received by time clients.

**Limits**

Enable one, and only one by defining either CFE\_PLATFORM\_TIME\_CFG\_SERVER or CFE\_PLATFORM\_TIME\_CFG\_CLIENT AS true. The other must be defined as false.

Definition at line 317 of file cpu1\_platform\_cfg.h.

**12.23.2.166 CFE\_PLATFORM\_TIME\_CFG\_SIGNAL**

```
#define CFE_PLATFORM_TIME_CFG_SIGNAL false
```

**Purpose** Include or Exclude the Primary/Redundant Tone Selection Cmd

**Description:**

Depending on the specific hardware system configuration, it may be possible to switch between a primary and redundant tone signal. If supported by hardware, this definition will enable command interfaces to select the active tone signal. Both Time Clients and Time Servers support this feature. Note: Set the CFE\_PLATFORM\_TIME\_CFG\_SIGNAL define to true to enable tone signal commands.

**Limits**

Not Applicable

Definition at line 365 of file cpu1\_platform\_cfg.h.

**12.23.2.167 CFE\_PLATFORM\_TIME\_CFG\_SOURCE**

```
#define CFE_PLATFORM_TIME_CFG_SOURCE false
```

**Purpose** Include or Exclude the Internal/External Time Source Selection Cmd

**Description:**

By default, Time Servers maintain time using an internal MET which may be a h/w register or software counter, depending on available hardware. The following definition enables command interfaces to switch between an internal MET, or external time data received from one of several supported external time sources. Only a Time Server may be configured to use external time data. Note: Set the CFE\_PLATFORM\_TIME\_CFG\_SOURCE define to true to include the Time Source Selection Command (command allows selection between the internal or external time source). Then choose the external source with the CFE\_TIME\_CFG\_SRC\_??? define.

**Limits**

Only applies if [CFE\\_PLATFORM\\_TIME\\_CFG\\_SERVER](#) is set to true.

Definition at line 385 of file [cpu1\\_platform\\_cfg.h](#).

**12.23.2.168 CFE\_PLATFORM\_TIME\_CFG\_SRC\_GPS**

```
#define CFE_PLATFORM_TIME_CFG_SRC_GPS false
```

Definition at line 402 of file [cpu1\\_platform\\_cfg.h](#).

**12.23.2.169 CFE\_PLATFORM\_TIME\_CFG\_SRC\_MET**

```
#define CFE_PLATFORM_TIME_CFG_SRC_MET false
```

**Purpose** Choose the External Time Source for Server only

**Description:**

If [CFE\\_PLATFORM\\_TIME\\_CFG\\_SOURCE](#) is set to true, then one of the following external time source types must also be set to true. Do not set any of the external time source types to true unless [CFE\\_PLATFORM\\_TIME\\_CFG\\_SOURCE](#) is set to true.

**Limits**

1. If [CFE\\_PLATFORM\\_TIME\\_CFG\\_SOURCE](#) is set to true then one and only one of the following three external time sources can and must be set true: [CFE\\_PLATFORM\\_TIME\\_CFG\\_SRC\\_MET](#), [CFE\\_PLATFORM\\_TIME\\_CFG\\_SRC\\_GPS](#), [CFE\\_PLATFORM\\_TIME\\_CFG\\_SRC\\_TIME](#)
2. Only applies if [CFE\\_PLATFORM\\_TIME\\_CFG\\_SERVER](#) is set to true.

Definition at line 401 of file [cpu1\\_platform\\_cfg.h](#).

**12.23.2.170 CFE\_PLATFORM\_TIME\_CFG\_SRC\_TIME**

```
#define CFE_PLATFORM_TIME_CFG_SRC_TIME false
```

Definition at line 403 of file cpu1\_platform\_cfg.h.

**12.23.2.171 CFE\_PLATFORM\_TIME\_CFG\_START\_FLY**

```
#define CFE_PLATFORM_TIME_CFG_START_FLY 2
```

**Purpose** Define Time to Start Flywheel Since Last Tone

**Description:**

Define time to enter flywheel mode (in seconds since last tone data update) Units are microseconds as measured with the local clock.

**Limits**

Not Applicable

Definition at line 462 of file cpu1\_platform\_cfg.h.

**12.23.2.172 CFE\_PLATFORM\_TIME\_CFG\_TONE\_LIMIT**

```
#define CFE_PLATFORM_TIME_CFG_TONE_LIMIT 20000
```

**Purpose** Define Timing Limits From One Tone To The Next

**Description:**

Defines limits to the timing of the 1Hz tone signal. A tone signal is valid only if it arrives within one second (plus or minus the tone limit) from the previous tone signal.Units are microseconds as measured with the local clock.

**Limits**

Not Applicable

Definition at line 450 of file cpu1\_platform\_cfg.h.

### 12.23.2.173 CFE\_PLATFORM\_TIME\_CFG\_VIRTUAL

```
#define CFE_PLATFORM_TIME_CFG_VIRTUAL true
```

**Purpose** Time Tone In Big-Endian Order

**Description:**

If this configuration parameter is defined, the CFE time server will publish time tones with payloads in big-endian order, and time clients will expect the tones to be in big-endian order. This is useful for mixed-endian environments. This will become obsolete once EDS is available and the CFE time tone message is defined.

**Purpose** Local MET or Virtual MET Selection for Time Servers

**Description:**

Depending on the specific hardware system configuration, it may be possible for Time Servers to read the "local" MET from a h/w register rather than having to track the MET as the count of tone signal interrupts (virtual MET)

Time Clients must be defined as using a virtual MET. Also, a Time Server cannot be defined as having both a h/w MET and an external time source (they both cannot synchronize to the same tone).

Note: "disable" this define (set to false) only for Time Servers with local hardware that supports a h/w MET that is synchronized to the tone signal !!!

**Limits**

Only applies if [CFE\\_PLATFORM\\_TIME\\_CFG\\_SERVER](#) is set to true.

Definition at line 350 of file cpu1\_platform\_cfg.h.

### 12.23.2.174 CFE\_PLATFORM\_TIME\_MAX\_DELTA\_SECS

```
#define CFE_PLATFORM_TIME_MAX_DELTA_SECS 0
```

**Purpose** Define the Max Delta Limits for Time Servers using an Ext Time Source

**Description:**

If [CFE\\_PLATFORM\\_TIME\\_CFG\\_SOURCE](#) is set to true and one of the external time sources is also set to true, then the delta time limits for range checking is used.

When a new time value is received from an external source, the value is compared against the "expected" time value. If the delta exceeds the following defined amount, then the new time data will be ignored. This range checking is only performed after the clock state has been commanded to "valid". Until then, external time data is accepted unconditionally.

**Limits**

Applies only if both [CFE\\_PLATFORM\\_TIME\\_CFG\\_SERVER](#) and [CFE\\_PLATFORM\\_TIME\\_CFG\\_SOURCE](#) are set to true.

Definition at line 422 of file cpu1\_platform\_cfg.h.

**12.23.2.175 CFE\_PLATFORM\_TIME\_MAX\_DELTA\_SUBS**

```
#define CFE_PLATFORM_TIME_MAX_DELTA_SUBS 500000
```

Definition at line 423 of file cpu1\_platform\_cfg.h.

**12.23.2.176 CFE\_PLATFORM\_TIME\_MAX\_LOCAL\_SECS**

```
#define CFE_PLATFORM_TIME_MAX_LOCAL_SECS 27
```

**Purpose** Define the Local Clock Rollover Value in seconds and subseconds

**Description:**

Specifies the capability of the local clock. Indicates the time at which the local clock rolls over.

**Limits**

Not Applicable

Definition at line 435 of file cpu1\_platform\_cfg.h.

**12.23.2.177 CFE\_PLATFORM\_TIME\_MAX\_LOCAL\_SUBS**

```
#define CFE_PLATFORM_TIME_MAX_LOCAL_SUBS 0
```

Definition at line 436 of file cpu1\_platform\_cfg.h.

**12.23.2.178 CFE\_PLATFORM\_TIME\_START\_TASK\_PRIORITY**

```
#define CFE_PLATFORM_TIME_START_TASK_PRIORITY 60
```

**Purpose** Define TIME Task Priorities

**Description:**

Defines the cFE\_TIME Task priority. Defines the cFE\_TIME Tone Task priority. Defines the cFE\_TIME 1HZ Task priority.

**Limits**

There is a lower limit of zero and an upper limit of 255 on these configuration parameters. Remember that the meaning of each task priority is inverted – a "lower" number has a "higher" priority.

Definition at line 1155 of file cpu1\_platform\_cfg.h.

### 12.23.2.179 CFE\_PLATFORM\_TIME\_START\_TASK\_STACK\_SIZE

```
#define CFE_PLATFORM_TIME_START_TASK_STACK_SIZE CFE_PLATFORM_ES_DEFAULT_STACK_SIZE
```

**Purpose** Define TIME Task Stack Sizes

#### Description:

Defines the cFE\_TIME Main Task Stack Size  
 Defines the cFE\_TIME Tone Task Stack Size  
 Defines the cFE\_TIME 1HZ Task Stack Size

#### Limits

There is a lower limit of 2048 on these configuration parameters. There are no restrictions on the upper limit however, the maximum stack size is system dependent and should be verified. Most operating systems provide tools for measuring the amount of stack used by a task during operation. It is always a good idea to verify that no more than 1/2 of the stack is used.

Definition at line 1174 of file cpu1\_platform\_cfg.h.

### 12.23.2.180 CFE\_PLATFORM\_TIME\_TONE\_TASK\_PRIORITY

```
#define CFE_PLATFORM_TIME_TONE_TASK_PRIORITY 25
```

Definition at line 1156 of file cpu1\_platform\_cfg.h.

### 12.23.2.181 CFE\_PLATFORM\_TIME\_TONE\_TASK\_STACK\_SIZE

```
#define CFE_PLATFORM_TIME_TONE_TASK_STACK_SIZE 4096
```

Definition at line 1175 of file cpu1\_platform\_cfg.h.

## 12.24 cfe/cmake/sample\_defs/sample\_mission\_cfg.h File Reference

#### Macros

- #define CFE\_MISSION\_SB\_MAX\_SB\_MSG\_SIZE 32768
- #define CFE\_MISSION\_TIME\_CFG\_DEFAULT\_TAI true
- #define CFE\_MISSION\_TIME\_CFG\_DEFAULT\_UTC false
- #define CFE\_MISSION\_TIME\_CFG\_FAKE\_TONE true
- #define CFE\_MISSION\_TIME\_AT\_TONE\_WAS true
- #define CFE\_MISSION\_TIME\_AT\_TONE\_WILL\_BE false
- #define CFE\_MISSION\_TIME\_MIN\_ELAPSED 0
- #define CFE\_MISSION\_TIME\_MAX\_ELAPSED 200000
- #define CFE\_MISSION\_TIME\_DEF\_MET\_SECS 1000

- #define CFE\_MISSION\_TIME\_DEF\_MET\_SUBS 0
- #define CFE\_MISSION\_TIME\_DEF\_STCF\_SECS 1000000
- #define CFE\_MISSION\_TIME\_DEF\_STCF\_SUBS 0
- #define CFE\_MISSION\_TIME\_DEF\_LEAPS 37
- #define CFE\_MISSION\_TIME\_DEF\_DELAY\_SECS 0
- #define CFE\_MISSION\_TIME\_DEF\_DELAY\_SUBS 1000
- #define CFE\_MISSION\_TIME\_EPOCH\_YEAR 1980
- #define CFE\_MISSION\_TIME\_EPOCH\_DAY 1
- #define CFE\_MISSION\_TIME\_EPOCH\_HOUR 0
- #define CFE\_MISSION\_TIME\_EPOCH\_MINUTE 0
- #define CFE\_MISSION\_TIME\_EPOCH\_SECOND 0
- #define CFE\_MISSION\_TIME\_EPOCH\_MICROS 0
- #define CFE\_MISSION\_TIME\_FS\_FACTOR 789004800
- #define CFE\_MISSION\_ES\_CDS\_MAX\_NAME\_LENGTH 16
- #define CFE\_MISSION\_ES\_MAX\_MESSAGE\_LENGTH 122
- #define CFE\_MISSION\_ES\_DEFAULT\_CRC CFE\_MISSION\_ES\_CRC\_16
- #define CFE\_MISSION\_TBL\_MAX\_NAME\_LENGTH 16
- #define CFE\_MISSION\_ES\_CMD\_MSG 1
- #define CFE\_MISSION\_TEST\_CMD\_MSG 2
- #define CFE\_MISSION\_SB\_CMD\_MSG 3
- #define CFE\_MISSION\_TBL\_CMD\_MSG 4
- #define CFE\_MISSION\_TIME\_CMD\_MSG 5
- #define CFE\_MISSION\_ES\_CMD\_MSG 6
- #define CFE\_MISSION\_ES\_SEND\_HK\_MSG 8
- #define CFE\_MISSION\_ES\_SEND\_HK\_MSG 9
- #define CFE\_MISSION\_SB\_SEND\_HK\_MSG 11
- #define CFE\_MISSION\_TBL\_SEND\_HK\_MSG 12
- #define CFE\_MISSION\_TIME\_SEND\_HK\_MSG 13
- #define CFE\_MISSION\_SB\_SUB\_RPT\_CTRL\_MSG 14
- #define CFE\_MISSION\_TIME\_TONE\_CMD\_MSG 16
- #define CFE\_MISSION\_TIME\_1HZ\_CMD\_MSG 17
- #define CFE\_MISSION\_TIME\_DATA\_CMD\_MSG 0
- #define CFE\_MISSION\_TIME\_SEND\_CMD\_MSG 2
- #define CFE\_MISSION\_ES\_HK\_TLM\_MSG 0
- #define CFE\_MISSION\_ES\_HK\_TLM\_MSG 1
- #define CFE\_MISSION\_TEST\_HK\_TLM\_MSG 2
- #define CFE\_MISSION\_SB\_HK\_TLM\_MSG 3
- #define CFE\_MISSION\_TBL\_HK\_TLM\_MSG 4
- #define CFE\_MISSION\_TIME\_HK\_TLM\_MSG 5
- #define CFE\_MISSION\_TIME\_DIAG\_TLM\_MSG 6
- #define CFE\_MISSION\_ES\_LONG\_EVENT\_MSG\_MSG 8
- #define CFE\_MISSION\_ES\_SHORT\_EVENT\_MSG\_MSG 9
- #define CFE\_MISSION\_SB\_STATS\_TLM\_MSG 10
- #define CFE\_MISSION\_ES\_APP\_TLM\_MSG 11
- #define CFE\_MISSION\_TBL\_REG\_TLM\_MSG 12
- #define CFE\_MISSION\_SB\_ALLSUBS\_TLM\_MSG 13
- #define CFE\_MISSION\_SB\_ONESUB\_TLM\_MSG 14
- #define CFE\_MISSION\_ES\_MEMSTATS\_TLM\_MSG 16
- #define CFE\_MISSION\_ES\_MAX\_APPLICATIONS 16
- #define CFE\_MISSION\_ES\_PERF\_MAX\_IDS 128
- #define CFE\_MISSION\_ES\_POOL\_MAX\_BUCKETS 17

- #define CFE\_MISSION\_TBL\_MAX\_FULL\_NAME\_LEN (CFE\_MISSION\_TBL\_MAX\_NAME\_LENGTH + CFE\_MISSION\_MAX\_API\_LEN + 4)
- #define CFE\_MISSION\_SB\_MAX\_PIPES 64
- #define CFE\_MISSION\_MAX\_PATH\_LEN 64
- #define CFE\_MISSION\_MAX\_FILE\_LEN 20
- #define CFE\_MISSION\_MAX\_API\_LEN 20
- #define CFE\_MISSION\_ES\_CDS\_MAX\_FULL\_NAME\_LEN (CFE\_MISSION\_ES\_CDS\_MAX\_NAME\_LENGTH + CFE\_MISSION\_MAX\_API\_LEN + 4)

### Checksum/CRC algorithm identifiers

- #define CFE\_MISSION\_ES\_CRC\_8 1  
*CRC ( 8 bit additive - returns 32 bit total) (Currently not implemented)*
- #define CFE\_MISSION\_ES\_CRC\_16 2  
*CRC (16 bit additive - returns 32 bit total)*
- #define CFE\_MISSION\_ES\_CRC\_32 3  
*CRC (32 bit additive - returns 32 bit total) (Currently not implemented) .*

#### 12.24.1 Detailed Description

Purpose: This header file contains the mission configuration parameters and typedefs with mission scope.

Notes: The impact of changing these configurations from their default value is not yet documented. Changing these values may impact the performance and functionality of the system.

Author: R.McGraw/SSI

#### 12.24.2 Macro Definition Documentation

##### 12.24.2.1 CFE\_MISSION\_ES\_APP\_TLM\_MSG

```
#define CFE_MISSION_ES_APP_TLM_MSG 11
```

Definition at line 366 of file sample\_mission\_cfg.h.

### 12.24.2.2 CFE\_MISSION\_ES\_CDS\_MAX\_FULL\_NAME\_LEN

```
#define CFE_MISSION_ES_CDS_MAX_FULL_NAME_LEN (CFE_MISSION_ES_CDS_MAX_NAME_LENGTH + CFE_MISSION_M->  
AX_API_LEN + 4)
```

**Purpose** Maximum Length of Full CDS Name in messages

#### Description:

Indicates the maximum length (in characters) of the entire CDS name of the following form: "ApplicationName.C->DSName"

This affects the layout of command/telemetry messages but does not affect run time behavior or internal allocation.

#### Limits

All CPUs within the same SB domain (mission) must share the same definition Note this affects the size of messages, so it must not cause any message to exceed the max length.

This value should be kept as a multiple of 4, to maintain alignment of any possible neighboring fields without implicit padding.

Definition at line 561 of file sample\_mission\_cfg.h.

### 12.24.2.3 CFE\_MISSION\_ES\_CDS\_MAX\_NAME\_LENGTH

```
#define CFE_MISSION_ES_CDS_MAX_NAME_LENGTH 16
```

**Purpose** Maximum Length of CDS Name

#### Description:

Indicates the maximum length (in characters) of the CDS name ('CDSName') portion of a Full CDS Name of the following form: "ApplicationName.CDSName"

This length does not need to include an extra character for NULL termination.

#### Limits

This value should be kept as a multiple of 4, to maintain alignment of any possible neighboring fields without implicit padding.

Definition at line 245 of file sample\_mission\_cfg.h.

#### 12.24.2.4 CFE\_MISSION\_ES\_CMD\_MSG

```
#define CFE_MISSION_ES_CMD_MSG 6
```

Definition at line 316 of file sample\_mission\_cfg.h.

#### 12.24.2.5 CFE\_MISSION\_ES\_CRC\_16

```
#define CFE_MISSION_ES_CRC_16 2
```

CRC (16 bit additive - returns 32 bit total)

Definition at line 264 of file sample\_mission\_cfg.h.

#### 12.24.2.6 CFE\_MISSION\_ES\_CRC\_32

```
#define CFE_MISSION_ES_CRC_32 3
```

CRC (32 bit additive - returns 32 bit total) (Currently not implemented) .

Definition at line 265 of file sample\_mission\_cfg.h.

#### 12.24.2.7 CFE\_MISSION\_ES\_CRC\_8

```
#define CFE_MISSION_ES_CRC_8 1
```

CRC ( 8 bit additive - returns 32 bit total) (Currently not implemented)

Definition at line 263 of file sample\_mission\_cfg.h.

#### 12.24.2.8 CFE\_MISSION\_ES\_DEFAULT\_CRC

```
#define CFE_MISSION_ES_DEFAULT_CRC CFE_MISSION_ES_CRC_16
```

**Purpose** Mission Default CRC algorithm

##### Description:

Indicates the which CRC algorithm should be used as the default for verifying the contents of Critical Data Stores and when calculating Table Image data integrity values.

##### Limits

Currently only CFE\_MISSION\_ES\_CRC\_16 is supported (see [CFE\\_MISSION\\_ES\\_CRC\\_16](#))

Definition at line 282 of file sample\_mission\_cfg.h.

**12.24.2.9 CFE\_MISSION\_ES\_HK\_TLM\_MSG**

```
#define CFE_MISSION_ES_HK_TLM_MSG 0
```

**Purpose** cFE Portable Message Numbers for Telemetry

**Description:**

Portable message numbers for the cFE telemetry messages NOTE: cFE MsgIds are the sum of the base numbers and the portable msg numbers.

**Limits**

Not Applicable

Definition at line 355 of file sample\_mission\_cfg.h.

**12.24.2.10 CFE\_MISSION\_ES\_MAX\_APPLICATIONS**

```
#define CFE_MISSION_ES_MAX_APPLICATIONS 16
```

**Purpose** Mission Max Apps in a message

**Description:**

Indicates the maximum number of apps in a telemetry housekeeping message

This affects the layout of command/telemetry messages but does not affect run time behavior or internal allocation.

**Limits**

All CPUs within the same SB domain (mission) must share the same definition Note this affects the size of messages, so it must not cause any message to exceed the max length.

Definition at line 386 of file sample\_mission\_cfg.h.

**12.24.2.11 CFE\_MISSION\_ES\_MEMSTATS\_TLM\_MSG**

```
#define CFE_MISSION_ES_MEMSTATS_TLM_MSG 16
```

Definition at line 370 of file sample\_mission\_cfg.h.

### 12.24.2.12 CFE\_MISSION\_ES\_PERF\_MAX\_IDS

```
#define CFE_MISSION_ES_PERF_MAX_IDS 128
```

**Purpose** Define Max Number of Performance IDs for messages

**Description:**

Defines the maximum number of perf ids allowed in command/telemetry messages

This affects the layout of command/telemetry messages but does not affect run time behavior or internal allocation.

**Limits**

All CPUs within the same SB domain (mission) must share the same definition Note this affects the size of messages, so it must not cause any message to exceed the max length.

Definition at line 403 of file sample\_mission\_cfg.h.

### 12.24.2.13 CFE\_MISSION\_ES\_POOL\_MAX\_BUCKETS

```
#define CFE_MISSION_ES_POOL_MAX_BUCKETS 17
```

**Purpose** Maximum number of block sizes in pool structures

**Description:**

The upper limit for the number of block sizes supported in the generic pool implementation, which in turn implements the memory pools and CDS. This definition is used as the array size with the pool stats structure, and therefore should be consistent across all CPUs in a mission, as well as with the ground station.

There is also a platform-specific limit which may be fewer than this value.

**Limits:**

Must be at least one. No specific upper limit, but the number is anticipated to be reasonably small (i.e. tens, not hundreds). Large values have not been tested.

Definition at line 424 of file sample\_mission\_cfg.h.

**12.24.2.14 CFE\_MISSION\_ES\_SEND\_HK\_MSG**

```
#define CFE_MISSION_ES_SEND_HK_MSG 8
```

Definition at line 318 of file sample\_mission\_cfg.h.

**12.24.2.15 CFE\_MISSION\_EVS\_CMD\_MSG**

```
#define CFE_MISSION_EVS_CMD_MSG 1
```

**Purpose** cFE Portable Message Numbers for Commands

**Description:**

Portable message numbers for the cFE command messages NOTE: cFE MsgIds are the sum of the base numbers and the portable msg numbers.

**Limits**

Not Applicable

Definition at line 311 of file sample\_mission\_cfg.h.

**12.24.2.16 CFE\_MISSION\_EVS\_HK\_TLM\_MSG**

```
#define CFE_MISSION_EVS_HK_TLM_MSG 1
```

Definition at line 356 of file sample\_mission\_cfg.h.

**12.24.2.17 CFE\_MISSION\_EVS\_LONG\_EVENT\_MSG\_MSG**

```
#define CFE_MISSION_EVS_LONG_EVENT_MSG_MSG 8
```

Definition at line 363 of file sample\_mission\_cfg.h.

#### 12.24.2.18 CFE\_MISSION\_EVS\_MAX\_MESSAGE\_LENGTH

```
#define CFE_MISSION_EVS_MAX_MESSAGE_LENGTH 122
```

**Purpose** Maximum Event Message Length

Description:

Indicates the maximum length (in characters) of the formatted text string portion of an event message

This length does not need to include an extra character for NULL termination.

Limits

Not Applicable

Definition at line 259 of file sample\_mission\_cfg.h.

#### 12.24.2.19 CFE\_MISSION\_EVS\_SEND\_HK\_MSG

```
#define CFE_MISSION_EVS_SEND_HK_MSG 9
```

Definition at line 319 of file sample\_mission\_cfg.h.

#### 12.24.2.20 CFE\_MISSION\_EVS\_SHORT\_EVENT\_MSG\_MSG

```
#define CFE_MISSION_EVS_SHORT_EVENT_MSG_MSG 9
```

Definition at line 364 of file sample\_mission\_cfg.h.

#### 12.24.2.21 CFE\_MISSION\_MAX\_API\_LEN

```
#define CFE_MISSION_MAX_API_LEN 20
```

**Purpose** cFE Maximum length for API names within data exchange structures

Description:

The value of this constant dictates the size of filenames within all structures used for external data exchange, such as Software bus messages and table definitions. This is typically the same as OS\_MAX\_API\_LEN but that is OSAL dependent – and as such it definable on a per-processor/OS basis and hence may be different across multiple processors. It is recommended to set this to the value of the largest OS\_MAX\_API\_LEN in use on any CPU on the mission.

This affects only the layout of command/telemetry messages and table definitions; internal allocation may use the platform-specific OS\_MAX\_API\_LEN value.

This length must include an extra character for NULL termination.

Limits

All CPUs within the same SB domain (mission) must share the same definition Note this affects the size of messages, so it must not cause any message to exceed the max length.

This value should be kept as a multiple of 4, to maintain alignment of any possible neighboring fields without implicit padding.

Definition at line 541 of file sample\_mission\_cfg.h.

#### 12.24.2.22 CFE\_MISSION\_MAX\_FILE\_LEN

```
#define CFE_MISSION_MAX_FILE_LEN 20
```

**Purpose** cFE Maximum length for filenames within data exchange structures

##### Description:

The value of this constant dictates the size of filenames within all structures used for external data exchange, such as Software bus messages and table definitions. This is typically the same as OS\_MAX\_FILE\_LEN but that is OSAL dependent – and as such it definable on a per-processor/OS basis and hence may be different across multiple processors. It is recommended to set this to the value of the largest OS\_MAX\_FILE\_LEN in use on any CPU on the mission.

This affects only the layout of command/telemetry messages and table definitions; internal allocation may use the platform-specific OS\_MAX\_FILE\_LEN value.

This length must include an extra character for NULL termination.

##### Limits

All CPUs within the same SB domain (mission) and ground tools must share the same definition. Note this affects the size of messages, so it must not cause any message to exceed the max length.

This value should be kept as a multiple of 4, to maintain alignment of any possible neighboring fields without implicit padding.

Definition at line 515 of file sample\_mission\_cfg.h.

#### 12.24.2.23 CFE\_MISSION\_MAX\_PATH\_LEN

```
#define CFE_MISSION_MAX_PATH_LEN 64
```

**Purpose** cFE Maximum length for pathnames within data exchange structures

##### Description:

The value of this constant dictates the size of pathnames within all structures used for external data exchange, such as Software bus messages and table definitions. This is typically the same as OS\_MAX\_PATH\_LEN but that is OSAL dependent – and as such it definable on a per-processor/OS basis and hence may be different across multiple processors. It is recommended to set this to the value of the largest OS\_MAX\_PATH\_LEN in use on any CPU on the mission.

This affects only the layout of command/telemetry messages and table definitions; internal allocation may use the platform-specific OS\_MAX\_PATH\_LEN value.

This length must include an extra character for NULL termination.

##### Limits

All CPUs within the same SB domain (mission) and ground tools must share the same definition. Note this affects the size of messages, so it must not cause any message to exceed the max length.

This value should be kept as a multiple of 4, to maintain alignment of any possible neighboring fields without implicit padding.

Definition at line 488 of file sample\_mission\_cfg.h.

**12.24.2.24 CFE\_MISSION\_SB\_ALLSUBS\_TLM\_MSG**

```
#define CFE_MISSION_SB_ALLSUBS_TLM_MSG 13
```

Definition at line 368 of file sample\_mission\_cfg.h.

**12.24.2.25 CFE\_MISSION\_SB\_CMD\_MSG**

```
#define CFE_MISSION_SB_CMD_MSG 3
```

Definition at line 313 of file sample\_mission\_cfg.h.

**12.24.2.26 CFE\_MISSION\_SB\_HK\_TLM\_MSG**

```
#define CFE_MISSION_SB_HK_TLM_MSG 3
```

Definition at line 358 of file sample\_mission\_cfg.h.

**12.24.2.27 CFE\_MISSION\_SB\_MAX\_PIPES**

```
#define CFE_MISSION_SB_MAX_PIPES 64
```

**Purpose** Maximum Number of pipes that SB command/telemetry messages may hold

**Description:**

Dictates the maximum number of unique Pipes the SB message definitions will hold.

This affects the layout of command/telemetry messages but does not affect run time behavior or internal allocation.

**Limits**

All CPUs within the same SB domain (mission) must share the same definition Note this affects the size of messages, so it must not cause any message to exceed the max length.

Definition at line 461 of file sample\_mission\_cfg.h.

**12.24.2.28 CFE\_MISSION\_SB\_MAX\_SB\_MSG\_SIZE**

```
#define CFE_MISSION_SB_MAX_SB_MSG_SIZE 32768
```

**Purpose** Maximum SB Message Size

**Description:**

The following definition dictates the maximum message size allowed on the software bus. SB checks the pkt length field in the header of all messages sent. If the pkt length field indicates the message is larger than this define, SB sends an event and rejects the send.

**Limits**

This parameter has a lower limit of 6 (CCSDS primary header size). There are no restrictions on the upper limit however, the maximum message size is system dependent and should be verified. Total message size values that are checked against this configuration are defined by a 16 bit data word.

Definition at line 53 of file sample\_mission\_cfg.h.

**12.24.2.29 CFE\_MISSION\_SB\_ONESUB\_TLM\_MSG**

```
#define CFE_MISSION_SB_ONESUB_TLM_MSG 14
```

Definition at line 369 of file sample\_mission\_cfg.h.

**12.24.2.30 CFE\_MISSION\_SB\_SEND\_HK\_MSG**

```
#define CFE_MISSION_SB_SEND_HK_MSG 11
```

Definition at line 321 of file sample\_mission\_cfg.h.

**12.24.2.31 CFE\_MISSION\_SB\_STATS\_TLM\_MSG**

```
#define CFE_MISSION_SB_STATS_TLM_MSG 10
```

Definition at line 365 of file sample\_mission\_cfg.h.

**12.24.2.32 CFE\_MISSION\_SB\_SUB\_RPT\_CTRL\_MSG**

```
#define CFE_MISSION_SB_SUB_RPT_CTRL_MSG 14
```

Definition at line 325 of file sample\_mission\_cfg.h.

**12.24.2.33 CFE\_MISSION\_TBL\_CMD\_MSG**

```
#define CFE_MISSION_TBL_CMD_MSG 4
```

Definition at line 314 of file sample\_mission\_cfg.h.

**12.24.2.34 CFE\_MISSION\_TBL\_HK\_TLM\_MSG**

```
#define CFE_MISSION_TBL_HK_TLM_MSG 4
```

Definition at line 359 of file sample\_mission\_cfg.h.

**12.24.2.35 CFE\_MISSION\_TBL\_MAX\_FULL\_NAME\_LEN**

```
#define CFE_MISSION_TBL_MAX_FULL_NAME_LEN (CFE_MISSION_TBL_MAX_NAME_LENGTH + CFE_MISSION_MAX_API←  
_LEN + 4)
```

**Purpose** Maximum Length of Full Table Name in messages

**Description:**

Indicates the maximum length (in characters) of the entire table name within software bus messages, in "App←Name.TableName" notation.

This affects the layout of command/telemetry messages but does not affect run time behavior or internal allocation.

**Limits**

All CPUs within the same SB domain (mission) must share the same definition Note this affects the size of messages, so it must not cause any message to exceed the max length.

This value should be kept as a multiple of 4, to maintain alignment of any possible neighboring fields without implicit padding.

Definition at line 444 of file sample\_mission\_cfg.h.

**12.24.2.36 CFE\_MISSION\_TBL\_MAX\_NAME\_LENGTH**

```
#define CFE_MISSION_TBL_MAX_NAME_LENGTH 16
```

**Purpose** Maximum Table Name Length

**Description:**

Indicates the maximum length (in characters) of the table name ('TblName') portion of a Full Table Name of the following form: "ApplicationName.TblName"

This length does not need to include an extra character for NULL termination.

**Limits**

This value should be kept as a multiple of 4, to maintain alignment of any possible neighboring fields without implicit padding.

Definition at line 298 of file sample\_mission\_cfg.h.

Referenced by DS\_AppProcessHK().

**12.24.2.37 CFE\_MISSION\_TBL\_REG\_TLM\_MSG**

```
#define CFE_MISSION_TBL_REG_TLM_MSG 12
```

Definition at line 367 of file sample\_mission\_cfg.h.

**12.24.2.38 CFE\_MISSION\_TBL\_SEND\_HK\_MSG**

```
#define CFE_MISSION_TBL_SEND_HK_MSG 12
```

Definition at line 322 of file sample\_mission\_cfg.h.

**12.24.2.39 CFE\_MISSION\_TEST\_CMD\_MSG**

```
#define CFE_MISSION_TEST_CMD_MSG 2
```

Definition at line 312 of file sample\_mission\_cfg.h.

**12.24.2.40 CFE\_MISSION\_TEST\_HK\_TLM\_MSG**

```
#define CFE_MISSION_TEST_HK_TLM_MSG 2
```

Definition at line 357 of file sample\_mission\_cfg.h.

**12.24.2.41 CFE\_MISSION\_TIME\_1HZ\_CMD\_MSG**

```
#define CFE_MISSION_TIME_1HZ_CMD_MSG 17
```

Definition at line 328 of file sample\_mission\_cfg.h.

**12.24.2.42 CFE\_MISSION\_TIME\_AT\_TONE\_WAS**

```
#define CFE_MISSION_TIME_AT_TONE_WAS true
```

**Purpose** Default Time and Tone Order

**Description:**

Time Services may be configured to expect the time at the tone data packet to either precede or follow the tone signal. If the time at the tone data packet follows the tone signal, then the data within the packet describes what the time "was" at the tone. If the time at the tone data packet precedes the tone signal, then the data within the packet describes what the time "will be" at the tone. One, and only one, of the following symbols must be set to true:

- CFE\_MISSION\_TIME\_AT\_TONE\_WAS
- CFE\_MISSION\_TIME\_AT\_TONE\_WILL\_BE Note: If Time Services is defined as using a simulated tone signal (see [CFE\\_MISSION\\_TIME\\_CFG\\_FAKE\\_TONE](#) above), then the tone data packet must follow the tone signal.

**Limits**

Either CFE\_MISSION\_TIME\_AT\_TONE\_WAS or CFE\_MISSION\_TIME\_AT\_TONE\_WILL\_BE must be set to true. They may not both be true and they may not both be false.

Definition at line 108 of file sample\_mission\_cfg.h.

**12.24.2.43 CFE\_MISSION\_TIME\_AT\_TONE\_WILL\_BE**

```
#define CFE_MISSION_TIME_AT_TONE_WILL_BE false
```

Definition at line 109 of file sample\_mission\_cfg.h.

#### 12.24.2.44 CFE\_MISSION\_TIME\_CFG\_DEFAULT\_TAI

```
#define CFE_MISSION_TIME_CFG_DEFAULT_TAI true
```

**Purpose** Default Time Format

##### Description:

The following definitions select either UTC or TAI as the default (mission specific) time format. Although it is possible for an application to request time in a specific format, most callers should use [CFE\\_TIME\\_GetTime\(\)](#), which returns time in the default format. This avoids having to modify each individual caller when the default choice is changed.

##### Limits

if CFE\_MISSION\_TIME\_CFG\_DEFAULT\_TAI is defined as true then CFE\_MISSION\_TIME\_CFG\_DEFAULT\_UTC must be defined as false. if CFE\_MISSION\_TIME\_CFG\_DEFAULT\_TAI is defined as false then CFE\_MISSION\_TIME\_CFG\_DEFAULT\_UTC must be defined as true.

Definition at line 72 of file sample\_mission\_cfg.h.

#### 12.24.2.45 CFE\_MISSION\_TIME\_CFG\_DEFAULT\_UTC

```
#define CFE_MISSION_TIME_CFG_DEFAULT_UTC false
```

Definition at line 73 of file sample\_mission\_cfg.h.

#### 12.24.2.46 CFE\_MISSION\_TIME\_CFG\_FAKE\_TONE

```
#define CFE_MISSION_TIME_CFG_FAKE_TONE true
```

**Purpose** Default Time Format

##### Description:

The following definition enables the use of a simulated time at the tone signal using a software bus message.

##### Limits

Not Applicable

Definition at line 85 of file sample\_mission\_cfg.h.

**12.24.2.47 CFE\_MISSION\_TIME\_CMD\_MSG**

```
#define CFE_MISSION_TIME_CMD_MSG 5
```

Definition at line 315 of file sample\_mission\_cfg.h.

**12.24.2.48 CFE\_MISSION\_TIME\_DATA\_CMD\_MSG**

```
#define CFE_MISSION_TIME_DATA_CMD_MSG 0
```

**Purpose** cFE Portable Message Numbers for Global Messages

**Description:**

Portable message numbers for the cFE global messages NOTE: cFE MsgIds are the sum of the base numbers and the portable msg numbers.

**Limits**

Not Applicable

Definition at line 341 of file sample\_mission\_cfg.h.

**12.24.2.49 CFE\_MISSION\_TIME\_DEF\_DELAY\_SECS**

```
#define CFE_MISSION_TIME_DEF_DELAY_SECS 0
```

Definition at line 167 of file sample\_mission\_cfg.h.

**12.24.2.50 CFE\_MISSION\_TIME\_DEF\_DELAY\_SUBS**

```
#define CFE_MISSION_TIME_DEF_DELAY_SUBS 1000
```

Definition at line 168 of file sample\_mission\_cfg.h.

**12.24.2.51 CFE\_MISSION\_TIME\_DEF\_LEAPS**

```
#define CFE_MISSION_TIME_DEF_LEAPS 37
```

Definition at line 165 of file sample\_mission\_cfg.h.

**12.24.2.52 CFE\_MISSION\_TIME\_DEF\_MET\_SECS**

```
#define CFE_MISSION_TIME_DEF_MET_SECS 1000
```

**Purpose** Default Time Values

Description:

Default time values are provided to avoid problems due to time calculations performed after startup but before commands can be processed. For example, if the default time format is UTC then it is important that the sum of MET and STCF always exceed the value of Leap Seconds to prevent the UTC time calculation ( $\text{time} = \text{MET} + \text{STCF} - \text{Leap Seconds}$ ) from resulting in a negative (very large) number.

Some past missions have also created known (albeit wrong) default timestamps. For example, assume the epoch is defined as Jan 1, 1970 and further assume the default time values are set to create a timestamp of Jan 1, 2000. Even though the year 2000 timestamps are wrong, it may be of value to keep the time within some sort of bounds acceptable to the software.

Note: Sub-second units are in micro-seconds (0 to 999,999) and all values must be defined

Limits

Not Applicable

Definition at line 159 of file sample\_mission\_cfg.h.

**12.24.2.53 CFE\_MISSION\_TIME\_DEF\_MET\_SUBS**

```
#define CFE_MISSION_TIME_DEF_MET_SUBS 0
```

Definition at line 160 of file sample\_mission\_cfg.h.

**12.24.2.54 CFE\_MISSION\_TIME\_DEF\_STCF\_SECS**

```
#define CFE_MISSION_TIME_DEF_STCF_SECS 1000000
```

Definition at line 162 of file sample\_mission\_cfg.h.

**12.24.2.55 CFE\_MISSION\_TIME\_DEF\_STCF\_SUBS**

```
#define CFE_MISSION_TIME_DEF_STCF_SUBS 0
```

Definition at line 163 of file sample\_mission\_cfg.h.

**12.24.2.56 CFE\_MISSION\_TIME\_DIAG\_TLM\_MSG**

```
#define CFE_MISSION_TIME_DIAG_TLM_MSG 6
```

Definition at line 361 of file sample\_mission\_cfg.h.

**12.24.2.57 CFE\_MISSION\_TIME\_EPOCH\_DAY**

```
#define CFE_MISSION_TIME_EPOCH_DAY 1
```

Definition at line 186 of file sample\_mission\_cfg.h.

**12.24.2.58 CFE\_MISSION\_TIME\_EPOCH\_HOUR**

```
#define CFE_MISSION_TIME_EPOCH_HOUR 0
```

Definition at line 187 of file sample\_mission\_cfg.h.

**12.24.2.59 CFE\_MISSION\_TIME\_EPOCH\_MICROS**

```
#define CFE_MISSION_TIME_EPOCH_MICROS 0
```

Definition at line 190 of file sample\_mission\_cfg.h.

**12.24.2.60 CFE\_MISSION\_TIME\_EPOCH\_MINUTE**

```
#define CFE_MISSION_TIME_EPOCH_MINUTE 0
```

Definition at line 188 of file sample\_mission\_cfg.h.

**12.24.2.61 CFE\_MISSION\_TIME\_EPOCH\_SECOND**

```
#define CFE_MISSION_TIME_EPOCH_SECOND 0
```

Definition at line 189 of file sample\_mission\_cfg.h.

#### 12.24.2.62 CFE\_MISSION\_TIME\_EPOCH\_YEAR

```
#define CFE_MISSION_TIME_EPOCH_YEAR 1980
```

**Purpose** Default EPOCH Values

**Description:**

Default ground time epoch values Note: these values are used only by the [CFE\\_TIME\\_Print\(\)](#) API function

**Limits**

Year - must be within 136 years Day - Jan 1 = 1, Feb 1 = 32, etc. Hour - 0 to 23 Minute - 0 to 59 Second - 0 to 59  
Micros - 0 to 999999

Definition at line 185 of file sample\_mission\_cfg.h.

#### 12.24.2.63 CFE\_MISSION\_TIME\_FS\_FACTOR

```
#define CFE_MISSION_TIME_FS_FACTOR 789004800
```

**Purpose** Time File System Factor

**Description:**

Define the s/c vs file system time conversion constant...

Note: this value is intended for use only by CFE TIME API functions to convert time values based on the ground system epoch (s/c time) to and from time values based on the file system epoch (fs time).

FS time = S/C time + factor S/C time = FS time - factor

**Worksheet:**

S/C epoch = Jan 1, 2005 (LRO ground system epoch) FS epoch = Jan 1, 1980 (vxWorks DOS file system epoch)

Delta = 25 years, 0 days, 0 hours, 0 minutes, 0 seconds

Leap years = 1980, 1984, 1988, 1992, 1996, 2000, 2004 (divisible by 4 – except if by 100 – unless also by 400)

1 year = 31,536,000 seconds 1 day = 86,400 seconds 1 hour = 3,600 seconds 1 minute = 60 seconds

25 years = 788,400,000 seconds 7 extra leap days = 604,800 seconds

total delta = 789,004,800 seconds

**Limits**

Not Applicable

Definition at line 228 of file sample\_mission\_cfg.h.

**12.24.2.64 CFE\_MISSION\_TIME\_HK\_TLM\_MSG**

```
#define CFE_MISSION_TIME_HK_TLM_MSG 5
```

Definition at line 360 of file sample\_mission\_cfg.h.

**12.24.2.65 CFE\_MISSION\_TIME\_MAX\_ELAPSED**

```
#define CFE_MISSION_TIME_MAX_ELAPSED 200000
```

Definition at line 134 of file sample\_mission\_cfg.h.

**12.24.2.66 CFE\_MISSION\_TIME\_MIN\_ELAPSED**

```
#define CFE_MISSION_TIME_MIN_ELAPSED 0
```

**Purpose** Min and Max Time Elapsed**Description:**

Based on the definition of Time and Tone Order (CFE\_MISSION\_TIME\_AT\_TONE\_WAS/WILL\_BE) either the "time at the tone" signal or data packet will follow the other. This definition sets the valid window of time for the second of the pair to lag behind the first. Time Services will invalidate both the tone and packet if the second does not arrive within this window following the first.

For example, if the data packet follows the tone, it might be valid for the data packet to arrive between zero and 100,000 micro-seconds after the tone. But, if the tone follows the packet, it might be valid only if the packet arrived between 200,000 and 700,000 micro-seconds before the tone.

Note: units are in micro-seconds

**Limits**

0 to 999,999 decimal

Definition at line 133 of file sample\_mission\_cfg.h.

**12.24.2.67 CFE\_MISSION\_TIME\_SEND\_CMD\_MSG**

```
#define CFE_MISSION_TIME_SEND_CMD_MSG 2
```

Definition at line 342 of file sample\_mission\_cfg.h.

**12.24.2.68 CFE\_MISSION\_TIME\_SEND\_HK\_MSG**

```
#define CFE_MISSION_TIME_SEND_HK_MSG 13
```

Definition at line 323 of file sample\_mission\_cfg.h.

**12.24.2.69 CFE\_MISSION\_TIME\_TONE\_CMD\_MSG**

```
#define CFE_MISSION_TIME_TONE_CMD_MSG 16
```

Definition at line 327 of file sample\_mission\_cfg.h.

**12.25 cfe/cmake/sample\_defs/sample\_perfids.h File Reference****Macros**

- #define CFE\_MISSION\_ES\_PERF\_EXIT\_BIT 31  
*bit (31) is reserved by the perf utilities*

**cFE Performance Monitor IDs (Reserved IDs 0-31)**

- #define CFE\_MISSION\_ES\_MAIN\_PERF\_ID 1  
*Performance ID for Executive Services Task.*
- #define CFE\_MISSION\_EVS\_MAIN\_PERF\_ID 2  
*Performance ID for Events Services Task.*
- #define CFE\_MISSION\_TBL\_MAIN\_PERF\_ID 3  
*Performance ID for Table Services Task.*
- #define CFE\_MISSION\_SB\_MAIN\_PERF\_ID 4  
*Performance ID for Software Bus Services Task.*
- #define CFE\_MISSION\_SB\_MSG\_LIM\_PERF\_ID 5  
*Performance ID for Software Bus Msg Limit Errors.*
- #define CFE\_MISSION\_SB\_PIPE\_OFLOW\_PERF\_ID 27  
*Performance ID for Software Bus Pipe Overflow Errors.*
- #define CFE\_MISSION\_TIME\_MAIN\_PERF\_ID 6  
*Performance ID for Time Services Task.*
- #define CFE\_MISSION\_TIME\_TONE1HZISR\_PERF\_ID 7  
*Performance ID for 1 Hz Tone ISR.*
- #define CFE\_MISSION\_TIME\_LOCAL1HZISR\_PERF\_ID 8  
*Performance ID for 1 Hz Local ISR.*
- #define CFE\_MISSION\_TIME\_SEDMET\_PERF\_ID 9  
*Performance ID for Time ToneSendMET.*
- #define CFE\_MISSION\_TIME\_LOCAL1HZTASK\_PERF\_ID 10  
*Performance ID for 1 Hz Local Task.*
- #define CFE\_MISSION\_TIME\_TONE1HZTASK\_PERF\_ID 11  
*Performance ID for 1 Hz Tone Task.*

### 12.25.1 Detailed Description

Purpose: This file contains the cFE performance IDs

Design Notes: Each performance id is used to identify something that needs to be measured. Performance ids are limited to the range of 0 to CFE\_MISSION\_ES\_PERF\_MAX\_IDS - 1. Any performance ids outside of this range will be ignored and will be flagged as an error. Note that performance ids 0-31 are reserved for the cFE Core.

References:

### 12.25.2 Macro Definition Documentation

#### 12.25.2.1 CFE\_MISSION\_ES\_MAIN\_PERF\_ID

```
#define CFE_MISSION_ES_MAIN_PERF_ID 1
```

Performance ID for Executive Services Task.

Definition at line 42 of file sample\_perfids.h.

#### 12.25.2.2 CFE\_MISSION\_ES\_PERF\_EXIT\_BIT

```
#define CFE_MISSION_ES_PERF_EXIT_BIT 31
```

bit (31) is reserved by the perf utilities

Definition at line 38 of file sample\_perfids.h.

#### 12.25.2.3 CFE\_MISSION\_EVS\_MAIN\_PERF\_ID

```
#define CFE_MISSION_EVS_MAIN_PERF_ID 2
```

Performance ID for Events Services Task.

Definition at line 43 of file sample\_perfids.h.

#### 12.25.2.4 CFE\_MISSION\_SB\_MAIN\_PERF\_ID

```
#define CFE_MISSION_SB_MAIN_PERF_ID 4
```

Performance ID for Software Bus Services Task.

Definition at line 45 of file sample\_perfids.h.

**12.25.2.5 CFE\_MISSION\_SB\_MSG\_LIM\_PERF\_ID**

```
#define CFE_MISSION_SB_MSG_LIM_PERF_ID 5
```

Performance ID for Software Bus Msg Limit Errors.

Definition at line 46 of file sample\_perfids.h.

**12.25.2.6 CFE\_MISSION\_SB\_PIPE\_OFLOW\_PERF\_ID**

```
#define CFE_MISSION_SB_PIPE_OFLOW_PERF_ID 27
```

Performance ID for Software Bus Pipe Overflow Errors.

Definition at line 47 of file sample\_perfids.h.

**12.25.2.7 CFE\_MISSION\_TBL\_MAIN\_PERF\_ID**

```
#define CFE_MISSION_TBL_MAIN_PERF_ID 3
```

Performance ID for Table Services Task.

Definition at line 44 of file sample\_perfids.h.

**12.25.2.8 CFE\_MISSION\_TIME\_LOCAL1HZISR\_PERF\_ID**

```
#define CFE_MISSION_TIME_LOCAL1HZISR_PERF_ID 8
```

Performance ID for 1 Hz Local ISR.

Definition at line 51 of file sample\_perfids.h.

**12.25.2.9 CFE\_MISSION\_TIME\_LOCAL1HZTASK\_PERF\_ID**

```
#define CFE_MISSION_TIME_LOCAL1HZTASK_PERF_ID 10
```

Performance ID for 1 Hz Local Task.

Definition at line 54 of file sample\_perfids.h.

**12.25.2.10 CFE\_MISSION\_TIME\_MAIN\_PERF\_ID**

```
#define CFE_MISSION_TIME_MAIN_PERF_ID 6
```

Performance ID for Time Services Task.

Definition at line 49 of file sample\_perfids.h.

**12.25.2.11 CFE\_MISSION\_TIME\_SENDMET\_PERF\_ID**

```
#define CFE_MISSION_TIME_SENDMET_PERF_ID 9
```

Performance ID for Time ToneSendMET.

Definition at line 53 of file sample\_perfids.h.

**12.25.2.12 CFE\_MISSION\_TIME\_TONE1HZISR\_PERF\_ID**

```
#define CFE_MISSION_TIME_TONE1HZISR_PERF_ID 7
```

Performance ID for 1 Hz Tone ISR.

Definition at line 50 of file sample\_perfids.h.

**12.25.2.13 CFE\_MISSION\_TIME\_TONE1HZTASK\_PERF\_ID**

```
#define CFE_MISSION_TIME_TONE1HZTASK_PERF_ID 11
```

Performance ID for 1 Hz Tone Task.

Definition at line 55 of file sample\_perfids.h.

12.26 cfe/docs/src/cfe\_api.dox File Reference

12.27 cfe/docs/src/cfe\_es.dox File Reference

12.28 cfe/docs/src/cfe\_evs.dox File Reference

12.29 cfe/docs/src/cfe\_frontpage.dox File Reference

12.30 cfe/docs/src/cfe\_glossary.dox File Reference

12.31 cfe/docs/src/cfe\_sb.dox File Reference

12.32 cfe/docs/src/cfe\_tbl.dox File Reference

12.33 cfe/docs/src/cfe\_time.dox File Reference

12.34 cfe/docs/src/cfe\_xref.dox File Reference

12.35 cfe/docs/src/cfs\_versions.dox File Reference

12.36 cfe/modules/core\_api/fsw/inc/cfe.h File Reference

```
#include "common_types.h"
#include "osapi.h"
#include "cfe_mission_cfg.h"
#include "cfe_error.h"
#include "cfe_es.h"
#include "cfe_evs.h"
#include "cfe_fs.h"
#include "cfe_sb.h"
#include "cfe_time.h"
#include "cfe_tbl.h"
#include "cfe_msg.h"
#include "cfe_resourceid.h"
#include "cfe_psp.h"
```

#### 12.36.1 Detailed Description

Purpose: cFE header file

Author: David Kobe, the Hammers Company, Inc.

Notes: This header file centralizes the includes for all cFE Applications. It includes all header files necessary to completely define the cFE interface.

## 12.37 cfe/modules/core\_api/fsw/inc/cfe\_config.h File Reference

```
#include "common_types.h"
#include "cfe_config_api_typedefs.h"
#include "cfe_config_ids.h"
```

### Functions

- `uint32 CFE_Config_GetValue (CFE_ConfigId_t ConfigId)`  
*Obtain an integer value correlating to an CFE configuration ID.*
- `const void * CFE_Config_GetObjPointer (CFE_ConfigId_t ConfigId)`  
*Obtain a pointer value correlating to an CFE configuration ID.*
- `const char * CFE_Config_GetString (CFE_ConfigId_t ConfigId)`  
*Obtain a string value correlating to an CFE configuration ID.*
- `const char * CFE_Config_getName (CFE_ConfigId_t ConfigId)`  
*Obtain the name of a CFE configuration ID.*
- `CFE_ConfigId_t CFE_Config_getIdByName (const char *Name)`  
*Obtain the ID value associated with a configuration name.*
- `void CFE_Config_IterateAll (void *Arg, CFE_Config_Callback_t Callback)`  
*Iterate all known name/ID value pairs.*

### 12.37.1 Detailed Description

Title: cFE Status Code Definition Header File

Purpose: Common source of cFE API return status codes.

Design Notes:

References: Flight Software Branch C Coding Standard Version 1.0a

### 12.37.2 Function Documentation

#### 12.37.2.1 CFE\_Config\_getIdByName()

```
CFE_ConfigId_t CFE_Config_getIdByName (
    const char * Name )
```

Obtain the ID value associated with a configuration name.

#### Parameters

in	Name	The name of the ID to look up
----	------	-------------------------------

**Returns**

ID associated with name

**Return values**

<i>CFE_CONFIGID_UNDEFINED</i>	if the name did not correspond to a key
-------------------------------	---

**12.37.2.2 CFE\_Config\_GetName()**

```
const char* CFE_Config_GetName (
    CFE_ConfigId_t ConfigId )
```

Obtain the name of a CFE configuration ID.

Retrieves the printable name associated with the specified key.

**Note**

This function does not return NULL.

If the ID is not valid/known, then the implementation returns the special string '[unknown]' rather than NULL, so this function may be more easily used in printf() style calls.

**Parameters**

in	<i>ConfigId</i>	Configuration ID/Key to look up
----	-----------------	---------------------------------

**Returns**

Name associated with key

**12.37.2.3 CFE\_Config\_GetObjPointer()**

```
const void* CFE_Config_GetObjPointer (
    CFE_ConfigId_t ConfigId )
```

Obtain a pointer value correlating to an CFE configuration ID.

Retrieves the pointer value associated with the specified key.

If no value has been set, or the key is not valid, this returns NULL.

**Parameters**

in	<i>ConfigId</i>	Configuration ID/Key to look up
----	-----------------	---------------------------------

**Returns**

Value associated with key

**Return values**

NULL	if key is not defined or not set
------	----------------------------------

**12.37.2.4 CFE\_Config\_GetString()**

```
const char* CFE_Config_GetString (
    CFE_ConfigId_t ConfigId )
```

Obtain a string value correlating to an CFE configuration ID.

Retrieves the string value associated with the specified key.

If no value has been set, or the key is not valid, this returns the special string "UNDEFINED"

**Note**

This function does not return NULL, so it can be used directly in printf-style calls.

**Parameters**

in	<i>ConfigId</i>	Configuration ID/Key to look up
----	-----------------	---------------------------------

**Returns**

String value associated with key

**12.37.2.5 CFE\_Config\_GetValue()**

```
uint32 CFE_Config_GetValue (
    CFE_ConfigId_t ConfigId )
```

Obtain an integer value correlating to an CFE configuration ID.

Retrieves the integer value associated with the specified key.

If no value has been set, or the key is not valid, this returns 0.

**Parameters**

in	<i>ConfigId</i>	Configuration ID/Key to look up
----	-----------------	---------------------------------

**Returns**

Value associated with key

**Return values**

0	if key is not defined or not set
---	----------------------------------

**12.37.2.6 CFE\_Config\_IterateAll()**

```
void CFE_Config_IterateAll (
    void * Arg,
    CFE_Config_Callback_t Callback )
```

Iterate all known name/ID value pairs.

**Parameters**

in	<i>Arg</i>	User-supplied opaque argument to pass to callback
in	<i>Callback</i>	User-supplied callback function to invoke for each ID

**12.38 cfe/modules/core\_api/fsw/inc/cfe\_config\_api\_typedefs.h File Reference**

```
#include "common_types.h"
#include "cfe_resourceid_api_typedefs.h"
```

**Macros**

- #define CFE\_CONFIGID\_C(val) ((CFE\_ConfigId\_t)CFE\_RESOURCEID\_WRAP(val))
- #define CFE\_CONFIGID\_UNDEFINED CFE\_CONFIGID\_C(CFE\_RESOURCEID\_UNDEFINED)

**Typedefs**

- typedef CFE\_RESOURCEID\_BASE\_TYPE CFE\_ConfigId\_t  
*A type for Configuration IDs.*
- typedef void(\* CFE\_Config\_Callback\_t) (void \*Arg, CFE\_ConfigId\_t Id, const char \*Name)

### 12.38.1 Detailed Description

Title: cFE Status Code Definition Header File

Purpose: Common source of cFE API return status codes.

Design Notes:

References: Flight Software Branch C Coding Standard Version 1.0a

### 12.38.2 Macro Definition Documentation

#### 12.38.2.1 CFE\_CONFIGID\_C

```
#define CFE_CONFIGID_C( val ) ((CFE_ConfigId_t)CFE_RESOURCEID_WRAP(val))
```

Definition at line 48 of file cfe\_config\_api\_typedefs.h.

#### 12.38.2.2 CFE\_CONFIGID\_UNDEFINED

```
#define CFE_CONFIGID_UNDEFINED CFE_CONFIGID_C(CFE_RESOURCEID_UNDEFINED)
```

Definition at line 49 of file cfe\_config\_api\_typedefs.h.

### 12.38.3 Typedef Documentation

#### 12.38.3.1 CFE\_Config\_Callback\_t

```
typedef void(* CFE_Config_Callback_t)(void *Arg, CFE_ConfigId_t Id, const char *Name)
```

Definition at line 51 of file cfe\_config\_api\_typedefs.h.

#### 12.38.3.2 CFE\_ConfigId\_t

```
typedef CFE_RESOURCEID_BASE_TYPE CFE_ConfigId_t
```

A type for Configuration IDs.

This is the type that is used for any API accepting or returning a configuration key ID

Definition at line 46 of file cfe\_config\_api\_typedefs.h.

## 12.39 cfe/modules/core\_api/fsw/inc/cfe\_endian.h File Reference

```
#include "common_types.h"
```

### Macros

- `#define CFE_MAKE_BIG16(n) (((n)&0x00FF) << 8) | (((n)&0xFF00) >> 8))`
- `#define CFE_MAKE_BIG32(n) (((n)&0x000000FF) << 24) | (((n)&0x0000FF00) << 8) | (((n)&0x00FF0000) >> 8) | (((n)&0xFF000000) >> 24))`

### 12.39.1 Detailed Description

Purpose: Define macros to enforce big-endian/network byte order for 16 and 32 bit integers

### 12.39.2 Macro Definition Documentation

#### 12.39.2.1 CFE\_MAKE\_BIG16

```
#define CFE_MAKE_BIG16(  
    n ) (((n)&0x00FF) << 8) | (((n)&0xFF00) >> 8))
```

Definition at line 64 of file cfe\_endian.h.

#### 12.39.2.2 CFE\_MAKE\_BIG32

```
#define CFE_MAKE_BIG32(  
    n ) (((n)&0x000000FF) << 24) | (((n)&0x0000FF00) << 8) | (((n)&0x00FF0000) >> 8) |  
    (((n)&0xFF000000) >> 24))
```

Definition at line 65 of file cfe\_endian.h.

## 12.40 cfe/modules/core\_api/fsw/inc/cfe\_error.h File Reference

```
#include "osapi.h"
```

## Macros

- #define **CFE\_STATUS\_C**(X) ((**CFE\_Status\_t**)(X))  
*cFE Status macro for literal*
- #define **CFE\_STATUS\_STRING\_LENGTH** 11  
*cFE Status converted to string length limit*
- #define **CFE\_SEVERITY\_BITMASK** ((**CFE\_Status\_t**)0xc0000000)  
*Error Severity Bitmask.*
- #define **CFE\_SEVERITY\_SUCCESS** ((**CFE\_Status\_t**)0x00000000)  
*Severity Success.*
- #define **CFE\_SEVERITY\_INFO** ((**CFE\_Status\_t**)0x40000000)  
*Severity Info.*
- #define **CFE\_SEVERITY\_ERROR** ((**CFE\_Status\_t**)0xc0000000)  
*Severity Error.*
- #define **CFE\_SERVICE\_BITMASK** ((**CFE\_Status\_t**)0x0e000000)  
*Error Service Bitmask.*
- #define **CFE\_EVENTS\_SERVICE** ((**CFE\_Status\_t**)0x02000000)  
*Event Service.*
- #define **CFE\_EXECUTIVE\_SERVICE** ((**CFE\_Status\_t**)0x04000000)  
*Executive Service.*
- #define **CFE\_FILE\_SERVICE** ((**CFE\_Status\_t**)0x06000000)  
*File Service.*
- #define **CFE\_GENERIC\_SERVICE** ((**CFE\_Status\_t**)0x08000000)  
*Generic Service.*
- #define **CFE\_SOFTWARE\_BUS\_SERVICE** ((**CFE\_Status\_t**)0x0a000000)  
*Software Bus Service.*
- #define **CFE\_TABLE\_SERVICE** ((**CFE\_Status\_t**)0x0c000000)  
*Table Service.*
- #define **CFE\_TIME\_SERVICE** ((**CFE\_Status\_t**)0x0e000000)  
*Time Service.*
- #define **CFE\_SUCCESS** ((**CFE\_Status\_t**)0)  
*Successful execution.*
- #define **CFE\_STATUS\_NO\_COUNTER\_INCREMENT** ((**CFE\_Status\_t**)0x48000001)  
*No Counter Increment.*
- #define **CFE\_STATUS\_WRONG\_MSG\_LENGTH** ((**CFE\_Status\_t**)0xc8000002)  
*Wrong Message Length.*
- #define **CFE\_STATUS\_UNKNOWN\_MSG\_ID** ((**CFE\_Status\_t**)0xc8000003)  
*Unknown Message ID.*
- #define **CFE\_STATUS\_BAD\_COMMAND\_CODE** ((**CFE\_Status\_t**)0xc8000004)  
*Bad Command Code.*
- #define **CFE\_STATUS\_EXTERNAL\_RESOURCE\_FAIL** ((**CFE\_Status\_t**)0xc8000005)  
*External failure.*
- #define **CFE\_STATUS\_REQUEST\_ALREADY\_PENDING** ((**int32**)0xc8000006)  
*Request already pending.*
- #define **CFE\_STATUS\_NOT\_IMPLEMENTED** ((**CFE\_Status\_t**)0xc800ffff)  
*Not Implemented.*
- #define **CFE\_EVS\_UNKNOWN\_FILTER** ((**CFE\_Status\_t**)0xc2000001)

- `#define CFE_EVS_APP_NOT_REGISTERED ((CFE_Status_t)0xc2000002)`  
*Application Not Registered.*
- `#define CFE_EVS_APP_ILLEGAL_APP_ID ((CFE_Status_t)0xc2000003)`  
*Illegal Application ID.*
- `#define CFE_EVS_APP_FILTER_OVERLOAD ((CFE_Status_t)0xc2000004)`  
*Application Filter Overload.*
- `#define CFE_EVS_RESET_AREA_POINTER ((CFE_Status_t)0xc2000005)`  
*Reset Area Pointer Failure.*
- `#define CFE_EVS_EVT_NOT_REGISTERED ((CFE_Status_t)0xc2000006)`  
*Event Not Registered.*
- `#define CFE_EVS_FILE_WRITE_ERROR ((CFE_Status_t)0xc2000007)`  
*File Write Error.*
- `#define CFE_EVS_INVALID_PARAMETER ((CFE_Status_t)0xc2000008)`  
*Invalid Pointer.*
- `#define CFE_EVS_APP_SQUELCHED ((CFE_Status_t)0xc2000009)`  
*Event squelched.*
- `#define CFE_EVS_NOT_IMPLEMENTED ((CFE_Status_t)0xc200ffff)`  
*Not Implemented.*
- `#define CFE_ES_ERR_RESOURCEID_NOT_VALID ((CFE_Status_t)0xc4000001)`  
*Resource ID is not valid.*
- `#define CFE_ES_ERR_NAME_NOT_FOUND ((CFE_Status_t)0xc4000002)`  
*Resource Name Error.*
- `#define CFE_ES_ERR_APP_CREATE ((CFE_Status_t)0xc4000004)`  
*Application Create Error.*
- `#define CFE_ES_ERR_CHILD_TASK_CREATE ((CFE_Status_t)0xc4000005)`  
*Child Task Create Error.*
- `#define CFE_ES_ERR_SYS_LOG_FULL ((CFE_Status_t)0xc4000006)`  
*System Log Full.*
- `#define CFE_ES_ERR_MEM_BLOCK_SIZE ((CFE_Status_t)0xc4000008)`  
*Memory Block Size Error.*
- `#define CFE_ES_ERR_LOAD_LIB ((CFE_Status_t)0xc4000009)`  
*Load Library Error.*
- `#define CFE_ES_BAD_ARGUMENT ((CFE_Status_t)0xc400000a)`  
*Bad Argument.*
- `#define CFE_ES_ERR_CHILD_TASK_REGISTER ((CFE_Status_t)0xc400000b)`  
*Child Task Register Error.*
- `#define CFE_ES_CDS_ALREADY_EXISTS ((CFE_Status_t)0x4400000d)`  
*CDS Already Exists.*
- `#define CFE_ES_CDS_INSUFFICIENT_MEMORY ((CFE_Status_t)0xc400000e)`  
*CDS Insufficient Memory.*
- `#define CFE_ES_CDS_INVALID_NAME ((CFE_Status_t)0xc400000f)`  
*CDS Invalid Name.*
- `#define CFE_ES_CDS_INVALID_SIZE ((CFE_Status_t)0xc4000010)`  
*CDS Invalid Size.*
- `#define CFE_ES_CDS_INVALID ((CFE_Status_t)0xc4000012)`  
*CDS Invalid.*

- #define CFE\_ES\_CDS\_ACCESS\_ERROR ((CFE\_Status\_t)0xc4000013)  
*CDS Access Error.*
- #define CFE\_ES\_FILE\_IO\_ERR ((CFE\_Status\_t)0xc4000014)  
*File IO Error.*
- #define CFE\_ES\_RST\_ACCESS\_ERR ((CFE\_Status\_t)0xc4000015)  
*Reset Area Access Error.*
- #define CFE\_ES\_ERR\_APP\_REGISTER ((CFE\_Status\_t)0xc4000017)  
*Application Register Error.*
- #define CFE\_ES\_ERR\_CHILD\_TASK\_DELETE ((CFE\_Status\_t)0xc4000018)  
*Child Task Delete Error.*
- #define CFE\_ES\_ERR\_CHILD\_TASK\_DELETE\_MAIN\_TASK ((CFE\_Status\_t)0xc4000019)  
*Child Task Delete Passed Main Task.*
- #define CFE\_ES\_CDS\_BLOCK\_CRC\_ERR ((CFE\_Status\_t)0xc400001A)  
*CDS Block CRC Error.*
- #define CFE\_ES\_MUT\_SEM\_DELETE\_ERR ((CFE\_Status\_t)0xc400001B)  
*Mutex Semaphore Delete Error.*
- #define CFE\_ES\_BIN\_SEM\_DELETE\_ERR ((CFE\_Status\_t)0xc400001C)  
*Binary Semaphore Delete Error.*
- #define CFE\_ES\_COUNT\_SEM\_DELETE\_ERR ((CFE\_Status\_t)0xc400001D)  
*Counting Semaphore Delete Error.*
- #define CFE\_ES\_QUEUE\_DELETE\_ERR ((CFE\_Status\_t)0xc400001E)  
*Queue Delete Error.*
- #define CFE\_ES\_FILE\_CLOSE\_ERR ((CFE\_Status\_t)0xc400001F)  
*File Close Error.*
- #define CFE\_ES\_CDS\_WRONG\_TYPE\_ERR ((CFE\_Status\_t)0xc4000020)  
*CDS Wrong Type Error.*
- #define CFE\_ES\_CDS\_OWNER\_ACTIVE\_ERR ((CFE\_Status\_t)0xc4000022)  
*CDS Owner Active Error.*
- #define CFE\_ES\_APP\_CLEANUP\_ERR ((CFE\_Status\_t)0xc4000023)  
*Application Cleanup Error.*
- #define CFE\_ES\_TIMER\_DELETE\_ERR ((CFE\_Status\_t)0xc4000024)  
*Timer Delete Error.*
- #define CFE\_ES\_BUFFER\_NOT\_IN\_POOL ((CFE\_Status\_t)0xc4000025)  
*Buffer Not In Pool.*
- #define CFE\_ES\_TASK\_DELETE\_ERR ((CFE\_Status\_t)0xc4000026)  
*Task Delete Error.*
- #define CFE\_ES\_OPERATION\_TIMED\_OUT ((CFE\_Status\_t)0xc4000027)  
*Operation Timed Out.*
- #define CFE\_ES\_LIB\_ALREADY\_LOADED ((CFE\_Status\_t)0x44000028)  
*Library Already Loaded.*
- #define CFE\_ES\_ERR\_SYS\_LOG\_TRUNCATED ((CFE\_Status\_t)0x44000029)  
*System Log Message Truncated.*
- #define CFE\_ES\_NO\_RESOURCE\_IDS\_AVAILABLE ((CFE\_Status\_t)0xc400002B)  
*Resource ID is not available.*
- #define CFE\_ES\_POOL\_BLOCK\_INVALID ((CFE\_Status\_t)0xc400002C)  
*Invalid pool block.*
- #define CFE\_ES\_ERR\_DUPLICATE\_NAME ((CFE\_Status\_t)0xc400002E)

- Duplicate Name Error.*
- #define CFE\_ES\_NOT\_IMPLEMENTED ((CFE\_Status\_t)0xc400ffff)  
*Not Implemented.*
  - #define CFE\_FS\_BAD\_ARGUMENT ((CFE\_Status\_t)0xc6000001)  
*Bad Argument.*
  - #define CFE\_FS\_INVALID\_PATH ((CFE\_Status\_t)0xc6000002)  
*Invalid Path.*
  - #define CFE\_FS\_FNAME\_TOO\_LONG ((CFE\_Status\_t)0xc6000003)  
*Filename Too Long.*
  - #define CFE\_FS\_NOT\_IMPLEMENTED ((CFE\_Status\_t)0xc600ffff)  
*Not Implemented.*
  - #define CFE\_SB\_TIME\_OUT ((CFE\_Status\_t)0xca000001)  
*Time Out.*
  - #define CFE\_SB\_NO\_MESSAGE ((CFE\_Status\_t)0xca000002)  
*No Message.*
  - #define CFE\_SB\_BAD\_ARGUMENT ((CFE\_Status\_t)0xca000003)  
*Bad Argument.*
  - #define CFE\_SB\_MAX\_PIPES\_MET ((CFE\_Status\_t)0xca000004)  
*Max Pipes Met.*
  - #define CFE\_SB\_PIPE\_CR\_ERR ((CFE\_Status\_t)0xca000005)  
*Pipe Create Error.*
  - #define CFE\_SB\_PIPE\_RD\_ERR ((CFE\_Status\_t)0xca000006)  
*Pipe Read Error.*
  - #define CFE\_SB\_MSG\_TOO\_BIG ((CFE\_Status\_t)0xca000007)  
*Message Too Big.*
  - #define CFE\_SB\_BUF\_ALOC\_ERR ((CFE\_Status\_t)0xca000008)  
*Buffer Allocation Error.*
  - #define CFE\_SB\_MAX\_MSGS\_MET ((CFE\_Status\_t)0xca000009)  
*Max Messages Met.*
  - #define CFE\_SB\_MAX\_DESTS\_MET ((CFE\_Status\_t)0xca00000a)  
*Max Destinations Met.*
  - #define CFE\_SB\_INTERNAL\_ERR ((CFE\_Status\_t)0xca00000c)  
*Internal Error.*
  - #define CFE\_SB\_WRONG\_MSG\_TYPE ((CFE\_Status\_t)0xca00000d)  
*Wrong Message Type.*
  - #define CFE\_SB\_BUFFER\_INVALID ((CFE\_Status\_t)0xca00000e)  
*Buffer Invalid.*
  - #define CFE\_SB\_NOT\_IMPLEMENTED ((CFE\_Status\_t)0xca00ffff)  
*Not Implemented.*
  - #define CFE\_TBL\_ERR\_INVALID\_HANDLE ((CFE\_Status\_t)0xcc000001)  
*Invalid Handle.*
  - #define CFE\_TBL\_ERR\_INVALID\_NAME ((CFE\_Status\_t)0xcc000002)  
*Invalid Name.*
  - #define CFE\_TBL\_ERR\_INVALID\_SIZE ((CFE\_Status\_t)0xcc000003)  
*Invalid Size.*
  - #define CFE\_TBL\_INFO\_UPDATE\_PENDING ((CFE\_Status\_t)0x4c000004)  
*Update Pending.*

- #define CFE\_TBL\_ERR\_NEVER\_LOADED ((CFE\_Status\_t)0xcc000005)  
*Never Loaded.*
- #define CFE\_TBL\_ERR\_REGISTRY\_FULL ((CFE\_Status\_t)0xcc000006)  
*Registry Full.*
- #define CFE\_TBL\_WARN\_DUPLICATE ((CFE\_Status\_t)0x4c000007)  
*Duplicate Warning.*
- #define CFE\_TBL\_ERR\_NO\_ACCESS ((CFE\_Status\_t)0xcc000008)  
*No Access.*
- #define CFE\_TBL\_ERR\_UNREGISTERED ((CFE\_Status\_t)0xcc000009)  
*Unregistered.*
- #define CFE\_TBL\_ERR\_HANDLES\_FULL ((CFE\_Status\_t)0xcc00000B)  
*Handles Full.*
- #define CFE\_TBL\_ERR\_DUPLICATE\_DIFF\_SIZE ((CFE\_Status\_t)0xcc00000C)  
*Duplicate Table With Different Size.*
- #define CFE\_TBL\_ERR\_DUPLICATE\_NOT OWNED ((CFE\_Status\_t)0xcc00000D)  
*Duplicate Table And Not Owned.*
- #define CFE\_TBL\_INFO\_UPDATED ((CFE\_Status\_t)0x4c00000E)  
*Updated.*
- #define CFE\_TBL\_ERR\_NO\_BUFFER\_AVAIL ((CFE\_Status\_t)0xcc00000F)  
*No Buffer Available.*
- #define CFE\_TBL\_ERR\_DUMP\_ONLY ((CFE\_Status\_t)0xcc000010)  
*Dump Only Error.*
- #define CFE\_TBL\_ERR\_ILLEGAL\_SRC\_TYPE ((CFE\_Status\_t)0xcc000011)  
*Illegal Source Type.*
- #define CFE\_TBL\_ERR\_LOAD\_IN\_PROGRESS ((CFE\_Status\_t)0xcc000012)  
*Load In Progress.*
- #define CFE\_TBL\_ERR\_FILE\_TOO\_LARGE ((CFE\_Status\_t)0xcc000014)  
*File Too Large.*
- #define CFE\_TBL\_WARN\_SHORT\_FILE ((CFE\_Status\_t)0x4c000015)  
*Short File Warning.*
- #define CFE\_TBL\_ERR\_BAD\_CONTENT\_ID ((CFE\_Status\_t)0xcc000016)  
*Bad Content ID.*
- #define CFE\_TBL\_INFO\_NO\_UPDATE\_PENDING ((CFE\_Status\_t)0x4c000017)  
*No Update Pending.*
- #define CFE\_TBL\_INFO\_TABLE\_LOCKED ((CFE\_Status\_t)0x4c000018)  
*Table Locked.*
- #define CFE\_TBL\_INFO\_VALIDATION\_PENDING ((CFE\_Status\_t)0x4c000019)
- #define CFE\_TBL\_INFO\_NO\_VALIDATION\_PENDING ((CFE\_Status\_t)0x4c00001A)
- #define CFE\_TBL\_ERR\_BAD\_SUBTYPE\_ID ((CFE\_Status\_t)0xcc00001B)  
*Bad Subtype ID.*
- #define CFE\_TBL\_ERR\_FILE\_SIZE\_INCONSISTENT ((CFE\_Status\_t)0xcc00001C)  
*File Size Inconsistent.*
- #define CFE\_TBL\_ERR\_NO\_STD\_HEADER ((CFE\_Status\_t)0xcc00001D)  
*No Standard Header.*
- #define CFE\_TBL\_ERR\_NO\_TBL\_HEADER ((CFE\_Status\_t)0xcc00001E)  
*No Table Header.*
- #define CFE\_TBL\_ERR\_FILENAME\_TOO\_LONG ((CFE\_Status\_t)0xcc00001F)

- `#define CFE_TBL_ERR_FILE_FOR_WRONG_TABLE ((CFE_Status_t)0xcc000020)`  
*File For Wrong Table.*
- `#define CFE_TBL_ERR_LOAD_INCOMPLETE ((CFE_Status_t)0xcc000021)`  
*Load Incomplete.*
- `#define CFE_TBL_WARN_PARTIAL_LOAD ((CFE_Status_t)0x4c000022)`  
*Partial Load Warning.*
- `#define CFE_TBL_ERR_PARTIAL_LOAD ((CFE_Status_t)0xcc000023)`  
*Partial Load Error.*
- `#define CFE_TBL_INFO_DUMP_PENDING ((CFE_Status_t)0x4c000024)`  
*Dump Pending.*
- `#define CFE_TBL_ERR_INVALID_OPTIONS ((CFE_Status_t)0xcc000025)`  
*Invalid Options.*
- `#define CFE_TBL_WARN_NOT_CRITICAL ((CFE_Status_t)0x4c000026)`  
*Not Critical Warning.*
- `#define CFE_TBL_INFO_RECOVERED_TBL ((CFE_Status_t)0x4c000027)`  
*Recovered Table.*
- `#define CFE_TBL_ERR_BAD_SPACECRAFT_ID ((CFE_Status_t)0xcc000028)`  
*Bad Spacecraft ID.*
- `#define CFE_TBL_ERR_BAD_PROCESSOR_ID ((CFE_Status_t)0xcc000029)`  
*Bad Processor ID.*
- `#define CFE_TBL_MESSAGE_ERROR ((CFE_Status_t)0xcc00002a)`  
*Message Error.*
- `#define CFE_TBL_ERR_SHORT_FILE ((CFE_Status_t)0xcc00002b)`
- `#define CFE_TBL_ERR_ACCESS ((CFE_Status_t)0xcc00002c)`
- `#define CFE_TBL_BAD_ARGUMENT ((CFE_Status_t)0xcc00002d)`  
*Bad Argument.*
- `#define CFE_TBL_NOT_IMPLEMENTED ((CFE_Status_t)0xcc00ffff)`  
*Not Implemented.*
- `#define CFE_TIME_NOT_IMPLEMENTED ((CFE_Status_t)0xce00ffff)`  
*Not Implemented.*
- `#define CFE_TIME_INTERNAL_ONLY ((CFE_Status_t)0xce000001)`  
*Internal Only.*
- `#define CFE_TIME_OUT_OF_RANGE ((CFE_Status_t)0xce000002)`  
*Out Of Range.*
- `#define CFE_TIME_TOO_MANY_SYNCH_CALLBACKS ((CFE_Status_t)0xce000003)`  
*Too Many Sync Callbacks.*
- `#define CFE_TIME_CALLBACK_NOT_REGISTERED ((CFE_Status_t)0xce000004)`  
*Callback Not Registered.*
- `#define CFE_TIME_BAD_ARGUMENT ((CFE_Status_t)0xce000005)`  
*Bad Argument.*

## Typedefs

- `typedef int32 CFE_Status_t`  
*cFE Status type for readability and eventually type safety*
- `typedef char CFE_StatusString_t[CFE_STATUS_STRING_LENGTH]`  
*For the `CFE_ES_StatusToString()` function, to ensure everyone is making an array of the same length.*

## Functions

- `char * CFE_ES_StatusToString (CFE_Status_t status, CFE_StatusString_t *status_string)`  
*Convert status to a string.*

### 12.40.1 Detailed Description

Title: cFE Status Code Definition Header File

Purpose: Common source of cFE API return status codes.

Design Notes:

References: Flight Software Branch C Coding Standard Version 1.0a

### 12.40.2 Macro Definition Documentation

#### 12.40.2.1 CFE\_EVENTS\_SERVICE

```
#define CFE_EVENTS_SERVICE ((CFE_Status_t) 0x02000000)
```

Event Service.

Definition at line 126 of file cfe\_error.h.

#### 12.40.2.2 CFE\_EXECUTIVE\_SERVICE

```
#define CFE_EXECUTIVE_SERVICE ((CFE_Status_t) 0x04000000)
```

Executive Service.

Definition at line 127 of file cfe\_error.h.

#### 12.40.2.3 CFE\_FILE\_SERVICE

```
#define CFE_FILE_SERVICE ((CFE_Status_t) 0x06000000)
```

File Service.

Definition at line 128 of file cfe\_error.h.

#### 12.40.2.4 CFE\_GENERIC\_SERVICE

```
#define CFE_GENERIC_SERVICE ((CFE_Status_t)0x08000000)
```

Generic Service.

Definition at line 129 of file cfe\_error.h.

#### 12.40.2.5 CFE\_SERVICE\_BITMASK

```
#define CFE_SERVICE_BITMASK ((CFE_Status_t)0x0e000000)
```

Error Service Bitmask.

Definition at line 124 of file cfe\_error.h.

#### 12.40.2.6 CFE\_SEVERITY\_BITMASK

```
#define CFE_SEVERITY_BITMASK ((CFE_Status_t)0xc0000000)
```

Error Severity Bitmask.

Definition at line 115 of file cfe\_error.h.

#### 12.40.2.7 CFE\_SEVERITY\_ERROR

```
#define CFE_SEVERITY_ERROR ((CFE_Status_t)0xc0000000)
```

Severity Error.

Definition at line 119 of file cfe\_error.h.

#### 12.40.2.8 CFE\_SEVERITY\_INFO

```
#define CFE_SEVERITY_INFO ((CFE_Status_t)0x40000000)
```

Severity Info.

Definition at line 118 of file cfe\_error.h.

#### 12.40.2.9 CFE\_SEVERITY\_SUCCESS

```
#define CFE_SEVERITY_SUCCESS ((CFE_Status_t) 0x00000000)
```

Severity Success.

Definition at line 117 of file cfe\_error.h.

#### 12.40.2.10 CFE\_SOFTWARE\_BUS\_SERVICE

```
#define CFE_SOFTWARE_BUS_SERVICE ((CFE_Status_t) 0x0a000000)
```

Software Bus Service.

Definition at line 130 of file cfe\_error.h.

#### 12.40.2.11 CFE\_STATUS\_C

```
#define CFE_STATUS_C(  
    X ) ((CFE_Status_t)(X))
```

cFE Status macro for literal

Definition at line 48 of file cfe\_error.h.

#### 12.40.2.12 CFE\_STATUS\_STRING\_LENGTH

```
#define CFE_STATUS_STRING_LENGTH 11
```

cFE Status converted to string length limit

Used for sizing CFE\_StatusString\_t intended for use in printing CFE\_Status\_t values Sized for 0x%08x and NULL

Definition at line 56 of file cfe\_error.h.

#### 12.40.2.13 CFE\_TABLE\_SERVICE

```
#define CFE_TABLE_SERVICE ((CFE_Status_t) 0x0c000000)
```

Table Service.

Definition at line 131 of file cfe\_error.h.

#### 12.40.2.14 CFE\_TIME\_SERVICE

```
#define CFE_TIME_SERVICE ((CFE_Status_t)0x0e000000)
```

Time Service.

Definition at line 132 of file cfe\_error.h.

#### 12.40.3 TYPEDOC Documentation

##### 12.40.3.1 CFE\_Status\_t

```
typedef int32 CFE_Status_t
```

cFE Status type for readability and eventually type safety

Definition at line 43 of file cfe\_error.h.

##### 12.40.3.2 CFE\_StatusString\_t

```
typedef char CFE_StatusString_t [CFE_STATUS_STRING_LENGTH]
```

For the [CFE\\_ES\\_StatusToString\(\)](#) function, to ensure everyone is making an array of the same length.

Definition at line 62 of file cfe\_error.h.

#### 12.40.4 Function Documentation

##### 12.40.4.1 CFE\_ES\_StatusToString()

```
char* CFE_ES_StatusToString (
    CFE_Status_t status,
    CFE_StatusString_t * status_string )
```

Convert status to a string.

##### Parameters

in	<i>status</i>	Status value to convert
out	<i>status_string</i>	Buffer to store status converted to string

## Returns

Passed in string pointer

## 12.41 cfe/modules/core\_api/fsw/inc/cfe\_es.h File Reference

```
#include "common_types.h"
#include "cfe_error.h"
#include "cfe_es_api_typedefs.h"
#include "cfe_resourceid_api_typedefs.h"
```

## Macros

- #define OS\_PRINTF(m, n)
- #define CFE\_ES\_DBIT(x) (1L << (x)) /\* Places a one at bit positions 0 thru 31 \*/
- #define CFE\_ES\_DTEST(i, x) (((i)&CFE\_ES\_DBIT(x)) != 0) /\* true iff bit x of i is set \*/
- #define CFE\_ES\_TEST\_LONG\_MASK(m, s) (CFE\_ES\_DTEST(m[(s) / 32], (s) % 32)) /\* Test a bit within an array of 32-bit integers. \*/
- #define CFE\_ES\_PerfLogEntry(id) (CFE\_ES\_PerfLogAdd(id, 0))  
*Entry marker for use with Software Performance Analysis Tool.*
- #define CFE\_ES\_PerfLogExit(id) (CFE\_ES\_PerfLogAdd(id, 1))  
*Exit marker for use with Software Performance Analysis Tool.*

## Functions

- CFE\_Status\_t CFE\_ES\_AppID\_ToIndex (CFE\_ES\_AppId\_t AppID, uint32 \*Idx)  
*Obtain an index value correlating to an ES Application ID.*
- int32 CFE\_ES\_LibID\_ToIndex (CFE\_ES\_LibId\_t LibId, uint32 \*Idx)  
*Obtain an index value correlating to an ES Library ID.*
- CFE\_Status\_t CFE\_ES\_TaskID\_ToIndex (CFE\_ES\_TaskId\_t TaskID, uint32 \*Idx)  
*Obtain an index value correlating to an ES Task ID.*
- CFE\_Status\_t CFE\_ES\_CounterID\_ToIndex (CFE\_ES\_CounterId\_t CounterId, uint32 \*Idx)  
*Obtain an index value correlating to an ES Counter ID.*
- void CFE\_ES\_Main (uint32 StartType, uint32 StartSubtype, uint32 ModelId, const char \*StartFilePath)  
*cFE Main Entry Point used by Board Support Package to start cFE*
- CFE\_Status\_t CFE\_ES\_ResetCFE (uint32 ResetType)  
*Reset the cFE Core and all cFE Applications.*
- CFE\_Status\_t CFE\_ES\_RestartApp (CFE\_ES\_AppId\_t AppID)  
*Restart a single cFE Application.*
- CFE\_Status\_t CFE\_ES\_ReloadApp (CFE\_ES\_AppId\_t AppID, const char \*AppFileName)  
*Reload a single cFE Application.*
- CFE\_Status\_t CFE\_ES\_DeleteApp (CFE\_ES\_AppId\_t AppID)  
*Delete a cFE Application.*
- void CFE\_ES\_ExitApp (uint32 ExitStatus)  
*Exit a cFE Application.*
- bool CFE\_ES\_RunLoop (uint32 \*RunStatus)

- Check for Exit, Restart, or Reload commands.*
- **CFE\_Status\_t CFE\_ES\_WaitForSystemState (uint32 MinSystemState, uint32 TimeOutMilliseconds)**  
*Allow an Application to Wait for a minimum global system state.*
  - void **CFE\_ES\_WaitForStartupSync (uint32 TimeOutMilliseconds)**  
*Allow an Application to Wait for the "OPERATIONAL" global system state.*
  - void **CFE\_ES\_IncrementTaskCounter (void)**  
*Increments the execution counter for the calling task.*
  - int32 **CFE\_ES\_GetResetType (uint32 \*ResetSubtypePtr)**  
*Return the most recent Reset Type.*
  - **CFE\_Status\_t CFE\_ES\_GetAppID (CFE\_ES\_AppId\_t \*AppIdPtr)**  
*Get an Application ID for the calling Application.*
  - **CFE\_Status\_t CFE\_ES\_GetTaskID (CFE\_ES\_TaskId\_t \*TaskIdPtr)**  
*Get the task ID of the calling context.*
  - **CFE\_Status\_t CFE\_ES\_GetAppIDByName (CFE\_ES\_AppId\_t \*AppIdPtr, const char \*AppName)**  
*Get an Application ID associated with a specified Application name.*
  - **CFE\_Status\_t CFE\_ES\_GetLibIDByName (CFE\_ES\_LibId\_t \*LibIdPtr, const char \*LibName)**  
*Get a Library ID associated with a specified Library name.*
  - **CFE\_Status\_t CFE\_ES\_GetAppName (char \*AppName, CFE\_ES\_AppId\_t AppId, size\_t BufferLength)**  
*Get an Application name for a specified Application ID.*
  - **CFE\_Status\_t CFE\_ES\_GetLibName (char \*LibName, CFE\_ES\_LibId\_t LibId, size\_t BufferLength)**  
*Get a Library name for a specified Library ID.*
  - **CFE\_Status\_t CFE\_ES\_GetAppInfo (CFE\_ES\_AppInfo\_t \*AppInfo, CFE\_ES\_AppId\_t AppId)**  
*Get Application Information given a specified App ID.*
  - **CFE\_Status\_t CFE\_ES\_GetTaskInfo (CFE\_ES\_TaskInfo\_t \*TaskInfo, CFE\_ES\_TaskId\_t TaskId)**  
*Get Task Information given a specified Task ID.*
  - int32 **CFE\_ES\_GetLibInfo (CFE\_ES\_AppInfo\_t \*LibInfo, CFE\_ES\_LibId\_t LibId)**  
*Get Library Information given a specified Resource ID.*
  - int32 **CFE\_ES\_GetModuleInfo (CFE\_ES\_AppInfo\_t \*ModuleInfo, CFE\_Resourceld\_t Resourceld)**  
*Get Information given a specified Resource ID.*
  - **CFE\_Status\_t CFE\_ES\_CreateChildTask (CFE\_ES\_TaskId\_t \*TaskIdPtr, const char \*TaskName, CFE\_ES\_ChildTaskMainFuncPtr\_t FunctionPtr, CFE\_ES\_StackPointer\_t StackPtr, size\_t StackSize, CFE\_ES\_TaskPriority\_Atom\_t Priority, uint32 Flags)**  
*Creates a new task under an existing Application.*
  - **CFE\_Status\_t CFE\_ES\_GetTaskIDByName (CFE\_ES\_TaskId\_t \*TaskIdPtr, const char \*TaskName)**  
*Get a Task ID associated with a specified Task name.*
  - **CFE\_Status\_t CFE\_ES\_GetTaskName (char \*TaskName, CFE\_ES\_TaskId\_t TaskId, size\_t BufferLength)**  
*Get a Task name for a specified Task ID.*
  - **CFE\_Status\_t CFE\_ES\_DeleteChildTask (CFE\_ES\_TaskId\_t TaskId)**  
*Deletes a task under an existing Application.*
  - void **CFE\_ES\_ExitChildTask (void)**  
*Exits a child task.*
  - void **CFE\_ES\_BackgroundWakeup (void)**  
*Wakes up the CFE background task.*
  - **CFE\_Status\_t CFE\_ES\_WriteToSysLog (const char \*SpecStringPtr,...) OS\_PRINTF(1**  
*Write a string to the cFE System Log.*
  - **CFE\_Status\_t uint32 CFE\_ES\_CalculateCRC (const void \*DataPtr, size\_t DataLength, uint32 InputCRC, uint32 TypeCRC)**

- Calculate a CRC on a block of memory.*
- void [CFE\\_ES\\_ProcessAsyncEvent](#) (void)
 

*Notification that an asynchronous event was detected by the underlying OS/PSP.*
  - [CFE\\_Status\\_t CFE\\_ES\\_RegisterCDS](#) ([CFE\\_ES\\_CDSHandle\\_t](#) \*CDSHandlePtr, [size\\_t](#) BlockSize, const char \*Name)
 

*Reserve space (or re-obtain previously reserved space) in the Critical Data Store (CDS)*
  - [CFE\\_Status\\_t CFE\\_ES\\_GetCDSBlockIDByName](#) ([CFE\\_ES\\_CDSHandle\\_t](#) \*BlockIdPtr, const char \*BlockName)
 

*Get a CDS Block ID associated with a specified CDS Block name.*
  - [CFE\\_Status\\_t CFE\\_ES\\_GetCDSBlockName](#) (char \*BlockName, [CFE\\_ES\\_CDSHandle\\_t](#) BlockId, [size\\_t](#) BufferLength)
 

*Get a Block name for a specified Block ID.*
  - [CFE\\_Status\\_t CFE\\_ES\\_CopyToCDS](#) ([CFE\\_ES\\_CDSHandle\\_t](#) Handle, const void \*DataToCopy)
 

*Save a block of data in the Critical Data Store (CDS)*
  - [CFE\\_Status\\_t CFE\\_ES\\_RestoreFromCDS](#) (void \*RestoreToMemory, [CFE\\_ES\\_CDSHandle\\_t](#) Handle)
 

*Recover a block of data from the Critical Data Store (CDS)*
  - [CFE\\_Status\\_t CFE\\_ES\\_PoolCreateNoSem](#) ([CFE\\_ES\\_MemHandle\\_t](#) \*PoolID, void \*MemPtr, [size\\_t](#) Size)
 

*Initializes a memory pool created by an application without using a semaphore during processing.*
  - [CFE\\_Status\\_t CFE\\_ES\\_PoolCreate](#) ([CFE\\_ES\\_MemHandle\\_t](#) \*PoolID, void \*MemPtr, [size\\_t](#) Size)
 

*Initializes a memory pool created by an application while using a semaphore during processing.*
  - [CFE\\_Status\\_t CFE\\_ES\\_PoolCreateEx](#) ([CFE\\_ES\\_MemHandle\\_t](#) \*PoolID, void \*MemPtr, [size\\_t](#) Size, [uint16](#) NumBlockSizes, const [size\\_t](#) \*BlockSizes, bool UseMutex)
 

*Initializes a memory pool created by an application with application specified block sizes.*
  - int32 [CFE\\_ES\\_PoolDelete](#) ([CFE\\_ES\\_MemHandle\\_t](#) PoolID)
 

*Deletes a memory pool that was previously created.*
  - int32 [CFE\\_ES\\_GetPoolBuf](#) ([CFE\\_ES\\_MemPoolBuf\\_t](#) \*BufPtr, [CFE\\_ES\\_MemHandle\\_t](#) Handle, [size\\_t](#) Size)
 

*Gets a buffer from the memory pool created by [CFE\\_ES\\_PoolCreate](#) or [CFE\\_ES\\_PoolCreateNoSem](#).*
  - [CFE\\_Status\\_t CFE\\_ES\\_GetPoolBufInfo](#) ([CFE\\_ES\\_MemHandle\\_t](#) Handle, [CFE\\_ES\\_MemPoolBuf\\_t](#) BufPtr)
 

*Gets info on a buffer previously allocated via [CFE\\_ES\\_GetPoolBuf](#).*
  - int32 [CFE\\_ES\\_PutPoolBuf](#) ([CFE\\_ES\\_MemHandle\\_t](#) Handle, [CFE\\_ES\\_MemPoolBuf\\_t](#) BufPtr)
 

*Releases a buffer from the memory pool that was previously allocated via [CFE\\_ES\\_GetPoolBuf](#).*
  - [CFE\\_Status\\_t CFE\\_ES\\_GetMemPoolStats](#) ([CFE\\_ES\\_MemPoolStats\\_t](#) \*BufPtr, [CFE\\_ES\\_MemHandle\\_t](#) Handle)
 

*Extracts the statistics maintained by the memory pool software.*
  - void [CFE\\_ES\\_PerfLogAdd](#) ([uint32](#) Marker, [uint32](#) EntryExit)
 

*Adds a new entry to the data buffer.*
  - [CFE\\_Status\\_t CFE\\_ES\\_RegisterGenCounter](#) ([CFE\\_ES\\_CounterId\\_t](#) \*CounterIdPtr, const char \*CounterName)
 

*Register a generic counter.*
  - [CFE\\_Status\\_t CFE\\_ES\\_DeleteGenCounter](#) ([CFE\\_ES\\_CounterId\\_t](#) CounterId)
 

*Delete a generic counter.*
  - [CFE\\_Status\\_t CFE\\_ES\\_IncrementGenCounter](#) ([CFE\\_ES\\_CounterId\\_t](#) CounterId)
 

*Increments the specified generic counter.*
  - [CFE\\_Status\\_t CFE\\_ES\\_SetGenCount](#) ([CFE\\_ES\\_CounterId\\_t](#) CounterId, [uint32](#) Count)
 

*Set the specified generic counter.*
  - [CFE\\_Status\\_t CFE\\_ES\\_GetGenCount](#) ([CFE\\_ES\\_CounterId\\_t](#) CounterId, [uint32](#) \*Count)
 

*Get the specified generic counter count.*
  - [CFE\\_Status\\_t CFE\\_ES\\_GetGenCounterIDByName](#) ([CFE\\_ES\\_CounterId\\_t](#) \*CounterIdPtr, const char \*CounterName)
 

*Get the Id associated with a generic counter name.*
  - [CFE\\_Status\\_t CFE\\_ES\\_GetGenCounterName](#) (char \*CounterName, [CFE\\_ES\\_CounterId\\_t](#) CounterId, [size\\_t](#) BufferLength)
 

*Get a Counter name for a specified Counter ID.*

### 12.41.1 Detailed Description

Purpose: Unit specification for Executive Services library functions and macros.

References: Flight Software Branch C Coding Standard Version 1.0a cFE Flight Software Application Developers Guide

Notes:

### 12.41.2 Macro Definition Documentation

#### 12.41.2.1 CFE\_ES\_DBIT

```
#define CFE_ES_DBIT(  
    x ) (1L << (x)) /* Places a one at bit positions 0 thru 31 */
```

Definition at line 57 of file cfe\_es.h.

#### 12.41.2.2 CFE\_ES\_DTEST

```
#define CFE_ES_DTEST(  
    i,  
    x ) (((i)&CFE_ES_DBIT(x)) != 0) /* true iff bit x of i is set */
```

Definition at line 58 of file cfe\_es.h.

#### 12.41.2.3 CFE\_ES\_TEST\_LONG\_MASK

```
#define CFE_ES_TEST_LONG_MASK(  
    m,  
    s ) (CFE_ES_DTEST(m[(s) / 32], (s) % 32)) /* Test a bit within an array of 32-bit  
integers. */
```

Definition at line 59 of file cfe\_es.h.

#### 12.41.2.4 OS\_PRINTF

```
#define OS_PRINTF(  
    m,  
    n )
```

Definition at line 50 of file cfe\_es.h.

## 12.42 cfe/modules/core\_api/fsw/inc/cfe\_es\_api\_typedefs.h File Reference

```
#include "common_types.h"
#include "cfe_es_extern_typedefs.h"
```

### Data Structures

- union [CFE\\_ES\\_PoolAlign](#)

*Pool Alignment.*

### Macros

- #define [CFE\\_ES\\_STATIC\\_POOL\\_TYPE](#)(size)  
*Static Pool Type.*
- #define [CFE\\_ES\\_MEMPOOLBUF\\_C](#)(x) (([CFE\\_ES\\_MemPoolBuf\\_t](#))(x))  
*Conversion macro to create buffer pointer from another type.*
- #define [CFE\\_ES\\_NO\\_MUTEX](#) false  
*Indicates that the memory pool selection will not use a semaphore.*
- #define [CFE\\_ES\\_USE\\_MUTEX](#) true  
*Indicates that the memory pool selection will use a semaphore.*

### Reset Type extensions

- #define [CFE\\_ES\\_APP\\_RESTART](#) CFE\_PSP\_RST\_TYPE\_MAX

### Conversions for ES resource IDs

- #define [CFE\\_ES\\_APPID\\_C](#)(val) (([CFE\\_ES\\_AppId\\_t](#))CFE\_RESOURCEID\_WRAP(val))
- #define [CFE\\_ES\\_TASKID\\_C](#)(val) (([CFE\\_ES\\_TaskId\\_t](#))CFE\_RESOURCEID\_WRAP(val))
- #define [CFE\\_ES\\_LIBID\\_C](#)(val) (([CFE\\_ES\\_LibId\\_t](#))CFE\_RESOURCEID\_WRAP(val))
- #define [CFE\\_ES\\_COUNTERID\\_C](#)(val) (([CFE\\_ES\\_CounterId\\_t](#))CFE\_RESOURCEID\_WRAP(val))
- #define [CFE\\_ES\\_MEMHANDLE\\_C](#)(val) (([CFE\\_ES\\_MemHandle\\_t](#))CFE\_RESOURCEID\_WRAP(val))
- #define [CFE\\_ES\\_CDSHANDLE\\_C](#)(val) (([CFE\\_ES\\_CDSHandle\\_t](#))CFE\_RESOURCEID\_WRAP(val))

### Type-specific initializers for "undefined" resource IDs

- #define [CFE\\_ES\\_APPID\\_UNDEFINED](#) CFE\_ES\_APPID\_C(CFE\_RESOURCEID\_UNDEFINED)
- #define [CFE\\_ES\\_TASKID\\_UNDEFINED](#) CFE\_ES\_TASKID\_C(CFE\_RESOURCEID\_UNDEFINED)
- #define [CFE\\_ES\\_LIBID\\_UNDEFINED](#) CFE\_ES\_LIBID\_C(CFE\_RESOURCEID\_UNDEFINED)
- #define [CFE\\_ES\\_COUNTERID\\_UNDEFINED](#) CFE\_ES\_COUNTERID\_C(CFE\_RESOURCEID\_UNDEFINED)
- #define [CFE\\_ES\\_MEMHANDLE\\_UNDEFINED](#) CFE\_ES\_MEMHANDLE\_C(CFE\_RESOURCEID\_UNDEFINED)
- #define [CFE\\_ES\\_CDS\\_BAD\\_HANDLE](#) CFE\_ES\_CDSHANDLE\_C(CFE\_RESOURCEID\_UNDEFINED)

### Task Stack Constants

- #define [CFE\\_ES\\_TASK\\_STACK\\_ALLOCATE](#) NULL /\* aka OS\_TASK\_STACK\_ALLOCATE in proposed O↔SAL change \*/  
*Indicates that the stack for the child task should be dynamically allocated.*

## Typedefs

- `typedef void(* CFE_ES_TaskEntryFuncPtr_t) (void)`  
*Required Prototype of Task Main Functions.*
- `typedef int32(* CFE_ES_LibraryEntryFuncPtr_t) (CFE_ES_LibId_t LibId)`  
*Required Prototype of Library Initialization Functions.*
- `typedef CFE_ES_TaskEntryFuncPtr_t CFE_ES_ChildTaskMainFuncPtr_t`  
*Compatible typedef for ES child task entry point.*
- `typedef void * CFE_ES_StackPointer_t`  
*Type for the stack pointer of tasks.*
- `typedef union CFE_ES_PoolAlign CFE_ES_PoolAlign_t`  
*Pool Alignment.*
- `typedef void * CFE_ES_MemPoolBuf_t`  
*Pointer type used for memory pool API.*

### 12.42.1 Detailed Description

Purpose: Unit specification for Executive Services library functions and macros.

References: Flight Software Branch C Coding Standard Version 1.0a cFE Flight Software Application Developers Guide

Notes:

### 12.42.2 Macro Definition Documentation

#### 12.42.2.1 CFE\_ES\_APP\_RESTART

```
#define CFE_ES_APP_RESTART CFE_PSP_RST_TYPE_MAX
```

Application only was reset (extend the PSP enumeration here)

Definition at line 57 of file cfe\_es\_api\_typedefs.h.

#### 12.42.2.2 CFE\_ES\_APPID\_C

```
#define CFE_ES_APPID_C(
    val ) ((CFE_ES_AppId_t)CFE_RESOURCEID_WRAP(val))
```

Definition at line 156 of file cfe\_es\_api\_typedefs.h.

#### 12.42.2.3 CFE\_ES\_APPID\_UNDEFINED

```
#define CFE_ES_APPID_UNDEFINED CFE_ES_APPID_C(CFE_RESOURCEID_UNDEFINED)
```

Definition at line 168 of file cfe\_es\_api\_typedefs.h.

#### 12.42.2.4 CFE\_ES\_CDS\_BAD\_HANDLE

```
#define CFE_ES_CDS_BAD_HANDLE CFE_ES_CDSHANDLE_C(CFE_RESOURCEID_UNDEFINED)
```

Definition at line 173 of file cfe\_es\_api\_typedefs.h.

Referenced by DS\_TableCreateCDS(), and DS\_TableUpdateCDS().

#### 12.42.2.5 CFE\_ES\_CDSHANDLE\_C

```
#define CFE_ES_CDSHANDLE_C( val ) ((CFE_ES_CDCHandle_t)CFE_RESOURCEID_WRAP(val))
```

Definition at line 161 of file cfe\_es\_api\_typedefs.h.

#### 12.42.2.6 CFE\_ES\_COUNTERID\_C

```
#define CFE_ES_COUNTERID_C( val ) ((CFE_ES_CounterId_t)CFE_RESOURCEID_WRAP(val))
```

Definition at line 159 of file cfe\_es\_api\_typedefs.h.

#### 12.42.2.7 CFE\_ES\_COUNTERID\_UNDEFINED

```
#define CFE_ES_COUNTERID_UNDEFINED CFE_ES_COUNTERID_C(CFE_RESOURCEID_UNDEFINED)
```

Definition at line 171 of file cfe\_es\_api\_typedefs.h.

#### 12.42.2.8 CFE\_ES\_LIBID\_C

```
#define CFE_ES_LIBID_C( val ) ((CFE_ES_LibId_t)CFE_RESOURCEID_WRAP(val))
```

Definition at line 158 of file cfe\_es\_api\_typedefs.h.

#### 12.42.2.9 CFE\_ES\_LIBID\_UNDEFINED

```
#define CFE_ES_LIBID_UNDEFINED CFE_ES_LIBID_C(CFE_RESOURCEID_UNDEFINED)
```

Definition at line 170 of file cfe\_es\_api\_typedefs.h.

#### 12.42.2.10 CFE\_ES\_MEMHANDLE\_C

```
#define CFE_ES_MEMHANDLE_C( val ) ((CFE_ES_MemHandle_t)CFE_RESOURCEID_WRAP(val))
```

Definition at line 160 of file cfe\_es\_api\_typedefs.h.

#### 12.42.2.11 CFE\_ES\_MEMHANDLE\_UNDEFINED

```
#define CFE_ES_MEMHANDLE_UNDEFINED CFE_ES_MEMHANDLE_C(CFE_RESOURCEID_UNDEFINED)
```

Definition at line 172 of file cfe\_es\_api\_typedefs.h.

#### 12.42.2.12 CFE\_ES\_MEMPOOLBUF\_C

```
#define CFE_ES_MEMPOOLBUF_C( x ) ((CFE_ES_MemPoolBuf_t)(x))
```

Conversion macro to create buffer pointer from another type.

In cases where the actual buffer pointer is computed, this macro aids in converting the computed address (typically an OSAL "cpuaddr" type) into a buffer pointer.

##### Note

Any address calculation needs to take machine alignment requirements into account.

Definition at line 141 of file cfe\_es\_api\_typedefs.h.

#### 12.42.2.13 CFE\_ES\_NO\_MUTEX

```
#define CFE_ES_NO_MUTEX false
```

Indicates that the memory pool selection will not use a semaphore.

Definition at line 188 of file cfe\_es\_api\_typedefs.h.

#### 12.42.2.14 CFE\_ES\_STATIC\_POOL\_TYPE

```
#define CFE_ES_STATIC_POOL_TYPE(
    size )
```

**Value:**

```
union \
{ \
    CFE_ES_PoolAlign_t Align; \
    uint8             Data[size]; \
}
```

Static Pool Type.

A macro to help instantiate static memory pools that are correctly aligned. This resolves to a union type that contains a member called "Data" that will be correctly aligned to be a memory pool and sized according to the argument.

Definition at line 108 of file cfe\_es\_api\_typedefs.h.

#### 12.42.2.15 CFE\_ES\_TASK\_STACK\_ALLOCATE

```
#define CFE_ES_TASK_STACK_ALLOCATE NULL /* aka OS_TASK_STACK_ALLOCATE in proposed OSAL change */
```

Indicates that the stack for the child task should be dynamically allocated.

This value may be supplied as the Stack Pointer argument to CFE\_ES\_ChildTaskCreate() to indicate that the stack should be dynamically allocated.

Definition at line 185 of file cfe\_es\_api\_typedefs.h.

#### 12.42.2.16 CFE\_ES\_TASKID\_C

```
#define CFE_ES_TASKID_C(
    val ) ((CFE_ES_TaskId_t)CFE_RESOURCEID_WRAP(val))
```

Definition at line 157 of file cfe\_es\_api\_typedefs.h.

#### 12.42.2.17 CFE\_ES\_TASKID\_UNDEFINED

```
#define CFE_ES_TASKID_UNDEFINED CFE_ES_TASKID_C(CFE_RESOURCEID_UNDEFINED)
```

Definition at line 169 of file cfe\_es\_api\_typedefs.h.

### 12.42.2.18 CFE\_ES\_USE\_MUTEX

```
#define CFE_ES_USE_MUTEX true
```

Indicates that the memory pool selection will use a semaphore.

Definition at line 189 of file cfe\_es\_api\_typedefs.h.

## 12.42.3 TYPEDEF Documentation

### 12.42.3.1 CFE\_ES\_ChildTaskMainFuncPtr\_t

```
typedef CFE_ES_TaskEntryFuncPtr_t CFE_ES_ChildTaskMainFuncPtr_t
```

Compatible typedef for ES child task entry point.

All ES task functions (main + child) use the same entry point type.

Definition at line 77 of file cfe\_es\_api\_typedefs.h.

### 12.42.3.2 CFE\_ES\_LibraryEntryFuncPtr\_t

```
typedef int32 (* CFE_ES_LibraryEntryFuncPtr_t) (CFE_ES_LibId_t LibId)
```

Required Prototype of Library Initialization Functions.

Definition at line 69 of file cfe\_es\_api\_typedefs.h.

### 12.42.3.3 CFE\_ES\_MemPoolBuf\_t

```
typedef void* CFE_ES_MemPoolBuf_t
```

Pointer type used for memory pool API.

This is used in the Get/Put API calls to refer to a pool buffer.

This pointer is expected to be type cast to the real object type after getting a new buffer. Using void\* allows this type conversion to occur easily.

#### Note

Older versions of CFE implemented the API using a uint32\*, which required explicit type casting everywhere it was called. Although the API type is now void\* to make usage easier, the pool buffers are aligned to machine requirements - typically 64 bits.

Definition at line 129 of file cfe\_es\_api\_typedefs.h.

#### 12.42.3.4 CFE\_ES\_PoolAlign\_t

```
typedef union CFE_ES_PoolAlign CFE_ES_PoolAlign_t
```

Pool Alignment.

Union that can be used for minimum memory alignment of ES memory pools on the target. It contains the longest native data types such that the alignment of this structure should reflect the largest possible alignment requirements for any data on this processor.

#### 12.42.3.5 CFE\_ES\_StackPointer\_t

```
typedef void* CFE_ES_StackPointer_t
```

Type for the stack pointer of tasks.

This type is used in the CFE ES task API.

Definition at line 84 of file cfe\_es\_api\_typedefs.h.

#### 12.42.3.6 CFE\_ES\_TaskEntryFuncPtr\_t

```
typedef void(* CFE_ES_TaskEntryFuncPtr_t) (void)
```

Required Prototype of Task Main Functions.

Definition at line 68 of file cfe\_es\_api\_typedefs.h.

### 12.43 cfe/modules/core\_api/fsw/inc/cfe\_es\_extern\_typedefs.h File Reference

```
#include "common_types.h"
#include "cfe_resourceid_typedef.h"
#include "cfe_mission_cfg.h"
```

#### Data Structures

- struct [CFE\\_ES\\_AppInfo](#)  
*Application Information.*
- struct [CFE\\_ES\\_TaskInfo](#)  
*Task Information.*
- struct [CFE\\_ES\\_CDSRegDumpRec](#)  
*CDS Register Dump Record.*
- struct [CFE\\_ES\\_BlockStats](#)  
*Block statistics.*
- struct [CFE\\_ES\\_MemPoolStats](#)  
*Memory Pool Statistics.*

## Macros

- #define CFE\_ES\_MEMOFFSET\_C(x) ((CFE\_ES\_MemOffset\_t)(x))
- #define CFE\_ES\_MEMADDRESS\_C(x) ((CFE\_ES\_MemAddress\_t)((cpuaddr)(x)&0xFFFFFFFF))

## TypeDefs

- typedef uint8 CFE\_ES\_LogMode\_Enum\_t  
*Identifies handling of log messages after storage is filled.*
- typedef uint8 CFE\_ES\_ExceptionAction\_Enum\_t  
*Identifies action to take if exception occurs.*
- typedef uint8 CFE\_ES\_AppType\_Enum\_t  
*Identifies type of CFE application.*
- typedef uint32 CFE\_ES\_RunStatus\_Enum\_t  
*Run Status and Exit Status identifiers.*
- typedef uint32 CFE\_ES\_SystemState\_Enum\_t  
*The overall cFE System State.*
- typedef uint8 CFE\_ES\_LogEntryType\_Enum\_t  
*Type of entry in the Error and Reset (ER) Log.*
- typedef uint32 CFE\_ES\_AppState\_Enum\_t  
*Application Run State.*
- typedef CFE\_RESOURCEID\_BASE\_TYPE CFE\_ES\_AppId\_t  
*A type for Application IDs.*
- typedef CFE\_RESOURCEID\_BASE\_TYPE CFE\_ES\_TaskId\_t  
*A type for Task IDs.*
- typedef CFE\_RESOURCEID\_BASE\_TYPE CFE\_ES\_LibId\_t  
*A type for Library IDs.*
- typedef CFE\_RESOURCEID\_BASE\_TYPE CFE\_ES\_CounterId\_t  
*A type for Counter IDs.*
- typedef CFE\_RESOURCEID\_BASE\_TYPE CFE\_ES\_MemHandle\_t  
*Memory Handle type.*
- typedef CFE\_RESOURCEID\_BASE\_TYPE CFE\_ES\_CDSHandle\_t  
*CDS Handle type.*
- typedef uint16 CFE\_ES\_TaskPriority\_Atom\_t  
*Type used for task priority in CFE ES as including the commands/telemetry messages.*
- typedef uint32 CFE\_ES\_MemOffset\_t  
*Type used for memory sizes and offsets in commands and telemetry.*
- typedef uint32 CFE\_ES\_MemAddress\_t  
*Type used for memory addresses in command and telemetry messages.*
- typedef struct CFE\_ES\_AppInfo CFE\_ES\_AppInfo\_t  
*Application Information.*
- typedef struct CFE\_ES\_TaskInfo CFE\_ES\_TaskInfo\_t  
*Task Information.*
- typedef struct CFE\_ES\_CDSRegDumpRec CFE\_ES\_CDSRegDumpRec\_t  
*CDS Register Dump Record.*
- typedef struct CFE\_ES\_BlockStats CFE\_ES\_BlockStats\_t  
*Block statistics.*
- typedef struct CFE\_ES\_MemPoolStats CFE\_ES\_MemPoolStats\_t  
*Memory Pool Statistics.*

## Enumerations

- enum `CFE_ES_LogMode` { `CFE_ES_LogMode_OVERWRITE` = 0, `CFE_ES_LogMode_DISCARD` = 1 }  
*Label definitions associated with CFE\_ES\_LogMode\_Enum\_t.*
- enum `CFE_ES_ExceptionAction` { `CFE_ES_ExceptionAction_RESTART_APP` = 0, `CFE_ES_ExceptionAction_PROC_RESTART` = 1 }  
*Label definitions associated with CFE\_ES\_ExceptionAction\_Enum\_t.*
- enum `CFE_ES_AppType` { `CFE_ES_AppType_CORE` = 1, `CFE_ES_AppType_EXTERNAL` = 2, `CFE_ES_AppType_LIBRARY` = 3 }  
*Label definitions associated with CFE\_ES\_AppType\_Enum\_t.*
- enum `CFE_ES_RunStatus` {  
`CFE_ES_RunStatus_UNDEFINED` = 0, `CFE_ES_RunStatus_APP_RUN` = 1, `CFE_ES_RunStatus_APP_EXIT` = 2, `CFE_ES_RunStatus_APP_ERROR` = 3,  
`CFE_ES_RunStatus_SYS_EXCEPTION` = 4, `CFE_ES_RunStatus_SYS_RESTART` = 5, `CFE_ES_RunStatus_SYS_RELOAD` = 6, `CFE_ES_RunStatus_SYS_DELETE` = 7,  
`CFE_ES_RunStatus_CORE_APP_INIT_ERROR` = 8, `CFE_ES_RunStatus_CORE_APP_RUNTIME_ERROR` = 9, `CFE_ES_RunStatus_MAX` }  
*Label definitions associated with CFE\_ES\_RunStatus\_Enum\_t.*
- enum `CFE_ES_SystemState` {  
`CFE_ES_SystemState_UNDEFINED` = 0, `CFE_ES_SystemState_EARLY_INIT` = 1, `CFE_ES_SystemState_CORE_STARTUP` = 2, `CFE_ES_SystemState_CORE_READY` = 3,  
`CFE_ES_SystemState_APPS_INIT` = 4, `CFE_ES_SystemState_OPERATIONAL` = 5, `CFE_ES_SystemState_SHUTDOWN` = 6, `CFE_ES_SystemState_MAX` }  
*Label definitions associated with CFE\_ES\_SystemState\_Enum\_t.*
- enum `CFE_ES_LogEntryType` { `CFE_ES_LogEntryType_CORE` = 1, `CFE_ES_LogEntryType_APPLICATION` = 2 }  
*Label definitions associated with CFE\_ES\_LogEntryType\_Enum\_t.*
- enum `CFE_ES_AppState` {  
`CFE_ES_AppState_UNDEFINED` = 0, `CFE_ES_AppState_EARLY_INIT` = 1, `CFE_ES_AppState_LATE_INIT` = 2, `CFE_ES_AppState_RUNNING` = 3,  
`CFE_ES_AppState_WAITING` = 4, `CFE_ES_AppState_STOPPED` = 5, `CFE_ES_AppState_MAX` }  
*Label definitions associated with CFE\_ES\_AppState\_Enum\_t.*

### 12.43.1 Detailed Description

Declarations and prototypes for `cfe_es_extern_typedefs` module

### 12.43.2 Macro Definition Documentation

#### 12.43.2.1 `CFE_ES_MEMADDRESS_C`

```
#define CFE_ES_MEMADDRESS_C(  
    x ) ((CFE_ES_MemAddress_t)((cpuaddr) (x)&0xFFFFFFFF))
```

Definition at line 426 of file `cfe_es_extern_typedefs.h`.

### 12.43.2.2 CFE\_ES\_MEMOFFSET\_C

```
#define CFE_ES_MEMOFFSET_C(  
    x ) ( (CFE_ES_MemOffset_t)(x))
```

Definition at line 395 of file cfe\_es\_extern\_typedefs.h.

### 12.43.3 TYPEDEF Documentation

#### 12.43.3.1 CFE\_ES\_AppId\_t

```
typedef CFE_RESOURCEID_BASE_TYPE CFE_ES_AppId_t
```

A type for Application IDs.

This is the type that is used for any API accepting or returning an App ID

Definition at line 329 of file cfe\_es\_extern\_typedefs.h.

#### 12.43.3.2 CFE\_ES\_AppInfo\_t

```
typedef struct CFE_ES_AppInfo CFE_ES_AppInfo_t
```

Application Information.

Structure that is used to provide information about an app. It is primarily used for the QueryOne and QueryAll Commands.

While this structure is primarily intended for Application info, it can also represent Library information where only a subset of the information applies.

#### 12.43.3.3 CFE\_ES\_AppState\_Enum\_t

```
typedef uint32 CFE_ES_AppState_Enum_t
```

Application Run State.

The normal progression of APP states: UNDEFINED -> EARLY\_INIT -> LATE\_INIT -> RUNNING -> WAITING -> STOPPED

##### Note

These are defined in order so that relational comparisons e.g. if (STATEA < STATEB) are possible

##### See also

enum [CFE\\_ES\\_AppState](#)

Definition at line 322 of file cfe\_es\_extern\_typedefs.h.

#### 12.43.3.4 CFE\_ES\_AppType\_Enum\_t

```
typedef uint8 CFE_ES_AppType_Enum_t
```

Identifies type of CFE application.

##### See also

enum [CFE\\_ES\\_AppType](#)

Definition at line 117 of file `cfe_es_extern_typedefs.h`.

#### 12.43.3.5 CFE\_ES\_BlockStats\_t

```
typedef struct CFE_ES_BlockStats CFE_ES_BlockStats_t
```

Block statistics.

Sub-Structure that is used to provide information about a specific block size/bucket within a memory pool.

#### 12.43.3.6 CFE\_ES\_CDSHandle\_t

```
typedef CFE_RESOURCEID_BASE_TYPE CFE_ES_CDSHandle_t
```

CDS Handle type.

Data type used to hold Handles of Critical Data Stores. See [CFE\\_ES\\_RegisterCDS](#)

Definition at line 365 of file `cfe_es_extern_typedefs.h`.

#### 12.43.3.7 CFE\_ES\_CDSRegDumpRec\_t

```
typedef struct CFE_ES_CDSRegDumpRec CFE_ES_CDSRegDumpRec_t
```

CDS Register Dump Record.

Structure that is used to provide information about a critical data store. It is primarily used for the Dump CDS registry ([CFE\\_ES\\_DUMP\\_CDS\\_REGISTRY\\_CC](#)) command.

##### Note

There is not currently a telemetry message directly containing this data structure, but it does define the format of the data file generated by the Dump CDS registry command. Therefore it should be considered part of the overall telemetry interface.

### 12.43.3.8 CFE\_ES\_CounterId\_t

```
typedef CFE_RESOURCEID_BASE_TYPE CFE_ES_CounterId_t
```

A type for Counter IDs.

This is the type that is used for any API accepting or returning a Counter ID

Definition at line 350 of file cfe\_es\_extern\_typedefs.h.

### 12.43.3.9 CFE\_ES\_ExceptionAction\_Enum\_t

```
typedef uint8 CFE_ES_ExceptionAction_Enum_t
```

Identifies action to take if exception occurs.

See also

enum [CFE\\_ES\\_ExceptionAction](#)

Definition at line 88 of file cfe\_es\_extern\_typedefs.h.

### 12.43.3.10 CFE\_ES\_LibId\_t

```
typedef CFE_RESOURCEID_BASE_TYPE CFE_ES_LibId_t
```

A type for Library IDs.

This is the type that is used for any API accepting or returning a Lib ID

Definition at line 343 of file cfe\_es\_extern\_typedefs.h.

### 12.43.3.11 CFE\_ES\_LogEntryType\_Enum\_t

```
typedef uint8 CFE_ES_LogEntryType_Enum_t
```

Type of entry in the Error and Reset (ER) Log.

See also

enum [CFE\\_ES\\_LogEntryType](#)

Definition at line 268 of file cfe\_es\_extern\_typedefs.h.

#### 12.43.3.12 CFE\_ES\_LogMode\_Enum\_t

```
typedef uint8 CFE_ES_LogMode_Enum_t
```

Identifies handling of log messages after storage is filled.

See also

enum [CFE\\_ES\\_LogMode](#)

Definition at line 64 of file cfe\_es\_extern\_typedefs.h.

#### 12.43.3.13 CFE\_ES\_MemAddress\_t

```
typedef uint32 CFE_ES_MemAddress_t
```

Type used for memory addresses in command and telemetry messages.

For backward compatibility with existing CFE code this should be uint32, but if running on a 64-bit platform, addresses in telemetry will be truncated to 32 bits and therefore will not be valid.

On 64-bit platforms this can be a 64-bit address which will allow the full memory address in commands and telemetry, but this will break compatibility with existing control systems, and may also change the alignment/padding of messages.

In either case this must be an unsigned type.

FSW code should access this value via the macros provided, which converts to the native "cpuaddr" type provided by OSAL. This macro provides independence between the message representation and local representation of a memory address.

Definition at line 416 of file cfe\_es\_extern\_typedefs.h.

#### 12.43.3.14 CFE\_ES\_MemHandle\_t

```
typedef CFE_RESOURCEID_BASE_TYPE CFE_ES_MemHandle_t
```

Memory Handle type.

Data type used to hold Handles of Memory Pools created via CFE\_ES\_PoolCreate and CFE\_ES\_PoolCreateNoSem

Definition at line 358 of file cfe\_es\_extern\_typedefs.h.

### 12.43.3.15 CFE\_ES\_MemOffset\_t

```
typedef uint32 CFE_ES_MemOffset_t
```

Type used for memory sizes and offsets in commands and telemetry.

For backward compatibility with existing CFE code this should be uint32, but all telemetry information will be limited to 4GB in size as a result.

On 64-bit platforms this can be a 64-bit value which will allow larger memory objects, but this will break compatibility with existing control systems, and may also change the alignment/padding of messages.

In either case this must be an unsigned type.

Definition at line 389 of file cfe\_es\_extern\_typedefs.h.

### 12.43.3.16 CFE\_ES\_MemPoolStats\_t

```
typedef struct CFE_ES_MemPoolStats CFE_ES_MemPoolStats_t
```

Memory Pool Statistics.

Structure that is used to provide information about a memory pool. Used by the Memory Pool Stats telemetry message.

See also

[CFE\\_ES\\_SEND\\_MEM\\_POOL\\_STATS\\_CC](#)

### 12.43.3.17 CFE\_ES\_RunStatus\_Enum\_t

```
typedef uint32 CFE_ES_RunStatus_Enum_t
```

Run Status and Exit Status identifiers.

See also

enum [CFE\\_ES\\_RunStatus](#)

Definition at line 186 of file cfe\_es\_extern\_typedefs.h.

#### 12.43.3.18 CFE\_ES\_SystemState\_Enum\_t

```
typedef uint32 CFE_ES_SystemState_Enum_t
```

The overall cFE System State.

These values are used with the [CFE\\_ES\\_WaitForSystemState](#) API call to synchronize application startup.

##### Note

These are defined in order so that relational comparisons e.g. if (STATEA < STATEB) are possible

##### See also

enum [CFE\\_ES\\_SystemState](#)

Definition at line 244 of file cfe\_es\_extern\_typedefs.h.

#### 12.43.3.19 CFE\_ES\_TaskId\_t

```
typedef CFE_RESOURCEID_BASE_TYPE CFE_ES_TaskId_t
```

A type for Task IDs.

This is the type that is used for any API accepting or returning a Task ID

Definition at line 336 of file cfe\_es\_extern\_typedefs.h.

#### 12.43.3.20 CFE\_ES\_TaskInfo\_t

```
typedef struct CFE_ES_TaskInfo CFE_ES_TaskInfo_t
```

Task Information.

Structure that is used to provide information about a task. It is primarily used for the Query All Tasks ([CFE\\_ES\\_QUERY\\_ALL\\_TASKS\\_CC](#)) command.

##### Note

There is not currently a telemetry message directly containing this data structure, but it does define the format of the data file generated by the Query All Tasks command. Therefore it should be considered part of the overall telemetry interface.

### 12.43.3.21 CFE\_ES\_TaskPriority\_Atom\_t

```
typedef uint16 CFE_ES_TaskPriority_Atom_t
```

Type used for task priority in CFE ES as including the commands/telemetry messages.

#### Note

the valid range is only 0-255 (same as OSAL) but a wider type is used for backward compatibility in binary formats of messages.

Definition at line 375 of file cfe\_es\_extern\_typedefs.h.

### 12.43.4 Enumeration Type Documentation

#### 12.43.4.1 CFE\_ES\_AppState

```
enum CFE_ES_AppState
```

Label definitions associated with CFE\_ES\_AppState\_Enum\_t.

##### Enumerator

CFE_ES_AppState_UNDEFINED	Initial state before app thread is started.
CFE_ES_AppState_EARLY_INIT	App thread has started, app performing early initialization of its own data.
CFE_ES_AppState_LATE_INIT	Early/Local initialization is complete. First sync point.
CFE_ES_AppState_RUNNING	All initialization is complete. Second sync point.
CFE_ES_AppState_WAITING	Application is waiting on a Restart/Reload/Delete request.
CFE_ES_AppState_STOPPED	Application is stopped.
CFE_ES_AppState_MAX	Reserved entry, marker for the maximum state.

Definition at line 273 of file cfe\_es\_extern\_typedefs.h.

#### 12.43.4.2 CFE\_ES\_AppType

```
enum CFE_ES_AppType
```

Label definitions associated with CFE\_ES\_AppType\_Enum\_t.

##### Enumerator

CFE_ES_AppType_CORE	CFE core application.
CFE_ES_AppType_EXTERNAL	CFE external application.
CFE_ES_AppType_LIBRARY	CFE library.

Definition at line 93 of file cfe\_es\_extern\_typedefs.h.

#### 12.43.4.3 CFE\_ES\_ExceptionAction

```
enum CFE_ES_ExceptionAction
```

Label definitions associated with CFE\_ES\_ExceptionAction\_Enum\_t.

Enumerator

CFE_ES_ExceptionAction_RESTART_APP	Restart application if exception occurs.
CFE_ES_ExceptionAction_PROC_RESTART	Restart processor if exception occurs.

Definition at line 69 of file cfe\_es\_extern\_typedefs.h.

#### 12.43.4.4 CFE\_ES\_LogEntryType

```
enum CFE_ES_LogEntryType
```

Label definitions associated with CFE\_ES\_LogEntryType\_Enum\_t.

Enumerator

CFE_ES_LogEntryType_CORE	Log entry from a core subsystem.
CFE_ES_LogEntryType_APPLICATION	Log entry from an application.

Definition at line 249 of file cfe\_es\_extern\_typedefs.h.

#### 12.43.4.5 CFE\_ES\_LogMode

```
enum CFE_ES_LogMode
```

Label definitions associated with CFE\_ES\_LogMode\_Enum\_t.

Enumerator

CFE_ES_LogMode_OVERWRITE	Overwrite Log Mode.
CFE_ES_LogMode_DISCARD	Discard Log Mode.

Definition at line 45 of file cfe\_es\_extern\_typedefs.h.

#### 12.43.4.6 CFE\_ES\_RunStatus

enum [CFE\\_ES\\_RunStatus](#)

Label definitions associated with CFE\_ES\_RunStatus\_Enum\_t.

##### Enumerator

CFE_ES_RunStatus_UNDEFINED	Reserved value, should not be used.
CFE_ES_RunStatus_APP_RUN	Indicates that the Application should continue to run.
CFE_ES_RunStatus_APP_EXIT	Indicates that the Application wants to exit normally.
CFE_ES_RunStatus_APP_ERROR	Indicates that the Application is quitting with an error.
CFE_ES_RunStatus_SYS_EXCEPTION	The cFE App caused an exception.
CFE_ES_RunStatus_SYS_RESTART	The system is requesting a restart of the cFE App.
CFE_ES_RunStatus_SYS_RELOAD	The system is requesting a reload of the cFE App.
CFE_ES_RunStatus_SYS_DELETE	The system is requesting that the cFE App is stopped.
CFE_ES_RunStatus_CORE_APP_INIT_ERROR	Indicates that the Core Application could not Init.
CFE_ES_RunStatus_CORE_APP_RUNTIME_ERROR	Indicates that the Core Application had a runtime failure.
CFE_ES_RunStatus_MAX	Reserved value, marker for the maximum state.

Definition at line 122 of file `cfe_es_extern_typedefs.h`.

#### 12.43.4.7 CFE\_ES\_SystemState

enum [CFE\\_ES\\_SystemState](#)

Label definitions associated with CFE\_ES\_SystemState\_Enum\_t.

##### Enumerator

CFE_ES_SystemState_UNDEFINED	reserved
CFE_ES_SystemState_EARLY_INIT	single threaded mode while setting up CFE itself
CFE_ES_SystemState_CORE_STARTUP	core apps (CFE_ES_ObjectTable) are starting (multi-threaded)
CFE_ES_SystemState_CORE_READY	core is ready, starting other external apps/libraries (if any)
CFE_ES_SystemState_APPS_INIT	startup apps have all completed their early init, but not necessarily operational yet
CFE_ES_SystemState_OPERATIONAL	normal operation mode; all apps are RUNNING
CFE_ES_SystemState_SHUTDOWN	reserved for future use, all apps would be STOPPED
CFE_ES_SystemState_MAX	Reserved value, marker for the maximum state.

Definition at line 191 of file `cfe_es_extern_typedefs.h`.

## 12.44 cfe/modules/core\_api/fsw/inc/cfe\_evs.h File Reference

```
#include "common_types.h"
#include "cfe_error.h"
#include "cfe_evs_api_typedefs.h"
#include "cfe_es_api_typedefs.h"
#include "cfe_time_api_typedefs.h"
```

### Macros

- #define CFE\_EVS\_Send(E, T, ...) CFE\_EVS\_SendEvent((E), CFE\_EVS\_EventType\_##T, \_\_VA\_ARGS\_\_)
- #define CFE\_EVS\_SendDbg(E, ...) CFE\_EVS\_Send(E, DEBUG, \_\_VA\_ARGS\_\_)
- #define CFE\_EVS\_SendInfo(E, ...) CFE\_EVS\_Send(E, INFORMATION, \_\_VA\_ARGS\_\_)
- #define CFE\_EVS\_SendErr(E, ...) CFE\_EVS\_Send(E, ERROR, \_\_VA\_ARGS\_\_)
- #define CFE\_EVS\_SendCrit(E, ...) CFE\_EVS\_Send(E, CRITICAL, \_\_VA\_ARGS\_\_)

### Functions

- CFE\_Status\_t CFE\_EVS\_Register (const void \*Filters, uint16 NumEventFilters, uint16 FilterScheme)
 

*Register an application for receiving event services.*
- CFE\_Status\_t CFE\_EVS\_SendEvent (uint16 EventID, uint16 EventType, const char \*Spec,...) OS\_PRINTF(3
 

*Generate a software event.*
- CFE\_Status\_t CFE\_Status\_t CFE\_EVS\_SendEventWithAppID (uint16 EventID, uint16 EventType, CFE\_ES\_AppID\_t AppID, const char \*Spec,...) OS\_PRINTF(4
 

*Generate a software event given the specified Application ID.*
- CFE\_Status\_t CFE\_Status\_t CFE\_Status\_t CFE\_EVS\_SendTimedEvent (CFE\_TIME\_SysTime\_t Time, uint16 EventID, uint16 EventType, const char \*Spec,...) OS\_PRINTF(4
 

*Generate a software event with a specific time tag.*
- CFE\_Status\_t CFE\_EVS\_ResetFilter (uint16 EventID)
 

*Resets the calling application's event filter for a single event ID.*
- CFE\_Status\_t CFE\_EVS\_ResetAllFilters (void)
 

*Resets all of the calling application's event filters.*

### 12.44.1 Detailed Description

Title: Event Services API Application Library Header File

Purpose: Unit specification for Event services library functions and macros.

Design Notes:

References: Flight Software Branch C Coding Standard Version 1.0a

### 12.44.2 Macro Definition Documentation

#### 12.44.2.1 CFE\_EVS\_Send

```
#define CFE_EVS_Send(  
    E,  
    T,  
    ... ) CFE_EVS_SendEvent ((E), CFE_EVS_EventType_##T, __VA_ARGS__)
```

Definition at line 46 of file cfe\_evs.h.

#### 12.44.2.2 CFE\_EVS\_SendCrit

```
#define CFE_EVS_SendCrit(  
    E,  
    ... ) CFE_EVS_Send(E, CRITICAL, __VA_ARGS__)
```

Definition at line 50 of file cfe\_evs.h.

#### 12.44.2.3 CFE\_EVS\_SendDbg

```
#define CFE_EVS_SendDbg(  
    E,  
    ... ) CFE_EVS_Send(E, DEBUG, __VA_ARGS__)
```

Definition at line 47 of file cfe\_evs.h.

#### 12.44.2.4 CFE\_EVS\_SendErr

```
#define CFE_EVS_SendErr(  
    E,  
    ... ) CFE_EVS_Send(E, ERROR, __VA_ARGS__)
```

Definition at line 49 of file cfe\_evs.h.

#### 12.44.2.5 CFE\_EVS\_SendInfo

```
#define CFE_EVS_SendInfo(  
    E,  
    ... ) CFE_EVS_Send(E, INFORMATION, __VA_ARGS__)
```

Definition at line 48 of file cfe\_evs.h.

## 12.45 cfe/modules/core\_api/fsw/inc/cfe\_evs\_api\_typedefs.h File Reference

```
#include "common_types.h"
#include "cfe_evs_extern_typedefs.h"
```

### Data Structures

- struct [CFE\\_EVS\\_BinFilter](#)

*Event message filter definition structure.*

### Macros

#### Common Event Filter Mask Values

*Message is sent if (previous event count) & MASK == 0*

- #define [CFE\\_EVS\\_NO\\_FILTER](#) 0x0000  
*Stops any filtering. All messages are sent.*
- #define [CFE\\_EVS\\_FIRST\\_ONE\\_STOP](#) 0xFFFF  
*Sends the first event. All remaining messages are filtered.*
- #define [CFE\\_EVS\\_FIRST\\_TWO\\_STOP](#) 0xFFFE  
*Sends the first 2 events. All remaining messages are filtered.*
- #define [CFE\\_EVS\\_FIRST\\_4\\_STOP](#) 0xFFFFC  
*Sends the first 4 events. All remaining messages are filtered.*
- #define [CFE\\_EVS\\_FIRST\\_8\\_STOP](#) 0xFFFF8  
*Sends the first 8 events. All remaining messages are filtered.*
- #define [CFE\\_EVS\\_FIRST\\_16\\_STOP](#) 0xFFFF0  
*Sends the first 16 events. All remaining messages are filtered.*
- #define [CFE\\_EVS\\_FIRST\\_32\\_STOP](#) 0xFFE0  
*Sends the first 32 events. All remaining messages are filtered.*
- #define [CFE\\_EVS\\_FIRST\\_64\\_STOP](#) 0xFFC0  
*Sends the first 64 events. All remaining messages are filtered.*
- #define [CFE\\_EVS\\_EVERY\\_OTHER\\_ONE](#) 0x0001  
*Sends every other event.*
- #define [CFE\\_EVS\\_EVERY\\_OTHER\\_TWO](#) 0x0002  
*Sends two, filters one, sends two, filters one, etc.*
- #define [CFE\\_EVS\\_EVERY\\_FOURTH\\_ONE](#) 0x0003  
*Sends every fourth event message. All others are filtered.*

### Typedefs

- typedef struct [CFE\\_EVS\\_BinFilter](#) [CFE\\_EVS\\_BinFilter\\_t](#)  
*Event message filter definition structure.*

#### 12.45.1 Detailed Description

Title: Event Services API Application Library Header File

Purpose: Unit specification for Event services library functions and macros.

Design Notes:

References: Flight Software Branch C Coding Standard Version 1.0a

## 12.45.2 Macro Definition Documentation

### 12.45.2.1 CFE\_EVS\_EVERY\_FOURTH\_ONE

```
#define CFE_EVS_EVERY_FOURTH_ONE 0x0003
```

Sends every fourth event message. All others are filtered.

Definition at line 54 of file cfe\_evs\_api\_typedefs.h.

### 12.45.2.2 CFE\_EVS\_EVERY\_OTHER\_ONE

```
#define CFE_EVS_EVERY_OTHER_ONE 0x0001
```

Sends every other event.

Definition at line 52 of file cfe\_evs\_api\_typedefs.h.

### 12.45.2.3 CFE\_EVS\_EVERY\_OTHER\_TWO

```
#define CFE_EVS_EVERY_OTHER_TWO 0x0002
```

Sends two, filters one, sends two, filters one, etc.

Definition at line 53 of file cfe\_evs\_api\_typedefs.h.

### 12.45.2.4 CFE\_EVS\_FIRST\_16\_STOP

```
#define CFE_EVS_FIRST_16_STOP 0xFFFF0
```

Sends the first 16 events. All remaining messages are filtered.

Definition at line 49 of file cfe\_evs\_api\_typedefs.h.

### 12.45.2.5 CFE\_EVS\_FIRST\_32\_STOP

```
#define CFE_EVS_FIRST_32_STOP 0xFFE0
```

Sends the first 32 events. All remaining messages are filtered.

Definition at line 50 of file cfe\_evs\_api\_typedefs.h.

#### 12.45.2.6 CFE\_EVS\_FIRST\_4\_STOP

```
#define CFE_EVS_FIRST_4_STOP 0xFFFFC
```

Sends the first 4 events. All remaining messages are filtered.

Definition at line 47 of file cfe\_evs\_api\_typedefs.h.

#### 12.45.2.7 CFE\_EVS\_FIRST\_64\_STOP

```
#define CFE_EVS_FIRST_64_STOP 0xFFC0
```

Sends the first 64 events. All remaining messages are filtered.

Definition at line 51 of file cfe\_evs\_api\_typedefs.h.

#### 12.45.2.8 CFE\_EVS\_FIRST\_8\_STOP

```
#define CFE_EVS_FIRST_8_STOP 0xFFFF8
```

Sends the first 8 events. All remaining messages are filtered.

Definition at line 48 of file cfe\_evs\_api\_typedefs.h.

#### 12.45.2.9 CFE\_EVS\_FIRST\_ONE\_STOP

```
#define CFE_EVS_FIRST_ONE_STOP 0xFFFFF
```

Sends the first event. All remaining messages are filtered.

Definition at line 45 of file cfe\_evs\_api\_typedefs.h.

#### 12.45.2.10 CFE\_EVS\_FIRST\_TWO\_STOP

```
#define CFE_EVS_FIRST_TWO_STOP 0xFFFFE
```

Sends the first 2 events. All remaining messages are filtered.

Definition at line 46 of file cfe\_evs\_api\_typedefs.h.

### 12.45.2.11 CFE\_EVS\_NO\_FILTER

```
#define CFE_EVS_NO_FILTER 0x0000
```

Stops any filtering. All messages are sent.

Definition at line 44 of file cfe\_evs\_api\_typedefs.h.

### 12.45.3 TYPEDef Documentation

#### 12.45.3.1 CFE\_EVS\_BinFilter\_t

```
typedef struct CFE_EVS_BinFilter CFE_EVS_BinFilter_t
```

Event message filter definition structure.

## 12.46 cfe/modules/core\_api/fsw/inc/cfe\_evs\_extern\_typedefs.h File Reference

```
#include "common_types.h"
```

### Typedefs

- **typedef uint8 CFE\_EVS\_MsgFormat\_Enum\_t**  
*Identifies format of log messages.*
- **typedef uint8 CFE\_EVS\_LogMode\_Enum\_t**  
*Identifies handling of log messages after storage is filled.*
- **typedef uint16 CFE\_EVS\_EventType\_Enum\_t**  
*Identifies type of event message.*
- **typedef uint8 CFE\_EVS\_EventFilter\_Enum\_t**  
*Identifies event filter schemes.*
- **typedef uint8 CFE\_EVS\_EventOutput\_Enum\_t**  
*Identifies event output port.*

### Enumerations

- enum **CFE\_EVS\_MsgFormat** { **CFE\_EVS\_MsgFormat\_SHORT** = 0, **CFE\_EVS\_MsgFormat\_LONG** = 1 }  
*Label definitions associated with CFE\_EVS\_MsgFormat\_Enum\_t.*
- enum **CFE\_EVS\_LogMode** { **CFE\_EVS\_LogMode\_OVERWRITE** = 0, **CFE\_EVS\_LogMode\_DISCARD** = 1 }  
*Label definitions associated with CFE\_EVS\_LogMode\_Enum\_t.*
- enum **CFE\_EVS\_EventType** { **CFE\_EVS\_EventType\_DEBUG** = 1, **CFE\_EVS\_EventType\_INFORMATION** = 2, **CFE\_EVS\_EventType\_ERROR** = 3, **CFE\_EVS\_EventType\_CRITICAL** = 4 }  
*Label definitions associated with CFE\_EVS\_EventType\_Enum\_t.*
- enum **CFE\_EVS\_EventFilter** { **CFE\_EVS\_EventFilter\_BINARY** = 0 }  
*Label definitions associated with CFE\_EVS\_EventFilter\_Enum\_t.*
- enum **CFE\_EVS\_EventOutput** { **CFE\_EVS\_EventOutput\_PORT1** = 1, **CFE\_EVS\_EventOutput\_PORT2** = 2, **CFE\_EVS\_EventOutput\_PORT3** = 3, **CFE\_EVS\_EventOutput\_PORT4** = 4 }  
*Label definitions associated with CFE\_EVS\_EventOutput\_Enum\_t.*

### 12.46.1 Detailed Description

Declarations and prototypes for cfe\_evs\_extern\_typedefs module

### 12.46.2 Typedef Documentation

#### 12.46.2.1 CFE\_EVS\_EventFilter\_Enum\_t

```
typedef uint8 CFE_EVS_EventFilter_Enum_t
```

Identifies event filter schemes.

See also

enum [CFE\\_EVS\\_EventFilter](#)

Definition at line 139 of file cfe\_evs\_extern\_typedefs.h.

#### 12.46.2.2 CFE\_EVS\_EventOutput\_Enum\_t

```
typedef uint8 CFE_EVS_EventOutput_Enum_t
```

Identifies event output port.

See also

enum [CFE\\_EVS\\_EventOutput](#)

Definition at line 173 of file cfe\_evs\_extern\_typedefs.h.

#### 12.46.2.3 CFE\_EVS\_EventType\_Enum\_t

```
typedef uint16 CFE_EVS_EventType_Enum_t
```

Identifies type of event message.

See also

enum [CFE\\_EVS\\_EventType](#)

Definition at line 120 of file cfe\_evs\_extern\_typedefs.h.

#### 12.46.2.4 CFE\_EVS\_LogMode\_Enum\_t

```
typedef uint8 CFE_EVS_LogMode_Enum_t
```

Identifies handling of log messages after storage is filled.

##### See also

enum [CFE\\_EVS\\_LogMode](#)

Definition at line 86 of file `cfe_evs_extern_typedefs.h`.

#### 12.46.2.5 CFE\_EVS\_MsgFormat\_Enum\_t

```
typedef uint8 CFE_EVS_MsgFormat_Enum_t
```

Identifies format of log messages.

##### See also

enum [CFE\\_EVS\\_MsgFormat](#)

Definition at line 62 of file `cfe_evs_extern_typedefs.h`.

### 12.46.3 Enumeration Type Documentation

#### 12.46.3.1 CFE\_EVS\_EventFilter

enum [CFE\\_EVS\\_EventFilter](#)

Label definitions associated with `CFE_EVS_EventFilter_Enum_t`.

##### Enumerator

<code>CFE_EVS_EventFilter_BINARY</code>	Binary event filter.
---	----------------------

Definition at line 125 of file `cfe_evs_extern_typedefs.h`.

#### 12.46.3.2 CFE\_EVS\_EventOutput

enum [CFE\\_EVS\\_EventOutput](#)

Label definitions associated with CFE\_EVS\_EventOutput\_Enum\_t.

**Enumerator**

<code>CFE_EVS_EventOutput_PORT1</code>	Output Port 1.
<code>CFE_EVS_EventOutput_PORT2</code>	Output Port 2.
<code>CFE_EVS_EventOutput_PORT3</code>	Output Port 3.
<code>CFE_EVS_EventOutput_PORT4</code>	Output Port 4.

Definition at line 144 of file `cfe_evs_extern_typedefs.h`.

**12.46.3.3 CFE\_EVS\_EventType**

```
enum CFE\_EVS\_EventType
```

Label definitions associated with `CFE_EVS_EventType_Enum_t`.

**Enumerator**

<code>CFE_EVS_EventType_DEBUG</code>	Events that are intended only for debugging, not nominal operations.
<code>CFE_EVS_EventType_INFORMATION</code>	Events that identify a state change or action that is not an error.
<code>CFE_EVS_EventType_ERROR</code>	Events that identify an error but are not catastrophic (e.g. - bad command).
<code>CFE_EVS_EventType_CRITICAL</code>	Events that identify errors that are unrecoverable autonomously.

Definition at line 91 of file `cfe_evs_extern_typedefs.h`.

**12.46.3.4 CFE\_EVS\_LogMode**

```
enum CFE\_EVS\_LogMode
```

Label definitions associated with `CFE_EVS_LogMode_Enum_t`.

**Enumerator**

<code>CFE_EVS_LogMode_OVERWRITE</code>	Overwrite Log Mode.
<code>CFE_EVS_LogMode_DISCARD</code>	Discard Log Mode.

Definition at line 67 of file `cfe_evs_extern_typedefs.h`.

**12.46.3.5 CFE\_EVS\_MsgFormat**

```
enum CFE\_EVS\_MsgFormat
```

Label definitions associated with `CFE_EVS_MsgFormat_Enum_t`.

## Enumerator

CFE_EVS_MsgFormat_SHORT	Short Format Messages.
CFE_EVS_MsgFormat_LONG	Long Format Messages.

Definition at line 43 of file cfe\_evs\_extern\_typedefs.h.

## 12.47 cfe/modules/core\_api/fsw/inc/cfe\_fs.h File Reference

```
#include "common_types.h"
#include "osconfig.h"
#include "cfe_platform_cfg.h"
#include "cfe_error.h"
#include "cfe_fs_api_typedefs.h"
#include "cfe_fs_extern_typedefs.h"
#include "cfe_time_api_typedefs.h"
```

## Functions

- [CFE\\_Status\\_t CFE\\_FS\\_ReadHeader \(CFE\\_FS\\_Header\\_t \\*Hdr, osal\\_id\\_t FileDes\)](#)  
*Read the contents of the Standard cFE File Header.*
- [void CFE\\_FS\\_InitHeader \(CFE\\_FS\\_Header\\_t \\*Hdr, const char \\*Description, uint32 SubType\)](#)  
*Initializes the contents of the Standard cFE File Header.*
- [CFE\\_Status\\_t CFE\\_FS\\_WriteHeader \(osal\\_id\\_t FileDes, CFE\\_FS\\_Header\\_t \\*Hdr\)](#)  
*Write the specified Standard cFE File Header to the specified file.*
- [CFE\\_Status\\_t CFE\\_FS\\_SetTimestamp \(osal\\_id\\_t FileDes, CFE\\_TIME\\_SysTime\\_t NewTimestamp\)](#)  
*Modifies the Time Stamp field in the Standard cFE File Header for the specified file.*
- [const char \\* CFE\\_FS\\_GetDefaultMountPoint \(CFE\\_FS\\_FileCategory\\_t FileCategory\)](#)  
*Get the default virtual mount point for a file category.*
- [const char \\* CFE\\_FS\\_GetDefaultExtension \(CFE\\_FS\\_FileCategory\\_t FileCategory\)](#)  
*Get the default filename extension for a file category.*
- [int32 CFE\\_FS\\_ParseInputFileNameEx \(char \\*OutputBuffer, const char \\*InputBuffer, size\\_t OutputBufSize, size\\_t InputBufSize, const char \\*DefaultInput, const char \\*DefaultPath, const char \\*DefaultExtension\)](#)  
*Parse a filename input from an input buffer into a local buffer.*
- [int32 CFE\\_FS\\_ParseInputFileName \(char \\*OutputBuffer, const char \\*InputName, size\\_t OutputBufSize, CFE\\_FS\\_FileCategory\\_t FileCategory\)](#)  
*Parse a filename string from the user into a local buffer.*
- [CFE\\_Status\\_t CFE\\_FS\\_ExtractFilenameFromPath \(const char \\*OriginalPath, char \\*FileNameOnly\)](#)  
*Extracts the filename from a unix style path and filename string.*
- [int32 CFE\\_FS\\_BackgroundFileDumpRequest \(CFE\\_FS\\_FileWriteMetaData\\_t \\*Meta\)](#)  
*Register a background file dump request.*
- [bool CFE\\_FS\\_BackgroundFileDumplsPending \(const CFE\\_FS\\_FileWriteMetaData\\_t \\*Meta\)](#)  
*Query if a background file write request is currently pending.*

### 12.47.1 Detailed Description

Purpose: cFE File Services (FS) library API header file

Author: S.Walling/Microtel

## 12.48 cfe/modules/core\_api/fsw/inc/cfe\_fs\_api\_typedefs.h File Reference

```
#include "common_types.h"
#include "osconfig.h"
#include "cfe_fs_extern_typedefs.h"
```

### Data Structures

- struct [CFE\\_FS\\_FileWriteMetaData](#)

*External Metadata/State object associated with background file writes.*

### Typedefs

- typedef bool(\* [CFE\\_FS\\_FileWriteGetData\\_t](#)) (void \*Meta, uint32 RecordNum, void \*\*Buffer, size\_t \*BufSize)
- typedef void(\* [CFE\\_FS\\_FileWriteOnEvent\\_t](#)) (void \*Meta, [CFE\\_FS\\_FileWriteEvent\\_t](#) Event, int32 Status, uint32 RecordNum, size\_t BlockSize, size\_t Position)
- typedef struct [CFE\\_FS\\_FileWriteMetaData](#) [CFE\\_FS\\_FileWriteMetaData\\_t](#)

*External Metadata/State object associated with background file writes.*

### Enumerations

- enum [CFE\\_FS\\_FileCategory\\_t](#) {
 [CFE\\_FS\\_FileCategory\\_UNKNOWN](#), [CFE\\_FS\\_FileCategory\\_DYNAMIC\\_MODULE](#), [CFE\\_FS\\_FileCategory\\_BINARY\\_DATA\\_DUMP](#), [CFE\\_FS\\_FileCategory\\_TEXT\\_LOG](#), [CFE\\_FS\\_FileCategory\\_SCRIPT](#), [CFE\\_FS\\_FileCategory\\_TEMP](#), [CFE\\_FS\\_FileCategory\\_MAX](#) }
- Generalized file types/categories known to FS.*
- enum [CFE\\_FS\\_FileWriteEvent\\_t](#) {
 [CFE\\_FS\\_FileWriteEvent\\_UNDEFINED](#), [CFE\\_FS\\_FileWriteEvent\\_COMPLETE](#), [CFE\\_FS\\_FileWriteEvent\\_CREATE\\_ERROR](#), [CFE\\_FS\\_FileWriteEvent\\_HEADER\\_WRITE\\_ERROR](#), [CFE\\_FS\\_FileWriteEvent\\_RECORD\\_WRITE\\_ERROR](#), [CFE\\_FS\\_FileWriteEvent\\_MAX](#) }

### 12.48.1 Detailed Description

Purpose: cFE File Services (FS) library API header file

Author: S.Walling/Microtel

## 12.48.2 Typedef Documentation

### 12.48.2.1 CFE\_FS\_FileWriteGetData\_t

```
typedef bool(* CFE_FS_FileWriteGetData_t) (void *Meta, uint32 RecordNum, void **Buffer, size_t *BufSize)
```

Data Getter routine provided by requester

Outputs a data block. Should return true if the file is complete (last record/EOF), otherwise return false.

#### Parameters

<i>in, out</i>	<i>Meta</i>	Pointer to the metadata object
<i>in</i>	<i>RecordNum</i>	Incrementing record number counter
<i>out</i>	<i>Buffer</i>	Pointer to buffer data block, should be set by implementation
<i>out</i>	<i>BufSize</i>	Pointer to buffer data size, should be set by implementation

#### Returns

End of file status

#### Return values

<i>true</i>	if at last data record, and output file should be closed
<i>false</i>	if not at last record, more data records to write

#### Note

The implementation of this function must always set the "Buffer" and "BufSize" outputs. If no data is available, they may be set to NULL and 0, respectively.

Definition at line 98 of file cfe\_fs\_api\_typedefs.h.

### 12.48.2.2 CFE\_FS\_FileWriteMetaData\_t

```
typedef struct CFE_FS_FileWriteMetaData CFE_FS_FileWriteMetaData_t
```

External Metadata/State object associated with background file writes.

Applications intending to schedule background file write jobs should instantiate this object in static/global data memory. This keeps track of the state of the file write request(s).

### 12.48.2.3 CFE\_FS\_FileWriteOnEvent\_t

```
typedef void(* CFE_FS_FileWriteOnEvent_t) (void *Meta, CFE_FS_FileWriteEvent_t Event, int32 Status,
                                          uint32 RecordNum, size_t BlockSize, size_t Position)
```

Event generator routine provided by requester

Invoked from certain points in the file write process. Implementation may invoke [CFE\\_EVS\\_SendEvent\(\)](#) appropriately to inform of progress.

#### Parameters

in, out	<i>Meta</i>	Pointer to the metadata object
in	<i>Event</i>	Generalized type of event to report (not actual event ID)
in	<i>Status</i>	Generalized status code (may be from OSAL or CFE)
in	<i>RecordNum</i>	Record number counter at which event occurred
in	<i>BlockSize</i>	Size of record being processed when event occurred (if applicable)
in	<i>Position</i>	File position/size when event occurred

Definition at line 114 of file cfe\_fs\_api\_typedefs.h.

### 12.48.3 Enumeration Type Documentation

#### 12.48.3.1 CFE\_FS\_FileCategory\_t

```
enum CFE_FS_FileCategory_t
```

Generalized file types/categories known to FS.

This defines different categories of files, where they may reside in different default locations of the virtualized file system.

This is different from, and should not be confused with, the "SubType" field in the FS header. This value is only used at runtime for FS APIs and should not actually appear in any output file or message.

#### Enumerator

CFE_FS_FileCategory_UNKNOWN	Placeholder, unknown file category
CFE_FS_FileCategory_DYNAMIC_MODULE	Dynamically loadable apps/libraries (e.g. .so, .o, .dll, etc)
CFE_FS_FileCategory_BINARY_DATA_DUMP	Binary log file generated by various data dump commands
CFE_FS_FileCategory_TEXT_LOG	Text-based log file generated by various commands
CFE_FS_FileCategory_SCRIPT	Text-based Script files (e.g. ES startup script)
CFE_FS_FileCategory_TEMP	Temporary/Ephemeral files
CFE_FS_FileCategory_MAX	Placeholder, keep last

Definition at line 48 of file cfe\_fs\_api\_typedefs.h.

### 12.48.3.2 CFE\_FS\_FileWriteEvent\_t

enum [CFE\\_FS\\_FileWriteEvent\\_t](#)

Enumerator

CFE_FS_FileWriteEvent_UNDEFINED	
CFE_FS_FileWriteEvent_COMPLETE	File is completed successfully
CFE_FS_FileWriteEvent_CREATE_ERROR	Unable to create/open file
CFE_FS_FileWriteEvent_HEADER_WRITE_ERROR	Unable to write FS header
CFE_FS_FileWriteEvent_RECORD_WRITE_ERROR	Unable to write data record
CFE_FS_FileWriteEvent_MAX	

Definition at line 68 of file cfe\_fs\_api\_typedefs.h.

## 12.49 cfe/modules/core\_api/fsw/inc/cfe\_fs\_extern\_typedefs.h File Reference

#include "common\_types.h"

### Data Structures

- struct [CFE\\_FS\\_Header](#)  
*Standard cFE File header structure definition.*

### Macros

- #define [CFE\\_FS\\_HDR\\_DESC\\_MAX\\_LEN](#) 32  
*Max length of description field in a standard cFE File Header.*
- #define [CFE\\_FS\\_FILE\\_CONTENT\\_ID](#) 0x63464531  
*Magic Number for cFE compliant files (= 'cFE1')*

### Typedefs

- typedef uint32 [CFE\\_FS\\_SubType\\_Enum\\_t](#)  
*Content descriptor for File Headers.*
- typedef struct [CFE\\_FS\\_Header](#) [CFE\\_FS\\_Header\\_t](#)  
*Standard cFE File header structure definition.*

## Enumerations

- enum `CFE_FS_SubType` {
 `CFE_FS_SubType_ES_ERLOG` = 1, `CFE_FS_SubType_ES_SYSLOG` = 2, `CFE_FS_SubType_ES_QUERYALL` = 3, `CFE_FS_SubType_ES_PERFDATA` = 4,
 `CFE_FS_SubType_ES_CDS_REG` = 6, `CFE_FS_SubType_TBL_REG` = 9, `CFE_FS_SubType_TBL_IMG` = 8,
 `CFE_FS_SubType_EVS_APPDATA` = 15,
 `CFE_FS_SubType_EVS_EVENTLOG` = 16, `CFE_FS_SubType_SB_PIPEDATA` = 20, `CFE_FS_SubType_SB_ROUTE DATA` = 21, `CFE_FS_SubType_SB_MAPDATA` = 22,
 `CFE_FS_SubType_ES_QUERYALLTASKS` = 23 }

*File subtypes used within cFE.*

### 12.49.1 Detailed Description

Declarations and prototypes for `cfe_fs_extern_typedefs` module

### 12.49.2 Macro Definition Documentation

#### 12.49.2.1 `CFE_FS_FILE_CONTENT_ID`

```
#define CFE_FS_FILE_CONTENT_ID 0x63464531
```

Magic Number for cFE compliant files (= 'cFE1')

Definition at line 51 of file `cfe_fs_extern_typedefs.h`.

#### 12.49.2.2 `CFE_FS_HDR_DESC_MAX_LEN`

```
#define CFE_FS_HDR_DESC_MAX_LEN 32
```

Max length of description field in a standard cFE File Header.

Definition at line 49 of file `cfe_fs_extern_typedefs.h`.

### 12.49.3 Typedef Documentation

#### 12.49.3.1 `CFE_FS_Header_t`

```
typedef struct CFE_FS_Header CFE_FS_Header_t
```

Standard cFE File header structure definition.

### 12.49.3.2 CFE\_FS\_SubType\_Enum\_t

```
typedef uint32 CFE_FS_SubType_Enum_t
```

Content descriptor for File Headers.

#### See also

enum [CFE\\_FS\\_SubType](#)

Definition at line 199 of file cfe\_fs\_extern\_typedefs.h.

### 12.49.4 Enumeration Type Documentation

#### 12.49.4.1 CFE\_FS\_SubType

```
enum CFE_FS_SubType
```

File subtypes used within cFE.

This defines all the file subtypes used by cFE. Note apps can extend as needed but need to avoid conflicts (app context not currently included in the file header).

#### Enumerator

CFE_FS_SubType_ES_ERLOG	Executive Services Exception/Reset Log Type. Executive Services Exception/Reset Log File which is generated in response to a <a href="#">\$sc_\$cpu_ES_WriteERLog2File</a> command.
CFE_FS_SubType_ES_SYSLOG	Executive Services System Log Type. Executive Services System Log File which is generated in response to a <a href="#">\$sc_\$cpu_ES_WriteSysLog2File</a> command.
CFE_FS_SubType_ES_QUERYALL	Executive Services Information on All Applications File. Executive Services Information on All Applications File which is generated in response to a <a href="#">\$sc_\$cpu_ES_WriteAppInfo2File</a> command.
CFE_FS_SubType_ES_PERFDATA	Executive Services Performance Data File. Executive Services Performance Analyzer Data File which is generated in response to a <a href="#">\$sc_\$cpu_ES_StopLAData</a> command.
CFE_FS_SubType_ES_CDS_REG	Executive Services Critical Data Store Registry Dump File. Executive Services Critical Data Store Registry Dump File which is generated in response to a <a href="#">\$sc_\$cpu_ES_WriteCDS2File</a> command.
CFE_FS_SubType_TBL_REG	Table Services Registry Dump File. Table Services Registry Dump File which is generated in response to a <a href="#">\$sc_\$cpu_TBL_WriteReg2File</a> command.
CFE_FS_SubType_TBL_IMG	Table Services Table Image File. Table Services Table Image File which is generated either on the ground or in response to a <a href="#">\$sc_\$cpu_TBL_DUMP</a> command.

## Enumerator

CFE_FS_SubType_EVS_APPDATA	Event Services Application Data Dump File. Event Services Application Data Dump File which is generated in response to a <a href="#">\$sc_\$cpu_EVS_WriteAppData2File</a> command.
CFE_FS_SubType_EVS_EVENTLOG	Event Services Local Event Log Dump File. Event Services Local Event Log Dump File which is generated in response to a <a href="#">\$sc_\$cpu_EVS_WriteLog2File</a> command.
CFE_FS_SubType_SB_PIPE DATA	Software Bus Pipe Data Dump File. Software Bus Pipe Data Dump File which is generated in response to a <a href="#">\$sc_\$cpu_SB_WritePipe2File</a> command.
CFE_FS_SubType_SB_ROUTEDATA	Software Bus Message Routing Data Dump File. Software Bus Message Routing Data Dump File which is generated in response to a <a href="#">\$sc_\$cpu_SB_WriteRouting2File</a> command.
CFE_FS_SubType_SB_MAPDATA	Software Bus Message Mapping Data Dump File. Software Bus Message Mapping Data Dump File which is generated in response to a <a href="#">\$sc_\$cpu_SB_WriteMap2File</a> command.
CFE_FS_SubType_ES_QUERYALLTASKS	Executive Services Query All Tasks Data File. Executive Services Query All Tasks Data File which is generated in response to a <a href="#">\$sc_\$cpu_ES_WriteTaskInfo2File</a> command.

Definition at line 61 of file cfe\_fs\_extern\_typedefs.h.

## 12.50 cfe/modules/core\_api/fsw/inc/cfe\_msg.h File Reference

```
#include "common_types.h"
#include "cfe_error.h"
#include "cfe_msg_hdr.h"
#include "cfe_msg_api_typedefs.h"
#include "cfe_es_api_typedefs.h"
#include "cfe_sb_api_typedefs.h"
#include "cfe_time_api_typedefs.h"
```

## Functions

- [CFE\\_Status\\_t CFE\\_MSG\\_Init \(CFE\\_MSG\\_Message\\_t \\*MsgPtr, CFE\\_SB\\_MsgId\\_t MsgId, CFE\\_MSG\\_Size\\_t Size\)](#)

*Initialize a message.*
- [CFE\\_Status\\_t CFE\\_MSG\\_GetSize \(const CFE\\_MSG\\_Message\\_t \\*MsgPtr, CFE\\_MSG\\_Size\\_t \\*Size\)](#)

*Gets the total size of a message.*
- [CFE\\_Status\\_t CFE\\_MSG\\_SetSize \(CFE\\_MSG\\_Message\\_t \\*MsgPtr, CFE\\_MSG\\_Size\\_t Size\)](#)

*Sets the total size of a message.*
- [CFE\\_Status\\_t CFE\\_MSG.GetType \(const CFE\\_MSG\\_Message\\_t \\*MsgPtr, CFE\\_MSG\\_Type\\_t \\*Type\)](#)

*Gets the message type.*
- [CFE\\_Status\\_t CFE\\_MSG\\_SetType \(CFE\\_MSG\\_Message\\_t \\*MsgPtr, CFE\\_MSG\\_Type\\_t Type\)](#)

*Sets the message type.*

- `CFE_Status_t CFE_MSG_GetHeaderVersion (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_HeaderVersion_t *Version)`  
*Gets the message header version.*
- `CFE_Status_t CFE_MSG_SetHeaderVersion (CFE_MSG_Message_t *MsgPtr, CFE_MSG_HeaderVersion_t Version)`  
*Sets the message header version.*
- `CFE_Status_t CFE_MSG_GetHasSecondaryHeader (const CFE_MSG_Message_t *MsgPtr, bool *HasSecondary)`  
*Gets the message secondary header boolean.*
- `CFE_Status_t CFE_MSG_SetHasSecondaryHeader (CFE_MSG_Message_t *MsgPtr, bool HasSecondary)`  
*Sets the message secondary header boolean.*
- `CFE_Status_t CFE_MSG_GetApld (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_Apld_t *Apld)`  
*Gets the message application ID.*
- `CFE_Status_t CFE_MSG_SetApld (CFE_MSG_Message_t *MsgPtr, CFE_MSG_Apld_t Apld)`  
*Sets the message application ID.*
- `CFE_Status_t CFE_MSG_GetSegmentationFlag (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_SegmentationFlag_t *SegFlag)`  
*Gets the message segmentation flag.*
- `CFE_Status_t CFE_MSG_SetSegmentationFlag (CFE_MSG_Message_t *MsgPtr, CFE_MSG_SegmentationFlag_t SegFlag)`  
*Sets the message segmentation flag.*
- `CFE_Status_t CFE_MSG_GetSequenceCount (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_SequenceCount_t *SeqCnt)`  
*Gets the message sequence count.*
- `CFE_Status_t CFE_MSG_SetSequenceCount (CFE_MSG_Message_t *MsgPtr, CFE_MSG_SequenceCount_t SeqCnt)`  
*Sets the message sequence count.*
- `CFE_MSG_SequenceCount_t CFE_MSG_GetNextSequenceCount (CFE_MSG_SequenceCount_t SeqCnt)`  
*Gets the next sequence count value (rolls over if appropriate)*
- `CFE_Status_t CFE_MSG_GetEDSVersion (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_EDSVersion_t *Version)`  
*Gets the message EDS version.*
- `CFE_Status_t CFE_MSG_SetEDSVersion (CFE_MSG_Message_t *MsgPtr, CFE_MSG_EDSVersion_t Version)`  
*Sets the message EDS version.*
- `CFE_Status_t CFE_MSG_GetEndian (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_Endian_t *Endian)`  
*Gets the message endian.*
- `CFE_Status_t CFE_MSG_SetEndian (CFE_MSG_Message_t *MsgPtr, CFE_MSG_Endian_t Endian)`  
*Sets the message endian.*
- `CFE_Status_t CFE_MSG_GetPlaybackFlag (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_PlaybackFlag_t *PlayFlag)`  
*Gets the message playback flag.*
- `CFE_Status_t CFE_MSG_SetPlaybackFlag (CFE_MSG_Message_t *MsgPtr, CFE_MSG_PlaybackFlag_t PlayFlag)`  
*Sets the message playback flag.*
- `CFE_Status_t CFE_MSG_GetSubsystem (const CFE_MSG_Message_t *MsgPtr, CFE_MSG_Subsystem_t *Subsystem)`  
*Gets the message subsystem.*
- `CFE_Status_t CFE_MSG_SetSubsystem (CFE_MSG_Message_t *MsgPtr, CFE_MSG_Subsystem_t Subsystem)`  
*Sets the message subsystem.*

- Sets the message subsystem.
- CFE\_Status\_t CFE\_MSG\_GetSystem (const CFE\_MSG\_Message\_t \*MsgPtr, CFE\_MSG\_System\_t \*System)
  - Gets the message system.
- CFE\_Status\_t CFE\_MSG\_SetSystem (CFE\_MSG\_Message\_t \*MsgPtr, CFE\_MSG\_System\_t System)
  - Sets the message system.
- CFE\_Status\_t CFE\_MSG\_GenerateChecksum (CFE\_MSG\_Message\_t \*MsgPtr)
  - Calculates and sets the checksum of a message.
- CFE\_Status\_t CFE\_MSG\_ValidateChecksum (const CFE\_MSG\_Message\_t \*MsgPtr, bool \*isValid)
  - Validates the checksum of a message.
- CFE\_Status\_t CFE\_MSG\_SetFcnCode (CFE\_MSG\_Message\_t \*MsgPtr, CFE\_MSG\_FcnCode\_t FcnCode)
  - Sets the function code field in a message.
- CFE\_Status\_t CFE\_MSG\_GetFcnCode (const CFE\_MSG\_Message\_t \*MsgPtr, CFE\_MSG\_FcnCode\_t \*FcnCode)
  - Gets the function code field from a message.
- CFE\_Status\_t CFE\_MSG\_GetMsgTime (const CFE\_MSG\_Message\_t \*MsgPtr, CFE\_TIME\_SysTime\_t \*Time)
  - Gets the time field from a message.
- CFE\_Status\_t CFE\_MSG\_SetMsgTime (CFE\_MSG\_Message\_t \*MsgPtr, CFE\_TIME\_SysTime\_t NewTime)
  - Sets the time field in a message.
- CFE\_Status\_t CFE\_MSG\_GetMsgId (const CFE\_MSG\_Message\_t \*MsgPtr, CFE\_SB\_MsgId\_t \*MsgId)
  - Gets the message id from a message.
- CFE\_Status\_t CFE\_MSG\_SetMsgId (CFE\_MSG\_Message\_t \*MsgPtr, CFE\_SB\_MsgId\_t MsgId)
  - Sets the message id bits in a message.
- CFE\_Status\_t CFE\_MSG\_GetTypeFromMsgId (CFE\_SB\_MsgId\_t MsgId, CFE\_MSG\_Type\_t \*Type)
  - Gets message type using message ID.

#### 12.50.1 Detailed Description

Message access APIs

#### 12.51 cfe/modules/core\_api/fsw/inc/cfe\_msg\_api\_typedefs.h File Reference

```
#include "common_types.h"
#include "cfe_error.h"
```

#### Macros

- #define CFE\_MSG\_BAD\_ARGUMENT CFE\_SB\_BAD\_ARGUMENT
  - Error - bad argument.
- #define CFE\_MSG\_NOT\_IMPLEMENTED CFE\_SB\_NOT\_IMPLEMENTED
  - Error - not implemented.
- #define CFE\_MSG\_WRONG\_MSG\_TYPE CFE\_SB\_WRONG\_MSG\_TYPE
  - Error - wrong type.

## Typedefs

- **typedef size\_t CFE\_MSG\_Size\_t**  
*Message size, note CCSDS maximum is UINT16\_MAX+7.*
- **typedef uint32 CFE\_MSG\_Checksum\_t**  
*Message checksum (Oversized to avoid redefine)*
- **typedef uint16 CFE\_MSG\_FcnCode\_t**  
*Message function code.*
- **typedef uint16 CFE\_MSG\_HeaderVersion\_t**  
*Message header version.*
- **typedef uint16 CFE\_MSG\_Apld\_t**  
*Message application ID.*
- **typedef uint16 CFE\_MSG\_SequenceCount\_t**  
*Message sequence count.*
- **typedef uint16 CFE\_MSG\_EDSVersion\_t**  
*Message EDS version.*
- **typedef uint16 CFE\_MSG\_Subsystem\_t**  
*Message subsystem.*
- **typedef uint16 CFE\_MSG\_System\_t**  
*Message system.*
- **typedef enum CFE\_MSG\_Type CFE\_MSG\_Type\_t**  
*Message type.*
- **typedef enum CFE\_MSG\_SegmentationFlag CFE\_MSG\_SegmentationFlag\_t**  
*Segmentation flags.*
- **typedef enum CFE\_MSG\_Endian CFE\_MSG\_Endian\_t**  
*Endian flag.*
- **typedef enum CFE\_MSG\_PlaybackFlag CFE\_MSG\_PlaybackFlag\_t**  
*Playback flag.*
- **typedef union CFE\_MSG\_Message CFE\_MSG\_Message\_t**  
*cFS generic base message*
- **typedef struct CFE\_MSG\_CommandHeader CFE\_MSG\_CommandHeader\_t**  
*cFS command header*
- **typedef struct CFE\_MSG\_TelemetryHeader CFE\_MSG\_TelemetryHeader\_t**  
*cFS telemetry header*

## Enumerations

- **enum CFE\_MSG\_Type { CFE\_MSG\_Type\_Invalid, CFE\_MSG\_Type\_Cmd, CFE\_MSG\_Type\_Tlm }**  
*Message type.*
- **enum CFE\_MSG\_SegmentationFlag {**  
`CFE_MSG_SegFlag_Invalid, CFE_MSG_SegFlag_Continue, CFE_MSG_SegFlag_First, CFE_MSG_SegFlag_Last,`  
`CFE_MSG_SegFlag_Unsegmented }`  
*Segmentation flags.*
- **enum CFE\_MSG\_Endian { CFE\_MSG\_Endian\_Invalid, CFE\_MSG\_Endian\_Big, CFE\_MSG\_Endian\_Little }**  
*Endian flag.*
- **enum CFE\_MSG\_PlaybackFlag { CFE\_MSG\_PlayFlag\_Invalid, CFE\_MSG\_PlayFlag\_Original, CFE\_MSG\_PlayFlag\_Playback }**  
*Playback flag.*

### 12.51.1 Detailed Description

TypeDefs for Message API

- Separate from API so these can be adjusted for custom implementations

### 12.51.2 Macro Definition Documentation

#### 12.51.2.1 CFE\_MSG\_BAD\_ARGUMENT

```
#define CFE_MSG_BAD_ARGUMENT CFE_SB_BAD_ARGUMENT
```

Error - bad argument.

Definition at line 39 of file cfe\_msg\_api\_typedefs.h.

#### 12.51.2.2 CFE\_MSG\_NOT\_IMPLEMENTED

```
#define CFE_MSG_NOT_IMPLEMENTED CFE_SB_NOT_IMPLEMENTED
```

Error - not implemented.

Definition at line 40 of file cfe\_msg\_api\_typedefs.h.

#### 12.51.2.3 CFE\_MSG\_WRONG\_MSG\_TYPE

```
#define CFE_MSG_WRONG_MSG_TYPE CFE_SB_WRONG_MSG_TYPE
```

Error - wrong type.

Definition at line 41 of file cfe\_msg\_api\_typedefs.h.

### 12.51.3 Typedef Documentation

### 12.51.3.1 CFE\_MSG\_ApId\_t

```
typedef uint16 CFE_MSG_ApId_t
```

Message application ID.

Definition at line 50 of file cfe\_msg\_api\_typedefs.h.

### 12.51.3.2 CFE\_MSG\_Checksum\_t

```
typedef uint32 CFE_MSG_Checksum_t
```

Message checksum (Oversized to avoid redefine)

Definition at line 47 of file cfe\_msg\_api\_typedefs.h.

### 12.51.3.3 CFE\_MSG\_CommandHeader\_t

```
typedef struct CFE_MSG_CommandHeader CFE_MSG_CommandHeader_t
```

cFS command header

Definition at line 107 of file cfe\_msg\_api\_typedefs.h.

### 12.51.3.4 CFE\_MSG\_EDSVersion\_t

```
typedef uint16 CFE_MSG_EDSVersion_t
```

Message EDS version.

Definition at line 52 of file cfe\_msg\_api\_typedefs.h.

### 12.51.3.5 CFE\_MSG\_Endian\_t

```
typedef enum CFE_MSG_Endian CFE_MSG_Endian_t
```

Endian flag.

### 12.51.3.6 CFE\_MSG\_FcnCode\_t

```
typedef uint16 CFE_MSG_FcnCode_t
```

Message function code.

Definition at line 48 of file cfe\_msg\_api\_typedefs.h.

### 12.51.3.7 CFE\_MSG\_HeaderVersion\_t

```
typedef uint16 CFE_MSG_HeaderVersion_t
```

Message header version.

Definition at line 49 of file cfe\_msg\_api\_typedefs.h.

### 12.51.3.8 CFE\_MSG\_Message\_t

```
typedef union CFE_MSG_Message CFE_MSG_Message_t
```

cFS generic base message

Definition at line 102 of file cfe\_msg\_api\_typedefs.h.

### 12.51.3.9 CFE\_MSG\_PlaybackFlag\_t

```
typedef enum CFE_MSG_PlaybackFlag CFE_MSG_PlaybackFlag_t
```

Playback flag.

### 12.51.3.10 CFE\_MSG\_SegmentationFlag\_t

```
typedef enum CFE_MSG_SegmentationFlag CFE_MSG_SegmentationFlag_t
```

Segmentation flags.

### 12.51.3.11 CFE\_MSG\_SequenceCount\_t

```
typedef uint16 CFE_MSG_SequenceCount_t
```

Message sequence count.

Definition at line 51 of file cfe\_msg\_api\_typedefs.h.

### 12.51.3.12 CFE\_MSG\_Size\_t

```
typedef size_t CFE_MSG_Size_t
```

Message size, note CCSDS maximum is UINT16\_MAX+7.

Definition at line 46 of file cfe\_msg\_api\_typedefs.h.

### 12.51.3.13 CFE\_MSG\_Subsystem\_t

```
typedef uint16 CFE_MSG_Subsystem_t
```

Message subsystem.

Definition at line 53 of file cfe\_msg\_api\_typedefs.h.

### 12.51.3.14 CFE\_MSG\_System\_t

```
typedef uint16 CFE_MSG_System_t
```

Message system.

Definition at line 54 of file cfe\_msg\_api\_typedefs.h.

### 12.51.3.15 CFE\_MSG\_TelemetryHeader\_t

```
typedef struct CFE_MSG_TelemetryHeader CFE_MSG_TelemetryHeader_t
```

cFS telemetry header

Definition at line 112 of file cfe\_msg\_api\_typedefs.h.

### 12.51.3.16 CFE\_MSG\_Type\_t

```
typedef enum CFE_MSG_Type CFE_MSG_Type_t
```

Message type.

## 12.51.4 Enumeration Type Documentation

### 12.51.4.1 CFE\_MSG\_Endian

```
enum CFE_MSG_Endian
```

Endian flag.

**Enumerator**

<code>CFE_MSG_Endian_Invalid</code>	Invalid endian setting.
<code>CFE_MSG_Endian_Big</code>	Big endian.
<code>CFE_MSG_Endian_Little</code>	Little endian.

Definition at line 75 of file `cfe_msg_api_typedefs.h`.

**12.51.4.2 CFE\_MSG\_PlaybackFlag**

`enum CFE_MSG_PlaybackFlag`

Playback flag.

**Enumerator**

<code>CFE_MSG_PlayFlag_Invalid</code>	Invalid playback setting.
<code>CFE_MSG_PlayFlag_Original</code>	Original.
<code>CFE_MSG_PlayFlag_Playback</code>	Playback.

Definition at line 83 of file `cfe_msg_api_typedefs.h`.

**12.51.4.3 CFE\_MSG\_SegmentationFlag**

`enum CFE_MSG_SegmentationFlag`

Segmentation flags.

**Enumerator**

<code>CFE_MSG_SegFlag_Invalid</code>	Invalid segmentation flag.
<code>CFE_MSG_SegFlag_Continue</code>	Continuation segment of User Data.
<code>CFE_MSG_SegFlag_First</code>	First segment of User Data.
<code>CFE_MSG_SegFlag_Last</code>	Last segment of User Data.
<code>CFE_MSG_SegFlag_Unsegmented</code>	Unsegmented data.

Definition at line 65 of file `cfe_msg_api_typedefs.h`.

**12.51.4.4 CFE\_MSG\_Type**

`enum CFE_MSG_Type`

Message type.

## Enumerator

<code>CFE_MSG_Type_Invalid</code>	Message type invalid, undefined, not implemented.
<code>CFE_MSG_Type_Cmd</code>	Command message type.
<code>CFE_MSG_Type_Tlm</code>	Telemetry message type.

Definition at line 57 of file `cfe_msg_api_typedefs.h`.

## 12.52 cfe/modules/core\_api/fsw/inc/cfe\_resourceid.h File Reference

```
#include "cfe_resourceid_api_typedefs.h"
```

## Functions

- `uint32 CFE_ResourceId_GetBase (CFE_ResourceId_t ResourceId)`  
*Get the Base value (type/category) from a resource ID value.*
- `uint32 CFE_ResourceId_GetSerial (CFE_ResourceId_t ResourceId)`  
*Get the Serial Number (sequential ID) from a resource ID value.*
- `CFE_ResourceId_t CFE_ResourceId_FindNext (CFE_ResourceId_t StartId, uint32 TableSize, bool(*Check←Func)(CFE_ResourceId_t))`  
*Locate the next resource ID which does not map to an in-use table entry.*
- `int32 CFE_ResourceId_ToIndex (CFE_ResourceId_t Id, uint32 BaseValue, uint32 TableSize, uint32 *Idx)`  
*Internal routine to aid in converting an ES resource ID to an array index.*

## Resource ID test/conversion macros and inline functions

- `#define CFE_RESOURCEID_TO ULONG(id) CFE_ResourceId_ToInteger(CFE_RESOURCEID_UNWRAP(id))`  
*Convert a derived (app-specific) ID directly into an "unsigned long".*
- `#define CFE_RESOURCEID_TEST_DEFINED(id) CFE_ResourceId_IsDefined(CFE_RESOURCEID_UNWRAP(id))`  
*Determine if a derived (app-specific) ID is defined or not.*
- `#define CFE_RESOURCEID_TEST_EQUAL(id1, id2) CFE_ResourceId_Equal(CFE_RESOURCEID_UNWRAP(id1), CFE_RESOURCEID_UNWRAP(id2))`  
*Determine if two derived (app-specific) IDs are equal.*
- `static unsigned long CFE_ResourceId_ToInteger (CFE_ResourceId_t id)`  
*Convert a resource ID to an integer.*
- `static CFE_ResourceId_t CFE_ResourceId_FromInteger (unsigned long Value)`  
*Convert an integer to a resource ID.*
- `static bool CFE_ResourceId_Equal (CFE_ResourceId_t id1, CFE_ResourceId_t id2)`  
*Compare two Resource ID values for equality.*
- `static bool CFE_ResourceId_IsDefined (CFE_ResourceId_t id)`  
*Check if a resource ID value is defined.*

### 12.52.1 Detailed Description

Contains global prototypes and definitions related to resource management and related CFE resource IDs.

A CFE ES Resource ID is a common way to identify CFE-managed resources such as apps, tasks, counters, memory pools, CDS blocks, and other entities.

Simple operations are provided as inline functions, which should alleviate the need to do direct manipulation of resource IDs:

- Check for undefined ID value
- Check for equality of two ID values
- Convert ID to simple integer (typically for printing/logging)
- Convert simple integer to ID (inverse of above)

### 12.52.2 Macro Definition Documentation

#### 12.52.2.1 CFE\_RESOURCEID\_TEST\_DEFINED

```
#define CFE_RESOURCEID_TEST_DEFINED( id ) CFE_ResourceId_IsDefined(CFE_RESOURCEID_UNWRAP(id))
```

Determine if a derived (app-specific) ID is defined or not.

This generic routine is implemented as a macro so it is agnostic to the actual argument type, and it will evaluate correctly so long as the argument type is based on the CFE\_RESOURCEID\_BASE\_TYPE.

Definition at line 70 of file cfe\_resourceid.h.

#### 12.52.2.2 CFE\_RESOURCEID\_TEST\_EQUAL

```
#define CFE_RESOURCEID_TEST_EQUAL( id1, id2 ) CFE_ResourceId_Equal(CFE_RESOURCEID_UNWRAP(id1), CFE_RESOURCEID_UNWRAP(id2))
```

Determine if two derived (app-specific) IDs are equal.

This generic routine is implemented as a macro so it is agnostic to the actual argument type, and it will evaluate correctly so long as the argument type is based on the CFE\_RESOURCEID\_BASE\_TYPE.

Definition at line 78 of file cfe\_resourceid.h.

Referenced by DS\_TableUpdateCDS().

### 12.52.2.3 CFE\_RESOURCEID\_TO ULONG

```
#define CFE_RESOURCEID_TO ULONG(
    id ) CFE_ResourceId_ToInteger(CFE_RESOURCEID_UNWRAP(id))
```

Convert a derived (app-specific) ID directly into an "unsigned long".

This generic routine is implemented as a macro so it is agnostic to the actual argument type, and it will evaluate correctly so long as the argument type is based on the CFE\_RESOURCEID\_BASE\_TYPE.

There is no inverse of this macro, as it depends on the actual derived type desired. Applications needing to recreate an ID from an integer should use [CFE\\_Resourceld\\_FromInteger\(\)](#) combined with a cast/conversion to the correct/intended derived type, as needed.

#### Note

This evaluates as an "unsigned long" such that it can be used in printf()-style functions with the "%lx" modifier without extra casting, as this is the most typical use-case for representing an ID as an integer.

Definition at line 62 of file cfe\_resourceid.h.

## 12.52.3 Function Documentation

### 12.52.3.1 CFE\_Resourceld\_Equal()

```
static bool CFE_ResourceId_Equal (
    CFE_ResourceId_t id1,
    CFE_ResourceId_t id2 ) [inline], [static]
```

Compare two Resource ID values for equality.

#### Parameters

in	<i>id1</i>	Resource ID to check
in	<i>id2</i>	Resource ID to check

#### Returns

true if id1 and id2 are equal, false otherwise.

Definition at line 133 of file cfe\_resourceid.h.

Referenced by [CFE\\_Resourceld\\_IsDefined\(\)](#).

### 12.52.3.2 CFE\_Resourceld\_FindNext()

```
CFE_ResourceId_t CFE_ResourceId_FindNext (
    CFE_ResourceId_t StartId,
    uint32 TableSize,
    bool(*) (CFE_ResourceId_t) CheckFunc )
```

Locate the next resource ID which does not map to an in-use table entry.

This begins searching from StartId which should be the most recently issued ID for the resource category. This will then search for the next ID which does *not* map to a table entry that is in use. That is, it does not alias any valid ID when converted to an array index.

returns an undefined ID value if no open slots are available

#### Parameters

in	<i>StartId</i>	the last issued ID for the resource category (app, lib, etc).
in	<i>TableSize</i>	the maximum size of the target table
in	<i>CheckFunc</i>	a function to check if the given ID is available

#### Returns

Next ID value which does not map to a valid entry

#### Return values

<a href="#">CFE_RESOURCEID_UNDEFINED</a>	if no open slots or bad arguments.
--	------------------------------------

Referenced by [CFE\\_Resourceld\\_IsDefined\(\)](#).

### 12.52.3.3 CFE\_Resourceld\_FromInteger()

```
static CFE_ResourceId_t CFE_ResourceId_FromInteger (
    unsigned long Value ) [inline], [static]
```

Convert an integer to a resource ID.

This is the inverse of [CFE\\_Resourceld\\_ToInteger\(\)](#), and reconstitutes the original CFE\_Resourceld\_t value from the integer representation.

This may be used, for instance, where an ID value is parsed from a text file or message using C library APIs such as scanf() or strtoul().

#### See also

[CFE\\_Resourceld\\_ToInteger\(\)](#)

**Parameters**

in	<i>Value</i>	Integer value to convert
----	--------------	--------------------------

**Returns**

ID value corresponding to integer

Definition at line 121 of file cfe\_resourceid.h.

**12.52.3.4 CFE\_Resourceld\_GetBase()**

```
uint32 CFE_ResourceId_GetBase (
    CFE_ResourceId_t ResourceId )
```

Get the Base value (type/category) from a resource ID value.

This masks out the ID serial number to obtain the base value, which is different for each resource type.

**Note**

The value is NOT shifted or otherwise adjusted.

**Parameters**

in	<i>ResourceId</i>	the resource ID to decode
----	-------------------	---------------------------

**Returns**

The base value associated with that ID

Referenced by CFE\_Resourceld\_IsDefined().

**12.52.3.5 CFE\_Resourceld\_GetSerial()**

```
uint32 CFE_ResourceId_GetSerial (
    CFE_ResourceId_t ResourceId )
```

Get the Serial Number (sequential ID) from a resource ID value.

This masks out the ID base value to obtain the serial number, which is different for each entity created.

**Parameters**

in	<i>ResourceId</i>	the resource ID to decode
----	-------------------	---------------------------

**Returns**

The serial number associated with that ID

Referenced by CFE\_ResourceId\_IsDefined().

**12.52.3.6 CFE\_ResourceId\_IsDefined()**

```
static bool CFE_ResourceId_IsDefined (
    CFE_ResourceId_t id ) [inline], [static]
```

Check if a resource ID value is defined.

The constant [CFE\\_RESOURCEID\\_UNDEFINED](#) represents an undefined ID value, such that the expression:

```
CFE_ResourceId_IsDefined(CFE_RESOURCEID_UNDEFINED)
```

Always returns false.

**Parameters**

in	<i>id</i>	Resource ID to check
----	-----------	----------------------


**Returns**

True if the ID may refer to a defined entity, false if invalid/undefined.

Definition at line 151 of file cfe\_resourceid.h.

References CFE\_ResourceId\_Equal(), CFE\_ResourceId\_FindNext(), CFE\_ResourceId\_GetBase(), CFE\_ResourceId\_GetSerial(), CFE\_ResourceId\_ToIndex(), and CFE\_RESOURCEID\_UNDEFINED.

Here is the call graph for this function:



### 12.52.3.7 CFE\_ResourcId\_ToIndex()

```
int32 CFE_ResourceId_ToIndex (
    CFE_ResourceId_t Id,
    uint32 BaseValue,
    uint32 TableSize,
    uint32 * Idx )
```

Internal routine to aid in converting an ES resource ID to an array index.

#### Parameters

in	<i>Id</i>	The resource ID
in	<i>BaseValue</i>	The respective ID base value corresponding to the ID type
in	<i>TableSize</i>	The actual size of the internal table (MAX index value + 1)
out	<i>Idx</i>	The output index

#### Returns

Execution status, see [cFE Return Code Defines](#)

#### Return values

<code>CFE_SUCCESS</code>	Successful execution.
<code>CFE_ES_BAD_ARGUMENT</code>	Bad Argument.
<code>CFE_ES_ERR_RESOURCEID_NOT_VALID</code>	Resource ID is not valid.

Referenced by CFE\_ResourceId\_IsDefined().

### 12.52.3.8 CFE\_ResourceId\_ToInteger()

```
static unsigned long CFE_ResourceId_ToInteger (
    CFE_ResourceId_t id ) [inline], [static]
```

Convert a resource ID to an integer.

This is primarily intended for logging purposes, such as writing to debug console, event messages, or log files, using printf-like APIs.

For compatibility with C library APIs, this returns an "unsigned long" type and should be used with the "%lx" format specifier in a printf format string.

#### Note

No assumptions should be made about the actual integer value, such as its base/range. It may be printed, but should not be modified or tested/compared using other arithmetic ops, and should never be used as the index to an array or table. See the related function [CFE\\_ResourceId\\_ToIndex\(\)](#) for cases where a zero-based array/table index is needed.

#### See also

[CFE\\_ResourceId\\_FromInteger\(\)](#)

#### Parameters

in	<i>id</i>	Resource ID to convert
----	-----------	------------------------

#### Returns

Integer value corresponding to ID

Definition at line 102 of file cfe\_resourceid.h.

## 12.53 cfe/modules/core\_api/fsw/inc/cfe\_resourceid\_api\_typedefs.h File Reference

```
#include "cfe_resourceid_typedef.h"
```

#### Macros

##### Resource ID predefined values

- #define [CFE\\_RESOURCEID\\_UNDEFINED](#) ((CFE\_ResourceId\_t)CFE\_RESOURCEID\_WRAP(0))  
*A resource ID value that represents an undefined/unused resource.*
- #define [CFE\\_RESOURCEID\\_RESERVED](#) ((CFE\_ResourceId\_t)CFE\_RESOURCEID\_WRAP(0xFFFFFFFF))  
*A resource ID value that represents a reserved entry.*

### 12.53.1 Detailed Description

Contains global prototypes and definitions related to resource management and related CFE resource IDs.

A CFE ES Resource ID is a common way to identify CFE-managed resources such as apps, tasks, counters, memory pools, CDS blocks, and other entities.

Simple operations are provided as inline functions, which should alleviate the need to do direct manipulation of resource IDs:

- Check for undefined ID value
- Check for equality of two ID values
- Convert ID to simple integer (typically for printing/logging)
- Convert simple integer to ID (inverse of above)

### 12.53.2 Macro Definition Documentation

#### 12.53.2.1 CFE\_RESOURCEID\_RESERVED

```
#define CFE_RESOURCEID_RESERVED ((CFE_ResourceId_t)CFE_RESOURCEID_WRAP(0xFFFFFFFF))
```

A resource ID value that represents a reserved entry.

This is not a valid value for any resource type, but is used to mark table entries that are not available for use. For instance, this may be used while setting up an entry initially.

Definition at line 74 of file cfe\_resourceid\_api\_typedefs.h.

#### 12.53.2.2 CFE\_RESOURCEID\_UNDEFINED

```
#define CFE_RESOURCEID_UNDEFINED ((CFE_ResourceId_t)CFE_RESOURCEID_WRAP(0))
```

A resource ID value that represents an undefined/unused resource.

This constant may be used to initialize local variables of the CFE\_Resourceld\_t type to a safe value that will not alias a valid ID.

By design, this value is also the result of zeroing a CFE\_Resourceld\_t type via standard functions like memset(), such that objects initialized using this method will also be set to safe values.

Definition at line 65 of file cfe\_resourceid\_api\_typedefs.h.

Referenced by CFE\_Resourceld\_IsDefined().

## 12.54 cfe/modules/core\_api/fsw/inc/cfe\_sb.h File Reference

```
#include "common_types.h"
#include "cfe_error.h"
#include "cfe_sb_api_typedefs.h"
#include "cfe_es_api_typedefs.h"
```

### Macros

- `#define CFE_BIT(x) (1 << (x))`  
*Places a one at bit positions 0 - 31.*
- `#define CFE_SET(i, x) ((i) |= CFE_BIT(x))`  
*Sets bit x of i.*
- `#define CFE_CLR(i, x) ((i) &= ~CFE_BIT(x))`  
*Clears bit x of i.*
- `#define CFE_TST(i, x) (((i)&CFE_BIT(x)) != 0)`  
*true(non zero) if bit x of i is set*

### Functions

- `CFE_Status_t CFE_SB_CreatePipe (CFE_SB_Pipeld_t *PipeldPtr, uint16 Depth, const char *PipeName)`  
*Creates a new software bus pipe.*
- `CFE_Status_t CFE_SB_DeletePipe (CFE_SB_Pipeld_t Pipeld)`  
*Delete a software bus pipe.*
- `CFE_Status_t CFE_SB_Pipeld_ToIndex (CFE_SB_Pipeld_t PipeID, uint32 *Idx)`  
*Obtain an index value correlating to an SB Pipe ID.*
- `CFE_Status_t CFE_SB_SetPipeOpts (CFE_SB_Pipeld_t Pipeld, uint8 Optis)`  
*Set options on a pipe.*
- `CFE_Status_t CFE_SB_GetPipeOpts (CFE_SB_Pipeld_t Pipeld, uint8 *Optsptr)`  
*Get options on a pipe.*
- `CFE_Status_t CFE_SB_GetPipeName (char *PipeNameBuf, size_t PipeNameSize, CFE_SB_Pipeld_t Pipeld)`  
*Get the pipe name for a given id.*
- `CFE_Status_t CFE_SB_GetPipeldByName (CFE_SB_Pipeld_t *PipeldPtr, const char *PipeName)`  
*Get pipe id by pipe name.*
- `CFE_Status_t CFE_SB_SubscribeEx (CFE_SB_MsgId_t MsgId, CFE_SB_Pipeld_t Pipeld, CFE_SB_Qos_t Quality, uint16 MsgLim)`  
*Subscribe to a message on the software bus.*
- `CFE_Status_t CFE_SB_Subscribe (CFE_SB_MsgId_t MsgId, CFE_SB_Pipeld_t Pipeld)`  
*Subscribe to a message on the software bus with default parameters.*
- `CFE_Status_t CFE_SB_SubscribeLocal (CFE_SB_MsgId_t MsgId, CFE_SB_Pipeld_t Pipeld, uint16 MsgLim)`  
*Subscribe to a message while keeping the request local to a cpu.*
- `CFE_Status_t CFE_SB_Unsubscribe (CFE_SB_MsgId_t MsgId, CFE_SB_Pipeld_t Pipeld)`  
*Remove a subscription to a message on the software bus.*
- `CFE_Status_t CFE_SB_UnsubscribeLocal (CFE_SB_MsgId_t MsgId, CFE_SB_Pipeld_t Pipeld)`  
*Remove a subscription to a message on the software bus on the current CPU.*

- `CFE_Status_t CFE_SB_TransmitMsg (const CFE_MSG_Message_t *MsgPtr, bool IncrementSequenceCount)`  
*Transmit a message.*
- `CFE_Status_t CFE_SB_ReceiveBuffer (CFE_SB_Buffer_t **BufPtr, CFE_SB_Pipeld_t Pipeld, int32 TimeOut)`  
*Receive a message from a software bus pipe.*
- `CFE_SB_Buffer_t * CFE_SB_AllocateMessageBuffer (size_t MsgSize)`  
*Get a buffer pointer to use for "zero copy" SB sends.*
- `CFE_Status_t CFE_SB_ReleaseMessageBuffer (CFE_SB_Buffer_t *BufPtr)`  
*Release an unused "zero copy" buffer pointer.*
- `CFE_Status_t CFE_SB_TransmitBuffer (CFE_SB_Buffer_t *BufPtr, bool IncrementSequenceCount)`  
*Transmit a buffer.*
- `void CFE_SB_SetUserDataLength (CFE_MSG_Message_t *MsgPtr, size_t DataLength)`  
*Sets the length of user data in a software bus message.*
- `void CFE_SB_TimeStampMsg (CFE_MSG_Message_t *MsgPtr)`  
*Sets the time field in a software bus message with the current spacecraft time.*
- `int32 CFE_SB_MessageStringSet (char *DestStringPtr, const char *SourceStringPtr, size_t DestMaxSize, size_t SourceMaxSize)`  
*Copies a string into a software bus message.*
- `void * CFE_SB_GetUserData (CFE_MSG_Message_t *MsgPtr)`  
*Get a pointer to the user data portion of a software bus message.*
- `size_t CFE_SB_GetUserDataLength (const CFE_MSG_Message_t *MsgPtr)`  
*Gets the length of user data in a software bus message.*
- `int32 CFE_SB_MessageStringGet (char *DestStringPtr, const char *SourceStringPtr, const char *DefaultString, size_t DestMaxSize, size_t SourceMaxSize)`  
*Copies a string out of a software bus message.*
- `bool CFE_SB_IsValidMsgId (CFE_SB_MsgId_t MsgId)`  
*Identifies whether a given `CFE_SB_MsgId_t` is valid.*
- `static bool CFE_SB_MsgId_Equal (CFE_SB_MsgId_t MsgId1, CFE_SB_MsgId_t MsgId2)`  
*Identifies whether two `CFE_SB_MsgId_t` values are equal.*
- `static CFE_SB_MsgId_Atom_t CFE_SB_MsgIdToValue (CFE_SB_MsgId_t MsgId)`  
*Converts a `CFE_SB_MsgId_t` to a normal integer.*
- `static CFE_SB_MsgId_t CFE_SB_ValueToMsgId (CFE_SB_MsgId_Atom_t MsgIdValue)`  
*Converts a normal integer into a `CFE_SB_MsgId_t`.*

#### 12.54.1 Detailed Description

Purpose: This header file contains all definitions for the cFE Software Bus Application Programmer's Interface.

Author: R.McGraw/SSI

#### 12.54.2 Macro Definition Documentation

### 12.54.2.1 CFE\_BIT

```
#define CFE_BIT(
    x ) (1 << (x))
```

Places a one at bit positions 0 - 31.

Definition at line 44 of file cfe\_sb.h.

### 12.54.2.2 CFE\_CLR

```
#define CFE_CLR(
    i,
    x ) ((i) &= ~CFE_BIT(x))
```

Clears bit x of i.

Definition at line 46 of file cfe\_sb.h.

### 12.54.2.3 CFE\_SET

```
#define CFE_SET(
    i,
    x ) ((i) |= CFE_BIT(x))
```

Sets bit x of i.

Definition at line 45 of file cfe\_sb.h.

### 12.54.2.4 CFE\_TST

```
#define CFE_TST(
    i,
    x ) (((i)&CFE_BIT(x)) != 0)
```

true(non zero) if bit x of i is set

Definition at line 47 of file cfe\_sb.h.

## 12.55 cfe/modules/core\_api/fsw/inc/cfe\_sb\_api\_typedefs.h File Reference

```
#include "common_types.h"
#include "cfe_sb_extern_typedefs.h"
#include "cfe_msg_api_typedefs.h"
#include "cfe_resourceid_api_typedefs.h"
#include "cfe_msg_hdr.h"
```

## Data Structures

- union [CFE\\_SB\\_Msg](#)  
*Software Bus generic message.*

## Macros

- #define [CFE\\_SB\\_POLL](#) 0  
*Option used with [CFE\\_SB\\_ReceiveBuffer](#) to request immediate pipe status.*
- #define [CFE\\_SB\\_PEND\\_FOREVER](#) -1  
*Option used with [CFE\\_SB\\_ReceiveBuffer](#) to force a wait for next message.*
- #define [CFE\\_SB\\_SUBSCRIPTION](#) 0  
*Subtype specifier used in [CFE\\_SB\\_SingleSubscriptionTlm\\_t](#) by SBN App.*
- #define [CFE\\_SB\\_UNSUBSCRIPTION](#) 1  
*Subtype specified used in [CFE\\_SB\\_SingleSubscriptionTlm\\_t](#) by SBN App.*
- #define [CFE\\_SB\\_MSGID\\_WRAP\\_VALUE](#)(val)  
*Translation macro to convert from MsgId integer values to opaque/abstract API values.*
- #define [CFE\\_SB\\_MSGID\\_C](#)(val) (([CFE\\_SB\\_MsgId\\_t](#))[CFE\\_SB\\_MSGID\\_WRAP\\_VALUE](#)(val))  
*Translation macro to convert to MsgId integer values from a literal.*
- #define [CFE\\_SB\\_MSGID\\_UNWRAP\\_VALUE](#)(mid) ((mid).Value)  
*Translation macro to convert to MsgId integer values from opaque/abstract API values.*
- #define [CFE\\_SB\\_MSGID\\_RESERVED](#) [CFE\\_SB\\_MSGID\\_WRAP\\_VALUE](#)(0)  
*Reserved value for [CFE\\_SB\\_MsgId\\_t](#) that will not match any valid MsgId.*
- #define [CFE\\_SB\\_INVALID\\_MSG\\_ID](#) [CFE\\_SB\\_MSGID\\_C](#)(0)  
*A literal of the [CFE\\_SB\\_MsgId\\_t](#) type representing an invalid ID.*
- #define [CFE\\_SB\\_PIPEID\\_C](#)(val) (([CFE\\_SB\\_Pipeld\\_t](#))[CFE\\_RESOURCEID\\_WRAP](#)(val))  
*Cast/Convert a generic [CFE\\_ResourceId\\_t](#) to a [CFE\\_SB\\_Pipeld\\_t](#).*
- #define [CFE\\_SB\\_INVALID\\_PIPE](#) [CFE\\_SB\\_PIPEID\\_C](#)([CFE\\_RESOURCEID\\_UNDEFINED](#))  
*A [CFE\\_SB\\_Pipeld\\_t](#) value which is always invalid.*
- #define [CFE\\_SB PIPEOPTS IGNOREMINE](#) 0x00000001  
*Messages sent by the app that owns this pipe will not be sent to this pipe.*
- #define [CFE\\_SB\\_DEFAULT\\_QOS](#) (([CFE\\_SB\\_Qos\\_t](#)) {0})  
*Default Qos macro.*

## Typedefs

- typedef union [CFE\\_SB\\_Msg](#) [CFE\\_SB\\_Buffer\\_t](#)  
*Software Bus generic message.*

### 12.55.1 Detailed Description

Purpose: This header file contains all definitions for the cFE Software Bus Application Programmer's Interface.

Author: R.McGraw/SSI

## 12.55.2 Macro Definition Documentation

### 12.55.2.1 CFE\_SB\_DEFAULT\_QOS

```
#define CFE_SB_DEFAULT_QOS ((CFE_SB_Qos_t) {0})
```

Default Qos macro.

Definition at line 135 of file cfe\_sb\_api\_typedefs.h.

Referenced by DS\_CmdAddMID(), and DS\_TableSubscribe().

### 12.55.2.2 CFE\_SB\_INVALID\_MSG\_ID

```
#define CFE_SB_INVALID_MSG_ID CFE_SB_MSGID_C(0)
```

A literal of the [CFE\\_SB\\_MsgId\\_t](#) type representing an invalid ID.

This value should be used for runtime initialization of [CFE\\_SB\\_MsgId\\_t](#) values.

#### Note

This may be a compound literal in a future revision. Per C99, compound literals are lvalues, not rvalues, so this value should not be used in static/compile-time data initialization. For static data initialization purposes (rvalue), [CFE\\_SB\\_MSGID\\_RESERVED](#) should be used instead. However, in the current implementation, they are equivalent.

Definition at line 113 of file cfe\_sb\_api\_typedefs.h.

Referenced by DS\_AppProcessMsg(), DS\_CmdAddMID(), DS\_TableSubscribe(), and DS\_TableUnsubscribe().

### 12.55.2.3 CFE\_SB\_INVALID\_PIPE

```
#define CFE_SB_INVALID_PIPE CFE_SB_PIPEID_C(CFE_RESOURCEID_UNDEFINED)
```

A CFE\_SB\_Pipeld\_t value which is always invalid.

This may be used as a safe initializer for CFE\_SB\_Pipeld\_t values

Definition at line 125 of file cfe\_sb\_api\_typedefs.h.

#### 12.55.2.4 CFE\_SB\_MSGID\_C

```
#define CFE_SB_MSGID_C(  
    val ) ((CFE_SB_MsgId_t)CFE_SB_MSGID_WRAP_VALUE(val))
```

Translation macro to convert to MsgId integer values from a literal.

This ensures that the literal is interpreted as the [CFE\\_SB\\_MsgId\\_t](#) type, rather than the default type associated with that literal (e.g. int/unsigned int).

##### Note

Due to constraints in C99 this style of initializer can only be used at runtime, not for static/compile-time initializers.

##### See also

[CFE\\_SB\\_ValueToMsgId\(\)](#)

Definition at line 80 of file `cfe_sb_api_typedefs.h`.

Referenced by [CFE\\_SB\\_ValueToMsgId\(\)](#).

#### 12.55.2.5 CFE\_SB\_MSGID\_RESERVED

```
#define CFE_SB_MSGID_RESERVED CFE_SB_MSGID_WRAP_VALUE(0)
```

Reserved value for [CFE\\_SB\\_MsgId\\_t](#) that will not match any valid MsgId.

This rvalue macro can be used for static/compile-time data initialization to ensure that the initialized value does not alias to a valid MsgId object.

Definition at line 100 of file `cfe_sb_api_typedefs.h`.

#### 12.55.2.6 CFE\_SB\_MSGID\_UNWRAP\_VALUE

```
#define CFE_SB_MSGID_UNWRAP_VALUE(  
    mid ) ((mid).Value)
```

Translation macro to convert to MsgId integer values from opaque/abstract API values.

This conversion exists in macro form to allow compile-time evaluation for constants, and should not be used directly in application code.

For applications, use the [CFE\\_SB\\_MsgIdToValue\(\)](#) inline function instead.

##### See also

[CFE\\_SB\\_MsgIdToValue\(\)](#)

Definition at line 92 of file `cfe_sb_api_typedefs.h`.

Referenced by [CFE\\_SB\\_MsgId\\_Equal\(\)](#), and [CFE\\_SB\\_MsgIdToValue\(\)](#).

### 12.55.2.7 CFE\_SB\_MSGID\_WRAP\_VALUE

```
#define CFE_SB_MSGID_WRAP_VALUE( val )
```

**Value:**

```
{           \           \
    val }
```

Translation macro to convert from MsgId integer values to opaque/abstract API values.

This conversion exists in macro form to allow compile-time evaluation for constants, and should not be used directly in application code.

For applications, use the [CFE\\_SB\\_ValueToMsgId\(\)](#) inline function instead.

**See also**

[CFE\\_SB\\_ValueToMsgId\(\)](#)

Definition at line 64 of file `cfe_sb_api_typedefs.h`.

### 12.55.2.8 CFE\_SB\_PEND\_FOREVER

```
#define CFE_SB_PEND_FOREVER -1
```

Option used with [CFE\\_SB\\_ReceiveBuffer](#) to force a wait for next message.

Definition at line 46 of file `cfe_sb_api_typedefs.h`.

### 12.55.2.9 CFE\_SB\_PIPEID\_C

```
#define CFE_SB_PIPEID_C( val ) ((CFE_SB_PipeId_t)CFE_RESOURCEID_WRAP(val))
```

Cast/Convert a generic `CFE_ResourceId_t` to a `CFE_SB_PipeId_t`.

Definition at line 118 of file `cfe_sb_api_typedefs.h`.

### 12.55.2.10 CFE\_SB\_POLL

```
#define CFE_SB_POLL 0
```

Option used with [CFE\\_SB\\_ReceiveBuffer](#) to request immediate pipe status.

Definition at line 45 of file `cfe_sb_api_typedefs.h`.

### 12.55.2.11 CFE\_SB\_SUBSCRIPTION

```
#define CFE_SB_SUBSCRIPTION 0
```

Subtype specifier used in [CFE\\_SB\\_SingleSubscriptionTlm\\_t](#) by SBN App.

Definition at line 47 of file `cfe_sb_api_typedefs.h`.

### 12.55.2.12 CFE\_SB\_UNSUBSCRIPTION

```
#define CFE_SB_UNSUBSCRIPTION 1
```

Subtype specified used in [CFE\\_SB\\_SingleSubscriptionTlm\\_t](#) by SBN App.

Definition at line 48 of file `cfe_sb_api_typedefs.h`.

## 12.55.3 Typedef Documentation

### 12.55.3.1 CFE\_SB\_Buffer\_t

```
typedef union CFE_SB_Msg CFE_SB_Buffer_t
```

Software Bus generic message.

## 12.56 cfe/modules/core\_api/fsw/inc/cfe\_sb\_extern\_typedefs.h File Reference

```
#include "common_types.h"
#include "cfe_mission_cfg.h"
#include "cfe_resourceid_typedef.h"
```

## Data Structures

- struct [CFE\\_SB\\_MsgId\\_t](#)  
*CFE\_SB\_MsgId\_t type definition.*
- struct [CFE\\_SB\\_Qos\\_t](#)  
*Quality Of Service Type Definition.*

## Macros

- #define [CFE\\_SB\\_SUB\\_ENTRIES\\_PER\\_PKT](#) 20  
*Configuration parameter used by SBN App.*

## Typedefs

- typedef uint8 [CFE\\_SB\\_QosPriority\\_Enum\\_t](#)  
*Selects the priority level for message routing.*
- typedef uint8 [CFE\\_SB\\_QosReliability\\_Enum\\_t](#)  
*Selects the reliability level for message routing.*
- typedef uint16 [CFE\\_SB\\_Routeld\\_Atom\\_t](#)  
*An integer type that should be used for indexing into the Routing Table.*
- typedef uint32 [CFE\\_SB\\_MsgId\\_Atom\\_t](#)  
*CFE\_SB\_MsgId\_Atom\_t primitive type definition.*
- typedef CFE\_RESOURCEID\_BASE\_TYPE [CFE\\_SB\\_Pipeld\\_t](#)  
*CFE\_SB\_Pipeld\_t to primitive type definition.*

## Enumerations

- enum [CFE\\_SB\\_QosPriority](#) { [CFE\\_SB\\_QosPriority\\_LOW](#) = 0, [CFE\\_SB\\_QosPriority\\_HIGH](#) = 1 }  
*Label definitions associated with CFE\_SB\_QosPriority\_Enum\_t.*
- enum [CFE\\_SB\\_QosReliability](#) { [CFE\\_SB\\_QosReliability\\_LOW](#) = 0, [CFE\\_SB\\_QosReliability\\_HIGH](#) = 1 }  
*Label definitions associated with CFE\_SB\_QosReliability\_Enum\_t.*

### 12.56.1 Detailed Description

Declarations and prototypes for cfe\_sb\_extern\_typedefs module

### 12.56.2 Macro Definition Documentation

### 12.56.2.1 CFE\_SB\_SUB\_ENTRIES\_PER\_PKT

```
#define CFE_SB_SUB_ENTRIES_PER_PKT 20
```

Configuration parameter used by SBN App.

Definition at line 42 of file cfe\_sb\_extern\_typedefs.h.

### 12.56.3 Typedef Documentation

#### 12.56.3.1 CFE\_SB\_MsgId\_Atom\_t

```
typedef uint32 CFE_SB_MsgId_Atom_t
```

CFE\_SB\_MsgId\_Atom\_t primitive type definition.

This is an integer type capable of holding any Message ID value Note: This value is limited via [CFE\\_PLATFORM\\_S←B\\_HIGHEST\\_VALID\\_MSGID](#)

Definition at line 103 of file cfe\_sb\_extern\_typedefs.h.

#### 12.56.3.2 CFE\_SB\_Pipeld\_t

```
typedef CFE_RESOURCEID_BASE_TYPE CFE_SB_PipeId_t
```

CFE\_SB\_Pipeld\_t to primitive type definition.

Software Bus pipe identifier used in many SB APIs, as well as SB Telemetry messages and data files.

Definition at line 126 of file cfe\_sb\_extern\_typedefs.h.

#### 12.56.3.3 CFE\_SB\_QosPriority\_Enum\_t

```
typedef uint8 CFE_SB_QosPriority_Enum_t
```

Selects the priority level for message routing.

##### See also

enum [CFE\\_SB\\_QosPriority](#)

Definition at line 66 of file cfe\_sb\_extern\_typedefs.h.

#### 12.56.3.4 CFE\_SB\_QosReliability\_Enum\_t

```
typedef uint8 CFE_SB_QosReliability_Enum_t
```

Selects the reliability level for message routing.

##### See also

enum [CFE\\_SB\\_QosReliability](#)

Definition at line 90 of file `cfe_sb_extern_typedefs.h`.

#### 12.56.3.5 CFE\_SB\_Routeld\_Atom\_t

```
typedef uint16 CFE_SB_RouteId_Atom_t
```

An integer type that should be used for indexing into the Routing Table.

Definition at line 95 of file `cfe_sb_extern_typedefs.h`.

### 12.56.4 Enumeration Type Documentation

#### 12.56.4.1 CFE\_SB\_QosPriority

```
enum CFE_SB_QosPriority
```

Label definitions associated with `CFE_SB_QosPriority_Enum_t`.

##### Enumerator

CFE_SB_QosPriority_LOW	Normal priority level.
CFE_SB_QosPriority_HIGH	High priority.

Definition at line 47 of file `cfe_sb_extern_typedefs.h`.

#### 12.56.4.2 CFE\_SB\_QosReliability

```
enum CFE_SB_QosReliability
```

Label definitions associated with `CFE_SB_QosReliability_Enum_t`.

**Enumerator**

CFE_SB_QosReliability_LOW	Normal (best-effort) reliability.
CFE_SB_QosReliability_HIGH	High reliability.

Definition at line 71 of file cfe\_sb\_extern\_typedefs.h.

## 12.57 cfe/modules/core\_api/fsw/inc/cfe\_tbl.h File Reference

```
#include "common_types.h"
#include "cfe_error.h"
#include "cfe_tbl_api_typedefs.h"
#include "cfe_sb_api_typedefs.h"
```

**Functions**

- **CFE\_Status\_t CFE\_TBL\_Register (CFE\_TBL\_Handle\_t \*TblHandlePtr, const char \*Name, size\_t Size, uint16 TblOptionFlags, CFE\_TBL\_CallbackFuncPtr\_t TblValidationFuncPtr)**

*Register a table with cFE to obtain Table Management Services.*
- **CFE\_Status\_t CFE\_TBL\_Share (CFE\_TBL\_Handle\_t \*TblHandlePtr, const char \*TblName)**

*Obtain handle of table registered by another application.*
- **CFE\_Status\_t CFE\_TBL\_Unregister (CFE\_TBL\_Handle\_t TblHandle)**

*Unregister a table.*
- **CFE\_Status\_t CFE\_TBL\_Load (CFE\_TBL\_Handle\_t TblHandle, CFE\_TBL\_SrcEnum\_t SrcType, const void \*SrcDataPtr)**

*Load a specified table with data from specified source.*
- **CFE\_Status\_t CFE\_TBL\_Update (CFE\_TBL\_Handle\_t TblHandle)**

*Update contents of a specified table, if an update is pending.*
- **CFE\_Status\_t CFE\_TBL\_Validate (CFE\_TBL\_Handle\_t TblHandle)**

*Perform steps to validate the contents of a table image.*
- **CFE\_Status\_t CFE\_TBL\_Manage (CFE\_TBL\_Handle\_t TblHandle)**

*Perform standard operations to maintain a table.*
- **CFE\_Status\_t CFE\_TBL\_DumpToBuffer (CFE\_TBL\_Handle\_t TblHandle)**

*Copies the contents of a Dump Only Table to a shared buffer.*
- **CFE\_Status\_t CFE\_TBL\_Modified (CFE\_TBL\_Handle\_t TblHandle)**

*Notify cFE Table Services that table contents have been modified by the Application.*
- **CFE\_Status\_t CFE\_TBL\_GetAddress (void \*\*TblPtr, CFE\_TBL\_Handle\_t TblHandle)**

*Obtain the current address of the contents of the specified table.*
- **CFE\_Status\_t CFE\_TBL\_ReleaseAddress (CFE\_TBL\_Handle\_t TblHandle)**

*Release previously obtained pointer to the contents of the specified table.*
- **CFE\_Status\_t CFE\_TBL\_GetAddresses (void \*\*TblPtrs[], uint16 NumTables, const CFE\_TBL\_Handle\_t TblHandles[])**

*Obtain the current addresses of an array of specified tables.*
- **CFE\_Status\_t CFE\_TBL\_ReleaseAddresses (uint16 NumTables, const CFE\_TBL\_Handle\_t TblHandles[])**

*Release the addresses of an array of specified tables.*

- **CFE\_Status\_t CFE\_TBL\_GetStatus (CFE\_TBL\_Handle\_t TblHandle)**  
*Obtain current status of pending actions for a table.*
- **CFE\_Status\_t CFE\_TBL\_GetInfo (CFE\_TBL\_Info\_t \*TblInfoPtr, const char \*TblName)**  
*Obtain characteristics/information of/about a specified table.*
- **CFE\_Status\_t CFE\_TBL\_NotifyByMessage (CFE\_TBL\_Handle\_t TblHandle, CFE\_SB\_MsgId\_t MsgId, CFE\_MSG\_FcnCode\_t CommandCode, uint32 Parameter)**  
*Instruct cFE Table Services to notify Application via message when table requires management.*

#### 12.57.1 Detailed Description

Title: Table Services API Application Library Header File

Purpose: Unit specification for Table services library functions and macros.

Design Notes:

References: Flight Software Branch C Coding Standard Version 1.0a

Notes:

## 12.58 cfe/modules/core\_api/fsw/inc/cfe\_tbl\_api\_typedefs.h File Reference

```
#include "common_types.h"
#include "cfe_mission_cfg.h"
#include "cfe_tbl_extern_typedefs.h"
#include "cfe_time_extern_typedefs.h"
```

### Data Structures

- struct **CFE\_TBL\_Info**

*Table Info.*

### Macros

- #define **CFE\_TBL\_OPT\_BUFFER\_MSK** (0x0001)  
*Table buffer mask.*
- #define **CFE\_TBL\_OPT\_SNGL\_BUFFER** (0x0000)  
*Single buffer table.*
- #define **CFE\_TBL\_OPT\_DBL\_BUFFER** (0x0001)  
*Double buffer table.*
- #define **CFE\_TBL\_OPT\_LD\_DMP\_MSK** (0x0002)  
*Table load/dump mask.*
- #define **CFE\_TBL\_OPT\_LOAD\_DUMP** (0x0000)  
*Load/Dump table.*
- #define **CFE\_TBL\_OPT\_DUMP\_ONLY** (0x0002)

- `#define CFE_TBL_OPT_USR_DEF_MSK (0x0004)`

*Table user defined mask.*
- `#define CFE_TBL_OPT_NOT_USR_DEF (0x0000)`

*Not user defined table.*
- `#define CFE_TBL_OPT_USR_DEF_ADDR (0x0006)`

*User Defined table.,*
- `#define CFE_TBL_OPT_CRITICAL_MSK (0x0008)`

*Table critical mask.*
- `#define CFE_TBL_OPT_NOT_CRITICAL (0x0000)`

*Not critical table.*
- `#define CFE_TBL_OPT_CRITICAL (0x0008)`

*Critical table.*
- `#define CFE_TBL_OPT_DEFAULT (CFE_TBL_OPT_SNGL_BUFFER | CFE_TBL_OPT_LOAD_DUMP)`

*Default table options.*
- `#define CFE_TBL_MAX_FULL_NAME_LEN (CFE_MISSION_TBL_MAX_FULL_NAME_LEN)`

*Table maximum full name length.*
- `#define CFE_TBL_BAD_TABLE_HANDLE (CFE_TBL_Handle_t)0xFFFF`

*Bad table handle.*

## Typedefs

- `typedef int32(* CFE_TBL_CallbackFuncPtr_t) (void *TblPtr)`

*Table Callback Function.*
- `typedef int16 CFE_TBL_Handle_t`

*Table Handle primitive.*
- `typedef enum CFE_TBL_SrcEnum CFE_TBL_SrcEnum_t`

*Table Source.*
- `typedef struct CFE_TBL_Info CFE_TBL_Info_t`

*Table Info.*

## Enumerations

- `enum CFE_TBL_SrcEnum { CFE_TBL_SRC_FILE = 0, CFE_TBL_SRC_ADDRESS }`

*Table Source.*

### 12.58.1 Detailed Description

Title: Table Services API Application Library Header File

Purpose: Unit specification for Table services library functions and macros.

Design Notes:

References: Flight Software Branch C Coding Standard Version 1.0a

Notes:

## 12.58.2 Macro Definition Documentation

### 12.58.2.1 CFE\_TBL\_BAD\_TABLE\_HANDLE

```
#define CFE_TBL_BAD_TABLE_HANDLE (CFE_TBL_Handle_t) 0xFFFF
```

Bad table handle.

Definition at line 79 of file cfe\_tbl\_api\_typedefs.h.

### 12.58.2.2 CFE\_TBL\_MAX\_FULL\_NAME\_LEN

```
#define CFE_TBL_MAX_FULL_NAME_LEN (CFE_MISSION_TBL_MAX_FULL_NAME_LEN)
```

Table maximum full name length.

The full length of table names is defined at the mission scope. This is defined here to support applications that depend on [cfe\\_tbl.h](#) providing this value.

Definition at line 76 of file cfe\_tbl\_api\_typedefs.h.

## 12.58.3 Typedef Documentation

### 12.58.3.1 CFE\_TBL\_CallbackFuncPtr\_t

```
typedef int32 (* CFE_TBL_CallbackFuncPtr_t) (void *TblPtr)
```

Table Callback Function.

Definition at line 84 of file cfe\_tbl\_api\_typedefs.h.

### 12.58.3.2 CFE\_TBL\_Handle\_t

```
typedef int16 CFE_TBL_Handle_t
```

Table Handle primitive.

Definition at line 87 of file cfe\_tbl\_api\_typedefs.h.

### 12.58.3.3 CFE\_TBL\_Info\_t

```
typedef struct CFE_TBL_Info CFE_TBL_Info_t
```

Table Info.

### 12.58.3.4 CFE\_TBL\_SrcEnum\_t

```
typedef enum CFE_TBL_SrcEnum CFE_TBL_SrcEnum_t
```

Table Source.

## 12.58.4 Enumeration Type Documentation

### 12.58.4.1 CFE\_TBL\_SrcEnum

```
enum CFE_TBL_SrcEnum
```

Table Source.

#### Enumerator

CFE_TBL_SRC_FILE	File source When this option is selected, the <code>SrcDataPtr</code> will be interpreted as a pointer to a null terminated character string. The string should specify the full path and filename of the file containing the initial data contents of the table.
CFE_TBL_SRC_ADDRESS	Address source When this option is selected, the <code>SrcDataPtr</code> will be interpreted as a pointer to a memory location that is the beginning of the initialization data for loading the table OR, in the case of a "user defined" dump only table, the address of the active table itself. The block of memory is assumed to be of the same size specified in the <code>CFE_TBL_Register</code> function <code>Size</code> parameter.

Definition at line 90 of file `cfe_tbl_api_typedefs.h`.

## 12.59 cfe/modules/core\_api/fsw/inc/cfe\_tbl\_extern\_typedefs.h File Reference

```
#include "common_types.h"
#include "cfe_es_extern_typedefs.h"
#include "cfe_mission_cfg.h"
```

#### Data Structures

- struct `CFE_TBL_File_Hdr`

*The definition of the header fields that are included in CFE Table Data files.*

## Typedefs

- **typedef uint16 CFE\_TBL\_BufferSelect\_Enum\_t**  
*Selects the buffer to operate on for validate or dump commands.*
- **typedef struct CFE\_TBL\_File\_Hdr CFE\_TBL\_File\_Hdr\_t**  
*The definition of the header fields that are included in CFE Table Data files.*

## Enumerations

- **enum CFE\_TBL\_BufferSelect { CFE\_TBL\_BufferSelect\_INACTIVE = 0, CFE\_TBL\_BufferSelect\_ACTIVE = 1 }**  
*Label definitions associated with CFE\_TBL\_BufferSelect\_Enum\_t.*

### 12.59.1 Detailed Description

Declarations and prototypes for cfe\_tbl\_extern\_typedefs module

### 12.59.2 Typedef Documentation

#### 12.59.2.1 CFE\_TBL\_BufferSelect\_Enum\_t

**typedef uint16 CFE\_TBL\_BufferSelect\_Enum\_t**

Selects the buffer to operate on for validate or dump commands.

See also

enum [CFE\\_TBL\\_BufferSelect](#)

Definition at line 64 of file cfe\_tbl\_extern\_typedefs.h.

#### 12.59.2.2 CFE\_TBL\_File\_Hdr\_t

**typedef struct CFE\_TBL\_File\_Hdr CFE\_TBL\_File\_Hdr\_t**

The definition of the header fields that are included in CFE Table Data files.

This header follows the CFE\_FS header and precedes the actual table data.

### 12.59.3 Enumeration Type Documentation

#### 12.59.3.1 CFE\_TBL\_BufferSelect

enum [CFE\\_TBL\\_BufferSelect](#)

Label definitions associated with CFE\_TBL\_BufferSelect\_Enum\_t.

**Enumerator**

CFE_TBL_BufferSelect_INACTIVE	Select the Inactive buffer for validate or dump.
CFE_TBL_BufferSelect_ACTIVE	Select the Active buffer for validate or dump.

Definition at line 45 of file cfe\_tbl\_extern\_typedefs.h.

## 12.60 cfe/modules/core\_api/fsw/inc/cfe\_tbl\_filedef.h File Reference

```
#include "cfe_mission_cfg.h"
#include "common_types.h"
#include "cfe_tbl_extern_typedefs.h"
#include "cfe_fs_extern_typedefs.h"
```

**Data Structures**

- struct [CFE\\_TBL\\_FileDef](#)

**Macros**

- #define [CFE\\_TBL\\_FILEDEF](#)(ObjName, TblName, Desc, Filename)

**Typedefs**

- typedef struct [CFE\\_TBL\\_FileDef](#) [CFE\\_TBL\\_FileDef\\_t](#)

### 12.60.1 Detailed Description

Title: ELF2CFETBL Utility Header File for Table Images

Purpose: This header file provides a data structure definition and macro definition required in source code that is intended to be compiled into a cFE compatible Table Image file.

Design Notes:

Typically, a user would include this file in a ".c" file that contains nothing but a desired instantiation of values for a table image along with the macro defined below. After compilation, the resultant elf file can be processed using the 'elf2cfetbl' utility to generate a file that can be loaded onto a cFE flight system and successfully loaded into a table using the cFE Table Services.

References: Flight Software Branch C Coding Standard Version 1.0a

Notes:

## 12.60.2 Macro Definition Documentation

### 12.60.2.1 CFE\_TBL\_FILEDEF

```
#define CFE_TBL_FILEDEF(ObjName, TblName, Desc, Filename )
```

#### Value:

```
static OS_USED CFE_TBL_FileDef_t CFE_TBL_FileDef = {#ObjName "\0", #TblName "\0", #Desc "\0", #Filename "\0", \
sizeof(ObjName)};
```

The CFE\_TBL\_FILEDEF macro can be used to simplify the declaration of a table image when using the elf2cfetbl utility.

Note that the macro adds a NULL at the end to ensure that it is null-terminated. (C allows a struct to be statically initialized with a string exactly the length of the array, which loses the null terminator.) This means the actual length limit of the fields are the above LEN - 1.

An example of the source code and how this macro would be used is as follows:

```
#include "cfe_tbl_filedef.h"

typedef struct MyTblStruct
{
    int      Int1;
    int      Int2;
    int      Int3;
    char    Char1;
} MyTblStruct_t;

MyTblStruct_t MyTblStruct = { 0x01020304, 0x05060708, 0x090A0B0C, 0x0D };

CFE_TBL_FILEDEF(MyTblStruct, MyApp.TableName, Table Utility Test Table, MyTblDefault.bin )
```

Definition at line 95 of file cfe\_tbl\_filedef.h.

## 12.60.3 Typedef Documentation

### 12.60.3.1 CFE\_TBL\_FileDef\_t

```
typedef struct CFE_TBL_FileDef CFE_TBL_FileDef_t
```

## 12.61 cfe/modules/core\_api/fsw/inc/cfe\_time.h File Reference

```
#include "common_types.h"
#include "cfe_error.h"
#include "cfe_time_api_typedefs.h"
#include "cfe_es_api_typedefs.h"
```

### Macros

- `#define CFE_TIME_Copy(m, t)`  
*Time Copy.*

### Functions

- `CFE_TIME_SysTime_t CFE_TIME_GetTime (void)`  
*Get the current spacecraft time.*
- `CFE_TIME_SysTime_t CFE_TIME_GetTAI (void)`  
*Get the current TAI (MET + SCTF) time.*
- `CFE_TIME_SysTime_t CFE_TIME_GetUTC (void)`  
*Get the current UTC (MET + SCTF - Leap Seconds) time.*
- `CFE_TIME_SysTime_t CFE_TIME_GetMET (void)`  
*Get the current value of the Mission Elapsed Time (MET).*
- `uint32 CFE_TIME_GetMETseconds (void)`  
*Get the current seconds count of the mission-elapsed time.*
- `uint32 CFE_TIME_GetMETsubsecs (void)`  
*Get the current sub-seconds count of the mission-elapsed time.*
- `CFE_TIME_SysTime_t CFE_TIME_GetSTCF (void)`  
*Get the current value of the spacecraft time correction factor (STCF).*
- `int16 CFE_TIME_GetLeapSeconds (void)`  
*Get the current value of the leap seconds counter.*
- `CFE_TIME_ClockState_Enum_t CFE_TIME_GetClockState (void)`  
*Get the current state of the spacecraft clock.*
- `uint16 CFE_TIME_GetClockInfo (void)`  
*Provides information about the spacecraft clock.*
- `CFE_TIME_SysTime_t CFE_TIME_Add (CFE_TIME_SysTime_t Time1, CFE_TIME_SysTime_t Time2)`  
*Adds two time values.*
- `CFE_TIME_SysTime_t CFE_TIME_Subtract (CFE_TIME_SysTime_t Time1, CFE_TIME_SysTime_t Time2)`  
*Subtracts two time values.*
- `CFE_TIME_Compare_t CFE_TIME_Compare (CFE_TIME_SysTime_t TimeA, CFE_TIME_SysTime_t TimeB)`  
*Compares two time values.*
- `CFE_TIME_SysTime_t CFE_TIME_MET2SCTime (CFE_TIME_SysTime_t METTime)`  
*Convert specified MET into Spacecraft Time.*
- `uint32 CFE_TIME_Sub2MicroSecs (uint32 SubSeconds)`  
*Converts a sub-seconds count to an equivalent number of microseconds.*
- `uint32 CFE_TIME_Micro2SubSecs (uint32 MicroSeconds)`

- Converts a number of microseconds to an equivalent sub-seconds count.
- void [CFE\\_TIME\\_ExternalTone](#) (void)
 

*Provides the 1 Hz signal from an external source.*
- void [CFE\\_TIME\\_ExternalMET](#) ([CFE\\_TIME\\_SysTime\\_t](#) NewMET)
 

*Provides the Mission Elapsed Time from an external source.*
- void [CFE\\_TIME\\_ExternalGPS](#) ([CFE\\_TIME\\_SysTime\\_t](#) NewTime, [int16](#) NewLeaps)
 

*Provide the time from an external source that has data common to GPS receivers.*
- void [CFE\\_TIME\\_ExternalTime](#) ([CFE\\_TIME\\_SysTime\\_t](#) NewTime)
 

*Provide the time from an external source that measures time relative to a known epoch.*
- [CFE\\_Status\\_t CFE\\_TIME\\_RegisterSynchCallback](#) ([CFE\\_TIME\\_SynchCallbackPtr\\_t](#) CallbackFuncPtr)
 

*Registers a callback function that is called whenever time synchronization occurs.*
- [CFE\\_Status\\_t CFE\\_TIME\\_UnregisterSynchCallback](#) ([CFE\\_TIME\\_SynchCallbackPtr\\_t](#) CallbackFuncPtr)
 

*Unregisters a callback function that is called whenever time synchronization occurs.*
- void [CFE\\_TIME\\_Print](#) (char \*PrintBuffer, [CFE\\_TIME\\_SysTime\\_t](#) TimeToPrint)
 

*Print a time value as a string.*
- void [CFE\\_TIME\\_Local1HzISR](#) (void)
 

*This function is called via a timer callback set up at initialization of the TIME service.*

### 12.61.1 Detailed Description

Purpose: cFE Time Services (TIME) library API header file

Author: S.Walling/Microtel

Notes:

### 12.61.2 Macro Definition Documentation

#### 12.61.2.1 CFE\_TIME\_Copy

```
#define CFE_TIME_Copy(
    m,
    t )
```

**Value:**

```
{
    (m)->Seconds      = (t)->Seconds;      \
    (m)->Subseconds   = (t)->Subseconds;   \
}
```

Time Copy.

Macro to copy systime into another systime. Preferred to use this macro as it does not require the two arguments to be exactly the same type, it will work with any two structures that define "Seconds" and "Subseconds" members.

Definition at line 48 of file [cfe\\_time.h](#).

## 12.62 cfe/modules/core\_api/fsw/inc/cfe\_time\_api\_typedefs.h File Reference

```
#include "common_types.h"
#include "cfe_time_extern_typedefs.h"
```

### Macros

- #define CFE\_TIME\_PRINTED\_STRING\_SIZE 24

*Required size of buffer to be passed into CFE\_TIME\_Print (includes null terminator)*

### Typedefs

- typedef enum CFE\_TIME\_Compare CFE\_TIME\_Compare\_t
  - Enumerated types identifying the relative relationships of two times.*
- typedef int32(\* CFE\_TIME\_SynchCallbackPtr\_t) (void)
  - Time Synchronization Callback Function Ptr Type.*

### Enumerations

- enum CFE\_TIME\_Compare { CFE\_TIME\_A\_LT\_B = -1, CFE\_TIME\_EQUAL = 0, CFE\_TIME\_A\_GT\_B = 1 }

*Enumerated types identifying the relative relationships of two times.*

### 12.62.1 Detailed Description

Purpose: cFE Time Services (TIME) library API header file

Author: S.Walling/Microtel

Notes:

### 12.62.2 Macro Definition Documentation

#### 12.62.2.1 CFE\_TIME\_PRINTED\_STRING\_SIZE

```
#define CFE_TIME_PRINTED_STRING_SIZE 24
```

Required size of buffer to be passed into CFE\_TIME\_Print (includes null terminator)

Definition at line 44 of file cfe\_time\_api\_typedefs.h.

### 12.62.3 Typedef Documentation

#### 12.62.3.1 CFE\_TIME\_Compare\_t

```
typedef enum CFE_TIME_Compare CFE_TIME_Compare_t
```

Enumerated types identifying the relative relationships of two times.

##### Description

Since time fields contain numbers that are relative to an epoch time, then it is possible for a time value to be "negative". This can lead to some confusion about what relationship exists between two time values. To resolve this confusion, the cFE provides the API [CFE\\_TIME\\_Compare](#) which returns these enumerated values.

#### 12.62.3.2 CFE\_TIME\_SynchCallbackPtr\_t

```
typedef int32 (* CFE_TIME_SynchCallbackPtr_t) (void)
```

Time Synchronization Callback Function Ptr Type.

##### Description

Applications that wish to get direct notification of the receipt of the cFE Time Synchronization signal (typically a 1 Hz signal), must register a callback function with the following prototype via the [CFE\\_TIME\\_RegisterSynchCallback](#) API.

Definition at line 75 of file cfe\_time\_api\_typedefs.h.

### 12.62.4 Enumeration Type Documentation

#### 12.62.4.1 CFE\_TIME\_Compare

```
enum CFE_TIME_Compare
```

Enumerated types identifying the relative relationships of two times.

##### Description

Since time fields contain numbers that are relative to an epoch time, then it is possible for a time value to be "negative". This can lead to some confusion about what relationship exists between two time values. To resolve this confusion, the cFE provides the API [CFE\\_TIME\\_Compare](#) which returns these enumerated values.

## Enumerator

CFE_TIME_A_LT_B	The first specified time is considered to be before the second specified time.
CFE_TIME_EQUAL	The two specified times are considered to be equal.
CFE_TIME_A_GT_B	The first specified time is considered to be after the second specified time.

Definition at line 60 of file cfe\_time\_api\_typedefs.h.

## 12.63 cfe/modules/core\_api/fsw/inc/cfe\_time\_extern\_typedefs.h File Reference

```
#include "common_types.h"
```

## Data Structures

- struct [CFE\\_TIME\\_SysTime](#)

*Data structure used to hold system time values.*

## Typedefs

- typedef struct [CFE\\_TIME\\_SysTime CFE\\_TIME\\_SysTime\\_t](#)

*Data structure used to hold system time values.*

- typedef [uint8 CFE\\_TIME\\_FlagBit\\_Enum\\_t](#)

*Bit positions of the various clock state flags.*

- typedef [int16 CFE\\_TIME\\_ClockState\\_Enum\\_t](#)

*Enumerated types identifying the quality of the current time.*

- typedef [uint8 CFE\\_TIME\\_SourceSelect\\_Enum\\_t](#)

*Clock Source Selection Parameters.*

- typedef [uint8 CFE\\_TIME\\_ToneSignalSelect\\_Enum\\_t](#)

*Tone Signal Selection Parameters.*

- typedef [uint8 CFE\\_TIME\\_AdjustDirection\\_Enum\\_t](#)

*STCF adjustment direction (for both one-time and 1Hz adjustments)*

- typedef [uint8 CFE\\_TIME\\_FlywheelState\\_Enum\\_t](#)

*Fly-wheel status values.*

- typedef [uint8 CFE\\_TIME\\_SetState\\_Enum\\_t](#)

*Clock status values (has the clock been set to correct time)*

## Enumerations

- enum `CFE_TIME_FlagBit` {  
    `CFE_TIME_FlagBit_CLKSET` = 0, `CFE_TIME_FlagBit_FLYING` = 1, `CFE_TIME_FlagBit_SRCINT` = 2, `CFE_TIME_FlagBit_SIGPRI` = 3,  
    `CFE_TIME_FlagBit_SRVFLY` = 4, `CFE_TIME_FlagBit_CMDFLY` = 5, `CFE_TIME_FlagBit_ADDADJ` = 6, `CFE_TIME_FlagBit_ADD1HZ` = 7,  
    `CFE_TIME_FlagBit_ADDTCL` = 8, `CFE_TIME_FlagBit_SERVER` = 9, `CFE_TIME_FlagBit_GDTONE` = 10 }  
        *Label definitions associated with CFE\_TIME\_FlagBit\_Enum\_t.*
- enum `CFE_TIME_ClockState` { `CFE_TIME_ClockState_INVALID` = -1, `CFE_TIME_ClockState_VALID` = 0, `CFE_TIME_ClockState_FLYWHEEL` = 1 }  
        *Label definitions associated with CFE\_TIME\_ClockState\_Enum\_t.*
- enum `CFE_TIME_SourceSelect` { `CFE_TIME_SourceSelect_INTERNAL` = 1, `CFE_TIME_SourceSelect_EXTERNAL` = 2 }  
        *Label definitions associated with CFE\_TIME\_SourceSelect\_Enum\_t.*
- enum `CFE_TIME_ToneSignalSelect` { `CFE_TIME_ToneSignalSelect_PRIMARY` = 1, `CFE_TIME_ToneSignalSelect_REDUNDANT` = 2 }  
        *Label definitions associated with CFE\_TIME\_ToneSignalSelect\_Enum\_t.*
- enum `CFE_TIME_AdjustDirection` { `CFE_TIME_AdjustDirection_ADD` = 1, `CFE_TIME_AdjustDirection_SUBTRACT` = 2 }  
        *Label definitions associated with CFE\_TIME\_AdjustDirection\_Enum\_t.*
- enum `CFE_TIME_FlywheelState` { `CFE_TIME_FlywheelState_NO_FLY` = 0, `CFE_TIME_FlywheelState_IS_FLY` = 1 }  
        *Label definitions associated with CFE\_TIME\_FlywheelState\_Enum\_t.*
- enum `CFE_TIME_SetState` { `CFE_TIME_SetState_NOT_SET` = 0, `CFE_TIME_SetState_WAS_SET` = 1 }  
        *Label definitions associated with CFE\_TIME\_SetState\_Enum\_t.*

### 12.63.1 Detailed Description

Declarations and prototypes for `cfe_time_extern_typedefs` module

### 12.63.2 Typedef Documentation

#### 12.63.2.1 `CFE_TIME_AdjustDirection_Enum_t`

```
typedef uint8 CFE_TIME_AdjustDirection_Enum_t
```

STCF adjustment direction (for both one-time and 1Hz adjustments)

#### See also

enum `CFE_TIME_AdjustDirection`

Definition at line 249 of file `cfe_time_extern_typedefs.h`.

### 12.63.2.2 CFE\_TIME\_ClockState\_Enum\_t

```
typedef int16 CFE_TIME_ClockState_Enum_t
```

Enumerated types identifying the quality of the current time.

#### Description

The `CFE_TIME_ClockState_Enum_t` enumerations identify the three recognized states of the current time. If the clock has never been successfully synchronized with the primary onboard clock source, the time is considered to be `CFE_TIME_ClockState_INVALID`. If the time is currently synchronized (i.e. - the primary synchronization mechanism has not been dropped for any significant amount of time), then the current time is considered to be `CFE_TIME_ClockState_VALID`. If the time had, at some point in the past, been synchronized, but the synchronization with the primary onboard clock has since been lost, then the time is considered to be `CFE_TIME_ClockState_FLYWHEEL`. Since different clocks drift at different rates from one another, the accuracy of the time while in `CFE_TIME_ClockState_FLYWHEEL` is dependent upon the time spent in that state.

#### See also

enum `CFE_TIME_ClockState`

Definition at line 177 of file `cfe_time_extern_typedefs.h`.

### 12.63.2.3 CFE\_TIME\_FlagBit\_Enum\_t

```
typedef uint8 CFE_TIME_FlagBit_Enum_t
```

Bit positions of the various clock state flags.

#### See also

enum `CFE_TIME_FlagBit`

Definition at line 124 of file `cfe_time_extern_typedefs.h`.

### 12.63.2.4 CFE\_TIME\_FlywheelState\_Enum\_t

```
typedef uint8 CFE_TIME_FlywheelState_Enum_t
```

Fly-wheel status values.

#### See also

enum `CFE_TIME_FlywheelState`

Definition at line 273 of file `cfe_time_extern_typedefs.h`.

### 12.63.2.5 CFE\_TIME\_SetState\_Enum\_t

```
typedef uint8 CFE_TIME_SetState_Enum_t
```

Clock status values (has the clock been set to correct time)

See also

```
enum CFE_TIME_SetState
```

Definition at line 297 of file cfe\_time\_extern\_typedefs.h.

### 12.63.2.6 CFE\_TIME\_SourceSelect\_Enum\_t

```
typedef uint8 CFE_TIME_SourceSelect_Enum_t
```

Clock Source Selection Parameters.

See also

```
enum CFE_TIME_SourceSelect
```

Definition at line 201 of file cfe\_time\_extern\_typedefs.h.

### 12.63.2.7 CFE\_TIME\_SysTime\_t

```
typedef struct CFE_TIME_SysTime CFE_TIME_SysTime_t
```

Data structure used to hold system time values.

#### Description

The `CFE_TIME_SysTime_t` data structure is used to hold time values. Time is referred to as the elapsed time (in seconds and subseconds) since a specified epoch time. The subseconds field contains the number of  $2^{(-32)}$  second intervals that have elapsed since the epoch.

### 12.63.2.8 CFE\_TIME\_ToneSignalSelect\_Enum\_t

```
typedef uint8 CFE_TIME_ToneSignalSelect_Enum_t
```

Tone Signal Selection Parameters.

See also

```
enum CFE_TIME_ToneSignalSelect
```

Definition at line 225 of file cfe\_time\_extern\_typedefs.h.

## 12.63.3 Enumeration Type Documentation

### 12.63.3.1 CFE\_TIME\_AdjustDirection

```
enum CFE_TIME_AdjustDirection
```

Label definitions associated with `CFE_TIME_AdjustDirection_Enum_t`.

**Enumerator**

CFE_TIME_AdjustDirection_ADD	Add time adjustment.
CFE_TIME_AdjustDirection_SUBTRACT	Subtract time adjustment.

Definition at line 230 of file cfe\_time\_extern\_typedefs.h.

**12.63.3.2 CFE\_TIME\_ClockState**

enum [CFE\\_TIME\\_ClockState](#)

Label definitions associated with CFE\_TIME\_ClockState\_Enum\_t.

**Enumerator**

CFE_TIME_ClockState_INVALID	The spacecraft time has not been set since the last clock reset. Times returned by clock routines have no relationship to any ground-based time reference.
CFE_TIME_ClockState_VALID	The spacecraft time has been set at least once since the last clock reset, and it is synchronized with the primary on-board time base. Times returned by clock routines can be trusted.
CFE_TIME_ClockState_FLYWHEEL	The spacecraft time has been set at least once since the last clock reset, but it is not currently synchronized with the primary on-board time base. Times returned by clock routines are a "best guess" based on a non-optimal oscillator.

Definition at line 129 of file cfe\_time\_extern\_typedefs.h.

**12.63.3.3 CFE\_TIME\_FlagBit**

enum [CFE\\_TIME\\_FlagBit](#)

Label definitions associated with CFE\_TIME\_FlagBit\_Enum\_t.

**Enumerator**

CFE_TIME_FlagBit_CLKSET	The spacecraft time has been set.
CFE_TIME_FlagBit_FLYING	This instance of Time Services is flywheeling.
CFE_TIME_FlagBit_SRCINT	The clock source is set to internal.
CFE_TIME_FlagBit_SIGPRI	The clock signal is set to primary.
CFE_TIME_FlagBit_SRVFLY	The Time Server is in flywheel mode.
CFE_TIME_FlagBit_CMDFLY	This instance of Time Services was commanded into flywheel mode.
CFE_TIME_FlagBit_ADDADJ	One time STCF Adjustment is to be done in positive direction.
CFE_TIME_FlagBit_ADD1HZ	1 Hz STCF Adjustment is to be done in a positive direction
CFE_TIME_FlagBit_ADDTCL	Time Client Latency is applied in a positive direction.
CFE_TIME_FlagBit_SERVER	This instance of Time Services is a Time Server.
CFE_TIME_FlagBit_GDTONE	The tone received is good compared to the last tone received.

Definition at line 60 of file cfe\_time\_extern\_typedefs.h.

#### 12.63.3.4 CFE\_TIME\_FlywheelState

enum [CFE\\_TIME\\_FlywheelState](#)

Label definitions associated with CFE\_TIME\_FlywheelState\_Enum\_t.

Enumerator

<a href="#">CFE_TIME_FlywheelState_NO_FLY</a>	Not in flywheel state.
<a href="#">CFE_TIME_FlywheelState_IS_FLY</a>	In flywheel state.

Definition at line 254 of file cfe\_time\_extern\_typedefs.h.

#### 12.63.3.5 CFE\_TIME\_SetState

enum [CFE\\_TIME\\_SetState](#)

Label definitions associated with CFE\_TIME\_SetState\_Enum\_t.

Enumerator

<a href="#">CFE_TIME_SetState_NOT_SET</a>	Spacecraft time has not been set.
<a href="#">CFE_TIME_SetState_WAS_SET</a>	Spacecraft time has been set.

Definition at line 278 of file cfe\_time\_extern\_typedefs.h.

#### 12.63.3.6 CFE\_TIME\_SourceSelect

enum [CFE\\_TIME\\_SourceSelect](#)

Label definitions associated with CFE\_TIME\_SourceSelect\_Enum\_t.

Enumerator

<a href="#">CFE_TIME_SourceSelect_INTERNAL</a>	Use Internal Source.
<a href="#">CFE_TIME_SourceSelect_EXTERNAL</a>	Use External Source.

Definition at line 182 of file cfe\_time\_extern\_typedefs.h.

### 12.63.3.7 CFE\_TIME\_ToneSignalSelect

enum `CFE_TIME_ToneSignalSelect`

Label definitions associated with `CFE_TIME_ToneSignalSelect_Enum_t`.

#### Enumerator

<code>CFE_TIME_ToneSignalSelect_PRIMARY</code>	Primary Source.
<code>CFE_TIME_ToneSignalSelect_REDUNDANT</code>	Redundant Source.

Definition at line 206 of file `cfe_time_extern_typedefs.h`.

## 12.64 cfe/modules/core\_api/fsw/inc/cfe\_version.h File Reference

#### Macros

- `#define CFE_BUILD_NUMBER 163`

*Development: Number of development git commits since CFE\_BUILD\_BASELINE.*
- `#define CFE_BUILD_BASELINE "v7.0.0-rc4"`

*Development: Reference git tag for build number.*
- `#define CFE_MAJOR_VERSION 6`

*Major version number.*
- `#define CFE_MINOR_VERSION 7`

*Minor version number.*
- `#define CFE_REVISION 99`

*Revision version number. Value of 99 indicates a development version.*
- `#define CFE_MISSION_REV 0xFF`

*Mission revision.*
- `#define CFE_STR_HELPER(x) #x`

*Convert argument to string.*
- `#define CFE_STR(x) CFE_STR_HELPER(x)`

*Expand macro before conversion.*
- `#define CFE_SRC_VERSION CFE_BUILD_BASELINE "+dev" CFE_STR(CFE_BUILD_NUMBER)`

*Short Build Version String.*
- `#define CFE_VERSION_STRING "cFE DEVELOPMENT BUILD " CFE_SRC_VERSION " (Codename: Draco), Last Official Release: cfe v6.7.0"`

*Long Build Version String.*

### 12.64.1 Detailed Description

Provide version identifiers for the cFE core. See [Version Numbers](#) for further details.

## 12.64.2 Macro Definition Documentation

### 12.64.2.1 CFE\_BUILD\_BASELINE

```
#define CFE_BUILD_BASELINE "v7.0.0-rc4"
```

Development: Reference git tag for build number.

Definition at line 30 of file cfe\_version.h.

### 12.64.2.2 CFE\_BUILD\_NUMBER

```
#define CFE_BUILD_NUMBER 163
```

Development: Number of development git commits since CFE\_BUILD\_BASELINE.

Definition at line 29 of file cfe\_version.h.

### 12.64.2.3 CFE\_MAJOR\_VERSION

```
#define CFE_MAJOR_VERSION 6
```

Major version number.

Definition at line 33 of file cfe\_version.h.

### 12.64.2.4 CFE\_MINOR\_VERSION

```
#define CFE_MINOR_VERSION 7
```

Minor version number.

Definition at line 34 of file cfe\_version.h.

### 12.64.2.5 CFE\_MISSION\_REV

```
#define CFE_MISSION_REV 0xFF
```

Mission revision.

Values 1-254 are reserved for mission use to denote patches/customizations as needed. NOTE: Reserving 0 and 0xFF for cFS open-source development use (pending resolution of nasa/cFS#440)

Definition at line 44 of file cfe\_version.h.

#### 12.64.2.6 CFE\_REVISION

```
#define CFE_REVISION 99
```

Revision version number. Value of 99 indicates a development version.

Definition at line 35 of file cfe\_version.h.

#### 12.64.2.7 CFE\_SRC\_VERSION

```
#define CFE_SRC_VERSION CFE_BUILD_BASELINE "+dev" CFE_STR(CFE_BUILD_NUMBER)
```

Short Build Version String.

Short string identifying the build, see [Version Numbers](#) for suggested format for development and official releases.

Definition at line 55 of file cfe\_version.h.

#### 12.64.2.8 CFE\_STR

```
#define CFE_STR( x ) CFE_STR_HELPER(x)
```

Expand macro before conversion.

Definition at line 47 of file cfe\_version.h.

#### 12.64.2.9 CFE\_STR\_HELPER

```
#define CFE_STR_HELPER( x ) #x
```

Convert argument to string.

Definition at line 46 of file cfe\_version.h.

#### 12.64.2.10 CFE\_VERSION\_STRING

```
#define CFE_VERSION_STRING " cFE DEVELOPMENT BUILD " CFE_SRC_VERSION " (Codename: Draco), Last  
Official Release: cfe v6.7.0"
```

Long Build Version String.

Long freeform string identifying the build, see [Version Numbers](#) for suggested format for development and official releases.

Definition at line 63 of file cfe\_version.h.

## 12.65 cfe/modules/es/fsw/inc/cfe\_es\_events.h File Reference

### Macros

#### ES event IDs

- #define `CFE_ES_INIT_INF_EID` 1  
*ES Initialization Event ID.*
- #define `CFE_ES_INITSTATS_INF_EID` 2  
*ES Initialization Statistics Information Event ID.*
- #define `CFE_ES_NOOP_INF_EID` 3  
*ES No-op Command Success Event ID.*
- #define `CFE_ES_RESET_INF_EID` 4  
*ES Reset Counters Command Success Event ID.*
- #define `CFE_ES_START_INF_EID` 6  
*ES Start Application Command Success Event ID.*
- #define `CFE_ES_STOP_DBG_EID` 7  
*ES Stop Application Command Request Success Event ID.*
- #define `CFE_ES_STOP_INF_EID` 8  
*ES Stop Application Completed Event ID.*
- #define `CFE_ES_RESTART_APP_DBG_EID` 9  
*ES Restart Application Command Request Success Event ID.*
- #define `CFE_ES_RESTART_APP_INF_EID` 10  
*ES Restart Application Completed Event ID.*
- #define `CFE_ES_RELOAD_APP_DBG_EID` 11  
*ES Reload Application Command Request Success Event ID.*
- #define `CFE_ES_RELOAD_APP_INF_EID` 12  
*ES Reload Application Complete Event ID.*
- #define `CFE_ES_EXIT_APP_INF_EID` 13  
*ES Nominal Exit Application Complete Event ID.*
- #define `CFE_ES_ERREXIT_APP_INF_EID` 14  
*ES Error Exit Application Complete Event ID.*
- #define `CFE_ES_ONE_APP_EID` 15  
*ES Query One Application Command Success Event ID.*
- #define `CFE_ES_ALL_APPS_EID` 16  
*ES Query All Applications Command Success Event ID.*
- #define `CFE_ES_SYSLOG1_INF_EID` 17  
*ES Clear System Log Command Success Event ID.*
- #define `CFE_ES_SYSLOG2_EID` 18  
*ES Write System Log Command Success Event ID.*
- #define `CFE_ES_ERLOG1_INF_EID` 19  
*ES Clear Exception Reset Log Command Success Event ID.*
- #define `CFE_ES_ERLOG2_EID` 20  
*ES Write Exception Reset Log Complete Event ID.*
- #define `CFE_ES_MID_ERR_EID` 21  
*ES Invalid Message ID Received Event ID.*
- #define `CFE_ES_CC1_ERR_EID` 22  
*ES Invalid Command Code Received Event ID.*
- #define `CFE_ES_LEN_ERR_EID` 23  
*ES Invalid Command Length Event ID.*
- #define `CFE_ES_BOOT_ERR_EID` 24  
*ES Restart Command Invalid Restart Type Event ID.*
- #define `CFE_ES_START_ERR_EID` 26  
*ES Start Application Command Application Creation Failed Event ID.*

- #define `CFE_ES_START_INVALID_FILENAME_ERR_EID` 27  
*ES Start Application Command Invalid Filename Event ID.*
- #define `CFE_ES_START_INVALID_ENTRY_POINT_ERR_EID` 28  
*ES Start Application Command Entry Point NULL Event ID.*
- #define `CFE_ES_START_NULL_APP_NAME_ERR_EID` 29  
*ES Start Application Command App Name NULL Event ID.*
- #define `CFE_ES_START_PRIORITY_ERR_EID` 31  
*ES Start Application Command Priority Too Large Event ID.*
- #define `CFE_ES_START_EXC_ACTION_ERR_EID` 32  
*ES Start Application Command Exception Action Invalid Event ID.*
- #define `CFE_ES_ERREXIT_APP_ERR_EID` 33  
*ES Error Exit Application Cleanup Failed Event ID.*
- #define `CFE_ES_STOP_ERR1_EID` 35  
*ES Stop Application Command Request Failed Event ID.*
- #define `CFE_ES_STOP_ERR2_EID` 36  
*ES Stop Application Command Get AppID By Name Failed Event ID.*
- #define `CFE_ES_STOP_ERR3_EID` 37  
*ES Stop Application Cleanup Failed Event ID.*
- #define `CFE_ES_RESTART_APP_ERR1_EID` 38  
*ES Restart Application Command Request Failed Event ID.*
- #define `CFE_ES_RESTART_APP_ERR2_EID` 39  
*ES Restart Application Command Get AppID By Name Failed Event ID.*
- #define `CFE_ES_RESTART_APP_ERR3_EID` 40  
*ES Restart Application Startup Failed Event ID.*
- #define `CFE_ES_RESTART_APP_ERR4_EID` 41  
*ES Restart Application Cleanup Failed Event ID.*
- #define `CFE_ES_RELOAD_APP_ERR1_EID` 42  
*ES Reload Application Command Request Failed Event ID.*
- #define `CFE_ES_RELOAD_APP_ERR2_EID` 43  
*ES Reload Application Command Get AppID By Name Failed Event ID.*
- #define `CFE_ES_RELOAD_APP_ERR3_EID` 44  
*ES Reload Application Startup Failed Event ID.*
- #define `CFE_ES_RELOAD_APP_ERR4_EID` 45  
*ES Reload Application Cleanup Failed Event ID.*
- #define `CFE_ES_EXIT_APP_ERR_EID` 46  
*ES Exit Application Cleanup Failed Event ID.*
- #define `CFE_ES_PCR_ERR1_EID` 47  
*ES Process Control Invalid Exception State Event ID.*
- #define `CFE_ES_PCR_ERR2_EID` 48  
*ES Process Control Unknown State Event ID.*
- #define `CFE_ES_ONE_ERR_EID` 49  
*ES Query One Application Data Command Transmit Message Failed Event ID.*
- #define `CFE_ES_ONE_APPID_ERR_EID` 50  
*ES Query One Application Data Command Get AppID By Name Failed Event ID.*
- #define `CFE_ES_OSCREATE_ERR_EID` 51  
*ES Query All Application Data Command File Creation Failed Event ID.*
- #define `CFE_ES_WRHDR_ERR_EID` 52  
*ES Query All Application Data Command File Write Header Failed Event ID.*
- #define `CFE_ES_TASKWR_ERR_EID` 53  
*ES Query All Application Data Command File Write App Data Failed Event ID.*
- #define `CFE_ES_SYSLOG2_ERR_EID` 55  
*ES Write System Log Command Filename Parse or File Creation Failed Event ID.*
- #define `CFE_ES_ERLOG2_ERR_EID` 56  
*ES Write Exception Reset Log Command Request or File Creation Failed Event ID.*
- #define `CFE_ES_PERF_STARTCMD_EID` 57

- #define CFE\_ES\_PERF\_STARTCMD\_ERR\_EID 58  
*ES Start Performance Analyzer Data Collection Command Success Event ID.*
- #define CFE\_ES\_PERF\_STARTCMD\_TRIG\_ERR\_EID 59  
*ES Start Performance Analyzer Data Collection Command Idle Check Failed Event ID.*
- #define CFE\_ES\_PERF\_STOPCMD\_EID 60  
*ES Start Performance Analyzer Data Collection Command Invalid Trigger Event ID.*
- #define CFE\_ES\_PERF\_STOPCMD\_ERR2\_EID 62  
*ES Stop Performance Analyzer Data Collection Command Request Success Event ID.*
- #define CFE\_ES\_PERF\_FILTMSKCMD\_EID 63  
*ES Stop Performance Analyzer Data Collection Command Request Idle Check Failed Event ID.*
- #define CFE\_ES\_PERF\_FILTMSKERR\_EID 64  
*ES Set Performance Analyzer Filter Mask Command Success Event ID.*
- #define CFE\_ES\_PERF\_TRIGMSKCMD\_EID 65  
*ES Set Performance Analyzer Filter Mask Command Invalid Index Event ID.*
- #define CFE\_ES\_PERF\_TRIGMSKERR\_EID 66  
*ES Set Performance Analyzer Trigger Mask Command Success Event ID.*
- #define CFE\_ES\_PERF\_LOG\_ERR\_EID 67  
*ES Set Performance Analyzer Trigger Mask Command Invalid Mask Event ID.*
- #define CFE\_ES\_PERF\_DATAWRITTEN\_EID 68  
*ES Stop Performance Analyzer Data Collection Command Filename Parse or File Create Failed Event ID.*
- #define CFE\_ES\_CDS\_REGISTER\_ERR\_EID 69  
*Performance Log Write Success Event ID.*
- #define CFE\_ES\_ERR\_SYSLOGMODE\_EID 70  
*ES Register CDS API Failed Event ID.*
- #define CFE\_ES\_SET\_SYSLOGMODE\_EID 71  
*ES Set System Log Overwrite Mode Command Success Event ID.*
- #define CFE\_ES\_RESET\_PR\_COUNT\_EID 72  
*ES Set System Log Overwrite Mode Command Failed Event ID.*
- #define CFE\_ES\_SET\_MAX\_PR\_COUNT\_EID 73  
*ES Set Processor Reset Counter to Zero Command Success Event ID.*
- #define CFE\_ES\_FILEWRITE\_ERR\_EID 74  
*ES Set Maximum Processor Reset Limit Command Success Event ID.*
- #define CFE\_ES\_CDS\_DELETE\_ERR\_EID 76  
*ES File Write Failed Event ID.*
- #define CFE\_ES\_CDS\_NAME\_ERR\_EID 77  
*ES Delete CDS Command Delete Failed Event ID.*
- #define CFE\_ES\_CDS\_DELETED\_INFO\_EID 78  
*ES Delete CDS Command Lookup CDS Failed Event ID.*
- #define CFE\_ES\_CDS\_DELETE\_TBL\_ERR\_EID 79  
*ES Delete CDS Command Success Event ID.*
- #define CFE\_ES\_CDS\_OWNER\_ACTIVE\_EID 80  
*ES Delete CDS Command For Critical Table Event ID.*
- #define CFE\_ES\_TLM\_POOL\_STATS\_INFO\_EID 81  
*ES Delete CDS Command With Active Owner Event ID.*
- #define CFE\_ES\_INVALID\_POOL\_HANDLE\_ERR\_EID 82  
*ES Telemeter Memory Statistics Command Success Event ID.*
- #define CFE\_ES\_CDS\_REG\_DUMP\_INF\_EID 83  
*ES Telemeter Memory Statistics Command Invalid Handle Event ID.*
- #define CFE\_ES\_CDS\_DUMP\_ERR\_EID 84  
*ES Write Critical Data Store Registry Command Success Event ID.*
- #define CFE\_ES\_WRITE\_CFE\_HDR\_ERR\_EID 85  
*ES Write Critical Data Store Registry Command Record Write Failed Event ID.*
- #define CFE\_ES\_CREATING\_CDS\_DUMP\_ERR\_EID 86  
*ES Write Critical Data Store Registry Command Header Write Failed Event ID.*
- #define CFE\_ES\_FILEWRITEN\_ERR\_EID 87  
*ES Write Critical Data Store Registry Command Filename Parse or File Create Failed Event ID.*

- #define [CFE\\_ES\\_TASKINFO\\_EID](#) 87  
*ES Write All Task Data Command Success Event ID.*
- #define [CFE\\_ES\\_TASKINFO\\_OSCREATE\\_ERR\\_EID](#) 88  
*ES Write All Task Data Command Filename Parse or File Create Failed Event ID.*
- #define [CFE\\_ES\\_TASKINFO\\_WRHDR\\_ERR\\_EID](#) 89  
*ES Write All Task Data Command Write Header Failed Event ID.*
- #define [CFE\\_ES\\_TASKINFO\\_WR\\_ERR\\_EID](#) 90  
*ES Write All Task Data Command Write Data Failed Event ID.*
- #define [CFE\\_ES\\_VERSION\\_INF\\_EID](#) 91  
*CFS Version Information Event ID*
- #define [CFE\\_ES\\_BUILD\\_INF\\_EID](#) 92  
*CFS Build Information Event ID*
- #define [CFE\\_ES\\_ERLOG\\_PENDING\\_ERR\\_EID](#) 93  
*ES Write Exception Reset Log Command Already In Progress Event ID.*

#### 12.65.1 Detailed Description

cFE Executive Services Event IDs

#### 12.65.2 Macro Definition Documentation

##### 12.65.2.1 [CFE\\_ES\\_ALL\\_APPS\\_EID](#)

```
#define CFE_ES_ALL_APPS_EID 16
```

ES Query All Applications Command Success Event ID.

Type: DEBUG

Cause:

[ES Query All Applications Command](#) success.

Definition at line 206 of file cfe\_es\_events.h.

### 12.65.2.2 CFE\_ES\_BOOT\_ERR\_EID

```
#define CFE_ES_BOOT_ERR_EID 24
```

ES Restart Command Invalid Restart Type Event ID.

Type: **ERROR**

Cause:

[ES cFE Restart Command](#) failure due to invalid restart type.

Definition at line 294 of file cfe\_es\_events.h.

### 12.65.2.3 CFE\_ES\_BUILD\_INF\_EID

```
#define CFE_ES_BUILD_INF_EID 92
```

cFS Build Information Event ID

Type: **INFORMATION**

Cause:

ES Initialization complete and response to [ES NO-OP Command](#).

The Build field identifies the build date, time, hostname and user identifier of the build host machine for the current running binary. The first string is the build date/time, and the second string is formatted as "user@hostname"

This additionally reports the configuration name that was selected by the user, which may affect various platform/mission limits.

By default, if not specified/overridden, the default values of these variables will be: BUILDDATE ==> the output of "date +%Y%m%d%H%M" HOSTNAME ==> the output of "hostname" USER ==> the output of "whoami"

The values can be overridden by setting an environment variable with the names above to the value desired for the field when running "make".

Definition at line 1047 of file cfe\_es\_events.h.

#### 12.65.2.4 CFE\_ES\_CC1\_ERR\_EID

```
#define CFE_ES_CC1_ERR_EID 22
```

ES Invalid Command Code Received Event ID.

Type: ERROR

Cause:

Invalid command code for message ID [CFE\\_ES\\_CMD\\_MID](#) received on the ES message pipe.

Definition at line 272 of file `cfe_es_events.h`.

#### 12.65.2.5 CFE\_ES\_CDS\_DELETE\_ERR\_EID

```
#define CFE_ES_CDS_DELETE_ERR_EID 76
```

ES Delete CDS Command Delete Failed Event ID.

Type: ERROR

Cause:

[ES Delete CDS Command](#) failed while deleting, see reported status code or system log for details.

Definition at line 834 of file `cfe_es_events.h`.

#### 12.65.2.6 CFE\_ES\_CDS\_DELETE\_TBL\_ERR\_EID

```
#define CFE_ES_CDS_DELETE_TBL_ERR_EID 79
```

ES Delete CDS Command For Critical Table Event ID.

Type: ERROR

Cause:

[Delete CDS Command](#) failure due to the specified CDS name being a critical table. Critical Table images can only be deleted via a Table Services command, [CFE\\_TBL\\_DELETE\\_CDS\\_CC](#).

Definition at line 871 of file `cfe_es_events.h`.

**12.65.2.7 CFE\_ES\_CDS\_DELETED\_INFO\_EID**

```
#define CFE_ES_CDS_DELETED_INFO_EID 78
```

ES Delete CDS Command Success Event ID.

Type: INFORMATION

Cause:

[ES Delete CDS Command](#) success.

Definition at line 857 of file cfe\_es\_events.h.

**12.65.2.8 CFE\_ES\_CDS\_DUMP\_ERR\_EID**

```
#define CFE_ES_CDS_DUMP_ERR_EID 84
```

ES Write Critical Data Store Registry Command Record Write Failed Event ID.

Type: ERROR

Cause:

[ES Write Critical Data Store Registry Command](#) failed to write CDS record.

Definition at line 929 of file cfe\_es\_events.h.

**12.65.2.9 CFE\_ES\_CDS\_NAME\_ERR\_EID**

```
#define CFE_ES_CDS_NAME_ERR_EID 77
```

ES Delete CDS Command Lookup CDS Failed Event ID.

Type: ERROR

Cause:

[ES Delete CDS Command](#) failed due to the specified CDS name not found in the CDS Registry.

Definition at line 846 of file cfe\_es\_events.h.

**12.65.2.10 CFE\_ES\_CDS\_OWNER\_ACTIVE\_EID**

```
#define CFE_ES_CDS_OWNER_ACTIVE_EID 80
```

ES Delete CDS Command With Active Owner Event ID.

Type: ERROR

Cause:

[ES Delete CDS Command](#) failure due to the specifies CDS name is registered to an active application.

Definition at line 883 of file cfe\_es\_events.h.

**12.65.2.11 CFE\_ES\_CDS\_REG\_DUMP\_INF\_EID**

```
#define CFE_ES_CDS_REG_DUMP_INF_EID 83
```

ES Write Critical Data Store Registry Command Success Event ID.

Type: DEBUG

Cause:

[ES Write Critical Data Store Registry Command](#) success.

Definition at line 917 of file cfe\_es\_events.h.

**12.65.2.12 CFE\_ES\_CDS\_REGISTER\_ERR\_EID**

```
#define CFE_ES_CDS_REGISTER_ERR_EID 69
```

ES Register CDS API Failed Event ID.

Type: ERROR

Cause:

[CFE\\_ES\\_RegisterCDS](#) API failure, see reported status code or system log for details.

Definition at line 766 of file cfe\_es\_events.h.

**12.65.2.13 CFE\_ES\_CREATING\_CDS\_DUMP\_ERR\_EID**

```
#define CFE_ES_CREATING_CDS_DUMP_ERR_EID 86
```

ES Write Critical Data Store Registry Command Filename Parse or File Create Failed Event ID.

Type: **ERROR**

Cause:

[ES Write Critical Data Store Registry Command](#) failed to parse filename or open/create the file. OVERLOADED

Definition at line 953 of file cfe\_es\_events.h.

**12.65.2.14 CFE\_ES\_ERLOG1\_INF\_EID**

```
#define CFE_ES_ERLOG1_INF_EID 19
```

ES Clear Exception Reset Log Command Success Event ID.

Type: **INFORMATION**

Cause:

[ES Clear Exception Reset Log Command](#) success.

Definition at line 239 of file cfe\_es\_events.h.

**12.65.2.15 CFE\_ES\_ERLOG2\_EID**

```
#define CFE_ES_ERLOG2_EID 20
```

ES Write Exception Reset Log Complete Event ID.

Type: **DEBUG**

Cause:

Request to write the Exception Reset log successfully completed.

Definition at line 250 of file cfe\_es\_events.h.

**12.65.2.16 CFE\_ES\_ERLOG2\_ERR\_EID**

```
#define CFE_ES_ERLOG2_ERR_EID 56
```

ES Write Exception Reset Log Command Request or File Creation Failed Event ID.

Type: ERROR

Cause:

[ES Write Exception Reset Log Command](#) request failed or file creation failed. OVERLOADED

Definition at line 626 of file cfe\_es\_events.h.

**12.65.2.17 CFE\_ES\_ERLOG\_PENDING\_ERR\_EID**

```
#define CFE_ES_ERLOG_PENDING_ERR_EID 93
```

ES Write Exception Reset Log Command Already In Progress Event ID.

Type: ERROR

Cause:

[ES Write Exception Reset Log Command](#) failure due to a write already being in progress.

Definition at line 1059 of file cfe\_es\_events.h.

**12.65.2.18 CFE\_ES\_ERR\_SYSLOGMODE\_EID**

```
#define CFE_ES_ERR_SYSLOGMODE_EID 71
```

ES Set System Log Overwrite Mode Command Failed Event ID.

Type: ERROR

Cause:

[ES Set System Log Overwrite Mode Command](#) failed due to invalid mode requested.

Definition at line 789 of file cfe\_es\_events.h.

**12.65.2.19 CFE\_ES\_ERREXIT\_APP\_ERR\_EID**

```
#define CFE_ES_ERREXIT_APP_ERR_EID 33
```

ES Error Exit Application Cleanup Failed Event ID.

**Type:** ERROR

**Cause:**

Error request to exit an application failed during application cleanup. Application and related resources will be in undefined state.

Definition at line 379 of file cfe\_es\_events.h.

**12.65.2.20 CFE\_ES\_ERREXIT\_APP\_INF\_EID**

```
#define CFE_ES_ERREXIT_APP_INF_EID 14
```

ES Error Exit Application Complete Event ID.

**Type:** INFORMATION

**Cause:**

Error request to exit an application successfully completed. This event indicates the Application exited due to an error condition. The details of the error that occurred should be given by the Application through an event message, System Log entry, or both.

Definition at line 184 of file cfe\_es\_events.h.

**12.65.2.21 CFE\_ES\_EXIT\_APP\_ERR\_EID**

```
#define CFE_ES_EXIT_APP_ERR_EID 46
```

ES Exit Application Cleanup Failed Event ID.

Type: **ERROR**

Cause:

Nominal request to exit an application failed during application cleanup. Application and related resources will be in undefined state.

Definition at line 522 of file cfe\_es\_events.h.

**12.65.2.22 CFE\_ES\_EXIT\_APP\_INF\_EID**

```
#define CFE_ES_EXIT_APP_INF_EID 13
```

ES Nominal Exit Application Complete Event ID.

Type: **INFORMATION**

Cause:

Nominal request to exit an application successfully completed. This event indicates the Application exited due to a nominal exit condition.

Definition at line 170 of file cfe\_es\_events.h.

**12.65.2.23 CFE\_ES\_FILEWRITE\_ERR\_EID**

```
#define CFE_ES_FILEWRITE_ERR_EID 74
```

ES File Write Failed Event ID.

Type: **ERROR**

Cause:

ES File Write failure writing data to file. OVERLOADED

Definition at line 822 of file cfe\_es\_events.h.

**12.65.2.24 CFE\_ES\_INIT\_INF\_EID**

```
#define CFE_ES_INIT_INF_EID 1
```

ES Initialization Event ID.

Type: INFORMATION

Cause:

Executive Services Task initialization complete.

Definition at line 42 of file cfe\_es\_events.h.

**12.65.2.25 CFE\_ES\_INITSTATS\_INF\_EID**

```
#define CFE_ES_INITSTATS_INF_EID 2
```

ES Initialization Statistics Information Event ID.

Type: INFORMATION

Cause:

Executive Services Task initialization complete.

Definition at line 53 of file cfe\_es\_events.h.

**12.65.2.26 CFE\_ES\_INVALID\_POOL\_HANDLE\_ERR\_EID**

```
#define CFE_ES_INVALID_POOL_HANDLE_ERR_EID 82
```

ES Telemeter Memory Statistics Command Invalid Handle Event ID.

Type: ERROR

Cause:

[ES Telemeter Memory Statistics Command](#) failure due to an invalid memory handle.

Definition at line 906 of file cfe\_es\_events.h.

**12.65.2.27 CFE\_ES\_LEN\_ERR\_EID**

```
#define CFE_ES_LEN_ERR_EID 23
```

ES Invalid Command Length Event ID.

Type: ERROR

Cause:

Invalid length for the command code in message ID [CFE\\_ES\\_CMD\\_MID](#) received on the ES message pipe.

Definition at line 283 of file cfe\_es\_events.h.

**12.65.2.28 CFE\_ES\_MID\_ERR\_EID**

```
#define CFE_ES_MID_ERR_EID 21
```

ES Invalid Message ID Received Event ID.

Type: ERROR

Cause:

Invalid message ID received on the ES message pipe.

Definition at line 261 of file cfe\_es\_events.h.

**12.65.2.29 CFE\_ES\_NOOP\_INF\_EID**

```
#define CFE_ES_NOOP_INF_EID 3
```

ES No-op Command Success Event ID.

Type: INFORMATION

Cause:

[ES No-op Command](#) success.

Definition at line 64 of file cfe\_es\_events.h.

**12.65.2.30 CFE\_ES\_ONE\_APP\_EID**

```
#define CFE_ES_ONE_APP_EID 15
```

ES Query One Application Command Success Event ID.

Type: DEBUG

Cause:

[ES Query One Application Command](#) success.

Definition at line 195 of file cfe\_es\_events.h.

**12.65.2.31 CFE\_ES\_ONE\_APPID\_ERR\_EID**

```
#define CFE_ES_ONE_APPID_ERR_EID 50
```

ES Query One Application Data Command Get AppID By Name Failed Event ID.

Type: ERROR

Cause:

[ES Query One Application Data Command](#) failed to get application ID from application name. Message will not be sent.

Definition at line 569 of file cfe\_es\_events.h.

**12.65.2.32 CFE\_ES\_ONE\_ERR\_EID**

```
#define CFE_ES_ONE_ERR_EID 49
```

ES Query One Application Data Command Transmit Message Failed Event ID.

Type: ERROR

Cause:

[ES Query One Application Data Command](#) failed during message transmission.

Definition at line 557 of file cfe\_es\_events.h.

**12.65.2.33 CFE\_ES\_OSCREATE\_ERR\_EID**

```
#define CFE_ES_OSCREATE_ERR_EID 51
```

ES Query All Application Data Command File Creation Failed Event ID.

Type: ERROR

Cause:

[ES Query All Application Data Command](#) failed to create file.

Definition at line 580 of file cfe\_es\_events.h.

**12.65.2.34 CFE\_ES\_PCR\_ERR1\_EID**

```
#define CFE_ES_PCR_ERR1_EID 47
```

ES Process Control Invalid Exception State Event ID.

Type: ERROR

Cause:

Invalid Exception state encountered when processing requests for application state changes. Exceptions are processed immediately, so this state should never occur during routine processing.

Definition at line 534 of file cfe\_es\_events.h.

**12.65.2.35 CFE\_ES\_PCR\_ERR2\_EID**

```
#define CFE_ES_PCR_ERR2_EID 48
```

ES Process Control Unknown State Event ID.

Type: ERROR

Cause:

Unknown state encountered when processing requests for application state changes.

Definition at line 545 of file cfe\_es\_events.h.

**12.65.2.36 CFE\_ES\_PERF\_DATAWRITTEN\_EID**

```
#define CFE_ES_PERF_DATAWRITTEN_EID 68
```

Performance Log Write Success Event ID.

Type: DEBUG

Cause:

Request to write the performance log successfully completed.

Definition at line 755 of file cfe\_es\_events.h.

**12.65.2.37 CFE\_ES\_PERF\_FILTMSKCMD\_EID**

```
#define CFE_ES_PERF_FILTMSKCMD_EID 63
```

ES Set Performance Analyzer Filter Mask Command Success Event ID.

Type: DEBUG

Cause:

[ES Set Performance Analyzer Filter Mask Command](#) success.

Definition at line 697 of file cfe\_es\_events.h.

**12.65.2.38 CFE\_ES\_PERF\_FILTMSKERR\_EID**

```
#define CFE_ES_PERF_FILTMSKERR_EID 64
```

ES Set Performance Analyzer Filter Mask Command Invalid Index Event ID.

Type: ERROR

Cause:

[ES Set Performance Analyzer Filter Mask Command](#) failed filter index range check.

Definition at line 709 of file cfe\_es\_events.h.

**12.65.2.39 CFE\_ES\_PERF\_LOG\_ERR\_EID**

```
#define CFE_ES_PERF_LOG_ERR_EID 67
```

ES Stop Performance Analyzer Data Collection Command Filename Parse or File Create Failed Event ID.

Type: **ERROR**

Cause:

[ES Stop Performance Analyzer Data Collection Command](#) failed either parsing the file name or during open/creation of the file. OVERLOADED

Definition at line 744 of file cfe\_es\_events.h.

**12.65.2.40 CFE\_ES\_PERF\_STARTCMD\_EID**

```
#define CFE_ES_PERF_STARTCMD_EID 57
```

ES Start Performance Analyzer Data Collection Command Success Event ID.

Type: **DEBUG**

Cause:

[ES Start Performance Analyzer Data Collection Command](#) success.

Definition at line 637 of file cfe\_es\_events.h.

**12.65.2.41 CFE\_ES\_PERF\_STARTCMD\_ERR\_EID**

```
#define CFE_ES_PERF_STARTCMD_ERR_EID 58
```

ES Start Performance Analyzer Data Collection Command Idle Check Failed Event ID.

Type: **ERROR**

Cause:

[ES Start Performance Analyzer Data Collection Command](#) failed due to already being started.

Definition at line 649 of file cfe\_es\_events.h.

**12.65.2.42 CFE\_ES\_PERF\_STARTCMD\_TRIG\_ERR\_EID**

```
#define CFE_ES_PERF_STARTCMD_TRIG_ERR_EID 59
```

ES Start Performance Analyzer Data Collection Command Invalid Trigger Event ID.

Type: **ERROR**

Cause:

[ES Start Performance Analyzer Data Collection Command](#) failed due to invalid trigger mode.

Definition at line 661 of file cfe\_es\_events.h.

**12.65.2.43 CFE\_ES\_PERF\_STOPCMD\_EID**

```
#define CFE_ES_PERF_STOPCMD_EID 60
```

ES Stop Performance Analyzer Data Collection Command Request Success Event ID.

Type: **DEBUG**

Cause:

[ES Stop Performance Analyzer Data Collection Command](#) success. Note this event signifies the request to stop and write the performance data has been successfully submitted. The successful completion will generate a [CFE\\_ES\\_P←ERF\\_DATAWRITTEN\\_EID](#) event.

Definition at line 674 of file cfe\_es\_events.h.

**12.65.2.44 CFE\_ES\_PERF\_STOPCMD\_ERR2\_EID**

```
#define CFE_ES_PERF_STOPCMD_ERR2_EID 62
```

ES Stop Performance Analyzer Data Collection Command Request Idle Check Failed Event ID.

Type: **ERROR**

Cause:

[ES Stop Performance Analyzer Data Collection Command](#) failed due to a write already in progress.

Definition at line 686 of file cfe\_es\_events.h.

**12.65.2.45 CFE\_ES\_PERF\_TRIGMSKCMD\_EID**

```
#define CFE_ES_PERF_TRIGMSKCMD_EID 65
```

ES Set Performance Analyzer Trigger Mask Command Success Event ID.

Type: DEBUG

Cause:

[ES Set Performance Analyzer Trigger Mask Command](#) success.

Definition at line 720 of file cfe\_es\_events.h.

**12.65.2.46 CFE\_ES\_PERF\_TRIGMSKERR\_EID**

```
#define CFE_ES_PERF_TRIGMSKERR_EID 66
```

ES Set Performance Analyzer Trigger Mask Command Invalid Mask Event ID.

Type: ERROR

Cause:

[ES Set Performance Analyzer Trigger Mask Command](#) failed the mask range check.

Definition at line 732 of file cfe\_es\_events.h.

**12.65.2.47 CFE\_ES\_RELOAD\_APP\_DBG\_EID**

```
#define CFE_ES_RELOAD_APP_DBG_EID 11
```

ES Reload Application Command Request Success Event ID.

Type: DEBUG

Cause:

[ES Reload Application Command](#) success. Note this event signifies the request to reload the application has been successfully submitted. The successful completion will generate a [CFE\\_ES\\_RELOAD\\_APP\\_INF\\_EID](#) event.

Definition at line 147 of file cfe\_es\_events.h.

**12.65.2.48 CFE\_ES\_RELOAD\_APP\_ERR1\_EID**

```
#define CFE_ES_RELOAD_APP_ERR1_EID 42
```

ES Reload Application Command Request Failed Event ID.

Type: ERROR

Cause:

[ES Reload Application Command](#) request failed.

Definition at line 473 of file cfe\_es\_events.h.

**12.65.2.49 CFE\_ES\_RELOAD\_APP\_ERR2\_EID**

```
#define CFE_ES_RELOAD_APP_ERR2_EID 43
```

ES Reload Application Command Get AppID By Name Failed Event ID.

Type: ERROR

Cause:

[ES Reload Application Command](#) failed to get application ID from application name. The application will not be reloaded.

Definition at line 485 of file cfe\_es\_events.h.

**12.65.2.50 CFE\_ES\_RELOAD\_APP\_ERR3\_EID**

```
#define CFE_ES_RELOAD_APP_ERR3_EID 44
```

ES Reload Application Startup Failed Event ID.

Type: ERROR

Cause:

Request to reload an application failed during application startup. The application will not be reloaded.

Definition at line 497 of file cfe\_es\_events.h.

**12.65.2.51 CFE\_ES\_RELOAD\_APP\_ERR4\_EID**

```
#define CFE_ES_RELOAD_APP_ERR4_EID 45
```

ES Reload Application Cleanup Failed Event ID.

Type: **ERROR**

Cause:

Request to reload an application failed during application cleanup. The application will not be reloaded and will be in an undefined state along with its associated resources.

Definition at line 510 of file cfe\_es\_events.h.

**12.65.2.52 CFE\_ES\_RELOAD\_APP\_INF\_EID**

```
#define CFE_ES_RELOAD_APP_INF_EID 12
```

ES Reload Application Complete Event ID.

Type: **INFORMATION**

Cause:

Request to reload an application successfully completed.

Definition at line 158 of file cfe\_es\_events.h.

**12.65.2.53 CFE\_ES\_RESET\_INF\_EID**

```
#define CFE_ES_RESET_INF_EID 4
```

ES Reset Counters Command Success Event ID.

Type: **INFORMATION**

Cause:

[ES Reset Counters Command](#) success.

Definition at line 75 of file cfe\_es\_events.h.

**12.65.2.54 CFE\_ES\_RESET\_PR\_COUNT\_EID**

```
#define CFE_ES_RESET_PR_COUNT_EID 72
```

ES Set Processor Reset Counter to Zero Command Success Event ID.

Type: INFORMATION

Cause:

[ES Set Processor Reset Counter to Zero Command](#) success.

Definition at line 800 of file cfe\_es\_events.h.

**12.65.2.55 CFE\_ES\_RESTART\_APP\_DBG\_EID**

```
#define CFE_ES_RESTART_APP_DBG_EID 9
```

ES Restart Application Command Request Success Event ID.

Type: DEBUG

Cause:

[ES Restart Application Command](#) success. Note this event signifies the request to restart the application has been successfully submitted. The successful completion will generate a [CFE\\_ES\\_RESTART\\_APP\\_INF\\_EID](#) event.

Definition at line 123 of file cfe\_es\_events.h.

**12.65.2.56 CFE\_ES\_RESTART\_APP\_ERR1\_EID**

```
#define CFE_ES_RESTART_APP_ERR1_EID 38
```

ES Restart Application Command Request Failed Event ID.

Type: ERROR

Cause:

[ES Restart Application Command](#) request failed.

Definition at line 425 of file cfe\_es\_events.h.

**12.65.2.57 CFE\_ES\_RESTART\_APP\_ERR2\_EID**

```
#define CFE_ES_RESTART_APP_ERR2_EID 39
```

ES Restart Application Command Get AppID By Name Failed Event ID.

Type: ERROR

Cause:

[ES Restart Application Command](#) failed to get application ID from application name. The application will not be restarted.

Definition at line 437 of file cfe\_es\_events.h.

**12.65.2.58 CFE\_ES\_RESTART\_APP\_ERR3\_EID**

```
#define CFE_ES_RESTART_APP_ERR3_EID 40
```

ES Restart Application Startup Failed Event ID.

Type: ERROR

Cause:

Request to restart an application failed during application startup. The application will not be restarted.

Definition at line 449 of file cfe\_es\_events.h.

**12.65.2.59 CFE\_ES\_RESTART\_APP\_ERR4\_EID**

```
#define CFE_ES_RESTART_APP_ERR4_EID 41
```

ES Restart Application Cleanup Failed Event ID.

Type: ERROR

Cause:

Request to restart an application failed during application cleanup. The application will not be restarted and will be in an undefined state along with its associated resources.

Definition at line 462 of file cfe\_es\_events.h.

**12.65.2.60 CFE\_ES\_RESTART\_APP\_INF\_EID**

```
#define CFE_ES_RESTART_APP_INF_EID 10
```

ES Restart Application Completed Event ID.

Type: INFORMATION

Cause:

Request to restart an application successfully completed.

Definition at line 134 of file cfe\_es\_events.h.

**12.65.2.61 CFE\_ES\_SET\_MAX\_PR\_COUNT\_EID**

```
#define CFE_ES_SET_MAX_PR_COUNT_EID 73
```

ES Set Maximum Processor Reset Limit Command Success Event ID.

Type: INFORMATION

Cause:

[ES Set Maximum Processor Reset Limit Command](#) success.

Definition at line 811 of file cfe\_es\_events.h.

**12.65.2.62 CFE\_ES\_START\_ERR\_EID**

```
#define CFE_ES_START_ERR_EID 26
```

ES Start Application Command Application Creation Failed Event ID.

Type: ERROR

Cause:

[ES Start Application Command](#) failure during application creation after successful parameter validation.

Definition at line 306 of file cfe\_es\_events.h.

**12.65.2.63 CFE\_ES\_START\_EXC\_ACTION\_ERR\_EID**

```
#define CFE_ES_START_EXC_ACTION_ERR_EID 32
```

ES Start Application Command Exception Action Invalid Event ID.

Type: **ERROR**

Cause:

[ES Start Application Command](#) failure due to invalid application exception action.

Definition at line 367 of file cfe\_es\_events.h.

**12.65.2.64 CFE\_ES\_START\_INF\_EID**

```
#define CFE_ES_START_INF_EID 6
```

ES Start Application Command Success Event ID.

Type: **INFORMATION**

Cause:

[ES Start Application Command](#) success.

Definition at line 86 of file cfe\_es\_events.h.

**12.65.2.65 CFE\_ES\_START\_INVALID\_ENTRY\_POINT\_ERR\_EID**

```
#define CFE_ES_START_INVALID_ENTRY_POINT_ERR_EID 28
```

ES Start Application Command Entry Point NULL Event ID.

Type: **ERROR**

Cause:

[ES Start Application Command](#) failure due to a NULL Application Entry Point.

Definition at line 330 of file cfe\_es\_events.h.

**12.65.2.66 CFE\_ES\_START\_INVALID\_FILENAME\_ERR\_EID**

```
#define CFE_ES_START_INVALID_FILENAME_ERR_EID 27
```

ES Start Application Command Invalid Filename Event ID.

Type: ERROR

Cause:

[ES Start Application Command](#) failure due to invalid filename.

Definition at line 318 of file cfe\_es\_events.h.

**12.65.2.67 CFE\_ES\_START\_NULL\_APP\_NAME\_ERR\_EID**

```
#define CFE_ES_START_NULL_APP_NAME_ERR_EID 29
```

ES Start Application Command App Name NULL Event ID.

Type: ERROR

Cause:

[ES Start Application Command](#) failure due to NULL Application Name.

Definition at line 342 of file cfe\_es\_events.h.

**12.65.2.68 CFE\_ES\_START\_PRIORITY\_ERR\_EID**

```
#define CFE_ES_START_PRIORITY_ERR_EID 31
```

ES Start Application Command Priority Too Large Event ID.

Type: ERROR

Cause:

[ES Start Application Command](#) failure due to a requested application priority greater than the maximum priority allowed for tasks as defined by the OS Abstraction Layer (OS\_MAX\_PRIORITY).

Definition at line 355 of file cfe\_es\_events.h.

### 12.65.2.69 CFE\_ES\_STOP\_DBG\_EID

```
#define CFE_ES_STOP_DBG_EID 7
```

ES Stop Application Command Request Success Event ID.

Type: DEBUG

Cause:

[ES Stop Application Command](#) success. Note this event signifies the request to delete the application has been successfully submitted. The successful completion will generate a [CFE\\_ES\\_STOP\\_INF\\_EID](#) event.

Definition at line 99 of file cfe\_es\_events.h.

### 12.65.2.70 CFE\_ES\_STOP\_ERR1\_EID

```
#define CFE_ES_STOP_ERR1_EID 35
```

ES Stop Application Command Request Failed Event ID.

Type: ERROR

Cause:

[ES Stop Application Command](#) request failed.

Definition at line 390 of file cfe\_es\_events.h.

### 12.65.2.71 CFE\_ES\_STOP\_ERR2\_EID

```
#define CFE_ES_STOP_ERR2_EID 36
```

ES Stop Application Command Get AppID By Name Failed Event ID.

Type: ERROR

Cause:

[ES Stop Application Command](#) failed to get application ID from application name. The application will not be deleted.

Definition at line 402 of file cfe\_es\_events.h.

**12.65.2.72 CFE\_ES\_STOP\_ERR3\_EID**

```
#define CFE_ES_STOP_ERR3_EID 37
```

ES Stop Application Cleanup Failed Event ID.

Type: **ERROR**

Cause:

Request to delete an application failed during application cleanup. Application and related resources will be in undefined state.

Definition at line 414 of file cfe\_es\_events.h.

**12.65.2.73 CFE\_ES\_STOP\_INF\_EID**

```
#define CFE_ES_STOP_INF_EID 8
```

ES Stop Application Completed Event ID.

Type: **INFORMATION**

Cause:

Request to delete an application successfully completed.

Definition at line 110 of file cfe\_es\_events.h.

**12.65.2.74 CFE\_ES\_SYSLOG1\_INF\_EID**

```
#define CFE_ES_SYSLOG1_INF_EID 17
```

ES Clear System Log Command Success Event ID.

Type: **INFORMATION**

Cause:

[ES Clear System Log Command](#) success.

Definition at line 217 of file cfe\_es\_events.h.

**12.65.2.75 CFE\_ES\_SYSLOG2\_EID**

```
#define CFE_ES_SYSLOG2_EID 18
```

ES Write System Log Command Success Event ID.

Type: DEBUG

Cause:

[ES Write System Log Command](#) success.

Definition at line 228 of file cfe\_es\_events.h.

**12.65.2.76 CFE\_ES\_SYSLOG2\_ERR\_EID**

```
#define CFE_ES_SYSLOG2_ERR_EID 55
```

ES Write System Log Command Filename Parse or File Creation Failed Event ID.

Type: ERROR

Cause:

[ES Write System Log Command](#) failed parsing file name or creating the file. OVERLOADED

Definition at line 614 of file cfe\_es\_events.h.

**12.65.2.77 CFE\_ES\_SYSLOGMODE\_EID**

```
#define CFE_ES_SYSLOGMODE_EID 70
```

ES Set System Log Overwrite Mode Command Success Event ID.

Type: DEBUG

Cause:

[ES Set System Log Overwrite Mode Command](#) success.

Definition at line 777 of file cfe\_es\_events.h.

**12.65.2.78 CFE\_ES\_TASKINFO\_EID**

```
#define CFE_ES_TASKINFO_EID 87
```

ES Write All Task Data Command Success Event ID.

Type: DEBUG

Cause:

[ES Write All Task Data Command](#) success.

Definition at line 964 of file cfe\_es\_events.h.

**12.65.2.79 CFE\_ES\_TASKINFO\_OSCREATE\_ERR\_EID**

```
#define CFE_ES_TASKINFO_OSCREATE_ERR_EID 88
```

ES Write All Task Data Command Filename Parse or File Create Failed Event ID.

Type: ERROR

Cause:

[ES Write All Task Data Command](#) failed to parse the filename or open/create the file.

Definition at line 976 of file cfe\_es\_events.h.

**12.65.2.80 CFE\_ES\_TASKINFO\_WR\_ERR\_EID**

```
#define CFE_ES_TASKINFO_WR_ERR_EID 90
```

ES Write All Task Data Command Write Data Failed Event ID.

Type: ERROR

Cause:

[ES Write All Task Data Command](#) failed to write task data to file.

Definition at line 1000 of file cfe\_es\_events.h.

**12.65.2.81 CFE\_ES\_TASKINFO\_WRHDR\_ERR\_EID**

```
#define CFE_ES_TASKINFO_WRHDR_ERR_EID 89
```

ES Write All Task Data Command Write Header Failed Event ID.

Type: ERROR

Cause:

[ES Write All Task Data Command](#) failed to write file header.

Definition at line 988 of file cfe\_es\_events.h.

**12.65.2.82 CFE\_ES\_TASKWR\_ERR\_EID**

```
#define CFE_ES_TASKWR_ERR_EID 53
```

ES Query All Application Data Command File Write App Data Failed Event ID.

Type: ERROR

Cause:

[ES Query All Application Data Command](#) failed to write file application data.

Definition at line 602 of file cfe\_es\_events.h.

**12.65.2.83 CFE\_ES\_TLM\_POOL\_STATS\_INFO\_EID**

```
#define CFE_ES_TLM_POOL_STATS_INFO_EID 81
```

ES Telemeter Memory Statistics Command Success Event ID.

Type: DEBUG

Cause:

[ES Telemeter Memory Statistics Command](#) success.

Definition at line 894 of file cfe\_es\_events.h.

**12.65.2.84 CFE\_ES\_VERSION\_INF\_EID**

```
#define CFE_ES_VERSION_INF_EID 91
```

cFS Version Information Event ID

Type: INFORMATION

Cause:

ES Initialization complete and response to [ES NO-OP Command](#).

A separate version info event will be generated for every module which is statically linked into the CFE core executable (e.g. OSAL, PSP, MSG, SBR, etc).

The version information reported in this event is derived from the source revision control system at build time, as opposed to manually-assigned semantic version numbers. It is intended to uniquely identify the actual source code that is currently running, to the extent this is possible.

The Mission version information also identifies the build configuration name, if available.

Definition at line 1021 of file cfe\_es\_events.h.

**12.65.2.85 CFE\_ES\_WRHDR\_ERR\_EID**

```
#define CFE_ES_WRHDR_ERR_EID 52
```

ES Query All Application Data Command File Write Header Failed Event ID.

Type: ERROR

Cause:

[ES Query All Application Data Command](#) failed to write file header.

Definition at line 591 of file cfe\_es\_events.h.

### 12.65.2.86 CFE\_ES\_WRITE\_CFE\_HDR\_ERR\_EID

```
#define CFE_ES_WRITE_CFE_HDR_ERR_EID 85
```

ES Write Critical Data Store Registry Command Header Write Failed Event ID.

Type: ERROR

Cause:

[ES Write Critical Data Store Registry Command](#) failed to write header.

Definition at line 941 of file cfe\_es\_events.h.

## 12.66 cfe/modules/es/fsw/inc/cfe\_es\_msg.h File Reference

```
#include "common_types.h"
#include "cfe_msg_hdr.h"
#include "cfe_es_extern_typedefs.h"
```

### Data Structures

- struct [CFE\\_ES\\_NoArgsCmd](#)  
*Generic "no arguments" command.*
- struct [CFE\\_ES\\_RestartCmd\\_Payload](#)  
*Restart cFE Command Payload.*
- struct [CFE\\_ES\\_RestartCmd](#)  
*Restart cFE Command.*
- struct [CFE\\_ES\\_FileNameCmd\\_Payload](#)  
*Generic file name command payload.*
- struct [CFE\\_ES\\_FileNameCmd](#)  
*Generic file name command.*
- struct [CFE\\_ES\\_OverWriteSysLogCmd\\_Payload](#)  
*Overwrite/Discard System Log Configuration Command Payload.*
- struct [CFE\\_ES\\_OverWriteSysLogCmd](#)  
*Overwrite/Discard System Log Configuration Command Payload.*
- struct [CFE\\_ES\\_StartAppCmd\\_Payload](#)  
*Start Application Command Payload.*
- struct [CFE\\_ES\\_StartApp](#)  
*Start Application Command.*
- struct [CFE\\_ES\\_AppNameCmd\\_Payload](#)  
*Generic application name command payload.*

- struct [CFE\\_ES\\_AppNameCmd](#)  
*Generic application name command.*
- struct [CFE\\_ES\\_AppReloadCmd\\_Payload](#)  
*Reload Application Command Payload.*
- struct [CFE\\_ES\\_ReloadAppCmd](#)  
*Reload Application Command.*
- struct [CFE\\_ES\\_SetMaxPRCountCmd\\_Payload](#)  
*Set Maximum Processor Reset Count Command Payload.*
- struct [CFE\\_ES\\_SetMaxPRCountCmd](#)  
*Set Maximum Processor Reset Count Command.*
- struct [CFE\\_ES\\_DeleteCDSCmd\\_Payload](#)  
*Delete Critical Data Store Command Payload.*
- struct [CFE\\_ES\\_DeleteCDSCmd](#)  
*Delete Critical Data Store Command.*
- struct [CFE\\_ES\\_StartPerfCmd\\_Payload](#)  
*Start Performance Analyzer Command Payload.*
- struct [CFE\\_ES\\_StartPerfDataCmd](#)  
*Start Performance Analyzer Command.*
- struct [CFE\\_ES\\_StopPerfCmd\\_Payload](#)  
*Stop Performance Analyzer Command Payload.*
- struct [CFE\\_ES\\_StopPerfDataCmd](#)  
*Stop Performance Analyzer Command.*
- struct [CFE\\_ES\\_SetPerfFilterMaskCmd\\_Payload](#)  
*Set Performance Analyzer Filter Mask Command Payload.*
- struct [CFE\\_ES\\_SetPerfFilterMaskCmd](#)  
*Set Performance Analyzer Filter Mask Command.*
- struct [CFE\\_ES\\_SetPerfTrigMaskCmd\\_Payload](#)  
*Set Performance Analyzer Trigger Mask Command Payload.*
- struct [CFE\\_ES\\_SetPerfTriggerMaskCmd](#)  
*Set Performance Analyzer Trigger Mask Command.*
- struct [CFE\\_ES\\_SendMemPoolStatsCmd\\_Payload](#)  
*Send Memory Pool Statistics Command Payload.*
- struct [CFE\\_ES\\_SendMemPoolStatsCmd](#)  
*Send Memory Pool Statistics Command.*
- struct [CFE\\_ES\\_DumpCDSRegistryCmd\\_Payload](#)  
*Dump CDS Registry Command Payload.*
- struct [CFE\\_ES\\_DumpCDSRegistryCmd](#)  
*Dump CDS Registry Command.*
- struct [CFE\\_ES\\_OneAppTlm\\_Payload](#)
- struct [CFE\\_ES\\_OneAppTlm](#)
- struct [CFE\\_ES\\_PoolStatsTlm\\_Payload](#)
- struct [CFE\\_ES\\_MemStatsTlm](#)
- struct [CFE\\_ES\\_HousekeepingTlm\\_Payload](#)
- struct [CFE\\_ES\\_HousekeepingTlm](#)

## Macros

### Executive Services Command Codes

- #define CFE\_ES\_NOOP\_CC 0
- #define CFE\_ES\_RESET\_COUNTERS\_CC 1
- #define CFE\_ES\_RESTART\_CC 2
- #define CFE\_ES\_START\_APP\_CC 4
- #define CFE\_ES\_STOP\_APP\_CC 5
- #define CFE\_ES\_RESTART\_APP\_CC 6
- #define CFE\_ES\_RELOAD\_APP\_CC 7
- #define CFE\_ES\_QUERY\_ONE\_CC 8
- #define CFE\_ES\_QUERY\_ALL\_CC 9
- #define CFE\_ES\_CLEAR\_SYSLOG\_CC 10
- #define CFE\_ES\_WRITE\_SYSLOG\_CC 11
- #define CFE\_ES\_CLEAR\_ER\_LOG\_CC 12
- #define CFE\_ES\_WRITE\_ER\_LOG\_CC 13
- #define CFE\_ES\_START\_PERF\_DATA\_CC 14
- #define CFE\_ES\_STOP\_PERF\_DATA\_CC 15
- #define CFE\_ES\_SET\_PERF\_FILTER\_MASK\_CC 16
- #define CFE\_ES\_SET\_PERF\_TRIGGER\_MASK\_CC 17
- #define CFE\_ES\_OVER\_WRITE\_SYSLOG\_CC 18
- #define CFE\_ES\_RESET\_PR\_COUNT\_CC 19
- #define CFE\_ES\_SET\_MAX\_PR\_COUNT\_CC 20
- #define CFE\_ES\_DELETE\_CDS\_CC 21
- #define CFE\_ES\_SEND\_MEM\_POOL\_STATS\_CC 22
- #define CFE\_ES\_DUMP\_CDS\_REGISTRY\_CC 23
- #define CFE\_ES\_QUERY\_ALL\_TASKS\_CC 24

## Typedefs

- typedef struct CFE\_ES\_NoArgsCmd CFE\_ES\_NoArgsCmd\_t
 

*Generic "no arguments" command.*
- typedef CFE\_ES\_NoArgsCmd\_t CFE\_ES\_NoopCmd\_t
- typedef CFE\_ES\_NoArgsCmd\_t CFE\_ES\_ResetCountersCmd\_t
- typedef CFE\_ES\_NoArgsCmd\_t CFE\_ES\_ClearSysLogCmd\_t
- typedef CFE\_ES\_NoArgsCmd\_t CFE\_ES\_ClearERLogCmd\_t
- typedef CFE\_ES\_NoArgsCmd\_t CFE\_ES\_ResetPRCountCmd\_t
- typedef struct CFE\_ES\_RestartCmd\_Payload CFE\_ES\_RestartCmd\_Payload\_t
 

*Restart cFE Command Payload.*
- typedef struct CFE\_ES\_RestartCmd CFE\_ES\_RestartCmd\_t
 

*Restart cFE Command.*
- typedef struct CFE\_ES\_FileNameCmd\_Payload CFE\_ES\_FileNameCmd\_Payload\_t
 

*Generic file name command payload.*
- typedef struct CFE\_ES\_FileNameCmd CFE\_ES\_FileNameCmd\_t
 

*Generic file name command.*
- typedef CFE\_ES\_FileNameCmd\_t CFE\_ES\_QueryAllCmd\_t
- typedef CFE\_ES\_FileNameCmd\_t CFE\_ES\_QueryAllTasksCmd\_t
- typedef CFE\_ES\_FileNameCmd\_t CFE\_ES\_WriteSysLogCmd\_t
- typedef CFE\_ES\_FileNameCmd\_t CFE\_ES\_WriteERLogCmd\_t
- typedef struct CFE\_ES\_OverWriteSysLogCmd\_Payload CFE\_ES\_OverWriteSysLogCmd\_Payload\_t
 

*Overwrite/Discard System Log Configuration Command Payload.*
- typedef struct CFE\_ES\_OverWriteSysLogCmd CFE\_ES\_OverWriteSysLogCmd\_t

- Overwrite/Discard System Log Configuration Command Payload.*
- **typedef struct CFE\_ES\_StartAppCmd\_Payload CFE\_ES\_StartAppCmd\_Payload\_t**  
*Start Application Command Payload.*
  - **typedef struct CFE\_ES\_StartApp CFE\_ES\_StartAppCmd\_t**  
*Start Application Command.*
  - **typedef struct CFE\_ES\_AppNameCmd\_Payload CFE\_ES\_AppNameCmd\_Payload\_t**  
*Generic application name command payload.*
  - **typedef struct CFE\_ES\_AppNameCmd CFE\_ES\_AppNameCmd\_t**  
*Generic application name command.*
  - **typedef CFE\_ES\_AppNameCmd\_t CFE\_ES\_StopAppCmd\_t**
  - **typedef CFE\_ES\_AppNameCmd\_t CFE\_ES\_RestartAppCmd\_t**
  - **typedef CFE\_ES\_AppNameCmd\_t CFE\_ES\_QueryOneCmd\_t**
  - **typedef struct CFE\_ES\_AppReloadCmd\_Payload CFE\_ES\_AppReloadCmd\_Payload\_t**  
*Reload Application Command Payload.*
  - **typedef struct CFE\_ES\_ReloadAppCmd CFE\_ES\_ReloadAppCmd\_t**  
*Reload Application Command.*
  - **typedef struct CFE\_ES\_SetMaxPRCountCmd\_Payload CFE\_ES\_SetMaxPRCountCmd\_Payload\_t**  
*Set Maximum Processor Reset Count Command Payload.*
  - **typedef struct CFE\_ES\_SetMaxPRCountCmd CFE\_ES\_SetMaxPRCountCmd\_t**  
*Set Maximum Processor Reset Count Command.*
  - **typedef struct CFE\_ES\_DeleteCDSCmd\_Payload CFE\_ES\_DeleteCDSCmd\_Payload\_t**  
*Delete Critical Data Store Command Payload.*
  - **typedef struct CFE\_ES\_DeleteCDSCmd CFE\_ES\_DeleteCDSCmd\_t**  
*Delete Critical Data Store Command.*
  - **typedef struct CFE\_ES\_StartPerfCmd\_Payload CFE\_ES\_StartPerfCmd\_Payload\_t**  
*Start Performance Analyzer Command Payload.*
  - **typedef struct CFE\_ES\_StartPerfDataCmd CFE\_ES\_StartPerfDataCmd\_t**  
*Start Performance Analyzer Command.*
  - **typedef struct CFE\_ES\_StopPerfCmd\_Payload CFE\_ES\_StopPerfCmd\_Payload\_t**  
*Stop Performance Analyzer Command Payload.*
  - **typedef struct CFE\_ES\_StopPerfDataCmd CFE\_ES\_StopPerfDataCmd\_t**  
*Stop Performance Analyzer Command.*
  - **typedef struct CFE\_ES\_SetPerfFilterMaskCmd\_Payload CFE\_ES\_SetPerfFilterMaskCmd\_Payload\_t**  
*Set Performance Analyzer Filter Mask Command Payload.*
  - **typedef struct CFE\_ES\_SetPerfFilterMaskCmd CFE\_ES\_SetPerfFilterMaskCmd\_t**  
*Set Performance Analyzer Filter Mask Command.*
  - **typedef struct CFE\_ES\_SetPerfTrigMaskCmd\_Payload CFE\_ES\_SetPerfTrigMaskCmd\_Payload\_t**  
*Set Performance Analyzer Trigger Mask Command Payload.*
  - **typedef struct CFE\_ES\_SetPerfTriggerMaskCmd CFE\_ES\_SetPerfTriggerMaskCmd\_t**  
*Set Performance Analyzer Trigger Mask Command.*
  - **typedef struct CFE\_ES\_SendMemPoolStatsCmd\_Payload CFE\_ES\_SendMemPoolStatsCmd\_Payload\_t**  
*Send Memory Pool Statistics Command Payload.*
  - **typedef struct CFE\_ES\_SendMemPoolStatsCmd CFE\_ES\_SendMemPoolStatsCmd\_t**  
*Send Memory Pool Statistics Command.*
  - **typedef struct CFE\_ES\_DumpCDSRegistryCmd\_Payload CFE\_ES\_DumpCDSRegistryCmd\_Payload\_t**  
*Dump CDS Registry Command Payload.*
  - **typedef struct CFE\_ES\_DumpCDSRegistryCmd CFE\_ES\_DumpCDSRegistryCmd\_t**

*Dump CDS Registry Command.*

- `typedef struct CFE_ES_OneAppTlm_Payload CFE_ES_OneAppTlm_Payload_t`
- `typedef struct CFE_ES_OneAppTlm CFE_ES_OneAppTlm_t`
- `typedef struct CFE_ES_PoolStatsTlm_Payload CFE_ES_PoolStatsTlm_Payload_t`
- `typedef struct CFE_ES_MemStatsTlm CFE_ES_MemStatsTlm_t`
- `typedef struct CFE_ES_HousekeepingTlm_Payload CFE_ES_HousekeepingTlm_Payload_t`
- `typedef struct CFE_ES_HousekeepingTlm CFE_ES_HousekeepingTlm_t`

### 12.66.1 Detailed Description

Purpose: cFE Executive Services (ES) Command and Telemetry packet definition file.

References: Flight Software Branch C Coding Standard Version 1.0a cFE Flight Software Application Developers Guide

Notes:

### 12.66.2 Macro Definition Documentation

#### 12.66.2.1 CFE\_ES\_CLEAR\_ER\_LOG\_CC

```
#define CFE_ES_CLEAR_ER_LOG_CC 12
```

**Name** Clears the contents of the Exception and Reset Log

##### Description

This command causes the contents of the Executive Services Exception and Reset Log to be cleared.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_ClearERLog

##### Command Structure

`CFE_ES_ClearERLogCmd_t`

##### Command Verification

Successful execution of this command may be verified with the following telemetry:

- `$sc_$cpu_ES_CMDPC` - command execution counter will increment
- The `CFE_ES_ERLOG1_INF_EID` informational event message will be generated.
- `$sc_$cpu_ES_ERLOGINDEX` - Index into Exception Reset Log goes to zero

##### Error Conditions

There are no error conditions for this command. If the Executive Services receives the command, the event is sent (although it may be filtered by EVS) and the counter is incremented unconditionally.

##### Criticality

This command is not dangerous. However, any previously logged data will be lost.

##### See also

`CFE_ES_CLEAR_SYSLOG_CC`, `CFE_ES_WRITE_SYSLOG_CC`, `CFE_ES_WRITE_ER_LOG_CC`

Definition at line 550 of file `cfe_es_msg.h`.

### 12.66.2.2 CFE\_ES\_CLEAR\_SYSLOG\_CC

```
#define CFE_ES_CLEAR_SYSLOG_CC 10
```

**Name** Clear Executive Services System Log

#### Description

This command clears the contents of the Executive Services System Log.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_ClearSysLog

#### Command Structure

[CFE\\_ES\\_ClearSysLogCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_ES\\_SYSLOG1\\_INF\\_EID](#) informational event message will be generated.
- [\\$sc\\_\\$cpu\\_ES\\_SYSLOGBYTEUSED](#) - System Log Bytes Used will go to zero
- [\\$sc\\_\\$cpu\\_ES\\_SYSLOGENTRIES](#) - Number of System Log Entries will go to zero

#### Error Conditions

There are no error conditions for this command. If the Executive Services receives the command, the event is sent (although it may be filtered by EVS) and the counter is incremented unconditionally.

#### Criticality

This command is not dangerous. However, any previously logged data will be lost.

#### See also

[CFE\\_ES\\_WRITE\\_SYSLOG\\_CC](#), [CFE\\_ES\\_CLEAR\\_ER\\_LOG\\_CC](#), [CFE\\_ES\\_WRITE\\_ER\\_LOG\\_CC](#), [CFE\\_ES\\_OVER\\_WRITE\\_SYSLOG\\_CC](#)

Definition at line 473 of file `cfe_es_msg.h`.

### 12.66.2.3 CFE\_ES\_DELETE\_CDS\_CC

```
#define CFE_ES_DELETE_CDS_CC 21
```

**Name** Delete Critical Data Store

#### Description

This command allows the user to delete a Critical Data Store that was created by an Application that is now no longer executing.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_DeleteCDS

#### Command Structure

[CFE\\_ES\\_DeleteCDSCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_ES\\_CDS\\_DELETED\\_INFO\\_EID](#) informational event message will be generated.
- The specified CDS should no longer appear in a CDS Registry dump generated upon receipt of the [CFE\\_ES\\_DUMP\\_CDS\\_REGISTRY\\_CC](#) command

#### Error Conditions

This command may fail for the following reason(s):

- The specified CDS is the CDS portion of a Critical Table
- The specified CDS is not found in the CDS Registry
- The specified CDS is associated with an Application that is still active
- An error occurred while accessing the CDS memory (see the System Log for more details)

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases

#### Criticality

This command is not critical because it is not possible to delete a CDS that is associated with an active application. However, deleting a CDS does eliminate any "history" that an application may be wishing to keep.

#### See also

[CFE\\_ES\\_DUMP\\_CDS\\_REGISTRY\\_CC](#), [CFE\\_TBL\\_DELETE\\_CDS\\_CC](#)

Definition at line 919 of file cfe\_es\_msg.h.

#### 12.66.2.4 CFE\_ES\_DUMP\_CDS\_REGISTRY\_CC

```
#define CFE_ES_DUMP_CDS_REGISTRY_CC 23
```

**Name** Dump Critical Data Store Registry to a File

##### Description

This command allows the user to dump the Critical Data Store Registry to an onboard file.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_WriteCDS2File

##### Command Structure

[CFE\\_ES\\_DumpCDSRegistryCmd\\_t](#)

##### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_ES\\_CDS\\_REG\\_DUMP\\_INF\\_EID](#) debug event message will be generated.
- The file specified in the command (or the default specified by the [CFE\\_PLATFORM\\_ES\\_DEFAULT\\_CDS\\_REG\\_DUMP\\_FILE](#) configuration parameter) will be updated with the latest information.

##### Error Conditions

This command may fail for the following reason(s):

- The file name specified could not be parsed
- Error occurred while creating or writing to the dump file

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases

##### Criticality

This command is not inherently dangerous. It will create a new file in the file system (or overwrite an existing one) and could, if performed repeatedly without sufficient file management by the operator, fill the file system.

##### See also

[CFE\\_ES\\_DELETE\\_CDS\\_CC](#), [CFE\\_TBL\\_DELETE\\_CDS\\_CC](#)

Definition at line 1000 of file `cfe_es_msg.h`.

### 12.66.2.5 CFE\_ES\_NOOP\_CC

```
#define CFE_ES_NOOP_CC 0
```

**Name** Executive Services No-Op

#### Description

This command performs no other function than to increment the command execution counter. The command may be used to verify general aliveness of the Executive Services task.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_NOOP

#### Command Structure

[CFE\\_ES\\_NoopCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_ES\\_BUILD\\_INF\\_EID](#) informational event message will be generated
- The [CFE\\_ES\\_NOOP\\_INF\\_EID](#) informational event message will be generated

#### Error Conditions

This command may fail for the following reason(s):

- The command packet length is incorrect

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDEC](#) - command error counter will increment
- the [CFE\\_ES\\_LEN\\_ERR\\_EID](#) error event message will be generated

#### Criticality

None

#### See also

Definition at line 83 of file [cfe\\_es\\_msg.h](#).

### 12.66.2.6 CFE\_ES\_OVER\_WRITE\_SYSLOG\_CC

```
#define CFE_ES_OVER_WRITE_SYSLOG_CC 18
```

**Name** Set Executive Services System Log Mode to Discard/Overwrite

#### Description

This command allows the user to configure the Executive Services to either discard new System Log messages when it is full or to overwrite the oldest messages.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_OverwriteSysLogMode

#### Command Structure

[CFE\\_ES\\_OverWriteSysLogCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter will increment
- [\\$sc\\_\\$cpu\\_ES\\_SYSLOGMODE](#) - Current System Log Mode should reflect the commanded value
- The [CFE\\_ES\\_SYSLOGMODE\\_EID](#) debug event message will be generated.

#### Error Conditions

This command may fail for the following reason(s):

- The desired mode is neither [CFE\\_ES\\_LogMode\\_OVERWRITE](#) or [CFE\\_ES\\_LogMode\\_DISCARD](#)

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases

#### Criticality

None. (It should be noted that "Overwrite" mode would allow a message identifying the cause of a problem to be lost by a subsequent flood of additional messages).

#### See also

[CFE\\_ES\\_CLEAR\\_SYSLOG\\_CC](#), [CFE\\_ES\\_WRITE\\_SYSLOG\\_CC](#)

Definition at line 802 of file `cfe_es_msg.h`.

### 12.66.2.7 CFE\_ES\_QUERY\_ALL\_CC

```
#define CFE_ES_QUERY_ALL_CC 9
```

**Name** Writes all Executive Services Information on all loaded modules to a File

#### Description

This command takes the information kept by Executive Services on all of the registered applications and libraries and writes it to the specified file.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_WriteAppInfo2File

#### Command Structure

[CFE\\_ES\\_QueryAllCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_ES\\_ALL\\_APPS\\_EID](#) debug event message will be generated.
- The file specified in the command (or the default specified by the [CFE\\_PLATFORM\\_ES\\_DEFAULT\\_APP\\_LOG\\_FILE](#) configuration parameter) will be updated with the latest information.

#### Error Conditions

This command may fail for the following reason(s):

- The specified FileName cannot be parsed
- An Error occurs while trying to write to the file

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases

#### Criticality

This command is not inherently dangerous. It will create a new file in the file system (or overwrite an existing one) and could, if performed repeatedly without sufficient file management by the operator, fill the file system.

#### See also

[CFE\\_ES\\_QUERY\\_ONE\\_CC](#), [CFE\\_ES\\_QUERY\\_ALL\\_TASKS\\_CC](#)

Definition at line 438 of file cfe\_es\_msg.h.

### 12.66.2.8 CFE\_ES\_QUERY\_ALL\_TASKS\_CC

```
#define CFE_ES_QUERY_ALL_TASKS_CC 24
```

**Name** Writes a list of All Executive Services Tasks to a File

#### Description

This command takes the information kept by Executive Services on all of the registered tasks and writes it to the specified file.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_WriteTaskInfo2File

#### Command Structure

[CFE\\_ES\\_QueryAllTasksCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_ES\\_TASKINFO\\_EID](#) debug event message will be generated.
- The file specified in the command (or the default specified by the [CFE\\_PLATFORM\\_ES\\_DEFAULT\\_TASKLOG\\_FILE](#) configuration parameter) will be updated with the latest information.

#### Error Conditions

This command may fail for the following reason(s):

- The file name specified could not be parsed
- An Error occurs while trying to write to the file

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases

#### Criticality

This command is not inherently dangerous. It will create a new file in the file system (or overwrite an existing one) and could, if performed repeatedly without sufficient file management by the operator, fill the file system.

#### See also

[CFE\\_ES\\_QUERY\\_ALL\\_CC](#), [CFE\\_ES\\_QUERY\\_ONE\\_CC](#)

Definition at line 1042 of file `cfe_es_msg.h`.

### 12.66.2.9 CFE\_ES\_QUERY\_ONE\_CC

```
#define CFE_ES_QUERY_ONE_CC 8
```

**Name** Request Executive Services Information on a specified module

#### Description

This command takes the information kept by Executive Services on the specified application or library and telemeters it to the ground.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_QueryApp

#### Command Structure

[CFE\\_ES\\_QueryOneCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_ES\\_ONE\\_APP\\_EID](#) debug event message will be generated.
- Receipt of the [CFE\\_ES\\_OneAppTlm\\_t](#) telemetry packet

#### Error Conditions

This command may fail for the following reason(s):

- The specified name is not recognized as an active application or library

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases

#### Criticality

None

#### See also

[CFE\\_ES\\_QUERY\\_ALL\\_CC](#), [CFE\\_ES\\_QUERY\\_ALL\\_TASKS\\_CC](#)

Definition at line 396 of file cfe\_es\_msg.h.

### 12.66.2.10 CFE\_ES\_RELOAD\_APP\_CC

```
#define CFE_ES_RELOAD_APP_CC 7
```

**Name** Stops, Unloads, Loads from the command specified File and Restarts an Application

#### Description

This command halts and removes the specified Application from the system. Then it immediately loads the Application from the command specified file and restarts it. This command is especially useful for restarting a Command Ingest Application since once it has been stopped, no further commands can come in to restart it.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_ReloadApp

#### Command Structure

[CFE\\_ES\\_ReloadAppCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_ES\\_RELOAD\\_APP\\_DBG\\_EID](#) debug event message will be generated. NOTE: This event message only identifies that the reload process has been initiated, not that it has completed.

#### Error Conditions

This command may fail for the following reason(s):

- The specified application filename string cannot be parsed
- The specified application name is not recognized as an active application
- The specified application is one of the cFE's Core applications (ES, EVS, SB, TBL, TIME)

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases
- Additional information on the reason for command failure may be found in the System Log

#### Criticality

This command is not inherently dangerous, however the restarting of certain applications (e.g. - Spacecraft Attitude and Control) may have a detrimental effect on the spacecraft.

#### See also

[CFE\\_ES\\_START\\_APP\\_CC](#), [CFE\\_ES\\_STOP\\_APP\\_CC](#), [CFE\\_ES\\_RESTART\\_APP\\_CC](#)

Definition at line 360 of file `cfe_es_msg.h`.

### 12.66.2.11 CFE\_ES\_RESET\_COUNTERS\_CC

```
#define CFE_ES_RESET_COUNTERS_CC 1
```

**Name** Executive Services Reset Counters

#### Description

This command resets the following counters within the Executive Services housekeeping telemetry:

- Command Execution Counter
- Command Error Counter

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_ResetCtrs

#### Command Structure

[CFE\\_ES\\_ResetCountersCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter and error counter will be reset to zero
- The [CFE\\_ES\\_RESET\\_INF\\_EID](#) informational event message will be generated

#### Error Conditions

There are no error conditions for this command. If the Executive Services receives the command, the event is sent (although it may be filtered by EVS) and the counter is incremented unconditionally.

#### Criticality

This command is not inherently dangerous. However, it is possible for ground systems and on-board safing procedures to be designed such that they react to changes in the counter values that are reset by this command.

#### See also

[CFE\\_ES\\_RESET\\_PR\\_COUNT\\_CC](#)

Definition at line 120 of file cfe\_es\_msg.h.

### 12.66.2.12 CFE\_ES\_RESET\_PR\_COUNT\_CC

```
#define CFE_ES_RESET_PR_COUNT_CC 19
```

**Name** Resets the Processor Reset Counter to Zero

#### Description

This command allows the user to reset the Processor Reset Counter to zero. The Processor Reset Counter counts the number of Processor Resets that have occurred so as to identify when a Processor Reset should automatically be upgraded to a full Power-On Reset.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_ResetPRCntr

#### Command Structure

[CFE\\_ES\\_ResetPRCountCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter will increment
- [\\$sc\\_\\$cpu\\_ES\\_ProcResetCnt](#) - Current number of processor resets will go to zero
- The [CFE\\_ES\\_RESET\\_PR\\_COUNT\\_EID](#) informational event message will be generated.

#### Error Conditions

There are no error conditions for this command. If the Executive Services receives the command, the event is sent (although it may be filtered by EVS) and the counter is incremented unconditionally.

#### Criticality

This command is not critical. The only impact would be that the system would have to have more processor resets before an automatic power-on reset occurred.

#### See also

[CFE\\_ES\\_SET\\_MAX\\_PR\\_COUNT\\_CC](#), [CFE\\_ES\\_RESET\\_COUNTERS\\_CC](#)

Definition at line 839 of file `cfe_es_msg.h`.

### 12.66.2.13 CFE\_ES\_RESTART\_APP\_CC

```
#define CFE_ES_RESTART_APP_CC 6
```

**Name** Stops, Unloads, Loads using the previous File name, and Restarts an Application

#### Description

This command halts and removes the specified Application from the system. Then it immediately loads the Application from the same filename last used to start. This command is especially useful for restarting a Command Ingest Application since once it has been stopped, no further commands can come in to restart it.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_ResetApp

#### Command Structure

[CFE\\_ES\\_RestartAppCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_ES\\_RESTART\\_APP\\_DBG\\_EID](#) debug event message will be generated. NOTE: This event message only identifies that the restart process has been initiated, not that it has completed.

#### Error Conditions

This command may fail for the following reason(s):

- The original file is missing
- The specified application name is not recognized as an active application
- The specified application is one of the cFE's Core applications (ES, EVS, SB, TBL, TIME)

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases
- Additional information on the reason for command failure may be found in the System Log

#### Criticality

This command is not inherently dangerous, however the restarting of certain applications (e.g. - Spacecraft Attitude and Control) may have a detrimental effect on the spacecraft.

#### See also

[CFE\\_ES\\_START\\_APP\\_CC](#), [CFE\\_ES\\_STOP\\_APP\\_CC](#), [CFE\\_ES\\_RELOAD\\_APP\\_CC](#)

Definition at line 314 of file `cfe_es_msg.h`.

### 12.66.2.14 CFE\_ES\_RESTART\_CC

```
#define CFE_ES_RESTART_CC 2
```

**Name** Executive Services Processor / Power-On Reset

#### Description

This command restarts the cFE in one of two modes. The Power-On Reset will cause the cFE to restart as though the power were first applied to the processor. The Processor Reset will attempt to retain the contents of the volatile disk and the contents of the Critical Data Store. NOTE: If a requested Processor Reset should cause the Processor Reset Counter (`$sc_$cpu_ES_ProcResetCnt`) to exceed OR EQUAL the limit `CFE_PLATFORM_ES_MAX_PROCESSOR_RESETS` (which is reported in housekeeping telemetry as `$sc_$cpu_ES_MaxProcResets`), the command is **AUTOMATICALLY** upgraded to a Power-On Reset.

**Command Mnemonic(s)** `$sc_$cpu_ES_ProcessorReset`, `$sc_$cpu_ES_PowerOnReset`

#### Command Structure

[CFE\\_ES\\_RestartCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- `$sc_$cpu_ES_ProcResetCnt` - processor reset counter will increment (processor reset) or reset to zero (power-on reset)
  - `$sc_$cpu_ES_ResetType` - processor reset type will be updated
  - `$sc_$cpu_ES_ResetSubtype` - processor reset subtype will be updated
  - New entries in the Exception Reset Log and System Log can be found  
NOTE: Verification of a Power-On Reset is shown through the loss of data nominally retained through a Processor Reset
- NOTE: Since the reset of the processor resets the command execution counter (`$sc_$cpu_ES_CMDPC`), this counter **CANNOT** be used to verify command execution.

#### Error Conditions

This command may fail for the following reason(s):

- The [Restart Type](#) was not a recognized value.

Evidence of failure may be found in the following telemetry:

- `$sc_$cpu_ES_CMDEC` - command error counter will increment
- the [CFE\\_ES\\_BOOT\\_ERR\\_EID](#) error event message will be generated

#### Criticality

This command is, by definition, dangerous. Significant loss of data will occur. All processes and the cFE itself will be stopped and restarted. With the Power-On reset option, all data on the volatile disk and the contents of the Critical Data Store will be lost.

#### See also

[CFE\\_ES\\_RESET\\_PR\\_COUNT\\_CC](#), [CFE\\_ES\\_SET\\_MAX\\_PR\\_COUNT\\_CC](#)

Definition at line 172 of file `cfe_es_msg.h`.

### 12.66.2.15 CFE\_ES\_SEND\_MEM\_POOL\_STATS\_CC

```
#define CFE_ES_SEND_MEM_POOL_STATS_CC 22
```

**Name** Telemeter Memory Pool Statistics

#### Description

This command allows the user to obtain a snapshot of the statistics maintained for a specified memory pool.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_PoolStats

#### Command Structure

[CFE\\_ES\\_SendMemPoolStatsCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_ES\\_TLM\\_POOL\\_STATS\\_INFO\\_EID](#) debug event message will be generated.
- The [Memory Pool Statistics Telemetry Packet](#) is produced

#### Error Conditions

This command may fail for the following reason(s):

- The specified handle is not associated with a known memory pool

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases

#### Criticality

**An incorrect Memory Pool Handle value can cause a system crash.** Extreme care should be taken to ensure the memory handle value used in the command is correct.

#### See also

Definition at line 958 of file [cfe\\_es\\_msg.h](#).

### 12.66.2.16 CFE\_ES\_SET\_MAX\_PR\_COUNT\_CC

```
#define CFE_ES_SET_MAX_PR_COUNT_CC 20
```

**Name** Configure the Maximum Number of Processor Resets before a Power-On Reset

#### Description

This command allows the user to specify the number of Processor Resets that are allowed before the next Processor Reset is upgraded to a Power-On Reset.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_SetMaxPRCntr

#### Command Structure

[CFE\\_ES\\_SetMaxPRCountCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter will increment
- [\\$sc\\_\\$cpu\\_ES\\_MaxProcResets](#) - Current maximum number of processor resets before an automatic power-on reset will go to the command specified value.
- The [CFE\\_ES\\_SET\\_MAX\\_PR\\_COUNT\\_EID](#) informational event message will be generated.

#### Error Conditions

There are no error conditions for this command. If the Executive Services receives the command, the event is sent (although it may be filtered by EVS) and the counter is incremented unconditionally.

#### Criticality

If the operator were to set the Maximum Processor Reset Count to too high a value, the processor would require an inordinate number of consecutive processor resets before an automatic power-on reset would occur. This could potentially leave the spacecraft without any control for a significant amount of time if a processor reset fails to clear a problem.

#### See also

[CFE\\_ES\\_RESET\\_PR\\_COUNT\\_CC](#)

Definition at line 877 of file cfe\_es\_msg.h.

### 12.66.2.17 CFE\_ES\_SET\_PERF\_FILTER\_MASK\_CC

```
#define CFE_ES_SET_PERF_FILTER_MASK_CC 16
```

**Name** Set Performance Analyzer's Filter Masks

#### Description

This command sets the Performance Analyzer's Filter Masks.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_LAFilterMask

#### Command Structure

[CFE\\_ES\\_SetPerfFilterMaskCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_ES\_CMDPC** - command execution counter will increment
- **\$sc\_\$cpu\_ES\_PerfFltrMask[MaskCnt]** - the current performance filter mask value(s) should reflect the commanded value
- The [CFE\\_ES\\_PERF\\_FILTMSKCMD\\_EID](#) debug event message will be generated.

#### Error Conditions

This command may fail for the following reason(s):

- The Filter Mask ID number is out of range

Evidence of failure may be found in the following telemetry:

- **\$sc\_\$cpu\_ES\_CMDEC** - command error counter will increment
- A command specific error event message is issued for all error cases

#### Criticality

Changing the filter masks may cause a small change in the Performance Analyzer's CPU utilization.

#### See also

[CFE\\_ES\\_START\\_PERF\\_DATA\\_CC](#), [CFE\\_ES\\_STOP\\_PERF\\_DATA\\_CC](#), [CFE\\_ES\\_SET\\_PERF\\_TRIGGER\\_MASK\\_CC](#)

Definition at line 725 of file cfe\_es\_msg.h.

### 12.66.2.18 CFE\_ES\_SET\_PERF\_TRIGGER\_MASK\_CC

```
#define CFE_ES_SET_PERF_TRIGGER_MASK_CC 17
```

**Name** Set Performance Analyzer's Trigger Masks

#### Description

This command sets the Performance Analyzer's Trigger Masks.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_LATriggerMask

#### Command Structure

[CFE\\_ES\\_SetPerfTriggerMaskCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_ES\_CMDPC** - command execution counter will increment
- **\$sc\_\$cpu\_ES\_PerfTrigMask[MaskCnt]** - the current performance trigger mask value(s) should reflect the commanded value
- The [CFE\\_ES\\_PERF\\_TRIGMSKCMD\\_EID](#) debug event message will be generated.

#### Error Conditions

This command may fail for the following reason(s):

- The Trigger Mask ID number is out of range

Evidence of failure may be found in the following telemetry:

- **\$sc\_\$cpu\_ES\_CMDEC** - command error counter will increment
- A command specific error event message is issued for all error cases

#### Criticality

Changing the trigger masks may cause a small change in the Performance Analyzer's CPU utilization.

#### See also

[CFE\\_ES\\_START\\_PERF\\_DATA\\_CC](#), [CFE\\_ES\\_STOP\\_PERF\\_DATA\\_CC](#), [CFE\\_ES\\_SET\\_PERF\\_FILTER\\_MASK\\_CC](#)

Definition at line 762 of file `cfe_es_msg.h`.

### 12.66.2.19 CFE\_ES\_START\_APP\_CC

```
#define CFE_ES_START_APP_CC 4
```

**Name** Load and Start an Application

#### Description

This command starts the specified application with the specified start address, stack size, etc options.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_StartApp

#### Command Structure

[CFE\\_ES\\_StartAppCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_ES\\_START\\_INF\\_EID](#) informational event message will be generated

#### Error Conditions

This command may fail for the following reason(s):

- The specified application filename string cannot be parsed
- The specified application entry point is an empty string
- The specified application name is an empty string
- The specified priority is greater than 255
- The specified exception action is neither [CFE\\_ES\\_ExceptionAction\\_RESTART\\_APP](#) (0) or [CFE\\_ES\\_ExceptionAction\\_PROC\\_RESTART](#) (1)
- The Operating System was unable to load the specified application file

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases

#### Criticality

This command is not inherently dangerous although system resources could be taxed beyond their limits with the starting of erroneous or invalid applications.

#### See also

[CFE\\_ES\\_STOP\\_APP\\_CC](#), [CFE\\_ES\\_RESTART\\_APP\\_CC](#), [CFE\\_ES\\_RELOAD\\_APP\\_CC](#)

Definition at line 215 of file `cfe_es_msg.h`.

### 12.66.2.20 CFE\_ES\_START\_PERF\_DATA\_CC

```
#define CFE_ES_START_PERF_DATA_CC 14
```

**Name** Start Performance Analyzer

#### Description

This command causes the Performance Analyzer to begin collecting data using the specified trigger mode.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_StartLAData

#### Command Structure

[CFE\\_ES\\_StartPerfDataCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_ES\_CMDPC** - command execution counter will increment
- **\$sc\_\$cpu\_ES\_PerfState** - Current performance analyzer state will change to either WAITING FOR TRIGGER or, if conditions are appropriate fast enough, TRIGGERED.
- **\$sc\_\$cpu\_ES\_PerfMode** - Performance Analyzer Mode will change to the commanded trigger mode (TRIGGER START, TRIGGER CENTER, or TRIGGER END).
- **\$sc\_\$cpu\_ES\_PerfTrigCnt** - Performance Trigger Count will go to zero
- **\$sc\_\$cpu\_ES\_PerfDataStart** - Data Start Index will go to zero
- **\$sc\_\$cpu\_ES\_PerfDataEnd** - Data End Index will go to zero
- **\$sc\_\$cpu\_ES\_PerfDataCnt** - Performance Data Counter will go to zero
- The [CFE\\_ES\\_PERF\\_STARTCMD\\_EID](#) debug event message will be generated.

#### Error Conditions

This command may fail for the following reason(s):

- A previous [CFE\\_ES\\_STOP\\_PERF\\_DATA\\_CC](#) command has not completely finished.
- An invalid trigger mode is requested.

Evidence of failure may be found in the following telemetry:

- **\$sc\_\$cpu\_ES\_CMDEC** - command error counter will increment
- A command specific error event message is issued for all error cases

#### Criticality

This command is not inherently dangerous but may cause a small increase in CPU utilization as the performance analyzer data is collected.

#### See also

[CFE\\_ES\\_STOP\\_PERF\\_DATA\\_CC](#), [CFE\\_ES\\_SET\\_PERF\\_FILTER\\_MASK\\_CC](#), [CFE\\_ES\\_SET\\_PERF\\_TRIGGER\\_MASK\\_CC](#)

Definition at line 638 of file cfe\_es\_msg.h.

### 12.66.2.21 CFE\_ES\_STOP\_APP\_CC

```
#define CFE_ES_STOP_APP_CC 5
```

**Name** Stop and Unload Application

#### Description

This command halts and removes the specified Application from the system. **NOTE:** This command should never be used on the Command Ingest application. This would prevent further commands from entering the system. If Command Ingest needs to be stopped and restarted, use [CFE\\_ES\\_RESTART\\_APP\\_CC](#) or [CFE\\_ES\\_RELOAD\\_APP\\_CC](#).

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_StopApp

#### Command Structure

[CFE\\_ES\\_StopAppCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_ES\_CMDPC** - command execution counter will increment
- The [CFE\\_ES\\_STOP\\_DBG\\_EID](#) debug event message will be generated. NOTE: This event message only identifies that the stop request has been initiated, not that it has completed.
- Once the stop has successfully completed, the list of Applications and Tasks created in response to the [\\$sc\\_\\$cpu\\_ES\\_WriteAppInfo2File](#), [\\$sc\\_\\$cpu\\_ES\\_WriteTaskInfo2File](#) should no longer contain the specified application.
- **\$sc\_\$cpu\_ES\_RegTasks** - number of tasks will decrease after tasks associated with app (main task and any child tasks) are stopped
- **\$sc\_\$cpu\_ES\_RegExtApps** - external application counter will decrement after app is cleaned up

#### Error Conditions

This command may fail for the following reason(s):

- The specified application name is not recognized as an active application
- The specified application is one of the cFE's Core applications (ES, EVS, SB, TBL, TIME)

Evidence of failure may be found in the following telemetry:

- **\$sc\_\$cpu\_ES\_CMDEC** - command error counter will increment
- A command specific error event message is issued for all error cases
- Additional information on the reason for command failure may be found in the System Log

#### Criticality

This command is not inherently dangerous, however the removal of certain applications (e.g. - Spacecraft Attitude and Control) may have a detrimental effect on the spacecraft.

#### See also

[CFE\\_ES\\_START\\_APP\\_CC](#), [CFE\\_ES\\_RESTART\\_APP\\_CC](#), [CFE\\_ES\\_RELOAD\\_APP\\_CC](#)

Definition at line 268 of file cfe\_es\_msg.h.

### 12.66.2.22 CFE\_ES\_STOP\_PERF\_DATA\_CC

```
#define CFE_ES_STOP_PERF_DATA_CC 15
```

**Name** Stop Performance Analyzer and write data file

#### Description

This command stops the Performance Analyzer from collecting any more data, and writes all previously collected performance data to a log file.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_StopLAData

#### Command Structure

`CFE_ES_StopPerfDataCmd_t`

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- `$sc_$cpu_ES_CMDPC` - command execution counter will increment
- `$sc_$cpu_ES_PerfState` - Current performance analyzer state will change to IDLE.
- The `CFE_ES_PERF_STOPCMD_EID` debug event message will be generated to indicate that data collection has been stopped. NOTE: Performance log data is written to the file as a background job. This event indicates that the file write process is initiated, not that it has completed.
- The file specified in the command (or the default specified by the `CFE_PLATFORM_ES_DEFAULT_PERF_DUMP_FILENAME` configuration parameter) will be updated with the latest information.

#### Error Conditions

This command may fail for the following reason(s):

- The file name specified could not be parsed
- Log data from a previous Stop Performance Analyzer command is still being written to a file.

Evidence of failure may be found in the following telemetry:

- `$sc_$cpu_ES_CMDEC` - command error counter will increment
- A command specific error event message is issued for all error cases

NOTE: The performance analyzer data collection will still be stopped in the event of an error parsing the log file name or writing the log file.

#### Criticality

This command is not inherently dangerous. However, depending on configuration, performance data log files may be large in size and thus may fill the available storage.

#### See also

[CFE\\_ES\\_START\\_PERF\\_DATA\\_CC](#), [CFE\\_ES\\_SET\\_PERF\\_FILTER\\_MASK\\_CC](#), [CFE\\_ES\\_SET\\_PERF\\_TRIGGER\\_MASK\\_CC](#)

Definition at line 688 of file `cfe_es_msg.h`.

### 12.66.2.23 CFE\_ES\_WRITE\_ER\_LOG\_CC

```
#define CFE_ES_WRITE_ER_LOG_CC 13
```

**Name** Writes Exception and Reset Log to a File

#### Description

This command causes the contents of the Executive Services Exception and Reset Log to be written to the specified file.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_WriteERLog2File

#### Command Structure

[CFE\\_ES\\_WriteERLogCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_ES\\_ERLOG2\\_EID](#) debug event message will be generated.
- The file specified in the command (or the default specified by the [CFE\\_PLATFORM\\_ES\\_DEFAULT\\_ER\\_LOG\\_FILE](#) configuration parameter) will be updated with the latest information.

#### Error Conditions

This command may fail for the following reason(s):

- A previous request to write the ER log has not yet completed
- The specified FileName cannot be parsed
- An Error occurs while trying to write to the file

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases

#### Criticality

This command is not inherently dangerous. It will create a new file in the file system (or overwrite an existing one) and could, if performed repeatedly without sufficient file management by the operator, fill the file system.

#### See also

[CFE\\_ES\\_CLEAR\\_SYSLOG\\_CC](#), [CFE\\_ES\\_WRITE\\_SYSLOG\\_CC](#), [CFE\\_ES\\_CLEAR\\_ER\\_LOG\\_CC](#)

Definition at line 593 of file cfe\_es\_msg.h.

### 12.66.2.24 CFE\_ES\_WRITE\_SYSLOG\_CC

```
#define CFE_ES_WRITE_SYSLOG_CC 11
```

**Name** Writes contents of Executive Services System Log to a File

#### Description

This command causes the contents of the Executive Services System Log to be written to a log file.

**Command Mnemonic(s)** \$sc\_\$cpu\_ES\_WriteSysLog2File

#### Command Structure

[CFE\\_ES\\_WriteSysLogCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_ES\\_SYSLOG2\\_EID](#) debug event message will be generated.
- The file specified in the command (or the default specified by the [CFE\\_PLATFORM\\_ES\\_DEFAULT\\_SYSLOG\\_FILE](#) configuration parameter) will be updated with the latest information.

#### Error Conditions

This command may fail for the following reason(s):

- The specified FileName cannot be parsed
- An Error occurs while trying to write to the file

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_ES\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases

#### Criticality

This command is not inherently dangerous. It will create a new file in the file system (or overwrite an existing one) and could, if performed repeatedly without sufficient file management by the operator, fill the file system.

#### See also

[CFE\\_ES\\_CLEAR\\_SYSLOG\\_CC](#), [CFE\\_ES\\_CLEAR\\_ER\\_LOG\\_CC](#), [CFE\\_ES\\_WRITE\\_ER\\_LOG\\_CC](#), [CFE\\_ES\\_OVER\\_WRITE\\_SYSLOG\\_CC](#)

Definition at line 516 of file `cfe_es_msg.h`.

### 12.66.3 Typedef Documentation

#### 12.66.3.1 CFE\_ES\_AppNameCmd\_Payload\_t

```
typedef struct CFE_ES_AppNameCmd_Payload CFE_ES_AppNameCmd_Payload_t
```

Generic application name command payload.

For command details, see [CFE\\_ES\\_STOP\\_APP\\_CC](#), [CFE\\_ES\\_RESTART\\_APP\\_CC](#), [CFE\\_ES\\_QUERY\\_ONE\\_CC](#)

#### 12.66.3.2 CFE\_ES\_AppNameCmd\_t

```
typedef struct CFE_ES_AppNameCmd CFE_ES_AppNameCmd_t
```

Generic application name command.

#### 12.66.3.3 CFE\_ES\_AppReloadCmd\_Payload\_t

```
typedef struct CFE_ES_AppReloadCmd_Payload CFE_ES_AppReloadCmd_Payload_t
```

Reload Application Command Payload.

For command details, see [CFE\\_ES\\_RELOAD\\_APP\\_CC](#)

#### 12.66.3.4 CFE\_ES\_ClearERLogCmd\_t

```
typedef CFE_ES_NoArgsCmd_t CFE_ES_ClearERLogCmd_t
```

Definition at line 1074 of file cfe\_es\_msg.h.

#### 12.66.3.5 CFE\_ES\_ClearSysLogCmd\_t

```
typedef CFE_ES_NoArgsCmd_t CFE_ES_ClearSysLogCmd_t
```

Definition at line 1073 of file cfe\_es\_msg.h.

#### 12.66.3.6 CFE\_ES\_DeleteCDSCmd\_Payload\_t

```
typedef struct CFE_ES_DeleteCDSCmd_Payload CFE_ES_DeleteCDSCmd_Payload_t
```

Delete Critical Data Store Command Payload.

For command details, see [CFE\\_ES\\_DELETE\\_CDS\\_CC](#)

### 12.66.3.7 CFE\_ES\_DeleteCDSCmd\_t

```
typedef struct CFE_ES_DeleteCDSCmd CFE_ES_DeleteCDSCmd_t
```

Delete Critical Data Store Command.

### 12.66.3.8 CFE\_ES\_DumpCDSRegistryCmd\_Payload\_t

```
typedef struct CFE_ES_DumpCDSRegistryCmd_Payload CFE_ES_DumpCDSRegistryCmd_Payload_t
```

Dump CDS Registry Command Payload.

For command details, see [CFE\\_ES\\_DUMP\\_CDS\\_REGISTRY\\_CC](#)

### 12.66.3.9 CFE\_ES\_DumpCDSRegistryCmd\_t

```
typedef struct CFE_ES_DumpCDSRegistryCmd CFE_ES_DumpCDSRegistryCmd_t
```

Dump CDS Registry Command.

### 12.66.3.10 CFE\_ES\_FileNameCmd\_Payload\_t

```
typedef struct CFE_ES_FileNameCmd_Payload CFE_ES_FileNameCmd_Payload_t
```

Generic file name command payload.

This format is shared by several executive services commands. For command details, see [CFE\\_ES\\_QUERY\\_ALL\\_CC](#), [CFE\\_ES\\_QUERY\\_ALL\\_TASKS\\_CC](#), [CFE\\_ES\\_WRITE\\_SYSLOG\\_CC](#), and [CFE\\_ES\\_WRITE\\_ER\\_LOG\\_CC](#)

### 12.66.3.11 CFE\_ES\_FileNameCmd\_t

```
typedef struct CFE_ES_FileNameCmd CFE_ES_FileNameCmd_t
```

Generic file name command.

### 12.66.3.12 CFE\_ES\_HousekeepingTlm\_Payload\_t

```
typedef struct CFE_ES_HousekeepingTlm_Payload CFE_ES_HousekeepingTlm_Payload_t
```

**Name** Executive Services Housekeeping Packet

### 12.66.3.13 CFE\_ES\_HousekeepingTlm\_t

```
typedef struct CFE_ES_HousekeepingTlm CFE_ES_HousekeepingTlm_t
```

### 12.66.3.14 CFE\_ES\_MemStatsTlm\_t

```
typedef struct CFE_ES_MemStatsTlm CFE_ES_MemStatsTlm_t
```

### 12.66.3.15 CFE\_ES\_NoArgsCmd\_t

```
typedef struct CFE_ES_NoArgsCmd CFE_ES_NoArgsCmd_t
```

Generic "no arguments" command.

This command structure is used for commands that do not have any parameters. This includes:

1. The Housekeeping Request Message
2. The No-Op Command (For details, see [CFE\\_ES\\_NOOP\\_CC](#))
3. The Reset Counters Command (For details, see [CFE\\_ES\\_RESET\\_COUNTERS\\_CC](#))

### 12.66.3.16 CFE\_ES\_NoopCmd\_t

```
typedef CFE_ES_NoArgsCmd_t CFE_ES_NoopCmd_t
```

Definition at line 1071 of file cfe\_es\_msg.h.

### 12.66.3.17 CFE\_ES\_OneAppTlm\_Payload\_t

```
typedef struct CFE_ES_OneAppTlm_Payload CFE_ES_OneAppTlm_Payload_t
```

**Name** Single Application Information Packet

### 12.66.3.18 CFE\_ES\_OneAppTlm\_t

```
typedef struct CFE_ES_OneAppTlm CFE_ES_OneAppTlm_t
```

**12.66.3.19 CFE\_ES\_OverWriteSysLogCmd\_Payload\_t**

```
typedef struct CFE_ES_OverWriteSysLogCmd_Payload CFE_ES_OverWriteSysLogCmd_Payload_t
```

Overwrite/Discard System Log Configuration Command Payload.

For command details, see [CFE\\_ES\\_OVER\\_WRITE\\_SYSLOG\\_CC](#)

**12.66.3.20 CFE\_ES\_OverWriteSysLogCmd\_t**

```
typedef struct CFE_ES_OverWriteSysLogCmd CFE_ES_OverWriteSysLogCmd_t
```

Overwrite/Discard System Log Configuration Command Payload.

**12.66.3.21 CFE\_ES\_PoolStatsTlm\_Payload\_t**

```
typedef struct CFE_ES_PoolStatsTlm_Payload CFE_ES_PoolStatsTlm_Payload_t
```

**Name** Memory Pool Statistics Packet

**12.66.3.22 CFE\_ES\_QueryAllCmd\_t**

```
typedef CFE_ES_FileNameCmd_t CFE_ES_QueryAllCmd_t
```

Definition at line 1125 of file cfe\_es\_msg.h.

**12.66.3.23 CFE\_ES\_QueryAllTasksCmd\_t**

```
typedef CFE_ES_FileNameCmd_t CFE_ES_QueryAllTasksCmd_t
```

Definition at line 1126 of file cfe\_es\_msg.h.

**12.66.3.24 CFE\_ES\_QueryOneCmd\_t**

```
typedef CFE_ES_AppNameCmd_t CFE_ES_QueryOneCmd_t
```

Definition at line 1211 of file cfe\_es\_msg.h.

**12.66.3.25 CFE\_ES\_ReloadAppCmd\_t**

```
typedef struct CFE_ES_ReloadAppCmd CFE_ES_ReloadAppCmd_t
```

Reload Application Command.

**12.66.3.26 CFE\_ES\_ResetCountersCmd\_t**

```
typedef CFE_ES_NoArgsCmd_t CFE_ES_ResetCountersCmd_t
```

Definition at line 1072 of file cfe\_es\_msg.h.

**12.66.3.27 CFE\_ES\_ResetPRCountCmd\_t**

```
typedef CFE_ES_NoArgsCmd_t CFE_ES_ResetPRCountCmd_t
```

Definition at line 1075 of file cfe\_es\_msg.h.

**12.66.3.28 CFE\_ES\_RestartAppCmd\_t**

```
typedef CFE_ES_AppNameCmd_t CFE_ES_RestartAppCmd_t
```

Definition at line 1210 of file cfe\_es\_msg.h.

**12.66.3.29 CFE\_ES\_RestartCmd\_Payload\_t**

```
typedef struct CFE_ES_RestartCmd_Payload CFE_ES_RestartCmd_Payload_t
```

Restart cFE Command Payload.

For command details, see [CFE\\_ES\\_RESTART\\_CC](#)

**12.66.3.30 CFE\_ES\_RestartCmd\_t**

```
typedef struct CFE_ES_RestartCmd CFE_ES_RestartCmd_t
```

Restart cFE Command.

**12.66.3.31 CFE\_ES\_SendMemPoolStatsCmd\_Payload\_t**

```
typedef struct CFE_ES_SendMemPoolStatsCmd_Payload CFE_ES_SendMemPoolStatsCmd_Payload_t
```

Send Memory Pool Statistics Command Payload.

For command details, see [CFE\\_ES\\_SEND\\_MEM\\_POOL\\_STATS\\_CC](#)

**12.66.3.32 CFE\_ES\_SendMemPoolStatsCmd\_t**

```
typedef struct CFE_ES_SendMemPoolStatsCmd CFE_ES_SendMemPoolStatsCmd_t
```

Send Memory Pool Statistics Command.

**12.66.3.33 CFE\_ES\_SetMaxPRCountCmd\_Payload\_t**

```
typedef struct CFE_ES_SetMaxPRCountCmd_Payload CFE_ES_SetMaxPRCountCmd_Payload_t
```

Set Maximum Processor Reset Count Command Payload.

For command details, see [CFE\\_ES\\_SET\\_MAX\\_PR\\_COUNT\\_CC](#)

**12.66.3.34 CFE\_ES\_SetMaxPRCountCmd\_t**

```
typedef struct CFE_ES_SetMaxPRCountCmd CFE_ES_SetMaxPRCountCmd_t
```

Set Maximum Processor Reset Count Command.

**12.66.3.35 CFE\_ES\_SetPerfFilterMaskCmd\_Payload\_t**

```
typedef struct CFE_ES_SetPerfFilterMaskCmd_Payload CFE_ES_SetPerfFilterMaskCmd_Payload_t
```

Set Performance Analyzer Filter Mask Command Payload.

For command details, see [CFE\\_ES\\_SET\\_PERF\\_FILTER\\_MASK\\_CC](#)

**12.66.3.36 CFE\_ES\_SetPerfFilterMaskCmd\_t**

```
typedef struct CFE_ES_SetPerfFilterMaskCmd CFE_ES_SetPerfFilterMaskCmd_t
```

Set Performance Analyzer Filter Mask Command.

**12.66.3.37 CFE\_ES\_SetPerfTriggerMaskCmd\_t**

```
typedef struct CFE_ES_SetPerfTriggerMaskCmd CFE_ES_SetPerfTriggerMaskCmd_t
```

Set Performance Analyzer Trigger Mask Command.

**12.66.3.38 CFE\_ES\_SetPerfTrigMaskCmd\_Payload\_t**

```
typedef struct CFE_ES_SetPerfTrigMaskCmd_Payload CFE_ES_SetPerfTrigMaskCmd_Payload_t
```

Set Performance Analyzer Trigger Mask Command Payload.

For command details, see [CFE\\_ES\\_SET\\_PERF\\_TRIGGER\\_MASK\\_CC](#)

**12.66.3.39 CFE\_ES\_StartAppCmd\_Payload\_t**

```
typedef struct CFE_ES_StartAppCmd_Payload CFE_ES_StartAppCmd_Payload_t
```

Start Application Command Payload.

For command details, see [CFE\\_ES\\_START\\_APP\\_CC](#)

**12.66.3.40 CFE\_ES\_StartAppCmd\_t**

```
typedef struct CFE_ES_StartApp CFE_ES_StartAppCmd_t
```

Start Application Command.

**12.66.3.41 CFE\_ES\_StartPerfCmd\_Payload\_t**

```
typedef struct CFE_ES_StartPerfCmd_Payload CFE_ES_StartPerfCmd_Payload_t
```

Start Performance Analyzer Command Payload.

For command details, see [CFE\\_ES\\_START\\_PERF\\_DATA\\_CC](#)

**12.66.3.42 CFE\_ES\_StartPerfDataCmd\_t**

```
typedef struct CFE_ES_StartPerfDataCmd CFE_ES_StartPerfDataCmd_t
```

Start Performance Analyzer Command.

**12.66.3.43 CFE\_ES\_StopAppCmd\_t**

```
typedef CFE_ES_AppNameCmd_t CFE_ES_StopAppCmd_t
```

Definition at line 1209 of file cfe\_es\_msg.h.

**12.66.3.44 CFE\_ES\_StopPerfCmd\_Payload\_t**

```
typedef struct CFE_ES_StopPerfCmd_Payload CFE_ES_StopPerfCmd_Payload_t
```

Stop Performance Analyzer Command Payload.

For command details, see [CFE\\_ES\\_STOP\\_PERF\\_DATA\\_CC](#)

**12.66.3.45 CFE\_ES\_StopPerfDataCmd\_t**

```
typedef struct CFE_ES_StopPerfDataCmd CFE_ES_StopPerfDataCmd_t
```

Stop Performance Analyzer Command.

**12.66.3.46 CFE\_ES\_WriteERLogCmd\_t**

```
typedef CFE_ES_FileNameCmd_t CFE_ES_WriteERLogCmd_t
```

Definition at line 1128 of file cfe\_es\_msg.h.

**12.66.3.47 CFE\_ES\_WriteSysLogCmd\_t**

```
typedef CFE_ES_FileNameCmd_t CFE_ES_WriteSysLogCmd_t
```

Definition at line 1127 of file cfe\_es\_msg.h.

## 12.67 cfe/modules/evs/fsw/inc/cfe\_evs\_events.h File Reference

### Macros

#### EVS event IDs

- #define `CFE_EVS_NOOP_EID` 0  
*EVS No-op Command Success Event ID.*
- #define `CFE_EVS_STARTUP_EID` 1  
*EVS Initialization Event ID.*
- #define `CFE_EVS_ERR_WRLOGFILE_EID` 2  
*EVS Write Event Log Command File Write Entry Failed Event ID.*
- #define `CFE_EVS_ERR_CRLOGFILE_EID` 3  
*EVS Write Event Log Command Filename Parse or File Create Failed Event ID.*
- #define `CFE_EVS_ERR_MSGID_EID` 5  
*EVS Invalid Message ID Received Event ID.*
- #define `CFE_EVS_ERR_EVTIDMOREGS_EID` 6  
*EVS Command Event Not Registered For Filtering Event ID.*
- #define `CFE_EVS_ERR_APPNOREGS_EID` 7  
*EVS Command Application Not Registered With EVS Event ID.*
- #define `CFE_EVS_ERR_ILLAPPIDRANGE_EID` 8  
*EVS Command Get Application Data Failure Event ID.*
- #define `CFE_EVS_ERR_NOAPPIDFOUND_EID` 9  
*EVS Command Get Application ID Failure Event ID.*
- #define `CFE_EVS_ERR_ILLEGALFMTMOD_EID` 10  
*EVS Set Event Format Command Invalid Format Event ID.*
- #define `CFE_EVS_ERR_MAXREGSFILTER_EID` 11  
*EVS Add Filter Command Max Filters Exceeded Event ID.*
- #define `CFE_EVS_ERR_WRDATFILE_EID` 12  
*EVS Write Application Data Command Write Data Failure Event ID.*
- #define `CFE_EVS_ERR_CRDATFILE_EID` 13  
*EVS Write Application Data Command Filename Parse or File Create Failed Event ID.*
- #define `CFE_EVS_ERR_CC_EID` 15  
*EVS Invalid Command Code Received Event ID.*
- #define `CFE_EVS_RSTCNT_EID` 16  
*EVS Reset Counters Command Success Event ID.*
- #define `CFE_EVS_SETFILTERMSK_EID` 17  
*EVS Set Filter Command Success Event ID.*
- #define `CFE_EVS_ENAPORT_EID` 18  
*EVS Enable Ports Command Success Event ID.*
- #define `CFE_EVS_DISPORT_EID` 19  
*EVS Disable Ports Command Success Event ID.*
- #define `CFE_EVS_ENAEVTTYPE_EID` 20  
*EVS Enable Event Type Command Success Event ID.*
- #define `CFE_EVS_DISEVTTYPE_EID` 21  
*EVS Disable Event Type Command Success Event ID.*
- #define `CFE_EVS_SETEVTFMTMOD_EID` 22  
*EVS Set Event Format Mode Command Success Event ID.*
- #define `CFE_EVS_ENAAPPEVTTYPE_EID` 23  
*EVS Enable App Event Type Command Success Event ID.*
- #define `CFE_EVS_DISAPPENTTYPE_EID` 24  
*EVS Disable App Event Type Command Success Event ID.*
- #define `CFE_EVS_ENAAPPEVT_EID` 25  
*EVS Enable App Events Command Success Event ID.*

- #define [CFE\\_EVS\\_DISAPPEVT\\_EID](#) 26  
*EVS Disable App Events Command Success Event ID.*
- #define [CFE\\_EVS\\_RSTEVTCNT\\_EID](#) 27  
*EVS Reset App Event Counter Command Success Event ID.*
- #define [CFE\\_EVS\\_RSTFILTER\\_EID](#) 28  
*EVS Reset App Event Filter Command Success Event ID.*
- #define [CFE\\_EVS\\_RSTALLFILTER\\_EID](#) 29  
*EVS Reset All Filters Command Success Event ID.*
- #define [CFE\\_EVS\\_ADDFILTER\\_EID](#) 30  
*EVS Add Event Filter Command Success Event ID.*
- #define [CFE\\_EVS\\_DELFILTER\\_EID](#) 31  
*EVS Delete Event Filter Command Success Event ID.*
- #define [CFE\\_EVS\\_WRDAT\\_EID](#) 32  
*EVS Write Application Data Command Success Event ID.*
- #define [CFE\\_EVS\\_WRLOG\\_EID](#) 33  
*EVS Write Event Log Command Success Event ID.*
- #define [CFE\\_EVS\\_EVT\\_FILTERED\\_EID](#) 37  
*EVS Add Filter Command Duplicate Registration Event ID.*
- #define [CFE\\_EVS\\_LOGMODE\\_EID](#) 38  
*EVS Set Log Mode Command Success Event ID.*
- #define [CFE\\_EVS\\_ERR\\_LOGMODE\\_EID](#) 39  
*EVS Set Log Mode Command Invalid Mode Event ID.*
- #define [CFE\\_EVS\\_ERR\\_INVALID\\_BITMASK\\_EID](#) 40  
*EVS Port Or Event Type Bitmask Invalid Event ID.*
- #define [CFE\\_EVS\\_ERR\\_UNREGISTERED\\_EVS\\_APP](#) 41  
*EVS Send Event API App Not Registered With EVS Event ID.*
- #define [CFE\\_EVS\\_FILTER\\_MAX\\_EID](#) 42  
*EVS Filter Max Count Reached Event ID.*
- #define [CFE\\_EVS\\_LEN\\_ERR\\_EID](#) 43  
*EVS Invalid Command Length Event ID.*
- #define [CFE\\_EVS\\_SQUELCHED\\_ERR\\_EID](#) 44  
*EVS Events Squelched Error Event ID.*

### 12.67.1 Detailed Description

cFE Event Services Event IDs

### 12.67.2 Macro Definition Documentation

#### 12.67.2.1 CFE\_EVS\_ADDFILTER\_EID

```
#define CFE_EVS_ADDFILTER_EID 30
```

EVS Add Event Filter Command Success Event ID.

Type: DEBUG

Cause:

[EVS Add Event Filter Command](#) success.

Definition at line 356 of file `cfe_evs_events.h`.

### 12.67.2.2 CFE\_EVS\_DELFILTER\_EID

```
#define CFE_EVS_DELFILTER_EID 31
```

EVS Delete Event Filter Command Success Event ID.

Type: DEBUG

Cause:

[EVS Delete Event Filter Command](#) success.

Definition at line 367 of file cfe\_evs\_events.h.

### 12.67.2.3 CFE\_EVS\_DISAPPENTTYPE\_EID

```
#define CFE_EVS_DISAPPENTTYPE_EID 24
```

EVS Disable App Event Type Command Success Event ID.

Type: DEBUG

Cause:

[EVS Disable App Event Type Command](#) success.

Definition at line 290 of file cfe\_evs\_events.h.

### 12.67.2.4 CFE\_EVS\_DISAPPEVT\_EID

```
#define CFE_EVS_DISAPPEVT_EID 26
```

EVS Disable App Events Command Success Event ID.

Type: DEBUG

Cause:

[EVS Disable App Events Command](#) success.

Definition at line 312 of file cfe\_evs\_events.h.

**12.67.2.5 CFE\_EVS\_DISEVTTYPE\_EID**

```
#define CFE_EVS_DISEVTTYPE_EID 21
```

EVS Disable Event Type Command Success Event ID.

Type: DEBUG

Cause:

[EVS Disable Event Type Command](#) success.

Definition at line 257 of file cfe\_evs\_events.h.

**12.67.2.6 CFE\_EVS\_DISPORT\_EID**

```
#define CFE_EVS_DISPORT_EID 19
```

EVS Disable Ports Command Success Event ID.

Type: DEBUG

Cause:

[EVS Disable Ports Command](#) success.

Definition at line 235 of file cfe\_evs\_events.h.

**12.67.2.7 CFE\_EVS\_ENAAPPEVT\_EID**

```
#define CFE_EVS_ENAAPPEVT_EID 25
```

EVS Enable App Events Command Success Event ID.

Type: DEBUG

Cause:

[EVS Enable App Events Command](#) success.

Definition at line 301 of file cfe\_evs\_events.h.

**12.67.2.8 CFE\_EVS\_ENAAPPEVTTYPE\_EID**

```
#define CFE_EVS_ENAAPPEVTTYPE_EID 23
```

EVS Enable App Event Type Command Success Event ID.

Type: DEBUG

Cause:

[EVS Enable App Event Type Command](#) success.

Definition at line 279 of file cfe\_evs\_events.h.

**12.67.2.9 CFE\_EVS\_ENAEVTTYPE\_EID**

```
#define CFE_EVS_ENAEVTTYPE_EID 20
```

EVS Enable Event Type Command Success Event ID.

Type: DEBUG

Cause:

[EVS Enable Event Type Command](#) success.

Definition at line 246 of file cfe\_evs\_events.h.

**12.67.2.10 CFE\_EVS\_ENAPORT\_EID**

```
#define CFE_EVS_ENAPORT_EID 18
```

EVS Enable Ports Command Success Event ID.

Type: DEBUG

Cause:

[EVS Enable Ports Command](#) success.

Definition at line 224 of file cfe\_evs\_events.h.

**12.67.2.11 CFE\_EVS\_ERR\_APPNOREGS\_EID**

```
#define CFE_EVS_ERR_APPNOREGS_EID 7
```

EVS Command Application Not Registered With EVS Event ID.

Type: ERROR

Cause:

An EVS command handler failure due to the referenced application not being registered with EVS. OVERLOADED

Definition at line 110 of file cfe\_evs\_events.h.

**12.67.2.12 CFE\_EVS\_ERR\_CC\_EID**

```
#define CFE_EVS_ERR_CC_EID 15
```

EVS Invalid Command Code Received Event ID.

Type: ERROR

Cause:

Invalid command code for message ID [CFE\\_EVS\\_CMD\\_MID](#) received on the EVS message pipe.

Definition at line 191 of file cfe\_evs\_events.h.

**12.67.2.13 CFE\_EVS\_ERR\_CRDATFILE\_EID**

```
#define CFE_EVS_ERR_CRDATFILE_EID 13
```

EVS Write Application Data Command Filename Parse or File Create Failed Event ID.

Type: ERROR

Cause:

[Write Application Data Command](#) failed to parse the filename or open/create the file. OVERLOADED

Definition at line 180 of file cfe\_evs\_events.h.

**12.67.2.14 CFE\_EVS\_ERR\_CRLOGFILE\_EID**

```
#define CFE_EVS_ERR_CRLOGFILE_EID 3
```

EVS Write Event Log Command Filename Parse or File Create Failed Event ID.

Type: ERROR

Cause:

[EVS Write Event Log Command](#) failure parsing the file name or during open/creation of the file. OVERLOADED

Definition at line 77 of file cfe\_evs\_events.h.

**12.67.2.15 CFE\_EVS\_ERR\_EVTIDNOREGS\_EID**

```
#define CFE_EVS_ERR_EVTIDNOREGS_EID 6
```

EVS Command Event Not Registered For Filtering Event ID.

Type: ERROR

Cause:

An EVS command handler failure due to the event not being registered for filtering. OVERLOADED

Definition at line 99 of file cfe\_evs\_events.h.

**12.67.2.16 CFE\_EVS\_ERR\_ILLAPPIDRANGE\_EID**

```
#define CFE_EVS_ERR_ILLAPPIDRANGE_EID 8
```

EVS Command Get Application Data Failure Event ID.

Type: ERROR

Cause:

An EVS command handler failure retrieving the application data. OVERLOADED

Definition at line 121 of file cfe\_evs\_events.h.

**12.67.2.17 CFE\_EVS\_ERR\_ILLEGALFMTMOD\_EID**

```
#define CFE_EVS_ERR_ILLEGALFMTMOD_EID 10
```

EVS Set Event Format Command Invalid Format Event ID.

Type: ERROR

Cause:

[EVS Set Event Format Command](#) failure due to invalid format argument.

Definition at line 144 of file cfe\_evs\_events.h.

**12.67.2.18 CFE\_EVS\_ERR\_INVALID\_BITMASK\_EID**

```
#define CFE_EVS_ERR_INVALID_BITMASK_EID 40
```

EVS Port Or Event Type Bitmask Invalid Event ID.

Type: ERROR

Cause:

Invalid bitmask for EVS port or event type. OVERLOADED

Definition at line 435 of file cfe\_evs\_events.h.

**12.67.2.19 CFE\_EVS\_ERR\_LOGMODE\_EID**

```
#define CFE_EVS_ERR_LOGMODE_EID 39
```

EVS Set Log Mode Command Invalid Mode Event ID.

Type: ERROR

Cause:

[EVS Set Log Mode Command](#) failure due to invalid log mode.

Definition at line 424 of file cfe\_evs\_events.h.

**12.67.2.20 CFE\_EVS\_ERR\_MAXREGSFILTER\_EID**

```
#define CFE_EVS_ERR_MAXREGSFILTER_EID 11
```

EVS Add Filter Command Max Filters Exceeded Event ID.

Type: ERROR

Cause:

[EVS Add Filter Command](#) failure due to exceeding the maximum number of filters.

Definition at line 156 of file cfe\_evs\_events.h.

**12.67.2.21 CFE\_EVS\_ERR\_MSGID\_EID**

```
#define CFE_EVS_ERR_MSGID_EID 5
```

EVS Invalid Message ID Received Event ID.

Type: ERROR

Cause:

Invalid message ID received on the EVS message pipe.

Definition at line 88 of file cfe\_evs\_events.h.

**12.67.2.22 CFE\_EVS\_ERR\_NOAPPIDFOUND\_EID**

```
#define CFE_EVS_ERR_NOAPPIDFOUND_EID 9
```

EVS Command Get Application ID Failure Event ID.

Type: ERROR

Cause:

An EVS command handler failure retrieving the application ID. OVERLOADED

Definition at line 132 of file cfe\_evs\_events.h.

**12.67.2.23 CFE\_EVS\_ERR\_UNREGISTERED\_EVS\_APP**

```
#define CFE_EVS_ERR_UNREGISTERED_EVS_APP 41
```

EVS Send Event API App Not Registered With EVS Event ID.

Type: ERROR

Cause:

An EVS Send Event API called for application not registered with EVS.

Definition at line 446 of file cfe\_evs\_events.h.

**12.67.2.24 CFE\_EVS\_ERR\_WRDATFILE\_EID**

```
#define CFE_EVS_ERR_WRDATFILE_EID 12
```

EVS Write Application Data Command Write Data Failure Event ID.

Type: ERROR

Cause:

[Write Application Data Command](#) failure to write application EVS data.

Definition at line 168 of file cfe\_evs\_events.h.

**12.67.2.25 CFE\_EVS\_ERR\_WRLOGFILE\_EID**

```
#define CFE_EVS_ERR_WRLOGFILE_EID 2
```

EVS Write Event Log Command File Write Entry Failed Event ID.

Type: ERROR

Cause:

[EVS Write Event Log Command](#) failure writing data to the file.

Definition at line 65 of file cfe\_evs\_events.h.

**12.67.2.26 CFE\_EVS\_EVT\_FILTERED\_EID**

```
#define CFE_EVS_EVT_FILTERED_EID 37
```

EVS Add Filter Command Duplicate Registration Event ID.

Type: **ERROR**

Cause:

[EVS Add Filter Command](#) failure due to event already being registered for filtering.

Definition at line 401 of file cfe\_evs\_events.h.

**12.67.2.27 CFE\_EVS\_FILTER\_MAX\_EID**

```
#define CFE_EVS_FILTER_MAX_EID 42
```

EVS Filter Max Count Reached Event ID.

Type: **INFORMATIONAL**

Cause:

Filter count for the event reached CFE\_EVS\_MAX\_FILTER\_COUNT and is latched until filter is reset.

Definition at line 457 of file cfe\_evs\_events.h.

**12.67.2.28 CFE\_EVS\_LEN\_ERR\_EID**

```
#define CFE_EVS_LEN_ERR_EID 43
```

EVS Invalid Command Length Event ID.

Type: **ERROR**

Cause:

Invalid length for the command code in message ID [CFE\\_EVS\\_CMD\\_MID](#) received on the EVS message pipe.

Definition at line 468 of file cfe\_evs\_events.h.

**12.67.2.29 CFE\_EVS\_LOGMODE\_EID**

```
#define CFE_EVS_LOGMODE_EID 38
```

EVS Set Log Mode Command Success Event ID.

Type: DEBUG

Cause:

[EVS Set Log Mode Command](#) success.

Definition at line 412 of file cfe\_evs\_events.h.

**12.67.2.30 CFE\_EVS\_NOOP\_EID**

```
#define CFE_EVS_NOOP_EID 0
```

EVS No-op Command Success Event ID.

Type: INFORMATION

Cause:

[EVS NO-OP command](#) success.

Definition at line 42 of file cfe\_evs\_events.h.

**12.67.2.31 CFE\_EVS\_RSTALLFILTER\_EID**

```
#define CFE_EVS_RSTALLFILTER_EID 29
```

EVS Reset All Filters Command Success Event ID.

Type: DEBUG

Cause:

[EVS Reset All Filters Command](#) success.

Definition at line 345 of file cfe\_evs\_events.h.

### 12.67.2.32 CFE\_EVS\_RSTCNT\_EID

```
#define CFE_EVS_RSTCNT_EID 16
```

EVS Reset Counters Command Success Event ID.

Type: DEBUG

Cause:

[EVS Reset Counters Command](#) success.

Definition at line 202 of file cfe\_evs\_events.h.

### 12.67.2.33 CFE\_EVS\_RSTEVCNT\_EID

```
#define CFE_EVS_RSTEVCNT_EID 27
```

EVS Reset App Event Counter Command Success Event ID.

Type: DEBUG

Cause:

[EVS Reset App Event Counter Command](#) success.

Definition at line 323 of file cfe\_evs\_events.h.

### 12.67.2.34 CFE\_EVS\_RSTFILTER\_EID

```
#define CFE_EVS_RSTFILTER_EID 28
```

EVS Reset App Event Filter Command Success Event ID.

Type: DEBUG

Cause:

[EVS Reset App Event Filter Command](#) success.

Definition at line 334 of file cfe\_evs\_events.h.

**12.67.2.35 CFE\_EVS\_SETEVTFMTMOD\_EID**

```
#define CFE_EVS_SETEVTFMTMOD_EID 22
```

EVS Set Event Format Mode Command Success Event ID.

Type: DEBUG

Cause:

[EVS Set Event Format Mode Command](#) success.

Definition at line 268 of file cfe\_evs\_events.h.

**12.67.2.36 CFE\_EVS\_SETFILTERMSK\_EID**

```
#define CFE_EVS_SETFILTERMSK_EID 17
```

EVS Set Filter Command Success Event ID.

Type: DEBUG

Cause:

[EVS Set Filter Command](#) success.

Definition at line 213 of file cfe\_evs\_events.h.

**12.67.2.37 CFE\_EVS\_SQUELCHED\_ERR\_EID**

```
#define CFE_EVS_SQUELCHED_ERR_EID 44
```

EVS Events Squelched Error Event ID.

Type: ERROR

Cause:

Events generated in app at a rate in excess of [CFE\\_PLATFORM\\_EVS\\_MAX\\_APP\\_EVENT\\_BURST](#) in one moment or [CFE\\_PLATFORM\\_EVS\\_APP\\_EVENTS\\_PER\\_SEC](#) sustained

Definition at line 481 of file cfe\_evs\_events.h.

**12.67.2.38 CFE\_EVS\_STARTUP\_EID**

```
#define CFE_EVS_STARTUP_EID 1
```

EVS Initialization Event ID.

Type: INFORMATION

Cause:

Event Services Task initialization complete.

Definition at line 53 of file cfe\_evs\_events.h.

**12.67.2.39 CFE\_EVS\_WRDAT\_EID**

```
#define CFE_EVS_WRDAT_EID 32
```

EVS Write Application Data Command Success Event ID.

Type: DEBUG

Cause:

[EVS Write Application Data Command](#) success.

Definition at line 378 of file cfe\_evs\_events.h.

**12.67.2.40 CFE\_EVS\_WRLOG\_EID**

```
#define CFE_EVS_WRLOG_EID 33
```

EVS Write Event Log Command Success Event ID.

Type: DEBUG

Cause:

[EVS Write Event Log Command](#) success.

Definition at line 389 of file cfe\_evs\_events.h.

## 12.68 cfe/modules/evs/fsw/inc/cfe\_evs\_msg.h File Reference

```
#include "common_types.h"
#include "cfe_msg_hdr.h"
#include "cfe_evs_extern_typedefs.h"
#include "cfe_es_extern_typedefs.h"
```

### Data Structures

- struct [CFE\\_EVS\\_NoArgsCmd](#)  
*Command with no additional arguments.*
- struct [CFE\\_EVS\\_LogFileCmd\\_Payload](#)  
*Write Event Log to File Command Payload.*
- struct [CFE\\_EVS\\_WriteLogDataFileCmd](#)  
*Write Event Log to File Command.*
- struct [CFE\\_EVS\\_AppDataCmd\\_Payload](#)  
*Write Event Services Application Information to File Command Payload.*
- struct [CFE\\_EVS\\_WriteAppDataFileCmd](#)  
*Write Event Services Application Information to File Command.*
- struct [CFE\\_EVS\\_SetLogMode\\_Payload](#)  
*Set Log Mode Command Payload.*
- struct [CFE\\_EVS\\_SetLogModeCmd](#)  
*Set Log Mode Command.*
- struct [CFE\\_EVS\\_SetEventFormatCode\\_Payload](#)  
*Set Event Format Mode Command Payload.*
- struct [CFE\\_EVS\\_SetEventFormatModeCmd](#)  
*Set Event Format Mode Command.*
- struct [CFE\\_EVS\\_BitMaskCmd\\_Payload](#)  
*Generic Bitmask Command Payload.*
- struct [CFE\\_EVS\\_BitMaskCmd](#)  
*Generic Bitmask Command.*
- struct [CFE\\_EVS\\_AppNameCmd\\_Payload](#)  
*Generic App Name Command Payload.*
- struct [CFE\\_EVS\\_AppNameCmd](#)  
*Generic App Name Command.*
- struct [CFE\\_EVS\\_AppNameEventIDCmd\\_Payload](#)  
*Generic App Name and Event ID Command Payload.*
- struct [CFE\\_EVS\\_AppNameEventIDCmd](#)  
*Generic App Name and Event ID Command.*
- struct [CFE\\_EVS\\_AppNameBitMaskCmd\\_Payload](#)  
*Generic App Name and Bitmask Command Payload.*
- struct [CFE\\_EVS\\_AppNameBitMaskCmd](#)  
*Generic App Name and Bitmask Command.*
- struct [CFE\\_EVS\\_AppNameEventIDMaskCmd\\_Payload](#)  
*Generic App Name, Event ID, Mask Command Payload.*
- struct [CFE\\_EVS\\_AppNameEventIDMaskCmd](#)

*Generic App Name, Event ID, Mask Command.*

- struct [CFE\\_EVS\\_AppTlmData](#)
- struct [CFE\\_EVS\\_HousekeepingTlm\\_Payload](#)
- struct [CFE\\_EVS\\_HousekeepingTlm](#)
- struct [CFE\\_EVS\\_PacketID](#)
- struct [CFE\\_EVS\\_LongEventTlm\\_Payload](#)
- struct [CFE\\_EVS\\_ShortEventTlm\\_Payload](#)
- struct [CFE\\_EVS\\_LongEventTlm](#)
- struct [CFE\\_EVS\\_ShortEventTlm](#)

## Macros

- #define [CFE\\_EVS\\_DEBUG\\_BIT](#) 0x0001
- #define [CFE\\_EVS\\_INFORMATION\\_BIT](#) 0x0002
- #define [CFE\\_EVS\\_ERROR\\_BIT](#) 0x0004
- #define [CFE\\_EVS\\_CRITICAL\\_BIT](#) 0x0008
- #define [CFE\\_EVS\\_PORT1\\_BIT](#) 0x0001
- #define [CFE\\_EVS\\_PORT2\\_BIT](#) 0x0002
- #define [CFE\\_EVS\\_PORT3\\_BIT](#) 0x0004
- #define [CFE\\_EVS\\_PORT4\\_BIT](#) 0x0008

## Event Services Command Codes

- #define [CFE\\_EVS\\_NOOP\\_CC](#) 0
- #define [CFE\\_EVS\\_RESET\\_COUNTERS\\_CC](#) 1
- #define [CFE\\_EVS\\_ENABLE\\_EVENT\\_TYPE\\_CC](#) 2
- #define [CFE\\_EVS\\_DISABLE\\_EVENT\\_TYPE\\_CC](#) 3
- #define [CFE\\_EVS\\_SET\\_EVENT\\_FORMAT\\_MODE\\_CC](#) 4
- #define [CFE\\_EVS\\_ENABLE\\_APP\\_EVENT\\_TYPE\\_CC](#) 5
- #define [CFE\\_EVS\\_DISABLE\\_APP\\_EVENT\\_TYPE\\_CC](#) 6
- #define [CFE\\_EVS\\_ENABLE\\_APP\\_EVENTS\\_CC](#) 7
- #define [CFE\\_EVS\\_DISABLE\\_APP\\_EVENTS\\_CC](#) 8
- #define [CFE\\_EVS\\_RESET\\_APP\\_COUNTER\\_CC](#) 9
- #define [CFE\\_EVS\\_SET\\_FILTER\\_CC](#) 10
- #define [CFE\\_EVS\\_ENABLE\\_PORTS\\_CC](#) 11
- #define [CFE\\_EVS\\_DISABLE\\_PORTS\\_CC](#) 12
- #define [CFE\\_EVS\\_RESET\\_FILTER\\_CC](#) 13
- #define [CFE\\_EVS\\_RESET\\_ALL\\_FILTERS\\_CC](#) 14
- #define [CFE\\_EVS\\_ADD\\_EVENT\\_FILTER\\_CC](#) 15
- #define [CFE\\_EVS\\_DELETE\\_EVENT\\_FILTER\\_CC](#) 16
- #define [CFE\\_EVS\\_WRITE\\_APP\\_DATA\\_FILE\\_CC](#) 17
- #define [CFE\\_EVS\\_WRITE\\_LOG\\_DATA\\_FILE\\_CC](#) 18
- #define [CFE\\_EVS\\_SET\\_LOG\\_MODE\\_CC](#) 19
- #define [CFE\\_EVS\\_CLEAR\\_LOG\\_CC](#) 20

## Typedefs

- `typedef struct CFE_EVS_NoArgsCmd CFE_EVS_NoArgsCmd_t`  
*Command with no additional arguments.*
- `typedef CFE_EVS_NoArgsCmd_t CFE_EVS_NoopCmd_t`
- `typedef CFE_EVS_NoArgsCmd_t CFE_EVS_ResetCountersCmd_t`
- `typedef CFE_EVS_NoArgsCmd_t CFE_EVS_ClearLogCmd_t`
- `typedef struct CFE_EVS_LogFileCmd_Payload CFE_EVS_LogFileCmd_Payload_t`  
*Write Event Log to File Command Payload.*
- `typedef struct CFE_EVS_WriteLogFileCmd CFE_EVS_WriteLogFileCmd_t`  
*Write Event Log to File Command.*
- `typedef struct CFE_EVS_AppDataCmd_Payload CFE_EVS_AppDataCmd_Payload_t`  
*Write Event Services Application Information to File Command Payload.*
- `typedef struct CFE_EVS_WriteAppDataFileCmd CFE_EVS_WriteAppDataFileCmd_t`  
*Write Event Services Application Information to File Command.*
- `typedef struct CFE_EVS_SetLogMode_Payload CFE_EVS_SetLogMode_Payload_t`  
*Set Log Mode Command Payload.*
- `typedef struct CFE_EVS_SetLogModeCmd CFE_EVS_SetLogModeCmd_t`  
*Set Log Mode Command.*
- `typedef struct CFE_EVS_SetEventFormatCode_Payload CFE_EVS_SetEventFormatMode_Payload_t`  
*Set Event Format Mode Command Payload.*
- `typedef struct CFE_EVS_SetEventFormatModeCmd CFE_EVS_SetEventFormatModeCmd_t`  
*Set Event Format Mode Command.*
- `typedef struct CFE_EVS_BitMaskCmd_Payload CFE_EVS_BitMaskCmd_Payload_t`  
*Generic Bitmask Command Payload.*
- `typedef struct CFE_EVS_BitMaskCmd CFE_EVS_BitMaskCmd_t`  
*Generic Bitmask Command.*
- `typedef CFE_EVS_BitMaskCmd_t CFE_EVS_EnablePortsCmd_t`
- `typedef CFE_EVS_BitMaskCmd_t CFE_EVS_DisablePortsCmd_t`
- `typedef CFE_EVS_BitMaskCmd_t CFE_EVS_EnableEventTypeCmd_t`
- `typedef CFE_EVS_BitMaskCmd_t CFE_EVS_DisableEventTypeCmd_t`
- `typedef struct CFE_EVS_AppNameCmd_Payload CFE_EVS_AppNameCmd_Payload_t`  
*Generic App Name Command Payload.*
- `typedef struct CFE_EVS_AppNameCmd CFE_EVS_AppNameCmd_t`  
*Generic App Name Command.*
- `typedef CFE_EVS_AppNameCmd_t CFE_EVS_EnableAppEventsCmd_t`
- `typedef CFE_EVS_AppNameCmd_t CFE_EVS_DisableAppEventsCmd_t`
- `typedef CFE_EVS_AppNameCmd_t CFE_EVS_ResetAppCounterCmd_t`
- `typedef CFE_EVS_AppNameCmd_t CFE_EVS_ResetAllFiltersCmd_t`
- `typedef struct CFE_EVS_AppNameEventIDCmd_Payload CFE_EVS_AppNameEventIDCmd_Payload_t`  
*Generic App Name and Event ID Command Payload.*
- `typedef struct CFE_EVS_AppNameEventIDCmd CFE_EVS_AppNameEventIDCmd_t`  
*Generic App Name and Event ID Command.*
- `typedef CFE_EVS_AppNameEventIDCmd_t CFE_EVS_ResetFilterCmd_t`
- `typedef CFE_EVS_AppNameEventIDCmd_t CFE_EVS_DeleteEventFilterCmd_t`
- `typedef struct CFE_EVS_AppNameBitMaskCmd_Payload CFE_EVS_AppNameBitMaskCmd_Payload_t`  
*Generic App Name and Bitmask Command Payload.*
- `typedef struct CFE_EVS_AppNameBitMaskCmd CFE_EVS_AppNameBitMaskCmd_t`

*Generic App Name and Bitmask Command.*

- `typedef CFE_EVS_AppNameBitMaskCmd_t CFE_EVS_EnableAppEventTypeCmd_t`
- `typedef CFE_EVS_AppNameBitMaskCmd_t CFE_EVS_DisableAppEventTypeCmd_t`
- `typedef struct CFE_EVS_AppNameEventIDMaskCmd_Payload CFE_EVS_AppNameEventIDMaskCmd_<Payload_t>`

*Generic App Name, Event ID, Mask Command Payload.*

- `typedef struct CFE_EVS_AppNameEventIDMaskCmd CFE_EVS_AppNameEventIDMaskCmd_t`  
*Generic App Name, Event ID, Mask Command.*

- `typedef CFE_EVS_AppNameEventIDMaskCmd_t CFE_EVS_AddEventFilterCmd_t`
- `typedef CFE_EVS_AppNameEventIDMaskCmd_t CFE_EVS_SetFilterCmd_t`
- `typedef struct CFE_EVS_AppTlmData CFE_EVS_AppTlmData_t`
- `typedef struct CFE_EVS_HousekeepingTlm_Payload CFE_EVS_HousekeepingTlm_Payload_t`
- `typedef struct CFE_EVS_HousekeepingTlm CFE_EVS_HousekeepingTlm_t`
- `typedef struct CFE_EVS_PacketID CFE_EVS_PacketID_t`
- `typedef struct CFE_EVS_LongEventTlm_Payload CFE_EVS_LongEventTlm_Payload_t`
- `typedef struct CFE_EVS_ShortEventTlm_Payload CFE_EVS_ShortEventTlm_Payload_t`
- `typedef struct CFE_EVS_LongEventTlm CFE_EVS_LongEventTlm_t`
- `typedef struct CFE_EVS_ShortEventTlm CFE_EVS_ShortEventTlm_t`

#### 12.68.1 Detailed Description

Title: Event Services Message definition header file Header File

Purpose: Unit specification for Event services command codes and data structures.

Design Notes:

References: Flight Software Branch C Coding Standard Version 1.0a

#### 12.68.2 Macro Definition Documentation

##### 12.68.2.1 CFE\_EVS\_ADD\_EVENT\_FILTER\_CC

```
#define CFE_EVS_ADD_EVENT_FILTER_CC 15
```

**Name** Add Application Event Filter

##### Description

This command adds the given filter for the given application identifier and event identifier. Note: In order for this command to take effect, applications must be registered for Event Service.

**Command Mnemonic(s)** \$sc\_\$cpu\_EVS\_AddEvtFltr

#### Command Structure

[CFE\\_EVS\\_AddEventFilterCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_EVS\\_CMDPC](#) - command execution counter will increment
- The generation of [CFE\\_EVS\\_ADDFILTER\\_EID](#) debug event message

#### Error Conditions

This command may fail for the following reason(s):

- Application name is not valid or not registered with event services
- Specified event ID is already added to the application event filter
- Maximum number of event IDs already added to filter

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_EVS\\_CMDEC](#) - command error counter will increment
- An Error specific event message

#### Criticality

None.

#### See also

[CFE\\_EVS\\_SET\\_FILTER\\_CC](#), [CFE\\_EVS\\_RESET\\_FILTER\\_CC](#), [CFE\\_EVS\\_RESET\\_ALL\\_FILTERS\\_CC](#), [CFE\\_EVS\\_DELETE\\_EVENT\\_FILTER\\_CC](#)

Definition at line 705 of file `cfe_evs_msg.h`.

#### 12.68.2.2 CFE\_EVS\_CLEAR\_LOG\_CC

```
#define CFE_EVS_CLEAR_LOG_CC 20
```

**Name** Clear Event Log

#### Description

This command clears the contents of the local event log.

**Command Mnemonic(s)** [\\$sc\\_\\$cpu\\_EVS\\_ClrLog](#)

**Command Structure**

[CFE\\_EVS\\_ClearLogCmd\\_t](#)

**Command Verification**

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_EVS\_CMDPC** - command execution counter will increment
- **\$sc\_\$cpu\_EVS\_LOGFULL** - The LogFullFlag in the Housekeeping telemetry will be cleared
- **\$sc\_\$cpu\_EVS\_LOGOVERFLOWC** - The LogOverflowCounter in the Housekeeping telemetry will be reset to 0

**Error Conditions**

There are no error conditions for this command. If the Event Services receives the command, the log is cleared.

**Criticality**

Clearing the local event log is not particularly hazardous, as the result may be making available space to record valuable event data. However, inappropriately clearing the local event log could result in a loss of critical information.  
Note: the event log is a back-up log to the on-board recorder.

**See also**

[CFE\\_EVS\\_WRITE\\_LOG\\_DATA\\_FILE\\_CC](#), [CFE\\_EVS\\_SET\\_LOG\\_MODE\\_CC](#)

Definition at line 885 of file cfe\_evs\_msg.h.

**12.68.2.3 CFE\_EVS\_CRITICAL\_BIT**

```
#define CFE_EVS_CRITICAL_BIT 0x0008
```

Definition at line 892 of file cfe\_evs\_msg.h.

**12.68.2.4 CFE\_EVS\_DEBUG\_BIT**

```
#define CFE_EVS_DEBUG_BIT 0x0001
```

Definition at line 889 of file cfe\_evs\_msg.h.

### 12.68.2.5 CFE\_EVS\_DELETE\_EVENT\_FILTER\_CC

```
#define CFE_EVS_DELETE_EVENT_FILTER_CC 16
```

**Name** Delete Application Event Filter

#### Description

This command removes the given filter for the given application identifier and event identifier. Note: In order for this command to take effect, applications must be registered for Event Service.

**Command Mnemonic(s)** \$sc\_\$cpu\_EVS\_DelEvtFltr

#### Command Structure

[CFE\\_EVS\\_DeleteEventFilterCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_EVS\_CMDPC** - command execution counter will increment
- The generation of [CFE\\_EVS\\_DELFILTER\\_EID](#) debug event message

#### Error Conditions

This command may fail for the following reason(s):

- Application name is not valid or not registered with event services
- Specified event ID is not found in the application event filter

Evidence of failure may be found in the following telemetry:

- **\$sc\_\$cpu\_EVS\_CMDEC** - command error counter will increment
- An Error specific event message

#### Criticality

None.

#### See also

[CFE\\_EVS\\_SET\\_FILTER\\_CC](#), [CFE\\_EVS\\_RESET\\_FILTER\\_CC](#), [CFE\\_EVS\\_RESET\\_ALL\\_FILTERS\\_CC](#), [CFE\\_EVS\\_ADD\\_EVENT\\_FILTER\\_CC](#)

Definition at line 740 of file `cfe_evs_msg.h`.

### 12.68.2.6 CFE\_EVS\_DISABLE\_APP\_EVENT\_TYPE\_CC

```
#define CFE_EVS_DISABLE_APP_EVENT_TYPE_CC 6
```

**Name** Disable Application Event Type

#### Description

This command disables the command specified event type for the command specified application, preventing the application from sending event messages of the command specified event type through Event Service. An Event Type is defined to be a classification of an Event Message such as debug, informational, critical, and error. Note: In order for this command to take effect, applications must be registered for Event Service.

**Command Mnemonic(s)** \$sc\_\$cpu\_EVS\_DisAppEvtType, \$sc\_\$cpu\_EVS\_DisAppEvtTypeMask

#### Command Structure

[CFE\\_EVS\\_DisableAppEventTypeCmd\\_t](#) The following bit positions apply to structure member named 'BitMask'. Bit 0 - Debug Bit 1 - Informational Bit 2 - Error Bit 3 - Critical A one in a bit position means the event type will be disabled (or filtered) for the specified application. A zero in a bit position means the filtering state is unchanged for the specified application.

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_EVS\\_CMDPC](#) - command execution counter will increment
- The generation of [CFE\\_EVS\\_DISAPPENTTYPE\\_EID](#) debug event message
- The clearing of the Event Type Active Flag in The Event Type Active Flag in EVS App Data File

#### Error Conditions

This command may fail for the following reason(s):

- BitMask field invalid - mask cannot be zero, and only bits 0-3 may be set
- Application name is not valid or not registered with event services

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_EVS\\_CMDEC](#) - command error counter will increment
- An Error specific event message

#### Criticality

Disabling an application's event type is not particularly hazardous, as the result may be shutting off unnecessary event messages and possible event flooding of the system. However, inappropriately disabling an application's event type could result in a loss of critical information and missed behavior for the ground system.

#### See also

[CFE\\_EVS\\_ENABLE\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_DISABLE\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_ENABLE\\_APP\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_ENABLE\\_APP\\_EVENTS\\_CC](#), [CFE\\_EVS\\_DISABLE\\_APP\\_EVENTS\\_CC](#)

Definition at line 365 of file cfe\_evs\_msg.h.

### 12.68.2.7 CFE\_EVS\_DISABLE\_APP\_EVENTS\_CC

```
#define CFE_EVS_DISABLE_APP_EVENTS_CC 8
```

**Name** Disable Event Services for an Application

#### Description

This command disables the command specified application from sending events through Event Service. Note: In order for this command to take effect, applications must be registered for Event Service.

**Command Mnemonic(s)** \$sc\_\$cpu\_EVS\_DisAppEvGen

#### Command Structure

[CFE\\_EVS\\_DisableAppEventsCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_EVS\\_CMDPC](#) - command execution counter will increment
- The generation of [CFE\\_EVS\\_DISAPPEVT\\_EID](#) debug event message

#### Error Conditions

This command may fail for the following reason(s):

- Application name is not valid or not registered with event services

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_EVS\\_CMDEC](#) - command error counter will increment
- An Error specific event message

#### Criticality

Disabling an application's events is not particularly hazardous, as the result may be shutting off unnecessary event messages and possible event flooding of the system. However, inappropriately disabling an application's events could result in a loss of critical information and missed behavior for the ground system.

#### See also

[CFE\\_EVS\\_ENABLE\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_DISABLE\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_ENABLE\\_APP\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_DISABLE\\_APP\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_ENABLE\\_APP\\_EVENTS\\_CC](#)

Definition at line 443 of file cfe\_evs\_msg.h.

### 12.68.2.8 CFE\_EVS\_DISABLE\_EVENT\_TYPE\_CC

```
#define CFE_EVS_DISABLE_EVENT_TYPE_CC 3
```

**Name** Disable Event Type

#### Description

This command disables the command specified Event Type preventing event messages of this type to be sent through Event Service. An Event Type is defined to be a classification of an Event Message such as debug, informational, error and critical. This command is a global disable of a particular event type, it applies to all applications.

**Command Mnemonic(s)** \$sc\_\$cpu\_EVS\_DisEventType, \$sc\_\$cpu\_EVS\_DisEventTypeMask

#### Command Structure

[CFE\\_EVS\\_DisableEventTypeCmd\\_t](#) The following bit positions apply to structure member named 'BitMask'. Bit 0 - Debug Bit 1 - Informational Bit 2 - Error Bit 3 - Critical A one in a bit position means the event type will be disabled (or filtered). A zero in a bit position means the filtering state is unchanged.

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_EVS\\_CMDPC](#) - command execution counter will increment
- The generation of [CFE\\_EVS\\_DISEVTTYPE\\_EID](#) debug message

#### Error Conditions

This command may fail for the following reason(s):

- BitMask field invalid - mask cannot be zero, and only bits 0-3 may be set

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_EVS\\_CMDEC](#) - command error counter will increment
- An Error specific event message

#### Criticality

Disabling an event type is not particularly hazardous, as the result may be shutting off unnecessary event messages and possible event flooding of the system. However, inappropriately disabling an event type could result in a loss of critical information and missed behavior for the ground system.

#### See also

[CFE\\_EVS\\_ENABLE\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_ENABLE\\_APP\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_DISABLE\\_APP\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_ENABLE\\_APP\\_EVENTS\\_CC](#), [CFE\\_EVS\\_DISABLE\\_APP\\_EVENTS\\_CC](#)

Definition at line 213 of file `cfe_evs_msg.h`.

### 12.68.2.9 CFE\_EVS\_DISABLE\_PORTS\_CC

```
#define CFE_EVS_DISABLE_PORTS_CC 12
```

**Name** Disable Event Services Output Ports

#### Description

This command disables the specified port from outputting event messages.

**Command Mnemonic(s)** \$sc\_\$cpu\_EVS\_DisPort, \$sc\_\$cpu\_EVS\_DisPortMask

#### Command Structure

**CFE\_EVS\_DisablePortsCmd\_t** The following bit positions apply to structure member named 'BitMask'. Bit 0 - Port 1 Bit 1 - Port 2 Bit 2 - Port 3 Bit 3 - Port 4 A one in a bit position means the port will be disabled. A zero in a bit position means the port state is unchanged.

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_EVS\_CMDPC** - command execution counter will increment
- The generation of **CFE\_EVS\_DISPORT\_EID** debug event message

#### Error Conditions

This command may fail for the following reason(s):

- BitMask field invalid - mask cannot be zero, and only bits 0-3 may be set

Evidence of failure may be found in the following telemetry:

- **\$sc\_\$cpu\_EVS\_CMDEC** - command error counter will increment
- An Error specific event message

#### Criticality

None.

#### See also

[CFE\\_EVS\\_ENABLE\\_PORTS\\_CC](#)

Definition at line 599 of file cfe\_evs\_msg.h.

### 12.68.2.10 CFE\_EVS\_ENABLE\_APP\_EVENT\_TYPE\_CC

```
#define CFE_EVS_ENABLE_APP_EVENT_TYPE_CC 5
```

**Name** Enable Application Event Type

#### Description

This command enables the command specified event type for the command specified application, allowing the application to send event messages of the command specified event type through Event Service. An Event Type is defined to be a classification of an Event Message such as debug, informational, critical, and error. Note: In order for this command to take effect, applications must be registered for Event Service.

**Command Mnemonic(s)** \$sc\_\$cpu\_EVS\_EnaAppEvtType, \$sc\_\$cpu\_EVS\_EnaAppEvtTypeMask

#### Command Structure

[CFE\\_EVS\\_EnableAppEventTypeCmd\\_t](#) The following bit positions apply to structure member named 'BitMask'. Bit 0 - Debug Bit 1 - Informational Bit 2 - Error Bit 3 - Critical A one in a bit position means the event type will be enabled (or unfiltered) for the specified application. A zero in a bit position means the filtering state is unchanged for the specified application.

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_EVS\\_CMDPC](#) - command execution counter will increment
- The generation of [CFE\\_EVS\\_ENAAPPEVTTYPE\\_EID](#) debug event message

#### Error Conditions

This command may fail for the following reason(s):

- BitMask field invalid - mask cannot be zero, and only bits 0-3 may be set
- Application name is not valid or not registered with event services

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_EVS\\_CMDEC](#) - command error counter will increment
- An Error specific event message

#### Criticality

Enabling an application event type is not particularly hazardous, as the result may be turning on necessary event messages and communication to the ground system. However, inappropriately enabling an application's event type could result in flooding of the ground system.

#### See also

[CFE\\_EVS\\_ENABLE\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_DISABLE\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_DISABLE\\_APP\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_ENABLE\\_APP\\_EVENTS\\_CC](#), [CFE\\_EVS\\_DISABLE\\_APP\\_EVENTS\\_CC](#)

Definition at line 312 of file cfe\_evs\_msg.h.

### 12.68.2.11 CFE\_EVS\_ENABLE\_APP\_EVENTS\_CC

```
#define CFE_EVS_ENABLE_APP_EVENTS_CC 7
```

**Name** Enable Event Services for an Application

#### Description

This command enables the command specified application to send events through the Event Service. Note: In order for this command to take effect, applications must be registered for Event Service.

**Command Mnemonic(s)** \$sc\_\$cpu\_EVS\_EnaAppEvGen

#### Command Structure

[CFE\\_EVS\\_EnableAppEventsCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_EVS\\_CMDPC](#) - command execution counter will increment
- The generation of [CFE\\_EVS\\_ENAAPPEVT\\_EID](#) debug event message
- The setting of the Active Flag in The Active Flag in EVS App Data File

#### Error Conditions

This command may fail for the following reason(s):

- Application name is not valid or not registered with event services

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_EVS\\_CMDEC](#) - command error counter will increment
- An Error specific event message

#### Criticality

Enabling an application events is not particularly hazardous, as the result may be turning on necessary event messages and communication to the ground system. However, inappropriately enabling an application's events could result in flooding of the ground system.

#### See also

[CFE\\_EVS\\_ENABLE\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_DISABLE\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_ENABLE\\_APP\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_DISABLE\\_APP\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_DISABLE\\_APP\\_EVENTS\\_CC](#)

Definition at line 404 of file `cfe_evs_msg.h`.

### 12.68.2.12 CFE\_EVS\_ENABLE\_EVENT\_TYPE\_CC

```
#define CFE_EVS_ENABLE_EVENT_TYPE_CC 2
```

**Name** Enable Event Type

#### Description

This command enables the command specified Event Type allowing event messages of this type to be sent through Event Service. An Event Type is defined to be a classification of an Event Message such as debug, informational, error and critical. This command is a global enable of a particular event type, it applies to all applications.

**Command Mnemonic(s)** \$sc\_\$cpu\_EVS\_EnaEventType, \$sc\_\$cpu\_EVS\_EnaEventTypeMask

#### Command Structure

[CFE\\_EVS\\_EnableEventTypeCmd\\_t](#) The following bit positions apply to structure member named 'BitMask'. Bit 0 - Debug Bit 1 - Informational Bit 2 - Error Bit 3 - Critical A one in a bit position means the event type will be enabled (or unfiltered). A zero in a bit position means the filtering state is unchanged.

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_EVS\\_CMDPC](#) - command execution counter will increment
- The generation of [CFE\\_EVS\\_ENAEVTTYPE\\_EID](#) debug message

#### Error Conditions

This command may fail for the following reason(s):

- BitMask field invalid - mask cannot be zero, and only bits 0-3 may be set

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_EVS\\_CMDEC](#) - command error counter will increment
- An Error specific event message

#### Criticality

Enabling an event type is not particularly hazardous, as the result may be turning on necessary event messages and communication to the ground system. However, inappropriately enabling an event type could result in flooding of the system.

#### See also

[CFE\\_EVS\\_DISABLE\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_ENABLE\\_APP\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_DISABLE\\_APP\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_ENABLE\\_APP\\_EVENTS\\_CC](#), [CFE\\_EVS\\_DISABLE\\_APP\\_EVENTS\\_CC](#)

Definition at line 164 of file cfe\_evs\_msg.h.

### 12.68.2.13 CFE\_EVS\_ENABLE\_PORTS\_CC

```
#define CFE_EVS_ENABLE_PORTS_CC 11
```

**Name** Enable Event Services Output Ports

#### Description

This command enables the command specified port to output event messages

**Command Mnemonic(s)** \$sc\_\$cpu\_EVS\_EnaPort, \$sc\_\$cpu\_EVS\_EnaPortMask

#### Command Structure

**CFE\_EVS\_EnablePortsCmd\_t** The following bit positions apply to structure member named 'BitMask'. Bit 0 - Port 1 Bit 1 - Port 2 Bit 2 - Port 3 Bit 3 - Port 4 A one in a bit position means the port will be enabled. A zero in a bit position means the port state is unchanged.

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_EVS\_CMDPC** - command execution counter will increment
- The generation of **CFE\_EVS\_ENAPORT\_EID** debug event message

#### Error Conditions

This command may fail for the following reason(s):

- BitMask field invalid - mask cannot be zero, and only bits 0-3 may be set

Evidence of failure may be found in the following telemetry:

- **\$sc\_\$cpu\_EVS\_CMDEC** - command error counter will increment
- An Error specific event message

#### Criticality

None.

#### See also

[CFE\\_EVS\\_DISABLE\\_PORTS\\_CC](#)

Definition at line 560 of file cfe\_evs\_msg.h.

### 12.68.2.14 CFE\_EVS\_ERROR\_BIT

```
#define CFE_EVS_ERROR_BIT 0x0004
```

Definition at line 891 of file cfe\_evs\_msg.h.

### 12.68.2.15 CFE\_EVS\_INFORMATION\_BIT

```
#define CFE_EVS_INFORMATION_BIT 0x0002
```

Definition at line 890 of file cfe\_evs\_msg.h.

### 12.68.2.16 CFE\_EVS\_NOOP\_CC

```
#define CFE_EVS_NOOP_CC 0
```

**Name** Event Services No-Op

#### Description

This command performs no other function than to increment the command execution counter. The command may be used to verify general aliveness of the Event Services task.

**Command Mnemonic(s)** \$sc\_\$cpu\_EVS\_NOOP

#### Command Structure

[CFE\\_EVS\\_NoopCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_EVS\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_EVS\\_NOOP\\_EID](#) informational event message will be generated

#### Error Conditions

There are no error conditions for this command. If the Event Services receives the command, the event is sent (although it may be filtered by EVS itself) and the counter is incremented unconditionally.

#### Criticality

None

#### See also

Definition at line 77 of file cfe\_evs\_msg.h.

### 12.68.2.17 CFE\_EVS\_PORT1\_BIT

```
#define CFE_EVS_PORT1_BIT 0x0001
```

Definition at line 895 of file cfe\_evs\_msg.h.

### 12.68.2.18 CFE\_EVS\_PORT2\_BIT

```
#define CFE_EVS_PORT2_BIT 0x0002
```

Definition at line 896 of file cfe\_evs\_msg.h.

### 12.68.2.19 CFE\_EVS\_PORT3\_BIT

```
#define CFE_EVS_PORT3_BIT 0x0004
```

Definition at line 897 of file cfe\_evs\_msg.h.

### 12.68.2.20 CFE\_EVS\_PORT4\_BIT

```
#define CFE_EVS_PORT4_BIT 0x0008
```

Definition at line 898 of file cfe\_evs\_msg.h.

### 12.68.2.21 CFE\_EVS\_RESET\_ALL\_FILTERS\_CC

```
#define CFE_EVS_RESET_ALL_FILTERS_CC 14
```

**Name** Reset All Event Filters for an Application

#### Description

This command resets all of the command specified applications event filters. Note: In order for this command to take effect, applications must be registered for Event Service.

**Command Mnemonic(s)** \$sc\_\$cpu\_EVS\_RstAllFltrs

#### Command Structure

[CFE\\_EVS\\_ResetAllFiltersCmd\\_t](#)

### Command Verification

Successful execution of this command may be verified with the following telemetry:

- `$sc_$cpu_EVS_CMDPC` - command execution counter will increment
- The generation of `CFE_EVS_RSTALLFILTER_EID` debug event message

### Error Conditions

This command may fail for the following reason(s):

- Application name is not valid or not registered with event services

Evidence of failure may be found in the following telemetry:

- `$sc_$cpu_EVS_CMDEC` - command error counter will increment
- An Error specific event message

### Criticality

None.

### See also

[CFE\\_EVS\\_SET\\_FILTER\\_CC](#), [CFE\\_EVS\\_RESET\\_FILTER\\_CC](#), [CFE\\_EVS\\_ADD\\_EVENT\\_FILTER\\_CC](#), [CFE\\_EVS\\_DELETE\\_EVENT\\_FILTER\\_CC](#)

Definition at line 669 of file `cfe_evs_msg.h`.

## 12.68.2.22 CFE\_EVS\_RESET\_APP\_COUNTER\_CC

```
#define CFE_EVS_RESET_APP_COUNTER_CC 9
```

**Name** Reset Application Event Counters

### Description

This command sets the command specified application's event counter to zero. Note: In order for this command to take effect, applications must be registered for Event Service.

**Command Mnemonic(s)** `$sc_$cpu_EVS_RstAppCtrs`

### Command Structure

[CFE\\_EVS\\_ResetAppCounterCmd\\_t](#)

### Command Verification

Successful execution of this command may be verified with the following telemetry:

- `$sc_$cpu_EVS_CMDPC` - command execution counter will increment
- The generation of `CFE_EVS_RSTEVTCNT_EID` debug event message

### Error Conditions

This command may fail for the following reason(s):

- Application name is not valid or not registered with event services

Evidence of failure may be found in the following telemetry:

- `$sc_$cpu_EVS_CMDEC` - command error counter will increment
- An Error specific event message

### Criticality

This command is not inherently dangerous. However, it is possible for ground systems and on-board safing procedures to be designed such that they react to changes in the counter value that is reset by this command.

### See also

[CFE\\_EVS\\_RESET\\_COUNTERS\\_CC](#)

Definition at line 479 of file `cfe_evs_msg.h`.

## 12.68.2.23 CFE\_EVS\_RESET\_COUNTERS\_CC

```
#define CFE_EVS_RESET_COUNTERS_CC 1
```

**Name** Event Services Reset Counters

### Description

This command resets the following counters within the Event Services housekeeping telemetry:

- Command Execution Counter (`$sc_$cpu_EVS_CMDPC`)
- Command Error Counter (`$sc_$cpu_EVS_CMDEC`)

**Command Mnemonic(s)** `$sc_$cpu_EVS_ResetCtrs`

### Command Structure

[CFE\\_EVS\\_ResetCountersCmd\\_t](#)

### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_EVS\_CMDPC** - command execution counter will be reset to 0
- **\$sc\_\$cpu\_EVS\_CMDEC** - command error counter will be reset to 0
- The [CFE\\_EVS\\_RSTCNT\\_EID](#) debug event message will be generated

### Error Conditions

There are no error conditions for this command. If the Event Services receives the command, the event is sent (although it may be filtered by EVS) and the counter is incremented unconditionally.

### Criticality

This command is not inherently dangerous. However, it is possible for ground systems and on-board safing procedures to be designed such that they react to changes in the counter values that are reset by this command.

### See also

[CFE\\_EVS\\_RESET\\_APP\\_COUNTER\\_CC](#)

Definition at line 116 of file cfe\_evs\_msg.h.

## 12.68.2.24 CFE\_EVS\_RESET\_FILTER\_CC

```
#define CFE_EVS_RESET_FILTER_CC 13
```

**Name** Reset an Event Filter for an Application

### Description

This command resets the command specified application's event filter for the command specified event ID. Note: In order for this command to take effect, applications must be registered for Event Service.

**Command Mnemonic(s)** \$sc\_\$cpu\_EVS\_RstBinFltrCtr

### Command Structure

[CFE\\_EVS\\_ResetFilterCmd\\_t](#)

### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_EVS\_CMDPC** - command execution counter will increment
- The generation of [CFE\\_EVS\\_RSTFILTER\\_EID](#) debug event message

### Error Conditions

This command may fail for the following reason(s):

- Application name is not valid or not registered with event services
- Specified event ID is not found in the application event filter

Evidence of failure may be found in the following telemetry:

- **\$sc\_\$cpu\_EVS\_CMDEC** - command error counter will increment
- An Error specific event message

### Criticality

None.

### See also

[CFE\\_EVS\\_SET\\_FILTER\\_CC](#), [CFE\\_EVS\\_RESET\\_ALL\\_FILTERS\\_CC](#), [CFE\\_EVS\\_ADD\\_EVENT\\_FILTER\\_CC](#),  
[CFE\\_EVS\\_DELETE\\_EVENT\\_FILTER\\_CC](#)

Definition at line 635 of file cfe\_evs\_msg.h.

### 12.68.2.25 CFE\_EVS\_SET\_EVENT\_FORMAT\_MODE\_CC

```
#define CFE_EVS_SET_EVENT_FORMAT_MODE_CC 4
```

**Name** Set Event Format Mode

### Description

This command sets the event format mode to the command specified value. The event format mode may be either short or long. A short event format detaches the Event Data from the event message and only includes the following information in the event packet: Processor ID, Application ID, Event ID, and Event Type. Refer to section 5.3.3.4 for a description of the Event Service event packet contents. Event Data is defined to be data describing an Event that is supplied to the cFE Event Service. ASCII text strings are used as the primary format for Event Data because heritage ground systems use string compares as the basis for their automated alert systems. Two systems, ANSR and SERS were looked at for interface definitions. The short event format is used to accommodate experiences with limited telemetry bandwidth. The long event format includes all event information included within the short format along with the Event Data.

**Command Mnemonic(s)** \$sc\_\$cpu\_EVS\_SetEvtFmt

### Command Structure

[CFE\\_EVS\\_SetEventFormatModeCmd\\_t](#)

## Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_EVS\_CMDPC** - command execution counter will increment
- The generation of **CFE\_EVS\_SETEVTFMTMOD\_EID** debug message

## Error Conditions

This command may fail for the following reason(s):

- Invalid MsgFormat mode selection

Evidence of failure may be found in the following telemetry:

- **\$sc\_\$cpu\_EVS\_CMDEC** - command error counter will increment
- An Error specific event message

## Criticality

Setting the event format mode is not particularly hazardous, as the result may be saving necessary bandwidth. However, inappropriately setting the event format mode could result in a loss of information and missed behavior for the ground system

## See also

Definition at line 260 of file cfe\_evs\_msg.h.

### 12.68.2.26 CFE\_EVS\_SET\_FILTER\_CC

```
#define CFE_EVS_SET_FILTER_CC 10
```

**Name** Set Application Event Filter

## Description

This command sets the command specified application's event filter mask to the command specified value for the command specified event. Note: In order for this command to take effect, applications must be registered for Event Service.

**Command Mnemonic(s)** \$sc\_\$cpu\_EVS\_SetBinFltrMask

### Command Structure

[CFE\\_EVS\\_SetFilterCmd\\_t](#)

### Command Verification

Successful execution of this command may be verified with the following telemetry:

- `$sc_$cpu_EVS_CMDPC` - command execution counter will increment
- The generation of [CFE\\_EVS\\_SETFILTERMSK\\_EID](#) debug event message

### Error Conditions

This command may fail for the following reason(s):

- Application name is not valid or not registered with event services
- Specified event ID is not found in the application event filter

Evidence of failure may be found in the following telemetry:

- `$sc_$cpu_EVS_CMDEC` - command error counter will increment
- An Error specific event message

### Criticality

Setting an application event filter mask is not particularly hazardous, as the result may be shutting off unnecessary event messages and possible event flooding of the system. However, inappropriately setting an application's event filter mask could result in a loss of critical information and missed behavior for the ground system or flooding of the ground system.

### See also

[CFE\\_EVS\\_RESET\\_FILTER\\_CC](#), [CFE\\_EVS\\_RESET\\_ALL\\_FILTERS\\_CC](#), [CFE\\_EVS\\_ADD\\_EVENT\\_FILTER\\_CC](#), [CFE\\_EVS\\_DELETE\\_EVENT\\_FILTER\\_CC](#)

Definition at line 521 of file `cfe_evs_msg.h`.

## 12.68.2.27 CFE\_EVS\_SET\_LOG\_MODE\_CC

```
#define CFE_EVS_SET_LOG_MODE_CC 19
```

**Name** Set Logging Mode

### Description

This command sets the logging mode to the command specified value.

**Command Mnemonic(s)** `$sc_$cpu_EVS_SetLogMode`

**Command Structure**

[CFE\\_EVS\\_SetLogModeCmd\\_t](#)

**Command Verification**

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_EVS\_CMDPC** - command execution counter will increment
- The generation of [CFE\\_EVS\\_LOGMODE\\_EID](#) debug event message

**Error Conditions**

This command may fail for the following reason(s):

- Invalid LogMode selected - must be either [CFE\\_EVS\\_LogMode\\_OVERWRITE](#) or [CFE\\_EVS\\_LogMode\\_DISCARD](#)

Evidence of failure may be found in the following telemetry:

- **\$sc\_\$cpu\_EVS\_CMDEC** - command error counter will increment
- An Error specific event message

**Criticality**

Setting the event logging mode is not particularly hazardous, as the result may be saving valuable event data. However, inappropriately setting the log mode could result in a loss of critical information. Note: the event log is a back-up log to the on-board recorder.

**See also**

[CFE\\_EVS\\_WRITE\\_LOG\\_DATA\\_FILE\\_CC](#), [CFE\\_EVS\\_CLEAR\\_LOG\\_CC](#)

Definition at line 850 of file cfe\_evs\_msg.h.

**12.68.2.28 CFE\_EVS\_WRITE\_APP\_DATA\_FILE\_CC**

```
#define CFE_EVS_WRITE_APP_DATA_FILE_CC 17
```

**Name** Write Event Services Application Information to File

**Description**

This command writes all application data to a file for all applications that have registered with the EVS. The application data includes the Application ID, Active Flag, Event Count, Event Types Active Flag, and Filter Data.

**Command Mnemonic(s)** \$sc\_\$cpu\_EVS\_WriteAppData2File

### Command Structure

[CFE\\_EVS\\_WriteAppDataFileCmd\\_t](#)

### Command Verification

Successful execution of this command may be verified with the following telemetry:

- `$sc_$cpu_EVS_CMDPC` - command execution counter will increment
- The generation of [CFE\\_EVS\\_WRDAT\\_EID](#) debug event message
- The file specified in the command (or the default specified by the [CFE\\_PLATFORM\\_EVS\\_DEFAULT\\_APP\\_DATA\\_FILE](#) configuration parameter) will be updated with the latest information.

### Error Conditions

This command may fail for the following reason(s):

- The specified FileName cannot be parsed
- An Error occurs while trying to write to the file

Evidence of failure may be found in the following telemetry:

- `$sc_$cpu_EVS_CMDEC` - command error counter will increment
- An Error specific event message

### Criticality

Writing a file is not particularly hazardous, but if proper file management is not taken, then the file system can fill up if this command is used repeatedly.

### See also

[CFE\\_EVS\\_WRITE\\_LOG\\_DATA\\_FILE\\_CC](#), [CFE\\_EVS\\_SET\\_LOG\\_MODE\\_CC](#)

Definition at line 779 of file `cfe_evs_msg.h`.

## 12.68.2.29 CFE\_EVS\_WRITE\_LOG\_DATA\_FILE\_CC

```
#define CFE_EVS_WRITE_LOG_DATA_FILE_CC 18
```

**Name** Write Event Log to File

### Description

This command requests the Event Service to generate a file containing the contents of the local event log.

**Command Mnemonic(s)** `$sc_$cpu_EVS_WriteLog2File`

**Command Structure**

[CFE\\_EVS\\_WriteLogFileCmd\\_t](#)

**Command Verification**

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_EVS\_CMDPC** - command execution counter will increment
- The generation of [CFE\\_EVS\\_WRLOG\\_EID](#) debug event message

**Error Conditions**

This command may fail for the following reason(s):

- The specified FileName cannot be parsed
- An Error occurs while trying to write to the file

Evidence of failure may be found in the following telemetry:

- **\$sc\_\$cpu\_EVS\_CMDEC** - command error counter will increment
- An Error specific event message

**Criticality**

Writing a file is not particularly hazardous, but if proper file management is not taken, then the file system can fill up if this command is used repeatedly.

**See also**

[CFE\\_EVS\\_WRITE\\_APP\\_DATA\\_FILE\\_CC](#), [CFE\\_EVS\\_SET\\_LOG\\_MODE\\_CC](#), [CFE\\_EVS\\_CLEAR\\_LOG\\_CC](#)

Definition at line 814 of file cfe\_evs\_msg.h.

**12.68.3 Typedef Documentation****12.68.3.1 CFE\_EVS\_AddEventFilterCmd\_t**

typedef [CFE\\_EVS\\_AppNameEventIDMaskCmd\\_t](#) CFE\_EVS\_AddEventFilterCmd\_t

Definition at line 1151 of file cfe\_evs\_msg.h.

### 12.68.3.2 CFE\_EVS\_AppDataCmd\_Payload\_t

```
typedef struct CFE_EVS_AppDataCmd_Payload CFE_EVS_AppDataCmd_Payload_t
```

Write Event Services Application Information to File Command Payload.

For command details, see [CFE\\_EVS\\_WRITE\\_APP\\_DATA\\_FILE\\_CC](#)

### 12.68.3.3 CFE\_EVS\_AppNameBitMaskCmd\_Payload\_t

```
typedef struct CFE_EVS_AppNameBitMaskCmd_Payload CFE_EVS_AppNameBitMaskCmd_Payload_t
```

Generic App Name and Bitmask Command Payload.

For command details, see [CFE\\_EVS\\_ENABLE\\_APP\\_EVENT\\_TYPE\\_CC](#) and/or [CFE\\_EVS\\_DISABLE\\_APP\\_EVENT\\_TYPE\\_CC](#)

### 12.68.3.4 CFE\_EVS\_AppNameBitMaskCmd\_t

```
typedef struct CFE_EVS_AppNameBitMaskCmd CFE_EVS_AppNameBitMaskCmd_t
```

Generic App Name and Bitmask Command.

### 12.68.3.5 CFE\_EVS\_AppNameCmd\_Payload\_t

```
typedef struct CFE_EVS_AppNameCmd_Payload CFE_EVS_AppNameCmd_Payload_t
```

Generic App Name Command Payload.

For command details, see [CFE\\_EVS\\_ENABLE\\_APP\\_EVENTS\\_CC](#), [CFE\\_EVS\\_DISABLE\\_APP\\_EVENTS\\_CC](#), [CFE\\_EVS\\_RESET\\_APP\\_COUNTER\\_CC](#) and/or [CFE\\_EVS\\_RESET\\_ALL\\_FILTERS\\_CC](#)

### 12.68.3.6 CFE\_EVS\_AppNameCmd\_t

```
typedef struct CFE_EVS_AppNameCmd CFE_EVS_AppNameCmd_t
```

Generic App Name Command.

### 12.68.3.7 CFE\_EVS\_AppNameEventIDCmd\_Payload\_t

```
typedef struct CFE_EVS_AppNameEventIDCmd_Payload CFE_EVS_AppNameEventIDCmd_Payload_t
```

Generic App Name and Event ID Command Payload.

For command details, see [CFE\\_EVS\\_RESET\\_FILTER\\_CC](#) and [CFE\\_EVS\\_DELETE\\_EVENT\\_FILTER\\_CC](#)

**12.68.3.8 CFE\_EVS\_AppNameEventIDCmd\_t**

```
typedef struct CFE_EVS_AppNameEventIDCmd CFE_EVS_AppNameEventIDCmd_t
```

Generic App Name and Event ID Command.

**12.68.3.9 CFE\_EVS\_AppNameEventIDMaskCmd\_Payload\_t**

```
typedef struct CFE_EVS_AppNameEventIDMaskCmd_Payload CFE_EVS_AppNameEventIDMaskCmd_Payload_t
```

Generic App Name, Event ID, Mask Command Payload.

For command details, see [CFE\\_EVS\\_SET\\_FILTER\\_CC](#), [CFE\\_EVS\\_ADD\\_EVENT\\_FILTER\\_CC](#) and/or [CFE\\_EVS\\_DELETE\\_EVENT\\_FILTER\\_CC](#)

**12.68.3.10 CFE\_EVS\_AppNameEventIDMaskCmd\_t**

```
typedef struct CFE_EVS_AppNameEventIDMaskCmd CFE_EVS_AppNameEventIDMaskCmd_t
```

Generic App Name, Event ID, Mask Command.

**12.68.3.11 CFE\_EVS\_AppTlmData\_t**

```
typedef struct CFE_EVS_AppTlmData CFE_EVS_AppTlmData_t
```

**12.68.3.12 CFE\_EVS\_BitMaskCmd\_Payload\_t**

```
typedef struct CFE_EVS_BitMaskCmd_Payload CFE_EVS_BitMaskCmd_Payload_t
```

Generic Bitmask Command Payload.

For command details, see [CFE\\_EVS\\_ENABLE\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_DISABLE\\_EVENT\\_TYPE\\_CC](#), [CFE\\_EVS\\_ENABLE\\_PORTS\\_CC](#) and/or [CFE\\_EVS\\_DISABLE\\_PORTS\\_CC](#)

**12.68.3.13 CFE\_EVS\_BitMaskCmd\_t**

```
typedef struct CFE_EVS_BitMaskCmd CFE_EVS_BitMaskCmd_t
```

Generic Bitmask Command.

**12.68.3.14 CFE\_EVS\_ClearLogCmd\_t**

```
typedef CFE_EVS_NoArgsCmd_t CFE_EVS_ClearLogCmd_t
```

Definition at line 917 of file cfe\_evs\_msg.h.

**12.68.3.15 CFE\_EVS\_DeleteEventFilterCmd\_t**

```
typedef CFE_EVS_AppNameEventIDCmd_t CFE_EVS_DeleteEventFilterCmd_t
```

Definition at line 1091 of file cfe\_evs\_msg.h.

**12.68.3.16 CFE\_EVS\_DisableAppEventsCmd\_t**

```
typedef CFE_EVS_AppNameCmd_t CFE_EVS_DisableAppEventsCmd_t
```

Definition at line 1060 of file cfe\_evs\_msg.h.

**12.68.3.17 CFE\_EVS\_DisableAppEventTypeCmd\_t**

```
typedef CFE_EVS_AppNameBitMaskCmd_t CFE_EVS_DisableAppEventTypeCmd_t
```

Definition at line 1121 of file cfe\_evs\_msg.h.

**12.68.3.18 CFE\_EVS\_DisableEventTypeCmd\_t**

```
typedef CFE_EVS_BitMaskCmd_t CFE_EVS_DisableEventTypeCmd_t
```

Definition at line 1031 of file cfe\_evs\_msg.h.

**12.68.3.19 CFE\_EVS\_DisablePortsCmd\_t**

```
typedef CFE_EVS_BitMaskCmd_t CFE_EVS_DisablePortsCmd_t
```

Definition at line 1029 of file cfe\_evs\_msg.h.

**12.68.3.20 CFE\_EVS\_EnableAppEventsCmd\_t**

```
typedef CFE_EVS_AppNameCmd_t CFE_EVS_EnableAppEventsCmd_t
```

Definition at line 1059 of file cfe\_evs\_msg.h.

**12.68.3.21 CFE\_EVS\_EnableAppEventTypeCmd\_t**

```
typedef CFE_EVS_AppNameBitMaskCmd_t CFE_EVS_EnableAppEventTypeCmd_t
```

Definition at line 1120 of file cfe\_evs\_msg.h.

**12.68.3.22 CFE\_EVS\_EnableEventTypeCmd\_t**

```
typedef CFE_EVS_BitMaskCmd_t CFE_EVS_EnableEventTypeCmd_t
```

Definition at line 1030 of file cfe\_evs\_msg.h.

**12.68.3.23 CFE\_EVS\_EnablePortsCmd\_t**

```
typedef CFE_EVS_BitMaskCmd_t CFE_EVS_EnablePortsCmd_t
```

Definition at line 1028 of file cfe\_evs\_msg.h.

**12.68.3.24 CFE\_EVS\_HousekeepingTlm\_Payload\_t**

```
typedef struct CFE_EVS_HousekeepingTlm_Payload CFE_EVS_HousekeepingTlm_Payload_t
```

**Name** Event Services Housekeeping Telemetry Packet

**12.68.3.25 CFE\_EVS\_HousekeepingTlm\_t**

```
typedef struct CFE_EVS_HousekeepingTlm CFE_EVS_HousekeepingTlm_t
```

**12.68.3.26 CFE\_EVS\_LogFileCmd\_Payload\_t**

```
typedef struct CFE_EVS_LogFileCmd_Payload CFE_EVS_LogFileCmd_Payload_t
```

Write Event Log to File Command Payload.

For command details, see [CFE\\_EVS\\_WRITE\\_LOG\\_DATA\\_FILE\\_CC](#)

**12.68.3.27 CFE\_EVS\_LongEventTlm\_Payload\_t**

```
typedef struct CFE_EVS_LongEventTlm_Payload CFE_EVS_LongEventTlm_Payload_t
```

**Name** Event Message Telemetry Packet (Long format)

**12.68.3.28 CFE\_EVS\_LongEventTlm\_t**

```
typedef struct CFE_EVS_LongEventTlm CFE_EVS_LongEventTlm_t
```

**12.68.3.29 CFE\_EVS\_NoArgsCmd\_t**

```
typedef struct CFE_EVS_NoArgsCmd CFE_EVS_NoArgsCmd_t
```

Command with no additional arguments.

**12.68.3.30 CFE\_EVS\_NoopCmd\_t**

```
typedef CFE_EVS_NoArgsCmd_t CFE_EVS_NoopCmd_t
```

Definition at line 915 of file cfe\_evs\_msg.h.

**12.68.3.31 CFE\_EVS\_PacketID\_t**

```
typedef struct CFE_EVS_PacketID CFE_EVS_PacketID_t
```

Telemetry packet structures

**12.68.3.32 CFE\_EVS\_ResetAllFiltersCmd\_t**

```
typedef CFE_EVS_AppNameCmd_t CFE_EVS_ResetAllFiltersCmd_t
```

Definition at line 1062 of file cfe\_evs\_msg.h.

**12.68.3.33 CFE\_EVS\_ResetAppCounterCmd\_t**

```
typedef CFE_EVS_AppNameCmd_t CFE_EVS_ResetAppCounterCmd_t
```

Definition at line 1061 of file cfe\_evs\_msg.h.

**12.68.3.34 CFE\_EVS\_ResetCountersCmd\_t**

```
typedef CFE_EVS_NoArgsCmd_t CFE_EVS_ResetCountersCmd_t
```

Definition at line 916 of file cfe\_evs\_msg.h.

**12.68.3.35 CFE\_EVS\_ResetFilterCmd\_t**

```
typedef CFE_EVS_AppNameEventIDCmd_t CFE_EVS_ResetFilterCmd_t
```

Definition at line 1090 of file cfe\_evs\_msg.h.

**12.68.3.36 CFE\_EVS\_SetEventFormatMode\_Payload\_t**

```
typedef struct CFE_EVS_SetEventFormatCode_Payload CFE_EVS_SetEventFormatMode_Payload_t
```

Set Event Format Mode Command Payload.

For command details, see [CFE\\_EVS\\_SET\\_EVENT\\_FORMAT\\_MODE\\_CC](#)

**12.68.3.37 CFE\_EVS\_SetEventFormatModeCmd\_t**

```
typedef struct CFE_EVS_SetEventFormatModeCmd CFE_EVS_SetEventFormatModeCmd_t
```

Set Event Format Mode Command.

**12.68.3.38 CFE\_EVS\_SetFilterCmd\_t**

```
typedef CFE_EVS_AppNameEventIDMaskCmd_t CFE_EVS_SetFilterCmd_t
```

Definition at line 1152 of file cfe\_evs\_msg.h.

**12.68.3.39 CFE\_EVS\_SetLogMode\_Payload\_t**

```
typedef struct CFE_EVS_SetLogMode_Payload CFE_EVS_SetLogMode_Payload_t
```

Set Log Mode Command Payload.

For command details, see [CFE\\_EVS\\_SET\\_LOG\\_MODE\\_CC](#)

**12.68.3.40 CFE\_EVS\_SetLogModeCmd\_t**

```
typedef struct CFE_EVS_SetLogModeCmd CFE_EVS_SetLogModeCmd_t
```

Set Log Mode Command.

**12.68.3.41 CFE\_EVS\_ShortEventTlm\_Payload\_t**

```
typedef struct CFE_EVS_ShortEventTlm_Payload CFE_EVS_ShortEventTlm_Payload_t
```

**Name** Event Message Telemetry Packet (Short format)

**12.68.3.42 CFE\_EVS\_ShortEventTlm\_t**

```
typedef struct CFE_EVS_ShortEventTlm CFE_EVS_ShortEventTlm_t
```

**12.68.3.43 CFE\_EVS\_WriteAppDataFileCmd\_t**

```
typedef struct CFE_EVS_WriteAppDataFileCmd CFE_EVS_WriteAppDataFileCmd_t
```

Write Event Services Application Information to File Command.

**12.68.3.44 CFE\_EVS\_WriteLogFileCmd\_t**

```
typedef struct CFE_EVS_WriteLogFileCmd CFE_EVS_WriteLogFileCmd_t
```

Write Event Log to File Command.

**12.69 cfe/modules/msg/fsw/inc/ccsds\_hdr.h File Reference**

```
#include "common_types.h"
```

## Data Structures

- struct [CCSDS\\_PrimaryHeader](#)  
*CCSDS packet primary header.*
- struct [CCSDS\\_ExtendedHeader](#)  
*CCSDS packet extended header.*

## Typedefs

- typedef struct [CCSDS\\_PrimaryHeader](#) CCSDS\_PrimaryHeader\_t  
*CCSDS packet primary header.*
- typedef struct [CCSDS\\_ExtendedHeader](#) CCSDS\_ExtendedHeader\_t  
*CCSDS packet extended header.*

### 12.69.1 Detailed Description

Define CCSDS packet header types

- Avoid direct access for portability, use APIs
- Used to construct message structures

### 12.69.2 Typedef Documentation

#### 12.69.2.1 CCSDS\_ExtendedHeader\_t

```
typedef struct CCSDS_ExtendedHeader CCSDS_ExtendedHeader_t
```

CCSDS packet extended header.

#### 12.69.2.2 CCSDS\_PrimaryHeader\_t

```
typedef struct CCSDS_PrimaryHeader CCSDS_PrimaryHeader_t
```

CCSDS packet primary header.

## 12.70 cfe/modules/resourceid/fsw/inc/cfe\_core\_resourceid\_basevalues.h File Reference

```
#include "cfe_resourceid_basevalue.h"
```

## Enumerations

- enum {
   
`CFE_RESOURCEID_ES_TASKID_BASE_OFFSET = OS_OBJECT_TYPE_OS_TASK, CFE_RESOURCEID_ES_APPID_BASE_OFFSET = OS_OBJECT_TYPE_USER + 1, CFE_RESOURCEID_ES_LIBID_BASE_OFFSET = OS_OBJECT_TYPE_USER + 2, CFE_RESOURCEID_ES_COUNTID_BASE_OFFSET = OS_OBJECT_TYPE_USER + 3,`
  
`CFE_RESOURCEID_ES_POOLID_BASE_OFFSET = OS_OBJECT_TYPE_USER + 4, CFE_RESOURCEID_ES_CDSBLOCKID_BASE_OFFSET = OS_OBJECT_TYPE_USER + 5, CFE_RESOURCEID_SB_PIPEID_RESOURCE_BASE_OFFSET = OS_OBJECT_TYPE_USER + 6, CFE_RESOURCEID_CONFIGID_BASE_OFFSET = OS_OBJECT_TYPE_USER + 7 }`
- enum {
   
`CFE_ES_TASKID_BASE = CFE_RESOURCEID_MAKE_BASE(CFE_RESOURCEID_ES_TASKID_BASE_OFFSET), CFE_ES_APPID_BASE = CFE_RESOURCEID_MAKE_BASE(CFE_RESOURCEID_ES_APPID_BASE_OFFSET), CFE_ES_LIBID_BASE = CFE_RESOURCEID_MAKE_BASE(CFE_RESOURCEID_ES_LIBID_BASE_OFFSET), CFE_ES_COUNTID_BASE = CFE_RESOURCEID_MAKE_BASE(CFE_RESOURCEID_ES_COUNTID_BASE_OFFSET),`
  
`CFE_ES_POOLID_BASE = CFE_RESOURCEID_MAKE_BASE(CFE_RESOURCEID_ES_POOLID_BASE_OFFSET), CFE_ES_CDSBLOCKID_BASE = CFE_RESOURCEID_MAKE_BASE(CFE_RESOURCEID_ES_CD_BLOCKID_BASE_OFFSET), CFE_SB_PIPEID_BASE = CFE_RESOURCEID_MAKE_BASE(CFE_RESOURCEID_SB_PIPEID_RESOURCE_BASE_OFFSET), CFE_CONFIGID_BASE = CFE_RESOURCEID_MAKE_BASE(CFE_RESOURCEID_CONFIGID_BASE_OFFSET) }`

### 12.70.1 Detailed Description

Contains CFE internal prototypes and definitions related to resource management and related CFE resource IDs.

A CFE ES Resource ID is a common way to identify CFE-managed resources such as apps, tasks, counters, memory pools, CDS blocks, and other entities.

## 12.71 cfe/modules/resourceid/fsw/inc/cfe\_resourceid\_basevalue.h File Reference

```
#include "cfe_resourceid_typedef.h"
#include "osapi-idmap.h"
```

## Macros

- #define CFE\_RESOURCEID\_SHIFT OS\_OBJECT\_TYPE\_SHIFT
- #define CFE\_RESOURCEID\_MAX OS\_OBJECT\_INDEX\_MASK
- #define CFE\_RESOURCEID\_MAKE\_BASE(offset) (CFE\_RESOURCEID\_MARK | ((offset) << CFE\_RESOURCEID\_SHIFT))

*A macro to generate a CFE resource ID base value from an offset.*

### 12.71.1 Detailed Description

An implementation of CFE resource ID base values/limits that will be compatible with OSAL IDs. This is intended as a transitional tool to provide runtime value uniqueness, particularly when the "simple" (compatible) resource ID implementation is used. In this mode, compiler type checking is disabled, and so OSAL IDs can be silently interchanged with CFE IDs.

However, by ensuring uniqueness in the runtime values, any ID handling errors may at least be detectable at runtime.

This still works fine with the "strict" resource ID option, but is less important as the compiler type checking should prevent this type of error before the code even runs.

The downside to this implementation is that it has a dependency on the OSAL ID structure.

### 12.71.2 Macro Definition Documentation

#### 12.71.2.1 CFE\_RESOURCEID\_MAKE\_BASE

```
#define CFE_RESOURCEID_MAKE_BASE( offset ) (CFE_RESOURCEID_MARK | ((offset) << CFE_RESOURCEID_SHIFT))
```

A macro to generate a CFE resource ID base value from an offset.

Each CFE ID range is effectively an extension of OSAL ID ranges by starting at OS\_OBJECT\_TYPE\_USER.

Definition at line 73 of file cfe\_resourceid\_basevalue.h.

#### 12.71.2.2 CFE\_RESOURCEID\_MAX

```
#define CFE_RESOURCEID_MAX OS_OBJECT_INDEX_MASK
```

Definition at line 65 of file cfe\_resourceid\_basevalue.h.

#### 12.71.2.3 CFE\_RESOURCEID\_SHIFT

```
#define CFE_RESOURCEID_SHIFT OS_OBJECT_TYPE_SHIFT
```

Definition at line 64 of file cfe\_resourceid\_basevalue.h.

## 12.72 cfe/modules/sb/fsw/inc/cfe\_sb\_events.h File Reference

### Macros

#### SB event IDs

- #define `CFE_SB_INIT_EID` 1  
*SB Initialization Event ID.*
- #define `CFE_SB_CR_PIPE_BAD_ARG_EID` 2  
*SB Create Pipe API Bad Argument Event ID.*
- #define `CFE_SB_MAX_PIPES_MET_EID` 3  
*SB Create Pipe API Max Pipes Exceeded Event ID.*
- #define `CFE_SB_CR_PIPE_ERR_EID` 4  
*SB Create Pipe API Queue Create Failure Event ID.*
- #define `CFE_SB_PIPE_ADDED_EID` 5  
*SB Create Pipe API Success Event ID.*
- #define `CFE_SB_SUB_ARG_ERR_EID` 6  
*SB Subscribe API Bad Argument Event ID.*
- #define `CFE_SB_DUP_SUBSCRIP_EID` 7  
*SB Subscribe API Duplicate MsgId Subscription Event ID.*
- #define `CFE_SB_MAX_MSGS_MET_EID` 8  
*SB Subscribe API Max Subscriptions Exceeded Event ID.*
- #define `CFE_SB_MAX_DESTS_MET_EID` 9  
*SB Subscribe API Max Destinations Exceeded Event ID.*
- #define `CFE_SB_SUBSCRIPTION_RCVD_EID` 10  
*SB Subscribe API Success Event ID.*
- #define `CFE_SB_UNSUB_ARG_ERR_EID` 11  
*SB Unsubscribe API Bad Argument Event ID.*
- #define `CFE_SB_UNSUB_NO_SUBS_EID` 12  
*SB Unsubscribe API No MsgId Subscription Event ID.*
- #define `CFE_SB_SEND_BAD_ARG_EID` 13  
*SB Transmit API Bad Argument Event ID.*
- #define `CFE_SB_SEND_NO_SUBS_EID` 14  
*SB Transmit API No MsgId Subscribers Event ID.*
- #define `CFE_SB_MSG_TOO_BIG_EID` 15  
*SB Transmit API Message Size Limit Exceeded Event ID.*
- #define `CFE_SB_GET_BUF_ERR_EID` 16  
*SB Transmit API Buffer Request Failure Event ID.*
- #define `CFE_SB_MSGID_LIM_ERR_EID` 17  
*SB Transmit API MsgId Pipe Limit Exceeded Event ID.*
- #define `CFE_SB_RCV_BAD_ARG_EID` 18  
*SB Receive Buffer API Bad Argument Event ID.*
- #define `CFE_SB_BAD_PIPEID_EID` 19  
*SB Receive Buffer API Invalid Pipe Event ID.*
- #define `CFE_SB_DEST_BLK_ERR_EID` 20  
*SB Subscribe API Get Destination Block Failure Event ID.*
- #define `CFE_SB_SEND_INV_MSGID_EID` 21  
*SB Transmit API Invalid MsgId Event ID.*
- #define `CFE_SB_SUBSCRIPTION_RPT_EID` 22  
*SB Subscription Report Sent Event ID.*
- #define `CFE_SB_HASHCOLLISION_EID` 23  
*SB Subscribe API Message Table Hash Collision Event ID.*
- #define `CFE_SB_Q_FULL_ERR_EID` 25  
*SB Transmit API Pipe Overflow Event ID.*

- #define [CFE\\_SB\\_Q\\_WR\\_ERR\\_EID](#) 26  
    *SB Transmit API Queue Write Failure Event ID.*
- #define [CFE\\_SB\\_Q\\_RD\\_ERR\\_EID](#) 27  
    *SB Transmit API Queue Read Failure Event ID.*
- #define [CFE\\_SB\\_CMD0\\_RCVD\\_EID](#) 28  
    *SB No-op Command Success Event ID.*
- #define [CFE\\_SB\\_CMD1\\_RCVD\\_EID](#) 29  
    *SB Reset Counters Command Success Event ID.*
- #define [CFE\\_SB SND\\_STATS\\_EID](#) 32  
    *SB Send Statistics Command Success Event ID.*
- #define [CFE\\_SB\\_ENBL RTE1\\_EID](#) 33  
    *SB Enable Route Command Invalid MsgId/PipeID Pair Event ID.*
- #define [CFE\\_SB\\_ENBL RTE2\\_EID](#) 34  
    *SB Enable Route Command Success Event ID.*
- #define [CFE\\_SB\\_ENBL RTE3\\_EID](#) 35  
    *SB Enable Route Command Invalid MsgId or Pipe Event ID.*
- #define [CFE\\_SB\\_DSBL RTE1\\_EID](#) 36  
    *SB Disable Route Command Invalid MsgId/PipeID Pair Event ID.*
- #define [CFE\\_SB\\_DSBL RTE2\\_EID](#) 37  
    *SB Disable Route Command Success Event ID.*
- #define [CFE\\_SB\\_DSBL RTE3\\_EID](#) 38  
    *SB Disable Route Command Invalid MsgId or Pipe Event ID.*
- #define [CFE\\_SB SND RTG\\_EID](#) 39  
    *SB File Write Success Event ID.*
- #define [CFE\\_SB SND RTG\\_ERR1\\_EID](#) 40  
    *SB File Write Create File Failure Event ID.*
- #define [CFE\\_SB\\_BAD\\_CMD\\_CODE\\_EID](#) 42  
    *SB Invalid Command Code Received Event ID.*
- #define [CFE\\_SB\\_BAD\\_MSGID\\_EID](#) 43  
    *SB Invalid Message ID Received Event ID.*
- #define [CFE\\_SB\\_FULL\\_SUB\\_PKT\\_EID](#) 44  
    *SB Send Previous Subscriptions Command Full Packet Sent Event ID.*
- #define [CFE\\_SB\\_PART\\_SUB\\_PKT\\_EID](#) 45  
    *SB Send Previous Subscriptions Command Partial Packet Sent Event ID.*
- #define [CFE\\_SB\\_DEL\\_PIPE\\_ERR1\\_EID](#) 46  
    *SB Pipe Delete API Bad Argument Event ID.*
- #define [CFE\\_SB\\_PIPE\\_DELETED\\_EID](#) 47  
    *SB Pipe Delete API Success Event ID.*
- #define [CFE\\_SB\\_SUBSCRIPTION\\_REMOVED\\_EID](#) 48  
    *SB Unsubscribe API Success Event ID.*
- #define [CFE\\_SB\\_FILEWRITE\\_ERR\\_EID](#) 49  
    *SB File Write Failed Event ID.*
- #define [CFE\\_SB\\_SUB\\_INV\\_PIPE\\_EID](#) 50  
    *SB Subscribe API Invalid Pipe Event ID.*
- #define [CFE\\_SB\\_SUB\\_INV\\_CALLER\\_EID](#) 51  
    *SB Subscribe API Not Owner Event ID.*
- #define [CFE\\_SB\\_UNSUB\\_INV\\_PIPE\\_EID](#) 52  
    *SB Unsubscribe API Invalid Pipe Event ID.*
- #define [CFE\\_SB\\_UNSUB\\_INV\\_CALLER\\_EID](#) 53  
    *SB Unsubscribe API Not Owner Event ID.*
- #define [CFE\\_SB\\_DEL\\_PIPE\\_ERR2\\_EID](#) 54  
    *SB Delete Pipe API Not Owner Event ID.*
- #define [CFE\\_SB\\_SETPIPEOPTS\\_ID\\_ERR\\_EID](#) 55  
    *SB Set Pipe Opts API Invalid Pipe Event ID.*
- #define [CFE\\_SB\\_SETPIPEOPTS\\_OWNER\\_ERR\\_EID](#) 56  
    *SB Set Pipe Opts API Invalid Pipe Event ID.*

- #define [CFE\\_SB\\_SETPPIPEOPTS\\_EID](#) 57  
*SB Set Pipe Opt API Not Owner Event ID.*
- #define [CFE\\_SB\\_GETPIPEOPTS\\_ID\\_ERR\\_EID](#) 58  
*SB Set Pipe Opt API Success Event ID.*
- #define [CFE\\_SB\\_GETPIPEOPTS\\_PTR\\_ERR\\_EID](#) 59  
*SB Get Pipe Opt API Invalid Pipe Event ID.*
- #define [CFE\\_SB\\_GETPIPEOPTS\\_EID](#) 60  
*SB Get Pipe Opt API Invalid Pointer Event ID.*
- #define [CFE\\_SB\\_GETPIPEOPTS\\_NAME\\_EID](#) 62  
*SB Get Pipe Opt API Success Event ID.*
- #define [CFE\\_SB\\_GETPIPEOPTS\\_NULL\\_PTR\\_EID](#) 63  
*SB Get Pipe Opt API Invalid Pointer Event ID.*
- #define [CFE\\_SB\\_GETPIPEOPTS\\_ID\\_ERR\\_EID](#) 64  
*SB Get Pipe Name API Invalid Pipe or Resource Event ID.*
- #define [CFE\\_SB\\_GETPIPEIDBYNAME\\_EID](#) 65  
*SB Get Pipe ID By Name API Success Event ID.*
- #define [CFE\\_SB\\_GETPIPEIDBYNAME\\_NULL\\_ERR\\_EID](#) 66  
*SB Get Pipe ID By Name API Invalid Pointer Event ID.*
- #define [CFE\\_SB\\_GETPIPEIDBYNAME\\_NAME\\_ERR\\_EID](#) 67  
*SB Get Pipe ID By Name API Name Not Found Or ID Not Matched Event ID.*
- #define [CFE\\_SB\\_LEN\\_ERR\\_EID](#) 68  
*SB Invalid Command Length Event ID.*
- #define [CFE\\_SB\\_CR\\_PIPE\\_NAME\\_TAKEN\\_EID](#) 69  
*SB Create Pipe API Name Taken Event ID.*
- #define [CFE\\_SB\\_CR\\_PIPE\\_NO\\_FREE\\_EID](#) 70  
*SB Create Pipe API Queues Exhausted Event ID.*

### 12.72.1 Detailed Description

cFE Software Bus Services Event IDs

### 12.72.2 Macro Definition Documentation

#### 12.72.2.1 CFE\_SB\_BAD\_CMD\_CODE\_EID

```
#define CFE_SB_BAD_CMD_CODE_EID 42
```

SB Invalid Command Code Received Event ID.

Type: ERROR

Cause:

Invalid command code for message ID [CFE\\_SB\\_CMD\\_MID](#) or [CFE\\_SB\\_SUB\\_RPT\\_CTRL\\_MID](#) received on the SB message pipe. OVERLOADED

Definition at line 461 of file cfe\_sb\_events.h.

### 12.72.2.2 CFE\_SB\_BAD\_MSGID\_EID

```
#define CFE_SB_BAD_MSGID_EID 43
```

SB Invalid Message ID Received Event ID.

Type: ERROR

Cause:

Invalid message ID received on the SB message pipe.

Definition at line 472 of file cfe\_sb\_events.h.

### 12.72.2.3 CFE\_SB\_BAD\_PIPEID\_EID

```
#define CFE_SB_BAD_PIPEID_EID 19
```

SB Receive Buffer API Invalid Pipe Event ID.

Type: ERROR

Cause:

[CFE\\_SB\\_ReceiveBuffer](#) API failure due to an invalid Pipe ID.

Definition at line 244 of file cfe\_sb\_events.h.

### 12.72.2.4 CFE\_SB\_CMD0\_RCVD\_EID

```
#define CFE_SB_CMD0_RCVD_EID 28
```

SB No-op Command Success Event ID.

Type: INFORMATION

Cause:

[SB NO-OP Command](#) success.

Definition at line 335 of file cfe\_sb\_events.h.

### 12.72.2.5 CFE\_SB\_CMD1\_RCVD\_EID

```
#define CFE_SB_CMD1_RCVD_EID 29
```

SB Reset Counters Command Success Event ID.

Type: DEBUG

Cause:

[SB Reset Counters Command](#) success.

Definition at line 346 of file cfe\_sb\_events.h.

### 12.72.2.6 CFE\_SB\_CR\_PIPE\_BAD\_ARG\_EID

```
#define CFE_SB_CR_PIPE_BAD_ARG_EID 2
```

SB Create Pipe API Bad Argument Event ID.

Type: ERROR

Cause:

[CFE\\_SB\\_CreatePipe](#) API failure due to a bad input argument.

Definition at line 53 of file cfe\_sb\_events.h.

### 12.72.2.7 CFE\_SB\_CR\_PIPE\_ERR\_EID

```
#define CFE_SB_CR_PIPE_ERR_EID 4
```

SB Create Pipe API Queue Create Failure Event ID.

Type: ERROR

Cause:

[CFE\\_SB\\_CreatePipe](#) API failure creating the queue.

Definition at line 75 of file cfe\_sb\_events.h.

#### 12.72.2.8 CFE\_SB\_CR\_PIPE\_NAME\_TAKEN\_EID

```
#define CFE_SB_CR_PIPE_NAME_TAKEN_EID 69
```

SB Create Pipe API Name Taken Event ID.

Type: ERROR

Cause:

[CFE\\_SB\\_CreatePipe](#) API failure due to pipe name taken.

Definition at line 750 of file cfe\_sb\_events.h.

#### 12.72.2.9 CFE\_SB\_CR\_PIPE\_NO\_FREE\_EID

```
#define CFE_SB_CR_PIPE_NO_FREE_EID 70
```

SB Create Pipe API Queues Exhausted Event ID.

Type: ERROR

Cause:

[CFE\\_SB\\_CreatePipe](#) API failure due to no free queues.

Definition at line 761 of file cfe\_sb\_events.h.

#### 12.72.2.10 CFE\_SB\_DEL\_PIPE\_ERR1\_EID

```
#define CFE_SB_DEL_PIPE_ERR1_EID 46
```

SB Pipe Delete API Bad Argument Event ID.

Type: ERROR

Cause:

An SB Delete Pipe API failed due to an invalid input argument.

Definition at line 507 of file cfe\_sb\_events.h.

**12.72.2.11 CFE\_SB\_DEL\_PIPE\_ERR2\_EID**

```
#define CFE_SB_DEL_PIPE_ERR2_EID 54
```

SB Delete Pipe API Not Owner Event ID.

Type: ERROR

Cause:

An SB Delete Pipe API failed due to not being the pipe owner.

Definition at line 595 of file cfe\_sb\_events.h.

**12.72.2.12 CFE\_SB\_DEST\_BLK\_ERR\_EID**

```
#define CFE_SB_DEST_BLK_ERR_EID 20
```

SB Subscribe API Get Destination Block Failure Event ID.

Type: ERROR

Cause:

An SB Subscribe API call failed to get a destination block.

Definition at line 255 of file cfe\_sb\_events.h.

**12.72.2.13 CFE\_SB\_DSBL RTE1\_EID**

```
#define CFE_SB_DSBL RTE1_EID 36
```

SB Disable Route Command Invalid MsgId/Pipeld Pair Event ID.

Type: ERROR

Cause:

[SB Disable Route Command](#) failure due to the Message ID not being subscribed to the pipe.

Definition at line 404 of file cfe\_sb\_events.h.

**12.72.2.14 CFE\_SB\_DSBL RTE2\_EID**

```
#define CFE_SB_DSBL RTE2_EID 37
```

SB Disable Route Command Success Event ID.

Type: DEBUG

Cause:

[SB Disable Route Command](#) success.

Definition at line 415 of file cfe\_sb\_events.h.

**12.72.2.15 CFE\_SB\_DSBL RTE3\_EID**

```
#define CFE_SB_DSBL RTE3_EID 38
```

SB Disable Route Command Invalid MsgId or Pipe Event ID.

Type: ERROR

Cause:

[SB Disable Route Command](#) failure due to an invalid MsgId or Pipe.

Definition at line 427 of file cfe\_sb\_events.h.

**12.72.2.16 CFE\_SB\_DUP\_SUBSCRIPT\_EID**

```
#define CFE_SB_DUP_SUBSCRIPT_EID 7
```

SB Subscribe API Duplicate MsgId Subscription Event ID.

Type: INFORMATION

Cause:

An SB Subscribe API was called with a Message ID that was already subscribed on the pipe on the pipe.

Definition at line 109 of file cfe\_sb\_events.h.

**12.72.2.17 CFE\_SB\_ENBL RTE1\_EID**

```
#define CFE_SB_ENBL RTE1_EID 33
```

SB Enable Route Command Invalid MsgId/PipeID Pair Event ID.

Type: **ERROR**

Cause:

[SB Enable Route Command](#) failure due to the Message ID not being subscribed to the pipe.

Definition at line 369 of file cfe\_sb\_events.h.

**12.72.2.18 CFE\_SB\_ENBL RTE2\_EID**

```
#define CFE_SB_ENBL RTE2_EID 34
```

SB Enable Route Command Success Event ID.

Type: **DEBUG**

Cause:

[SB Enable Route Command](#) success.

Definition at line 380 of file cfe\_sb\_events.h.

**12.72.2.19 CFE\_SB\_ENBL RTE3\_EID**

```
#define CFE_SB_ENBL RTE3_EID 35
```

SB Enable Route Command Invalid MsgId or Pipe Event ID.

Type: **ERROR**

Cause:

[SB Enable Route Command](#) failure due to an invalid MsgId or Pipe.

Definition at line 392 of file cfe\_sb\_events.h.

**12.72.2.20 CFE\_SB\_FILEWRITE\_ERR\_EID**

```
#define CFE_SB_FILEWRITE_ERR_EID 49
```

SB File Write Failed Event ID.

Type: ERROR

Cause:

An SB file write failure encountered when writing to the file.

Definition at line 540 of file cfe\_sb\_events.h.

**12.72.2.21 CFE\_SB\_FULL\_SUB\_PKT\_EID**

```
#define CFE_SB_FULL_SUB_PKT_EID 44
```

SB Send Previous Subscriptions Command Full Packet Sent Event ID.

Type: DEBUG

Cause:

[SB Send Previous Subscriptions Command](#) processing sent a full subscription packet.

Definition at line 484 of file cfe\_sb\_events.h.

**12.72.2.22 CFE\_SB\_GET\_BUF\_ERR\_EID**

```
#define CFE_SB_GET_BUF_ERR_EID 16
```

SB Transmit API Buffer Request Failure Event ID.

Type: ERROR

Cause:

An SB Transmit API call buffer request failed.

Definition at line 210 of file cfe\_sb\_events.h.

**12.72.2.23 CFE\_SB\_GETPIPEIDBYNAME\_EID**

```
#define CFE_SB_GETPIPEIDBYNAME_EID 65
```

SB Get Pipe ID By Name API Success Event ID.

Type: DEBUG

Cause:

[CFE\\_SB\\_GetPipeIdByName](#) success.

Definition at line 705 of file cfe\_sb\_events.h.

**12.72.2.24 CFE\_SB\_GETPIPEIDBYNAME\_NAME\_ERR\_EID**

```
#define CFE_SB_GETPIPEIDBYNAME_NAME_ERR_EID 67
```

SB Get Pipe ID By Name API Name Not Found Or ID Not Matched Event ID.

Type: ERROR

Cause:

[CFE\\_SB\\_GetPipeIdByName](#) failure due to name not found or ID mismatch. OVERLOADED

Definition at line 727 of file cfe\_sb\_events.h.

**12.72.2.25 CFE\_SB\_GETPIPEIDBYNAME\_NULL\_ERR\_EID**

```
#define CFE_SB_GETPIPEIDBYNAME_NULL_ERR_EID 66
```

SB Get Pipe ID By Name API Invalid Pointer Event ID.

Type: ERROR

Cause:

[CFE\\_SB\\_GetPipeIdByName](#) failure due to invalid pointer.

Definition at line 716 of file cfe\_sb\_events.h.

**12.72.2.26 CFE\_SB\_GETPIPENAME\_EID**

```
#define CFE_SB_GETPIPENAME_EID 62
```

SB Get Pipe Name API Success Event ID.

Type: DEBUG

Cause:

[CFE\\_SB\\_GetPipeName](#) success.

Definition at line 672 of file cfe\_sb\_events.h.

**12.72.2.27 CFE\_SB\_GETPIPENAME\_ID\_ERR\_EID**

```
#define CFE_SB_GETPIPENAME_ID_ERR_EID 64
```

SB Get Pipe Name API Invalid Pipe or Resource Event ID.

Type: ERROR

Cause:

[CFE\\_SB\\_GetPipeName](#) failure due to invalid pipe ID or failure in retrieving resource name. OVERLOADED

Definition at line 694 of file cfe\_sb\_events.h.

**12.72.2.28 CFE\_SB\_GETPIPENAME\_NULL\_PTR\_EID**

```
#define CFE_SB_GETPIPENAME_NULL_PTR_EID 63
```

SB Get Pipe Name API Invalid Pointer Event ID.

Type: ERROR

Cause:

[CFE\\_SB\\_GetPipeName](#) failure due to invalid pointer.

Definition at line 683 of file cfe\_sb\_events.h.

**12.72.2.29 CFE\_SB\_GETPIPEOPTS\_EID**

```
#define CFE_SB_GETPIPEOPTS_EID 60
```

SB Get Pipe Opt API Success Event ID.

Type: DEBUG

Cause:

[CFE\\_SB\\_GetPipeOpts](#) success.

Definition at line 661 of file `cfe_sb_events.h`.

**12.72.2.30 CFE\_SB\_GETPIPEOPTS\_ID\_ERR\_EID**

```
#define CFE_SB_GETPIPEOPTS_ID_ERR_EID 58
```

SB Get Pipe Opt API Invalid Pipe Event ID.

Type: ERROR

Cause:

[CFE\\_SB\\_GetPipeOpts](#) failure due to invalid pipe ID.

Definition at line 639 of file `cfe_sb_events.h`.

**12.72.2.31 CFE\_SB\_GETPIPEOPTS\_PTR\_ERR\_EID**

```
#define CFE_SB_GETPIPEOPTS_PTR_ERR_EID 59
```

SB Get Pipe Opt API Invalid Pointer Event ID.

Type: ERROR

Cause:

[CFE\\_SB\\_GetPipeOpts](#) failure due to invalid pointer.

Definition at line 650 of file `cfe_sb_events.h`.

### 12.72.2.32 CFE\_SB\_HASHCOLLISION\_EID

```
#define CFE_SB_HASHCOLLISION_EID 23
```

SB Subscribe API Message Table Hash Collision Event ID.

Type: DEBUG

Cause:

An SB Subscribe API call caused a message table hash collision, which will impact message transmission performance. This can be resolved by deconflicting MsgId values or increasing [CFE\\_PLATFORM\\_SB\\_MAX\\_MSG\\_IDS](#).

Definition at line 290 of file cfe\_sb\_events.h.

### 12.72.2.33 CFE\_SB\_INIT\_EID

```
#define CFE_SB_INIT_EID 1
```

SB Initialization Event ID.

Type: INFORMATION

Cause:

Software Bus Services Task initialization complete.

Definition at line 42 of file cfe\_sb\_events.h.

### 12.72.2.34 CFE\_SB\_LEN\_ERR\_EID

```
#define CFE_SB_LEN_ERR_EID 68
```

SB Invalid Command Length Event ID.

Type: ERROR

Cause:

Invalid length for the command code in message ID [CFE\\_SB\\_CMD\\_MID](#) or [CFE\\_SB\\_SUB\\_RPT\\_CTRL\\_MID](#) received on the SB message pipe.

Definition at line 739 of file cfe\_sb\_events.h.

**12.72.2.35 CFE\_SB\_MAX\_DESTS\_MET\_EID**

```
#define CFE_SB_MAX_DESTS_MET_EID 9
```

SB Subscribe API Max Destinations Exceeded Event ID.

Type: ERROR

Cause:

An SB Subscribe API was called with a message id that already has the maximum allowed number of destinations.

Definition at line 133 of file cfe\_sb\_events.h.

**12.72.2.36 CFE\_SB\_MAX\_MSGS\_MET\_EID**

```
#define CFE_SB_MAX_MSGS_MET_EID 8
```

SB Subscribe API Max Subscriptions Exceeded Event ID.

Type: ERROR

Cause:

An SB Subscribe API was called on a pipe that already has the maximum allowed number of subscriptions.

Definition at line 121 of file cfe\_sb\_events.h.

**12.72.2.37 CFE\_SB\_MAX\_PIPES\_MET\_EID**

```
#define CFE_SB_MAX_PIPES_MET_EID 3
```

SB Create Pipe API Max Pipes Exceeded Event ID.

Type: ERROR

Cause:

[CFE\\_SB\\_CreatePipe](#) API failure to do maximum number of pipes being exceeded.

Definition at line 64 of file cfe\_sb\_events.h.

**12.72.2.38 CFE\_SB\_MSG\_TOO\_BIG\_EID**

```
#define CFE_SB_MSG_TOO_BIG_EID 15
```

SB Transmit API Message Size Limit Exceeded Event ID.

Type: **ERROR**

Cause:

An SB Transmit API was called with a message that is too big.

Definition at line 199 of file cfe\_sb\_events.h.

**12.72.2.39 CFE\_SB\_MSGID\_LIM\_ERR\_EID**

```
#define CFE_SB_MSGID_LIM_ERR_EID 17
```

SB Transmit API MsgId Pipe Limit Exceeded Event ID.

Type: **ERROR**

Cause:

An SB Transmit API call failed to deliver the MsgId to a pipe due to the limit for the number of messages with that MsgId for that pipe being exceeded.

Definition at line 222 of file cfe\_sb\_events.h.

**12.72.2.40 CFE\_SB\_PART\_SUB\_PKT\_EID**

```
#define CFE_SB_PART_SUB_PKT_EID 45
```

SB Send Previous Subscriptions Command Partial Packet Sent Event ID.

Type: **DEBUG**

Cause:

[SB Send Previous Subscriptions Command](#) processing sent a partial subscription packet.

Definition at line 496 of file cfe\_sb\_events.h.

**12.72.2.41 CFE\_SB\_PIPE\_ADDED\_EID**

```
#define CFE_SB_PIPE_ADDED_EID 5
```

SB Create Pipe API Success Event ID.

Type: DEBUG

Cause:

[CFE\\_SB\\_CreatePipe](#) API successfully completed.

Definition at line 86 of file `cfe_sb_events.h`.

**12.72.2.42 CFE\_SB\_PIPE\_DELETED\_EID**

```
#define CFE_SB_PIPE_DELETED_EID 47
```

SB Pipe Delete API Success Event ID.

Type: DEBUG

Cause:

An SB Delete Pipe API successfully completed.

Definition at line 518 of file `cfe_sb_events.h`.

**12.72.2.43 CFE\_SB\_Q\_FULL\_ERR\_EID**

```
#define CFE_SB_Q_FULL_ERR_EID 25
```

SB Transmit API Pipe Overflow Event ID.

Type: ERROR

Cause:

An SB Transmit API call failed to deliver the Message ID to a pipe due to the pipe queue being full.

Definition at line 302 of file `cfe_sb_events.h`.

**12.72.2.44 CFE\_SB\_Q\_RD\_ERR\_EID**

```
#define CFE_SB_Q_RD_ERR_EID 27
```

SB Transmit API Queue Read Failure Event ID.

Type: ERROR

Cause:

An SB Transmit API called failed due to a pipe queue read failure.

Definition at line 324 of file cfe\_sb\_events.h.

**12.72.2.45 CFE\_SB\_Q\_WR\_ERR\_EID**

```
#define CFE_SB_Q_WR_ERR_EID 26
```

SB Transmit API Queue Write Failure Event ID.

Type: ERROR

Cause:

An SB Transmit API call failed due to a pipe queue write failure.

Definition at line 313 of file cfe\_sb\_events.h.

**12.72.2.46 CFE\_SB\_RCV\_BAD\_ARG\_EID**

```
#define CFE_SB_RCV_BAD_ARG_EID 18
```

SB Receive Buffer API Bad Argument Event ID.

Type: ERROR

Cause:

[CFE\\_SB\\_ReceiveBuffer](#) API failure due to a bad input argument.

Definition at line 233 of file cfe\_sb\_events.h.

**12.72.2.47 CFE\_SB\_SEND\_BAD\_ARG\_EID**

```
#define CFE_SB_SEND_BAD_ARG_EID 13
```

SB Transmit API Bad Argument Event ID.

Type: ERROR

Cause:

An SB Transmit API failed due to an invalid input argument.

Definition at line 177 of file cfe\_sb\_events.h.

**12.72.2.48 CFE\_SB\_SEND\_INV\_MSGID\_EID**

```
#define CFE_SB_SEND_INV_MSGID_EID 21
```

SB Transmit API Invalid MsgId Event ID.

Type: ERROR

Cause:

An SB Transmit API was called with an invalid message ID.

Definition at line 266 of file cfe\_sb\_events.h.

**12.72.2.49 CFE\_SB\_SEND\_NO\_SUBS\_EID**

```
#define CFE_SB_SEND_NO_SUBS_EID 14
```

SB Transmit API No MsgId Subscribers Event ID.

Type: INFORMATION

Cause:

An SB Transmit API was called with a Message ID with no subscriptions.

Definition at line 188 of file cfe\_sb\_events.h.

**12.72.2.50 CFE\_SB\_SETPPIPEOPTS\_EID**

```
#define CFE_SB_SETPPIPEOPTS_EID 57
```

SB Set Pipe Opt API Success Event ID.

Type: DEBUG

Cause:

[CFE\\_SB\\_SetPipeOpt](#) success.

Definition at line 628 of file cfe\_sb\_events.h.

**12.72.2.51 CFE\_SB\_SETPPIPEOPTS\_ID\_ERR\_EID**

```
#define CFE_SB_SETPPIPEOPTS_ID_ERR_EID 55
```

SB Set Pipe Opt API Invalid Pipe Event ID.

Type: ERROR

Cause:

[CFE\\_SB\\_SetPipeOpt](#) API failure due to an invalid pipe ID

Definition at line 606 of file cfe\_sb\_events.h.

**12.72.2.52 CFE\_SB\_SETPPIPEOPTS\_OWNER\_ERR\_EID**

```
#define CFE_SB_SETPPIPEOPTS_OWNER_ERR_EID 56
```

SB Set Pipe Opt API Not Owner Event ID.

Type: ERROR

Cause:

[CFE\\_SB\\_SetPipeOpt](#) API failure due to not being the pipe owner.

Definition at line 617 of file cfe\_sb\_events.h.

**12.72.2.53 CFE\_SB SND RTG\_EID**

```
#define CFE_SB SND RTG_EID 39
```

SB File Write Success Event ID.

Type: DEBUG

Cause:

An SB file write successfully completed. OVERLOADED

Definition at line 438 of file cfe\_sb\_events.h.

**12.72.2.54 CFE\_SB SND RTG\_ERR1\_EID**

```
#define CFE_SB SND RTG_ERR1_EID 40
```

SB File Write Create File Failure Event ID.

Type: ERROR

Cause:

An SB file write failure due to file creation error. OVERLOADED

Definition at line 449 of file cfe\_sb\_events.h.

**12.72.2.55 CFE\_SB SND STATS\_EID**

```
#define CFE_SB SND STATS_EID 32
```

SB Send Statistics Command Success Event ID.

Type: DEBUG

Cause:

[SB Send Statistics Command](#) success.

Definition at line 357 of file cfe\_sb\_events.h.

**12.72.2.56 CFE\_SB\_SUB\_ARG\_ERR\_EID**

```
#define CFE_SB_SUB_ARG_ERR_EID 6
```

SB Subscribe API Bad Argument Event ID.

Type: ERROR

Cause:

An SB Subscribe API failed due to an invalid input argument.

Definition at line 97 of file cfe\_sb\_events.h.

**12.72.2.57 CFE\_SB\_SUB\_INV\_CALLER\_EID**

```
#define CFE_SB_SUB_INV_CALLER_EID 51
```

SB Subscribe API Not Owner Event ID.

Type: ERROR

Cause:

An SB Subscribe API failed due to not being the pipe owner.

Definition at line 562 of file cfe\_sb\_events.h.

**12.72.2.58 CFE\_SB\_SUB\_INV\_PIPE\_EID**

```
#define CFE_SB_SUB_INV_PIPE_EID 50
```

SB Subscribe API Invalid Pipe Event ID.

Type: ERROR

Cause:

An SB Subscribe API failed due to an invalid pipe ID.

Definition at line 551 of file cfe\_sb\_events.h.

**12.72.2.59 CFE\_SB\_SUBSCRIPTION\_RCVD\_EID**

```
#define CFE_SB_SUBSCRIPTION_RCVD_EID 10
```

SB Subscribe API Success Event ID.

Type: DEBUG

Cause:

An SB Subscribe API completed successfully.

Definition at line 144 of file cfe\_sb\_events.h.

**12.72.2.60 CFE\_SB\_SUBSCRIPTION\_REMOVED\_EID**

```
#define CFE_SB_SUBSCRIPTION_REMOVED_EID 48
```

SB Unsubscribe API Success Event ID.

Type: DEBUG

Cause:

An SB Unsubscribe API successfully completed.

Definition at line 529 of file cfe\_sb\_events.h.

**12.72.2.61 CFE\_SB\_SUBSCRIPTION\_RPT\_EID**

```
#define CFE_SB_SUBSCRIPTION_RPT_EID 22
```

SB Subscription Report Sent Event ID.

Type: DEBUG

Cause:

SB Subscription Report sent in response to a successful subscription.

Definition at line 277 of file cfe\_sb\_events.h.

**12.72.2.62 CFE\_SB\_UNSUB\_ARG\_ERR\_EID**

```
#define CFE_SB_UNSUB_ARG_ERR_EID 11
```

SB Unsubscribe API Bad Argument Event ID.

Type: ERROR

Cause:

An SB Unsubscribe API failed due to an invalid input argument.

Definition at line 155 of file cfe\_sb\_events.h.

**12.72.2.63 CFE\_SB\_UNSUB\_INV\_CALLER\_EID**

```
#define CFE_SB_UNSUB_INV_CALLER_EID 53
```

SB Unsubscribe API Not Owner Event ID.

Type: ERROR

Cause:

An SB Unsubscribe API failed due to not being the pipe owner.

Definition at line 584 of file cfe\_sb\_events.h.

**12.72.2.64 CFE\_SB\_UNSUB\_INV\_PIPE\_EID**

```
#define CFE_SB_UNSUB_INV_PIPE_EID 52
```

SB Unsubscribe API Invalid Pipe Event ID.

Type: ERROR

Cause:

An SB Unsubscribe API failed due to an invalid pipe ID.

Definition at line 573 of file cfe\_sb\_events.h.

#### 12.72.2.65 CFE\_SB\_UNSUB\_NO\_SUBS\_EID

```
#define CFE_SB_UNSUB_NO_SUBS_EID 12
```

SB Unsubscribe API No MsgId Subscription Event ID.

Type: INFORMATION

Cause:

An SB Unsubscribe API was called with a Message ID that wasn't subscribed on the pipe

Definition at line 166 of file cfe\_sb\_events.h.

## 12.73 cfe/modules/sb/fsw/inc/cfe\_sb\_msg.h File Reference

```
#include "common_types.h"
#include "cfe_msg_hdr.h"
#include "cfe_sb_extern_typedefs.h"
#include "cfe_es_extern_typedefs.h"
```

### Data Structures

- struct [CFE\\_SB\\_WriteFileInfoCmd\\_Payload](#)  
*Write File Info Command Payload.*
- struct [CFE\\_SB\\_WriteFileInfoCmd](#)  
*Write File Info Command.*
- struct [CFE\\_SB\\_RouteCmd\\_Payload](#)  
*Enable/Disable Route Command Payload.*
- struct [CFE\\_SB\\_RouteCmd](#)  
*Enable/Disable Route Command.*
- struct [CFE\\_SB\\_HousekeepingTlm\\_Payload](#)
- struct [CFE\\_SB\\_HousekeepingTlm](#)
- struct [CFE\\_SB\\_PipeDepthStats](#)  
*SB Pipe Depth Statistics.*
- struct [CFE\\_SB\\_PipeInfoEntry](#)  
*SB Pipe Information File Entry.*
- struct [CFE\\_SB\\_StatsTlm\\_Payload](#)
- struct [CFE\\_SB\\_StatsTlm](#)
- struct [CFE\\_SB\\_RoutingFileEntry](#)  
*SB Routing File Entry.*
- struct [CFE\\_SB\\_MsgMapFileEntry](#)  
*SB Map File Entry.*
- struct [CFE\\_SB\\_SingleSubscriptionTlm\\_Payload](#)
- struct [CFE\\_SB\\_SingleSubscriptionTlm](#)
- struct [CFE\\_SB\\_SubEntries](#)  
*SB Previous Subscriptions Entry.*
- struct [CFE\\_SB\\_AllSubscriptionsTlm\\_Payload](#)
- struct [CFE\\_SB\\_AllSubscriptionsTlm](#)

**Macros**

- #define CFE\_SB\_NOOP\_CC 0
- #define CFE\_SB\_RESET\_COUNTERS\_CC 1
- #define CFE\_SB\_SEND\_SB\_STATS\_CC 2
- #define CFE\_SB\_WRITE\_ROUTING\_INFO\_CC 3
- #define CFE\_SB\_ENABLE\_ROUTE\_CC 4
- #define CFE\_SB\_DISABLE\_ROUTE\_CC 5
- #define CFE\_SB\_WRITE\_PIPE\_INFO\_CC 7
- #define CFE\_SB\_WRITE\_MAP\_INFO\_CC 8
- #define CFE\_SB\_ENABLE\_SUB\_REPORTING\_CC 9
- #define CFE\_SB\_DISABLE\_SUB\_REPORTING\_CC 10
- #define CFE\_SB\_SEND\_PREV\_SUBS\_CC 11

**Typedefs**

- typedef CFE\_MSG\_CommandHeader\_t CFE\_SB\_NoopCmd\_t
- typedef CFE\_MSG\_CommandHeader\_t CFE\_SB\_ResetCountersCmd\_t
- typedef CFE\_MSG\_CommandHeader\_t CFE\_SB\_EnableSubReportingCmd\_t
- typedef CFE\_MSG\_CommandHeader\_t CFE\_SB\_DisableSubReportingCmd\_t
- typedef CFE\_MSG\_CommandHeader\_t CFE\_SB\_SendSbStatsCmd\_t
- typedef CFE\_MSG\_CommandHeader\_t CFE\_SB\_SendPrevSubsCmd\_t
- typedef struct CFE\_SB\_WriteFileInfoCmd\_Payload CFE\_SB\_WriteFileInfoCmd\_Payload\_t  
*Write File Info Command Payload.*
- typedef struct CFE\_SB\_WriteFileInfoCmd CFE\_SB\_WriteFileInfoCmd\_t  
*Write File Info Command.*
- typedef CFE\_SB\_WriteFileInfoCmd\_t CFE\_SB\_WriteRoutingInfoCmd\_t
- typedef CFE\_SB\_WriteFileInfoCmd\_t CFE\_SB\_WritePipeInfoCmd\_t
- typedef CFE\_SB\_WriteFileInfoCmd\_t CFE\_SB\_WriteMapInfoCmd\_t
- typedef struct CFE\_SB\_RouteCmd\_Payload CFE\_SB\_RouteCmd\_Payload\_t  
*Enable/Disable Route Command Payload.*
- typedef struct CFE\_SB\_RouteCmd CFE\_SB\_RouteCmd\_t  
*Enable/Disable Route Command.*
- typedef CFE\_SB\_RouteCmd\_t CFE\_SB\_EnableRouteCmd\_t
- typedef CFE\_SB\_RouteCmd\_t CFE\_SB\_DisableRouteCmd\_t
- typedef struct CFE\_SB\_HousekeepingTlm\_Payload CFE\_SB\_HousekeepingTlm\_Payload\_t
- typedef struct CFE\_SB\_HousekeepingTlm CFE\_SB\_HousekeepingTlm\_t
- typedef struct CFE\_SB\_PipeDepthStats CFE\_SB\_PipeDepthStats\_t  
*SB Pipe Depth Statistics.*
- typedef struct CFE\_SB\_PipeInfoEntry CFE\_SB\_PipeInfoEntry\_t  
*SB Pipe Information File Entry.*
- typedef struct CFE\_SB\_StatsTlm\_Payload CFE\_SB\_StatsTlm\_Payload\_t
- typedef struct CFE\_SB\_StatsTlm CFE\_SB\_StatsTlm\_t
- typedef struct CFE\_SB\_RoutingFileEntry CFE\_SB\_RoutingFileEntry\_t  
*SB Routing File Entry.*
- typedef struct CFE\_SB\_MsgMapFileEntry CFE\_SB\_MsgMapFileEntry\_t  
*SB Map File Entry.*
- typedef struct CFE\_SB\_SingleSubscriptionTlm\_Payload CFE\_SB\_SingleSubscriptionTlm\_Payload\_t
- typedef struct CFE\_SB\_SingleSubscriptionTlm CFE\_SB\_SingleSubscriptionTlm\_t
- typedef struct CFE\_SB\_SubEntries CFE\_SB\_SubEntries\_t  
*SB Previous Subscriptions Entry.*
- typedef struct CFE\_SB\_AllSubscriptionsTlm\_Payload CFE\_SB\_AllSubscriptionsTlm\_Payload\_t
- typedef struct CFE\_SB\_AllSubscriptionsTlm CFE\_SB\_AllSubscriptionsTlm\_t

### 12.73.1 Detailed Description

Purpose: This header file contains structure definitions for all SB command and telemetry packets

Author: R.McGraw/SSI

### 12.73.2 Macro Definition Documentation

#### 12.73.2.1 CFE\_SB\_DISABLE\_ROUTE\_CC

```
#define CFE_SB_DISABLE_ROUTE_CC 5
```

**Name** Disable Software Bus Route

##### Description

This command will disable a particular destination. The destination is specified in terms of MsgID and PipeID. The MsgId and PipeID are parameters in the command. All destinations are enabled by default.

**Command Mnemonic(s)** \$sc\_\$cpu\_SB\_DisRoute

##### Command Structure

[CFE\\_SB\\_DisableRouteCmd\\_t](#)

##### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_SB\\_CMDPC](#) - command execution counter will increment
- View routing information [CFE\\_SB\\_WRITE\\_ROUTING\\_INFO\\_CC](#) to verify enable/disable state change
- The [CFE\\_SB\\_DSBL RTE2 EID](#) debug event message will be generated
- Destination will stop receiving messages

##### Error Conditions

This command may fail for the following reason(s):

- the MsgId or PipeId parameters do not pass validation
- the destination does not exist.

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_SB\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases. See [CFE\\_SB\\_DSBL RTE1 EID](#) or [CFE\\_SB\\_DSBL RTE3 EID](#)

##### Criticality

This command is not intended to be used in nominal conditions. It is possible to get into a state where a destination cannot be re-enabled without resetting the processor. For instance, sending this command with [CFE\\_SB\\_CM↔D\\_MID](#) and the SB\_Cmd\_Pipe would inhibit any ground commanding to the software bus until the processor was reset. There are similar problems that may occur when using this command.

Definition at line 281 of file cfe\_sb\_msg.h.

### 12.73.2.2 CFE\_SB\_DISABLE\_SUB\_REPORTING\_CC

```
#define CFE_SB_DISABLE_SUB_REPORTING_CC 10
```

**Name** Disable Subscription Reporting Command

#### Description

This command will disable subscription reporting and is intended to be used only by the CFS SBN (Software Bus Networking) Application. It is not intended to be sent from the ground or used by operations. When subscription reporting is enabled, SB will generate and send a software bus packet for each subscription received. The software bus packet that is sent contains the information received in the subscription API. This subscription report is needed by SBN if offboard routing is required.

**Command Mnemonic(s)** \$sc\_\$cpu\_SB\_DisSubRptg

#### Command Structure

[CFE\\_SB\\_DisableSubReportingCmd\\_t](#)

#### Command Verification

Successful execution of this command will result in the suppression of packets (with the [CFE\\_SB\\_ONESUB\\_TLM\\_MID](#) MsgId) for each subscription received by SB through the subscription APIs.

#### Error Conditions

None

#### Criticality

None

#### See also

[CFE\\_SB\\_SingleSubscriptionTlm\\_t](#), [CFE\\_SB\\_ENABLE\\_SUB\\_REPORTING\\_CC](#), [CFE\\_SB\\_SEND\\_PREV\\_SUB\\_CC](#)

Definition at line 438 of file cfe\_sb\_msg.h.

### 12.73.2.3 CFE\_SB\_ENABLE\_ROUTE\_CC

```
#define CFE_SB_ENABLE_ROUTE_CC 4
```

**Name** Enable Software Bus Route

#### Description

This command will enable a particular destination. The destination is specified in terms of MsgID and PipeID. The MsgId and PipeID are parameters in the command. All destinations are enabled by default. This command is needed only after a [CFE\\_SB\\_DISABLE\\_ROUTE\\_CC](#) command is used.

**Command Mnemonic(s)** \$sc\_\$cpu\_SB\_EnaRoute

#### Command Structure

[CFE\\_SB\\_EnableRouteCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_SB\\_CMDPC](#) - command execution counter will increment
- View routing information [CFE\\_SB\\_WRITE\\_ROUTING\\_INFO\\_CC](#) to verify enable/disable state change
- The [CFE\\_SB\\_ENBL RTE2\\_EID](#) debug event message will be generated
- Destination will begin receiving messages

#### Error Conditions

This command may fail for the following reason(s):

- the MsgId or PipeId parameters do not pass validation
- the destination does not exist.

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_SB\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases. See [CFE\\_SB\\_ENBL RTE1\\_EID](#) or [CFE\\_SB\\_ENBL RTE3\\_EID](#)

#### Criticality

This command is not inherently dangerous.

Definition at line 240 of file cfe\_sb\_msg.h.

#### 12.73.2.4 CFE\_SB\_ENABLE\_SUB\_REPORTING\_CC

```
#define CFE_SB_ENABLE_SUB_REPORTING_CC 9
```

**Name** Enable Subscription Reporting Command

##### Description

This command will enable subscription reporting and is intended to be used only by the CFS SBN (Software Bus Networking) Application. It is not intended to be sent from the ground or used by operations. When subscription reporting is enabled, SB will generate and send a software bus packet for each subscription received. The software bus packet that is sent contains the information received in the subscription API. This subscription report is needed by SBN if offboard routing is required.

**Command Mnemonic(s)** \$sc\_\$cpu\_SB\_EnaSubRptg

##### Command Structure

[CFE\\_SB\\_EnableSubReportingCmd\\_t](#)

##### Command Verification

Successful execution of this command will result in the sending of a packet (with the [CFE\\_SB\\_ONESUB\\_TLM\\_MID](#) MsgId) for each subscription received by SB through the subscription APIs.

##### Error Conditions

None

##### Criticality

None

##### See also

[CFE\\_SB\\_SingleSubscriptionTlm\\_t](#), [CFE\\_SB\\_DISABLE\\_SUB\\_REPORTING\\_CC](#), [CFE\\_SB\\_SEND\\_PREV\\_SUBLIST\\_CC](#)

Definition at line 405 of file cfe\_sb\_msg.h.

### 12.73.2.5 CFE\_SB\_NOOP\_CC

```
#define CFE_SB_NOOP_CC 0
```

**Name** Software Bus No-Op

#### Description

This command performs no other function than to increment the command execution counter. The command may be used to verify general aliveness of the Software Bus task.

**Command Mnemonic(s)** \$sc\_\$cpu\_SB\_NOOP

#### Command Structure

[CFE\\_SB\\_NoopCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_SB\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_SB\\_CMD0\\_RCVD\\_EID](#) informational event message will be generated

#### Error Conditions

There are no error conditions for this command. If the Software Bus receives the command, the event is sent (although it may be filtered by EVS) and the counter is incremented unconditionally.

#### Criticality

None

#### See also

Definition at line 76 of file cfe\_sb\_msg.h.

### 12.73.2.6 CFE\_SB\_RESET\_COUNTERS\_CC

```
#define CFE_SB_RESET_COUNTERS_CC 1
```

**Name** Software Bus Reset Counters

#### Description

This command resets the following counters within the Software Bus housekeeping telemetry:

- Command Execution Counter (\$sc\_\$cpu\_SB\_CMDPC)
- Command Error Counter (\$sc\_\$cpu\_SB\_CMDEC)
- No Subscribers Counter (\$sc\_\$cpu\_SB\_NoSubEC)
- Duplicate Subscriptions Counter (\$sc\_\$cpu\_SB\_DupSubCnt)
- Msg Send Error Counter (\$sc\_\$cpu\_SB\_MsgSndEC)
- Msg Receive Error Counter (\$sc\_\$cpu\_SB\_MsgRecEC)
- Internal Error Counter (\$sc\_\$cpu\_SB\_InternalEC)
- Create Pipe Error Counter (\$sc\_\$cpu\_SB\_NewPipeEC)
- Subscribe Error Counter (\$sc\_\$cpu\_SB\_SubscrEC)
- Pipe Overflow Error Counter (\$sc\_\$cpu\_SB\_PipeOvrEC)
- Msg Limit Error Counter (\$sc\_\$cpu\_SB\_MsgLimEC)

**Command Mnemonic(s)** \$sc\_\$cpu\_SB\_ResetCtrs

#### Command Structure

[CFE\\_SB\\_ResetCountersCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_SB\_CMDPC** - command execution counter will be reset to 0
- All other counters listed in description will be reset to 0
- The [CFE\\_SB\\_CMD1\\_RCVD\\_EID](#) informational event message will be generated

#### Error Conditions

There are no error conditions for this command. If the Software Bus receives the command, the event is sent (although it may be filtered by EVS) and the counter is incremented unconditionally.

#### Criticality

This command is not inherently dangerous. However, it is possible for ground systems and on-board safing procedures to be designed such that they react to changes in the counter values that are reset by this command.

#### See also

Definition at line 123 of file `cfe_sb_msg.h`.

### 12.73.2.7 CFE\_SB\_SEND\_PREV\_SUBS\_CC

```
#define CFE_SB_SEND_PREV_SUBS_CC 11
```

**Name** Send Previous Subscriptions Command

This command generates a series of packets that contain information

regarding all subscriptions previously received by SB. This command is intended to be used only by the CFS SBN(Software Bus Networking) Application. It is not intended to be sent from the ground or used by operations. When this command is received the software bus will generate and send a series of packets containing information about all subscription previously received.

**Command Mnemonic(s)** \$sc\_\$cpu\_SB\_SendPrevSubs

**Command Structure**

[CFE\\_SB\\_SendPrevSubsCmd\\_t](#)

**Command Verification**

Successful execution of this command will result in a series of packets (with the [CFE\\_SB\\_ALLSUBS\\_TLM\\_MID](#) MsgId) being sent on the software bus.

**Error Conditions**

None

**Criticality**

None

**See also**

[CFE\\_SB\\_AllSubscriptionsTlm\\_t](#), [CFE\\_SB\\_ENABLE\\_SUB\\_REPORTING\\_CC](#), [CFE\\_SB\\_DISABLE\\_SUB\\_REPORTING\\_CC](#)

Definition at line 470 of file `cfe_sb_msg.h`.

### 12.73.2.8 CFE\_SB\_SEND\_SB\_STATS\_CC

```
#define CFE_SB_SEND_SB_STATS_CC 2
```

**Name** Send Software Bus Statistics

#### Description

This command will cause the SB task to send a statistics packet containing current utilization figures and high water marks which may be useful for checking the margin of the SB platform configuration settings.

**Command Mnemonic(s)** \$sc\_\$cpu\_SB\_DumpStats

#### Command Structure

[CFE\\_SB\\_SendSbStatsCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_SB\\_CMDPC](#) - command execution counter will increment
- Receipt of statistics packet with MsgId [CFE\\_SB\\_STATS\\_TLM\\_MID](#)
- The [CFE\\_SB\\_SND\\_STATS\\_EID](#) debug event message will be generated

#### Error Conditions

There are no error conditions for this command. If the Software Bus receives the command, the debug event is sent and the counter is incremented unconditionally.

#### Criticality

This command is not inherently dangerous. It will create and send a message on the software bus. If performed repeatedly, it is possible that receiver pipes may overflow.

#### See also

Definition at line 157 of file cfe\_sb\_msg.h.

### 12.73.2.9 CFE\_SB\_WRITE\_MAP\_INFO\_CC

```
#define CFE_SB_WRITE_MAP_INFO_CC 8
```

**Name** Write Map Info to a File

This command will create a file containing the software bus message

map information. The message map is a lookup table (an array of uint16s) that allows fast access to the correct routing table element during a software bus send operation. This is diagnostic information that may be needed due to the dynamic nature of the cFE software bus. An absolute path and filename may be specified in the command. If this command field contains an empty string (NULL terminator as the first character) the default file path and name is used. The default file path and name is defined in the platform configuration file as [CFE\\_PLATFORM\\_SB\\_DEFAULT\\_MAP\\_FILENAME](#).

**Command Mnemonic(s)** \$sc\_\$cpu\_SB\_WriteMap2File

**Command Structure**

[CFE\\_SB\\_WriteMapInfoCmd\\_t](#)

**Command Verification**

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_SB\\_CMDPC](#) - command execution counter will increment. NOTE: the command counter is incremented when the request is accepted, before writing the file, which is performed as a background task.
- The file specified in the command (or the default specified by the [CFE\\_PLATFORM\\_SB\\_DEFAULT\\_MAP\\_FILENAME](#) configuration parameter) will be updated with the latest information.
- The [CFE\\_SB SND RTG EID](#) debug event message will be generated

**Error Conditions**

This command may fail for the following reason(s):

- A previous request to write a software bus information file has not yet completed
- The specified FileName cannot be parsed

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_SB\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases. See [CFE\\_SB SND RTG ERR1 EID](#) and [CFE\\_SB\\_FILEWRITE\\_ERR\\_EID](#)

**Criticality**

This command is not inherently dangerous. It will create a new file in the file system and could, if performed repeatedly without sufficient file management by the operator, fill the file system.

Definition at line 372 of file cfe\_sb\_msg.h.

### 12.73.2.10 CFE\_SB\_WRITE\_PIPE\_INFO\_CC

```
#define CFE_SB_WRITE_PIPE_INFO_CC 7
```

**Name** Write Pipe Info to a File

#### Description

This command will create a file containing the software bus pipe information. The pipe information contains information about every pipe that has been created through the [CFE\\_SB\\_CreatePipe](#) API. An absolute path and filename may be specified in the command. If this command field contains an empty string (NULL terminator as the first character) the default file path and name is used. The default file path and name is defined in the platform configuration file as [CFE\\_PLATFORM\\_SB\\_DEFAULT\\_PIPE\\_FILENAME](#).

**Command Mnemonic(s)** \$sc\_\$cpu\_SB\_WritePipe2File

#### Command Structure

[CFE\\_SB\\_WritePipeInfoCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_SB\\_CMDPC](#) - command execution counter will increment. NOTE: the command counter is incremented when the request is accepted, before writing the file, which is performed as a background task.
- The file specified in the command (or the default specified by the [CFE\\_PLATFORM\\_SB\\_DEFAULT\\_PIPE\\_FILENAME](#) configuration parameter) will be updated with the latest information.
- The [CFE\\_SB SND RTG EID](#) debug event message will be generated

#### Error Conditions

This command may fail for the following reason(s):

- A previous request to write a software bus information file has not yet completed
- The specified FileName cannot be parsed

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_SB\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases. See [CFE\\_SB SND RTG ERR1 EID](#) and [CFE\\_SB\\_FILEWRITE\\_ERR\\_EID](#)

#### Criticality

This command is not inherently dangerous. It will create a new file in the file system and could, if performed repeatedly without sufficient file management by the operator, fill the file system.

Definition at line 326 of file cfe\_sb\_msg.h.

### 12.73.2.11 CFE\_SB\_WRITE\_ROUTING\_INFO\_CC

```
#define CFE_SB_WRITE_ROUTING_INFO_CC 3
```

**Name** Write Software Bus Routing Info to a File

#### Description

This command will create a file containing the software bus routing information. The routing information contains information about every subscription that has been received through the SB subscription APIs. An absolute path and filename may be specified in the command. If this command field contains an empty string (NULL terminator as the first character) the default file path and name is used. The default file path and name is defined in the platform configuration file as [CFE\\_PLATFORM\\_SB\\_DEFAULT\\_ROUTING\\_FILENAME](#).

**Command Mnemonic(s)** \$sc\_\$cpu\_SB\_WriteRouting2File

#### Command Structure

[CFE\\_SB\\_WriteRoutingInfoCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_SB\\_CMDPC](#) - command execution counter will increment. NOTE: the command counter is incremented when the request is accepted, before writing the file, which is performed as a background task.
- The file specified in the command (or the default specified by the [CFE\\_PLATFORM\\_SB\\_DEFAULT\\_ROUTING\\_FILENAME](#) configuration parameter) will be updated with the latest information.
- The [CFE\\_SB SND RTG EID](#) debug event message will be generated

#### Error Conditions

This command may fail for the following reason(s):

- A previous request to write a software bus information file has not yet completed
- The specified FileName cannot be parsed

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_SB\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases. See [CFE\\_SB SND RTG ERR1 EID](#) and [CFE\\_SB FILEWRITE\\_ERR\\_EID](#)

#### Criticality

This command is not inherently dangerous. It will create a new file in the file system and could, if performed repeatedly without sufficient file management by the operator, fill the file system.

Definition at line 202 of file [cfe\\_sb\\_msg.h](#).

### 12.73.3 Typedef Documentation

#### 12.73.3.1 CFE\_SB\_AllSubscriptionsTlm\_Payload\_t

```
typedef struct CFE_SB_AllSubscriptionsTlm_Payload CFE_SB_AllSubscriptionsTlm_Payload_t
```

**Name** SB Previous Subscriptions Packet

This structure defines the pkt(s) sent by SB that contains a list of all current subscriptions. This pkt is generated on cmd and intended to be used primarily by the Software Bus Networking Application (SBN). Typically, when the cmd is received there are more subscriptions than can fit in one pkt. The complete list of subscriptions is sent via a series of segmented pkts.

#### 12.73.3.2 CFE\_SB\_AllSubscriptionsTlm\_t

```
typedef struct CFE_SB_AllSubscriptionsTlm CFE_SB_AllSubscriptionsTlm_t
```

#### 12.73.3.3 CFE\_SB\_DisableRouteCmd\_t

```
typedef CFE_SB_RouteCmd_t CFE_SB_DisableRouteCmd_t
```

Definition at line 545 of file cfe\_sb\_msg.h.

#### 12.73.3.4 CFE\_SB\_DisableSubReportingCmd\_t

```
typedef CFE_MSG_CommandHeader_t CFE_SB_DisableSubReportingCmd_t
```

Definition at line 486 of file cfe\_sb\_msg.h.

#### 12.73.3.5 CFE\_SB\_EnableRouteCmd\_t

```
typedef CFE_SB_RouteCmd_t CFE_SB_EnableRouteCmd_t
```

Definition at line 544 of file cfe\_sb\_msg.h.

**12.73.3.6 CFE\_SB\_EnableSubReportingCmd\_t**

```
typedef CFE_MSG_CommandHeader_t CFE_SB_EnableSubReportingCmd_t
```

Definition at line 485 of file cfe\_sb\_msg.h.

**12.73.3.7 CFE\_SB\_HousekeepingTlm\_Payload\_t**

```
typedef struct CFE_SB_HousekeepingTlm_Payload CFE_SB_HousekeepingTlm_Payload_t
```

**Name** Software Bus task housekeeping Packet

**12.73.3.8 CFE\_SB\_HousekeepingTlm\_t**

```
typedef struct CFE_SB_HousekeepingTlm CFE_SB_HousekeepingTlm_t
```

**12.73.3.9 CFE\_SB\_MsgMapFileEntry\_t**

```
typedef struct CFE_SB_MsgMapFileEntry CFE_SB_MsgMapFileEntry_t
```

SB Map File Entry.

Structure of one element of the map information in response to [CFE\\_SB\\_WRITE\\_MAP\\_INFO\\_CC](#)

**12.73.3.10 CFE\_SB\_NoopCmd\_t**

```
typedef CFE_MSG_CommandHeader_t CFE_SB_NoopCmd_t
```

Definition at line 483 of file cfe\_sb\_msg.h.

**12.73.3.11 CFE\_SB\_PipeDepthStats\_t**

```
typedef struct CFE_SB_PipeDepthStats CFE_SB_PipeDepthStats_t
```

SB Pipe Depth Statistics.

Used in SB Statistics Telemetry Packet [CFE\\_SB\\_StatsTlm\\_t](#)

### 12.73.3.12 CFE\_SB\_PipeInfoEntry\_t

```
typedef struct CFE_SB_PipeInfoEntry CFE_SB_PipeInfoEntry_t
```

SB Pipe Information File Entry.

This statistics structure is output as part of the CFE SB "Send Pipe Info" command (CFE\_SB\_SEND\_PIPE\_INFO\_CC).

Previous versions of CFE simply wrote the internal CFE\_SB\_PipeD\_t object to the file, but this also contains information such as pointers which are not relevant outside the running CFE process.

By defining the pipe info structure separately, it also provides some independence, such that the internal CFE\_SB\_PipeD\_t definition can evolve without changing the binary format of the information file.

### 12.73.3.13 CFE\_SB\_ResetCountersCmd\_t

```
typedef CFE_MSG_CommandHeader_t CFE_SB_ResetCountersCmd_t
```

Definition at line 484 of file cfe\_sb\_msg.h.

### 12.73.3.14 CFE\_SB\_RouteCmd\_Payload\_t

```
typedef struct CFE_SB_RouteCmd_Payload CFE_SB_RouteCmd_Payload_t
```

Enable/Disable Route Command Payload.

This structure contains a definition used by two SB commands, 'Enable Route' [CFE\\_SB\\_ENABLE\\_ROUTE\\_CC](#) and 'Disable Route' [CFE\\_SB\\_DISABLE\\_ROUTE\\_CC](#). A route is the destination pipe for a particular message and is therefore defined as a MsgId and Pipeld combination.

### 12.73.3.15 CFE\_SB\_RouteCmd\_t

```
typedef struct CFE_SB_RouteCmd CFE_SB_RouteCmd_t
```

Enable/Disable Route Command.

### 12.73.3.16 CFE\_SB\_RoutingFileEntry\_t

```
typedef struct CFE_SB_RoutingFileEntry CFE_SB_RoutingFileEntry_t
```

SB Routing File Entry.

Structure of one element of the routing information in response to [CFE\\_SB\\_WRITE\\_ROUTING\\_INFO\\_CC](#)

#### 12.73.3.17 CFE\_SB\_SendPrevSubsCmd\_t

```
typedef CFE_MSG_CommandHeader_t CFE_SB_SendPrevSubsCmd_t
```

Definition at line 488 of file cfe\_sb\_msg.h.

#### 12.73.3.18 CFE\_SB\_SendSbStatsCmd\_t

```
typedef CFE_MSG_CommandHeader_t CFE_SB_SendSbStatsCmd_t
```

Definition at line 487 of file cfe\_sb\_msg.h.

#### 12.73.3.19 CFE\_SB\_SingleSubscriptionTlm\_Payload\_t

```
typedef struct CFE_SB_SingleSubscriptionTlm_Payload CFE_SB_SingleSubscriptionTlm_Payload_t
```

**Name** SB Subscription Report Packet

This structure defines the pkt sent by SB when a subscription or a request to unsubscribe is received while subscription reporting is enabled. By default subscription reporting is disabled. This feature is intended to be used primarily by Software Bus Networking Application (SBN)

See also

[CFE\\_SB\\_ENABLE\\_SUB\\_REPORTING\\_CC](#), [CFE\\_SB\\_DISABLE\\_SUB\\_REPORTING\\_CC](#)

#### 12.73.3.20 CFE\_SB\_SingleSubscriptionTlm\_t

```
typedef struct CFE_SB_SingleSubscriptionTlm CFE_SB_SingleSubscriptionTlm_t
```

#### 12.73.3.21 CFE\_SB\_StatsTlm\_Payload\_t

```
typedef struct CFE_SB_StatsTlm_Payload CFE_SB_StatsTlm_Payload_t
```

**Name** SB Statistics Telemetry Packet

SB Statistics packet sent in response to [CFE\\_SB\\_SEND\\_SB\\_STATS\\_CC](#)

**12.73.3.22 CFE\_SB\_StatsTlm\_t**

```
typedef struct CFE_SB_StatsTlm CFE_SB_StatsTlm_t
```

**12.73.3.23 CFE\_SB\_SubEntries\_t**

```
typedef struct CFE_SB_SubEntries CFE_SB_SubEntries_t
```

SB Previous Subscriptions Entry.

This structure defines an entry used in the CFE\_SB\_PrevSubsPkt\_t Intended to be used primarily by Software Bus Networking Application (SBN)

Used in structure definition [CFE\\_SB\\_AllSubscriptionsTlm\\_t](#)

**12.73.3.24 CFE\_SB\_WriteFileInfoCmd\_Payload\_t**

```
typedef struct CFE_SB_WriteFileInfoCmd_Payload CFE_SB_WriteFileInfoCmd_Payload_t
```

Write File Info Command Payload.

This structure contains a generic definition used by SB commands that write to a file

**12.73.3.25 CFE\_SB\_WriteFileInfoCmd\_t**

```
typedef struct CFE_SB_WriteFileInfoCmd CFE_SB_WriteFileInfoCmd_t
```

Write File Info Command.

**12.73.3.26 CFE\_SB\_WriteMapInfoCmd\_t**

```
typedef CFE_SB_WriteFileInfoCmd_t CFE_SB_WriteMapInfoCmd_t
```

Definition at line 514 of file cfe\_sb\_msg.h.

**12.73.3.27 CFE\_SB\_WritePipeInfoCmd\_t**

```
typedef CFE_SB_WriteFileInfoCmd_t CFE_SB_WritePipeInfoCmd_t
```

Definition at line 513 of file cfe\_sb\_msg.h.

### 12.73.3.28 CFE\_SB\_WriteRoutingInfoCmd\_t

```
typedef CFE_SB_WriteFileInfoCmd_t CFE_SB_WriteRoutingInfoCmd_t
```

Definition at line 512 of file cfe\_sb\_msg.h.

## 12.74 cfe/modules/tbl/fsw/inc/cfe\_tbl\_events.h File Reference

### Macros

#### TBL event IDs

- #define CFE\_TBL\_INIT\_INF\_EID 1  
*TBL Initialization Event ID.*
- #define CFE\_TBL\_NOOP\_INF\_EID 10  
*TBL No-op Command Success Event ID.*
- #define CFE\_TBL\_RESET\_INF\_EID 11  
*TBL Reset Counters Command Success Event ID.*
- #define CFE\_TBL\_FILE\_LOADED\_INF\_EID 12  
*TBL Load Table Command Success Event ID.*
- #define CFE\_TBL\_OVERWRITE\_DUMP\_INF\_EID 13  
*TBL Write Table To Existing File Success Event ID.*
- #define CFE\_TBL\_WRITE\_DUMP\_INF\_EID 14  
*TBL Write Table To New File Success Event ID.*
- #define CFE\_TBL\_OVERWRITE\_REG\_DUMP\_INF\_EID 15  
*TBL Write Table Registry To Existing File Success Event ID.*
- #define CFE\_TBL\_VAL\_REQ\_MADE\_INF\_EID 16  
*TBL Validate Table Request Success Event ID.*
- #define CFE\_TBL\_LOAD\_PEND\_REQ\_INF\_EID 17  
*TBL Load Table Pending Notification Success Event ID.*
- #define CFE\_TBL\_TLM\_REG\_CMD\_INF\_EID 18  
*TBL Telemeter Table Registry Entry Command Success Event ID.*
- #define CFE\_TBL\_LOAD\_ABORT\_INF\_EID 21  
*TBL Abort Table Load Success Event ID.*
- #define CFE\_TBL\_WRITE\_REG\_DUMP\_INF\_EID 22  
*TBL Write Table Registry To New File Success Event ID.*
- #define CFE\_TBL\_ASSUMED\_VALID\_INF\_EID 23  
*TBL Validate Table Valid Due To No Validation Function Event ID.*
- #define CFE\_TBL\_LOAD\_SUCCESS\_INF\_EID 35  
*TBL Load Table API Success Event ID.*
- #define CFE\_TBL\_VALIDATION\_INF\_EID 36  
*TBL Validate Table Success Event ID.*
- #define CFE\_TBL\_UPDATE\_SUCCESS\_INF\_EID 37  
*TBL Update Table Success Event ID.*
- #define CFE\_TBL\_CDS\_DELETED\_INFO\_EID 38  
*TBL Delete Table CDS Command Success Event ID.*
- #define CFE\_TBL\_MID\_ERR\_EID 50  
*TBL Invalid Message ID Received Event ID.*
- #define CFE\_TBL\_CC1\_ERR\_EID 51  
*TBL Invalid Command Code Received Event ID.*
- #define CFE\_TBL\_LEN\_ERR\_EID 52  
*TBL Invalid Command Length Event ID.*
- #define CFE\_TBL\_FILE\_ACCESS\_ERR\_EID 53

- `#define CFE_TBL_FILE_STD_HDR_ERR_EID 54`  
*TBL Load Table File Open Failure Event ID.*
- `#define CFE_TBL_FILE_TBL_HDR_ERR_EID 55`  
*TBL Load Table File Read Standard Header Failure Event ID.*
- `#define CFE_TBL_FAIL_HK_SEND_ERR_EID 56`  
*TBL Load Table File Read Table Header Failure Event ID.*
- `#define CFE_TBL_NO SUCH_TABLE_ERR_EID 57`  
*TBL Send Housekeeping Command Transmit Failure Event ID.*
- `#define CFE_TBL_FILE_TYPE_ERR_EID 58`  
*TBL Load Table Invalid File Content ID Event ID.*
- `#define CFE_TBL_FILE_SUBTYPE_ERR_EID 59`  
*TBL Load Table Invalid File Subtype Event ID.*
- `#define CFE_TBL_NO_WORK_BUFFERS_ERR_EID 60`  
*TBL Load Or Dump Table No Working Buffers Available Event ID.*
- `#define CFE_TBL_INTERNAL_ERROR_ERR_EID 61`  
*TBL Load Table Command Get Working Buffer Internal Failure Event ID.*
- `#define CFE_TBL_CREATING_DUMP_FILE_ERR_EID 62`  
*TBL Write File Creation Failure Event ID.*
- `#define CFE_TBL_WRITE_CFE_HDR_ERR_EID 63`  
*TBL Write Standard File Header Failure Event ID.*
- `#define CFE_TBL_WRITE_TBL_HDR_ERR_EID 64`  
*TBL Write Table File Header Failure Event ID.*
- `#define CFE_TBL_WRITE_TBL_IMG_ERR_EID 65`  
*TBL Write Table File Data Failure Event ID.*
- `#define CFE_TBL_NO_INACTIVE_BUFFER_ERR_EID 66`  
*TBL Validate Or Write Table Command No Inactive Buffer Event ID.*
- `#define CFE_TBL_TOO_MANY_VALIDATIONS_ERR_EID 67`  
*TBL Validate Table Command Result Storage Exceeded Event ID.*
- `#define CFE_TBL_WRITE_TBL_REG_ERR_EID 68`  
*TBL Write Table Registry File Data Failure Event ID.*
- `#define CFE_TBL_LOAD_ABORT_ERR_EID 69`  
*TBL Abort Table Load No Load Started Event ID.*
- `#define CFE_TBL_ACTIVATE_ERR_EID 70`  
*TBL Activate Table Command No Inactive Buffer Event ID.*
- `#define CFE_TBL_FILE_INCOMPLETE_ERR_EID 71`  
*TBL Load Table Incomplete Load Event ID.*
- `#define CFE_TBL_LOAD_EXCEEDS_SIZE_ERR_EID 72`  
*TBL Load Table File Exceeds Table Size Event ID.*
- `#define CFE_TBL_ZERO_LENGTH_LOAD_ERR_EID 73`  
*TBL Load Table File Zero Length Event ID.*
- `#define CFE_TBL_PARTIAL_LOAD_ERR_EID 74`  
*TBL Load Table Uninitialized Partial Load Event ID.*
- `#define CFE_TBL_FILE_TOO_BIG_ERR_EID 75`  
*TBL Load Table File Excess Data Event ID.*
- `#define CFE_TBL_TOO_MANY_DUMPS_ERR_EID 76`  
*TBL Write Table Command Dump Only Control Blocks Exceeded Event ID.*
- `#define CFE_TBL_DUMP_PENDING_ERR_EID 77`  
*TBL Write Table Command Already In Progress Event ID.*
- `#define CFE_TBL_ACTIVATE_DUMP_ONLY_ERR_EID 78`  
*TBL Activate Table Command For Dump Only Table Event ID.*
- `#define CFE_TBL_LOADING_A_DUMP_ONLY_ERR_EID 79`  
*TBL Load Table For Dump Only Table Event ID.*
- `#define CFE_TBL_ILLEGAL_BUFF_PARAM_ERR_EID 80`  
*TBL Validate Or Write Table Command Invalid Buffer Event ID.*

- #define `CFE_TBL_UNVALIDATED_ERR_EID` 81  
*TBL Activate Table Command Inactive Image Not Validated Event ID.*
- #define `CFE_TBL_IN_REGISTRY_ERR_EID` 82  
*TBL Delete Table CDS Command For Registered Table Event ID.*
- #define `CFE_TBL_NOT_CRITICAL_TBL_ERR_EID` 83  
*TBL Delete Table CDS Command Invalid CDS Type Event ID.*
- #define `CFE_TBL_NOT_IN_CRIT_REG_ERR_EID` 84  
*TBL Delete Table CDS Command Not In Critical Table Registry Event ID.*
- #define `CFE_TBL_CDS_NOT_FOUND_ERR_EID` 85  
*TBL Delete Table CDS Command Not In CDS Registry Event ID.*
- #define `CFE_TBL_CDS_DELETE_ERR_EID` 86  
*TBL Delete Table CDS Command Internal Error Event ID.*
- #define `CFE_TBL_CDS_OWNER_ACTIVE_ERR_EID` 87  
*TBL Delete Table CDS Command App Active Event ID.*
- #define `CFE_TBL_LOADING_PENDING_ERR_EID` 88  
*TBL Load Table Command Load Pending Event ID.*
- #define `CFE_TBL_FAIL_NOTIFY_SEND_ERR_EID` 89  
*TBL Send Notification Transmit Failed Event ID.*
- #define `CFE_TBL_REGISTER_ERR_EID` 90  
*TBL Register Table Failed Event ID.*
- #define `CFE_TBL_SHARE_ERR_EID` 91  
*TBL Share Table Failed Event ID.*
- #define `CFE_TBL_UNREGISTER_ERR_EID` 92  
*TBL Unregister Table Failed Event ID.*
- #define `CFE_TBL_LOAD_VAL_ERR_EID` 93  
*TBL Validation Function Invalid Return Code Event ID.*
- #define `CFE_TBL_LOAD_TYPE_ERR_EID` 94  
*TBL Load Table API Invalid Source Type Event ID.*
- #define `CFE_TBL_UPDATE_ERR_EID` 95  
*TBL Update Table Failed Event ID.*
- #define `CFE_TBL_VALIDATION_ERR_EID` 96  
*TBL Validate Table Validation Failed Event ID.*
- #define `CFE_TBL_SPACECRAFT_ID_ERR_EID` 97  
*TBL Read Header Invalid Spacecraft ID Event ID.*
- #define `CFE_TBL_PROCESSOR_ID_ERR_EID` 98  
*TBL Read Header Invalid Processor ID Event ID.*
- #define `CFE_TBL_LOAD_IN_PROGRESS_ERR_EID` 100  
*TBL Load Table API Load Already In Progress Event ID.*
- #define `CFE_TBL_LOAD_FILENAME_LONG_ERR_EID` 101  
*TBL Load Table Filename Too Long Event ID.*
- #define `CFE_TBL_LOAD_TBLNAME_MISMATCH_ERR_EID` 102  
*TBL Load Table Name Mismatch Event ID.*
- #define `CFE_TBL_HANDLE_ACCESS_ERR_EID` 103  
*TBL Load Table API Access Violation Event ID.*

#### 12.74.1 Detailed Description

cFE Table Services Event IDs

#### 12.74.2 Macro Definition Documentation

#### 12.74.2.1 CFE\_TBL\_ACTIVATE\_DUMP\_ONLY\_ERR\_EID

```
#define CFE_TBL_ACTIVATE_DUMP_ONLY_ERR_EID 78
```

TBL Activate Table Command For Dump Only Table Event ID.

Type: ERROR

Cause:

[TBL Activate Table Command](#) failure due to table being dump only.

Definition at line 556 of file cfe\_tbl\_events.h.

#### 12.74.2.2 CFE\_TBL\_ACTIVATE\_ERR\_EID

```
#define CFE_TBL_ACTIVATE_ERR_EID 70
```

TBL Activate Table Command No Inactive Buffer Event ID.

Type: ERROR

Cause:

[TBL Activate Table Command](#) failure due to no associated inactive buffer.

Definition at line 462 of file cfe\_tbl\_events.h.

#### 12.74.2.3 CFE\_TBL\_ASSUMED\_VALID\_INF\_EID

```
#define CFE_TBL_ASSUMED_VALID_INF_EID 23
```

TBL Validate Table Valid Due To No Validation Function Event ID.

Type: INFORMATION

Cause:

[TBL Validate Table Command](#) marking table as valid due to no validation function being registered.

Definition at line 180 of file cfe\_tbl\_events.h.

#### 12.74.2.4 CFE\_TBL\_CC1\_ERR\_EID

```
#define CFE_TBL_CC1_ERR_EID 51
```

TBL Invalid Command Code Received Event ID.

Type: ERROR

Cause:

Invalid command code for message ID [CFE\\_TBL\\_CMD\\_MID](#) received on the TBL message pipe.

Definition at line 246 of file `cfe_tbl_events.h`.

#### 12.74.2.5 CFE\_TBL\_CDS\_DELETE\_ERR\_EID

```
#define CFE_TBL_CDS_DELETE_ERR_EID 86
```

TBL Delete Table CDS Command Internal Error Event ID.

Type: ERROR

Cause:

[TBL Delete Table CDS Command](#) failure due to an internal error. See the system log for more information.

Definition at line 652 of file `cfe_tbl_events.h`.

#### 12.74.2.6 CFE\_TBL\_CDS\_DELETED\_INFO\_EID

```
#define CFE_TBL_CDS_DELETED_INFO_EID 38
```

TBL Delete Table CDS Command Success Event ID.

Type: INFORMATION

Cause:

[TBL Delete Table CDS Command](#) success.

Definition at line 224 of file `cfe_tbl_events.h`.

**12.74.2.7 CFE\_TBL\_CDS\_NOT\_FOUND\_ERR\_EID**

```
#define CFE_TBL_CDS_NOT_FOUND_ERR_EID 85
```

TBL Delete Table CDS Command Not In CDS Registry Event ID.

Type: ERROR

Cause:

[TBL Delete Table CDS Command](#) failure due to the table name not found in the CDS registry.

Definition at line 640 of file cfe\_tbl\_events.h.

**12.74.2.8 CFE\_TBL\_CDS\_OWNER\_ACTIVE\_ERR\_EID**

```
#define CFE_TBL_CDS_OWNER_ACTIVE_ERR_EID 87
```

TBL Delete Table CDS Command App Active Event ID.

Type: ERROR

Cause:

[TBL Delete Table CDS Command](#) failure due to the owning application being active.

Definition at line 664 of file cfe\_tbl\_events.h.

**12.74.2.9 CFE\_TBL\_CREATING\_DUMP\_FILE\_ERR\_EID**

```
#define CFE_TBL_CREATING_DUMP_FILE_ERR_EID 62
```

TBL Write File Creation Failure Event ID.

Type: ERROR

Cause:

TBL Write Table or Table Registry File failed to create file. OVERLOADED

Definition at line 369 of file cfe\_tbl\_events.h.

**12.74.2.10 CFE\_TBL\_DUMP\_PENDING\_ERR\_EID**

```
#define CFE_TBL_DUMP_PENDING_ERR_EID 77
```

TBL Write Table Command Already In Progress Event ID.

Type: ERROR

Cause:

[TBL Write Table Command](#) failure due to a dump already in progress for the same table.

Definition at line 544 of file cfe\_tbl\_events.h.

**12.74.2.11 CFE\_TBL\_FAIL\_HK\_SEND\_ERR\_EID**

```
#define CFE_TBL_FAIL_HK_SEND_ERR_EID 56
```

TBL Send Housekeeping Command Transmit Failure Event ID.

Type: ERROR

Cause:

[TBL Send Housekeeping Command](#) failure transmitting the housekeeping message.

Definition at line 302 of file cfe\_tbl\_events.h.

**12.74.2.12 CFE\_TBL\_FAIL\_NOTIFY\_SEND\_ERR\_EID**

```
#define CFE_TBL_FAIL_NOTIFY_SEND_ERR_EID 89
```

TBL Send Notification Transmit Failed Event ID.

Type: ERROR

Cause:

TBL send notification transmit message failure.

Definition at line 686 of file cfe\_tbl\_events.h.

**12.74.2.13 CFE\_TBL\_FILE\_ACCESS\_ERR\_EID**

```
#define CFE_TBL_FILE_ACCESS_ERR_EID 53
```

TBL Load Table File Open Failure Event ID.

Type: ERROR

Cause:

Load Table failure opening the file. OVERLOADED

Definition at line 268 of file cfe\_tbl\_events.h.

**12.74.2.14 CFE\_TBL\_FILE\_INCOMPLETE\_ERR\_EID**

```
#define CFE_TBL_FILE_INCOMPLETE_ERR_EID 71
```

TBL Load Table Incomplete Load Event ID.

Type: ERROR

Cause:

TBL Load Table failure due to inability to read the size of data specified in the table header from file. OVERLOADED

Definition at line 474 of file cfe\_tbl\_events.h.

**12.74.2.15 CFE\_TBL\_FILE\_LOADED\_INF\_EID**

```
#define CFE_TBL_FILE_LOADED_INF_EID 12
```

TBL Load Table Command Success Event ID.

Type: INFORMATION

Cause:

[TBL Load Table Command](#) successfully loaded the new table data to the working buffer.

Definition at line 76 of file cfe\_tbl\_events.h.

**12.74.2.16 CFE\_TBL\_FILE\_STD\_HDR\_ERR\_EID**

```
#define CFE_TBL_FILE_STD_HDR_ERR_EID 54
```

TBL Load Table File Read Standard Header Failure Event ID.

Type: ERROR

Cause:

Load Table failure reading the file standard header.

Definition at line 279 of file cfe\_tbl\_events.h.

**12.74.2.17 CFE\_TBL\_FILE\_SUBTYPE\_ERR\_EID**

```
#define CFE_TBL_FILE_SUBTYPE_ERR_EID 59
```

TBL Load Table Invalid File Subtype Event ID.

Type: ERROR

Cause:

TBL Load Table Failure due to invalid file subtype.

Definition at line 335 of file cfe\_tbl\_events.h.

**12.74.2.18 CFE\_TBL\_FILE\_TBL\_HDR\_ERR\_EID**

```
#define CFE_TBL_FILE_TBL_HDR_ERR_EID 55
```

TBL Load Table File Read Table Header Failure Event ID.

Type: ERROR

Cause:

Load Table failure reading the file table header.

Definition at line 290 of file cfe\_tbl\_events.h.

**12.74.2.19 CFE\_TBL\_FILE\_TOO\_BIG\_ERR\_EID**

```
#define CFE_TBL_FILE_TOO_BIG_ERR_EID 75
```

TBL Load Table File Excess Data Event ID.

Type: ERROR

Cause:

TBL Load Table failure due to the file header specified size of data being smaller than the actual data contained in the file. OVERLOADED

Definition at line 520 of file cfe\_tbl\_events.h.

**12.74.2.20 CFE\_TBL\_FILE\_TYPE\_ERR\_EID**

```
#define CFE_TBL_FILE_TYPE_ERR_EID 58
```

TBL Load Table Invalid File Content ID Event ID.

Type: ERROR

Cause:

TBL Load Table failure due to invalid file content ID.

Definition at line 324 of file cfe\_tbl\_events.h.

**12.74.2.21 CFE\_TBL\_HANDLE\_ACCESS\_ERR\_EID**

```
#define CFE_TBL_HANDLE_ACCESS_ERR_EID 103
```

TBL Load Table API Access Violation Event ID.

Type: ERROR

Cause:

[CFE\\_TBL\\_Load](#) API failure due to the application not owning the table.

Definition at line 829 of file cfe\_tbl\_events.h.

**12.74.2.22 CFE\_TBL\_ILLEGAL\_BUFF\_PARAM\_ERR\_EID**

```
#define CFE_TBL_ILLEGAL_BUFF_PARAM_ERR_EID 80
```

TBL Validate Or Write Table Command Invalid Buffer Event ID.

Type: ERROR

Cause:

[TBL Validate Table Command](#) or [TBL Write Table Command](#) failure due to an invalid buffer selection. OVERLOADED

Definition at line 580 of file cfe\_tbl\_events.h.

**12.74.2.23 CFE\_TBL\_IN\_REGISTRY\_ERR\_EID**

```
#define CFE_TBL_IN_REGISTRY_ERR_EID 82
```

TBL Delete Table CDS Command For Registered Table Event ID.

Type: ERROR

Cause:

[TBL Delete Table CDS Command](#) failure due to the table being currently registered.

Definition at line 604 of file cfe\_tbl\_events.h.

**12.74.2.24 CFE\_TBL\_INIT\_INF\_EID**

```
#define CFE_TBL_INIT_INF_EID 1
```

TB Initialization Event ID.

Type: INFORMATION

Cause:

Table Services Task initialization complete.

Definition at line 42 of file cfe\_tbl\_events.h.

**12.74.2.25 CFE\_TBL\_INTERNAL\_ERROR\_ERR\_EID**

```
#define CFE_TBL_INTERNAL_ERROR_ERR_EID 61
```

TBL Load Table Command Get Working Buffer Internal Failure Event ID.

Type: ERROR

Cause:

[TBL Load Table Command](#) failure due to internal get working buffer error.

Definition at line 358 of file cfe\_tbl\_events.h.

**12.74.2.26 CFE\_TBL\_LEN\_ERR\_EID**

```
#define CFE_TBL_LEN_ERR_EID 52
```

TBL Invalid Command Length Event ID.

Type: ERROR

Cause:

Invalid length for the message ID and command code received on the TBL message pipe.

Definition at line 257 of file cfe\_tbl\_events.h.

**12.74.2.27 CFE\_TBL\_LOAD\_ABORT\_ERR\_EID**

```
#define CFE_TBL_LOAD_ABORT_ERR_EID 69
```

TBL Abort Table Load No Load Started Event ID.

Type: ERROR

Cause:

[TBL Abort Table Load Command](#) failure due to no load in progress.

Definition at line 450 of file cfe\_tbl\_events.h.

**12.74.2.28 CFE\_TBL\_LOAD\_ABORT\_INF\_EID**

```
#define CFE_TBL_LOAD_ABORT_INF_EID 21
```

TBL Abort Table Load Success Event ID.

Type: INFORMATION

Cause:

[TBL Abort Table Load Command](#) success.

Definition at line 157 of file cfe\_tbl\_events.h.

**12.74.2.29 CFE\_TBL\_LOAD\_EXCEEDS\_SIZE\_ERR\_EID**

```
#define CFE_TBL_LOAD_EXCEEDS_SIZE_ERR_EID 72
```

TBL Load Table File Exceeds Table Size Event ID.

Type: ERROR

Cause:

TBL Load Table failure due to the file header specified offset and/or size of data exceeding the table size. OVERLOADED

Definition at line 486 of file cfe\_tbl\_events.h.

**12.74.2.30 CFE\_TBL\_LOAD\_FILENAME\_LONG\_ERR\_EID**

```
#define CFE_TBL_LOAD_FILENAME_LONG_ERR_EID 101
```

TBL Load Table Filename Too Long Event ID.

Type: ERROR

Cause:

Load table filename too long.

Definition at line 807 of file cfe\_tbl\_events.h.

**12.74.2.31 CFE\_TBL\_LOAD\_IN\_PROGRESS\_ERR\_EID**

```
#define CFE_TBL_LOAD_IN_PROGRESS_ERR_EID 100
```

TBL Load Table API Load Already In Progress Event ID.

Type: **ERROR**

Cause:

[CFE\\_TBL\\_Load](#) API failure due to load already in progress.

Definition at line 796 of file cfe\_tbl\_events.h.

**12.74.2.32 CFE\_TBL\_LOAD\_PEND\_REQ\_INF\_EID**

```
#define CFE_TBL_LOAD_PEND_REQ_INF_EID 17
```

TBL Load Table Pending Notification Success Event ID.

Type: **DEBUG**

Cause:

TBL load table pending notification successfully sent.

Definition at line 134 of file cfe\_tbl\_events.h.

**12.74.2.33 CFE\_TBL\_LOAD\_SUCCESS\_INF\_EID**

```
#define CFE_TBL_LOAD_SUCCESS_INF_EID 35
```

TBL Load Table API Success Event ID.

Type: **DEBUG** (the first time) and **INFORMATION** (normally)

Cause:

[CFE\\_TBL\\_Load](#) API success for dump only or normal table. OVERLOADED

Definition at line 191 of file cfe\_tbl\_events.h.

**12.74.2.34 CFE\_TBL\_LOAD\_TBLNAME\_MISMATCH\_ERR\_EID**

```
#define CFE_TBL_LOAD_TBLNAME_MISMATCH_ERR_EID 102
```

TBL Load Table Name Mismatch Event ID.

Type: ERROR

Cause:

Load table name in the table file header does not match the specified table name.

Definition at line 818 of file cfe\_tbl\_events.h.

**12.74.2.35 CFE\_TBL\_LOAD\_TYPE\_ERR\_EID**

```
#define CFE_TBL_LOAD_TYPE_ERR_EID 94
```

TBL Load Table API Invalid Source Type Event ID.

Type: ERROR

Cause:

[CFE\\_TBL\\_Load](#) API valid due to invalid source type.

Definition at line 741 of file cfe\_tbl\_events.h.

**12.74.2.36 CFE\_TBL\_LOAD\_VAL\_ERR\_EID**

```
#define CFE_TBL_LOAD_VAL_ERR_EID 93
```

TBL Validation Function Invalid Return Code Event ID.

Type: ERROR

Cause:

Invalid table validation function return code.

Definition at line 730 of file cfe\_tbl\_events.h.

**12.74.2.37 CFE\_TBL\_LOADING\_A\_DUMP\_ONLY\_ERR\_EID**

```
#define CFE_TBL_LOADING_A_DUMP_ONLY_ERR_EID 79
```

TBL Load Table For Dump Only Table Event ID.

Type: ERROR

Cause:

TBL Load Table failure due to table being dump only. OVERLOADED

Definition at line 567 of file cfe\_tbl\_events.h.

**12.74.2.38 CFE\_TBL\_LOADING\_PENDING\_ERR\_EID**

```
#define CFE_TBL_LOADING_PENDING_ERR_EID 88
```

TBL Load Table Command Load Pending Event ID.

Type: ERROR

Cause:

[TBL Load Table Command](#) failed due to a load already pending.

Definition at line 675 of file cfe\_tbl\_events.h.

**12.74.2.39 CFE\_TBL\_MID\_ERR\_EID**

```
#define CFE_TBL_MID_ERR_EID 50
```

TBL Invalid Message ID Received Event ID.

Type: ERROR

Cause:

Invalid message ID received on the TBL message pipe.

Definition at line 235 of file cfe\_tbl\_events.h.

**12.74.2.40 CFE\_TBL\_NO\_INACTIVE\_BUFFER\_ERR\_EID**

```
#define CFE_TBL_NO_INACTIVE_BUFFER_ERR_EID 66
```

TBL Validate Or Write Table Command No Inactive Buffer Event ID.

Type: ERROR

Cause:

[TBL Validate Table Command](#) or [TBL Write Table Command](#) failure due to requesting non-existent inactive buffer.  
OVERLOADED

Definition at line 415 of file cfe\_tbl\_events.h.

**12.74.2.41 CFE\_TBL\_NO\_SUCH\_TABLE\_ERR\_EID**

```
#define CFE_TBL_NO_SUCH_TABLE_ERR_EID 57
```

TBL Table Name Not Found Event ID.

Type: ERROR

Cause:

TBL command handler unable to find table name. OVERLOADED

Definition at line 313 of file cfe\_tbl\_events.h.

**12.74.2.42 CFE\_TBL\_NO\_WORK\_BUFFERS\_ERR\_EID**

```
#define CFE_TBL_NO_WORK_BUFFERS_ERR_EID 60
```

TBL Load Or Dump Table No Working Buffers Available Event ID.

Type: ERROR

Cause:

TBL Load or Dump failure due to no working buffers available or internal error. OVERLOADED

Definition at line 346 of file cfe\_tbl\_events.h.

**12.74.2.43 CFE\_TBL\_NOOP\_INF\_EID**

```
#define CFE_TBL_NOOP_INF_EID 10
```

TBL No-op Command Success Event ID.

Type: INFORMATION

Cause:

[NO-OP TBL No-op Command](#) success.

Definition at line 53 of file cfe\_tbl\_events.h.

**12.74.2.44 CFE\_TBL\_NOT\_CRITICAL\_TBL\_ERR\_EID**

```
#define CFE_TBL_NOT_CRITICAL_TBL_ERR_EID 83
```

TBL Delete Table CDS Command Invalid CDS Type Event ID.

Type: ERROR

Cause:

[TBL Delete Table CDS Command](#) failure due to CDS being in the table registry but not registered as a table within ES.

Definition at line 616 of file cfe\_tbl\_events.h.

**12.74.2.45 CFE\_TBL\_NOT\_IN\_CRIT\_REG\_ERR\_EID**

```
#define CFE_TBL_NOT_IN_CRIT_REG_ERR_EID 84
```

TBL Delete Table CDS Command Not In Critical Table Registry Event ID.

Type: ERROR

Cause:

[TBL Delete Table CDS Command](#) failure due to the table not being in the critical table registry.

Definition at line 628 of file cfe\_tbl\_events.h.

**12.74.2.46 CFE\_TBL\_OVERWRITE\_DUMP\_INF\_EID**

```
#define CFE_TBL_OVERWRITE_DUMP_INF_EID 13
```

TBL Write Table To Existing File Success Event ID.

Type: INFORMATION

Cause:

TBL write table to an existing file success.

Definition at line 87 of file cfe\_tbl\_events.h.

**12.74.2.47 CFE\_TBL\_OVERWRITE\_REG\_DUMP\_INF\_EID**

```
#define CFE_TBL_OVERWRITE_REG_DUMP_INF_EID 15
```

TBL Write Table Registry To Existing File Success Event ID.

Type: DEBUG

Cause:

TBL Write Table Registry to an existing file completed successfully.

Definition at line 109 of file cfe\_tbl\_events.h.

**12.74.2.48 CFE\_TBL\_PARTIAL\_LOAD\_ERR\_EID**

```
#define CFE_TBL_PARTIAL_LOAD_ERR_EID 74
```

TBL Load Table Uninitialized Partial Load Event ID.

Type: ERROR

Cause:

TBL Load Table failure due to attempting a partial load to an uninitialized table. OVERLOADED

Definition at line 508 of file cfe\_tbl\_events.h.

**12.74.2.49 CFE\_TBL\_PROCESSOR\_ID\_ERR\_EID**

```
#define CFE_TBL_PROCESSOR_ID_ERR_EID 98
```

TBL Read Header Invalid Processor ID Event ID.

Type: ERROR

Cause:

Invalid processor ID in table file header.

Definition at line 785 of file cfe\_tbl\_events.h.

**12.74.2.50 CFE\_TBL\_REGISTER\_ERR\_EID**

```
#define CFE_TBL_REGISTER_ERR_EID 90
```

TBL Register Table Failed Event ID.

Type: ERROR

Cause:

TBL table registration failure. See system log for more information.

Definition at line 697 of file cfe\_tbl\_events.h.

**12.74.2.51 CFE\_TBL\_RESET\_INF\_EID**

```
#define CFE_TBL_RESET_INF_EID 11
```

TBL Reset Counters Command Success Event ID.

Type: DEBUG

Cause:

[TBL Reset Counters Command](#) success.

Definition at line 64 of file cfe\_tbl\_events.h.

**12.74.2.52 CFE\_TBL\_SHARE\_ERR\_EID**

```
#define CFE_TBL_SHARE_ERR_EID 91
```

TBL Share Table Failed Event ID.

Type: ERROR

Cause:

TBL share table failure. See system log for more information.

Definition at line 708 of file cfe\_tbl\_events.h.

**12.74.2.53 CFE\_TBL\_SPACECRAFT\_ID\_ERR\_EID**

```
#define CFE_TBL_SPACECRAFT_ID_ERR_EID 97
```

TBL Read Header Invalid Spacecraft ID Event ID.

Type: ERROR

Cause:

Invalid spacecraft ID in table file header.

Definition at line 774 of file cfe\_tbl\_events.h.

**12.74.2.54 CFE\_TBL\_TLM\_REG\_CMD\_INF\_EID**

```
#define CFE_TBL_TLM_REG_CMD_INF_EID 18
```

TBL Telemeter Table Registry Entry Command Success Event ID.

Type: DEBUG

Cause:

[TBL Telemeter Table Registry Entry command](#) successfully set the table registry index to telemeter in the next house-keeping packet.

Definition at line 146 of file cfe\_tbl\_events.h.

**12.74.2.55 CFE\_TBL\_TOO\_MANY\_DUMPS\_ERR\_EID**

```
#define CFE_TBL_TOO_MANY_DUMPS_ERR_EID 76
```

TBL Write Table Command Dump Only Control Blocks Exceeded Event ID.

Type: ERROR

Cause:

[TBL Write Table Command](#) failure due to exceeding the allocated number of control blocks available to write a dump only table.

Definition at line 532 of file cfe\_tbl\_events.h.

**12.74.2.56 CFE\_TBL\_TOO\_MANY\_VALIDATIONS\_ERR\_EID**

```
#define CFE_TBL_TOO_MANY_VALIDATIONS_ERR_EID 67
```

TBL Validate Table Command Result Storage Exceeded Event ID.

Type: ERROR

Cause:

[TBL Validate Table Command](#) failure due to exceeding result storage.

Definition at line 427 of file cfe\_tbl\_events.h.

**12.74.2.57 CFE\_TBL\_UNREGISTER\_ERR\_EID**

```
#define CFE_TBL_UNREGISTER_ERR_EID 92
```

TBL Unregister Table Failed Event ID.

Type: ERROR

Cause:

TBL unregister table failure. See system log for more information.

Definition at line 719 of file cfe\_tbl\_events.h.

**12.74.2.58 CFE\_TBL\_UNVALIDATED\_ERR\_EID**

```
#define CFE_TBL_UNVALIDATED_ERR_EID 81
```

TBL Activate Table Command Inactive Image Not Validated Event ID.

Type: ERROR

Cause:

[TBL Activate Table Command](#) failure due to the inactive image not being validated.

Definition at line 592 of file cfe\_tbl\_events.h.

**12.74.2.59 CFE\_TBL\_UPDATE\_ERR\_EID**

```
#define CFE_TBL_UPDATE_ERR_EID 95
```

TBL Update Table Failed Event ID.

Type: ERROR

Cause:

TBL update table failure due to an internal error. OVERLOADED

Definition at line 752 of file cfe\_tbl\_events.h.

**12.74.2.60 CFE\_TBL\_UPDATE\_SUCCESS\_INF\_EID**

```
#define CFE_TBL_UPDATE_SUCCESS_INF_EID 37
```

TBL Update Table Success Event ID.

Type: INFORMATION

Cause:

Table update successfully completed.

Definition at line 213 of file cfe\_tbl\_events.h.

**12.74.2.61 CFE\_TBL\_VAL\_REQ\_MADE\_INF\_EID**

```
#define CFE_TBL_VAL_REQ_MADE_INF_EID 16
```

TBL Validate Table Request Success Event ID.

Type: DEBUG

Cause:

[TBL Validate Table Command](#) success. Note this event signifies the request to validate the table has been successfully submitted. Completion will generate a [CFE\\_TBL\\_VALIDATION\\_INF\\_EID](#) or [CFE\\_TBL\\_VALIDATION\\_ERR\\_EID](#) event messages.

Definition at line 123 of file cfe\_tbl\_events.h.

**12.74.2.62 CFE\_TBL\_VALIDATION\_ERR\_EID**

```
#define CFE_TBL_VALIDATION_ERR_EID 96
```

TBL Validate Table Validation Failed Event ID.

Type: ERROR

Cause:

TBL validate table function indicates validation failed. OVERLOADED

Definition at line 763 of file cfe\_tbl\_events.h.

**12.74.2.63 CFE\_TBL\_VALIDATION\_INF\_EID**

```
#define CFE_TBL_VALIDATION_INF_EID 36
```

TBL Validate Table Success Event ID.

Type: INFORMATION

Cause:

Table active or inactive image successfully validated by the registered validation function. OVERLOADED

Definition at line 202 of file cfe\_tbl\_events.h.

**12.74.2.64 CFE\_TBL\_WRITE\_CFE\_HDR\_ERR\_EID**

```
#define CFE_TBL_WRITE_CFE_HDR_ERR_EID 63
```

TBL Write Standard File Header Failure Event ID.

Type: **ERROR**

Cause:

TBL Write Table or Table Registry File failure writing the standard file header. OVERLOADED

Definition at line 380 of file cfe\_tbl\_events.h.

**12.74.2.65 CFE\_TBL\_WRITE\_DUMP\_INF\_EID**

```
#define CFE_TBL_WRITE_DUMP_INF_EID 14
```

TBL Write Table To New File Success Event ID.

Type: **INFORMATION**

Cause:

TBL write table to a new file success.

Definition at line 98 of file cfe\_tbl\_events.h.

**12.74.2.66 CFE\_TBL\_WRITE\_REG\_DUMP\_INF\_EID**

```
#define CFE_TBL_WRITE_REG_DUMP_INF_EID 22
```

TBL Write Table Registry To New File Success Event ID.

Type: **DEBUG**

Cause:

TBL Write Table Registry to a new file completed successfully.

Definition at line 168 of file cfe\_tbl\_events.h.

**12.74.2.67 CFE\_TBL\_WRITE\_TBL\_HDR\_ERR\_EID**

```
#define CFE_TBL_WRITE_TBL_HDR_ERR_EID 64
```

TBL Write Table File Header Failure Event ID.

Type: ERROR

Cause:

TBL Write Table failure writing the table image file header.

Definition at line 391 of file cfe\_tbl\_events.h.

**12.74.2.68 CFE\_TBL\_WRITE\_TBL\_IMG\_ERR\_EID**

```
#define CFE_TBL_WRITE_TBL_IMG_ERR_EID 65
```

TBL Write Table File Data Failure Event ID.

Type: ERROR

Cause:

TBL Write Table failure writing the table data.

Definition at line 402 of file cfe\_tbl\_events.h.

**12.74.2.69 CFE\_TBL\_WRITE\_TBL\_REG\_ERR\_EID**

```
#define CFE_TBL_WRITE_TBL_REG_ERR_EID 68
```

TBL Write Table Registry File Data Failure Event ID.

Type: ERROR

Cause:

TB Write Table Registry failure writing file data.

Definition at line 438 of file cfe\_tbl\_events.h.

#### 12.74.2.70 CFE\_TBL\_ZERO\_LENGTH\_LOAD\_ERR\_EID

```
#define CFE_TBL_ZERO_LENGTH_LOAD_ERR_EID 73
```

TBL Load Table File Zero Length Event ID.

Type: ERROR

Cause:

TBL Load Table failure due to the file header specified size of data being zero.

Definition at line 497 of file cfe\_tbl\_events.h.

## 12.75 cfe/modules/tbl/fsw/inc/cfe\_tbl\_msg.h File Reference

```
#include "common_types.h"
#include "cfe_msg_hdr.h"
#include "cfe_tbl_extern_typedefs.h"
#include "cfe_time_extern_typedefs.h"
```

### Data Structures

- struct [CFE\\_TBL\\_NoArgsCmd](#)  
*Generic "no arguments" command.*
- struct [CFE\\_TBL\\_LoadCmd\\_Payload](#)  
*Load Table Command Payload.*
- struct [CFE\\_TBL\\_LoadCmd](#)  
*Load Table Command.*
- struct [CFE\\_TBL\\_DumpCmd\\_Payload](#)  
*Dump Table Command Payload.*
- struct [CFE\\_TBL\\_DumpCmd](#)
- struct [CFE\\_TBL\\_ValidateCmd\\_Payload](#)  
*Validate Table Command Payload.*
- struct [CFE\\_TBL\\_ValidateCmd](#)  
*Validate Table Command.*
- struct [CFE\\_TBL\\_ActivateCmd\\_Payload](#)  
*Activate Table Command Payload.*
- struct [CFE\\_TBL\\_ActivateCmd](#)  
*Activate Table Command.*
- struct [CFE\\_TBL\\_DumpRegistryCmd\\_Payload](#)  
*Dump Registry Command Payload.*

- struct [CFE\\_TBL\\_DumpRegistryCmd](#)  
*Dump Registry Command.*
- struct [CFE\\_TBL\\_SendRegistryCmd\\_Payload](#)  
*Send Table Registry Command Payload.*
- struct [CFE\\_TBL\\_SendRegistryCmd](#)  
*Send Table Registry Command.*
- struct [CFE\\_TBL\\_DeleteCDSCmd\\_Payload](#)  
*Delete Critical Table CDS Command Payload.*
- struct [CFE\\_TBL\\_DeleteCDSCmd](#)  
*Delete Critical Table CDS Command.*
- struct [CFE\\_TBL\\_AbortLoadCmd\\_Payload](#)  
*Abort Load Command Payload.*
- struct [CFE\\_TBL\\_AbortLoadCmd](#)  
*Abort Load Command.*
- struct [CFE\\_TBL\\_NotifyCmd\\_Payload](#)  
*Table Management Notification Command Payload.*
- struct [CFE\\_TBL\\_NotifyCmd](#)
- struct [CFE\\_TBL\\_HousekeepingTlm\\_Payload](#)
- struct [CFE\\_TBL\\_HousekeepingTlm](#)
- struct [CFE\\_TBL\\_TblRegPacket\\_Payload](#)
- struct [CFE\\_TBL\\_TableRegistryTlm](#)

## Macros

### Table Services Command Codes

- #define [CFE\\_TBL\\_NOOP\\_CC](#) 0
- #define [CFE\\_TBL\\_RESET\\_COUNTERS\\_CC](#) 1
- #define [CFE\\_TBL\\_LOAD\\_CC](#) 2
- #define [CFE\\_TBL\\_DUMP\\_CC](#) 3
- #define [CFE\\_TBL\\_VALIDATE\\_CC](#) 4
- #define [CFE\\_TBL\\_ACTIVATE\\_CC](#) 5
- #define [CFE\\_TBL\\_DUMP\\_REGISTRY\\_CC](#) 6
- #define [CFE\\_TBL\\_SEND\\_REGISTRY\\_CC](#) 7
- #define [CFE\\_TBL\\_DELETE\\_CDS\\_CC](#) 8
- #define [CFE\\_TBL\\_ABORT\\_LOAD\\_CC](#) 9

## Typedefs

- typedef struct [CFE\\_TBL\\_NoArgsCmd](#) [CFE\\_TBL\\_NoArgsCmd\\_t](#)  
*Generic "no arguments" command.*
- typedef [CFE\\_TBL\\_NoArgsCmd\\_t](#) [CFE\\_TBL\\_NoopCmd\\_t](#)
- typedef [CFE\\_TBL\\_NoArgsCmd\\_t](#) [CFE\\_TBL\\_ResetCountersCmd\\_t](#)
- typedef struct [CFE\\_TBL\\_LoadCmd\\_Payload](#) [CFE\\_TBL\\_LoadCmd\\_Payload\\_t](#)  
*Load Table Command Payload.*
- typedef struct [CFE\\_TBL\\_LoadCmd](#) [CFE\\_TBL\\_LoadCmd\\_t](#)  
*Load Table Command.*
- typedef struct [CFE\\_TBL\\_DumpCmd\\_Payload](#) [CFE\\_TBL\\_DumpCmd\\_Payload\\_t](#)  
*Dump Table Command Payload.*

- typedef struct `CFE_TBL_DumpCmd` `CFE_TBL_DumpCmd_t`
- typedef struct `CFE_TBL_ValidateCmd_Payload` `CFE_TBL_ValidateCmd_Payload_t`  
*Validate Table Command Payload.*
- typedef struct `CFE_TBL_ValidateCmd` `CFE_TBL_ValidateCmd_t`  
*Validate Table Command.*
- typedef struct `CFE_TBL_ActivateCmd_Payload` `CFE_TBL_ActivateCmd_Payload_t`  
*Activate Table Command Payload.*
- typedef struct `CFE_TBL_ActivateCmd` `CFE_TBL_ActivateCmd_t`  
*Activate Table Command.*
- typedef struct `CFE_TBL_DumpRegistryCmd_Payload` `CFE_TBL_DumpRegistryCmd_Payload_t`  
*Dump Registry Command Payload.*
- typedef struct `CFE_TBL_DumpRegistryCmd` `CFE_TBL_DumpRegistryCmd_t`  
*Dump Registry Command.*
- typedef struct `CFE_TBL_SendRegistryCmd_Payload` `CFE_TBL_SendRegistryCmd_Payload_t`  
*Send Table Registry Command Payload.*
- typedef struct `CFE_TBL_SendRegistryCmd` `CFE_TBL_SendRegistryCmd_t`  
*Send Table Registry Command.*
- typedef struct `CFE_TBL_DeleteCDSCmd_Payload` `CFE_TBL_DeleteCDSCmd_Payload_t`  
*Delete Critical Table CDS Command Payload.*
- typedef struct `CFE_TBL_DeleteCDSCmd` `CFE_TBL_DeleteCDSCmd_t`  
*Delete Critical Table CDS Command.*
- typedef struct `CFE_TBL_AbortLoadCmd_Payload` `CFE_TBL_AbortLoadCmd_Payload_t`  
*Abort Load Command Payload.*
- typedef struct `CFE_TBL_AbortLoadCmd` `CFE_TBL_AbortLoadCmd_t`  
*Abort Load Command.*
- typedef struct `CFE_TBL_NotifyCmd_Payload` `CFE_TBL_NotifyCmd_Payload_t`  
*Table Management Notification Command Payload.*
- typedef struct `CFE_TBL_NotifyCmd` `CFE_TBL_NotifyCmd_t`
- typedef struct `CFE_TBL_HousekeepingTlm_Payload` `CFE_TBL_HousekeepingTlm_Payload_t`
- typedef struct `CFE_TBL_HousekeepingTlm` `CFE_TBL_HousekeepingTlm_t`
- typedef struct `CFE_TBL_TblRegPacket_Payload` `CFE_TBL_TblRegPacket_Payload_t`
- typedef struct `CFE_TBL_TableRegistryTlm` `CFE_TBL_TableRegistryTlm_t`

### 12.75.1 Detailed Description

Purpose: cFE Table Services (TBL) SB message definitions header file

Author: D.Kobe/Hammers

Notes:

### 12.75.2 Macro Definition Documentation

### 12.75.2.1 CFE\_TBL\_ABORT\_LOAD\_CC

```
#define CFE_TBL_ABORT_LOAD_CC 9
```

**Name** Abort Table Load

#### Description

This command will cause Table Services to discard the contents of a table buffer that was previously loaded with the data in a file as specified by a Table Load command. For single buffered tables, the allocated shared working buffer is freed and becomes available for other Table Load commands.

**Command Mnemonic(s)** \$sc\_\$cpu\_TBL\_LOADABORT

#### Command Structure

`CFE_TBL_AbortLoadCmd_t`

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- `$sc_$cpu_TBL_CMDPC` - command execution counter will increment
- The `CFE_TBL_LOAD_ABORT_INF_EID` informational event message is generated
- If the load was aborted for a single buffered table, the `$sc_$cpu_TBL_NumFreeShrBuf` telemetry point should increment

#### Error Conditions

This command may fail for the following reason(s):

- The specified table name was not found in the table registry.
- The specified table did not have a load in progress to be aborted.

Evidence of failure may be found in the following telemetry:

- `$sc_$cpu_TBL_CMDEC` - command error counter will increment
- Error specific event message

#### Criticality

This command will cause the loss of data put into an inactive table buffer.

#### See also

[CFE\\_TBL\\_LOAD\\_CC](#), [CFE\\_TBL\\_DUMP\\_CC](#), [CFE\\_TBL\\_VALIDATE\\_CC](#), [CFE\\_TBL\\_ACTIVATE\\_CC](#)

Definition at line 473 of file `cfe_tbl_msg.h`.

### 12.75.2.2 CFE\_TBL\_ACTIVATE\_CC

```
#define CFE_TBL_ACTIVATE_CC 5
```

**Name** Activate Table

#### Description

This command will cause Table Services to notify a table's owner that an update is pending. The owning application will then update the contents of the active table buffer with the contents of the associated inactive table buffer at a time of their convenience.

**Command Mnemonic(s)** \$sc\_\$cpu\_TBL\_ACTIVATE

#### Command Structure

`CFE_TBL_ActivateCmd_t`

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- `$sc_$cpu_TBL_CMDPC` - command execution counter will increment
- The `CFE_TBL_UPDATE_SUCCESS_INF_EID` informational event message will be generated

#### Error Conditions

This command may fail for the following reason(s):

- The specified table name was not found in the table registry.
- The table was registered as a "dump only" type and thus cannot be activated
- The table buffer has not been validated.

Evidence of failure may be found in the following telemetry:

- `$sc_$cpu_TBL_CMDEC` - command error counter will increment
- Command specific error event message are issued for all error cases

#### Criticality

This command will cause the contents of the specified table to be updated with the contents in the inactive table buffer.

#### See also

[CFE\\_TBL\\_LOAD\\_CC](#), [CFE\\_TBL\\_DUMP\\_CC](#), [CFE\\_TBL\\_VALIDATE\\_CC](#), [CFE\\_TBL\\_ABORT\\_LOAD\\_CC](#)

Definition at line 311 of file `cfe_tbl_msg.h`.

### 12.75.2.3 CFE\_TBL\_DELETE\_CDS\_CC

```
#define CFE_TBL_DELETE_CDS_CC 8
```

**Name** Delete Critical Table from Critical Data Store

#### Description

This command will delete the Critical Data Store (CDS) associated with the specified Critical Table. Note that any table still present in the Table Registry is unable to be deleted from the Critical Data Store. All Applications that are accessing the critical table must release and unregister their access before the CDS can be deleted.

**Command Mnemonic(s)** \$sc\_\$cpu\_TBL\_DeleteCDS

#### Command Structure

`CFE_TBL_DeleteCDSCmd_t`

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- `$sc_$cpu_TBL_CMDPC` - command execution counter will increment
- The `CFE_TBL_CDS_DELETED_INFO_EID` informational event message will be generated

#### Error Conditions

This command may fail for the following reason(s):

- The specified table name was not found in the critical data store registry
- The specified table name WAS found in the table registry (all registrations/sharing of the table must be unregistered before the table's CDS can be deleted)
- The table's owning application is still active

Evidence of failure may be found in the following telemetry:

- `$sc_$cpu_TBL_CMDEC` - command error counter will increment
- Error specific event message

#### Criticality

This command will cause the loss of the specified table's contents before the owning Application was terminated.

#### See also

[CFE\\_ES\\_DUMP\\_CDS\\_REGISTRY\\_CC](#), [CFE\\_ES\\_DELETE\\_CDS\\_CC](#)

Definition at line 434 of file `cfe_tbl_msg.h`.

#### 12.75.2.4 CFE\_TBL\_DUMP\_CC

```
#define CFE_TBL_DUMP_CC 3
```

##### Name Dump Table

##### Description

This command will cause the Table Services to put the contents of the specified table buffer into the command specified file.

##### Command Mnemonic(s) \$sc\_\$cpu\_TBL\_DUMP

##### Command Structure

[CFE\\_TBL\\_DumpCmd\\_t](#)

##### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_TBL\\_CMDPC](#) - command execution counter will increment
- Either the [CFE\\_TBL\\_OVERWRITE\\_DUMP\\_INF\\_EID](#) OR the [CFE\\_TBL\\_WRITE\\_DUMP\\_INF\\_EID](#) informational event message will be generated

##### Error Conditions

This command may fail for the following reason(s):

- A single buffered table's inactive buffer was requested to be dumped and no such buffer is currently allocated.
- Error occurred during write operation to file. Possible causes might be insufficient space in the file system or the filename or file path is improperly specified.
- The specified table name was not found in the table registry.

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_TBL\\_CMDEC](#) - command error counter will increment
- A command specific error event message is issued for all error cases

##### Criticality

This command is not inherently dangerous. It will create a new file in the file system and could, if performed repeatedly without sufficient file management by the operator, fill the file system.

##### See also

[CFE\\_TBL\\_LOAD\\_CC](#), [CFE\\_TBL\\_VALIDATE\\_CC](#), [CFE\\_TBL\\_ACTIVATE\\_CC](#), [CFE\\_TBL\\_ABORT\\_LOAD\\_CC](#)

Definition at line 214 of file `cfe_tbl_msg.h`.

### 12.75.2.5 CFE\_TBL\_DUMP\_REGISTRY\_CC

```
#define CFE_TBL_DUMP_REGISTRY_CC 6
```

**Name** Dump Table Registry

#### Description

This command will cause Table Services to write some of the contents of the Table Registry to the command specified file. This allows the operator to see the current state and configuration of all tables that have been registered with the cFE.

**Command Mnemonic(s)** \$sc\_\$cpu\_TBL\_WriteReg2File

#### Command Structure

[CFE\\_TBL\\_DumpRegistryCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_TBL\\_CMDPC](#) - command execution counter will increment
- The generation of either [CFE\\_TBL\\_OVERWRITE\\_REG\\_DUMP\\_INF\\_EID](#) or [CFE\\_TBL\\_WRITE\\_REG\\_DUMP\\_INF\\_EID](#) debug event messages
- The specified file should appear (or be updated) at the specified location in the file system

#### Error Conditions

This command may fail for the following reason(s):

- A table registry dump is already in progress, not yet completed
- The specified DumpFilename could not be parsed
- Error occurred during write operation to file. Possible causes might be insufficient space in the file system or the filename or file path is improperly specified.

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_TBL\\_CMDEC](#) - command error counter will increment
- An Error specific event message

#### Criticality

This command is not inherently dangerous. It will create a new file in the file system and could, if performed repeatedly without sufficient file management by the operator, fill the file system.

#### See also

[CFE\\_TBL\\_SEND\\_REGISTRY\\_CC](#)

Definition at line 355 of file `cfe_tbl_msg.h`.

### 12.75.2.6 CFE\_TBL\_LOAD\_CC

```
#define CFE_TBL_LOAD_CC 2
```

#### Name Load Table

#### Description

This command loads the contents of the specified file into an inactive buffer for the table specified within the file.

#### Command Mnemonic(s) \$sc\_\$cpu\_TBL\_Load

#### Command Structure

[CFE\\_TBL\\_LoadCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_TBL\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_TBL\\_FILE\\_LOADED\\_INF\\_EID](#) informational event message will be generated

#### Error Conditions

This command can fail for the following reasons:

- Table name found in table image file's table header is not found in table registry (ie - The table associated with the table image in the file has not been registered by an application).
- The table image file has an invalid or incorrect size. The size of the image file must match the size field within in the header, and must also match the expected size of the table indicated in the registry.
- No working buffers are available for the load. This would indicate that too many single-buffered table loads are in progress at the same time.
- An attempt is being made to load an uninitialized table with a file containing only a partial table image.
- The table image file was unable to be opened. Either the file does not exist at the specified location, the filename is in error, or the file system has been corrupted.

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_TBL\\_CMDEC](#) - command error counter will increment
- Command specific error event messages are issued for all error cases

#### Criticality

This command is not inherently dangerous. It is performing the first step of loading a table and can be aborted (using the Abort Table Load command described below) without affecting the contents of the active table image.

#### See also

[CFE\\_TBL\\_DUMP\\_CC](#), [CFE\\_TBL\\_VALIDATE\\_CC](#), [CFE\\_TBL\\_ACTIVATE\\_CC](#), [CFE\\_TBL\\_ABORT\\_LOAD\\_CC](#)

Definition at line 171 of file `cfe_tbl_msg.h`.

### 12.75.2.7 CFE\_TBL\_NOOP\_CC

```
#define CFE_TBL_NOOP_CC 0
```

**Name** Table No-Op

#### Description

This command performs no other function than to increment the command execution counter. The command may be used to verify general aliveness of the Table Services task.

**Command Mnemonic(s)** \$sc\_\$cpu\_TBL\_NOOP

#### Command Structure

[CFE\\_TBL\\_NoopCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_TBL\\_CMDPC](#) - command execution counter will increment
- The [CFE\\_TBL\\_NOOP\\_INF\\_EID](#) informational event message will be generated

#### Error Conditions

There are no error conditions for this command. If the Table Services receives the command, the event is sent (although it may be filtered by EVS) and the counter is incremented unconditionally.

#### Criticality

None

#### See also

Definition at line 80 of file cfe\_tbl\_msg.h.

### 12.75.2.8 CFE\_TBL\_RESET\_COUNTERS\_CC

```
#define CFE_TBL_RESET_COUNTERS_CC 1
```

#### Name Table Reset Counters

##### Description

This command resets the following counters within the Table Services housekeeping telemetry:

- Command Execution Counter (\$sc\_\$cpu\_TBL\_CMDPC)
- Command Error Counter (\$sc\_\$cpu\_TBL\_CMDEC)
- Successful Table Validations Counter (\$sc\_\$cpu\_TBL\_ValSuccessCtr)
- Failed Table Validations Counter (\$sc\_\$cpu\_TBL\_ValFailedCtr)
- Number of Table Validations Requested (\$sc\_\$cpu\_TBL\_ValReqCtr)
- Number of completed table validations (\$sc\_\$cpu\_TBL\_ValCompltdCtr)

#### Command Mnemonic(s) \$sc\_\$cpu\_TBL\_ResetCtrs

##### Command Structure

[CFE\\_TBL\\_ResetCountersCmd\\_t](#)

##### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_TBL\_CMDPC** - command execution counter will be reset to 0
- The [CFE\\_TBL\\_RESET\\_INF\\_EID](#) debug event message will be generated

##### Error Conditions

There are no error conditions for this command. If the Table Services receives the command, the event is sent (although it may be filtered by EVS) and the counter is incremented unconditionally.

##### Criticality

This command is not inherently dangerous. However, it is possible for ground systems and on-board safing procedures to be designed such that they react to changes in the counter values that are reset by this command.

##### See also

Definition at line 121 of file [cfe\\_tbl\\_msg.h](#).

### 12.75.2.9 CFE\_TBL\_SEND\_REGISTRY\_CC

```
#define CFE_TBL_SEND_REGISTRY_CC 7
```

**Name** Telemeter One Table Registry Entry

#### Description

This command will cause Table Services to telemeter the contents of the Table Registry for the command specified table.

**Command Mnemonic(s)** \$sc\_\$cpu\_TBL\_TLMReg

#### Command Structure

[CFE\\_TBL\\_SendRegistryCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_TBL\\_CMDPC](#) - command execution counter will increment
- Receipt of a Table Registry Info Packet (see [CFE\\_TBL\\_TableRegistryTlm\\_t](#))
- The [CFE\\_TBL\\_TLM\\_REG\\_CMD\\_INF\\_EID](#) debug event message will be generated

#### Error Conditions

This command may fail for the following reason(s):

- The specified table name was not found in the table registry.

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_TBL\\_CMDEC](#) - command error counter will increment
- Error specific event message

#### Criticality

This command is not inherently dangerous. It will generate additional telemetry.

#### See also

[CFE\\_TBL\\_DUMP\\_REGISTRY\\_CC](#)

Definition at line 390 of file cfe\_tbl\_msg.h.

### 12.75.2.10 CFE\_TBL\_VALIDATE\_CC

```
#define CFE_TBL_VALIDATE_CC 4
```

#### Name Validate Table

#### Description

This command will cause Table Services to calculate the Data Integrity Value for the specified table and to notify the owning application that the table's validation function should be executed. The results of both the Data Integrity Value computation and the validation function are reported in Table Services Housekeeping Telemetry.

#### Command Mnemonic(s) \$sc\_\$cpu\_TBL\_VALIDATE

#### Command Structure

[CFE\\_TBL\\_ValidateCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_TBL\\_CMDPC](#) - command execution counter will increment
- [\\$sc\\_\\$cpu\\_TBL\\_ValReqCtr](#) - table validation request counter will increment
- [\\$sc\\_\\$cpu\\_TBL\\_LastValCRC](#) - calculated data integrity value will be updated
- The [CFE\\_TBL\\_VAL\\_REQ\\_MADE\\_INF\\_EID](#) debug event message (indicating the application is being notified of a validation request)

If the specified table has an associated validation function, then the following telemetry will also change:

- Either [\\$sc\\_\\$cpu\\_TBL\\_ValSuccessCtr](#) OR [\\$sc\\_\\$cpu\\_TBL\\_ValFailedCtr](#) will increment
- [\\$sc\\_\\$cpu\\_TBL\\_ValCompltdCtr](#) - table validations performed counter will increment
- [\\$sc\\_\\$cpu\\_TBL\\_LastVals](#) - table validation function return status will update
- The [CFE\\_TBL\\_VALIDATION\\_INF\\_EID](#) informational event message (indicating the validation function return status) will be generated

#### Error Conditions

This command may fail for the following reason(s):

- A single buffered table's inactive buffer was requested to be validated and no such buffer is currently allocated.
- Too many validations have been requested simultaneously. The operator must wait for one or more applications to perform their table validation functions before trying again.
- The specified table name was not found in the table registry.

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_TBL\\_CMDEC](#) - command error counter will increment
- Command specific error event message are issued for all error cases

#### Criticality

The success or failure of a table validation does not have any immediate impact on table contents. The results are sent to the operator in telemetry and the operator must determine whether the results are acceptable and send a command to activate the validated table image.

See also

[CFE\\_TBL\\_LOAD\\_CC](#), [CFE\\_TBL\\_DUMP\\_CC](#), [CFE\\_TBL\\_ACTIVATE\\_CC](#), [CFE\\_TBL\\_ABORT\\_LOAD\\_CC](#)

Definition at line 271 of file `cfe_tbl_msg.h`.

### 12.75.3 Typedef Documentation

#### 12.75.3.1 CFE\_TBL\_AbortLoadCmd\_Payload\_t

```
typedef struct CFE_TBL_AbortLoadCmd_Payload CFE_TBL_AbortLoadCmd_Payload_t
```

Abort Load Command Payload.

For command details, see [CFE\\_TBL\\_ABORT\\_LOAD\\_CC](#)

#### 12.75.3.2 CFE\_TBL\_AbortLoadCmd\_t

```
typedef struct CFE_TBL_AbortLoadCmd CFE_TBL_AbortLoadCmd_t
```

Abort Load Command.

#### 12.75.3.3 CFE\_TBL\_ActivateCmd\_Payload\_t

```
typedef struct CFE_TBL_ActivateCmd_Payload CFE_TBL_ActivateCmd_Payload_t
```

Activate Table Command Payload.

For command details, see [CFE\\_TBL\\_ACTIVATE\\_CC](#)

#### 12.75.3.4 CFE\_TBL\_ActivateCmd\_t

```
typedef struct CFE_TBL_ActivateCmd CFE_TBL_ActivateCmd_t
```

Activate Table Command.

#### 12.75.3.5 CFE\_TBL\_DelCDSCmd\_Payload\_t

```
typedef struct CFE_TBL_DelCDSCmd_Payload CFE_TBL_DelCDSCmd_Payload_t
```

Delete Critical Table CDS Command Payload.

For command details, see [CFE\\_TBL\\_DELETE\\_CDS\\_CC](#)

### 12.75.3.6 CFE\_TBL\_DeleteCDSCmd\_t

```
typedef struct CFE_TBL_DeleteCDSCmd CFE_TBL_DeleteCDSCmd_t
```

Delete Critical Table CDS Command.

### 12.75.3.7 CFE\_TBL\_DumpCmd\_Payload\_t

```
typedef struct CFE_TBL_DumpCmd_Payload CFE_TBL_DumpCmd_Payload_t
```

Dump Table Command Payload.

For command details, see [CFE\\_TBL\\_DUMP\\_CC](#)

### 12.75.3.8 CFE\_TBL\_DumpCmd\_t

```
typedef struct CFE_TBL_DumpCmd CFE_TBL_DumpCmd_t
```

/brief Dump Table Command

### 12.75.3.9 CFE\_TBL\_DumpRegistryCmd\_Payload\_t

```
typedef struct CFE_TBL_DumpRegistryCmd_Payload CFE_TBL_DumpRegistryCmd_Payload_t
```

Dump Registry Command Payload.

For command details, see [CFE\\_TBL\\_DUMP\\_REGISTRY\\_CC](#)

### 12.75.3.10 CFE\_TBL\_DumpRegistryCmd\_t

```
typedef struct CFE_TBL_DumpRegistryCmd CFE_TBL_DumpRegistryCmd_t
```

Dump Registry Command.

### 12.75.3.11 CFE\_TBL\_HousekeepingTlm\_Payload\_t

```
typedef struct CFE_TBL_HousekeepingTlm_Payload CFE_TBL_HousekeepingTlm_Payload_t
```

**Name** Table Services Housekeeping Packet

### 12.75.3.12 CFE\_TBL\_HousekeepingTlm\_t

```
typedef struct CFE_TBL_HousekeepingTlm CFE_TBL_HousekeepingTlm_t
```

### 12.75.3.13 CFE\_TBL\_LoadCmd\_Payload\_t

```
typedef struct CFE_TBL_LoadCmd_Payload CFE_TBL_LoadCmd_Payload_t
```

Load Table Command Payload.

For command details, see [CFE\\_TBL\\_LOAD\\_CC](#)

### 12.75.3.14 CFE\_TBL\_LoadCmd\_t

```
typedef struct CFE_TBL_LoadCmd CFE_TBL_LoadCmd_t
```

Load Table Command.

### 12.75.3.15 CFE\_TBL\_NoArgsCmd\_t

```
typedef struct CFE_TBL_NoArgsCmd CFE_TBL_NoArgsCmd_t
```

Generic "no arguments" command.

This command structure is used for commands that do not have any parameters. This includes:

1. The Housekeeping Request Message
2. The No-Op Command (For details, see [CFE\\_TBL\\_NOOP\\_CC](#))
3. The Reset Counters Command (For details, see [CFE\\_TBL\\_RESET\\_COUNTERS\\_CC](#))

### 12.75.3.16 CFE\_TBL\_NoopCmd\_t

```
typedef CFE_TBL_NoArgsCmd_t CFE_TBL_NoopCmd_t
```

Definition at line 500 of file cfe\_tbl\_msg.h.

**12.75.3.17 CFE\_TBL\_NotifyCmd\_Payload\_t**

```
typedef struct CFE_TBL_NotifyCmd_Payload CFE_TBL_NotifyCmd_Payload_t
```

Table Management Notification Command Payload.

**Description**

Whenever an application that owns a table calls the [CFE\\_TBL\\_NotifyByMessage](#) API following the table registration, Table services will generate the following command message with the application specified message ID, command code and parameter whenever the table requires management (e.g. - loads and validations).

**12.75.3.18 CFE\_TBL\_NotifyCmd\_t**

```
typedef struct CFE_TBL_NotifyCmd CFE_TBL_NotifyCmd_t
```

/brief Table Management Notification Command

**12.75.3.19 CFE\_TBL\_ResetCountersCmd\_t**

```
typedef CFE_TBL_NoArgsCmd_t CFE_TBL_ResetCountersCmd_t
```

Definition at line 501 of file cfe\_tbl\_msg.h.

**12.75.3.20 CFE\_TBL\_SendRegistryCmd\_Payload\_t**

```
typedef struct CFE_TBL_SendRegistryCmd_Payload CFE_TBL_SendRegistryCmd_Payload_t
```

Send Table Registry Command Payload.

For command details, see [CFE\\_TBL\\_SEND\\_REGISTRY\\_CC](#)

**12.75.3.21 CFE\_TBL\_SendRegistryCmd\_t**

```
typedef struct CFE_TBL_SendRegistryCmd CFE_TBL_SendRegistryCmd_t
```

Send Table Registry Command.

**12.75.3.22 CFE\_TBL\_TableRegistryTlm\_t**

```
typedef struct CFE_TBL_TableRegistryTlm CFE_TBL_TableRegistryTlm_t
```

### 12.75.3.23 CFE\_TBL\_TblRegPacket\_Payload\_t

```
typedef struct CFE_TBL_TblRegPacket_Payload CFE_TBL_TblRegPacket_Payload_t
```

**Name** Table Registry Info Packet

### 12.75.3.24 CFE\_TBL\_ValidateCmd\_Payload\_t

```
typedef struct CFE_TBL_ValidateCmd_Payload CFE_TBL_ValidateCmd_Payload_t
```

Validate Table Command Payload.

For command details, see [CFE\\_TBL\\_VALIDATE\\_CC](#)

### 12.75.3.25 CFE\_TBL\_ValidateCmd\_t

```
typedef struct CFE_TBL_ValidateCmd CFE_TBL_ValidateCmd_t
```

Validate Table Command.

## 12.76 cfe/modules/time/fsw/inc/cfe\_time\_events.h File Reference

### Macros

#### TIME event IDs

- #define [CFE\\_TIME\\_INIT\\_EID](#) 1  
*TIME Initialization Event ID.*
- #define [CFE\\_TIME\\_NOOP\\_EID](#) 4  
*TIME No-op Command Success Event ID.*
- #define [CFE\\_TIME\\_RESET\\_EID](#) 5  
*TIME Reset Counters Command Success Event ID.*
- #define [CFE\\_TIME\\_DIAG\\_EID](#) 6  
*TIME Request Diagnostics Command Success Event ID.*
- #define [CFE\\_TIME\\_STATE\\_EID](#) 7  
*TIME Set Time State Command Success Event ID.*
- #define [CFE\\_TIME\\_SOURCE\\_EID](#) 8  
*TIME Set Time Source Command Success Event ID.*
- #define [CFE\\_TIME\\_SIGNAL\\_EID](#) 9  
*TIME Set Tone Source Command Success Event ID.*
- #define [CFE\\_TIME\\_DELAY\\_EID](#) 11  
*TIME Add or Subtract Delay Command Success Event ID.*
- #define [CFE\\_TIME\\_TIME\\_EID](#) 12  
*TIME Set Time Command Success Event ID.*
- #define [CFE\\_TIME\\_MET\\_EID](#) 13  
*TIME Set Mission Elapsed Time Command Success Event ID.*
- #define [CFE\\_TIME\\_STCF\\_EID](#) 14  
*TIME Set Spacecraft Time Correlation Factor Command Success Event ID.*

- #define `CFE_TIME_DELTA_EID` 15  
*TIME Add or Subtract Single STCF Adjustment Command Success Event ID.*
- #define `CFE_TIME_1HZ_EID` 16  
*TIME Add or Subtract STCF Adjustment Each Second Command Success Event ID.*
- #define `CFE_TIME_LEAPS_EID` 17  
*TIME Set Leap Seconds Command Success Event ID.*
- #define `CFE_TIME_FLY_ON_EID` 20  
*TIME Entered FLYWHEEL Mode Event ID.*
- #define `CFE_TIME_FLY_OFF_EID` 21  
*TIME Exited FLYWHEEL Mode Event ID.*
- #define `CFE_TIME_ID_ERR_EID` 26  
*TIME Invalid Message ID Received Event ID.*
- #define `CFE_TIME_CC_ERR_EID` 27  
*TIME Invalid Command Code Received Event ID.*
- #define `CFE_TIME_STATE_ERR_EID` 30  
*TIME Set Clock State Command Invalid State Event ID.*
- #define `CFE_TIME_SOURCE_ERR_EID` 31  
*TIME Set Clock Source Command Invalid Source Event ID.*
- #define `CFE_TIME_SIGNAL_ERR_EID` 32  
*TIME Set Clock Tone Source Command Invalid Source Event ID.*
- #define `CFE_TIME_DELAY_ERR_EID` 33  
*TIME Add or Subtract Tone Delay Command Invalid Time Value Event ID.*
- #define `CFE_TIME_TIME_ERR_EID` 34  
*TIME Set Spacecraft Time Command Invalid Time Value Event ID.*
- #define `CFE_TIME_MET_ERR_EID` 35  
*TIME Set Mission Elapsed Time Command Invalid Time Value Event ID.*
- #define `CFE_TIME_STCF_ERR_EID` 36  
*TIME Set Spacecraft Time Correlation Factor Command Invalid Time Value Event ID.*
- #define `CFE_TIME_DELTA_ERR_EID` 37  
*TIME Add or Subtract Single STCF Adjustment Command Invalid Time Value Event ID.*
- #define `CFE_TIME_SOURCE_CFG_EID` 40  
*TIME Set Clock Source Command Incompatible Mode Event ID.*
- #define `CFE_TIME_SIGNAL_CFG_EID` 41  
*TIME Set Clock Signal Command Incompatible Mode Event ID.*
- #define `CFE_TIME_DELAY_CFG_EID` 42  
*TIME Add or Subtract Tone Delay Command Incompatible Mode Event ID.*
- #define `CFE_TIME_TIME_CFG_EID` 43  
*TIME Set Spacecraft Time Command Incompatible Mode Event ID.*
- #define `CFE_TIME_MET_CFG_EID` 44  
*TIME Set Mission Elapsed Time Command Incompatible Mode Event ID.*
- #define `CFE_TIME_STCF_CFG_EID` 45  
*TIME Set Spacecraft Time Correlation Factor Command Incompatible Mode Event ID.*
- #define `CFE_TIME_LEAPS_CFG_EID` 46  
*TIME Set Leap Seconds Command Incompatible Mode Event ID.*
- #define `CFE_TIME_DELTA_CFG_EID` 47  
*TIME Add or Subtract Single STCF Adjustment Command Incompatible Mode Event ID.*
- #define `CFE_TIME_1HZ_CFG_EID` 48  
*TIME Add or Subtract STCF Adjustment Each Second Command Incompatible Mode Event ID.*
- #define `CFE_TIME_LEN_ERR_EID` 49  
*TIME Invalid Command Length Event ID.*

### 12.76.1 Detailed Description

cFE Time Services Event IDs

## 12.76.2 Macro Definition Documentation

### 12.76.2.1 CFE\_TIME\_1HZ\_CFG\_EID

```
#define CFE_TIME_1HZ_CFG_EID 48
```

TIME Add or Subtract STCF Adjustment Each Second Command Incompatible Mode Event ID.

Type: ERROR

Cause:

TIME Add STCF Adjustment Each Second Command OR TIME Subtract STCF Adjustment Each Second Command failure due to being in an incompatible mode.

Definition at line 438 of file cfe\_time\_events.h.

### 12.76.2.2 CFE\_TIME\_1HZ\_EID

```
#define CFE_TIME_1HZ_EID 16
```

TIME Add or Subtract STCF Adjustment Each Second Command Success Event ID.

Type: INFORMATION

Cause:

TIME Add STCF Adjustment Each Second Command OR TIME Subtract STCF Adjustment Each Second Command success.

Definition at line 177 of file cfe\_time\_events.h.

### 12.76.2.3 CFE\_TIME\_CC\_ERR\_EID

```
#define CFE_TIME_CC_ERR_EID 27
```

TIME Invalid Command Code Received Event ID.

Type: **ERROR**

Cause:

Invalid command code for message ID [CFE\\_TIME\\_CMD\\_MID](#) received on the TIME message pipe.

Definition at line 232 of file [cfe\\_time\\_events.h](#).

### 12.76.2.4 CFE\_TIME\_DELAY\_CFG\_EID

```
#define CFE_TIME_DELAY_CFG_EID 42
```

TIME Add or Subtract Tone Delay Command Incompatible Mode Event ID.

Type: **ERROR**

Cause:

[TIME Add Tone Delay Command](#) OR [TIME Subtract Tone Delay Command](#) failure due to being in an incompatible mode.

Definition at line 364 of file [cfe\\_time\\_events.h](#).

### 12.76.2.5 CFE\_TIME\_DELAY\_EID

```
#define CFE_TIME_DELAY_EID 11
```

TIME Add or Subtract Delay Command Success Event ID.

Type: **INFORMATION**

Cause:

[TIME Add Time Delay Command](#) OR a [Subtract Time Delay Command](#) success.

Definition at line 120 of file [cfe\\_time\\_events.h](#).

#### 12.76.2.6 CFE\_TIME\_DELAY\_ERR\_EID

```
#define CFE_TIME_DELAY_ERR_EID 33
```

TIME Add or Subtract Tone Delay Command Invalid Time Value Event ID.

Type: ERROR

Cause:

[TIME Add Tone Delay Command](#) OR [TIME Subtract Tone Delay Command](#) failure due to an invalid time value.

Definition at line 278 of file cfe\_time\_events.h.

#### 12.76.2.7 CFE\_TIME\_DELTA\_CFG\_EID

```
#define CFE_TIME_DELTA_CFG_EID 47
```

TIME Add or Subtract Single STCF Adjustment Command Incompatible Mode Event ID.

Type: ERROR

Cause:

[TIME Add Single STCF Adjustment Command](#) OR [TIME Subtract Single STCF Adjustment Command](#) failure due to being in an incompatible mode.

Definition at line 425 of file cfe\_time\_events.h.

#### 12.76.2.8 CFE\_TIME\_DELTA\_EID

```
#define CFE_TIME_DELTA_EID 15
```

TIME Add or Subtract Single STCF Adjustment Command Success Event ID.

Type: INFORMATION

Cause:

[TIME Add Single STCF Adjustment Command](#) OR [TIME Subtract Single STCF Adjustment Command](#) success.

Definition at line 165 of file cfe\_time\_events.h.

### 12.76.2.9 CFE\_TIME\_DELTA\_ERR\_EID

```
#define CFE_TIME_DELTA_ERR_EID 37
```

TIME Add or Subtract Single STCF Adjustment Command Invalid Time Value Event ID.

Type: ERROR

Cause:

[TIME Add Single STCF Adjustment Command](#) OR [TIME Subtract Single STCF Adjustment Command](#) failure due to an invalid time value.

Definition at line 327 of file `cfe_time_events.h`.

### 12.76.2.10 CFE\_TIME\_DIAG\_EID

```
#define CFE_TIME_DIAG_EID 6
```

TIME Request Diagnostics Command Success Event ID.

Type: DEBUG

Cause:

[TIME Request Diagnostics Command](#) success.

Definition at line 75 of file `cfe_time_events.h`.

### 12.76.2.11 CFE\_TIME\_FLY\_OFF\_EID

```
#define CFE_TIME_FLY_OFF_EID 21
```

TIME Exited FLYWHEEL Mode Event ID.

Type: INFORMATION

Cause:

TIME Exited FLYWHEEL Mode.

Definition at line 210 of file `cfe_time_events.h`.

**12.76.2.12 CFE\_TIME\_FLY\_ON\_EID**

```
#define CFE_TIME_FLY_ON_EID 20
```

TIME Entered FLYWHEEL Mode Event ID.

Type: INFORMATION

Cause:

TIME Entered FLYWHEEL Mode.

Definition at line 199 of file cfe\_time\_events.h.

**12.76.2.13 CFE\_TIME\_ID\_ERR\_EID**

```
#define CFE_TIME_ID_ERR_EID 26
```

TIME Invalid Message ID Received Event ID.

Type: ERROR

Cause:

Invalid message ID received on the TIME message pipe.

Definition at line 221 of file cfe\_time\_events.h.

**12.76.2.14 CFE\_TIME\_INIT\_EID**

```
#define CFE_TIME_INIT_EID 1
```

TIME Initialization Event ID.

Type: INFORMATION

Cause:

Time Services Task Initialization complete.

Definition at line 42 of file cfe\_time\_events.h.

**12.76.2.15 CFE\_TIME\_LEAPS\_CFG\_EID**

```
#define CFE_TIME_LEAPS_CFG_EID 46
```

TIME Set Leap Seconds Command Incompatible Mode Event ID.

Type: **ERROR**

Cause:

[TIME Set Leap Seconds Command](#) failure due to being in an incompatible mode.

Definition at line 412 of file `cfe_time_events.h`.

**12.76.2.16 CFE\_TIME\_LEAPS\_EID**

```
#define CFE_TIME_LEAPS_EID 17
```

TIME Set Leap Seconds Command Success Event ID.

Type: **INFORMATION**

Cause:

[TIME Set Leap Seconds Command](#) success.

Definition at line 188 of file `cfe_time_events.h`.

**12.76.2.17 CFE\_TIME\_LEN\_ERR\_EID**

```
#define CFE_TIME_LEN_ERR_EID 49
```

TIME Invalid Command Length Event ID.

Type: **ERROR**

Cause:

Invalid length for the command code in message ID [CFE\\_TIME\\_CMD\\_MID](#) received on the TIME message pipe.

Definition at line 450 of file `cfe_time_events.h`.

**12.76.2.18 CFE\_TIME\_MET\_CFG\_EID**

```
#define CFE_TIME_MET_CFG_EID 44
```

TIME Set Mission Elapsed Time Command Incompatible Mode Event ID.

Type: **ERROR**

Cause:

[TIME Set Mission Elapsed Time Command](#) failure due to being in an incompatible mode.

Definition at line 388 of file cfe\_time\_events.h.

**12.76.2.19 CFE\_TIME\_MET\_EID**

```
#define CFE_TIME_MET_EID 13
```

TIME Set Mission Elapsed Time Command Success Event ID.

Type: **INFORMATION**

Cause:

[TIME Set Mission Elapsed Time Command](#) success.

Definition at line 142 of file cfe\_time\_events.h.

**12.76.2.20 CFE\_TIME\_MET\_ERR\_EID**

```
#define CFE_TIME_MET_ERR_EID 35
```

TIME Set Mission Elapsed Time Command Invalid Time Value Event ID.

Type: **ERROR**

Cause:

[TIME Set Mission Elapsed Time Command](#) failure due to an invalid time value.

Definition at line 302 of file cfe\_time\_events.h.

**12.76.2.21 CFE\_TIME\_NOOP\_EID**

```
#define CFE_TIME_NOOP_EID 4
```

TIME No-op Command Success Event ID.

Type: INFORMATION

Cause:

TIME NO-OP Command success.

Definition at line 53 of file cfe\_time\_events.h.

**12.76.2.22 CFE\_TIME\_RESET\_EID**

```
#define CFE_TIME_RESET_EID 5
```

TIME Reset Counters Command Success Event ID.

Type: DEBUG

Cause:

TIME Reset Counters Command success.

Definition at line 64 of file cfe\_time\_events.h.

**12.76.2.23 CFE\_TIME\_SIGNAL\_CFG\_EID**

```
#define CFE_TIME_SIGNAL_CFG_EID 41
```

TIME Set Clock Signal Command Incompatible Mode Event ID.

Type: ERROR

Cause:

TIME Set Clock Signal Command failure due to being in an incompatible mode.

Definition at line 351 of file cfe\_time\_events.h.

#### 12.76.2.24 CFE\_TIME\_SIGNAL\_EID

```
#define CFE_TIME_SIGNAL_EID 9
```

TIME Set Tone Source Command Success Event ID.

Type: INFORMATION

Cause:

[TIME Set Clock Tone Source Command](#) success.

Definition at line 108 of file cfe\_time\_events.h.

#### 12.76.2.25 CFE\_TIME\_SIGNAL\_ERR\_EID

```
#define CFE_TIME_SIGNAL_ERR_EID 32
```

TIME Set Clock Tone Source Command Invalid Source Event ID.

Type: ERROR

Cause:

[Set Clock Tone Source Command](#) failed due to invalid source requested.

Definition at line 265 of file cfe\_time\_events.h.

#### 12.76.2.26 CFE\_TIME\_SOURCE\_CFG\_EID

```
#define CFE_TIME_SOURCE_CFG_EID 40
```

TIME Set Clock Source Command Incompatible Mode Event ID.

Type: ERROR

Cause:

[TIME Set Clock Source Command](#) failure due to being in an incompatible mode.

Definition at line 339 of file cfe\_time\_events.h.

**12.76.2.27 CFE\_TIME\_SOURCE\_EID**

```
#define CFE_TIME_SOURCE_EID 8
```

TIME Set Time Source Command Success Event ID.

Type: INFORMATION

Cause:

[TIME Set Time Source Command](#) success.

Definition at line 97 of file cfe\_time\_events.h.

**12.76.2.28 CFE\_TIME\_SOURCE\_ERR\_EID**

```
#define CFE_TIME_SOURCE_ERR_EID 31
```

TIME Set Clock Source Command Invalid Source Event ID.

Type: ERROR

Cause:

[TIME Set Clock Source Command](#) failed due to invalid source requested.

Definition at line 254 of file cfe\_time\_events.h.

**12.76.2.29 CFE\_TIME\_STATE\_EID**

```
#define CFE_TIME_STATE_EID 7
```

TIME Set Time State Command Success Event ID.

Type: INFORMATION

Cause:

[TIME Set Time State Command](#) success.

Definition at line 86 of file cfe\_time\_events.h.

**12.76.2.30 CFE\_TIME\_STATE\_ERR\_EID**

```
#define CFE_TIME_STATE_ERR_EID 30
```

TIME Set Clock State Command Invalid State Event ID.

Type: ERROR

Cause:

[TIME Set Clock State Command](#) failed due to invalid state requested.

Definition at line 243 of file cfe\_time\_events.h.

**12.76.2.31 CFE\_TIME\_STCF\_CFG\_EID**

```
#define CFE_TIME_STCF_CFG_EID 45
```

TIME Set Spacecraft Time Correlation Factor Command Incompatible Mode Event ID.

Type: ERROR

Cause:

[TIME Set Spacecraft Time Correlation Factor Command](#) failure due to being in an incompatible mode.

Definition at line 400 of file cfe\_time\_events.h.

**12.76.2.32 CFE\_TIME\_STCF\_EID**

```
#define CFE_TIME_STCF_EID 14
```

TIME Set Spacecraft Time Correlation Factor Command Success Event ID.

Type: INFORMATION

Cause:

[TIME Set Spacecraft Time Correlation Factor Command](#) success.

Definition at line 153 of file cfe\_time\_events.h.

**12.76.2.33 CFE\_TIME\_STCF\_ERR\_EID**

```
#define CFE_TIME_STCF_ERR_EID 36
```

TIME Set Spacecraft Time Correlation Factor Command Invalid Time Value Event ID.

Type: ERROR

Cause:

TIME Set Spacecraft Time Correlation Factor Command failure due to an invalid time value.

Definition at line 314 of file cfe\_time\_events.h.

**12.76.2.34 CFE\_TIME\_TIME\_CFG\_EID**

```
#define CFE_TIME_TIME_CFG_EID 43
```

TIME Set Spacecraft Time Command Incompatible Mode Event ID.

Type: ERROR

Cause:

TIME Set Spacecraft Time Command failure due to being in an incompatible mode.

Definition at line 376 of file cfe\_time\_events.h.

**12.76.2.35 CFE\_TIME\_TIME\_EID**

```
#define CFE_TIME_TIME_EID 12
```

TIME Set Time Command Success Event ID.

Type: INFORMATION

Cause:

TIME Set Time Command success.

Definition at line 131 of file cfe\_time\_events.h.

### 12.76.2.36 CFE\_TIME\_TIME\_ERR\_EID

```
#define CFE_TIME_TIME_ERR_EID 34
```

TIME Set Spacecraft Time Command Invalid Time Value Event ID.

Type: ERROR

Cause:

TIME Set Spacecraft Time Command failure due to an invalid time value.

Definition at line 290 of file cfe\_time\_events.h.

## 12.77 cfe/modules/time/fsw/inc/cfe\_time\_msg.h File Reference

```
#include "common_types.h"
#include "cfe-msg-hdr.h"
#include "cfe_time_extern_typedefs.h"
```

### Data Structures

- struct [CFE\\_TIME\\_NoArgsCmd](#)  
*Generic no argument command.*
- struct [CFE\\_TIME\\_LeapsCmd\\_Payload](#)  
*Set leap seconds command payload.*
- struct [CFE\\_TIME\\_SetLeapSecondsCmd](#)  
*Set leap seconds command.*
- struct [CFE\\_TIME\\_StateCmd\\_Payload](#)  
*Set clock state command payload.*
- struct [CFE\\_TIME\\_SetStateCmd](#)  
*Set clock state command.*
- struct [CFE\\_TIME\\_SourceCmd\\_Payload](#)  
*Set time data source command payload.*
- struct [CFE\\_TIME\\_SetSourceCmd](#)  
*Set time data source command.*
- struct [CFE\\_TIME\\_SignalCmd\\_Payload](#)  
*Set tone signal source command payload.*
- struct [CFE\\_TIME\\_SetSignalCmd](#)  
*Set tone signal source command.*
- struct [CFE\\_TIME\\_TimeCmd\\_Payload](#)  
*Generic seconds, microseconds command payload.*

- struct `CFE_TIME_TimeCmd`  
*Generic seconds, microseconds argument command.*
- struct `CFE_TIME_OneHzAdjustmentCmd_Payload`  
*Generic seconds, subseconds command payload.*
- struct `CFE_TIME_OneHzAdjustmentCmd`  
*Generic seconds, subseconds adjustment command.*
- struct `CFE_TIME_ToneDataCmd_Payload`  
*Time at tone data command payload.*
- struct `CFE_TIME_ToneDataCmd`  
*Time at tone data command.*
- struct `CFE_TIME_HousekeepingTlm_Payload`
- struct `CFE_TIME_HousekeepingTlm`
- struct `CFE_TIME_DiagnosticTlm_Payload`
- struct `CFE_TIME_DiagnosticTlm`

## Macros

- `#define CFE_TIME_FLAG_CLKSET 0x8000`  
*The spacecraft time has been set.*
- `#define CFE_TIME_FLAG_FLYING 0x4000`  
*This instance of Time Services is flywheeling.*
- `#define CFE_TIME_FLAG_SRCINT 0x2000`  
*The clock source is set to "internal".*
- `#define CFE_TIME_FLAG_SIGPRI 0x1000`  
*The clock signal is set to "primary".*
- `#define CFE_TIME_FLAG_SRVFLY 0x0800`  
*The Time Server is in flywheel mode.*
- `#define CFE_TIME_FLAG_CMDFLY 0x0400`  
*This instance of Time Services was commanded into flywheel mode.*
- `#define CFE_TIME_FLAG_ADDADJ 0x0200`  
*One time STCF Adjustment is to be done in positive direction.*
- `#define CFE_TIME_FLAG_ADD1HZ 0x0100`  
*1 Hz STCF Adjustment is to be done in a positive direction*
- `#define CFE_TIME_FLAG_ADDTCL 0x0080`  
*Time Client Latency is applied in a positive direction.*
- `#define CFE_TIME_FLAG_SERVER 0x0040`  
*This instance of Time Services is a Time Server.*
- `#define CFE_TIME_FLAG_GDTONE 0x0020`  
*The tone received is good compared to the last tone received.*
- `#define CFE_TIME_FLAG_REFERR 0x0010`  
*GetReference read error, will be set if unable to get a consistent ref value.*
- `#define CFE_TIME_FLAG_UNUSED 0x000F`  
*Reserved flags - should be zero.*

## Time Services Command Codes

- `#define CFE_TIME_NOOP_CC 0 /* no-op command */`

- #define CFE\_TIME\_RESET\_COUNTERS\_CC 1 /\* reset counters \*/
- #define CFE\_TIME\_SEND\_DIAGNOSTIC\_TLM\_CC 2 /\* request diagnostic hk telemetry \*/
- #define CFE\_TIME\_SET\_SOURCE\_CC 3 /\* set clock source (int vs ext) \*/
- #define CFE\_TIME\_SET\_STATE\_CC 4 /\* set clock state \*/
- #define CFE\_TIME\_ADD\_DELAY\_CC 5 /\* add tone delay value \*/
- #define CFE\_TIME\_SUB\_DELAY\_CC 6 /\* sub tone delay value \*/
- #define CFE\_TIME\_SET\_TIME\_CC 7 /\* set time \*/
- #define CFE\_TIME\_SET\_MET\_CC 8 /\* set MET \*/
- #define CFE\_TIME\_SET\_STCF\_CC 9 /\* set STCF \*/
- #define CFE\_TIME\_SET\_LEAP\_SECONDS\_CC 10 /\* set Leap Seconds \*/
- #define CFE\_TIME\_ADD\_ADJUST\_CC 11 /\* add one time STCF adjustment \*/
- #define CFE\_TIME\_SUB\_ADJUST\_CC 12 /\* subtract one time STCF adjustment \*/
- #define CFE\_TIME\_ADD\_1HZ\_ADJUSTMENT\_CC 13 /\* add 1Hz STCF adjustment \*/
- #define CFE\_TIME\_SUB\_1HZ\_ADJUSTMENT\_CC 14 /\* subtract 1Hz STCF adjustment \*/
- #define CFE\_TIME\_SET\_SIGNAL\_CC 15 /\* set clock signal (pri vs red) \*/

## Typedefs

- typedef struct CFE\_TIME\_NoArgsCmd CFE\_TIME\_NoArgsCmd\_t
 

*Generic no argument command.*
- typedef CFE\_TIME\_NoArgsCmd\_t CFE\_TIME\_NoopCmd\_t
- typedef CFE\_TIME\_NoArgsCmd\_t CFE\_TIME\_ResetCountersCmd\_t
- typedef CFE\_TIME\_NoArgsCmd\_t CFE\_TIME\_SendDiagnosticCmd\_t
- typedef CFE\_TIME\_NoArgsCmd\_t CFE\_TIME\_1HzCmd\_t
- typedef CFE\_TIME\_NoArgsCmd\_t CFE\_TIME\_ToneSignalCmd\_t
- typedef CFE\_TIME\_NoArgsCmd\_t CFE\_TIME\_FakeToneCmd\_t
- typedef struct CFE\_TIME\_LeapsCmd\_Payload CFE\_TIME\_LeapsCmd\_Payload\_t
 

*Set leap seconds command payload.*
- typedef struct CFE\_TIME\_SetLeapSecondsCmd CFE\_TIME\_SetLeapSecondsCmd\_t
 

*Set leap seconds command.*
- typedef struct CFE\_TIME\_StateCmd\_Payload CFE\_TIME\_StateCmd\_Payload\_t
 

*Set clock state command payload.*
- typedef struct CFE\_TIME\_SetStateCmd CFE\_TIME\_SetStateCmd\_t
 

*Set clock state command.*
- typedef struct CFE\_TIME\_SourceCmd\_Payload CFE\_TIME\_SourceCmd\_Payload\_t
 

*Set time data source command payload.*
- typedef struct CFE\_TIME\_SetSourceCmd CFE\_TIME\_SetSourceCmd\_t
 

*Set time data source command.*
- typedef struct CFE\_TIME\_SignalCmd\_Payload CFE\_TIME\_SignalCmd\_Payload\_t
 

*Set tone signal source command payload.*
- typedef struct CFE\_TIME\_SetSignalCmd CFE\_TIME\_SetSignalCmd\_t
 

*Set tone signal source command.*
- typedef struct CFE\_TIME\_TimeCmd\_Payload CFE\_TIME\_TimeCmd\_Payload\_t
 

*Generic seconds, microseconds command payload.*
- typedef struct CFE\_TIME\_TimeCmd CFE\_TIME\_TimeCmd\_t
 

*Generic seconds, microseconds argument command.*
- typedef CFE\_TIME\_TimeCmd\_t CFE\_TIME\_AddDelayCmd\_t
- typedef CFE\_TIME\_TimeCmd\_t CFE\_TIME\_SubDelayCmd\_t
- typedef CFE\_TIME\_TimeCmd\_t CFE\_TIME\_SetMETCmd\_t
- typedef CFE\_TIME\_TimeCmd\_t CFE\_TIME\_SetSTCFCmd\_t

- `typedef CFE_TIME_TimeCmd_t CFE_TIME_AddAdjustCmd_t`
- `typedef CFE_TIME_TimeCmd_t CFE_TIME_SubAdjustCmd_t`
- `typedef CFE_TIME_TimeCmd_t CFE_TIME_SetTimeCmd_t`
- `typedef struct CFE_TIME_OneHzAdjustmentCmd_Payload CFE_TIME_OneHzAdjustmentCmd_Payload_t`  
*Generic seconds, subseconds command payload.*
- `typedef struct CFE_TIME_OneHzAdjustmentCmd CFE_TIME_OneHzAdjustmentCmd_t`  
*Generic seconds, subseconds adjustment command.*
- `typedef CFE_TIME_OneHzAdjustmentCmd_t CFE_TIME_Add1HZAdjustmentCmd_t`
- `typedef CFE_TIME_OneHzAdjustmentCmd_t CFE_TIME_Sub1HZAdjustmentCmd_t`
- `typedef struct CFE_TIME_ToneDataCmd_Payload CFE_TIME_ToneDataCmd_Payload_t`  
*Time at tone data command payload.*
- `typedef struct CFE_TIME_ToneDataCmd CFE_TIME_ToneDataCmd_t`  
*Time at tone data command.*
- `typedef struct CFE_TIME_HousekeepingTlm_Payload CFE_TIME_HousekeepingTlm_Payload_t`
- `typedef struct CFE_TIME_HousekeepingTlm CFE_TIME_HousekeepingTlm_t`
- `typedef struct CFE_TIME_DiagnosticTlm_Payload CFE_TIME_DiagnosticTlm_Payload_t`
- `typedef struct CFE_TIME_DiagnosticTlm CFE_TIME_DiagnosticTlm_t`

### 12.77.1 Detailed Description

Purpose: cFE Time Services (TIME) SB message definitions header file

Author: S.Walling/Microtel

Notes:

### 12.77.2 Macro Definition Documentation

#### 12.77.2.1 CFE\_TIME\_ADD\_1HZ\_ADJUSTMENT\_CC

```
#define CFE_TIME_ADD_1HZ_ADJUSTMENT_CC 13 /* add 1Hz STCF adjustment */
```

**Name** Add Delta to Spacecraft Time Correlation Factor each 1Hz

##### Description

This command has been updated to take actual sub-seconds ( $1/2^{32}$  seconds) rather than micro-seconds as an input argument. This change occurred after the determination was made that one micro-second is too large an increment for a constant 1Hz adjustment.

This command continuously adjusts the Spacecraft Time Correlation Factor (STCF) every second, by adding the specified value. The adjustment to the STCF is applied in the Time Service local 1Hz interrupt handler. As the local 1Hz interrupt is not synchronized to the tone signal, one cannot say when the adjustment will occur, other than once a second, at about the same time relative to the tone.

There was some debate about whether the maximum 1Hz clock drift correction factor would ever need to exceed some small fraction of a second. But, the decision was made to provide the capability to make 1Hz adjustments greater than one second and leave it to the ground system to provide mission specific limits.

**Command Mnemonic(s)** \$sc\_\$cpu\_TIME\_Add1HzSTCF

#### Command Structure

[CFE\\_TIME\\_Add1HZAdjustmentCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDPC** - command execution counter will increment
- **\$sc\_\$cpu\_TIME\_STCFSecs** - Housekeeping Telemetry point indicating new STCF seconds value
- **\$sc\_\$cpu\_TIME\_STCFSubsecs** - Housekeeping Telemetry point indicating new STCF subseconds value
- The [CFE\\_TIME\\_1HZ\\_EID](#) informational event message will be generated

#### Error Conditions

- Platform receiving the command is not a Time Server

Evidence of Failure may be found in the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDEC** - command error counter will increment
- Error specific event message will be issued ([CFE\\_TIME\\_1HZ\\_CFG\\_EID](#))

#### Criticality

Inappropriately setting the clock may result in other sub-systems performing incorrect time based calculations. The specific risk is dependent upon the behavior of those sub-systems.

#### See also

[CFE\\_TIME\\_ADD\\_ADJUST\\_CC](#), [CFE\\_TIME\\_SUB\\_ADJUST\\_CC](#), [CFE\\_TIME\\_SUB\\_1HZ\\_ADJUSTMENT\\_CC](#)

Definition at line 612 of file cfe\_time\_msg.h.

#### 12.77.2.2 CFE\_TIME\_ADD\_ADJUST\_CC

```
#define CFE_TIME_ADD_ADJUST_CC 11 /* add one time STCF adjustment */
```

**Name** Add Delta to Spacecraft Time Correlation Factor

#### Description

This command adjusts the Spacecraft Time Correlation Factor (STCF) by adding the specified value. The new STCF takes effect immediately upon execution of this command.

**Command Mnemonic(s)** \$sc\_\$cpu\_TIME\_AddSTCFAdj

### Command Structure

[CFE\\_TIME\\_AddAdjustCmd\\_t](#)

### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDPC** - command execution counter will increment
- **\$sc\_\$cpu\_TIME\_STCFSecs** - Housekeeping Telemetry point indicating new STCF seconds value
- **\$sc\_\$cpu\_TIME\_STCFSubsecs** - Housekeeping Telemetry point indicating new STCF subseconds value
- The [CFE\\_TIME\\_DELTA\\_EID](#) informational event message will be generated

### Error Conditions

- An invalid number of microseconds was specified (must be less than 1 million)
- Platform receiving the command is not a Time Server

Evidence of Failure may be found in the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDEC** - command error counter will increment
- Error specific event messages will be issued ([CFE\\_TIME\\_DELTA\\_ERR\\_EID](#) or [CFE\\_TIME\\_DELTA\\_CFG\\_EID](#))

### Criticality

Inappropriately setting the clock may result in other sub-systems performing incorrect time based calculations. The specific risk is dependent upon the behavior of those sub-systems.

### See also

[CFE\\_TIME\\_ADD\\_ADJUST\\_CC](#), [CFE\\_TIME\\_SUB\\_ADJUST\\_CC](#), [CFE\\_TIME\\_ADD\\_1HZ\\_ADJUSTMENT\\_CC](#),  
[CFE\\_TIME\\_SUB\\_1HZ\\_ADJUSTMENT\\_CC](#)

Definition at line 532 of file `cfe_time_msg.h`.

### 12.77.2.3 CFE\_TIME\_ADD\_DELAY\_CC

```
#define CFE_TIME_ADD_DELAY_CC 5 /* add tone delay value */
```

**Name** Add Time to Tone Time Delay

### Description

This command is used to factor out a known, predictable latency between the Time Server and a particular Time Client. The correction is applied (added) to the current time calculation for Time Clients, so this command has no meaning for Time Servers. Each Time Client can have a unique latency setting. The latency value is a positive number of seconds and microseconds that represent the deviation from the time maintained by the Time Server.

**Command Mnemonic(s)** \$sc\_\$cpu\_TIME\_AddClockLat**Command Structure**[CFE\\_TIME\\_AddDelayCmd\\_t](#)**Command Verification**

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDPC** - command execution counter will increment
- **\$sc\_\$cpu\_TIME\_DLAtents**, **\$sc\_\$cpu\_TIME\_DLlatentSs** - Housekeeping Telemetry point indicating command specified values
- **\$sc\_\$cpu\_TIME\_DLlatentDir** - Diagnostic Telemetry point indicating commanded latency direction
- The [CFE\\_TIME\\_DELAY\\_EID](#) informational event message will be generated

**Error Conditions**

- An invalid number of microseconds was specified (must be less than 1 million)
- Platform receiving the command is not a Time Client

Evidence of Failure may be found in the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDEC** - command error counter will increment
- Error specific event messages will be issued ([CFE\\_TIME\\_DELAY\\_CFG\\_EID](#) or [CFE\\_TIME\\_DELAY\\_ERR\\_EID](#))

**Criticality**

Inappropriately setting the clock may result in other sub-systems performing incorrect time based calculations. The specific risk is dependent upon the behavior of those sub-systems.

**See also**[CFE\\_TIME\\_SUB\\_DELAY\\_CC](#)

Definition at line 301 of file cfe\_time\_msg.h.

**12.77.2.4 CFE\_TIME\_NOOP\_CC**

```
#define CFE_TIME_NOOP_CC 0 /* no-op command */
```

**Name** Time No-Op

**Description**

This command performs no other function than to increment the command execution counter. The command may be used to verify general aliveness of the Time Services task.

**Command Mnemonic(s)** \$sc\_\$cpu\_TIME\_NOOP**Command Structure**`CFE_TIME_NoopCmd_t`**Command Verification**

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDPC** - command execution counter will increment
- The **CFE\_TIME\_NOOP\_EID** informational event message will be generated

**Error Conditions**

There are no error conditions for this command. If the Time Services receives the command, the event is sent (although it may be filtered by EVS) and the counter is incremented unconditionally.

**Criticality**

None

**See also**

Definition at line 77 of file `cfe_time_msg.h`.

**12.77.2.5 CFE\_TIME\_RESET\_COUNTERS\_CC**

```
#define CFE_TIME_RESET_COUNTERS_CC 1 /* reset counters */
```

**Name** Time Reset Counters**Description**

This command resets the following counters within the Time Services [Housekeeping Telemetry](#) :

- Command Execution Counter (\$sc\_\$cpu\_TIME\_CMDPC)
- Command Error Counter (\$sc\_\$cpu\_TIME\_CMDEC) This command also resets the following counters within the Time Services [Diagnostic Telemetry](#) :
  - Tone Signal Detected Software Bus Message Counter (\$sc\_\$cpu\_TIME\_DTSDetCNT)
  - Time at the Tone Data Software Bus Message Counter (\$sc\_\$cpu\_TIME\_DTatTCNT)
  - Tone Signal/Data Verify Counter (\$sc\_\$cpu\_TIME\_DVerifyCNT)
  - Tone Signal/Data Error Counter (\$sc\_\$cpu\_TIME\_DVerifyER)
  - Tone Signal Interrupt Counter (\$sc\_\$cpu\_TIME\_DTsISRCNT)
  - Tone Signal Interrupt Error Counter (\$sc\_\$cpu\_TIME\_DTsISRERR)
  - Tone Signal Task Counter (\$sc\_\$cpu\_TIME\_DTsTaskCNT)

- Local 1 Hz Interrupt Counter (\$sc\_\$cpu\_TIME\_D1HzISRCNT)
- Local 1 Hz Task Counter (\$sc\_\$cpu\_TIME\_D1HzTaskCNT)
- Reference Time Version Counter (\$sc\_\$cpu\_TIME\_DVersionCNT)

**Command Mnemonic(s)** \$sc\_\$cpu\_TIME\_ResetCtrs

#### Command Structure

[CFE\\_TIME\\_ResetCountersCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDPC** - command execution counter will reset to 0
- **\$sc\_\$cpu\_TIME\_CMDEC** - command error counter will reset to 0
- The [CFE\\_TIME\\_RESET\\_EID](#) informational event message will be generated

#### Error Conditions

There are no error conditions for this command. If the Time Services receives the command, the event is sent (although it may be filtered by EVS) and the counter is reset unconditionally.

#### Criticality

None

#### See also

Definition at line 122 of file cfe\_time\_msg.h.

### 12.77.2.6 CFE\_TIME\_SEND\_DIAGNOSTIC\_TLM\_CC

```
#define CFE_TIME_SEND_DIAGNOSTIC_TLM_CC 2 /* request diagnostic hk telemetry */
```

**Name** Request TIME Diagnostic Telemetry

#### Description

This command requests that the Time Service generate a message containing various data values not included in the normal Time Service housekeeping message. The command requests only a single copy of the diagnostic message. Refer to [CFE\\_TIME\\_DiagnosticTlm\\_t](#) for a description of the Time Service diagnostic message contents.

**Command Mnemonic(s)** \$sc\_\$cpu\_TIME\_RequestDiag

**Command Structure**

[CFE\\_TIME\\_SendDiagnosticCmd\\_t](#)

**Command Verification**

Successful execution of this command may be verified with the following telemetry:

- `$sc_$cpu_TIME_CMDPC` - command execution counter will increment
- Sequence Counter for [CFE\\_TIME\\_DiagnosticTlm\\_t](#) will increment
- The [CFE\\_TIME\\_DIAG\\_EID](#) debug event message will be generated

**Error Conditions**

There are no error conditions for this command. If the Time Services receives the command, the event and telemetry is sent (although one or both may be filtered by EVS and TO) and the counter is incremented unconditionally.

**Criticality**

None

**See also**

Definition at line 156 of file `cfe_time_msg.h`.

### 12.77.2.7 CFE\_TIME\_SET\_LEAP\_SECONDS\_CC

```
#define CFE_TIME_SET_LEAP_SECONDS_CC 10 /* set Leap Seconds */
```

**Name** Set Leap Seconds

**Description**

This command sets the spacecraft Leap Seconds to the specified value. Leap Seconds may be positive or negative, and there is no limit to the value except, of course, the limit imposed by the 16 bit signed integer data type. The new Leap Seconds value takes effect immediately upon execution of this command.

**Command Mnemonic(s)** `$sc_$cpu_TIME_SetClockLeap`

**Command Structure**

[CFE\\_TIME\\_SetLeapSecondsCmd\\_t](#)

**Command Verification**

Successful execution of this command may be verified with the following telemetry:

- `$sc_$cpu_TIME_CMDPC` - command execution counter will increment

- **\$sc\_\$cpu\_TIME\_LeapSecs** - Housekeeping Telemetry point indicating new Leap seconds value
- The [CFE\\_TIME\\_LEAPS\\_EID](#) informational event message will be generated

#### Error Conditions

- Platform receiving the command is not a Time Server
  - Evidence of Failure may be found in the following telemetry:
- **\$sc\_\$cpu\_TIME\_CMDEC** - command error counter will increment
- Error specific event messages will be issued ([CFE\\_TIME\\_LEAPS\\_CFG\\_EID](#))

#### Criticality

Inappropriately setting the clock may result in other sub-systems performing incorrect time based calculations. The specific risk is dependent upon the behavior of those sub-systems.

#### See also

[CFE\\_TIME\\_SET\\_TIME\\_CC](#), [CFE\\_TIME\\_SET\\_MET\\_CC](#), [CFE\\_TIME\\_SET\\_STCF\\_CC](#)

Definition at line 496 of file `cfe_time_msg.h`.

### 12.77.2.8 CFE\_TIME\_SET\_MET\_CC

```
#define CFE_TIME_SET_MET_CC 8 /* set MET */
```

**Name** Set Mission Elapsed Time

#### Description

This command sets the Mission Elapsed Timer (MET) to the specified value.

Note that the MET (as implemented for cFE Time Service) is a logical representation and not a physical timer. Thus, setting the MET is not dependent on whether the hardware supports a MET register that can be written to.

Note also that Time Service "assumes" that during normal operation, the MET is synchronized to the tone signal. Therefore, unless operating in FLYWHEEL mode, the sub-seconds portion of the MET will be set to zero at the next tone signal interrupt.

The new MET takes effect immediately upon execution of this command.

**Command Mnemonic(s)** \$sc\_\$cpu\_TIME\_SetClockMET

#### Command Structure

[CFE\\_TIME\\_SetMETCmd\\_t](#)

### Command Verification

Successful execution of this command may be verified with the following telemetry:

- `$sc_$cpu_TIME_CMDPC` - command execution counter will increment
- `$sc_$cpu_TIME_METSecs` - Housekeeping Telemetry point indicating new MET seconds value
- `$sc_$cpu_TIME_METSubsecs` - Housekeeping Telemetry point indicating new MET subseconds value
- The [CFE\\_TIME\\_MET\\_EID](#) informational event message will be generated

### Error Conditions

- An invalid number of microseconds was specified (must be less than 1 million)
- Platform receiving the command is not a Time Server

Evidence of Failure may be found in the following telemetry:

- `$sc_$cpu_TIME_CMDEC` - command error counter will increment
- Error specific event messages will be issued ([CFE\\_TIME\\_MET\\_CFG\\_EID](#) or [CFE\\_TIME\\_MET\\_ERR\\_EID](#))

### Criticality

Inappropriately setting the clock may result in other sub-systems performing incorrect time based calculations. The specific risk is dependent upon the behavior of those sub-systems.

### See also

[CFE\\_TIME\\_SET\\_TIME\\_CC](#), [CFE\\_TIME\\_SET\\_STCF\\_CC](#), [CFE\\_TIME\\_SET\\_LEAP\\_SECONDS\\_CC](#)

Definition at line 424 of file `cfe_time_msg.h`.

### 12.77.2.9 CFE\_TIME\_SET\_SIGNAL\_CC

```
#define CFE_TIME_SET_SIGNAL_CC 15 /* set clock signal (pri vs red) */
```

**Name** Set Tone Signal Source

### Description

This command selects the Time Service tone signal source. Although the list of potential tone signal sources is mission specific, a common choice is the selection of primary or redundant tone signal. The selection may be available to both the Time Server and Time Clients, depending on hardware configuration.

Notes:

- This command is only valid when the `CFE_PLATFORM_TIME_CFG_SIGNAL` configuration parameter in the `cfe_platform_cfg.h` file has been set to true.

**Command Mnemonic(s)** `$sc_$cpu_TIME_SetSignal`

**Command Structure**

[CFE\\_TIME\\_SetSignalCmd\\_t](#)

**Command Verification**

Successful execution of this command may be verified with the following telemetry:

- [`\$sc\_\$cpu\_TIME\_CMDPC`](#) - command execution counter will increment
- [`\$sc\_\$cpu\_TIME\_DSignal`](#) - Diagnostic Telemetry point will indicate the command specified value
- The [CFE\\_TIME\\_SIGNAL\\_EID](#) informational event message will be generated

**Error Conditions**

- Invalid Signal selection (a value other than [CFE\\_TIME\\_ToneSignalSelect\\_PRIMARY](#) or [CFE\\_TIME\\_ToneSignalSelect\\_REDUNDANT](#) was specified)
- Multiple Tone Signal Sources not available on this platform

Evidence of failure may be found in the following telemetry:

- [`\$sc\_\$cpu\_TIME\_CMDEC`](#) - Command Error counter will increment
- Error specific event message (either [CFE\\_TIME\\_SIGNAL\\_CFG\\_EID](#) or [CFE\\_TIME\\_SIGNAL\\_ERR\\_EID](#))

**Criticality**

Although tone signal source selection is important, this command is not critical

**See also**

[CFE\\_TIME\\_SET\\_STATE\\_CC](#), [CFE\\_TIME\\_SET\\_SOURCE\\_CC](#)

Definition at line 702 of file cfe\_time\_msg.h.

### 12.77.2.10 CFE\_TIME\_SET\_SOURCE\_CC

```
#define CFE_TIME_SET_SOURCE_CC 3 /* set clock source (int vs ext) */
```

**Name** Set Time Source**Description**

This command selects the Time Service clock source. Although the list of potential clock sources is mission specific and defined via configuration parameters, this command provides a common method for switching between the local processor clock and an external source for time data.

When commanded to accept external time data (GPS, MET, spacecraft time, etc.), the Time Server will enable input via an API function specific to the configuration definitions for the particular source. When commanded to use internal time data, the Time Server will ignore the external data. However, the Time Server will continue to use the API function as the trigger to generate a "time at the tone" command packet regardless of the internal/external command selection.

Notes:

- Operating in FLYWHEEL mode is not considered a choice related to clock source, but rather an element of the clock state. See below for a description of the [CFE\\_TIME\\_SET\\_STATE\\_CC](#) command.
- This command is only valid when the [CFE\\_PLATFORM\\_TIME\\_CFG\\_SOURCE](#) configuration parameter in the `cfe_platform_cfg.h` file has been set to true.

**Command Mnemonic(s)** \$sc\_\$cpu\_TIME\_SetSource

#### Command Structure

[CFE\\_TIME\\_SetSourceCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_TIME\\_CMDPC](#) - command execution counter will increment
- [\\$sc\\_\\$cpu\\_TIME\\_DSource](#) - Diagnostic Telemetry point will indicate the command specified value
- The [CFE\\_TIME\\_SOURCE\\_EID](#) informational event message will be generated

#### Error Conditions

- Invalid Source selection (a value other than [CFE\\_TIME\\_SourceSelect\\_INTERNAL](#) or [CFE\\_TIME\\_SourceSelect\\_EXTERNAL](#) was specified)
- Time source selection not allowed on this platform

Evidence of failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_TIME\\_CMDEC](#) - Command Error counter will increment
- Error specific event message (either [CFE\\_TIME\\_SOURCE\\_CFG\\_EID](#) or [CFE\\_TIME\\_SOURCE\\_ERR\\_EID](#))

#### Criticality

Although clock source selection is important, this command is not critical.

#### See also

[CFE\\_TIME\\_SET\\_STATE\\_CC](#), [CFE\\_TIME\\_SET\\_SIGNAL\\_CC](#)

Definition at line 206 of file `cfe_time_msg.h`.

### 12.77.2.11 CFE\_TIME\_SET\_STATE\_CC

```
#define CFE_TIME_SET_STATE_CC 4 /* set clock state */
```

**Name** Set Time State

#### Description

This command indirectly affects the Time Service on-board determination of clock state. Clock state is a combination of factors, most significantly whether the spacecraft time has been accurately set, and whether Time Service is operating in FLYWHEEL mode.

This command may be used to notify the Time Server that spacecraft time is now correct, or that time is no longer correct. This information will be distributed to Time Clients, and in turn, to any interested sub-systems.

Also, this command may be used to force a Time Server or Time Client into FLYWHEEL mode. Use of FLYWHEEL mode is mainly for debug purposes although in extreme circumstances, it may be of value to force Time Service not to rely on normal time updates. Note that when commanded into FLYWHEEL mode, the Time Service will remain so until receipt of another "set state" command setting the state into a mode other than FLYWHEEL.

Note also that setting the clock state to VALID or INVALID on a Time Client that is currently getting time updates from the Time Server will have very limited effect. As soon as the Time Client receives the next time update, the VALID/INVALID selection will be set to that of the Time Server. However, setting a Time Client to FLYWHEEL cannot be overridden by the Time Server since the Time Client will ignore time updates from the Time Server while in FLYWHEEL mode.

**Command Mnemonic(s)** \$sc\_\$cpu\_TIME\_SetState

#### Command Structure

[CFE\\_TIME\\_SetStateCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDPC** - command execution counter will increment
- **\$sc\_\$cpu\_TIME\_StateFlg**, **\$sc\_\$cpu\_TIME\_FlagSet**, **\$sc\_\$cpu\_TIME\_FlagFly**, **\$sc\_\$cpu\_TIME\_FlagSrc**, **\$sc\_\$cpu\_TIME\_FlagPri**, **\$sc\_\$cpu\_TIME\_FlagSfly**, **\$sc\_\$cpu\_TIME\_FlagCfly**, **\$sc\_\$cpu\_TIME\_FlagAdjd**, **\$sc\_\$cpu\_TIME\_Flag1Hzd**, **\$sc\_\$cpu\_TIME\_FlagClat**, **\$sc\_\$cpu\_TIME\_FlagSorC**, **\$sc\_\$cpu\_TIME\_FlagNIU** - Housekeeping Telemetry point "may" indicate the command specified value (see above)
- The [CFE\\_TIME\\_STATE\\_EID](#) informational event message will be generated

#### Error Conditions

- Invalid State selection (a value other than [CFE\\_TIME\\_ClockState\\_INVALID](#), [CFE\\_TIME\\_ClockState\\_VALID](#) or [CFE\\_TIME\\_ClockState\\_FLYWHEEL](#) was specified)
- Time source selection not allowed on this platform

Evidence of failure may be found in the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDEC** - Command Error counter will increment

- Error specific event message ([CFE\\_TIME\\_STATE\\_ERR\\_EID](#))

#### Criticality

Setting Time Service into FLYWHEEL mode is not particularly hazardous, as the result may be that the calculation of spacecraft time is done using a less than optimal timer. However, inappropriately setting the clock state to V $\leftarrow$  ALID (indicating that spacecraft time is accurate) may result in other sub-systems performing incorrect time based calculations. The specific risk is dependent upon the behavior of those sub-systems.

#### See also

[CFE\\_TIME\\_SET\\_SOURCE\\_CC](#), [CFE\\_TIME\\_SET\\_SIGNAL\\_CC](#)

Definition at line 263 of file `cfe_time_msg.h`.

### 12.77.2.12 CFE\_TIME\_SET\_STCF\_CC

```
#define CFE_TIME_SET_STCF_CC 9 /* set STCF */
```

**Name** Set Spacecraft Time Correlation Factor

#### Description

This command sets the Spacecraft Time Correlation Factor (STCF) to the specified value. This command differs from the previously described SET CLOCK in the nature of the command argument. This command sets the STCF value directly, rather than extracting the STCF from a value representing the total of MET, STCF and optionally, Leap Seconds. The new STCF takes effect immediately upon execution of this command.

**Command Mnemonic(s)** \$sc\_\$cpu\_TIME\_SetClockSTCF

#### Command Structure

[CFE\\_TIME\\_SetSTCFCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDPC** - command execution counter will increment
- **\$sc\_\$cpu\_TIME\_STCFSecs** - Housekeeping Telemetry point indicating new STCF seconds value
- **\$sc\_\$cpu\_TIME\_STCFSubsecs** - Housekeeping Telemetry point indicating new STCF subseconds value
- The [CFE\\_TIME\\_STCF\\_EID](#) informational event message will be generated

#### Error Conditions

- An invalid number of microseconds was specified (must be less than 1 million)

- Platform receiving the command is not a Time Server

Evidence of Failure may be found in the following telemetry:

- **`$sc_$cpu_TIME_CMDEC`** - command error counter will increment
- Error specific event messages will be issued ([CFE\\_TIME\\_STCF\\_CFG\\_EID](#) or [CFE\\_TIME\\_STCF\\_ERR\\_EID](#))

#### Criticality

Inappropriately setting the clock may result in other sub-systems performing incorrect time based calculations. The specific risk is dependent upon the behavior of those sub-systems.

#### See also

[CFE\\_TIME\\_SET\\_TIME\\_CC](#), [CFE\\_TIME\\_SET\\_MET\\_CC](#), [CFE\\_TIME\\_SET\\_LEAP\\_SECONDS\\_CC](#)

Definition at line 461 of file `cfe_time_msg.h`.

### 12.77.2.13 CFE\_TIME\_SET\_TIME\_CC

```
#define CFE_TIME_SET_TIME_CC 7 /* set time */
```

**Name** Set Spacecraft Time

#### Description

This command sets the spacecraft clock to a new value, regardless of the current setting (time jam). The new time value represents the desired offset from the mission-defined time epoch and takes effect immediately upon execution of this command. Time Service will calculate a new STCF value based on the current MET and the desired new time using one of the following:

If Time Service is configured to compute current time as TAI

- **STCF = (new time) - (current MET)**
- **(current time) = (current MET) + STCF**

If Time Service is configured to compute current time as UTC

- **STCF = ((new time) - (current MET)) + (Leap Seconds)**
- **(current time) = ((current MET) + STCF) - (Leap Seconds)**

**Command Mnemonic(s)** `$sc_$cpu_TIME_SetClock`

#### Command Structure

[CFE\\_TIME\\_SetTimeCmd\\_t](#)

### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDPC** - command execution counter will increment
- **\$sc\_\$cpu\_TIME\_STCFSecs** - Housekeeping Telemetry point indicating newly calculated STCF seconds value
- **\$sc\_\$cpu\_TIME\_STCFSubsecs** - Housekeeping Telemetry point indicating newly calculated STCF sub-seconds value
- The [CFE\\_TIME\\_TIME\\_EID](#) informational event message will be generated

### Error Conditions

- An invalid number of microseconds was specified (must be less than 1 million)
- Platform receiving the command is not a Time Server

Evidence of Failure may be found in the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDEC** - command error counter will increment
- Error specific event messages will be issued ([CFE\\_TIME\\_TIME\\_CFG\\_EID](#) or [CFE\\_TIME\\_TIME\\_ERR\\_EID](#))

### Criticality

Inappropriately setting the clock may result in other sub-systems performing incorrect time based calculations. The specific risk is dependent upon the behavior of those sub-systems.

### See also

[CFE\\_TIME\\_SET\\_MET\\_CC](#), [CFE\\_TIME\\_SET\\_STCF\\_CC](#), [CFE\\_TIME\\_SET\\_LEAP\\_SECONDS\\_CC](#)

Definition at line 384 of file `cfe_time_msg.h`.

#### 12.77.2.14 CFE\_TIME\_SUB\_1HZ\_ADJUSTMENT\_CC

```
#define CFE_TIME_SUB_1HZ_ADJUSTMENT_CC 14 /* subtract 1Hz STCF adjustment */
```

**Name** Subtract Delta from Spacecraft Time Correlation Factor each 1Hz

### Description

This command has been updated to take actual sub-seconds ( $1/2^{32}$  seconds) rather than micro-seconds as an input argument. This change occurred after the determination was made that one micro-second is too large an increment for a constant 1Hz adjustment.

This command continuously adjusts the Spacecraft Time Correlation Factor (STCF) every second, by subtracting the specified value. The adjustment to the STCF is applied in the Time Service local 1Hz interrupt handler. As the local 1Hz interrupt is not synchronized to the tone signal, one cannot say when the adjustment will occur, other than once a second, at about the same time relative to the tone.

There was some debate about whether the maximum 1Hz clock drift correction factor would ever need to exceed some small fraction of a second. But, the decision was made to provide the capability to make 1Hz adjustments greater than one second and leave it to the ground system to provide mission specific limits.

**Command Mnemonic(s)** \$sc\_\$cpu\_TIME\_Sub1HzSTCF

#### Command Structure

[CFE\\_TIME\\_Sub1HZAdjustmentCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry: Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDPC** - command execution counter will increment
- **\$sc\_\$cpu\_TIME\_STCFSecs** - Housekeeping Telemetry point indicating new STCF seconds value
- **\$sc\_\$cpu\_TIME\_STCFSubsecs** - Housekeeping Telemetry point indicating new STCF subseconds value
- The [CFE\\_TIME\\_1HZ\\_EID](#) informational event message will be generated

#### Error Conditions

- Platform receiving the command is not a Time Server

Evidence of Failure may be found in the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDEC** - command error counter will increment
- Error specific event message will be issued ([CFE\\_TIME\\_1HZ\\_CFG\\_EID](#))

#### Criticality

Inappropriately setting the clock may result in other sub-systems performing incorrect time based calculations. The specific risk is dependent upon the behavior of those sub-systems.

#### See also

[CFE\\_TIME\\_ADD\\_ADJUST\\_CC](#), [CFE\\_TIME\\_SUB\\_ADJUST\\_CC](#), [CFE\\_TIME\\_ADD\\_1HZ\\_ADJUSTMENT\\_CC](#)

Definition at line 660 of file cfe\_time\_msg.h.

#### 12.77.2.15 CFE\_TIME\_SUB\_ADJUST\_CC

```
#define CFE_TIME_SUB_ADJUST_CC 12 /* subtract one time STCF adjustment */
```

**Name** Subtract Delta from Spacecraft Time Correlation Factor

#### Description

This command adjusts the Spacecraft Time Correlation Factor (STCF) by subtracting the specified value. The new STCF takes effect immediately upon execution of this command.

**Command Mnemonic(s)** \$sc\_\$cpu\_TIME\_SubSTCFAdj

#### Command Structure

[CFE\\_TIME\\_SubAdjustCmd\\_t](#)

#### Command Verification

Successful execution of this command may be verified with the following telemetry:

- [\\$sc\\_\\$cpu\\_TIME\\_CMDPC](#) - command execution counter will increment
- [\\$sc\\_\\$cpu\\_TIME\\_STCFSecs](#) - Housekeeping Telemetry point indicating new STCF seconds value
- [\\$sc\\_\\$cpu\\_TIME\\_STCFSubsecs](#) - Housekeeping Telemetry point indicating new STCF subseconds value
- The [CFE\\_TIME\\_DELTA\\_EID](#) informational event message will be generated

#### Error Conditions

- An invalid number of microseconds was specified (must be less than 1 million)
- Platform receiving the command is not a Time Server

Evidence of Failure may be found in the following telemetry:

- [\\$sc\\_\\$cpu\\_TIME\\_CMDEC](#) - command error counter will increment
- Error specific event messages will be issued ([CFE\\_TIME\\_DELTA\\_ERR\\_EID](#) or [CFE\\_TIME\\_DELTA\\_CFG\\_EID](#))

#### Criticality

Inappropriately setting the clock may result in other sub-systems performing incorrect time based calculations. The specific risk is dependent upon the behavior of those sub-systems.

#### See also

[CFE\\_TIME\\_ADD\\_ADJUST\\_CC](#), [CFE\\_TIME\\_ADD\\_1HZ\\_ADJUSTMENT\\_CC](#), [CFE\\_TIME\\_SUB\\_1HZ\\_ADJUSTMENT\\_CC](#)

Definition at line 566 of file `cfe_time_msg.h`.

#### 12.77.2.16 CFE\_TIME\_SUB\_DELAY\_CC

```
#define CFE_TIME_SUB_DELAY_CC 6 /* sub tone delay value */
```

**Name** Subtract Time from Tone Time Delay

## Description

This command is used to factor out a known, predictable latency between the Time Server and a particular Time Client. The correction is applied (subtracted) to the current time calculation for Time Clients, so this command has no meaning for Time Servers. Each Time Client can have a unique latency setting. The latency value is a positive number of seconds and microseconds that represent the deviation from the time maintained by the Time Server.

Note that it is unimaginable that the seconds value will ever be anything but zero.

## **Command Mnemonic(s)** \$sc\_\$cpu\_TIME\_SubClockLat

### Command Structure

[CFE\\_TIME\\_SubDelayCmd\\_t](#)

### Command Verification

Successful execution of this command may be verified with the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDPC** - command execution counter will increment
- **\$sc\_\$cpu\_TIME\_DLatentS**, **\$sc\_\$cpu\_TIME\_DLlatentSs** - Housekeeping Telemetry point indicating command specified values
- **\$sc\_\$cpu\_TIME\_DLlatentDir** - Diagnostic Telemetry point indicating commanded latency direction
- The [CFE\\_TIME\\_DELAY\\_EID](#) informational event message will be generated

### Error Conditions

- An invalid number of microseconds was specified (must be less than 1 million)
- Platform receiving the command is not a Time Client

Evidence of Failure may be found in the following telemetry:

- **\$sc\_\$cpu\_TIME\_CMDEC** - command error counter will increment
- Error specific event messages will be issued ([CFE\\_TIME\\_DELAY\\_CFG\\_EID](#) or [CFE\\_TIME\\_DELAY\\_ERR\\_EID](#))

### Criticality

Inappropriately setting the clock may result in other sub-systems performing incorrect time based calculations. The specific risk is dependent upon the behavior of those sub-systems.

### See also

[CFE\\_TIME\\_ADD\\_DELAY\\_CC](#)

Definition at line 339 of file cfe\_time\_msg.h.

### 12.77.3 Typedef Documentation

### 12.77.3.1 CFE\_TIME\_1HzCmd\_t

```
typedef CFE_TIME_NoArgsCmd_t CFE_TIME_1HzCmd_t
```

Definition at line 743 of file cfe\_time\_msg.h.

### 12.77.3.2 CFE\_TIME\_Add1HZAdjustmentCmd\_t

```
typedef CFE_TIME_OneHzAdjustmentCmd_t CFE_TIME_Add1HZAdjustmentCmd_t
```

Definition at line 878 of file cfe\_time\_msg.h.

### 12.77.3.3 CFE\_TIME\_AddAdjustCmd\_t

```
typedef CFE_TIME_TimeCmd_t CFE_TIME_AddAdjustCmd_t
```

Definition at line 850 of file cfe\_time\_msg.h.

### 12.77.3.4 CFE\_TIME\_AddDelayCmd\_t

```
typedef CFE_TIME_TimeCmd_t CFE_TIME_AddDelayCmd_t
```

Definition at line 846 of file cfe\_time\_msg.h.

### 12.77.3.5 CFE\_TIME\_DiagnosticTlm\_Payload\_t

```
typedef struct CFE_TIME_DiagnosticTlm_Payload CFE_TIME_DiagnosticTlm_Payload_t
```

**Name** Time Services Diagnostics Packet

### 12.77.3.6 CFE\_TIME\_DiagnosticTlm\_t

```
typedef struct CFE_TIME_DiagnosticTlm CFE_TIME_DiagnosticTlm_t
```

### 12.77.3.7 CFE\_TIME\_FakeToneCmd\_t

```
typedef CFE_TIME_NoArgsCmd_t CFE_TIME_FakeToneCmd_t
```

Definition at line 745 of file cfe\_time\_msg.h.

### 12.77.3.8 CFE\_TIME\_HousekeepingTlm\_Payload\_t

```
typedef struct CFE_TIME_HousekeepingTlm_Payload CFE_TIME_HousekeepingTlm_Payload_t
```

**Name** Time Services Housekeeping Packet

### 12.77.3.9 CFE\_TIME\_HousekeepingTlm\_t

```
typedef struct CFE_TIME_HousekeepingTlm CFE_TIME_HousekeepingTlm_t
```

### 12.77.3.10 CFE\_TIME\_LeapsCmd\_Payload\_t

```
typedef struct CFE_TIME_LeapsCmd_Payload CFE_TIME_LeapsCmd_Payload_t
```

Set leap seconds command payload.

### 12.77.3.11 CFE\_TIME\_NoArgsCmd\_t

```
typedef struct CFE_TIME_NoArgsCmd CFE_TIME_NoArgsCmd_t
```

Generic no argument command.

### 12.77.3.12 CFE\_TIME\_NoopCmd\_t

```
typedef CFE_TIME_NoArgsCmd_t CFE_TIME_NoopCmd_t
```

Definition at line 740 of file cfe\_time\_msg.h.

**12.77.3.13 CFE\_TIME\_OneHzAdjustmentCmd\_Payload\_t**

```
typedef struct CFE_TIME_OneHzAdjustmentCmd_Payload CFE_TIME_OneHzAdjustmentCmd_Payload_t
```

Generic seconds, subseconds command payload.

**12.77.3.14 CFE\_TIME\_OneHzAdjustmentCmd\_t**

```
typedef struct CFE_TIME_OneHzAdjustmentCmd CFE_TIME_OneHzAdjustmentCmd_t
```

Generic seconds, subseconds adjustment command.

**12.77.3.15 CFE\_TIME\_ResetCountersCmd\_t**

```
typedef CFE_TIME_NoArgsCmd_t CFE_TIME_ResetCountersCmd_t
```

Definition at line 741 of file cfe\_time\_msg.h.

**12.77.3.16 CFE\_TIME\_SendDiagnosticCmd\_t**

```
typedef CFE_TIME_NoArgsCmd_t CFE_TIME_SendDiagnosticCmd_t
```

Definition at line 742 of file cfe\_time\_msg.h.

**12.77.3.17 CFE\_TIME\_SetLeapSecondsCmd\_t**

```
typedef struct CFE_TIME_SetLeapSecondsCmd CFE_TIME_SetLeapSecondsCmd_t
```

Set leap seconds command.

**12.77.3.18 CFE\_TIME\_SetMETCmd\_t**

```
typedef CFE_TIME_TimeCmd_t CFE_TIME_SetMETCmd_t
```

Definition at line 848 of file cfe\_time\_msg.h.

**12.77.3.19 CFE\_TIME\_SetSignalCmd\_t**

```
typedef struct CFE_TIME_SetSignalCmd CFE_TIME_SetSignalCmd_t
```

Set tone signal source command.

**12.77.3.20 CFE\_TIME\_SetSourceCmd\_t**

```
typedef struct CFE_TIME_SetSourceCmd CFE_TIME_SetSourceCmd_t
```

Set time data source command.

**12.77.3.21 CFE\_TIME\_SetStateCmd\_t**

```
typedef struct CFE_TIME_SetStateCmd CFE_TIME_SetStateCmd_t
```

Set clock state command.

**12.77.3.22 CFE\_TIME\_SetSTCFCmd\_t**

```
typedef CFE_TIME_TimeCmd_t CFE_TIME_SetSTCFCmd_t
```

Definition at line 849 of file cfe\_time\_msg.h.

**12.77.3.23 CFE\_TIME\_SetTimeCmd\_t**

```
typedef CFE_TIME_TimeCmd_t CFE_TIME_SetTimeCmd_t
```

Definition at line 852 of file cfe\_time\_msg.h.

**12.77.3.24 CFE\_TIME\_SignalCmd\_Payload\_t**

```
typedef struct CFE_TIME_SignalCmd_Payload CFE_TIME_SignalCmd_Payload_t
```

Set tone signal source command payload.

**12.77.3.25 CFE\_TIME\_SourceCmd\_Payload\_t**

```
typedef struct CFE_TIME_SourceCmd_Payload CFE_TIME_SourceCmd_Payload_t
```

Set time data source command payload.

**12.77.3.26 CFE\_TIME\_StateCmd\_Payload\_t**

```
typedef struct CFE_TIME_StateCmd_Payload CFE_TIME_StateCmd_Payload_t
```

Set clock state command payload.

**12.77.3.27 CFE\_TIME\_Sub1HZAdjustmentCmd\_t**

```
typedef CFE_TIME_OneHzAdjustmentCmd_t CFE_TIME_Sub1HZAdjustmentCmd_t
```

Definition at line 879 of file cfe\_time\_msg.h.

**12.77.3.28 CFE\_TIME\_SubAdjustCmd\_t**

```
typedef CFE_TIME_TimeCmd_t CFE_TIME_SubAdjustCmd_t
```

Definition at line 851 of file cfe\_time\_msg.h.

**12.77.3.29 CFE\_TIME\_SubDelayCmd\_t**

```
typedef CFE_TIME_TimeCmd_t CFE_TIME_SubDelayCmd_t
```

Definition at line 847 of file cfe\_time\_msg.h.

**12.77.3.30 CFE\_TIME\_TimeCmd\_Payload\_t**

```
typedef struct CFE_TIME_TimeCmd_Payload CFE_TIME_TimeCmd_Payload_t
```

Generic seconds, microseconds command payload.

**12.77.3.31 CFE\_TIME\_TimeCmd\_t**

```
typedef struct CFE_TIME_TimeCmd CFE_TIME_TimeCmd_t
```

Generic seconds, microseconds argument command.

**12.77.3.32 CFE\_TIME\_ToneDataCmd\_Payload\_t**

```
typedef struct CFE_TIME_ToneDataCmd_Payload CFE_TIME_ToneDataCmd_Payload_t
```

Time at tone data command payload.

**12.77.3.33 CFE\_TIME\_ToneDataCmd\_t**

```
typedef struct CFE_TIME_ToneDataCmd CFE_TIME_ToneDataCmd_t
```

Time at tone data command.

**12.77.3.34 CFE\_TIME\_ToneSignalCmd\_t**

```
typedef CFE_TIME_NoArgsCmd_t CFE_TIME_ToneSignalCmd_t
```

Definition at line 744 of file cfe\_time\_msg.h.

**12.78 osal/docs/src/osal\_frontpage.dox File Reference****12.79 osal/docs/src/osal\_fs.dox File Reference****12.80 osal/docs/src/osal\_timer.dox File Reference****12.81 osal/src/os/inc/common\_types.h File Reference**

```
#include <stdint.h>
#include <stddef.h>
#include <stdbool.h>
```

## Macros

- `#define CompileTimeAssert(Condition, Message) typedef char Message[(Condition) ? 1 : -1]`
- `#define _EXTENSION_`
- `#define OS_USED`
- `#define OS_PRINTF(n, m)`
- `#define OSAL_SIZE_C(X) ((size_t)(X))`
- `#define OSAL_BLOCKCOUNT_C(X) ((osal_blockcount_t)(X))`
- `#define OSAL_INDEX_C(X) ((osal_index_t)(X))`
- `#define OSAL_OBJTYPE_C(X) ((osal_objtype_t)(X))`
- `#define OSAL_STATUS_C(X) ((osal_status_t)(X))`

## Typedefs

- `typedef int8_t int8`
- `typedef int16_t int16`
- `typedef int32_t int32`
- `typedef int64_t int64`
- `typedef uint8_t uint8`
- `typedef uint16_t uint16`
- `typedef uint32_t uint32`
- `typedef uint64_t uint64`
- `typedef intptr_t intptr`
- `typedef uintptr_t cpuaddr`
- `typedef size_t cpusize`
- `typedef ptrdiff_t cpudiff`
- `typedef uint32 osal_id_t`
- `typedef size_t osal_blockcount_t`
- `typedef uint32 osal_index_t`
- `typedef uint32 osal_objtype_t`
- `typedef int32 osal_status_t`
- `typedef void(* OS_ArgCallback_t) (osal_id_t object_id, void *arg)`

*General purpose OSAL callback function.*

## Functions

- `CompileTimeAssert (sizeof(uint8)==1, TypeUint8WrongSize)`
- `CompileTimeAssert (sizeof(uint16)==2, TypeUint16WrongSize)`
- `CompileTimeAssert (sizeof(uint32)==4, TypeUint32WrongSize)`
- `CompileTimeAssert (sizeof(uint64)==8, TypeUint64WrongSize)`
- `CompileTimeAssert (sizeof(int8)==1, Typeint8WrongSize)`
- `CompileTimeAssert (sizeof(int16)==2, Typeint16WrongSize)`
- `CompileTimeAssert (sizeof(int32)==4, Typeint32WrongSize)`
- `CompileTimeAssert (sizeof(int64)==8, Typeint64WrongSize)`
- `CompileTimeAssert (sizeof(cpuaddr) >=sizeof(void *), TypePtrWrongSize)`

### 12.81.1 Detailed Description

Purpose: Unit specification for common types.

Design Notes: Assumes make file has defined processor family

### 12.81.2 Macro Definition Documentation

#### 12.81.2.1 \_EXTENSION\_

```
#define _EXTENSION_
```

Definition at line 65 of file common\_types.h.

#### 12.81.2.2 CompileTimeAssert

```
#define CompileTimeAssert(  
    Condition,  
    Message ) typedef char Message[(Condition) ? 1 : -1]
```

Definition at line 48 of file common\_types.h.

#### 12.81.2.3 OS\_PRINTF

```
#define OS_PRINTF(  
    n,  
    m )
```

Definition at line 67 of file common\_types.h.

#### 12.81.2.4 OS\_USED

```
#define OS_USED
```

Definition at line 66 of file common\_types.h.

### 12.81.2.5 OSAL\_BLOCKCOUNT\_C

```
#define OSAL_BLOCKCOUNT_C(  
    X ) ((osal_blockcount_t)(X))
```

Definition at line 172 of file common\_types.h.

### 12.81.2.6 OSAL\_INDEX\_C

```
#define OSAL_INDEX_C(  
    X ) ((osal_index_t)(X))
```

Definition at line 173 of file common\_types.h.

### 12.81.2.7 OSAL\_OBJTYPE\_C

```
#define OSAL_OBJTYPE_C(  
    X ) ((osal_objtype_t)(X))
```

Definition at line 174 of file common\_types.h.

### 12.81.2.8 OSAL\_SIZE\_C

```
#define OSAL_SIZE_C(  
    X ) ((size_t)(X))
```

Definition at line 171 of file common\_types.h.

### 12.81.2.9 OSAL\_STATUS\_C

```
#define OSAL_STATUS_C(  
    X ) ((osal_status_t)(X))
```

Definition at line 175 of file common\_types.h.

## 12.81.3 Typedef Documentation

**12.81.3.1 cpuaddr**

```
typedef uintptr_t cpuaddr
```

Definition at line 88 of file common\_types.h.

**12.81.3.2 cpudiff**

```
typedef ptrdiff_t cpudiff
```

Definition at line 90 of file common\_types.h.

**12.81.3.3 cpusize**

```
typedef size_t cpusize
```

Definition at line 89 of file common\_types.h.

**12.81.3.4 int16**

```
typedef int16_t int16
```

Definition at line 80 of file common\_types.h.

**12.81.3.5 int32**

```
typedef int32_t int32
```

Definition at line 81 of file common\_types.h.

**12.81.3.6 int64**

```
typedef int64_t int64
```

Definition at line 82 of file common\_types.h.

**12.81.3.7 int8**

```
typedef int8_t int8
```

Definition at line 79 of file common\_types.h.

**12.81.3.8 intptr**

```
typedef intptr_t intptr
```

Definition at line 87 of file common\_types.h.

**12.81.3.9 OS\_ArgCallback\_t**

```
typedef void(* OS_ArgCallback_t) (osal_id_t object_id, void *arg)
```

General purpose OSAL callback function.

This may be used by multiple APIS

Definition at line 143 of file common\_types.h.

**12.81.3.10 osal\_blockcount\_t**

```
typedef size_t osal_blockcount_t
```

A type used to represent a number of blocks or buffers

This is used with file system and queue implementations.

Definition at line 116 of file common\_types.h.

**12.81.3.11 osal\_id\_t**

```
typedef uint32 osal_id_t
```

A type to be used for OSAL resource identifiers. This typedef is backward compatible with the IDs from older versions of OSAL

Definition at line 108 of file common\_types.h.

**12.81.3.12 osal\_index\_t**

```
typedef uint32 osal_index_t
```

A type used to represent an index into a table structure

This is used when referring directly to a table index as opposed to an object ID. It is primarily intended for internal use, but is also output from public APIs such as [OS\\_ObjectIdToIndex\(\)](#).

Definition at line 126 of file common\_types.h.

**12.81.3.13 osal\_objtype\_t**

```
typedef uint32 osal_objtype_t
```

A type used to represent the runtime type or category of an OSAL object

Definition at line 131 of file common\_types.h.

**12.81.3.14 osal\_status\_t**

```
typedef int32 osal_status_t
```

The preferred type to represent OSAL status codes defined in [osapi-error.h](#)

Definition at line 136 of file common\_types.h.

**12.81.3.15 uint16**

```
typedef uint16_t uint16
```

Definition at line 84 of file common\_types.h.

**12.81.3.16 uint32**

```
typedef uint32_t uint32
```

Definition at line 85 of file common\_types.h.

**12.81.3.17 uint64**

```
typedef uint64_t uint64
```

Definition at line 86 of file common\_types.h.

**12.81.3.18 uint8**

```
typedef uint8_t uint8
```

Definition at line 83 of file common\_types.h.

**12.81.4 Function Documentation****12.81.4.1 CompileTimeAssert() [1/9]**

```
CompileTimeAssert (
    sizeof(uint8) == 1,
    TypeUint8WrongSize )
```

**12.81.4.2 CompileTimeAssert() [2/9]**

```
CompileTimeAssert (
    sizeof(uint16) == 2,
    TypeUint16WrongSize )
```

**12.81.4.3 CompileTimeAssert() [3/9]**

```
CompileTimeAssert (
    sizeof(uint32) == 4,
    TypeUint32WrongSize )
```

**12.81.4.4 CompileTimeAssert() [4/9]**

```
CompileTimeAssert (
    sizeof(uint64) == 8,
    TypeUint64WrongSize )
```

#### 12.81.4.5 `CompileTimeAssert()` [5/9]

```
CompileTimeAssert (
    sizeof(int8)  == 1,
    Typeint8WrongSize )
```

#### 12.81.4.6 `CompileTimeAssert()` [6/9]

```
CompileTimeAssert (
    sizeof(int16) == 2,
    Typeint16WrongSize )
```

#### 12.81.4.7 `CompileTimeAssert()` [7/9]

```
CompileTimeAssert (
    sizeof(int32) == 4,
    Typeint32WrongSize )
```

#### 12.81.4.8 `CompileTimeAssert()` [8/9]

```
CompileTimeAssert (
    sizeof(int64) == 8,
    Typeint64WrongSize )
```

#### 12.81.4.9 `CompileTimeAssert()` [9/9]

```
CompileTimeAssert (
    sizeof(cpuaddr) >= sizeof(void *) ,
    TypePtrWrongSize )
```

### 12.82 osal/src/os/inc/osapi-binsem.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

#### Data Structures

- struct `OS_bin_sem_prop_t`  
*OSAL binary semaphore properties.*

## Macros

- `#define OS_SEM_FULL 1`  
*Semaphore full state.*
- `#define OS_SEM_EMPTY 0`  
*Semaphore empty state.*

## Functions

- `int32 OS_BinSemCreate (osal_id_t *sem_id, const char *sem_name, uint32 sem_initial_value, uint32 options)`  
*Creates a binary semaphore.*
- `int32 OS_BinSemFlush (osal_id_t sem_id)`  
*Unblock all tasks pending on the specified semaphore.*
- `int32 OS_BinSemGive (osal_id_t sem_id)`  
*Increment the semaphore value.*
- `int32 OS_BinSemTake (osal_id_t sem_id)`  
*Decrement the semaphore value.*
- `int32 OS_BinSemTimedWait (osal_id_t sem_id, uint32 msecs)`  
*Decrement the semaphore value with a timeout.*
- `int32 OS_BinSemDelete (osal_id_t sem_id)`  
*Deletes the specified Binary Semaphore.*
- `int32 OS_BinSemGetIdByName (osal_id_t *sem_id, const char *sem_name)`  
*Find an existing semaphore ID by name.*
- `int32 OS_BinSemGetInfo (osal_id_t sem_id, OS_bin_sem_prop_t *bin_prop)`  
*Fill a property object buffer with details regarding the resource.*

### 12.82.1 Detailed Description

Declarations and prototypes for binary semaphores

## 12.83 osal/src/os/inc/osapi-bsp.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

## Functions

- `void OS_BSP_SetResourceTypeConfig (uint32 ResourceType, uint32 ConfigOptionValue)`
- `uint32 OS_BSP_GetResourceTypeConfig (uint32 ResourceType)`
- `uint32 OS_BSP_GetArgC (void)`
- `char *const * OS_BSP_GetArgV (void)`
- `void OS_BSP_SetExitCode (int32 code)`

### 12.83.1 Detailed Description

Declarations and prototypes for OSAL BSP

## 12.84 osal/src/os/inc/osapi-clock.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

### Data Structures

- struct `OS_time_t`  
*OSAL time interval structure.*

### Enumerations

- enum { `OS_TIME_TICK_RESOLUTION_NS` = 100, `OS_TIME_TICKS_PER_SECOND` = 1000000000 / `OS_TIME_TICK_RESOLUTION_NS`, `OS_TIME_TICKS_PER_MSEC` = 1000000 / `OS_TIME_TICK_RESOLUTION_NS`, `OS_TIME_TICKS_PER_USEC` = 1000 / `OS_TIME_TICK_RESOLUTION_NS` }

*Multippliers/divisors to convert ticks into standardized units.*

### Functions

- `int32 OS_GetLocalTime (OS_time_t *time_struct)`  
*Get the local time.*
- `int32 OS_SetLocalTime (const OS_time_t *time_struct)`  
*Set the local time.*
- static `int64 OS_TimeGetTotalSeconds (OS_time_t tm)`  
*Get interval from an `OS_time_t` object normalized to whole number of seconds.*
- static `int64 OS_TimeGetTotalMilliseconds (OS_time_t tm)`  
*Get interval from an `OS_time_t` object normalized to millisecond units.*
- static `int64 OS_TimeGetTotalMicroseconds (OS_time_t tm)`  
*Get interval from an `OS_time_t` object normalized to microsecond units.*
- static `int64 OS_TimeGetTotalNanoseconds (OS_time_t tm)`  
*Get interval from an `OS_time_t` object normalized to nanosecond units.*
- static `int64 OS_TimeGetFractionalPart (OS_time_t tm)`  
*Get subseconds portion (fractional part only) from an `OS_time_t` object.*
- static `uint32 OS_TimeGetSubsecondsPart (OS_time_t tm)`  
*Get 32-bit normalized subseconds (fractional part only) from an `OS_time_t` object.*
- static `uint32 OS_TimeGetMillisecondsPart (OS_time_t tm)`  
*Get milliseconds portion (fractional part only) from an `OS_time_t` object.*
- static `uint32 OS_TimeGetMicrosecondsPart (OS_time_t tm)`  
*Get microseconds portion (fractional part only) from an `OS_time_t` object.*
- static `uint32 OS_TimeGetNanosecondsPart (OS_time_t tm)`  
*Get nanoseconds portion (fractional part only) from an `OS_time_t` object.*

*Get nanoseconds portion (fractional part only) from an [OS\\_time\\_t](#) object.*

- static [OS\\_time\\_t OS\\_TimeAssembleFromNanoseconds](#) (int64 seconds, uint32 nanoseconds)  
*Assemble/Convert a number of seconds + nanoseconds into an [OS\\_time\\_t](#) interval.*
- static [OS\\_time\\_t OS\\_TimeAssembleFromMicroseconds](#) (int64 seconds, uint32 microseconds)  
*Assemble/Convert a number of seconds + microseconds into an [OS\\_time\\_t](#) interval.*
- static [OS\\_time\\_t OS\\_TimeAssembleFromMilliseconds](#) (int64 seconds, uint32 milliseconds)  
*Assemble/Convert a number of seconds + milliseconds into an [OS\\_time\\_t](#) interval.*
- static [OS\\_time\\_t OS\\_TimeAssembleFromSubseconds](#) (int64 seconds, uint32 subseconds)  
*Assemble/Convert a number of seconds + subseconds into an [OS\\_time\\_t](#) interval.*
- static [OS\\_time\\_t OS\\_TimeAdd](#) ([OS\\_time\\_t](#) time1, [OS\\_time\\_t](#) time2)  
*Computes the sum of two time intervals.*
- static [OS\\_time\\_t OS\\_TimeSubtract](#) ([OS\\_time\\_t](#) time1, [OS\\_time\\_t](#) time2)  
*Computes the difference between two time intervals.*

#### 12.84.1 Detailed Description

Declarations and prototypes for osapi-clock module

#### 12.84.2 Enumeration Type Documentation

##### 12.84.2.1 anonymous enum

anonymous enum

Multipliers/divisors to convert ticks into standardized units.

Various fixed conversion factor constants used by the conversion routines

A 100ns tick time allows max intervals of about +/- 14000 years in a 64-bit signed integer value.

##### Note

Applications should not directly use these values, but rather use conversion routines below to obtain standardized units (seconds/microseconds/etc).

##### Enumerator

<code>OS_TIME_TICK_RESOLUTION_NS</code>	
<code>OS_TIME_TICKS_PER_SECOND</code>	
<code>OS_TIME_TICKS_PER_MSEC</code>	
<code>OS_TIME_TICKS_PER_USEC</code>	

Definition at line 61 of file osapi-clock.h.

## 12.85 osal/src/os/inc/osapi-common.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

### Typedefs

- **typedef int32(\* OS\_EventHandler\_t)** (**OS\_Event\_t** event, **osal\_id\_t** object\_id, void \*data)  
*A callback routine for event handling.*

### Enumerations

- **enum OS\_Event\_t {**  
**OS\_EVENT\_RESERVED** = 0, **OS\_EVENT\_RESOURCE\_ALLOCATED**, **OS\_EVENT\_RESOURCE\_CREATED**,  
**OS\_EVENT\_RESOURCE\_DELETED**,  
**OS\_EVENT\_TASK\_STARTUP**, **OS\_EVENT\_MAX** **}**  
*A set of events that can be used with BSP event callback routines.*

### Functions

- **void OS\_Application\_Startup (void)**  
*Application startup.*
- **void OS\_Application\_Run (void)**  
*Application run.*
- **int32 OS\_API\_Init (void)**  
*Initialization of API.*
- **void OS\_API\_Teardown (void)**  
*Teardown/de-initialization of OSAL API.*
- **void OS\_IdleLoop (void)**  
*Background thread implementation - waits forever for events to occur.*
- **void OS\_DeleteAllObjects (void)**  
*delete all resources created in OSAL.*
- **void OS\_ApplicationShutdown (uint8 flag)**  
*Initiate orderly shutdown.*
- **void OS\_ApplicationExit (int32 Status)**  
*Exit/Abort the application.*
- **int32 OS\_RegisterEventHandler (OS\_EventHandler\_t handler)**  
*Callback routine registration.*

#### 12.85.1 Detailed Description

Declarations and prototypes for general OSAL functions that are not part of a subsystem

## 12.85.2 Typedef Documentation

### 12.85.2.1 OS\_EventHandler\_t

```
typedef int32 (* OS_EventHandler_t) (OS_Event_t event, osal_id_t object_id, void *data)
```

A callback routine for event handling.

**Parameters**

in	<i>event</i>	The event that occurred
in	<i>object_id</i>	The associated object_id, or 0 if not associated with an object
in, out	<i>data</i>	An abstract data/context object associated with the event, or NULL.

**Returns**

status Execution status, see [OSAL Return Code Defines](#).

Definition at line 98 of file osapi-common.h.

**12.85.3 Enumeration Type Documentation****12.85.3.1 OS\_Event\_t**

enum [OS\\_Event\\_t](#)

A set of events that can be used with BSP event callback routines.

**Enumerator**

OS_EVENT_RESERVED	no-op/reserved event id value
OS_EVENT_RESOURCE_ALLOCATED	resource/id has been newly allocated but not yet created. This event is invoked from WITHIN the locked region, in the context of the task which is allocating the resource. If the handler returns non-success, the error will be returned to the caller and the creation process is aborted.
OS_EVENT_RESOURCE_CREATED	resource/id has been fully created/finalized. Invoked outside locked region, in the context of the task which created the resource. Data object is not used, passed as NULL. Return value is ignored - this is for information purposes only.
OS_EVENT_RESOURCE_DELETED	resource/id has been deleted. Invoked outside locked region, in the context of the task which deleted the resource. Data object is not used, passed as NULL. Return value is ignored - this is for information purposes only.
OS_EVENT_TASK_STARTUP	New task is starting. Invoked outside locked region, in the context of the task which is currently starting, before the entry point is called. Data object is not used, passed as NULL. If the handler returns non-success, task startup is aborted and the entry point is not called.
OS_EVENT_MAX	placeholder for end of enum, not used

Definition at line 34 of file osapi-common.h.

## 12.86 osal/src/os/inc/osapi-constants.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

### Macros

- #define OS\_PEND (-1)
- #define OS\_CHECK (0)
- #define OS\_OBJECT\_ID\_UNDEFINED ((osal\_id\_t){0})  
*Initializer for the osal\_id\_t type which will not match any valid value.*
- #define OS\_OBJECT\_CREATOR\_ANY OS\_OBJECT\_ID\_UNDEFINED  
*Constant that may be passed to OS\_ForEachObject() /OS\_ForEachObjectOfType() to match any creator (i.e. get all objects)*
- #define OS\_MAX\_LOCAL\_PATH\_LEN (OS\_MAX\_PATH\_LEN + OS\_FS\_PHYS\_NAME\_LEN)  
*Maximum length of a local/native path name string.*

### 12.86.1 Detailed Description

General constants for OSAL that are shared across subsystems

### 12.86.2 Macro Definition Documentation

#### 12.86.2.1 OS\_CHECK

```
#define OS_CHECK (0)
```

Definition at line 35 of file osapi-constants.h.

#### 12.86.2.2 OS\_MAX\_LOCAL\_PATH\_LEN

```
#define OS_MAX_LOCAL_PATH_LEN (OS_MAX_PATH_LEN + OS_FS_PHYS_NAME_LEN)
```

Maximum length of a local/native path name string.

This is a concatenation of the OSAL virtual path with the system mount point or device name

Definition at line 54 of file osapi-constants.h.

### 12.86.2.3 OS\_OBJECT\_CREATOR\_ANY

```
#define OS_OBJECT_CREATOR_ANY OS_OBJECT_ID_UNDEFINED
```

Constant that may be passed to [OS\\_ForEachObject\(\)](#)/[OS\\_ForEachObjectType\(\)](#) to match any creator (i.e. get all objects)

Definition at line 46 of file osapi-constants.h.

### 12.86.2.4 OS\_OBJECT\_ID\_UNDEFINED

```
#define OS_OBJECT_ID_UNDEFINED ((osal_id_t) {0})
```

Initializer for the osal\_id\_t type which will not match any valid value.

Definition at line 40 of file osapi-constants.h.

Referenced by [DS\\_AppInitialize\(\)](#), [DS\\_FileCloseDest\(\)](#), and [DS\\_FileCreateDest\(\)](#).

### 12.86.2.5 OS\_PEND

```
#define OS_PEND (-1)
```

Definition at line 34 of file osapi-constants.h.

## 12.87 osal/src/os/inc/osapi-countsem.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

### Data Structures

- struct [OS\\_count\\_sem\\_prop\\_t](#)

*OSAL counting semaphore properties.*

## Functions

- `int32 OS_CountSemCreate (osal_id_t *sem_id, const char *sem_name, uint32 sem_initial_value, uint32 options)`  
*Creates a counting semaphore.*
- `int32 OS_CountSemGive (osal_id_t sem_id)`  
*Increment the semaphore value.*
- `int32 OS_CountSemTake (osal_id_t sem_id)`  
*Decrement the semaphore value.*
- `int32 OS_CountSemTimedWait (osal_id_t sem_id, uint32 msecs)`  
*Decrement the semaphore value with timeout.*
- `int32 OS_CountSemDelete (osal_id_t sem_id)`  
*Deletes the specified counting Semaphore.*
- `int32 OS_CountSemGetIdByName (osal_id_t *sem_id, const char *sem_name)`  
*Find an existing semaphore ID by name.*
- `int32 OS_CountSemGetInfo (osal_id_t sem_id, OS_count_sem_prop_t *count_prop)`  
*Fill a property object buffer with details regarding the resource.*

### 12.87.1 Detailed Description

Declarations and prototypes for counting semaphores

## 12.88 osal/src/os/inc/osapi-dir.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

## Data Structures

- `struct os_dirent_t`  
*Directory entry.*

## Macros

- `#define OS_DIRENTRY_NAME(x) ((x).FileName)`  
*Access filename part of the dirent structure.*

## Functions

- [int32 OS\\_DirectoryOpen \(osal\\_id\\_t \\*dir\\_id, const char \\*path\)](#)  
*Opens a directory.*
- [int32 OS\\_DirectoryClose \(osal\\_id\\_t dir\\_id\)](#)  
*Closes an open directory.*
- [int32 OS\\_DirectoryRewind \(osal\\_id\\_t dir\\_id\)](#)  
*Rewinds an open directory.*
- [int32 OS\\_DirectoryRead \(osal\\_id\\_t dir\\_id, os\\_dirent\\_t \\*dirent\)](#)  
*Reads the next name in the directory.*
- [int32 OS\\_mkdir \(const char \\*path, uint32 access\)](#)  
*Makes a new directory.*
- [int32 OS\\_rmdir \(const char \\*path\)](#)  
*Removes a directory from the file system.*

### 12.88.1 Detailed Description

Declarations and prototypes for directories

### 12.88.2 Macro Definition Documentation

#### 12.88.2.1 OS\_DIRENTRY\_NAME

```
#define OS_DIRENTRY_NAME (x) ((x).FileName)
```

Access filename part of the dirent structure.

Definition at line 38 of file osapi-dir.h.

### 12.89 osal/src/os/inc/osapi-error.h File Reference

```
#include "common_types.h"
```

## Macros

- #define **OS\_ERROR\_NAME\_LENGTH** 35  
*Error string name length.*
- #define **OS\_STATUS\_STRING\_LENGTH** 12  
*Status converted to string length limit.*
- #define **OS\_SUCCESS** (0)  
*Successful execution.*
- #define **OS\_ERROR** (-1)  
*Failed execution.*
- #define **OS\_INVALID\_POINTER** (-2)  
*Invalid pointer.*
- #define **OS\_ERROR\_ADDRESS\_MISALIGNED** (-3)  
*Address misalignment.*
- #define **OS\_ERROR\_TIMEOUT** (-4)  
*Error timeout.*
- #define **OS\_INVALID\_INT\_NUM** (-5)  
*Invalid Interrupt number.*
- #define **OS\_SEM\_FAILURE** (-6)  
*Semaphore failure.*
- #define **OS\_SEM\_TIMEOUT** (-7)  
*Semaphore timeout.*
- #define **OS\_QUEUE\_EMPTY** (-8)  
*Queue empty.*
- #define **OS\_QUEUE\_FULL** (-9)  
*Queue full.*
- #define **OS\_QUEUE\_TIMEOUT** (-10)  
*Queue timeout.*
- #define **OS\_QUEUE\_INVALID\_SIZE** (-11)  
*Queue invalid size.*
- #define **OS\_QUEUE\_ID\_ERROR** (-12)  
*Queue ID error.*
- #define **OS\_ERR\_NAME\_TOO\_LONG** (-13)  
*name length including null terminator greater than `OS_MAX_API_NAME`*
- #define **OS\_ERR\_NO\_FREE\_IDS** (-14)  
*No free IDs.*
- #define **OS\_ERR\_NAME\_TAKEN** (-15)  
*Name taken.*
- #define **OS\_ERR\_INVALID\_ID** (-16)  
*Invalid ID.*
- #define **OS\_ERR\_NAME\_NOT\_FOUND** (-17)  
*Name not found.*
- #define **OS\_ERR\_SEM\_NOT\_FULL** (-18)  
*Semaphore not full.*
- #define **OS\_ERR\_INVALID\_PRIORITY** (-19)  
*Invalid priority.*
- #define **OS\_INVALID\_SEM\_VALUE** (-20)

- `#define OS_ERR_FILE (-27)`  
*File error.*
- `#define OS_ERR_NOT_IMPLEMENTED (-28)`  
*Not implemented.*
- `#define OS_TIMER_ERR_INVALID_ARGS (-29)`  
*Timer invalid arguments.*
- `#define OS_TIMER_ERR_TIMER_ID (-30)`  
*Timer ID error.*
- `#define OS_TIMER_ERR_UNAVAILABLE (-31)`  
*Timer unavailable.*
- `#define OS_TIMER_ERR_INTERNAL (-32)`  
*Timer internal error.*
- `#define OS_ERR_OBJECT_IN_USE (-33)`  
*Object in use.*
- `#define OS_ERR_BAD_ADDRESS (-34)`  
*Bad address.*
- `#define OS_ERR_INCORRECT_OBJ_STATE (-35)`  
*Incorrect object state.*
- `#define OS_ERR_INCORRECT_OBJ_TYPE (-36)`  
*Incorrect object type.*
- `#define OS_ERR_STREAM_DISCONNECTED (-37)`  
*Stream disconnected.*
- `#define OS_ERR_OPERATION_NOT_SUPPORTED (-38)`  
*Requested operation not support on supplied object(s)*
- `#define OS_ERR_INVALID_SIZE (-40)`  
*Invalid Size.*
- `#define OS_ERR_OUTPUT_TOO_LARGE (-41)`  
*Size of output exceeds limit.*
- `#define OS_ERR_INVALID_ARGUMENT (-42)`  
*Invalid argument value (other than ID or size)*
- `#define OS_FS_ERR_PATH_TOO_LONG (-103)`  
*FS path too long.*
- `#define OS_FS_ERR_NAME_TOO_LONG (-104)`  
*FS name too long.*
- `#define OS_FS_ERR_DRIVE_NOT_CREATED (-106)`  
*FS drive not created.*
- `#define OS_FS_ERR_DEVICE_NOT_FREE (-107)`  
*FS device not free.*
- `#define OS_FS_ERR_PATH_INVALID (-108)`  
*FS path invalid.*

## Typedefs

- `typedef char os_err_name_t[OS_ERROR_NAME_LENGTH]`  
*For the `OS_GetErrorName()` function, to ensure everyone is making an array of the same length.*
- `typedef char os_status_string_t[OS_STATUS_STRING_LENGTH]`  
*For the `OS_StatusToString()` function, to ensure everyone is making an array of the same length.*

## Functions

- static long [OS\\_StatusToInteger \(osal\\_status\\_t Status\)](#)  
*Convert a status code to a native "long" type.*
- int32 [OS\\_GetErrorName \(int32 error\\_num, os\\_err\\_name\\_t \\*err\\_name\)](#)  
*Convert an error number to a string.*
- char \* [OS\\_StatusToString \(osal\\_status\\_t status, os\\_status\\_string\\_t \\*status\\_string\)](#)  
*Convert status to a string.*

### 12.89.1 Detailed Description

OSAL error code definitions

### 12.89.2 Macro Definition Documentation

#### 12.89.2.1 OS\_ERROR\_NAME\_LENGTH

```
#define OS_ERROR_NAME_LENGTH 35
```

Error string name length.

The sizes of strings in OSAL functions are built with this limit in mind. Always check the uses of `os_err_name_t` when changing this value.

Definition at line 35 of file `osapi-error.h`.

#### 12.89.2.2 OS\_STATUS\_STRING\_LENGTH

```
#define OS_STATUS_STRING_LENGTH 12
```

Status converted to string length limit.

Used for sizing `os_status_string_t` intended for use in printing `osal_status_t` values. Sized to fit `LONG_MIN` including NULL termination

Definition at line 55 of file `osapi-error.h`.

### 12.89.3 Typedef Documentation

### 12.89.3.1 os\_err\_name\_t

```
typedef char os_err_name_t[OS_ERROR_NAME_LENGTH]
```

For the [OS\\_GetErrorName\(\)](#) function, to ensure everyone is making an array of the same length.

Implementation note for developers:

The sizes of strings in OSAL functions are built with this `OS_ERROR_NAME_LENGTH` limit in mind. Always check the uses of `os_err_name_t` when changing this value.

Definition at line 47 of file osapi-error.h.

### 12.89.3.2 os\_status\_string\_t

```
typedef char os_status_string_t[OS_STATUS_STRING_LENGTH]
```

For the [OS\\_StatusToString\(\)](#) function, to ensure everyone is making an array of the same length.

Definition at line 61 of file osapi-error.h.

## 12.90 osal/src/os/inc/osapi-file.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
#include "osapi-clock.h"
```

### Data Structures

- struct [OS\\_file\\_prop\\_t](#)

*OSAL file properties.*

- struct [os\\_fstat\\_t](#)

*File system status.*

## Macros

- `#define OS_READ_ONLY 0`
- `#define OS_WRITE_ONLY 1`
- `#define OS_READ_WRITE 2`
- `#define OS_SEEK_SET 0`
- `#define OS_SEEK_CUR 1`
- `#define OS_SEEK_END 2`
- `#define OS_FILESTAT_MODE(x) ((x). FileModeBits)`

*Access file stat mode bits.*
- `#define OS_FILESTAT_ISDIR(x) ((x). FileModeBits & OS_FILESTAT_MODE_DIR)`

*File stat is directory logical.*
- `#define OS_FILESTAT_EXEC(x) ((x). FileModeBits & OS_FILESTAT_MODE_EXEC)`

*File stat is executable logical.*
- `#define OS_FILESTAT_WRITE(x) ((x). FileModeBits & OS_FILESTAT_MODE_WRITE)`

*File stat is write enabled logical.*
- `#define OS_FILESTAT_READ(x) ((x). FileModeBits & OS_FILESTAT_MODE_READ)`

*File stat is read enabled logical.*
- `#define OS_FILESTAT_SIZE(x) ((x).FileSize)`

*Access file stat size field.*
- `#define OS_FILESTAT_TIME(x) (OS_TimeGetTotalSeconds((x).FileTime))`

*Access file stat time field as a whole number of seconds.*

## Enumerations

- `enum { OS_FILESTAT_MODE_EXEC = 0x000001, OS_FILESTAT_MODE_WRITE = 0x000002, OS_FILESTAT_MODE_READ = 0x000004, OS_FILESTAT_MODE_DIR = 0x10000 }` 

*File stat mode bits.*
- `enum OS_file_flag_t { OS_FILE_FLAG_NONE = 0x00, OS_FILE_FLAG_CREATE = 0x01, OS_FILE_FLAG_TRUNCATE = 0x02 }`

*Flags that can be used with opening of a file (bitmask)*

## Functions

- `int32 OS_OpenCreate (osal_id_t *filedes, const char *path, int32 flags, int32 access_mode)`

*Open or create a file.*
- `int32 OS_close (osal_id_t filedes)`

*Closes an open file handle.*
- `int32 OS_read (osal_id_t filedes, void *buffer, size_t nbytes)`

*Read from a file handle.*
- `int32 OS_write (osal_id_t filedes, const void *buffer, size_t nbytes)`

*Write to a file handle.*
- `int32 OS_TimedRead (osal_id_t filedes, void *buffer, size_t nbytes, int32 timeout)`

*File/Stream input read with a timeout.*
- `int32 OS_TimedWrite (osal_id_t filedes, const void *buffer, size_t nbytes, int32 timeout)`

*File/Stream output write with a timeout.*
- `int32 OS_chmod (const char *path, uint32 access_mode)`

- `int32 OS_stat (const char *path, os_fstat_t *filestats)`

*Changes the permissions of a file.*
- `int32 OS_lseek (osal_id_t filedes, int32 offset, uint32 whence)`

*Obtain information about a file or directory.*
- `int32 OS_remove (const char *path)`

*Seeks to the specified position of an open file.*
- `int32 OS_rename (const char *old_filename, const char *new_filename)`

*Removes a file from the file system.*
- `int32 OS_cp (const char *src, const char *dest)`

*Renames a file.*
- `int32 OS_mv (const char *src, const char *dest)`

*Copies a single file from src to dest.*
- `int32 OS_FDGetInfo (osal_id_t filedes, OS_file_prop_t *fd_prop)`

*Move a single file from src to dest.*
- `int32 OS_FileOpenCheck (const char *Filename)`

*Obtain information about an open file.*
- `int32 OS_CloseAllFiles (void)`

*Checks to see if a file is open.*
- `int32 OS_CloseFileByName (const char *Filename)`

*Close all open files.*
- `int32 OS_CloseFileByHandle (osal_id_t handle)`

*Close a file by filename.*

#### 12.90.1 Detailed Description

Declarations and prototypes for file objects

#### 12.90.2 Macro Definition Documentation

##### 12.90.2.1 OS\_FILESTAT\_EXEC

```
#define OS_FILESTAT_EXEC(
    x ) ((x). FileModeBits & OS_FILESTAT_MODE_EXEC)
```

File stat is executable logical.

Definition at line 92 of file osapi-file.h.

##### 12.90.2.2 OS\_FILESTAT\_ISDIR

```
#define OS_FILESTAT_ISDIR(
    x ) ((x). FileModeBits & OS_FILESTAT_MODE_DIR)
```

File stat is directory logical.

Definition at line 90 of file osapi-file.h.

### 12.90.2.3 OS\_FILESTAT\_MODE

```
#define OS_FILESTAT_MODE( x ) ((x). FileModeBits)
```

Access file stat mode bits.

Definition at line 88 of file osapi-file.h.

### 12.90.2.4 OS\_FILESTAT\_READ

```
#define OS_FILESTAT_READ( x ) ((x). FileModeBits & OS_FILESTAT_MODE_READ)
```

File stat is read enabled logical.

Definition at line 96 of file osapi-file.h.

### 12.90.2.5 OS\_FILESTAT\_SIZE

```
#define OS_FILESTAT_SIZE( x ) ((x).FileSize)
```

Access file stat size field.

Definition at line 98 of file osapi-file.h.

### 12.90.2.6 OS\_FILESTAT\_TIME

```
#define OS_FILESTAT_TIME( x ) (OS_TimeGetTotalSeconds((x).FileTime))
```

Access file stat time field as a whole number of seconds.

Definition at line 100 of file osapi-file.h.

### 12.90.2.7 OS\_FILESTAT\_WRITE

```
#define OS_FILESTAT_WRITE( x ) ((x). FileModeBits & OS_FILESTAT_MODE_WRITE)
```

File stat is write enabled logical.

Definition at line 94 of file osapi-file.h.

## 12.90.3 Enumeration Type Documentation

### 12.90.3.1 anonymous enum

```
anonymous enum
```

File stat mode bits.

We must also define replacements for the stat structure's mode bits. This is currently just a small subset since the OSAL just presents a very simplified view of the filesystem to the upper layers. And since not all OS'es are POSIX, the more POSIX-specific bits are not relevant anyway.

**Enumerator**

OS_FILESTAT_MODE_EXEC	
OS_FILESTAT_MODE_WRITE	
OS_FILESTAT_MODE_READ	
OS_FILESTAT_MODE_DIR	

Definition at line 79 of file osapi-file.h.

**12.90.3.2 OS\_file\_flag\_t**

enum [OS\\_file\\_flag\\_t](#)

Flags that can be used with opening of a file (bitmask)

**Enumerator**

OS_FILE_FLAG_NONE	
OS_FILE_FLAG_CREATE	
OS_FILE_FLAG_TRUNCATE	

Definition at line 105 of file osapi-file.h.

**12.91 osal/src/os/inc/osapi-filesystem.h File Reference**

```
#include "osconfig.h"
#include "common_types.h"
```

**Data Structures**

- struct [os\\_fsinfo\\_t](#)  
*OSAL file system info.*
- struct [OS\\_statvfs\\_t](#)

**Macros**

- #define [OS\\_CHK\\_ONLY](#) 0
- #define [OS\\_REPAIR](#) 1

## Functions

- `int32 OS_FileSysAddFixedMap (osal_id_t *filesystems_id, const char *phys_path, const char *virt_path)`  
*Create a fixed mapping between an existing directory and a virtual OSAL mount point.*
- `int32 OS_mkfs (char *address, const char *devname, const char *volname, size_t blocksize, osal_blockcount_t numblocks)`  
*Makes a file system on the target.*
- `int32 OS_mount (const char *devname, const char *mountpoint)`  
*Mounts a file system.*
- `int32 OS_initfs (char *address, const char *devname, const char *volname, size_t blocksize, osal_blockcount_t numblocks)`  
*Initializes an existing file system.*
- `int32 OS_rmfs (const char *devname)`  
*Removes a file system.*
- `int32 OS_unmount (const char *mountpoint)`  
*Unmounts a mounted file system.*
- `int32 OS_FileSysStatVolume (const char *name, OS_statvfs_t *statbuf)`  
*Obtains information about size and free space in a volume.*
- `int32 OS_chkfs (const char *name, bool repair)`  
*Checks the health of a file system and repairs it if necessary.*
- `int32 OS_FS_GetPhysDriveName (char *PhysDriveName, const char *MountPoint)`  
*Obtains the physical drive name associated with a mount point.*
- `int32 OS_TranslatePath (const char *VirtualPath, char *LocalPath)`  
*Translates an OSAL Virtual file system path to a host Local path.*
- `int32 OS_GetFsInfo (os_fsinfo_t *filesystems_info)`  
*Returns information about the file system.*

### 12.91.1 Detailed Description

Declarations and prototypes for file systems

### 12.91.2 Macro Definition Documentation

#### 12.91.2.1 OS\_CHK\_ONLY

```
#define OS_CHK_ONLY 0
```

Unused, API takes bool

Definition at line 31 of file osapi-filesystems.h.

### 12.91.2.2 OS\_REPAIR

```
#define OS_REPAIR 1
```

Unused, API takes bool

Definition at line 32 of file osapi-fs.h.

## 12.92 osal/src/os/inc/osapi-heap.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

### Data Structures

- struct [OS\\_heap\\_prop\\_t](#)

*OSAL heap properties.*

### Functions

- [int32 OS\\_HeapGetInfo \(OS\\_heap\\_prop\\_t \\*heap\\_prop\)](#)

*Return current info on the heap.*

### 12.92.1 Detailed Description

Declarations and prototypes for heap functions

## 12.93 osal/src/os/inc/osapi-idmap.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

## Macros

- `#define OS_OBJECT_INDEX_MASK 0xFFFF`  
*Object index mask.*
- `#define OS_OBJECT_TYPE_SHIFT 16`  
*Object type shift.*
- `#define OS_OBJECT_TYPE_UNDEFINED 0x00`  
*Object type undefined.*
- `#define OS_OBJECT_TYPE_OS_TASK 0x01`  
*Object task type.*
- `#define OS_OBJECT_TYPE_OS_QUEUE 0x02`  
*Object queue type.*
- `#define OS_OBJECT_TYPE_OS_COUNTSEM 0x03`  
*Object counting semaphore type.*
- `#define OS_OBJECT_TYPE_OS_BINSEM 0x04`  
*Object binary semaphore type.*
- `#define OS_OBJECT_TYPE_OS_MUTEX 0x05`  
*Object mutex type.*
- `#define OS_OBJECT_TYPE_OS_STREAM 0x06`  
*Object stream type.*
- `#define OS_OBJECT_TYPE_OS_DIR 0x07`  
*Object directory type.*
- `#define OS_OBJECT_TYPE_OS_TIMEBASE 0x08`  
*Object timebase type.*
- `#define OS_OBJECT_TYPE_OS_TIMECB 0x09`  
*Object timer callback type.*
- `#define OS_OBJECT_TYPE_OS_MODULE 0x0A`  
*Object module type.*
- `#define OS_OBJECT_TYPE_OS_FILESYS 0x0B`  
*Object file system type.*
- `#define OS_OBJECT_TYPE_OS_CONSOLE 0x0C`  
*Object console type.*
- `#define OS_OBJECT_TYPE_USER 0x10`  
*Object user type.*

## Functions

- `static unsigned long OS_ObjectIdToInteger (osal_id_t object_id)`  
*Obtain an integer value corresponding to an object ID.*
- `static osal_id_t OS_ObjectIdFromInteger (unsigned long value)`  
*Obtain an osal ID corresponding to an integer value.*
- `static bool OS_ObjectIdEqual (osal_id_t object_id1, osal_id_t object_id2)`  
*Check two OSAL object ID values for equality.*
- `static bool OS_ObjectIdDefined (osal_id_t object_id)`  
*Check if an object ID is defined.*
- `int32 OS_GetResourceName (osal_id_t object_id, char *buffer, size_t buffer_size)`  
*Obtain the name of an object given an arbitrary object ID.*

- `osal_objtype_t OS_IdentifyObject (osal_id_t object_id)`  
*Obtain the type of an object given an arbitrary object ID.*
- `int32 OS_ConvertToArrayIndex (osal_id_t object_id, osal_index_t *ArrayIndex)`  
*Converts an abstract ID into a number suitable for use as an array index.*
- `int32 OS_ObjectIdToArrayIndex (osal_objtype_t idtype, osal_id_t object_id, osal_index_t *ArrayIndex)`  
*Converts an abstract ID into a number suitable for use as an array index.*
- `void OS_ForEachObject (osal_id_t creator_id, OS_ArgCallback_t callback_ptr, void *callback_arg)`  
*call the supplied callback function for all valid object IDs*
- `void OS_ForEachObjectType (osal_objtype_t objtype, osal_id_t creator_id, OS_ArgCallback_t callback_ptr, void *callback_arg)`  
*call the supplied callback function for valid object IDs of a specific type*

### 12.93.1 Detailed Description

Declarations and prototypes for object IDs

### 12.93.2 Macro Definition Documentation

#### 12.93.2.1 OS\_OBJECT\_INDEX\_MASK

```
#define OS_OBJECT_INDEX_MASK 0xFFFF
```

Object index mask.

Definition at line 32 of file osapi-idmap.h.

#### 12.93.2.2 OS\_OBJECT\_TYPE\_SHIFT

```
#define OS_OBJECT_TYPE_SHIFT 16
```

Object type shift.

Definition at line 33 of file osapi-idmap.h.

## 12.94 osal/src/os/inc/osapi-macros.h File Reference

```
#include <stdio.h>
#include <stdlib.h>
#include <string.h>
#include "osconfig.h"
#include "common_types.h"
#include "osapi-printf.h"
```

## Macros

- `#define BUGREPORT(...)` `OS_printf(__VA_ARGS__)`
- `#define BUGCHECK(cond, errcode)`  
*Basic Bug-Checking macro.*
- `#define ARGCHECK(cond, errcode)`  
*Generic argument checking macro for non-critical values.*
- `#define LENGTHCHECK(str, len, errcode)` `ARGCHECK(memchr(str, '\0', len), errcode)`  
*String length limit check macro.*

### 12.94.1 Detailed Description

Macro definitions that are used across all OSAL subsystems

### 12.94.2 Macro Definition Documentation

#### 12.94.2.1 ARGCHECK

```
#define ARGCHECK(  
    cond,  
    errcode )
```

##### Value:

```
if (! (cond))  
{  
    return errcode;  
}
```

Generic argument checking macro for non-critical values.

This macro checks a conditional that is expected to be true, and return a value if it evaluates false.

ARGCHECK can be used to check for out of range or other invalid argument conditions which may (validly) occur at runtime and do not necessarily indicate bugs in the application.

These argument checks are NOT considered fatal errors. The application continues to run normally. This does not report the error on the console.

As such, ARGCHECK actions are always compiled in - not selectable at compile-time.

##### See also

[BUGCHECK](#) for checking critical values that indicate bugs

Definition at line 122 of file osapi-macros.h.

### 12.94.2.2 BUGCHECK

```
#define BUGCHECK(
    cond,
    errcode )
```

#### Value:

```
if (! (cond))
{
    \
    BUGREPORT("\n**BUG** %s():%d:check \'%s\' FAILED --> %s\n\n", __func__, __LINE__, #cond, #errcode);
    \
    return errcode;
}
```

Basic Bug-Checking macro.

This macro checks a conditional, and if it is FALSE, then it generates a report - which may in turn contain additional actions.

BUGCHECK should only be used for conditions which are critical and must always be true. If such a condition is ever false then it indicates a bug in the application which must be resolved. It may or may not be possible to continue operation if a bugcheck fails.

#### See also

[ARGCHECK](#) for checking non-critical values

Definition at line 96 of file osapi-macros.h.

### 12.94.2.3 BUGREPORT

```
#define BUGREPORT(
    ... ) OS_printf(__VA_ARGS__)
```

Definition at line 79 of file osapi-macros.h.

### 12.94.2.4 LENGTHCHECK

```
#define LENGTHCHECK(
    str,
    len,
    errcode ) ARGCHECK(memchr(str, '\0', len), errcode)
```

String length limit check macro.

This macro is a specialized version of ARGCHECK that confirms a string will fit into a buffer of the specified length, and return an error code if it will not.

#### Note

this uses ARGCHECK, thus treating a string too long as a normal runtime (i.e. non-bug) error condition with a typical error return to the caller.

Definition at line 137 of file osapi-macros.h.

## 12.95 osal/src/os/inc/osapi-module.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

### Data Structures

- struct [OS\\_module\\_address\\_t](#)  
*OSAL module address properties.*
- struct [OS\\_module\\_prop\\_t](#)  
*OSAL module properties.*
- struct [OS\\_static\\_symbol\\_record\\_t](#)  
*Associates a single symbol name with a memory address.*

### Macros

- #define [OS\\_MODULE\\_FLAG\\_GLOBAL\\_SYMBOLS](#) 0x00  
*Requests [OS\\_ModuleLoad\(\)](#) to add the symbols to the global symbol table.*
- #define [OS\\_MODULE\\_FLAG\\_LOCAL\\_SYMBOLS](#) 0x01  
*Requests [OS\\_ModuleLoad\(\)](#) to keep the symbols local/private to this module.*

### Functions

- [int32 OS\\_SymbolLookup \(cpuaddr \\*symbol\\_address, const char \\*symbol\\_name\)](#)  
*Find the Address of a Symbol.*
- [int32 OS\\_ModuleSymbolLookup \(osal\\_id\\_t module\\_id, cpuaddr \\*symbol\\_address, const char \\*symbol\\_name\)](#)  
*Find the Address of a Symbol within a module.*
- [int32 OS\\_SymbolTableDump \(const char \\*filename, size\\_t size\\_limit\)](#)  
*Dumps the system symbol table to a file.*
- [int32 OS\\_ModuleLoad \(osal\\_id\\_t \\*module\\_id, const char \\*module\\_name, const char \\*filename, uint32 flags\)](#)  
*Loads an object file.*
- [int32 OS\\_ModuleUnload \(osal\\_id\\_t module\\_id\)](#)  
*Unloads the module file.*
- [int32 OS\\_ModuleInfo \(osal\\_id\\_t module\\_id, OS\\_module\\_prop\\_t \\*module\\_info\)](#)  
*Obtain information about a module.*

### 12.95.1 Detailed Description

Declarations and prototypes for module subsystem

### 12.95.2 Macro Definition Documentation

### 12.95.2.1 OS\_MODULE\_FLAG\_GLOBAL\_SYMBOLS

```
#define OS_MODULE_FLAG_GLOBAL_SYMBOLS 0x00
```

Requests [OS\\_ModuleLoad\(\)](#) to add the symbols to the global symbol table.

When supplied as the "flags" argument to [OS\\_ModuleLoad\(\)](#), this indicates that the symbols in the loaded module should be added to the global symbol table. This will make symbols in this library available for use when resolving symbols in future module loads.

This is the default mode of operation for [OS\\_ModuleLoad\(\)](#).

#### Note

On some operating systems, use of this option may make it difficult to unload the module in the future, if the symbols are in use by other entities.

Definition at line 49 of file osapi-module.h.

### 12.95.2.2 OS\_MODULE\_FLAG\_LOCAL\_SYMBOLS

```
#define OS_MODULE_FLAG_LOCAL_SYMBOLS 0x01
```

Requests [OS\\_ModuleLoad\(\)](#) to keep the symbols local/private to this module.

When supplied as the "flags" argument to [OS\\_ModuleLoad\(\)](#), this indicates that the symbols in the loaded module should NOT be added to the global symbol table. This means the symbols in the loaded library will not be available for use by other modules.

Use this option is recommended for cases where no other entities will need to reference symbols within this module. This helps ensure that the module can be more safely unloaded in the future, by preventing other modules from binding to it. It also helps reduce the likelihood of symbol name conflicts among modules.

#### Note

To look up symbols within a module loaded with this flag, use [OS\\_SymbolLookupInModule\(\)](#) instead of [OS\\_SymbolLookup\(\)](#). Also note that references obtained using this method are not tracked by the OS; the application must ensure that all references obtained in this manner have been cleaned up/released before unloading the module.

Definition at line 71 of file osapi-module.h.

## 12.96 osal/src/os/inc/osapi-mutex.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

## Data Structures

- struct [OS\\_mut\\_sem\\_prop\\_t](#)

*OSAL mutex properties.*

## Functions

- [int32 OS\\_MutSemCreate \(osal\\_id\\_t \\*sem\\_id, const char \\*sem\\_name, uint32 options\)](#)  
*Creates a mutex semaphore.*
- [int32 OS\\_MutSemGive \(osal\\_id\\_t sem\\_id\)](#)  
*Releases the mutex object referenced by sem\_id.*
- [int32 OS\\_MutSemTake \(osal\\_id\\_t sem\\_id\)](#)  
*Acquire the mutex object referenced by sem\_id.*
- [int32 OS\\_MutSemDelete \(osal\\_id\\_t sem\\_id\)](#)  
*Deletes the specified Mutex Semaphore.*
- [int32 OS\\_MutSemGetIdByName \(osal\\_id\\_t \\*sem\\_id, const char \\*sem\\_name\)](#)  
*Find an existing mutex ID by name.*
- [int32 OS\\_MutSemGetInfo \(osal\\_id\\_t sem\\_id, OS\\_mut\\_sem\\_prop\\_t \\*mut\\_prop\)](#)  
*Fill a property object buffer with details regarding the resource.*

### 12.96.1 Detailed Description

Declarations and prototypes for mutexes

## 12.97 osal/src/os/inc/osapi-network.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

## Functions

- [int32 OS\\_NetworkGetID \(void\)](#)  
*Gets the network ID of the local machine.*
- [int32 OS\\_NetworkGetHostName \(char \\*host\\_name, size\\_t name\\_len\)](#)  
*Gets the local machine network host name.*

### 12.97.1 Detailed Description

Declarations and prototypes for network subsystem

## 12.98 osal/src/os/inc/osapi-printf.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

### Functions

- void **OS\_printf** (const char \*string,...) **OS\_PRINTF(1)**  
*Abstraction for the system printf() call.*
- void **OS\_printf\_disable** (void)  
*This function disables the output from OS\_printf.*
- void **OS\_printf\_enable** (void)  
*This function enables the output from OS\_printf.*

### 12.98.1 Detailed Description

Declarations and prototypes for printf/console output

## 12.99 osal/src/os/inc/osapi-queue.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

### Data Structures

- struct **OS\_queue\_prop\_t**  
*OSAL queue properties.*

### Functions

- int32 **OS\_QueueCreate** (osal\_id\_t \*queue\_id, const char \*queue\_name, osal\_blockcount\_t queue\_depth, size\_t data\_size, uint32 flags)  
*Create a message queue.*
- int32 **OS\_QueueDelete** (osal\_id\_t queue\_id)  
*Deletes the specified message queue.*
- int32 **OS\_QueueGet** (osal\_id\_t queue\_id, void \*data, size\_t size, size\_t \*size\_copied, int32 timeout)  
*Receive a message on a message queue.*
- int32 **OS\_QueuePut** (osal\_id\_t queue\_id, const void \*data, size\_t size, uint32 flags)  
*Put a message on a message queue.*
- int32 **OS\_QueueGetIdByName** (osal\_id\_t \*queue\_id, const char \*queue\_name)  
*Find an existing queue ID by name.*
- int32 **OS\_QueueGetInfo** (osal\_id\_t queue\_id, OS\_queue\_prop\_t \*queue\_prop)  
*Fill a property object buffer with details regarding the resource.*

### 12.99.1 Detailed Description

Declarations and prototypes for queue subsystem

## 12.100 osal/src/os/inc/osapi-select.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

### Data Structures

- struct [OS\\_FdSet](#)

*An abstract structure capable of holding several OSAL IDs.*

### Enumerations

- enum [OS\\_StreamState\\_t](#) { [OS\\_STREAM\\_STATE\\_BOUND](#) = 0x01, [OS\\_STREAM\\_STATE\\_CONNECTED](#) = 0x02, [OS\\_STREAM\\_STATE\\_READABLE](#) = 0x04, [OS\\_STREAM\\_STATE\\_WRITABLE](#) = 0x08 }

*For the [OS\\_SelectSingle\(\)](#) function's in/out [StateFlags](#) parameter, the state(s) of the stream and the result of the select is a combination of one or more of these states.*

### Functions

- [int32 OS\\_SelectMultiple \(OS\\_FdSet \\*ReadSet, OS\\_FdSet \\*WriteSet, int32 msecs\)](#)  
*Wait for events across multiple file handles.*
- [int32 OS\\_SelectSingle \(osal\\_id\\_t objid, uint32 \\*StateFlags, int32 msecs\)](#)  
*Wait for events on a single file handle.*
- [int32 OS\\_SelectFdZero \(OS\\_FdSet \\*Set\)](#)  
*Clear a FdSet structure.*
- [int32 OS\\_SelectFdAdd \(OS\\_FdSet \\*Set, osal\\_id\\_t objid\)](#)  
*Add an ID to an FdSet structure.*
- [int32 OS\\_SelectFdClear \(OS\\_FdSet \\*Set, osal\\_id\\_t objid\)](#)  
*Clear an ID from an FdSet structure.*
- [bool OS\\_SelectFdsSet \(const OS\\_FdSet \\*Set, osal\\_id\\_t objid\)](#)  
*Check if an FdSet structure contains a given ID.*

### 12.100.1 Detailed Description

Declarations and prototypes for select abstraction

### 12.100.2 Enumeration Type Documentation

### 12.100.2.1 OS\_StreamState\_t

enum `OS_StreamState_t`

For the [OS\\_SelectSingle\(\)](#) function's in/out StateFlags parameter, the state(s) of the stream and the result of the select is a combination of one or more of these states.

#### See also

[OS\\_SelectSingle\(\)](#)

#### Enumerator

<code>OS_STREAM_STATE_BOUND</code>	whether the stream is bound
<code>OS_STREAM_STATE_CONNECTED</code>	whether the stream is connected
<code>OS_STREAM_STATE_READABLE</code>	whether the stream is readable
<code>OS_STREAM_STATE_WRITABLE</code>	whether the stream is writable

Definition at line 55 of file osapi-select.h.

## 12.101 osal/src/os/inc/osapi-shell.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

#### Functions

- `int32 OS_ShellOutputToFile (const char *Cmd, osal_id_t filedes)`  
*Executes the command and sends output to a file.*

### 12.101.1 Detailed Description

Declarations and prototypes for shell abstraction

## 12.102 osal/src/os/inc/osapi-sockets.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

## Data Structures

- union **OS\_SockAddrData\_t**  
*Storage buffer for generic network address.*
- struct **OS\_SockAddr\_t**  
*Encapsulates a generic network address.*
- struct **OS\_socket\_prop\_t**  
*Encapsulates socket properties.*

## Macros

- #define **OS SOCKADDR\_MAX\_LEN** 28

## Enumerations

- enum **OS\_SocketDomain\_t** { **OS\_SocketDomain\_INVALID**, **OS\_SocketDomain\_INET**, **OS\_SocketDomain\_INET6**, **OS\_SocketDomain\_MAX** }  
*Socket domain.*
- enum **OS\_SocketType\_t** { **OS\_SocketType\_INVALID**, **OS\_SocketType\_DATAGRAM**, **OS\_SocketType\_STREAM**, **OS\_SocketType\_MAX** }  
*Socket type.*
- enum **OS\_SocketShutdownMode\_t** { **OS\_SocketShutdownMode\_NONE** = 0, **OS\_SocketShutdownMode\_SHUT\_RDWR** = 1, **OS\_SocketShutdownMode\_SHUT\_WRITE** = 2, **OS\_SocketShutdownMode\_SHUT\_READWRITE** = 3 }  
*Shutdown Mode.*

## Functions

- int32 **OS\_SockAddrInit** (**OS\_SockAddr\_t** \*Addr, **OS\_SocketDomain\_t** Domain)  
*Initialize a socket address structure to hold an address of the given family.*
- int32 **OS\_SockAddrToString** (char \*buffer, size\_t buflen, const **OS\_SockAddr\_t** \*Addr)  
*Get a string representation of a network host address.*
- int32 **OS\_SockAddrFromString** (**OS\_SockAddr\_t** \*Addr, const char \*string)  
*Set a network host address from a string representation.*
- int32 **OS\_SockAddrGetPort** (uint16 \*PortNum, const **OS\_SockAddr\_t** \*Addr)  
*Get the port number of a network address.*
- int32 **OS\_SockAddrSetPort** (**OS\_SockAddr\_t** \*Addr, uint16 PortNum)  
*Set the port number of a network address.*
- int32 **OS\_SocketOpen** (**osal\_id\_t** \*sock\_id, **OS\_SocketDomain\_t** Domain, **OS\_SocketType\_t** Type)  
*Opens a socket.*
- int32 **OS\_SocketBind** (**osal\_id\_t** sock\_id, const **OS\_SockAddr\_t** \*Addr)  
*Binds a socket to a given local address.*
- int32 **OS\_SocketConnect** (**osal\_id\_t** sock\_id, const **OS\_SockAddr\_t** \*Addr, int32 timeout)  
*Connects a socket to a given remote address.*
- int32 **OS\_SocketShutdown** (**osal\_id\_t** sock\_id, **OS\_SocketShutdownMode\_t** Mode)  
*Implement graceful shutdown of a stream socket.*

- `int32 OS_SocketAccept (osal_id_t sock_id, osal_id_t *connsock_id, OS_SockAddr_t *Addr, int32 timeout)`  
*Waits for and accept the next incoming connection on the given socket.*
- `int32 OS_SocketRecvFrom (osal_id_t sock_id, void *buffer, size_t buflen, OS_SockAddr_t *RemoteAddr, int32 timeout)`  
*Reads data from a message-oriented (datagram) socket.*
- `int32 OS_SocketSendTo (osal_id_t sock_id, const void *buffer, size_t buflen, const OS_SockAddr_t *RemoteAddr)`  
*Sends data to a message-oriented (datagram) socket.*
- `int32 OS_SocketGetIdByName (osal_id_t *sock_id, const char *sock_name)`  
*Gets an OSAL ID from a given name.*
- `int32 OS_SocketGetInfo (osal_id_t sock_id, OS_socket_prop_t *sock_prop)`  
*Gets information about an OSAL Socket ID.*

### 12.102.1 Detailed Description

Declarations and prototypes for sockets abstraction

### 12.102.2 Macro Definition Documentation

#### 12.102.2.1 OS SOCKADDR\_MAX\_LEN

```
#define OS_SOCKADDR_MAX_LEN 28
```

Definition at line 45 of file osapi-sockets.h.

### 12.102.3 Enumeration Type Documentation

#### 12.102.3.1 OS\_SocketDomain\_t

```
enum OS_SocketDomain_t
```

Socket domain.

Enumerator

<code>OS_SocketDomain_INVALID</code>	Invalid.
<code>OS_SocketDomain_INET</code>	IPv4 address family, most commonly used)
<code>OS_SocketDomain_INET6</code>	IPv6 address family, depends on OS/network stack support.
<code>OS_SocketDomain_MAX</code>	Maximum.

Definition at line 60 of file osapi-sockets.h.

### 12.102.3.2 OS\_SocketShutdownMode\_t

enum [OS\\_SocketShutdownMode\\_t](#)

Shutdown Mode.

Enumerator

<a href="#">OS_SocketShutdownMode_NONE</a>	Reserved value, no effect.
<a href="#">OS_SocketShutdownMode_SHUT_READ</a>	Disable future reading.
<a href="#">OS_SocketShutdownMode_SHUT_WRITE</a>	Disable future writing.
<a href="#">OS_SocketShutdownMode_SHUT_RDWR</a>	Disable future reading or writing.

Definition at line 79 of file osapi-sockets.h.

### 12.102.3.3 OS\_SocketType\_t

enum [OS\\_SocketType\\_t](#)

Socket type.

Enumerator

<a href="#">OS_SocketType_INVALID</a>	Invalid.
<a href="#">OS_SocketType_DATAGRAM</a>	A connectionless, message-oriented socket.
<a href="#">OS_SocketType_STREAM</a>	A stream-oriented socket with the concept of a connection.
<a href="#">OS_SocketType_MAX</a>	Maximum.

Definition at line 69 of file osapi-sockets.h.

## 12.103 osal/src/os/inc/osapi-task.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

### Data Structures

- struct [OS\\_task\\_prop\\_t](#)  
*OSAL task properties.*

## Macros

- `#define OS_MAX_TASK_PRIORITY 255`  
*Upper limit for OSAL task priorities.*
- `#define OS_FP_ENABLED 1`  
*Floating point enabled state for a task.*
- `#define OSAL_PRIORITY_C(X) ((osal_priority_t){X})`
- `#define OSAL_STACKPTR_C(X) ((osal_stackptr_t){X})`
- `#define OSAL_TASK_STACK_ALLOCATE OSAL_STACKPTR_C(NULL)`

## TypeDefs

- `typedef uint8_t osal_priority_t`  
*Type to be used for OSAL task priorities.*
- `typedef void * osal_stackptr_t`  
*Type to be used for OSAL stack pointer.*
- `typedef void osal_task`  
*For task entry point.*

## Functions

- `typedef osal_task ((*osal_task_entry))(void)`  
*For task entry point.*
- `int32 OS_TaskCreate (osal_id_t *task_id, const char *task_name, osal_task_entry function_pointer, osal_stackptr_t stack_pointer, size_t stack_size, osal_priority_t priority, uint32 flags)`  
*Creates a task and starts running it.*
- `int32 OS_TaskDelete (osal_id_t task_id)`  
*Deletes the specified Task.*
- `void OS_TaskExit (void)`  
*Exits the calling task.*
- `int32 OS_TaskInstallDeleteHandler (osal_task_entry function_pointer)`  
*Installs a handler for when the task is deleted.*
- `int32 OS_TaskDelay (uint32 millisecond)`  
*Delay a task for specified amount of milliseconds.*
- `int32 OS_TaskSetPriority (osal_id_t task_id, osal_priority_t new_priority)`  
*Sets the given task to a new priority.*
- `osal_id_t OS_TaskGetId (void)`  
*Obtain the task id of the calling task.*
- `int32 OS_TaskGetIdByName (osal_id_t *task_id, const char *task_name)`  
*Find an existing task ID by name.*
- `int32 OS_TaskGetInfo (osal_id_t task_id, OS_task_prop_t *task_prop)`  
*Fill a property object buffer with details regarding the resource.*
- `int32 OS_TaskFindIdBySystemData (osal_id_t *task_id, const void *sysdata, size_t sysdata_size)`  
*Reverse-lookup the OSAL task ID from an operating system ID.*

### 12.103.1 Detailed Description

Declarations and prototypes for task abstraction

### 12.103.2 Macro Definition Documentation

#### 12.103.2.1 OS\_FP\_ENABLED

```
#define OS_FP_ENABLED 1
```

Floating point enabled state for a task.

Definition at line 35 of file osapi-task.h.

#### 12.103.2.2 OS\_MAX\_TASK\_PRIORITY

```
#define OS_MAX_TASK_PRIORITY 255
```

Upper limit for OSAL task priorities.

Definition at line 32 of file osapi-task.h.

#### 12.103.2.3 OSAL\_PRIORITY\_C

```
#define OSAL_PRIORITY_C(  
    X ) ((osal_priority_t) {X})
```

Definition at line 46 of file osapi-task.h.

#### 12.103.2.4 OSAL\_STACKPTR\_C

```
#define OSAL_STACKPTR_C(  
    X ) ((osal_stackptr_t) {X})
```

Definition at line 53 of file osapi-task.h.

### 12.103.2.5 OSAL\_TASK\_STACK\_ALLOCATE

```
#define OSAL_TASK_STACK_ALLOCATE OSAL_STACKPTR_C(NULL)
```

Definition at line 54 of file osapi-task.h.

## 12.103.3 Typedef Documentation

### 12.103.3.1 osal\_priority\_t

```
typedef uint8_t osal_priority_t
```

Type to be used for OSAL task priorities.

OSAL priorities are in reverse order, and range from 0 (highest; will preempt all other tasks) to 255 (lowest; will not preempt any other task).

Definition at line 44 of file osapi-task.h.

### 12.103.3.2 osal\_stackptr\_t

```
typedef void* osal_stackptr_t
```

Type to be used for OSAL stack pointer.

Definition at line 51 of file osapi-task.h.

### 12.103.3.3 osal\_task

```
typedef void osal_task
```

For task entry point.

Definition at line 68 of file osapi-task.h.

## 12.103.4 Function Documentation

#### 12.103.4.1 osal\_task()

```
typedef osal_task (
    (*) (void) osal_task_entry )
```

For task entry point.

### 12.104 osal/src/os/inc/osapi-timebase.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

#### Data Structures

- struct OS\_timebase\_prop\_t

*Time base properties.*

#### Typedefs

- typedef uint32(\* OS\_TimerSync\_t) (osal\_id\_t timer\_id)

*Timer sync.*

#### Functions

- int32 OS\_TimeBaseCreate (osal\_id\_t \*timebase\_id, const char \*timebase\_name, OS\_TimerSync\_t external\_sync)  
*Create an abstract Time Base resource.*
- int32 OS\_TimeBaseSet (osal\_id\_t timebase\_id, uint32 start\_time, uint32 interval\_time)  
*Sets the tick period for simulated time base objects.*
- int32 OS\_TimeBaseDelete (osal\_id\_t timebase\_id)  
*Deletes a time base object.*
- int32 OS\_TimeBaseGetIdByName (osal\_id\_t \*timebase\_id, const char \*timebase\_name)  
*Find the ID of an existing time base resource.*
- int32 OS\_TimeBaseGetInfo (osal\_id\_t timebase\_id, OS\_timebase\_prop\_t \*timebase\_prop)  
*Obtain information about a timebase resource.*
- int32 OS\_TimeBaseGetFreeRun (osal\_id\_t timebase\_id, uint32 \*freerun\_val)  
*Read the value of the timebase free run counter.*

#### 12.104.1 Detailed Description

Declarations and prototypes for timebase abstraction

## 12.104.2 Typedef Documentation

### 12.104.2.1 OS\_TimerSync\_t

```
typedef uint32 (* OS_TimerSync_t) (osal_id_t timer_id)
```

Timer sync.

Definition at line 34 of file osapi-timebase.h.

## 12.105 osal/src/os/inc/osapi-timer.h File Reference

```
#include "osconfig.h"
#include "common_types.h"
```

### Data Structures

- struct [OS\\_timer\\_prop\\_t](#)

*Timer properties.*

### Typedefs

- [typedef void\(\\* OS\\_TimerCallback\\_t\) \(osal\\_id\\_t timer\\_id\)](#)

*Timer callback.*

### Functions

- [int32 OS\\_TimerCreate \(osal\\_id\\_t \\*timer\\_id, const char \\*timer\\_name, uint32 \\*clock\\_accuracy, OS\\_TimerCallback\\_t callback\\_ptr\)](#)  
*Create a timer object.*
- [int32 OS\\_TimerAdd \(osal\\_id\\_t \\*timer\\_id, const char \\*timer\\_name, osal\\_id\\_t timebase\\_id, OS\\_ArgCallback\\_t callback\\_ptr, void \\*callback\\_arg\)](#)  
*Add a timer object based on an existing TimeBase resource.*
- [int32 OS\\_TimerSet \(osal\\_id\\_t timer\\_id, uint32 start\\_time, uint32 interval\\_time\)](#)  
*Configures a periodic or one shot timer.*
- [int32 OS\\_TimerDelete \(osal\\_id\\_t timer\\_id\)](#)  
*Deletes a timer resource.*
- [int32 OS\\_TimerGetIdByName \(osal\\_id\\_t \\*timer\\_id, const char \\*timer\\_name\)](#)  
*Locate an existing timer resource by name.*
- [int32 OS\\_TimerGetInfo \(osal\\_id\\_t timer\\_id, OS\\_timer\\_prop\\_t \\*timer\\_prop\)](#)  
*Gets information about an existing timer.*

### 12.105.1 Detailed Description

Declarations and prototypes for timer abstraction (app callbacks)

### 12.105.2 Typedef Documentation

#### 12.105.2.1 OS\_TimerCallback\_t

```
typedef void(* OS_TimerCallback_t) (osal_id_t timer_id)
```

Timer callback.

Definition at line 34 of file osapi-timer.h.

## 12.106 osal/src/os/inc/osapi-version.h File Reference

```
#include "common_types.h"
```

### Macros

- #define OS\_BUILD\_NUMBER 103
  - Major version number.
- #define OS\_BUILD\_BASELINE "v6.0.0-rc4"
- #define OS\_MAJOR\_VERSION 5
  - Major version number.
- #define OS\_MINOR\_VERSION 0
  - Minor version number.
- #define OS\_REVISION 99
  - Revision version number. Value of 99 indicates a development version.
- #define OS\_MISSION\_REV 0xFF
  - Mission revision.
- #define OS\_STR\_HELPER(x) #x
  - Helper function to concatenate strings from integer.
- #define OS\_STR(x) OS\_STR\_HELPER(x)
  - Helper function to concatenate strings from integer.
- #define OS\_VERSION OS\_BUILD\_BASELINE "+dev" OS\_STR(OS\_BUILD\_NUMBER)
  - Development Build Version Number.
- #define OS\_VERSION\_CODENAME "Draco"
  - Version code name All modular components which are tested/validated together should share the same code name.
- #define OS\_VERSION\_STRING
  - Development Build Version String.
- #define OSAL\_API\_VERSION ((OS\_MAJOR\_VERSION \* 10000) + (OS\_MINOR\_VERSION \* 100) + OS\_REVISION)
  - Combines the revision components into a single value.

## Functions

- `const char * OS_GetVersionString (void)`
- `const char * OS_GetVersionCodeName (void)`
- `void OS_GetVersionNumber (uint8 VersionNumbers[4])`  
*Obtain the OSAL numeric version number.*
- `uint32 OS_GetBuildNumber (void)`  
*Obtain the OSAL library numeric build number.*

### 12.106.1 Detailed Description

Provide version identifiers for Operating System Abstraction Layer

#### Note

OSAL follows the same version semantics as cFS, which in turn is based on the Semantic Versioning 2.0 Specification. For more information, see the documentation provided with cFE.

### 12.106.2 Macro Definition Documentation

#### 12.106.2.1 OS\_BUILD\_BASELINE

```
#define OS_BUILD_BASELINE "v6.0.0-rc4"
```

Definition at line 38 of file osapi-version.h.

#### 12.106.2.2 OS\_BUILD\_NUMBER

```
#define OS_BUILD_NUMBER 103
```

Definition at line 37 of file osapi-version.h.

#### 12.106.2.3 OS\_MAJOR\_VERSION

```
#define OS_MAJOR_VERSION 5
```

Major version number.

Definition at line 43 of file osapi-version.h.

#### 12.106.2.4 OS\_MINOR\_VERSION

```
#define OS_MINOR_VERSION 0
```

Minor version number.

Definition at line 44 of file osapi-version.h.

#### 12.106.2.5 OS\_MISSION\_REV

```
#define OS_MISSION_REV 0xFF
```

Mission revision.

Reserved for mission use to denote patches/customizations as needed. Values 1-254 are reserved for mission use to denote patches/customizations as needed. NOTE: Reserving 0 and 0xFF for cFS open-source development use (pending resolution of nasa/cFS#440)

Definition at line 54 of file osapi-version.h.

#### 12.106.2.6 OS\_REVISION

```
#define OS_REVISION 99
```

Revision version number. Value of 99 indicates a development version.

Definition at line 45 of file osapi-version.h.

#### 12.106.2.7 OS\_STR

```
#define OS_STR( x ) OS_STR_HELPER(x)
```

Helper function to concatenate strings from integer.

Definition at line 60 of file osapi-version.h.

#### 12.106.2.8 OS\_STR\_HELPER

```
#define OS_STR_HELPER( x ) #x
```

Helper function to concatenate strings from integer.

Definition at line 59 of file osapi-version.h.

**12.106.2.9 OS\_VERSION**

```
#define OS_VERSION OS_BUILD_BASELINE "+dev" OS_STR(OS_BUILD_NUMBER)
```

Development Build Version Number.

Baseline git tag + Number of commits since baseline.

Definition at line 65 of file osapi-version.h.

**12.106.2.10 OS\_VERSION\_CODENAME**

```
#define OS_VERSION_CODENAME "Draco"
```

Version code name All modular components which are tested/validated together should share the same code name.

Definition at line 70 of file osapi-version.h.

**12.106.2.11 OS\_VERSION\_STRING**

```
#define OS_VERSION_STRING
```

**Value:**

```
" OSAL Development Build\n"
" " OS_VERSION " (Codename: " OS_VERSION_CODENAME ") \n" /* Codename for \
current development */ \
" Latest Official Version: osal v5.0.0" \
/* For full support please use official release \
version */
```

Development Build Version String.

Reports the current development build's baseline, number, and name. Also includes a note about the latest official version.

Definition at line 76 of file osapi-version.h.

**12.106.2.12 OSAL\_API\_VERSION**

```
#define OSAL_API_VERSION ((OS_MAJOR_VERSION * 10000) + (OS_MINOR_VERSION * 100) + OS_REVISION)
```

Combines the revision components into a single value.

Applications can check against this number

e.g. "#if OSAL\_API\_VERSION >= 40100" would check if some feature added in OSAL 4.1 is present.

Definition at line 86 of file osapi-version.h.

### 12.106.3 Function Documentation

#### 12.106.3.1 OS\_GetBuildNumber()

```
uint32 OS_GetBuildNumber (
    void )
```

Obtain the OSAL library numeric build number.

The build number is a monotonically increasing number that (coarsely) reflects the number of commits/changes that have been merged since the epoch release. During development cycles this number should increase after each subsequent merge/modification.

Like other version information, this is a fixed number assigned at compile time.

##### Returns

The OSAL library build number

#### 12.106.3.2 OS\_GetVersionCodeName()

```
const char* OS_GetVersionCodeName (
    void )
```

Gets the OSAL version code name

All NASA CFE/CFS components (including CFE framework, OSAL and PSP) that work together will share the same code name.

##### Returns

OSAL code name. This is a fixed value string and is never NULL.

#### 12.106.3.3 OS\_GetVersionNumber()

```
void OS_GetVersionNumber (
    uint8 VersionNumbers[4] )
```

Obtain the OSAL numeric version number.

This retrieves the numeric OSAL version identifier as an array of 4 uint8 values.

The array of numeric values is in order of precedence: [0] = Major Number [1] = Minor Number [2] = Revision Number [3] = Mission Revision

The "Mission Revision" (last output) also indicates whether this is an official release, a patched release, or a development version. 0 indicates an official release 1-254 local patch level (reserved for mission use) 255 indicates a development build

**Parameters**

<code>out</code>	<code>VersionNumbers</code>	A fixed-size array to be filled with the version numbers
------------------	-----------------------------	--

**12.106.3.4 OS\_GetVersionString()**

```
const char* OS_GetVersionString (
    void )
```

Gets the OSAL version/baseline ID as a string

This returns the content of the [OS\\_VERSION](#) macro defined above, and is specifically just the baseline and development build ID (if applicable), without any extra info.

**Returns**

Basic version identifier. This is a fixed value string and is never NULL.

**12.107 osal/src/os/inc/osapi.h File Reference**

```
#include <stdio.h>
#include <stdlib.h>
#include <stdarg.h>
#include "common_types.h"
#include "osapi-version.h"
#include "osconfig.h"
#include "osapi-binsem.h"
#include "osapi-clock.h"
#include "osapi-common.h"
#include "osapi-constants.h"
#include "osapi-countsem.h"
#include "osapi-dir.h"
#include "osapi-error.h"
#include "osapi-file.h"
#include "osapi-fs.h"
#include "osapi-heap.h"
#include "osapi-macros.h"
#include "osapi-idmap.h"
#include "osapi-module.h"
#include "osapi-mutex.h"
#include "osapi-network.h"
#include "osapi-printf.h"
#include "osapi-queue.h"
#include "osapi-select.h"
#include "osapi-shell.h"
#include "osapi-sockets.h"
#include "osapi-task.h"
#include "osapi-timebase.h"
#include "osapi-timer.h"
#include "osapi-bsp.h"
```

### 12.107.1 Detailed Description

Purpose: Contains functions prototype definitions and variables declarations for the OS Abstraction Layer, Core OS module

## 12.108 psp/fsw/inc/cfe\_psp.h File Reference

```
#include "common_types.h"
#include "osapi.h"
#include "cfe_psp_error.h"
```

### Macros

- #define CFE\_PSP\_PANIC\_STARTUP 1
- #define CFE\_PSP\_PANIC\_VOLATILE\_DISK 2
- #define CFE\_PSP\_PANIC\_MEMORY\_ALLOC 3
- #define CFE\_PSP\_PANIC\_NONVOL\_DISK 4
- #define CFE\_PSP\_PANIC\_STARTUP\_SEM 5
- #define CFE\_PSP\_PANIC\_CORE\_APP 6
- #define CFE\_PSP\_PANIC\_GENERAL\_FAILURE 7
- #define BUFF\_SIZE 256
- #define SIZE\_BYTE 1
- #define SIZE\_HALF 2
- #define SIZE\_WORD 3
- #define CFE\_PSP\_MEM\_RAM 1
- #define CFE\_PSP\_MEM\_EEPROM 2
- #define CFE\_PSP\_MEM\_ANY 3
- #define CFE\_PSP\_MEM\_INVALID 4
- #define CFE\_PSP\_MEM\_ATTR\_WRITE 0x01
- #define CFE\_PSP\_MEM\_ATTR\_READ 0x02
- #define CFE\_PSP\_MEM\_ATTR\_READWRITE 0x03
- #define CFE\_PSP\_MEM\_SIZE\_BYTE 0x01
- #define CFE\_PSP\_MEM\_SIZE\_WORD 0x02
- #define CFE\_PSP\_MEM\_SIZE\_DWORD 0x04
- #define CFE\_PSP\_SOFT\_TIMEBASE\_NAME "cFS-Master"

*The name of the software/RTOS timebase for general system timers.*

### Reset Types

- #define CFE\_PSP\_RST\_TYPE\_PROCESSOR 1
- #define CFE\_PSP\_RST\_TYPE\_POWERON 2
- #define CFE\_PSP\_RST\_TYPE\_MAX 3

### Reset Sub-Types

- #define CFE\_PSP\_RST\_SUBTYPE\_POWER\_CYCLE 1

*Reset caused by power having been removed and restored.*

- #define `CFE_PSP_RST_SUBTYPE_PUSH_BUTTON` 2  
*Reset caused by reset button on the board.*
- #define `CFE_PSP_RST_SUBTYPE_HW_SPECIAL_COMMAND` 3  
*Reset was caused by a reset line having been stimulated by a hardware special command.*
- #define `CFE_PSP_RST_SUBTYPE_HW_WATCHDOG` 4  
*Reset was caused by a watchdog timer expiring.*
- #define `CFE_PSP_RST_SUBTYPE_RESET_COMMAND` 5  
*Reset was caused by cFE ES processing a `Reset Command`.*
- #define `CFE_PSP_RST_SUBTYPE_EXCEPTION` 6  
*Reset was caused by a Processor Exception.*
- #define `CFE_PSP_RST_SUBTYPE_UNDEFINED_RESET` 7  
*Reset was caused in an unknown manner.*
- #define `CFE_PSP_RST_SUBTYPE_HWDEBUG_RESET` 8  
*Reset was caused by a JTAG or BDM connection.*
- #define `CFE_PSP_RST_SUBTYPE_BANKSWITCH_RESET` 9  
*Reset reverted to a cFE POWERON due to a boot bank switch.*
- #define `CFE_PSP_RST_SUBTYPE_MAX` 10  
*Placeholder to indicate 1+ the maximum value that the PSP will ever use.*

## Functions

- void `CFE_PSP_Main` (void)
- void `CFE_PSP_GetTime` (`OS_time_t` \*LocalTime)  
*Sample/Read a monotonic platform clock with normalization.*
- void `CFE_PSP_Restart` (`uint32` resetType)
- `uint32` `CFE_PSP_GetRestartType` (`uint32` \*restartSubType)
- void `CFE_PSP_FlushCaches` (`uint32` type, void \*address, `uint32` size)
- `uint32` `CFE_PSP_GetProcessorId` (void)
- `uint32` `CFE_PSP_GetSpacecraftId` (void)
- const char \* `CFE_PSP_GetProcessorName` (void)
- `uint32` `CFE_PSP_Get_Timer_Tick` (void)
- `uint32` `CFE_PSP_GetTimerTicksPerSecond` (void)
- `uint32` `CFE_PSP_GetTimerLow32Rollover` (void)
- void `CFE_PSP_Get_Timebase` (`uint32` \*Tbu, `uint32` \*Tbl)  
*Sample/Read a monotonic platform clock without normalization.*
- `uint32` `CFE_PSP_Get_Dec` (void)
- `int32` `CFE_PSP_GetCDSSize` (`uint32` \*SizeOfCDS)
- `int32` `CFE_PSP_WriteToCDS` (const void \*PtrToDataToWrite, `uint32` CDSOffset, `uint32` NumBytes)
- `int32` `CFE_PSP_ReadFromCDS` (void \*PtrToDataToRead, `uint32` CDSOffset, `uint32` NumBytes)
- `int32` `CFE_PSP_GetResetArea` (`cpuaddr` \*PtrToResetArea, `uint32` \*SizeOfResetArea)
- `int32` `CFE_PSP.GetUserReservedArea` (`cpuaddr` \*PtrToUserArea, `uint32` \*SizeOfUserArea)
- `int32` `CFE_PSP_GetVolatileDiskMem` (`cpuaddr` \*PtrToVolDisk, `uint32` \*SizeOfVolDisk)
- `int32` `CFE_PSP_GetKernelTextSegmentInfo` (`cpuaddr` \*PtrToKernelSegment, `uint32` \*SizeOfKernelSegment)
- `int32` `CFE_PSP_GetCFETextSegmentInfo` (`cpuaddr` \*PtrToCFESegment, `uint32` \*SizeOfCFESegment)
- void `CFE_PSP_WatchdogInit` (void)
- void `CFE_PSP_WatchdogEnable` (void)
- void `CFE_PSP_WatchdogDisable` (void)
- void `CFE_PSP_WatchdogService` (void)
- `uint32` `CFE_PSP_WatchdogGet` (void)
- void `CFE_PSP_WatchdogSet` (`uint32` WatchdogValue)
- void `CFE_PSP_Panic` (`int32` ErrorCode)

- int32 CFE\_PSP\_InitSSR (uint32 bus, uint32 device, char \*DeviceName)
- int32 CFE\_PSP\_Decompress (char \*srcFileName, char \*dstFileName)
- void CFE\_PSP\_AttachExceptions (void)
- void CFE\_PSP\_SetDefaultExceptionEnvironment (void)
- uint32 CFE\_PSP\_Exception\_GetCount (void)
- int32 CFE\_PSP\_Exception\_GetSummary (uint32 \*ContextLogId, osal\_id\_t \*TaskId, char \*ReasonBuf, uint32 ReasonSize)
- int32 CFE\_PSP\_Exception\_CopyContext (uint32 ContextLogId, void \*ContextBuf, uint32 ContextSize)
- int32 CFE\_PSP\_PortRead8 (cpuaddr PortAddress, uint8 \*ByteValue)
- int32 CFE\_PSP\_PortWrite8 (cpuaddr PortAddress, uint8 ByteValue)
- int32 CFE\_PSP\_PortRead16 (cpuaddr PortAddress, uint16 \*uint16Value)
- int32 CFE\_PSP\_PortWrite16 (cpuaddr PortAddress, uint16 uint16Value)
- int32 CFE\_PSP\_PortRead32 (cpuaddr PortAddress, uint32 \*uint32Value)
- int32 CFE\_PSP\_PortWrite32 (cpuaddr PortAddress, uint32 uint32Value)
- int32 CFE\_PSP\_MemRead8 (cpuaddr MemoryAddress, uint8 \*ByteValue)
- int32 CFE\_PSP\_MemWrite8 (cpuaddr MemoryAddress, uint8 ByteValue)
- int32 CFE\_PSP\_MemRead16 (cpuaddr MemoryAddress, uint16 \*uint16Value)
- int32 CFE\_PSP\_MemWrite16 (cpuaddr MemoryAddress, uint16 uint16Value)
- int32 CFE\_PSP\_MemRead32 (cpuaddr MemoryAddress, uint32 \*uint32Value)
- int32 CFE\_PSP\_MemWrite32 (cpuaddr MemoryAddress, uint32 uint32Value)
- int32 CFE\_PSP\_MemCpy (void \*dest, const void \*src, uint32 n)
- int32 CFE\_PSP\_MemSet (void \*dest, uint8 value, uint32 n)
- int32 CFE\_PSP\_MemValidateRange (cpuaddr Address, size\_t Size, uint32 MemoryType)
- uint32 CFE\_PSP\_MemRanges (void)
- int32 CFE\_PSP\_MemRangeSet (uint32 RangeNum, uint32 MemoryType, cpuaddr StartAddr, size\_t Size, size\_t WordSize, uint32 Attributes)
- int32 CFE\_PSP\_MemRangeGet (uint32 RangeNum, uint32 \*MemoryType, cpuaddr \*StartAddr, size\_t \*Size, size\_t \*WordSize, uint32 \*Attributes)
- int32 CFE\_PSP\_EepromWrite8 (cpuaddr MemoryAddress, uint8 ByteValue)
- int32 CFE\_PSP\_EepromWrite16 (cpuaddr MemoryAddress, uint16 uint16Value)
- int32 CFE\_PSP\_EepromWrite32 (cpuaddr MemoryAddress, uint32 uint32Value)
- int32 CFE\_PSP\_EepromWriteEnable (uint32 Bank)
- int32 CFE\_PSP\_EepromWriteDisable (uint32 Bank)
- int32 CFE\_PSP\_EepromPowerUp (uint32 Bank)
- int32 CFE\_PSP\_EepromPowerDown (uint32 Bank)
- const char \* CFE\_PSP\_GetVersionString (void)
  - Obtain the PSP version/baseline identifier string.*
- const char \* CFE\_PSP\_GetVersionCodeName (void)
  - Obtain the version code name.*
- void CFE\_PSP\_GetVersionNumber (uint8 VersionNumbers[4])
  - Obtain the PSP numeric version numbers as uint8 values.*
- uint32 CFE\_PSP\_GetBuildNumber (void)
  - Obtain the PSP library numeric build number.*

#### 12.108.1 Macro Definition Documentation

**12.108.1.1 BUFF\_SIZE**

```
#define BUFF_SIZE 256
```

Definition at line 62 of file cfe\_psp.h.

**12.108.1.2 CFE\_PSP\_MEM\_ANY**

```
#define CFE_PSP_MEM_ANY 3
```

Definition at line 72 of file cfe\_psp.h.

**12.108.1.3 CFE\_PSP\_MEM\_ATTR\_READ**

```
#define CFE_PSP_MEM_ATTR_READ 0x02
```

Definition at line 79 of file cfe\_psp.h.

**12.108.1.4 CFE\_PSP\_MEM\_ATTR\_READWRITE**

```
#define CFE_PSP_MEM_ATTR_READWRITE 0x03
```

Definition at line 80 of file cfe\_psp.h.

**12.108.1.5 CFE\_PSP\_MEM\_ATTR\_WRITE**

```
#define CFE_PSP_MEM_ATTR_WRITE 0x01
```

Definition at line 78 of file cfe\_psp.h.

**12.108.1.6 CFE\_PSP\_MEM\_EEPROM**

```
#define CFE_PSP_MEM_EEPROM 2
```

Definition at line 71 of file cfe\_psp.h.

**12.108.1.7 CFE\_PSP\_MEM\_INVALID**

```
#define CFE_PSP_MEM_INVALID 4
```

Definition at line 73 of file cfe\_psp.h.

**12.108.1.8 CFE\_PSP\_MEM\_RAM**

```
#define CFE_PSP_MEM_RAM 1
```

Definition at line 70 of file cfe\_psp.h.

**12.108.1.9 CFE\_PSP\_MEM\_SIZE\_BYTE**

```
#define CFE_PSP_MEM_SIZE_BYTE 0x01
```

Definition at line 85 of file cfe\_psp.h.

**12.108.1.10 CFE\_PSP\_MEM\_SIZE\_DWORD**

```
#define CFE_PSP_MEM_SIZE_DWORD 0x04
```

Definition at line 87 of file cfe\_psp.h.

**12.108.1.11 CFE\_PSP\_MEM\_SIZE\_WORD**

```
#define CFE_PSP_MEM_SIZE_WORD 0x02
```

Definition at line 86 of file cfe\_psp.h.

**12.108.1.12 CFE\_PSP\_PANIC\_CORE\_APP**

```
#define CFE_PSP_PANIC_CORE_APP 6
```

Definition at line 56 of file cfe\_psp.h.

**12.108.1.13 CFE\_PSP\_PANIC\_GENERAL\_FAILURE**

```
#define CFE_PSP_PANIC_GENERAL_FAILURE 7
```

Definition at line 57 of file cfe\_psp.h.

**12.108.1.14 CFE\_PSP\_PANIC\_MEMORY\_ALLOC**

```
#define CFE_PSP_PANIC_MEMORY_ALLOC 3
```

Definition at line 53 of file cfe\_psp.h.

**12.108.1.15 CFE\_PSP\_PANIC\_NONVOL\_DISK**

```
#define CFE_PSP_PANIC_NONVOL_DISK 4
```

Definition at line 54 of file cfe\_psp.h.

**12.108.1.16 CFE\_PSP\_PANIC\_STARTUP**

```
#define CFE_PSP_PANIC_STARTUP 1
```

Definition at line 51 of file cfe\_psp.h.

**12.108.1.17 CFE\_PSP\_PANIC\_STARTUP\_SEM**

```
#define CFE_PSP_PANIC_STARTUP_SEM 5
```

Definition at line 55 of file cfe\_psp.h.

**12.108.1.18 CFE\_PSP\_PANIC\_VOLATILE\_DISK**

```
#define CFE_PSP_PANIC_VOLATILE_DISK 2
```

Definition at line 52 of file cfe\_psp.h.

**12.108.1.19 CFE\_PSP\_RST\_SUBTYPE\_BANKSWITCH\_RESET**

```
#define CFE_PSP_RST_SUBTYPE_BANKSWITCH_RESET 9
```

Reset reverted to a cFE POWERON due to a boot bank switch.

Definition at line 122 of file cfe\_psp.h.

**12.108.1.20 CFE\_PSP\_RST\_SUBTYPE\_EXCEPTION**

```
#define CFE_PSP_RST_SUBTYPE_EXCEPTION 6
```

Reset was caused by a Processor Exception.

Definition at line 116 of file cfe\_psp.h.

**12.108.1.21 CFE\_PSP\_RST\_SUBTYPE\_HW\_SPECIAL\_COMMAND**

```
#define CFE_PSP_RST_SUBTYPE_HW_SPECIAL_COMMAND 3
```

Reset was caused by a reset line having been stimulated by a hardware special command.

Definition at line 110 of file cfe\_psp.h.

**12.108.1.22 CFE\_PSP\_RST\_SUBTYPE\_HW\_WATCHDOG**

```
#define CFE_PSP_RST_SUBTYPE_HW_WATCHDOG 4
```

Reset was caused by a watchdog timer expiring.

Definition at line 112 of file cfe\_psp.h.

**12.108.1.23 CFE\_PSP\_RST\_SUBTYPE\_HWDEBUG\_RESET**

```
#define CFE_PSP_RST_SUBTYPE_HWDEBUG_RESET 8
```

Reset was caused by a JTAG or BDM connection.

Definition at line 120 of file cfe\_psp.h.

**12.108.1.24 CFE\_PSP\_RST\_SUBTYPE\_MAX**

```
#define CFE_PSP_RST_SUBTYPE_MAX 10
```

Placeholder to indicate 1+ the maximum value that the PSP will ever use.

Definition at line 124 of file cfe\_psp.h.

**12.108.1.25 CFE\_PSP\_RST\_SUBTYPE\_POWER\_CYCLE**

```
#define CFE_PSP_RST_SUBTYPE_POWER_CYCLE 1
```

Reset caused by power having been removed and restored.

Definition at line 106 of file cfe\_psp.h.

**12.108.1.26 CFE\_PSP\_RST\_SUBTYPE\_PUSH\_BUTTON**

```
#define CFE_PSP_RST_SUBTYPE_PUSH_BUTTON 2
```

Reset caused by reset button on the board.

Definition at line 108 of file cfe\_psp.h.

**12.108.1.27 CFE\_PSP\_RST\_SUBTYPE\_RESET\_COMMAND**

```
#define CFE_PSP_RST_SUBTYPE_RESET_COMMAND 5
```

Reset was caused by cFE ES processing a [Reset Command](#).

Definition at line 114 of file cfe\_psp.h.

**12.108.1.28 CFE\_PSP\_RST\_SUBTYPE\_UNDEFINED\_RESET**

```
#define CFE_PSP_RST_SUBTYPE_UNDEFINED_RESET 7
```

Reset was caused in an unknown manner.

Definition at line 118 of file cfe\_psp.h.

**12.108.1.29 CFE\_PSP\_RST\_TYPE\_MAX**

```
#define CFE_PSP_RST_TYPE_MAX 3
```

Placeholder to indicate 1+ the maximum value that the PSP will ever use.

Definition at line 96 of file cfe\_psp.h.

**12.108.1.30 CFE\_PSP\_RST\_TYPE\_POWERON**

```
#define CFE_PSP_RST_TYPE_POWERON 2
```

All memory has been cleared

Definition at line 95 of file cfe\_psp.h.

**12.108.1.31 CFE\_PSP\_RST\_TYPE\_PROCESSOR**

```
#define CFE_PSP_RST_TYPE_PROCESSOR 1
```

Volatile disk, CDS and User Reserved memory may be valid

Definition at line 94 of file cfe\_psp.h.

**12.108.1.32 CFE\_PSP\_SOFT\_TIMEBASE\_NAME**

```
#define CFE_PSP_SOFT_TIMEBASE_NAME "cFS-Master"
```

The name of the software/RTOS timebase for general system timers.

This name may be referred to by CFE TIME and/or SCH when setting up its own timers.

Definition at line 132 of file cfe\_psp.h.

**12.108.1.33 SIZE\_BYTE**

```
#define SIZE_BYTE 1
```

Definition at line 63 of file cfe\_psp.h.

**12.108.1.34 SIZE\_HALF**

```
#define SIZE_HALF 2
```

Definition at line 64 of file cfe\_psp.h.

**12.108.1.35 SIZE\_WORD**

```
#define SIZE_WORD 3
```

Definition at line 65 of file cfe\_psp.h.

**12.108.2 Function Documentation****12.108.2.1 CFE\_PSP\_AttachExceptions()**

```
void CFE_PSP_AttachExceptions (
    void )
```

**12.108.2.2 CFE\_PSP\_Decompress()**

```
int32 CFE_PSP_Decompress (
    char * srcFileName,
    char * dstFileName )
```

**12.108.2.3 CFE\_PSP\_EepromPowerDown()**

```
int32 CFE_PSP_EepromPowerDown (
    uint32 Bank )
```

**12.108.2.4 CFE\_PSP\_EepromPowerUp()**

```
int32 CFE_PSP_EepromPowerUp (
    uint32 Bank )
```

**12.108.2.5 CFE\_PSP\_EepromWrite16()**

```
int32 CFE_PSP_EepromWrite16 (
    cpuaddr MemoryAddress,
    uint16 uint16Value )
```

**12.108.2.6 CFE\_PSP\_EepromWrite32()**

```
int32 CFE_PSP_EepromWrite32 (
    cpuaddr MemoryAddress,
    uint32 uint32Value )
```

**12.108.2.7 CFE\_PSP\_EepromWrite8()**

```
int32 CFE_PSP_EepromWrite8 (
    cpuaddr MemoryAddress,
    uint8 ByteValue )
```

**12.108.2.8 CFE\_PSP\_EepromWriteDisable()**

```
int32 CFE_PSP_EepromWriteDisable (
    uint32 Bank )
```

**12.108.2.9 CFE\_PSP\_EepromWriteEnable()**

```
int32 CFE_PSP_EepromWriteEnable (
    uint32 Bank )
```

**12.108.2.10 CFE\_PSP\_Exception\_CopyContext()**

```
int32 CFE_PSP_Exception_CopyContext (
    uint32 ContextLogId,
    void * ContextBuf,
    uint32 ContextSize )
```

### 12.108.2.11 CFE\_PSP\_Exception\_GetCount()

```
uint32 CFE_PSP_Exception_GetCount (
    void )
```

### 12.108.2.12 CFE\_PSP\_Exception\_GetSummary()

```
int32 CFE_PSP_Exception_GetSummary (
    uint32 * ContextLogId,
    osal_id_t * TaskId,
    char * ReasonBuf,
    uint32 ReasonSize )
```

### 12.108.2.13 CFE\_PSP\_FlushCaches()

```
void CFE_PSP_FlushCaches (
    uint32 type,
    void * address,
    uint32 size )
```

### 12.108.2.14 CFE\_PSP\_Get\_Dec()

```
uint32 CFE_PSP_Get_Dec (
    void )
```

### 12.108.2.15 CFE\_PSP\_Get\_Timebase()

```
void CFE_PSP_Get_Timebase (
    uint32 * Tbu,
    uint32 * Tbl )
```

Sample/Read a monotonic platform clock without normalization.

This is defined as a free-running, monotonically-increasing tick counter. The epoch is not defined, but typically is the system boot time, and the value increases indefinitely as the system runs. The tick period/rate is also not defined.

Rollover events - where the range of representable values is exceeded - are theoretically possible, but would take many years of continuous uptime to occur (typically hundreds of years, if not thousands). System designers should ensure that the actual tick rate and resulting timebase range is sufficiently large to ensure that rollover is not a concern.

#### Note

This is a "raw" value from the underlying platform with minimal/no conversions or normalization applied. Neither the epoch nor the resolution of this tick counter is specified, and it may vary from platform to platform. Use the [CFE\\_PSP\\_GetTime\(\)](#) function to sample the timebase and also convert the units into a normalized/more consistent form.

#### See also

[CFE\\_PSP\\_GetTime\(\)](#)

**Parameters**

out	<i>Tbu</i>	Buffer to hold the upper 32 bits of a 64-bit tick counter
out	<i>Tbl</i>	Buffer to hold the lower 32 bits of a 64-bit tick counter

**12.108.2.16 CFE\_PSP\_Get\_Timer\_Tick()**

```
uint32 CFE_PSP_Get_Timer_Tick (
    void )
```

**12.108.2.17 CFE\_PSP\_GetBuildNumber()**

```
uint32 CFE_PSP_GetBuildNumber (
    void )
```

Obtain the PSP library numeric build number.

The build number is a monotonically increasing number that (coarsely) reflects the number of commits/changes that have been merged since the epoch release. During development cycles this number should increase after each subsequent merge/modification.

Like other version information, this is a fixed number assigned at compile time.

**Returns**

The OSAL library build number

**12.108.2.18 CFE\_PSP\_GetCDSSize()**

```
int32 CFE_PSP_GetCDSSize (
    uint32 * SizeOfCDS )
```

**12.108.2.19 CFE\_PSP\_GetCFETextSegmentInfo()**

```
int32 CFE_PSP_GetCFETextSegmentInfo (
    cpuaddr * PtrToCFEsegment,
    uint32 * SizeOfCFEsegment )
```

**12.108.2.20 CFE\_PSP\_GetKernelTextSegmentInfo()**

```
int32 CFE_PSP_GetKernelTextSegmentInfo (
    cpuaddr * PtrToKernelSegment,
    uint32 * SizeOfKernelSegment )
```

**12.108.2.21 CFE\_PSP\_GetProcessorId()**

```
uint32 CFE_PSP_GetProcessorId (
    void )
```

**12.108.2.22 CFE\_PSP\_GetProcessorName()**

```
const char* CFE_PSP_GetProcessorName (
    void )
```

**12.108.2.23 CFE\_PSP\_GetResetArea()**

```
int32 CFE_PSP_GetResetArea (
    cpuaddr * PtrToResetArea,
    uint32 * SizeOfResetArea )
```

**12.108.2.24 CFE\_PSP\_GetRestartType()**

```
uint32 CFE_PSP_GetRestartType (
    uint32 * restartSubType )
```

**12.108.2.25 CFE\_PSP\_GetSpacecraftId()**

```
uint32 CFE_PSP_GetSpacecraftId (
    void )
```

**12.108.2.26 CFE\_PSP\_GetTime()**

```
void CFE_PSP_GetTime (
    OS_time_t * LocalTime )
```

Sample/Read a monotonic platform clock with normalization.

Outputs an [OS\\_time\\_t](#) value indicating the time elapsed since an epoch. The epoch is not defined, but typically represents the system boot time. The value increases continuously over time and cannot be reset by software.

This is similar to the [CFE\\_PSP\\_Get\\_Timebase\(\)](#), but additionally it normalizes the output value to an [OS\\_time\\_t](#), thereby providing consistent units to the calling application. Any OSAL-provided routine accepts [OS\\_time\\_t](#) inputs may be used to convert this value into other standardized time units.

**Note**

This should refer to the same time domain as [CFE\\_PSP\\_Get\\_Timebase\(\)](#), the primary difference being the format and units of the output value.

**See also**

[CFE\\_PSP\\_Get\\_Timebase\(\)](#)

**Parameters**

<code>out</code>	<code>LocalTime</code>	Value of PSP tick counter as <a href="#">OS_time_t</a>
------------------	------------------------	---

**12.108.2.27 CFE\_PSP\_GetTimerLow32Rollover()**

```
uint32 CFE_PSP_GetTimerLow32Rollover (
    void )
```

**12.108.2.28 CFE\_PSP\_GetTimerTicksPerSecond()**

```
uint32 CFE_PSP_GetTimerTicksPerSecond (
    void )
```

**12.108.2.29 CFE\_PSP.GetUserReservedArea()**

```
int32 CFE_PSP.GetUserReservedArea (
    cpuaddr * PtrToUserArea,
    uint32 * SizeOfUserArea )
```

### 12.108.2.30 CFE\_PSP\_GetVersionCodeName()

```
const char* CFE_PSP_GetVersionCodeName (
    void )
```

Obtain the version code name.

This retrieves the PSP code name. This is a compatibility indicator for the overall NASA CFS ecosystem. All modular components which are intended to interoperate should report the same code name.

#### Returns

Code name. This is a fixed string and cannot be NULL.

### 12.108.2.31 CFE\_PSP\_GetVersionNumber()

```
void CFE_PSP_GetVersionNumber (
    uint8 VersionNumbers[4] )
```

Obtain the PSP numeric version numbers as uint8 values.

This retrieves the numeric PSP version identifier as an array of 4 uint8 values.

The array of numeric values is in order of precedence: [0] = Major Number [1] = Minor Number [2] = Revision Number [3] = Mission Revision

The "Mission Revision" (last output) also indicates whether this is an official release, a patched release, or a development version. 0 indicates an official release 1-254 local patch level (reserved for mission use) 255 indicates a development build

#### Parameters

out	VersionNumbers	A fixed-size array to be filled with the version numbers
-----	----------------	--

### 12.108.2.32 CFE\_PSP\_GetVersionString()

```
const char* CFE_PSP_GetVersionString (
    void )
```

Obtain the PSP version/baseline identifier string.

This retrieves the PSP version identifier string without extra info

#### Returns

Version string. This is a fixed string and cannot be NULL.

**12.108.2.33 CFE\_PSP\_GetVolatileDiskMem()**

```
int32 CFE_PSP_GetVolatileDiskMem (
    cpuaddr * PtrToVolDisk,
    uint32 * SizeOfVolDisk )
```

**12.108.2.34 CFE\_PSP\_InitSSR()**

```
int32 CFE_PSP_InitSSR (
    uint32 bus,
    uint32 device,
    char * DeviceName )
```

**12.108.2.35 CFE\_PSP\_Main()**

```
void CFE_PSP_Main (
    void )
```

**12.108.2.36 CFE\_PSP\_MemCpy()**

```
int32 CFE_PSP_MemCpy (
    void * dest,
    const void * src,
    uint32 n )
```

**12.108.2.37 CFE\_PSP\_MemRangeGet()**

```
int32 CFE_PSP_MemRangeGet (
    uint32 RangeNum,
    uint32 * MemoryType,
    cpuaddr * StartAddr,
    size_t * Size,
    size_t * WordSize,
    uint32 * Attributes )
```

**12.108.2.38 CFE\_PSP\_MemRanges()**

```
uint32 CFE_PSP_MemRanges (
    void )
```

**12.108.2.39 CFE\_PSP\_MemRangeSet()**

```
int32 CFE_PSP_MemRangeSet (
    uint32 RangeNum,
    uint32 MemoryType,
    cpuaddr StartAddr,
    size_t Size,
    size_t WordSize,
    uint32 Attributes )
```

**12.108.2.40 CFE\_PSP\_MemRead16()**

```
int32 CFE_PSP_MemRead16 (
    cpuaddr MemoryAddress,
    uint16 * uint16Value )
```

**12.108.2.41 CFE\_PSP\_MemRead32()**

```
int32 CFE_PSP_MemRead32 (
    cpuaddr MemoryAddress,
    uint32 * uint32Value )
```

**12.108.2.42 CFE\_PSP\_MemRead8()**

```
int32 CFE_PSP_MemRead8 (
    cpuaddr MemoryAddress,
    uint8 * ByteValue )
```

**12.108.2.43 CFE\_PSP\_MemSet()**

```
int32 CFE_PSP_MemSet (
    void * dest,
    uint8 value,
    uint32 n )
```

**12.108.2.44 CFE\_PSP\_MemValidateRange()**

```
int32 CFE_PSP_MemValidateRange (
    cpuaddr Address,
    size_t Size,
    uint32 MemoryType )
```

**12.108.2.45 CFE\_PSP\_MemWrite16()**

```
int32 CFE_PSP_MemWrite16 (
    cpuaddr MemoryAddress,
    uint16 uint16Value )
```

**12.108.2.46 CFE\_PSP\_MemWrite32()**

```
int32 CFE_PSP_MemWrite32 (
    cpuaddr MemoryAddress,
    uint32 uint32Value )
```

**12.108.2.47 CFE\_PSP\_MemWrite8()**

```
int32 CFE_PSP_MemWrite8 (
    cpuaddr MemoryAddress,
    uint8 ByteValue )
```

**12.108.2.48 CFE\_PSP\_Panic()**

```
void CFE_PSP_Panic (
    int32 ErrorCode )
```

**12.108.2.49 CFE\_PSP\_PortRead16()**

```
int32 CFE_PSP_PortRead16 (
    cpuaddr PortAddress,
    uint16 * uint16Value )
```

**12.108.2.50 CFE\_PSP\_PortRead32()**

```
int32 CFE_PSP_PortRead32 (
    cpuaddr PortAddress,
    uint32 * uint32Value )
```

**12.108.2.51 CFE\_PSP\_PortRead8()**

```
int32 CFE_PSP_PortRead8 (
    cpuaddr PortAddress,
    uint8 * ByteValue )
```

**12.108.2.52 CFE\_PSP\_PortWrite16()**

```
int32 CFE_PSP_PortWrite16 (
    cpuaddr PortAddress,
    uint16 uint16Value )
```

**12.108.2.53 CFE\_PSP\_PortWrite32()**

```
int32 CFE_PSP_PortWrite32 (
    cpuaddr PortAddress,
    uint32 uint32Value )
```

**12.108.2.54 CFE\_PSP\_PortWrite8()**

```
int32 CFE_PSP_PortWrite8 (
    cpuaddr PortAddress,
    uint8 ByteValue )
```

**12.108.2.55 CFE\_PSP\_ReadFromCDS()**

```
int32 CFE_PSP_ReadFromCDS (
    void * PtrToDataToRead,
    uint32 CDSOffset,
    uint32 NumBytes )
```

**12.108.2.56 CFE\_PSP\_Restart()**

```
void CFE_PSP_Restart (
    uint32 resetType )
```

**12.108.2.57 CFE\_PSP\_SetDefaultExceptionEnvironment()**

```
void CFE_PSP_SetDefaultExceptionEnvironment (
    void )
```

**12.108.2.58 CFE\_PSP\_WatchdogDisable()**

```
void CFE_PSP_WatchdogDisable (
    void )
```

**12.108.2.59 CFE\_PSP\_WatchdogEnable()**

```
void CFE_PSP_WatchdogEnable (
    void )
```

**12.108.2.60 CFE\_PSP\_WatchdogGet()**

```
uint32 CFE_PSP_WatchdogGet (
    void )
```

**12.108.2.61 CFE\_PSP\_WatchdogInit()**

```
void CFE_PSP_WatchdogInit (
    void )
```

**12.108.2.62 CFE\_PSP\_WatchdogService()**

```
void CFE_PSP_WatchdogService (
    void )
```

**12.108.2.63 CFE\_PSP\_WatchdogSet()**

```
void CFE_PSP_WatchdogSet (
    uint32 WatchdogValue )
```

### 12.108.2.64 CFE\_PSP\_WriteToCDS()

```
int32 CFE_PSP_WriteToCDS (
    const void * PtrToDataToWrite,
    uint32 CDSOffset,
    uint32 NumBytes )
```

## 12.109 psp/fsw/inc/cfe\_psp\_error.h File Reference

cFE PSP Error header

```
#include "common_types.h"
```

### Macros

- #define CFE\_PSP\_STATUS\_C(X) ((CFE\_PSP\_Status\_t)(X))  
*PSP Status macro for literal.*
- #define CFE\_PSP\_STATUS\_STRING\_LENGTH 12  
*PSP Status converted to string length limit.*
- #define CFE\_PSP\_SUCCESS (CFE\_PSP\_STATUS\_C(0))
- #define CFE\_PSP\_ERROR (CFE\_PSP\_STATUS\_C(-1))
- #define CFE\_PSP\_INVALID\_POINTER (CFE\_PSP\_STATUS\_C(-2))
- #define CFE\_PSP\_ERROR\_ADDRESS\_MISALIGNED (CFE\_PSP\_STATUS\_C(-3))
- #define CFE\_PSP\_ERROR\_TIMEOUT (CFE\_PSP\_STATUS\_C(-4))
- #define CFE\_PSP\_INVALID\_INT\_NUM (CFE\_PSP\_STATUS\_C(-5))
- #define CFE\_PSP\_INVALID\_MEM\_ADDR (CFE\_PSP\_STATUS\_C(-21))
- #define CFE\_PSP\_INVALID\_MEM\_TYPE (CFE\_PSP\_STATUS\_C(-22))
- #define CFE\_PSP\_INVALID\_MEM\_RANGE (CFE\_PSP\_STATUS\_C(-23))
- #define CFE\_PSP\_INVALID\_MEM\_WORDSIZE (CFE\_PSP\_STATUS\_C(-24))
- #define CFE\_PSP\_INVALID\_MEM\_SIZE (CFE\_PSP\_STATUS\_C(-25))
- #define CFE\_PSP\_INVALID\_MEM\_ATTR (CFE\_PSP\_STATUS\_C(-26))
- #define CFE\_PSP\_ERROR\_NOT\_IMPLEMENTED (CFE\_PSP\_STATUS\_C(-27))
- #define CFE\_PSP\_INVALID\_MODULE\_NAME (CFE\_PSP\_STATUS\_C(-28))
- #define CFE\_PSP\_INVALID\_MODULE\_ID (CFE\_PSP\_STATUS\_C(-29))
- #define CFE\_PSP\_NO\_EXCEPTION\_DATA (CFE\_PSP\_STATUS\_C(-30))

### Typedefs

- typedef int32 CFE\_PSP\_Status\_t  
*PSP Status type for readability and potentially type safety.*
- typedef char CFE\_PSP\_StatusString\_t[CFE\_PSP\_STATUS\_STRING\_LENGTH]  
*For the CFE\_PSP\_StatusToString() function, to ensure everyone is making an array of the same length.*

## Functions

- `char * CFE_PSP_StatusToString (CFE_PSP_Status_t status, CFE_PSP_StatusString_t *status_string)`  
*Convert status to a string.*

### 12.109.1 Detailed Description

cFE PSP Error header

### 12.109.2 Macro Definition Documentation

#### 12.109.2.1 CFE\_PSP\_ERROR

```
#define CFE_PSP_ERROR (CFE_PSP_STATUS_C (-1))
```

Definition at line 66 of file cfe\_psp\_error.h.

#### 12.109.2.2 CFE\_PSP\_ERROR\_ADDRESS\_MISALIGNED

```
#define CFE_PSP_ERROR_ADDRESS_MISALIGNED (CFE_PSP_STATUS_C (-3))
```

Definition at line 68 of file cfe\_psp\_error.h.

#### 12.109.2.3 CFE\_PSP\_ERROR\_NOT\_IMPLEMENTED

```
#define CFE_PSP_ERROR_NOT_IMPLEMENTED (CFE_PSP_STATUS_C (-27))
```

Definition at line 77 of file cfe\_psp\_error.h.

#### 12.109.2.4 CFE\_PSP\_ERROR\_TIMEOUT

```
#define CFE_PSP_ERROR_TIMEOUT (CFE_PSP_STATUS_C (-4))
```

Definition at line 69 of file cfe\_psp\_error.h.

**12.109.2.5 CFE\_PSP\_INVALID\_INT\_NUM**

```
#define CFE_PSP_INVALID_INT_NUM (CFE_PSP_STATUS_C(-5))
```

Definition at line 70 of file cfe\_psp\_error.h.

**12.109.2.6 CFE\_PSP\_INVALID\_MEM\_ADDR**

```
#define CFE_PSP_INVALID_MEM_ADDR (CFE_PSP_STATUS_C(-21))
```

Definition at line 71 of file cfe\_psp\_error.h.

**12.109.2.7 CFE\_PSP\_INVALID\_MEM\_ATTR**

```
#define CFE_PSP_INVALID_MEM_ATTR (CFE_PSP_STATUS_C(-26))
```

Definition at line 76 of file cfe\_psp\_error.h.

**12.109.2.8 CFE\_PSP\_INVALID\_MEM\_RANGE**

```
#define CFE_PSP_INVALID_MEM_RANGE (CFE_PSP_STATUS_C(-23))
```

Definition at line 73 of file cfe\_psp\_error.h.

**12.109.2.9 CFE\_PSP\_INVALID\_MEM\_SIZE**

```
#define CFE_PSP_INVALID_MEM_SIZE (CFE_PSP_STATUS_C(-25))
```

Definition at line 75 of file cfe\_psp\_error.h.

**12.109.2.10 CFE\_PSP\_INVALID\_MEM\_TYPE**

```
#define CFE_PSP_INVALID_MEM_TYPE (CFE_PSP_STATUS_C(-22))
```

Definition at line 72 of file cfe\_psp\_error.h.

**12.109.2.11 CFE\_PSP\_INVALID\_MEM\_WORDSIZE**

```
#define CFE_PSP_INVALID_MEM_WORDSIZE (CFE_PSP_STATUS_C(-24))
```

Definition at line 74 of file cfe\_psp\_error.h.

**12.109.2.12 CFE\_PSP\_INVALID\_MODULE\_ID**

```
#define CFE_PSP_INVALID_MODULE_ID (CFE_PSP_STATUS_C(-29))
```

Definition at line 79 of file cfe\_psp\_error.h.

**12.109.2.13 CFE\_PSP\_INVALID\_MODULE\_NAME**

```
#define CFE_PSP_INVALID_MODULE_NAME (CFE_PSP_STATUS_C(-28))
```

Definition at line 78 of file cfe\_psp\_error.h.

**12.109.2.14 CFE\_PSP\_INVALID\_POINTER**

```
#define CFE_PSP_INVALID_POINTER (CFE_PSP_STATUS_C(-2))
```

Definition at line 67 of file cfe\_psp\_error.h.

**12.109.2.15 CFE\_PSP\_NO\_EXCEPTION\_DATA**

```
#define CFE_PSP_NO_EXCEPTION_DATA (CFE_PSP_STATUS_C(-30))
```

Definition at line 80 of file cfe\_psp\_error.h.

**12.109.2.16 CFE\_PSP\_STATUS\_C**

```
#define CFE_PSP_STATUS_C( X ) ( (CFE_PSP_Status_t) (X) )
```

PSP Status macro for literal.

Definition at line 36 of file cfe\_psp\_error.h.

### 12.109.2.17 CFE\_PSP\_STATUS\_STRING\_LENGTH

```
#define CFE_PSP_STATUS_STRING_LENGTH 12
```

PSP Status converted to string length limit.

Used for sizing CFE\_PSP\_StatusString\_t intended for use in printing CFE\_PSP\_Status\_t values Sized for Id (LONG←\_MIN) including NULL

Definition at line 44 of file cfe\_psp\_error.h.

### 12.109.2.18 CFE\_PSP\_SUCCESS

```
#define CFE_PSP_SUCCESS (CFE_PSP_STATUS_C(0))
```

Definition at line 65 of file cfe\_psp\_error.h.

## 12.109.3 Typedef Documentation

### 12.109.3.1 CFE\_PSP\_Status\_t

```
typedef int32 CFE_PSP_Status_t
```

PSP Status type for readability and potentially type safety.

Definition at line 31 of file cfe\_psp\_error.h.

### 12.109.3.2 CFE\_PSP\_StatusString\_t

```
typedef char CFE_PSP_StatusString_t[CFE_PSP_STATUS_STRING_LENGTH]
```

For the [CFE\\_PSP\\_StatusToString\(\)](#) function, to ensure everyone is making an array of the same length.

Definition at line 50 of file cfe\_psp\_error.h.

## 12.109.4 Function Documentation

### 12.109.4.1 CFE\_PSP\_StatusToString()

```
char* CFE_PSP_StatusToString (
    CFE_PSP_Status_t status,
    CFE_PSP_StatusString_t * status_string )
```

Convert status to a string.

**Parameters**

in	<i>status</i>	Status value to convert
out	<i>status_string</i>	Buffer to store status converted to string

**Returns**

Passed in string pointer



## Index

\_EXTENSION\_  
    common\_types.h, 1486

ARGCHECK  
    osapi-macros.h, 1515

accuracy  
    OS\_timebase\_prop\_t, 849  
    OS\_timer\_prop\_t, 851

ActiveBuffer  
    CFE\_TBL\_HousekeepingTlm\_Payload, 712

ActiveBufferAddr  
    CFE\_TBL\_TblRegPacket\_Payload, 729

ActiveTableFlag  
    CFE\_TBL\_DumpCmd\_Payload, 705  
    CFE\_TBL\_ValidateCmd\_Payload, 735

ActualLength  
    OS\_SockAddr\_t, 842

addr  
    OS\_module\_prop\_t, 838

AddrData  
    OS\_SockAddr\_t, 842

Address  
    OS\_static\_symbol\_record\_t, 845

AddressesAreValid  
    CFE\_ES\_AppInfo, 566

Algorithm\_N  
    DS\_FilterParms\_t, 811  
    DS\_FilterParmsCmd\_t, 813

Algorithm\_O  
    DS\_FilterParms\_t, 811  
    DS\_FilterParmsCmd\_t, 813

Algorithm\_X  
    DS\_FilterParms\_t, 811  
    DS\_FilterParmsCmd\_t, 813

AlignPtr  
    OS\_SockAddrData\_t, 843

AlignU32  
    OS\_SockAddrData\_t, 843

AppData  
    CFE\_EVS\_HousekeepingTlm\_Payload, 641

AppDataFilename  
    CFE\_EVS\_AppDataCmd\_Payload, 626

AppEnableState  
    DS\_AppData\_t, 772  
    DS\_HkPacket\_t, 821

AppEnableStatus  
    CFE\_EVS\_AppTlmData, 635

AppEntryPoint  
    CFE\_ES\_StartAppCmd\_Payload, 618

AppFileName  
    CFE\_ES\_AppReloadCmd\_Payload, 574

                CFE\_ES\_StartAppCmd\_Payload, 618

AppID  
    CFE\_EVS\_AppTlmData, 635

AppId  
    CFE\_ES\_TaskInfo, 624  
    CFE\_SB\_PipeInfoEntry, 678

AppInfo  
    CFE\_ES\_OneAppTlm\_Payload, 602

AppMessageSentCounter  
    CFE\_EVS\_AppTlmData, 636

AppMessageSquelchedCounter  
    CFE\_EVS\_AppTlmData, 636

AppName  
    CFE\_ES\_TaskInfo, 624  
    CFE\_EVS\_AppNameBitMaskCmd\_Payload, 628  
    CFE\_EVS\_AppNameCmd\_Payload, 630  
    CFE\_EVS\_AppNameEventIDCmd\_Payload, 632  
    CFE\_EVS\_AppNameEventIDMaskCmd\_Payload, 634  
    CFE\_EVS\_PacketID, 650  
    CFE\_SB\_PipeInfoEntry, 678  
    CFE\_SB\_RoutingFileEntry, 684

Application  
    CFE\_ES\_AppNameCmd\_Payload, 573  
    CFE\_ES\_AppReloadCmd\_Payload, 574  
    CFE\_ES\_SendMemPoolStatsCmd\_Payload, 610  
    CFE\_ES\_StartAppCmd\_Payload, 618

ApplicationID  
    CFE\_FS\_Header, 661

apps/ds/docs/dox\_src/cfs\_ds.dox, 852

apps/ds/fsw/mission\_inc/ds\_perfids.h, 852

apps/ds/fsw/platform\_inc/ds\_msgids.h, 852

apps/ds/fsw/platform\_inc/ds\_platform\_cfg.h, 853

apps/ds/fsw/src/ds\_app.c, 854

apps/ds/fsw/src/ds\_app.h, 865

apps/ds/fsw/src/ds\_appdefs.h, 877

apps/ds/fsw/src/ds\_cmds.c, 882

apps/ds/fsw/src/ds\_cmds.h, 907

apps/ds/fsw/src/ds\_events.h, 932

apps/ds/fsw/src/ds\_file.c, 935

apps/ds/fsw/src/ds\_file.h, 955

apps/ds/fsw/src/ds\_msg.h, 971

apps/ds/fsw/src/ds\_msgdefs.h, 972

apps/ds/fsw/src/ds\_table.c, 973

apps/ds/fsw/src/ds\_table.h, 999

apps/ds/fsw/src/ds\_verify.h, 1026

apps/ds/fsw/src/ds\_version.h, 1027

apps/ds/fsw/tables/ds\_file\_tbl.c, 1027

apps/ds/fsw/tables/ds\_filter\_tbl.c, 1029

AtToneDelay  
    CFE\_TIME\_DiagnosticTlm\_Payload, 739

AtToneLatch  
     CFE\_TIME\_DiagnosticTlm\_Payload, 739

AtToneLeapSeconds  
     CFE\_TIME\_DiagnosticTlm\_Payload, 739  
     CFE\_TIME\_ToneDataCmd\_Payload, 769

AtToneMET  
     CFE\_TIME\_DiagnosticTlm\_Payload, 739  
     CFE\_TIME\_ToneDataCmd\_Payload, 769

AtToneSTCF  
     CFE\_TIME\_DiagnosticTlm\_Payload, 739  
     CFE\_TIME\_ToneDataCmd\_Payload, 769

AtToneState  
     CFE\_TIME\_ToneDataCmd\_Payload, 769

BSSAddress  
     CFE\_ES\_AppInfo, 566

BSSSize  
     CFE\_ES\_AppInfo, 567

BUFSIZE  
     cfe\_psp.h, 1539

BUGCHECK  
     osapi-macros.h, 1515

BUGREPORT  
     osapi-macros.h, 1516

Basename  
     DS\_DestBaseCmd\_t, 787  
     DS\_DestFileEntry\_t, 792

BitMask  
     CFE\_EVS\_AppNameBitMaskCmd\_Payload, 628  
     CFE\_EVS\_BitMaskCmd\_Payload, 639

block\_size  
     OS\_statvfs\_t, 846

BlockSize  
     CFE\_ES\_BlockStats, 575

BlockStats  
     CFE\_ES\_MemPoolStats, 597

blocks\_free  
     OS\_statvfs\_t, 846

BootSource  
     CFE\_ES\_HousekeepingTlm\_Payload, 586

bss\_address  
     OS\_module\_address\_t, 836

bss\_size  
     OS\_module\_address\_t, 837

Buffer  
     OS\_SockAddrData\_t, 843

build/docs/osconfig-example.h, 1032

ByteAlign  
     CFE\_TBL\_TblRegPacket\_Payload, 729

ByteAlignPad1  
     CFE\_TBL\_HousekeepingTlm\_Payload, 712

ByteAlignSpare  
     CFE\_ES\_CDSRegDumpRec, 576

CCSDS\_ExtendedHeader, 563

Subsystem, 563

SystemId, 563

CCSDS\_ExtendedHeader\_t  
     ccsds\_hdr.h, 1356

CCSDS\_PrimaryHeader, 564

Length, 564

Sequence, 564

StreamId, 564

CCSDS\_PrimaryHeader\_t  
     ccsds\_hdr.h, 1356

cFE Access Table Content APIs, 383

    CFE\_TBL\_GetAddress, 383  
     CFE\_TBL\_GetAddresses, 384  
     CFE\_TBL\_ReleaseAddress, 385  
     CFE\_TBL\_ReleaseAddresses, 386

cFE Application Behavior APIs, 246

    CFE\_ES\_ExitApp, 246  
     CFE\_ES\_IncrementTaskCounter, 247  
     CFE\_ES\_RunLoop, 247  
     CFE\_ES\_WaitForStartupSync, 249  
     CFE\_ES\_WaitForSystemState, 249

cFE Application Control APIs, 243

    CFE\_ES\_DeleteApp, 243  
     CFE\_ES\_ReloadApp, 244  
     CFE\_ES\_RestartApp, 244

cFE Child Task APIs, 261

    CFE\_ES\_CreateChildTask, 261  
     CFE\_ES\_DeleteChildTask, 262  
     CFE\_ES\_ExitChildTask, 263  
     CFE\_ES\_GetTaskIDByName, 263  
     CFE\_ES\_GetTaskName, 264

cFE Clock State Flag Defines, 418

    CFE\_TIME\_FLAG\_ADD1HZ, 418  
     CFE\_TIME\_FLAG\_ADDADJ, 418  
     CFE\_TIME\_FLAG\_ADDTCL, 419  
     CFE\_TIME\_FLAG\_CLKSET, 419  
     CFE\_TIME\_FLAG\_CMDFLY, 419  
     CFE\_TIME\_FLAG\_FLYING, 419  
     CFE\_TIME\_FLAG\_GDTONE, 419  
     CFE\_TIME\_FLAG\_REFERR, 420  
     CFE\_TIME\_FLAG\_SERVER, 420  
     CFE\_TIME\_FLAG\_SIGPRI, 420  
     CFE\_TIME\_FLAG\_SRCINT, 420  
     CFE\_TIME\_FLAG\_SRVFLY, 420  
     CFE\_TIME\_FLAG\_UNUSED, 420

cFE Critical Data Store APIs, 270

    CFE\_ES\_CopyToCDS, 270  
     CFE\_ES\_GetCDSBlockIDByName, 271  
     CFE\_ES\_GetCDSBlockName, 272  
     CFE\_ES\_RegisterCDS, 273  
     CFE\_ES\_RestoreFromCDS, 274

cFE Entry/Exit APIs, 241

    CFE\_ES\_Main, 241  
     CFE\_ES\_ResetCFE, 242

- cFE External Time Source APIs, [409](#)  
  CFE\_TIME\_ExternalGPS, [409](#)  
  CFE\_TIME\_ExternalMET, [410](#)  
  CFE\_TIME\_ExternalTime, [410](#)  
  CFE\_TIME\_ExternalTone, [411](#)  
  CFE\_TIME\_RegisterSynchCallback, [412](#)  
  CFE\_TIME\_UnregisterSynchCallback, [412](#)
- cFE File Header Management APIs, [304](#)  
  CFE\_FS\_InitHeader, [304](#)  
  CFE\_FS\_ReadHeader, [304](#)  
  CFE\_FS\_SetTimestamp, [305](#)  
  CFE\_FS\_WriteHeader, [306](#)
- cFE File Utility APIs, [309](#)  
  CFE\_FS\_BackgroundFileDumpIsPending, [309](#)  
  CFE\_FS\_BackgroundFileDumpRequest, [310](#)  
  CFE\_FS\_ExtractFilenameFromPath, [310](#)  
  CFE\_FS\_GetDefaultExtension, [311](#)  
  CFE\_FS\_GetDefaultMountPoint, [312](#)  
  CFE\_FS\_ParseInputFileName, [312](#)  
  CFE\_FS\_ParseInputFileNameEx, [313](#)
- cFE Generic Counter APIs, [287](#)  
  CFE\_ES\_DeleteGenCounter, [287](#)  
  CFE\_ES\_GetGenCount, [288](#)  
  CFE\_ES\_GetGenCounterIDByName, [289](#)  
  CFE\_ES\_GetGenCounterName, [289](#)  
  CFE\_ES\_IncrementGenCounter, [290](#)  
  CFE\_ES\_RegisterGenCounter, [292](#)  
  CFE\_ES\_SetGenCount, [293](#)
- cFE Generic Message APIs, [315](#)  
  CFE\_MSG\_Init, [315](#)
- cFE Get Current Time APIs, [396](#)  
  CFE\_TIME\_GetMETseconds, [396](#)  
  CFE\_TIME\_GetMETsubsecs, [397](#)  
  CFE\_TIME\_GetMET, [396](#)  
  CFE\_TIME\_GetTAI, [397](#)  
  CFE\_TIME\_GetTime, [398](#)  
  CFE\_TIME\_GetUTC, [399](#)
- cFE Get Table Information APIs, [388](#)  
  CFE\_TBL\_GetInfo, [388](#)  
  CFE\_TBL\_GetStatus, [389](#)  
  CFE\_TBL\_NotifyByMessage, [390](#)
- cFE Get Time Information APIs, [400](#)  
  CFE\_TIME\_GetClockInfo, [400](#)  
  CFE\_TIME\_GetClockState, [400](#)  
  CFE\_TIME\_GetLeapSeconds, [401](#)  
  CFE\_TIME\_GetSTCF, [401](#)
- cFE Information APIs, [251](#)  
  CFE\_ES\_GetAppIDByName, [252](#)  
  CFE\_ES\_GetAppID, [251](#)  
  CFE\_ES\_GetAppInfo, [253](#)  
  CFE\_ES\_GetAppName, [254](#)  
  CFE\_ES\_GetLibIDByName, [254](#)  
  CFE\_ES\_GetLibInfo, [255](#)  
  CFE\_ES\_GetLibName, [256](#)
- CFE\_ES\_GetModuleInfo, [257](#)  
CFE\_ES\_GetResetType, [258](#)  
CFE\_ES\_GetTaskID, [259](#)  
CFE\_ES\_GetTaskInfo, [260](#)
- cFE Manage Table Content APIs, [376](#)  
  CFE\_TBL\_DumpToBuffer, [376](#)  
  CFE\_TBL\_Load, [377](#)  
  CFE\_TBL\_Manage, [378](#)  
  CFE\_TBL\_Modified, [379](#)  
  CFE\_TBL\_Update, [380](#)  
  CFE\_TBL\_Validate, [381](#)
- cFE Memory Manager APIs, [276](#)  
  CFE\_ES\_GetMemPoolStats, [276](#)  
  CFE\_ES\_GetPoolBuf, [277](#)  
  CFE\_ES\_GetPoolBufInfo, [278](#)  
  CFE\_ES\_PoolCreate, [279](#)  
  CFE\_ES\_PoolCreateEx, [280](#)  
  CFE\_ES\_PoolCreateNoSem, [281](#)  
  CFE\_ES\_PoolDelete, [282](#)  
  CFE\_ES\_PutPoolBuf, [283](#)
- cFE Message Characteristics APIs, [361](#)  
  CFE\_SB\_GetUserData, [361](#)  
  CFE\_SB\_GetUserDataLength, [362](#)  
  CFE\_SB\_MessageStringGet, [362](#)  
  CFE\_SB\_MessageStringSet, [363](#)  
  CFE\_SB\_SetUserDataLength, [364](#)  
  CFE\_SB\_TimeStampMsg, [365](#)
- cFE Message Extended Header APIs, [327](#)  
  CFE\_MSG\_GetEDSVersion, [327](#)  
  CFE\_MSG\_GetEndian, [328](#)  
  CFE\_MSG\_GetPlaybackFlag, [328](#)  
  CFE\_MSG\_GetSubsystem, [329](#)  
  CFE\_MSG\_GetSystem, [330](#)  
  CFE\_MSG\_SetEDSVersion, [330](#)  
  CFE\_MSG\_SetEndian, [331](#)  
  CFE\_MSG\_SetPlaybackFlag, [332](#)  
  CFE\_MSG\_SetSubsystem, [332](#)  
  CFE\_MSG\_SetSystem, [333](#)
- cFE Message ID APIs, [366](#)  
  CFE\_SB\_IsValidMsgId, [366](#)  
  CFE\_SB\_MsgId\_Equal, [366](#)  
  CFE\_SB\_MsgIdToValue, [367](#)  
  CFE\_SB\_ValueToMsgId, [368](#)
- cFE Message Id APIs, [339](#)  
  CFE\_MSG\_GetMsgId, [339](#)  
  CFE\_MSG\_GetTypeFromMsgId, [340](#)  
  CFE\_MSG\_SetMsgId, [340](#)
- cFE Message Primary Header APIs, [316](#)  
  CFE\_MSG\_GetApld, [316](#)  
  CFE\_MSG\_GetHasSecondaryHeader, [317](#)  
  CFE\_MSG\_GetHeaderVersion, [318](#)  
  CFE\_MSG\_GetNextSequenceCount, [318](#)  
  CFE\_MSG\_GetSegmentationFlag, [319](#)  
  CFE\_MSG\_GetSequenceCount, [319](#)

CFE\_MSG\_GetSize, 320  
 CFE\_MSG.GetType, 321  
 CFE\_MSG\_SetApId, 321  
 CFE\_MSG\_SetHasSecondaryHeader, 322  
 CFE\_MSG\_SetHeaderVersion, 323  
 CFE\_MSG\_SetSegmentationFlag, 323  
 CFE\_MSG\_SetSequenceCount, 324  
 CFE\_MSG\_SetSize, 325  
 CFE\_MSG\_SetType, 325  
 cFE Message Secondary Header APIs, 334  
 CFE\_MSG\_GenerateChecksum, 334  
 CFE\_MSG\_GetFcnCode, 335  
 CFE\_MSG\_GetMsgTime, 335  
 CFE\_MSG\_SetFcnCode, 336  
 CFE\_MSG\_SetMsgTime, 337  
 CFE\_MSG\_ValidateChecksum, 338  
 cFE Message Subscription Control APIs, 349  
 CFE\_SB\_Subscribe, 349  
 CFE\_SB\_SubscribeEx, 350  
 CFE\_SB\_SubscribeLocal, 351  
 CFE\_SB\_Unsubscribe, 352  
 CFE\_SB\_UnsubscribeLocal, 353  
 cFE Miscellaneous APIs, 266  
 CFE\_ES\_BackgroundWakeUp, 266  
 CFE\_ES\_CalculateCRC, 266  
 CFE\_ES\_ProcessAsyncEvent, 268  
 CFE\_ES\_WriteToSysLog, 268  
 cFE Miscellaneous Time APIs, 414  
 CFE\_TIME\_Local1HzISR, 414  
 CFE\_TIME\_Print, 414  
 cFE Performance Monitor APIs, 284  
 CFE\_ES\_PerfLogAdd, 285  
 CFE\_ES\_PerfLogEntry, 284  
 CFE\_ES\_PerfLogExit, 285  
 cFE Pipe Management APIs, 342  
 CFE\_SB\_CreatePipe, 342  
 CFE\_SB\_DeletePipe, 343  
 CFE\_SB\_GetPipeIdByName, 344  
 CFE\_SB\_GetPipeName, 345  
 CFE\_SB\_GetPipeOpts, 345  
 CFE\_SB\_PipeId\_ToIndex, 347  
 CFE\_SB\_SetPipeOpts, 348  
 cFE Registration APIs, 295, 370  
 CFE\_EVS\_Register, 295  
 CFE\_TBL\_Register, 370  
 CFE\_TBL\_Share, 373  
 CFE\_TBL\_Unregister, 374  
 cFE Reset Event Filter APIs, 302  
 CFE\_EVS\_ResetAllFilters, 302  
 CFE\_EVS\_ResetFilter, 302  
 cFE Resource ID APIs, 237  
 CFE\_ES\_AppID\_ToIndex, 237  
 CFE\_ES\_CounterID\_ToIndex, 238  
 CFE\_ES\_LibID\_ToIndex, 238  
 CFE\_ES\_TaskID\_ToIndex, 239  
 cFE Resource ID base values, 416  
 cFE Return Code Defines, 200  
 CFE\_ES\_APP\_CLEANUP\_ERR, 205  
 CFE\_ES\_BAD\_ARGUMENT, 205  
 CFE\_ES\_BIN\_SEM\_DELETE\_ERR, 205  
 CFE\_ES\_BUFFER\_NOT\_IN\_POOL, 206  
 CFE\_ES\_CDS\_ACCESS\_ERROR, 206  
 CFE\_ES\_CDS\_ALREADY\_EXISTS, 206  
 CFE\_ES\_CDS\_BLOCK\_CRC\_ERR, 206  
 CFE\_ES\_CDS\_INSUFFICIENT\_MEMORY, 207  
 CFE\_ES\_CDS\_INVALID\_NAME, 207  
 CFE\_ES\_CDS\_INVALID\_SIZE, 207  
 CFE\_ES\_CDS\_INVALID, 207  
 CFE\_ES\_CDS\_OWNER\_ACTIVE\_ERR, 208  
 CFE\_ES\_CDS\_WRONG\_TYPE\_ERR, 208  
 CFE\_ES\_COUNT\_SEM\_DELETE\_ERR, 208  
 CFE\_ES\_ERR\_APP\_CREATE, 208  
 CFE\_ES\_ERR\_APP\_REGISTER, 209  
 CFE\_ES\_ERR\_CHILD\_TASK\_CREATE, 209  
 CFE\_ES\_ERR\_CHILD\_TASK\_DELETE\_MAIN\_T← ASK, 209  
 CFE\_ES\_ERR\_CHILD\_TASK\_DELETE, 209  
 CFE\_ES\_ERR\_CHILD\_TASK\_REGISTER, 210  
 CFE\_ES\_ERR\_DUPLICATE\_NAME, 210  
 CFE\_ES\_ERR\_LOAD\_LIB, 210  
 CFE\_ES\_ERR\_MEM\_BLOCK\_SIZE, 210  
 CFE\_ES\_ERR\_NAME\_NOT\_FOUND, 211  
 CFE\_ES\_ERR\_RESOURCEID\_NOT\_VALID, 211  
 CFE\_ES\_ERR\_SYS\_LOG\_FULL, 211  
 CFE\_ES\_ERR\_SYS\_LOG\_TRUNCATED, 211  
 CFE\_ES\_FILE\_CLOSE\_ERR, 212  
 CFE\_ES\_FILE\_IO\_ERR, 212  
 CFE\_ES\_LIB\_ALREADY\_LOADED, 212  
 CFE\_ES\_MUT\_SEM\_DELETE\_ERR, 212  
 CFE\_ES\_NO\_RESOURCE\_IDS\_AVAILABLE, 213  
 CFE\_ES\_NOT\_IMPLEMENTED, 213  
 CFE\_ES\_OPERATION\_TIMED\_OUT, 213  
 CFE\_ES\_POOL\_BLOCK\_INVALID, 213  
 CFE\_ES\_QUEUE\_DELETE\_ERR, 214  
 CFE\_ES\_RST\_ACCESS\_ERR, 214  
 CFE\_ES\_TASK\_DELETE\_ERR, 214  
 CFE\_ES\_TIMER\_DELETE\_ERR, 214  
 CFE\_EVS\_APP\_FILTER\_OVERLOAD, 215  
 CFE\_EVS\_APP\_ILLEGAL\_APP\_ID, 215  
 CFE\_EVS\_APP\_NOT\_REGISTERED, 215  
 CFE\_EVS\_APP\_SQUELCHED, 215  
 CFE\_EVS\_EVT\_NOT\_REGISTERED, 216  
 CFE\_EVS\_FILE\_WRITE\_ERROR, 216  
 CFE\_EVS\_INVALID\_PARAMETER, 216  
 CFE\_EVS\_NOT\_IMPLEMENTED, 216  
 CFE\_EVS\_RESET\_AREA\_POINTER, 217  
 CFE\_EVS\_UNKNOWN\_FILTER, 217  
 CFE\_FS\_BAD\_ARGUMENT, 217

CFE\_FS\_FNAME\_TOO\_LONG, 217  
CFE\_FS\_INVALID\_PATH, 218  
CFE\_FS\_NOT\_IMPLEMENTED, 218  
CFE\_SB\_BAD\_ARGUMENT, 218  
CFE\_SB\_BUF\_ALOC\_ERR, 218  
CFE\_SB\_BUFFER\_INVALID, 219  
CFE\_SB\_INTERNAL\_ERR, 219  
CFE\_SB\_MAX\_DESTS\_MET, 219  
CFE\_SB\_MAX\_MSGS\_MET, 219  
CFE\_SB\_MAX\_PIPES\_MET, 220  
CFE\_SB\_MSG\_TOO\_BIG, 220  
CFE\_SB\_NO\_MESSAGE, 220  
CFE\_SB\_NOT\_IMPLEMENTED, 220  
CFE\_SB\_PIPE\_CR\_ERR, 221  
CFE\_SB\_PIPE\_RD\_ERR, 221  
CFE\_SB\_TIME\_OUT, 221  
CFE\_SB\_WRONG\_MSG\_TYPE, 221  
CFE\_STATUS\_BAD\_COMMAND\_CODE, 222  
CFE\_STATUS\_EXTERNAL\_RESOURCE\_FAIL, 222  
CFE\_STATUS\_NO\_COUNTER\_INCREMENT, 222  
CFE\_STATUS\_NOT\_IMPLEMENTED, 222  
CFE\_STATUS\_REQUEST\_ALREADY\_PENDING, 223  
CFE\_STATUS\_UNKNOWN\_MSG\_ID, 223  
CFE\_STATUS\_WRONG\_MSG\_LENGTH, 223  
CFE\_SUCCESS, 223  
CFE\_TBL\_BAD\_ARGUMENT, 224  
CFE\_TBL\_ERR\_ACCESS, 224  
CFE\_TBL\_ERR\_BAD\_CONTENT\_ID, 224  
CFE\_TBL\_ERR\_BAD\_PROCESSOR\_ID, 224  
CFE\_TBL\_ERR\_BAD\_SPACECRAFT\_ID, 225  
CFE\_TBL\_ERR\_BAD\_SUBTYPE\_ID, 225  
CFE\_TBL\_ERR\_DUMP\_ONLY, 225  
CFE\_TBL\_ERR\_DUPLICATE\_DIFF\_SIZE, 225  
CFE\_TBL\_ERR\_DUPLICATE\_NOT\_OWNED, 226  
CFE\_TBL\_ERR\_FILE\_FOR\_WRONG\_TABLE, 226  
CFE\_TBL\_ERR\_FILE\_SIZE\_INCONSISTENT, 226  
CFE\_TBL\_ERR\_FILE\_TOO\_LARGE, 226  
CFE\_TBL\_ERR\_FILENAME\_TOO\_LONG, 227  
CFE\_TBL\_ERR\_HANDLES\_FULL, 227  
CFE\_TBL\_ERR\_ILLEGAL\_SRC\_TYPE, 227  
CFE\_TBL\_ERR\_INVALID\_HANDLE, 227  
CFE\_TBL\_ERR\_INVALID\_NAME, 228  
CFE\_TBL\_ERR\_INVALID\_OPTIONS, 228  
CFE\_TBL\_ERR\_INVALID\_SIZE, 228  
CFE\_TBL\_ERR\_LOAD\_IN\_PROGRESS, 229  
CFE\_TBL\_ERR\_LOAD\_INCOMPLETE, 229  
CFE\_TBL\_ERR\_NEVER\_LOADED, 229  
CFE\_TBL\_ERR\_NO\_ACCESS, 229  
CFE\_TBL\_ERR\_NO\_BUFFER\_AVAIL, 230  
CFE\_TBL\_ERR\_NO\_STD\_HEADER, 230  
CFE\_TBL\_ERR\_NO\_TBL\_HEADER, 230  
CFE\_TBL\_ERR\_PARTIAL\_LOAD, 230  
CFE\_TBL\_ERR\_REGISTRY\_FULL, 231  
CFE\_TBL\_ERR\_SHORT\_FILE, 231  
CFE\_TBL\_ERR\_UNREGISTERED, 231  
CFE\_TBL\_INFO\_DUMP\_PENDING, 231  
CFE\_TBL\_INFO\_NO\_UPDATE\_PENDING, 232  
CFE\_TBL\_INFO\_NO\_VALIDATION\_PENDING, 232  
CFE\_TBL\_INFO\_RECOVERED\_TBL, 232  
CFE\_TBL\_INFO\_TABLE\_LOCKED, 232  
CFE\_TBL\_INFO\_UPDATE\_PENDING, 233  
CFE\_TBL\_INFO\_UPDATED, 233  
CFE\_TBL\_INFO\_VALIDATION\_PENDING, 233  
CFE\_TBL\_MESSAGE\_ERROR, 233  
CFE\_TBL\_NOT\_IMPLEMENTED, 234  
CFE\_TBL\_WARN\_DUPLICATE, 234  
CFE\_TBL\_WARN\_NOT\_CRITICAL, 234  
CFE\_TBL\_WARN\_PARTIAL\_LOAD, 234  
CFE\_TBL\_WARN\_SHORT\_FILE, 235  
CFE\_TIME\_BAD\_ARGUMENT, 235  
CFE\_TIME\_CALLBACK\_NOT\_REGISTERED, 235  
CFE\_TIME\_INTERNAL\_ONLY, 235  
CFE\_TIME\_NOT\_IMPLEMENTED, 236  
CFE\_TIME\_OUT\_OF\_RANGE, 236  
CFE\_TIME\_TOO\_MANY\_SYNCH\_CALLBACKS, 236  
cFE SB Pipe options, 369  
CFE\_SB PIPEOPTS IGNOREMINE, 369  
cFE Send Event APIs, 297  
CFE\_EVS\_SendEvent, 297  
CFE\_EVS\_SendEventWithAppID, 298  
CFE\_EVS\_SendTimedEvent, 300  
cFE Send/Receive Message APIs, 355  
CFE\_SB\_ReceiveBuffer, 355  
CFE\_SB\_TransmitMsg, 356  
cFE Table Type Defines, 392  
CFE\_TBL\_OPT\_BUFFER\_MSK, 392  
CFE\_TBL\_OPT\_CRITICAL\_MSK, 393  
CFE\_TBL\_OPT\_CRITICAL, 392  
CFE\_TBL\_OPT\_DBL\_BUFFER, 393  
CFE\_TBL\_OPT\_DEFAULT, 393  
CFE\_TBL\_OPT\_DUMP\_ONLY, 393  
CFE\_TBL\_OPT\_LD\_DMP\_MSK, 393  
CFE\_TBL\_OPT\_LOAD\_DUMP, 394  
CFE\_TBL\_OPT\_NOT\_CRITICAL, 394  
CFE\_TBL\_OPT\_NOT\_USR\_DEF, 394  
CFE\_TBL\_OPT\_SNGL\_BUFFER, 394  
CFE\_TBL\_OPT\_USR\_DEF\_ADDR, 394  
CFE\_TBL\_OPT\_USR\_DEF\_MSK, 395  
cFE Time Arithmetic APIs, 403  
CFE\_TIME\_Add, 403  
CFE\_TIME\_Compare, 404  
CFE\_TIME\_Subtract, 405  
cFE Time Conversion APIs, 406  
CFE\_TIME\_MET2SCTime, 406  
CFE\_TIME\_Micro2SubSecs, 406  
CFE\_TIME\_Sub2MicroSecs, 407

cFE Zero Copy APIs, 358  
 CFE\_SB\_AllocateMessageBuffer, 358  
 CFE\_SB\_ReleaseMessageBuffer, 359  
 CFE\_SB\_TransmitBuffer, 359

CFE\_BIT  
 cfe\_sb.h, 1208

CFE\_BUILD\_BASELINE  
 cfe\_version.h, 1237

CFE\_BUILD\_NUMBER  
 cfe\_version.h, 1237

CFE\_CLR  
 cfe\_sb.h, 1209

CFE\_CONFIGID\_UNDEFINED  
 cfe\_config\_api\_typedefs.h, 1137

CFE\_CONFIGID\_C  
 cfe\_config\_api\_typedefs.h, 1137

CFE\_Config\_Callback\_t  
 cfe\_config\_api\_typedefs.h, 1137

CFE\_Config\_GetIdByName  
 cfe\_config.h, 1132

CFE\_Config\_GetName  
 cfe\_config.h, 1133

CFE\_Config\_GetObjPointer  
 cfe\_config.h, 1133

CFE\_Config\_GetString  
 cfe\_config.h, 1134

CFE\_Config\_GetValue  
 cfe\_config.h, 1134

CFE\_Config\_IterateAll  
 cfe\_config.h, 1136

CFE\_ConfigId\_t  
 cfe\_config\_api\_typedefs.h, 1137

CFE\_DDD\_INDEX  
 ds\_file.c, 936

CFE\_ES\_ALL\_APPS\_EID  
 cfe\_es\_events.h, 1242

CFE\_ES\_APP\_CLEANUP\_ERR  
 cFE Return Code Defines, 205

CFE\_ES\_APP\_RESTART  
 cfe\_es\_api\_typedefs.h, 1154

CFE\_ES\_APP\_TLM\_MID  
 cpu1\_msgids.h, 1042

CFE\_ES\_APPID\_UNDEFINED  
 cfe\_es\_api\_typedefs.h, 1154

CFE\_ES\_APPID\_C  
 cfe\_es\_api\_typedefs.h, 1154

CFE\_ES\_AppID\_ToIndex  
 cFE Resource ID APIs, 237

CFE\_ES\_AppId\_t  
 cfe\_es\_extern\_typedefs.h, 1162

CFE\_ES\_AppInfo, 565  
 AddressesAreValid, 566  
 BSSAddress, 566  
 BSSSize, 567

CodeAddress, 567  
 CodeSize, 567  
 DataAddress, 567  
 DataSize, 568  
 EntryPoint, 568  
 ExceptionAction, 568  
 ExecutionCounter, 568  
 FileName, 569  
 MainTaskId, 569  
 MainTaskName, 569  
 Name, 569  
 NumOfChildTasks, 570  
 Priority, 570  
 ResourceId, 570  
 StackSize, 570  
 StartAddress, 571  
 Type, 571

CFE\_ES\_AppInfo\_t  
 cfe\_es\_extern\_typedefs.h, 1162

CFE\_ES\_AppNameCmd, 571  
 CommandHeader, 572  
 Payload, 572

CFE\_ES\_AppNameCmd\_Payload, 572  
 Application, 573

CFE\_ES\_AppNameCmd\_Payload\_t  
 cfe\_es\_msg.h, 1300

CFE\_ES\_AppNameCmd\_t  
 cfe\_es\_msg.h, 1300

CFE\_ES\_AppReloadCmd\_Payload, 573  
 AppFileName, 574  
 Application, 574

CFE\_ES\_AppReloadCmd\_Payload\_t  
 cfe\_es\_msg.h, 1300

CFE\_ES\_AppState  
 cfe\_es\_extern\_typedefs.h, 1168

CFE\_ES\_AppState\_Enum\_t  
 cfe\_es\_extern\_typedefs.h, 1162

CFE\_ES\_AppType  
 cfe\_es\_extern\_typedefs.h, 1168

CFE\_ES\_AppType\_Enum\_t  
 cfe\_es\_extern\_typedefs.h, 1162

CFE\_ES\_BAD\_ARGUMENT  
 cFE Return Code Defines, 205

CFE\_ES\_BIN\_SEM\_DELETE\_ERR  
 cFE Return Code Defines, 205

CFE\_ES\_BOOT\_ERR\_EID  
 cfe\_es\_events.h, 1242

CFE\_ES\_BUFFER\_NOT\_IN\_POOL  
 cFE Return Code Defines, 206

CFE\_ES\_BUILD\_INF\_EID  
 cfe\_es\_events.h, 1243

CFE\_ES\_BackgroundWakeUp  
 cFE Miscellaneous APIs, 266

CFE\_ES\_BlockStats, 574

BlockSize, 575  
NumCreated, 575  
NumFree, 575  
**CFE\_ES\_BlockStats\_t**  
  cfe\_es\_extern\_typedefs.h, 1163  
**CFE\_ES\_CC1\_ERR\_EID**  
  cfe\_es\_events.h, 1243  
**CFE\_ES\_CDS\_ACCESS\_ERROR**  
  cFE Return Code Defines, 206  
**CFE\_ES\_CDS\_ALREADY\_EXISTS**  
  cFE Return Code Defines, 206  
**CFE\_ES\_CDS\_BAD\_HANDLE**  
  cfe\_es\_api\_typedefs.h, 1155  
**CFE\_ES\_CDS\_BLOCK\_CRC\_ERR**  
  cFE Return Code Defines, 206  
**CFE\_ES\_CDS\_DELETE\_ERR\_EID**  
  cfe\_es\_events.h, 1244  
**CFE\_ES\_CDS\_DELETE\_TBL\_ERR\_EID**  
  cfe\_es\_events.h, 1244  
**CFE\_ES\_CDS\_DELETED\_INFO\_EID**  
  cfe\_es\_events.h, 1244  
**CFE\_ES\_CDS\_DUMP\_ERR\_EID**  
  cfe\_es\_events.h, 1245  
**CFE\_ES\_CDS\_INSUFFICIENT\_MEMORY**  
  cFE Return Code Defines, 207  
**CFE\_ES\_CDS\_INVALID\_NAME**  
  cFE Return Code Defines, 207  
**CFE\_ES\_CDS\_INVALID\_SIZE**  
  cFE Return Code Defines, 207  
**CFE\_ES\_CDS\_INVALID**  
  cFE Return Code Defines, 207  
**CFE\_ES\_CDS\_NAME\_ERR\_EID**  
  cfe\_es\_events.h, 1245  
**CFE\_ES\_CDS\_OWNER\_ACTIVE\_EID**  
  cfe\_es\_events.h, 1245  
**CFE\_ES\_CDS\_OWNER\_ACTIVE\_ERR**  
  cFE Return Code Defines, 208  
**CFE\_ES\_CDS\_REG\_DUMP\_INF\_EID**  
  cfe\_es\_events.h, 1246  
**CFE\_ES\_CDS\_REGISTER\_ERR\_EID**  
  cfe\_es\_events.h, 1246  
**CFE\_ES\_CDS\_WRONG\_TYPE\_ERR**  
  cFE Return Code Defines, 208  
**CFE\_ES\_CDHANDLE\_C**  
  cfe\_es\_api\_typedefs.h, 1155  
**CFE\_ES\_CDHandle\_t**  
  cfe\_es\_extern\_typedefs.h, 1163  
**CFE\_ES\_CDSRegDumpRec**, 575  
  ByteAlignSpare, 576  
  Handle, 576  
  Name, 576  
  Size, 577  
  Table, 577  
**CFE\_ES\_CDSRegDumpRec\_t**  
  cfe\_es\_extern\_typedefs.h, 1163  
**CFE\_ES\_CLEAR\_ER\_LOG\_CC**  
  cfe\_es\_msg.h, 1276  
**CFE\_ES\_CLEAR\_SYSLOG\_CC**  
  cfe\_es\_msg.h, 1276  
**CFE\_ES\_CMD\_MID**  
  cpu1\_msjids.h, 1042  
**CFE\_ES\_COUNT\_SEM\_DELETE\_ERR**  
  cFE Return Code Defines, 208  
**CFE\_ES\_COUNTERID\_UNDEFINED**  
  cfe\_es\_api\_typedefs.h, 1155  
**CFE\_ES\_COUNTERID\_C**  
  cfe\_es\_api\_typedefs.h, 1155  
**CFE\_ES\_CREATING\_CDS\_DUMP\_ERR\_EID**  
  cfe\_es\_events.h, 1246  
**CFE\_ES\_CalculateCRC**  
  cFE Miscellaneous APIs, 266  
**CFE\_ES\_ChildTaskMainFuncPtr\_t**  
  cfe\_es\_api\_typedefs.h, 1158  
**CFE\_ES\_ClearERLogCmd\_t**  
  cfe\_es\_msg.h, 1300  
**CFE\_ES\_ClearSysLogCmd\_t**  
  cfe\_es\_msg.h, 1300  
**CFE\_ES\_CopyToCDS**  
  cFE Critical Data Store APIs, 270  
**CFE\_ES\_CounterID\_ToIndex**  
  cFE Resource ID APIs, 238  
**CFE\_ES\_CounterId\_t**  
  cfe\_es\_extern\_typedefs.h, 1163  
**CFE\_ES\_CreateChildTask**  
  cFE Child Task APIs, 261  
**CFE\_ES\_DBIT**  
  cfe\_es.h, 1152  
**CFE\_ES\_DELETE\_CDS\_CC**  
  cfe\_es\_msg.h, 1277  
**CFE\_ES\_DTEST**  
  cfe\_es.h, 1152  
**CFE\_ES\_DUMP\_CDS\_REGISTRY\_CC**  
  cfe\_es\_msg.h, 1278  
**CFE\_ES\_DeleteApp**  
  cFE Application Control APIs, 243  
**CFE\_ES\_DeleteCDSCmd**, 577  
  CommandHeader, 578  
  Payload, 578  
**CFE\_ES\_DeleteCDSCmd\_Payload**, 578  
  CdsName, 579  
**CFE\_ES\_DeleteCDSCmd\_Payload\_t**  
  cfe\_es\_msg.h, 1300  
**CFE\_ES\_DeleteCDSCmd\_t**  
  cfe\_es\_msg.h, 1300  
**CFE\_ES\_DeleteChildTask**  
  cFE Child Task APIs, 262  
**CFE\_ES\_DeleteGenCounter**  
  cFE Generic Counter APIs, 287

**CFE\_ES\_DumpCDSRegistryCmd**, [579](#)  
 CommandHeader, [580](#)  
 Payload, [580](#)  
**CFE\_ES\_DumpCDSRegistryCmd\_Payload**, [580](#)  
 DumpFilename, [581](#)  
**CFE\_ES\_DumpCDSRegistryCmd\_Payload\_t**  
 cfe\_es\_msg.h, [1301](#)  
**CFE\_ES\_DumpCDSRegistryCmd\_t**  
 cfe\_es\_msg.h, [1301](#)  
**CFE\_ES\_ERLOG1\_INF\_EID**  
 cfe\_es\_events.h, [1247](#)  
**CFE\_ES\_ERLOG2\_EID**  
 cfe\_es\_events.h, [1247](#)  
**CFE\_ES\_ERLOG2\_ERR\_EID**  
 cfe\_es\_events.h, [1247](#)  
**CFE\_ES\_ERLOG\_PENDING\_ERR\_EID**  
 cfe\_es\_events.h, [1248](#)  
**CFE\_ES\_ERR\_APP\_CREATE**  
 cFE Return Code Defines, [208](#)  
**CFE\_ES\_ERR\_APP\_REGISTER**  
 cFE Return Code Defines, [209](#)  
**CFE\_ES\_ERR\_CHILD\_TASK\_CREATE**  
 cFE Return Code Defines, [209](#)  
**CFE\_ES\_ERR\_CHILD\_TASK\_DELETE\_MAIN\_TASK**  
 cFE Return Code Defines, [209](#)  
**CFE\_ES\_ERR\_CHILD\_TASK\_DELETE**  
 cFE Return Code Defines, [209](#)  
**CFE\_ES\_ERR\_CHILD\_TASK\_REGISTER**  
 cFE Return Code Defines, [210](#)  
**CFE\_ES\_ERR\_DUPLICATE\_NAME**  
 cFE Return Code Defines, [210](#)  
**CFE\_ES\_ERR\_LOAD\_LIB**  
 cFE Return Code Defines, [210](#)  
**CFE\_ES\_ERR\_MEM\_BLOCK\_SIZE**  
 cFE Return Code Defines, [210](#)  
**CFE\_ES\_ERR\_NAME\_NOT\_FOUND**  
 cFE Return Code Defines, [211](#)  
**CFE\_ES\_ERR\_RESOURCEID\_NOT\_VALID**  
 cFE Return Code Defines, [211](#)  
**CFE\_ES\_ERR\_SYS\_LOG\_FULL**  
 cFE Return Code Defines, [211](#)  
**CFE\_ES\_ERR\_SYS\_LOG\_TRUNCATED**  
 cFE Return Code Defines, [211](#)  
**CFE\_ES\_ERR\_SYSLOGMODE\_EID**  
 cfe\_es\_events.h, [1248](#)  
**CFE\_ES\_ERREXIT\_APP\_ERR\_EID**  
 cfe\_es\_events.h, [1248](#)  
**CFE\_ES\_ERREXIT\_APP\_INF\_EID**  
 cfe\_es\_events.h, [1249](#)  
**CFE\_ES\_EXIT\_APP\_ERR\_EID**  
 cfe\_es\_events.h, [1249](#)  
**CFE\_ES\_EXIT\_APP\_INF\_EID**  
 cfe\_es\_events.h, [1250](#)  
**CFE\_ES\_ExceptionAction**  
 cfe\_es\_extern\_typedefs.h, [1169](#)  
**CFE\_ES\_ExceptionAction\_Enum\_t**  
 cfe\_es\_extern\_typedefs.h, [1164](#)  
**CFE\_ES\_ExitApp**  
 cFE Application Behavior APIs, [246](#)  
**CFE\_ES\_ExitChildTask**  
 cFE Child Task APIs, [263](#)  
**CFE\_ES\_FILE\_CLOSE\_ERR**  
 cFE Return Code Defines, [212](#)  
**CFE\_ES\_FILE\_IO\_ERR**  
 cFE Return Code Defines, [212](#)  
**CFE\_ES\_FILEWRITE\_ERR\_EID**  
 cfe\_es\_events.h, [1250](#)  
**CFE\_ES\_FileNameCmd**, [581](#)  
 CommandHeader, [581](#)  
 Payload, [581](#)  
**CFE\_ES\_FileNameCmd\_Payload**, [582](#)  
 FileName, [582](#)  
**CFE\_ES\_FileNameCmd\_Payload\_t**  
 cfe\_es\_msg.h, [1301](#)  
**CFE\_ES\_FileNameCmd\_t**  
 cfe\_es\_msg.h, [1301](#)  
**CFE\_ES\_GetAppIDByName**  
 cFE Information APIs, [252](#)  
**CFE\_ES\_GetAppID**  
 cFE Information APIs, [251](#)  
**CFE\_ES\_GetAppInfo**  
 cFE Information APIs, [253](#)  
**CFE\_ES\_GetAppName**  
 cFE Information APIs, [254](#)  
**CFE\_ES\_GetCDSBlockIDByName**  
 cFE Critical Data Store APIs, [271](#)  
**CFE\_ES\_GetCDSBlockName**  
 cFE Critical Data Store APIs, [272](#)  
**CFE\_ES\_GetGenCount**  
 cFE Generic Counter APIs, [288](#)  
**CFE\_ES\_GetGenCounterIDByName**  
 cFE Generic Counter APIs, [289](#)  
**CFE\_ES\_GetGenCounterName**  
 cFE Generic Counter APIs, [289](#)  
**CFE\_ES\_GetLibIDByName**  
 cFE Information APIs, [254](#)  
**CFE\_ES\_GetLibInfo**  
 cFE Information APIs, [255](#)  
**CFE\_ES\_GetLibName**  
 cFE Information APIs, [256](#)  
**CFE\_ES\_GetMemPoolStats**  
 cFE Memory Manager APIs, [276](#)  
**CFE\_ES\_GetModuleInfo**  
 cFE Information APIs, [257](#)  
**CFE\_ES\_GetPoolBuf**  
 cFE Memory Manager APIs, [277](#)  
**CFE\_ES\_GetPoolBufInfo**  
 cFE Memory Manager APIs, [278](#)

CFE\_ES\_GetResetType  
  cFE Information APIs, 258  
CFE\_ES\_GetTaskIDByName  
  cFE Child Task APIs, 263  
CFE\_ES\_GetTaskID  
  cFE Information APIs, 259  
CFE\_ES\_GetTaskInfo  
  cFE Information APIs, 260  
CFE\_ES\_GetTaskName  
  cFE Child Task APIs, 264  
CFE\_ES\_HK\_TLM\_MID  
  cpu1\_msgids.h, 1043  
CFE\_ES\_HousekeepingTlm, 583  
  Payload, 583  
  TelemetryHeader, 583  
CFE\_ES\_HousekeepingTlm\_Payload, 583  
  BootSource, 586  
  CFECoreChecksum, 586  
  CFEMajorVersion, 586  
  CFEMinorVersion, 586  
  CFEMissionRevision, 586  
  CFERevision, 587  
  CommandCounter, 587  
  CommandErrorCounter, 587  
  ERLogEntries, 587  
  ERLogIndex, 588  
  HeapBlocksFree, 588  
  HeapBytesFree, 588  
  HeapMaxBlockSize, 588  
  MaxProcessorResets, 589  
  OSALMajorVersion, 589  
  OSALMinorVersion, 589  
  OSALMissionRevision, 589  
  OSALRevision, 590  
  PSPMajorVersion, 592  
  PSPMinorVersion, 593  
  PSPMissionRevision, 593  
  PSPRevision, 593  
  PerfDataCount, 590  
  PerfDataEnd, 590  
  PerfDataStart, 590  
  PerfDataToWrite, 591  
  PerfFilterMask, 591  
  PerfMode, 591  
  PerfState, 591  
  PerfTriggerCount, 592  
  PerfTriggerMask, 592  
  ProcessorResets, 592  
  RegisteredCoreApps, 593  
  RegisteredExternalApps, 594  
  RegisteredLibs, 594  
  RegisteredTasks, 594  
  ResetSubtype, 594  
  ResetType, 595  
    SysLogBytesUsed, 595  
    SysLogEntries, 595  
    SysLogMode, 595  
    SysLogSize, 596  
CFE\_ES\_HousekeepingTlm\_Payload\_t  
  cfe\_es\_msg.h, 1301  
CFE\_ES\_HousekeepingTlm\_t  
  cfe\_es\_msg.h, 1301  
CFE\_ES\_INIT\_INF\_EID  
  cfe\_es\_events.h, 1250  
CFE\_ES\_INITSTATS\_INF\_EID  
  cfe\_es\_events.h, 1251  
CFE\_ES\_INVALID\_POOL\_HANDLE\_ERR\_EID  
  cfe\_es\_events.h, 1251  
CFE\_ES\_IncrementGenCounter  
  cFE Generic Counter APIs, 290  
CFE\_ES\_IncrementTaskCounter  
  cFE Application Behavior APIs, 247  
CFE\_ES\_LEN\_ERR\_EID  
  cfe\_es\_events.h, 1251  
CFE\_ES\_LIB\_ALREADY\_LOADED  
  cFE Return Code Defines, 212  
CFE\_ES\_LIBID\_UNDEFINED  
  cfe\_es\_api\_typedefs.h, 1155  
CFE\_ES\_LIBID\_C  
  cfe\_es\_api\_typedefs.h, 1155  
CFE\_ES\_LibID\_ToIndex  
  cFE Resource ID APIs, 238  
CFE\_ES\_LibId\_t  
  cfe\_es\_extern\_typedefs.h, 1164  
CFE\_ES\_LibraryEntryFuncPtr\_t  
  cfe\_es\_api\_typedefs.h, 1158  
CFE\_ES\_LogEntryType  
  cfe\_es\_extern\_typedefs.h, 1169  
CFE\_ES\_LogEntryType\_Enum\_t  
  cfe\_es\_extern\_typedefs.h, 1164  
CFE\_ES\_LogMode  
  cfe\_es\_extern\_typedefs.h, 1169  
CFE\_ES\_LogMode\_Enum\_t  
  cfe\_es\_extern\_typedefs.h, 1164  
CFE\_ES\_MEMADDRESS\_C  
  cfe\_es\_extern\_typedefs.h, 1161  
CFE\_ES\_MEMHANDLE\_UNDEFINED  
  cfe\_es\_api\_typedefs.h, 1156  
CFE\_ES\_MEMHANDLE\_C  
  cfe\_es\_api\_typedefs.h, 1156  
CFE\_ES\_MEMOFFSET\_C  
  cfe\_es\_extern\_typedefs.h, 1161  
CFE\_ES\_MEMPOOLBUF\_C  
  cfe\_es\_api\_typedefs.h, 1156  
CFE\_ES\_MEMSTATS\_TLM\_MID  
  cpu1\_msgids.h, 1043  
CFE\_ES\_MID\_ERR\_EID  
  cfe\_es\_events.h, 1252

**CFE\_ES\_MUT\_SEM\_DELETE\_ERR**  
 cFE Return Code Defines, [212](#)  
**CFE\_ES\_Main**  
 cFE Entry/Exit APIs, [241](#)  
**CFE\_ES\_MemAddress\_t**  
`cfe_es_extern_typedefs.h`, [1165](#)  
**CFE\_ES\_MemHandle\_t**  
`cfe_es_extern_typedefs.h`, [1165](#)  
**CFE\_ES\_MemOffset\_t**  
`cfe_es_extern_typedefs.h`, [1165](#)  
**CFE\_ES\_MemPoolBuf\_t**  
`cfe_es_api_typedefs.h`, [1158](#)  
**CFE\_ES\_MemPoolStats**, [596](#)  
 BlockStats, [597](#)  
 CheckErrCtr, [597](#)  
 NumBlocksRequested, [597](#)  
 NumFreeBytes, [598](#)  
 PoolSize, [598](#)  
**CFE\_ES\_MemPoolStats\_t**  
`cfe_es_extern_typedefs.h`, [1166](#)  
**CFE\_ES\_MemStatsTlm**, [598](#)  
 Payload, [599](#)  
 TelemetryHeader, [599](#)  
**CFE\_ES\_MemStatsTlm\_t**  
`cfe_es_msg.h`, [1302](#)  
**CFE\_ES\_NO\_MUTEX**  
`cfe_es_api_typedefs.h`, [1156](#)  
**CFE\_ES\_NO\_RESOURCE\_IDS\_AVAILABLE**  
 cFE Return Code Defines, [213](#)  
**CFE\_ES\_NOOP\_CC**  
`cfe_es_msg.h`, [1279](#)  
**CFE\_ES\_NOOP\_INF\_EID**  
`cfe_es_events.h`, [1252](#)  
**CFE\_ES\_NOT\_IMPLEMENTED**  
 cFE Return Code Defines, [213](#)  
**CFE\_ES\_NoArgsCmd**, [599](#)  
 CommandHeader, [600](#)  
**CFE\_ES\_NoArgsCmd\_t**  
`cfe_es_msg.h`, [1302](#)  
**CFE\_ES\_NoopCmd\_t**  
`cfe_es_msg.h`, [1302](#)  
**CFE\_ES\_ONE\_APP\_EID**  
`cfe_es_events.h`, [1252](#)  
**CFE\_ES\_ONE\_APPID\_ERR\_EID**  
`cfe_es_events.h`, [1253](#)  
**CFE\_ES\_ONE\_ERR\_EID**  
`cfe_es_events.h`, [1253](#)  
**CFE\_ES\_OPERATION\_TIMED\_OUT**  
 cFE Return Code Defines, [213](#)  
**CFE\_ES\_OSCREATE\_ERR\_EID**  
`cfe_es_events.h`, [1253](#)  
**CFE\_ES\_OVER\_WRITE\_SYSLOG\_CC**  
`cfe_es_msg.h`, [1280](#)  
**CFE\_ES\_OneAppTlm**, [600](#)  
 Payload, [601](#)  
 TelemetryHeader, [601](#)  
**CFE\_ES\_OneAppTlm\_Payload**, [601](#)  
`ApplInfo`, [602](#)  
**CFE\_ES\_OneAppTlm\_Payload\_t**  
`cfe_es_msg.h`, [1302](#)  
**CFE\_ES\_OneAppTlm\_t**  
`cfe_es_msg.h`, [1302](#)  
**CFE\_ES\_OverWriteSysLogCmd**, [602](#)  
 CommandHeader, [602](#)  
 Payload, [602](#)  
**CFE\_ES\_OverWriteSysLogCmd\_Payload**, [603](#)  
 Mode, [603](#)  
**CFE\_ES\_OverWriteSysLogCmd\_Payload\_t**  
`cfe_es_msg.h`, [1302](#)  
**CFE\_ES\_OverWriteSysLogCmd\_t**  
`cfe_es_msg.h`, [1303](#)  
**CFE\_ES\_PCR\_ERR1\_EID**  
`cfe_es_events.h`, [1254](#)  
**CFE\_ES\_PCR\_ERR2\_EID**  
`cfe_es_events.h`, [1254](#)  
**CFE\_ES\_PERF\_DATAWRITTEN\_EID**  
`cfe_es_events.h`, [1254](#)  
**CFE\_ES\_PERF\_FILTMSKCMD\_EID**  
`cfe_es_events.h`, [1255](#)  
**CFE\_ES\_PERF\_FILTMSKERR\_EID**  
`cfe_es_events.h`, [1255](#)  
**CFE\_ES\_PERF\_LOG\_ERR\_EID**  
`cfe_es_events.h`, [1255](#)  
**CFE\_ES\_PERF\_STARTCMD\_EID**  
`cfe_es_events.h`, [1256](#)  
**CFE\_ES\_PERF\_STARTCMD\_ERR\_EID**  
`cfe_es_events.h`, [1256](#)  
**CFE\_ES\_PERF\_STARTCMD\_TRIG\_ERR\_EID**  
`cfe_es_events.h`, [1256](#)  
**CFE\_ES\_PERF\_STOPCMD\_EID**  
`cfe_es_events.h`, [1257](#)  
**CFE\_ES\_PERF\_STOPCMD\_ERR2\_EID**  
`cfe_es_events.h`, [1257](#)  
**CFE\_ES\_PERF\_TRIGMSKCMD\_EID**  
`cfe_es_events.h`, [1257](#)  
**CFE\_ES\_PERF\_TRIGMSKERR\_EID**  
`cfe_es_events.h`, [1258](#)  
**CFE\_ES\_POOL\_BLOCK\_INVALID**  
 cFE Return Code Defines, [213](#)  
**CFE\_ES\_PerfLogAdd**  
 cFE Performance Monitor APIs, [285](#)  
**CFE\_ES\_PerfLogEntry**  
 cFE Performance Monitor APIs, [284](#)  
**CFE\_ES\_PerfLogExit**  
 cFE Performance Monitor APIs, [285](#)  
**CFE\_ES\_PoolAlign**, [604](#)  
 LongDouble, [604](#)  
 LongInt, [604](#)

Ptr, 604  
CFE\_ES\_PoolAlign\_t  
  cfe\_es\_api\_typedefs.h, 1158  
CFE\_ES\_PoolCreate  
  cFE Memory Manager APIs, 279  
CFE\_ES\_PoolCreateEx  
  cFE Memory Manager APIs, 280  
CFE\_ES\_PoolCreateNoSem  
  cFE Memory Manager APIs, 281  
CFE\_ES\_PoolDelete  
  cFE Memory Manager APIs, 282  
CFE\_ES\_PoolStatsTlm\_Payload, 605  
  PoolHandle, 605  
  PoolStats, 605  
CFE\_ES\_PoolStatsTlm\_Payload\_t  
  cfe\_es\_msg.h, 1303  
CFE\_ES\_ProcessAsyncEvent  
  cFE Miscellaneous APIs, 268  
CFE\_ES\_PutPoolBuf  
  cFE Memory Manager APIs, 283  
CFE\_ES\_QUERY\_ALL\_CC  
  cfe\_es\_msg.h, 1281  
CFE\_ES\_QUERY\_ALL\_TASKS\_CC  
  cfe\_es\_msg.h, 1282  
CFE\_ES\_QUERY\_ONE\_CC  
  cfe\_es\_msg.h, 1283  
CFE\_ES\_QUEUE\_DELETE\_ERR  
  cFE Return Code Defines, 214  
CFE\_ES\_QueryAllCmd\_t  
  cfe\_es\_msg.h, 1303  
CFE\_ES\_QueryAllTasksCmd\_t  
  cfe\_es\_msg.h, 1303  
CFE\_ES\_QueryOneCmd\_t  
  cfe\_es\_msg.h, 1303  
CFE\_ES\_RELOAD\_APP\_CC  
  cfe\_es\_msg.h, 1284  
CFE\_ES\_RELOAD\_APP\_DBG\_EID  
  cfe\_es\_events.h, 1258  
CFE\_ES\_RELOAD\_APP\_ERR1\_EID  
  cfe\_es\_events.h, 1258  
CFE\_ES\_RELOAD\_APP\_ERR2\_EID  
  cfe\_es\_events.h, 1259  
CFE\_ES\_RELOAD\_APP\_ERR3\_EID  
  cfe\_es\_events.h, 1259  
CFE\_ES\_RELOAD\_APP\_ERR4\_EID  
  cfe\_es\_events.h, 1259  
CFE\_ES\_RELOAD\_APP\_INF\_EID  
  cfe\_es\_events.h, 1260  
CFE\_ES\_RESET\_COUNTERS\_CC  
  cfe\_es\_msg.h, 1285  
CFE\_ES\_RESET\_INF\_EID  
  cfe\_es\_events.h, 1260  
CFE\_ES\_RESET\_PR\_COUNT\_CC  
  cfe\_es\_msg.h, 1286  
CFE\_ES\_RESET\_PR\_COUNT\_EID  
  cfe\_es\_events.h, 1260  
CFE\_ES\_RESTART\_APP\_CC  
  cfe\_es\_msg.h, 1287  
CFE\_ES\_RESTART\_APP\_DBG\_EID  
  cfe\_es\_events.h, 1261  
CFE\_ES\_RESTART\_APP\_ERR1\_EID  
  cfe\_es\_events.h, 1261  
CFE\_ES\_RESTART\_APP\_ERR2\_EID  
  cfe\_es\_events.h, 1261  
CFE\_ES\_RESTART\_APP\_ERR3\_EID  
  cfe\_es\_events.h, 1262  
CFE\_ES\_RESTART\_APP\_ERR4\_EID  
  cfe\_es\_events.h, 1262  
CFE\_ES\_RESTART\_APP\_INF\_EID  
  cfe\_es\_events.h, 1262  
CFE\_ES\_RESTART\_CC  
  cfe\_es\_msg.h, 1288  
CFE\_ES\_RST\_ACCESS\_ERR  
  cFE Return Code Defines, 214  
CFE\_ES\_RegisterCDS  
  cFE Critical Data Store APIs, 273  
CFE\_ES\_RegisterGenCounter  
  cFE Generic Counter APIs, 292  
CFE\_ES\_ReloadApp  
  cFE Application Control APIs, 244  
CFE\_ES\_ReloadAppCmd, 606  
  CommandHeader, 606  
  Payload, 606  
CFE\_ES\_ReloadAppCmd\_t  
  cfe\_es\_msg.h, 1303  
CFE\_ES\_ResetCFE  
  cFE Entry/Exit APIs, 242  
CFE\_ES\_ResetCountersCmd\_t  
  cfe\_es\_msg.h, 1304  
CFE\_ES\_ResetPRCountCmd\_t  
  cfe\_es\_msg.h, 1304  
CFE\_ES.RestartApp  
  cFE Application Control APIs, 244  
CFE\_ES.RestartAppCmd\_t  
  cfe\_es\_msg.h, 1304  
CFE\_ES.RestartCmd, 607  
  CommandHeader, 607  
  Payload, 607  
CFE\_ES.RestartCmd\_Payload, 608  
  RestartType, 608  
CFE\_ES.RestartCmd\_Payload\_t  
  cfe\_es\_msg.h, 1304  
CFE\_ES.RestartCmd\_t  
  cfe\_es\_msg.h, 1304  
CFE\_ES.RestoreFromCDS  
  cFE Critical Data Store APIs, 274  
CFE\_ES.RunLoop  
  cFE Application Behavior APIs, 247

CFE\_ES\_RunStatus  
     cfe\_es\_extern\_typedefs.h, 1170

CFE\_ES\_RunStatus\_Enum\_t  
     cfe\_es\_extern\_typedefs.h, 1166

CFE\_ES\_SEND\_HK\_MID  
     cpu1\_msgids.h, 1043

CFE\_ES\_SEND\_MEM\_POOL\_STATS\_CC  
     cfe\_es\_msg.h, 1289

CFE\_ES\_SET\_MAX\_PR\_COUNT\_CC  
     cfe\_es\_msg.h, 1290

CFE\_ES\_SET\_MAX\_PR\_COUNT\_EID  
     cfe\_es\_events.h, 1263

CFE\_ES\_SET\_PERF\_FILTER\_MASK\_CC  
     cfe\_es\_msg.h, 1291

CFE\_ES\_SET\_PERF\_TRIGGER\_MASK\_CC  
     cfe\_es\_msg.h, 1292

CFE\_ES\_START\_APP\_CC  
     cfe\_es\_msg.h, 1293

CFE\_ES\_START\_ERR\_EID  
     cfe\_es\_events.h, 1263

CFE\_ES\_START\_EXC\_ACTION\_ERR\_EID  
     cfe\_es\_events.h, 1263

CFE\_ES\_START\_INF\_EID  
     cfe\_es\_events.h, 1264

CFE\_ES\_START\_INVALID\_ENTRY\_POINT\_ERR\_EID  
     cfe\_es\_events.h, 1264

CFE\_ES\_START\_INVALID\_FILENAME\_ERR\_EID  
     cfe\_es\_events.h, 1264

CFE\_ES\_START\_NULL\_APP\_NAME\_ERR\_EID  
     cfe\_es\_events.h, 1265

CFE\_ES\_START\_PERF\_DATA\_CC  
     cfe\_es\_msg.h, 1294

CFE\_ES\_START\_PRIORITY\_ERR\_EID  
     cfe\_es\_events.h, 1265

CFE\_ES\_STATIC\_POOL\_TYPE  
     cfe\_es\_api\_typedefs.h, 1156

CFE\_ES\_STOP\_APP\_CC  
     cfe\_es\_msg.h, 1295

CFE\_ES\_STOP\_DBG\_EID  
     cfe\_es\_events.h, 1265

CFE\_ES\_STOP\_ERR1\_EID  
     cfe\_es\_events.h, 1266

CFE\_ES\_STOP\_ERR2\_EID  
     cfe\_es\_events.h, 1266

CFE\_ES\_STOP\_ERR3\_EID  
     cfe\_es\_events.h, 1266

CFE\_ES\_STOP\_INF\_EID  
     cfe\_es\_events.h, 1267

CFE\_ES\_STOP\_PERF\_DATA\_CC  
     cfe\_es\_msg.h, 1296

CFE\_ES\_SYSLOG1\_INF\_EID  
     cfe\_es\_events.h, 1267

CFE\_ES\_SYSLOG2\_EID  
     cfe\_es\_events.h, 1267

CFE\_ES\_SYSLOG2\_ERR\_EID  
     cfe\_es\_events.h, 1268

CFE\_ES\_SYSLOGMODE\_EID  
     cfe\_es\_events.h, 1268

CFE\_ES\_SendMemPoolStatsCmd, 609  
     CommandHeader, 609  
     Payload, 609

CFE\_ES\_SendMemPoolStatsCmd\_Payload, 610  
     Application, 610  
     PoolHandle, 610

CFE\_ES\_SendMemPoolStatsCmd\_Payload\_t  
     cfe\_es\_msg.h, 1304

CFE\_ES\_SendMemPoolStatsCmd\_t  
     cfe\_es\_msg.h, 1305

CFE\_ES\_SetGenCount  
     cFE Generic Counter APIs, 293

CFE\_ES\_SetMaxPRCountCmd, 611  
     CommandHeader, 611  
     Payload, 611

CFE\_ES\_SetMaxPRCountCmd\_Payload, 612  
     MaxPRCount, 612

CFE\_ES\_SetMaxPRCountCmd\_Payload\_t  
     cfe\_es\_msg.h, 1305

CFE\_ES\_SetMaxPRCountCmd\_t  
     cfe\_es\_msg.h, 1305

CFE\_ES\_SetPerfFilterMaskCmd, 612  
     CommandHeader, 613  
     Payload, 613

CFE\_ES\_SetPerfFilterMaskCmd\_Payload, 613  
     FilterMask, 614  
     FilterMaskNum, 614

CFE\_ES\_SetPerfFilterMaskCmd\_Payload\_t  
     cfe\_es\_msg.h, 1305

CFE\_ES\_SetPerfFilterMaskCmd\_t  
     cfe\_es\_msg.h, 1305

CFE\_ES\_SetPerfTrigMaskCmd\_Payload, 615  
     TriggerMask, 616  
     TriggerMaskNum, 616

CFE\_ES\_SetPerfTrigMaskCmd\_Payload\_t  
     cfe\_es\_msg.h, 1306

CFE\_ES\_SetPerfTriggerMaskCmd, 614  
     CommandHeader, 615  
     Payload, 615

CFE\_ES\_SetPerfTriggerMaskCmd\_t  
     cfe\_es\_msg.h, 1305

CFE\_ES\_StackPointer\_t  
     cfe\_es\_api\_typedefs.h, 1159

CFE\_ES\_StartApp, 616  
     CommandHeader, 617  
     Payload, 617

CFE\_ES\_StartAppCmd\_Payload, 617  
     AppEntryPoint, 618  
     AppFileName, 618  
     Application, 618

ExceptionAction, 619  
Priority, 619  
StackSize, 619  
CFE\_ES\_StartAppCmd\_Payload\_t  
  cfe\_es\_msg.h, 1306  
CFE\_ES\_StartAppCmd\_t  
  cfe\_es\_msg.h, 1306  
CFE\_ES\_StartPerfCmd\_Payload, 619  
  TriggerMode, 620  
CFE\_ES\_StartPerfCmd\_Payload\_t  
  cfe\_es\_msg.h, 1306  
CFE\_ES\_StartPerfDataCmd, 620  
  CommandHeader, 621  
  Payload, 621  
CFE\_ES\_StartPerfDataCmd\_t  
  cfe\_es\_msg.h, 1306  
CFE\_ES\_StatusToString  
  cfe\_error.h, 1148  
CFE\_ES\_StopAppCmd\_t  
  cfe\_es\_msg.h, 1306  
CFE\_ES\_StopPerfCmd\_Payload, 621  
  DataFileName, 622  
CFE\_ES\_StopPerfCmd\_Payload\_t  
  cfe\_es\_msg.h, 1307  
CFE\_ES\_StopPerfDataCmd, 622  
  CommandHeader, 623  
  Payload, 623  
CFE\_ES\_StopPerfDataCmd\_t  
  cfe\_es\_msg.h, 1307  
CFE\_ES\_SystemState  
  cfe\_es\_extern\_typedefs.h, 1170  
CFE\_ES\_SystemState\_Enum\_t  
  cfe\_es\_extern\_typedefs.h, 1166  
CFE\_ES\_TASK\_DELETE\_ERR  
  cFE Return Code Defines, 214  
CFE\_ES\_TASK\_STACK\_ALLOCATE  
  cfe\_es\_api\_typedefs.h, 1157  
CFE\_ES\_TASKID\_UNDEFINED  
  cfe\_es\_api\_typedefs.h, 1157  
CFE\_ES\_TASKID\_C  
  cfe\_es\_api\_typedefs.h, 1157  
CFE\_ES\_TASKINFO\_EID  
  cfe\_es\_events.h, 1268  
CFE\_ES\_TASKINFO\_OSCREATE\_ERR\_EID  
  cfe\_es\_events.h, 1269  
CFE\_ES\_TASKINFO\_WR\_ERR\_EID  
  cfe\_es\_events.h, 1269  
CFE\_ES\_TASKINFO\_WRHDR\_ERR\_EID  
  cfe\_es\_events.h, 1269  
CFE\_ES\_TASKWR\_ERR\_EID  
  cfe\_es\_events.h, 1270  
CFE\_ES\_TEST\_LONG\_MASK  
  cfe\_es.h, 1152  
CFE\_ES\_TIMER\_DELETE\_ERR  
  cFE Return Code Defines, 214  
CFE\_ES\_TLM\_POOL\_STATS\_INFO\_EID  
  cfe\_es\_events.h, 1270  
CFE\_ES\_TaskEntryFuncPtr\_t  
  cfe\_es\_api\_typedefs.h, 1159  
CFE\_ES\_TaskID\_ToIndex  
  cFE Resource ID APIs, 239  
CFE\_ES\_TaskId\_t  
  cfe\_es\_extern\_typedefs.h, 1167  
CFE\_ES\_TaskInfo, 623  
  Appld, 624  
  AppName, 624  
  ExecutionCounter, 624  
  Priority, 624  
  Spare, 625  
  StackSize, 625  
  TaskId, 625  
  TaskName, 625  
CFE\_ES\_TaskInfo\_t  
  cfe\_es\_extern\_typedefs.h, 1167  
CFE\_ES\_TaskPriority\_Atom\_t  
  cfe\_es\_extern\_typedefs.h, 1167  
CFE\_ES\_USE\_MUTEX  
  cfe\_es\_api\_typedefs.h, 1157  
CFE\_ES\_VERSION\_INF\_EID  
  cfe\_es\_events.h, 1270  
CFE\_ES\_WRHDR\_ERR\_EID  
  cfe\_es\_events.h, 1271  
CFE\_ES\_WRITE\_CFE\_HDR\_ERR\_EID  
  cfe\_es\_events.h, 1271  
CFE\_ES\_WRITE\_ER\_LOG\_CC  
  cfe\_es\_msg.h, 1297  
CFE\_ES\_WRITE\_SYSLOG\_CC  
  cfe\_es\_msg.h, 1298  
CFE\_ES\_WaitForStartupSync  
  cFE Application Behavior APIs, 249  
CFE\_ES\_WaitForSystemState  
  cFE Application Behavior APIs, 249  
CFE\_ES\_WriteERLogCmd\_t  
  cfe\_es\_msg.h, 1307  
CFE\_ES\_WriteSysLogCmd\_t  
  cfe\_es\_msg.h, 1307  
CFE\_ES\_WriteToSysLog  
  cFE Miscellaneous APIs, 268  
CFE\_EVENTS\_SERVICE  
  cfe\_error.h, 1145  
CFE\_EVS\_ADD\_EVENT\_FILTER\_CC  
  cfe\_evs\_msg.h, 1326  
CFE\_EVS\_ADDFILTER\_EID  
  cfe\_evs\_events.h, 1309  
CFE\_EVS\_APP\_FILTER\_OVERLOAD  
  cFE Return Code Defines, 215  
CFE\_EVS\_APP\_ILLEGAL\_APP\_ID  
  cFE Return Code Defines, 215

**CFE\_EVS\_APP\_NOT\_REGISTERED**  
 cFE Return Code Defines, [215](#)  
**CFE\_EVS\_APP\_SQUELCHED**  
 cFE Return Code Defines, [215](#)  
**CFE\_EVS\_AddEventFilterCmd\_t**  
`cfe_evs_msg.h`, [1348](#)  
**CFE\_EVS\_AppDataCmd\_Payload**, [626](#)  
 AppDataFilename, [626](#)  
**CFE\_EVS\_AppDataCmd\_Payload\_t**  
`cfe_evs_msg.h`, [1348](#)  
**CFE\_EVS\_AppNameBitMaskCmd**, [626](#)  
 CommandHeader, [627](#)  
 Payload, [627](#)  
**CFE\_EVS\_AppNameBitMaskCmd\_Payload**, [627](#)  
 AppName, [628](#)  
 BitMask, [628](#)  
 Spare, [628](#)  
**CFE\_EVS\_AppNameBitMaskCmd\_Payload\_t**  
`cfe_evs_msg.h`, [1349](#)  
**CFE\_EVS\_AppNameBitMaskCmd\_t**  
`cfe_evs_msg.h`, [1349](#)  
**CFE\_EVS\_AppNameCmd**, [629](#)  
 CommandHeader, [629](#)  
 Payload, [629](#)  
**CFE\_EVS\_AppNameCmd\_Payload**, [630](#)  
 AppName, [630](#)  
**CFE\_EVS\_AppNameCmd\_Payload\_t**  
`cfe_evs_msg.h`, [1349](#)  
**CFE\_EVS\_AppNameCmd\_t**  
`cfe_evs_msg.h`, [1349](#)  
**CFE\_EVS\_AppNameEventIDCmd**, [631](#)  
 CommandHeader, [631](#)  
 Payload, [631](#)  
**CFE\_EVS\_AppNameEventIDCmd\_Payload**, [632](#)  
 AppName, [632](#)  
 EventID, [632](#)  
**CFE\_EVS\_AppNameEventIDCmd\_Payload\_t**  
`cfe_evs_msg.h`, [1349](#)  
**CFE\_EVS\_AppNameEventIDCmd\_t**  
`cfe_evs_msg.h`, [1349](#)  
**CFE\_EVS\_AppNameEventIDMaskCmd**, [633](#)  
 CommandHeader, [633](#)  
 Payload, [633](#)  
**CFE\_EVS\_AppNameEventIDMaskCmd\_Payload**, [634](#)  
 AppName, [634](#)  
 EventID, [634](#)  
 Mask, [634](#)  
**CFE\_EVS\_AppNameEventIDMaskCmd\_Payload\_t**  
`cfe_evs_msg.h`, [1350](#)  
**CFE\_EVS\_AppNameEventIDMaskCmd\_t**  
`cfe_evs_msg.h`, [1350](#)  
**CFE\_EVS\_AppTlmData**, [635](#)  
 AppEnableStatus, [635](#)  
 AppID, [635](#)  
**AppMessageSentCounter**, [636](#)  
**AppMessageSquelchedCounter**, [636](#)  
**CFE\_EVS\_AppTlmData\_t**  
`cfe_evs_msg.h`, [1350](#)  
**CFE\_EVS\_BinFilter**, [636](#)  
 EventID, [637](#)  
 Mask, [637](#)  
**CFE\_EVS\_BinFilter\_t**  
`cfe_evs_api_typedefs.h`, [1176](#)  
**CFE\_EVS\_BitMaskCmd**, [637](#)  
 CommandHeader, [638](#)  
 Payload, [638](#)  
**CFE\_EVS\_BitMaskCmd\_Payload**, [638](#)  
 BitMask, [639](#)  
 Spare, [639](#)  
**CFE\_EVS\_BitMaskCmd\_Payload\_t**  
`cfe_evs_msg.h`, [1350](#)  
**CFE\_EVS\_BitMaskCmd\_t**  
`cfe_evs_msg.h`, [1350](#)  
**CFE\_EVS\_CLEAR\_LOG\_CC**  
`cfe_evs_msg.h`, [1327](#)  
**CFE\_EVS\_CMD\_MID**  
`cpu1_msgids.h`, [1043](#)  
**CFE\_EVS\_CRITICAL\_BIT**  
`cfe_evs_msg.h`, [1328](#)  
**CFE\_EVS\_ClearLogCmd\_t**  
`cfe_evs_msg.h`, [1350](#)  
**CFE\_EVS\_DEBUG\_BIT**  
`cfe_evs_msg.h`, [1328](#)  
**CFE\_EVS\_DELETE\_EVENT\_FILTER\_CC**  
`cfe_evs_msg.h`, [1328](#)  
**CFE\_EVS\_DELFILTER\_EID**  
`cfe_evs_events.h`, [1309](#)  
**CFE\_EVS\_DISABLE\_APP\_EVENT\_TYPE\_CC**  
`cfe_evs_msg.h`, [1329](#)  
**CFE\_EVS\_DISABLE\_APP\_EVENTS\_CC**  
`cfe_evs_msg.h`, [1330](#)  
**CFE\_EVS\_DISABLE\_EVENT\_TYPE\_CC**  
`cfe_evs_msg.h`, [1331](#)  
**CFE\_EVS\_DISABLE\_PORTS\_CC**  
`cfe_evs_msg.h`, [1332](#)  
**CFE\_EVS\_DISAPPENTTYPE\_EID**  
`cfe_evs_events.h`, [1310](#)  
**CFE\_EVS\_DISAPPEVT\_EID**  
`cfe_evs_events.h`, [1310](#)  
**CFE\_EVS\_DISEVTTYPE\_EID**  
`cfe_evs_events.h`, [1310](#)  
**CFE\_EVS\_DISPORT\_EID**  
`cfe_evs_events.h`, [1311](#)  
**CFE\_EVS\_DeleteEventFilterCmd\_t**  
`cfe_evs_msg.h`, [1351](#)  
**CFE\_EVS\_DisableAppEventTypeCmd\_t**  
`cfe_evs_msg.h`, [1351](#)  
**CFE\_EVS\_DisableAppEventsCmd\_t**

cfe\_evs\_msg.h, 1351  
CFE\_EVS\_DisableEventTypeCmd\_t  
  cfe\_evs\_msg.h, 1351  
CFE\_EVS\_DisablePortsCmd\_t  
  cfe\_evs\_msg.h, 1351  
CFE\_EVS\_ENAAPPEVT\_EID  
  cfe\_evs\_events.h, 1311  
CFE\_EVS\_ENAAPPEVTTYPE\_EID  
  cfe\_evs\_events.h, 1311  
CFE\_EVS\_ENABLE\_APP\_EVENT\_TYPE\_CC  
  cfe\_evs\_msg.h, 1333  
CFE\_EVS\_ENABLE\_APP\_EVENTS\_CC  
  cfe\_evs\_msg.h, 1334  
CFE\_EVS\_ENABLE\_EVENT\_TYPE\_CC  
  cfe\_evs\_msg.h, 1335  
CFE\_EVS\_ENABLE\_PORTS\_CC  
  cfe\_evs\_msg.h, 1336  
CFE\_EVS\_ENAEVTTYPE\_EID  
  cfe\_evs\_events.h, 1312  
CFE\_EVS\_ENAPORT\_EID  
  cfe\_evs\_events.h, 1312  
CFE\_EVS\_ERR\_APPNOREGS\_EID  
  cfe\_evs\_events.h, 1312  
CFE\_EVS\_ERR\_CC\_EID  
  cfe\_evs\_events.h, 1313  
CFE\_EVS\_ERR\_CRDATFILE\_EID  
  cfe\_evs\_events.h, 1313  
CFE\_EVS\_ERR\_CRLOGFILE\_EID  
  cfe\_evs\_events.h, 1313  
CFE\_EVS\_ERR\_EVTIDNOREGS\_EID  
  cfe\_evs\_events.h, 1314  
CFE\_EVS\_ERR\_ILLAPPIDRANGE\_EID  
  cfe\_evs\_events.h, 1314  
CFE\_EVS\_ERR\_ILLEGALFMTMOD\_EID  
  cfe\_evs\_events.h, 1314  
CFE\_EVS\_ERR\_INVALID\_BITMASK\_EID  
  cfe\_evs\_events.h, 1315  
CFE\_EVS\_ERR\_LOGMODE\_EID  
  cfe\_evs\_events.h, 1315  
CFE\_EVS\_ERR\_MAXREGSFILTER\_EID  
  cfe\_evs\_events.h, 1315  
CFE\_EVS\_ERR\_MSGID\_EID  
  cfe\_evs\_events.h, 1316  
CFE\_EVS\_ERR\_NOAPPIDFOUND\_EID  
  cfe\_evs\_events.h, 1316  
CFE\_EVS\_ERR\_UNREGISTERED\_EVS\_APP  
  cfe\_evs\_events.h, 1316  
CFE\_EVS\_ERR\_WRDATFILE\_EID  
  cfe\_evs\_events.h, 1317  
CFE\_EVS\_ERR\_WRLOGFILE\_EID  
  cfe\_evs\_events.h, 1317  
CFE\_EVS\_ERROR\_BIT  
  cfe\_evs\_msg.h, 1337  
CFE\_EVS\_EVERY\_FOURTH\_ONE  
  cfe\_evs\_api\_typedefs.h, 1174  
CFE\_EVS\_EVERY\_OTHER\_ONE  
  cfe\_evs\_api\_typedefs.h, 1174  
CFE\_EVS\_EVERY\_OTHER\_TWO  
  cfe\_evs\_api\_typedefs.h, 1174  
CFE\_EVS\_EVT\_FILTERED\_EID  
  cfe\_evs\_events.h, 1317  
CFE\_EVS\_EVT\_NOT\_REGISTERED  
  cFE Return Code Defines, 216  
CFE\_EVS\_EnableAppEventCmd\_t  
  cfe\_evs\_msg.h, 1352  
CFE\_EVS\_EnableAppEventsCmd\_t  
  cfe\_evs\_msg.h, 1351  
CFE\_EVS\_EnableEventTypeCmd\_t  
  cfe\_evs\_msg.h, 1352  
CFE\_EVS\_EnablePortsCmd\_t  
  cfe\_evs\_msg.h, 1352  
CFE\_EVS\_EventFilter  
  cfe\_evs\_extern\_typedefs.h, 1178  
CFE\_EVS\_EventFilter\_Enum\_t  
  cfe\_evs\_extern\_typedefs.h, 1177  
CFE\_EVS\_EventOutput  
  cfe\_evs\_extern\_typedefs.h, 1178  
CFE\_EVS\_EventOutput\_Enum\_t  
  cfe\_evs\_extern\_typedefs.h, 1177  
CFE\_EVS\_EventType  
  cfe\_evs\_extern\_typedefs.h, 1180  
CFE\_EVS\_EventType\_Enum\_t  
  cfe\_evs\_extern\_typedefs.h, 1177  
CFE\_EVS\_FILE\_WRITE\_ERROR  
  cFE Return Code Defines, 216  
CFE\_EVS\_FILTER\_MAX\_EID  
  cfe\_evs\_events.h, 1318  
CFE\_EVS\_FIRST\_16\_STOP  
  cfe\_evs\_api\_typedefs.h, 1174  
CFE\_EVS\_FIRST\_32\_STOP  
  cfe\_evs\_api\_typedefs.h, 1174  
CFE\_EVS\_FIRST\_4\_STOP  
  cfe\_evs\_api\_typedefs.h, 1174  
CFE\_EVS\_FIRST\_64\_STOP  
  cfe\_evs\_api\_typedefs.h, 1175  
CFE\_EVS\_FIRST\_8\_STOP  
  cfe\_evs\_api\_typedefs.h, 1175  
CFE\_EVS\_FIRST\_ONE\_STOP  
  cfe\_evs\_api\_typedefs.h, 1175  
CFE\_EVS\_FIRST\_TWO\_STOP  
  cfe\_evs\_api\_typedefs.h, 1175  
CFE\_EVS\_HK\_TLM\_MID  
  cpu1\_msgids.h, 1043  
CFE\_EVS\_HousekeepingTlm, 639  
  Payload, 640  
  TelemetryHeader, 640  
CFE\_EVS\_HousekeepingTlm\_Payload, 640  
  AppData, 641

CommandCounter, 642  
 CommandErrorCounter, 642  
 LogEnabled, 642  
 LogFullFlag, 642  
 LogMode, 643  
 LogOverflowCounter, 643  
 MessageFormatMode, 643  
 MessageSendCounter, 643  
 MessageTruncCounter, 644  
 OutputPort, 644  
 Spare1, 644  
 Spare2, 644  
 Spare3, 645  
 UnregisteredAppCounter, 645  
**CFE\_EVS\_HousekeepingTlm\_Payload\_t**  
 cfe\_evs\_msg.h, 1352  
**CFE\_EVS\_HousekeepingTlm\_t**  
 cfe\_evs\_msg.h, 1352  
**CFE\_EVS\_INFORMATION\_BIT**  
 cfe\_evs\_msg.h, 1338  
**CFE\_EVS\_INVALID\_PARAMETER**  
 cFE Return Code Defines, 216  
**CFE\_EVS\_LEN\_ERR\_EID**  
 cfe\_evs\_events.h, 1318  
**CFE\_EVS\_LOGMODE\_EID**  
 cfe\_evs\_events.h, 1318  
**CFE\_EVS\_LONG\_EVENT\_MSG\_MID**  
 cpu1\_msgids.h, 1043  
**CFE\_EVS\_LogFileCmd\_Payload**, 645  
 LogFilename, 646  
**CFE\_EVS\_LogFileCmd\_Payload\_t**  
 cfe\_evs\_msg.h, 1352  
**CFE\_EVS\_LogMode**  
 cfe\_evs\_extern\_typedefs.h, 1180  
**CFE\_EVS\_LogMode\_Enum\_t**  
 cfe\_evs\_extern\_typedefs.h, 1177  
**CFE\_EVS\_LongEventTlm**, 646  
 Payload, 647  
 TelemetryHeader, 647  
**CFE\_EVS\_LongEventTlm\_Payload**, 647  
 Message, 648  
 PacketID, 648  
 Spare1, 648  
 Spare2, 648  
**CFE\_EVS\_LongEventTlm\_Payload\_t**  
 cfe\_evs\_msg.h, 1353  
**CFE\_EVS\_LongEventTlm\_t**  
 cfe\_evs\_msg.h, 1353  
**CFE\_EVS\_MsgFormat**  
 cfe\_evs\_extern\_typedefs.h, 1180  
**CFE\_EVS\_MsgFormat\_Enum\_t**  
 cfe\_evs\_extern\_typedefs.h, 1178  
**CFE\_EVS\_NO\_FILTER**  
 cfe\_evs\_api\_typedefs.h, 1175  
**CFE\_EVS\_NOOP\_CC**  
 cfe\_evs\_msg.h, 1338  
**CFE\_EVS\_NOOP\_EID**  
 cfe\_evs\_events.h, 1319  
**CFE\_EVS\_NOT\_IMPLEMENTED**  
 cFE Return Code Defines, 216  
**CFE\_EVS\_NoArgsCmd**, 649  
 CommandHeader, 649  
**CFE\_EVS\_NoArgsCmd\_t**  
 cfe\_evs\_msg.h, 1353  
**CFE\_EVS\_NoopCmd\_t**  
 cfe\_evs\_msg.h, 1353  
**CFE\_EVS\_PORT1\_BIT**  
 cfe\_evs\_msg.h, 1338  
**CFE\_EVS\_PORT2\_BIT**  
 cfe\_evs\_msg.h, 1339  
**CFE\_EVS\_PORT3\_BIT**  
 cfe\_evs\_msg.h, 1339  
**CFE\_EVS\_PORT4\_BIT**  
 cfe\_evs\_msg.h, 1339  
**CFE\_EVS\_PacketID\_t**  
 cfe\_evs\_msg.h, 1353  
**CFE\_EVS\_PacketID**, 649  
 AppName, 650  
 EventID, 650  
 EventType, 650  
 ProcessorID, 650  
 SpacecraftID, 651  
**CFE\_EVS\_RESET\_ALL\_FILTERS\_CC**  
 cfe\_evs\_msg.h, 1339  
**CFE\_EVS\_RESET\_APP\_COUNTER\_CC**  
 cfe\_evs\_msg.h, 1340  
**CFE\_EVS\_RESET\_AREA\_POINTER**  
 cFE Return Code Defines, 217  
**CFE\_EVS\_RESET\_COUNTERS\_CC**  
 cfe\_evs\_msg.h, 1341  
**CFE\_EVS\_RESET\_FILTER\_CC**  
 cfe\_evs\_msg.h, 1342  
**CFE\_EVS\_RSTALLFILTER\_EID**  
 cfe\_evs\_events.h, 1319  
**CFE\_EVS\_RSTCNT\_EID**  
 cfe\_evs\_events.h, 1319  
**CFE\_EVS\_RSTEVCNT\_EID**  
 cfe\_evs\_events.h, 1320  
**CFE\_EVS\_RSTFILTER\_EID**  
 cfe\_evs\_events.h, 1320  
**CFE\_EVS\_Register**  
 cFE Registration APIs, 295  
**CFE\_EVS\_ResetAllFilters**  
 cFE Reset Event Filter APIs, 302  
**CFE\_EVS\_ResetAllFiltersCmd\_t**  
 cfe\_evs\_msg.h, 1353  
**CFE\_EVS\_ResetAppCounterCmd\_t**  
 cfe\_evs\_msg.h, 1353

CFE\_EVS\_ResetCountersCmd\_t  
  cfe\_evs\_msg.h, 1354

CFE\_EVS\_ResetFilter  
  cFE Reset Event Filter APIs, 302

CFE\_EVS\_ResetFilterCmd\_t  
  cfe\_evs\_msg.h, 1354

CFE\_EVS\_SEND\_HK\_MID  
  cpu1\_msgids.h, 1044

CFE\_EVS\_SET\_EVENT\_FORMAT\_MODE\_CC  
  cfe\_evs\_msg.h, 1343

CFE\_EVS\_SET\_FILTER\_CC  
  cfe\_evs\_msg.h, 1344

CFE\_EVS\_SET\_LOG\_MODE\_CC  
  cfe\_evs\_msg.h, 1345

CFE\_EVS\_SETEVTFMTMOD\_EID  
  cfe\_evs\_events.h, 1320

CFE\_EVS\_SETFILTERMSK\_EID  
  cfe\_evs\_events.h, 1321

CFE\_EVS\_SHORT\_EVENT\_MSG\_MID  
  cpu1\_msgids.h, 1044

CFE\_EVS\_SQUELCHED\_ERR\_EID  
  cfe\_evs\_events.h, 1321

CFE\_EVS\_STARTUP\_EID  
  cfe\_evs\_events.h, 1321

CFE\_EVS\_Send  
  cfe\_evs.h, 1171

CFE\_EVS\_SendCrit  
  cfe\_evs.h, 1172

CFE\_EVS\_SendDbg  
  cfe\_evs.h, 1172

CFE\_EVS\_SendErr  
  cfe\_evs.h, 1172

CFE\_EVS\_SendEvent  
  cFE Send Event APIs, 297

CFE\_EVS\_SendEventWithAppID  
  cFE Send Event APIs, 298

CFE\_EVS\_SendInfo  
  cfe\_evs.h, 1172

CFE\_EVS\_SendTimedEvent  
  cFE Send Event APIs, 300

CFE\_EVS\_SetEventFormatCode\_Payload, 651  
  MsgFormat, 652  
  Spare, 652

CFE\_EVS\_SetEventFormatMode\_Payload\_t  
  cfe\_evs\_msg.h, 1354

CFE\_EVS\_SetEventFormatModeCmd, 652  
  CommandHeader, 653  
  Payload, 653

CFE\_EVS\_SetEventFormatModeCmd\_t  
  cfe\_evs\_msg.h, 1354

CFE\_EVS\_SetFilterCmd\_t  
  cfe\_evs\_msg.h, 1354

CFE\_EVS\_SetLogMode\_Payload, 653  
  LogMode, 654

            Spare, 654

CFE\_EVS\_SetLogMode\_Payload\_t  
  cfe\_evs\_msg.h, 1354

CFE\_EVS\_SetLogModeCmd, 654  
  CommandHeader, 655  
  Payload, 655

CFE\_EVS\_SetLogModeCmd\_t  
  cfe\_evs\_msg.h, 1355

CFE\_EVS\_ShortEventTlm, 655  
  Payload, 655

CFE\_EVS\_ShortEventTlm\_Payload, 656  
  PacketID, 656

CFE\_EVS\_ShortEventTlm\_Payload\_t  
  cfe\_evs\_msg.h, 1355

CFE\_EVS\_ShortEventTlm\_t  
  cfe\_evs\_msg.h, 1355

CFE\_EVS\_UNKNOWN\_FILTER  
  cFE Return Code Defines, 217

CFE\_EVS\_WRDAT\_EID  
  cfe\_evs\_events.h, 1322

CFE\_EVS\_WRITE\_APP\_DATA\_FILE\_CC  
  cfe\_evs\_msg.h, 1346

CFE\_EVS\_WRITE\_LOG\_DATA\_FILE\_CC  
  cfe\_evs\_msg.h, 1347

CFE\_EVS\_WRLOG\_EID  
  cfe\_evs\_events.h, 1322

CFE\_EVS\_WriteAppDataFileCmd, 657  
  CommandHeader, 657  
  Payload, 657

CFE\_EVS\_WriteAppDataFileCmd\_t  
  cfe\_evs\_msg.h, 1355

CFE\_EVS\_WriteLogFileCmd, 658  
  CommandHeader, 658  
  Payload, 658

CFE\_EVS\_WriteLogFileCmd\_t  
  cfe\_evs\_msg.h, 1355

CFE\_EXECUTIVE\_SERVICE  
  cfe\_error.h, 1145

CFE\_FILE\_SERVICE  
  cfe\_error.h, 1145

CFE\_FS\_BAD\_ARGUMENT  
  cFE Return Code Defines, 217

CFE\_FS\_BackgroundFileDumplIsPending  
  cFE File Utility APIs, 309

CFE\_FS\_BackgroundFileDumpRequest  
  cFE File Utility APIs, 310

CFE\_FS\_ExtractFilenameFromPath  
  cFE File Utility APIs, 310

CFE\_FS\_FILE\_CONTENT\_ID  
  cfe\_fs\_extern\_typedefs.h, 1186

CFE\_FS\_FNAME\_TOO\_LONG  
  cFE Return Code Defines, 217

CFE\_FS\_FileCategory\_t

cfe\_fs\_api\_typedefs.h, 1184  
CFE\_FS\_FileWriteEvent\_t  
    cfe\_fs\_api\_typedefs.h, 1185  
CFE\_FS\_FileWriteGetData\_t  
    cfe\_fs\_api\_typedefs.h, 1183  
CFE\_FS\_FileWriteMetaData, 659  
    Description, 659  
    FileName, 659  
    FileSubType, 660  
    GetData, 660  
    IsPending, 660  
    OnEvent, 660  
CFE\_FS\_FileWriteMetaData\_t  
    cfe\_fs\_api\_typedefs.h, 1183  
CFE\_FS\_FileWriteOnEvent\_t  
    cfe\_fs\_api\_typedefs.h, 1183  
CFE\_FS\_GetDefaultExtension  
    cFE File Utility APIs, 311  
CFE\_FS\_GetDefaultMountPoint  
    cFE File Utility APIs, 312  
CFE\_FS\_HDR\_DESC\_MAX\_LEN  
    cfe\_fs\_extern\_typedefs.h, 1186  
CFE\_FS\_Header, 661  
    ApplicationID, 661  
    ContentType, 661  
    Description, 662  
    Length, 662  
    ProcessorID, 662  
    SpacecraftID, 662  
    SubType, 662  
    TimeSeconds, 663  
    TimeSubSeconds, 663  
CFE\_FS\_Header\_t  
    cfe\_fs\_extern\_typedefs.h, 1186  
CFE\_FS\_INVALID\_PATH  
    cFE Return Code Defines, 218  
CFE\_FS\_InitHeader  
    cFE File Header Management APIs, 304  
CFE\_FS\_NOT\_IMPLEMENTED  
    cFE Return Code Defines, 218  
CFE\_FS\_ParseInputFileName  
    cFE File Utility APIs, 312  
CFE\_FS\_ParseInputFileNameEx  
    cFE File Utility APIs, 313  
CFE\_FS\_ReadHeader  
    cFE File Header Management APIs, 304  
CFE\_FS\_SetTimestamp  
    cFE File Header Management APIs, 305  
CFE\_FS\_SubType  
    cfe\_fs\_extern\_typedefs.h, 1187  
CFE\_FS\_SubType\_Enum\_t  
    cfe\_fs\_extern\_typedefs.h, 1186  
CFE\_FS\_WriteHeader  
    cFE File Header Management APIs, 306

CFE\_GENERIC\_SERVICE  
    cfe\_error.h, 1145  
CFE\_HH\_INDEX  
    ds\_file.c, 936  
CFE\_MAJOR\_VERSION  
    cfe\_version.h, 1237  
CFE\_MAKE\_BIG16  
    cfe\_endian.h, 1138  
CFE\_MAKE\_BIG32  
    cfe\_endian.h, 1138  
CFE\_MINOR\_VERSION  
    cfe\_version.h, 1237  
CFE\_MISSION\_ES\_APP\_TLM\_MSG  
    sample\_mission\_cfg.h, 1108  
CFE\_MISSION\_ES\_CDS\_MAX\_FULL\_NAME\_LEN  
    sample\_mission\_cfg.h, 1108  
CFE\_MISSION\_ES\_CDS\_MAX\_NAME\_LENGTH  
    sample\_mission\_cfg.h, 1109  
CFE\_MISSION\_ES\_CMD\_MSG  
    sample\_mission\_cfg.h, 1109  
CFE\_MISSION\_ES\_CRC\_16  
    sample\_mission\_cfg.h, 1110  
CFE\_MISSION\_ES\_CRC\_32  
    sample\_mission\_cfg.h, 1110  
CFE\_MISSION\_ES\_CRC\_8  
    sample\_mission\_cfg.h, 1110  
CFE\_MISSION\_ES\_DEFAULT\_CRC  
    sample\_mission\_cfg.h, 1110  
CFE\_MISSION\_ES\_HK\_TLM\_MSG  
    sample\_mission\_cfg.h, 1110  
CFE\_MISSION\_ES\_MAIN\_PERF\_ID  
    sample\_perfids.h, 1128  
CFE\_MISSION\_ES\_MAX\_APPLICATIONS  
    sample\_mission\_cfg.h, 1111  
CFE\_MISSION\_ES\_MEMSTATS\_TLM\_MSG  
    sample\_mission\_cfg.h, 1111  
CFE\_MISSION\_ES\_PERF\_EXIT\_BIT  
    sample\_perfids.h, 1128  
CFE\_MISSION\_ES\_PERF\_MAX\_IDS  
    sample\_mission\_cfg.h, 1111  
CFE\_MISSION\_ES\_POOL\_MAX\_BUCKETS  
    sample\_mission\_cfg.h, 1112  
CFE\_MISSION\_ES\_SEND\_HK\_MSG  
    sample\_mission\_cfg.h, 1112  
CFE\_MISSION\_ES\_EVS\_CMD\_MSG  
    sample\_mission\_cfg.h, 1113  
CFE\_MISSION\_ES\_HK\_TLM\_MSG  
    sample\_mission\_cfg.h, 1113  
CFE\_MISSION\_ES\_LONG\_EVENT\_MSG\_MSG  
    sample\_mission\_cfg.h, 1113  
CFE\_MISSION\_ES\_MAIN\_PERF\_ID  
    sample\_perfids.h, 1128  
CFE\_MISSION\_ES\_MAX\_MESSAGE\_LENGTH  
    sample\_mission\_cfg.h, 1113

CFE\_MISSION\_EVS\_SEND\_HK\_MSG  
sample\_mission\_cfg.h, 1114

CFE\_MISSION\_EVS\_SHORT\_EVENT\_MSG\_MSG  
sample\_mission\_cfg.h, 1114

CFE\_MISSION\_MAX\_API\_LEN  
sample\_mission\_cfg.h, 1114

CFE\_MISSION\_MAX\_FILE\_LEN  
sample\_mission\_cfg.h, 1114

CFE\_MISSION\_MAX\_PATH\_LEN  
sample\_mission\_cfg.h, 1115

CFE\_MISSION\_REV  
cfe\_version.h, 1237

CFE\_MISSION\_SB\_ALLSUBS\_TLM\_MSG  
sample\_mission\_cfg.h, 1115

CFE\_MISSION\_SB\_CMD\_MSG  
sample\_mission\_cfg.h, 1116

CFE\_MISSION\_SB\_HK\_TLM\_MSG  
sample\_mission\_cfg.h, 1116

CFE\_MISSION\_SB\_MAIN\_PERF\_ID  
sample\_perfids.h, 1128

CFE\_MISSION\_SB\_MAX\_PIPES  
sample\_mission\_cfg.h, 1116

CFE\_MISSION\_SB\_MAX\_SB\_MSG\_SIZE  
sample\_mission\_cfg.h, 1116

CFE\_MISSION\_SB\_MSG\_LIM\_PERF\_ID  
sample\_perfids.h, 1128

CFE\_MISSION\_SB\_ONESUB\_TLM\_MSG  
sample\_mission\_cfg.h, 1117

CFE\_MISSION\_SB\_PIPE\_OFLOW\_PERF\_ID  
sample\_perfids.h, 1129

CFE\_MISSION\_SB\_SEND\_HK\_MSG  
sample\_mission\_cfg.h, 1117

CFE\_MISSION\_SB\_STATS\_TLM\_MSG  
sample\_mission\_cfg.h, 1117

CFE\_MISSION\_SB\_SUB\_RPT\_CTRL\_MSG  
sample\_mission\_cfg.h, 1117

CFE\_MISSION\_TBL\_CMD\_MSG  
sample\_mission\_cfg.h, 1118

CFE\_MISSION\_TBL\_HK\_TLM\_MSG  
sample\_mission\_cfg.h, 1118

CFE\_MISSION\_TBL\_MAIN\_PERF\_ID  
sample\_perfids.h, 1129

CFE\_MISSION\_TBL\_MAX\_FULL\_NAME\_LEN  
sample\_mission\_cfg.h, 1118

CFE\_MISSION\_TBL\_MAX\_NAME\_LENGTH  
sample\_mission\_cfg.h, 1118

CFE\_MISSION\_TBL\_REG\_TLM\_MSG  
sample\_mission\_cfg.h, 1119

CFE\_MISSION\_TBL\_SEND\_HK\_MSG  
sample\_mission\_cfg.h, 1119

CFE\_MISSION\_TEST\_CMD\_MSG  
sample\_mission\_cfg.h, 1119

CFE\_MISSION\_TEST\_HK\_TLM\_MSG  
sample\_mission\_cfg.h, 1119

CFE\_MISSION\_TIME\_1HZ\_CMD\_MSG  
sample\_mission\_cfg.h, 1120

CFE\_MISSION\_TIME\_AT\_TONE\_WAS  
sample\_mission\_cfg.h, 1120

CFE\_MISSION\_TIME\_AT\_TONE\_WILL\_BE  
sample\_mission\_cfg.h, 1120

CFE\_MISSION\_TIME\_CFG\_DEFAULT\_TAI  
sample\_mission\_cfg.h, 1120

CFE\_MISSION\_TIME\_CFG\_DEFAULT\_UTC  
sample\_mission\_cfg.h, 1121

CFE\_MISSION\_TIME\_CFG\_FAKE\_TONE  
sample\_mission\_cfg.h, 1121

CFE\_MISSION\_TIME\_CMD\_MSG  
sample\_mission\_cfg.h, 1121

CFE\_MISSION\_TIME\_DATA\_CMD\_MSG  
sample\_mission\_cfg.h, 1122

CFE\_MISSION\_TIME\_DEF\_DELAY\_SECS  
sample\_mission\_cfg.h, 1122

CFE\_MISSION\_TIME\_DEF\_DELAY\_SUBS  
sample\_mission\_cfg.h, 1122

CFE\_MISSION\_TIME\_DEF\_LEAPS  
sample\_mission\_cfg.h, 1122

CFE\_MISSION\_TIME\_DEF\_MET\_SECS  
sample\_mission\_cfg.h, 1122

CFE\_MISSION\_TIME\_DEF\_MET\_SUBS  
sample\_mission\_cfg.h, 1123

CFE\_MISSION\_TIME\_DEF\_STCF\_SECS  
sample\_mission\_cfg.h, 1123

CFE\_MISSION\_TIME\_DEF\_STCF\_SUBS  
sample\_mission\_cfg.h, 1123

CFE\_MISSION\_TIME\_DIAG\_TLM\_MSG  
sample\_mission\_cfg.h, 1123

CFE\_MISSION\_TIME\_EPOCH\_DAY  
sample\_mission\_cfg.h, 1124

CFE\_MISSION\_TIME\_EPOCH\_HOUR  
sample\_mission\_cfg.h, 1124

CFE\_MISSION\_TIME\_EPOCH\_MICROS  
sample\_mission\_cfg.h, 1124

CFE\_MISSION\_TIME\_EPOCH\_MINUTE  
sample\_mission\_cfg.h, 1124

CFE\_MISSION\_TIME\_EPOCH\_SECOND  
sample\_mission\_cfg.h, 1124

CFE\_MISSION\_TIME\_EPOCH\_YEAR  
sample\_mission\_cfg.h, 1124

CFE\_MISSION\_TIME\_FS\_FACTOR  
sample\_mission\_cfg.h, 1125

CFE\_MISSION\_TIME\_HK\_TLM\_MSG  
sample\_mission\_cfg.h, 1125

CFE\_MISSION\_TIME\_LOCAL1HZISR\_PERF\_ID  
sample\_perfids.h, 1129

CFE\_MISSION\_TIME\_LOCAL1HZTASK\_PERF\_ID  
sample\_perfids.h, 1129

CFE\_MISSION\_TIME\_MAIN\_PERF\_ID  
sample\_perfids.h, 1129

**CFE\_MISSION\_TIME\_MAX\_ELAPSED**  
 sample\_mission\_cfg.h, 1126  
**CFE\_MISSION\_TIME\_MIN\_ELAPSED**  
 sample\_mission\_cfg.h, 1126  
**CFE\_MISSION\_TIME\_SEND\_CMD\_MSG**  
 sample\_mission\_cfg.h, 1126  
**CFE\_MISSION\_TIME\_SEND\_HK\_MSG**  
 sample\_mission\_cfg.h, 1126  
**CFE\_MISSION\_TIME\_SEDMET\_PERF\_ID**  
 sample\_perfids.h, 1130  
**CFE\_MISSION\_TIME\_TONE1HZISR\_PERF\_ID**  
 sample\_perfids.h, 1130  
**CFE\_MISSION\_TIME\_TONE1HZTASK\_PERF\_ID**  
 sample\_perfids.h, 1130  
**CFE\_MISSION\_TIME\_TONE\_CMD\_MSG**  
 sample\_mission\_cfg.h, 1127  
**CFE\_MM\_INDEX**  
 ds\_file.c, 937  
**CFE\_MSG\_Apld\_t**  
 cfe\_msg\_api\_typedefs.h, 1192  
**CFE\_MSG\_BAD\_ARGUMENT**  
 cfe\_msg\_api\_typedefs.h, 1192  
**CFE\_MSG\_Checksum\_t**  
 cfe\_msg\_api\_typedefs.h, 1193  
**CFE\_MSG\_CommandHeader\_t**  
 cfe\_msg\_api\_typedefs.h, 1193  
**CFE\_MSG\_EDSVersion\_t**  
 cfe\_msg\_api\_typedefs.h, 1193  
**CFE\_MSG\_Endian**  
 cfe\_msg\_api\_typedefs.h, 1195  
**CFE\_MSG\_Endian\_t**  
 cfe\_msg\_api\_typedefs.h, 1193  
**CFE\_MSG\_FcnCode\_t**  
 cfe\_msg\_api\_typedefs.h, 1193  
**CFE\_MSG\_GenerateChecksum**  
 cFE Message Secondary Header APIs, 334  
**CFE\_MSG\_GetApld**  
 cFE Message Primary Header APIs, 316  
**CFE\_MSG\_GetEDSVersion**  
 cFE Message Extended Header APIs, 327  
**CFE\_MSG\_GetEndian**  
 cFE Message Extended Header APIs, 328  
**CFE\_MSG\_GetFcnCode**  
 cFE Message Secondary Header APIs, 335  
**CFE\_MSG\_GetHasSecondaryHeader**  
 cFE Message Primary Header APIs, 317  
**CFE\_MSG\_GetHeaderVersion**  
 cFE Message Primary Header APIs, 318  
**CFE\_MSG\_GetMsgId**  
 cFE Message Id APIs, 339  
**CFE\_MSG\_GetMsgTime**  
 cFE Message Secondary Header APIs, 335  
**CFE\_MSG\_GetNextSequenceCount**  
 cFE Message Primary Header APIs, 318  
**CFE\_MSG\_GetPlaybackFlag**  
 cFE Message Extended Header APIs, 328  
**CFE\_MSG\_GetSegmentationFlag**  
 cFE Message Primary Header APIs, 319  
**CFE\_MSG\_GetSequenceCount**  
 cFE Message Primary Header APIs, 319  
**CFE\_MSG.GetSize**  
 cFE Message Primary Header APIs, 320  
**CFE\_MSG\_GetSubsystem**  
 cFE Message Extended Header APIs, 329  
**CFE\_MSG\_GetSystem**  
 cFE Message Extended Header APIs, 330  
**CFE\_MSG.GetType**  
 cFE Message Primary Header APIs, 321  
**CFE\_MSG.GetTypeFromMsgId**  
 cFE Message Id APIs, 340  
**CFE\_MSG\_HeaderVersion\_t**  
 cfe\_msg\_api\_typedefs.h, 1194  
**CFE\_MSG\_Init**  
 cFE Generic Message APIs, 315  
**CFE\_MSG\_Message\_t**  
 cfe\_msg\_api\_typedefs.h, 1194  
**CFE\_MSG\_NOT\_IMPLEMENTED**  
 cfe\_msg\_api\_typedefs.h, 1192  
**CFE\_MSG\_PlaybackFlag**  
 cfe\_msg\_api\_typedefs.h, 1196  
**CFE\_MSG\_PlaybackFlag\_t**  
 cfe\_msg\_api\_typedefs.h, 1194  
**CFE\_MSG\_SegmentationFlag**  
 cfe\_msg\_api\_typedefs.h, 1196  
**CFE\_MSG\_SegmentationFlag\_t**  
 cfe\_msg\_api\_typedefs.h, 1194  
**CFE\_MSG\_SequenceCount\_t**  
 cfe\_msg\_api\_typedefs.h, 1194  
**CFE\_MSG\_SetApld**  
 cFE Message Primary Header APIs, 321  
**CFE\_MSG\_SetEDSVersion**  
 cFE Message Extended Header APIs, 330  
**CFE\_MSG\_SetEndian**  
 cFE Message Extended Header APIs, 331  
**CFE\_MSG\_SetFcnCode**  
 cFE Message Secondary Header APIs, 336  
**CFE\_MSG\_SetHasSecondaryHeader**  
 cFE Message Primary Header APIs, 322  
**CFE\_MSG\_SetHeaderVersion**  
 cFE Message Primary Header APIs, 323  
**CFE\_MSG\_SetMsgId**  
 cFE Message Id APIs, 340  
**CFE\_MSG\_SetMsgTime**  
 cFE Message Secondary Header APIs, 337  
**CFE\_MSG\_SetPlaybackFlag**  
 cFE Message Extended Header APIs, 332  
**CFE\_MSG\_SetSegmentationFlag**  
 cFE Message Primary Header APIs, 323

CFE\_MSG\_SetSequenceCount  
  cFE Message Primary Header APIs, 324

CFE\_MSG\_SetSize  
  cFE Message Primary Header APIs, 325

CFE\_MSG\_SetSubsystem  
  cFE Message Extended Header APIs, 332

CFE\_MSG\_SetSystem  
  cFE Message Extended Header APIs, 333

CFE\_MSG\_SetType  
  cFE Message Primary Header APIs, 325

CFE\_MSG\_Size\_t  
  `cfe_msg_api_typedefs.h`, 1195

CFE\_MSG\_Subsystem\_t  
  `cfe_msg_api_typedefs.h`, 1195

CFE\_MSG\_System\_t  
  `cfe_msg_api_typedefs.h`, 1195

CFE\_MSG\_TelemetryHeader\_t  
  `cfe_msg_api_typedefs.h`, 1195

CFE\_MSG\_Type  
  `cfe_msg_api_typedefs.h`, 1196

CFE\_MSG\_Type\_t  
  `cfe_msg_api_typedefs.h`, 1195

CFE\_MSG\_ValidateChecksum  
  cFE Message Secondary Header APIs, 338

CFE\_MSG\_WRONG\_MSG\_TYPE  
  `cfe_msg_api_typedefs.h`, 1192

CFE\_PLATFORM\_CMD\_MID\_BASE\_GLOB  
  `cpu1_msgids.h`, 1044

CFE\_PLATFORM\_CMD\_MID\_BASE  
  `cpu1_msgids.h`, 1044

CFE\_PLATFORM\_CORE\_MAX\_STARTUP\_MSEC  
  `cpu1_platform_cfg.h`, 1052

CFE\_PLATFORM\_ENDIAN  
  `cpu1_platform_cfg.h`, 1053

CFE\_PLATFORM\_ES\_APP\_KILL\_TIMEOUT  
  `cpu1_platform_cfg.h`, 1053

CFE\_PLATFORM\_ES\_APP\_SCAN\_RATE  
  `cpu1_platform_cfg.h`, 1054

CFE\_PLATFORM\_ES\_CDS\_MAX\_BLOCK\_SIZE  
  `cpu1_platform_cfg.h`, 1054

CFE\_PLATFORM\_ES\_CDS\_MAX\_NUM\_ENTRIES  
  `cpu1_platform_cfg.h`, 1055

CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_01  
  `cpu1_platform_cfg.h`, 1055

CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_02  
  `cpu1_platform_cfg.h`, 1055

CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_03  
  `cpu1_platform_cfg.h`, 1056

CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_04  
  `cpu1_platform_cfg.h`, 1056

CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_05  
  `cpu1_platform_cfg.h`, 1056

CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_06  
  `cpu1_platform_cfg.h`, 1056

CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_07  
  `cpu1_platform_cfg.h`, 1056

CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_08  
  `cpu1_platform_cfg.h`, 1056

CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_09  
  `cpu1_platform_cfg.h`, 1057

CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_10  
  `cpu1_platform_cfg.h`, 1057

CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_11  
  `cpu1_platform_cfg.h`, 1057

CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_12  
  `cpu1_platform_cfg.h`, 1057

CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_13  
  `cpu1_platform_cfg.h`, 1057

CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_14  
  `cpu1_platform_cfg.h`, 1057

CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_15  
  `cpu1_platform_cfg.h`, 1058

CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_16  
  `cpu1_platform_cfg.h`, 1058

CFE\_PLATFORM\_ES\_CDS\_SIZE  
  `cpu1_platform_cfg.h`, 1058

CFE\_PLATFORM\_ES\_DEFAULT\_APP\_LOG\_FILE  
  `cpu1_platform_cfg.h`, 1058

CFE\_PLATFORM\_ES\_DEFAULT\_CDS\_REG\_DUMP\_←  
  FILE  
  `cpu1_platform_cfg.h`, 1059

CFE\_PLATFORM\_ES\_DEFAULT\_ER\_LOG\_FILE  
  `cpu1_platform_cfg.h`, 1059

CFE\_PLATFORM\_ES\_DEFAULT\_PERF\_DUMP\_FILE←  
  NAME  
  `cpu1_platform_cfg.h`, 1059

CFE\_PLATFORM\_ES\_DEFAULT\_POR\_SYSLOG\_MO←  
  DE  
  `cpu1_platform_cfg.h`, 1060

CFE\_PLATFORM\_ES\_DEFAULT\_PR\_SYSLOG\_MODE  
  `cpu1_platform_cfg.h`, 1060

CFE\_PLATFORM\_ES\_DEFAULT\_STACK\_SIZE  
  `cpu1_platform_cfg.h`, 1061

CFE\_PLATFORM\_ES\_DEFAULT\_SYSLOG\_FILE  
  `cpu1_platform_cfg.h`, 1061

CFE\_PLATFORM\_ES\_DEFAULT\_TASK\_LOG\_FILE  
  `cpu1_platform_cfg.h`, 1062

CFE\_PLATFORM\_ES\_ER\_LOG\_ENTRIES  
  `cpu1_platform_cfg.h`, 1062

CFE\_PLATFORM\_ES\_ER\_LOG\_MAX\_CONTEXT\_SIZE  
  `cpu1_platform_cfg.h`, 1063

CFE\_PLATFORM\_ES\_MAX\_APPLICATIONS  
  `cpu1_platform_cfg.h`, 1063

CFE\_PLATFORM\_ES\_MAX\_BLOCK\_SIZE  
  `cpu1_platform_cfg.h`, 1063

CFE\_PLATFORM\_ES\_MAX\_GEN\_COUNTERS  
  `cpu1_platform_cfg.h`, 1064

CFE\_PLATFORM\_ES\_MAX\_LIBRARIES

CFE\_PLATFORM\_ES\_PERF\_ENTRIES\_BTWN\_DLYS  
 cpu1\_platform\_cfg.h, 1071  
 CFE\_PLATFORM\_ES\_MAX\_MEMORY\_POOLS  
 cpu1\_platform\_cfg.h, 1064  
 CFE\_PLATFORM\_ES\_MAX\_PROCESSOR\_RESETS  
 cpu1\_platform\_cfg.h, 1065  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_01  
 cpu1\_platform\_cfg.h, 1065  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_02  
 cpu1\_platform\_cfg.h, 1066  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_03  
 cpu1\_platform\_cfg.h, 1066  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_04  
 cpu1\_platform\_cfg.h, 1066  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_05  
 cpu1\_platform\_cfg.h, 1066  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_06  
 cpu1\_platform\_cfg.h, 1067  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_07  
 cpu1\_platform\_cfg.h, 1067  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_08  
 cpu1\_platform\_cfg.h, 1067  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_09  
 cpu1\_platform\_cfg.h, 1067  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_10  
 cpu1\_platform\_cfg.h, 1067  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_11  
 cpu1\_platform\_cfg.h, 1067  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_12  
 cpu1\_platform\_cfg.h, 1068  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_13  
 cpu1\_platform\_cfg.h, 1068  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_14  
 cpu1\_platform\_cfg.h, 1068  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_15  
 cpu1\_platform\_cfg.h, 1068  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_16  
 cpu1\_platform\_cfg.h, 1068  
 CFE\_PLATFORM\_ES\_MEMPOOL\_ALIGN\_SIZE\_MIN  
 cpu1\_platform\_cfg.h, 1068  
 CFE\_PLATFORM\_ES\_NONVOL\_DISK\_MOUNT\_STRI-  
     NG  
 cpu1\_platform\_cfg.h, 1069  
 CFE\_PLATFORM\_ES\_NONVOL\_STARTUP\_FILE  
 cpu1\_platform\_cfg.h, 1069  
 CFE\_PLATFORM\_ES\_OBJECT\_TABLE\_SIZE  
 cpu1\_platform\_cfg.h, 1069  
 CFE\_PLATFORM\_ES\_PERF\_CHILD\_MS\_DELAY  
 cpu1\_platform\_cfg.h, 1070  
 CFE\_PLATFORM\_ES\_PERF\_CHILD\_PRIORITY  
 cpu1\_platform\_cfg.h, 1070  
 CFE\_PLATFORM\_ES\_PERF\_CHILD\_STACK\_SIZE  
 cpu1\_platform\_cfg.h, 1070  
 CFE\_PLATFORM\_ES\_PERF\_DATA\_BUFFER\_SIZE  
 cpu1\_platform\_cfg.h, 1071  
 CFE\_PLATFORM\_ES\_PERF\_ENTRIES\_BTWN\_DLYS  
 cpu1\_platform\_cfg.h, 1071  
 CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_ALL  
 cpu1\_platform\_cfg.h, 1071  
 CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_INIT  
 cpu1\_platform\_cfg.h, 1072  
 CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_NONE  
 cpu1\_platform\_cfg.h, 1072  
 CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_ALL  
 cpu1\_platform\_cfg.h, 1072  
 CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_INIT  
 cpu1\_platform\_cfg.h, 1073  
 CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_NONE  
 cpu1\_platform\_cfg.h, 1073  
 CFE\_PLATFORM\_ES\_POOL\_MAX\_BUCKETS  
 cpu1\_platform\_cfg.h, 1073  
 CFE\_PLATFORM\_ES\_RAM\_DISK\_MOUNT\_STRING  
 cpu1\_platform\_cfg.h, 1074  
 CFE\_PLATFORM\_ES\_RAM\_DISK\_NUM\_SECTORS  
 cpu1\_platform\_cfg.h, 1074  
 CFE\_PLATFORM\_ES\_RAM\_DISK\_PERCENT\_RESE-  
     RVED  
 cpu1\_platform\_cfg.h, 1074  
 CFE\_PLATFORM\_ES\_RAM\_DISK\_SECTOR\_SIZE  
 cpu1\_platform\_cfg.h, 1075  
 CFE\_PLATFORM\_ES\_RESET\_AREA\_SIZE  
 cpu1\_platform\_cfg.h, 1075  
 CFE\_PLATFORM\_ES\_START\_TASK\_PRIORITY  
 cpu1\_platform\_cfg.h, 1076  
 CFE\_PLATFORM\_ES\_START\_TASK\_STACK\_SIZE  
 cpu1\_platform\_cfg.h, 1076  
 CFE\_PLATFORM\_ES\_STARTUP\_SCRIPT\_TIMEOUT-  
     \_MSEC  
 cpu1\_platform\_cfg.h, 1077  
 CFE\_PLATFORM\_ES\_STARTUP\_SYNC\_POLL\_MSEC  
 cpu1\_platform\_cfg.h, 1077  
 CFE\_PLATFORM\_ES\_SYSTEM\_LOG\_SIZE  
 cpu1\_platform\_cfg.h, 1078  
 CFE\_PLATFORM\_ES\_USER\_RESERVED\_SIZE  
 cpu1\_platform\_cfg.h, 1078  
 CFE\_PLATFORM\_ES\_VOLATILE\_STARTUP\_FILE  
 cpu1\_platform\_cfg.h, 1079  
 CFE\_PLATFORM\_EVS\_APP\_EVENTS\_PER\_SEC  
 cpu1\_platform\_cfg.h, 1079  
 CFE\_PLATFORM\_EVS\_DEFAULT\_APP\_DATA\_FILE  
 cpu1\_platform\_cfg.h, 1080  
 CFE\_PLATFORM\_EVS\_DEFAULT\_LOG\_FILE  
 cpu1\_platform\_cfg.h, 1080  
 CFE\_PLATFORM\_EVS\_DEFAULT\_LOG\_MODE  
 cpu1\_platform\_cfg.h, 1080  
 CFE\_PLATFORM\_EVS\_DEFAULT\_MSG\_FORMAT\_-  
     MODE  
 cpu1\_platform\_cfg.h, 1081  
 CFE\_PLATFORM\_EVS\_DEFAULT\_TYPE\_FLAG

cpu1\_platform\_cfg.h, 1081  
CFE\_PLATFORM\_EVS\_LOG\_MAX  
    cpu1\_platform\_cfg.h, 1081  
CFE\_PLATFORM\_EVS\_MAX\_APP\_EVENT\_BURST  
    cpu1\_platform\_cfg.h, 1082  
CFE\_PLATFORM\_EVS\_MAX\_EVENT\_FILTERS  
    cpu1\_platform\_cfg.h, 1082  
CFE\_PLATFORM\_EVS\_PORT\_DEFAULT  
    cpu1\_platform\_cfg.h, 1082  
CFE\_PLATFORM\_EVS\_START\_TASK\_PRIORITY  
    cpu1\_platform\_cfg.h, 1083  
CFE\_PLATFORM\_EVS\_START\_TASK\_STACK\_SIZE  
    cpu1\_platform\_cfg.h, 1083  
CFE\_PLATFORM\_SB\_BUF\_MEMORY\_BYTES  
    cpu1\_platform\_cfg.h, 1083  
CFE\_PLATFORM\_SB\_DEFAULT\_MAP\_FILENAME  
    cpu1\_platform\_cfg.h, 1084  
CFE\_PLATFORM\_SB\_DEFAULT\_MSG\_LIMIT  
    cpu1\_platform\_cfg.h, 1084  
CFE\_PLATFORM\_SB\_DEFAULT\_PIPE\_FILENAME  
    cpu1\_platform\_cfg.h, 1085  
CFE\_PLATFORM\_SB\_DEFAULT\_ROUTING\_FILENA←  
    ME  
    cpu1\_platform\_cfg.h, 1085  
CFE\_PLATFORM\_SB\_FILTER\_MASK1  
    cpu1\_platform\_cfg.h, 1085  
CFE\_PLATFORM\_SB\_FILTER\_MASK2  
    cpu1\_platform\_cfg.h, 1086  
CFE\_PLATFORM\_SB\_FILTER\_MASK3  
    cpu1\_platform\_cfg.h, 1086  
CFE\_PLATFORM\_SB\_FILTER\_MASK4  
    cpu1\_platform\_cfg.h, 1086  
CFE\_PLATFORM\_SB\_FILTER\_MASK5  
    cpu1\_platform\_cfg.h, 1086  
CFE\_PLATFORM\_SB\_FILTER\_MASK6  
    cpu1\_platform\_cfg.h, 1086  
CFE\_PLATFORM\_SB\_FILTER\_MASK7  
    cpu1\_platform\_cfg.h, 1086  
CFE\_PLATFORM\_SB\_FILTER\_MASK8  
    cpu1\_platform\_cfg.h, 1087  
CFE\_PLATFORM\_SB\_FILTERED\_EVENT1  
    cpu1\_platform\_cfg.h, 1087  
CFE\_PLATFORM\_SB\_FILTERED\_EVENT2  
    cpu1\_platform\_cfg.h, 1087  
CFE\_PLATFORM\_SB\_FILTERED\_EVENT3  
    cpu1\_platform\_cfg.h, 1087  
CFE\_PLATFORM\_SB\_FILTERED\_EVENT4  
    cpu1\_platform\_cfg.h, 1087  
CFE\_PLATFORM\_SB\_FILTERED\_EVENT5  
    cpu1\_platform\_cfg.h, 1088  
CFE\_PLATFORM\_SB\_FILTERED\_EVENT6  
    cpu1\_platform\_cfg.h, 1088  
CFE\_PLATFORM\_SB\_FILTERED\_EVENT7  
    cpu1\_platform\_cfg.h, 1088  
CFE\_PLATFORM\_SB\_FILTERED\_EVENT8  
    cpu1\_platform\_cfg.h, 1088  
CFE\_PLATFORM\_SB\_HIGHEST\_VALID\_MSGID  
    cpu1\_platform\_cfg.h, 1088  
CFE\_PLATFORM\_SB\_MAX\_BLOCK\_SIZE  
    cpu1\_platform\_cfg.h, 1089  
CFE\_PLATFORM\_SB\_MAX\_DEST\_PER\_PKT  
    cpu1\_platform\_cfg.h, 1089  
CFE\_PLATFORM\_SB\_MAX\_MSG\_IDS  
    cpu1\_platform\_cfg.h, 1089  
CFE\_PLATFORM\_SB\_MAX\_PIPES  
    cpu1\_platform\_cfg.h, 1090  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_01  
    cpu1\_platform\_cfg.h, 1090  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_02  
    cpu1\_platform\_cfg.h, 1091  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_03  
    cpu1\_platform\_cfg.h, 1091  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_04  
    cpu1\_platform\_cfg.h, 1091  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_05  
    cpu1\_platform\_cfg.h, 1091  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_06  
    cpu1\_platform\_cfg.h, 1091  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_07  
    cpu1\_platform\_cfg.h, 1092  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_08  
    cpu1\_platform\_cfg.h, 1092  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_09  
    cpu1\_platform\_cfg.h, 1092  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_10  
    cpu1\_platform\_cfg.h, 1092  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_11  
    cpu1\_platform\_cfg.h, 1092  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_12  
    cpu1\_platform\_cfg.h, 1092  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_13  
    cpu1\_platform\_cfg.h, 1093  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_14  
    cpu1\_platform\_cfg.h, 1093  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_15  
    cpu1\_platform\_cfg.h, 1093  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_16  
    cpu1\_platform\_cfg.h, 1093  
CFE\_PLATFORM\_SB\_START\_TASK\_PRIORITY  
    cpu1\_platform\_cfg.h, 1093  
CFE\_PLATFORM\_SB\_START\_TASK\_STACK\_SIZE  
    cpu1\_platform\_cfg.h, 1093  
CFE\_PLATFORM\_TBL\_BUF\_MEMORY\_BYTES  
    cpu1\_platform\_cfg.h, 1094  
CFE\_PLATFORM\_TBL\_DEFAULT\_REG\_DUMP\_FILE  
    cpu1\_platform\_cfg.h, 1094  
CFE\_PLATFORM\_TBL\_MAX\_CRITICAL\_TABLES  
    cpu1\_platform\_cfg.h, 1094

CFE\_PLATFORM\_TBL\_MAX\_DBL\_TABLE\_SIZE  
     cpu1\_platform\_cfg.h, 1095

CFE\_PLATFORM\_TBL\_MAX\_NUM\_HANDLES  
     cpu1\_platform\_cfg.h, 1095

CFE\_PLATFORM\_TBL\_MAX\_NUM\_TABLES  
     cpu1\_platform\_cfg.h, 1095

CFE\_PLATFORM\_TBL\_MAX\_NUM\_VALIDATIONS  
     cpu1\_platform\_cfg.h, 1096

CFE\_PLATFORM\_TBL\_MAX\_SIMULTANEOUS\_LOADS  
     cpu1\_platform\_cfg.h, 1096

CFE\_PLATFORM\_TBL\_MAX\_SNGL\_TABLE\_SIZE  
     cpu1\_platform\_cfg.h, 1096

CFE\_PLATFORM\_TBL\_START\_TASK\_PRIORITY  
     cpu1\_platform\_cfg.h, 1097

CFE\_PLATFORM\_TBL\_START\_TASK\_STACK\_SIZE  
     cpu1\_platform\_cfg.h, 1097

CFE\_PLATFORM\_TBL\_U32FROM4CHARS  
     cpu1\_platform\_cfg.h, 1097

CFE\_PLATFORM\_TBL\_VALID\_PRID\_1  
     cpu1\_platform\_cfg.h, 1098

CFE\_PLATFORM\_TBL\_VALID\_PRID\_2  
     cpu1\_platform\_cfg.h, 1098

CFE\_PLATFORM\_TBL\_VALID\_PRID\_3  
     cpu1\_platform\_cfg.h, 1098

CFE\_PLATFORM\_TBL\_VALID\_PRID\_4  
     cpu1\_platform\_cfg.h, 1098

CFE\_PLATFORM\_TBL\_VALID\_PRID\_COUNT  
     cpu1\_platform\_cfg.h, 1099

CFE\_PLATFORM\_TBL\_VALID\_SCID\_1  
     cpu1\_platform\_cfg.h, 1099

CFE\_PLATFORM\_TBL\_VALID\_SCID\_2  
     cpu1\_platform\_cfg.h, 1099

CFE\_PLATFORM\_TBL\_VALID\_SCID\_COUNT  
     cpu1\_platform\_cfg.h, 1100

CFE\_PLATFORM\_TIME\_1HZ\_TASK\_PRIORITY  
     cpu1\_platform\_cfg.h, 1100

CFE\_PLATFORM\_TIME\_1HZ\_TASK\_STACK\_SIZE  
     cpu1\_platform\_cfg.h, 1100

CFE\_PLATFORM\_TIME\_CFG\_CLIENT  
     cpu1\_platform\_cfg.h, 1100

CFE\_PLATFORM\_TIME\_CFG\_LATCH\_FLY  
     cpu1\_platform\_cfg.h, 1100

CFE\_PLATFORM\_TIME\_CFG\_SERVER  
     cpu1\_platform\_cfg.h, 1101

CFE\_PLATFORM\_TIME\_CFG\_SIGNAL  
     cpu1\_platform\_cfg.h, 1101

CFE\_PLATFORM\_TIME\_CFG\_SOURCE  
     cpu1\_platform\_cfg.h, 1101

CFE\_PLATFORM\_TIME\_CFG\_SRC\_GPS  
     cpu1\_platform\_cfg.h, 1102

CFE\_PLATFORM\_TIME\_CFG\_SRC\_MET  
     cpu1\_platform\_cfg.h, 1102

CFE\_PLATFORM\_TIME\_CFG\_SRC\_TIME  
     cpu1\_platform\_cfg.h, 1102

CFE\_PLATFORM\_TIME\_CFG\_START\_FLY  
     cpu1\_platform\_cfg.h, 1103

CFE\_PLATFORM\_TIME\_CFG\_TONE\_LIMIT  
     cpu1\_platform\_cfg.h, 1103

CFE\_PLATFORM\_TIME\_CFG\_VIRTUAL  
     cpu1\_platform\_cfg.h, 1103

CFE\_PLATFORM\_TIME\_MAX\_DELTA\_SECS  
     cpu1\_platform\_cfg.h, 1104

CFE\_PLATFORM\_TIME\_MAX\_DELTA\_SUBS  
     cpu1\_platform\_cfg.h, 1104

CFE\_PLATFORM\_TIME\_MAX\_LOCAL\_SECS  
     cpu1\_platform\_cfg.h, 1105

CFE\_PLATFORM\_TIME\_MAX\_LOCAL\_SUBS  
     cpu1\_platform\_cfg.h, 1105

CFE\_PLATFORM\_TIME\_START\_TASK\_PRIORITY  
     cpu1\_platform\_cfg.h, 1105

CFE\_PLATFORM\_TIME\_START\_TASK\_STACK\_SIZE  
     cpu1\_platform\_cfg.h, 1105

CFE\_PLATFORM\_TIME\_TONE\_TASK\_PRIORITY  
     cpu1\_platform\_cfg.h, 1106

CFE\_PLATFORM\_TIME\_TONE\_TASK\_STACK\_SIZE  
     cpu1\_platform\_cfg.h, 1106

CFE\_PLATFORM\_TLM\_MID\_BASE  
     cpu1\_msgids.h, 1045

CFE\_PSP\_AttachExceptions  
     cfe\_psp.h, 1546

CFE\_PSP\_Decompress  
     cfe\_psp.h, 1546

CFE\_PSP\_ERROR\_ADDRESS\_MISALIGNED  
     cfe\_psp\_error.h, 1559

CFE\_PSP\_ERROR\_NOT\_IMPLEMENTED  
     cfe\_psp\_error.h, 1559

CFE\_PSP\_ERROR\_TIMEOUT  
     cfe\_psp\_error.h, 1559

CFE\_PSP\_ERROR  
     cfe\_psp\_error.h, 1559

CFE\_PSP\_EepromPowerDown  
     cfe\_psp.h, 1546

CFE\_PSP\_EepromPowerUp  
     cfe\_psp.h, 1546

CFE\_PSP\_EepromWrite16  
     cfe\_psp.h, 1546

CFE\_PSP\_EepromWrite32  
     cfe\_psp.h, 1547

CFE\_PSP\_EepromWrite8  
     cfe\_psp.h, 1547

CFE\_PSP\_EepromWriteDisable  
     cfe\_psp.h, 1547

CFE\_PSP\_EepromWriteEnable  
     cfe\_psp.h, 1547

CFE\_PSP\_Exception\_CopyContext  
     cfe\_psp.h, 1547

CFE\_PSP\_Exception\_GetCount  
     cfe\_psp.h, 1547

CFE\_PSP\_Exception\_GetSummary  
    cfe\_psp.h, 1548

CFE\_PSP\_FlushCaches  
    cfe\_psp.h, 1548

CFE\_PSP\_Get\_Dec  
    cfe\_psp.h, 1548

CFE\_PSP\_Get\_Timebase  
    cfe\_psp.h, 1548

CFE\_PSP\_Get\_Timer\_Tick  
    cfe\_psp.h, 1549

CFE\_PSP\_GetBuildNumber  
    cfe\_psp.h, 1549

CFE\_PSP\_GetCDSSize  
    cfe\_psp.h, 1549

CFE\_PSP\_GetCFETextSegmentInfo  
    cfe\_psp.h, 1549

CFE\_PSP\_GetKernelTextSegmentInfo  
    cfe\_psp.h, 1549

CFE\_PSP\_GetProcessorId  
    cfe\_psp.h, 1550

CFE\_PSP\_GetProcessorName  
    cfe\_psp.h, 1550

CFE\_PSP\_GetResetArea  
    cfe\_psp.h, 1550

CFE\_PSP\_GetRestartType  
    cfe\_psp.h, 1550

CFE\_PSP\_GetSpacecraftId  
    cfe\_psp.h, 1550

CFE\_PSP\_GetTime  
    cfe\_psp.h, 1550

CFE\_PSP\_GetTimerLow32Rollover  
    cfe\_psp.h, 1551

CFE\_PSP\_GetTimerTicksPerSecond  
    cfe\_psp.h, 1551

CFE\_PSP GetUserReservedArea  
    cfe\_psp.h, 1551

CFE\_PSP\_GetVersionCodeName  
    cfe\_psp.h, 1551

CFE\_PSP\_GetVersionNumber  
    cfe\_psp.h, 1552

CFE\_PSP\_GetVersionString  
    cfe\_psp.h, 1552

CFE\_PSP\_GetVolatileDiskMem  
    cfe\_psp.h, 1552

CFE\_PSP\_INVALID\_INT\_NUM  
    cfe\_psp\_error.h, 1559

CFE\_PSP\_INVALID\_MEM\_ADDR  
    cfe\_psp\_error.h, 1560

CFE\_PSP\_INVALID\_MEM\_ATTR  
    cfe\_psp\_error.h, 1560

CFE\_PSP\_INVALID\_MEM\_RANGE  
    cfe\_psp\_error.h, 1560

CFE\_PSP\_INVALID\_MEM\_SIZE  
    cfe\_psp\_error.h, 1560

CFE\_PSP\_INVALID\_MEM\_TYPE  
    cfe\_psp\_error.h, 1560

CFE\_PSP\_INVALID\_MEM\_WORDSIZE  
    cfe\_psp\_error.h, 1560

CFE\_PSP\_INVALID\_MODULE\_ID  
    cfe\_psp\_error.h, 1561

CFE\_PSP\_INVALID\_MODULE\_NAME  
    cfe\_psp\_error.h, 1561

CFE\_PSP\_INVALID\_POINTER  
    cfe\_psp\_error.h, 1561

CFE\_PSP\_InitSSR  
    cfe\_psp.h, 1553

CFE\_PSP\_MEM\_ANY  
    cfe\_psp.h, 1540

CFE\_PSP\_MEM\_ATTR\_READWRITE  
    cfe\_psp.h, 1540

CFE\_PSP\_MEM\_ATTR\_READ  
    cfe\_psp.h, 1540

CFE\_PSP\_MEM\_ATTR\_WRITE  
    cfe\_psp.h, 1540

CFE\_PSP\_MEM\_EEPROM  
    cfe\_psp.h, 1540

CFE\_PSP\_MEM\_INVALID  
    cfe\_psp.h, 1540

CFE\_PSP\_MEM\_RAM  
    cfe\_psp.h, 1541

CFE\_PSP\_MEM\_SIZE\_BYTE  
    cfe\_psp.h, 1541

CFE\_PSP\_MEM\_SIZE\_DWORD  
    cfe\_psp.h, 1541

CFE\_PSP\_MEM\_SIZE\_WORD  
    cfe\_psp.h, 1541

CFE\_PSP\_Main  
    cfe\_psp.h, 1553

CFE\_PSP\_MemCpy  
    cfe\_psp.h, 1553

CFE\_PSP\_MemRangeGet  
    cfe\_psp.h, 1553

CFE\_PSP\_MemRangeSet  
    cfe\_psp.h, 1553

CFE\_PSP\_MemRanges  
    cfe\_psp.h, 1553

CFE\_PSP\_MemRead16  
    cfe\_psp.h, 1554

CFE\_PSP\_MemRead32  
    cfe\_psp.h, 1554

CFE\_PSP\_MemRead8  
    cfe\_psp.h, 1554

CFE\_PSP\_MemSet  
    cfe\_psp.h, 1554

CFE\_PSP\_MemValidateRange  
    cfe\_psp.h, 1554

CFE\_PSP\_MemWrite16  
    cfe\_psp.h, 1554

CFE\_PSP\_MemWrite32  
  cfe\_psp.h, 1555  
CFE\_PSP\_MemWrite8  
  cfe\_psp.h, 1555  
CFE\_PSP\_NO\_EXCEPTION\_DATA  
  cfe\_psp\_error.h, 1561  
CFE\_PSP\_PANIC\_CORE\_APP  
  cfe\_psp.h, 1541  
CFE\_PSP\_PANIC\_GENERAL\_FAILURE  
  cfe\_psp.h, 1541  
CFE\_PSP\_PANIC\_MEMORY\_ALLOC  
  cfe\_psp.h, 1542  
CFE\_PSP\_PANIC\_NONVOL\_DISK  
  cfe\_psp.h, 1542  
CFE\_PSP\_PANIC\_STARTUP\_SEM  
  cfe\_psp.h, 1542  
CFE\_PSP\_PANIC\_STARTUP  
  cfe\_psp.h, 1542  
CFE\_PSP\_PANIC\_VOLATILE\_DISK  
  cfe\_psp.h, 1542  
CFE\_PSP\_Panic  
  cfe\_psp.h, 1555  
CFE\_PSP\_PortRead16  
  cfe\_psp.h, 1555  
CFE\_PSP\_PortRead32  
  cfe\_psp.h, 1555  
CFE\_PSP\_PortRead8  
  cfe\_psp.h, 1555  
CFE\_PSP\_PortWrite16  
  cfe\_psp.h, 1556  
CFE\_PSP\_PortWrite32  
  cfe\_psp.h, 1556  
CFE\_PSP\_PortWrite8  
  cfe\_psp.h, 1556  
CFE\_PSP\_RST\_SUBTYPE\_BANKSWITCH\_RESET  
  cfe\_psp.h, 1542  
CFE\_PSP\_RST\_SUBTYPE\_EXCEPTION  
  cfe\_psp.h, 1543  
CFE\_PSP\_RST\_SUBTYPE\_HW\_SPECIAL\_COMMAND  
  cfe\_psp.h, 1543  
CFE\_PSP\_RST\_SUBTYPE\_HW\_WATCHDOG  
  cfe\_psp.h, 1543  
CFE\_PSP\_RST\_SUBTYPE\_HWDEBUG\_RESET  
  cfe\_psp.h, 1543  
CFE\_PSP\_RST\_SUBTYPE\_MAX  
  cfe\_psp.h, 1543  
CFE\_PSP\_RST\_SUBTYPE\_POWER\_CYCLE  
  cfe\_psp.h, 1544  
CFE\_PSP\_RST\_SUBTYPE\_PUSH\_BUTTON  
  cfe\_psp.h, 1544  
CFE\_PSP\_RST\_SUBTYPE\_RESET\_COMMAND  
  cfe\_psp.h, 1544  
CFE\_PSP\_RST\_SUBTYPE\_UNDEFINED\_RESET  
  cfe\_psp.h, 1544  
  
CFE\_PSP\_RST\_TYPE\_MAX  
  cfe\_psp.h, 1544  
CFE\_PSP\_RST\_TYPE\_POWERON  
  cfe\_psp.h, 1545  
CFE\_PSP\_RST\_TYPE\_PROCESSOR  
  cfe\_psp.h, 1545  
CFE\_PSP\_ReadFromCDS  
  cfe\_psp.h, 1556  
CFE\_PSP\_Restart  
  cfe\_psp.h, 1556  
CFE\_PSP\_SOFT\_TIMEBASE\_NAME  
  cfe\_psp.h, 1545  
CFE\_PSP\_STATUS\_STRING\_LENGTH  
  cfe\_psp\_error.h, 1561  
CFE\_PSP\_STATUS\_C  
  cfe\_psp\_error.h, 1561  
CFE\_PSP\_SUCCESS  
  cfe\_psp\_error.h, 1562  
CFE\_PSP\_SetDefaultExceptionEnvironment  
  cfe\_psp.h, 1556  
CFE\_PSP\_Status\_t  
  cfe\_psp\_error.h, 1562  
CFE\_PSP\_StatusString\_t  
  cfe\_psp\_error.h, 1562  
CFE\_PSP\_StatusToString  
  cfe\_psp\_error.h, 1562  
CFE\_PSP\_WatchdogDisable  
  cfe\_psp.h, 1557  
CFE\_PSP\_WatchdogEnable  
  cfe\_psp.h, 1557  
CFE\_PSP\_WatchdogGet  
  cfe\_psp.h, 1557  
CFE\_PSP\_WatchdogInit  
  cfe\_psp.h, 1557  
CFE\_PSP\_WatchdogService  
  cfe\_psp.h, 1557  
CFE\_PSP\_WatchdogSet  
  cfe\_psp.h, 1557  
CFE\_PSP\_WriteToCDS  
  cfe\_psp.h, 1557  
  
CFE\_RESOURCEID\_MAKE\_BASE  
  cfe\_resourceid\_basevalue.h, 1358  
CFE\_RESOURCEID\_MAX  
  cfe\_resourceid\_basevalue.h, 1358  
CFE\_RESOURCEID\_RESERVED  
  cfe\_resourceid\_api\_typedefs.h, 1206  
CFE\_RESOURCEID\_SHIFT  
  cfe\_resourceid\_basevalue.h, 1358  
CFE\_RESOURCEID\_TEST\_DEFINED  
  cfe\_resourceid.h, 1199  
CFE\_RESOURCEID\_TEST\_EQUAL  
  cfe\_resourceid.h, 1199  
CFE\_RESOURCEID\_TO\_ULONG  
  cfe\_resourceid.h, 1199

CFE\_RESOURCEID\_UNDEFINED  
  cfe\_resourceid\_api\_typedefs.h, 1206

CFE\_REVISION  
  cfe\_version.h, 1237

CFE\_Resourceld\_Equal  
  cfe\_resourceid.h, 1200

CFE\_Resourceld\_FindNext  
  cfe\_resourceid.h, 1200

CFE\_Resourceld\_FromInteger  
  cfe\_resourceid.h, 1201

CFE\_Resourceld\_GetBase  
  cfe\_resourceid.h, 1202

CFE\_Resourceld\_GetSerial  
  cfe\_resourceid.h, 1202

CFE\_Resourceld\_IsDefined  
  cfe\_resourceid.h, 1203

CFE\_Resourceld\_ToIndex  
  cfe\_resourceid.h, 1204

CFE\_Resourceld\_ToInteger  
  cfe\_resourceid.h, 1205

CFE\_SB\_ALLSUBS\_TLM\_MID  
  cpu1\_msgids.h, 1045

CFE\_SB\_AllSubscriptionsTlm, 663  
  Payload, 664  
  TelemetryHeader, 664

CFE\_SB\_AllSubscriptionsTlm\_Payload, 664  
  Entries, 665  
  Entry, 665  
  PktSegment, 665  
  TotalSegments, 665

CFE\_SB\_AllSubscriptionsTlm\_Payload\_t  
  cfe\_sb\_msg.h, 1396

CFE\_SB\_AllSubscriptionsTlm\_t  
  cfe\_sb\_msg.h, 1396

CFE\_SB\_AllocateMessageBuffer  
  cFE Zero Copy APIs, 358

CFE\_SB\_BAD\_ARGUMENT  
  cFE Return Code Defines, 218

CFE\_SB\_BAD\_CMD\_CODE\_EID  
  cfe\_sb\_events.h, 1361

CFE\_SB\_BAD\_MSGID\_EID  
  cfe\_sb\_events.h, 1361

CFE\_SB\_BAD\_PIPEID\_EID  
  cfe\_sb\_events.h, 1362

CFE\_SB\_BUF\_ALOC\_ERR  
  cFE Return Code Defines, 218

CFE\_SB\_BUFFER\_INVALID  
  cFE Return Code Defines, 219

CFE\_SB\_Buffer\_t  
  cfe\_sb\_api\_typedefs.h, 1214

CFE\_SB\_CMD0\_RCVD\_EID  
  cfe\_sb\_events.h, 1362

CFE\_SB\_CMD1\_RCVD\_EID  
  cfe\_sb\_events.h, 1362

CFE\_SB\_CMD\_MID  
  cpu1\_msgids.h, 1045

CFE\_SB\_CR\_PIPE\_BAD\_ARG\_EID  
  cfe\_sb\_events.h, 1363

CFE\_SB\_CR\_PIPE\_ERR\_EID  
  cfe\_sb\_events.h, 1363

CFE\_SB\_CR\_PIPE\_NAME\_TAKEN\_EID  
  cfe\_sb\_events.h, 1363

CFE\_SB\_CR\_PIPE\_NO\_FREE\_EID  
  cfe\_sb\_events.h, 1364

CFE\_SB\_CreatePipe  
  cFE Pipe Management APIs, 342

CFE\_SB\_DEFAULT\_QOS  
  cfe\_sb\_api\_typedefs.h, 1211

CFE\_SB\_DEL\_PIPE\_ERR1\_EID  
  cfe\_sb\_events.h, 1364

CFE\_SB\_DEL\_PIPE\_ERR2\_EID  
  cfe\_sb\_events.h, 1364

CFE\_SB\_DEST\_BLK\_ERR\_EID  
  cfe\_sb\_events.h, 1365

CFE\_SB\_DISABLE\_ROUTE\_CC  
  cfe\_sb\_msg.h, 1385

CFE\_SB\_DISABLE\_SUB\_REPORTING\_CC  
  cfe\_sb\_msg.h, 1385

CFE\_SB\_DSBL\_RTE1\_EID  
  cfe\_sb\_events.h, 1365

CFE\_SB\_DSBL\_RTE2\_EID  
  cfe\_sb\_events.h, 1365

CFE\_SB\_DSBL\_RTE3\_EID  
  cfe\_sb\_events.h, 1366

CFE\_SB\_DUP\_SUBSCRIPTION\_EID  
  cfe\_sb\_events.h, 1366

CFE\_SB\_DeletePipe  
  cFE Pipe Management APIs, 343

CFE\_SB\_DisableRouteCmd\_t  
  cfe\_sb\_msg.h, 1396

CFE\_SB\_DisableSubReportingCmd\_t  
  cfe\_sb\_msg.h, 1396

CFE\_SB\_ENABLE\_ROUTE\_CC  
  cfe\_sb\_msg.h, 1386

CFE\_SB\_ENABLE\_SUB\_REPORTING\_CC  
  cfe\_sb\_msg.h, 1387

CFE\_SB\_ENBL\_RTE1\_EID  
  cfe\_sb\_events.h, 1366

CFE\_SB\_ENBL\_RTE2\_EID  
  cfe\_sb\_events.h, 1367

CFE\_SB\_ENBL\_RTE3\_EID  
  cfe\_sb\_events.h, 1367

CFE\_SB\_EnableRouteCmd\_t  
  cfe\_sb\_msg.h, 1396

CFE\_SB\_EnableSubReportingCmd\_t  
  cfe\_sb\_msg.h, 1396

CFE\_SB\_FILEWRITE\_ERR\_EID  
  cfe\_sb\_events.h, 1367

**CFE\_SB\_FULL\_SUB\_PKT\_EID**  
 cfe\_sb\_events.h, 1368  
**CFE\_SB\_GET\_BUF\_ERR\_EID**  
 cfe\_sb\_events.h, 1368  
**CFE\_SB\_GETPIPEIDBYNAME\_EID**  
 cfe\_sb\_events.h, 1368  
**CFE\_SB\_GETPIPEIDBYNAME\_NAME\_ERR\_EID**  
 cfe\_sb\_events.h, 1369  
**CFE\_SB\_GETPIPEIDBYNAME\_NULL\_ERR\_EID**  
 cfe\_sb\_events.h, 1369  
**CFE\_SB\_GETPIPENAME\_EID**  
 cfe\_sb\_events.h, 1369  
**CFE\_SB\_GETPIPENAME\_ID\_ERR\_EID**  
 cfe\_sb\_events.h, 1370  
**CFE\_SB\_GETPIPENAME\_NULL\_PTR\_EID**  
 cfe\_sb\_events.h, 1370  
**CFE\_SB\_GETPIPEOPTS\_EID**  
 cfe\_sb\_events.h, 1370  
**CFE\_SB\_GETPIPEOPTS\_ID\_ERR\_EID**  
 cfe\_sb\_events.h, 1371  
**CFE\_SB\_GETPIPEOPTS\_PTR\_ERR\_EID**  
 cfe\_sb\_events.h, 1371  
**CFE\_SB\_GetPipeIdByName**  
 cFE Pipe Management APIs, 344  
**CFE\_SB\_GetPipeName**  
 cFE Pipe Management APIs, 345  
**CFE\_SB\_GetPipeOpts**  
 cFE Pipe Management APIs, 345  
**CFE\_SB\_GetUserData**  
 cFE Message Characteristics APIs, 361  
**CFE\_SB\_GetUserDataLength**  
 cFE Message Characteristics APIs, 362  
**CFE\_SB\_HASHCOLLISION\_EID**  
 cfe\_sb\_events.h, 1371  
**CFE\_SB\_HK\_TLM\_MID**  
 cpu1\_msgids.h, 1045  
**CFE\_SB\_HousekeepingTlm**, 666  
 Payload, 666  
 TelemetryHeader, 666  
**CFE\_SB\_HousekeepingTlm\_Payload**, 667  
 CommandCounter, 668  
 CommandErrorCounter, 668  
 CreatePipeErrorCounter, 668  
 DuplicateSubscriptionsCounter, 668  
 GetPipeIdByNameErrorCounter, 669  
 InternalErrorCounter, 669  
 MemInUse, 669  
 MemPoolHandle, 669  
 MsgLimitErrorCounter, 670  
 MsgReceiveErrorCounter, 670  
 MsgSendErrorCounter, 670  
 NoSubscribersCounter, 670  
 PipeOptsErrorCounter, 671  
 PipeOverflowErrorCounter, 671  
**Spare2Align**, 671  
**SubscribeErrorCounter**, 671  
**UnmarkedMem**, 672  
**CFE\_SB\_HousekeepingTlm\_Payload\_t**  
 cfe\_sb\_msg.h, 1397  
**CFE\_SB\_HousekeepingTlm\_t**  
 cfe\_sb\_msg.h, 1397  
**CFE\_SB\_INIT\_EID**  
 cfe\_sb\_events.h, 1372  
**CFE\_SB\_INTERNAL\_ERR**  
 cFE Return Code Defines, 219  
**CFE\_SB\_INVALID\_MSG\_ID**  
 cfe\_sb\_api\_typedefs.h, 1211  
**CFE\_SB\_INVALID\_PIPE**  
 cfe\_sb\_api\_typedefs.h, 1211  
**CFE\_SB\_IsValidMsgId**  
 cFE Message ID APIs, 366  
**CFE\_SB\_LEN\_ERR\_EID**  
 cfe\_sb\_events.h, 1372  
**CFE\_SB\_MAX\_DESTS\_MET\_EID**  
 cfe\_sb\_events.h, 1372  
**CFE\_SB\_MAX\_DESTS\_MET**  
 cFE Return Code Defines, 219  
**CFE\_SB\_MAX\_MSGS\_MET\_EID**  
 cfe\_sb\_events.h, 1373  
**CFE\_SB\_MAX\_MSGS\_MET**  
 cFE Return Code Defines, 219  
**CFE\_SB\_MAX\_PIPES\_MET\_EID**  
 cfe\_sb\_events.h, 1373  
**CFE\_SB\_MAX\_PIPES\_MET**  
 cFE Return Code Defines, 220  
**CFE\_SB\_MSG\_TOO\_BIG\_EID**  
 cfe\_sb\_events.h, 1373  
**CFE\_SB\_MSG\_TOO\_BIG**  
 cFE Return Code Defines, 220  
**CFE\_SB\_MSGID\_LIM\_ERR\_EID**  
 cfe\_sb\_events.h, 1374  
**CFE\_SB\_MSGID\_RESERVED**  
 cfe\_sb\_api\_typedefs.h, 1212  
**CFE\_SB\_MSGID\_UNWRAP\_VALUE**  
 cfe\_sb\_api\_typedefs.h, 1212  
**CFE\_SB\_MSGID\_WRAP\_VALUE**  
 cfe\_sb\_api\_typedefs.h, 1212  
**CFE\_SB\_MSGID\_C**  
 cfe\_sb\_api\_typedefs.h, 1211  
**CFE\_SB\_MessageStringGet**  
 cFE Message Characteristics APIs, 362  
**CFE\_SB\_MessageStringSet**  
 cFE Message Characteristics APIs, 363  
**CFE\_SB\_Msg**, 672  
 LongDouble, 673  
 LongInt, 673  
 Msg, 673  
**CFE\_SB\_MsgId\_Atom\_t**

cfe\_sb\_extern\_typedefs.h, 1216  
CFE\_SB\_MsgId\_Equal  
cFE Message ID APIs, 366  
CFE\_SB\_MsgId\_t, 673  
Value, 674  
CFE\_SB\_MsgIdToValue  
cFE Message ID APIs, 367  
CFE\_SB\_MsgMapFileEntry, 674  
Index, 675  
MsgId, 675  
CFE\_SB\_MsgMapFileEntry\_t  
cfe\_sb\_msg.h, 1397  
CFE\_SB\_NO\_MESSAGE  
cFE Return Code Defines, 220  
CFE\_SB\_NOOP\_CC  
cfe\_sb\_msg.h, 1388  
CFE\_SB\_NOT\_IMPLEMENTED  
cFE Return Code Defines, 220  
CFE\_SB\_NoopCmd\_t  
cfe\_sb\_msg.h, 1397  
CFE\_SB\_ONESUB\_TLM\_MID  
cpu1\_msgids.h, 1045  
CFE\_SB\_PART\_SUB\_PKT\_EID  
cfe\_sb\_events.h, 1374  
CFE\_SB\_PEND\_FOREVER  
cfe\_sb\_api\_typedefs.h, 1213  
CFE\_SB\_PIPE\_ADDED\_EID  
cfe\_sb\_events.h, 1374  
CFE\_SB\_PIPE\_CR\_ERR  
cFE Return Code Defines, 221  
CFE\_SB\_PIPE\_DELETED\_EID  
cfe\_sb\_events.h, 1375  
CFE\_SB\_PIPE\_RD\_ERR  
cFE Return Code Defines, 221  
CFE\_SB\_PIPEID\_C  
cfe\_sb\_api\_typedefs.h, 1213  
CFE\_SB\_PIPEOPTS\_IGNOREMINE  
cFE SB Pipe options, 369  
CFE\_SB\_POLL  
cfe\_sb\_api\_typedefs.h, 1213  
CFE\_SB\_PipeDepthStats, 675  
CurrentQueueDepth, 676  
MaxQueueDepth, 676  
PeakQueueDepth, 676  
Pipeld, 677  
Spare, 677  
CFE\_SB\_PipeDepthStats\_t  
cfe\_sb\_msg.h, 1397  
CFE\_SB\_Pipeld\_ToIndex  
cFE Pipe Management APIs, 347  
CFE\_SB\_Pipeld\_t  
cfe\_sb\_extern\_typedefs.h, 1216  
CFE\_SB\_PipeInfoEntry, 677  
AppId, 678  
AppName, 678  
CurrentQueueDepth, 678  
MaxQueueDepth, 679  
Opts, 679  
PeakQueueDepth, 679  
Pipeld, 679  
PipeName, 679  
SendErrors, 680  
Spare, 680  
CFE\_SB\_PipeInfoEntry\_t  
cfe\_sb\_msg.h, 1397  
CFE\_SB\_Q\_FULL\_ERR\_EID  
cfe\_sb\_events.h, 1375  
CFE\_SB\_Q\_RD\_ERR\_EID  
cfe\_sb\_events.h, 1375  
CFE\_SB\_Q\_WR\_ERR\_EID  
cfe\_sb\_events.h, 1376  
CFE\_SB\_Qos\_t, 680  
Priority, 681  
Reliability, 681  
CFE\_SB\_QosPriority  
cfe\_sb\_extern\_typedefs.h, 1217  
CFE\_SB\_QosPriority\_Enum\_t  
cfe\_sb\_extern\_typedefs.h, 1216  
CFE\_SB\_QosReliability  
cfe\_sb\_extern\_typedefs.h, 1217  
CFE\_SB\_QosReliability\_Enum\_t  
cfe\_sb\_extern\_typedefs.h, 1216  
CFE\_SB\_RCV\_BAD\_ARG\_EID  
cfe\_sb\_events.h, 1376  
CFE\_SB\_RESET\_COUNTERS\_CC  
cfe\_sb\_msg.h, 1389  
CFE\_SB\_ReceiveBuffer  
cFE Send/Receive Message APIs, 355  
CFE\_SB\_ReleaseMessageBuffer  
cFE Zero Copy APIs, 359  
CFE\_SB\_ResetCountersCmd\_t  
cfe\_sb\_msg.h, 1398  
CFE\_SB\_RouteCmd, 681  
CommandHeader, 682  
Payload, 682  
CFE\_SB\_RouteCmd\_Payload, 682  
MsgId, 683  
Pipe, 683  
Spare, 683  
CFE\_SB\_RouteCmd\_Payload\_t  
cfe\_sb\_msg.h, 1398  
CFE\_SB\_RouteCmd\_t  
cfe\_sb\_msg.h, 1398  
CFE\_SB\_Routeld\_Atom\_t  
cfe\_sb\_extern\_typedefs.h, 1217  
CFE\_SB\_RoutingFileEntry, 684  
AppName, 684  
MsgCnt, 684

MsgId, 685  
 PipeId, 685  
 PipeName, 685  
 State, 685  
**CFE\_SB\_RoutingFileEntry\_t**  
*cfe\_sb\_msg.h*, 1398  
**CFE\_SB\_SEND\_BAD\_ARG\_EID**  
*cfe\_sb\_events.h*, 1376  
**CFE\_SB\_SEND\_HK\_MID**  
*cpu1\_msgids.h*, 1046  
**CFE\_SB\_SEND\_INV\_MSGID\_EID**  
*cfe\_sb\_events.h*, 1377  
**CFE\_SB\_SEND\_NO\_SUBS\_EID**  
*cfe\_sb\_events.h*, 1377  
**CFE\_SB\_SEND\_PREV\_SUBS\_CC**  
*cfe\_sb\_msg.h*, 1390  
**CFE\_SB\_SEND\_SB\_STATS\_CC**  
*cfe\_sb\_msg.h*, 1391  
**CFE\_SB\_SETPPIPEOPTS\_EID**  
*cfe\_sb\_events.h*, 1377  
**CFE\_SB\_SETPPIPEOPTS\_ID\_ERR\_EID**  
*cfe\_sb\_events.h*, 1378  
**CFE\_SB\_SETPPIPEOPTS\_OWNER\_ERR\_EID**  
*cfe\_sb\_events.h*, 1378  
**CFE\_SB\_SND\_RTG\_EID**  
*cfe\_sb\_events.h*, 1378  
**CFE\_SB\_SND\_RTG\_ERR1\_EID**  
*cfe\_sb\_events.h*, 1379  
**CFE\_SB\_SND\_STATS\_EID**  
*cfe\_sb\_events.h*, 1379  
**CFE\_SB\_STATS\_TLM\_MID**  
*cpu1\_msgids.h*, 1046  
**CFE\_SB\_SUB\_ARG\_ERR\_EID**  
*cfe\_sb\_events.h*, 1379  
**CFE\_SB\_SUB\_ENTRIES\_PER\_PKT**  
*cfe\_sb\_extern\_typedefs.h*, 1215  
**CFE\_SB\_SUB\_INV\_CALLER\_EID**  
*cfe\_sb\_events.h*, 1380  
**CFE\_SB\_SUB\_INV\_PIPE\_EID**  
*cfe\_sb\_events.h*, 1380  
**CFE\_SB\_SUB\_RPT\_CTRL\_MID**  
*cpu1\_msgids.h*, 1046  
**CFE\_SB\_SUBSCRIPTION\_RCVD\_EID**  
*cfe\_sb\_events.h*, 1380  
**CFE\_SB\_SUBSCRIPTION\_REMOVED\_EID**  
*cfe\_sb\_events.h*, 1381  
**CFE\_SB\_SUBSCRIPTION\_RPT\_EID**  
*cfe\_sb\_events.h*, 1381  
**CFE\_SB\_SUBSCRIPTION**  
*cfe\_sb\_api\_typedefs.h*, 1214  
**CFE\_SB\_SendPrevSubsCmd\_t**  
*cfe\_sb\_msg.h*, 1398  
**CFE\_SB\_SendSbStatsCmd\_t**  
*cfe\_sb\_msg.h*, 1399  
**CFE\_SB\_SetPipeOpts**  
*cFE Pipe Management APIs*, 348  
**CFE\_SB\_SetUserDataLength**  
*cFE Message Characteristics APIs*, 364  
**CFE\_SB\_SingleSubscriptionTlm**, 686  
 Payload, 686  
 TelemetryHeader, 686  
**CFE\_SB\_SingleSubscriptionTlm\_Payload**, 686  
 MsgId, 687  
 Pipe, 687  
 Qos, 687  
 SubType, 688  
**CFE\_SB\_SingleSubscriptionTlm\_Payload\_t**  
*cfe\_sb\_msg.h*, 1399  
**CFE\_SB\_SingleSubscriptionTlm\_t**  
*cfe\_sb\_msg.h*, 1399  
**CFE\_SB\_StatsTlm**, 688  
 Payload, 688  
 TelemetryHeader, 689  
**CFE\_SB\_StatsTlm\_Payload**, 689  
 MaxMemAllowed, 690  
 MaxMsgIdsAllowed, 690  
 MaxPipeDepthAllowed, 690  
 MaxPipesAllowed, 691  
 MaxSubscriptionsAllowed, 691  
 MemInUse, 691  
 MsgIdsInUse, 691  
 PeakMemInUse, 692  
 PeakMsgIdsInUse, 692  
 PeakPipesInUse, 692  
 PeakSBBuffersInUse, 692  
 PeakSubscriptionsInUse, 693  
 PipeDepthStats, 693  
 PipesInUse, 693  
 SBBuffersInUse, 693  
 SubscriptionsInUse, 694  
**CFE\_SB\_StatsTlm\_Payload\_t**  
*cfe\_sb\_msg.h*, 1399  
**CFE\_SB\_StatsTlm\_t**  
*cfe\_sb\_msg.h*, 1399  
**CFE\_SB\_SubEntries**, 694  
 MsgId, 695  
 Pipe, 695  
 Qos, 695  
**CFE\_SB\_SubEntries\_t**  
*cfe\_sb\_msg.h*, 1400  
**CFE\_SB\_Subscribe**  
*cFE Message Subscription Control APIs*, 349  
**CFE\_SB\_SubscribeEx**  
*cFE Message Subscription Control APIs*, 350  
**CFE\_SB\_SubscribeLocal**  
*cFE Message Subscription Control APIs*, 351  
**CFE\_SB\_TIME\_OUT**  
*cFE Return Code Defines*, 221

CFE\_SB\_TimeStampMsg  
cFE Message Characteristics APIs, 365

CFE\_SB\_TransmitBuffer  
cFE Zero Copy APIs, 359

CFE\_SB\_TransmitMsg  
cFE Send/Receive Message APIs, 356

CFE\_SB\_UNSUB\_ARG\_ERR\_EID  
cfe\_sb\_events.h, 1381

CFE\_SB\_UNSUB\_INV\_CALLER\_EID  
cfe\_sb\_events.h, 1382

CFE\_SB\_UNSUB\_INV\_PIPE\_EID  
cfe\_sb\_events.h, 1382

CFE\_SB\_UNSUB\_NO\_SUBS\_EID  
cfe\_sb\_events.h, 1382

CFE\_SB\_UNSUBSCRIPTION  
cfe\_sb\_api\_typedefs.h, 1214

CFE\_SB\_Unsubscribe  
cFE Message Subscription Control APIs, 352

CFE\_SB\_UnsubscribeLocal  
cFE Message Subscription Control APIs, 353

CFE\_SB\_ValueToMsgId  
cFE Message ID APIs, 368

CFE\_SB\_WRITE\_MAP\_INFO\_CC  
cfe\_sb\_msg.h, 1392

CFE\_SB\_WRITE\_PIPE\_INFO\_CC  
cfe\_sb\_msg.h, 1393

CFE\_SB\_WRITE\_ROUTING\_INFO\_CC  
cfe\_sb\_msg.h, 1394

CFE\_SB\_WRONG\_MSG\_TYPE  
cFE Return Code Defines, 221

CFE\_SB\_WriteFileInfoCmd, 696  
CommandHeader, 696  
Payload, 696

CFE\_SB\_WriteFileInfoCmd\_Payload, 697  
Filename, 697

CFE\_SB\_WriteFileInfoCmd\_Payload\_t  
cfe\_sb\_msg.h, 1400

CFE\_SB\_WriteFileInfoCmd\_t  
cfe\_sb\_msg.h, 1400

CFE\_SB\_WriteMapInfoCmd\_t  
cfe\_sb\_msg.h, 1400

CFE\_SB\_WritePipeInfoCmd\_t  
cfe\_sb\_msg.h, 1400

CFE\_SB\_WriteRoutingInfoCmd\_t  
cfe\_sb\_msg.h, 1400

CFE\_SERVICE\_BITMASK  
cfe\_error.h, 1146

CFE\_SEVERITY\_BITMASK  
cfe\_error.h, 1146

CFE\_SEVERITY\_ERROR  
cfe\_error.h, 1146

CFE\_SEVERITY\_INFO  
cfe\_error.h, 1146

CFE\_SEVERITY\_SUCCESS  
cfe\_error.h, 1146

CFE\_SET  
cfe\_sb.h, 1209

CFE\_SOFTWARE\_BUS\_SERVICE  
cfe\_error.h, 1147

CFE\_SRC\_VERSION  
cfe\_version.h, 1238

CFE\_SS\_INDEX  
ds\_file.c, 937

CFE\_STATUS\_BAD\_COMMAND\_CODE  
cFE Return Code Defines, 222

CFE\_STATUS\_EXTERNAL\_RESOURCE\_FAIL  
cFE Return Code Defines, 222

CFE\_STATUS\_NO\_COUNTER\_INCREMENT  
cFE Return Code Defines, 222

CFE\_STATUS\_NOT\_IMPLEMENTED  
cFE Return Code Defines, 222

CFE\_STATUS\_REQUEST\_ALREADY\_PENDING  
cFE Return Code Defines, 223

CFE\_STATUS\_STRING\_LENGTH  
cfe\_error.h, 1147

CFE\_STATUS\_UNKNOWN\_MSG\_ID  
cFE Return Code Defines, 223

CFE\_STATUS\_WRONG\_MSG\_LENGTH  
cFE Return Code Defines, 223

CFE\_STATUS\_C  
cfe\_error.h, 1147

CFE\_STR\_HELPER  
cfe\_version.h, 1238

CFE\_STR  
cfe\_version.h, 1238

CFE\_SUCCESS  
cFE Return Code Defines, 223

CFE\_Status\_t  
cfe\_error.h, 1148

CFE\_StatusString\_t  
cfe\_error.h, 1148

CFE\_TABLE\_SERVICE  
cfe\_error.h, 1147

CFE\_TBL\_ABORT\_LOAD\_CC  
cfe\_tbl\_msg.h, 1429

CFE\_TBL\_ACTIVATE\_CC  
cfe\_tbl\_msg.h, 1430

CFE\_TBL\_ACTIVATE\_DUMP\_ONLY\_ERR\_EID  
cfe\_tbl\_events.h, 1403

CFE\_TBL\_ACTIVATE\_ERR\_EID  
cfe\_tbl\_events.h, 1404

CFE\_TBL\_ASSUMED\_VALID\_INF\_EID  
cfe\_tbl\_events.h, 1404

CFE\_TBL\_AbortLoadCmd, 697  
CommandHeader, 698  
Payload, 698

CFE\_TBL\_AbortLoadCmd\_Payload, 698  
TableName, 699

CFE\_TBL\_AbortLoadCmd\_Payload\_t  
     cfe\_tbl\_msg.h, 1440

CFE\_TBL\_AbortLoadCmd\_t  
     cfe\_tbl\_msg.h, 1440

CFE\_TBL\_ActivateCmd, 699  
     CommandHeader, 700  
     Payload, 700

CFE\_TBL\_ActivateCmd\_Payload, 700  
     TableName, 701

CFE\_TBL\_ActivateCmd\_Payload\_t  
     cfe\_tbl\_msg.h, 1440

CFE\_TBL\_ActivateCmd\_t  
     cfe\_tbl\_msg.h, 1440

CFE\_TBL\_BAD\_ARGUMENT  
     cFE Return Code Defines, 224

CFE\_TBL\_BAD\_TABLE\_HANDLE  
     cfe\_tbl\_api\_typedefs.h, 1221

CFE\_TBL\_BufferSelect  
     cfe\_tbl\_extern\_typedefs.h, 1223

CFE\_TBL\_BufferSelect\_Enum\_t  
     cfe\_tbl\_extern\_typedefs.h, 1223

CFE\_TBL\_CC1\_ERR\_EID  
     cfe\_tbl\_events.h, 1404

CFE\_TBL\_CDS\_DELETE\_ERR\_EID  
     cfe\_tbl\_events.h, 1405

CFE\_TBL\_CDS\_DELETED\_INFO\_EID  
     cfe\_tbl\_events.h, 1405

CFE\_TBL\_CDS\_NOT\_FOUND\_ERR\_EID  
     cfe\_tbl\_events.h, 1405

CFE\_TBL\_CDS\_OWNER\_ACTIVE\_ERR\_EID  
     cfe\_tbl\_events.h, 1406

CFE\_TBL\_CMD\_MID  
     cpu1\_msgids.h, 1046

CFE\_TBL\_CREATING\_DUMP\_FILE\_ERR\_EID  
     cfe\_tbl\_events.h, 1406

CFE\_TBL\_CallbackFuncPtr\_t  
     cfe\_tbl\_api\_typedefs.h, 1221

CFE\_TBL\_DELETE\_CDS\_CC  
     cfe\_tbl\_msg.h, 1431

CFE\_TBL\_DUMP\_CC  
     cfe\_tbl\_msg.h, 1432

CFE\_TBL\_DUMP\_PENDING\_ERR\_EID  
     cfe\_tbl\_events.h, 1406

CFE\_TBL\_DUMP\_REGISTRY\_CC  
     cfe\_tbl\_msg.h, 1433

CFE\_TBL\_DelCDSCmd\_Payload, 701  
     TableName, 702

CFE\_TBL\_DelCDSCmd\_Payload\_t  
     cfe\_tbl\_msg.h, 1440

CFE\_TBL\_DeleteCDSCmd, 702  
     CommandHeader, 702  
     Payload, 703

CFE\_TBL\_DeleteCDSCmd\_t  
     cfe\_tbl\_msg.h, 1440

CFE\_TBL\_DumpCmd, 703  
     CommandHeader, 703  
     Payload, 704

CFE\_TBL\_DumpCmd\_Payload, 704  
     ActiveTableFlag, 705  
     DumpFilename, 705  
     TableName, 705

CFE\_TBL\_DumpCmd\_Payload\_t  
     cfe\_tbl\_msg.h, 1441

CFE\_TBL\_DumpCmd\_t  
     cfe\_tbl\_msg.h, 1441

CFE\_TBL\_DumpRegistryCmd, 705  
     CommandHeader, 706  
     Payload, 706

CFE\_TBL\_DumpRegistryCmd\_Payload, 706  
     DumpFilename, 707

CFE\_TBL\_DumpRegistryCmd\_Payload\_t  
     cfe\_tbl\_msg.h, 1441

CFE\_TBL\_DumpRegistryCmd\_t  
     cfe\_tbl\_msg.h, 1441

CFE\_TBL\_DumpToBuffer  
     cFE Manage Table Content APIs, 376

CFE\_TBL\_ERR\_ACCESS  
     cFE Return Code Defines, 224

CFE\_TBL\_ERR\_BAD\_CONTENT\_ID  
     cFE Return Code Defines, 224

CFE\_TBL\_ERR\_BAD\_PROCESSOR\_ID  
     cFE Return Code Defines, 224

CFE\_TBL\_ERR\_BAD\_SPACECRAFT\_ID  
     cFE Return Code Defines, 225

CFE\_TBL\_ERR\_BAD\_SUBTYPE\_ID  
     cFE Return Code Defines, 225

CFE\_TBL\_ERR\_DUMP\_ONLY  
     cFE Return Code Defines, 225

CFE\_TBL\_ERR\_DUPLICATE\_DIFF\_SIZE  
     cFE Return Code Defines, 225

CFE\_TBL\_ERR\_DUPLICATE\_NOT\_OWNED  
     cFE Return Code Defines, 226

CFE\_TBL\_ERR\_FILE\_FOR\_WRONG\_TABLE  
     cFE Return Code Defines, 226

CFE\_TBL\_ERR\_FILE\_SIZE\_INCONSISTENT  
     cFE Return Code Defines, 226

CFE\_TBL\_ERR\_FILE\_TOO\_LARGE  
     cFE Return Code Defines, 226

CFE\_TBL\_ERR\_FILENAME\_TOO\_LONG  
     cFE Return Code Defines, 227

CFE\_TBL\_ERR\_HANDLES\_FULL  
     cFE Return Code Defines, 227

CFE\_TBL\_ERR\_ILLEGAL\_SRC\_TYPE  
     cFE Return Code Defines, 227

CFE\_TBL\_ERR\_INVALID\_HANDLE  
     cFE Return Code Defines, 227

CFE\_TBL\_ERR\_INVALID\_NAME  
     cFE Return Code Defines, 228

CFE\_TBL\_ERR\_INVALID\_OPTIONS  
  cFE Return Code Defines, 228

CFE\_TBL\_ERR\_INVALID\_SIZE  
  cFE Return Code Defines, 228

CFE\_TBL\_ERR\_LOAD\_IN\_PROGRESS  
  cFE Return Code Defines, 229

CFE\_TBL\_ERR\_LOAD\_INCOMPLETE  
  cFE Return Code Defines, 229

CFE\_TBL\_ERR\_NEVER\_LOADED  
  cFE Return Code Defines, 229

CFE\_TBL\_ERR\_NO\_ACCESS  
  cFE Return Code Defines, 229

CFE\_TBL\_ERR\_NO\_BUFFER\_AVAIL  
  cFE Return Code Defines, 230

CFE\_TBL\_ERR\_NO\_STD\_HEADER  
  cFE Return Code Defines, 230

CFE\_TBL\_ERR\_NO\_TBL\_HEADER  
  cFE Return Code Defines, 230

CFE\_TBL\_ERR\_PARTIAL\_LOAD  
  cFE Return Code Defines, 230

CFE\_TBL\_ERR\_REGISTRY\_FULL  
  cFE Return Code Defines, 231

CFE\_TBL\_ERR\_SHORT\_FILE  
  cFE Return Code Defines, 231

CFE\_TBL\_ERR\_UNREGISTERED  
  cFE Return Code Defines, 231

CFE\_TBL\_FAIL\_HK\_SEND\_ERR\_EID  
  cfe\_tbl\_events.h, 1407

CFE\_TBL\_FAIL\_NOTIFY\_SEND\_ERR\_EID  
  cfe\_tbl\_events.h, 1407

CFE\_TBL\_FILE\_ACCESS\_ERR\_EID  
  cfe\_tbl\_events.h, 1407

CFE\_TBL\_FILE\_INCOMPLETE\_ERR\_EID  
  cfe\_tbl\_events.h, 1408

CFE\_TBL\_FILE\_LOADED\_INF\_EID  
  cfe\_tbl\_events.h, 1408

CFE\_TBL\_FILE\_STD\_HDR\_ERR\_EID  
  cfe\_tbl\_events.h, 1408

CFE\_TBL\_FILE\_SUBTYPE\_ERR\_EID  
  cfe\_tbl\_events.h, 1409

CFE\_TBL\_FILE\_TBL\_HDR\_ERR\_EID  
  cfe\_tbl\_events.h, 1409

CFE\_TBL\_FILE\_TOO\_BIG\_ERR\_EID  
  cfe\_tbl\_events.h, 1409

CFE\_TBL\_FILE\_TYPE\_ERR\_EID  
  cfe\_tbl\_events.h, 1410

CFE\_TBL\_FILEDEF  
  cfe\_tbl\_filedef.h, 1225

CFE\_TBL\_File\_Hdr, 707  
  NumBytes, 708  
  Offset, 708  
  Reserved, 708  
  TableName, 708

CFE\_TBL\_File\_Hdr\_t

          cfe\_tbl\_extern\_typedefs.h, 1223

CFE\_TBL\_FileDef, 709  
  Description, 709  
  ObjectName, 709  
  ObjectSize, 709  
  TableName, 710  
  TgtFilename, 710

CFE\_TBL\_FileDef\_t  
  cfe\_tbl\_filedef.h, 1225

CFE\_TBL\_GetAddress  
  cFE Access Table Content APIs, 383

CFE\_TBL\_GetAddresses  
  cFE Access Table Content APIs, 384

CFE\_TBL\_GetInfo  
  cFE Get Table Information APIs, 388

CFE\_TBL\_GetStatus  
  cFE Get Table Information APIs, 389

CFE\_TBL\_HANDLE\_ACCESS\_ERR\_EID  
  cfe\_tbl\_events.h, 1410

CFE\_TBL\_HK\_TLM\_MID  
  cpu1\_msghids.h, 1046

CFE\_TBL\_Handle\_t  
  cfe\_tbl\_api\_typedefs.h, 1221

CFE\_TBL\_HousekeepingTlm, 710  
  Payload, 711  
  TelemetryHeader, 711

CFE\_TBL\_HousekeepingTlm\_Payload, 711  
  ActiveBuffer, 712  
  ByteAlignPad1, 712  
  CommandCounter, 713  
  CommandErrorCounter, 713  
  FailedValCounter, 713  
  LastFileDumped, 713  
  LastFileLoaded, 714  
  LastTableLoaded, 714  
  LastUpdateTime, 714  
  LastUpdatedTable, 714  
  LastValCrc, 715  
  LastValStatus, 715  
  LastValTableName, 715  
  MemPoolHandle, 715  
  NumFreeSharedBufs, 716  
  NumLoadPending, 716  
  NumTables, 716  
  NumValRequests, 716  
  SuccessValCounter, 717  
  ValidationCounter, 717

CFE\_TBL\_HousekeepingTlm\_Payload\_t  
  cfe\_tbl\_msg.h, 1441

CFE\_TBL\_HousekeepingTlm\_t  
  cfe\_tbl\_msg.h, 1441

CFE\_TBL\_ILLEGAL\_BUFF\_PARAM\_ERR\_EID  
  cfe\_tbl\_events.h, 1410

CFE\_TBL\_IN\_REGISTRY\_ERR\_EID

cfe\_tbl\_events.h, [1411](#)  
**CFE\_TBL\_INFO\_DUMP\_PENDING**  
 cFE Return Code Defines, [231](#)  
**CFE\_TBL\_INFO\_NO\_UPDATE\_PENDING**  
 cFE Return Code Defines, [232](#)  
**CFE\_TBL\_INFO\_NO\_VALIDATION\_PENDING**  
 cFE Return Code Defines, [232](#)  
**CFE\_TBL\_INFO\_RECOVERED\_TBL**  
 cFE Return Code Defines, [232](#)  
**CFE\_TBL\_INFO\_TABLE\_LOCKED**  
 cFE Return Code Defines, [232](#)  
**CFE\_TBL\_INFO\_UPDATE\_PENDING**  
 cFE Return Code Defines, [233](#)  
**CFE\_TBL\_INFO\_UPDATED**  
 cFE Return Code Defines, [233](#)  
**CFE\_TBL\_INFO\_VALIDATION\_PENDING**  
 cFE Return Code Defines, [233](#)  
**CFE\_TBL\_INIT\_INF\_EID**  
 cfe\_tbl\_events.h, [1411](#)  
**CFE\_TBL\_INTERNAL\_ERROR\_ERR\_EID**  
 cfe\_tbl\_events.h, [1411](#)  
**CFE\_TBL\_Info**, [717](#)  
 Crc, [718](#)  
 Critical, [718](#)  
 DoubleBuffered, [719](#)  
 DumpOnly, [719](#)  
 FileCreateTimeSecs, [719](#)  
 FileCreateTimeSubSecs, [719](#)  
 LastFileLoaded, [719](#)  
 NumUsers, [720](#)  
 Size, [720](#)  
 TableLoadedOnce, [720](#)  
 TimeOfLastUpdate, [720](#)  
 UserDefAddr, [720](#)  
**CFE\_TBL\_Info\_t**  
 cfe\_tbl\_api\_typedefs.h, [1221](#)  
**CFE\_TBL\_LEN\_ERR\_EID**  
 cfe\_tbl\_events.h, [1412](#)  
**CFE\_TBL\_LOAD\_ABORT\_ERR\_EID**  
 cfe\_tbl\_events.h, [1412](#)  
**CFE\_TBL\_LOAD\_ABORT\_INF\_EID**  
 cfe\_tbl\_events.h, [1412](#)  
**CFE\_TBL\_LOAD\_CC**  
 cfe\_tbl\_msg.h, [1434](#)  
**CFE\_TBL\_LOAD\_EXCEEDS\_SIZE\_ERR\_EID**  
 cfe\_tbl\_events.h, [1413](#)  
**CFE\_TBL\_LOAD\_FILENAME\_LONG\_ERR\_EID**  
 cfe\_tbl\_events.h, [1413](#)  
**CFE\_TBL\_LOAD\_IN\_PROGRESS\_ERR\_EID**  
 cfe\_tbl\_events.h, [1413](#)  
**CFE\_TBL\_LOAD\_PEND\_REQ\_INF\_EID**  
 cfe\_tbl\_events.h, [1414](#)  
**CFE\_TBL\_LOAD\_SUCCESS\_INF\_EID**  
 cfe\_tbl\_events.h, [1414](#)  
**CFE\_TBL\_LOAD\_TBLNAME\_MISMATCH\_ERR\_EID**  
 cfe\_tbl\_events.h, [1414](#)  
**CFE\_TBL\_LOAD\_TYPE\_ERR\_EID**  
 cfe\_tbl\_events.h, [1415](#)  
**CFE\_TBL\_LOAD\_VAL\_ERR\_EID**  
 cfe\_tbl\_events.h, [1415](#)  
**CFE\_TBL\_LOADING\_A\_DUMP\_ONLY\_ERR\_EID**  
 cfe\_tbl\_events.h, [1415](#)  
**CFE\_TBL\_LOADING\_PENDING\_ERR\_EID**  
 cfe\_tbl\_events.h, [1416](#)  
**CFE\_TBL\_Load**  
 cFE Manage Table Content APIs, [377](#)  
**CFE\_TBL\_LoadCmd**, [721](#)  
 CommandHeader, [721](#)  
 Payload, [721](#)  
**CFE\_TBL\_LoadCmd\_Payload**, [722](#)  
 LoadFilename, [722](#)  
**CFE\_TBL\_LoadCmd\_Payload\_t**  
 cfe\_tbl\_msg.h, [1442](#)  
**CFE\_TBL\_LoadCmd\_t**  
 cfe\_tbl\_msg.h, [1442](#)  
**CFE\_TBL\_MAX\_FULL\_NAME\_LEN**  
 cfe\_tbl\_api\_typedefs.h, [1221](#)  
**CFE\_TBL\_MESSAGE\_ERROR**  
 cFE Return Code Defines, [233](#)  
**CFE\_TBL\_MID\_ERR\_EID**  
 cfe\_tbl\_events.h, [1416](#)  
**CFE\_TBL\_Manage**  
 cFE Manage Table Content APIs, [378](#)  
**CFE\_TBL\_Modified**  
 cFE Manage Table Content APIs, [379](#)  
**CFE\_TBL\_NO\_INACTIVE\_BUFFER\_ERR\_EID**  
 cfe\_tbl\_events.h, [1416](#)  
**CFE\_TBL\_NO\_SUCH\_TABLE\_ERR\_EID**  
 cfe\_tbl\_events.h, [1417](#)  
**CFE\_TBL\_NO\_WORK\_BUFFERS\_ERR\_EID**  
 cfe\_tbl\_events.h, [1417](#)  
**CFE\_TBL\_NOOP\_CC**  
 cfe\_tbl\_msg.h, [1435](#)  
**CFE\_TBL\_NOOP\_INF\_EID**  
 cfe\_tbl\_events.h, [1417](#)  
**CFE\_TBL\_NOT\_CRITICAL\_TBL\_ERR\_EID**  
 cfe\_tbl\_events.h, [1418](#)  
**CFE\_TBL\_NOT\_IMPLEMENTED**  
 cFE Return Code Defines, [234](#)  
**CFE\_TBL\_NOT\_IN\_CRIT\_REG\_ERR\_EID**  
 cfe\_tbl\_events.h, [1418](#)  
**CFE\_TBL\_NoArgsCmd**, [723](#)  
 CommandHeader, [723](#)  
**CFE\_TBL\_NoArgsCmd\_t**  
 cfe\_tbl\_msg.h, [1442](#)  
**CFE\_TBL\_NoopCmd\_t**  
 cfe\_tbl\_msg.h, [1442](#)  
**CFE\_TBL\_NotifyByMessage**

cFE Get Table Information APIs, 390  
CFE\_TBL\_NotifyCmd, 723  
    CommandHeader, 724  
    Payload, 724  
CFE\_TBL\_NotifyCmd\_Payload, 724  
    Parameter, 725  
CFE\_TBL\_NotifyCmd\_Payload\_t  
    cfe\_tbl\_msg.h, 1442  
CFE\_TBL\_NotifyCmd\_t  
    cfe\_tbl\_msg.h, 1443  
CFE\_TBL\_OPT\_BUFFER\_MSK  
    cFE Table Type Defines, 392  
CFE\_TBL\_OPT\_CRITICAL\_MSK  
    cFE Table Type Defines, 393  
CFE\_TBL\_OPT\_CRITICAL  
    cFE Table Type Defines, 392  
CFE\_TBL\_OPT\_DBL\_BUFFER  
    cFE Table Type Defines, 393  
CFE\_TBL\_OPT\_DEFAULT  
    cFE Table Type Defines, 393  
CFE\_TBL\_OPT\_DUMP\_ONLY  
    cFE Table Type Defines, 393  
CFE\_TBL\_OPT\_LD\_DMP\_MSK  
    cFE Table Type Defines, 393  
CFE\_TBL\_OPT\_LOAD\_DUMP  
    cFE Table Type Defines, 394  
CFE\_TBL\_OPT\_NOT\_CRITICAL  
    cFE Table Type Defines, 394  
CFE\_TBL\_OPT\_NOT\_USR\_DEF  
    cFE Table Type Defines, 394  
CFE\_TBL\_OPT\_SNGL\_BUFFER  
    cFE Table Type Defines, 394  
CFE\_TBL\_OPT\_USR\_DEF\_ADDR  
    cFE Table Type Defines, 394  
CFE\_TBL\_OPT\_USR\_DEF\_MSK  
    cFE Table Type Defines, 395  
CFE\_TBL\_OVERWRITE\_DUMP\_INF\_EID  
    cfe\_tbl\_events.h, 1418  
CFE\_TBL\_OVERWRITE\_REG\_DUMP\_INF\_EID  
    cfe\_tbl\_events.h, 1419  
CFE\_TBL\_PARTIAL\_LOAD\_ERR\_EID  
    cfe\_tbl\_events.h, 1419  
CFE\_TBL\_PROCESSOR\_ID\_ERR\_EID  
    cfe\_tbl\_events.h, 1419  
CFE\_TBL\_REG\_TLM\_MID  
    cpu1\_msgids.h, 1046  
CFE\_TBL\_REGISTER\_ERR\_EID  
    cfe\_tbl\_events.h, 1420  
CFE\_TBL\_RESET\_COUNTERS\_CC  
    cfe\_tbl\_msg.h, 1436  
CFE\_TBL\_RESET\_INF\_EID  
    cfe\_tbl\_events.h, 1420  
CFE\_TBL\_Register  
    cFE Registration APIs, 370  
CFE\_TBL\_ReleaseAddress  
    cFE Access Table Content APIs, 385  
CFE\_TBL\_ReleaseAddresses  
    cFE Access Table Content APIs, 386  
CFE\_TBL\_ResetCountersCmd\_t  
    cfe\_tbl\_msg.h, 1443  
CFE\_TBL\_SEND\_HK\_MID  
    cpu1\_msgids.h, 1047  
CFE\_TBL\_SEND\_REGISTRY\_CC  
    cfe\_tbl\_msg.h, 1437  
CFE\_TBL\_SHARE\_ERR\_EID  
    cfe\_tbl\_events.h, 1420  
CFE\_TBL\_SPACECRAFT\_ID\_ERR\_EID  
    cfe\_tbl\_events.h, 1421  
CFE\_TBL\_SendRegistryCmd, 725  
    CommandHeader, 726  
    Payload, 726  
CFE\_TBL\_SendRegistryCmd\_Payload, 726  
    TableName, 727  
CFE\_TBL\_SendRegistryCmd\_Payload\_t  
    cfe\_tbl\_msg.h, 1443  
CFE\_TBL\_SendRegistryCmd\_t  
    cfe\_tbl\_msg.h, 1443  
CFE\_TBL\_Share  
    cFE Registration APIs, 373  
CFE\_TBL\_SrcEnum  
    cfe\_tbl\_api\_typedefs.h, 1222  
CFE\_TBL\_SrcEnum\_t  
    cfe\_tbl\_api\_typedefs.h, 1222  
CFE\_TBL\_TLM\_REG\_CMD\_INF\_EID  
    cfe\_tbl\_events.h, 1421  
CFE\_TBL\_TOO\_MANY\_DUMPS\_ERR\_EID  
    cfe\_tbl\_events.h, 1421  
CFE\_TBL\_TOO\_MANY\_VALIDATIONS\_ERR\_EID  
    cfe\_tbl\_events.h, 1422  
CFE\_TBL\_TableRegistryTlm, 727  
    Payload, 728  
    TelemetryHeader, 728  
CFE\_TBL\_TableRegistryTlm\_t  
    cfe\_tbl\_msg.h, 1443  
CFE\_TBL\_TblRegPacket\_Payload, 728  
    ActiveBufferAddr, 729  
    ByteAlign4, 729  
    Crc, 730  
    Critical, 730  
    DoubleBuffered, 730  
    DumpOnly, 730  
    FileCreateTimeSecs, 731  
    FileCreateTimeSubSecs, 731  
    InactiveBufferAddr, 731  
    LastFileLoaded, 731  
    LoadPending, 732  
    Name, 732  
    OwnerAppName, 732

Size, [732](#)  
TableLoadedOnce, [733](#)  
TimeOfLastUpdate, [733](#)  
ValidationFuncPtr, [733](#)  
**CFE\_TBL\_TblRegPacket\_Payload\_t**  
  cfe\_tbl\_msg.h, [1443](#)  
**CFE\_TBL\_UNREGISTER\_ERR\_EID**  
  cfe\_tbl\_events.h, [1422](#)  
**CFE\_TBL\_UNVALIDATED\_ERR\_EID**  
  cfe\_tbl\_events.h, [1422](#)  
**CFE\_TBL\_UPDATE\_ERR\_EID**  
  cfe\_tbl\_events.h, [1423](#)  
**CFE\_TBL\_UPDATE\_SUCCESS\_INF\_EID**  
  cfe\_tbl\_events.h, [1423](#)  
**CFE\_TBL\_Unregister**  
  cFE Registration APIs, [374](#)  
**CFE\_TBL\_Update**  
  cFE Manage Table Content APIs, [380](#)  
**CFE\_TBL\_VAL\_REQ\_MADE\_INF\_EID**  
  cfe\_tbl\_events.h, [1423](#)  
**CFE\_TBL\_VALIDATE\_CC**  
  cfe\_tbl\_msg.h, [1438](#)  
**CFE\_TBL\_VALIDATION\_ERR\_EID**  
  cfe\_tbl\_events.h, [1424](#)  
**CFE\_TBL\_VALIDATION\_INF\_EID**  
  cfe\_tbl\_events.h, [1424](#)  
**CFE\_TBL\_Validate**  
  cFE Manage Table Content APIs, [381](#)  
**CFE\_TBL\_ValidateCmd**, [734](#)  
  CommandHeader, [734](#)  
  Payload, [734](#)  
**CFE\_TBL\_ValidateCmd\_Payload**, [735](#)  
  ActiveTableFlag, [735](#)  
  TableName, [735](#)  
**CFE\_TBL\_ValidateCmd\_Payload\_t**  
  cfe\_tbl\_msg.h, [1444](#)  
**CFE\_TBL\_ValidateCmd\_t**  
  cfe\_tbl\_msg.h, [1444](#)  
**CFE\_TBL\_WARN\_DUPLICATE**  
  cFE Return Code Defines, [234](#)  
**CFE\_TBL\_WARN\_NOT\_CRITICAL**  
  cFE Return Code Defines, [234](#)  
**CFE\_TBL\_WARN\_PARTIAL\_LOAD**  
  cFE Return Code Defines, [234](#)  
**CFE\_TBL\_WARN\_SHORT\_FILE**  
  cFE Return Code Defines, [235](#)  
**CFE\_TBL\_WRITE\_CFE\_HDR\_ERR\_EID**  
  cfe\_tbl\_events.h, [1424](#)  
**CFE\_TBL\_WRITE\_DUMP\_INF\_EID**  
  cfe\_tbl\_events.h, [1425](#)  
**CFE\_TBL\_WRITE\_REG\_DUMP\_INF\_EID**  
  cfe\_tbl\_events.h, [1425](#)  
**CFE\_TBL\_WRITE\_TBL\_HDR\_ERR\_EID**  
  cfe\_tbl\_events.h, [1425](#)

**CFE\_TBL\_WRITE\_TBL\_IMG\_ERR\_EID**  
  cfe\_tbl\_events.h, [1426](#)  
**CFE\_TBL\_WRITE\_TBL\_REG\_ERR\_EID**  
  cfe\_tbl\_events.h, [1426](#)  
**CFE\_TBL\_ZERO\_LENGTH\_LOAD\_ERR\_EID**  
  cfe\_tbl\_events.h, [1426](#)  
**CFE\_TEST\_CMD\_MID**  
  cpu1\_msgids.h, [1047](#)  
**CFE\_TEST\_HK\_TLM\_MID**  
  cpu1\_msgids.h, [1047](#)  
**CFE\_TIME\_1HZ\_CFG\_EID**  
  cfe\_time\_events.h, [1446](#)  
**CFE\_TIME\_1HZ\_CMD\_MID**  
  cpu1\_msgids.h, [1047](#)  
**CFE\_TIME\_1HZ\_EID**  
  cfe\_time\_events.h, [1446](#)  
**CFE\_TIME\_1HzCmd\_t**  
  cfe\_time\_msg.h, [1478](#)  
**CFE\_TIME\_ADD\_1HZ\_ADJUSTMENT\_CC**  
  cfe\_time\_msg.h, [1461](#)  
**CFE\_TIME\_ADD\_ADJUST\_CC**  
  cfe\_time\_msg.h, [1462](#)  
**CFE\_TIME\_ADD\_DELAY\_CC**  
  cfe\_time\_msg.h, [1463](#)  
**CFE\_TIME\_Add**  
  cFE Time Arithmetic APIs, [403](#)  
**CFE\_TIME\_Add1HZAdjustmentCmd\_t**  
  cfe\_time\_msg.h, [1479](#)  
**CFE\_TIME\_AddAdjustCmd\_t**  
  cfe\_time\_msg.h, [1479](#)  
**CFE\_TIME\_AddDelayCmd\_t**  
  cfe\_time\_msg.h, [1479](#)  
**CFE\_TIME\_AdjustDirection**  
  cfe\_time\_extern\_typedefs.h, [1233](#)  
**CFE\_TIME\_AdjustDirection\_Enum\_t**  
  cfe\_time\_extern\_typedefs.h, [1231](#)  
**CFE\_TIME\_BAD\_ARGUMENT**  
  cFE Return Code Defines, [235](#)  
**CFE\_TIME\_CALLBACK\_NOT\_REGISTERED**  
  cFE Return Code Defines, [235](#)  
**CFE\_TIME\_CC\_ERR\_EID**  
  cfe\_time\_events.h, [1446](#)  
**CFE\_TIME\_CMD\_MID**  
  cpu1\_msgids.h, [1047](#)  
**CFE\_TIME\_ClockState**  
  cfe\_time\_extern\_typedefs.h, [1234](#)  
**CFE\_TIME\_ClockState\_Enum\_t**  
  cfe\_time\_extern\_typedefs.h, [1231](#)  
**CFE\_TIME\_Compare**  
  cFE Time Arithmetic APIs, [404](#)  
  cfe\_time\_api\_typedefs.h, [1229](#)  
**CFE\_TIME\_Compare\_t**  
  cfe\_time\_api\_typedefs.h, [1229](#)  
**CFE\_TIME\_Copy**

cfe\_time.h, 1227  
CFE\_TIME\_DATA\_CMD\_MID  
cpu1\_msgids.h, 1047  
CFE\_TIME\_DELAY\_CFG\_EID  
cfe\_time\_events.h, 1447  
CFE\_TIME\_DELAY\_EID  
cfe\_time\_events.h, 1447  
CFE\_TIME\_DELAY\_ERR\_EID  
cfe\_time\_events.h, 1447  
CFE\_TIME\_DELTA\_CFG\_EID  
cfe\_time\_events.h, 1448  
CFE\_TIME\_DELTA\_EID  
cfe\_time\_events.h, 1448  
CFE\_TIME\_DELTA\_ERR\_EID  
cfe\_time\_events.h, 1448  
CFE\_TIME\_DIAG\_EID  
cfe\_time\_events.h, 1449  
CFE\_TIME\_DIAG\_TLM\_MID  
cpu1\_msgids.h, 1048  
CFE\_TIME\_DiagnosticTlm, 736  
    Payload, 736  
    TelemetryHeader, 736  
CFE\_TIME\_DiagnosticTlm\_Payload, 736  
    AtToneDelay, 739  
    AtToneLatch, 739  
    AtToneLeapSeconds, 739  
    AtToneMET, 739  
    AtToneSTCF, 739  
    ClockFlyState, 740  
    ClockSetState, 740  
    ClockSignal, 740  
    ClockSource, 740  
    ClockStateAPI, 741  
    ClockStateFlags, 741  
    CurrentLatch, 741  
    CurrentMET, 741  
    CurrentTAI, 742  
    CurrentUTC, 742  
    DataStoreStatus, 742  
    DelayDirection, 742  
    Forced2Fly, 743  
    LocallIntCounter, 743  
    LocalTaskCounter, 743  
    MaxElapsed, 743  
    MaxLocalClock, 744  
    MinElapsed, 744  
    OneHzAdjust, 744  
    OneHzDirection, 744  
    OneTimeAdjust, 745  
    OneTimeDirection, 745  
    ServerFlyState, 745  
    TimeSinceTone, 745  
    ToneDataCounter, 746  
    ToneDataLatch, 746  
    ToneIntCounter, 746  
    ToneIntErrorCounter, 746  
    ToneMatchCounter, 747  
    ToneMatchErrorCounter, 747  
    ToneOverLimit, 747  
    ToneSignalCounter, 747  
    ToneSignalLatch, 748  
    ToneTaskCounter, 748  
    ToneUnderLimit, 748  
    VersionCounter, 748  
    VirtualMET, 749  
CFE\_TIME\_DiagnosticTlm\_Payload\_t  
    cfe\_time\_msg.h, 1479  
CFE\_TIME\_DiagnosticTlm\_t  
    cfe\_time\_msg.h, 1479  
CFE\_TIME\_ExternalGPS  
    cFE External Time Source APIs, 409  
CFE\_TIME\_ExternalMET  
    cFE External Time Source APIs, 410  
CFE\_TIME\_ExternalTime  
    cFE External Time Source APIs, 410  
CFE\_TIME\_ExternalTone  
    cFE External Time Source APIs, 411  
CFE\_TIME\_FLAG\_ADD1HZ  
    cFE Clock State Flag Defines, 418  
CFE\_TIME\_FLAG\_ADDADJ  
    cFE Clock State Flag Defines, 418  
CFE\_TIME\_FLAG\_ADDTCL  
    cFE Clock State Flag Defines, 419  
CFE\_TIME\_FLAG\_CLKSET  
    cFE Clock State Flag Defines, 419  
CFE\_TIME\_FLAG\_CMDFLY  
    cFE Clock State Flag Defines, 419  
CFE\_TIME\_FLAG\_FLYING  
    cFE Clock State Flag Defines, 419  
CFE\_TIME\_FLAG\_GDTONE  
    cFE Clock State Flag Defines, 419  
CFE\_TIME\_FLAG\_REFERR  
    cFE Clock State Flag Defines, 420  
CFE\_TIME\_FLAG\_SERVER  
    cFE Clock State Flag Defines, 420  
CFE\_TIME\_FLAG\_SRCINT  
    cFE Clock State Flag Defines, 420  
CFE\_TIME\_FLAG\_SIGPRI  
    cFE Clock State Flag Defines, 420  
CFE\_TIME\_FLAG\_SRCINT  
    cFE Clock State Flag Defines, 420  
CFE\_TIME\_FLAG\_SRVFLY  
    cFE Clock State Flag Defines, 420  
CFE\_TIME\_FLAG\_UNUSED  
    cFE Clock State Flag Defines, 420  
CFE\_TIME\_FLY\_OFF\_EID  
    cfe\_time\_events.h, 1449  
CFE\_TIME\_FLY\_ON\_EID  
    cfe\_time\_events.h, 1449  
CFE\_TIME\_FakeToneCmd\_t

cfe\_time\_msg.h, 1479  
 CFE\_TIME\_FlagBit  
     cfe\_time\_extern\_typedefs.h, 1234  
 CFE\_TIME\_FlagBit\_Enum\_t  
     cfe\_time\_extern\_typedefs.h, 1232  
 CFE\_TIME\_FlywheelState  
     cfe\_time\_extern\_typedefs.h, 1235  
 CFE\_TIME\_FlywheelState\_Enum\_t  
     cfe\_time\_extern\_typedefs.h, 1232  
 CFE\_TIME\_GetClockInfo  
     cFE Get Time Information APIs, 400  
 CFE\_TIME\_GetClockState  
     cFE Get Time Information APIs, 400  
 CFE\_TIME\_GetLeapSeconds  
     cFE Get Time Information APIs, 401  
 CFE\_TIME\_GetMETseconds  
     cFE Get Current Time APIs, 396  
 CFE\_TIME\_GetMETsubsecs  
     cFE Get Current Time APIs, 397  
 CFE\_TIME\_GetMET  
     cFE Get Current Time APIs, 396  
 CFE\_TIME\_GetSTCF  
     cFE Get Time Information APIs, 401  
 CFE\_TIME\_GetTAI  
     cFE Get Current Time APIs, 397  
 CFE\_TIME\_GetTime  
     cFE Get Current Time APIs, 398  
 CFE\_TIME\_GetUTC  
     cFE Get Current Time APIs, 399  
 CFE\_TIME\_HK\_TLM\_MID  
     cpu1\_msghdr.h, 1048  
 CFE\_TIME\_HousekeepingTlm, 749  
     Payload, 750  
         TelemetryHeader, 750  
 CFE\_TIME\_HousekeepingTlm\_Payload, 750  
     ClockStateAPI, 751  
     ClockStateFlags, 751  
     CommandCounter, 751  
     CommandErrorCounter, 752  
     LeapSeconds, 752  
     Seconds1HzAdj, 752  
     SecondsDelay, 752  
     SecondsMET, 753  
     SecondsSTCF, 753  
     Subsecs1HzAdj, 753  
     SubsecsDelay, 753  
     SubsecsMET, 754  
     SubsecsSTCF, 754  
 CFE\_TIME\_HousekeepingTlm\_Payload\_t  
     cfe\_time\_msg.h, 1480  
 CFE\_TIME\_HousekeepingTlm\_t  
     cfe\_time\_msg.h, 1480  
 CFE\_TIME\_ID\_ERR\_EID  
     cfe\_time\_events.h, 1450  
 CFE\_TIME\_INIT\_EID  
     cfe\_time\_events.h, 1450  
 CFE\_TIME\_INTERNAL\_ONLY  
     cFE Return Code Defines, 235  
 CFE\_TIME\_LEAPS\_CFG\_EID  
     cfe\_time\_events.h, 1450  
 CFE\_TIME\_LEAPS\_EID  
     cfe\_time\_events.h, 1451  
 CFE\_TIME\_LEN\_ERR\_EID  
     cfe\_time\_events.h, 1451  
 CFE\_TIME\_LeapsCmd\_Payload, 754  
     LeapSeconds, 755  
 CFE\_TIME\_LeapsCmd\_Payload\_t  
     cfe\_time\_msg.h, 1480  
 CFE\_TIME\_Local1HzISR  
     cFE Miscellaneous Time APIs, 414  
 CFE\_TIME\_MET2SCTime  
     cFE Time Conversion APIs, 406  
 CFE\_TIME\_MET\_CFG\_EID  
     cfe\_time\_events.h, 1451  
 CFE\_TIME\_MET\_EID  
     cfe\_time\_events.h, 1452  
 CFE\_TIME\_MET\_ERR\_EID  
     cfe\_time\_events.h, 1452  
 CFE\_TIME\_Micro2SubSecs  
     cFE Time Conversion APIs, 406  
 CFE\_TIME\_NOOP\_CC  
     cfe\_time\_msg.h, 1464  
 CFE\_TIME\_NOOP\_EID  
     cfe\_time\_events.h, 1452  
 CFE\_TIME\_NOT\_IMPLEMENTED  
     cFE Return Code Defines, 236  
 CFE\_TIME\_NoArgsCmd, 755  
     CommandHeader, 756  
 CFE\_TIME\_NoArgsCmd\_t  
     cfe\_time\_msg.h, 1480  
 CFE\_TIME\_NoopCmd\_t  
     cfe\_time\_msg.h, 1480  
 CFE\_TIME\_OUT\_OF\_RANGE  
     cFE Return Code Defines, 236  
 CFE\_TIME\_OneHzAdjustmentCmd, 756  
     CommandHeader, 756  
     Payload, 756  
 CFE\_TIME\_OneHzAdjustmentCmd\_Payload, 757  
     Seconds, 757  
     Subseconds, 757  
 CFE\_TIME\_OneHzAdjustmentCmd\_Payload\_t  
     cfe\_time\_msg.h, 1480  
 CFE\_TIME\_OneHzAdjustmentCmd\_t  
     cfe\_time\_msg.h, 1481  
 CFE\_TIME\_PRINTED\_STRING\_SIZE  
     cfe\_time\_api\_typedefs.h, 1228  
 CFE\_TIME\_Print  
     cFE Miscellaneous Time APIs, 414

CFE\_TIME\_RESET\_COUNTERS\_CC  
  cfe\_time\_msg.h, 1465

CFE\_TIME\_RESET\_EID  
  cfe\_time\_events.h, 1453

CFE\_TIME\_RegisterSyncCallback  
  cFE External Time Source APIs, 412

CFE\_TIME\_ResetCountersCmd\_t  
  cfe\_time\_msg.h, 1481

CFE\_TIME\_SEND\_CMD\_MID  
  cpu1\_msgids.h, 1048

CFE\_TIME\_SEND\_DIAGNOSTIC\_TLM\_CC  
  cfe\_time\_msg.h, 1466

CFE\_TIME\_SEND\_HK\_MID  
  cpu1\_msgids.h, 1048

CFE\_TIME\_SERVICE  
  cfe\_error.h, 1147

CFE\_TIME\_SET\_LEAP\_SECONDS\_CC  
  cfe\_time\_msg.h, 1467

CFE\_TIME\_SET\_MET\_CC  
  cfe\_time\_msg.h, 1468

CFE\_TIME\_SET\_SIGNAL\_CC  
  cfe\_time\_msg.h, 1469

CFE\_TIME\_SET\_SOURCE\_CC  
  cfe\_time\_msg.h, 1470

CFE\_TIME\_SET\_STATE\_CC  
  cfe\_time\_msg.h, 1471

CFE\_TIME\_SET\_STCF\_CC  
  cfe\_time\_msg.h, 1473

CFE\_TIME\_SET\_TIME\_CC  
  cfe\_time\_msg.h, 1474

CFE\_TIME\_SIGNAL\_CFG\_EID  
  cfe\_time\_events.h, 1453

CFE\_TIME\_SIGNAL\_EID  
  cfe\_time\_events.h, 1453

CFE\_TIME\_SIGNAL\_ERR\_EID  
  cfe\_time\_events.h, 1454

CFE\_TIME\_SOURCE\_CFG\_EID  
  cfe\_time\_events.h, 1454

CFE\_TIME\_SOURCE\_EID  
  cfe\_time\_events.h, 1454

CFE\_TIME\_SOURCE\_ERR\_EID  
  cfe\_time\_events.h, 1455

CFE\_TIME\_STATE\_EID  
  cfe\_time\_events.h, 1455

CFE\_TIME\_STATE\_ERR\_EID  
  cfe\_time\_events.h, 1455

CFE\_TIME\_STCF\_CFG\_EID  
  cfe\_time\_events.h, 1456

CFE\_TIME\_STCF\_EID  
  cfe\_time\_events.h, 1456

CFE\_TIME\_STCF\_ERR\_EID  
  cfe\_time\_events.h, 1456

CFE\_TIME\_SUB\_1HZ\_ADJUSTMENT\_CC  
  cfe\_time\_msg.h, 1475

CFE\_TIME\_SUB\_ADJUST\_CC  
  cfe\_time\_msg.h, 1476

CFE\_TIME\_SUB\_DELAY\_CC  
  cfe\_time\_msg.h, 1477

CFE\_TIME\_SendDiagnosticCmd\_t  
  cfe\_time\_msg.h, 1481

CFE\_TIME\_SetLeapSecondsCmd, 758  
  CommandHeader, 758  
  Payload, 758

CFE\_TIME\_SetLeapSecondsCmd\_t  
  cfe\_time\_msg.h, 1481

CFE\_TIME\_SetMETCmd\_t  
  cfe\_time\_msg.h, 1481

CFE\_TIME\_SetSTCFCmd\_t  
  cfe\_time\_msg.h, 1482

CFE\_TIME\_SetSignalCmd, 759  
  CommandHeader, 759  
  Payload, 759

CFE\_TIME\_SetSignalCmd\_t  
  cfe\_time\_msg.h, 1481

CFE\_TIME\_SetSourceCmd, 760  
  CommandHeader, 760  
  Payload, 760

CFE\_TIME\_SetSourceCmd\_t  
  cfe\_time\_msg.h, 1482

CFE\_TIME\_SetState  
  cfe\_time\_extern\_typedefs.h, 1235

CFE\_TIME\_SetState\_Enum\_t  
  cfe\_time\_extern\_typedefs.h, 1232

CFE\_TIME\_SetStateCmd, 761  
  CommandHeader, 761  
  Payload, 761

CFE\_TIME\_SetStateCmd\_t  
  cfe\_time\_msg.h, 1482

CFE\_TIME\_SetTimeCmd\_t  
  cfe\_time\_msg.h, 1482

CFE\_TIME\_SignalCmd\_Payload, 762  
  ToneSource, 762

CFE\_TIME\_SignalCmd\_Payload\_t  
  cfe\_time\_msg.h, 1482

CFE\_TIME\_SourceCmd\_Payload, 763  
  TimeSource, 763

CFE\_TIME\_SourceCmd\_Payload\_t  
  cfe\_time\_msg.h, 1482

CFE\_TIME\_SourceSelect  
  cfe\_time\_extern\_typedefs.h, 1235

CFE\_TIME\_SourceSelect\_Enum\_t  
  cfe\_time\_extern\_typedefs.h, 1233

CFE\_TIME\_StateCmd\_Payload, 763  
  ClockState, 764

CFE\_TIME\_StateCmd\_Payload\_t  
  cfe\_time\_msg.h, 1483

CFE\_TIME\_Sub1HZAdjustmentCmd\_t  
  cfe\_time\_msg.h, 1483

**CFE\_TIME\_Sub2MicroSecs**  
 cFE Time Conversion APIs, [407](#)  
**CFE\_TIME\_SubAdjustCmd\_t**  
*cfe\_time\_msg.h*, [1483](#)  
**CFE\_TIME\_SubDelayCmd\_t**  
*cfe\_time\_msg.h*, [1483](#)  
**CFE\_TIME\_Subtract**  
 cFE Time Arithmetic APIs, [405](#)  
**CFE\_TIME\_SynchCallbackPtr\_t**  
*cfe\_time\_api\_typedefs.h*, [1229](#)  
**CFE\_TIME\_SysTime**, [764](#)  
 Seconds, [765](#)  
 Subseconds, [765](#)  
**CFE\_TIME\_SysTime\_t**  
*cfe\_time\_extern\_typedefs.h*, [1233](#)  
**CFE\_TIME\_TIME\_CFG\_EID**  
*cfe\_time\_events.h*, [1457](#)  
**CFE\_TIME\_TIME\_EID**  
*cfe\_time\_events.h*, [1457](#)  
**CFE\_TIME\_TIME\_ERR\_EID**  
*cfe\_time\_events.h*, [1457](#)  
**CFE\_TIME\_TONE\_CMD\_MID**  
*cpu1\_msgids.h*, [1048](#)  
**CFE\_TIME\_TOO\_MANY\_SYNCH\_CALLBACKS**  
 cFE Return Code Defines, [236](#)  
**CFE\_TIME\_TimeCmd**, [765](#)  
 CommandHeader, [766](#)  
 Payload, [766](#)  
**CFE\_TIME\_TimeCmd\_Payload**, [766](#)  
 MicroSeconds, [766](#)  
 Seconds, [767](#)  
**CFE\_TIME\_TimeCmd\_Payload\_t**  
*cfe\_time\_msg.h*, [1483](#)  
**CFE\_TIME\_TimeCmd\_t**  
*cfe\_time\_msg.h*, [1483](#)  
**CFE\_TIME\_ToneDataCmd**, [767](#)  
 CommandHeader, [767](#)  
 Payload, [768](#)  
**CFE\_TIME\_ToneDataCmd\_Payload**, [768](#)  
 AtToneLeapSeconds, [769](#)  
 AtToneMET, [769](#)  
 AtToneSTCF, [769](#)  
 AtToneState, [769](#)  
**CFE\_TIME\_ToneDataCmd\_Payload\_t**  
*cfe\_time\_msg.h*, [1484](#)  
**CFE\_TIME\_ToneDataCmd\_t**  
*cfe\_time\_msg.h*, [1484](#)  
**CFE\_TIME\_ToneSignalCmd\_t**  
*cfe\_time\_msg.h*, [1484](#)  
**CFE\_TIME\_ToneSignalSelect**  
*cfe\_time\_extern\_typedefs.h*, [1235](#)  
**CFE\_TIME\_ToneSignalSelect\_Enum\_t**  
*cfe\_time\_extern\_typedefs.h*, [1233](#)  
**CFE\_TIME\_UnregisterSynchCallback**

cFE External Time Source APIs, [412](#)  
**CFE\_TST**  
*cfe\_sb.h*, [1209](#)  
**CFE\_VERSION\_STRING**  
*cfe\_version.h*, [1238](#)  
**CFE\_YYYY\_INDEX**  
*ds\_file.c*, [937](#)  
**CFE\_ssss\_INDEX**  
*ds\_file.c*, [937](#)  
**CFECoreChecksum**  
 CFE\_ES\_HousekeepingTlm\_Payload, [586](#)  
**CFEMajorVersion**  
 CFE\_ES\_HousekeepingTlm\_Payload, [586](#)  
**CFEMinorVersion**  
 CFE\_ES\_HousekeepingTlm\_Payload, [586](#)  
**CFEMissionRevision**  
 CFE\_ES\_HousekeepingTlm\_Payload, [586](#)  
**CFERevision**  
 CFE\_ES\_HousekeepingTlm\_Payload, [587](#)  
**CFS Data Storage Command Codes**, [180](#)  
 DS\_ADD\_MID\_CC, [180](#)  
 DS\_CLOSE\_ALL\_CC, [181](#)  
 DS\_CLOSE\_FILE\_CC, [182](#)  
 DS\_GET\_FILE\_INFO\_CC, [183](#)  
 DS\_NOOP\_CC, [184](#)  
 DS\_RESET\_CC, [185](#)  
 DS\_SET\_APP\_STATE\_CC, [186](#)  
 DS\_SET\_DEST\_AGE\_CC, [187](#)  
 DS\_SET\_DEST\_BASE\_CC, [188](#)  
 DS\_SET\_DEST\_COUNT\_CC, [189](#)  
 DS\_SET\_DEST\_EXT\_CC, [190](#)  
 DS\_SET\_DEST\_PATH\_CC, [191](#)  
 DS\_SET\_DEST\_SIZE\_CC, [192](#)  
 DS\_SET\_DEST\_STATE\_CC, [193](#)  
 DS\_SET\_DEST\_TYPE\_CC, [194](#)  
 DS\_SET\_FILTER\_FILE\_CC, [195](#)  
 DS\_SET\_FILTER\_PARMS\_CC, [196](#)  
 DS\_SET\_FILTER\_TYPE\_CC, [197](#)  
**CFS Data Storage Command Structures**, [178](#)  
**CFS Data Storage Message IDs**, [133](#), [134](#)  
 DS\_CMD\_MID, [133](#)  
 DS\_COMP\_TLM\_MID, [134](#)  
 DS\_DIAG\_TLM\_MID, [134](#)  
 DS\_HK\_TLM\_MID, [134](#)  
 DS\_SEND\_HK\_MID, [133](#)  
**CFS Data Storage Mission Configuration**, [132](#)  
 DS\_APPMAIN\_PERF\_ID, [132](#)  
**CFS Data Storage Platform Configuration**, [135](#)  
 DS\_APP\_PIPE\_DEPTH, [136](#)  
 DS\_APP\_PIPE\_NAME, [136](#)  
 DS\_BASENAME\_BUFSIZE, [137](#)  
 DS\_CDS\_ENABLE\_STATE, [137](#)  
 DS\_DEF\_DEST\_FILENAME, [138](#)  
 DS\_DEF\_ENABLE\_STATE, [138](#)

DS\_DEF\_FILTER\_FILENAME, 138  
DS\_DESCRIPTOR\_BUFSIZE, 139  
DS\_DEST\_FILE\_CNT, 139  
DS\_DESTINATION\_TBL\_NAME, 139  
DS\_EXTENSION\_BUFSIZE, 140  
DS\_FILE\_HDR\_DESCRIPTION, 140  
DS\_FILE\_HDR\_SUBTYPE, 141  
DS\_FILE\_HEADER\_TYPE, 141  
DS\_FILE\_MIN\_AGE\_LIMIT, 141  
DS\_FILE\_MIN\_SIZE\_LIMIT, 142  
DS\_FILTER\_TBL\_NAME, 142  
DS\_FILTERS\_PER\_PACKET, 143  
DS\_MAKE\_TABLES\_CRITICAL, 143  
DS\_MAX\_SEQUENCE\_COUNT, 144  
DS\_MISSION\_REV, 144  
DS\_MOVE\_FILES, 144  
DS\_PACKETS\_IN\_FILTER\_TABLE, 145  
DS\_PATHNAME\_BUFSIZE, 145  
DS\_PER\_PACKET\_PIPE\_LIMIT, 146  
DS\_SECS\_PER\_HK\_CYCLE, 146  
DS\_SEQUENCE\_DIGITS, 147  
DS\_TOTAL\_FNAME\_BUFSIZE, 147  
CFS Data Storage Telemetry, 179  
CFS Data Storage Version, 199  
  DS\_MAJOR\_VERSION, 199  
  DS\_MINOR\_VERSION, 199  
  DS\_REVISION, 199  
CFS Data Store Event IDs, 148  
  DS\_ADD\_MID\_CMD\_EID, 150  
  DS\_ADD\_MID\_CMD\_ERR\_EID, 150  
  DS\_AGE\_CMD\_EID, 151  
  DS\_AGE\_CMD\_ERR\_EID, 151  
  DS\_APPHK\_FILTER\_TBL\_ERR\_EID, 152  
  DS\_APPHK\_FILTER\_TBL\_PRINT\_ERR\_EID, 152  
  DS\_BASE\_CMD\_EID, 153  
  DS\_BASE\_CMD\_ERR\_EID, 153  
  DS\_CLOSE\_ALL\_CMD\_EID, 154  
  DS\_CLOSE\_ALL\_CMD\_ERR\_EID, 154  
  DS\_CLOSE\_CMD\_EID, 155  
  DS\_CLOSE\_CMD\_ERR\_EID, 155  
  DS\_CMD\_CODE\_ERR\_EID, 156  
  DS\_CREATE\_FILE\_ERR\_EID, 156  
  DS\_ENADIS\_CMD\_EID, 157  
  DS\_ENADIS\_CMD\_ERR\_EID, 157  
  DS\_EXIT\_ERR\_EID, 158  
  DS\_EXT\_CMD\_EID, 158  
  DS\_EXT\_CMD\_ERR\_EID, 159  
  DS\_FIL\_TBL\_EID, 159  
  DS\_FIL\_TBL\_ERR\_EID, 160  
  DS\_FILE\_CMD\_EID, 160  
  DS\_FILE\_CMD\_ERR\_EID, 161  
  DS\_FILE\_CREATE\_EMPTY\_PATH\_ERR\_EID, 161  
  DS\_FILE\_NAME\_ERR\_EID, 162  
  DS\_FLT\_TBL\_EID, 162  
  DS\_FLT\_TBL\_ERR\_EID, 163  
  DS\_FTYPE\_CMD\_EID, 163  
  DS\_FTYPE\_CMD\_ERR\_EID, 164  
  DS\_GET\_FILE\_INFO\_CMD\_EID, 164  
  DS\_GET\_FILE\_INFO\_CMD\_ERR\_EID, 165  
  DS\_HK\_REQUEST\_ERR\_EID, 165  
  DS\_INIT\_CDS\_ERR\_EID, 166  
  DS\_INIT\_EID, 166  
  DS\_INIT\_ERR\_EID, 167  
  DS\_INIT\_TBL\_CDS\_EID, 167  
  DS\_INIT\_TBL\_ERR\_EID, 168  
  DS\_MOVE\_FILE\_ERR\_EID, 168  
  DS\_NOOP\_CMD\_EID, 169  
  DS\_NOOP\_CMD\_ERR\_EID, 169  
  DS\_NTYPED\_CMD\_EID, 170  
  DS\_NTYPED\_CMD\_ERR\_EID, 170  
  DS\_PARMS\_CMD\_EID, 171  
  DS\_PARMS\_CMD\_ERR\_EID, 171  
  DS\_PATH\_CMD\_EID, 172  
  DS\_PATH\_CMD\_ERR\_EID, 172  
  DS\_RESET\_CMD\_EID, 173  
  DS\_RESET\_CMD\_ERR\_EID, 173  
  DS\_SEQ\_CMD\_EID, 174  
  DS\_SEQ\_CMD\_ERR\_EID, 174  
  DS\_SIZE\_CMD\_EID, 175  
  DS\_SIZE\_CMD\_ERR\_EID, 175  
  DS\_STATE\_CMD\_EID, 176  
  DS\_STATE\_CMD\_ERR\_EID, 176  
  DS\_WRITE\_FILE\_ERR\_EID, 177  
ccsds\_hdr.h  
  CCSDS\_ExtendedHeader\_t, 1356  
  CCSDS\_PrimaryHeader\_t, 1356  
CdsName  
  CFE\_ES\_DeleteCDSCmd\_Payload, 579  
cfe/cmake/sample\_defs/cpu1\_msgids.h, 1041  
cfe/cmake/sample\_defs/cpu1\_platform\_cfg.h, 1049  
cfe/cmake/sample\_defs/sample\_mission\_cfg.h, 1106  
cfe/cmake/sample\_defs/sample\_perfids.h, 1127  
cfe/docs/src/cfe\_api.dox, 1131  
cfe/docs/src/cfe\_es.dox, 1131  
cfe/docs/src/cfe\_evs.dox, 1131  
cfe/docs/src/cfe\_frontpage.dox, 1131  
cfe/docs/src/cfe\_glossary.dox, 1131  
cfe/docs/src/cfe\_sb.dox, 1131  
cfe/docs/src/cfe\_tbl.dox, 1131  
cfe/docs/src/cfe\_time.dox, 1131  
cfe/docs/src/cfe\_xref.dox, 1131  
cfe/docs/src/cfs\_versions.dox, 1131  
cfe/modules/core\_api/fsw/inc/cfe.h, 1131  
cfe/modules/core\_api/fsw/inc/cfe\_config.h, 1132  
cfe/modules/core\_api/fsw/inc/cfe\_config\_api\_typedefs.h, 1136  
cfe/modules/core\_api/fsw/inc/cfe\_endian.h, 1138  
cfe/modules/core\_api/fsw/inc/cfe\_error.h, 1138

cfe/modules/core\_api/fsw/inc/cfe\_es.h, 1149  
cfe/modules/core\_api/fsw/inc/cfe\_es\_api\_typedefs.h, 1153  
cfe/modules/core\_api/fsw/inc/cfe\_es\_extern\_typedefs.h, 1159  
cfe/modules/core\_api/fsw/inc/cfe\_evs.h, 1171  
cfe/modules/core\_api/fsw/inc/cfe\_evs\_api\_typedefs.h, 1173  
cfe/modules/core\_api/fsw/inc/cfe\_evs\_extern\_typedefs.h, 1176  
cfe/modules/core\_api/fsw/inc/cfe\_fs.h, 1181  
cfe/modules/core\_api/fsw/inc/cfe\_fs\_api\_typedefs.h, 1182  
cfe/modules/core\_api/fsw/inc/cfe\_fs\_extern\_typedefs.h, 1185  
cfe/modules/core\_api/fsw/inc/cfe\_msg.h, 1188  
cfe/modules/core\_api/fsw/inc/cfe\_msg\_api\_typedefs.h, 1190  
cfe/modules/core\_api/fsw/inc/cfe\_resourceid.h, 1198  
cfe/modules/core\_api/fsw/inc/cfe\_resourceid\_api\_typedefs.h, 1205  
cfe/modules/core\_api/fsw/inc/cfe\_sb.h, 1207  
cfe/modules/core\_api/fsw/inc/cfe\_sb\_api\_typedefs.h, 1209  
cfe/modules/core\_api/fsw/inc/cfe\_sb\_extern\_typedefs.h, 1214  
cfe/modules/core\_api/fsw/inc/cfe\_tbl.h, 1218  
cfe/modules/core\_api/fsw/inc/cfe\_tbl\_api\_typedefs.h, 1219  
cfe/modules/core\_api/fsw/inc/cfe\_tbl\_extern\_typedefs.h, 1222  
cfe/modules/core\_api/fsw/inc/cfe\_tbl\_filedef.h, 1224  
cfe/modules/core\_api/fsw/inc/cfe\_time.h, 1226  
cfe/modules/core\_api/fsw/inc/cfe\_time\_api\_typedefs.h, 1228  
cfe/modules/core\_api/fsw/inc/cfe\_time\_extern\_typedefs.h, 1230  
cfe/modules/core\_api/fsw/inc/cfe\_version.h, 1236  
cfe/modules/es/fsw/inc/cfe\_es\_events.h, 1239  
cfe/modules/es/fsw/inc/cfe\_es\_msg.h, 1272  
cfe/modules/evs/fsw/inc/cfe\_evs\_events.h, 1308  
cfe/modules/evs/fsw/inc/cfe\_evs\_msg.h, 1323  
cfe/modules/msg/fsw/inc/ccsds\_hdr.h, 1355  
cfe/modules/resourceid/fsw/inc/cfe\_core\_resourceid\_basevalues.h, 1356  
cfe/modules/resourceid/fsw/inc/cfe\_resourceid\_basevalue.h, 1357  
cfe/modules/sb/fsw/inc/cfe\_sb\_events.h, 1359  
cfe/modules/sb/fsw/inc/cfe\_sb\_msg.h, 1383  
cfe/modules/tbl/fsw/inc/cfe\_tbl\_events.h, 1401  
cfe/modules/tbl/fsw/inc/cfe\_tbl\_msg.h, 1427  
cfe/modules/time/fsw/inc/cfe\_time\_events.h, 1444  
cfe/modules/time/fsw/inc/cfe\_time\_msg.h, 1458  
cfe\_config.h  
    CFE\_Config\_GetIdByName, 1132

CFE\_Config\_GetName, 1133  
CFE\_Config\_GetObjPointer, 1133  
CFE\_Config\_GetString, 1134  
CFE\_Config\_GetValue, 1134  
CFE\_Config\_IterateAll, 1136  
cfe\_config\_api\_typedefs.h  
    CFE\_CONFIGID\_UNDEFINED, 1137  
    CFE\_CONFIGID\_C, 1137  
    CFE\_Config\_Callback\_t, 1137  
    CFE\_ConfigId\_t, 1137  
cfe\_endian.h  
    CFE\_MAKE\_BIG16, 1138  
    CFE\_MAKE\_BIG32, 1138  
cfe\_error.h  
    CFE\_ES\_StatusToString, 1148  
    CFE\_EVENTS\_SERVICE, 1145  
    CFE\_EXECUTIVE\_SERVICE, 1145  
    CFE\_FILE\_SERVICE, 1145  
    CFE\_GENERIC\_SERVICE, 1145  
    CFE\_SERVICE\_BITMASK, 1146  
    CFE\_SEVERITY\_BITMASK, 1146  
    CFE\_SEVERITY\_ERROR, 1146  
    CFE\_SEVERITY\_INFO, 1146  
    CFE\_SEVERITY\_SUCCESS, 1146  
    CFE\_SOFTWARE\_BUS\_SERVICE, 1147  
    CFE\_STATUS\_STRING\_LENGTH, 1147  
    CFE\_STATUS\_C, 1147  
    CFE\_Status\_t, 1148  
    CFE\_StatusString\_t, 1148  
    CFE\_TABLE\_SERVICE, 1147  
    CFE\_TIME\_SERVICE, 1147  
cfe\_es.h  
    CFE\_ES\_DBIT, 1152  
    CFE\_ES\_DTEST, 1152  
    CFE\_ES\_TEST\_LONG\_MASK, 1152  
    OS\_PRINTF, 1152  
cfe\_es\_api\_typedefs.h  
    CFE\_ES\_APP\_RESTART, 1154  
    CFE\_ES\_APPID\_UNDEFINED, 1154  
    CFE\_ES\_APPID\_C, 1154  
    CFE\_ES\_CDS\_BAD\_HANDLE, 1155  
    CFE\_ES\_CDSHANDLE\_C, 1155  
    CFE\_ES\_COUNTERID\_UNDEFINED, 1155  
    CFE\_ES\_COUNTERID\_C, 1155  
    CFE\_ES\_ChildTaskMainFuncPtr\_t, 1158  
    CFE\_ES\_LIBID\_UNDEFINED, 1155  
    CFE\_ES\_LIBID\_C, 1155  
    CFE\_ES\_LibraryEntryFuncPtr\_t, 1158  
    CFE\_ES\_MEMHANDLE\_UNDEFINED, 1156  
    CFE\_ES\_MEMHANDLE\_C, 1156  
    CFE\_ES\_MEMPOOLBUF\_C, 1156  
    CFE\_ES\_MemPoolBuf\_t, 1158  
    CFE\_ES\_NO\_MUTEX, 1156  
    CFE\_ES\_PoolAlign\_t, 1158

CFE\_ES\_STATIC\_POOL\_TYPE, [1156](#)  
CFE\_ES\_StackPointer\_t, [1159](#)  
CFE\_ES\_TASK\_STACK\_ALLOCATE, [1157](#)  
CFE\_ES\_TASKID\_UNDEFINED, [1157](#)  
CFE\_ES\_TASKID\_C, [1157](#)  
CFE\_ES\_TaskEntryFuncPtr\_t, [1159](#)  
CFE\_ES\_USE\_MUTEX, [1157](#)  
cfe\_es\_events.h  
CFE\_ES\_ALL\_APPS\_EID, [1242](#)  
CFE\_ES\_BOOT\_ERR\_EID, [1242](#)  
CFE\_ES\_BUILD\_INF\_EID, [1243](#)  
CFE\_ES\_CC1\_ERR\_EID, [1243](#)  
CFE\_ES\_CDS\_DELETE\_ERR\_EID, [1244](#)  
CFE\_ES\_CDS\_DELETE\_TBL\_ERR\_EID, [1244](#)  
CFE\_ES\_CDS\_DELETED\_INFO\_EID, [1244](#)  
CFE\_ES\_CDS\_DUMP\_ERR\_EID, [1245](#)  
CFE\_ES\_CDS\_NAME\_ERR\_EID, [1245](#)  
CFE\_ES\_CDS\_OWNER\_ACTIVE\_EID, [1245](#)  
CFE\_ES\_CDS\_REG\_DUMP\_INF\_EID, [1246](#)  
CFE\_ES\_CDS\_REGISTER\_ERR\_EID, [1246](#)  
CFE\_ES\_CREATING\_CDS\_DUMP\_ERR\_EID, [1246](#)  
CFE\_ES\_ERLOG1\_INF\_EID, [1247](#)  
CFE\_ES\_ERLOG2\_EID, [1247](#)  
CFE\_ES\_ERLOG2\_ERR\_EID, [1247](#)  
CFE\_ES\_ERLOG\_PENDING\_ERR\_EID, [1248](#)  
CFE\_ES\_ERR\_SYSLOGMODE\_EID, [1248](#)  
CFE\_ES\_ERREXIT\_APP\_ERR\_EID, [1248](#)  
CFE\_ES\_ERREXIT\_APP\_INF\_EID, [1249](#)  
CFE\_ES\_EXIT\_APP\_ERR\_EID, [1249](#)  
CFE\_ES\_EXIT\_APP\_INF\_EID, [1250](#)  
CFE\_ES\_FILEWRITE\_ERR\_EID, [1250](#)  
CFE\_ES\_INIT\_INF\_EID, [1250](#)  
CFE\_ES\_INITSTATS\_INF\_EID, [1251](#)  
CFE\_ES\_INVALID\_POOL\_HANDLE\_ERR\_EID, [1251](#)  
CFE\_ES\_LEN\_ERR\_EID, [1251](#)  
CFE\_ES\_MID\_ERR\_EID, [1252](#)  
CFE\_ES\_NOOP\_INF\_EID, [1252](#)  
CFE\_ES\_ONE\_APP\_EID, [1252](#)  
CFE\_ES\_ONE\_APPID\_ERR\_EID, [1253](#)  
CFE\_ES\_ONE\_ERR\_EID, [1253](#)  
CFE\_ES\_OSCREATE\_ERR\_EID, [1253](#)  
CFE\_ES\_PCR\_ERR1\_EID, [1254](#)  
CFE\_ES\_PCR\_ERR2\_EID, [1254](#)  
CFE\_ES\_PERF\_DATAWRITTEN\_EID, [1254](#)  
CFE\_ES\_PERF\_FILTMSKCMD\_EID, [1255](#)  
CFE\_ES\_PERF\_FILTMSKERR\_EID, [1255](#)  
CFE\_ES\_PERF\_LOG\_ERR\_EID, [1255](#)  
CFE\_ES\_PERF\_STARTCMD\_EID, [1256](#)  
CFE\_ES\_PERF\_STARTCMD\_ERR\_EID, [1256](#)  
CFE\_ES\_PERF\_STARTCMD\_TRIG\_ERR\_EID, [1256](#)  
CFE\_ES\_PERF\_STOPCMD\_EID, [1257](#)  
CFE\_ES\_PERF\_STOPCMD\_ERR2\_EID, [1257](#)  
CFE\_ES\_PERF\_TRIGMSKCMD\_EID, [1257](#)  
CFE\_ES\_PERF\_TRIGMSKERR\_EID, [1258](#)  
CFE\_ES\_RELOAD\_APP\_DBG\_EID, [1258](#)  
CFE\_ES\_RELOAD\_APP\_ERR1\_EID, [1258](#)  
CFE\_ES\_RELOAD\_APP\_ERR2\_EID, [1259](#)  
CFE\_ES\_RELOAD\_APP\_ERR3\_EID, [1259](#)  
CFE\_ES\_RELOAD\_APP\_ERR4\_EID, [1259](#)  
CFE\_ES\_RELOAD\_APP\_INF\_EID, [1260](#)  
CFE\_ES\_RESET\_INF\_EID, [1260](#)  
CFE\_ES\_RESET\_PR\_COUNT\_EID, [1260](#)  
CFE\_ES\_RESTART\_APP\_DBG\_EID, [1261](#)  
CFE\_ES\_RESTART\_APP\_ERR1\_EID, [1261](#)  
CFE\_ES\_RESTART\_APP\_ERR2\_EID, [1261](#)  
CFE\_ES\_RESTART\_APP\_ERR3\_EID, [1262](#)  
CFE\_ES\_RESTART\_APP\_ERR4\_EID, [1262](#)  
CFE\_ES\_RESTART\_APP\_INF\_EID, [1262](#)  
CFE\_ES\_SET\_MAX\_PR\_COUNT\_EID, [1263](#)  
CFE\_ES\_START\_ERR\_EID, [1263](#)  
CFE\_ES\_START\_EXC\_ACTION\_ERR\_EID, [1263](#)  
CFE\_ES\_START\_INF\_EID, [1264](#)  
CFE\_ES\_START\_INVALID\_ENTRY\_POINT\_ERR\_EID, [1264](#)  
CFE\_ES\_START\_INVALID\_FILENAME\_ERR\_EID, [1264](#)  
CFE\_ES\_START\_NULL\_APP\_NAME\_ERR\_EID, [1265](#)  
CFE\_ES\_START\_PRIORITY\_ERR\_EID, [1265](#)  
CFE\_ES\_STOP\_DBG\_EID, [1265](#)  
CFE\_ES\_STOP\_ERR1\_EID, [1266](#)  
CFE\_ES\_STOP\_ERR2\_EID, [1266](#)  
CFE\_ES\_STOP\_ERR3\_EID, [1266](#)  
CFE\_ES\_STOP\_INF\_EID, [1267](#)  
CFE\_ES\_SYSLOG1\_INF\_EID, [1267](#)  
CFE\_ES\_SYSLOG2\_EID, [1267](#)  
CFE\_ES\_SYSLOG2\_ERR\_EID, [1268](#)  
CFE\_ES\_SYSLOGMODE\_EID, [1268](#)  
CFE\_ES\_TASKINFO\_EID, [1268](#)  
CFE\_ES\_TASKINFO\_OSCREATE\_ERR\_EID, [1269](#)  
CFE\_ES\_TASKINFO\_WR\_ERR\_EID, [1269](#)  
CFE\_ES\_TASKINFO\_WRHDR\_ERR\_EID, [1269](#)  
CFE\_ES\_TASKWR\_ERR\_EID, [1270](#)  
CFE\_ES\_TLM\_POOL\_STATS\_INFO\_EID, [1270](#)  
CFE\_ES\_VERSION\_INF\_EID, [1270](#)  
CFE\_ES\_WRHDR\_ERR\_EID, [1271](#)  
CFE\_ES\_WRITE\_CFE\_HDR\_ERR\_EID, [1271](#)  
cfe\_es\_extern\_typedefs.h  
CFE\_ES\_AppId\_t, [1162](#)  
CFE\_ES\_AppInfo\_t, [1162](#)  
CFE\_ES\_AppState, [1168](#)  
CFE\_ES\_AppState\_Enum\_t, [1162](#)  
CFE\_ES\_AppType, [1168](#)  
CFE\_ES\_AppType\_Enum\_t, [1162](#)  
CFE\_ES\_BlockStats\_t, [1163](#)  
CFE\_ES\_CDSHandle\_t, [1163](#)

CFE\_ES\_CDSRegDumpRec\_t, [1163](#)  
 CFE\_ES\_CounterId\_t, [1163](#)  
 CFE\_ES\_ExceptionAction, [1169](#)  
 CFE\_ES\_ExceptionAction\_Enum\_t, [1164](#)  
 CFE\_ES\_LibId\_t, [1164](#)  
 CFE\_ES\_LogEntryType, [1169](#)  
 CFE\_ES\_LogEntryType\_Enum\_t, [1164](#)  
 CFE\_ES\_LogMode, [1169](#)  
 CFE\_ES\_LogMode\_Enum\_t, [1164](#)  
 CFE\_ES\_MEMADDRESS\_C, [1161](#)  
 CFE\_ES\_MEMOFFSET\_C, [1161](#)  
 CFE\_ES\_MemAddress\_t, [1165](#)  
 CFE\_ES\_MemHandle\_t, [1165](#)  
 CFE\_ES\_MemOffset\_t, [1165](#)  
 CFE\_ES\_MemPoolStats\_t, [1166](#)  
 CFE\_ES\_RunStatus, [1170](#)  
 CFE\_ES\_RunStatus\_Enum\_t, [1166](#)  
 CFE\_ES\_SystemState, [1170](#)  
 CFE\_ES\_SystemState\_Enum\_t, [1166](#)  
 CFE\_ES\_TaskId\_t, [1167](#)  
 CFE\_ES\_TaskInfo\_t, [1167](#)  
 CFE\_ES\_TaskPriority\_Atom\_t, [1167](#)  
**cfe\_es\_msg.h**  
   CFE\_ES\_AppNameCmd\_Payload\_t, [1300](#)  
   CFE\_ES\_AppNameCmd\_t, [1300](#)  
   CFE\_ES\_AppReloadCmd\_Payload\_t, [1300](#)  
   CFE\_ES\_CLEAR\_ER\_LOG\_CC, [1276](#)  
   CFE\_ES\_CLEAR\_SYSLOG\_CC, [1276](#)  
   CFE\_ES\_ClearERLogCmd\_t, [1300](#)  
   CFE\_ES\_ClearSysLogCmd\_t, [1300](#)  
   CFE\_ES\_DELETE\_CDS\_CC, [1277](#)  
   CFE\_ES\_DUMP\_CDS\_REGISTRY\_CC, [1278](#)  
   CFE\_ES\_DeleteCDSCmd\_Payload\_t, [1300](#)  
   CFE\_ES\_DeleteCDSCmd\_t, [1300](#)  
   CFE\_ES\_DumpCDSRegistryCmd\_Payload\_t, [1301](#)  
   CFE\_ES\_DumpCDSRegistryCmd\_t, [1301](#)  
   CFE\_ES\_FileNameCmd\_Payload\_t, [1301](#)  
   CFE\_ES\_FileNameCmd\_t, [1301](#)  
   CFE\_ES\_HousekeepingTlm\_Payload\_t, [1301](#)  
   CFE\_ES\_HousekeepingTlm\_t, [1301](#)  
   CFE\_ES\_MemStatsTlm\_t, [1302](#)  
   CFE\_ES\_NOOP\_CC, [1279](#)  
   CFE\_ES\_NoArgsCmd\_t, [1302](#)  
   CFE\_ES\_NoopCmd\_t, [1302](#)  
   CFE\_ES\_OVER\_WRITE\_SYSLOG\_CC, [1280](#)  
   CFE\_ES\_OneAppTlm\_Payload\_t, [1302](#)  
   CFE\_ES\_OneAppTlm\_t, [1302](#)  
   CFE\_ES\_OverWriteSysLogCmd\_Payload\_t, [1302](#)  
   CFE\_ES\_OverWriteSysLogCmd\_t, [1303](#)  
   CFE\_ES\_PoolStatsTlm\_Payload\_t, [1303](#)  
   CFE\_ES\_QUERY\_ALL\_CC, [1281](#)  
   CFE\_ES\_QUERY\_ALL\_TASKS\_CC, [1282](#)  
   CFE\_ES\_QUERY\_ONE\_CC, [1283](#)  
   CFE\_ES\_QueryAllCmd\_t, [1303](#)  
  
 CFE\_ES\_QueryAllTasksCmd\_t, [1303](#)  
 CFE\_ES\_QueryOneCmd\_t, [1303](#)  
 CFE\_ES\_RELOAD\_APP\_CC, [1284](#)  
 CFE\_ES\_RESET\_COUNTERS\_CC, [1285](#)  
 CFE\_ES\_RESET\_PR\_COUNT\_CC, [1286](#)  
 CFE\_ES\_RESTART\_APP\_CC, [1287](#)  
 CFE\_ES\_RESTART\_CC, [1288](#)  
 CFE\_ES\_ReloadAppCmd\_t, [1303](#)  
 CFE\_ES\_ResetCountersCmd\_t, [1304](#)  
 CFE\_ES\_ResetPRCountCmd\_t, [1304](#)  
 CFE\_ES\_RestartAppCmd\_t, [1304](#)  
 CFE\_ES\_RestartCmd\_Payload\_t, [1304](#)  
 CFE\_ES\_RestartCmd\_t, [1304](#)  
 CFE\_ES\_SEND\_MEM\_POOL\_STATS\_CC, [1289](#)  
 CFE\_ES\_SET\_MAX\_PR\_COUNT\_CC, [1290](#)  
 CFE\_ES\_SET\_PERF\_FILTER\_MASK\_CC, [1291](#)  
 CFE\_ES\_SET\_PERF\_TRIGGER\_MASK\_CC, [1292](#)  
 CFE\_ES\_START\_APP\_CC, [1293](#)  
 CFE\_ES\_START\_PERF\_DATA\_CC, [1294](#)  
 CFE\_ES\_STOP\_APP\_CC, [1295](#)  
 CFE\_ES\_STOP\_PERF\_DATA\_CC, [1296](#)  
 CFE\_ES\_SendMemPoolStatsCmd\_Payload\_t, [1304](#)  
 CFE\_ES\_SendMemPoolStatsCmd\_t, [1305](#)  
 CFE\_ES\_SetMaxPRCountCmd\_Payload\_t, [1305](#)  
 CFE\_ES\_SetMaxPRCountCmd\_t, [1305](#)  
 CFE\_ES\_SetPerfFilterMaskCmd\_Payload\_t, [1305](#)  
 CFE\_ES\_SetPerfFilterMaskCmd\_t, [1305](#)  
 CFE\_ES\_SetPerfTrigMaskCmd\_Payload\_t, [1306](#)  
 CFE\_ES\_SetPerfTriggerMaskCmd\_t, [1305](#)  
 CFE\_ES\_StartAppCmd\_Payload\_t, [1306](#)  
 CFE\_ES\_StartAppCmd\_t, [1306](#)  
 CFE\_ES\_StartPerfCmd\_Payload\_t, [1306](#)  
 CFE\_ES\_StartPerfDataCmd\_t, [1306](#)  
 CFE\_ES\_StopAppCmd\_t, [1306](#)  
 CFE\_ES\_StopPerfCmd\_Payload\_t, [1307](#)  
 CFE\_ES\_StopPerfDataCmd\_t, [1307](#)  
 CFE\_ES\_WRITE\_ER\_LOG\_CC, [1297](#)  
 CFE\_ES\_WRITE\_SYSLOG\_CC, [1298](#)  
 CFE\_ES\_WriteERLogCmd\_t, [1307](#)  
 CFE\_ES\_WriteSysLogCmd\_t, [1307](#)  
**cfe\_evs.h**  
   CFE\_EVS\_Send, [1171](#)  
   CFE\_EVS\_SendCrit, [1172](#)  
   CFE\_EVS\_SendDbg, [1172](#)  
   CFE\_EVS\_SendErr, [1172](#)  
   CFE\_EVS\_SendInfo, [1172](#)  
**cfe\_evs\_api\_typedefs.h**  
   CFE\_EVS\_BinFilter\_t, [1176](#)  
   CFE\_EVS\_EVERY\_FOURTH\_ONE, [1174](#)  
   CFE\_EVS\_EVERY\_OTHER\_ONE, [1174](#)  
   CFE\_EVS\_EVERY\_OTHER\_TWO, [1174](#)  
   CFE\_EVS\_FIRST\_16\_STOP, [1174](#)  
   CFE\_EVS\_FIRST\_32\_STOP, [1174](#)  
   CFE\_EVS\_FIRST\_4\_STOP, [1174](#)

CFE\_EVS\_FIRST\_64\_STOP, 1175  
CFE\_EVS\_FIRST\_8\_STOP, 1175  
CFE\_EVS\_FIRST\_ONE\_STOP, 1175  
CFE\_EVS\_FIRST\_TWO\_STOP, 1175  
CFE\_EVS\_NO\_FILTER, 1175  
**cfe\_evs\_events.h**  
CFE\_EVS\_ADDFILTER\_EID, 1309  
CFE\_EVS\_DELFILTER\_EID, 1309  
CFE\_EVS\_DISAPPENTTYPE\_EID, 1310  
CFE\_EVS\_DISAPPEVT\_EID, 1310  
CFE\_EVS\_DISEVTTYPE\_EID, 1310  
CFE\_EVS\_DISPRT\_EID, 1311  
CFE\_EVS\_ENAAPPEVT\_EID, 1311  
CFE\_EVS\_ENAAPPEVTTYPE\_EID, 1311  
CFE\_EVS\_ENAEVTTYPE\_EID, 1312  
CFE\_EVS\_ENAPORT\_EID, 1312  
CFE\_EVS\_ERR\_APPNOREGS\_EID, 1312  
CFE\_EVS\_ERR\_CC\_EID, 1313  
CFE\_EVS\_ERR\_CRDATFILE\_EID, 1313  
CFE\_EVS\_ERR\_CRLOGFILE\_EID, 1313  
CFE\_EVS\_ERR\_EVTIDNOREGS\_EID, 1314  
CFE\_EVS\_ERR\_ILLAPPIDRANGE\_EID, 1314  
CFE\_EVS\_ERR\_ILLEGALFMTMOD\_EID, 1314  
CFE\_EVS\_ERR\_INVALID\_BITMASK\_EID, 1315  
CFE\_EVS\_ERR\_LOGMODE\_EID, 1315  
CFE\_EVS\_ERR\_MAXREGSFILTER\_EID, 1315  
CFE\_EVS\_ERR\_MSGID\_EID, 1316  
CFE\_EVS\_ERR\_NOAPPIDFOUND\_EID, 1316  
CFE\_EVS\_ERR\_UNREGISTERED\_EVS\_APP,  
    1316  
CFE\_EVS\_ERR\_WRDATFILE\_EID, 1317  
CFE\_EVS\_ERR\_WRLOGFILE\_EID, 1317  
CFE\_EVS\_EVT\_FILTERED\_EID, 1317  
CFE\_EVS\_FILTER\_MAX\_EID, 1318  
CFE\_EVS\_LEN\_ERR\_EID, 1318  
CFE\_EVS\_LOGMODE\_EID, 1318  
CFE\_EVS\_NOOP\_EID, 1319  
CFE\_EVS\_RSTALLFILTER\_EID, 1319  
CFE\_EVS\_RSTCNT\_EID, 1319  
CFE\_EVS\_RSTEVCNT\_EID, 1320  
CFE\_EVS\_RSTFILTER\_EID, 1320  
CFE\_EVS\_SETEVTFMTMOD\_EID, 1320  
CFE\_EVS\_SETFILTERMSK\_EID, 1321  
CFE\_EVS\_SQUELCHED\_ERR\_EID, 1321  
CFE\_EVS\_STARTUP\_EID, 1321  
CFE\_EVS\_WRDAT\_EID, 1322  
CFE\_EVS\_WRLOG\_EID, 1322  
**cfe\_evs\_extern\_typedefs.h**  
CFE\_EVS\_EventFilter, 1178  
CFE\_EVS\_EventFilter\_Enum\_t, 1177  
CFE\_EVS\_EventOutput, 1178  
CFE\_EVS\_EventOutput\_Enum\_t, 1177  
CFE\_EVS\_EventType, 1180  
CFE\_EVS\_EventType\_Enum\_t, 1177  
CFE\_EVS\_LogMode, 1180  
CFE\_EVS\_LogMode\_Enum\_t, 1177  
CFE\_EVS\_MsgFormat, 1180  
CFE\_EVS\_MsgFormat\_Enum\_t, 1178  
**cfe\_evs\_msg.h**  
CFE\_EVS\_ADD\_EVENT\_FILTER\_CC, 1326  
CFE\_EVS\_AddEventFilterCmd\_t, 1348  
CFE\_EVS\_AppDataCmd\_Payload\_t, 1348  
CFE\_EVS\_AppNameBitMaskCmd\_Payload\_t, 1349  
CFE\_EVS\_AppNameBitMaskCmd\_t, 1349  
CFE\_EVS\_AppNameCmd\_Payload\_t, 1349  
CFE\_EVS\_AppNameCmd\_t, 1349  
CFE\_EVS\_AppNameEventIDCmd\_Payload\_t, 1349  
CFE\_EVS\_AppNameEventIDCmd\_t, 1349  
CFE\_EVS\_AppNameEventIDMaskCmd\_Payload\_t,  
    1350  
CFE\_EVS\_AppNameEventIDMaskCmd\_t, 1350  
CFE\_EVS\_AppTlmData\_t, 1350  
CFE\_EVS\_BitMaskCmd\_Payload\_t, 1350  
CFE\_EVS\_BitMaskCmd\_t, 1350  
CFE\_EVS\_CLEAR\_LOG\_CC, 1327  
CFE\_EVS\_CRITICAL\_BIT, 1328  
CFE\_EVS\_ClearLogCmd\_t, 1350  
CFE\_EVS\_DEBUG\_BIT, 1328  
CFE\_EVS\_DELETE\_EVENT\_FILTER\_CC, 1328  
CFE\_EVS\_DISABLE\_APP\_EVENT\_TYPE\_CC,  
    1329  
CFE\_EVS\_DISABLE\_APP\_EVENTS\_CC, 1330  
CFE\_EVS\_DISABLE\_EVENT\_TYPE\_CC, 1331  
CFE\_EVS\_DISABLE\_PORTS\_CC, 1332  
CFE\_EVS\_DeleteEventFilterCmd\_t, 1351  
CFE\_EVS\_DisableAppEventTypeCmd\_t, 1351  
CFE\_EVS\_DisableAppEventsCmd\_t, 1351  
CFE\_EVS\_DisableEventTypeCmd\_t, 1351  
CFE\_EVS\_DisablePortsCmd\_t, 1351  
CFE\_EVS\_ENABLE\_APP\_EVENT\_TYPE\_CC, 1333  
CFE\_EVS\_ENABLE\_APP\_EVENTS\_CC, 1334  
CFE\_EVS\_ENABLE\_EVENT\_TYPE\_CC, 1335  
CFE\_EVS\_ENABLE\_PORTS\_CC, 1336  
CFE\_EVS\_ERROR\_BIT, 1337  
CFE\_EVS\_EnableAppEventTypeCmd\_t, 1352  
CFE\_EVS\_EnableAppEventsCmd\_t, 1351  
CFE\_EVS\_EnableEventTypeCmd\_t, 1352  
CFE\_EVS\_EnablePortsCmd\_t, 1352  
CFE\_EVS\_HousekeepingTlm\_Payload\_t, 1352  
CFE\_EVS\_HousekeepingTlm\_t, 1352  
CFE\_EVS\_INFORMATION\_BIT, 1338  
CFE\_EVS\_LogFileCmd\_Payload\_t, 1352  
CFE\_EVS\_LongEventTlm\_Payload\_t, 1353  
CFE\_EVS\_LongEventTlm\_t, 1353  
CFE\_EVS\_NOOP\_CC, 1338  
CFE\_EVS\_NoArgsCmd\_t, 1353  
CFE\_EVS\_NoopCmd\_t, 1353  
CFE\_EVS\_PORT1\_BIT, 1338

CFE\_EVS\_PORT2\_BIT, 1339  
 CFE\_EVS\_PORT3\_BIT, 1339  
 CFE\_EVS\_PORT4\_BIT, 1339  
 CFE\_EVS\_PacketID\_t, 1353  
 CFE\_EVS\_RESET\_ALL\_FILTERS\_CC, 1339  
 CFE\_EVS\_RESET\_APP\_COUNTER\_CC, 1340  
 CFE\_EVS\_RESET\_COUNTERS\_CC, 1341  
 CFE\_EVS\_RESET\_FILTER\_CC, 1342  
 CFE\_EVS\_ResetAllFiltersCmd\_t, 1353  
 CFE\_EVS\_ResetAppCounterCmd\_t, 1353  
 CFE\_EVS\_ResetCountersCmd\_t, 1354  
 CFE\_EVS\_ResetFilterCmd\_t, 1354  
 CFE\_EVS\_SET\_EVENT\_FORMAT\_MODE\_CC,  
     1343  
 CFE\_EVS\_SET\_FILTER\_CC, 1344  
 CFE\_EVS\_SET\_LOG\_MODE\_CC, 1345  
 CFE\_EVS\_SetEventFormatMode\_Payload\_t, 1354  
 CFE\_EVS\_SetEventFormatModeCmd\_t, 1354  
 CFE\_EVS\_SetFilterCmd\_t, 1354  
 CFE\_EVS\_SetLogMode\_Payload\_t, 1354  
 CFE\_EVS\_SetLogModeCmd\_t, 1355  
 CFE\_EVS\_ShortEventTlm\_Payload\_t, 1355  
 CFE\_EVS\_ShortEventTlm\_t, 1355  
 CFE\_EVS\_WRITE\_APP\_DATA\_FILE\_CC, 1346  
 CFE\_EVS\_WRITE\_LOG\_DATA\_FILE\_CC, 1347  
 CFE\_EVS\_WriteAppDataFileCmd\_t, 1355  
 CFE\_EVS\_WriteLogDataFileCmd\_t, 1355  
**cfe\_fs\_api\_typedefs.h**  
     CFE\_FS\_FileCategory\_t, 1184  
     CFE\_FS\_FileWriteEvent\_t, 1185  
     CFE\_FS\_FileWriteGetData\_t, 1183  
     CFE\_FS\_FileWriteMetaData\_t, 1183  
     CFE\_FS\_FileWriteOnEvent\_t, 1183  
**cfe\_fs\_extern\_typedefs.h**  
     CFE\_FS\_FILE\_CONTENT\_ID, 1186  
     CFE\_FS\_HDR\_DESC\_MAX\_LEN, 1186  
     CFE\_FS\_Header\_t, 1186  
     CFE\_FS\_SubType, 1187  
     CFE\_FS\_SubType\_Enum\_t, 1186  
**cfe\_msg\_api\_typedefs.h**  
     CFE\_MSG\_Apld\_t, 1192  
     CFE\_MSG\_BAD\_ARGUMENT, 1192  
     CFE\_MSG\_Checksum\_t, 1193  
     CFE\_MSG\_CommandHeader\_t, 1193  
     CFE\_MSG\_EDSVersion\_t, 1193  
     CFE\_MSG\_Endian, 1195  
     CFE\_MSG\_Endian\_t, 1193  
     CFE\_MSG\_FcnCode\_t, 1193  
     CFE\_MSG\_HeaderVersion\_t, 1194  
     CFE\_MSG\_Message\_t, 1194  
     CFE\_MSG\_NOT\_IMPLEMENTED, 1192  
     CFE\_MSG\_PlaybackFlag, 1196  
     CFE\_MSG\_PlaybackFlag\_t, 1194  
     CFE\_MSG\_SegmentationFlag, 1196  
  
 CFE\_MSG\_SegmentationFlag\_t, 1194  
 CFE\_MSG\_SequenceCount\_t, 1194  
 CFE\_MSG\_Size\_t, 1195  
 CFE\_MSG\_Subsystem\_t, 1195  
 CFE\_MSG\_System\_t, 1195  
 CFE\_MSG\_TelemetryHeader\_t, 1195  
 CFE\_MSG\_Type, 1196  
 CFE\_MSG\_Type\_t, 1195  
 CFE\_MSG\_WRONG\_MSG\_TYPE, 1192  
**cfe\_psp.h**  
     BUFF\_SIZE, 1539  
     CFE\_PSP\_AttachExceptions, 1546  
     CFE\_PSP\_Decompress, 1546  
     CFE\_PSP\_EepromPowerDown, 1546  
     CFE\_PSP\_EepromPowerUp, 1546  
     CFE\_PSP\_EepromWrite16, 1546  
     CFE\_PSP\_EepromWrite32, 1547  
     CFE\_PSP\_EepromWrite8, 1547  
     CFE\_PSP\_EepromWriteDisable, 1547  
     CFE\_PSP\_EepromWriteEnable, 1547  
     CFE\_PSP\_Exception\_CopyContext, 1547  
     CFE\_PSP\_Exception\_GetCount, 1547  
     CFE\_PSP\_Exception\_GetSummary, 1548  
     CFE\_PSP\_FlushCaches, 1548  
     CFE\_PSP\_Get\_Dec, 1548  
     CFE\_PSP\_Get\_Timebase, 1548  
     CFE\_PSP\_Get\_Timer\_Tick, 1549  
     CFE\_PSP\_GetBuildNumber, 1549  
     CFE\_PSP\_GetCDSSize, 1549  
     CFE\_PSP\_GetCFETextSegmentInfo, 1549  
     CFE\_PSP\_GetKernelTextSegmentInfo, 1549  
     CFE\_PSP\_GetProcessorId, 1550  
     CFE\_PSP\_GetProcessorName, 1550  
     CFE\_PSP\_GetResetArea, 1550  
     CFE\_PSP\_GetRestartType, 1550  
     CFE\_PSP\_GetSpacecraftId, 1550  
     CFE\_PSP\_GetTime, 1550  
     CFE\_PSP\_GetTimerLow32Rollover, 1551  
     CFE\_PSP\_GetTimerTicksPerSecond, 1551  
     CFE\_PSP.GetUserReservedArea, 1551  
     CFE\_PSP\_GetVersionCodeName, 1551  
     CFE\_PSP\_GetVersionNumber, 1552  
     CFE\_PSP\_GetVersionString, 1552  
     CFE\_PSP\_GetVolatileDiskMem, 1552  
     CFE\_PSP\_InitSSR, 1553  
     CFE\_PSP\_MEM\_ANY, 1540  
     CFE\_PSP\_MEM\_ATTR\_READWRITE, 1540  
     CFE\_PSP\_MEM\_ATTR\_READ, 1540  
     CFE\_PSP\_MEM\_ATTR\_WRITE, 1540  
     CFE\_PSP\_MEM\_EEPROM, 1540  
     CFE\_PSP\_MEM\_INVALID, 1540  
     CFE\_PSP\_MEM\_RAM, 1541  
     CFE\_PSP\_MEM\_SIZE\_BYTE, 1541  
     CFE\_PSP\_MEM\_SIZE\_DWORD, 1541

CFE\_PSP\_MEM\_SIZE\_WORD, 1541  
CFE\_PSP\_Main, 1553  
CFE\_PSP\_MemCopy, 1553  
CFE\_PSP\_MemRangeGet, 1553  
CFE\_PSP\_MemRangeSet, 1553  
CFE\_PSP\_MemRanges, 1553  
CFE\_PSP\_MemRead16, 1554  
CFE\_PSP\_MemRead32, 1554  
CFE\_PSP\_MemRead8, 1554  
CFE\_PSP\_MemSet, 1554  
CFE\_PSP\_MemValidateRange, 1554  
CFE\_PSP\_MemWrite16, 1554  
CFE\_PSP\_MemWrite32, 1555  
CFE\_PSP\_MemWrite8, 1555  
CFE\_PSP\_PANIC\_CORE\_APP, 1541  
CFE\_PSP\_PANIC\_GENERAL\_FAILURE, 1541  
CFE\_PSP\_PANIC\_MEMORY\_ALLOC, 1542  
CFE\_PSP\_PANIC\_NONVOL\_DISK, 1542  
CFE\_PSP\_PANIC\_STARTUP\_SEM, 1542  
CFE\_PSP\_PANIC\_STARTUP, 1542  
CFE\_PSP\_PANIC\_VOLATILE\_DISK, 1542  
CFE\_PSP\_Panic, 1555  
CFE\_PSP\_PortRead16, 1555  
CFE\_PSP\_PortRead32, 1555  
CFE\_PSP\_PortRead8, 1555  
CFE\_PSP\_PortWrite16, 1556  
CFE\_PSP\_PortWrite32, 1556  
CFE\_PSP\_PortWrite8, 1556  
CFE\_PSP\_RST\_SUBTYPE\_BANKSWITCH\_RES←  
ET, 1542  
CFE\_PSP\_RST\_SUBTYPE\_EXCEPTION, 1543  
CFE\_PSP\_RST\_SUBTYPE\_HW\_SPECIAL\_COM←  
MAND, 1543  
CFE\_PSP\_RST\_SUBTYPE\_HW\_WATCHDOG,  
1543  
CFE\_PSP\_RST\_SUBTYPE\_HWDEBUG\_RESET,  
1543  
CFE\_PSP\_RST\_SUBTYPE\_MAX, 1543  
CFE\_PSP\_RST\_SUBTYPE\_POWER\_CYCLE, 1544  
CFE\_PSP\_RST\_SUBTYPE\_PUSH\_BUTTON, 1544  
CFE\_PSP\_RST\_SUBTYPE\_RESET\_COMMAND,  
1544  
CFE\_PSP\_RST\_SUBTYPE\_UNDEFINED\_RESET,  
1544  
CFE\_PSP\_RST\_TYPE\_MAX, 1544  
CFE\_PSP\_RST\_TYPE\_POWERON, 1545  
CFE\_PSP\_RST\_TYPE\_PROCESSOR, 1545  
CFE\_PSP\_ReadFromCDS, 1556  
CFE\_PSP\_Restart, 1556  
CFE\_PSP\_SOFT\_TIMEBASE\_NAME, 1545  
CFE\_PSP\_SetDefaultExceptionEnvironment, 1556  
CFE\_PSP\_WatchdogDisable, 1557  
CFE\_PSP\_WatchdogEnable, 1557  
CFE\_PSP\_WatchdogGet, 1557  
CFE\_PSP\_WatchdogInit, 1557  
CFE\_PSP\_WatchdogService, 1557  
CFE\_PSP\_WatchdogSet, 1557  
CFE\_PSP\_WriteToCDS, 1557  
SIZE\_BYTE, 1545  
SIZE\_HALF, 1545  
SIZE\_WORD, 1546  
cfe\_psp\_error.h  
CFE\_PSP\_ERROR\_ADDRESS\_MISALIGNED,  
1559  
CFE\_PSP\_ERROR\_NOT\_IMPLEMENTED, 1559  
CFE\_PSP\_ERROR\_TIMEOUT, 1559  
CFE\_PSP\_ERROR, 1559  
CFE\_PSP\_INVALID\_INT\_NUM, 1559  
CFE\_PSP\_INVALID\_MEM\_ADDR, 1560  
CFE\_PSP\_INVALID\_MEM\_ATTR, 1560  
CFE\_PSP\_INVALID\_MEM\_RANGE, 1560  
CFE\_PSP\_INVALID\_MEM\_SIZE, 1560  
CFE\_PSP\_INVALID\_MEM\_TYPE, 1560  
CFE\_PSP\_INVALID\_MEM\_WORDSIZE, 1560  
CFE\_PSP\_INVALID\_MODULE\_ID, 1561  
CFE\_PSP\_INVALID\_MODULE\_NAME, 1561  
CFE\_PSP\_INVALID\_POINTER, 1561  
CFE\_PSP\_NO\_EXCEPTION\_DATA, 1561  
CFE\_PSP\_STATUS\_STRING\_LENGTH, 1561  
CFE\_PSP\_STATUS\_C, 1561  
CFE\_PSP\_SUCCESS, 1562  
CFE\_PSP\_Status\_t, 1562  
CFE\_PSP\_StatusString\_t, 1562  
CFE\_PSP\_StatusToString, 1562  
cfe\_resourceid.h  
CFE\_RESOURCEID\_TEST\_DEFINED, 1199  
CFE\_RESOURCEID\_TEST\_EQUAL, 1199  
CFE\_RESOURCEID\_TO ULONG, 1199  
CFE\_Resourceld\_Equal, 1200  
CFE\_Resourceld\_FindNext, 1200  
CFE\_Resourceld\_FromInteger, 1201  
CFE\_Resourceld\_GetBase, 1202  
CFE\_Resourceld\_GetSerial, 1202  
CFE\_Resourceld\_IsDefined, 1203  
CFE\_Resourceld\_ToIndex, 1204  
CFE\_Resourceld\_ToInteger, 1205  
cfe\_resourceid\_api\_typedefs.h  
CFE\_RESOURCEID\_RESERVED, 1206  
CFE\_RESOURCEID\_UNDEFINED, 1206  
cfe\_resourceid\_basevalue.h  
CFE\_RESOURCEID\_MAKE\_BASE, 1358  
CFE\_RESOURCEID\_MAX, 1358  
CFE\_RESOURCEID\_SHIFT, 1358  
cfe\_sb.h  
CFE\_BIT, 1208  
CFE\_CLR, 1209  
CFE\_SET, 1209  
CFE\_TST, 1209

cfe\_sb\_api\_typedefs.h

- CFE\_SB\_Buffer\_t, 1214
- CFE\_SB\_DEFAULT\_QOS, 1211
- CFE\_SB\_INVALID\_MSG\_ID, 1211
- CFE\_SB\_INVALID\_PIPE, 1211
- CFE\_SB\_MSGID\_RESERVED, 1212
- CFE\_SB\_MSGID\_UNWRAP\_VALUE, 1212
- CFE\_SB\_MSGID\_WRAP\_VALUE, 1212
- CFE\_SB\_MSGID\_C, 1211
- CFE\_SB\_PEND\_FOREVER, 1213
- CFE\_SB\_PIPEID\_C, 1213
- CFE\_SB\_POLL, 1213
- CFE\_SB\_SUBSCRIPTION, 1214
- CFE\_SB\_UNSUBSCRIPTION, 1214

cfe\_sb\_events.h

- CFE\_SB\_BAD\_CMD\_CODE\_EID, 1361
- CFE\_SB\_BAD\_MSGID\_EID, 1361
- CFE\_SB\_BAD\_PIPEID\_EID, 1362
- CFE\_SB\_CMD0\_RCVD\_EID, 1362
- CFE\_SB\_CMD1\_RCVD\_EID, 1362
- CFE\_SB\_CR\_PIPE\_BAD\_ARG\_EID, 1363
- CFE\_SB\_CR\_PIPE\_ERR\_EID, 1363
- CFE\_SB\_CR\_PIPE\_NAME\_TAKEN\_EID, 1363
- CFE\_SB\_CR\_PIPE\_NO\_FREE\_EID, 1364
- CFE\_SB\_DEL\_PIPE\_ERR1\_EID, 1364
- CFE\_SB\_DEL\_PIPE\_ERR2\_EID, 1364
- CFE\_SB\_DEST\_BLK\_ERR\_EID, 1365
- CFE\_SB\_DSBL RTE1\_EID, 1365
- CFE\_SB\_DSBL RTE2\_EID, 1365
- CFE\_SB\_DSBL RTE3\_EID, 1366
- CFE\_SB\_DUP\_SUBSCRIPT\_EID, 1366
- CFE\_SB\_ENBL RTE1\_EID, 1366
- CFE\_SB\_ENBL RTE2\_EID, 1367
- CFE\_SB\_ENBL RTE3\_EID, 1367
- CFE\_SB\_FILEWRITE\_ERR\_EID, 1367
- CFE\_SB\_FULL\_SUB\_PKT\_EID, 1368
- CFE\_SB\_GET\_BUF\_ERR\_EID, 1368
- CFE\_SB\_GETPIPEIDBYNAME\_EID, 1368
- CFE\_SB\_GETPIPEIDBYNAME\_NAME\_ERR\_EID, 1369
- CFE\_SB\_GETPIPEIDBYNAME\_NULL\_ERR\_EID, 1369
- CFE\_SB\_GETPIPENAME\_EID, 1369
- CFE\_SB\_GETPIPENAME\_ID\_ERR\_EID, 1370
- CFE\_SB\_GETPIPENAME\_NULL\_PTR\_EID, 1370
- CFE\_SB\_GETPIPEOPTS\_EID, 1370
- CFE\_SB\_GETPIPEOPTS\_ID\_ERR\_EID, 1371
- CFE\_SB\_GETPIPEOPTS\_PTR\_ERR\_EID, 1371
- CFE\_SB\_HASHCOLLISION\_EID, 1371
- CFE\_SB\_INIT\_EID, 1372
- CFE\_SB\_LEN\_ERR\_EID, 1372
- CFE\_SB\_MAX\_DESTS\_MET\_EID, 1372
- CFE\_SB\_MAX\_MSGS\_MET\_EID, 1373
- CFE\_SB\_MAX\_PIPES\_MET\_EID, 1373

CFE\_SB\_MSG\_TOO\_BIG\_EID, 1373

CFE\_SB\_MSGID\_LIM\_ERR\_EID, 1374

CFE\_SB\_PART\_SUB\_PKT\_EID, 1374

CFE\_SB\_PIPE\_ADDED\_EID, 1374

CFE\_SB\_PIPE\_DELETED\_EID, 1375

CFE\_SB\_Q\_FULL\_ERR\_EID, 1375

CFE\_SB\_Q\_RD\_ERR\_EID, 1375

CFE\_SB\_Q\_WR\_ERR\_EID, 1376

CFE\_SB\_RCV\_BAD\_ARG\_EID, 1376

CFE\_SB\_SEND\_BAD\_ARG\_EID, 1376

CFE\_SB\_SEND\_INV\_MSGID\_EID, 1377

CFE\_SB\_SEND\_NO\_SUBS\_EID, 1377

CFE\_SB\_SETPipeopts\_EID, 1377

CFE\_SB\_SETPipeopts\_ID\_ERR\_EID, 1378

CFE\_SB\_SETPipeopts\_Owner\_ERR\_EID, 1378

CFE\_SB\_SND\_RTG\_EID, 1378

CFE\_SB\_SND\_RTG\_ERR1\_EID, 1379

CFE\_SB\_SND\_STATS\_EID, 1379

CFE\_SB\_SUB\_ARG\_ERR\_EID, 1379

CFE\_SB\_SUB\_INV\_CALLER\_EID, 1380

CFE\_SB\_SUB\_INV\_PIPE\_EID, 1380

CFE\_SB\_SUBSCRIPTION\_RCVD\_EID, 1380

CFE\_SB\_SUBSCRIPTION\_REMOVED\_EID, 1381

CFE\_SB\_SUBSCRIPTION\_RPT\_EID, 1381

CFE\_SB\_UNSUB\_ARG\_ERR\_EID, 1381

CFE\_SB\_UNSUB\_INV\_CALLER\_EID, 1382

CFE\_SB\_UNSUB\_INV\_PIPE\_EID, 1382

CFE\_SB\_UNSUB\_NO\_SUBS\_EID, 1382

cfe\_sb\_extern\_typedefs.h

- CFE\_SB\_MsgId\_Atom\_t, 1216
- CFE\_SB\_Pipeld\_t, 1216
- CFE\_SB\_QosPriority, 1217
- CFE\_SB\_QosPriority\_Enum\_t, 1216
- CFE\_SB\_QosReliability, 1217
- CFE\_SB\_QosReliability\_Enum\_t, 1216
- CFE\_SB\_Routeld\_Atom\_t, 1217
- CFE\_SB\_SUB\_ENTRIES\_PER\_PKT, 1215

cfe\_sb\_msg.h

- CFE\_SB\_AllSubscriptionsTlm\_Payload\_t, 1396
- CFE\_SB\_AllSubscriptionsTlm\_t, 1396
- CFE\_SB\_DISABLE\_ROUTE\_CC, 1385
- CFE\_SB\_DISABLE\_SUB\_REPORTING\_CC, 1385
- CFE\_SB\_DisableRouteCmd\_t, 1396
- CFE\_SB\_DisableSubReportingCmd\_t, 1396
- CFE\_SB\_ENABLE\_ROUTE\_CC, 1386
- CFE\_SB\_ENABLE\_SUB\_REPORTING\_CC, 1387
- CFE\_SB\_EnableRouteCmd\_t, 1396
- CFE\_SB\_EnableSubReportingCmd\_t, 1396
- CFE\_SB\_HousekeepingTlm\_Payload\_t, 1397
- CFE\_SB\_HousekeepingTlm\_t, 1397
- CFE\_SB\_MsgMapFileEntry\_t, 1397
- CFE\_SB\_NOOP\_CC, 1388
- CFE\_SB\_NoopCmd\_t, 1397
- CFE\_SB\_PipeDepthStats\_t, 1397

CFE\_SB\_PipeInfoEntry\_t, 1397  
CFE\_SB\_RESET\_COUNTERS\_CC, 1389  
CFE\_SB\_ResetCountersCmd\_t, 1398  
CFE\_SB\_RouteCmd\_Payload\_t, 1398  
CFE\_SB\_RouteCmd\_t, 1398  
CFE\_SB\_RoutingFileEntry\_t, 1398  
CFE\_SB\_SEND\_PREV\_SUBS\_CC, 1390  
CFE\_SB\_SEND\_SB\_STATS\_CC, 1391  
CFE\_SB\_SendPrevSubsCmd\_t, 1398  
CFE\_SB\_SendSbStatsCmd\_t, 1399  
CFE\_SB\_SingleSubscriptionTlm\_Payload\_t, 1399  
CFE\_SB\_SingleSubscriptionTlm\_t, 1399  
CFE\_SB\_StatsTlm\_Payload\_t, 1399  
CFE\_SB\_StatsTlm\_t, 1399  
CFE\_SB\_SubEntries\_t, 1400  
CFE\_SB\_WRITE\_MAP\_INFO\_CC, 1392  
CFE\_SB\_WRITE\_PIPE\_INFO\_CC, 1393  
CFE\_SB\_WRITE\_ROUTING\_INFO\_CC, 1394  
CFE\_SB\_WriteFileInfoCmd\_Payload\_t, 1400  
CFE\_SB\_WriteFileInfoCmd\_t, 1400  
CFE\_SB\_WriteMapInfoCmd\_t, 1400  
CFE\_SB\_WritePipeInfoCmd\_t, 1400  
CFE\_SB\_WriteRoutingInfoCmd\_t, 1400  
cfe\_tbl\_api\_typedefs.h  
CFE\_TBL\_BAD\_TABLE\_HANDLE, 1221  
CFE\_TBL\_CallbackFuncPtr\_t, 1221  
CFE\_TBL\_Handle\_t, 1221  
CFE\_TBL\_Info\_t, 1221  
CFE\_TBL\_MAX\_FULL\_NAME\_LEN, 1221  
CFE\_TBL\_SrcEnum, 1222  
CFE\_TBL\_SrcEnum\_t, 1222  
cfe\_tbl\_events.h  
CFE\_TBL\_ACTIVATE\_DUMP\_ONLY\_ERR\_EID,  
    1403  
CFE\_TBL\_ACTIVATE\_ERR\_EID, 1404  
CFE\_TBL\_ASSUMED\_VALID\_INF\_EID, 1404  
CFE\_TBL\_CC1\_ERR\_EID, 1404  
CFE\_TBL\_CDS\_DELETE\_ERR\_EID, 1405  
CFE\_TBL\_CDS\_DELETED\_INFO\_EID, 1405  
CFE\_TBL\_CDS\_NOT\_FOUND\_ERR\_EID, 1405  
CFE\_TBL\_CDS\_OWNER\_ACTIVE\_ERR\_EID, 1406  
CFE\_TBL\_CREATING\_DUMP\_FILE\_ERR\_EID,  
    1406  
CFE\_TBL\_DUMP\_PENDING\_ERR\_EID, 1406  
CFE\_TBL\_FAIL\_HK\_SEND\_ERR\_EID, 1407  
CFE\_TBL\_FAIL\_NOTIFY\_SEND\_ERR\_EID, 1407  
CFE\_TBL\_FILE\_ACCESS\_ERR\_EID, 1407  
CFE\_TBL\_FILE\_INCOMPLETE\_ERR\_EID, 1408  
CFE\_TBL\_FILE\_LOADED\_INF\_EID, 1408  
CFE\_TBL\_FILE\_STD\_HDR\_ERR\_EID, 1408  
CFE\_TBL\_FILE\_SUBTYPE\_ERR\_EID, 1409  
CFE\_TBL\_FILE\_TBL\_HDR\_ERR\_EID, 1409  
CFE\_TBL\_FILE\_TOO\_BIG\_ERR\_EID, 1409  
CFE\_TBL\_FILE\_TYPE\_ERR\_EID, 1410  
CFE\_TBL\_HANDLE\_ACCESS\_ERR\_EID, 1410  
CFE\_TBL\_ILLEGAL\_BUFF\_PARAM\_ERR\_EID,  
    1410  
CFE\_TBL\_IN\_REGISTRY\_ERR\_EID, 1411  
CFE\_TBL\_INIT\_INF\_EID, 1411  
CFE\_TBL\_INTERNAL\_ERROR\_ERR\_EID, 1411  
CFE\_TBL\_LEN\_ERR\_EID, 1412  
CFE\_TBL\_LOAD\_ABORT\_ERR\_EID, 1412  
CFE\_TBL\_LOAD\_ABORT\_INF\_EID, 1412  
CFE\_TBL\_LOAD\_EXCEEDS\_SIZE\_ERR\_EID, 1413  
CFE\_TBL\_LOAD\_FILENAME\_LONG\_ERR\_EID,  
    1413  
CFE\_TBL\_LOAD\_IN\_PROGRESS\_ERR\_EID, 1413  
CFE\_TBL\_LOAD\_PEND\_REQ\_INF\_EID, 1414  
CFE\_TBL\_LOAD\_SUCCESS\_INF\_EID, 1414  
CFE\_TBL\_LOAD\_TBLNAME\_MISMATCH\_ERR\_←  
    EID, 1414  
CFE\_TBL\_LOAD\_TYPE\_ERR\_EID, 1415  
CFE\_TBL\_LOAD\_VAL\_ERR\_EID, 1415  
CFE\_TBL\_LOADING\_A\_DUMP\_ONLY\_ERR\_EID,  
    1415  
CFE\_TBL\_LOADING\_PENDING\_ERR\_EID, 1416  
CFE\_TBL\_MID\_ERR\_EID, 1416  
CFE\_TBL\_NO\_INACTIVE\_BUFFER\_ERR\_EID,  
    1416  
CFE\_TBL\_NO SUCH\_TABLE\_ERR\_EID, 1417  
CFE\_TBL\_NO\_WORK\_BUFFERS\_ERR\_EID, 1417  
CFE\_TBL\_NOOP\_INF\_EID, 1417  
CFE\_TBL\_NOT\_CRITICAL\_TBL\_ERR\_EID, 1418  
CFE\_TBL\_NOT\_IN\_CRIT\_REG\_ERR\_EID, 1418  
CFE\_TBL\_OVERWRITE\_DUMP\_INF\_EID, 1418  
CFE\_TBL\_OVERWRITE\_REG\_DUMP\_INF\_EID,  
    1419  
CFE\_TBL\_PARTIAL\_LOAD\_ERR\_EID, 1419  
CFE\_TBL\_PROCESSOR\_ID\_ERR\_EID, 1419  
CFE\_TBL\_REGISTER\_ERR\_EID, 1420  
CFE\_TBL\_RESET\_INF\_EID, 1420  
CFE\_TBL\_SHARE\_ERR\_EID, 1420  
CFE\_TBL\_SPACECRAFT\_ID\_ERR\_EID, 1421  
CFE\_TBL\_TLM\_REG\_CMD\_INF\_EID, 1421  
CFE\_TBL\_TOO\_MANY\_DUMPS\_ERR\_EID, 1421  
CFE\_TBL\_TOO\_MANY\_VALIDATIONS\_ERR\_EID,  
    1422  
CFE\_TBL\_UNREGISTER\_ERR\_EID, 1422  
CFE\_TBL\_UNVALIDATED\_ERR\_EID, 1422  
CFE\_TBL\_UPDATE\_ERR\_EID, 1423  
CFE\_TBL\_UPDATE\_SUCCESS\_INF\_EID, 1423  
CFE\_TBL\_VAL\_REQ\_MADE\_INF\_EID, 1423  
CFE\_TBL\_VALIDATION\_ERR\_EID, 1424  
CFE\_TBL\_VALIDATION\_INF\_EID, 1424  
CFE\_TBL\_WRITE\_CFE\_HDR\_ERR\_EID, 1424  
CFE\_TBL\_WRITE\_DUMP\_INF\_EID, 1425  
CFE\_TBL\_WRITE\_REG\_DUMP\_INF\_EID, 1425  
CFE\_TBL\_WRITE\_TBL\_HDR\_ERR\_EID, 1425

CFE\_TBL\_WRITE\_TBL\_IMG\_ERR\_EID, 1426  
 CFE\_TBL\_WRITE\_TBL\_REG\_ERR\_EID, 1426  
 CFE\_TBL\_ZERO\_LENGTH\_LOAD\_ERR\_EID, 1426  
**cfe\_tbl\_extern\_typedefs.h**  
   CFE\_TBL\_BufferSelect, 1223  
   CFE\_TBL\_BufferSelect\_Enum\_t, 1223  
   CFE\_TBL\_File\_Hdr\_t, 1223  
**cfe\_tbl\_filedef.h**  
   CFE\_TBL\_FILEDEF, 1225  
   CFE\_TBL\_FileDef\_t, 1225  
**cfe\_tbl\_msg.h**  
   CFE\_TBL\_ABORT\_LOAD\_CC, 1429  
   CFE\_TBL\_ACTIVATE\_CC, 1430  
   CFE\_TBL\_AbortLoadCmd\_Payload\_t, 1440  
   CFE\_TBL\_AbortLoadCmd\_t, 1440  
   CFE\_TBL\_ActivateCmd\_Payload\_t, 1440  
   CFE\_TBL\_ActivateCmd\_t, 1440  
   CFE\_TBL\_DELETE\_CDS\_CC, 1431  
   CFE\_TBL\_DUMP\_CC, 1432  
   CFE\_TBL\_DUMP\_REGISTRY\_CC, 1433  
   CFE\_TBL\_DelCDSCmd\_Payload\_t, 1440  
   CFE\_TBL\_DeleteCDSCmd\_t, 1440  
   CFE\_TBL\_DumpCmd\_Payload\_t, 1441  
   CFE\_TBL\_DumpCmd\_t, 1441  
   CFE\_TBL\_DumpRegistryCmd\_Payload\_t, 1441  
   CFE\_TBL\_DumpRegistryCmd\_t, 1441  
   CFE\_TBL\_HousekeepingTlm\_Payload\_t, 1441  
   CFE\_TBL\_HousekeepingTlm\_t, 1441  
   CFE\_TBL\_LOAD\_CC, 1434  
   CFE\_TBL\_LoadCmd\_Payload\_t, 1442  
   CFE\_TBL\_LoadCmd\_t, 1442  
   CFE\_TBL\_NOOP\_CC, 1435  
   CFE\_TBL\_NoArgsCmd\_t, 1442  
   CFE\_TBL\_NoopCmd\_t, 1442  
   CFE\_TBL\_NotifyCmd\_Payload\_t, 1442  
   CFE\_TBL\_NotifyCmd\_t, 1443  
   CFE\_TBL\_RESET\_COUNTERS\_CC, 1436  
   CFE\_TBL\_ResetCountersCmd\_t, 1443  
   CFE\_TBL\_SEND\_REGISTRY\_CC, 1437  
   CFE\_TBL\_SendRegistryCmd\_Payload\_t, 1443  
   CFE\_TBL\_SendRegistryCmd\_t, 1443  
   CFE\_TBL\_TableRegistryTlm\_t, 1443  
   CFE\_TBL\_TblRegPacket\_Payload\_t, 1443  
   CFE\_TBL\_VALIDATE\_CC, 1438  
   CFE\_TBL\_ValidateCmd\_Payload\_t, 1444  
   CFE\_TBL\_ValidateCmd\_t, 1444  
**cfe\_time.h**  
   CFE\_TIME\_Copy, 1227  
**cfe\_time\_api\_typedefs.h**  
   CFE\_TIME\_Compare, 1229  
   CFE\_TIME\_Compare\_t, 1229  
   CFE\_TIME\_PRINTED\_STRING\_SIZE, 1228  
   CFE\_TIME\_SynchCallbackPtr\_t, 1229  
**cfe\_time\_events.h**  
**cfe\_time\_extern\_typedefs.h**  
   CFE\_TIME\_AdjustDirection, 1233  
   CFE\_TIME\_AdjustDirection\_Enum\_t, 1231  
   CFE\_TIME\_ClockState, 1234  
   CFE\_TIME\_ClockState\_Enum\_t, 1231  
   CFE\_TIME\_FlagBit, 1234  
   CFE\_TIME\_FlagBit\_Enum\_t, 1232  
   CFE\_TIME\_FlywheelState, 1235  
   CFE\_TIME\_FlywheelState\_Enum\_t, 1232  
   CFE\_TIME\_SetState, 1235  
   CFE\_TIME\_SetState\_Enum\_t, 1232  
   CFE\_TIME\_SourceSelect, 1235  
   CFE\_TIME\_SourceSelect\_Enum\_t, 1233  
   CFE\_TIME\_SysTime\_t, 1233  
   CFE\_TIME\_ToneSignalSelect, 1235  
   CFE\_TIME\_ToneSignalSelect\_Enum\_t, 1233  
**cfe\_time\_msg.h**  
   CFE\_TIME\_1HzCmd\_t, 1478

CFE\_TIME\_ADD\_1HZ\_ADJUSTMENT\_CC, 1461  
CFE\_TIME\_ADD\_ADJUST\_CC, 1462  
CFE\_TIME\_ADD\_DELAY\_CC, 1463  
CFE\_TIME\_Add1HZAdjustmentCmd\_t, 1479  
CFE\_TIME\_AddAdjustCmd\_t, 1479  
CFE\_TIME\_AddDelayCmd\_t, 1479  
CFE\_TIME\_DiagnosticTlm\_Payload\_t, 1479  
CFE\_TIME\_DiagnosticTlm\_t, 1479  
CFE\_TIME\_FakeToneCmd\_t, 1479  
CFE\_TIME\_HousekeepingTlm\_Payload\_t, 1480  
CFE\_TIME\_HousekeepingTlm\_t, 1480  
CFE\_TIME\_LeapsCmd\_Payload\_t, 1480  
CFE\_TIME\_NOOP\_CC, 1464  
CFE\_TIME\_NoArgsCmd\_t, 1480  
CFE\_TIME\_NoopCmd\_t, 1480  
CFE\_TIME\_OneHzAdjustmentCmd\_Payload\_t, 1480  
CFE\_TIME\_OneHzAdjustmentCmd\_t, 1481  
CFE\_TIME\_RESET\_COUNTERS\_CC, 1465  
CFE\_TIME\_ResetCountersCmd\_t, 1481  
CFE\_TIME\_SEND\_DIAGNOSTIC\_TLM\_CC, 1466  
CFE\_TIME\_SET\_LEAP\_SECONDS\_CC, 1467  
CFE\_TIME\_SET\_MET\_CC, 1468  
CFE\_TIME\_SET\_SIGNAL\_CC, 1469  
CFE\_TIME\_SET\_SOURCE\_CC, 1470  
CFE\_TIME\_SET\_STATE\_CC, 1471  
CFE\_TIME\_SET\_STCF\_CC, 1473  
CFE\_TIME\_SET\_TIME\_CC, 1474  
CFE\_TIME\_SUB\_1HZ\_ADJUSTMENT\_CC, 1475  
CFE\_TIME\_SUB\_ADJUST\_CC, 1476  
CFE\_TIME\_SUB\_DELAY\_CC, 1477  
CFE\_TIME\_SendDiagnosticCmd\_t, 1481  
CFE\_TIME\_SetLeapSecondsCmd\_t, 1481  
CFE\_TIME\_SetMETCmd\_t, 1481  
CFE\_TIME\_SetSTCFCmd\_t, 1482  
CFE\_TIME\_SetSignalCmd\_t, 1481  
CFE\_TIME\_SetSourceCmd\_t, 1482  
CFE\_TIME\_SetStateCmd\_t, 1482  
CFE\_TIME\_SetTimeCmd\_t, 1482  
CFE\_TIME\_SignalCmd\_Payload\_t, 1482  
CFE\_TIME\_SourceCmd\_Payload\_t, 1482  
CFE\_TIME\_StateCmd\_Payload\_t, 1483  
CFE\_TIME\_Sub1HZAdjustmentCmd\_t, 1483  
CFE\_TIME\_SubAdjustCmd\_t, 1483  
CFE\_TIME\_SubDelayCmd\_t, 1483  
CFE\_TIME\_TimeCmd\_Payload\_t, 1483  
CFE\_TIME\_TimeCmd\_t, 1483  
CFE\_TIME\_ToneDataCmd\_Payload\_t, 1484  
CFE\_TIME\_ToneDataCmd\_t, 1484  
CFE\_TIME\_ToneSignalCmd\_t, 1484  
cfe\_version.h  
CFE\_BUILD\_BASELINE, 1237  
CFE\_BUILD\_NUMBER, 1237  
CFE\_MAJOR\_VERSION, 1237  
CFE\_MINOR\_VERSION, 1237  
CFE\_MISSION\_REV, 1237  
CFE\_REVISION, 1237  
CFE\_SRC\_VERSION, 1238  
CFE\_STR\_HELPER, 1238  
CFE\_STR, 1238  
CFE\_VERSION\_STRING, 1238  
CheckErrCtr  
CFE\_ES\_MemPoolStats, 597  
ClockFlyState  
CFE\_TIME\_DiagnosticTlm\_Payload, 740  
ClockSetState  
CFE\_TIME\_DiagnosticTlm\_Payload, 740  
ClockSignal  
CFE\_TIME\_DiagnosticTlm\_Payload, 740  
ClockSource  
CFE\_TIME\_DiagnosticTlm\_Payload, 740  
ClockState  
CFE\_TIME\_StateCmd\_Payload, 764  
ClockStateAPI  
CFE\_TIME\_DiagnosticTlm\_Payload, 741  
CFE\_TIME\_HousekeepingTlm\_Payload, 751  
ClockStateFlags  
CFE\_TIME\_DiagnosticTlm\_Payload, 741  
CFE\_TIME\_HousekeepingTlm\_Payload, 751  
CloseSeconds  
DS\_FileHeader\_t, 804  
CloseSubsecs  
DS\_FileHeader\_t, 804  
CmdAcceptedCounter  
DS\_AppData\_t, 772  
DS\_HkPacket\_t, 821  
CmdHeader  
DS\_AddMidCmd\_t, 770  
DS\_AppStateCmd\_t, 782  
DS\_CloseAllCmd\_t, 783  
DS\_CloseFileCmd\_t, 784  
DS\_DestAgeCmd\_t, 785  
DS\_DestBaseCmd\_t, 787  
DS\_DestCountCmd\_t, 789  
DS\_DestExtCmd\_t, 790  
DS\_DestPathCmd\_t, 796  
DS\_DestSizeCmd\_t, 797  
DS\_DestStateCmd\_t, 799  
DS\_DestTypeCmd\_t, 800  
DS\_FilterFileCmd\_t, 809  
DS\_FilterParmsCmd\_t, 813  
DS\_FilterTypeCmd\_t, 816  
DS\_GetFileInfoCmd\_t, 818  
DS\_NoopCmd\_t, 825  
DS\_ResetCmd\_t, 827  
CmdRejectedCounter  
DS\_AppData\_t, 772  
DS\_HkPacket\_t, 821  
code\_address

OS\_module\_address\_t, 837  
code\_size  
  OS\_module\_address\_t, 837  
CodeAddress  
  CFE\_ES\_AppInfo, 567  
CodeSize  
  CFE\_ES\_AppInfo, 567  
CommandCounter  
  CFE\_ES\_HousekeepingTlm\_Payload, 587  
  CFE\_EVS\_HousekeepingTlm\_Payload, 642  
  CFE\_SB\_HousekeepingTlm\_Payload, 668  
  CFE\_TBL\_HousekeepingTlm\_Payload, 713  
  CFE\_TIME\_HousekeepingTlm\_Payload, 751  
CommandErrorCounter  
  CFE\_ES\_HousekeepingTlm\_Payload, 587  
  CFE\_EVS\_HousekeepingTlm\_Payload, 642  
  CFE\_SB\_HousekeepingTlm\_Payload, 668  
  CFE\_TBL\_HousekeepingTlm\_Payload, 713  
  CFE\_TIME\_HousekeepingTlm\_Payload, 752  
CommandHeader  
  CFE\_ES\_AppNameCmd, 572  
  CFE\_ES\_DeleteCDSCmd, 578  
  CFE\_ES\_DumpCDSRegistryCmd, 580  
  CFE\_ES\_FileNameCmd, 581  
  CFE\_ES\_NoArgsCmd, 600  
  CFE\_ES\_OverWriteSysLogCmd, 602  
  CFE\_ES\_ReloadAppCmd, 606  
  CFE\_ES\_RestartCmd, 607  
  CFE\_ES\_SendMemPoolStatsCmd, 609  
  CFE\_ES\_SetMaxPRCountCmd, 611  
  CFE\_ES\_SetPerfFilterMaskCmd, 613  
  CFE\_ES\_SetPerfTriggerMaskCmd, 615  
  CFE\_ES\_StartApp, 617  
  CFE\_ES\_StartPerfDataCmd, 621  
  CFE\_ES\_StopPerfDataCmd, 623  
  CFE\_EVS\_AppNameBitMaskCmd, 627  
  CFE\_EVS\_AppNameCmd, 629  
  CFE\_EVS\_AppNameEventIDCmd, 631  
  CFE\_EVS\_AppNameEventIDMaskCmd, 633  
  CFE\_EVS\_BitMaskCmd, 638  
  CFE\_EVS\_NoArgsCmd, 649  
  CFE\_EVS\_SetEventFormatModeCmd, 653  
  CFE\_EVS\_SetLogModeCmd, 655  
  CFE\_EVS\_WriteAppDataFileCmd, 657  
  CFE\_EVS\_WriteLogDataFileCmd, 658  
  CFE\_SB\_RouteCmd, 682  
  CFE\_SB\_WriteFileInfoCmd, 696  
  CFE\_TBL\_AbortLoadCmd, 698  
  CFE\_TBL\_ActivateCmd, 700  
  CFE\_TBL\_DeleteCDSCmd, 702  
  CFE\_TBL\_DumpCmd, 703  
  CFE\_TBL\_DumpRegistryCmd, 706  
  CFE\_TBL\_LoadCmd, 721  
  CFE\_TBL\_NoArgsCmd, 723  
CFE\_TBL\_NotifyCmd, 724  
CFE\_TBL\_SendRegistryCmd, 726  
CFE\_TBL\_ValidateCmd, 734  
CFE\_TIME\_NoArgsCmd, 756  
CFE\_TIME\_OneHzAdjustmentCmd, 756  
CFE\_TIME\_SetLeapSecondsCmd, 758  
CFE\_TIME\_SetSignalCmd, 759  
CFE\_TIME\_SetSourceCmd, 760  
CFE\_TIME\_SetStateCmd, 761  
CFE\_TIME\_TimeCmd, 766  
CFE\_TIME\_ToneDataCmd, 767  
common\_types.h  
  \_EXTENSION\_, 1486  
  CompileTimeAssert, 1486, 1491, 1492  
  cpuaddr, 1487  
  cpudiff, 1488  
  cpusize, 1488  
  int16, 1488  
  int32, 1488  
  int64, 1488  
  int8, 1488  
  intptr, 1489  
  OS\_ArgCallback\_t, 1489  
  OS\_PRINTF, 1486  
  OS\_USED, 1486  
  OSAL\_BLOCKCOUNT\_C, 1486  
  OSAL\_INDEX\_C, 1487  
  OSAL\_OBJTYPE\_C, 1487  
  OSAL\_SIZE\_C, 1487  
  OSAL\_STATUS\_C, 1487  
  osal\_blockcount\_t, 1489  
  osal\_id\_t, 1489  
  osal\_index\_t, 1489  
  osal\_objtype\_t, 1490  
  osal\_status\_t, 1490  
  uint16, 1490  
  uint32, 1490  
  uint64, 1490  
  uint8, 1491  
CompileTimeAssert  
  common\_types.h, 1486, 1491, 1492  
ContentType  
  CFE\_FS\_Header, 661  
cpu1\_msgids.h  
  CFE\_ES\_APP\_TLM\_MID, 1042  
  CFE\_ES\_CMD\_MID, 1042  
  CFE\_ES\_HK\_TLM\_MID, 1043  
  CFE\_ES\_MEMSTATS\_TLM\_MID, 1043  
  CFE\_ES\_SEND\_HK\_MID, 1043  
  CFE\_EVS\_CMD\_MID, 1043  
  CFE\_EVS\_HK\_TLM\_MID, 1043  
  CFE\_EVS\_LONG\_EVENT\_MSG\_MID, 1043  
  CFE\_EVS\_SEND\_HK\_MID, 1044  
  CFE\_EVS\_SHORT\_EVENT\_MSG\_MID, 1044

CFE\_PLATFORM\_CMD\_MID\_BASE\_GLOB, 1044  
CFE\_PLATFORM\_CMD\_MID\_BASE, 1044  
CFE\_PLATFORM\_TLM\_MID\_BASE, 1045  
CFE\_SB\_ALLSUBS\_TLM\_MID, 1045  
CFE\_SB\_CMD\_MID, 1045  
CFE\_SB\_HK\_TLM\_MID, 1045  
CFE\_SB\_ONESUB\_TLM\_MID, 1045  
CFE\_SB\_SEND\_HK\_MID, 1046  
CFE\_SB\_STATS\_TLM\_MID, 1046  
CFE\_SB\_SUB\_RPT\_CTRL\_MID, 1046  
CFE\_TBL\_CMD\_MID, 1046  
CFE\_TBL\_HK\_TLM\_MID, 1046  
CFE\_TBL\_REG\_TLM\_MID, 1046  
CFE\_TBL\_SEND\_HK\_MID, 1047  
CFE\_TEST\_CMD\_MID, 1047  
CFE\_TEST\_HK\_TLM\_MID, 1047  
CFE\_TIME\_1HZ\_CMD\_MID, 1047  
CFE\_TIME\_CMD\_MID, 1047  
CFE\_TIME\_DATA\_CMD\_MID, 1047  
CFE\_TIME\_DIAG\_TLM\_MID, 1048  
CFE\_TIME\_HK\_TLM\_MID, 1048  
CFE\_TIME\_SEND\_CMD\_MID, 1048  
CFE\_TIME\_SEND\_HK\_MID, 1048  
CFE\_TIME\_TONE\_CMD\_MID, 1048  
cpu1\_platform\_cfg.h  
CFE\_PLATFORM\_CORE\_MAX\_STARTUP\_MSEC, 1052  
CFE\_PLATFORM\_ENDIAN, 1053  
CFE\_PLATFORM\_ES\_APP\_KILL\_TIMEOUT, 1053  
CFE\_PLATFORM\_ES\_APP\_SCAN\_RATE, 1054  
CFE\_PLATFORM\_ES\_CDS\_MAX\_BLOCK\_SIZE, 1054  
CFE\_PLATFORM\_ES\_CDS\_MAX\_NUM\_ENTRIES, 1055  
CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_01, 1055  
CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_02, 1055  
CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_03, 1056  
CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_04, 1056  
CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_05, 1056  
CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_06, 1056  
CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_07, 1056  
CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_08, 1056  
CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_09, 1057  
CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_10, 1057  
CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_11, 1057  
CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_12, 1057  
CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_13, 1057  
CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_14, 1057  
CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_15, 1058  
CFE\_PLATFORM\_ES\_CDS\_MEM\_BLOCK\_SIZE\_16, 1058  
CFE\_PLATFORM\_ES\_CDS\_SIZE, 1058  
CFE\_PLATFORM\_ES\_DEFAULT\_APP\_LOG\_FILE, 1058  
CFE\_PLATFORM\_ES\_DEFAULT\_CDS\_REG\_DUMPF\_FILE, 1059  
CFE\_PLATFORM\_ES\_DEFAULT\_ER\_LOG\_FILE, 1059  
CFE\_PLATFORM\_ES\_DEFAULT\_PERF\_DUMP\_FILENAME, 1059  
CFE\_PLATFORM\_ES\_DEFAULT\_POR\_SYSLOG\_MODE, 1060  
CFE\_PLATFORM\_ES\_DEFAULT\_PR\_SYSLOG\_MODE, 1060  
CFE\_PLATFORM\_ES\_DEFAULT\_STACK\_SIZE, 1061  
CFE\_PLATFORM\_ES\_DEFAULT\_SYSLOG\_FILE, 1061  
CFE\_PLATFORM\_ES\_DEFAULT\_TASK\_LOGFILE, 1062  
CFE\_PLATFORM\_ES\_ER\_LOG\_ENTRIES, 1062  
CFE\_PLATFORM\_ES\_ER\_LOG\_MAX\_CONTEXT\_SIZE, 1063  
CFE\_PLATFORM\_ES\_MAX\_APPLICATIONS, 1063  
CFE\_PLATFORM\_ES\_MAX\_BLOCK\_SIZE, 1063  
CFE\_PLATFORM\_ES\_MAX\_GEN\_COUNTERS, 1064  
CFE\_PLATFORM\_ES\_MAX\_LIBRARIES, 1064  
CFE\_PLATFORM\_ES\_MAX\_MEMORY\_POOLS, 1064  
CFE\_PLATFORM\_ES\_MAX\_PROCESSOR\_RESOURCES, 1065  
CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_01, 1065  
CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_02, 1066  
CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_03, 1066  
CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_04, 1066  
CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_05, 1066  
CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_06,

CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_07,  
     **1067**  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_08,  
     **1067**  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_09,  
     **1067**  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_10,  
     **1067**  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_11,  
     **1067**  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_12,  
     **1068**  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_13,  
     **1068**  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_14,  
     **1068**  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_15,  
     **1068**  
 CFE\_PLATFORM\_ES\_MEM\_BLOCK\_SIZE\_16,  
     **1068**  
 CFE\_PLATFORM\_ES\_MEMPOOL\_ALIGN\_SIZE  
     **\_MIN**, **1068**  
 CFE\_PLATFORM\_ES\_NONVOL\_DISK\_MOUNT\_  
     **STRING**, **1069**  
 CFE\_PLATFORM\_ES\_NONVOL\_STARTUP\_FILE,  
     **1069**  
 CFE\_PLATFORM\_ES\_OBJECT\_TABLE\_SIZE,  
     **1069**  
 CFE\_PLATFORM\_ES\_PERF\_CHILD\_MS\_DELAY,  
     **1070**  
 CFE\_PLATFORM\_ES\_PERF\_CHILD\_PRIORITY,  
     **1070**  
 CFE\_PLATFORM\_ES\_PERF\_CHILD\_STACK\_SI  
     **ZE**, **1070**  
 CFE\_PLATFORM\_ES\_PERF\_DATA\_BUFFER\_SI  
     **ZE**, **1071**  
 CFE\_PLATFORM\_ES\_PERF\_ENTRIES\_BTWN\_  
     **DLYS**, **1071**  
 CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_ALL,  
     **1071**  
 CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_INIT,  
     **1072**  
 CFE\_PLATFORM\_ES\_PERF\_FILTMASK\_NONE,  
     **1072**  
 CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_ALL,  
     **1072**  
 CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_INIT,  
     **1073**  
 CFE\_PLATFORM\_ES\_PERF\_TRIGMASK\_NONE,  
     **1073**  
 CFE\_PLATFORM\_ES\_POOL\_MAX\_BUCKETS,  
     **1073**  
 CFE\_PLATFORM\_ES\_RAM\_DISK\_MOUNT\_STR  
     **ING**, **1074**  
 CFE\_PLATFORM\_ES\_RAM\_DISK\_NUM\_SECTO  
     **RS**, **1074**  
 CFE\_PLATFORM\_ES\_RAM\_DISK\_PERCENT\_R  
     **ESERVED**, **1074**  
 CFE\_PLATFORM\_ES\_RAM\_DISK\_SECTOR\_SIZE,  
     **1075**  
 CFE\_PLATFORM\_ES\_RESET\_AREA\_SIZE, **1075**  
 CFE\_PLATFORM\_ES\_START\_TASK\_PRIORITY,  
     **1076**  
 CFE\_PLATFORM\_ES\_START\_TASK\_STACK\_SI  
     **ZE**, **1076**  
 CFE\_PLATFORM\_ES\_STARTUP\_SCRIPT\_TIME  
     **OUT\_MSEC**, **1077**  
 CFE\_PLATFORM\_ES\_STARTUP\_SYNC\_POLL\_  
     **MSEC**, **1077**  
 CFE\_PLATFORM\_ES\_SYSTEM\_LOG\_SIZE, **1078**  
 CFE\_PLATFORM\_ES\_USER\_RESERVED\_SIZE,  
     **1078**  
 CFE\_PLATFORM\_ES\_VOLATILE\_STARTUP\_FILE,  
     **1079**  
 CFE\_PLATFORM\_EVS\_APP\_EVENTS\_PER\_SEC,  
     **1079**  
 CFE\_PLATFORM\_EVS\_DEFAULT\_APP\_DATA\_  
     **FILE**, **1080**  
 CFE\_PLATFORM\_EVS\_DEFAULT\_LOG\_FILE,  
     **1080**  
 CFE\_PLATFORM\_EVS\_DEFAULT\_LOG\_MODE,  
     **1080**  
 CFE\_PLATFORM\_EVS\_DEFAULT\_MSG\_FORM  
     **AT\_MODE**, **1081**  
 CFE\_PLATFORM\_EVS\_DEFAULT\_TYPE\_FLAG,  
     **1081**  
 CFE\_PLATFORM\_EVS\_LOG\_MAX, **1081**  
 CFE\_PLATFORM\_EVS\_MAX\_APP\_EVENT\_BUR  
     **ST**, **1082**  
 CFE\_PLATFORM\_EVS\_MAX\_EVENT\_FILTERS,  
     **1082**  
 CFE\_PLATFORM\_EVS\_PORT\_DEFAULT, **1082**  
 CFE\_PLATFORM\_EVS\_START\_TASK\_PRIORITY,  
     **1083**  
 CFE\_PLATFORM\_EVS\_START\_TASK\_STACK\_  
     **SIZE**, **1083**  
 CFE\_PLATFORM\_SB\_BUF\_MEMORY\_BYTES,  
     **1083**  
 CFE\_PLATFORM\_SB\_DEFAULT\_MAP\_FILENA  
     **ME**, **1084**  
 CFE\_PLATFORM\_SB\_DEFAULT\_MSG\_LIMIT,  
     **1084**  
 CFE\_PLATFORM\_SB\_DEFAULT\_PIPE\_FILENA  
     **ME**, **1085**  
 CFE\_PLATFORM\_SB\_DEFAULT\_ROUTING\_FIL  
     **ENAME**, **1085**  
 CFE\_PLATFORM\_SB\_FILTER\_MASK1, **1085**

CFE\_PLATFORM\_SB\_FILTER\_MASK2, 1086  
CFE\_PLATFORM\_SB\_FILTER\_MASK3, 1086  
CFE\_PLATFORM\_SB\_FILTER\_MASK4, 1086  
CFE\_PLATFORM\_SB\_FILTER\_MASK5, 1086  
CFE\_PLATFORM\_SB\_FILTER\_MASK6, 1086  
CFE\_PLATFORM\_SB\_FILTER\_MASK7, 1086  
CFE\_PLATFORM\_SB\_FILTER\_MASK8, 1087  
CFE\_PLATFORM\_SB\_FILTERED\_EVENT1, 1087  
CFE\_PLATFORM\_SB\_FILTERED\_EVENT2, 1087  
CFE\_PLATFORM\_SB\_FILTERED\_EVENT3, 1087  
CFE\_PLATFORM\_SB\_FILTERED\_EVENT4, 1087  
CFE\_PLATFORM\_SB\_FILTERED\_EVENT5, 1088  
CFE\_PLATFORM\_SB\_FILTERED\_EVENT6, 1088  
CFE\_PLATFORM\_SB\_FILTERED\_EVENT7, 1088  
CFE\_PLATFORM\_SB\_FILTERED\_EVENT8, 1088  
CFE\_PLATFORM\_SB\_HIGHEST\_VALID\_MSGID, 1088  
CFE\_PLATFORM\_SB\_MAX\_BLOCK\_SIZE, 1089  
CFE\_PLATFORM\_SB\_MAX\_DEST\_PER\_PKT, 1089  
CFE\_PLATFORM\_SB\_MAX\_MSG\_IDS, 1089  
CFE\_PLATFORM\_SB\_MAX\_PIPES, 1090  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_01, 1090  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_02, 1091  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_03, 1091  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_04, 1091  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_05, 1091  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_06, 1091  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_07, 1092  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_08, 1092  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_09, 1092  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_10, 1092  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_11, 1092  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_12, 1092  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_13, 1093  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_14, 1093  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_15, 1093  
CFE\_PLATFORM\_SB\_MEM\_BLOCK\_SIZE\_16, 1093  
CFE\_PLATFORM\_SB\_START\_TASK\_PRIORITY, 1093  
CFE\_PLATFORM\_SB\_START\_TASK\_STACK\_SIZE, 1093  
CFE\_PLATFORM\_TBL\_BUF\_MEMORY\_BYTES, 1094  
CFE\_PLATFORM\_TBL\_DEFAULT\_REG\_DUMP\_FILE, 1094  
CFE\_PLATFORM\_TBL\_MAX\_CRITICAL\_TABLES, 1094  
CFE\_PLATFORM\_TBL\_MAX\_DBL\_TABLE\_SIZE, 1095  
CFE\_PLATFORM\_TBL\_MAX\_NUM\_HANDLES, 1095  
CFE\_PLATFORM\_TBL\_MAX\_NUM\_TABLES, 1095  
CFE\_PLATFORM\_TBL\_MAX\_NUM\_VALIFICATIONS, 1096  
CFE\_PLATFORM\_TBL\_MAX\_SIMULTANEOUS\_LOADS, 1096  
CFE\_PLATFORM\_TBL\_MAX\_SNGL\_TABLE\_SIZE, 1096  
CFE\_PLATFORM\_TBL\_START\_TASK\_PRIORITY, 1097  
CFE\_PLATFORM\_TBL\_START\_TASK\_STACK\_SIZE, 1097  
CFE\_PLATFORM\_TBL\_U32FROM4CHARS, 1097  
CFE\_PLATFORM\_TBL\_VALID\_PRID\_1, 1098  
CFE\_PLATFORM\_TBL\_VALID\_PRID\_2, 1098  
CFE\_PLATFORM\_TBL\_VALID\_PRID\_3, 1098  
CFE\_PLATFORM\_TBL\_VALID\_PRID\_4, 1098  
CFE\_PLATFORM\_TBL\_VALID\_PRID\_COUNT, 1099  
CFE\_PLATFORM\_TBL\_VALID\_SCID\_1, 1099  
CFE\_PLATFORM\_TBL\_VALID\_SCID\_2, 1099  
CFE\_PLATFORM\_TBL\_VALID\_SCID\_COUNT, 1100  
CFE\_PLATFORM\_TIME\_1HZ\_TASK\_PRIORITY, 1100  
CFE\_PLATFORM\_TIME\_1HZ\_TASK\_STACK\_SIZE, 1100  
CFE\_PLATFORM\_TIME\_CFG\_CLIENT, 1100  
CFE\_PLATFORM\_TIME\_CFG\_LATCH\_FLY, 1100  
CFE\_PLATFORM\_TIME\_CFG\_SERVER, 1101  
CFE\_PLATFORM\_TIME\_CFG\_SIGNAL, 1101  
CFE\_PLATFORM\_TIME\_CFG\_SOURCE, 1101  
CFE\_PLATFORM\_TIME\_CFG\_SRC\_GPS, 1102  
CFE\_PLATFORM\_TIME\_CFG\_SRC\_MET, 1102  
CFE\_PLATFORM\_TIME\_CFG\_SRC\_TIME, 1102  
CFE\_PLATFORM\_TIME\_CFG\_START\_FLY, 1103  
CFE\_PLATFORM\_TIME\_CFG\_TONE\_LIMIT, 1103  
CFE\_PLATFORM\_TIME\_CFG\_VIRTUAL, 1103  
CFE\_PLATFORM\_TIME\_MAX\_DELTA\_SECS, 1104  
CFE\_PLATFORM\_TIME\_MAX\_DELTA\_SUBS, 1104  
CFE\_PLATFORM\_TIME\_MAX\_LOCAL\_SECS,

1105  
 CFE\_PLATFORM\_TIME\_MAX\_LOCAL\_SUBS,  
   1105  
 CFE\_PLATFORM\_TIME\_START\_TASK\_PRIORITY,  
   TY, 1105  
 CFE\_PLATFORM\_TIME\_START\_TASK\_STACK\_SIZE,  
   1105  
 CFE\_PLATFORM\_TIME\_TONE\_TASK\_PRIORITY,  
   1106  
 CFE\_PLATFORM\_TIME\_TONE\_TASK\_STACK\_SIZE,  
   1106

cpuaddr  
   common\_types.h, 1487

cpudiff  
   common\_types.h, 1488

cupsize  
   common\_types.h, 1488

Crc  
   CFE\_TBL\_Info, 718  
   CFE\_TBL\_TblRegPacket\_Payload, 730

CreatePipeErrorCounter  
   CFE\_SB\_HousekeepingTlm\_Payload, 668

creator  
   OS\_bin\_sem\_prop\_t, 828  
   OS\_count\_sem\_prop\_t, 829  
   OS\_mut\_sem\_prop\_t, 840  
   OS\_queue\_prop\_t, 841  
   OS\_socket\_prop\_t, 844  
   OS\_task\_prop\_t, 847  
   OS\_timebase\_prop\_t, 850  
   OS\_timer\_prop\_t, 851

Critical  
   CFE\_TBL\_Info, 718  
   CFE\_TBL\_TblRegPacket\_Payload, 730

CurrentLatch  
   CFE\_TIME\_DiagnosticTlm\_Payload, 741

CurrentMET  
   CFE\_TIME\_DiagnosticTlm\_Payload, 741

CurrentQueueDepth  
   CFE\_SB\_PipeDepthStats, 676  
   CFE\_SB\_PipeInfoEntry, 678

CurrentTAI  
   CFE\_TIME\_DiagnosticTlm\_Payload, 742

CurrentUTC  
   CFE\_TIME\_DiagnosticTlm\_Payload, 742

DS\_11\_LSB\_SECONDS\_MASK  
   ds\_file.c, 937

DS\_11\_LSB\_SECONDS\_SHIFT  
   ds\_file.c, 937

DS\_16\_MSB\_SUBSECS\_SHIFT  
   ds\_file.c, 938

DS\_4\_MSB\_SUBSECS\_MASK  
   ds\_file.c, 938

DS\_4\_MSB\_SUBSECS\_SHIFT  
   ds\_file.c, 938

DS\_ADD\_MID\_CMD\_EID  
   CFS Data Store Event IDs, 150

DS\_ADD\_MID\_CMD\_ERR\_EID  
   CFS Data Store Event IDs, 150

DS\_ADD\_MID\_CC  
   CFS Data Storage Command Codes, 180

DS\_AGE\_CMD\_EID  
   CFS Data Store Event IDs, 151

DS\_AGE\_CMD\_ERR\_EID  
   CFS Data Store Event IDs, 151

DS\_APP\_PIPE\_DEPTH  
   CFS Data Storage Platform Configuration, 136

DS\_APP\_PIPE\_NAME  
   CFS Data Storage Platform Configuration, 136

DS\_APPHK\_FILTER\_TBL\_ERR\_EID  
   CFS Data Store Event IDs, 152

DS\_APPHK\_FILTER\_TBL\_PRINT\_ERR\_EID  
   CFS Data Store Event IDs, 152

DS\_APPMAIN\_PERF\_ID  
   CFS Data Storage Mission Configuration, 132

DS\_AddMidCmd\_t, 770  
   CmdHeader, 770  
   MessageID, 770

DS\_AppData  
   ds\_app.c, 865  
   ds\_app.h, 877

DS\_AppData\_t, 771  
   AppEnableState, 772  
   CmdAcceptedCounter, 772  
   CmdRejectedCounter, 772  
   DataStoreHandle, 773  
   DestFileTblHandle, 773  
   DestFileTblPtr, 773  
   DestTblErrCounter, 773  
   DestTblLoadCounter, 774  
   DisabledPktCounter, 774  
   FileStatus, 774  
   FileUpdateCounter, 774  
   FileUpdateErrCounter, 775  
   FileWriteCounter, 775  
   FileWriteErrCounter, 775  
   FilterTblErrCounter, 776  
   FilterTblHandle, 776  
   FilterTblLoadCounter, 776  
   FilterTblPtr, 776  
   FilteredPktCounter, 775  
   HashLinks, 777  
   HashTable, 777  
   IgnoredPktCounter, 777  
   InputPipe, 777  
   PassedPktCounter, 778  
   Spare8, 778

DS\_AppFileStatus\_t, [778](#)  
    FileAge, [779](#)  
    FileCount, [779](#)  
    FileGrowth, [780](#)  
    FileHandle, [780](#)  
    FileName, [780](#)  
    FileRate, [780](#)  
    FileSize, [781](#)  
    FileState, [781](#)  
    Unused, [781](#)  
DS\_AppInitialize  
    ds\_app.c, [855](#)  
    ds\_app.h, [867](#)  
DS\_AppMain  
    ds\_app.c, [856](#)  
    ds\_app.h, [868](#)  
DS\_AppProcessCmd  
    ds\_app.c, [857](#)  
    ds\_app.h, [869](#)  
DS\_AppProcessHK  
    ds\_app.c, [859](#)  
    ds\_app.h, [871](#)  
DS\_AppProcessMsg  
    ds\_app.c, [861](#)  
    ds\_app.h, [873](#)  
DS\_AppStateCmd\_t, [782](#)  
    CmdHeader, [782](#)  
    EnableState, [782](#)  
    Padding, [782](#)  
DS\_AppStorePacket  
    ds\_app.c, [863](#)  
    ds\_app.h, [875](#)  
DS\_BASE\_CMD\_EID  
    CFS Data Store Event IDs, [153](#)  
DS\_BASE\_CMD\_ERR\_EID  
    CFS Data Store Event IDs, [153](#)  
DS\_BASENAME\_BUFSIZE  
    CFS Data Storage Platform Configuration, [137](#)  
DS\_BY\_COUNT  
    ds\_appdefs.h, [878](#)  
DS\_BY\_TIME  
    ds\_appdefs.h, [878](#)  
DS\_CDS\_ENABLE\_STATE  
    CFS Data Storage Platform Configuration, [137](#)  
DS\_CDS\_NAME  
    ds\_table.c, [975](#)  
DS\_CLOSE\_ALL\_CMD\_EID  
    CFS Data Store Event IDs, [154](#)  
DS\_CLOSE\_ALL\_CMD\_ERR\_EID  
    CFS Data Store Event IDs, [154](#)  
DS\_CLOSE\_ALL\_CC  
    CFS Data Storage Command Codes, [181](#)  
DS\_CLOSE\_CMD\_EID  
    CFS Data Store Event IDs, [155](#)  
DS\_CLOSE\_CMD\_ERR\_EID  
    CFS Data Store Event IDs, [155](#)  
DS\_CLOSE\_FILE\_CC  
    CFS Data Storage Command Codes, [182](#)  
DS\_CLOSED  
    ds\_appdefs.h, [878](#)  
DS\_CMD\_CODE\_ERR\_EID  
    CFS Data Store Event IDs, [156](#)  
DS\_CMD\_MID  
    CFS Data Storage Message IDs, [133](#)  
DS\_COMP\_TLM\_MID  
    CFS Data Storage Message IDs, [134](#)  
DS\_CREATE\_FILE\_ERR\_EID  
    CFS Data Store Event IDs, [156](#)  
DS\_CloseAllCmd\_t, [783](#)  
    CmdHeader, [783](#)  
DS\_CloseFileCmd\_t, [784](#)  
    CmdHeader, [784](#)  
    FileTableIndex, [784](#)  
    Padding, [784](#)  
DS\_CmdAddMID  
    ds\_cmds.c, [883](#)  
    ds\_cmds.h, [908](#)  
DS\_CmdCloseAll  
    ds\_cmds.c, [884](#)  
    ds\_cmds.h, [910](#)  
DS\_CmdCloseFile  
    ds\_cmds.c, [886](#)  
    ds\_cmds.h, [911](#)  
DS\_CmdGetFileInfo  
    ds\_cmds.c, [887](#)  
    ds\_cmds.h, [912](#)  
DS\_CmdNoop  
    ds\_cmds.c, [889](#)  
    ds\_cmds.h, [914](#)  
DS\_CmdReset  
    ds\_cmds.c, [890](#)  
    ds\_cmds.h, [915](#)  
DS\_CmdSetAppState  
    ds\_cmds.c, [891](#)  
    ds\_cmds.h, [916](#)  
DS\_CmdSetDestAge  
    ds\_cmds.c, [892](#)  
    ds\_cmds.h, [917](#)  
DS\_CmdSetDestBase  
    ds\_cmds.c, [893](#)  
    ds\_cmds.h, [918](#)  
DS\_CmdSetDestCount  
    ds\_cmds.c, [895](#)  
    ds\_cmds.h, [920](#)  
DS\_CmdSetDestExt  
    ds\_cmds.c, [896](#)  
    ds\_cmds.h, [921](#)  
DS\_CmdSetDestPath

ds\_cmds.c, 897  
 ds\_cmds.h, 922  
**DS\_CmdSetDestSize**  
 ds\_cmds.c, 899  
 ds\_cmds.h, 924  
**DS\_CmdSetDestState**  
 ds\_cmds.c, 901  
 ds\_cmds.h, 926  
**DS\_CmdSetDestType**  
 ds\_cmds.c, 902  
 ds\_cmds.h, 927  
**DS\_CmdSetFilterFile**  
 ds\_cmds.c, 903  
 ds\_cmds.h, 928  
**DS\_CmdSetFilterParms**  
 ds\_cmds.c, 905  
 ds\_cmds.h, 930  
**DS\_CmdSetFilterType**  
 ds\_cmds.c, 906  
 ds\_cmds.h, 931  
**DS\_DDD\_INDEX**  
 ds\_file.c, 938  
**DS\_DEF\_DEST\_FILENAME**  
 CFS Data Storage Platform Configuration, 138  
**DS\_DEF\_ENABLE\_STATE**  
 CFS Data Storage Platform Configuration, 138  
**DS\_DEF\_FILTER\_FILENAME**  
 CFS Data Storage Platform Configuration, 138  
**DS\_DESCRIPTOR\_TEXT**  
 ds\_appdefs.h, 879  
**DS\_DESCRIPTOR\_BUFSIZE**  
 CFS Data Storage Platform Configuration, 139  
**DS\_DEST\_FILE\_CNT**  
 CFS Data Storage Platform Configuration, 139  
**DS\_DESTINATION\_TBL\_NAME**  
 CFS Data Storage Platform Configuration, 139  
**DS\_DIAG\_TLM\_MID**  
 CFS Data Storage Message IDs, 134  
**DS\_DISABLED**  
 ds\_appdefs.h, 879  
**DS\_DestAgeCmd\_t**, 785  
 CmdHeader, 785  
 FileTableIndex, 786  
 MaxFileAge, 786  
 Padding, 786  
**DS\_DestBaseCmd\_t**, 786  
 Basename, 787  
 CmdHeader, 787  
 FileTableIndex, 787  
 Padding, 788  
**DS\_DestCountCmd\_t**, 788  
 CmdHeader, 789  
 FileTableIndex, 789  
 Padding, 789  
 SequenceCount, 789  
**DS\_DestExtCmd\_t**, 790  
 CmdHeader, 790  
 Extension, 790  
 FileTableIndex, 790  
 Padding, 791  
**DS\_DestFileEntry\_t**, 791  
 Basename, 792  
 EnableState, 792  
 Extension, 792  
 FileNameType, 792  
 MaxFileAge, 793  
 MaxFileSize, 793  
 Movename, 793  
 Pathname, 793  
 SequenceCount, 794  
**DS\_DestFileTable**  
 ds\_file\_tbl.c, 1029  
**DS\_DestFileTable\_t**, 794  
 Descriptor, 795  
 File, 795  
**DS\_DestPathCmd\_t**, 795  
 CmdHeader, 796  
 FileTableIndex, 796  
 Padding, 796  
 Pathname, 796  
**DS\_DestSizeCmd\_t**, 797  
 CmdHeader, 797  
 FileTableIndex, 798  
 MaxFileSize, 798  
 Padding, 798  
**DS\_DestStateCmd\_t**, 798  
 CmdHeader, 799  
 EnableState, 799  
 FileTableIndex, 799  
**DS\_DestTypeCmd\_t**, 800  
 CmdHeader, 800  
 FileNameType, 801  
 FileTableIndex, 801  
**DS\_EMPTY\_STRING**  
 ds\_appdefs.h, 879  
**DS\_ENABLED**  
 ds\_appdefs.h, 879  
**DS\_ENADIS\_CMD\_EID**  
 CFS Data Store Event IDs, 157  
**DS\_ENADIS\_CMD\_ERR\_EID**  
 CFS Data Store Event IDs, 157  
**DS\_EXIT\_ERR\_EID**  
 CFS Data Store Event IDs, 158  
**DS\_EXT\_CMD\_EID**  
 CFS Data Store Event IDs, 158  
**DS\_EXT\_CMD\_ERR\_EID**  
 CFS Data Store Event IDs, 159  
**DS\_EXTENSION\_BUFSIZE**

CFS Data Storage Platform Configuration, [140](#)  
DS\_FIL\_TBL\_EID  
    CFS Data Store Event IDs, [159](#)  
DS\_FIL\_TBL\_ERR\_EID  
    CFS Data Store Event IDs, [160](#)  
DS\_FILE\_CMD\_EID  
    CFS Data Store Event IDs, [160](#)  
DS\_FILE\_CMD\_ERR\_EID  
    CFS Data Store Event IDs, [161](#)  
DS\_FILE\_CREATE\_EMPTY\_PATH\_ERR\_EID  
    CFS Data Store Event IDs, [161](#)  
DS\_FILE\_HDR\_DESCRIPTION  
    CFS Data Storage Platform Configuration, [140](#)  
DS\_FILE\_HDR\_SUBTYPE  
    CFS Data Storage Platform Configuration, [141](#)  
DS\_FILE\_HEADER\_CFE  
    ds\_appdefs.h, [879](#)  
DS\_FILE\_HEADER\_NONE  
    ds\_appdefs.h, [880](#)  
DS\_FILE\_HEADER\_TYPE  
    CFS Data Storage Platform Configuration, [141](#)  
DS\_FILE\_MIN\_AGE\_LIMIT  
    CFS Data Storage Platform Configuration, [141](#)  
DS\_FILE\_MIN\_SIZE\_LIMIT  
    CFS Data Storage Platform Configuration, [142](#)  
DS\_FILE\_NAME\_ERR\_EID  
    CFS Data Store Event IDs, [162](#)  
DS\_FILENAME\_TEXT  
    ds\_appdefs.h, [880](#)  
DS\_FILTER\_TBL\_NAME  
    CFS Data Storage Platform Configuration, [142](#)  
DS\_FILTERS\_PER\_PACKET  
    CFS Data Storage Platform Configuration, [143](#)  
DS\_FLT\_TBL\_EID  
    CFS Data Store Event IDs, [162](#)  
DS\_FLT\_TBL\_ERR\_EID  
    CFS Data Store Event IDs, [163](#)  
DS\_FTYPE\_CMD\_EID  
    CFS Data Store Event IDs, [163](#)  
DS\_FTYPE\_CMD\_ERR\_EID  
    CFS Data Store Event IDs, [164](#)  
DS\_FileCloseDest  
    ds\_file.c, [940](#)  
    ds\_file.h, [956](#)  
DS\_FileCompletePkt\_t, [801](#)  
    FileInfo, [802](#)  
    TlmHeader, [802](#)  
DS\_FileCompletePktBuf\_t, [802](#)  
    Pkt, [803](#)  
    SBBuf, [803](#)  
DS\_FileCreateDest  
    ds\_file.c, [941](#)  
    ds\_file.h, [957](#)  
DS\_FileCreateName

ds\_file.c, [942](#)  
ds\_file.h, [958](#)  
DS\_FileCreateSequence  
    ds\_file.c, [943](#)  
    ds\_file.h, [959](#)  
DS\_FileHeader\_t, [803](#)  
    CloseSeconds, [804](#)  
    CloseSubsecs, [804](#)  
    FileName, [804](#)  
    FileNameType, [804](#)  
    FileTableIndex, [805](#)  
DS\_FileInfo\_t, [805](#)  
    EnableState, [806](#)  
    FileAge, [806](#)  
    FileName, [806](#)  
    FileRate, [806](#)  
    FileSize, [807](#)  
    OpenState, [807](#)  
    SequenceCount, [807](#)  
DS\_FileInfoPkt\_t, [808](#)  
    FileInfo, [808](#)  
    TlmHeader, [808](#)  
DS\_FileSetupWrite  
    ds\_file.c, [944](#)  
    ds\_file.h, [960](#)  
DS\_FileStorePacket  
    ds\_file.c, [945](#)  
    ds\_file.h, [961](#)  
DS\_FileTestAge  
    ds\_file.c, [947](#)  
    ds\_file.h, [963](#)  
DS\_FileTransmit  
    ds\_file.c, [948](#)  
    ds\_file.h, [964](#)  
DS\_FileUpdateHeader  
    ds\_file.c, [949](#)  
    ds\_file.h, [965](#)  
DS\_FileWriteData  
    ds\_file.c, [950](#)  
    ds\_file.h, [966](#)  
DS\_FileWriteError  
    ds\_file.c, [951](#)  
    ds\_file.h, [967](#)  
DS\_FileWriteHeader  
    ds\_file.c, [952](#)  
    ds\_file.h, [968](#)  
DS\_FilterFileCmd\_t, [809](#)  
    CmdHeader, [809](#)  
    FileTableIndex, [809](#)  
    FilterParmsIndex, [809](#)  
    MessageID, [810](#)  
DS\_FilterParms\_t, [810](#)  
    Algorithm\_N, [811](#)  
    Algorithm\_O, [811](#)

Algorithm\_X, 811  
 FileTableIndex, 811  
 FilterType, 812  
**DS\_FilterParmsCmd\_t**, 812  
 Algorithm\_N, 813  
 Algorithm\_O, 813  
 Algorithm\_X, 813  
 CmdHeader, 813  
 FilterParmsIndex, 814  
 MessageID, 814  
**DS\_FilterTable**  
 ds\_filter\_tbl.c, 1031  
**DS\_FilterTable\_t**, 814  
 Descriptor, 815  
 Packet, 815  
**DS\_FilterTypeCmd\_t**, 815  
 CmdHeader, 816  
 FilterParmsIndex, 816  
 FilterType, 816  
 MessageID, 817  
**DS\_GET\_FILE\_INFO\_CMD\_EID**  
 CFS Data Store Event IDs, 164  
**DS\_GET\_FILE\_INFO\_CMD\_ERR\_EID**  
 CFS Data Store Event IDs, 165  
**DS\_GET\_FILE\_INFO\_CC**  
 CFS Data Storage Command Codes, 183  
**DS\_GetFileInfoCmd\_t**, 817  
 CmdHeader, 818  
**DS\_HASH\_TABLE\_ENTRIES**  
 ds\_table.h, 1001  
**DS\_HASH\_TABLE\_MASK**  
 ds\_table.h, 1001  
**DS\_HH\_INDEX**  
 ds\_file.c, 938  
**DS\_HK\_REQUEST\_ERR\_EID**  
 CFS Data Store Event IDs, 165  
**DS\_HK\_TLM\_MID**  
 CFS Data Storage Message IDs, 134  
**DS\_HashLink\_t**  
 ds\_table.h, 1002  
**DS\_HashTag**, 818  
 Index, 818  
 MessageID, 819  
 Next, 819  
**DS\_HkPacket\_t**, 819  
 AppEnableState, 821  
 CmdAcceptedCounter, 821  
 CmdRejectedCounter, 821  
 DestTblErrCounter, 821  
 DestTblLoadCounter, 821  
 DisabledPktCounter, 822  
 FileUpdateCounter, 822  
 FileUpdateErrCounter, 822  
 FileWriteCounter, 822  
 FileWriteErrCounter, 823  
 FilterTblErrCounter, 823  
 FilterTblFilename, 823  
 FilterTblLoadCounter, 824  
 FilteredPktCounter, 823  
 IgnoredPktCounter, 824  
 PassedPktCounter, 824  
 Spare8, 824  
 TimHeader, 825  
**DS\_INDEX\_NONE**  
 ds\_appdefs.h, 880  
**DS\_INIT\_CDS\_ERR\_EID**  
 CFS Data Store Event IDs, 166  
**DS\_INIT\_EID**  
 CFS Data Store Event IDs, 166  
**DS\_INIT\_ERR\_EID**  
 CFS Data Store Event IDs, 167  
**DS\_INIT\_TBL\_CDS\_EID**  
 CFS Data Store Event IDs, 167  
**DS\_INIT\_TBL\_ERR\_EID**  
 CFS Data Store Event IDs, 168  
**DS\_IsPacketFiltered**  
 ds\_file.c, 953  
 ds\_file.h, 969  
**DS\_MAJOR\_VERSION**  
 CFS Data Storage Version, 199  
**DS\_MAKE\_TABLES\_CRITICAL**  
 CFS Data Storage Platform Configuration, 143  
**DS\_MAX\_SEQUENCE\_COUNT**  
 CFS Data Storage Platform Configuration, 144  
**DS\_MINOR\_VERSION**  
 CFS Data Storage Version, 199  
**DS\_MISSION\_REV**  
 CFS Data Storage Platform Configuration, 144  
**DS\_MM\_INDEX**  
 ds\_file.c, 939  
**DS\_MOVE\_FILE\_ERR\_EID**  
 CFS Data Store Event IDs, 168  
**DS\_MOVE\_FILES**  
 CFS Data Storage Platform Configuration, 144  
**DS\_NOOP\_CMD\_EID**  
 CFS Data Store Event IDs, 169  
**DS\_NOOP\_CMD\_ERR\_EID**  
 CFS Data Store Event IDs, 169  
**DS\_NOOP\_CC**  
 CFS Data Storage Command Codes, 184  
**DS\_NTTYPE\_CMD\_EID**  
 CFS Data Store Event IDs, 170  
**DS\_NTTYPE\_CMD\_ERR\_EID**  
 CFS Data Store Event IDs, 170  
**DS\_NoopCmd\_t**, 825  
 CmdHeader, 825  
**DS\_OPEN**  
 ds\_appdefs.h, 880

DS\_PACKETS\_IN\_FILTER\_TABLE  
    CFS Data Storage Platform Configuration, 145

DS\_PARMS\_CMD\_EID  
    CFS Data Store Event IDs, 171

DS\_PARMS\_CMD\_ERR\_EID  
    CFS Data Store Event IDs, 171

DS\_PATH\_CMD\_EID  
    CFS Data Store Event IDs, 172

DS\_PATH\_CMD\_ERR\_EID  
    CFS Data Store Event IDs, 172

DS\_PATH\_SEPARATOR  
    ds\_appdefs.h, 880

DS\_PATHNAME\_BUFSIZE  
    CFS Data Storage Platform Configuration, 145

DS\_PER\_PACKET\_PIPE\_LIMIT  
    CFS Data Storage Platform Configuration, 146

DS\_PKT\_SEQUENCE\_BASED\_FILTER\_TYPE  
    ds\_file.c, 939

DS\_PKT\_TIME\_BASED\_FILTER\_TYPE  
    ds\_file.c, 939

DS\_PacketEntry\_t, 826  
    Filter, 826  
    MessageID, 826

DS\_RESET\_CMD\_EID  
    CFS Data Store Event IDs, 173

DS\_RESET\_CMD\_ERR\_EID  
    CFS Data Store Event IDs, 173

DS\_RESET\_CC  
    CFS Data Storage Command Codes, 185

DS\_REVISION  
    CFS Data Storage Version, 199

DS\_ResetCmd\_t, 827  
    CmdHeader, 827

DS\_SB\_TIMEOUT  
    ds\_app.h, 866

DS\_SECS\_PER\_HK\_CYCLE  
    CFS Data Storage Platform Configuration, 146

DS\_SECS\_PER\_TIMEOUT  
    ds\_app.h, 866

DS\_SEND\_HK\_MID  
    CFS Data Storage Message IDs, 133

DS\_SEQ\_CMD\_EID  
    CFS Data Store Event IDs, 174

DS\_SEQ\_CMD\_ERR\_EID  
    CFS Data Store Event IDs, 174

DS\_SEQUENCE\_DIGITS  
    CFS Data Storage Platform Configuration, 147

DS\_SET\_APP\_STATE\_CC  
    CFS Data Storage Command Codes, 186

DS\_SET\_DEST\_AGE\_CC  
    CFS Data Storage Command Codes, 187

DS\_SET\_DEST\_BASE\_CC  
    CFS Data Storage Command Codes, 188

DS\_SET\_DEST\_COUNT\_CC  
    CFS Data Storage Command Codes, 189

DS\_SET\_DEST\_EXT\_CC  
    CFS Data Storage Command Codes, 190

DS\_SET\_DEST\_PATH\_CC  
    CFS Data Storage Command Codes, 191

DS\_SET\_DEST\_SIZE\_CC  
    CFS Data Storage Command Codes, 192

DS\_SET\_DEST\_STATE\_CC  
    CFS Data Storage Command Codes, 193

DS\_SET\_DEST\_TYPE\_CC  
    CFS Data Storage Command Codes, 194

DS\_SET\_FILTER\_FILE\_CC  
    CFS Data Storage Command Codes, 195

DS\_SET\_FILTER\_PARMS\_CC  
    CFS Data Storage Command Codes, 196

DS\_SET\_FILTER\_TYPE\_CC  
    CFS Data Storage Command Codes, 197

DS\_SIZE\_CMD\_EID  
    CFS Data Store Event IDs, 175

DS\_SIZE\_CMD\_ERR\_EID  
    CFS Data Store Event IDs, 175

DS\_SS\_INDEX  
    ds\_file.c, 939

DS\_STATE\_CMD\_EID  
    CFS Data Store Event IDs, 176

DS\_STATE\_CMD\_ERR\_EID  
    CFS Data Store Event IDs, 176

DS\_STRING\_OPTIONAL  
    ds\_appdefs.h, 881

DS\_STRING\_REQUIRED  
    ds\_appdefs.h, 881

DS\_STRING\_TERMINATOR  
    ds\_appdefs.h, 881

DS\_TABLE\_VERIFY\_ERR  
    ds\_appdefs.h, 881

DS\_TERM\_INDEX  
    ds\_file.c, 939

DS\_TOTAL\_FNAME\_BUFSIZE  
    CFS Data Storage Platform Configuration, 147

DS\_TableAddMsgID  
    ds\_table.c, 975  
    ds\_table.h, 1002

DS\_TableCreateCDS  
    ds\_table.c, 976  
    ds\_table.h, 1003

DS\_TableCreateHash  
    ds\_table.c, 977  
    ds\_table.h, 1004

DS\_TableEntryUnused  
    ds\_table.c, 978  
    ds\_table.h, 1005

DS\_TableFindMsgID  
    ds\_table.c, 979  
    ds\_table.h, 1006

DS\_TableHashFunction  
  ds\_table.c, 980  
  ds\_table.h, 1007  
DS\_TableInit  
  ds\_table.c, 981  
  ds\_table.h, 1008  
DS\_TableManageDestFile  
  ds\_table.c, 982  
  ds\_table.h, 1009  
DS\_TableManageFilter  
  ds\_table.c, 983  
  ds\_table.h, 1010  
DS\_TableSubscribe  
  ds\_table.c, 985  
  ds\_table.h, 1012  
DS\_TableUnsubscribe  
  ds\_table.c, 985  
  ds\_table.h, 1012  
DS\_TableUpdateCDS  
  ds\_table.c, 986  
  ds\_table.h, 1013  
DS\_TableVerifyAge  
  ds\_table.c, 987  
  ds\_table.h, 1014  
DS\_TableVerifyCount  
  ds\_table.c, 988  
  ds\_table.h, 1015  
DS\_TableVerifyDestFile  
  ds\_table.c, 990  
  ds\_table.h, 1017  
DS\_TableVerifyDestFileEntry  
  ds\_table.c, 991  
  ds\_table.h, 1018  
DS\_TableVerifyFileIndex  
  ds\_table.c, 992  
  ds\_table.h, 1019  
DS\_TableVerifyFilter  
  ds\_table.c, 993  
  ds\_table.h, 1020  
DS\_TableVerifyFilterEntry  
  ds\_table.c, 995  
  ds\_table.h, 1022  
DS\_TableVerifyParms  
  ds\_table.c, 996  
  ds\_table.h, 1023  
DS\_TableVerifySize  
  ds\_table.c, 997  
  ds\_table.h, 1024  
DS\_TableVerifyState  
  ds\_table.c, 998  
  ds\_table.h, 1025  
DS\_TableVerifyType  
  ds\_table.c, 999  
  ds\_table.h, 1026

DS\_UNUSED  
  ds\_appdefs.h, 881  
DS\_WRITE\_FILE\_ERR\_EID  
  CFS Data Store Event IDs, 177  
DS\_YYYY\_INDEX  
  ds\_file.c, 939  
data\_address  
  OS\_module\_address\_t, 837  
data\_size  
  OS\_module\_address\_t, 837  
DataAddress  
  CFE\_ES\_AppInfo, 567  
DataFileName  
  CFE\_ES\_StopPerfCmd\_Payload, 622  
DataSize  
  CFE\_ES\_AppInfo, 568  
DataStoreHandle  
  DS\_AppData\_t, 773  
DataStoreStatus  
  CFE\_TIME\_DiagnosticTlm\_Payload, 742  
DelayDirection  
  CFE\_TIME\_DiagnosticTlm\_Payload, 742  
Description  
  CFE\_FS\_FileWriteMetaData, 659  
  CFE\_FS\_Header, 662  
  CFE\_TBL\_FileDef, 709  
Descriptor  
  DS\_DestFileTable\_t, 795  
  DS\_FilterTable\_t, 815  
DestFileTblHandle  
  DS\_AppData\_t, 773  
DestFileTblPtr  
  DS\_AppData\_t, 773  
DestTblErrCounter  
  DS\_AppData\_t, 773  
  DS\_HkPacket\_t, 821  
DestTblLoadCounter  
  DS\_AppData\_t, 774  
  DS\_HkPacket\_t, 821  
DisabledPktCounter  
  DS\_AppData\_t, 774  
  DS\_HkPacket\_t, 822  
DoubleBuffered  
  CFE\_TBL\_Info, 719  
  CFE\_TBL\_TblRegPacket\_Payload, 730  
ds\_app.c  
  DS\_AppData, 865  
  DS\_AppInitialize, 855  
  DS\_AppMain, 856  
  DS\_AppProcessCmd, 857  
  DS\_AppProcessHK, 859  
  DS\_AppProcessMsg, 861  
  DS\_AppStorePacket, 863  
ds\_app.h

DS\_AppData, 877  
DS\_AppInitialize, 867  
DS\_AppMain, 868  
DS\_AppProcessCmd, 869  
DS\_AppProcessHK, 871  
DS\_AppProcessMsg, 873  
DS\_AppStorePacket, 875  
DS\_SB\_TIMEOUT, 866  
DS\_SECS\_PER\_TIMEOUT, 866  
**ds\_appdefs.h**  
  DS\_BY\_COUNT, 878  
  DS\_BY\_TIME, 878  
  DS\_CLOSED, 878  
  DS DESCRIPTIVE\_TEXT, 879  
  DS\_DISABLED, 879  
  DS\_EMPTY\_STRING, 879  
  DS\_ENABLED, 879  
  DS\_FILE\_HEADER\_CFE, 879  
  DS\_FILE\_HEADER\_NONE, 880  
  DS\_FILENAME\_TEXT, 880  
  DS\_INDEX\_NONE, 880  
  DS\_OPEN, 880  
  DS\_PATH\_SEPARATOR, 880  
  DS\_STRING\_OPTIONAL, 881  
  DS\_STRING\_REQUIRED, 881  
  DS\_STRING\_TERMINATOR, 881  
  DS\_TABLE\_VERIFY\_ERR, 881  
  DS\_UNUSED, 881  
**ds\_cmds.c**  
  DS\_CmdAddMID, 883  
  DS\_CmdCloseAll, 884  
  DS\_CmdCloseFile, 886  
  DS\_CmdGetFileInfo, 887  
  DS\_CmdNoop, 889  
  DS\_CmdReset, 890  
  DS\_CmdSetAppState, 891  
  DS\_CmdSetDestAge, 892  
  DS\_CmdSetDestBase, 893  
  DS\_CmdSetDestCount, 895  
  DS\_CmdSetDestExt, 896  
  DS\_CmdSetDestPath, 897  
  DS\_CmdSetDestSize, 899  
  DS\_CmdSetDestState, 901  
  DS\_CmdSetDestType, 902  
  DS\_CmdSetFilterFile, 903  
  DS\_CmdSetFilterParms, 905  
  DS\_CmdSetFilterType, 906  
**ds\_cmds.h**  
  DS\_CmdAddMID, 908  
  DS\_CmdCloseAll, 910  
  DS\_CmdCloseFile, 911  
  DS\_CmdGetFileInfo, 912  
  DS\_CmdNoop, 914  
  DS\_CmdReset, 915  
**ds\_file.c**  
  CFE\_DDD\_INDEX, 936  
  CFE\_HH\_INDEX, 936  
  CFE\_MM\_INDEX, 937  
  CFE\_SS\_INDEX, 937  
  CFE\_YYYY\_INDEX, 937  
  CFE\_ssss\_INDEX, 937  
  DS\_11 LSB\_SECONDS\_MASK, 937  
  DS\_11 LSB\_SECONDS\_SHIFT, 937  
  DS\_16 MSB\_SUBSECS\_SHIFT, 938  
  DS\_4 MSB\_SUBSECS\_MASK, 938  
  DS\_4 MSB\_SUBSECS\_SHIFT, 938  
  DS\_DDD\_INDEX, 938  
  DS\_FileCloseDest, 940  
  DS\_FileCreateDest, 941  
  DS\_FileCreateName, 942  
  DS\_FileCreateSequence, 943  
  DS\_FileSetupWrite, 944  
  DS\_FileStorePacket, 945  
  DS\_FileTestAge, 947  
  DS\_FileTransmit, 948  
  DS\_FileUpdateHeader, 949  
  DS\_FileWriteData, 950  
  DS\_FileWriteError, 951  
  DS\_FileWriteHeader, 952  
  DS\_HH\_INDEX, 938  
  DS\_IsPacketFiltered, 953  
  DS\_MM\_INDEX, 939  
  DS\_PKT\_SEQUENCE\_BASED\_FILTER\_TYPE, 939  
  DS\_PKT\_TIME\_BASED\_FILTER\_TYPE, 939  
  DS\_SS\_INDEX, 939  
  DS\_TERM\_INDEX, 939  
  DS\_YYYY\_INDEX, 939  
**ds\_file.h**  
  DS\_FileCloseDest, 956  
  DS\_FileCreateDest, 957  
  DS\_FileCreateName, 958  
  DS\_FileCreateSequence, 959  
  DS\_FileSetupWrite, 960  
  DS\_FileStorePacket, 961  
  DS\_FileTestAge, 963  
  DS\_FileTransmit, 964

DS\_FileUpdateHeader, 965  
 DS\_FileWriteData, 966  
 DS\_FileWriteError, 967  
 DS\_FileWriteHeader, 968  
 DS\_IsPacketFiltered, 969  
**ds\_file\_tbl.c**  
   DS\_DestFileTable, 1029  
   FILE\_ALL\_APP\_HK\_PKTS, 1028  
   FILE\_ALL\_APP\_TLM\_PKTS, 1028  
   FILE\_ALL\_EVENTS, 1028  
   FILE\_ALL\_HW\_TLM\_PKTS, 1028  
   FILE\_CFE\_APP\_HK\_PKTS, 1029  
   FILE\_CFE\_APP\_TLM\_PKTS, 1029  
**ds\_filter\_tbl.c**  
   DS\_FilterTable, 1031  
   FILE\_ALL\_APP\_HK\_PKTS, 1030  
   FILE\_ALL\_APP\_TLM\_PKTS, 1030  
   FILE\_ALL\_EVENTS, 1030  
   FILE\_ALL\_HW\_TLM\_PKTS, 1031  
   FILE\_CFE\_APP\_HK\_PKTS, 1031  
   FILE\_CFE\_APP\_TLM\_PKTS, 1031  
**ds\_table.c**  
   DS\_CDS\_NAME, 975  
   DS\_TableAddMsgID, 975  
   DS\_TableCreateCDS, 976  
   DS\_TableCreateHash, 977  
   DS\_TableEntryUnused, 978  
   DS\_TableFindMsgID, 979  
   DS\_TableHashFunction, 980  
   DS\_TableInit, 981  
   DS\_TableManageDestFile, 982  
   DS\_TableManageFilter, 983  
   DS\_TableSubscribe, 985  
   DS\_TableUnsubscribe, 985  
   DS\_TableUpdateCDS, 986  
   DS\_TableVerifyAge, 987  
   DS\_TableVerifyCount, 988  
   DS\_TableVerifyDestFile, 990  
   DS\_TableVerifyDestFileEntry, 991  
   DS\_TableVerifyFileIndex, 992  
   DS\_TableVerifyFilter, 993  
   DS\_TableVerifyFilterEntry, 995  
   DS\_TableVerifyParms, 996  
   DS\_TableVerifyParms, 997  
   DS\_TableVerifySize, 997  
   DS\_TableVerifyState, 998  
   DS\_TableVerifyType, 999  
**ds\_table.h**  
   DS\_HASH\_TABLE\_ENTRIES, 1001  
   DS\_HASH\_TABLE\_MASK, 1001  
   DS\_HashLink\_t, 1002  
   DS\_TableAddMsgID, 1002  
   DS\_TableCreateCDS, 1003  
   DS\_TableCreateHash, 1004  
   DS\_TableEntryUnused, 1005  
 DS\_TableFindMsgID, 1006  
 DS\_TableHashFunction, 1007  
 DS\_TableInit, 1008  
 DS\_TableManageDestFile, 1009  
 DS\_TableManageFilter, 1010  
 DS\_TableSubscribe, 1012  
 DS\_TableUnsubscribe, 1012  
 DS\_TableUpdateCDS, 1013  
 DS\_TableVerifyAge, 1014  
 DS\_TableVerifyCount, 1015  
 DS\_TableVerifyDestFile, 1017  
 DS\_TableVerifyDestFileEntry, 1018  
 DS\_TableVerifyFileIndex, 1019  
 DS\_TableVerifyFilter, 1020  
 DS\_TableVerifyFilterEntry, 1022  
 DS\_TableVerifyParms, 1023  
 DS\_TableVerifySize, 1024  
 DS\_TableVerifyState, 1025  
 DS\_TableVerifyType, 1026  
**DumpFilename**  
   CFE\_ES\_DumpCDSRegistryCmd\_Payload, 581  
   CFE\_TBL\_DumpCmd\_Payload, 705  
   CFE\_TBL\_DumpRegistryCmd\_Payload, 707  
**DumpOnly**  
   CFE\_TBL\_Info, 719  
   CFE\_TBL\_TblRegPacket\_Payload, 730  
**DuplicateSubscriptionsCounter**  
   CFE\_SB\_HousekeepingTlm\_Payload, 668  
**ERLogEntries**  
   CFE\_ES\_HousekeepingTlm\_Payload, 587  
**ERLogIndex**  
   CFE\_ES\_HousekeepingTlm\_Payload, 588  
**EnableState**  
   DS\_AppStateCmd\_t, 782  
   DS\_DestFileEntry\_t, 792  
   DS\_DestStateCmd\_t, 799  
   DS\_FileInfo\_t, 806  
**Entries**  
   CFE\_SB\_AllSubscriptionsTlm\_Payload, 665  
**Entry**  
   CFE\_SB\_AllSubscriptionsTlm\_Payload, 665  
**entry\_point**  
   OS\_module\_prop\_t, 839  
**EntryPoint**  
   CFE\_ES\_AppInfo, 568  
**EventID**  
   CFE\_EVS\_AppNameEventIDCmd\_Payload, 632  
   CFE\_EVS\_AppNameEventIDMaskCmd\_Payload,  
     634  
   CFE\_EVS\_BinFilter, 637  
   CFE\_EVS\_PacketID, 650  
**EventType**  
   CFE\_EVS\_PacketID, 650

ExceptionAction  
    CFE\_ES\_AppInfo, 568  
    CFE\_ES\_StartAppCmd\_Payload, 619

ExecutionCounter  
    CFE\_ES\_AppInfo, 568  
    CFE\_ES\_TaskInfo, 624

Extension  
    DS\_DestExtCmd\_t, 790  
    DS\_DestFileEntry\_t, 792

FILE\_ALL\_APP\_HK\_PKTS  
    ds\_file\_tbl.c, 1028  
    ds\_filter\_tbl.c, 1030

FILE\_ALL\_APP\_TLM\_PKTS  
    ds\_file\_tbl.c, 1028  
    ds\_filter\_tbl.c, 1030

FILE\_ALL\_EVENTS  
    ds\_file\_tbl.c, 1028  
    ds\_filter\_tbl.c, 1030

FILE\_ALL\_HW\_TLM\_PKTS  
    ds\_file\_tbl.c, 1028  
    ds\_filter\_tbl.c, 1031

FILE\_CFE\_APP\_HK\_PKTS  
    ds\_file\_tbl.c, 1029  
    ds\_filter\_tbl.c, 1031

FILE\_CFE\_APP\_TLM\_PKTS  
    ds\_file\_tbl.c, 1029  
    ds\_filter\_tbl.c, 1031

FailedValCounter  
    CFE\_TBL\_HousekeepingTlm\_Payload, 713

File  
    DS\_DestFileTable\_t, 795

FileAge  
    DS\_AppFileStatus\_t, 779  
    DS\_FileInfo\_t, 806

FileCount  
    DS\_AppFileStatus\_t, 779

FileCreateTimeSecs  
    CFE\_TBL\_Info, 719  
    CFE\_TBL\_TblRegPacket\_Payload, 731

FileCreateTimeSubSecs  
    CFE\_TBL\_Info, 719  
    CFE\_TBL\_TblRegPacket\_Payload, 731

FileGrowth  
    DS\_AppFileStatus\_t, 780

FileHandle  
    DS\_AppFileStatus\_t, 780

FileInfo  
    DS\_FileCompletePkt\_t, 802  
    DS\_FileInfoPkt\_t, 808

FileModeBits  
    os\_fstat\_t, 834

FileName  
    CFE\_ES\_AppInfo, 569

    CFE\_ES\_FileNameCmd\_Payload, 582  
    CFE\_FS\_FileWriteMetaData, 659

    DS\_AppFileStatus\_t, 780  
    DS\_FileHeader\_t, 804  
    DS\_FileInfo\_t, 806  
    os\_dirent\_t, 830

FileNameType  
    DS\_DestFileEntry\_t, 792  
    DS\_DestTypeCmd\_t, 801  
    DS\_FileHeader\_t, 804

FileRate  
    DS\_AppFileStatus\_t, 780  
    DS\_FileInfo\_t, 806

FileSize  
    DS\_AppFileStatus\_t, 781  
    DS\_FileInfo\_t, 807  
    os\_fstat\_t, 834

FileState  
    DS\_AppFileStatus\_t, 781

FileStatus  
    DS\_AppData\_t, 774

FileSubType  
    CFE\_FS\_FileWriteMetaData, 660

FileTableIndex  
    DS\_CloseFileCmd\_t, 784  
    DS\_DestAgeCmd\_t, 786  
    DS\_DestBaseCmd\_t, 787  
    DS\_DestCountCmd\_t, 789  
    DS\_DestExtCmd\_t, 790  
    DS\_DestPathCmd\_t, 796  
    DS\_DestSizeCmd\_t, 798  
    DS\_DestStateCmd\_t, 799  
    DS\_DestTypeCmd\_t, 801  
    DS\_FileHeader\_t, 805  
    DS\_FilterFileCmd\_t, 809  
    DS\_FilterParms\_t, 811

FileTime  
    os\_fstat\_t, 834

FileUpdateCounter  
    DS\_AppData\_t, 774  
    DS\_HkPacket\_t, 822

FileUpdateErrCounter  
    DS\_AppData\_t, 775  
    DS\_HkPacket\_t, 822

FileWriteCounter  
    DS\_AppData\_t, 775  
    DS\_HkPacket\_t, 822

FileWriteErrCounter  
    DS\_AppData\_t, 775  
    DS\_HkPacket\_t, 823

Filename  
    CFE\_SB\_WriteFileInfoCmd\_Payload, 697

filename  
    OS\_module\_prop\_t, 839

Filter  
     DS\_PacketEntry\_t, 826

FilterMask  
     CFE\_ES\_SetPerfFilterMaskCmd\_Payload, 614

FilterMaskNum  
     CFE\_ES\_SetPerfFilterMaskCmd\_Payload, 614

FilterParmsIndex  
     DS\_FilterFileCmd\_t, 809  
     DS\_FilterParmsCmd\_t, 814  
     DS\_FilterTypeCmd\_t, 816

FilterTblErrCounter  
     DS\_AppData\_t, 776  
     DS\_HkPacket\_t, 823

FilterTblFilename  
     DS\_HkPacket\_t, 823

FilterTblHandle  
     DS\_AppData\_t, 776

FilterTblLoadCounter  
     DS\_AppData\_t, 776  
     DS\_HkPacket\_t, 824

FilterTblPtr  
     DS\_AppData\_t, 776

FilterType  
     DS\_FilterParms\_t, 812  
     DS\_FilterTypeCmd\_t, 816

FilteredPktCounter  
     DS\_AppData\_t, 775  
     DS\_HkPacket\_t, 823

flags  
     OS\_module\_address\_t, 837

Forced2Fly  
     CFE\_TIME\_DiagnosticTlm\_Payload, 743

free\_blocks  
     OS\_heap\_prop\_t, 835

free\_bytes  
     OS\_heap\_prop\_t, 835

FreeFds  
     os\_fsinfo\_t, 833

FreeVolumes  
     os\_fsinfo\_t, 833

freerun\_time  
     OS\_timebase\_prop\_t, 850

GetData  
     CFE\_FS\_FileWriteMetaData, 660

GetPipeIdByNameErrorCounter  
     CFE\_SB\_HousekeepingTlm\_Payload, 669

Handle  
     CFE\_ES\_CDSRegDumpRec, 576

HashLinks  
     DS\_AppData\_t, 777

HashTable  
     DS\_AppData\_t, 777

HeapBlocksFree

CFE\_ES\_HousekeepingTlm\_Payload, 588

HeapBytesFree  
     CFE\_ES\_HousekeepingTlm\_Payload, 588

HeapMaxBlockSize  
     CFE\_ES\_HousekeepingTlm\_Payload, 588

host\_module\_id  
     OS\_module\_prop\_t, 839

IgnoredPktCounter  
     DS\_AppData\_t, 777  
     DS\_HkPacket\_t, 824

InactiveBufferAddr  
     CFE\_TBL\_TblRegPacket\_Payload, 731

Index  
     CFE\_SB\_MsgMapFileEntry, 675  
     DS\_HashTag, 818

InputPipe  
     DS\_AppData\_t, 777

int16  
     common\_types.h, 1488

int32  
     common\_types.h, 1488

int64  
     common\_types.h, 1488

int8  
     common\_types.h, 1488

InternalErrorCounter  
     CFE\_SB\_HousekeepingTlm\_Payload, 669

interval\_time  
     OS\_timer\_prop\_t, 851

intptr  
     common\_types.h, 1489

IsPending  
     CFE\_FS\_FileWriteMetaData, 660

IsValid  
     OS\_file\_prop\_t, 832

LENGTHCHECK  
     osapi-macros.h, 1516

largest\_free\_block  
     OS\_heap\_prop\_t, 836

LastFileDumped  
     CFE\_TBL\_HousekeepingTlm\_Payload, 713

LastFileLoaded  
     CFE\_TBL\_HousekeepingTlm\_Payload, 714  
     CFE\_TBL\_Info, 719  
     CFE\_TBL\_TblRegPacket\_Payload, 731

LastTableLoaded  
     CFE\_TBL\_HousekeepingTlm\_Payload, 714

LastUpdateTime  
     CFE\_TBL\_HousekeepingTlm\_Payload, 714

LastUpdatedTable  
     CFE\_TBL\_HousekeepingTlm\_Payload, 714

LastValCrc  
     CFE\_TBL\_HousekeepingTlm\_Payload, 715

LastValStatus  
    CFE\_TBL\_HousekeepingTlm\_Payload, 715

LastValTableName  
    CFE\_TBL\_HousekeepingTlm\_Payload, 715

LeapSeconds  
    CFE\_TIME\_HousekeepingTlm\_Payload, 752  
    CFE\_TIME\_LeapsCmd\_Payload, 755

Length  
    CCSDS\_PrimaryHeader, 564  
    CFE\_FS\_Header, 662

LoadFilename  
    CFE\_TBL\_LoadCmd\_Payload, 722

LoadPending  
    CFE\_TBL\_TblRegPacket\_Payload, 732

LocalIntCounter  
    CFE\_TIME\_DiagnosticTlm\_Payload, 743

LocalTaskCounter  
    CFE\_TIME\_DiagnosticTlm\_Payload, 743

LogEnabled  
    CFE\_EVS\_HousekeepingTlm\_Payload, 642

LogFilename  
    CFE\_EVS\_LogFileCmd\_Payload, 646

LogFullFlag  
    CFE\_EVS\_HousekeepingTlm\_Payload, 642

LogMode  
    CFE\_EVS\_HousekeepingTlm\_Payload, 643  
    CFE\_EVS\_SetLogMode\_Payload, 654

LogOverflowCounter  
    CFE\_EVS\_HousekeepingTlm\_Payload, 643

LongDouble  
    CFE\_ES\_PoolAlign, 604  
    CFE\_SB\_Msg, 673

LongInt  
    CFE\_ES\_PoolAlign, 604  
    CFE\_SB\_Msg, 673

MainTaskId  
    CFE\_ES\_AppInfo, 569

MainTaskName  
    CFE\_ES\_AppInfo, 569

Mask  
    CFE\_EVS\_AppNameEventIDMaskCmd\_Payload,  
        634  
    CFE\_EVS\_BinFilter, 637

MaxElapsed  
    CFE\_TIME\_DiagnosticTlm\_Payload, 743

MaxFds  
    os\_fsinfo\_t, 833

MaxFileAge  
    DS\_DestAgeCmd\_t, 786  
    DS\_DestFileEntry\_t, 793

MaxFileSize  
    DS\_DestFileEntry\_t, 793  
    DS\_DestSizeCmd\_t, 798

MaxLocalClock  
    CFE\_TIME\_DiagnosticTlm\_Payload, 744

MaxMemAllowed  
    CFE\_SB\_StatsTlm\_Payload, 690

MaxMsgIdsAllowed  
    CFE\_SB\_StatsTlm\_Payload, 690

MaxPRCount  
    CFE\_ES\_SetMaxPRCountCmd\_Payload, 612

MaxPipeDepthAllowed  
    CFE\_SB\_StatsTlm\_Payload, 690

MaxPipesAllowed  
    CFE\_SB\_StatsTlm\_Payload, 691

MaxProcessorResets  
    CFE\_ES\_HousekeepingTlm\_Payload, 589

MaxQueueDepth  
    CFE\_SB\_PipeDepthStats, 676  
    CFE\_SB\_PipeInfoEntry, 679

MaxSubscriptionsAllowed  
    CFE\_SB\_StatsTlm\_Payload, 691

MaxVolumes  
    os\_fsinfo\_t, 833

MemInUse  
    CFE\_SB\_HousekeepingTlm\_Payload, 669  
    CFE\_SB\_StatsTlm\_Payload, 691

MemPoolHandle  
    CFE\_SB\_HousekeepingTlm\_Payload, 669  
    CFE\_TBL\_HousekeepingTlm\_Payload, 715

Message  
    CFE\_EVS\_LongEventTlm\_Payload, 648

MessageFormatMode  
    CFE\_EVS\_HousekeepingTlm\_Payload, 643

MessageID  
    DS\_AddMidCmd\_t, 770  
    DS\_FilterFileCmd\_t, 810  
    DS\_FilterParmsCmd\_t, 814  
    DS\_FilterTypeCmd\_t, 817  
    DS\_HashTag, 819  
    DS\_PacketEntry\_t, 826

MessageSendCounter  
    CFE\_EVS\_HousekeepingTlm\_Payload, 643

MessageTruncCounter  
    CFE\_EVS\_HousekeepingTlm\_Payload, 644

MicroSeconds  
    CFE\_TIME\_TimeCmd\_Payload, 766

MinElapsed  
    CFE\_TIME\_DiagnosticTlm\_Payload, 744

Mode  
    CFE\_ES\_OverWriteSysLogCmd\_Payload, 603

Module  
    OS\_static\_symbol\_record\_t, 845

Movename  
    DS\_DestFileEntry\_t, 793

Msg  
    CFE\_SB\_Msg, 673

MsgCnt  
     CFE\_SB\_RoutingFileEntry, 684

MsgFormat  
     CFE\_EVS\_SetEventFormatCode\_Payload, 652

MsgId  
     CFE\_SB\_MsgMapFileEntry, 675  
     CFE\_SB\_RouteCmd\_Payload, 683  
     CFE\_SB\_RoutingFileEntry, 685  
     CFE\_SB\_SingleSubscriptionTlm\_Payload, 687  
     CFE\_SB\_SubEntries, 695

MsgIdsInUse  
     CFE\_SB\_StatsTlm\_Payload, 691

MsgLimitErrorCounter  
     CFE\_SB\_HousekeepingTlm\_Payload, 670

MsgReceiveErrorCounter  
     CFE\_SB\_HousekeepingTlm\_Payload, 670

MsgSendErrorCounter  
     CFE\_SB\_HousekeepingTlm\_Payload, 670

Name  
     CFE\_ES\_AppInfo, 569  
     CFE\_ES\_CDSRegDumpRec, 576  
     CFE\_TBL\_TblRegPacket\_Payload, 732  
     OS\_static\_symbol\_record\_t, 845

name  
     OS\_bin\_sem\_prop\_t, 828  
     OS\_count\_sem\_prop\_t, 829  
     OS\_module\_prop\_t, 839  
     OS\_mut\_sem\_prop\_t, 840  
     OS\_queue\_prop\_t, 841  
     OS\_socket\_prop\_t, 844  
     OS\_task\_prop\_t, 847  
     OS\_timebase\_prop\_t, 850  
     OS\_timer\_prop\_t, 851

Next  
     DS\_HashTag, 819

NoSubscribersCounter  
     CFE\_SB\_HousekeepingTlm\_Payload, 670

nominal\_interval\_time  
     OS\_timebase\_prop\_t, 850

NumBlocksRequested  
     CFE\_ES\_MemPoolStats, 597

NumBytes  
     CFE\_TBL\_File\_Hdr, 708

NumCreated  
     CFE\_ES\_BlockStats, 575

NumFree  
     CFE\_ES\_BlockStats, 575

NumFreeBytes  
     CFE\_ES\_MemPoolStats, 598

NumFreeSharedBufs  
     CFE\_TBL\_HousekeepingTlm\_Payload, 716

NumLoadPending  
     CFE\_TBL\_HousekeepingTlm\_Payload, 716

NumOfChildTasks  
     CFE\_ES\_AppInfo, 570

NumTables  
     CFE\_TBL\_HousekeepingTlm\_Payload, 716

NumUsers  
     CFE\_TBL\_Info, 720

NumValRequests  
     CFE\_TBL\_HousekeepingTlm\_Payload, 716

OS\_API\_Init  
     OSAL Core Operation APIs, 441

OS\_API\_Teardown  
     OSAL Core Operation APIs, 442

OS\_Application\_Run  
     OSAL Core Operation APIs, 442

OS\_Application\_Startup  
     OSAL Core Operation APIs, 442

OS\_ApplicationExit  
     OSAL Core Operation APIs, 442

OS\_ApplicationShutdown  
     OSAL Core Operation APIs, 443

OS\_ArgCallback\_t  
     common\_types.h, 1489

OS\_BSP\_GetArgC  
     OSAL BSP low level access APIs, 428

OS\_BSP\_GetArgV  
     OSAL BSP low level access APIs, 428

OS\_BSP\_GetResourceTypeConfig  
     OSAL BSP low level access APIs, 428

OS\_BSP\_SetExitCode  
     OSAL BSP low level access APIs, 428

OS\_BSP\_SetResourceTypeConfig  
     OSAL BSP low level access APIs, 428

OS\_BUFFER\_MSG\_DEPTH  
     osconfig-example.h, 1033

OS\_BUFFER\_SIZE  
     osconfig-example.h, 1033

OS\_BUILD\_BASELINE  
     osapi-version.h, 1532

OS\_BUILD\_NUMBER  
     osapi-version.h, 1532

OS\_BinSemCreate  
     OSAL Binary Semaphore APIs, 422

OS\_BinSemDelete  
     OSAL Binary Semaphore APIs, 423

OS\_BinSemFlush  
     OSAL Binary Semaphore APIs, 423

OS\_BinSemGetIdByName  
     OSAL Binary Semaphore APIs, 424

OS\_BinSemGetInfo  
     OSAL Binary Semaphore APIs, 425

OS\_BinSemGive  
     OSAL Binary Semaphore APIs, 425

OS\_BinSemTake

OSAL Binary Semaphore APIs, 426  
OS\_BinSemTimedWait  
    OSAL Binary Semaphore APIs, 426  
OS\_CHECK  
    osapi-constants.h, 1499  
OS\_CHK\_ONLY  
    osapi-filesystems.h, 1511  
OS\_CloseAllFiles  
    OSAL Standard File APIs, 474  
OS\_CloseFileByName  
    OSAL Standard File APIs, 474  
OS\_ConvertToArrayIndex  
    OSAL Object ID Utility APIs, 499  
OS\_CountSemCreate  
    OSAL Counting Semaphore APIs, 445  
OS\_CountSemDelete  
    OSAL Counting Semaphore APIs, 446  
OS\_CountSemGetIdByName  
    OSAL Counting Semaphore APIs, 447  
OS\_CountSemGetInfo  
    OSAL Counting Semaphore APIs, 447  
OS\_CountSemGive  
    OSAL Counting Semaphore APIs, 448  
OS\_CountSemTake  
    OSAL Counting Semaphore APIs, 448  
OS\_CountSemTimedWait  
    OSAL Counting Semaphore APIs, 450  
OS\_DIRENTRY\_NAME  
    osapi-dir.h, 1502  
OS\_DeleteAllObjects  
    OSAL Core Operation APIs, 443  
OS\_DirectoryClose  
    OSAL Directory APIs, 451  
OS\_DirectoryOpen  
    OSAL Directory APIs, 452  
OS\_DirectoryRead  
    OSAL Directory APIs, 452  
OS\_DirectoryRewind  
    OSAL Directory APIs, 453  
OS\_ERR\_BAD\_ADDRESS  
    OSAL Return Code Defines, 458  
OS\_ERR\_FILE  
    OSAL Return Code Defines, 458  
OS\_ERR\_INCORRECT\_OBJ\_STATE  
    OSAL Return Code Defines, 458  
OS\_ERR\_INCORRECT\_OBJ\_TYPE  
    OSAL Return Code Defines, 459  
OS\_ERR\_INVALID\_ARGUMENT  
    OSAL Return Code Defines, 459  
OS\_ERR\_INVALID\_ID  
    OSAL Return Code Defines, 459  
OS\_ERR\_INVALID\_PRIORITY  
    OSAL Return Code Defines, 459  
OS\_ERR\_INVALID\_SIZE  
    OSAL Return Code Defines, 459  
OSAL Return Code Defines, 459  
OS\_ERR\_NAME\_NOT\_FOUND  
    OSAL Return Code Defines, 460  
OS\_ERR\_NAME\_TAKEN  
    OSAL Return Code Defines, 460  
OS\_ERR\_NAME\_TOO\_LONG  
    OSAL Return Code Defines, 460  
OS\_ERR\_NO\_FREE\_IDS  
    OSAL Return Code Defines, 460  
OS\_ERR\_NOT\_IMPLEMENTED  
    OSAL Return Code Defines, 460  
OS\_ERR\_OBJECT\_IN\_USE  
    OSAL Return Code Defines, 461  
OS\_ERR\_OPERATION\_NOT\_SUPPORTED  
    OSAL Return Code Defines, 461  
OS\_ERR\_OUTPUT\_TOO\_LARGE  
    OSAL Return Code Defines, 461  
OS\_ERR\_SEM\_NOT\_FULL  
    OSAL Return Code Defines, 461  
OS\_ERR\_STREAM\_DISCONNECTED  
    OSAL Return Code Defines, 461  
OS\_ERROR\_ADDRESS\_MISALIGNED  
    OSAL Return Code Defines, 462  
OS\_ERROR\_NAME\_LENGTH  
    osapi-error.h, 1505  
OS\_ERROR\_TIMEOUT  
    OSAL Return Code Defines, 462  
OS\_ERROR  
    OSAL Return Code Defines, 462  
OS\_Event\_t  
    osapi-common.h, 1498  
OS\_EventHandler\_t  
    osapi-common.h, 1497  
OS\_FDGetInfo  
    OSAL Standard File APIs, 475  
OS\_FILESTAT\_EXEC  
    osapi-file.h, 1508  
OS\_FILESTAT\_ISDIR  
    osapi-file.h, 1508  
OS\_FILESTAT\_MODE  
    osapi-file.h, 1508  
OS\_FILESTAT\_READ  
    osapi-file.h, 1509  
OS\_FILESTAT\_SIZE  
    osapi-file.h, 1509  
OS\_FILESTAT\_TIME  
    osapi-file.h, 1509  
OS\_FILESTAT\_WRITE  
    osapi-file.h, 1509  
OS\_FP\_ENABLED  
    osapi-task.h, 1527  
OS\_FS\_DEV\_NAME\_LEN  
    osconfig-example.h, 1033  
OS\_FS\_ERR\_DEVICE\_NOT\_FREE

OSAL Return Code Defines, 462  
**OS\_FS\_ERR\_DRIVE\_NOT\_CREATED**  
     OSAL Return Code Defines, 462  
**OS\_FS\_ERR\_NAME\_TOO\_LONG**  
     OSAL Return Code Defines, 463  
**OS\_FS\_ERR\_PATH\_INVALID**  
     OSAL Return Code Defines, 463  
**OS\_FS\_ERR\_PATH\_TOO\_LONG**  
     OSAL Return Code Defines, 463  
**OS\_FS\_GetPhysDriveName**  
     OSAL File System Level APIs, 487  
**OS\_FS\_PHYS\_NAME\_LEN**  
     osconfig-example.h, 1033  
**OS\_FS\_VOL\_NAME\_LEN**  
     osconfig-example.h, 1034  
**OS\_FdSet**, 830  
     object\_ids, 831  
**OS\_FileOpenCheck**  
     OSAL Standard File APIs, 476  
**OS\_FileSysAddFixedMap**  
     OSAL File System Level APIs, 486  
**OS\_FileSysStatVolume**  
     OSAL File System Level APIs, 487  
**OS\_ForEachObject**  
     OSAL Object ID Utility APIs, 500  
**OS\_ForEachObjectType**  
     OSAL Object ID Utility APIs, 500  
**OS\_GetBuildNumber**  
     osapi-version.h, 1535  
**OS\_GetErrorName**  
     OSAL Error Info APIs, 467  
**OS\_GetFsInfo**  
     OSAL File System Level APIs, 488  
**OS\_GetLocalTime**  
     OSAL Real Time Clock APIs, 429  
**OS\_GetResourceName**  
     OSAL Object ID Utility APIs, 501  
**OS\_GetVersionCodeName**  
     osapi-version.h, 1535  
**OS\_GetVersionNumber**  
     osapi-version.h, 1535  
**OS\_GetVersionString**  
     osapi-version.h, 1536  
**OS\_HeapGetInfo**  
     OSAL Heap APIs, 494  
**OS\_INVALID\_INT\_NUM**  
     OSAL Return Code Defines, 463  
**OS\_INVALID\_POINTER**  
     OSAL Return Code Defines, 463  
**OS\_INVALID\_SEM\_VALUE**  
     OSAL Return Code Defines, 464  
**OS\_IdentifyObject**  
     OSAL Object ID Utility APIs, 502  
**OS\_IdleLoop**

OSAL Core Operation APIs, 443  
**OS\_MAJOR\_VERSION**  
     osapi-version.h, 1532  
**OS\_MAX\_API\_NAME**  
     osconfig-example.h, 1034  
**OS\_MAX\_BIN\_SEMAPHORES**  
     osconfig-example.h, 1034  
**OS\_MAX\_CMD\_LEN**  
     osconfig-example.h, 1034  
**OS\_MAX\_CONSOLES**  
     osconfig-example.h, 1035  
**OS\_MAX\_COUNT\_SEMAPHORES**  
     osconfig-example.h, 1035  
**OS\_MAX\_FILE\_NAME**  
     osconfig-example.h, 1035  
**OS\_MAX\_FILE\_SYSTEMS**  
     osconfig-example.h, 1035  
**OS\_MAX\_LOCAL\_PATH\_LEN**  
     osapi-constants.h, 1499  
**OS\_MAX\_MODULES**  
     osconfig-example.h, 1036  
**OS\_MAX\_MUTEXES**  
     osconfig-example.h, 1036  
**OS\_MAX\_NUM\_OPEN\_DIRS**  
     osconfig-example.h, 1036  
**OS\_MAX\_NUM\_OPEN\_FILES**  
     osconfig-example.h, 1036  
**OS\_MAX\_PATH\_LEN**  
     osconfig-example.h, 1037  
**OS\_MAX\_QUEUES**  
     osconfig-example.h, 1037  
**OS\_MAX\_SYM\_LEN**  
     osconfig-example.h, 1037  
**OS\_MAX\_TASK\_PRIORITY**  
     osapi-task.h, 1527  
**OS\_MAX\_TASKS**  
     osconfig-example.h, 1038  
**OS\_MAX\_TIMEBASES**  
     osconfig-example.h, 1038  
**OS\_MAX\_TIMERS**  
     osconfig-example.h, 1038  
**OS\_MINOR\_VERSION**  
     osapi-version.h, 1532  
**OS\_MISSION\_REV**  
     osapi-version.h, 1533  
**OS\_MODULE\_FILE\_EXTENSION**  
     osconfig-example.h, 1039  
**OS\_MODULE\_FLAG\_GLOBAL\_SYMBOLS**  
     osapi-module.h, 1517  
**OS\_MODULE\_FLAG\_LOCAL\_SYMBOLS**  
     osapi-module.h, 1518  
**OS\_ModuleInfo**  
     OSAL Dynamic Loader and Symbol APIs, 506  
**OS\_ModuleLoad**

OSAL Dynamic Loader and Symbol APIs, 507  
OS\_ModuleSymbolLookup  
    OSAL Dynamic Loader and Symbol APIs, 507  
OS\_ModuleUnload  
    OSAL Dynamic Loader and Symbol APIs, 508  
OS\_MutSemCreate  
    OSAL Mutex APIs, 511  
OS\_MutSemDelete  
    OSAL Mutex APIs, 512  
OS\_MutSemGetIdByName  
    OSAL Mutex APIs, 512  
OS\_MutSemGetInfo  
    OSAL Mutex APIs, 513  
OS\_MutSemGive  
    OSAL Mutex APIs, 513  
OS\_MutSemTake  
    OSAL Mutex APIs, 514  
OS\_NetworkGetHostName  
    OSAL Network ID APIs, 516  
OS\_NetworkGetID  
    OSAL Network ID APIs, 516  
OS\_OBJECT\_CREATOR\_ANY  
    osapi-constants.h, 1499  
OS\_OBJECT\_ID\_UNDEFINED  
    osapi-constants.h, 1500  
OS\_OBJECT\_INDEX\_MASK  
    osapi-idmap.h, 1514  
OS\_OBJECT\_TYPE\_OS\_BINSEM  
    OSAL Object Type Defines, 495  
OS\_OBJECT\_TYPE\_OS\_CONSOLE  
    OSAL Object Type Defines, 495  
OS\_OBJECT\_TYPE\_OS\_COUNTSEM  
    OSAL Object Type Defines, 496  
OS\_OBJECT\_TYPE\_OS\_DIR  
    OSAL Object Type Defines, 496  
OS\_OBJECT\_TYPE\_OS\_FILESYS  
    OSAL Object Type Defines, 496  
OS\_OBJECT\_TYPE\_OS\_MODULE  
    OSAL Object Type Defines, 496  
OS\_OBJECT\_TYPE\_OS\_MUTEX  
    OSAL Object Type Defines, 496  
OS\_OBJECT\_TYPE\_OS\_QUEUE  
    OSAL Object Type Defines, 497  
OS\_OBJECT\_TYPE\_OS\_STREAM  
    OSAL Object Type Defines, 497  
OS\_OBJECT\_TYPE\_OS\_TASK  
    OSAL Object Type Defines, 497  
OS\_OBJECT\_TYPE\_OS\_TIMEBASE  
    OSAL Object Type Defines, 497  
OS\_OBJECT\_TYPE\_OS\_TIMECB  
    OSAL Object Type Defines, 497  
OS\_OBJECT\_TYPE\_SHIFT  
    osapi-idmap.h, 1514  
OS\_OBJECT\_TYPE\_UNDEFINED  
    OSAL Object Type Defines, 498  
OS\_OBJECT\_TYPE\_USER  
    OSAL Object Type Defines, 498  
OS\_ObjectIdDefined  
    OSAL Object ID Utility APIs, 502  
OS\_ObjectIdEqual  
    OSAL Object ID Utility APIs, 503  
OS\_ObjectIdFromInteger  
    OSAL Object ID Utility APIs, 503  
OS\_ObjectIdToArrayIndex  
    OSAL Object ID Utility APIs, 504  
OS\_ObjectIdToInteger  
    OSAL Object ID Utility APIs, 504  
OS\_OpenCreate  
    OSAL Standard File APIs, 478  
OS\_PEND  
    osapi-constants.h, 1500  
OS\_PRINTF\_CONSOLE\_NAME  
    osconfig-example.h, 1039  
OS\_PRINTF  
    cfe\_es.h, 1152  
    common\_types.h, 1486  
OS\_QUEUE\_EMPTY  
    OSAL Return Code Defines, 464  
OS\_QUEUE\_FULL  
    OSAL Return Code Defines, 464  
OS\_QUEUE\_ID\_ERROR  
    OSAL Return Code Defines, 464  
OS\_QUEUE\_INVALID\_SIZE  
    OSAL Return Code Defines, 464  
OS\_QUEUE\_MAX\_DEPTH  
    osconfig-example.h, 1039  
OS\_QUEUE\_TIMEOUT  
    OSAL Return Code Defines, 465  
OS\_QueueCreate  
    OSAL Message Queue APIs, 520  
OS\_QueueDelete  
    OSAL Message Queue APIs, 521  
OS\_QueueGet  
    OSAL Message Queue APIs, 522  
OS\_QueueGetIdByName  
    OSAL Message Queue APIs, 522  
OS\_QueueGetInfo  
    OSAL Message Queue APIs, 523  
OS\_QueuePut  
    OSAL Message Queue APIs, 523  
OS\_READ\_ONLY  
    OSAL File Access Option Defines, 470  
OS\_READ\_WRITE  
    OSAL File Access Option Defines, 470  
OS\_REPAIR  
    osapi-filesystems.h, 1511  
OS\_REVISION  
    osapi-version.h, 1533

OS\_RegisterEventHandler  
    OSAL Core Operation APIs, 444

OS\_SEEK\_CUR  
    OSAL Reference Point For Seek Offset Defines, 471

OS\_SEEK\_END  
    OSAL Reference Point For Seek Offset Defines, 471

OS\_SEEK\_SET  
    OSAL Reference Point For Seek Offset Defines, 471

OS\_SEM\_EMPTY  
    OSAL Semaphore State Defines, 421

OS\_SEM\_FAILURE  
    OSAL Return Code Defines, 465

OS\_SEM\_FULL  
    OSAL Semaphore State Defines, 421

OS\_SEM\_TIMEOUT  
    OSAL Return Code Defines, 465

OS\_SHELL\_CMD\_INPUT\_FILE\_NAME  
    osconfig-example.h, 1039

OS SOCKADDR\_MAX\_LEN  
    osapi-sockets.h, 1524

osconfig-example.h, 1040

OS\_STATUS\_STRING\_LENGTH  
    osapi-error.h, 1505

OS\_STR\_HELPER  
    osapi-version.h, 1533

OS\_STR  
    osapi-version.h, 1533

OS\_SUCCESS  
    OSAL Return Code Defines, 465

OS\_SelectFdAdd  
    OSAL Select APIs, 525

OS\_SelectFdClear  
    OSAL Select APIs, 526

OS\_SelectFdIsSet  
    OSAL Select APIs, 526

OS\_SelectFdZero  
    OSAL Select APIs, 527

OS\_SelectMultiple  
    OSAL Select APIs, 527

OS\_SelectSingle  
    OSAL Select APIs, 528

OS\_SetLocalTime  
    OSAL Real Time Clock APIs, 430

OS\_ShellOutputToFile  
    OSAL Shell APIs, 530

OS\_SockAddr\_t, 841

    ActualLength, 842

    AddrData, 842

OS\_SockAddrData\_t, 842

    AlignPtr, 843

    AlignU32, 843

    Buffer, 843

OS\_SocketAccept  
    OSAL Socket Management APIs, 535

OS\_SocketAddrFromString  
    OSAL Socket Address APIs, 531

OS\_SocketAddrGetPort  
    OSAL Socket Address APIs, 532

OS\_SocketAddrInit  
    OSAL Socket Address APIs, 532

OS\_SocketAddrSetPort  
    OSAL Socket Address APIs, 533

OS\_SocketAddrToString  
    OSAL Socket Address APIs, 534

OS\_SocketBind  
    OSAL Socket Management APIs, 537

OS\_SocketConnect  
    OSAL Socket Management APIs, 538

OS\_SocketDomain\_t  
    osapi-sockets.h, 1524

OS\_SocketGetIdByName  
    OSAL Socket Management APIs, 538

OS\_SocketGetInfo  
    OSAL Socket Management APIs, 539

OS\_SocketOpen  
    OSAL Socket Management APIs, 540

OS\_SocketRecvFrom  
    OSAL Socket Management APIs, 540

OS\_SocketSendTo  
    OSAL Socket Management APIs, 541

OS\_SocketShutdown  
    OSAL Socket Management APIs, 542

OS\_SocketShutdownMode\_t  
    osapi-sockets.h, 1525

OS\_SocketType\_t  
    osapi-sockets.h, 1525

OS\_StatusToInteger  
    OSAL Error Info APIs, 467

OS\_StatusToString  
    OSAL Error Info APIs, 468

OS\_StreamState\_t  
    osapi-select.h, 1521

OS\_SymbolLookup  
    OSAL Dynamic Loader and Symbol APIs, 509

OS\_SymbolTableDump  
    OSAL Dynamic Loader and Symbol APIs, 509

OS\_TIMER\_ERR\_INTERNAL  
    OSAL Return Code Defines, 465

OS\_TIMER\_ERR\_INVALID\_ARGS  
    OSAL Return Code Defines, 466

OS\_TIMER\_ERR\_TIMER\_ID  
    OSAL Return Code Defines, 466

OS\_TIMER\_ERR\_UNAVAILABLE  
    OSAL Return Code Defines, 466

OS\_TaskCreate  
    OSAL Task APIs, 543

OS\_TaskDelay  
    OSAL Task APIs, 544

OS\_TaskDelete  
    OSAL Task APIs, 545

OS\_TaskExit  
    OSAL Task APIs, 545

OS\_TaskFindIdBySystemData  
    OSAL Task APIs, 545

OS\_TaskGetId  
    OSAL Task APIs, 546

OS\_TaskGetIdByName  
    OSAL Task APIs, 546

OS\_TaskGetInfo  
    OSAL Task APIs, 547

OS\_TaskInstallDeleteHandler  
    OSAL Task APIs, 548

OS\_TaskSetPriority  
    OSAL Task APIs, 548

OS\_TimeAdd  
    OSAL Real Time Clock APIs, 431

OS\_TimeAssembleFromMicroseconds  
    OSAL Real Time Clock APIs, 431

OS\_TimeAssembleFromMilliseconds  
    OSAL Real Time Clock APIs, 432

OS\_TimeAssembleFromNanoseconds  
    OSAL Real Time Clock APIs, 432

OS\_TimeAssembleFromSubseconds  
    OSAL Real Time Clock APIs, 433

OS\_TimeBaseCreate  
    OSAL Time Base APIs, 550

OS\_TimeBaseDelete  
    OSAL Time Base APIs, 551

OS\_TimeBaseGetFreeRun  
    OSAL Time Base APIs, 552

OS\_TimeBaseGetIdByName  
    OSAL Time Base APIs, 553

OS\_TimeBaseGetInfo  
    OSAL Time Base APIs, 553

OS\_TimeBaseSet  
    OSAL Time Base APIs, 554

OS\_TimeGetFractionalPart  
    OSAL Real Time Clock APIs, 434

OS\_TimeGetMicrosecondsPart  
    OSAL Real Time Clock APIs, 434

OS\_TimeGetMillisecondsPart  
    OSAL Real Time Clock APIs, 435

OS\_TimeGetNanosecondsPart  
    OSAL Real Time Clock APIs, 436

OS\_TimeGetSecondsPart  
    OSAL Real Time Clock APIs, 437

OS\_TimeGetTotalMicroseconds  
    OSAL Real Time Clock APIs, 437

OS\_TimeGetTotalMilliseconds  
    OSAL Real Time Clock APIs, 438

OS\_TimeGetTotalNanoseconds  
    OSAL Real Time Clock APIs, 438

OS\_TimeGetTotalSeconds  
    OSAL Real Time Clock APIs, 439

OS\_TimeSubtract  
    OSAL Real Time Clock APIs, 440

OS\_TimedRead  
    OSAL Standard File APIs, 482

OS\_TimedWrite  
    OSAL Standard File APIs, 483

OS\_TimerAdd  
    OSAL Timer APIs, 556

OS\_TimerCallback\_t  
    osapi-timer.h, 1531

OS\_TimerCreate  
    OSAL Timer APIs, 558

OS\_TimerDelete  
    OSAL Timer APIs, 559

OS\_TimerGetIdByName  
    OSAL Timer APIs, 560

OS\_TimerGetInfo  
    OSAL Timer APIs, 561

OS\_TimerSet  
    OSAL Timer APIs, 562

OS\_TimerSync\_t  
    osapi-timebase.h, 1530

OS\_TranslatePath  
    OSAL File System Level APIs, 492

OS\_USED  
    common\_types.h, 1486

OS\_UTILITYTASK\_PRIORITY  
    osconfig-example.h, 1040

OS\_UTILITYTASK\_STACK\_SIZE  
    osconfig-example.h, 1040

OS\_VERSION\_CODENAME  
    osapi-version.h, 1534

OS\_VERSION\_STRING  
    osapi-version.h, 1534

OS\_VERSION  
    osapi-version.h, 1533

OS\_WRITE\_ONLY  
    OSAL File Access Option Defines, 470

OS\_bin\_sem\_prop\_t, 828  
    creator, 828  
    name, 828  
    value, 828

OS\_chkfs  
    OSAL File System Level APIs, 485

OS\_chmod  
    OSAL Standard File APIs, 472

OS\_close  
    OSAL Standard File APIs, 473

OS\_count\_sem\_prop\_t, 829  
    creator, 829  
    name, 829  
    value, 829

OS\_cp  
     OSAL Standard File APIs, 475

OS\_file\_flag\_t  
     osapi-file.h, 1510

OS\_file\_prop\_t, 831  
     IsValid, 832  
     Path, 832  
     User, 832

OS\_heap\_prop\_t, 835  
     free\_blocks, 835  
     free\_bytes, 835  
     largest\_free\_block, 836

OS\_initfs  
     OSAL File System Level APIs, 489

OS\_lseek  
     OSAL Standard File APIs, 476

OS\_mkdir  
     OSAL Directory APIs, 453

OS\_mkfs  
     OSAL File System Level APIs, 490

OS\_module\_address\_t, 836  
     bss\_address, 836  
     bss\_size, 837  
     code\_address, 837  
     code\_size, 837  
     data\_address, 837  
     data\_size, 837  
     flags, 837  
     valid, 838

OS\_module\_prop\_t, 838  
     addr, 838  
     entry\_point, 839  
     filename, 839  
     host\_module\_id, 839  
     name, 839

OS\_mount  
     OSAL File System Level APIs, 490

OS\_mut\_sem\_prop\_t, 839  
     creator, 840  
     name, 840

OS\_mv  
     OSAL Standard File APIs, 477

OS\_printf  
     OSAL Printf APIs, 518

OS\_printf\_disable  
     OSAL Printf APIs, 518

OS\_printf\_enable  
     OSAL Printf APIs, 519

OS\_queue\_prop\_t, 840  
     creator, 841  
     name, 841

OS\_read  
     OSAL Standard File APIs, 479

OS\_remove  
     OSAL Standard File APIs, 479

OS\_rename  
     OSAL Standard File APIs, 480

OS\_rmdir  
     OSAL Directory APIs, 454

OS\_rmfs  
     OSAL File System Level APIs, 491

OS\_socket\_prop\_t, 844  
     creator, 844  
     name, 844

OS\_stat  
     OSAL Standard File APIs, 481

OS\_static\_symbol\_record\_t, 845  
     Address, 845  
     Module, 845  
     Name, 845

OS\_statvfs\_t, 846  
     block\_size, 846  
     blocks\_free, 846  
     total\_blocks, 846

OS\_task\_prop\_t, 847  
     creator, 847  
     name, 847  
     priority, 848  
     stack\_size, 848

OS\_time\_t, 848  
     ticks, 849

OS\_timebase\_prop\_t, 849  
     accuracy, 849  
     creator, 850  
     freerun\_time, 850  
     name, 850  
     nominal\_interval\_time, 850

OS\_timer\_prop\_t, 850  
     accuracy, 851  
     creator, 851  
     interval\_time, 851  
     name, 851  
     start\_time, 851

OS\_unmount  
     OSAL File System Level APIs, 492

OS\_write  
     OSAL Standard File APIs, 483

OSAL BSP low level access APIs, 428  
     OS\_BSP\_GetArgC, 428  
     OS\_BSP\_GetArgV, 428  
     OS\_BSP\_GetResourceTypeConfig, 428  
     OS\_BSP\_SetExitCode, 428  
     OS\_BSP\_SetResourceTypeConfig, 428

OSAL Binary Semaphore APIs, 422  
     OS\_BinSemCreate, 422  
     OS\_BinSemDelete, 423  
     OS\_BinSemFlush, 423  
     OS\_BinSemGetIdByName, 424

OS\_BinSemGetInfo, 425  
OS\_BinSemGive, 425  
OS\_BinSemTake, 426  
OS\_BinSemTimedWait, 426  
OSAL Core Operation APIs, 441  
    OS\_API\_Init, 441  
    OS\_API\_Teardown, 442  
    OS\_Application\_Run, 442  
    OS\_Application\_Startup, 442  
    OS\_ApplicationExit, 442  
    OS\_ApplicationShutdown, 443  
    OS\_DeleteAllObjects, 443  
    OS\_IdleLoop, 443  
    OS\_RegisterEventHandler, 444  
OSAL Counting Semaphore APIs, 445  
    OS\_CountSemCreate, 445  
    OS\_CountSemDelete, 446  
    OS\_CountSemGetIdByName, 447  
    OS\_CountSemGetInfo, 447  
    OS\_CountSemGive, 448  
    OS\_CountSemTake, 448  
    OS\_CountSemTimedWait, 450  
OSAL Directory APIs, 451  
    OS\_DirectoryClose, 451  
    OS\_DirectoryOpen, 452  
    OS\_DirectoryRead, 452  
    OS\_DirectoryRewind, 453  
    OS\_mkdir, 453  
    OS\_rmdir, 454  
OSAL Dynamic Loader and Symbol APIs, 506  
    OS\_ModuleInfo, 506  
    OS\_ModuleLoad, 507  
    OS\_ModuleSymbolLookup, 507  
    OS\_ModuleUnload, 508  
    OS\_SymbolLookup, 509  
    OS\_SymbolTableDump, 509  
OSAL Error Info APIs, 467  
    OS\_GetErrorName, 467  
    OS\_StatusToInteger, 467  
    OS\_StatusToString, 468  
OSAL File Access Option Defines, 470  
    OS\_READ\_ONLY, 470  
    OS\_READ\_WRITE, 470  
    OS\_WRITE\_ONLY, 470  
OSAL File System Level APIs, 485  
    OS\_FS\_GetPhysDriveName, 487  
    OS\_FileSysAddFixedMap, 486  
    OS\_FileSysStatVolume, 487  
    OS\_GetFsInfo, 488  
    OS\_TranslatePath, 492  
    OS\_chkfs, 485  
    OS\_initfs, 489  
    OS\_mkfs, 490  
    OS\_mount, 490  
                OS\_rmfs, 491  
                OS\_unmount, 492  
OSAL Heap APIs, 494  
    OS\_HeapGetInfo, 494  
OSAL Message Queue APIs, 520  
    OS\_QueueCreate, 520  
    OS\_QueueDelete, 521  
    OS\_QueueGet, 522  
    OS\_QueueGetIdByName, 522  
    OS\_QueueGetInfo, 523  
    OS\_QueuePut, 523  
OSAL Mutex APIs, 511  
    OS\_MutSemCreate, 511  
    OS\_MutSemDelete, 512  
    OS\_MutSemGetIdByName, 512  
    OS\_MutSemGetInfo, 513  
    OS\_MutSemGive, 513  
    OS\_MutSemTake, 514  
OSAL Network ID APIs, 516  
    OS\_NetworkGetHostName, 516  
    OS\_NetworkGetID, 516  
OSAL Object ID Utility APIs, 499  
    OS\_ConvertToArrayIndex, 499  
    OS\_ForEachObject, 500  
    OS\_ForEachObjectType, 500  
    OS\_GetResourceName, 501  
    OS\_IdentifyObject, 502  
    OS\_ObjectIdDefined, 502  
    OS\_ObjectIdEqual, 503  
    OS\_ObjectIdFromInteger, 503  
    OS\_ObjectIdToArrayIndex, 504  
    OS\_ObjectIdToInteger, 504  
OSAL Object Type Defines, 495  
    OS\_OBJECT\_TYPE\_OS\_BINSEM, 495  
    OS\_OBJECT\_TYPE\_OS\_CONSOLE, 495  
    OS\_OBJECT\_TYPE\_OS\_COUNTSEM, 496  
    OS\_OBJECT\_TYPE\_OS\_DIR, 496  
    OS\_OBJECT\_TYPE\_OS\_FILESYS, 496  
    OS\_OBJECT\_TYPE\_OS\_MODULE, 496  
    OS\_OBJECT\_TYPE\_OS\_MUTEX, 496  
    OS\_OBJECT\_TYPE\_OS\_QUEUE, 497  
    OS\_OBJECT\_TYPE\_OS\_STREAM, 497  
    OS\_OBJECT\_TYPE\_OS\_TASK, 497  
    OS\_OBJECT\_TYPE\_OS\_TIMEBASE, 497  
    OS\_OBJECT\_TYPE\_OS\_TIMECB, 497  
    OS\_OBJECT\_TYPE\_UNDEFINED, 498  
    OS\_OBJECT\_TYPE\_USER, 498  
OSAL Printf APIs, 518  
    OS\_printf, 518  
    OS\_printf\_disable, 518  
    OS\_printf\_enable, 519  
OSAL Real Time Clock APIs, 429  
    OS\_GetLocalTime, 429  
    OS\_SetLocalTime, 430

OS\_TimeAdd, 431  
 OS\_TimeAssembleFromMicroseconds, 431  
 OS\_TimeAssembleFromMilliseconds, 432  
 OS\_TimeAssembleFromNanoseconds, 432  
 OS\_TimeAssembleFromSubseconds, 433  
 OS\_TimeGetFractionalPart, 434  
 OS\_TimeGetMicrosecondsPart, 434  
 OS\_TimeGetMillisecondsPart, 435  
 OS\_TimeGetNanosecondsPart, 436  
 OS\_TimeGetSubsecondsPart, 437  
 OS\_TimeGetTotalMicroseconds, 437  
 OS\_TimeGetTotalMilliseconds, 438  
 OS\_TimeGetTotalNanoseconds, 438  
 OS\_TimeGetTotalSeconds, 439  
 OS\_TimeSubtract, 440  
 OSAL Reference Point For Seek Offset Defines, 471  
 OS\_SEEK\_CUR, 471  
 OS\_SEEK\_END, 471  
 OS\_SEEK\_SET, 471  
 OSAL Return Code Defines, 456  
 OS\_ERR\_BAD\_ADDRESS, 458  
 OS\_ERR\_FILE, 458  
 OS\_ERR\_INCORRECT\_OBJ\_STATE, 458  
 OS\_ERR\_INCORRECT\_OBJ\_TYPE, 459  
 OS\_ERR\_INVALID\_ARGUMENT, 459  
 OS\_ERR\_INVALID\_ID, 459  
 OS\_ERR\_INVALID\_PRIORITY, 459  
 OS\_ERR\_INVALID\_SIZE, 459  
 OS\_ERR\_NAME\_NOT\_FOUND, 460  
 OS\_ERR\_NAME\_TAKEN, 460  
 OS\_ERR\_NAME\_TOO\_LONG, 460  
 OS\_ERR\_NO\_FREE\_IDS, 460  
 OS\_ERR\_NOT\_IMPLEMENTED, 460  
 OS\_ERR\_OBJECT\_IN\_USE, 461  
 OS\_ERR\_OPERATION\_NOT\_SUPPORTED, 461  
 OS\_ERR\_OUTPUT\_TOO\_LARGE, 461  
 OS\_ERR\_SEM\_NOT\_FULL, 461  
 OS\_ERR\_STREAM\_DISCONNECTED, 461  
 OS\_ERROR\_ADDRESS\_MISALIGNED, 462  
 OS\_ERROR\_TIMEOUT, 462  
 OS\_ERROR, 462  
 OS\_FS\_ERR\_DEVICE\_NOT\_FREE, 462  
 OS\_FS\_ERR\_DRIVE\_NOT\_CREATED, 462  
 OS\_FS\_ERR\_NAME\_TOO\_LONG, 463  
 OS\_FS\_ERR\_PATH\_INVALID, 463  
 OS\_FS\_ERR\_PATH\_TOO\_LONG, 463  
 OS\_INVALID\_INT\_NUM, 463  
 OS\_INVALID\_POINTER, 463  
 OS\_INVALID\_SEM\_VALUE, 464  
 OS\_QUEUE\_EMPTY, 464  
 OS\_QUEUE\_FULL, 464  
 OS\_QUEUE\_ID\_ERROR, 464  
 OS\_QUEUE\_INVALID\_SIZE, 464  
 OS\_QUEUE\_TIMEOUT, 465  
 OS\_SEM\_FAILURE, 465  
 OS\_SEM\_TIMEOUT, 465  
 OS\_SUCCESS, 465  
 OS\_TIMER\_ERR\_INTERNAL, 465  
 OS\_TIMER\_ERR\_INVALID\_ARGS, 466  
 OS\_TIMER\_ERR\_TIMER\_ID, 466  
 OS\_TIMER\_ERR\_UNAVAILABLE, 466  
 OSAL Select APIs, 525  
 OS\_SelectFdAdd, 525  
 OS\_SelectFdClear, 526  
 OS\_SelectFdIsSet, 526  
 OS\_SelectFdZero, 527  
 OS\_SelectMultiple, 527  
 OS\_SelectSingle, 528  
 OSAL Semaphore State Defines, 421  
 OS\_SEM\_EMPTY, 421  
 OS\_SEM\_FULL, 421  
 OSAL Shell APIs, 530  
 OS\_ShellOutputToFile, 530  
 OSAL Socket Address APIs, 531  
 OS\_SocketAddrFromString, 531  
 OS\_SocketAddrGetPort, 532  
 OS\_SocketAddrInit, 532  
 OS\_SocketAddrSetPort, 533  
 OS\_SocketAddrToString, 534  
 OSAL Socket Management APIs, 535  
 OS\_SocketAccept, 535  
 OS\_SocketBind, 537  
 OS\_SocketConnect, 538  
 OS\_SocketGetIdByName, 538  
 OS\_SocketGetInfo, 539  
 OS\_SocketOpen, 540  
 OS\_SocketRecvFrom, 540  
 OS\_SocketSendTo, 541  
 OS\_SocketShutdown, 542  
 OSAL Standard File APIs, 472  
 OS\_CloseAllFiles, 474  
 OS\_CloseFileByName, 474  
 OS\_FDGetInfo, 475  
 OS\_FileOpenCheck, 476  
 OS\_OpenCreate, 478  
 OS\_TimedRead, 482  
 OS\_TimedWrite, 483  
 OS\_chmod, 472  
 OS\_close, 473  
 OS\_cp, 475  
 OS\_lseek, 476  
 OS\_mv, 477  
 OS\_read, 479  
 OS\_remove, 479  
 OS\_rename, 480  
 OS\_stat, 481  
 OS\_write, 483  
 OSAL Task APIs, 543

OS\_TaskCreate, 543  
OS\_TaskDelay, 544  
OS\_TaskDelete, 545  
OS\_TaskExit, 545  
OS\_TaskFindIdBySystemData, 545  
OS\_TaskGetId, 546  
OS\_TaskGetIdByName, 546  
OS\_TaskGetInfo, 547  
OS\_TaskInstallDeleteHandler, 548  
OS\_TaskSetPriority, 548  
OSAL Time Base APIs, 550  
  OS\_TimeBaseCreate, 550  
  OS\_TimeBaseDelete, 551  
  OS\_TimeBaseGetFreeRun, 552  
  OS\_TimeBaseGetIdByName, 553  
  OS\_TimeBaseGetInfo, 553  
  OS\_TimeBaseSet, 554  
OSAL Timer APIs, 556  
  OS\_TimerAdd, 556  
  OS\_TimerCreate, 558  
  OS\_TimerDelete, 559  
  OS\_TimerGetIdByName, 560  
  OS\_TimerGetInfo, 561  
  OS\_TimerSet, 562  
OSAL\_API\_VERSION  
  osapi-version.h, 1534  
OSAL\_BLOCKCOUNT\_C  
  common\_types.h, 1486  
OSAL\_INDEX\_C  
  common\_types.h, 1487  
OSAL\_OBJTYPE\_C  
  common\_types.h, 1487  
OSAL\_PRIORITY\_C  
  osapi-task.h, 1527  
OSAL\_SIZE\_C  
  common\_types.h, 1487  
OSAL\_STACKPTR\_C  
  osapi-task.h, 1527  
OSAL\_STATUS\_C  
  common\_types.h, 1487  
OSAL\_TASK\_STACK\_ALLOCATE  
  osapi-task.h, 1527  
OSALMajorVersion  
  CFE\_ES\_HousekeepingTlm\_Payload, 589  
OSALMinorVersion  
  CFE\_ES\_HousekeepingTlm\_Payload, 589  
OSALMissionRevision  
  CFE\_ES\_HousekeepingTlm\_Payload, 589  
OSALRevision  
  CFE\_ES\_HousekeepingTlm\_Payload, 590  
object\_ids  
  OS\_FdSet, 831  
ObjectName  
  CFE\_TBL\_FileDef, 709  
ObjectSize  
  CFE\_TBL\_FileDef, 709  
Offset  
  CFE\_TBL\_File\_Hdr, 708  
OnEvent  
  CFE\_FS\_FileWriteMetaData, 660  
OneHzAdjust  
  CFE\_TIME\_DiagnosticTlm\_Payload, 744  
OneHzDirection  
  CFE\_TIME\_DiagnosticTlm\_Payload, 744  
OneTimeAdjust  
  CFE\_TIME\_DiagnosticTlm\_Payload, 745  
OneTimeDirection  
  CFE\_TIME\_DiagnosticTlm\_Payload, 745  
OpenState  
  DSFileInfo\_t, 807  
Opts  
  CFE\_SB\_PipeInfoEntry, 679  
os\_dirent\_t, 830  
  FileName, 830  
os\_err\_name\_t  
  osapi-error.h, 1505  
os\_finfo\_t, 832  
  FreeFds, 833  
  FreeVolumes, 833  
  MaxFds, 833  
  MaxVolumes, 833  
os\_fstat\_t, 834  
   FileModeBits, 834  
  FileSize, 834  
  FileTime, 834  
os\_status\_string\_t  
  osapi-error.h, 1506  
osal/docs/src/osal\_frontpage.dox, 1484  
osal/docs/src/osal\_fs.dox, 1484  
osal/docs/src/osal\_timer.dox, 1484  
osal/src/os/inc/common\_types.h, 1484  
osal/src/os/inc/osapi-binsem.h, 1492  
osal/src/os/inc/osapi-bsp.h, 1493  
osal/src/os/inc/osapi-clock.h, 1494  
osal/src/os/inc/osapi-common.h, 1496  
osal/src/os/inc/osapi-constants.h, 1499  
osal/src/os/inc/osapi-countsem.h, 1500  
osal/src/os/inc/osapi-dir.h, 1501  
osal/src/os/inc/osapi-error.h, 1502  
osal/src/os/inc/osapi-file.h, 1506  
osal/src/os/inc/osapi-filesystems.h, 1510  
osal/src/os/inc/osapi-heap.h, 1512  
osal/src/os/inc/osapi-idmap.h, 1512  
osal/src/os/inc/osapi-macros.h, 1514  
osal/src/os/inc/osapi-module.h, 1517  
osal/src/os/inc/osapi-mutex.h, 1518  
osal/src/os/inc/osapi-network.h, 1519  
osal/src/os/inc/osapi-printf.h, 1520

osal/src/os/inc/osapi-queue.h, [1520](#)  
 osal/src/os/inc/osapi-select.h, [1521](#)  
 osal/src/os/inc/osapi-shell.h, [1522](#)  
 osal/src/os/inc/osapi-sockets.h, [1522](#)  
 osal/src/os/inc/osapi-task.h, [1525](#)  
 osal/src/os/inc/osapi-timebase.h, [1529](#)  
 osal/src/os/inc/osapi-timer.h, [1530](#)  
 osal/src/os/inc/osapi-version.h, [1531](#)  
 osal/src/os/inc/osapi.h, [1536](#)  
 osal\_blockcount\_t  
     common\_types.h, [1489](#)  
 osal\_id\_t  
     common\_types.h, [1489](#)  
 osal\_index\_t  
     common\_types.h, [1489](#)  
 osal\_objtype\_t  
     common\_types.h, [1490](#)  
 osal\_priority\_t  
     osapi-task.h, [1528](#)  
 osal\_stackptr\_t  
     osapi-task.h, [1528](#)  
 osal\_status\_t  
     common\_types.h, [1490](#)  
 osal\_task  
     osapi-task.h, [1528](#)  
 osapi-common.h  
     OS\_Event\_t, [1498](#)  
     OS\_EventHandler\_t, [1497](#)  
 osapi-constants.h  
     OS\_CHECK, [1499](#)  
     OS\_MAX\_LOCAL\_PATH\_LEN, [1499](#)  
     OS\_OBJECT\_CREATOR\_ANY, [1499](#)  
     OS\_OBJECT\_ID\_UNDEFINED, [1500](#)  
     OS\_PEND, [1500](#)  
 osapi-dir.h  
     OS\_DIRENTRY\_NAME, [1502](#)  
 osapi-error.h  
     OS\_ERROR\_NAME\_LENGTH, [1505](#)  
     OS\_STATUS\_STRING\_LENGTH, [1505](#)  
     os\_err\_name\_t, [1505](#)  
     os\_status\_string\_t, [1506](#)  
 osapi-file.h  
     OS\_FILESTAT\_EXEC, [1508](#)  
     OS\_FILESTAT\_ISDIR, [1508](#)  
     OS\_FILESTAT\_MODE, [1508](#)  
     OS\_FILESTAT\_READ, [1509](#)  
     OS\_FILESTAT\_SIZE, [1509](#)  
     OS\_FILESTAT\_TIME, [1509](#)  
     OS\_FILESTAT\_WRITE, [1509](#)  
     OS\_file\_flag\_t, [1510](#)  
 osapi-fs.h  
     OS\_CHK\_ONLY, [1511](#)  
     OS\_REPAIR, [1511](#)  
 osapi-idmap.h

OS\_OBJECT\_INDEX\_MASK, [1514](#)  
 OS\_OBJECT\_TYPE\_SHIFT, [1514](#)  
 osapi-macros.h  
     ARGCHECK, [1515](#)  
     BUGCHECK, [1515](#)  
     BUGREPORT, [1516](#)  
     LENGTHCHECK, [1516](#)  
 osapi-module.h  
     OS\_MODULE\_FLAG\_GLOBAL\_SYMBOLS, [1517](#)  
     OS\_MODULE\_FLAG\_LOCAL\_SYMBOLS, [1518](#)  
 osapi-select.h  
     OS\_StreamState\_t, [1521](#)  
 osapi-sockets.h  
     OS SOCKADDR\_MAX\_LEN, [1524](#)  
     OS\_SocketDomain\_t, [1524](#)  
     OS\_SocketShutdownMode\_t, [1525](#)  
     OS\_SocketType\_t, [1525](#)  
 osapi-task.h  
     OS\_FP\_ENABLED, [1527](#)  
     OS\_MAX\_TASK\_PRIORITY, [1527](#)  
     OSAL\_PRIORITY\_C, [1527](#)  
     OSAL\_STACKPTR\_C, [1527](#)  
     OSAL\_TASK\_STACK\_ALLOCATE, [1527](#)  
     osal\_priority\_t, [1528](#)  
     osal\_stackptr\_t, [1528](#)  
     osal\_task, [1528](#)  
 osapi-timebase.h  
     OS\_TimerSync\_t, [1530](#)  
 osapi-timer.h  
     OS\_TimerCallback\_t, [1531](#)  
 osapi-version.h  
     OS\_BUILD\_BASELINE, [1532](#)  
     OS\_BUILD\_NUMBER, [1532](#)  
     OS\_GetBuildNumber, [1535](#)  
     OS\_GetVersionCodeName, [1535](#)  
     OS\_GetVersionNumber, [1535](#)  
     OS\_GetVersionString, [1536](#)  
     OS\_MAJOR\_VERSION, [1532](#)  
     OS\_MINOR\_VERSION, [1532](#)  
     OS\_MISISON\_REV, [1533](#)  
     OS\_REVISION, [1533](#)  
     OS\_STR\_HELPER, [1533](#)  
     OS\_STR, [1533](#)  
     OS\_VERSION\_CODENAME, [1534](#)  
     OS\_VERSION\_STRING, [1534](#)  
     OS\_VERSION, [1533](#)  
     OSAL\_API\_VERSION, [1534](#)  
 osconfig-example.h  
     OS\_BUFFER\_MSG\_DEPTH, [1033](#)  
     OS\_BUFFER\_SIZE, [1033](#)  
     OS\_FS\_DEV\_NAME\_LEN, [1033](#)  
     OS\_FS\_PHYS\_NAME\_LEN, [1033](#)  
     OS\_FS\_VOL\_NAME\_LEN, [1034](#)  
     OS\_MAX\_API\_NAME, [1034](#)

OS\_MAX\_BIN\_SEMAPHORES, 1034  
OS\_MAX\_CMD\_LEN, 1034  
OS\_MAX\_CONSOLES, 1035  
OS\_MAX\_COUNT\_SEMAPHORES, 1035  
OS\_MAX\_FILE\_NAME, 1035  
OS\_MAX\_FILE\_SYSTEMS, 1035  
OS\_MAX\_MODULES, 1036  
OS\_MAX\_MUTEXES, 1036  
OS\_MAX\_NUM\_OPEN\_DIRS, 1036  
OS\_MAX\_NUM\_OPEN\_FILES, 1036  
OS\_MAX\_PATH\_LEN, 1037  
OS\_MAX\_QUEUES, 1037  
OS\_MAX\_SYM\_LEN, 1037  
OS\_MAX\_TASKS, 1038  
OS\_MAX\_TIMEBASES, 1038  
OS\_MAX\_TIMERS, 1038  
OS\_MODULE\_FILE\_EXTENSION, 1039  
OS\_PRINTF\_CONSOLE\_NAME, 1039  
OS\_QUEUE\_MAX\_DEPTH, 1039  
OS\_SHELL\_CMD\_INPUT\_FILE\_NAME, 1039  
OS SOCKADDR\_MAX\_LEN, 1040  
OS\_UTILITYTASK\_PRIORITY, 1040  
OS\_UTILITYTASK\_STACK\_SIZE, 1040

OutputPort  
CFE\_EVS\_HousekeepingTlm\_Payload, 644

OwnerAppName  
CFE\_TBL\_TblRegPacket\_Payload, 732

PSPMajorVersion  
CFE\_ES\_HousekeepingTlm\_Payload, 592

PSPMinorVersion  
CFE\_ES\_HousekeepingTlm\_Payload, 593

PSPMissionRevision  
CFE\_ES\_HousekeepingTlm\_Payload, 593

PSPRevision  
CFE\_ES\_HousekeepingTlm\_Payload, 593

Packet  
DS\_FilterTable\_t, 815

PacketID  
CFE\_EVS\_LongEventTlm\_Payload, 648  
CFE\_EVS\_ShortEventTlm\_Payload, 656

Padding  
DS\_AppStateCmd\_t, 782  
DS\_CloseFileCmd\_t, 784  
DS\_DestAgeCmd\_t, 786  
DS\_DestBaseCmd\_t, 788  
DS\_DestCountCmd\_t, 789  
DS\_DestExtCmd\_t, 791  
DS\_DestPathCmd\_t, 796  
DS\_DestSizeCmd\_t, 798

Parameter  
CFE\_TBL\_NotifyCmd\_Payload, 725

PassedPktCounter  
DS\_AppData\_t, 778

DS\_HkPacket\_t, 824

Path  
OS\_file\_prop\_t, 832

Pathname  
DS\_DestFileEntry\_t, 793  
DS\_DestPathCmd\_t, 796

Payload  
CFE\_ES\_AppNameCmd, 572  
CFE\_ES\_DeleteCDSCmd, 578  
CFE\_ES\_DumpCDSRegistryCmd, 580  
CFE\_ES\_FileNameCmd, 581  
CFE\_ES\_HousekeepingTlm, 583  
CFE\_ES\_MemStatsTlm, 599  
CFE\_ES\_OneAppTlm, 601  
CFE\_ES\_OverWriteSysLogCmd, 602  
CFE\_ES\_ReloadAppCmd, 606  
CFE\_ES\_RestartCmd, 607  
CFE\_ES\_SendMemPoolStatsCmd, 609  
CFE\_ES\_SetMaxPRCountCmd, 611  
CFE\_ES\_SetPerfFilterMaskCmd, 613  
CFE\_ES\_SetPerfTriggerMaskCmd, 615  
CFE\_ES\_StartApp, 617  
CFE\_ES\_StartPerfDataCmd, 621  
CFE\_ES\_StopPerfDataCmd, 623  
CFE\_EVS\_AppNameBitMaskCmd, 627  
CFE\_EVS\_AppNameCmd, 629  
CFE\_EVS\_AppNameEventIDCmd, 631  
CFE\_EVS\_AppNameEventIDMaskCmd, 633  
CFE\_EVS\_BitMaskCmd, 638  
CFE\_EVS\_HousekeepingTlm, 640  
CFE\_EVS\_LongEventTlm, 647  
CFE\_EVS\_SetEventFormatModeCmd, 653  
CFE\_EVS\_SetLogModeCmd, 655  
CFE\_EVS\_ShortEventTlm, 655  
CFE\_EVS\_WriteAppDataFileCmd, 657  
CFE\_EVS\_WriteLogDataFileCmd, 658  
CFE\_SB\_AllSubscriptionsTlm, 664  
CFE\_SB\_HousekeepingTlm, 666  
CFE\_SB\_RouteCmd, 682  
CFE\_SB\_SingleSubscriptionTlm, 686  
CFE\_SB\_StatsTlm, 688  
CFE\_SB\_WriteFileInfoCmd, 696  
CFE\_TBL\_AbortLoadCmd, 698  
CFE\_TBL\_ActivateCmd, 700  
CFE\_TBL\_DeleteCDSCmd, 703  
CFE\_TBL\_DumpCmd, 704  
CFE\_TBL\_DumpRegistryCmd, 706  
CFE\_TBL\_HousekeepingTlm, 711  
CFE\_TBL\_LoadCmd, 721  
CFE\_TBL\_NotifyCmd, 724  
CFE\_TBL\_SendRegistryCmd, 726  
CFE\_TBL\_TableRegistryTlm, 728  
CFE\_TBL\_ValidateCmd, 734  
CFE\_TIME\_DiagnosticTlm, 736

CFE\_TIME\_HousekeepingTlm, 750  
 CFE\_TIME\_OneHzAdjustmentCmd, 756  
 CFE\_TIME\_SetLeapSecondsCmd, 758  
 CFE\_TIME\_SetSignalCmd, 759  
 CFE\_TIME\_SetSourceCmd, 760  
 CFE\_TIME\_SetStateCmd, 761  
 CFE\_TIME\_TimeCmd, 766  
 CFE\_TIME\_ToneDataCmd, 768  
**PeakMemInUse**  
 CFE\_SB\_StatsTlm\_Payload, 692  
**PeakMsgIdsInUse**  
 CFE\_SB\_StatsTlm\_Payload, 692  
**PeakPipesInUse**  
 CFE\_SB\_StatsTlm\_Payload, 692  
**PeakQueueDepth**  
 CFE\_SB\_PipeDepthStats, 676  
 CFE\_SB\_PipeInfoEntry, 679  
**PeakSBBuffersInUse**  
 CFE\_SB\_StatsTlm\_Payload, 692  
**PeakSubscriptionsInUse**  
 CFE\_SB\_StatsTlm\_Payload, 693  
**PerfDataCount**  
 CFE\_ES\_HousekeepingTlm\_Payload, 590  
**PerfDataEnd**  
 CFE\_ES\_HousekeepingTlm\_Payload, 590  
**PerfDataStart**  
 CFE\_ES\_HousekeepingTlm\_Payload, 590  
**PerfDataToWrite**  
 CFE\_ES\_HousekeepingTlm\_Payload, 591  
**PerfFilterMask**  
 CFE\_ES\_HousekeepingTlm\_Payload, 591  
**PerfMode**  
 CFE\_ES\_HousekeepingTlm\_Payload, 591  
**PerfState**  
 CFE\_ES\_HousekeepingTlm\_Payload, 591  
**PerfTriggerCount**  
 CFE\_ES\_HousekeepingTlm\_Payload, 592  
**PerfTriggerMask**  
 CFE\_ES\_HousekeepingTlm\_Payload, 592  
**Pipe**  
 CFE\_SB\_RouteCmd\_Payload, 683  
 CFE\_SB\_SingleSubscriptionTlm\_Payload, 687  
 CFE\_SB\_SubEntries, 695  
**PipeDepthStats**  
 CFE\_SB\_StatsTlm\_Payload, 693  
**Pipeld**  
 CFE\_SB\_PipeDepthStats, 677  
 CFE\_SB\_PipeInfoEntry, 679  
 CFE\_SB\_RoutingFileEntry, 685  
**PipeName**  
 CFE\_SB\_PipeInfoEntry, 679  
 CFE\_SB\_RoutingFileEntry, 685  
**PipeOptsErrorCounter**  
 CFE\_SB\_HousekeepingTlm\_Payload, 671  
**PipeOverflowErrorCounter**  
 CFE\_SB\_HousekeepingTlm\_Payload, 671  
**PipesInUse**  
 CFE\_SB\_StatsTlm\_Payload, 693  
**Pkt**  
 DS\_FileCompletePktBuf\_t, 803  
**PktSegment**  
 CFE\_SB\_AllSubscriptionsTlm\_Payload, 665  
**PoolHandle**  
 CFE\_ES\_PoolStatsTlm\_Payload, 605  
 CFE\_ES\_SendMemPoolStatsCmd\_Payload, 610  
**PoolSize**  
 CFE\_ES\_MemPoolStats, 598  
**PoolStats**  
 CFE\_ES\_PoolStatsTlm\_Payload, 605  
**Priority**  
 CFE\_ES\_AppInfo, 570  
 CFE\_ES\_StartAppCmd\_Payload, 619  
 CFE\_ES\_TaskInfo, 624  
 CFE\_SB\_Qos\_t, 681  
**priority**  
 OS\_task\_prop\_t, 848  
**ProcessorID**  
 CFE\_EVS\_PacketID, 650  
 CFE\_FS\_Header, 662  
**ProcessorResets**  
 CFE\_ES\_HousekeepingTlm\_Payload, 592  
**psp/fsw/inc/cfe\_psp.h**, 1537  
**psp/fsw/inc/cfe\_psp\_error.h**, 1558  
**Ptr**  
 CFE\_ES\_PoolAlign, 604  
**Qos**  
 CFE\_SB\_SingleSubscriptionTlm\_Payload, 687  
 CFE\_SB\_SubEntries, 695  
**RegisteredCoreApps**  
 CFE\_ES\_HousekeepingTlm\_Payload, 593  
**RegisteredExternalApps**  
 CFE\_ES\_HousekeepingTlm\_Payload, 594  
**RegisteredLibs**  
 CFE\_ES\_HousekeepingTlm\_Payload, 594  
**RegisteredTasks**  
 CFE\_ES\_HousekeepingTlm\_Payload, 594  
**Reliability**  
 CFE\_SB\_Qos\_t, 681  
**Reserved**  
 CFE\_TBL\_File\_Hdr, 708  
**ResetSubtype**  
 CFE\_ES\_HousekeepingTlm\_Payload, 594  
**ResetType**  
 CFE\_ES\_HousekeepingTlm\_Payload, 595  
**ResourceId**  
 CFE\_ES\_AppInfo, 570  
**RestartType**

CFE\_ES\_RestartCmd\_Payload, 608

SBBuf  
  DS\_FileCompletePktBuf\_t, 803

SBBuffersInUse  
  CFE\_SB\_StatsTlm\_Payload, 693

SIZE\_BYTExxx  
  cfe\_psp.h, 1545

SIZE\_HALFxxx  
  cfe\_psp.h, 1545

SIZE\_WORD  
  cfe\_psp.h, 1546

sample\_mission\_cfg.h  
  CFE\_MISSION\_ES\_APP\_TLM\_MSG, 1108  
  CFE\_MISSION\_ES\_CDS\_MAX\_FULL\_NAME\_LEN,  
    1108  
  CFE\_MISSION\_ES\_CDS\_MAX\_NAME\_LENGTH,  
    1109  
  CFE\_MISSION\_ES\_CMD\_MSG, 1109  
  CFE\_MISSION\_ES\_CRC\_16, 1110  
  CFE\_MISSION\_ES\_CRC\_32, 1110  
  CFE\_MISSION\_ES\_CRC\_8, 1110  
  CFE\_MISSION\_ES\_DEFAULT\_CRC, 1110  
  CFE\_MISSION\_ES\_HK\_TLM\_MSG, 1110  
  CFE\_MISSION\_ES\_MAX\_APPLICATIONS, 1111  
  CFE\_MISSION\_ES\_MEMSTATS\_TLM\_MSG, 1111  
  CFE\_MISSION\_ES\_PERF\_MAX\_IDS, 1111  
  CFE\_MISSION\_ES\_POOL\_MAX\_BUCKETS, 1112  
  CFE\_MISSION\_ES\_SEND\_HK\_MSG, 1112  
  CFE\_MISSION\_EVS\_CMD\_MSG, 1113  
  CFE\_MISSION\_EVS\_HK\_TLM\_MSG, 1113  
  CFE\_MISSION\_EVS\_LONG\_EVENT\_MSG\_MSG,  
    1113  
  CFE\_MISSION\_EVS\_MAX\_MESSAGE\_LENGTH,  
    1113  
  CFE\_MISSION\_EVS\_SEND\_HK\_MSG, 1114  
  CFE\_MISSION\_EVS\_SHORT\_EVENT\_MSG\_MSG,  
    1114  
  CFE\_MISSION\_MAX\_API\_LEN, 1114  
  CFE\_MISSION\_MAX\_FILE\_LEN, 1114  
  CFE\_MISSION\_MAX\_PATH\_LEN, 1115  
  CFE\_MISSION\_SB\_ALLSUBS\_TLM\_MSG, 1115  
  CFE\_MISSION\_SB\_CMD\_MSG, 1116  
  CFE\_MISSION\_SB\_HK\_TLM\_MSG, 1116  
  CFE\_MISSION\_SB\_MAX\_PIPES, 1116  
  CFE\_MISSION\_SB\_MAX\_SB\_MSG\_SIZE, 1116  
  CFE\_MISSION\_SB\_ONESUB\_TLM\_MSG, 1117  
  CFE\_MISSION\_SB\_SEND\_HK\_MSG, 1117  
  CFE\_MISSION\_SB\_STATS\_TLM\_MSG, 1117  
  CFE\_MISSION\_SB\_SUB\_RPT\_CTRL\_MSG, 1117  
  CFE\_MISSION\_TBL\_CMD\_MSG, 1118  
  CFE\_MISSION\_TBL\_HK\_TLM\_MSG, 1118  
  CFE\_MISSION\_TBL\_MAX\_FULL\_NAME\_LEN,  
    1118

CFE\_MISSION\_TBL\_MAX\_NAME\_LENGTH, 1118  
CFE\_MISSION\_TBL\_REG\_TLM\_MSG, 1119  
CFE\_MISSION\_TBL\_SEND\_HK\_MSG, 1119  
CFE\_MISSION\_TEST\_CMD\_MSG, 1119  
CFE\_MISSION\_TEST\_HK\_TLM\_MSG, 1119  
CFE\_MISSION\_TIME\_1HZ\_CMD\_MSG, 1120  
CFE\_MISSION\_TIME\_AT\_TONE\_WAS, 1120  
CFE\_MISSION\_TIME\_AT\_TONE\_WILL\_BE, 1120  
CFE\_MISSION\_TIME\_CFG\_DEFAULT\_TAI, 1120  
CFE\_MISSION\_TIME\_CFG\_DEFAULT\_UTC, 1121  
CFE\_MISSION\_TIME\_CFG\_FAKE\_TONE, 1121  
CFE\_MISSION\_TIME\_CMD\_MSG, 1121  
CFE\_MISSION\_TIME\_DATA\_CMD\_MSG, 1122  
CFE\_MISSION\_TIME\_DEF\_DELAY\_SECS, 1122  
CFE\_MISSION\_TIME\_DEF\_DELAY\_SUBS, 1122  
CFE\_MISSION\_TIME\_DEF\_LEAPS, 1122  
CFE\_MISSION\_TIME\_DEF\_MET\_SECS, 1122  
CFE\_MISSION\_TIME\_DEF\_MET\_SUBS, 1123  
CFE\_MISSION\_TIME\_DEF\_STCF\_SECS, 1123  
CFE\_MISSION\_TIME\_DEF\_STCF\_SUBS, 1123  
CFE\_MISSION\_TIME\_DIAG\_TLM\_MSG, 1123  
CFE\_MISSION\_TIME\_EPOCH\_DAY, 1124  
CFE\_MISSION\_TIME\_EPOCH\_HOUR, 1124  
CFE\_MISSION\_TIME\_EPOCH\_MICROS, 1124  
CFE\_MISSION\_TIME\_EPOCH\_MINUTE, 1124  
CFE\_MISSION\_TIME\_EPOCH\_SECOND, 1124  
CFE\_MISSION\_TIME\_EPOCH\_YEAR, 1124  
CFE\_MISSION\_TIME\_FS\_FACTOR, 1125  
CFE\_MISSION\_TIME\_HK\_TLM\_MSG, 1125  
CFE\_MISSION\_TIME\_MAX\_ELAPSED, 1126  
CFE\_MISSION\_TIME\_MIN\_ELAPSED, 1126  
CFE\_MISSION\_TIME\_SEND\_CMD\_MSG, 1126  
CFE\_MISSION\_TIME\_SEND\_HK\_MSG, 1126  
CFE\_MISSION\_TIME\_TONE\_CMD\_MSG, 1127

sample\_perfids.h  
  CFE\_MISSION\_ES\_MAIN\_PERF\_ID, 1128  
  CFE\_MISSION\_ES\_PERF\_EXIT\_BIT, 1128  
  CFE\_MISSION\_EVS\_MAIN\_PERF\_ID, 1128  
  CFE\_MISSION\_SB\_MAIN\_PERF\_ID, 1128  
  CFE\_MISSION\_SB\_MSG\_LIM\_PERF\_ID, 1128  
  CFE\_MISSION\_SB\_PIPE\_OFLOW\_PERF\_ID, 1129  
  CFE\_MISSION\_TBL\_MAIN\_PERF\_ID, 1129  
  CFE\_MISSION\_TIME\_LOCAL1HZISR\_PERF\_ID,  
    1129  
  CFE\_MISSION\_TIME\_LOCAL1HZTASK\_PERF\_ID,  
    1129  
  CFE\_MISSION\_TIME\_MAIN\_PERF\_ID, 1129  
  CFE\_MISSION\_TIME\_SENDMET\_PERF\_ID, 1130  
  CFE\_MISSION\_TIME\_TONE1HZISR\_PERF\_ID,  
    1130  
  CFE\_MISSION\_TIME\_TONE1HZTASK\_PERF\_ID,  
    1130

Seconds  
  CFE\_TIME\_OneHzAdjustmentCmd\_Payload, 757

CFE\_TIME\_SysTime, 765  
 CFE\_TIME\_TimeCmd\_Payload, 767  
 Seconds1HzAdj  
   CFE\_TIME\_HousekeepingTlm\_Payload, 752  
 SecondsDelay  
   CFE\_TIME\_HousekeepingTlm\_Payload, 752  
 SecondsMET  
   CFE\_TIME\_HousekeepingTlm\_Payload, 753  
 SecondsSTCF  
   CFE\_TIME\_HousekeepingTlm\_Payload, 753  
 SendErrors  
   CFE\_SB\_PipeInfoEntry, 680  
 Sequence  
   CCSDS\_PrimaryHeader, 564  
 SequenceCount  
   DS\_DestCountCmd\_t, 789  
   DS\_DestFileEntry\_t, 794  
   DS\_FileInfo\_t, 807  
 ServerFlyState  
   CFE\_TIME\_DiagnosticTlm\_Payload, 745  
 Size  
   CFE\_ES\_CDSRegDumpRec, 577  
   CFE\_TBL\_Info, 720  
   CFE\_TBL\_TblRegPacket\_Payload, 732  
 SpacecraftID  
   CFE\_EVS\_PacketID, 651  
   CFE\_FS\_Header, 662  
 Spare  
   CFE\_ES\_TaskInfo, 625  
   CFE\_EVS\_AppNameBitMaskCmd\_Payload, 628  
   CFE\_EVS\_BitMaskCmd\_Payload, 639  
   CFE\_EVS\_SetEventFormatCode\_Payload, 652  
   CFE\_EVS\_SetLogMode\_Payload, 654  
   CFE\_SB\_PipeDepthStats, 677  
   CFE\_SB\_PipeInfoEntry, 680  
   CFE\_SB\_RouteCmd\_Payload, 683  
 Spare1  
   CFE\_EVS\_HousekeepingTlm\_Payload, 644  
   CFE\_EVS\_LongEventTlm\_Payload, 648  
 Spare2  
   CFE\_EVS\_HousekeepingTlm\_Payload, 644  
   CFE\_EVS\_LongEventTlm\_Payload, 648  
 Spare2Align  
   CFE\_SB\_HousekeepingTlm\_Payload, 671  
 Spare3  
   CFE\_EVS\_HousekeepingTlm\_Payload, 645  
 Spare8  
   DS\_AppData\_t, 778  
   DS\_HkPacket\_t, 824  
 stack\_size  
   OS\_task\_prop\_t, 848  
 StackSize  
   CFE\_ES\_AppInfo, 570  
   CFE\_ES\_StartAppCmd\_Payload, 619  
   CFE\_ES\_TaskInfo, 625  
 start\_time  
   OS\_timer\_prop\_t, 851  
 StartAddress  
   CFE\_ES\_AppInfo, 571  
 State  
   CFE\_SB\_RoutingFileEntry, 685  
 StreamId  
   CCSDS\_PrimaryHeader, 564  
 SubType  
   CFE\_FS\_Header, 662  
   CFE\_SB\_SingleSubscriptionTlm\_Payload, 688  
 SubscribeErrorCounter  
   CFE\_SB\_HousekeepingTlm\_Payload, 671  
 SubscriptionsInUse  
   CFE\_SB\_StatsTlm\_Payload, 694  
 Subseconds  
   CFE\_TIME\_OneHzAdjustmentCmd\_Payload, 757  
   CFE\_TIME\_SysTime, 765  
 Subsecs1HzAdj  
   CFE\_TIME\_HousekeepingTlm\_Payload, 753  
 SubsecsDelay  
   CFE\_TIME\_HousekeepingTlm\_Payload, 753  
 SubsecsMET  
   CFE\_TIME\_HousekeepingTlm\_Payload, 754  
 SubsecsSTCF  
   CFE\_TIME\_HousekeepingTlm\_Payload, 754  
 Subsystem  
   CCSDS\_ExtendedHeader, 563  
 SuccessValCounter  
   CFE\_TBL\_HousekeepingTlm\_Payload, 717  
 SysLogBytesUsed  
   CFE\_ES\_HousekeepingTlm\_Payload, 595  
 SysLogEntries  
   CFE\_ES\_HousekeepingTlm\_Payload, 595  
 SysLogMode  
   CFE\_ES\_HousekeepingTlm\_Payload, 595  
 SysLogSize  
   CFE\_ES\_HousekeepingTlm\_Payload, 596  
 SystemId  
   CCSDS\_ExtendedHeader, 563  
 Table  
   CFE\_ES\_CDSRegDumpRec, 577  
 TableLoadedOnce  
   CFE\_TBL\_Info, 720  
   CFE\_TBL\_TblRegPacket\_Payload, 733  
 TableName  
   CFE\_TBL\_AbortLoadCmd\_Payload, 699  
   CFE\_TBL\_ActivateCmd\_Payload, 701  
   CFE\_TBL\_DeICDSCmd\_Payload, 702  
   CFE\_TBL\_DumpCmd\_Payload, 705  
   CFE\_TBL\_File\_Hdr, 708  
   CFE\_TBL\_FileDef, 710

CFE\_TBL\_SendRegistryCmd\_Payload, 727  
CFE\_TBL\_ValidateCmd\_Payload, 735

TaskId  
    CFE\_ES\_TaskInfo, 625

TaskName  
    CFE\_ES\_TaskInfo, 625

TelemetryHeader  
    CFE\_ES\_HousekeepingTlm, 583  
    CFE\_ES\_MemStatsTlm, 599  
    CFE\_ES\_OneAppTlm, 601  
    CFE\_EVS\_HousekeepingTlm, 640  
    CFE\_EVS\_LongEventTlm, 647  
    CFE\_EVS\_ShortEventTlm, 656  
    CFE\_SB\_AllSubscriptionsTlm, 664  
    CFE\_SB\_HousekeepingTlm, 666  
    CFE\_SB\_SingleSubscriptionTlm, 686  
    CFE\_SB\_StatsTlm, 689  
    CFE\_TBL\_HousekeepingTlm, 711  
    CFE\_TBL\_TableRegistryTlm, 728  
    CFE\_TIME\_DiagnosticTlm, 736  
    CFE\_TIME\_HousekeepingTlm, 750

TgtFilename  
    CFE\_TBL\_FileDef, 710

ticks  
    OS\_time\_t, 849

TimeOfLastUpdate  
    CFE\_TBL\_Info, 720  
    CFE\_TBL\_TblRegPacket\_Payload, 733

TimeSeconds  
    CFE\_FS\_Header, 663

TimeSinceTone  
    CFE\_TIME\_DiagnosticTlm\_Payload, 745

TimeSource  
    CFE\_TIME\_SourceCmd\_Payload, 763

TimeSubSeconds  
    CFE\_FS\_Header, 663

TlmHeader  
    DS\_FileCompletePkt\_t, 802  
    DS\_FileInfoPkt\_t, 808  
    DS\_HkPacket\_t, 825

ToneDataCounter  
    CFE\_TIME\_DiagnosticTlm\_Payload, 746

ToneDataLatch  
    CFE\_TIME\_DiagnosticTlm\_Payload, 746

ToneIntCounter  
    CFE\_TIME\_DiagnosticTlm\_Payload, 746

ToneIntErrorCounter  
    CFE\_TIME\_DiagnosticTlm\_Payload, 746

ToneMatchCounter  
    CFE\_TIME\_DiagnosticTlm\_Payload, 747

ToneMatchErrorCounter  
    CFE\_TIME\_DiagnosticTlm\_Payload, 747

ToneOverLimit  
    CFE\_TIME\_DiagnosticTlm\_Payload, 747

ToneSignalCounter  
    CFE\_TIME\_DiagnosticTlm\_Payload, 747

ToneSignalLatch  
    CFE\_TIME\_DiagnosticTlm\_Payload, 748

ToneSource  
    CFE\_TIME\_SignalCmd\_Payload, 762

ToneTaskCounter  
    CFE\_TIME\_DiagnosticTlm\_Payload, 748

ToneUnderLimit  
    CFE\_TIME\_DiagnosticTlm\_Payload, 748

total\_blocks  
    OS\_statvfs\_t, 846

TotalSegments  
    CFE\_SB\_AllSubscriptionsTlm\_Payload, 665

TriggerMask  
    CFE\_ES\_SetPerfTrigMaskCmd\_Payload, 616

TriggerMaskNum  
    CFE\_ES\_SetPerfTrigMaskCmd\_Payload, 616

TriggerMode  
    CFE\_ES\_StartPerfCmd\_Payload, 620

Type  
    CFE\_ES\_AppInfo, 571

uint16  
    common\_types.h, 1490

uint32  
    common\_types.h, 1490

uint64  
    common\_types.h, 1490

uint8  
    common\_types.h, 1491

UnmarkedMem  
    CFE\_SB\_HousekeepingTlm\_Payload, 672

UnregisteredAppCounter  
    CFE\_EVS\_HousekeepingTlm\_Payload, 645

Unused  
    DS\_AppFileStatus\_t, 781

User  
    OS\_file\_prop\_t, 832

UserDefAddr  
    CFE\_TBL\_Info, 720

valid  
    OS\_module\_address\_t, 838

ValidationCounter  
    CFE\_TBL\_HousekeepingTlm\_Payload, 717

ValidationFuncPtr  
    CFE\_TBL\_TblRegPacket\_Payload, 733

Value  
    CFE\_SB\_MsgId\_t, 674

value  
    OS\_bin\_sem\_prop\_t, 828  
    OS\_count\_sem\_prop\_t, 829

VersionCounter  
    CFE\_TIME\_DiagnosticTlm\_Payload, 748

VirtualMET

CFE\_TIME\_DiagnosticTlm\_Payload, [749](#)