

2016.0 RANGE ROVER (LG), 501-11

GLASS, FRAMES AND MECHANISMS

DOOR WINDOW MOTOR INITIALIZATION (G1345535)

GENERAL PROCEDURES

NOTES:

- Make sure that the vehicle battery is fully charged before carrying out this procedure.
- After the battery has been disconnected or a new window regulator and motor or door module has been installed, it is necessary to initialize each door window motor separately to operate the **one-touch** and anti-trap function.
- In addition to this manual procedure, the approved diagnostic tool can also be used to initialize the door window motor.

-
1. Start the engine.
-
2. Operate the window control switch until the door window glass is in the fully closed position, continue to operate the window control switch for a further two seconds.
-
3. Release the window control switch.
-

4. Operate the window control switch in the closed position and continue to operate the window control switch for a further two seconds.

-
5. Operate the window control switch until the door window glass is in the fully open position (**one-touch** down).

6.

NOTES:

- If the door window motor initialization has been completed correctly, when the window control switch is operated, the door window glass should move to the fully closed position (**one-touch** up) automatically.
- If the door window glass does not fully close automatically (**one-touch** up), repeat the complete procedure.

Operate the window control switch once to the close position.

- If multiple attempts have failed to initialize the door window motor, refer the diagnosis and testing procedure.

For additional information, refer to: [Glass, Frames and Mechanisms](#) (501-11 Glass, Frames and Mechanisms, Diagnosis and Testing).

-
7. Repeat the door window motor initialization for each door window motor.