

2016.0 RANGE ROVER (LG), 501-17

ROOF OPENING PANEL

# POWER ROOF OPENING PANEL INITIALIZATION [G1999297]

GENERAL PROCEDURES

---

---

## ACTIVATION

### NOTE:

Roof opening panel blind/roof opening panel glass initialization will be lost if the battery is disconnected, or if the roof opening panel blind/roof opening panel glass motor power supply is interrupted whilst the roof opening panel blind/roof opening panel glass is in motion.

1. Start the engine.
2. The roof opening panel and roof opening panel blind system must be in the closed position.
3. Press the roof opening panel and roof opening panel blind close switch for approximately 20 seconds until the roof opening panel and roof opening panel blind actuates forwards and then rearwards approximately 10mm.

4.
  - 1.** Release the roof opening panel and roof opening panel blind close switch and then re-press the roof opening panel and roof opening panel blind close switch again within 5 seconds and keep pressed until the following sequence has completed.
    - 2.** The roof opening panel blind opens fully.
    - 3.** The roof opening panel opens fully.
    - 4.** The roof opening panel closes fully.
    - 5.** The roof opening panel blind closes fully.
5. Release the roof opening panel and roof opening panel blind close switch, roof is now fully initialized.
6. Test the operation of the roof opening panel, if the one touch and anti-trap functions are inoperative repeat step one to five.