

2016.0 RANGE ROVER (LG), 206-11

BRAKE CONTROLS

DIAGNOSIS AND TESTING

PRINCIPLE OF OPERATION

For additional information on the braking control system, refer to the relevant description and operation section in the workshop manual
REFER to: [Braking Control System](#) (206-11 Brake Controls, Description and Operation).

INSPECTION AND VERIFICATION

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable.
Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle

1. Verify the customer concern
2. Visually inspect for obvious mechanical or electrical faults

Visual Inspection

MECHANICAL	ELECTRICAL
▪ Tire size, condition and installation	▪ Fuses

- | | |
|---|---|
| <ul style="list-style-type: none"> ▪ Wheel speed sensor condition and installation ▪ Steering angle sensor condition and installation ▪ Yaw rate sensor and accelerometer condition and installation ▪ Hydraulic control unit (with attached ABS control module) condition and installation | <ul style="list-style-type: none"> ▪ Harnesses and connectors ▪ Warning lamp operation ▪ Wheel speed sensors ▪ Body control module ▪ Hill descent control switch ▪ Dynamic stability control switch ▪ Stop lamp switch ▪ Yaw rate sensor and accelerometer ▪ Steering angle sensor ▪ ABS control module ▪ CAN circuits |
|---|---|

3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step
4. If the cause is not visually evident, check for diagnostic trouble codes (DTCs) and refer to the DTC index

DTC INDEX

For a list of DTCs that could be logged on this vehicle, please refer to Section 100-00.

REFER to: [Diagnostic Trouble Code Index: ABS Control Module - DTC: Anti-Lock Brake System Control Module \(ABS\)](#) (100-00 General Information, Description and Operation).