

2016.0 RANGE ROVER (LG), 206-05

PARKING BRAKE AND ACTUATION

DIAGNOSIS AND TESTING

PRINCIPLES OF OPERATION

For a detailed description of the electric park brake system, refer to the relevant description and operation section in the workshop manual. REFER to: [Parking Brake](#) (206-05 Parking Brake and Actuation, Description and Operation).

INSPECTION AND VERIFICATION

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle

NOTE:

Prior to any testing or inspection, the vehicle should be checked for any relevant warning lamps being illuminated. If a warning lamp is illuminated, check for DTCs and refer to the relevant DTC Index, if no warning lamp is illuminated, continue with diagnostic procedures below

1. Verify the customer concern

2. Visually inspect for obvious signs of damage and system integrity

Visual Inspection

MECHANICAL	ELECTRICAL
▪ Electric park brake actuator(s) ▪ Brake caliper ▪ Brake discs / pads ▪ Electric park brake control module mounting	▪ Fuse(s) ▪ Wiring harness/electrical connectors ▪ Check for bent/corroded electric park brake control module connector pins ▪ Electric park brake switch ▪ Electric park brake control module ▪ CAN circuit

3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step

4. If the cause is not visually evident, check the anti-lock braking system and steering rotation sensor modules for DTCs and refer to the relevant DTC index

SYMPTOM CHART

SYMPTOM	POSSIBLE CAUSE	ACTION

The electric park brake will not engage or release (with no electric park brake warning message)	▪ Both electric park brake control module fuse(s) failure ▪ Electric park brake actuator incorrectly installed to the vehicle ▪ Rear brake lining wear ▪ Service brake incorrectly adjusted following lining change ▪ Brake caliper malfunction ▪ Electric park brake actuator internal fault	▪ Check fuse(s) ▪ Check both electric park brake actuator is correctly installed to the vehicle. Rectify as required ▪ Check the rear and primary cables for correct installation and damage ▪ Inspect the rear brake linings for wear ▪ Re-calibrate the park brake, refer to the calibration procedure ▪ Check the rear service brake for correct installation and operation ▪ Check for related electric park brake control module DTCs and refer to the relevant DTC index
The electric park brake will not engage or release (with no electric park brake warning message)	▪ Electric park brake actuator incorrectly installed to the vehicle ▪ Rear brake lining wear ▪ Brake caliper malfunction ▪ Electric park brake actuator internal fault	▪ Check both electric park brake actuator is correctly installed to the vehicle. Rectify as required ▪ Inspect the rear brake linings for wear ▪ Check the rear service brake for correct installation and operation ▪ Check for related electric park brake control module DTCs and refer to the relevant DTC index
No communication with the electric park brake control module	▪ Fuse(s) ▪ Module off bus ▪ CAN network error ▪ Electric park brake control module internal fault	▪ Check fuse(s) ▪ Ensure battery is fully charged and in serviceable condition. Check battery voltage at electric park brake control module ▪ Check CAN network using manufacturer approved diagnostic system ▪ Check for related electric park brake control module DTCs and

		refer to the relevant DTC index
'Park Brake Fault' displayed on message center with associated warning lamps	▪ Electric park brake control module internal fault	▪ Check for related electric park brake control module DTCs and refer to the relevant DTC index
Brakes drag	▪ Electric park brake actuator incorrectly installed to the vehicle ▪ Rear brake lining wear ▪ Brake caliper malfunction ▪ Electric park brake actuator internal fault	▪ Check both electric park brake actuator is correctly installed to the vehicle. Rectify as required ▪ Inspect the rear brake linings for wear ▪ Check the rear service brake for correct installation and operation ▪ Check for related electric park brake control module DTCs and refer to the relevant DTC index

DTC Index

For a complete list of all diagnostic trouble codes that could be logged on this vehicle, please refer to section 100-00.

REFER to: [Diagnostic Trouble Code Index - DTC: Electric Park Brake Control Module \(EPBCM\)](#) (100-00 General Information, Description and Operation).