

2016.0 RANGE ROVER (LG), 204-05

VEHICLE DYNAMIC SUSPENSION

AIR SUSPENSION MANUAL TIGHT TOLERANCE SETTING MODE (G1563402)

GENERAL PROCEDURES

ACTIVATION

NOTES:

- If this procedure has been successful the instrument cluster will emit two soft chimes 1 second after the drivers door is closed. The instrument cluster will then emit two soft chimes each time the drivers door is closed to confirm that air suspension manual tight tolerance setting mode is still active.
- Apply 3 light applications to the brake pedal during this procedure. Make sure that the pedal is returned to the fully off position before the next application.

1. Make sure the transmission is in the P position.
2. Run the engine.
3. Set the suspension to the normal height.

4. Open the drivers door.
5. Press the brake pedal 3 times (making sure that the pedal is fully returned to the rest position before applying the next application).
6. Close the drivers door within 10 seconds of the first brake pedal application.

DEACTIVATION

7. Turn the engine off or drive the vehicle over 5 mph (8 Km/h).