

2016.0 RANGE ROVER (LG), 204-04

WHEELS AND TIRES

DIAGNOSIS AND TESTING

PRINCIPLES OF OPERATION

For a detailed description of the Tire Pressure Monitoring System, refer to the relevant Description and Operation section in the workshop manual.

REFER to: [Tire Pressure Monitoring System](#) (204-04 Wheels and Tires, Description and Operation).

INSPECTION AND VERIFICATION

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.

NOTES:

- If a control module or a component is suspect and the vehicle remains under manufacturer warranty, refer to the Warranty Policy and Procedures manual, or determine if any prior approval programme is in operation, prior to the installation of a new module/component.
- When performing voltage or resistance tests, always use a digital multimeter accurate to three decimal places, and with an up-to-date calibration certificate. When testing resistance always take the resistance of the digital multimeter leads into account.
- Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.

1. Verify the customer concern

2. Visually inspect for obvious signs of damage and system integrity

Visual Inspection

MECHANICAL	ELECTRICAL
▪ Wheels/tires ▪ Tire pressure sensors	▪ Fuses ▪ Wiring harnesses and connectors ▪ Tire pressure monitoring system control module ▪ Anti-lock brake system control module ▪ Tire pressure sensors

3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step

4. If the cause is not visually evident, verify the symptom and refer to the Symptom Chart, alternatively check for Diagnostic Trouble Codes (DTCs) and refer to the DTC Index

5. Check DDW for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and carry out the recommendations as required

SYMPTOM CHART

SYMPTOM	POSSIBLE CAUSES	ACTION
Tire pressure monitoring system warning indicator illuminated continuously	▪ One or more tires punctured / incorrectly inflated	▪ Check the tires for punctures. Check the tire pressures and correct as necessary
Tire pressure monitoring system warning indicator flashing for 75 seconds and then illuminated continuously	▪ Tire pressure monitoring system fault	NOTE: It is not possible to have a TPMS fault without a DTC being set. ▪ Using the manufacturer approved diagnostic system, check the tire pressure monitoring system control module for related DTCs and refer to the relevant DTC index

DTC INDEX

For a list of Diagnostic Trouble Codes (DTCs) that could be logged on this vehicle, please refer to Section 100-00. REFER to: [Diagnostic Trouble Code Index - DTC: Tire Pressure Monitoring System Control Module \(TPMSCM\)](#) (100-00 General Information, Description and Operation).