

2016.0 RANGE ROVER (LG), 412-00

CLIMATE CONTROL SYSTEM - GENERAL INFORMATION

AIR CONDITIONING COMPRESSOR COMMISSIONING (G1704335)

GENERAL PROCEDURES

ACTIVATION

CAUTION:

Failure to follow this instruction may result in damage to the component.

1. Set the ignition to the on position, make sure the air conditioning (A/C) is in the off position.
2. Start the engine and allow to run for a minimum of 5 minutes.
3. Set the heater controls to 22°C, with the fan speed set to 75%.
4. Switch on the A/C system.
5. Open all air vents in the dashboard.
6. Run the A/C system for a minimum of 5 minutes, while the engine is

still at idle speed.

7. Once this is achieved the compressor is stabilized, with the oil being distributed evenly throughout the system.