

2016.0 RANGE ROVER (LG), 412-00

CLIMATE CONTROL SYSTEM – GENERAL INFORMATION

DIAGNOSIS AND TESTING

PRINCIPLES OF OPERATION

For a detailed description of the auxiliary climate control system and operation, refer to the relevant description and operation section of the workshop manual. REFER to: (412-02)

Electric Booster Heater (Description and Operation),
Fuel Fired Booster Heater (Description and Operation),
Auxiliary Climate Control (Description and Operation).

INSPECTION AND VERIFICATION

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable.
Substitution of control modules does not guarantee confirmation of a fault and may also cause additional faults in the vehicle being checked and/or the donor vehicle

1. Verify the customer concern
2. Visually inspect for obvious signs of mechanical or electrical damage

Visual Inspection

MECHANICAL	ELECTRICAL
▪ Electric booster heater ▪ Fuel fired booster heater assembly ▪ Combustion air fan ▪ Coolant inlet/outlet ▪ Heat exchanger ▪ Temperature sensor ▪ Exhaust ▪ Fuel inlet ▪ Air inlet ▪ Evaporator ▪ Auxiliary fuel pump and lines ▪ Auxiliary coolant pump	▪ Fuses ▪ Harnesses ▪ Electrical connector(s) ▪ Control module(s) ▪ Control module(s)

3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step

4. If the cause is not visually evident, check for diagnostic trouble codes (DTCs) and refer to the DTC index

DTC INDEX

For a list of diagnostic trouble codes (DTCs) that could be logged on this vehicle, please refer to Section 100-00.

REFER to: [Diagnostic Trouble Code Index - DTC: Automatic Temperature Control Module \(ATCM\)](#) (100-00 General Information, Description and Operation).