

2016.0 RANGE ROVER (LG), 412-01

CLIMATE CONTROL

AMBIENT AIR TEMPERATURE SENSOR (G1509822)

REMOVAL AND INSTALLATION

REMOVAL

NOTE:

Removal steps in this procedure may contain installation details.

1. Disconnect the battery ground cable.
Refer to: [Specifications](#) (414-00 Battery and Charging System - General Information, Specifications).
2. The ambient air temperature sensor is an integral part of the door mirror and cannot be removed. A new door mirror must be installed.
Refer to: [Exterior Mirror](#) (501-09 Rear View Mirrors, Removal and Installation).

INSTALLATION

1. To install, reverse the removal procedure.

