

2016.0 RANGE ROVER (LG), 413-06

HORN

DIAGNOSIS AND TESTING

PRINCIPLES OF OPERATION

For a detailed description of the horn system and operation, refer to the relevant Description and Operation section of the workshop manual.

INSPECTION AND VERIFICATION

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault and may also cause additional faults in the vehicle being checked and/or the donor vehicle.

NOTE:

Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.

1. Verify the customer concern.
2. Visually inspect for obvious signs of mechanical or electrical damage.

Visual Inspection

MECHANICAL	ELECTRICAL
▪ Horn(s) condition and installation	▪ Battery condition and state of charge ▪ Fuses ▪ Relay ▪ Electrical connections ▪ Horn switches ▪ Clockspring ▪ Body Control Module ▪ Battery Junction Box

3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step.
4. If the cause is not visually evident, verify the symptom and refer to the Symptom Chart, alternatively check for Diagnostic Trouble Codes (DTCs) and refer to the DTC Index.

SYMPTOM CHART

SYMPTOM	POSSIBLE CAUSES	ACTION
Horn(s) operate with a muffled tone	▪ Low battery voltage ▪ Horn circuit short circuit to ground, short circuit to power, open circuit, high resistance	▪ Refer to the relevant section of the workshop manual and test the battery ▪ Refer to the electrical circuit diagrams and test the horn circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, check the body control module for related DTCs and refer to the relevant DTC index
Horn(s) inoperative		

DTC INDEX

For a list of Diagnostic Trouble Codes (DTCs) that could be logged on this vehicle, please refer to Section 100-00.

REFER to: [Diagnostic Trouble Code Index - DTC: Body Control Module \(BCM\)](#) (100-00 General Information, Description and Operation).