

2016.0 RANGE ROVER (LG), 417-01

EXTERIOR LIGHTING

DIAGNOSIS AND TESTING

PRINCIPLE OF OPERATION

For a detailed description of the exterior lighting system and operation, refer to the relevant description and operation section of the workshop manual. REFER to: [Exterior Lighting](#) (417-01 Exterior Lighting, Description and Operation).

INSPECTION AND VERIFICATION

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault and may also cause additional faults in the vehicle being checked and/or the donor vehicle

1. Verify the customer concern
2. Visually inspect for obvious signs of mechanical or electrical damage

Visual Inspection

MECHANICAL	ELECTRICAL
▪ Front fog lamp condition and installation	▪ Fuses

- | | |
|---|--|
| <ul style="list-style-type: none"> ▪ Bulb and installation ▪ Bulb holder and installation ▪ Adjuster screw ▪ Lighting control switch condition and installation | <ul style="list-style-type: none"> ▪ Wiring harness ▪ Loose or corroded connector(s) ▪ Front fog lamp relay ▪ Front fog lamp warning indicator ▪ Lighting control switch ▪ Battery junction box ▪ Body control module |
|---|--|

3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step
4. If the cause is not visually evident, verify the symptom and refer to the symptom chart, alternatively check for diagnostic trouble codes (DTCs) and refer to the relevant DTC index

SYMPTOM CHART

SYMPTOM	POSSIBLE CAUSES	ACTION
Front fog lamp inoperative	▪ Bulb failure ▪ Fuse(s) blown ▪ Circuit fault ▪ Lighting control switch inoperative	Check the bulb condition. Check the fuse(s). Check the front fog lamp circuits. Check the lighting control switch function. Refer to the electrical guides
Front fog lamp dim	▪ Incorrect bulb rating ▪ Circuit fault ▪ Lighting control switch fault	Check the bulb condition and rating. Check the front fog lamp circuits. Check the lighting control switch function. Refer to the electrical guides

Front fog lamp lighting coverage poor	▪ Front fog lamp alignment incorrect	Check and adjust front fog lamp alignment
Front fog lamp warning indicator inoperative	▪ Fuse(s) blown ▪ Lighting control switch inoperative ▪ Circuit fault ▪ Instrument cluster fault	Check the fuse(s). Check the lighting control switch function. Check the warning lamp circuits. Refer to the electrical guides. Check for DTCs indicating an instrument cluster fault

DTC INDEX

For a list of diagnostic trouble codes (DTCs) that could be logged on this vehicle, please refer to Section 100-00. REFER to: [Diagnostic Trouble Code Index - DTC: Body Control Module \(BCM\)](#) (100-00 General Information, Description and Operation).