

2016.0 RANGE ROVER (LG), 417-01

EXTERIOR LIGHTING

DIAGNOSIS AND TESTING

PRINCIPLE OF OPERATION

For a detailed description of the headlamp leveling system and operation, refer to the relevant description and operation section of the workshop manual. REFER to: [Exterior Lighting](#) (417-01 Exterior Lighting, Description and Operation).

INSPECTION AND VERIFICATION

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault and may also cause additional faults in the vehicle being checked and/or the donor vehicle

1. Verify the customer concern
2. Visually inspect for obvious signs of mechanical or electrical damage

Visual Inspection

MECHANICAL	ELECTRICAL
▪ Headlamp leveling motor(s) and linkage(s) condition	▪ Fuses

and installation ▪ Lighting control switch and installation ▪ Left-side steering column multifunction switch and installation	▪ Wiring harness ▪ Loose or corroded connector(s) ▪ Battery junction box ▪ Body control module ▪ Headlamp power modules ▪ Engine control module ▪ ABS control module ▪ Integrated suspension control module ▪ LIN circuits ▪ CAN circuits
---	--

3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step
4. If the cause is not visually evident, verify the symptom and refer to the symptom chart, alternatively check for diagnostic trouble codes (DTCs) and refer to the relevant DTC index

SYMPTOM CHART

SYMPTOM	POSSIBLE CAUSES	ACTION
Headlamp leveling system inoperative	▪ Fuse(s) blown ▪ Leveling motor/linkage fault	Check the fuse(s) condition. Check the headlamp leveling motor and linkage condition. Check the headlamp leveling circuit. Refer to the electrical guides. Check for DTCs indicating headlamp leveling circuit and air suspension system fault(s)
Headlamp alignment incorrect	▪ Headlamp leveling circuit fault ▪ Air suspension system fault	

DTC INDEX

For a list of diagnostic trouble codes (DTCs) that could be logged on this vehicle, please refer to Section 100-00. REFER to: (100-00 General Information)

[Diagnostic Trouble Code Index - DTC: Body Control Module \(BCM\)](#)

(Description and Operation),

[Diagnostic Trouble Code Index: Integrated Suspension Control Module](#)

(Description and Operation).