

2016.0 RANGE ROVER (LG), 417-01

EXTERIOR LIGHTING

DIAGNOSIS AND TESTING

PRINCIPLE OF OPERATION

For a detailed description of the exterior lighting system and operation, refer to the relevant description and operation section of the workshop manual. REFER to: [Exterior Lighting](#) (417-01 Exterior Lighting, Description and Operation).

INSPECTION AND VERIFICATION

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault and may also cause additional faults in the vehicle being checked and/or the donor vehicle

1. Verify the customer concern
2. Visually inspect for obvious signs of mechanical or electrical damage

Visual Inspection

MECHANICAL	ELECTRICAL
▪ Reverse lamp condition and installation	▪ Fuses

- | | |
|---|--|
| <ul style="list-style-type: none"> ▪ Bulb and installation ▪ Bulb holder and installation | <ul style="list-style-type: none"> ▪ Wiring harness ▪ Loose or corroded connector(s) ▪ Reverse lamp relay ▪ Battery junction box ▪ Body control module ▪ Transmission control module ▪ CAN circuits |
|---|--|

3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step
4. If the cause is not visually evident, verify the symptom and refer to the symptom chart, alternatively check for diagnostic trouble codes (DTCs) and refer to the relevant DTC index

SYMPTOM CHART

SYMPTOM	POSSIBLE CAUSES	ACTION
Reverse lamp(s) inoperative	▪ Bulb failure ▪ Fuse(s) blown ▪ Circuit fault ▪ Missing reverse lamp switch signal	Check the bulb and fuse condition. Check the reverse lamp circuits. Refer to the electrical guides. Check for DTCs indicating a reverse lamp circuit fault
Reverse lamp(s) dim	▪ Incorrect bulb rating ▪ Circuit fault	Check the bulb condition and rating. Check the reverse lamp circuits. Refer to the electrical guides

DTC INDEX

For a list of diagnostic trouble codes (DTCs) that could be logged on this vehicle, please refer to Section 100-00. REFER to: [Diagnostic Trouble Code Index - DTC: Body Control Module \(BCM\)](#) (100-00 General Information, Description and Operation).