

2016.0 RANGE ROVER (LG), 417-01

EXTERIOR LIGHTING

DIAGNOSIS AND TESTING

PRINCIPLE OF OPERATION

For a detailed description of the exterior lighting system and operation, refer to the relevant description and operation section of the workshop manual. REFER to: [Exterior Lighting](#) (417-01 Exterior Lighting, Description and Operation).

INSPECTION AND VERIFICATION

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault and may also cause additional faults in the vehicle being checked and/or the donor vehicle

NOTE:

Prior to carrying out fault diagnosis of the trailer lamp system, verify the operation of the towing vehicle lighting system with the trailer lighting plug(s) disconnected from the vehicle socket(s)

- 1. Verify the customer concern
- 2. Visually inspect for obvious signs of mechanical or electrical damage

Visual Inspection

MECHANICAL	ELECTRICAL
▪ Trailer lamp(s) condition and installation ▪ Bulbs and installation ▪ Bulb holders and installation ▪ Trailer socket(s), plug(s) and installation	▪ Fuses ▪ Relays ▪ Stop lamp switch ▪ Wiring harness ▪ Loose or corroded connector(s) ▪ Trailer socket(s) ground circuit(s) ▪ Battery junction box ▪ Body control module ▪ Trailer fuse box ▪ Trailer relay box ▪ Instrument cluster ▪ CAN circuits

- 3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step
- 4. If the cause is not visually evident, verify the symptom and refer to the symptom chart, alternatively check for diagnostic trouble codes (DTCs) and refer to the relevant DTC index

SYMPTOM CHART

SYMPTOM	POSSIBLE CAUSES	ACTION
Trailer stop lamp(s) inoperative	▪ Bulb failure ▪ Fuse(s) blown	Check the bulb and fuse condition. Check the trailer stop lamp circuit. Check the stop lamp switch function. Refer to the electrical guides

	▪ Circuit fault ▪ Stop lamp switch fault	
Trailer stop lamp(s) dim	▪ Incorrect bulb rating ▪ Circuit fault ▪ Stop lamp switch fault	Check the bulb condition and rating. Check the trailer stop lamp circuit. Check the stop lamp switch function. Refer to the electrical guides
Trailer stop lamp(s) stuck on	▪ Circuit fault ▪ Stop lamp switch fault	Check the trailer stop lamp circuits. Check the stop lamp switch function. Refer to the electrical guides
Trailer fog lamp(s) inoperative	▪ Bulb failure ▪ Fuse(s) blown ▪ Circuit fault	Check the bulb and fuse condition. Check the trailer fog lamp circuit. Refer to the electrical guides
Trailer fog lamp(s) dim	▪ Incorrect bulb rating ▪ Circuit fault	Check the bulb condition and rating. Check the trailer fog lamp circuit. Refer to the electrical guides
Trailer fog lamp(s) stuck on	▪ Circuit fault	Check the trailer fog lamp circuit. Refer to the electrical guides
Trailer tail and license plate lamp(s) inoperative	▪ Bulb failure ▪ Fuse(s) blown ▪ Circuit fault ▪ Trailer side lamp relay fault	Check the bulb and fuse condition. Check the trailer tail and license plate lamp circuit. Check the trailer tail and license plate lamp relay function. Refer to the electrical guides
Trailer tail	▪ Incorrect	Check the bulb condition and rating. Check the trailer

and license plate lamp(s) dim	bulb rating ▪ Circuit fault ▪ Trailer side lamp relay fault	tail and license plate lamp circuit. Check the trailer side lamp relay function. Refer to the electrical guides
Trailer tail and license plate lamp(s) stuck on	▪ Circuit fault ▪ Trailer tail and license plate lamp relay fault	Check the trailer tail and license plate lamp circuit. Check the trailer tail and license plate lamp relay function. Refer to the electrical guides
Trailer turn signal indicator(s) inoperative	▪ Bulb failure ▪ Fuse(s) blown ▪ Circuit fault	Check the bulb and fuse condition. Check the trailer turn signal indicator circuit. Refer to the electrical guides
Trailer turn signal indicator(s) dim	▪ Incorrect bulb rating ▪ Circuit fault	Check the bulb condition and rating. Check the trailer turn signal indicator circuits. Refer to the electrical guides
Trailer turn signal indicator(s) stuck on	▪ Circuit fault	Check the bulb and fuse condition. Check the trailer turn signal indicator circuit. Refer to the electrical guides
Trailer reverse lamp(s) inoperative	▪ Bulb failure ▪ Fuse(s) blown ▪ Circuit fault ▪ Trailer reverse lamp relay fault	Check the bulb and fuse condition. Check the trailer reverse lamp circuit. Check the trailer reverse lamp relay function. Refer to the electrical guides
Trailer reverse lamp(s) dim	▪ Circuit fault ▪ Trailer	Check the bulb condition and rating. Check the trailer reverse lamp circuit. Check the trailer reverse lamp relay function. Refer to the electrical guides

	reverse lamp relay fault	
Trailer reverse lamp(s) stuck on	▪ Circuit fault ▪ Trailer reverse lamp relay fault	Check the trailer reverse lamp circuit. Check the trailer reverse lamp relay function. Refer to the electrical guides
Warning lamp(s) inoperative	▪ Fuse(s) blown ▪ Circuit fault ▪ Instrument cluster fault	Check the fuse(s). Check the warning lamp circuit. Refer to the electrical guides. Check for DTCs indicating an instrument cluster or CAN system fault
Trailer socket battery feed missing	▪ Fuse(s) blown ▪ Circuit fault	Check the fuse condition. Check the trailer battery feed circuit. Refer to the electrical guides
Trailer socket ignition feed missing	▪ Fuse(s) blown ▪ Circuit fault ▪ Trailer socket relay fault	Check the fuse condition. Check the trailer ignition feed circuit. Check the trailer ignition feed relay operation. Refer to the electrical guides

DTC INDEX

For a list of diagnostic trouble codes (DTCs) that could be logged on this vehicle, please refer to Section 100-00. REFER to: [Diagnostic Trouble Code Index - DTC: Body Control Module \(BCM\)](#) (100-00 General Information, Description and Operation).

