

2016.0 RANGE ROVER (LG), 417-01

EXTERIOR LIGHTING

DIAGNOSIS AND TESTING

PRINCIPLE OF OPERATION

For a detailed description of the exterior lighting system and operation, refer to the relevant description and operation section of the workshop manual. REFER to: [Exterior Lighting](#) (417-01 Exterior Lighting, Description and Operation).

INSPECTION AND VERIFICATION

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault and may also cause additional faults in the vehicle being checked and/or the donor vehicle

1. Verify the customer concern
2. Visually inspect for obvious signs of mechanical or electrical damage

Visual Inspection

MECHANICAL	ELECTRICAL
▪ Turn signal indicator(s) condition and installation	▪ Fuses

▪ Cornering lamp(s) condition and installation ▪ Bulbs and installation ▪ Bulb holders and installation ▪ Lighting control switch and installation ▪ Hazard warning lamp switch condition and installation	▪ Wiring harness ▪ Loose or corroded connector(s) ▪ Battery junction box ▪ Body control module ▪ Steering angle sensor ▪ Anti-lock brake system control module ▪ Instrument cluster ▪ Restraints control module ▪ CAN circuits
--	--

3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step
4. If the cause is not visually evident, verify the symptom and refer to the symptom chart, alternatively check for diagnostic trouble codes (DTCs) and refer to the relevant DTC index

SYMPTOM CHART

SYMPTOM	POSSIBLE CAUSES	ACTION
Turn signal indicator(s)/hazard warning lamp(s) inoperative	▪ Bulb failure ▪ Fuse(s) blown ▪ Circuit fault ▪ Lighting control switch fault ▪ Hazard warning lamp switch fault	Check the bulb and fuse condition. Check the turn signal indicator/hazard warning lamp circuits. Check the lighting control switch function. Check the hazard warning lamp switch function. Refer to the electrical guides. Check for DTCs indicating a turn signal indicator/hazard warning lamp circuit fault
Turn signal	▪ Incorrect	Check the bulb condition and rating. Check the turn

indicator(s)/hazard warning lamp(s) dim	bulb rating ▪ Circuit fault ▪ Lighting control switch fault ▪ Hazard warning lamp switch fault	signal indicator/hazard warning lamp circuits. Check the lighting control switch function. Check the hazard warning lamp switch function. Refer to the electrical guides
Turn signal indicator(s)/hazard warning lamp(s) stuck on	▪ Lighting control switch fault ▪ Hazard warning lamp switch fault ▪ Circuit fault	Check the turn signal indicator/hazard warning lamp circuits. Check the lighting control switch function. Check the hazard warning lamp switch function. Refer to the electrical guides. Check for DTCs indicating a turn signal indicator/hazard warning lamp circuit fault
Hazard warning lamp(s) inoperative	▪ Fuse(s) blown ▪ Lighting control switch inoperative ▪ Hazard warning lamp switch inoperative ▪ Circuit fault ▪ Instrument cluster fault	Check the fuse(s). Check the lighting control switch function. Check the hazard warning lamp switch function. Check the hazard warning lamp circuits. Refer to the electrical guides. Check for DTCs indicating an instrument cluster or CAN system fault
Cornering lamp(s) inoperative	▪ Bulb failure ▪ Fuse(s) blown ▪ Circuit fault	Check the bulb and fuse condition. Check cornering lamp circuits. Check the lighting control switch function. Refer to the electrical guides. Check for DTCs indicating a cornering lamp circuit fault

	▪ Lighting control switch fault	
Cornering lamp(s) dim	▪ Incorrect bulb rating ▪ Circuit fault ▪ Lighting control switch fault	Check the bulb condition and rating. Check the cornering lamp circuits. Check the lighting control switch function. Refer to the electrical guides
Cornering lamp(s) stuck on	▪ Lighting control switch fault ▪ Circuit fault	Check the cornering lamp circuits. Check the lighting control switch function. Refer to the electrical guides. Check for DTCs indicating a cornering lamp circuit fault

DTC INDEX

For a list of diagnostic trouble codes (DTCs) that could be logged on this vehicle, please refer to Section 100-00. REFER to: [Diagnostic Trouble Code Index - DTC: Body Control Module \(BCM\)](#) (100-00 General Information, Description and Operation).