

2016.0 RANGE ROVER (LG), 419-10

MULTIFUNCTION ELECTRONIC MODULES

DIAGNOSIS AND TESTING

PRINCIPLES OF OPERATION

For a detailed description of the keyless vehicle system, refer to the relevant description and operation sections in the workshop manual.

INSPECTION AND VERIFICATION

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.

NOTE:

Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.

1. Verify the customer concern

2. Visually inspect for obvious signs of damage and system integrity

Visual Inspection

MECHANICAL	ELECTRICAL
▪ Misaligned door(s), hood or luggage compartment lid ▪ Door latch(s) ▪ Actuating rod(s) ▪ Exterior door handle(s) ▪ Interior door handle(s) ▪ Door lock cylinder ▪ Cable(s) ▪ Door mirror - Powerfold ▪ Stop / start switch ▪ Luggage compartment lid exterior release switch	▪ Fuse(s) ▪ Wiring harness ▪ Electrical connector(s) ▪ Door lock actuator(s) ▪ Remote transmitter batteries ▪ Vehicle battery ▪ Remote transmitter (Key-fob or smart key) ▪ Keyless vehicle module ▪ Door lock switch(s) ▪ Body control module (BCM) ▪ Radio frequency (RF) receiver ▪ Immobilizer antenna unit (IAU) ▪ Keyless vehicle module (KVM) ▪ Instrument cluster (IC) ▪ Stop / start switch ▪ Hazard warning lamp switch ▪ Low frequency antenna (LF antenna)

3. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step
 4. If the cause is not visually evident, check for diagnostic trouble codes (DTCs) and refer to the DTC index
 5. Check DDW for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and carry out the recommendations as required
-

DTC INDEX

For a list of diagnostic trouble codes that could be logged on this vehicle, please refer to Section 100-00.

REFER to: [Diagnostic Trouble Code Index - DTC: Keyless Vehicle Module \(KVM\)](#) (100-00 General Information, Description and Operation).