

2016.0 RANGE ROVER (LG), 100-00

GENERAL INFORMATION

DESCRIPTION AND OPERATION

AUDIO AMPLIFIER MODULE (AAM)

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable.
Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.

NOTES:

- If a control module or a component is suspect and the vehicle remains under manufacturer warranty, refer to the Warranty Policy and Procedures manual, or determine if any prior approval programme is in operation, prior to the installation of a new module/component.
- Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system).
- When performing voltage or resistance tests, always use a digital multimeter accurate to three decimal places, and with an up-to-date calibration certificate. When testing resistance always take the resistance of the digital multimeter leads into account.
- Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.
- Inspect connectors for signs of water ingress, and pins for damage and/or corrosion.
- If DTCs are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always check for loose connections and corroded terminals.
- Check DDW for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and carry out the recommendations as required.

The table below lists all Diagnostic Trouble Codes (DTCs) that could be logged in the Audio Amplifier Module (AAM). For additional diagnosis and testing information, refer to the relevant Diagnosis and Testing section in the workshop manual.

For additional information, refer to: [Information and Entertainment System](#)

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B128A-11	Speaker #13 - Circuit short to ground	NOTE: Circuit reference - LH_SURR_POS / LH_SURR_NEG ▪ Rear left surround tweeter/mid-range speaker circuit short circuit to ground ▪ Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the rear left surround tweeter/mid-range speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left surround tweeter/mid-range speaker as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128A-12	Speaker #13 - Circuit short to battery	NOTE: Circuit reference - LH_SURR_POS / LH_SURR_NEG ▪ Rear left surround tweeter/mid-range speaker circuit short circuit to power ▪ Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only ▪ Refer to the

			electrical circuit diagrams and test the rear left surround tweeter/mid-range speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left surround tweeter/mid-range speaker as necessary ■ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128A-13	Speaker #13 - Circuit open	NOTE: Circuit reference - LH_SURR_POS / LH_SURR_NEG ■ Rear left surround tweeter/mid-range speaker circuit open circuit, high resistance ■ Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only ■ Refer to the electrical circuit diagrams and test the rear left surround tweeter/mid-range speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left surround tweeter/mid-range

			speaker as necessary Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128A-1A	Speaker #13 - Circuit resistance below threshold	NOTE: Circuit reference - LH_SURR_POS / LH_SURR_NEG - Rear left surround tweeter/mid-range speaker circuit short circuit - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the rear left surround tweeter/mid-range speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left surround tweeter/mid-range speaker as necessary - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128A-1E	Speaker #13 - Circuit resistance out of range		

			NOTE: Circuit reference - LH_SURR_POS / LH_SURR_NEG ▪ Rear left surround tweeter/mid-range speaker circuit open circuit, high resistance ▪ Rear left surround tweeter/mid-range speaker circuit short circuit ▪ Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the rear left surround tweeter/mid-range speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left surround tweeter/mid-range speaker as necessary ▪ Refer to the electrical circuit diagrams and test the rear left surround tweeter/mid-range speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left surround tweeter/mid-range speaker as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
--	--	--	---	--

B128B-11	Speaker #14 - Circuit short to ground	▪ Rear right surround tweeter/mid-range speaker circuit short circuit to ground ▪ Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the rear right surround tweeter/mid-range speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right surround tweeter/mid-range speaker as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128B-12	Speaker #14 - Circuit short to battery	▪ Rear right surround tweeter/mid-range speaker circuit short circuit to power ▪ Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the rear right surround

			tweeter/mid-range speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right surround tweeter/mid-range speaker as necessary Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128B-13	Speaker #14 - Circuit open	- Rear right surround tweeter/mid-range speaker circuit open circuit, high resistance - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the rear right surround tweeter/mid-range speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right surround tweeter/mid-range speaker as necessary - Using the manufacturer

			approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128B-1A	Speaker #14 - Circuit resistance below threshold	▪ Rear right surround tweeter/mid-range speaker circuit short circuit ▪ Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the rear right surround tweeter/mid-range speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right surround tweeter/mid-range speaker as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128B-1E	Speaker #14 - Circuit resistance out of range	▪ Rear right surround tweeter/mid-range speaker circuit open circuit, high resistance ▪ Rear right surround tweeter/mid-range speaker circuit short circuit ▪ Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only

			- Refer to the electrical circuit diagrams and test the rear right surround tweeter/mid-range speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right surround tweeter/mid-range speaker as necessary - Refer to the electrical circuit diagrams and test the rear right surround tweeter/mid-range speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right surround tweeter/mid-range speaker as necessary - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128C-11	Speaker #15 - Circuit short to ground	NOTE: Circuit reference - FRONT CENTRE MID POS / FRONT CENTRE MID NEG	

		- Front centre tweeter/mid-range speaker circuit short circuit to ground - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the front centre tweeter/mid-range speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front centre tweeter/mid-range speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128C-12	Speaker #15 - Circuit short to battery	NOTE: Circuit reference - FRONT CENTRE MID POS / FRONT CENTRE MID NEG - Front centre tweeter/mid-range speaker circuit short circuit to power - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only Refer to the electrical circuit diagrams and test the front centre tweeter/mid-range speaker circuit for short circuit to power. Using the

			manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front centre tweeter/mid-range speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128C-13	Speaker #15 - Circuit open	NOTE: Circuit reference - FRONT CENTRE MID POS / FRONT CENTRE MID NEG - Front centre tweeter/mid-range speaker circuit open circuit, high resistance - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the front centre tweeter/mid-range speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front centre tweeter/mid-range speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module

B128C-1A	Speaker #15 - Circuit resistance below threshold	NOTE: Circuit reference - FRONT CENTRE MID POS / FRONT CENTRE MID NEG - Front centre tweeter/mid-range speaker circuit short circuit - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the front centre tweeter/mid-range speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front centre tweeter/mid-range speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128C-1E	Speaker #15 - Circuit resistance out of range	NOTE: Circuit reference - FRONT CENTRE MID POS / FRONT CENTRE MID NEG - Front centre tweeter/mid-range speaker circuit open circuit, high resistance - Front centre mid-range speaker circuit short circuit - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only Refer to the electrical circuit diagrams and test the front centre tweeter/mid-range speaker circuit for open circuit, high resistance. Using the manufacturer

			approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front centre tweeter/mid-range speaker - Refer to the electrical circuit diagrams and test the front centre tweeter/mid-range speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front centre tweeter/mid-range speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128D-11	Speaker #16 - Circuit short to ground	NOTE: Circuit reference - FRONT CENTRE HIGH POS / FRONT CENTRE HIGH NEG - Front centre tweeter speaker circuit short circuit to ground - Audio amplifier module - Failure	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the front centre tweeter speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If

			the fault persists, install a new front centre tweeter speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128D-12	Speaker #16 - Circuit short to battery	NOTE: Circuit reference - FRONT CENTRE HIGH POS / FRONT CENTRE HIGH NEG - Front centre tweeter speaker circuit short circuit to power - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the front centre tweeter speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front centre tweeter speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128D-13	Speaker #16 - Circuit open		

		NOTE: Circuit reference - FRONT CENTRE HIGH POS / FRONT CENTRE HIGH NEG - Front centre tweeter speaker circuit open circuit, high resistance - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the front centre tweeter speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front centre tweeter speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128D-1A	Speaker #16 - Circuit resistance below threshold	NOTE: Circuit reference - FRONT CENTRE HIGH POS / FRONT CENTRE HIGH NEG - Front centre tweeter speaker circuit short circuit - Audio amplifier module - Failure	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the front centre tweeter speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the

			DTCs and retest. If the fault persists, install a new front centre tweeter speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128D-1E	Speaker #16 - Circuit resistance out of range	NOTE: Circuit reference - FRONT CENTRE HIGH POS / FRONT CENTRE HIGH NEG - Front centre tweeter speaker circuit open circuit, high resistance - Front centre tweeter speaker circuit short circuit - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the front centre tweeter speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front centre tweeter speaker - Refer to the electrical circuit diagrams and test the front centre tweeter speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front

			centre tweeter speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128E-11	Speaker #17 - Circuit short to ground	NOTE: Circuit reference - FL_SEAT_BACK_POS/RL_MID_POS FL_SEAT_BACK_NEG/RL_MID_NEG - Front left seat backrest tweeter speaker / mid-range speakers circuit short circuit to ground - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the front left seat backrest tweeter speaker / mid-range speakers circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left seat backrest tweeter speaker / mid-range speaker as necessary - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128E-12	Speaker #17 - Circuit short to battery		

		NOTE: Circuit reference - FL_SEAT_BACK_POS/RL_MID_POS FL_SEAT_BACK_NEG/RL_MID_NEG - Front left seat backrest tweeter speaker / mid-range speakers circuit short circuit to power - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the front left seat backrest tweeter speaker / mid-range speakers circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left seat backrest tweeter speaker / mid-range speaker as necessary - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128E-13	Speaker #17 - Circuit open	NOTE: Circuit reference - FL_SEAT_BACK_POS/RL_MID_POS FL_SEAT_BACK_NEG/RL_MID_NEG - Front left seat backrest tweeter speaker / mid-range speakers circuit open circuit, high resistance - Audio amplifier module - Failure	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the front left seat backrest tweeter speaker / mid-range speakers circuit for

			open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left seat backrest tweeter speaker / mid-range speaker as necessary Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128E-1A	Speaker #17 - Circuit resistance below threshold	NOTE: Circuit reference - FL_SEAT_BACK_POS/RL_MID_POS FL_SEAT_BACK_NEG/RL_MID_NEG - Front left seat backrest tweeter speaker / mid-range speakers circuit short circuit - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the front left seat backrest tweeter speaker / mid-range speakers circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left seat backrest tweeter speaker / mid-range speaker as necessary - Using the manufacturer approved diagnostic system, clear the

			DTCs and retest. If the fault persists, install a new audio amplifier module
B128E-1E	Speaker #17 - Circuit resistance out of range	NOTE: Circuit reference - FL_SEAT_BACK_POS/RL_MID_POS FL_SEAT_BACK_NEG/RL_MID_NEG - Front left seat backrest tweeter speaker / mid-range speakers circuit open circuit, high resistance - Front left seat backrest tweeter speaker / mid-range speakers circuit short circuit - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the front left seat backrest tweeter speaker / mid-range speakers circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left seat backrest tweeter speaker / mid-range speaker as necessary - Refer to the electrical circuit diagrams and test the front left seat backrest tweeter speaker / mid-range speakers circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left seat backrest tweeter speaker / mid-range speaker as necessary - Using the

			manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128F-11	Speaker #18 - Circuit short to ground	NOTE: Circuit reference - FR_SEAT_BACK_POS/RR_MID_POS FR_SEAT_BACK_NEG/RR_MID_NEG ▪ Front right seat backrest tweeter speaker / mid-range speakers circuit short circuit to ground ▪ Audio amplifier module - Failure	NOTE: Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the front right seat backrest tweeter speaker / mid-range speakers circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right seat backrest tweeter speaker / mid-range speaker as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128F-12	Speaker #18 - Circuit short to battery		

		NOTE: Circuit reference - FR_SEAT_BACK_POS/RR_MID_POS FR_SEAT_BACK_NEG/RR_MID_NEG - Front right seat backrest tweeter speaker / mid-range speakers circuit short circuit to power - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the front right seat backrest tweeter speaker / mid-range speakers circuit for short circuit to power. If the fault persists, install a new front right seat backrest tweeter speaker / mid-range speaker as necessary - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128F-13	Speaker #18 - Circuit open	NOTE: Circuit reference - FR_SEAT_BACK_POS/RR_MID_POS FR_SEAT_BACK_NEG/RR_MID_NEG - Front right seat backrest tweeter speaker / mid-range speakers circuit open circuit, high resistance - Audio amplifier module - Failure	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the front right seat backrest tweeter speaker / mid-range speakers circuit for open circuit, high resistance. If the fault persists, install a new front right seat backrest

			tweeter speaker / mid-range speaker as necessary Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128F-1A	Speaker #18 - Circuit resistance below threshold	NOTE: Circuit reference - FR_SEAT_BACK_POS/RR_MID_POS FR_SEAT_BACK_NEG/RR_MID_NEG - Front right seat backrest tweeter speaker / mid-range speakers circuit short circuit - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the front right seat backrest tweeter speaker / mid-range speakers circuit for short circuit. If the fault persists, install a new front right seat backrest tweeter speaker / mid-range speaker as necessary - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B128F-1E	Speaker #18 - Circuit resistance out of range	NOTE: Circuit reference - FR_SEAT_BACK_POS/RR_MID_POS FR_SEAT_BACK_NEG/RR_MID_NEG	NOTE: Super Premium audio system only

		▪ Front right seat backrest tweeter speaker / mid-range speakers circuit open circuit, high resistance ▪ Front right seat backrest tweeter speaker / mid-range speakers circuit short circuit ▪ Audio amplifier module - Failure	▪ Refer to the electrical circuit diagrams and test the front right seat backrest tweeter speaker / mid-range speakers circuit for open circuit, high resistance. If the fault persists, install a new front right seat backrest tweeter speaker / mid-range speaker as necessary ▪ Refer to the electrical circuit diagrams and test the front right seat backrest tweeter speaker / mid-range speakers circuit for short circuit. If the fault persists, install a new front right seat backrest tweeter speaker / mid-range speaker as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1290-11	Speaker #19 - Circuit short to ground	NOTE: Circuit reference - LEFT_REAR_HIGH_POS / LEFT_REAR_HIGH_NEG ▪ Rear left door tweeter speaker circuit short circuit to ground ▪ Audio amplifier module - Failure	NOTE: Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the rear left door

			tweeter speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door tweeter speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1290-12	Speaker #19 - Circuit short to battery	NOTE: Circuit reference - LEFT_REAR_HIGH_POS / LEFT_REAR_HIGH_NEG - Rear left door tweeter speaker circuit short circuit to power - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the rear left door tweeter speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door tweeter speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists,

			install a new audio amplifier module
B1290-13	Speaker #19 - Circuit open	NOTE: Circuit reference - LEFT_REAR_HIGH_POS / LEFT_REAR_HIGH_NEG ▪ Rear left door tweeter speaker circuit open circuit, high resistance ▪ Audio amplifier module - Failure	NOTE: Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the rear left door tweeter speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door tweeter speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1290-1A	Speaker #19 - Circuit resistance below threshold	NOTE: Circuit reference - LEFT_REAR_HIGH_POS / LEFT_REAR_HIGH_NEG ▪ Rear left door tweeter speaker circuit short circuit ▪ Audio amplifier module - Failure	NOTE: Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the rear left door tweeter speaker circuit for short

			circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door tweeter speaker ■ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1290-1E	Speaker #19 - Circuit resistance out of range	NOTE: Circuit reference - LEFT_REAR_HIGH_POS / LEFT_REAR_HIGH_NEG ■ Rear left door tweeter speaker circuit open circuit, high resistance ■ Rear left door tweeter speaker circuit short circuit ■ Audio amplifier module - Failure	NOTE: Super Premium audio system only ■ Refer to the electrical circuit diagrams and test the rear left door tweeter speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door tweeter speaker ■ Refer to the electrical circuit diagrams and test the rear left door tweeter speaker circuit for short circuit. Using the manufacturer approved diagnostic

			system, clear the DTCs and retest. If the fault persists, install a new rear left door tweeter speaker ■ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1291-11	Speaker #20 - Circuit short to ground	NOTE: Circuit reference - RIGHT_REAR_HIGH_POS / RIGHT_REAR_HIGH_NEG ■ Rear right door tweeter speaker circuit short circuit to ground ■ Audio amplifier module - Failure	NOTE: Super Premium audio system only ■ Refer to the electrical circuit diagrams and test the rear right door tweeter speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right door tweeter speaker ■ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1291-12	Speaker #20 - Circuit short to		

battery

NOTE:

Circuit reference -
RIGHT_REAR_HIGH_POS /
RIGHT_REAR_HIGH_NEG

- Rear right door tweeter speaker circuit short circuit to power
- Audio amplifier module - Failure

NOTE:

Super Premium
audio system
only

- Refer to the electrical circuit diagrams and test the rear right door tweeter speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right door tweeter speaker
- Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module

B1291-
13

Speaker #20 -
Circuit open

NOTE:

Circuit reference -
RIGHT_REAR_HIGH_POS /
RIGHT_REAR_HIGH_NEG

- Rear right door tweeter speaker circuit open circuit, high resistance
- Audio amplifier module - Failure

NOTE:

Super Premium
audio system
only

- Refer to the electrical circuit diagrams and test the rear right door tweeter speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic

			system, clear the DTCs and retest. If the fault persists, install a new rear right door tweeter speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1291-1A	Speaker #20 - Circuit resistance below threshold	NOTE: Circuit reference - RIGHT_REAR_HIGH_POS / RIGHT_REAR_HIGH_NEG - Rear right door tweeter speaker circuit short circuit - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the rear right door tweeter speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right door tweeter speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1291-1E	Speaker #20 - Circuit resistance out of range		

		NOTE: Circuit reference - RIGHT_REAR_HIGH_POS / RIGHT_REAR_HIGH_NEG ▪ Rear right door tweeter speaker circuit open circuit, high resistance ▪ Rear right door tweeter speaker circuit short circuit ▪ Audio amplifier module - Failure	NOTE: Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the rear right door tweeter speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right door tweeter speaker ▪ Refer to the electrical circuit diagrams and test the rear right door tweeter speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right door tweeter speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1292-11	Speaker #21 - Circuit short to ground		

		NOTE: Circuit reference - FRONT_LEFT_HEADLINING_POS / FRONT_LEFT_HEADLINING_NEG - Front left headliner speaker circuit short circuit to ground - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the front left headliner speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left headliner speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1292-12	Speaker #21 - Circuit short to battery	NOTE: Circuit reference - FRONT_LEFT_HEADLINING_POS / FRONT_LEFT_HEADLINING_NEG - Front left headliner speaker circuit short circuit to power - Audio amplifier module - Failure	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the front left headliner speaker circuit for short circuit to power. Using the manufacturer approved diagnostic

			system, clear the DTCs and retest. If the fault persists, install a new front left headliner speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1292-13	Speaker #21 - Circuit open	NOTE: Circuit reference - FRONT_LEFT_HEADLINING_POS / FRONT_LEFT_HEADLINING_NEG - Front left headliner speaker circuit open circuit, high resistance - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the front left headliner speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left headliner speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1292-1A	Speaker #21 - Circuit resistance		

below threshold

NOTE:

Circuit reference -
FRONT_LEFT_HEADLINING_POS /
FRONT_LEFT_HEADLINING_NEG

- Front left headliner speaker circuit short circuit
- Audio amplifier module - Failure

NOTE:

Super Premium
audio system
only

- Refer to the electrical circuit diagrams and test the front left headliner speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left headliner speaker
- Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module

B1292-
1E

Speaker #21 -
Circuit resistance
out of range

NOTE:

Circuit reference -
FRONT_LEFT_HEADLINING_POS /
FRONT_LEFT_HEADLINING_NEG

- Front left headliner speaker circuit open circuit, high resistance
- Front left headliner speaker circuit short circuit
- Audio amplifier module - Failure

NOTE:

Super Premium
audio system
only

- Refer to the electrical circuit diagrams and test the front left headliner speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the

			DTCs and retest. If the fault persists, install a new front left headliner speaker - Refer to the electrical circuit diagrams and test the front left headliner speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left headliner speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1293-11	Speaker #22 - Circuit short to ground	NOTE: Circuit reference - FRONT_RIGHT_HEADLINING_POS / FRONT_RIGHT_HEADLINING_NEG - Front right headliner speaker circuit short circuit to ground - Audio amplifier module - Failure	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the front right headliner speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front

			right headliner speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1293-12	Speaker #22 - Circuit short to battery	NOTE: Circuit reference - FRONT_RIGHT_HEADLINING_POS / FRONT_RIGHT_HEADLINING_NEG - Front right headliner speaker circuit short circuit to power - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the front right headliner speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right headliner speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1293-13	Speaker #22 - Circuit open		

		NOTE: Circuit reference - FRONT_RIGHT_HEADLINING_POS / FRONT_RIGHT_HEADLINING_NEG - Front right headliner speaker circuit open circuit, high resistance - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the front right headliner speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right headliner speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1293-1A	Speaker #22 - Circuit resistance below threshold	NOTE: Circuit reference - FRONT_RIGHT_HEADLINING_POS / FRONT_RIGHT_HEADLINING_NEG - Front right headliner speaker circuit short circuit - Audio amplifier module - Failure	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the front right headliner speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the

			DTCs and retest. If the fault persists, install a new front right headliner speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1293-1E	Speaker #22 - Circuit resistance out of range	NOTE: Circuit reference - FRONT_RIGHT_HEADLINING_POS / FRONT_RIGHT_HEADLINING_NEG - Front right headliner speaker circuit open circuit, high resistance - Front right headliner speaker circuit short circuit - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the front right headliner speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right headliner speaker - Refer to the electrical circuit diagrams and test the front right headliner speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front

			right headliner speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1294-11	Speaker #23 - Circuit short to ground	NOTE: Circuit reference - REAR_LEFT_HEADLINING_POS / REAR_LEFT_HEADLINING_NEG - Rear left headliner speaker circuit short circuit to ground - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the rear left headliner speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left headliner speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1294-12	Speaker #23 - Circuit short to battery	NOTE: Circuit reference - REAR_LEFT_HEADLINING_POS / REAR_LEFT_HEADLINING_NEG	NOTE: Super Premium audio system only

		▪ Rear left headliner speaker circuit short circuit to power ▪ Audio amplifier module - Failure	▪ Refer to the electrical circuit diagrams and test the rear left headliner speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left headliner speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1294-13	Speaker #23 - Circuit open	NOTE: Circuit reference - REAR_LEFT_HEADLINING_POS / REAR_LEFT_HEADLINING_NEG ▪ Rear left headliner speaker circuit open circuit, high resistance ▪ Audio amplifier module - Failure	NOTE: Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the rear left headliner speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left headliner speaker ▪ Using the manufacturer approved diagnostic

			system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1294-1A	Speaker #23 - Circuit resistance below threshold	NOTE: Circuit reference - REAR_LEFT_HEADLINING_POS / REAR_LEFT_HEADLINING_NEG ▪ Rear left headliner speaker circuit short circuit ▪ Audio amplifier module - Failure	NOTE: Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the rear left headliner speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left headliner speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1294-1E	Speaker #23 - Circuit resistance out of range	NOTE: Circuit reference - REAR_LEFT_HEADLINING_POS / REAR_LEFT_HEADLINING_NEG ▪ Rear left headliner speaker circuit open circuit, high resistance ▪ Rear left headliner speaker circuit short circuit	NOTE: Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the rear left headliner speaker

		Audio amplifier module - Failure	circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left headliner speaker - Refer to the electrical circuit diagrams and test the rear left headliner speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left headliner speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1295-11	Speaker #24 - Circuit short to ground	NOTE: Circuit reference - REAR_RIGHT_HEADLINING_POS / REAR_RIGHT_HEADLINING_NEG - Rear right headliner speaker circuit short circuit to ground - Audio amplifier module - Failure	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the rear right headliner speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic

			system, clear the DTCs and retest. If the fault persists, install a new rear right headliner speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1295-12	Speaker #24 - Circuit short to battery	NOTE: Circuit reference - REAR_RIGHT_HEADLINING_POS / REAR_RIGHT_HEADLINING_NEG - Rear right headliner speaker circuit short circuit to power - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the rear right headliner speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right headliner speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1295-13	Speaker #24 - Circuit open		

		NOTE: Circuit reference - REAR_RIGHT_HEADLINING_POS / REAR_RIGHT_HEADLINING_NEG ▪ Rear right headliner speaker circuit open circuit, high resistance ▪ Audio amplifier module - Failure	NOTE: Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the rear right headliner speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right headliner speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1295-1A	Speaker #24 - Circuit resistance below threshold	NOTE: Circuit reference - REAR_RIGHT_HEADLINING_POS / REAR_RIGHT_HEADLINING_NEG ▪ Rear right headliner speaker circuit short circuit ▪ Audio amplifier module - Failure	NOTE: Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the rear right headliner speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the

			DTCs and retest. If the fault persists, install a new rear right headliner speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1295-1E	Speaker #24 - Circuit resistance out of range	NOTE: Circuit reference - REAR_RIGHT_HEADLINING_POS / REAR_RIGHT_HEADLINING_NEG - Rear right headliner speaker circuit open circuit, high resistance - Rear right headliner speaker circuit short circuit - Audio amplifier module - Failure	NOTE: Super Premium audio system only - Refer to the electrical circuit diagrams and test the rear right headliner speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right headliner speaker - Refer to the electrical circuit diagrams and test the rear right headliner speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear

			right headliner speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1297-01	Digital Headphone Module - General electrical failure	NOTE: Circuit reference - WHITEFIRE_POWER / WHITEFIRE_GND Headphone transmitter circuit short circuit to ground, short circuit to power, open circuit, high resistance	NOTE: Digital headphones (Whitefire) only Refer to the electrical circuit diagrams and test the headphone transmitter circuit for short circuit to ground, short circuit to power, open circuit, high resistance
B1297-13	Digital Headphone Module - Circuit open	NOTE: Circuit reference - WHITEFIRE_POWER / WHITEFIRE_GND Headphone transmitter circuit open circuit, high resistance	NOTE: Digital headphones (Whitefire) only Refer to the electrical circuit diagrams and test the headphone transmitter circuit for open circuit, high resistance
B13E4-11	Microphone 1 - Circuit short to ground		

		NOTE: Circuit reference - FRONT_LEFT_HEADLING_MIC_POS / FRONT_LEFT_HEADLING_MIC_NEG / FRONT_LEFT_HEADLING_MIC_SCR Microphone 1 circuit short circuit to ground	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the microphone 1 circuit for short circuit to ground
B13E4-15	Microphone 1 - Circuit short to battery or open	NOTE: Circuit reference - FRONT_LEFT_HEADLING_MIC_POS / FRONT_LEFT_HEADLING_MIC_NEG / FRONT_LEFT_HEADLING_MIC_SCR Microphone 1 circuit short circuit to power, open circuit, high resistance	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the microphone 1 circuit for short circuit to power, open circuit, high resistance
B13E4-1A	Microphone 1 - Circuit resistance below threshold	NOTE: Circuit reference - FRONT_LEFT_HEADLING_MIC_POS / FRONT_LEFT_HEADLING_MIC_NEG / FRONT_LEFT_HEADLING_MIC_SCR Microphone 1 circuit short circuit	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the microphone 1 circuit for short circuit
B13E5-11	Microphone 2 - Circuit short to		

	ground	NOTE: Circuit reference - FRONT_RIGHT_HEADLING_MIC_POS / FRONT_RIGHT_HEADLING_MIC_NEG / FRONT_RIGHT_HEADLING_MIC_SCR Microphone 2 circuit short circuit to ground	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the microphone 2 circuit for short circuit to ground
B13E5-15	Microphone 2 - Circuit short to battery or open	NOTE: Circuit reference - FRONT_RIGHT_HEADLING_MIC_POS / FRONT_RIGHT_HEADLING_MIC_NEG / FRONT_RIGHT_HEADLING_MIC_SCR Microphone 2 circuit short circuit to power, open circuit, high resistance	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the microphone 2 circuit for short circuit to power, open circuit, high resistance
B13E5-1A	Microphone 2 - Circuit resistance below threshold	NOTE: Circuit reference - FRONT_RIGHT_HEADLING_MIC_POS / FRONT_RIGHT_HEADLING_MIC_NEG / FRONT_RIGHT_HEADLING_MIC_SCR Microphone 2 circuit short circuit	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the microphone 2 circuit for short circuit
B13E6-11	Microphone 3 - Circuit short to		

	ground	NOTE: Circuit reference - REAR_LEFT_HEADLING_MIC_POS / REAR_LEFT_HEADLING_MIC_NEG / REAR_LEFT_HEADLING_MIC_SCR Microphone 3 circuit short circuit to ground	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the microphone 3 circuit for short circuit to ground
B13E6-15	Microphone 3 - Circuit short to battery or open	NOTE: Circuit reference - REAR_LEFT_HEADLING_MIC_POS / REAR_LEFT_HEADLING_MIC_NEG / REAR_LEFT_HEADLING_MIC_SCR Microphone 3 circuit short circuit to power, open circuit, high resistance	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the microphone 3 circuit for short circuit to power, open circuit, high resistance
B13E6-1A	Microphone 3 - Circuit resistance below threshold	NOTE: Circuit reference - REAR_LEFT_HEADLING_MIC_POS / REAR_LEFT_HEADLING_MIC_NEG / REAR_LEFT_HEADLING_MIC_SCR Microphone 3 circuit short circuit	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the microphone 3 circuit for short circuit
B13E7-11	Microphone 4 - Circuit short to		

	ground	NOTE: Circuit reference - REAR_RIGHT_HEADLING_MIC_POS / REAR_RIGHT_HEADLING_MIC_NEG / REAR_RIGHT_HEADLING_MIC_SCR Microphone 4 circuit short circuit to ground	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the microphone 4 circuit for short circuit to ground
B13E7-15	Microphone 4 - Circuit short to battery or open	NOTE: Circuit reference - REAR_RIGHT_HEADLING_MIC_POS / REAR_RIGHT_HEADLING_MIC_NEG / REAR_RIGHT_HEADLING_MIC_SCR Microphone 4 circuit short circuit to power, open circuit, high resistance	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the microphone 4 circuit for short circuit to power, open circuit, high resistance
B13E7-1A	Microphone 4 - Circuit resistance below threshold	NOTE: Circuit reference - REAR_RIGHT_HEADLING_MIC_POS / REAR_RIGHT_HEADLING_MIC_NEG / REAR_RIGHT_HEADLING_MIC_SCR Microphone 4 circuit short circuit	NOTE: Super Premium audio system only Refer to the electrical circuit diagrams and test the microphone 4 circuit for short circuit
B1A01-11	Speaker #1 - Circuit short to		Refer to the electrical circuit

	ground	NOTE: Circuit reference - LEFT_FRONT_HIGH_POS / LEFT_FRONT_HIGH_NEG ▪ Front left door tweeter speaker circuit short circuit to ground ▪ Audio amplifier module - Failure	diagrams and test the front left door tweeter speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door tweeter speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A01-12	Speaker #1 - Circuit short to battery	NOTE: Circuit reference - LEFT_FRONT_HIGH_POS / LEFT_FRONT_HIGH_NEG ▪ Front left door tweeter speaker circuit short circuit to power ▪ Audio amplifier module - Failure	▪ Refer to the electrical circuit diagrams and test the front left door tweeter speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door tweeter speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A01-13	Speaker #1 - Circuit open		▪ Refer to the electrical circuit diagrams and test

		NOTE: Circuit reference - LEFT_FRONT_HIGH_POS / LEFT_FRONT_HIGH_NEG - Front left door tweeter speaker circuit open circuit, high resistance - Audio amplifier module - Failure	the front left door tweeter speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door tweeter speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A01-1A	Speaker #1 - Circuit resistance below threshold	NOTE: Circuit reference - LEFT_FRONT_HIGH_POS / LEFT_FRONT_HIGH_NEG - Front left door tweeter speaker circuit short circuit - Audio amplifier module - Failure	- Refer to the electrical circuit diagrams and test the front left door tweeter speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door tweeter speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A01-1E	Speaker #1 - Circuit resistance out of range		Refer to the electrical circuit diagrams and test

		NOTE: Circuit reference - LEFT_FRONT_HIGH_POS / LEFT_FRONT_HIGH_NEG - Front left door tweeter speaker circuit open circuit, high resistance - Front left door tweeter speaker circuit short circuit - Audio amplifier module - Failure	the front left door tweeter speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door tweeter speaker - Refer to the electrical circuit diagrams and test the front left door tweeter speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door tweeter speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A02-11	Speaker #2 - Circuit short to ground	NOTE: Circuit reference - LEFT_FRONT_LOW_POS / LEFT_FRONT_LOW_NEG - Front left door bass speaker circuit short circuit to ground - Audio amplifier module - Failure	Refer to the electrical circuit diagrams and test the front left door bass speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front

			left door bass speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A02-12	Speaker #2 - Circuit short to battery	NOTE: Circuit reference - LEFT_FRONT_LOW_POS / LEFT_FRONT_LOW_NEG - Front left door bass speaker circuit short circuit to power - Audio amplifier module - Failure	- Refer to the electrical circuit diagrams and test the front left door bass speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door bass speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A02-13	Speaker #2 - Circuit open	NOTE: Circuit reference - LEFT_FRONT_LOW_POS / LEFT_FRONT_LOW_NEG - Front left door bass speaker circuit open circuit, high resistance - Audio amplifier module - Failure	Refer to the electrical circuit diagrams and test the front left door bass speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door bass speaker

			Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A02-1A	Speaker #2 - Circuit resistance below threshold	NOTE: Circuit reference - LEFT_FRONT_LOW_POS / LEFT_FRONT_LOW_NEG - Front left door bass speaker circuit short circuit - Audio amplifier module - Failure	- Refer to the electrical circuit diagrams and test the front left door bass speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door bass speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A02-1E	Speaker #2 - Circuit resistance out of range	NOTE: Circuit reference - LEFT_FRONT_LOW_POS / LEFT_FRONT_LOW_NEG - Front left door bass speaker circuit open circuit, high resistance - Front left door bass speaker circuit short circuit - Audio amplifier module - Failure	- Refer to the electrical circuit diagrams and test the front left door bass speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door bass speaker - Refer to the electrical circuit diagrams and test

			the front left door bass speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door bass speaker ■ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A03-11	Speaker #3 - Circuit short to ground	NOTE: Circuit reference - RIGHT_FRONT_HIGH_POS / RIGHT_FRONT_HIGH_NEG ■ Front right door tweeter speaker circuit short circuit to ground ■ Audio amplifier module - Failure	■ Refer to the electrical circuit diagrams and test the front right door tweeter speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door tweeter speaker ■ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A03-12	Speaker #3 - Circuit short to battery		■ Refer to the electrical circuit diagrams and test the front right door

		NOTE: Circuit reference - RIGHT_FRONT_HIGH_POS / RIGHT_FRONT_HIGH_NEG - Front right door tweeter speaker circuit short circuit to power - Audio amplifier module - Failure	tweeter speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door tweeter speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A03-13	Speaker #3 - Circuit open	NOTE: Circuit reference - RIGHT_FRONT_HIGH_POS / RIGHT_FRONT_HIGH_NEG - Front right door tweeter speaker circuit open circuit, high resistance - Audio amplifier module - Failure	- Refer to the electrical circuit diagrams and test the front right door tweeter speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door tweeter speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A03-1A	Speaker #3 - Circuit resistance below threshold		Refer to the electrical circuit diagrams and test the front right door

		NOTE: Circuit reference - RIGHT_FRONT_HIGH_POS / RIGHT_FRONT_HIGH_NEG ▪ Front right door tweeter speaker circuit short circuit ▪ Audio amplifier module - Failure	tweeter speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door tweeter speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A03-1E	Speaker #3 - Circuit resistance out of range	NOTE: Circuit reference - RIGHT_FRONT_HIGH_POS / RIGHT_FRONT_HIGH_NEG ▪ Front right door tweeter speaker circuit open circuit, high resistance ▪ Front right door tweeter speaker circuit short circuit ▪ Audio amplifier module - Failure	▪ Refer to the electrical circuit diagrams and test the front right door tweeter speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door tweeter speaker ▪ Refer to the electrical circuit diagrams and test the front right door tweeter speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front

			right door tweeter speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A04-11	Speaker #4 - Circuit short to ground	NOTE: Circuit reference - RIGHT_FRONT_LOW_POS / RIGHT_FRONT_LOW_NEG - Front right door bass speaker circuit short circuit to ground - Audio amplifier module - Failure	- Refer to the electrical circuit diagrams and test the front right door bass speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door bass speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A04-12	Speaker #4 - Circuit short to battery	NOTE: Circuit reference - RIGHT_FRONT_LOW_POS / RIGHT_FRONT_LOW_NEG - Front right door bass speaker circuit short circuit to power - Audio amplifier module - Failure	Refer to the electrical circuit diagrams and test the front right door bass speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door bass speaker

			Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A04-13	Speaker #4 - Circuit open	NOTE: Circuit reference - RIGHT_FRONT_LOW_POS / RIGHT_FRONT_LOW_NEG - Front right door bass speaker circuit open circuit, high resistance - Audio amplifier module - Failure	- Refer to the electrical circuit diagrams and test the front right door bass speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door bass speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A04-1A	Speaker #4 - Circuit resistance below threshold	NOTE: Circuit reference - RIGHT_FRONT_LOW_POS / RIGHT_FRONT_LOW_NEG - Front right door bass speaker circuit short circuit - Audio amplifier module - Failure	- Refer to the electrical circuit diagrams and test the front right door bass speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door bass speaker - Using the manufacturer approved diagnostic

			system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A04-1E	Speaker #4 - Circuit resistance out of range	NOTE: Circuit reference - RIGHT_FRONT_LOW_POS / RIGHT_FRONT_LOW_NEG - Front right door bass speaker circuit open circuit, high resistance - Front right door bass speaker circuit short circuit - Audio amplifier module - Failure	- Refer to the electrical circuit diagrams and test the front right door bass speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door bass speaker - Refer to the electrical circuit diagrams and test the front right door bass speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door bass speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A05-11	Speaker #5 - Circuit short to ground		

		NOTE: Circuit reference - LEFT_REAR_MID_POS / LEFT_REAR_MID_NEG ▪ Rear left door tweeter/mid-range speaker circuit short circuit to ground ▪ Audio amplifier module - Failure	NOTE: A coaxial tweeter speaker is connected in parallel with the mid-range speaker on all except the Super Premium audio system ▪ Refer to the electrical circuit diagrams and test the rear left door tweeter/mid-range speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door tweeter/mid-range speaker as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A05-12	Speaker #5 - Circuit short to battery	NOTE: Circuit reference - LEFT_REAR_MID_POS / LEFT_REAR_MID_NEG ▪ Rear left door tweeter/mid-range speaker circuit short circuit to power	

		Audio amplifier module - Failure	NOTE: A coaxial tweeter speaker is connected in parallel with the mid-range speaker on all except the Super Premium audio system - Refer to the electrical circuit diagrams and test the rear left door tweeter/mid-range speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door tweeter/mid-range speaker as necessary - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A05-13	Speaker #5 - Circuit open	NOTE: Circuit reference - LEFT_REAR_MID_POS / LEFT_REAR_MID_NEG Rear left door tweeter/mid-range speaker circuit open circuit, high resistance	

		Audio amplifier module - Failure	NOTE: A coaxial tweeter speaker is connected in parallel with the mid-range speaker on all except the Super Premium audio system - Refer to the electrical circuit diagrams and test the rear left door tweeter/mid-range speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door tweeter/mid-range speaker as necessary - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A05-1A	Speaker #5 - Circuit resistance below threshold	NOTE: Circuit reference - LEFT_REAR_MID_POS / LEFT_REAR_MID_NEG Rear left door tweeter/mid-range speaker circuit short circuit	

		Audio amplifier module - Failure	NOTE: A coaxial tweeter speaker is connected in parallel with the mid-range speaker on all except the Super Premium audio system - Refer to the electrical circuit diagrams and test the rear left door tweeter/mid-range speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door tweeter/mid-range speaker as necessary - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A05-1E	Speaker #5 - Circuit resistance out of range	NOTE: Circuit reference - LEFT_REAR_MID_POS / LEFT_REAR_MID_NEG Rear left door tweeter/mid-range speaker circuit open circuit, high resistance	

- Rear left door tweeter/mid-range speaker circuit short circuit
- Audio amplifier module - Failure

NOTE:

A coaxial tweeter speaker is connected in parallel with the mid-range speaker on all except the Super Premium audio system

- Refer to the electrical circuit diagrams and test the rear left door tweeter/mid-range speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door tweeter/mid-range speaker as necessary
- Refer to the electrical circuit diagrams and test the rear left door tweeter/mid-range speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door tweeter/mid-range speaker as necessary
- Using the manufacturer approved diagnostic system, clear the

			DTCs and retest. If the fault persists, install a new audio amplifier module
B1A06-11	Speaker #6 - Circuit short to ground	NOTE: Circuit reference - LEFT_REAR_LOW_POS / LEFT_REAR_LOW_NEG ▪ Rear left door bass speaker circuit short circuit to ground ▪ Audio amplifier module - Failure	▪ Refer to the electrical circuit diagrams and test the rear left door bass speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door bass speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A06-12	Speaker #6 - Circuit short to battery	NOTE: Circuit reference - LEFT_REAR_LOW_POS / LEFT_REAR_LOW_NEG ▪ Rear left door bass speaker circuit short circuit to power ▪ Audio amplifier module - Failure	▪ Refer to the electrical circuit diagrams and test the rear left door bass speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door bass speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module

B1A06-13	Speaker #6 - Circuit open	NOTE: Circuit reference - LEFT_REAR_LOW_POS / LEFT_REAR_LOW_NEG ■ Rear left door bass speaker circuit open circuit, high resistance ■ Audio amplifier module - Failure	■ Refer to the electrical circuit diagrams and test the rear left door bass speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door bass speaker ■ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A06-1A	Speaker #6 - Circuit resistance below threshold	NOTE: Circuit reference - LEFT_REAR_LOW_POS / LEFT_REAR_LOW_NEG ■ Rear left door bass speaker circuit short circuit ■ Audio amplifier module - Failure	■ Refer to the electrical circuit diagrams and test the rear left door bass speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door bass speaker ■ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A06-1E	Speaker #6 - Circuit resistance out of range		■ Refer to the electrical circuit diagrams and test the rear left door

		NOTE: Circuit reference - LEFT_REAR_LOW_POS / LEFT_REAR_LOW_NEG ▪ Rear left door bass speaker circuit open circuit, high resistance ▪ Rear left door bass speaker circuit short circuit ▪ Audio amplifier module - Failure	bass speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door bass speaker ▪ Refer to the electrical circuit diagrams and test the rear left door bass speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left door bass speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A07-11	Speaker #7 - Circuit short to battery	NOTE: Circuit reference - RIGHT_REAR_MID_POS / RIGHT_REAR_MID_NEG ▪ Rear right door tweeter/mid-range speaker circuit short circuit to ground ▪ Audio amplifier module - Failure	NOTE: A coaxial tweeter speaker is connected in parallel with the mid-range speaker on all except the Super Premium audio system ▪ Refer to the electrical circuit diagrams and test

			the rear right door tweeter/mid-range speaker circuit for short circuit ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right door tweeter/mid-range speaker as necessary ■ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A07-12	Speaker #7 - Circuit short to battery	NOTE: Circuit reference - RIGHT_REAR_MID_POS / RIGHT_REAR_MID_NEG ■ Rear right door tweeter/mid-range speaker circuit short circuit to power ■ Audio amplifier module - Failure	NOTE: A coaxial tweeter speaker is connected in parallel with the mid-range speaker on all except the Super Premium audio system ■ Refer to the electrical circuit diagrams and test the rear right door tweeter/mid-range speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear

			right door tweeter/mid-range speaker as necessary Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A07-13	Speaker #7 - Circuit open	NOTE: Circuit reference - RIGHT_REAR_MID_POS / RIGHT_REAR_MID_NEG - Rear right door tweeter/mid-range speaker circuit open circuit, high resistance - Audio amplifier module - Failure	NOTE: A coaxial tweeter speaker is connected in parallel with the mid-range speaker on all except the Super Premium audio system - Refer to the electrical circuit diagrams and test the rear right door tweeter/mid-range speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right door tweeter/mid-range speaker as necessary - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio

			amplifier module
B1A07-1A	Speaker #7 - Circuit resistance below threshold	NOTE: Circuit reference - RIGHT_REAR_MID_POS / RIGHT_REAR_MID_NEG ▪ Rear right door tweeter/mid-range speaker circuit short circuit ▪ Audio amplifier module - Failure	NOTE: A coaxial tweeter speaker is connected in parallel with the mid-range speaker on all except the Super Premium audio system ▪ Refer to the electrical circuit diagrams and test the rear right door tweeter/mid-range speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right door tweeter/mid-range speaker as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A07-1E	Speaker #7 - Circuit resistance out of range	NOTE: Circuit reference - RIGHT_REAR_MID_POS / RIGHT_REAR_MID_NEG	

- Rear right door tweeter/mid-range speaker circuit open circuit, high resistance
- Rear right door tweeter/mid-range speaker circuit short circuit
- Audio amplifier module - Failure

NOTE:

A coaxial tweeter speaker is connected in parallel with the mid-range speaker on all except the Super Premium audio system

- Refer to the electrical circuit diagrams and test the rear right door tweeter/mid-range speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right door tweeter/mid-range speaker as necessary
- Refer to the electrical circuit diagrams and test the rear right door tweeter/mid-range speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right door tweeter/mid-range speaker as necessary
- Using the manufacturer approved diagnostic system, clear the

			DTCs and retest. If the fault persists, install a new audio amplifier module
B1A08-11	Speaker #8 - Circuit short to ground	NOTE: Circuit reference - RIGHT_REAR_LOW_POS / RIGHT_REAR_LOW_NEG ▪ Rear right door bass speaker circuit short circuit to ground ▪ Audio amplifier module - Failure	▪ Refer to the electrical circuit diagrams and test the rear right door bass speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right door bass speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A08-12	Speaker #8 - Circuit short to battery	NOTE: Circuit reference - RIGHT_REAR_LOW_POS / RIGHT_REAR_LOW_NEG ▪ Rear right door bass speaker circuit short circuit to power ▪ Audio amplifier module - Failure	▪ Refer to the electrical circuit diagrams and test the rear right door bass speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right door bass speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio

			amplifier module
B1A08-13	Speaker #8 - Circuit open	NOTE: Circuit reference - RIGHT_REAR_LOW_POS / RIGHT_REAR_LOW_NEG ▪ Rear right door bass speaker circuit open circuit, high resistance ▪ Audio amplifier module - Failure	▪ Refer to the electrical circuit diagrams and test the rear right door bass speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right door bass speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A08-1A	Speaker #8 - Circuit resistance below threshold	NOTE: Circuit reference - RIGHT_REAR_LOW_POS / RIGHT_REAR_LOW_NEG ▪ Rear right door bass speaker circuit short circuit ▪ Audio amplifier module - Failure	▪ Refer to the electrical circuit diagrams and test the rear right door bass speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right door bass speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module

B1A08-1E	Speaker #8 - Circuit resistance out of range	NOTE: Circuit reference - RIGHT_REAR_LOW_POS / RIGHT_REAR_LOW_NEG ▪ Rear right door bass speaker circuit open circuit, high resistance ▪ Rear right door bass speaker circuit short circuit ▪ Audio amplifier module - Failure	▪ Refer to the electrical circuit diagrams and test the rear right door bass speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right door bass speaker ▪ Refer to the electrical circuit diagrams and test the rear right door bass speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right door bass speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A09-11	Speaker #9 - Circuit short to ground	NOTE: Circuit reference - LEFT_FRONT_MID_POS / LEFT_FRONT_MID_NEG ▪ Front left door mid-range speaker circuit short circuit to ground ▪ Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test

			the front left door mid-range speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door mid-range speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A09-12	Speaker #9 - Circuit short to battery	NOTE: Circuit reference - LEFT_FRONT_MID_POS / LEFT_FRONT_MID_NEG - Front left door mid-range speaker circuit short circuit to power - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the front left door mid-range speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door mid-range speaker - Using the manufacturer approved diagnostic system, clear the

			DTCs and retest. If the fault persists, install a new audio amplifier module
B1A09-13	Speaker #9 - Circuit open	NOTE: Circuit reference - LEFT_FRONT_MID_POS / LEFT_FRONT_MID_NEG - Front left door mid-range speaker circuit open circuit, high resistance - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the front left door mid-range speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door mid-range speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A09-1A	Speaker #9 - Circuit resistance below threshold	NOTE: Circuit reference - LEFT_FRONT_MID_POS / LEFT_FRONT_MID_NEG Front left door mid-range speaker circuit short circuit	NOTE: Premium and Super Premium audio system only Refer to the electrical circuit

		Audio amplifier module - Failure	diagrams and test the front left door mid-range speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door mid-range speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A09-1E	Speaker #9 - Circuit resistance out of range	NOTE: Circuit reference - LEFT_FRONT_MID_POS / LEFT_FRONT_MID_NEG - Front left door mid-range speaker circuit open circuit, high resistance - Front left door mid-range speaker circuit short circuit - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the front left door mid-range speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door mid-range speaker - Refer to the electrical circuit diagrams and test the front left door

			mid-range speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left door mid-range speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A10-11	Speaker #10 - Circuit short to ground	NOTE: Circuit reference - RIGHT_FRONT_MID_POS / RIGHT_FRONT_MID_NEG ▪ Front right door mid-range speaker circuit short circuit to ground ▪ Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the front right door mid-range speaker circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door mid-range speaker ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists,

			install a new audio amplifier module
B1A10-12	Speaker #10 - Circuit short to battery	NOTE: Circuit reference - RIGHT_FRONT_MID_POS / RIGHT_FRONT_MID_NEG - Front right door mid-range speaker circuit short circuit to power - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the front right door mid-range speaker circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door mid-range speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A10-13	Speaker #10 - Circuit open	NOTE: Circuit reference - RIGHT_FRONT_MID_POS / RIGHT_FRONT_MID_NEG - Front right door mid-range speaker circuit open circuit, high resistance - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only Refer to the electrical circuit diagrams and test the front right door

			mid-range speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door mid-range speaker Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A10-1A	Speaker #10 - Circuit resistance below threshold	NOTE: Circuit reference - RIGHT_FRONT_MID_POS / RIGHT_FRONT_MID_NEG - Front right door mid-range speaker circuit short circuit - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the front right door mid-range speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door mid-range speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists,

			install a new audio amplifier module
B1A10-1E	Speaker #10 - Circuit resistance out of range	NOTE: Circuit reference - RIGHT_FRONT_MID_POS / RIGHT_FRONT_MID_NEG - Front right door mid-range speaker circuit open circuit, high resistance - Front right door mid-range speaker circuit short circuit - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the front right door mid-range speaker circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door mid-range speaker - Refer to the electrical circuit diagrams and test the front right door mid-range speaker circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right door mid-range speaker - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module

B1A11-11	Speaker #11 - Circuit short to ground	NOTE: Circuit reference - SW1 POS / SW1 NEG - Sub-woofer 1 circuit short circuit to ground - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the sub-woofer 1 circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new sub-woofer - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A11-12	Speaker #11 - Circuit short to battery	NOTE: Circuit reference - SW1 POS / SW1 NEG - Sub-woofer 1 circuit short circuit to power - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only Refer to the electrical circuit diagrams and test the sub-woofer 1 circuit for short circuit to power. Using the manufacturer approved diagnostic

			system, clear the DTCs and retest. If the fault persists, install a new sub-woofer Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A11-13	Speaker #11 - Circuit open	NOTE: Circuit reference - SW1 POS / SW1 NEG - Sub-woofer 1 circuit open circuit, high resistance - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the sub-woofer 1 circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new sub-woofer - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A11-1A	Speaker #11 - Circuit resistance below threshold		

		NOTE: Circuit reference - SW1 POS / SW1 NEG - Sub-woofer 1 circuit short circuit - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the sub-woofer 1 circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new sub-woofer - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A11-1E	Speaker #11 - Circuit resistance out of range	NOTE: Circuit reference - SW1 POS / SW1 NEG - Sub-woofer 1 circuit open circuit, high resistance - Sub-woofer 1 circuit short circuit - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only Refer to the electrical circuit diagrams and test the sub-woofer 1 circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If

			the fault persists, install a new sub-woofer - Refer to the electrical circuit diagrams and test the sub-woofer 1 circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new sub-woofer - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A12-11	Speaker #12 - Circuit short to ground	NOTE: Circuit reference - SW2 POS / SW2 NEG - Sub-woofer 2 circuit short circuit to ground - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the sub-woofer 2 circuit for short circuit to ground. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new sub-woofer - Using the manufacturer approved diagnostic

			system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A12-12	Speaker #12 - Circuit short to battery	NOTE: Circuit reference - SW2 POS / SW2 NEG - Sub-woofer 2 circuit short circuit to power - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the sub-woofer 2 circuit for short circuit to power. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new sub-woofer - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A12-13	Speaker #12 - Circuit open	NOTE: Circuit reference - SW2 POS / SW2 NEG - Sub-woofer 2 circuit open circuit, high resistance - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only Refer to the electrical circuit diagrams and test

			the sub-woofer 2 circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new sub-woofer ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1A12-1A	Speaker #12 - Circuit resistance below threshold	NOTE: Circuit reference - SW2 POS / SW2 NEG ▪ Sub-woofer 2 circuit short circuit ▪ Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only ▪ Refer to the electrical circuit diagrams and test the sub-woofer 2 circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new sub-woofer ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module

B1A12-1E	Speaker #12 - Circuit resistance out of range	NOTE: Circuit reference - SW2 POS / SW2 NEG - Sub-woofer 2 circuit open circuit, high resistance - Sub-woofer 2 circuit short circuit - Audio amplifier module - Failure	NOTE: Premium and Super Premium audio system only - Refer to the electrical circuit diagrams and test the sub-woofer 2 circuit for open circuit, high resistance. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new sub-woofer - Refer to the electrical circuit diagrams and test the sub-woofer 2 circuit for short circuit. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new sub-woofer - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new audio amplifier module
B1D84-11	Headphone panel 1 - Circuit short to ground	Headphone panel 1 left or right signal circuit short circuit to ground	Refer to the electrical circuit diagrams and check the headphone panel 1 left or right signal circuit for

			short circuit to ground
B1D84-13	Headphone panel 1 - Circuit open	Headphone panel 1 left or right signal circuit open circuit, high resistance	Refer to the electrical circuit diagrams and check the headphone panel 1 left or right signal circuit for open circuit, high resistance
B1D85-11	Headphone panel 2 - Circuit short to ground	Headphone panel 2 left or right signal circuit short circuit to ground	Refer to the electrical circuit diagrams and check the headphone panel 2 left or right signal circuit for short circuit to ground
B1D85-13	Headphone panel 2 - Circuit open	Headphone panel 2 left or right signal circuit open circuit, high resistance	Refer to the electrical circuit diagrams and check the headphone panel 2 left or right signal circuit for open circuit, high resistance
B1D86-11	Headphone panel 3 - Circuit short to ground	Headphone panel 3 left or right signal circuit short circuit to ground	Refer to the electrical circuit diagrams and check the headphone panel 3 left or right signal circuit for short circuit to ground
B1D86-13	Headphone panel 3 - Circuit open	Headphone panel 3 left or right signal circuit open circuit, high resistance	Refer to the electrical circuit diagrams and check the headphone panel 3 left or right signal circuit for open circuit, high resistance

B1D87-11	Headphone panel 4 - Circuit short to ground	Headphone panel 4 left or right signal circuit short circuit to ground	Refer to the electrical circuit diagrams and check the headphone panel 4 left or right signal circuit for short circuit to ground
B1D87-13	Headphone panel 4 - Circuit open	Headphone panel 4 left or right signal circuit open circuit, high resistance	Refer to the electrical circuit diagrams and check the headphone panel 4 left or right signal circuit for open circuit, high resistance
U2300-54	Central Configuration - Missing calibration	- Audio amplifier module is not configured correctly - Car configuration file mismatch with vehicle specification	- Using the manufacturer approved diagnostic system, re-configure the audio amplifier module with the latest level software - Using the manufacturer approved diagnostic system, check and up-date the car configuration file as necessary
U2300-56	Central Configuration - Invalid/incomplete configuration	- Audio amplifier module is not configured correctly - Car configuration file mismatch with vehicle specification	- Using the manufacturer approved diagnostic system, re-configure the audio amplifier module with the latest level software - Using the manufacturer approved diagnostic system, check and up-date the car configuration file as necessary
U2300-	Central	Car configuration file mismatch with vehicle	Using the

64	Configuration - Signal plausibility failure	specification Incorrect audio amplifier module installed	manufacturer approved diagnostic system, check and up-date the car configuration file as necessary Install a new audio amplifier module as necessary
U3000-55	Control Module - Not configured	- Audio amplifier module is not configured correctly - New audio amplifier module	- Using the manufacturer approved diagnostic system, re-configure the audio amplifier module with the latest level software - This DTC will occur once if a new module is installed. Clear the DTC, cycle the ignition state to off. Lock the vehicle (to ensure the infotainment system has reset). Unlock the vehicle, cycle the ignition state to on. Retest the system
U3000-96	Control Module - Component internal failure	Audio amplifier module - Failure	Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - On Demand Self Test (0202). If the fault persists, install a new audio amplifier module
U3000-98	Control Module - Component or system over temperature	- Audio amplifier cooling vents obstructed - Speaker circuit fault - Audio amplifier module - Failure	- Check that the amplifier module ventilation is not obstructed - Rectify speaker related faults first. Clear the DTCs and

			retest Rectify audio amplifier module - Failure related faults first. Clear the DTCs and retest
U3003-16	Battery Voltage - Circuit voltage below threshold	- Audio amplifier module power or ground circuit open circuit, high resistance - Battery/charging system fault	- Using the manufacturer approved diagnostic system, check datalogger signal - ECU Power Supply Voltage (0xD110). Refer to the electrical circuit diagrams and test the audio amplifier module power and ground circuits for open circuit, high resistance - Refer to the relevant section of the workshop manual and test the battery and charging system
U3003-17	Battery Voltage - Circuit voltage above threshold	Battery/charging system fault	Using the manufacturer approved diagnostic system, check datalogger signal - ECU Power Supply Voltage (0xD110). Refer to the relevant section of the workshop manual and test the battery and charging system