

2016.0 RANGE ROVER (LG), 100-00

GENERAL INFORMATION

DESCRIPTION AND OPERATION

AUTOMATIC TEMPERATURE CONTROL MODULE (ATCM)

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.

NOTES:

- If a control module or a component is suspect and the vehicle remains under manufacturer warranty, refer to the Warranty Policy and Procedures manual, or determine if any prior approval programme is in operation, prior to the installation of a new module/component.
- Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system).
- When performing voltage or resistance tests, always use a digital multimeter accurate to three decimal places, and with an up-to-date calibration certificate. When testing resistance always take the resistance of the digital multimeter leads into account.
- Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.
- Inspect connectors for signs of water ingress, and pins for damage and/or corrosion.
- If DTCs are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always check for loose connections and corroded terminals.
- Check DDW for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and carry out the recommendations as required.

The table below lists all Diagnostic Trouble Codes (DTCs) that could be logged in the Automatic Temperature Control Module (ATCM). For additional diagnosis and testing information, refer to the relevant Diagnosis and Testing section in the workshop manual. For additional information, refer to: (412-00 Climate Control System - General Information)

Climate Control System (Diagnosis and Testing),
Auxiliary Climate Control (Diagnosis and Testing).

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B102A-11	Flame Sensor - Circuit short to ground	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater flame sensor circuit short circuit to ground	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault - Refer to the electrical circuit diagrams and check the flame sensor circuit for short circuit to ground. Repair the circuit or install a new flame sensor located within the fuel fired booster heater as necessary - Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to

			maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B102A-15	Flame Sensor - Circuit short to battery or open	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater flame sensor circuit short circuit to power, open circuit, high resistance	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault - Refer to the electrical circuit diagrams and check the flame sensor circuit for short circuit to power, open circuit, high resistance. Repair the circuit or install a new flame sensor located within the fuel fired booster heater as necessary - Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the

			engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B102A-64	Flame Sensor - Signal plausibility failure	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater flame sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault - Refer to the electrical circuit diagrams and check the flame sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair the circuit or install a new flame sensor located within the fuel fired booster heater as necessary - Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater

			(AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B102E-11	Air Quality Sensor - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Pollution sensor signal circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the pollution sensor circuit for short circuit to ground
B102E-15	Air Quality Sensor - Circuit short to battery or open		▪ Refer to the electrical circuit diagrams and check the pollution sensor circuit for short circuit to power, open circuit, high resistance

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Pollution sensor signal circuit short circuit to power, open circuit, high resistance	
B102E-96	Air Quality Sensor - Component internal failure	▪ Pollution sensor internal failure	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new pollution sensor
B1030-01	Left Front Seat Heater - General electrical failure	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front left seat heater control module internal failure	▪ Clear DTC and retest. If fault persists, check and install new front left seat heater control module as required

B1030-4B	Left Front Seat Heater - Over temperature	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front left heated seat cushion element internal failure - Front left heated seat backrest element internal failure	- Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left heated seat cushion element - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left heated seat backrest element
B1030-87	Left Front Seat Heater - Missing message	NOTE: This DTC will log with the ignition set to on for a minimum of 6 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front left heated seat cushion element power or ground circuit open circuit, high resistance - LIN circuit short circuit to ground, short	- Refer to the electrical circuit diagrams and check the front left heated seat cushion element power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left heated seat cushion element - Using the manufacturer approved diagnostic system, clear the DTCs

		circuit to power, open circuit, high resistance ▪ Front left heated seat cushion element internal failure ▪ Front left heated seat backrest element internal failure	and retest. If the fault persists, install a new front left heated seat backrest element
B1031-01	Left Rear Seat Heater - General electrical failure	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat heater control module internal failure	▪ Clear DTC and retest. If fault persists, check and install new rear left seat heater control module as required
B1031-4B	Left Rear Seat Heater - Over temperature	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left heated seat cushion element internal failure ▪ Rear left heated seat	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left heated seat cushion element ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left heated seat backrest element

		backrest element internal failure	
B1031-87	Left Rear Seat Heater - Missing message	NOTE: This DTC will log with the ignition set to on for a minimum of 6 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left heated seat cushion element power or ground circuit open circuit, high resistance ▪ LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Rear left heated seat cushion element internal failure ▪ Rear left heated seat backrest element internal failure	▪ Refer to the electrical circuit diagrams and check the rear left heated seat cushion element power and ground circuits for open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left heated seat cushion element ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left heated seat backrest element
B1032-01	Right Front Seat Heater - General electrical failure		▪ Refer to the electrical circuit diagrams and check the front right heated seat cushion element power and ground circuits for open circuit, high resistance ▪ Clear DTC and retest. If fault persists, check

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front right heated seat cushion element power or ground circuit open circuit, high resistance - Front right seat heater control module internal failure	and install new front right seat heater control module as required
B1032-4B	Right Front Seat Heater - Over temperature	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front right heated seat cushion element internal failure - Front right heated seat backrest element internal failure	- Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right heated seat cushion element - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right heated seat backrest element
B1032-	Right Front Seat Heater		Refer to the electrical

87	- Missing message	NOTE: This DTC will log with the ignition set to on for a minimum of 6 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front right heated seat cushion element power or ground circuit open circuit, high resistance - LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance - Front right heated seat cushion element internal failure - Front right heated seat backrest element internal failure	circuit diagrams and check the front right heated seat cushion element power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right heated seat cushion element - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right heated seat backrest element
B1033-01	Right Rear Seat Heater - General electrical failure		Clear DTC and retest. If fault persists, check and install new rear right seat heater control module as required

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat heater control module internal failure	
B1033-4B	Right Rear Seat Heater - Over temperature	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right heated seat cushion element internal failure ▪ Rear right heated seat backrest element internal failure	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right heated seat cushion element ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right heated seat backrest element
B1033-87	Right Rear Seat Heater - Missing message		▪ Refer to the electrical circuit diagrams and check the rear right heated seat cushion element power and ground circuits for open circuit, high

		NOTE: This DTC will log with the ignition set to on for a minimum of 6 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right heated seat cushion element power or ground circuit open circuit, high resistance ▪ LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Rear right heated seat cushion element internal failure ▪ Rear right heated seat backrest element internal failure	resistance ▪ Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right heated seat cushion element ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right heated seat backrest element
B1034-01	Left Front Seat Heater Element - General electrical failure		▪ Refer to the electrical circuit diagrams and check the front left heated seat cushion element circuit for open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the front left heated seat backrest element circuit for open circuit, high resistance

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front left heated seat cushion element circuit open circuit, high resistance ▪ Front left heated seat backrest element circuit open circuit, high resistance	
B1035-01	Left Rear Seat Heater Element - General electrical failure	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left heated seat cushion element circuit open circuit, high resistance ▪ Rear left heated seat backrest element circuit open circuit, high resistance	▪ Refer to the electrical circuit diagrams and check the rear left heated seat cushion element circuit for open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the rear left heated seat backrest element circuit for open circuit, high resistance

B1036-01	Right Front Seat Heater Element - General electrical failure	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front right heated seat cushion element circuit open circuit, high resistance - Front right heated seat backrest element circuit open circuit, high resistance	- Refer to the electrical circuit diagrams and check the front right heated seat cushion element circuit for open circuit, high resistance - Refer to the electrical circuit diagrams and check the front right heated seat backrest element circuit for open circuit, high resistance
B1037-01	Right Rear Seat Heater Element - General electrical failure	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Rear right heated seat cushion element circuit open circuit, high resistance - Rear right heated seat backrest element circuit open circuit, high resistance	- Refer to the electrical circuit diagrams and check the rear right heated seat cushion element circuit for open circuit, high resistance - Refer to the electrical circuit diagrams and check the rear right heated seat backrest element circuit for open circuit, high resistance

B1038-01	Left Front Seat Heater Sensor - General electrical failure	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left heated seat cushion element internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left heated seat cushion element
B1039-01	Left Rear Seat Heater Sensor - General electrical failure	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Rear left heated seat cushion element internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left heated seat cushion element
B103A-01	Right Front Seat Heater Sensor - General electrical failure		Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right heated seat cushion element

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right heated seat cushion element internal failure	
B103B-01	Right Rear Seat Heater Sensor - General electrical failure	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Rear right heated seat cushion element internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right heated seat cushion element
B103F-87	Rear Seat Heater Control - Missing message		- Refer to the electrical circuit diagrams and check the rear seat heater switchpack power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the LIN circuit

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear seat heater switchpack power or ground circuit open circuit, high resistance ▪ LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Rear seat heater switchpack internal failure	for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear seat heater switchpack
B105A-11	Cabin Temperature Sensor Fan - Circuit short to ground		▪ Refer to the electrical circuit diagrams and check the in-vehicle temperature sensor fan circuit for short circuit to ground

		NOTES: ▪ This DTC will log with the engine running for a minimum of 7 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - ASPIRATOR DRIVE ▪ In-vehicle temperature sensor fan circuit short circuit to ground	
B105A-12	Cabin Temperature Sensor Fan - Circuit short to battery		▪ Refer to the electrical circuit diagrams and check the in-vehicle temperature sensor fan circuit for short circuit to power

		NOTES: ▪ This DTC will log with the ignition set to on for a minimum of 7 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - ASPIRATOR DRIVE ▪ In-vehicle temperature sensor fan circuit short circuit to power	
B105A-13	Cabin Temperature Sensor Fan - Circuit open		▪ Refer to the electrical circuit diagrams and check the in-vehicle temperature sensor fan circuit for open circuit, high resistance

		NOTES: ▪ This DTC will log with the engine running for a minimum of 7 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - ASPIRATOR DRIVE	
		▪ In-vehicle temperature sensor fan circuit open circuit, high resistance	
B105A-97	Cabin Temperature Sensor Fan - Component or system operation obstructed or blocked	NOTE: This DTC will log with the ignition set to on for a minimum of 7 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system	▪ Remove any obstructions from the fan. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new in-vehicle temperature sensor
		▪ In-vehicle	

		temperature sensor fan jammed or broken	
B1083-49	Recirculation Damper Motor - Internal electronic failure	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Recirculation motor internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new recirculation motor
B1083-87	Recirculation Damper Motor - Missing message	NOTE: This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Recirculation motor power or ground circuit open circuit, high resistance - LIN circuit short circuit to ground, short	- Refer to the electrical circuit diagrams and check the recirculation motor power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new recirculation motor

		circuit to power, open circuit, high resistance Recirculation motor internal failure	
B1083-97	Recirculation Damper Motor - Component or system operation obstructed or blocked	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Recirculation motor jammed or broken	Remove any obstructions from the recirculation motor mechanism. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, compare datalogger signals - Fresh/Recirculated Air Flap Actuator Requested Position (0x985A) - and - Fresh/Recirculated Air Flap Actuator Measured Position (0x9859). If inconsistent, install a new recirculation motor
B1085-49	Defroster Damper Motor - Internal electronic failure	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Demist distribution motor internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new demist distribution motor
B1085-87	Defroster Damper Motor - Missing		Refer to the electrical circuit diagrams and

	message	NOTE: This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Demist distribution motor power or ground circuit open circuit, high resistance - LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance - Demist distribution motor internal failure	check the demist distribution motor power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new demist distribution motor
B1085-97	Defroster Damper Motor - Component or system operation obstructed or blocked	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Demist distribution	Remove any obstructions from the demist distribution motor mechanism. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, compare datalogger signals - Defrost Air Flap Actuator Requested Position (0x9862) - and - Defrost Air Flap Actuator Measured Position (0x9861). If inconsistent, install a new demist distribution motor

		motor jammed or broken	
B1087-4A	LIN Bus "A" - Incorrect component installed	NOTE: This DTC will log with the engine running for a minimum of 11 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Incorrect component connected to the LIN bus	Using the manufacturer approved diagnostic system, check for other LIN related DTCs and perform the relevant corrective action
B1087-88	LIN Bus "A" - Bus off		Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance

		NOTES: ▪ This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - LIN 1 (HVAC)	
		▪ LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance	
B1088-4A	LIN Bus "B" - Incorrect component installed	NOTE: This DTC will log with the engine running for a minimum of 11 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system	▪ Using the manufacturer approved diagnostic system, check for other LIN related DTCs and perform the relevant corrective action
		▪ Incorrect component	

		connected to the LIN bus	
B1088-88	LIN Bus "B" - Bus off	NOTES: ■ This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ■ Circuit reference - LIN 2 (HVAC)	■ Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance
B10AF-11	Blower Fan Relay - Circuit short to ground		■ Refer to the electrical circuit diagrams and check the front blower relay control circuit for short circuit to ground. Repair circuit as required, clear DTC and retest ■ If fault persists, check and install a new front blower relay as required

		NOTE: This DTC will log with the ignition set to on for a minimum of 7 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front blower relay control circuit short circuit to ground ▪ Front blower relay internal failure	
B10AF-12	Blower Fan Relay - Circuit short to battery	NOTE: This DTC will log with the ignition set to on for a minimum of 7 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front blower relay control circuit short circuit to power ▪ Front blower relay	▪ Refer to the electrical circuit diagrams and check the front blower relay control circuit for short circuit to power. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new front blower relay as required

		internal failure	
B10AF-13	Blower Fan Relay - Circuit open	NOTE: This DTC will log with the ignition set to on for a minimum of 7 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front blower relay control circuit open circuit, high resistance - Front blower relay internal failure	- Refer to the electrical circuit diagrams and check the front blower relay control circuit for open circuit, high resistance. Repair circuit as required, clear DTC and retest - If fault persists, check and install a new front blower relay as required
B10B0-12	Rear Blower Fan Relay - Circuit short to battery	NOTE: This DTC will log with the engine running for a minimum of 7 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Rear climate control blower relay circuit short circuit to power	- Refer to the electrical circuit diagrams and check the rear climate control blower relay circuit for short circuit to power - If fault persists, check and install a new rear climate control blower relay as required

		▪ Rear climate control blower relay internal failure	
B10B0-13	Rear Blower Fan Relay - Circuit open	NOTE: This DTC will log with the engine running for a minimum of 7 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear climate control blower relay circuit open circuit, high resistance ▪ Rear climate control blower relay internal failure	▪ Refer to the electrical circuit diagrams and check the rear climate control blower relay circuit for open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new rear climate control blower relay as required
B10B0-14	Rear Blower Fan Relay - Circuit short to ground or open	NOTE: This DTC will log with the engine running for a minimum of 7 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear climate control blower relay circuit	▪ Refer to the electrical circuit diagrams and check the rear climate control blower relay circuit for short circuit to ground, open circuit, high resistance ▪ If fault persists, check and install a new rear climate control blower relay as required

		short circuit to ground, open circuit, high resistance ▪ Rear climate control blower relay internal failure	
B10B9-11	Blower Control - Circuit short to ground	NOTE: This DTC will log with the ignition set to on for a minimum of 6 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Blower control circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the blower control circuit for short circuit to ground
B10B9-12	Blower Control - Circuit short to battery	NOTE: This DTC will log with the ignition set to on for a minimum of 6 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system	▪ Refer to the electrical circuit diagrams and check the blower control circuit for short circuit to power

		Blower control circuit short circuit to power	
B10B9-13	Blower Control - Circuit open	NOTE: This DTC will log with the ignition set to on for a minimum of 6 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Blower control circuit open circuit, high resistance	Refer to the electrical circuit diagrams and check the blower control circuit for open circuit, high resistance
B10BA-11	Rear Blower Control - Circuit short to ground	NOTE: This DTC will log with the ignition set to on for a minimum of 6 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Rear climate control blower control circuit short circuit to ground	Refer to the electrical circuit diagrams and check the rear climate control blower control circuit for short circuit to ground

B10BA-12	Rear Blower Control - Circuit short to battery	NOTE: This DTC will log with the engine running for a minimum of 6 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ■ Rear climate control blower control circuit short circuit to power	■ Refer to the electrical circuit diagrams and check the rear climate control blower control circuit for short circuit to power
B10BA-13	Rear Blower Control - Circuit open	NOTE: This DTC will log with the engine running for a minimum of 6 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ■ Rear climate control blower control circuit open circuit, high resistance	■ Refer to the electrical circuit diagrams and check the rear climate control blower control circuit for open circuit, high resistance
B11D1-4A	LIN Bus "C" - Incorrect component installed		■ Using the manufacturer approved diagnostic system, check for

		NOTE: This DTC will log with the engine running for a minimum of 11 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Incorrect component connected to the LIN bus	other LIN related DTCs and perform the relevant corrective action
B11D1-88	LIN Bus "C" - Bus off	NOTES: - This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Circuit reference - LIN3 - LIN circuit short circuit to ground, short	Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance

		circuit to power, open circuit, high resistance	
B129A-4A	LIN Bus "D" - Incorrect component installed	NOTES: ▪ This DTC will log with the engine running for a minimum of 11 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - LIN4 ▪ Incorrect component connected to the LIN bus	NOTE: Customer symptoms will be fuel fired booster heater not working and electric air conditioning compressor not working ▪ Using the manufacturer approved diagnostic system, check for other LIN related DTCs and perform the relevant corrective action
B129A-88	LIN Bus "D" - Bus off		NOTE: Customer symptoms will be fuel fired booster heater not working and electric air conditioning compressor not working ▪ Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to

		NOTES: ▪ This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - LIN4	power, open circuit, high resistance
B12A6-11	Auxiliary Heater Water Pump - Circuit short to ground	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Fuel fired booster	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault ▪ Refer to the electrical circuit diagrams and

		heater coolant pump circuit short circuit to ground	check the fuel fired booster heater coolant pump circuit for short circuit to ground Repair the circuit or install a new coolant pump located within the fuel fired booster heater as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B12A6-12	Auxiliary Heater Water Pump - Circuit short to battery		

			NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater coolant pump circuit short circuit to power	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault - Refer to the electrical circuit diagrams and check the fuel fired booster heater coolant pump circuit for short circuit to power - Repair the circuit or install a new coolant pump located within the fuel fired booster heater as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater	
--	--	--	--	--	--

			exhaust pipe or from the area surrounding the fuel fired booster heater
B12A6-13	Auxiliary Heater Water Pump - Circuit open	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater coolant pump circuit open circuit, high resistance	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault - Refer to the electrical circuit diagrams and check the fuel fired booster heater coolant pump circuit for open circuit, high resistance - Repair the circuit or install a new coolant pump located within the fuel fired booster heater as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to

			maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B12B1-11	Heated Washer Jet and Wiper Park Relay - Circuit short to ground	NOTE: This DTC will log with the engine running for a minimum of 30 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Heated washer jet relay circuit short circuit to ground - Heated washer jet relay internal failure	- Refer to the electrical circuit diagrams and check the heated washer jet relay control circuit for short circuit to ground. Repair circuit as required, clear DTC and retest - If fault persists, check and install a new heated washer jet relay as required
B12B1-12	Heated Washer Jet and Wiper Park Relay - Circuit short to battery		- Refer to the electrical circuit diagrams and check the heated washer jet relay control circuit for short circuit to power. Repair circuit as required, clear DTC and retest - If fault persists, check and install a new heated washer jet relay as required

		NOTE: This DTC will log with the engine running for a minimum of 30 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Heated washer jet relay circuit short circuit to power ▪ Heated washer jet relay internal failure	
B12B1-13	Heated Washer Jet and Wiper Park Relay - Circuit open	NOTE: This DTC will log with the engine running for a minimum of 30 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Heated washer jet relay circuit open circuit, high resistance ▪ Heated washer jet relay internal failure	▪ Refer to the electrical circuit diagrams and check the heated washer jet relay control circuit for open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new heated washer jet relay as required
B12B2-	AUX Heater Coolant		

NOTE:

This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system

- Fuel fired booster heater engine coolant bypass valve circuit short circuit to ground

NOTE:

The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault

- Refer to the electrical circuit diagrams and check the fuel fired booster heater engine coolant bypass valve circuit for short circuit to ground
- Repair the circuit or install a new engine coolant bypass valve located within the fuel fired booster heater as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel

			fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B12B2-12	AUX Heater Coolant Diverter Valve - Circuit short to battery	NOTE: This DTC will log with the ignition set to on for a minimum of 7 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater engine coolant bypass valve circuit short circuit to power	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault - Refer to the electrical circuit diagrams and check the fuel fired booster heater engine coolant bypass valve circuit for short circuit to power - Repair the circuit or install a new engine coolant bypass valve located within the fuel fired booster heater as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and

			with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B12B2-13	AUX Heater Coolant Diverter Valve - Circuit open	NOTE: This DTC will log with the ignition set to on for a minimum of 7 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater engine coolant bypass valve circuit open circuit, high resistance	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault - Refer to the electrical circuit diagrams and check the fuel fired booster heater engine coolant bypass valve circuit for open circuit, high resistance - Repair the circuit or install a new engine coolant bypass valve located within the fuel fired booster heater as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15

			minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B12B9-16	Auxiliary Heater Control Module - Circuit voltage below threshold	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Fuel fired booster heater power or ground circuit open circuit, high resistance ▪ Battery/charging system fault ▪ Fuel fired booster heater control module internal failure	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault ▪ Refer to the electrical circuit diagrams and check the fuel fired booster heater power and ground circuits for open circuit, high resistance ▪ Refer to the relevant section of the workshop manual and test the battery and charging system ▪ Using the manufacturer

			approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater ▪ If the fault persists, install a new fuel fired booster heater control module located within the fuel fired booster heater, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A)
B12B9-17	Auxiliary Heater Control Module - Circuit voltage above threshold		

			NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Battery/charging system fault ▪ Fuel fired booster heater control module internal failure	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault ▪ Refer to the relevant section of the workshop manual and test the battery and charging system ▪ Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater ▪ If the fault persists,	
--	--	--	--	--	--

			install a new fuel fired booster heater control module located within the fuel fired booster heater, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A)
B12B9-49	Auxiliary Heater Control Module - Internal electronic failure	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater control module internal failure	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater

			exhaust pipe or from the area surrounding the fuel fired booster heater ▪ If the fault persists, install a new fuel fired booster heater control module located within the fuel fired booster heater, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A)
B12B9-64	Auxiliary Heater Control Module - Signal plausibility failure	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Fuel fired booster heater overheated	NOTE: Consider whether environmental conditions may have caused this DTC to log before condemning the unit ▪ Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel

			fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater ▪ If the fault persists, install a new fuel fired booster heater control module located within the fuel fired booster heater, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A)
B12B9-87	Auxiliary Heater Control Module - Missing message	NOTES: ▪ This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - LIN 4 - ▪ Fuel fired booster heater power or ground circuit open circuit, high resistance ▪ LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault ▪ Refer to the electrical circuit diagrams and check the fuel fired booster heater power and ground circuits for open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs

		■ Fuel fired booster heater control module internal failure	and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater ■ If the fault persists, install a new fuel fired booster heater control module located within the fuel fired booster heater, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A)
B1352-49	Left Front Temperature Damper Motor - Internal electronic failure		■ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left temperature blend motor

		NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left temperature blend motor internal failure	
B1352-87	Left Front Temperature Damper Motor - Missing message	NOTE: This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front left temperature blend motor power or ground circuit open circuit, high resistance - LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance	- Refer to the electrical circuit diagrams and check the front left temperature blend motor power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left temperature blend motor

		Front left temperature blend motor internal failure	
B1352-97	Left Front Temperature Damper Motor - Component or system operation obstructed or blocked	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left temperature blend motor jammed or broken	Remove any obstructions from the front left temperature blend motor mechanism. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, compare datalogger signals - Left Front Air Temperature Blend Flap Actuator Requested Position (0x9864) - and - Left Front Air Temperature Blend Flap Actuator Measured Position (0x986F). If inconsistent, install a new front left temperature blend motor
B1354-49	Right Rear Temperature Damper Motor - Internal electronic failure	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Rear right temperature blend motor internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right temperature blend motor

B1354-87	Right Rear Temperature Damper Motor - Missing message	NOTE: This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right temperature blend motor power or ground circuit open circuit, high resistance ▪ LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Rear right temperature blend motor internal failure	▪ Refer to the electrical circuit diagrams and check the rear right temperature blend motor power and ground circuits for open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right temperature blend motor
B1354-97	Right Rear Temperature Damper Motor - Component or system operation obstructed or blocked	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system	▪ Remove any obstructions from the rear right temperature blend motor mechanism. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, compare datalogger signals - Right Rear Air Temperature Blend Flap Actuator Requested Position (0x9868) - and - Right Rear Air Temperature Blend Flap Actuator

		▪ Rear right temperature blend motor jammed or broken	Measured Position (0x9867). If inconsistent, install a new rear right temperature blend motor
B1364-49	Left Rear Temperature Damper Motor - Internal electronic failure	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left temperature blend motor internal failure	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left temperature blend motor
B1364-87	Left Rear Temperature Damper Motor - Missing message	NOTE: This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left temperature blend motor power or	▪ Refer to the electrical circuit diagrams and check the rear left temperature blend motor power and ground circuits for open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new

		ground circuit open circuit, high resistance ■ LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance ■ Rear left temperature blend motor internal failure	rear left temperature blend motor
B1364-97	Left Rear Temperature Damper Motor - Component or system operation obstructed or blocked	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ■ Rear left temperature blend motor jammed or broken	■ Remove any obstructions from the rear left temperature blend motor mechanism. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, compare datalogger signals - Left Rear Air Temperature Blend Flap Actuator Requested Position (0x9866) - and - Left Rear Air Temperature Blend Flap Actuator Measured Position (0x9865). If inconsistent, install a new rear left temperature blend motor
B1366-49	Right Front Temperature Damper Motor - Internal electronic failure		■ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right temperature blend motor

		NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right temperature blend motor internal failure	
B1366-87	Right Front Temperature Damper Motor - Missing message	NOTE: This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front right temperature blend motor power or ground circuit open circuit, high resistance - LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance	- Refer to the electrical circuit diagrams and check the front right temperature blend motor power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right temperature blend motor

		Front right temperature blend motor internal failure	
B1366-97	Right Front Temperature Damper Motor - Component or system operation obstructed or blocked	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right temperature blend motor jammed or broken	Remove any obstructions from the front right temperature blend motor mechanism. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, compare datalogger signals - Right Front Air Temperature Blend Flap Actuator Requested Position (0x9863) - and - Right Front Air Temperature Blend Flap Actuator Measured Position (0x986E). If inconsistent, install a new front right temperature blend motor
B13C2-49	Front Windscreen/Windshield Misting Sensor - Internal electronic failure	Humidity sensor internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new humidity sensor
B13C2-87	Front Windscreen/Windshield Misting Sensor - Missing message	- Humidity sensor power or ground circuit open circuit, high resistance - LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance - Humidity sensor internal failure	- Refer to the electrical circuit diagrams and check the humidity sensor power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit,

			high resistance Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new humidity sensor
B13E2-11	Left Front Face Duct Air Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front left face duct temperature sensor circuit short circuit to ground - Sensor internal failure	- Refer to the electrical circuit diagrams and check the front left face duct temperature sensor circuit for short circuit to ground. Repair circuit as required, clear DTC and retest - If fault persists, check and install a new temperature sensor as required
B13E2-15	Left Front Face Duct Air Temperature Sensor - Circuit short to battery or open		- Refer to the electrical circuit diagrams and check the front left face duct temperature sensor circuit for short circuit to power, open circuit, high resistance. Repair circuit as required, clear DTC and retest - If fault persists, check and install a new temperature sensor as required

		NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front left face duct temperature sensor circuit short circuit to power, open circuit, high resistance ▪ Sensor internal failure	
B13E3-11	Right Front Face Duct Air Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front right face duct temperature sensor circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the front right face duct temperature sensor circuit for short circuit to ground. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new temperature sensor as required

		▪ Sensor internal failure	
B13E3-15	Right Front Face Duct Air Temperature Sensor - Circuit short to battery or open	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front right face duct temperature sensor circuit short circuit to power, open circuit, high resistance ▪ Sensor internal failure	▪ Refer to the electrical circuit diagrams and check the front right face duct temperature sensor circuit for short circuit to power, open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new temperature sensor as required
B13E8-11	Left Front Foot Duct Air Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front left foot duct	▪ Refer to the electrical circuit diagrams and check the front left foot duct temperature sensor circuit for short circuit to ground. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new temperature sensor as required

		temperature sensor circuit short circuit to ground ▪ Sensor internal failure	
B13E8-15	Left Front Foot Duct Air Temperature Sensor - Circuit short to battery or open	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front left foot duct temperature sensor circuit short circuit to power, open circuit, high resistance ▪ Sensor internal failure	▪ Refer to the electrical circuit diagrams and check the front left foot duct temperature sensor circuit for short circuit to power, open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new temperature sensor as required
B13E9-11	Right Front Foot Duct Air Temperature Sensor - Circuit short to ground		▪ Refer to the electrical circuit diagrams and check the front right foot duct temperature sensor circuit for short circuit to ground. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new temperature sensor as required

		NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front right foot duct temperature sensor circuit short circuit to ground ▪ Sensor internal failure	
B13E9-15	Right Front Foot Duct Air Temperature Sensor - Circuit short to battery or open	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front right foot duct temperature sensor circuit short circuit to power, open circuit, high resistance	▪ Refer to the electrical circuit diagrams and check the front right foot duct temperature sensor circuit for short circuit to power, open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new temperature sensor as required

		▪ Sensor internal failure	
B13EA-11	Left Rear Face Duct Air Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left face duct temperature sensor circuit short circuit to ground ▪ Sensor internal failure	▪ Refer to the electrical circuit diagrams and check the rear left face duct temperature sensor circuit for short circuit to ground. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new temperature sensor as required
B13EA-15	Left Rear Face Duct Air Temperature Sensor - Circuit short to battery or open	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left face duct temperature sensor	▪ Refer to the electrical circuit diagrams and check the rear left face duct temperature sensor circuit for short circuit to power, open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new temperature sensor as required

		circuit short circuit to power, open circuit, high resistance ▪ Sensor internal failure	
B13EB-11	Right Rear Face Duct Air Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right face duct temperature sensor circuit short circuit to ground ▪ Sensor internal failure	▪ Refer to the electrical circuit diagrams and check the rear right face duct temperature sensor circuit for short circuit to ground. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new temperature sensor as required
B13EB-15	Right Rear Face Duct Air Temperature Sensor - Circuit short to battery or open	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system	▪ Refer to the electrical circuit diagrams and check the rear right face duct temperature sensor circuit for short circuit to power, open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new temperature sensor as required

		▪ Rear right face duct temperature sensor circuit short circuit to power, open circuit, high resistance ▪ Sensor internal failure	
B13EC-11	Left Rear Foot Duct Air Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left foot duct temperature sensor circuit short circuit to ground ▪ Sensor internal failure	▪ Refer to the electrical circuit diagrams and check the rear left foot duct temperature sensor circuit for short circuit to ground. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new temperature sensor as required
B13EC-15	Left Rear Foot Duct Air Temperature Sensor - Circuit short to battery or open		▪ Refer to the electrical circuit diagrams and check the rear left foot duct temperature sensor circuit for short circuit to power, open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new temperature sensor as required

		NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left foot duct temperature sensor circuit short circuit to power, open circuit, high resistance ▪ Sensor internal failure	
B13ED-11	Right Rear Foot Duct Air Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right foot duct temperature sensor circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the rear right foot duct temperature sensor circuit for short circuit to ground. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new temperature sensor as required

		▪ Sensor internal failure	
B13ED-15	Right Rear Foot Duct Air Temperature Sensor - Circuit short to battery or open	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right foot duct temperature sensor circuit short circuit to power, open circuit, high resistance ▪ Sensor internal failure	▪ Refer to the electrical circuit diagrams and check the rear right foot duct temperature sensor circuit for short circuit to power, open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new temperature sensor as required
B13EE-49	Front Cold Air Bypass Flap Actuator Motor - Internal electronic failure	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Cool air bypass motor internal failure	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new cool air bypass motor

B13EE-87	Front Cold Air Bypass Flap Actuator Motor - Missing message	NOTE: This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Cool air bypass motor power or ground circuit open circuit, high resistance ▪ LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Cool air bypass motor internal failure	▪ Refer to the electrical circuit diagrams and check the cool air bypass motor power and ground circuits for open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new cool air bypass motor
B13EE-97	Front Cold Air Bypass Flap Actuator Motor - Component or system operation obstructed or blocked		▪ Remove any obstructions from the cool air bypass motor mechanism. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault

		NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Cool air bypass motor jammed or broken	persists, compare datalogger signals - Front Cold Air Bypass Flap Actuator Requested Position (0x985C) - and - Front Cold Air Bypass Flap Actuator Measured Position (0x985B). If inconsistent, install a new cool air bypass motor
B13EF-49	Left Front Distribution Flap Actuator Motor - Internal electronic failure	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front left face/feet distribution motor internal failure	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left face/feet distribution motor
B13EF-87	Left Front Distribution Flap Actuator Motor - Missing message		▪ Refer to the electrical circuit diagrams and check the front left face/feet distribution motor power and ground circuits for open circuit, high resistance

		NOTE: This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front left face/feet distribution motor power or ground circuit open circuit, high resistance - LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance - Front left face/feet distribution motor internal failure	- Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left face/feet distribution motor
B13EF-97	Left Front Distribution Flap Actuator Motor - Component or system operation obstructed or blocked	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system	Remove any obstructions from the front left face/feet distribution motor mechanism. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, compare datalogger signals - Left Front Distribution Air Flap Actuator Requested Position (0x985E) - and - Left Front Distribution Air Flap Actuator Measured Position

		Front left face/feet distribution motor jammed or broken	(0x985D). If inconsistent, install a new front left face/feet distribution motor
B13F0-49	Right Front Distribution Flap Actuator Motor - Internal electronic failure	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right face/feet distribution motor internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right face/feet distribution motor
B13F0-87	Right Front Distribution Flap Actuator Motor - Missing message		- Refer to the electrical circuit diagrams and check the front right face/feet distribution motor power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance

		NOTE: This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front right face/feet distribution motor power or ground circuit open circuit, high resistance ▪ LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Front right face/feet distribution motor internal failure	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right face/feet distribution motor
B13F0-97	Right Front Distribution Flap Actuator Motor - Component or system operation obstructed or blocked	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system	▪ Remove any obstructions from the front right face/feet distribution motor mechanism. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, compare datalogger signals - Right Front Distribution Air Flap Actuator Requested Position (0x9860) - and - Right Front Distribution Air Flap Actuator Measured

		Front right face/feet distribution motor jammed or broken	Position (0x985F). If inconsistent, install a new front right face/feet distribution motor
B13F1-49	Auxiliary Distribution Flap Actuator Motor - Internal electronic failure	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Auxiliary climate control face/feet distribution motor internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new auxiliary climate control face/feet distribution motor
B13F1-87	Auxiliary Distribution Flap Actuator Motor - Missing message	NOTE: This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Auxiliary climate control face/feet	- Refer to the electrical circuit diagrams and check the auxiliary climate control face/feet distribution motor power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault

		distribution motor power or ground circuit open circuit, high resistance ■ LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance ■ Auxiliary climate control face/feet distribution motor internal failure	persists, install a new auxiliary climate control face/feet distribution motor
B13F1-97	Auxiliary Distribution Flap Actuator Motor - Component or system operation obstructed or blocked	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ■ Auxiliary climate control face/feet distribution motor jammed or broken	■ Remove any obstructions from the auxiliary climate control face/feet distribution motor mechanism. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, compare datalogger signals - Auxiliary Distribution Air Flap Actuator Requested Position (0x986D) - and - Auxiliary Distribution Air Flap Actuator Measured Position (0x9872). If inconsistent, install a new auxiliary climate control face/feet distribution motor
B13F2-49	Left Auxiliary Air Temperature Blend Flap Actuator Motor - Internal electronic failure		■ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new auxiliary climate control left temperature blend motor

		NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Auxiliary climate control left temperature blend motor internal failure	
B13F2-87	Left Auxiliary Air Temperature Blend Flap Actuator Motor - Missing message	NOTE: This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Auxiliary climate control left temperature blend motor power or ground circuit open circuit, high resistance ▪ LIN circuit short circuit to ground, short	▪ Refer to the electrical circuit diagrams and check the auxiliary climate control left temperature blend motor power and ground circuits for open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new auxiliary climate control left temperature blend motor

		circuit to power, open circuit, high resistance ▪ Auxiliary climate control left temperature blend motor internal failure	
B13F2-97	Left Auxiliary Air Temperature Blend Flap Actuator Motor - Component or system operation obstructed or blocked	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Auxiliary climate control left temperature blend motor jammed or broken	▪ Remove any obstructions from the auxiliary climate control left temperature blend motor mechanism. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, compare datalogger signals - Left Auxiliary Air Temperature Blend Flap Actuator Requested Position (0x986B) - and - Left Auxiliary Air Temperature Blend Flap Actuator Measured Position (0x9870). If inconsistent, install a new auxiliary climate control left temperature blend motor

B13F3-49	Right Auxiliary Air Temperature Blend Flap Actuator Motor - Internal electronic failure	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Auxiliary climate control right temperature blend motor internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new auxiliary climate control right temperature blend motor
B13F3-87	Right Auxiliary Air Temperature Blend Flap Actuator Motor - Missing message		- Refer to the electrical circuit diagrams and check the auxiliary climate control right temperature blend motor power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the

		NOTE: This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Auxiliary climate control right temperature blend motor power or ground circuit open circuit, high resistance ▪ LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Auxiliary climate control right temperature blend motor internal failure	manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new auxiliary climate control right temperature blend motor
B13F3-97	Right Auxiliary Air Temperature Blend Flap Actuator Motor - Component or system operation obstructed or blocked		▪ Remove any obstructions from the auxiliary climate control right temperature blend motor mechanism. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, compare datalogger signals - Right Auxiliary Air Temperature Blend Flap Actuator

		NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Auxiliary climate control right temperature blend motor jammed or broken	Requested Position (0x986C) - and - Right Auxiliary Air Temperature Blend Flap Actuator Measured Position (0x9871). If inconsistent, install a new auxiliary climate control right temperature blend motor
B13F4-11	Electric (PTC) Heater Control Circuit #1 - Circuit short to ground	NOTES: ▪ This DTC will log with the engine running for a minimum of 30 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - PTC RLY 1 CTRL ▪ Electric booster heater relay 1 circuit	▪ Refer to the electrical circuit diagrams and check the electric booster heater relay 1 circuit for short circuit to ground. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new electric booster heater relay 1 as required

		short circuit to ground ▪ Electric booster heater relay internal failure	
B13F4-12	Electric (PTC) Heater Control Circuit #1 - Circuit short to battery	NOTES: ▪ This DTC will log with the engine running for a minimum of 30 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - PTC RLY 1 CTRL ▪ Electric booster heater relay 1 circuit short circuit to power ▪ Electric booster heater relay internal failure	▪ Refer to the electrical circuit diagrams and check the electric booster heater relay 1 circuit for short circuit to power. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new electric booster heater relay 1 as required
B13F4-13	Electric (PTC) Heater Control Circuit #1 - Circuit open		▪ Refer to the electrical circuit diagrams and check the electric booster heater relay 1 circuit for open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new electric booster heater relay 1 as required

		NOTES: ▪ This DTC will log with the engine running for a minimum of 30 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - PTC RLY 1 CTRL ▪ Electric booster heater relay 1 circuit open circuit, high resistance ▪ Electric booster heater relay internal failure	
B13F5-11	Electric (PTC) Heater Control Circuit #2 - Circuit short to ground		▪ Refer to the electrical circuit diagrams and check the electric booster heater relay 2 circuit for short circuit to ground. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new electric booster heater relay 2 as required

		NOTES: ▪ This DTC will log with the engine running for a minimum of 30 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - PTC RLY 2 CTRL	
		▪ Electric booster heater relay 2 circuit short circuit to ground ▪ Electric booster heater relay internal failure	
B13F5-12	Electric (PTC) Heater Control Circuit #2 - Circuit short to battery		▪ Refer to the electrical circuit diagrams and check the electric booster heater relay 2 circuit for short circuit to power. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new electric booster heater relay 2 as required

		NOTES: ▪ This DTC will log with the engine running for a minimum of 30 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - PTC RLY 2 CTRL ▪ Electric booster heater relay 2 circuit short circuit to power ▪ Electric booster heater relay internal failure	
B13F5-13	Electric (PTC) Heater Control Circuit #2 - Circuit open		▪ Refer to the electrical circuit diagrams and check the electric booster heater relay 2 circuit for open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new electric booster heater relay 2 as required

		NOTES: ▪ This DTC will log with the engine running for a minimum of 30 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - PTC RLY 2 CTRL ▪ Electric booster heater relay 2 circuit open circuit, high resistance ▪ Electric booster heater relay internal failure	
B13FF-12	Left Rear Solar Sensor - Circuit short to battery		▪ Refer to the electrical circuit diagrams and check the rear sunload sensor circuit for short circuit to power. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new rear sunload sensor as required

		NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear sunload sensor circuit short circuit to power ▪ Rear sunload sensor internal failure	
B13FF-14	Left Rear Solar Sensor - Circuit short to ground or open	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear sunload sensor circuit short circuit to ground, open circuit, high resistance	▪ Refer to the electrical circuit diagrams and check the rear sunload sensor circuit for short circuit to ground, open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new rear sunload sensor as required

		▪ Rear sunload sensor internal failure	
B1400-12	Right Rear Solar Sensor - Circuit short to battery	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear sunload sensor circuit short circuit to power ▪ Rear sunload sensor internal failure	▪ Refer to the electrical circuit diagrams and check the rear sunload sensor circuit for short circuit to power. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new rear sunload sensor as required
B1400-14	Right Rear Solar Sensor - Circuit short to ground or open	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear sunload sensor	▪ Refer to the electrical circuit diagrams and check the rear sunload sensor circuit for short circuit to ground, open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new rear sunload sensor as required

		circuit short circuit to ground, open circuit, high resistance ▪ Rear sunload sensor internal failure	
B1406-88	Park Heater Remote Receiver Module - Bus off	▪ Fuel fired booster heater receiver power or ground circuit open circuit, high resistance ▪ LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Fuel fired booster heater receiver internal failure	▪ Refer to the electrical circuit diagrams and check the fuel fired booster heater receiver power and ground circuits for open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new fuel fired booster heater receiver
B1406-96	Park Heater Remote Receiver Module - Component internal failure	▪ Fuel fired booster heater receiver internal failure	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new fuel fired booster heater receiver
B140F-08	Electric A/C Compressor - Bus signal / Message failures		▪ Refer to the electrical circuit diagrams and check the electric air conditioning compressor LIN bus circuit for short circuit to ground, short circuit to power, open circuit, high resistance

		NOTES: ▪ This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - LIN 4	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new electric air conditioning compressor as required
B140F-49	Electric A/C Compressor - Internal electronic failure	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Electric air	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new electric air conditioning compressor as required

		conditioning compressor internal failure	
B140F-87	Electric A/C Compressor - Missing message	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Electric air conditioning compressor power or ground circuit open circuit, high resistance ▪ Electric air conditioning compressor LIN bus circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Electric air conditioning compressor internal failure	▪ Refer to the electrical circuit diagrams and check the electric air conditioning compressor power and ground circuits for open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the electric air conditioning compressor LIN bus circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new electric air conditioning compressor as required
B1410-11	Front Refrigerant Magnetic Valve - Circuit short to ground		▪ Refer to the electrical circuit diagrams and check the climate control isolation valve circuit for short circuit to ground

		NOTES: ▪ This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - FRONT HEVAC MAG VALVE ▪ Climate control isolation valve circuit short circuit to ground	
B1410-12	Front Refrigerant Magnetic Valve - Circuit short to battery		▪ Refer to the electrical circuit diagrams and check the climate control isolation valve circuit for short circuit to power

		NOTES: ▪ This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - FRONT HEVAC MAG VALVE ▪ Climate control isolation valve circuit short circuit to power	
B1410-13	Front Refrigerant Magnetic Valve - Circuit open		▪ Refer to the electrical circuit diagrams and check the climate control isolation valve circuit for open circuit, high resistance

		NOTES: ▪ This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - FRONT HEVAC MAG VALVE ▪ Climate control isolation valve circuit open circuit, high resistance	
B1411-11	Battery Chiller Magnetic Valve - Circuit short to ground		▪ Refer to the electrical circuit diagrams and check the hybrid electric vehicle battery isolation valve circuit for short circuit to ground

		NOTES: ▪ This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - BAT PACK REFF VALVE ▪ Hybrid electric vehicle battery isolation valve circuit short circuit to ground	
B1411-12	Battery Chiller Magnetic Valve - Circuit short to battery		▪ Refer to the electrical circuit diagrams and check the hybrid electric vehicle battery isolation valve circuit for short circuit to power

		NOTES: ▪ This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - BAT PACK REFF VALVE ▪ Hybrid electric vehicle battery isolation valve circuit short circuit to power	
B1411-13	Battery Chiller Magnetic Valve - Circuit open		▪ Refer to the electrical circuit diagrams and check the hybrid electric vehicle battery isolation valve circuit for open circuit, high resistance

		NOTES: ▪ This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - BAT PACK REFV VALVE	
		▪ Hybrid electric vehicle battery isolation valve circuit open circuit, high resistance	
B1414-11	Left Front Cooled/Heated Seat Module Blower #2 Motor Speed Control - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front left seat cushion climate assembly blower control circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the front left seat cushion climate assembly blower control circuit for short circuit to ground

B1414-15	Left Front Cooled/Heated Seat Module Blower #2 Motor Speed Control - Circuit short to battery or open	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left seat cushion climate assembly blower control circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the front left seat cushion climate assembly blower control circuit for short circuit to power, open circuit, high resistance
B1415-49	Left Front Cooled/Heated Seat Control Module - Internal electronic failure	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left seat climate control module internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left seat climate control module
B1415-55	Left Front Cooled/Heated Seat Control Module - Not configured		Using the manufacturer approved diagnostic system, re-configure the front left seat climate control module with the latest level

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left seat climate control module is not programmed	software
B1415-87	Left Front Cooled/Heated Seat Control Module - Missing message	NOTE: This DTC will log with the engine running for a minimum of 11 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front left seat climate control module power or ground circuit open circuit, high resistance - LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance - Front left seat climate control module internal failure	- Refer to the electrical circuit diagrams and check the front left seat climate control module power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left seat climate control module

B1415-93	Left Front Cooled/Heated Seat Control Module - No operation	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front left seat climate control module power or ground circuit open circuit, high resistance - Front left seat climate control module internal failure	- Refer to the electrical circuit diagrams and check the front left seat climate control module power and ground circuits for open circuit, high resistance - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left seat climate control module
B1416-11	Left Front Cooled/Heated Seat Thermal Electric Device #2 Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left seat cushion climate assembly temperature sensor circuit short circuit to ground	Refer to the electrical circuit diagrams and check the front left seat cushion climate assembly temperature sensor circuit for short circuit to ground
B1416-15	Left Front Cooled/Heated Seat		Refer to the electrical circuit diagrams and

	Thermal Electric Device #2 Temperature Sensor - Circuit short to battery or open	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left seat cushion climate assembly temperature sensor circuit short circuit to power, open circuit, high resistance	check the front left seat cushion climate assembly temperature sensor circuit for short circuit to power, open circuit, high resistance
B1417-11	Left Front Cooled/Heated Seat Thermal Electric Device #1 Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left seat backrest climate assembly temperature sensor circuit short circuit to ground	Refer to the electrical circuit diagrams and check the front left seat backrest climate assembly temperature sensor circuit for short circuit to ground
B1417-15	Left Front Cooled/Heated Seat Thermal Electric Device #1 Temperature Sensor - Circuit short to battery or open		Refer to the electrical circuit diagrams and check the front left seat backrest climate assembly temperature sensor circuit for short

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left seat backrest climate assembly temperature sensor circuit short circuit to power, open circuit, high resistance	circuit to power, open circuit, high resistance
B1418-49	Right Front Cooled/Heated Seat Control Module - Internal electronic failure	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right seat climate control module internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right seat climate control module
B1418-55	Right Front Cooled/Heated Seat Control Module - Not configured		Using the manufacturer approved diagnostic system, re-configure the front right seat climate control module with the latest level software

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right seat climate control module is not programmed	
B1418-87	Right Front Cooled/Heated Seat Control Module - Missing message	NOTE: This DTC will log with the engine running for a minimum of 11 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front right seat climate control module power or ground circuit open circuit, high resistance - LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance - Front right seat climate control	- Refer to the electrical circuit diagrams and check the front right seat climate control module power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right seat climate control module

		module internal failure	
B1418-93	Right Front Cooled/Heated Seat Control Module - No operation	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front right seat climate control module power or ground circuit open circuit, high resistance - Front right seat climate control module internal failure	- Refer to the electrical circuit diagrams and check the front right seat climate control module power and ground circuits for open circuit, high resistance - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right seat climate control module
B1419-49	Left Rear Cooled/Heated Seat Control Module - Internal electronic failure	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Rear left seat climate control module internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left seat climate control module
B1419-	Left Rear		Using the

55	Cooled/Heated Seat Control Module - Not configured	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat climate control module is not programmed	manufacturer approved diagnostic system, re-configure the rear left seat climate control module with the latest level software
B1419-87	Left Rear Cooled/Heated Seat Control Module - Missing message	NOTE: This DTC will log with the engine running for a minimum of 11 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat climate control module power or ground circuit open circuit, high resistance ▪ LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Rear left seat climate control module internal failure	▪ Refer to the electrical circuit diagrams and check the rear left seat climate control module power and ground circuits for open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left seat climate control module

B1419-93	Left Rear Cooled/Heated Seat Control Module - No operation	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat climate control module power or ground circuit open circuit, high resistance ▪ Rear left seat climate control module internal failure	▪ Refer to the electrical circuit diagrams and check the rear left seat climate control module power and ground circuits for open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left seat climate control module
B141A-49	Right Rear Cooled/Heated Seat Control Module - Internal electronic failure	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat climate control module internal failure	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right seat climate control module
B141A-55	Right Rear Cooled/Heated Seat Control Module - Not configured		▪ Using the manufacturer approved diagnostic system, re-configure the rear right seat

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat climate control module is not programmed	climate control module with the latest level software
B141A-87	Right Rear Cooled/Heated Seat Control Module - Missing message	NOTE: This DTC will log with the engine running for a minimum of 11 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat climate control module power or ground circuit open circuit, high resistance ▪ LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Rear right seat climate control module internal failure	▪ Refer to the electrical circuit diagrams and check the rear right seat climate control module power and ground circuits for open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right seat climate control module

B141A-93	Right Rear Cooled/Heated Seat Control Module - No operation	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat climate control module power or ground circuit open circuit, high resistance ▪ Rear right seat climate control module internal failure	▪ Refer to the electrical circuit diagrams and check the rear right seat climate control module power and ground circuits for open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right seat climate control module
B141B-11	Right Front Cooled/Heated Seat Thermal Electric Device #2 Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front right seat cushion climate assembly temperature sensor circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the front right seat cushion climate assembly temperature sensor circuit for short circuit to ground
B141B-15	Right Front Cooled/Heated Seat Thermal Electric Device #2 Temperature Sensor		▪ Refer to the electrical circuit diagrams and check the front right seat cushion climate

	- Circuit short to battery or open	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front right seat cushion climate assembly temperature sensor circuit short circuit to power, open circuit, high resistance	assembly temperature sensor circuit for short circuit to power, open circuit, high resistance
B141C-11	Right Front Cooled/Heated Seat Thermal Electric Device #1 Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front right seat backrest climate assembly temperature sensor circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the front right seat backrest climate assembly temperature sensor circuit for short circuit to ground
B141C-15	Right Front Cooled/Heated Seat Thermal Electric Device #1 Temperature Sensor - Circuit short to battery or open		▪ Refer to the electrical circuit diagrams and check the front right seat backrest climate assembly temperature sensor circuit for short

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right seat backrest climate assembly temperature sensor circuit short circuit to power, open circuit, high resistance	circuit to power, open circuit, high resistance
B141D-11	Left Rear Cooled/Heated Seat Thermal Electric Device #2 Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Rear left seat cushion climate assembly temperature sensor circuit short circuit to ground	Refer to the electrical circuit diagrams and check the rear left seat cushion climate assembly temperature sensor circuit for short circuit to ground
B141D-15	Left Rear Cooled/Heated Seat Thermal Electric Device #2 Temperature Sensor - Circuit short to battery or open		Refer to the electrical circuit diagrams and check the rear left seat cushion climate assembly temperature sensor circuit for short

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat cushion climate assembly temperature sensor circuit short circuit to power, open circuit, high resistance	circuit to power, open circuit, high resistance
B141E-11	Left Rear Cooled/Heated Seat Thermal Electric Device #1 Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat backrest climate assembly temperature sensor circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the rear left seat backrest climate assembly temperature sensor circuit for short circuit to ground
B141E-15	Left Rear Cooled/Heated Seat Thermal Electric Device #1 Temperature Sensor - Circuit short to battery or open		▪ Refer to the electrical circuit diagrams and check the rear left seat backrest climate assembly temperature sensor circuit for short

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat backrest climate assembly temperature sensor circuit short circuit to power, open circuit, high resistance	circuit to power, open circuit, high resistance
B141F-11	Right Rear Cooled/Heated Seat Thermal Electric Device #2 Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat cushion climate assembly temperature sensor circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the rear right seat cushion climate assembly temperature sensor circuit for short circuit to ground
B141F-15	Right Rear Cooled/Heated Seat Thermal Electric Device #2 Temperature Sensor - Circuit short to battery or open		▪ Refer to the electrical circuit diagrams and check the rear right seat cushion climate assembly temperature sensor circuit for short

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat cushion climate assembly temperature sensor circuit short circuit to power, open circuit, high resistance	circuit to power, open circuit, high resistance
B1420-11	Right Rear Cooled/Heated Seat Thermal Electric Device #1 Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat backrest climate assembly temperature sensor circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the rear right seat backrest climate assembly temperature sensor circuit for short circuit to ground
B1420-15	Right Rear Cooled/Heated Seat Thermal Electric Device #1 Temperature Sensor - Circuit short to battery or open		▪ Refer to the electrical circuit diagrams and check the rear right seat backrest climate assembly temperature sensor circuit for short

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat backrest climate assembly temperature sensor circuit short circuit to power, open circuit, high resistance	circuit to power, open circuit, high resistance
B1421-11	Left Front Cooled/Heated Seat Thermal Electric Device #2 - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Front left seat cushion climate assembly thermal electric device circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the front left seat cushion climate assembly thermal electric device circuit for short circuit to ground
B1421-12	Left Front Cooled/Heated Seat Thermal Electric Device #2 - Circuit short to battery		▪ Refer to the electrical circuit diagrams and check the front left seat cushion climate assembly thermal electric device circuit

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left seat cushion climate assembly thermal electric device circuit short circuit to power	for short circuit to power
B1421-13	Left Front Cooled/Heated Seat Thermal Electric Device #2 - Circuit open	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left seat cushion climate assembly thermal electric device circuit open circuit, high resistance	Refer to the electrical circuit diagrams and check the front left seat cushion climate assembly thermal electric device circuit for open circuit, high resistance
B1421-4B	Left Front Cooled/Heated Seat Thermal Electric Device #2 - Over temperature		Check the airflow to the front left seat cushion climate assembly thermal electric device is not blocked

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Insufficient airflow to the front left seat cushion climate assembly thermal electric device - Front left seat cushion climate assembly thermal electric device internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left seat cushion climate assembly thermal electric device
B1422-11	Left Front Cooled/Heated Seat Thermal Electric Device #1 - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left seat backrest climate assembly thermal electric device circuit short circuit to ground	Refer to the electrical circuit diagrams and check the front left seat backrest climate assembly thermal electric device circuit for short circuit to ground
B1422-12	Left Front Cooled/Heated Seat		Refer to the electrical circuit diagrams and

	Thermal Electric Device #1 - Circuit short to battery	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left seat backrest climate assembly thermal electric device circuit short circuit to power	check the front left seat backrest climate assembly thermal electric device circuit for short circuit to power
B1422-13	Left Front Cooled/Heated Seat Thermal Electric Device #1 - Circuit open	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left seat backrest climate assembly thermal electric device circuit open circuit, high resistance	Refer to the electrical circuit diagrams and check the front left seat backrest climate assembly thermal electric device circuit for open circuit, high resistance
B1422-4B	Left Front Cooled/Heated Seat Thermal Electric Device #1 - Over temperature		Check the airflow to the front left seat backrest climate assembly thermal electric device is not blocked

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Insufficient airflow to the front left seat backrest climate assembly thermal electric device - Front left seat backrest climate assembly thermal electric device internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left seat backrest climate assembly thermal electric device
B1423-11	Left Front Cooled/Heated Seat Module Blower #1 Motor Speed Control - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left seat backrest climate assembly blower control circuit short circuit to ground	Refer to the electrical circuit diagrams and check the front left seat backrest climate assembly blower control circuit for short circuit to ground
B1423-	Left Front		Refer to the electrical

15	Cooled/Heated Seat Module Blower #1 Motor Speed Control - Circuit short to battery or open	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left seat backrest climate assembly blower control circuit short circuit to power, open circuit, high resistance	circuit diagrams and check the front left seat backrest climate assembly blower control circuit for short circuit to power, open circuit, high resistance
B1424-11	Left Front Cooled/Heated Seat Module Blower Motor Power - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left seat climate assembly blower circuit short circuit to ground	Refer to the electrical circuit diagrams and check the front left seat climate assembly blower circuit for short circuit to ground
B1424-15	Left Front Cooled/Heated Seat Module Blower Motor Power - Circuit short to battery or open		Refer to the electrical circuit diagrams and check the front left seat climate assembly blower circuit for short circuit to power, open circuit, high resistance

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front left seat climate assembly blower circuit short circuit to power, open circuit, high resistance	
B1425-11	Right Front Cooled/Heated Seat Thermal Electric Device #2 - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right seat cushion climate assembly thermal electric device circuit short circuit to ground	Refer to the electrical circuit diagrams and check the front right seat cushion climate assembly thermal electric device circuit for short circuit to ground
B1425-12	Right Front Cooled/Heated Seat Thermal Electric Device #2 - Circuit short to battery		Refer to the electrical circuit diagrams and check the front right seat cushion climate assembly thermal electric device circuit for short circuit to

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right seat cushion climate assembly thermal electric device circuit short circuit to power	power
B1425-13	Right Front Cooled/Heated Seat Thermal Electric Device #2 - Circuit open	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right seat cushion climate assembly thermal electric device circuit open circuit, high resistance	Refer to the electrical circuit diagrams and check the front right seat cushion climate assembly thermal electric device circuit for open circuit, high resistance
B1425-4B	Right Front Cooled/Heated Seat Thermal Electric Device #2 - Over temperature		Check the airflow to the front right seat cushion climate assembly thermal electric device is not blocked

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Insufficient airflow to the front right seat cushion climate assembly thermal electric device - Front right seat cushion climate assembly thermal electric device internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right seat cushion climate assembly thermal electric device
B1426-11	Right Front Cooled/Heated Seat Thermal Electric Device #1 - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right seat backrest climate assembly thermal electric device circuit short circuit to ground	Refer to the electrical circuit diagrams and check the front right seat backrest climate assembly thermal electric device circuit for short circuit to ground
B1426-	Right Front		Refer to the electrical

12	Cooled/Heated Seat Thermal Electric Device #1 - Circuit short to battery	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right seat backrest climate assembly thermal electric device circuit short circuit to power	circuit diagrams and check the front right seat backrest climate assembly thermal electric device circuit for short circuit to power
B1426-13	Right Front Cooled/Heated Seat Thermal Electric Device #1 - Circuit open	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right seat backrest climate assembly thermal electric device circuit open circuit, high resistance	Refer to the electrical circuit diagrams and check the front right seat backrest climate assembly thermal electric device circuit for open circuit, high resistance
B1426-4B	Right Front Cooled/Heated Seat Thermal Electric Device #1 - Over temperature		Check the airflow to the front right seat backrest climate assembly thermal electric device is not blocked

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Insufficient airflow to the front right seat backrest climate assembly thermal electric device - Front right seat backrest climate assembly thermal electric device internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right seat backrest climate assembly thermal electric device
B1427-11	Right Front Cooled/Heated Seat Module Blower Motor Power - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right seat climate assembly blower circuit short circuit to ground	Refer to the electrical circuit diagrams and check the front right seat climate assembly blower circuit for short circuit to ground
B1427-15	Right Front Cooled/Heated Seat		Refer to the electrical circuit diagrams and

	Module Blower Motor Power - Circuit short to battery or open	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right seat climate assembly blower circuit short circuit to power, open circuit, high resistance	check the front right seat climate assembly blower circuit for short circuit to power, open circuit, high resistance
B1428-11	Right Front Cooled/Heated Seat Module Blower #1 Motor Speed Control - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right seat backrest climate assembly blower control circuit short circuit to ground	Refer to the electrical circuit diagrams and check the front right seat backrest climate assembly blower control circuit for short circuit to ground
B1428-15	Right Front Cooled/Heated Seat Module Blower #1 Motor Speed Control - Circuit short to battery or open		Refer to the electrical circuit diagrams and check the front right seat backrest climate assembly blower control circuit for short circuit to power, open

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right seat backrest climate assembly blower control circuit short circuit to power, open circuit, high resistance	circuit, high resistance
B1429-11	Right Front Cooled/Heated Seat Module Blower #2 Motor Speed Control - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right seat cushion climate assembly blower control circuit short circuit to ground	Refer to the electrical circuit diagrams and check the front right seat cushion climate assembly blower control circuit for short circuit to ground
B1429-15	Right Front Cooled/Heated Seat Module Blower #2 Motor Speed Control - Circuit short to battery or open		Refer to the electrical circuit diagrams and check the front right seat cushion climate assembly blower control circuit for short

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front right seat cushion climate assembly blower control circuit short circuit to power, open circuit, high resistance	circuit to power, open circuit, high resistance
B142A-11	Left Rear Cooled/Heated Seat Module Blower Motor Power - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Rear left seat climate assembly blower circuit short circuit to ground	Refer to the electrical circuit diagrams and check the rear left seat climate assembly blower circuit for short circuit to ground
B142A-15	Left Rear Cooled/Heated Seat Module Blower Motor Power - Circuit short to battery or open		Refer to the electrical circuit diagrams and check the rear left seat climate assembly blower circuit for short circuit to power, open circuit, high resistance

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat climate assembly blower circuit short circuit to power, open circuit, high resistance	
B142B-11	Left Rear Cooled/Heated Seat Module Blower #1 Motor Speed Control - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat backrest climate assembly blower control circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the rear left seat backrest climate assembly blower control circuit for short circuit to ground
B142B-15	Left Rear Cooled/Heated Seat Module Blower #1 Motor Speed Control - Circuit short to battery or open		▪ Refer to the electrical circuit diagrams and check the rear left seat backrest climate assembly blower control circuit for short circuit to power, open circuit, high resistance

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat backrest climate assembly blower control circuit short circuit to power, open circuit, high resistance	
B142C-11	Left Rear Cooled/Heated Seat Module Blower #2 Motor Speed Control - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat cushion climate assembly blower control circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the rear left seat cushion climate assembly blower control circuit for short circuit to ground
B142C-15	Left Rear Cooled/Heated Seat Module Blower #2 Motor Speed Control - Circuit short to battery or open		▪ Refer to the electrical circuit diagrams and check the rear left seat cushion climate assembly blower control circuit for short circuit to power, open

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat cushion climate assembly blower control circuit short circuit to power, open circuit, high resistance	circuit, high resistance
B142D-11	Left Rear Cooled/Heated Seat Thermal Electric Device #1 - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat backrest climate assembly thermal electric device circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the rear left seat backrest climate assembly thermal electric device circuit for short circuit to ground
B142D-12	Left Rear Cooled/Heated Seat Thermal Electric Device #1 - Circuit short to battery		▪ Refer to the electrical circuit diagrams and check the rear left seat backrest climate assembly thermal electric device circuit

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat backrest climate assembly thermal electric device circuit short circuit to power	for short circuit to power
B142D-13	Left Rear Cooled/Heated Seat Thermal Electric Device #1 - Circuit open	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat backrest climate assembly thermal electric device circuit open circuit, high resistance	▪ Refer to the electrical circuit diagrams and check the rear left seat backrest climate assembly thermal electric device circuit for open circuit, high resistance
B142D-4B	Left Rear Cooled/Heated Seat Thermal Electric Device #1 - Over temperature		▪ Check the airflow to the rear left seat backrest climate assembly thermal electric device is not blocked

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Insufficient airflow to the rear left seat backrest climate assembly thermal electric device - Rear left seat backrest climate assembly thermal electric device internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left seat backrest climate assembly thermal electric device
B142E-11	Left Rear Cooled/Heated Seat Thermal Electric Device #2 - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Rear left seat cushion climate assembly thermal electric device circuit short circuit to ground	Refer to the electrical circuit diagrams and check the rear left seat cushion climate assembly thermal electric device circuit for short circuit to ground
B142E-12	Left Rear Cooled/Heated Seat		Refer to the electrical circuit diagrams and

	Thermal Electric Device #2 - Circuit short to battery	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat cushion climate assembly thermal electric device circuit short circuit to power	check the rear left seat cushion climate assembly thermal electric device circuit for short circuit to power
B142E-13	Left Rear Cooled/Heated Seat Thermal Electric Device #2 - Circuit open	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear left seat cushion climate assembly thermal electric device circuit open circuit, high resistance	▪ Refer to the electrical circuit diagrams and check the rear left seat cushion climate assembly thermal electric device circuit for open circuit, high resistance
B142E-4B	Left Rear Cooled/Heated Seat Thermal Electric Device #2 - Over temperature		▪ Check the airflow to the rear left seat cushion climate assembly thermal electric device is not blocked

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Insufficient airflow to the rear left seat cushion climate assembly thermal electric device - Rear left seat cushion climate assembly thermal electric device internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left seat cushion climate assembly thermal electric device
B142F-11	Right Rear Cooled/Heated Seat Module Blower Motor Power - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Rear right seat climate assembly blower circuit short circuit to ground	Refer to the electrical circuit diagrams and check the rear right seat climate assembly blower circuit for short circuit to ground
B142F-15	Right Rear Cooled/Heated Seat Module Blower Motor		Refer to the electrical circuit diagrams and check the rear right

	Power - Circuit short to battery or open	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat climate assembly blower circuit short circuit to power, open circuit, high resistance	seat climate assembly blower circuit for short circuit to power, open circuit, high resistance
B1430-11	Right Rear Cooled/Heated Seat Module Blower #1 Motor Speed Control - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat backrest climate assembly blower control circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the rear right seat backrest climate assembly blower control circuit for short circuit to ground
B1430-15	Right Rear Cooled/Heated Seat Module Blower #1 Motor Speed Control - Circuit short to battery or open		▪ Refer to the electrical circuit diagrams and check the rear right seat backrest climate assembly blower control circuit for short circuit to power, open

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat backrest climate assembly blower control circuit short circuit to power, open circuit, high resistance	circuit, high resistance
B1431-11	Right Rear Cooled/Heated Seat Module Blower #2 Motor Speed Control - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat cushion climate assembly blower control circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the rear right seat cushion climate assembly blower control circuit for short circuit to ground
B1431-15	Right Rear Cooled/Heated Seat Module Blower #2 Motor Speed Control - Circuit short to battery or open		▪ Refer to the electrical circuit diagrams and check the rear right seat cushion climate assembly blower control circuit for short

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat cushion climate assembly blower control circuit short circuit to power, open circuit, high resistance	circuit to power, open circuit, high resistance
B1432-11	Right Rear Cooled/Heated Seat Thermal Electric Device #1 - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat backrest climate assembly thermal electric device circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the rear right seat backrest climate assembly thermal electric device circuit for short circuit to ground
B1432-12	Right Rear Cooled/Heated Seat Thermal Electric Device #1 - Circuit short to battery		▪ Refer to the electrical circuit diagrams and check the rear right seat backrest climate assembly thermal electric device circuit

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat backrest climate assembly thermal electric device circuit short circuit to power	for short circuit to power
B1432-13	Right Rear Cooled/Heated Seat Thermal Electric Device #1 - Circuit open	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat backrest climate assembly thermal electric device circuit open circuit, high resistance	▪ Refer to the electrical circuit diagrams and check the rear right seat backrest climate assembly thermal electric device circuit for open circuit, high resistance
B1432-4B	Right Rear Cooled/Heated Seat Thermal Electric Device #1 - Over temperature		▪ Check the airflow to the rear right seat backrest climate assembly thermal electric device is not blocked

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Insufficient airflow to the rear right seat backrest climate assembly thermal electric device - Rear right seat backrest climate assembly thermal electric device internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right seat backrest climate assembly thermal electric device
B1433-11	Right Rear Cooled/Heated Seat Thermal Electric Device #2 - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Rear right seat cushion climate assembly thermal electric device circuit short circuit to ground	Refer to the electrical circuit diagrams and check the rear right seat cushion climate assembly thermal electric device circuit for short circuit to ground
B1433-	Right Rear		Refer to the electrical

12	Cooled/Heated Seat Thermal Electric Device #2 - Circuit short to battery	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat cushion climate assembly thermal electric device circuit short circuit to power	circuit diagrams and check the rear right seat cushion climate assembly thermal electric device circuit for short circuit to power
B1433-13	Right Rear Cooled/Heated Seat Thermal Electric Device #2 - Circuit open	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear right seat cushion climate assembly thermal electric device circuit open circuit, high resistance	▪ Refer to the electrical circuit diagrams and check the rear right seat cushion climate assembly thermal electric device circuit for open circuit, high resistance
B1433-4B	Right Rear Cooled/Heated Seat Thermal Electric Device #2 - Over temperature		▪ Check the airflow to the rear right seat cushion climate assembly thermal electric device is not blocked

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Insufficient airflow to the rear right seat cushion climate assembly thermal electric device - Rear right seat cushion climate assembly thermal electric device internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right seat cushion climate assembly thermal electric device
B1434-49	Front Distribution Flap Actuator Motor - Internal electronic failure	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front face/feet distribution motor internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front face/feet distribution motor
B1434-	Front Distribution Flap		Refer to the electrical

87	Actuator Motor - Missing message	NOTE: This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front face/feet distribution motor power or ground circuit open circuit, high resistance - LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance - Front face/feet distribution motor internal failure	circuit diagrams and check the front face/feet distribution motor power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front face/feet distribution motor
B1434-97	Front Distribution Flap Actuator Motor - Component or system operation obstructed or blocked	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system	Remove any obstructions from the front face/feet distribution motor mechanism. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, compare datalogger signals - Front Distribution Flap Actuator Motor Requested Position (0x989B) - and - Front Distribution Flap Actuator Motor Measured Position

		Front face/feet distribution motor jammed or broken	(0x989C). If inconsistent, install a new front face/feet distribution motor
B1435-49	Rear Air Temperature Blend Flap Actuator Motor - Internal electronic failure	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Rear temperature blend motor internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear temperature blend motor
B1435-87	Rear Air Temperature Blend Flap Actuator Motor - Missing message		- Refer to the electrical circuit diagrams and check the rear temperature blend motor power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and

		NOTE: This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear temperature blend motor power or ground circuit open circuit, high resistance ▪ LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Rear temperature blend motor internal failure	check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear temperature blend motor
B1435-97	Rear Air Temperature Blend Flap Actuator Motor - Component or system operation obstructed or blocked	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system	▪ Remove any obstructions from the rear temperature blend motor mechanism. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, compare datalogger signals - Rear Air Temperature Blend Flap Actuator Position Requested Position (0x989E) - and - Rear Air Temperature Blend Flap Actuator Position Measured Position (0x989D). If

		▪ Rear temperature blend motor jammed or broken	inconsistent, install a new rear temperature blend motor
B1A59-11	Sensor 5 Volt Supply - Circuit short to ground	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Refrigerant pressure sensor circuit short circuit to ground ▪ Front sunload sensor circuit short circuit to ground ▪ Refrigerant pressure sensor internal failure ▪ Front sunload sensor internal failure	▪ Refer to the electrical circuit diagrams and check the refrigerant pressure sensor circuit for short circuit to ground ▪ Refer to the electrical circuit diagrams and check the front sunload sensor circuit for short circuit to ground ▪ If fault persists, check and install a new refrigerant pressure sensor as required. Clear DTC and retest ▪ If fault persists, check and install a new front sunload sensor as required. Clear DTC and retest
B1A59-12	Sensor 5 Volt Supply - Circuit short to battery		▪ Refer to the electrical circuit diagrams and check the refrigerant pressure sensor circuit for short circuit to power ▪ Refer to the electrical circuit diagrams and check the front sunload sensor circuit for short circuit to power ▪ If fault persists, check

		NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Refrigerant pressure sensor circuit short circuit to power - Front sunload sensor circuit short circuit to power - Refrigerant pressure sensor internal failure - Front sunload sensor internal failure	and install a new refrigerant pressure sensor as required. Clear DTC and retest If fault persists, check and install a new front sunload sensor as required. Clear DTC and retest
B1A61-11	Cabin Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system	- Refer to the electrical circuit diagrams and check the in-vehicle temperature sensor circuit for short circuit to ground. Repair circuit as required, clear DTC and retest - If fault persists, check and install a new in-vehicle temperature sensor as required. Clear DTC and retest

		▪ In-vehicle temperature sensor circuit short circuit to ground ▪ In-vehicle temperature sensor internal failure	
B1A61-15	Cabin Temperature Sensor - Circuit short to battery or open	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ In-vehicle temperature sensor circuit short circuit to power, open circuit, high resistance ▪ In-vehicle temperature sensor internal failure	▪ Refer to the electrical circuit diagrams and check the in-vehicle temperature sensor circuit for short circuit to power, open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new in-vehicle temperature sensor as required. Clear DTC and retest
B1A63-	Right Solar Sensor -		▪ Refer to the electrical

12	Circuit short to battery	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front sunload sensor circuit short circuit to power - Front sunload sensor internal failure	circuit diagrams and check the front sunload sensor circuit for short circuit to power. Repair circuit as required, clear DTC and retest If fault persists, check and install a new front sunload sensor as required. Clear DTC and retest
B1A63-14	Right Solar Sensor - Circuit short to ground or open	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Front sunload sensor circuit short circuit to ground, open circuit, high resistance	- Refer to the electrical circuit diagrams and check the front sunload sensor circuit for short circuit to ground, open circuit, high resistance. Repair circuit as required, clear DTC and retest - If fault persists, check and install a new front sunload sensor as required. Clear DTC and retest

		Front sunload sensor internal failure	
B1A64-12	Left Solar Sensor - Circuit short to battery	NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front sunload sensor circuit short circuit to power - Front sunload sensor internal failure	- Refer to the electrical circuit diagrams and check the front sunload sensor circuit for short circuit to power. Repair circuit as required, clear DTC and retest - If fault persists, check and install a new front sunload sensor as required. Clear DTC and retest
B1A64-14	Left Solar Sensor - Circuit short to ground or open		Refer to the electrical circuit diagrams and check the front

		NOTE: This DTC will log with the ignition set to on for a minimum of 30 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Front sunload sensor circuit short circuit to ground, open circuit, high resistance - Front sunload sensor internal failure	sunload sensor circuit for short circuit to ground, open circuit, high resistance. Repair circuit as required, clear DTC and retest If fault persists, check and install a new front sunload sensor as required. Clear DTC and retest
B1B71-11	Evaporator Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the ignition set to on for a minimum of 7 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Evaporator temperature sensor circuit short circuit to ground	- Refer to the electrical circuit diagrams and check the evaporator temperature sensor circuit for short circuit to ground. Repair circuit as required, clear DTC and retest - If fault persists, check and install a new evaporator temperature sensor as required. Clear DTC and retest

		Evaporator temperature sensor internal failure	
B1B71-15	Evaporator Temperature Sensor - Circuit short to battery or open	NOTE: This DTC will log with the ignition set to on for a minimum of 7 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Evaporator temperature sensor circuit short to power, open circuit, high resistance - Evaporator temperature sensor internal failure	- Refer to the electrical circuit diagrams and check the evaporator temperature sensor circuit for short circuit to power, open circuit, high resistance. Repair circuit as required, clear DTC and retest - If fault persists, check and install a new evaporator temperature sensor as required. Clear DTC and retest
B1B72-11	LIN Bus #1 Power Supply Circuit - Circuit short to ground	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system	Refer to the electrical circuit diagrams and check the LIN component supply circuit for short circuit to ground

		■ LIN component supply circuit short circuit to ground	
B1B72-12	LIN Bus #1 Power Supply Circuit - Circuit short to battery	NOTE: This DTC will log with the ignition set to on for a minimum of 7 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ■ LIN component supply circuit short circuit to power	■ Refer to the electrical circuit diagrams and check the LIN component supply circuit for short circuit to power
B1B7D-49	Rear Air Distribution Actuator - Internal electronic failure		■ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear face/feet distribution motor

		NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear face/feet distribution motor internal failure	
B1B7D-87	Rear Air Distribution Actuator - Missing message	NOTE: This DTC will log with the ignition set to on for a minimum of 11 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear face/feet distribution motor power or ground circuit open circuit, high resistance ▪ LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance	▪ Refer to the electrical circuit diagrams and check the rear face/feet distribution motor power and ground circuits for open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear face/feet distribution motor

		▪ Rear face/feet distribution motor internal failure	
B1B7D-97	Rear Air Distribution Actuator - Component or system operation obstructed or blocked	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear face/feet distribution motor jammed or broken	▪ Remove any obstructions from the rear face/feet distribution motor mechanism. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, compare datalogger signals - Rear Distribution Air Flap Actuator Requested Position (0x986A) - and - Rear Distribution Air Flap Actuator Measured Position (0x9869). If inconsistent, install a new rear face/feet distribution motor
B1C0B-11	Rear Refrigerant Magnetic Valve - Circuit short to ground	NOTE: This DTC will log with the engine running for a minimum of 30 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear climate control magnetic valve circuit short circuit to ground ▪ Rear climate control magnetic valve internal failure	▪ Refer to the electrical circuit diagrams and check the rear climate control magnetic valve circuit for short circuit to ground. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new rear climate control magnetic valve as required. Clear DTC and retest

B1C0B-12	Rear Refrigerant Magnetic Valve - Circuit short to battery	NOTE: This DTC will log with the engine running for a minimum of 30 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear climate control magnetic valve circuit short circuit to power ▪ Rear climate control magnetic valve internal failure	▪ Refer to the electrical circuit diagrams and check the rear climate control magnetic valve circuit for short circuit to power. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new rear climate control magnetic valve as required. Clear DTC and retest
B1C0B-13	Rear Refrigerant Magnetic Valve - Circuit open	NOTE: This DTC will log with the engine running for a minimum of 30 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Rear climate control magnetic valve circuit open circuit, high resistance ▪ Rear climate control magnetic valve	▪ Refer to the electrical circuit diagrams and check the rear climate control magnetic valve circuit for open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new rear climate control magnetic valve as required. Clear DTC and retest

		internal failure	
B1D22-11	Coolant Temperature Sensor - Circuit short to ground	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater coolant temperature sensor circuit short circuit to ground	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault Refer to the electrical circuit diagrams and check the fuel fired booster heater coolant temperature sensor circuit for short circuit to ground. Repair the circuit or install a new coolant temperature sensor located within the fuel fired booster heater as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat

			the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B1D22-15	Coolant Temperature Sensor - Circuit short to battery or open	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater coolant temperature sensor circuit short circuit to power, open circuit, high resistance	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault Refer to the electrical circuit diagrams and check the fuel fired booster heater coolant temperature sensor circuit for short circuit to power, open circuit, high resistance. Repair the circuit or install a new coolant temperature sensor located within the fuel fired booster heater as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the

			engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B1D23-11	Overheat Sensor - Circuit short to ground	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater overheat temperature sensor circuit short circuit to ground	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault Refer to the electrical circuit diagrams and check the fuel fired booster heater overheat temperature sensor circuit for short circuit to ground. Repair the circuit or install a new overheat temperature sensor located within the fuel fired booster heater as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater

			(AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B1D23-15	Overheat Sensor - Circuit short to battery or open	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater overheat temperature sensor circuit short circuit to power, open circuit, high resistance	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault Refer to the electrical circuit diagrams and check the fuel fired booster heater overheat temperature sensor circuit for short circuit to power, open circuit, high resistance. Repair the circuit or install a new overheat temperature sensor

			located within the fuel fired booster heater as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater	
B1D23-85	Overheat Sensor - Signal above allowable range			

		NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater internal failure	NOTE: Consider whether environmental conditions may have caused this DTC to log before condemning the unit Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new fuel fired booster heater. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B1D24-11	Glow Plug - Circuit short to ground		

NOTE:

This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system

- Fuel fired booster heater glow plug circuit short circuit to ground

NOTE:

The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault

- Refer to the electrical circuit diagrams and check the fuel fired booster heater glow plug circuit for short circuit to ground. Repair the circuit or install a new glow plug located within the fuel fired booster heater as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from

			the area surrounding the fuel fired booster heater
B1D24-12	Glow Plug - Circuit short to battery	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater glow plug circuit short circuit to power	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault Refer to the electrical circuit diagrams and check the fuel fired booster heater glow plug circuit for short circuit to power. Repair the circuit or install a new glow plug located within the fuel fired booster heater as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat

			the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B1D24-13	Glow Plug - Circuit open	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater glow plug circuit open circuit, high resistance	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault Refer to the electrical circuit diagrams and check the fuel fired booster heater glow plug circuit for open circuit, high resistance. Repair the circuit or install a new glow plug located within the fuel fired booster heater as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the

			engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B1D24-64	Glow Plug - Signal plausibility failure	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater glow plug failure	NOTES: - The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault - This DTC is set when a flame is detected before combustion is activated - Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The

			routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater. If the fault persists, install a new glow plug located within the fuel fired booster heater, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A) and re-test ▪ If the fault persists, install a new fuel fired booster heater control module located within the fuel fired booster heater, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A) and re-test
B1D25-11	Heater Fuel Pump - Circuit short to ground		▪ Refer to the electrical circuit diagrams and check the fuel fired booster heater fuel pump circuit for short circuit to ground. Repair the circuit or install a new fuel fired booster heater fuel pump as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater

		NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Fuel fired booster heater fuel pump circuit short circuit to ground	(AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B1D25-12	Heater Fuel Pump - Circuit short to battery		▪ Refer to the electrical circuit diagrams and check the fuel fired booster heater fuel pump circuit for short circuit to power. Repair the circuit or install a new fuel fired booster heater fuel pump as necessary. Using the manufacturer approved diagnostic system, clear the DTCs

		NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Fuel fired booster heater fuel pump circuit short circuit to power	and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B1D25-13	Heater Fuel Pump - Circuit open		▪ Refer to the electrical circuit diagrams and check the fuel fired booster heater fuel pump circuit for open circuit, high resistance. Repair the circuit or install a new fuel fired booster heater fuel pump as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation

		NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater fuel pump circuit open circuit, high resistance	Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater
B1D26-11	Combustion Air Blower - Circuit short to ground	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater blower contaminated with water or debris ingress following driving through deep water or extreme off-road driving	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault Check the fuel fired booster heater air intake and the fuel fired booster heater blower for signs of restriction from sediment or debris. Remove any foreign matter from the air

▪ Fuel fired booster heater blower circuit short circuit to ground ▪ Fuel fired booster heater evaporator assembly contaminated with water or debris ingress following driving through deep water or extreme off-road driving	intake and blower assembly. Clear DTC and retest ▪ If fault persists, refer to the electrical circuit diagrams and check the fuel fired booster heater blower circuit for short circuit to ground. Repair the circuit or install a new blower located within the fuel fired booster heater as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater ▪ If the fuel fired booster heater does not operate correctly following replacement of the blower located within the fuel fired booster heater, replace the fuel fired booster heater combustion tube and evaporator
--	---

			assembly, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A)
B1D26-12	Combustion Air Blower - Circuit short to battery	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Fuel fired booster heater blower contaminated with water or debris ingress following driving through deep water or extreme off-road driving ▪ Fuel fired booster heater blower circuit short circuit to power	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault ▪ Check the fuel fired booster heater air intake and the fuel fired booster heater blower for signs of restriction from sediment or debris. Remove any foreign matter from the air intake and blower assembly. Clear DTC and retest

- | | | |
|--|--|--|
| | <ul style="list-style-type: none">■ Fuel fired booster heater evaporator assembly contaminated with water or debris ingress following driving through deep water or extreme off-road driving | <ul style="list-style-type: none">■ If fault persists, refer to the electrical circuit diagrams and check the fuel fired booster heater blower circuit for short circuit to power. Repair the circuit or install a new blower located within the fuel fired booster heater as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater■ If the fuel fired booster heater does not operate correctly following replacement of the blower located within the fuel fired booster heater, replace the fuel fired booster heater combustion tube and evaporator assembly, clear the DTCs and perform routine - Auxiliary |
|--|--|--|

			Heater (AHCM) Activation Test (0x900A)
B1D26-13	Combustion Air Blower - Circuit open	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Fuel fired booster heater blower contaminated with water or debris ingress following driving through deep water or extreme off-road driving ▪ Fuel fired booster heater blower circuit open circuit, high resistance ▪ Fuel fired booster heater evaporator assembly contaminated with water or debris ingress following driving through deep water or extreme off-road driving	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault ▪ Check the fuel fired booster heater air intake and the fuel fired booster heater blower for signs of restriction from sediment or debris. Remove any foreign matter from the air intake and blower assembly. Clear DTC and retest ▪ If fault persists, refer to the electrical circuit diagrams and check the fuel fired booster heater blower circuit for open circuit, high resistance. Install a new blower located within the fuel fired booster heater as necessary. Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired

			booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater ■ If the fuel fired booster heater does not operate correctly following replacement of the blower located within the fuel fired booster heater, replace the fuel fired booster heater combustion tube and evaporator assembly, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A)
B1D26-71	Combustion Air Blower - Actuator stuck		

			NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Fuel fired booster heater blower contaminated with water or debris ingress following driving through deep water or extreme off-road driving - Fuel fired booster heater blower jammed/seized - Fuel fired booster heater evaporator assembly contaminated with water or debris ingress following driving through deep water or extreme off-road driving	NOTE: The fuel fired booster heater assembly contains many serviceable components. It should NOT be necessary to replace the entire fuel fired booster heater unit to rectify this fault - Check the fuel fired booster heater air intake and the fuel fired booster heater blower for signs of restriction from sediment or debris. Remove any foreign matter from the air intake and blower assembly - Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater
--	--	--	--	---

			exhaust pipe or from the area surrounding the fuel fired booster heater. If the fault persists, install a new blower located within the fuel fired booster heater as necessary ▪ If the fuel fired booster heater does not operate correctly following replacement of the blower located within the fuel fired booster heater, replace the fuel fired booster heater combustion tube and evaporator assembly, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A)
B1D27-11	Heater Coolant Pump - Circuit short to ground	NOTES: ▪ This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - AUX WATER PUMP	▪ Refer to the electrical circuit diagrams and check the auxiliary coolant pump circuit for short circuit to ground. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new auxiliary coolant pump as required. Clear DTC and retest
		▪ Auxiliary coolant	

		pump circuit short circuit to ground ▪ Auxiliary coolant pump internal failure	
B1D27-12	Heater Coolant Pump - Circuit short to battery	NOTES: ▪ This DTC will log with the ignition set to on for a minimum of 7 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - AUX WATER PUMP ▪ Auxiliary coolant pump circuit short circuit to power ▪ Auxiliary coolant pump internal failure	▪ Refer to the electrical circuit diagrams and check the auxiliary coolant pump circuit for short circuit to power. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new auxiliary coolant pump as required. Clear DTC and retest
B1D27-13	Heater Coolant Pump - Circuit open		▪ Refer to the electrical circuit diagrams and check the auxiliary coolant pump circuit for open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new

		NOTES: ▪ This DTC will log with the ignition set to on for a minimum of 7 seconds or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Circuit reference - AUX WATER PUMP	auxiliary coolant pump as required. Clear DTC and retest
B1D29-93	No Start, Even After Restart Attempt - No	▪ Fuel fired booster heater fuel pipe	

operation

blocked/leaking

- Fuel fired booster heater exhaust restricted following driving through deep water or extreme off-road driving
- Fuel fired booster heater evaporator assembly contaminated with water or debris ingress following driving through deep water or extreme off-road driving
- Fuel fired booster heater internal failure

NOTES:

- This DTC is set when no flame is detected, even after re-start attempt
 - If additional fuel fired booster heater related DTCs are also set, perform the relevant corrective action(s) first
-
- Check the fuel fired booster heater fuel pipe for blockages/leaks and replace as required
 - If the fuel fired booster heater fuel pipe is replaced then, using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Fuel Priming (0x9009)
 - Check the fuel fired booster heater exhaust for blockages and rectify as required
 - Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be

			performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater ▪ If a fuel fired booster heater fault persists, replace the fuel fired booster heater combustion tube and evaporator assembly, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A) ▪ If the fault persists, install a new fuel fired booster heater, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A)
B1D33-92	Flame Interruption During Normal	▪ Fuel fired booster heater fuel pipe	

Operation -
Performance or
incorrect operation

blocked/leaking

- Fuel fired booster heater exhaust restricted following driving through deep water or extreme off-road driving
- Fuel fired booster heater evaporator assembly contaminated with water or debris ingress following driving through deep water or extreme off-road driving
- Fuel fired booster heater internal failure

NOTES:

- This DTC is set when no flame is detected, even after re-start attempt
- If additional fuel fired booster heater related DTCs are also set, perform the relevant corrective action(s) first

- Check the fuel fired booster heater fuel pipe for blockages/leaks and replace as required
- If the fuel fired booster heater fuel pipe is replaced then, using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Fuel Priming (0x9009)
- Check the fuel fired booster heater exhaust for blockages and rectify as required
- Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be

			performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater ▪ If a fuel fired booster heater fault persists, replace the fuel fired booster heater combustion tube and evaporator assembly, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A) ▪ If the fault persists, install a new fuel fired booster heater, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A)
B1D34-66	Heater In Lock Out Mode - Signal has too	▪ Fuel fired booster heater fuel pipe	

many transitions/events

blocked/leaking

- Fuel fired booster heater exhaust restricted following driving through deep water or extreme off-road driving
- Fuel fired booster heater evaporator assembly contaminated with water or debris ingress following driving through deep water or extreme off-road driving
- Fuel fired booster heater internal failure

NOTES:

- This DTC is set when the fuel fired booster heater repeatedly fails to operate
- If additional fuel fired booster heater related DTCs are also set, perform the relevant corrective action(s) first

- Check the fuel fired booster heater fuel pipe for blockages/leaks and replace as required
- If the fuel fired booster heater fuel pipe is replaced then, using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Fuel Priming (0x9009)
- Check the fuel fired booster heater exhaust for blockages and rectify as required
- Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The

			routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater ■ If a fuel fired booster heater fault persists, replace the fuel fired booster heater combustion tube and evaporator assembly, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A) ■ If the fault persists, install a new fuel fired booster heater, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A)	
P0530-	A/C Refrigerant		■ Refer to the electrical	

11	Pressure Sensor A Circuit - Circuit short to ground	NOTE: This DTC will log with the engine running for a minimum of 30 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Refrigerant pressure sensor signal circuit short circuit to ground - Refrigerant pressure sensor internal failure	circuit diagrams and check the refrigerant pressure sensor signal circuit for short circuit to ground. Repair circuit as required, clear DTC and retest If fault persists, check and install a new refrigerant pressure sensor as required. Clear DTC and retest
P0530-15	A/C Refrigerant Pressure Sensor A Circuit - Circuit short to battery or open		- Refer to the electrical circuit diagrams and check the refrigerant pressure sensor signal circuit for short circuit to power, open circuit, high resistance. Repair circuit as required, clear DTC and retest - If fault persists, check and install a new

		NOTE: This DTC will log with the engine running for a minimum of 30 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Refrigerant pressure sensor signal circuit short circuit to power, open circuit, high resistance - Refrigerant pressure sensor internal failure	refrigerant pressure sensor as required. Clear DTC and retest
P06A1-11	Variable A/C Compressor Control Circuit Low - Circuit short to ground	NOTE: This DTC will log with the engine running for a minimum of 7 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Air conditioning compressor solenoid circuit short circuit to ground - Air conditioning compressor solenoid	- Refer to the electrical circuit diagrams and check the air conditioning compressor solenoid circuit for short circuit to ground. Repair circuit as required, clear DTC and retest - If fault persists, check and install a new air conditioning compressor solenoid as required. Clear DTC and retest

		internal failure	
P06A1-12	Variable A/C Compressor Control Circuit Low - Circuit short to battery	NOTE: This DTC will log with the engine running for a minimum of 7 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system - Air conditioning compressor solenoid circuit short circuit to power - Air conditioning compressor solenoid internal failure	- Refer to the electrical circuit diagrams and check the air conditioning compressor solenoid circuit for short circuit to power. Repair circuit as required, clear DTC and retest - If fault persists, check and install a new air conditioning compressor solenoid as required. Clear DTC and retest
P06A1-13	Variable A/C Compressor Control Circuit Low - Circuit open	NOTE: This DTC will log with the engine running for a minimum of 7 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Air conditioning compressor solenoid circuit open circuit,	- Refer to the electrical circuit diagrams and check the air conditioning compressor solenoid circuit for open circuit, high resistance. Repair circuit as required, clear DTC and retest - If fault persists, check and install a new air conditioning compressor solenoid as required. Clear DTC and retest

		high resistance ▪ Air conditioning compressor solenoid internal failure	
P06A2-11	Variable A/C Compressor Control Circuit High - Circuit short to ground	NOTE: This DTC will log with the engine running for a minimum of 7 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Air conditioning compressor solenoid circuit short circuit to ground ▪ Air conditioning compressor solenoid internal failure	▪ Refer to the electrical circuit diagrams and check the air conditioning compressor solenoid circuit for short circuit to ground. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new air conditioning compressor solenoid as required. Clear DTC and retest
P06A2-12	Variable A/C Compressor Control Circuit High - Circuit short to battery	NOTE: This DTC will log with the engine running for a minimum of 7 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system	▪ Refer to the electrical circuit diagrams and check the air conditioning compressor solenoid circuit for short circuit to power. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new air conditioning compressor solenoid as required. Clear DTC and retest

		▪ Air conditioning compressor solenoid circuit short circuit to power ▪ Air conditioning compressor solenoid internal failure	
P06A2-13	Variable A/C Compressor Control Circuit High - Circuit open	NOTE: This DTC will log with the engine running for a minimum of 7 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Air conditioning compressor solenoid circuit open circuit, high resistance ▪ Air conditioning compressor solenoid internal failure	▪ Refer to the electrical circuit diagrams and check the air conditioning compressor solenoid circuit for open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new air conditioning compressor solenoid as required. Clear DTC and retest
P1308-11	A/C Clutch Circuit - Circuit short to ground	NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system	▪ Refer to the electrical circuit diagrams and check the air conditioning compressor clutch circuit for short circuit to ground. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new air conditioning compressor clutch as required. Clear DTC and retest

		▪ Air conditioning compressor clutch circuit short circuit to ground ▪ Air conditioning compressor clutch internal failure	
P1308-12	A/C Clutch Circuit - Circuit short to battery	NOTE: This DTC will log with the engine running for a minimum of 7 seconds. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Air conditioning compressor clutch circuit short circuit to power ▪ Air conditioning compressor clutch internal failure	▪ Refer to the electrical circuit diagrams and check the air conditioning compressor clutch circuit for short circuit to power. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new air conditioning compressor clutch as required. Clear DTC and retest
P1308-13	A/C Clutch Circuit - Circuit open		▪ Refer to the electrical circuit diagrams and check the air conditioning compressor clutch circuit for open circuit, high resistance. Repair circuit as required, clear DTC and retest ▪ If fault persists, check and install a new air conditioning compressor clutch as required. Clear DTC

		NOTE: This DTC will log with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system ▪ Air conditioning compressor clutch circuit open circuit, high resistance ▪ Air conditioning compressor clutch internal failure	and retest
U0010-88	Medium Speed CAN Communication Bus - Bus off	▪ Medium speed CAN bus (comfort) circuit short circuit to ground, short circuit to power, open circuit, high resistance	▪ Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the medium speed CAN bus (comfort) circuit for short circuit to ground, short circuit to power, open circuit, high resistance
U0300-00	Internal Control Module Software Incompatibility - No sub type information	▪ Car configuration file mismatch with vehicle specification ▪ Incorrect automatic temperature control module installed	▪ Using the manufacturer approved diagnostic system, check and update the car configuration file as necessary ▪ Install a new automatic temperature control module as necessary

U1000-00	Solid State Driver Protection Activated - Driver Disabled - No sub type information	Control module internal output driver is disabled due to a fault condition detected on an output circuit to protect the control module. Another DTC will be logged to show which specific output has the error	NOTE: The fault must be rectified on the output circuit before the DTC is cleared. Repeated logs of this diagnostic trouble code will result in unrecoverable control module shut down to prevent module damage Check the automatic temperature control module for output circuit DTCs and perform the relevant corrective action
U2101-56	Control Module Configuration Incompatible - Invalid / incomplete configuration	Car configuration file mismatch with vehicle specification	Using the manufacturer approved diagnostic system, check and update the car configuration file as necessary
U3000-01	Control Module - General electrical failure		Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new automatic temperature control module

		NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Automatic temperature control module internal failure	
U3000-48	Control Module - Supervision software failure	NOTE: This DTC will log with the ignition set to on or with the engine running. When it is repaired, it will self-delete with age, or instantly using the manufacturer approved diagnostic system Fuel fired booster heater internal failure	- Using the manufacturer approved diagnostic system, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A). This will operate the fuel fired booster heater for 15 minutes. Note that the routine should be started only when the engine is cool. The routine should be performed with the engine running and with the climate controls set to maximum heat and maximum fan. Repeat the routine again if smoke continues to be visible from the fuel fired booster heater exhaust pipe or from the area surrounding the fuel fired booster heater - If the fault persists,

			install a new fuel fired booster heater, clear the DTCs and perform routine - Auxiliary Heater (AHCM) Activation Test (0x900A)
U3000-87	Control Module - Missing message	▪ Car configuration file mismatch with vehicle specification	▪ Using the manufacturer approved diagnostic system, check and update the car configuration file as necessary
U3003-62	Battery Voltage - Signal compare failure	▪ Mismatch between the voltage at the automatic temperature control module and the voltage value broadcast on the CAN bus	▪ Using the manufacturer approved diagnostic system, check datalogger signal - ECU Power Supply Voltage (0xD111) - and compare it to battery voltage