

2016.0 RANGE ROVER (LG), 100-00

GENERAL INFORMATION

DESCRIPTION AND OPERATION

DEPLOYABLE SIDESTEP CONTROL MODULE (DSCM)

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.

NOTES:

- If a control module or a component is suspect and the vehicle remains under manufacturer warranty, refer to the Warranty Policy and Procedures manual, or determine if any prior approval programme is in operation, prior to the installation of a new module/component.
- Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system).
- When performing voltage or resistance tests, always use a digital multimeter accurate to three decimal places, and with an up-to-date calibration certificate. When testing resistance always take the resistance of the digital multimeter leads into account.
- Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.
- Inspect connectors for signs of water ingress, and pins for damage and/or corrosion.
- If DTCs are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always check for loose connections and corroded terminals.
- Check DDW for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and carry out the recommendations as required.

The table below lists all Diagnostic Trouble Codes (DTCs) that could be logged in the Deployable Sidestep Control Module (DSCM). For additional diagnosis and testing information, refer to the relevant Diagnosis and Testing section in the workshop manual.

For additional information, refer to: [Retractable Running Board](#) (501-08)

Exterior Trim and Ornamentation, Diagnosis and Testing).

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
C1002-77	Left Power Running Board Stow - Commanded position not reachable	1) Mechanical fault with the link 2) Output shaft torque ring slipping 3) Deployable sidestep motor assembly fault 4) Deployable sidestep mechanism fouled by snow, ice or other debris	1) If the deployable sidestep motor is rotating fast but the sidestep is not moving: 1a) Check the link assembly for a missing or damaged link wedge and install or replace the link wedge as required. Clear DTC and retest 1b) Check if the output shaft torque ring is slipping. If the ring is slipping, replace the deployable sidestep motor assembly as required. Clear DTC and retest 1c) Check for mechanical faults in the link assembly. If a fault is evident, replace the link assembly as required. Clear DTC and retest 2) If the deployable sidestep motor is rotating fast, the sidestep is moving and stows/deploys fully: - Check if the output shaft torque ring is slipping. If the ring is slipping, replace the deployable sidestep motor assembly as required. Clear DTC and retest 3) If the deployable sidestep motor is rotating slowly and stops before the sidestep has stowed/deployed fully: 3a) Check if the motor assembly is tight or seized. If a fault is evident, replace the deployable sidestep motor assembly as required. Clear DTC and retest 3b) Check if the link assembly pins are tight or seized. If a fault is evident, wash the deployable

			sidestep and retest. If fault persists, replace the link assembly as required. Clear DTC and retest ▪ 3c) Check for mechanical faults in the link assembly. If a fault is evident, replace the link assembly as required. Clear DTC and retest ▪ 4) If the deployable sidestep has been exposed to severe cold, snow or icy conditions: ▪ Wash/clear the deployable sidestep and retest
C1003-77	Right Power Running Board Stow - Commanded position not reachable	▪ 1) Mechanical fault with the link ▪ 2) Output shaft torque ring slipping ▪ 3) Deployable sidestep motor assembly fault ▪ 4) Deployable sidestep mechanism fouled by snow, ice or other debris	▪ 1) If the deployable sidestep motor is rotating fast but the sidestep is not moving: ▪ 1a) Check the link assembly for a missing or damaged link wedge and install or replace the link wedge as required. Clear DTC and retest ▪ 1b) Check if the output shaft torque ring is slipping. If the ring is slipping, replace the deployable sidestep motor assembly as required. Clear DTC and retest ▪ 1c) Check for mechanical faults in the link assembly. If a fault is evident, replace the link assembly as required. Clear DTC and retest ▪ 2) If the deployable sidestep motor is rotating fast, the sidestep is moving and stows/deploys fully: ▪ Check if the output shaft torque ring is slipping. If the ring is slipping, replace the deployable sidestep motor assembly as required. Clear DTC and retest ▪ 3) If the deployable sidestep

			motor is rotating slowly and stops before the sidestep has stowed/deployed fully: ▪ 3a) Check if the motor assembly is tight or seized. If a fault is evident, replace the deployable sidestep motor assembly as required. Clear DTC and retest ▪ 3b) Check if the link assembly pins are tight or seized. If a fault is evident, wash the deployable sidestep and retest. If fault persists, replace the link assembly as required. Clear DTC and retest ▪ 3c) Check for mechanical faults in the link assembly. If a fault is evident, replace the link assembly as required. Clear DTC and retest ▪ 4) If the deployable sidestep has been exposed to severe cold, snow or icy conditions: ▪ Wash/clear the deployable sidestep and retest
C1004-77	Right Power Running Board Deploy - Commanded position not reachable	▪ 1) Mechanical fault with the link ▪ 2) Output shaft torque ring slipping ▪ 3) Deployable sidestep motor assembly fault ▪ 4) Deployable sidestep mechanism fouled by snow, ice or other debris	▪ 1) If the deployable sidestep motor is rotating fast but the sidestep is not moving: ▪ 1a) Check the link assembly for a missing or damaged link wedge and install or replace the link wedge as required. Clear DTC and retest ▪ 1b) Check if the output shaft torque ring is slipping. If the ring is slipping, replace the deployable sidestep motor assembly as required. Clear DTC and retest ▪ 1c) Check for mechanical faults in the link assembly. If a fault is evident, replace the link assembly as required. Clear DTC and

			retest ■ 2) If the deployable sidestep motor is rotating fast, the sidestep is moving and stows/deploys fully: ■ Check if the output shaft torque ring is slipping. If the ring is slipping, replace the deployable sidestep motor assembly as required. Clear DTC and retest ■ 3) If the deployable sidestep motor is rotating slowly and stops before the sidestep has stowed/deployed fully: ■ 3a) Check if the motor assembly is tight or seized. If a fault is evident, replace the deployable sidestep motor assembly as required. Clear DTC and retest ■ 3b) Check if the link assembly pins are tight or seized. If a fault is evident, wash the deployable sidestep and retest. If fault persists, replace the link assembly as required. Clear DTC and retest ■ 3c) Check for mechanical faults in the link assembly. If a fault is evident, replace the link assembly as required. Clear DTC and retest ■ 4) If the deployable sidestep has been exposed to severe cold, snow or icy conditions: ■ Wash/clear the deployable sidestep and retest
C1005-77	Left Power Running Board Deploy - Commanded position not reachable	■ 1) Mechanical fault with the link ■ 2) Output shaft torque ring slipping ■ 3) Deployable sidestep motor assembly fault	■ 1) If the deployable sidestep motor is rotating fast but the sidestep is not moving: ■ 1a) Check the link assembly for a missing or damaged link wedge and install or replace the link wedge as required. Clear DTC and retest

- | | |
|--|---|
| <ul style="list-style-type: none"> 4) Deployable sidestep mechanism fouled by snow, ice or other debris | <ul style="list-style-type: none"> 1b) Check if the output shaft torque ring is slipping. If the ring is slipping, replace the deployable sidestep motor assembly as required. Clear DTC and retest 1c) Check for mechanical faults in the link assembly. If a fault is evident, replace the link assembly as required. Clear DTC and retest 2) If the deployable sidestep motor is rotating fast, the sidestep is moving and stows/deploys fully: <ul style="list-style-type: none"> Check if the output shaft torque ring is slipping. If the ring is slipping, replace the deployable sidestep motor assembly as required. Clear DTC and retest 3) If the deployable sidestep motor is rotating slowly and stops before the sidestep has stowed/deployed fully: <ul style="list-style-type: none"> 3a) Check if the motor assembly is tight or seized. If a fault is evident, replace the deployable sidestep motor assembly as required. Clear DTC and retest 3b) Check if the link assembly pins are tight or seized. If a fault is evident, wash the deployable sidestep and retest. If fault persists, replace the link assembly as required. Clear DTC and retest 3c) Check for mechanical faults in the link assembly. If a fault is evident, replace the link assembly as required. Clear DTC and retest 4) If the deployable sidestep has been exposed to severe cold, snow or icy conditions: <ul style="list-style-type: none"> Wash/clear the deployable |
|--|---|

			sidestep and retest
C1006-11	Left Power Running Board Motor - Circuit short to ground	NOTE: - Circuit reference LH DEPLOY / LH STOW - - Left deployable sidestep motor circuit(s) short circuit to ground 1) Deployable sidestep motor internal failure 2) Harness failure 3) Deployable sidestep control module internal failure	- If the deployable sidestep is not moving, refer to the electrical circuit diagrams and check the resistance between the left deployable sidestep deploy circuit and the vehicle ground. If the resistance is less than 0.5 kOhms: 1) Unplug the deployable sidestep motor connector and measure the resistance between the motor harness (pins 1 and 5) and the vehicle ground. If the resistance is less than 0.5 kOhms, replace the deployable sidestep motor assembly as required. Clear DTC and retest 2) Unplug the vehicle harness connector from deployable sidestep control module and measure the resistance between the harness (pins 1 and 5) and the vehicle ground. If the resistance is less than 0.5 kOhms, replace the harness as required. Clear DTC and retest - If the deployable sidestep is not moving: 3) Refer to the electrical circuit diagrams and check the resistance between the left deployable sidestep deploy circuit and the left deployable sidestep stow circuit to the vehicle ground. If the resistance is greater than 1 kOhms, this indicates a possible fault with the deployable sidestep control module. Clear DTC and retest. If the fault persists, replace the deployable sidestep control module as required - If the deployable sidestep

			control module is replaced, the new module requires initialization. Once the module is connected, press and hold down the deployable sidestep switch for over 3 seconds. The deployable sidestep status LED will flash three times to indicate the system has initialized
C1006-12	Left Power Running Board Motor - Circuit short to battery	NOTE: - Circuit reference LH DEPLOY / LH STOW - - Left deployable sidestep motor circuit(s) short circuit to power 1) Harness failure	1) Refer to the electrical circuit diagrams and check the left deployable sidestep deploy and stow circuits for short circuit to power. Repair circuit(s) as required. Clear DTC and retest
C1006-13	Left Power Running Board Motor - Circuit open	NOTE: - Circuit reference LH DEPLOY / LH STOW - - Left deployable sidestep motor circuit(s) open circuit, high resistance 1) Harness failure 2) Deployable sidestep motor internal failure	- Refer to the electrical circuit diagrams and check the left deployable sidestep deploy and stow circuits for open circuit, high resistance: 1) If the deployable sidestep is not moving and no voltage is present between the deploy and stow circuits when disconnected from the motor, repair or replace the vehicle harness as required. Clear DTC and retest 2) If the deployable sidestep is not moving and voltage is present between the deploy and stow circuits when disconnected from the motor, repair the faulty motor harness or replace the deployable sidestep motor assembly as required. Clear DTC and retest

C1006-19	Left Power Running Board Motor - Circuit current above threshold	NOTE: - Circuit reference LH DEPLOY / LH STOW - - Left deployable sidestep motor circuit short circuit to ground, short circuit to power 1) Harness failure 2) Deployable sidestep motor internal failure	- Refer to the electrical circuit diagrams, unplug the harness from the deployable sidestep motor and check the left deployable sidestep deploy and stow circuits for short circuit to ground, short circuit to power: 1) If the deployable sidestep is not moving and a short circuit is present at the deploy or stow circuits when disconnected from the motor, repair or replace the vehicle harness as required. Clear DTC and retest 2) If the deployable sidestep is not moving and a short circuit cannot be detected at the deploy or stow circuits when disconnected from the motor, check for short circuit between the corresponding motor pins. If a short is detected at the motor, replace the deployable sidestep motor assembly as required. Clear DTC and retest
C1006-67	Left Power Running Board Motor - Signal incorrect after event	- Deployable sidestep control module no current detected when motor being driven 1) Harness failure 2) Deployable sidestep motor overheat 3) Deployable sidestep control module internal failure	- Refer to the electrical circuit diagrams and check the left deployable sidestep deploy and stow circuits for open circuit, high resistance: 1) If the deployable sidestep is not moving and no voltage is present between the deploy and stow circuits when disconnected from the motor, repair or replace the vehicle harness as required. Clear DTC and retest 2) Allow time for the deployable sidestep motor to cool. Clear DTC and retest 3) If the fault persists, install a new deployable sidestep control module

			▪ If the deployable sidestep control module is replaced, the new module requires initialization. Once the module is connected, press and hold down the deployable sidestep switch for over 3 seconds. The deployable sidestep status LED will flash three times to indicate the system has initialized
C1007-11	Right Power Running Board Motor - Circuit short to ground	NOTE: - Circuit reference RH DEPLOY / RH STOW - ▪ Right deployable sidestep motor circuit(s) short circuit to ground ▪ 1) Deployable sidestep motor internal failure ▪ 2) Harness failure ▪ 3) Deployable sidestep control module internal failure	▪ If the deployable sidestep is not moving, refer to the electrical circuit diagrams and check the resistance between the right deployable sidestep deploy circuit and the vehicle ground. If the resistance is less than 0.5 kOhms: ▪ 1) Unplug the deployable sidestep motor connector and measure the resistance between the motor harness (pins 1 and 5) and the vehicle ground. If the resistance is less than 0.5 kOhms, replace the deployable sidestep motor assembly as required. Clear DTC and retest ▪ 2) Unplug the vehicle harness connector from deployable sidestep control module and measure the resistance between the harness (pins 1 and 5) and the vehicle ground. If the resistance is less than 0.5 kOhms, replace the harness as required. Clear DTC and retest ▪ If the deployable sidestep is not moving: ▪ 3) Refer to the electrical circuit diagrams and check the resistance between the right deployable sidestep deploy circuit and the right deployable sidestep stow circuit to the vehicle ground. If the resistance is greater than 1 kOhms, this

			indicates a possible fault with the deployable sidestep control module. Clear DTC and retest. If the fault persists, replace the deployable sidestep control module as required ▪ If the deployable sidestep control module is replaced, the new module requires initialization. Once the module is connected, press and hold down the deployable sidestep switch for over 3 seconds. The deployable sidestep status LED will flash three times to indicate the system has initialized
C1007-12	Right Power Running Board Motor - Circuit short to battery	NOTE: - Circuit reference RH DEPLOY / RH STOW - ▪ Right deployable sidestep motor circuit(s) short circuit to power ▪ 1) Harness failure	▪ 1) Refer to the electrical circuit diagrams and check the right deployable sidestep deploy and stow circuits for short circuit to power. Repair circuit(s) as required. Clear DTC and retest
C1007-13	Right Power Running Board Motor - Circuit open	NOTE: - Circuit reference RH DEPLOY / RH STOW - ▪ Right deployable sidestep motor circuit(s) open circuit, high resistance ▪ 1) Harness failure	▪ Refer to the electrical circuit diagrams and check the right deployable sidestep deploy and stow circuits for open circuit, high resistance: ▪ 1) If the deployable sidestep is not moving and no voltage is present between the deploy and stow circuits when disconnected from the motor, repair or replace the vehicle harness as required. Clear DTC and retest ▪ 2) If the deployable sidestep is not moving and

		2) Deployable sidestep motor internal failure	voltage is present between the deploy and stow circuits when disconnected from the motor, repair the faulty motor harness or replace the deployable sidestep motor assembly as required. Clear DTC and retest
C1007-19	Right Power Running Board Motor - Circuit current above threshold	NOTE: - Circuit reference RH DEPLOY / RH STOW - - Right deployable sidestep motor circuit short circuit to ground, short circuit to power 1) Harness failure 2) Deployable sidestep motor internal failure	- Refer to the electrical circuit diagrams, unplug the harness from the deployable sidestep motor and check the right deployable sidestep deploy and stow circuits for short circuit to ground, short circuit to power: 1) If the deployable sidestep is not moving and a short circuit is present at the deploy or stow circuits when disconnected from the motor, repair or replace the vehicle harness as required. Clear DTC and retest 2) If the deployable sidestep is not moving and a short circuit cannot be detected at the deploy or stow circuits when disconnected from the motor, check for short circuit between the corresponding motor pins. If a short is detected at the motor, replace the deployable sidestep motor assembly as required. Clear DTC and retest
C1007-67	Right Power Running Board Motor - Signal incorrect after event	- Deployable sidestep control module no current detected when motor being driven 1) Harness failure 2) Deployable sidestep motor overheat 3) Deployable	- Refer to the electrical circuit diagrams and check the right deployable sidestep deploy and stow circuits for open circuit, high resistance: 1) If the deployable sidestep is not moving and no voltage is present between the deploy and stow circuits when disconnected from the

		sidestep control module internal failure	motor, repair or replace the vehicle harness as required. Clear DTC and retest 2) Allow time for the deployable sidestep motor to cool. Clear DTC and retest 3) If the fault persists, install a new deployable sidestep control module - If the deployable sidestep control module is replaced, the new module requires initialization. Once the module is connected, press and hold down the deployable sidestep switch for over 3 seconds. The deployable sidestep status LED will flash three times to indicate the system has initialized
C1008-3A	Left Power Running Board Position/Motion Sensor - Incorrect has too many pulses	1) Output shaft torque ring slipping 2) Deployable side step wedge missing 3) Deployable side step motor internal failure	- If the deployable sidestep deploys or stows fully, but the motor continues to operate after the board completes the movement: 1) Check if the output shaft torque ring is slipping. If the ring is slipping, replace the deployable sidestep motor assembly as required. Clear DTC and retest 2) If the deployable sidestep motor is operating for 4 seconds then stops but the sidestep does not move: 2a) Check the link assembly for a missing or damaged link wedge and install or replace the link wedge as required. Clear DTC and retest 2b) Check for mechanical faults in the link assembly. If a fault is evident, replace the link assembly as required. Clear DTC and retest 3) Check if the output shaft torque ring is slipping. If the

			ring is slipping, replace the deployable sidestep motor assembly as required. Clear DTC and retest
C1008-93	Left Power Running Board Position/Motion Sensor - No operation	NOTE: - Circuit reference HALL SENSOR LH - ▪ Left deployable sidestep motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ 1) Harness failure ▪ 2) Deployable sidestep motor position sensor failure	▪ 1) Refer to the electrical circuit diagrams and check the left deployable sidestep motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear DTC and retest ▪ 2) If fault persists, replace the deployable sidestep motor assembly as required. Clear DTC and retest
C1009-3A	Right Power Running Board Position/Motion Sensor - Incorrect has too many pulses	▪ 1) Output shaft torque ring slipping ▪ 2) Deployable side step wedge missing ▪ 3) Deployable side step motor internal failure	▪ If the deployable sidestep deploys or stows fully, but the motor continues to operate after the board completes the movement: ▪ 1) Check if the output shaft torque ring is slipping. If the ring is slipping, replace the deployable sidestep motor assembly as required. Clear DTC and retest ▪ 2) If the deployable sidestep motor is operating for 4 seconds then stops but the sidestep does not move: ▪ 2a) Check the link assembly for a missing or damaged link wedge and install or replace the link wedge as required. Clear DTC and retest ▪ 2b) Check for mechanical

			faults in the link assembly. If a fault is evident, replace the link assembly as required. Clear DTC and retest 3) Check if the output shaft torque ring is slipping. If the ring is slipping, replace the deployable sidestep motor assembly as required. Clear DTC and retest
C1009-93	Right Power Running Board Position/Motion Sensor - No operation	NOTE: - Circuit reference HALL SENSOR RH - - Right deployable sidestep motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance 1) Harness failure 2) Deployable sidestep motor position sensor failure	1) Refer to the electrical circuit diagrams and check the right deployable sidestep motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear DTC and retest 2) If fault persists, replace the deployable sidestep motor assembly as required. Clear DTC and retest
C1B14-11	Sensor Supply Voltage A - Circuit short to ground	NOTE: - Circuit reference HALL SENSOR +VE - - Deployable sidestep motor position sensor supply circuit short circuit to ground 1) Harness failure	- Refer to the electrical circuit diagrams and check the deployable sidestep motor position sensor supply circuit for short circuit to ground - Disconnect the deployable sidestep motor and check the voltage between the sidestep motor position sensor supply circuit and ground: 1) If there is no voltage present, unplug the vehicle harness from the deployable sidestep control module and check the

		2) Deployable side step motor internal failure	harness for short circuit, repair or replace harness as required. If no fault is found with the harness, replace the deployable sidestep control module. Clear DTC and retest 2) If voltage is detected between the sidestep motor position sensor supply circuit and ground when the harness is disconnected from the deployable sidestep motor, replace the motor as required. Clear DTC and retest
C1B14-12	Sensor Supply Voltage A - Circuit short to battery	NOTE: - Circuit reference HALL SENSOR +VE - - Deployable sidestep motor position sensor supply circuit short circuit to power 1) Harness failure 2) Deployable side step motor internal failure	NOTE: Perform this test when the vehicle has entered sleep mode (doors closed > 5 minutes) - Refer to the electrical circuit diagrams and check the deployable sidestep motor position sensor supply circuit for short circuit to power - Disconnect the deployable sidestep motor and check the voltage between the sidestep motor position sensor supply circuit and ground: 1) If voltage is detected, unplug the vehicle harness from the deployable sidestep control module and check the harness for short circuit to power, repair or replace harness as required. If no fault is found with the harness, replace the deployable sidestep control module. Clear DTC and retest 2) If voltage is not present between the sidestep

			motor position sensor supply circuit and ground when the harness is disconnected from the deployable sidestep motor, check the motor harness or short circuit to power. Repair the motor harness or replace the motor as required. Clear DTC and retest
U0010-88	Medium Speed CAN Communication Bus - Bus off	Medium speed CAN bus (body) circuit short circuit to ground, short circuit to power, open circuit, high resistance	Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the medium speed CAN bus (body) circuit for short circuit to ground, short circuit to power, open circuit, high resistance
U0121-68	Lost Communication With Anti-Lock Brake System (ABS) Control Module - Event information	1) Anti-lock brake system control module power or ground circuit open circuit, high resistance 2) High speed CAN bus (chassis or powertrain) circuit short circuit to ground, short circuit to power, open circuit, high resistance 3) Missing/invalid data from the anti-lock brake system control module	1) Refer to the electrical circuit diagrams and check the anti-lock brake system control module power and ground circuits for open circuit, high resistance 2) Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the high speed CAN bus (chassis and powertrain) circuit for short circuit to ground, short circuit to power, open circuit, high resistance 3) Using the manufacturer approved diagnostic system, check the anti-lock brake system control module for related DTCs and refer to the relevant DTC index
U0140-00	Lost Communication With Body Control Module	1) Central junction box power or ground circuit open circuit, high	1) Refer to the electrical circuit diagrams and check the central junction box power and ground circuits for open circuit, high

	- No sub type information	resistance 2) Medium speed CAN bus (body) circuit short circuit to ground, short circuit to power, open circuit, high resistance 3) Missing/invalid data from the central junction box	resistance 2) Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the medium speed CAN bus (body) circuit for short circuit to ground, short circuit to power, open circuit, high resistance 3) Using the manufacturer approved diagnostic system, check the central junction box for related DTCs and refer to the relevant DTC index
U0300-00	Internal Control Module Software Incompatibility - No sub type information	1) Car configuration file mismatch with vehicle specification 2) Incorrect deployable sidestep control module installed	1) Using the manufacturer approved diagnostic system, check and update the car configuration file as necessary 2) Install a new deployable sidestep control module as necessary
U0439-68	Invalid Data Received From All Terrain Control Module - Event information	Missing/invalid data from the terrain response switchpack	Using the manufacturer approved diagnostic system, check the terrain response switchpack for related DTCs and refer to the relevant DTC index
U1001-23	Switch Pack - Switch Circuit - Signal stuck low	NOTE: - Circuit reference INHIBIT SWITCH - 1) Deployable sidestep switch stuck active 2) Deployable sidestep switch circuit short circuit to ground	1) Test the operation of the deployable sidestep switch - Refer to the electrical circuit diagrams and check the deployable sidestep switch circuit for short circuit to ground 2) Disconnect the deployable sidestep control module from the vehicle and check for continuity between pin 5 (connector 2) and ground. If a short is detected, replace the faulty switch or repair/replace faulty harness as required. Clear DTC and retest

U1002-11	Switch Pack - Status Indicator Circuit - Circuit short to ground	NOTE: - Circuit reference STATUS LED - Deployable sidestep switch LED circuit short circuit to ground	Refer to the electrical circuit diagrams and check the deployable sidestep switch LED circuit for short circuit to ground. Repair circuit as required. Clear DTC and retest
U1002-12	Switch Pack - Status Indicator Circuit - Circuit short to battery	NOTE: - Circuit reference STATUS LED - Deployable sidestep switch LED circuit short circuit to power	Refer to the electrical circuit diagrams and check the deployable sidestep switch LED circuit for short circuit to power. Repair circuit as required. Clear DTC and retest
U2101-00	Control Module Configuration Incompatible - No sub type information	1) Car configuration file mismatch with vehicle specification 2) Insecure module connector	1) Using the manufacturer approved diagnostic system, check and update the car configuration file as necessary 2) Unplug the module then plug it back in to see if resolves the issue (loose connector)
U3000-41	Control Module - General checksum failure	- Deployable sidestep control module internal failure - RAM fault (data memory failure leading to possible corrupt local configuration file)	Using the manufacturer approved diagnostic system, reconfigure the deployable sidestep control module with the latest level software. Clear the DTCs and retest. If the fault persists, install a new deployable sidestep control module
U3000-	Control Module	Deployable sidestep	Using the manufacturer

49	- Internal electronic failure	control module internal failure	approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new deployable sidestep control module
U3000-52	Control Module - Not activated	▪ Deployable sidestep control module service mode active	▪ Using the manufacturer approved diagnostic system, run the diagnostic routine - Deactivate Running Board Service Mode - (0x300D)
U3003-16	Battery Voltage - Circuit voltage below threshold	▪ Deployable sidestep control module power or ground circuit open circuit, high resistance ▪ 1) Harness failure ▪ 2) Insecure module connector ▪ 3) Deployable sidestep control module internal failure ▪ 4) Battery/charging system fault	▪ Using the manufacturer approved diagnostic system, check datalogger signal - ECU Power Supply Voltage (0xD111). Refer to the electrical circuit diagrams and check the deployable sidestep control module power and ground circuits for open circuit, high resistance ▪ 1) If battery voltage is normal (around 12V) then unplug the module and measure voltage at the deployable sidestep control module power supply circuit, if voltage is less than battery voltage (-1 Volt for voltage drop across the wires) then check vehicle harness for short circuit to ground. Repair or replace vehicle harness as required. Clear DTC and retest ▪ 2) If the supply voltage at the module is normal, check the module connector for broken or bent pins, repair or replace the connector as required. Clear DTC and retest ▪ 3) If the fault persists, replace deployable sidestep control module. Clear DTC and retest ▪ 4) Refer to the relevant section of the workshop manual and test the battery and charging system

U3003-17	Battery Voltage - Circuit voltage above threshold	▪ Battery/charging system fault	▪ Using the manufacturer approved diagnostic system, check datalogger signal - ECU Power Supply Voltage (0xD111). Refer to the relevant section of the workshop manual and test the battery and charging system
U3003-62	Battery Voltage - Signal compare failure	▪ Deployable sidestep control module internal failure	▪ Clear DTC and retest. If the fault persists, replace the deployable sidestep control module