

2016.0 RANGE ROVER (LG), 100-00

GENERAL INFORMATION

DESCRIPTION AND OPERATION

DRIVER/PASSENGER/REAR -
LEFT/RIGHT SEAT MODULE
(DSM/PSM/RSM)

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable.
Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle

NOTES:

- If the control module or a component is suspect and the vehicle remains under manufacturer warranty, refer to the warranty policy and procedures manual, or determine if any prior approval programme is in operation, prior to the installation of a new module/component
- Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system)
- When performing voltage or resistance tests, always use a digital multimeter accurate to three decimal places and with a current calibration certificate. When testing resistance, always take the resistance of the digital multimeter leads into account
- Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests
- Inspect connectors for signs of water ingress, and pins for damage and/or corrosion
- If diagnostic trouble codes are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always check for loose connections and corroded terminals
- Where an 'on demand self-test' is referred to, this can be accessed via the 'diagnostic trouble code monitor' tab on the manufacturers approved diagnostic system
- Check DDW for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and carry out the recommendations as required

The table below lists all diagnostic trouble codes (DTCs) that could be logged in the Driver/Passenger/Rear - Left/Right Seat Module (DSM/PSM/RSM), for additional diagnosis and testing information refer to the relevant diagnosis and testing section.

For additional information, refer to: [Seats](#) (501-10A Seating - Standard Wheel Base, Diagnosis and Testing) /

[Seats - Vehicles With: Lumbar/Massage](#) (501-10A Seating - Standard Wheel Base, Diagnosis and Testing).

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B1087-88	LIN Bus "A" - Bus Off	NOTE: On vehicles fitted with 18-way specification seats, this LIN circuit connects the seat module to the seat switch pack; on vehicles fitted with 18-way business seats specification seats, this LIN circuit connects the seat module to the seat switch pack and the massage module; on vehicles fitted with 8-way specification seats, this LIN circuit connects the seat module to the seat switch pack - Seat switchpack LIN circuit short circuit to ground, short circuit to power, open circuit, high resistance - Seat switchpack power or ground circuit open circuit, high resistance - Seat switchpack internal	- Refer to the electrical circuit diagrams and check the seat switchpack LIN circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Refer to the electrical circuit diagrams and check the power and ground circuits of the modules/switchpacks connected to the LIN circuit for open circuit, high resistance - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, check the operation of the modules/switchpacks connected to the LIN circuit and replace as required

		failure	
B1088-01	LIN Bus "B" - General Electric Failure	NOTE: On vehicles fitted with 18-way specification seats, this LIN circuit connects the seat module to the rear seat switch pack; on vehicles fitted with 18-way business seats specification seats, this LIN circuit connects the seat module to the rear seat switch pack and the rear massage module - Seat switchpack LIN2 circuit short circuit to ground, short circuit to power, open circuit, high resistance - Seat switchpack power or ground circuit open circuit, high resistance - Seat switchpack internal failure	- Refer to the electrical circuit diagrams and check the seat switchpack LIN2 circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Refer to the electrical circuit diagrams and check the power and ground circuits of the modules/switchpacks connected to the LIN2 circuit for open circuit, high resistance - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, check the operation of the modules/switchpacks connected to the LIN2 circuit and replace as required
B12CC-00	Driver Seat Massage Module Pump Assembly - No sub type information	- Driver seat massage air pump circuit open circuit, high resistance - Driver seat massage air pump pneumatic hose leaking	NOTE: This DTC can only be set if the fault is detected during the Massage ECU On Demand Self Test routine Refer to the

			electrical circuit diagrams and check the driver seat massage air pump circuit for open circuit, high resistance Refer to the relevant section of the workshop manual and check the driver seat massage air pump pneumatic hoses
B12D9-00	Driver Seat Massage Module Back Carrier Assembly - No sub type information	- Driver seat massage slave solenoid circuit open circuit, high resistance - Driver seat massage slave solenoid pneumatic hose leaking/blocked	NOTE: This DTC can only be set if the fault is detected during the Massage ECU On Demand Self Test routine - Refer to the electrical circuit diagrams and check the driver seat massage slave solenoid circuit for open circuit, high resistance - Refer to the relevant section of the workshop manual and check the driver seat massage slave solenoid pneumatic hoses
B12DB-00	Passenger Seat Massage Module Pump Assembly - No sub type information	- Passenger seat massage air pump circuit open circuit, high resistance - Passenger seat massage	

		air pump pneumatic hose leaking	NOTE: This DTC can only be set if the fault is detected during the Massage ECU On Demand Self Test routine - Refer to the electrical circuit diagrams and check the passenger seat massage air pump circuit for open circuit, high resistance - Refer to the relevant section of the workshop manual and check the passenger seat massage air pump pneumatic hoses
B12E6-00	Passenger Seat Massage Module Back Carrier Assembly - No sub type information	- Passenger seat massage slave solenoid circuit open circuit, high resistance - Passenger seat massage slave solenoid pneumatic hose leaking/blocked	NOTE: This DTC can only be set if the fault is detected during the Massage ECU On Demand Self Test routine Refer to the electrical circuit diagrams and check the passenger seat massage slave solenoid circuit for open circuit, high

			resistance Refer to the relevant section of the workshop manual and check the passenger seat massage slave solenoid pneumatic hoses
B14EF-18	Bank 'A' motor #1 Output - Circuit current below threshold	- Seat height motor circuit short circuit to ground, short circuit to power - Seat height motor internal failure	NOTE: This DTC does not apply to 8-way specification seating - Refer to the electrical circuit diagrams and check the seat height motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest - If fault persists, install a new seat height motor
B14EF-19	Bank 'A' motor #1 Output - Circuit current above threshold	- Seat height motor circuit short circuit to ground, short circuit to power - Seat height motor internal failure	NOTE: This DTC does not apply to 8-way specification seating Refer to the electrical circuit diagrams and check the seat height

			motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ■ If fault persists, install a new seat height motor
B14F0-18	Bank 'A' motor #2 Output - Circuit current below threshold	■ All 18-way specification seating: Seat cushion extension motor circuit short circuit to ground, short circuit to power ■ All 18-way specification seating: Seat cushion extension motor internal failure ■ 8-way specification seating: Seat forward/rearward motor circuit short circuit to ground, short circuit to power ■ 8-way specification seating: Seat forward/rearward motor internal failure	■ All 18-way specification seating: Refer to the electrical circuit diagrams and check the seat cushion extension motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ■ All 18-way specification seating: If fault persists, install a new seat cushion extension motor ■ 8-way specification seating: Refer to the electrical circuit diagrams and check the seat forward/rearward motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ■ 8-way specification seating: If fault persists, install a new seat forward/rearward motor

B14F0-19	Bank 'A' motor #2 Output - Circuit current above threshold	■ All 18-way specification seating: Seat cushion extension motor circuit short circuit to ground, short circuit to power ■ All 18-way specification seating: Seat cushion extension motor internal failure ■ 8-way specification seating: Seat forward/rearward motor circuit short circuit to ground, short circuit to power ■ 8-way specification seating: Seat forward/rearward motor internal failure	■ All 18-way specification seating: Refer to the electrical circuit diagrams and check the seat cushion extension motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ■ All 18-way specification seating: If fault persists, install a new seat cushion extension motor ■ 8-way specification seating: Refer to the electrical circuit diagrams and check the seat forward/rearward motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ■ 8-way specification seating: If fault persists, install a new seat forward/rearward motor
B14F1-18	Bank 'A' motor #3 Output - Circuit current below threshold	■ All 18-way specification seating: Seat forward/rearward motor circuit short circuit to ground, short circuit to power ■ All 18-way specification seating: Seat forward/rearward motor internal failure ■ 8-way specification	■ All 18-way specification seating: Refer to the electrical circuit diagrams and check the seat forward/rearward motor circuit for short circuit to ground, short circuit to power. Repair circuit as required.

		seating: Seat height motor circuit short circuit to ground, short circuit to power 8-way specification seating: Seat height motor internal failure	Clear the DTCs and retest - All 18-way and specification seating: If fault persists, install a new seat forward/rearward motor 8-way specification seating: Refer to the electrical circuit diagrams and check the seat height motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest 8-way specification seating: If fault persists, install a new seat height motor
B14F1-19	Bank 'A' motor #3 Output - Circuit current above threshold	- All 18-way specification seating: Seat forward/rearward motor circuit short circuit to ground, short circuit to power - All 18-way specification seating: Seat forward/rearward motor internal failure 8-way specification seating: Seat height motor circuit short circuit to ground, short circuit to power 8-way specification seating: Seat height motor internal failure	- All 18-way specification seating: Refer to the electrical circuit diagrams and check the seat forward/rearward motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest - All 18-way specification seating: If fault persists, install a new seat forward/rearward motor 8-way specification seating: Refer to the electrical circuit diagrams and check the seat height

			motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest 8-way specification seating: If fault persists, install a new seat height motor
B14F2-18	Bank 'A' motor #4 Output - Circuit current below threshold	- All 18-way specification seating: Head restraint motor circuit short circuit to ground, short circuit to power - All 18-way specification seating: Head restraint motor internal failure	NOTE: This DTC does not apply to 8-way specification seating - Refer to the electrical circuit diagrams and check the head restraint motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest - If fault persists, install a new head restraint motor
B14F2-19	Bank 'A' motor #4 Output - Circuit current above threshold	- All 18-way specification seating: Head restraint motor circuit short circuit to ground, short circuit to power - All 18-way specification seating: Head restraint motor internal failure	NOTE: This DTC does not apply to 8-way specification seating Refer to the electrical circuit

			diagrams and check the head restraint motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ▪ If fault persists, install a new head restraint motor
B14F3-18	Bank 'B' motor #1 Output - Circuit current below threshold	▪ 18-way specification seating: Rear seat backrest two speed recline motor circuit short circuit to ground, short circuit to power ▪ 18-way specification seating: Rear seat backrest two speed recline motor internal failure ▪ 18-way business seats specification seating: Rear seat backrest recline motor circuit short circuit to ground, short circuit to power ▪ 18-way business seats specification seating: Rear seat backrest recline motor internal failure ▪ 8-way specification seating: Seat cushion tilt motor circuit short circuit to ground, short circuit to power ▪ 8-way specification seating: Seat cushion tilt motor internal failure	▪ 18-way specification seating: Refer to the electrical circuit diagrams and check the rear seat backrest two speed recline motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ▪ All 18-way specification seating: If fault persists, install a new rear seat backrest two speed recline motor ▪ 18-way business seats specification seating: Refer to the electrical circuit diagrams and check the rear seat backrest recline motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ▪ All 18-way business seats specification seating: If fault persists, install a new rear seat backrest

			recline motor 8-way specification seating: Refer to the electrical circuit diagrams and check the seat cushion tilt motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest 8-way specification seating: If fault persists, install a new seat cushion tilt motor
B14F3-19	Bank 'B' motor #1 Output - Circuit current above threshold	18-way specification seating: Rear seat backrest two speed recline motor circuit short circuit to ground, short circuit to power 18-way specification seating: Rear seat backrest two speed recline motor internal failure 18-way business seats specification seating: Rear seat backrest recline motor circuit short circuit to ground, short circuit to power 18-way business seats specification seating: Rear seat backrest recline motor internal failure 8-way specification seating: Seat cushion tilt motor circuit short circuit to ground, short circuit to power 8-way specification seating: Seat cushion tilt motor internal failure	18-way specification seating: Refer to the electrical circuit diagrams and check the rear seat backrest two speed recline motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest - All 18-way specification seating: If fault persists, install a new rear seat backrest two speed recline motor 18-way business seats specification seating: Refer to the electrical circuit diagrams and check the rear seat backrest recline motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and

			retest ■ All 18-way business seats specification seating: If fault persists, install a new rear seat backrest recline motor ■ 8-way specification seating: Refer to the electrical circuit diagrams and check the seat cushion tilt motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ■ 8-way specification seating: If fault persists, install a new seat cushion tilt motor
B14F4-18	Bank 'B' motor #2 Output - Circuit current below threshold	■ 18-way business seats specification seating: Rear seat upper backrest recline motor circuit short circuit to ground, short circuit to power ■ 18-way business seats specification seating: Rear seat upper backrest recline motor internal failure ■ 8-way specification seating: Seat backrest recline motor circuit short circuit to ground, short circuit to power ■ 8-way specification seating: Seat backrest recline motor internal failure	NOTE: This DTC only applies to 18-way business seats and 8-way specification seating ■ 18-way business seats specification seating: Refer to the electrical circuit diagrams and check the rear seat upper backrest recline motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest

			■ 18-way business seats specification seating: If fault persists, install a new rear seat upper backrest recline motor ■ 8-way specification seating: Refer to the electrical circuit diagrams and check the seat backrest recline motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ■ 8-way specification seating: If fault persists, install a new seat backrest recline motor
B14F4-19	Bank 'B' motor #2 Output - Circuit current above threshold	■ 18-way business seats specification seating: Rear seat upper backrest recline motor circuit short circuit to ground, short circuit to power ■ 18-way business seats specification seating: Rear seat upper backrest recline motor internal failure ■ 8-way specification seating: Seat backrest recline motor circuit short circuit to ground, short circuit to power ■ 8-way specification seating: Seat backrest recline motor internal failure	NOTE: This DTC only applies to 18-way business seats and 8-way specification seating ■ 18-way business seats specification seating: Refer to the electrical circuit diagrams and check the rear seat upper backrest recline motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ■ 18-way business

			seats specification seating: If fault persists, install a new rear seat upper backrest recline motor 8-way specification seating: Refer to the electrical circuit diagrams and check the seat backrest recline motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest 8-way specification seating: If fault persists, install a new seat backrest recline motor
B14F5-18	Bank 'B' Motor #3 Output - Circuit current below threshold	- Rear seat head restraint motor circuit short circuit to ground, short circuit to power - Rear seat head restraint motor internal failure	NOTE: This DTC only applies to 18-way business seats specification seating - Refer to the electrical circuit diagrams and check the rear seat head restraint motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest - If fault persists, install a new rear seat head restraint motor

B14F5-19	Bank 'B' Motor #3 Output - Circuit current above threshold	▪ Rear seat head restraint motor circuit short circuit to ground, short circuit to power ▪ Rear seat head restraint motor internal failure	NOTE: This DTC only applies to 18-way business seats specification seating ▪ Refer to the electrical circuit diagrams and check the rear seat head restraint motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ▪ If fault persists, install a new rear seat head restraint motor
B14F6-18	Bank 'B' Motor #4 Output - Circuit current below threshold	▪ Seat upper backrest recline motor circuit short circuit to ground, short circuit to power ▪ Seat upper backrest recline motor internal failure	NOTE: This DTC does not apply to 8-way specification seating ▪ Refer to the electrical circuit diagrams and check the seat upper backrest recline motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest

			▪ If fault persists, install a new seat upper backrest recline motor
B14F6-19	Bank 'B' Motor #4 Output - Circuit current above threshold	▪ Seat upper backrest recline motor circuit short circuit to ground, short circuit to power ▪ Seat upper backrest recline motor internal failure	NOTE: This DTC does not apply to 8-way specification seating ▪ Refer to the electrical circuit diagrams and check the seat upper backrest recline motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ▪ If fault persists, install a new seat upper backrest recline motor
B14F7-18	Bank 'C' motor #1 Output - Circuit current below threshold	▪ Seat cushion tilt motor circuit short circuit to ground, short circuit to power ▪ Seat cushion tilt motor internal failure	NOTE: This DTC does not apply to 8-way specification seating ▪ Refer to the electrical circuit diagrams and check the seat cushion tilt motor circuit for short circuit to ground, short circuit to power. Repair

			circuit as required. Clear the DTCs and retest ▪ If fault persists, install a new seat cushion tilt motor
B14F7-19	Bank 'C' motor #1 Output - Circuit current above threshold	▪ Seat cushion tilt motor circuit short circuit to ground, short circuit to power ▪ Seat cushion tilt motor internal failure	NOTE: This DTC does not apply to 8-way specification seating ▪ Refer to the electrical circuit diagrams and check the seat cushion tilt motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ▪ If fault persists, install a new seat cushion tilt motor
B14F8-18	Bank 'C' motor #2 Output - Circuit current below threshold	▪ Seat backrest recline motor circuit short circuit to ground, short circuit to power ▪ Seat backrest recline motor internal failure	NOTE: This DTC does not apply to 8-way specification seating ▪ Refer to the electrical circuit diagrams and check the seat backrest recline motor circuit for short circuit to ground, short circuit

			to power. Repair circuit as required. Clear the DTCs and retest ▪ If fault persists, install a new seat backrest recline motor
B14F8-19	Bank 'C' motor #2 Output - Circuit current above threshold	▪ Seat backrest recline motor circuit short circuit to ground, short circuit to power ▪ Seat backrest recline motor internal failure	NOTE: This DTC does not apply to 8-way specification seating ▪ Refer to the electrical circuit diagrams and check the seat backrest recline motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ▪ If fault persists, install a new seat backrest recline motor
B14F9-18	Bank 'D' motor #1 Output - Circuit current below threshold	▪ Rear seat cushion tilt motor circuit short circuit to ground, short circuit to power ▪ Rear seat cushion tilt motor internal failure	NOTE: This DTC only applies to 18-way business seats specification seating ▪ Refer to the electrical circuit diagrams and check

			the rear seat cushion tilt motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ▪ If fault persists, install a new rear seat cushion tilt motor
B14F9-19	Bank 'D' motor #1 Output - Circuit current above threshold	▪ Rear seat cushion tilt motor circuit short circuit to ground, short circuit to power ▪ Rear seat cushion tilt motor internal failure	NOTE: This DTC only applies to 18-way business seats specification seating ▪ Refer to the electrical circuit diagrams and check the rear seat cushion tilt motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest ▪ If fault persists, install a new rear seat cushion tilt motor
B14FA-18	Bank 'D' motor #2 Output - Circuit current below threshold	▪ Rear seat forward/rearward motor circuit short circuit to ground, short circuit to power ▪ Rear seat forward/rearward motor internal failure	NOTE: This DTC only applies to 18-way business seats specification seating

			- Refer to the electrical circuit diagrams and check the rear seat forward/rearward motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest - If fault persists, install a new rear seat forward/rearward motor
B14FA-19	Bank 'D' motor #2 Output - Circuit current above threshold	- Rear seat forward/rearward motor circuit short circuit to ground, short circuit to power - Rear seat forward/rearward motor internal failure	NOTE: This DTC only applies to 18-way business seats specification seating - Refer to the electrical circuit diagrams and check the rear seat forward/rearward motor circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest - If fault persists, install a new rear seat forward/rearward motor
B14FB-31	Bank 'A' Motor #1 Speed/Position	Seat height motor position sensor circuit	

	Sensor - No Signal	short circuit to ground, short circuit to power, open circuit, high resistance ▪ Seat height motor position sensor internal failure	NOTE: This DTC does not apply to 8-way specification seating ▪ Refer to the electrical circuit diagrams and check the seat height motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear the DTCs and retest ▪ If fault persists, install a new seat height motor
B14FC-31	Bank 'A' Motor #2 Speed/Position Sensor - No Signal	▪ All 18-way specification seating: Seat cushion extension motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ All 18-way specification seating: Seat cushion extension motor internal failure ▪ 8-way specification seating: Seat forward/rearward motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ 8-way specification seating: Seat forward/rearward motor	▪ All 18-way specification seating: Refer to the electrical circuit diagrams and check the seat cushion extension motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear the DTCs and retest ▪ All 18-way specification seating: If fault persists, install a new seat cushion extension motor ▪ 8-way specification

		internal failure	seating: Refer to the electrical circuit diagrams and check the seat forward/rearward motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear the DTCs and retest 8-way specification seating: If fault persists, install a new seat forward/rearward motor
B14FD-31	Bank 'A' Motor #3 Speed/Position Sensor - No Signal	- All 18-way specification seating: Seat forward/rearward motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance - All 18-way specification seating: Seat forward/rearward motor internal failure 8-way specification seating: Seat height motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance 8-way specification seating: Seat height motor position sensor internal failure	- All 18-way specification seating: Refer to the electrical circuit diagrams and check the seat forward/rearward motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear the DTCs and retest - All 18-way specification seating: If fault persists, install a new seat forward/rearward motor 8-way specification seating: Refer to the electrical circuit diagrams and check the seat height motor position

			sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear the DTCs and retest 8-way specification seating: If fault persists, install a new seat height motor
B14FE-31	Bank 'A' Motor #4 Speed/Position Sensor - No Signal	- Head restraint motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance - Head restraint motor internal failure	NOTE: This DTC does not apply to 8-way specification seating - Refer to the electrical circuit diagrams and check the head restraint motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear the DTCs and retest - If fault persists, install a new head restraint motor
B14FF-31	Bank 'B' Motor #1 Speed/Position Sensor - No Signal	18-way specification seating: Rear seat backrest two speed recline motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance	18-way specification seating: Refer to the electrical circuit diagrams and check the rear seat backrest two speed recline motor position sensor

			▪ 18-way specification seating: Rear seat backrest two speed recline motor position sensor internal failure ▪ 18-way business seats specification seating: Rear seat backrest recline motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ 18-way business seats specification seating: Rear seat backrest recline motor position sensor internal failure ▪ 8-way specification seating: Seat cushion tilt motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ 8-way specification seating: Seat cushion tilt motor internal failure	circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear the DTCs and retest ▪ 18-way specification seating: If fault persists, install a new rear seat backrest two speed recline motor ▪ 18-way business seats specification seating: Refer to the electrical circuit diagrams and check the rear seat backrest recline motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear the DTCs and retest ▪ 18-way business seats specification seating: If fault persists, install a new rear seat backrest recline motor ▪ 8-way specification seating: Refer to the electrical circuit diagrams and check the seat cushion tilt motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear the DTCs and retest
--	--	--	---	---

			8-way specification seating: If fault persists, install a new seat cushion tilt motor
B1500-31	Bank 'B' Motor #2 Speed/Position Sensor - No Signal	18-way business seats specification seating: Rear seat upper backrest recline motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance 18-way business seats specification seating: Rear seat upper backrest recline motor internal failure 8-way specification seating: Seat backrest recline motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance 8-way specification seating: Seat backrest recline motor internal failure	NOTE: This DTC only applies to 18-way business seats and 8-way specification seating 18-way business seats specification seating: Refer to the electrical circuit diagrams and check the rear seat upper backrest recline motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear the DTCs and retest 18-way business seats specification seating: If fault persists, install a new rear seat upper backrest recline motor 8-way specification seating: Refer to the electrical circuit diagrams and check the seat backrest recline motor position sensor circuit for short circuit to ground, short circuit to

			power, open circuit, high resistance. Repair circuit as required. Clear the DTCs and retest 8-way specification seating: If fault persists, install a new seat backrest recline motor
B1501-31	Bank 'B' Motor #3 Speed/Position Sensor - No Signal	- Rear seat head restraint motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance - Rear seat head restraint motor internal failure	NOTE: This DTC only applies to 18-way business seats specification seating - Refer to the electrical circuit diagrams and check the rear seat head restraint motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear the DTCs and retest - If fault persists, install a new rear seat head restraint motor
B1502-31	Bank 'B' Motor #4 Speed/Position Sensor - No Signal	- Seat upper backrest recline motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance - Seat upper backrest recline motor internal	NOTE: This DTC does not apply to 8-way specification seating

		failure	- Refer to the electrical circuit diagrams and check the seat upper backrest recline motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear the DTCs and retest - If fault persists, install a new seat upper backrest recline motor
B1503-31	Bank 'C' Motor #1 Speed/Position Sensor - No Signal	- Seat cushion tilt motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance - Seat cushion tilt motor internal failure	NOTE: This DTC does not apply to 8-way specification seating - Refer to the electrical circuit diagrams and check the seat cushion tilt motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear the DTCs and retest - If fault persists, install a new seat cushion tilt motor
B1504-	Bank 'C' Motor #2	Seat backrest recline	

31	Speed/Position Sensor - No Signal	motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Seat backrest recline motor internal failure	NOTE: This DTC does not apply to 8-way specification seating ▪ Refer to the electrical circuit diagrams and check the seat backrest recline motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear the DTCs and retest ▪ If fault persists, install a new seat backrest recline motor
B1505-31	Bank 'D' Motor #1 Speed/Position Sensor - No Signal	▪ Rear seat cushion tilt motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Rear seat cushion tilt motor internal failure	NOTE: This DTC only applies to 18-way business seats specification seating ▪ Refer to the electrical circuit diagrams and check the rear seat cushion tilt motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair

			circuit as required. Clear the DTCs and retest ▪ If fault persists, install a new rear seat cushion tilt motor
B1506-31	Bank 'D' Motor #2 Speed/Position Sensor - No Signal	▪ Rear seat forward/rearward motor position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Rear seat forward/rearward motor internal failure	NOTE: This DTC only applies to 18-way business seats specification seating ▪ Refer to the electrical circuit diagrams and check the rear seat forward/rearward motor position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required. Clear the DTCs and retest ▪ If fault persists, install a new rear seat forward/rearward motor
B1507-23	Digital input Bank '1' switch #1 - Signal Stuck Low	▪ Front passenger seat away move forward switch stuck active	▪ Test the operation of the front passenger seat away move forward switch and rectify as required. Clear the DTCs and retest ▪ If fault persists, install a new front

			passenger seat away switch
B1508-23	Digital input Bank '1' switch #2 - Signal Stuck Low	Front passenger seat away move rearward switch stuck active	- Test the operation of the front passenger seat away move rearward switch and rectify as required. Clear the DTCs and retest - If fault persists, install a new front passenger seat away switch
B150B-23	Digital input Bank '2' switch #3 - Signal Stuck Low	18-way business seats specification seating: Rear floor console advanced seat away switch1 stuck active 18-way specification seating: Rear seat backrest powerfold incline switch stuck active	NOTE: This DTC does not apply to 8-way specification seating 8-way business seats specification seating: Test the operation of the rear floor console advanced seat away switch1 and rectify as required. Clear the DTCs and retest 8-way business seats specification seating: If fault persists, install a new rear floor console advanced seat away switch1 18-way specification seating: Test the operation of the rear seat backrest powerfold incline switch and rectify as required. Clear the DTCs and retest

			18-way specification seating: If fault persists, install a new rear seat backrest powerfold incline switch
B150C-23	Digital input Bank '2' switch #4 - Signal Stuck Low	18-way business seats specification seating: Rear floor console advanced seat away switch2 stuck active 18-way specification seating: Rear seat backrest powerfold recline switch stuck active	NOTE: This DTC does not apply to 8-way specification seating 18-way business seats specification seating: Test the operation of the rear floor console advanced seat away switch2 and rectify as required. Clear the DTCs and retest 18-way business seats specification seating: If fault persists, install a new Rear floor console advanced seat away switch2 18-way specification seating: Test the operation of the rear seat backrest powerfold recline switch and rectify as required. Clear the DTCs and retest 18-way specification seating: If fault persists, install a new rear seat backrest powerfold recline switch
B1513-	5A Battery Side	Rear seat lumbar pump	

18	Output Drive #1 - Circuit current below threshold	circuit short circuit to ground, short circuit to power	NOTE: This DTC does not apply to 8-way specification seating Refer to the electrical circuit diagrams and check the rear seat lumbar pump circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest
B1513-19	5A Battery Side Output Drive #1 - Circuit current above threshold	Rear seat lumbar pump circuit short circuit to ground, short circuit to power	NOTE: This DTC does not apply to 8-way specification seating Refer to the electrical circuit diagrams and check the rear seat lumbar pump circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest
B1515-18	3A Battery Side Output Drive #1 - Circuit current below threshold	Rear seat lumbar pump (high) circuit short circuit to ground, short circuit to power	

			NOTE: This DTC does not apply to 8-way specification seating Refer to the electrical circuit diagrams and check the rear seat lumbar pump (high) circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest
B1515-19	3A Battery Side Output Drive #1 - Circuit current above threshold	Rear seat lumbar pump (high) circuit short circuit to ground, short circuit to power	NOTE: This DTC does not apply to 8-way specification seating Refer to the electrical circuit diagrams and check the rear seat lumbar pump (high) circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest
B1517-18	3A Ground Side Output Drive #1 - Circuit current below threshold	Rear seat lumbar pump (low) circuit short circuit to ground, short circuit to power	

			NOTE: This DTC does not apply to 8-way specification seating Refer to the electrical circuit diagrams and check the rear seat lumbar pump (low) circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest
B1517-19	3A Ground Side Output Drive #1 - Circuit current above threshold	Rear seat lumbar pump (low) circuit short circuit to ground, short circuit to power	NOTE: This DTC does not apply to 8-way specification seating Refer to the electrical circuit diagrams and check the rear seat lumbar pump (low) circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest
B1518-18	3A Ground Side Output Drive #2 - Circuit current below threshold	Rear seat lumbar pump (low) circuit short circuit to ground, short circuit to power	

			NOTE: This DTC does not apply to 8-way specification seating Refer to the electrical circuit diagrams and check the rear seat lumbar pump (low) circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest
B1518-19	3A Ground Side Output Drive #2 - Circuit current above threshold	Rear seat lumbar pump (low) circuit short circuit to ground, short circuit to power	NOTE: This DTC does not apply to 8-way specification seating Refer to the electrical circuit diagrams and check the rear seat lumbar pump (low) circuit for short circuit to ground, short circuit to power. Repair circuit as required. Clear the DTCs and retest
B1543-24	Front Seat Switch Pack - Signal Stuck High	- Front seat switchpack switch(es) stuck active - Front seat switchpack internal failure	Check the operation of the front seat switchpack switches and rectify as required. Clear the DTCs and retest

			▪ If fault persists, install a new front seat switchpack
B1543-87	Front Seat Switch Pack - Missing message	▪ Front seat switchpack internal failure	▪ Refer to the electrical circuit diagrams and check the front seat switchpack power and ground circuits. Repair circuit(s) as required. Clear the DTCs and retest ▪ If fault persists, install a new front seat switchpack
B1544-24	Front Seat Memory Switch Pack - Signal Stuck High	▪ Front seat memory switchpack switch(es) stuck active ▪ Front seat memory switchpack internal failure	▪ Check the operation of the front seat memory switchpack switches and rectify as required. Clear the DTCs and retest ▪ If fault persists, install a new front seat memory switchpack
B1545-87	Front Seat Massage Module - Missing message	▪ Front seat massage assembly internal failure	▪ Refer to the electrical circuit diagrams and check the front seat massage assembly power and ground circuits. Repair circuit(s) as required. Clear the DTCs and retest ▪ If fault persists, install a new front seat massage assembly
B1546-24	Rear Seat Switch Pack - Signal Stuck High	▪ Rear seat switchpack switch(es) stuck active ▪ Rear seat switchpack internal failure	▪ Check the operation of the rear seat switchpack switches and rectify as required. Clear the

			DTCs and retest ▪ If fault persists, install a new rear seat switchpack
B1546-87	Rear Seat Switch Pack - Missing message	▪ Rear seat switchpack internal failure	▪ Refer to the electrical circuit diagrams and check the rear seat switchpack power and ground circuits. Repair circuit(s) as required. Clear the DTCs and retest ▪ If fault persists, install a new rear seat switchpack
B1547-24	Rear Seat Memory Switch Pack - Signal Stuck High	▪ Rear seat memory switchpack switch(es) stuck active ▪ Rear seat memory switchpack internal failure	▪ Check the operation of the rear seat memory switchpack switches and rectify as required. Clear the DTCs and retest ▪ If fault persists, install a new rear seat memory switchpack
B1547-87	Rear Seat Memory Switch Pack - Missing message	▪ Rear seat memory switchpack internal failure	▪ Refer to the electrical circuit diagrams and check the rear seat memory switchpack power and ground circuits. Repair circuit(s) as required. Clear the DTCs and retest ▪ If fault persists, install a new rear seat memory switchpack
B154A-87	Rear Seat Massage Module - Missing message	▪ Rear seat massage assembly internal failure	▪ Refer to the electrical circuit diagrams and check

			the rear seat massage assembly power and ground circuits. Repair circuit(s) as required. Clear the DTCs and retest ▪ If fault persists, install a new rear seat massage assembly
B1554-00	Rear Seat Massage Module Pump Assembly - No sub type information	▪ Rear seat massage lumbar pump internal failure	▪ Refer to the electrical circuit diagrams and check the rear seat massage lumbar pump power and ground circuits. Repair circuit(s) as required. Clear the DTCs and retest ▪ If fault persists, install a new rear seat massage lumbar pump
B1555-00	Rear Seat Massage Module Back Carrier Assembly - No sub type information	▪ Rear seat lumbar massage solenoid internal failure	▪ Refer to the electrical circuit diagrams and check the rear seat lumbar massage solenoid power and ground circuits. Repair circuit(s) as required. Clear the DTCs and retest ▪ If fault persists, install a new rear seat lumbar massage solenoid
U0037-87	Vehicle Communication Bus B - Missing message	▪ Missing message from another control module via the medium speed CAN bus (body)	▪ Using the manufacturer approved diagnostic system, check the snapshot data to determine the missing message

			source control module. Check the relevant control module for related DTCs and refer to the relevant DTC index
U0037-88	Vehicle Communication Bus B - Bus off	Medium speed CAN bus (body) circuit short circuit to ground, short circuit to power, open circuit, high resistance	Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the medium speed CAN bus (body) circuit for short circuit to ground, short circuit to power, open circuit, high resistance
U1000-00	Solid State Driver Protection Active - Driver Disabled - No Sub Type Information	Control module internal output driver is disabled due to a fault condition detected on an output circuit to protect the control module. Another DTC will be logged to show which specific output has the error	- Check for other seat module output circuit short circuit to ground/power DTCs. Refer to the electrical circuit diagrams and perform the relevant corrective action(s) as specified by the DTC helptext - After all other seat module output circuit DTCs have been corrected, using the manufacturer approved diagnostic system, perform routine - Reset Short Protection (0x040E). Clear the DTCs and retest
U1A4C-	Build / End of Line	Seat module is not	Using the

00	mode active - No sub type information	configured correctly	manufacturer approved diagnostic system, reconfigure the seat module with the latest level software Using the manufacturer approved diagnostic system, configure the seat module as a new module
U2300-54	Central Configuration - Missing calibration	Car configuration file mismatch with vehicle specification	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs Using the manufacturer approved diagnostic system, check and update the car configuration file as necessary. Clear the DTCs and retest
U2300-55	Central Configuration - Not configured	Car configuration file mismatch with vehicle specification	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs

			Using the manufacturer approved diagnostic system, check and update the car configuration file as necessary. Clear the DTCs and retest
U2300-56	Central Configuration - Invalid/incomplete configuration	Car configuration file mismatch with vehicle specification	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs Using the manufacturer approved diagnostic system, check and update the car configuration file as necessary. Clear the DTCs and retest
U3000-49	Control Module - Internal electronic failure	Driver/passenger seat control module internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new driver/passenger seat control module as necessary
U3000-76	Control Module - Wrong mounting position	- Control module connectors are incorrectly installed - The seat module has been in initially configured to passenger or driver side and has	Check the seat module connectors are securely installed in the correct sockets and rectify as required. Clear the DTCs and retest

		subsequently been removed and then re-installed to the wrong side of the vehicle	Check the seat module is fitted to the correct side of the vehicle in line with module selection pins and rectify as required. Clear the DTCs and retest
U3001-46	Control Module Improper Shutdown - Calibration/parameter memory failure	Seat operation interrupted by power disconnection or diagnostic session control	NOTE: This DTC is for information only and does not indicate a fault Using the manufacturer approved diagnostic system, perform routine - Calibration Run (0x205F). Clear the DTCs and retest. If the fault persists, install a new driver/passenger seat control module as necessary
U3002-81	Vehicle Identification Number - Invalid serial data received	Driver/passenger seat control module is not configured correctly	Using the manufacturer approved diagnostic system, re-configure the driver/passenger seat control module with the latest level software