

2016.0 RANGE ROVER (LG), 100-00

GENERAL INFORMATION

DESCRIPTION AND OPERATION

DYNAMIC RESPONSE CONTROL MODULE (DRM)

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable.
Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle

NOTES:

- If the control module or a component is suspect and the vehicle remains under manufacturer warranty, refer to the warranty policy and procedures manual, or determine if any prior approval programme is in operation, prior to the installation of a new module/component
- Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system)
- When performing voltage or resistance tests, always use a digital multimeter accurate to three decimal places and with a current calibration certificate. When testing resistance, always take the resistance of the digital multimeter leads into account
- Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests
- Inspect connectors for signs of water ingress, and pins for damage and/or corrosion
- If diagnostic trouble codes are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always check for loose connections and corroded terminals
- Where an 'on demand self-test' is referred to, this can be accessed via the 'diagnostic trouble code monitor' tab on the manufacturers approved diagnostic system
- Check DDW for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and carry out the recommendations as required

The table below lists all diagnostic trouble codes (DTCs) that could be logged in the dynamic response control module, for additional diagnosis and testing information refer to the relevant diagnosis and testing section. For additional information, refer to: [Ride and Handling Optimization](#) (204-06 Ride and Handling Optimization, Diagnosis and Testing).

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
C1024-00	System Temporarily Disabled Due To Power Interruption During Driving - No sub type information	Loss of power to control module whilst driving	Refer to the electrical circuit diagrams and check power and ground circuits to the dynamic response control module for intermittent or poor connections. Repair circuits as required, Clear the DTCs and retest
C1037-1C	Pressure Control Valve Pressure Sensor - Circuit voltage out of range	- Pressure control valve pressure sensor signal circuit - Short circuit to ground, short circuit to power, short circuit to another circuit - Sensor fault	- Refer to the electrical circuit diagrams and check the pressure control valve pressure sensor circuit for short circuit to ground, short circuit to power, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1037-22	Pressure Control Valve Pressure Sensor - Signal amplitude > maximum	- Pressure control valve coil negative circuit short circuit to ground - Sensor fault - Pressure control valve internal failure	- Refer to the electrical circuit diagrams and check the pressure control valve coil negative circuit for short circuit to ground. Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1037-26	Pressure Control Valve Pressure Sensor - Signal rate of change below threshold	- Dynamic response hydraulic fluid low - Dynamic	Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and primary hydraulic circuit for leaks. Repair or replace as required

		response primary hydraulic circuit fluid leak - Dynamic response fluid reservoir leak - Pressure control valve pressure sensor signal circuit - Short circuit to another circuit - Pressure control valve pressure sensor learnt offset incorrect - No dynamic response hydraulic pump drive - Pressure control valve pressure sensor fault	- Refer to the electrical circuit diagrams and check the pressure control valve pressure sensor circuit for short circuit to another circuit. Repair circuit as required, clear the DTCs and retest - Clear adaptive data. Clear the DTCs and retest - Check operation of dynamic response hydraulic pump drive. Rectify as required. Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1037-28	Pressure Control Valve Pressure Sensor - Signal bias level out of range / zero adjustment failure	- Pressure control valve pressure sensor learnt offset incorrect - Sensor fault	- Reset pressure sensor offset settings and clear adaptive data. Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1040-1C	Front Axle Rod Pressure Sensor - Circuit voltage out of range	- Dynamic response front actuator rod-side pressure sensor circuit short circuit to ground, short circuit to power, short circuit to another circuit - Sensor fault	- Refer to the electrical circuit diagrams and check the dynamic response front actuator rod-side pressure sensor circuit for short circuit to ground, short circuit to power, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1040-22	Front Axle Rod Pressure Sensor	Dynamic response front	Refer to the electrical circuit diagrams and check the dynamic

	- Signal amplitude > maximum	actuator rod-side pressure regulating valve coil negative circuit short circuit to ground ▪ Sensor fault ▪ Dynamic response front actuator rod-side pressure regulating valve internal failure	response front actuator rod-side pressure regulating valve coil negative circuit for short circuit to ground. Repair circuit as required, clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1040-26	Front Axle Rod Pressure Sensor - Signal rate of change below threshold	▪ Dynamic response hydraulic fluid low ▪ Dynamic response secondary hydraulic circuit fluid leak ▪ Dynamic response front actuator rod-side pressure sensor circuit short circuit to another circuit ▪ Dynamic response front actuator rod-side pressure sensor learnt offset incorrect ▪ Sensor fault	▪ Check dynamic response system hydraulic fluid levels. Rectify as required ▪ Check dynamic response system secondary circuit for leaks. Repair as required ▪ Refer to the electrical circuit diagrams and check the dynamic response front actuator rod-side pressure sensor circuit for short circuit to another circuit. Repair circuit as required, clear the DTCs and retest ▪ Reset pressure sensor offset settings and clear adaptive data. Clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1040-28	Front Axle Rod Pressure Sensor - Signal bias level out of range / zero adjustment failure	▪ Dynamic response front actuator rod-side pressure sensor learnt offset incorrect ▪ Sensor fault	▪ Reset pressure sensor offset settings and clear adaptive data. Clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1041-	Front Axle	▪ Dynamic	▪ Refer to the electrical circuit

1C	Piston Pressure Sensor - Circuit voltage out of range	response front actuator piston-side pressure sensor circuit short circuit to ground, short circuit to power, short circuit to another circuit ▪ Sensor fault	diagrams and check the dynamic response front actuator piston-side pressure sensor circuit for short circuit to ground, short circuit to power, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1041-22	Front Axle Piston Pressure Sensor - Signal amplitude > maximum	▪ Dynamic response front actuator piston-side pressure regulating valve coil negative circuit short circuit to ground ▪ Sensor fault ▪ Dynamic response front actuator piston-side pressure regulating valve internal failure	▪ Refer to the electrical circuit diagrams and check the dynamic response front actuator piston-side pressure regulating valve coil negative circuit for short circuit to ground. Repair circuit as required, clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1041-26	Front Axle Piston Pressure Sensor - Signal rate of change below threshold	▪ Dynamic response hydraulic fluid low ▪ Dynamic response secondary hydraulic circuit Fluid leak ▪ Dynamic response front actuator piston-side pressure sensor circuit short circuit to another circuit ▪ Dynamic response front actuator piston-side pressure	▪ Check dynamic response system hydraulic fluid levels. Rectify as required ▪ Check dynamic response system secondary circuit for leaks. Repair as required ▪ Refer to the electrical circuit diagrams and check the dynamic response front actuator piston-side pressure sensor circuit for short circuit to another circuit. Repair circuit as required, clear the DTCs and retest ▪ Reset pressure sensor offset settings and clear adaptive data. Clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest

		sensor learnt offset incorrect ▪ Sensor fault	
C1041-28	Front Axle Piston Pressure Sensor - Signal bias level out of range / zero adjustment failure	▪ Dynamic response front actuator piston-side pressure sensor learnt offset incorrect ▪ Sensor fault	▪ Reset pressure sensor offset settings and clear adaptive data. Clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1042-1C	Rear Axle Rod Pressure Sensor - Circuit voltage out of range	▪ Dynamic response rear actuator rod-side pressure sensor circuit short circuit to ground, short circuit to power, short circuit to another circuit ▪ Sensor fault	▪ Refer to the electrical circuit diagrams and check the dynamic response rear actuator rod-side pressure sensor circuit for short circuit to ground, short circuit to power, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1042-22	Rear Axle Rod Pressure Sensor - Signal amplitude > maximum	▪ Dynamic response rear actuator rod-side pressure regulating valve coil negative circuit short circuit to ground ▪ Sensor fault ▪ Dynamic response rear actuator rod-side pressure regulating valve internal failure	▪ Refer to the electrical circuit diagrams and check the dynamic response rear actuator rod-side pressure regulating valve coil negative circuit for short circuit to ground. Repair circuit as required, clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1042-26	Rear Axle Rod Pressure Sensor - Signal rate of change below threshold	▪ Dynamic response hydraulic fluid low ▪ Dynamic	▪ Check dynamic response system hydraulic fluid levels. Rectify as required ▪ Check dynamic response system secondary circuit for leaks. Repair

		response secondary hydraulic circuit fluid leak - Dynamic response rear actuator rod-side pressure sensor circuit short circuit to another circuit - Dynamic response rear actuator rod-side pressure sensor learnt offset incorrect - Sensor fault	as required - Refer to the electrical circuit diagrams and check the dynamic response rear actuator rod-side pressure sensor circuit for short circuit to another circuit. Repair circuit as required, clear the DTCs and retest - Reset pressure sensor offset settings and clear adaptive data. Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1042-28	Rear Axle Rod Pressure Sensor - Signal bias level out of range / zero adjustment failure	- Dynamic response rear actuator rod-side pressure sensor learnt offset incorrect - Sensor fault	- Reset pressure sensor offset settings and clear adaptive data. Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1043-1C	Rear Axle Piston Pressure Sensor - Circuit voltage out of range	- Dynamic response rear actuator piston-side pressure sensor circuit short circuit to ground, short circuit to power, short circuit to another circuit - Sensor fault	- Refer to the electrical circuit diagrams and check the dynamic response rear actuator piston-side pressure sensor circuit for short circuit to ground, short circuit to power, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1043-22	Rear Axle Piston Pressure Sensor - Signal amplitude > maximum	Dynamic response rear actuator piston-side pressure regulating valve coil negative circuit short circuit to ground	Refer to the electrical circuit diagrams and check the dynamic response rear actuator piston-side pressure regulating valve coil negative circuit for short circuit to ground. Repair circuit as required, clear the DTCs and retest

		▪ Sensor fault ▪ Dynamic response rear actuator piston-side pressure regulating valve internal failure	▪ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1043-26	Rear Axle Piston Pressure Sensor - Signal rate of change below threshold	▪ Dynamic response hydraulic fluid low ▪ Dynamic response secondary hydraulic circuit fluid leak ▪ Dynamic response rear actuator piston-side pressure sensor circuit short circuit to another circuit ▪ Dynamic response rear actuator piston-side pressure sensor learnt offset incorrect ▪ Sensor fault	▪ Check dynamic response system hydraulic fluid levels. Rectify as required ▪ Check dynamic response system secondary circuit for leaks. Repair as required ▪ Refer to the electrical circuit diagrams and check the dynamic response rear actuator piston-side pressure sensor circuit for short circuit to another circuit. Repair circuit as required, clear the DTCs and retest ▪ Reset pressure sensor offset settings and clear adaptive data. Clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1043-28	Rear Axle Piston Pressure Sensor - Signal bias level out of range / zero adjustment failure	▪ Dynamic response rear actuator piston-side pressure sensor learnt offset incorrect ▪ Sensor fault	▪ Reset pressure sensor offset settings and clear adaptive data. Clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1044-91	Hydraulic Return Line Pressure - Parametric	▪ Dynamic response hydraulic fluid circuit requires bleeding ▪ Dynamic response	▪ Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required ▪ Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir, the dynamic

		hydraulic fluid low - Dynamic response hydraulic fluid leak - Dynamic response hydraulic fluid contaminated - Kinked or blocked dynamic response hydraulic fluid return line - Sensor fault (front or rear) - Valve fault (front or rear) - Dynamic response hydraulic pump pressure/flow too low	response hydraulic fluid return line and other hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest - Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid - Check the condition and integrity of the dynamic response hydraulic fluid return line and replace as required. Clear the DTCs and retest - If the fault persists, check the dynamic response control module for front/rear dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest - If the fault persists, check the dynamic response hydraulic pump pressure/fluid flow. If faulty, check and install a new dynamic response hydraulic pump as required
C1045-91	Hydraulic Residual Pressure - Parametric	- Dynamic response hydraulic fluid contaminated - Kinked or blocked dynamic response hydraulic fluid return line - Sensor fault	- Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid - Check the condition and integrity

		Valve fault	of the dynamic response hydraulic fluid return line and replace as required. Clear the DTCs and retest - If the fault persists, check the dynamic response control module for front/rear dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1046-91	Front Axle Actuator Torque - Parametric	- Dynamic response hydraulic fluid circuit requires bleeding - Dynamic response hydraulic fluid low - Dynamic response hydraulic fluid leak - Dynamic response hydraulic fluid contaminated - Sensor fault (front) - Valve fault (front) - Dynamic response hydraulic pump pressure/flow too low - Front actuator internal failure	- Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required - Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest - Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid - If the fault persists, check the dynamic response control module for front dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest - If the fault persists, check the dynamic response hydraulic pump

			pressure/fluid flow. If faulty, install a new dynamic response hydraulic pump. Clear the DTCs and retest ■ Using the manufacture approved diagnostic system, demand 55 bar pressure from the pressure control valve for 5 minutes to heat the system. Then, demand 50 bar from the front axle rod pressure regulating valve for 2 minutes, if pressure drops and/or the pipes to the front actuator get hot, this indicates a faulty actuator. Check and install a new roll bar module as required. Clear the DTCs and retest
C1047-91	Rear Axle Actuator Torque - Parametric	■ Dynamic response hydraulic fluid circuit requires bleeding ■ Dynamic response hydraulic fluid low ■ Dynamic response hydraulic fluid leak ■ Dynamic response hydraulic fluid contaminated ■ Sensor fault (rear) ■ Valve fault (rear) ■ Dynamic response hydraulic pump pressure/flow too low ■ Rear actuator - Internal failure	■ Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required ■ Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest ■ Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid ■ If the fault persists, check the dynamic response control module for rear dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest ■ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest ■ If the fault persists, check the dynamic response hydraulic pump

			pressure/fluid flow. If faulty, install a new dynamic response hydraulic pump Using the manufacture approved diagnostic system, demand 55 bar pressure from the pressure control valve for 5 minutes to heat the system. Then, demand 50 bar from the rear axle rod pressure regulating valve for 2 minutes, if pressure drops and/or the pipes to the rear actuator get hot, this indicates a faulty actuator. Check and install a new roll bar module as required. Clear the DTCs and retest
C1048-12	Safety Control Valve - Circuit short to battery	- Dynamic response safety control valve circuit faulty connector - Dynamic response safety control valve circuit short circuit to power, short circuit to another circuit - Dynamic response safety control valve circuit very low resistance - Valve fault	- Refer to the electrical circuit diagrams and check the dynamic response safety control valve circuit, harness and connectors for short circuit to power, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response safety control valve circuit (nominal value should be 1.9 ohms). Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1048-14	Safety Control Valve - Circuit short to ground or open	- Dynamic response safety control valve circuit faulty connector - Dynamic response safety control valve circuit short circuit to ground, open circuit, high resistance	- Refer to the electrical circuit diagrams and check the dynamic response safety control valve circuit, harness and connectors for short circuit to ground, open circuit, high resistance. Repair circuit as required, Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response safety control valve circuit (nominal value should be 1.9 ohms). Repair circuit

		Valve fault	as required, Clear the DTCs and retest If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1048-18	Safety Control Valve - Circuit current below threshold	- Dynamic response safety control valve circuit faulty connector - Dynamic response safety control valve circuit open circuit, high resistance - Valve fault	- Refer to the electrical circuit diagrams and check the dynamic response safety control valve circuit, harness and connectors for open circuit, high resistance. Repair circuit as required, Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response safety control valve circuit (nominal value should be 1.9 ohms). Repair circuit as required, Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1048-1D	Safety Control Valve - Circuit current out of range	- Dynamic response safety control valve circuit faulty connector - Dynamic response safety control valve circuit short circuit to ground, short circuit to another circuit - Valve fault	- Refer to the electrical circuit diagrams and check the dynamic response safety control valve circuit, harness and connectors for short circuit to ground, short circuit to another circuit. Repair circuit as required, Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response safety control valve circuit (nominal value should be 1.9 ohms). Repair circuit as required, Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1048-28	Safety Control Valve - Signal	Dynamic response safety	Refer to the electrical circuit diagrams and check the dynamic

	bias level out of range / zero adjustment failure	control valve circuit faulty connector - Dynamic response safety control valve circuit (positive or negative) short circuit to another circuit - Dynamic response control module amplifier failure	response safety control valve circuit, harness and connectors (positive or negative) for short circuit to another circuit. Repair circuit as required, Clear the DTCs and retest If the fault persists, check and install a new dynamic response control module
C1048-72	Safety Control Valve - Actuator stuck open	Dynamic response safety control valve, valve stuck open	Clear the DTCs and retest. If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1049-12	Front Axle Rod Pressure Regulating Valve - Circuit short to battery	- Dynamic response front actuator rod-side pressure regulating valve coil circuit short circuit to power, short circuit to another circuit - Dynamic response front actuator rod-side pressure regulating valve coil circuit very low resistance - Valve fault	- Refer to the electrical circuit diagrams and check the dynamic response front actuator rod-side pressure regulating valve coil circuit, harness and connectors for short circuit to power, short circuit to another circuit. Repair circuit as required, Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response front actuator rod-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1049-18	Front Axle Rod Pressure Regulating Valve - Circuit current below threshold	Dynamic response front actuator rod-side pressure regulating valve	Refer to the electrical circuit diagrams and check the dynamic response front actuator rod-side pressure regulating valve coil circuit, harness and connectors for

		coil circuit faulty connector - Dynamic response front actuator rod-side pressure regulating valve coil circuit open circuit, high resistance - Valve fault	open circuit, high resistance. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response front actuator rod-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1049-1D	Front Axle Rod Pressure Regulating Valve - Circuit current out of range	- Dynamic response front actuator rod-side pressure regulating valve coil circuit - Faulty connector - Dynamic response front actuator rod-side pressure regulating valve coil circuit short circuit to ground, short circuit to another circuit - Valve fault	- Refer to the electrical circuit diagrams and check the dynamic response front actuator rod-side pressure regulating valve coil circuit, harness and connectors for short circuit to ground, short circuit to another circuit. Repair circuit as required, Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response front actuator rod-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1049-28	Front Axle Rod Pressure Regulating Valve - Signal bias level out of range / zero adjustment failure	- Dynamic response front actuator rod-side pressure regulating valve coil circuit faulty connector - Dynamic response front actuator rod-side pressure	- Refer to the electrical circuit diagrams and check the dynamic response front actuator rod-side pressure regulating valve coil circuit, harness and connectors for short circuit to another circuit. Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response control module

		regulating valve coil circuit (positive or negative) short circuit to another circuit Dynamic response control module amplifier failure	
C1049-62	Front Axle Rod Pressure Regulating Valve - Signal compare failure	- Dynamic response hydraulic fluid circuit requires bleeding - Dynamic response hydraulic fluid low - Dynamic response hydraulic fluid leak from high front axle rod pressure primary circuit, secondary circuit or dynamic response hydraulic fluid reservoir - Dynamic response hydraulic fluid contaminated - Broken stabilisation link - Broken roll bar module - Sensor fault - Valve fault - Sticking valve - Actuator fault - Dynamic response hydraulic fluid	- Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required - Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest - Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid - Check the security and integrity of the stabilisation link. Repair or replace components as required. Clear the DTCs and retest - Check the security and integrity of the roll bar module. Repair or replace components as required. Clear the DTCs and retest - If the fault persists, check the dynamic response control module for dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest - If the fault persists, check and install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and

		reservoir suction port screen damaged Dynamic response hydraulic pump pressure/flow too low	retest - Using the manufacture approved diagnostic system, demand 55 bar pressure from the pressure control valve for 5 minutes to heat the system. Then, demand 50 bar from the front axle rod pressure regulating valve for 2 minutes, if pressure drops and/or the pipes to the front actuator get hot, this indicates a faulty actuator. Check and install a new roll bar module as required. Clear the DTCs and retest - If DTC occurs on right hand bends only, check reservoir suction port screen for damage. If damage is evident, replace reservoir if faulty and bleed system. Clear the DTCs and retest - If the fault persists, check the dynamic response hydraulic pump pressure/fluid flow. If faulty, install a new dynamic response hydraulic pump
C1049-64	Front Axle Rod Pressure Regulating Valve - Signal plausibility failure	- Dynamic response front actuator rod-side pressure regulating valve coil circuit faulty connector - Dynamic response front actuator rod-side pressure regulating valve coil circuit high resistance - Valve fault	- Refer to the electrical circuit diagrams and check the dynamic response front actuator rod-side pressure regulating valve coil circuit, harness and connectors for short circuit faults. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response front actuator rod-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1049-92	Front Axle Rod Pressure	Dynamic response	Check for air and/or other contaminants in dynamic response

	Regulating Valve - Performance or incorrect operation	hydraulic fluid circuit requires bleeding - Dynamic response hydraulic fluid low - Dynamic response front actuator rod-side pressure regulating valve coil circuit faulty connector - Dynamic response hydraulic fluid contaminated - Sensor fault - Valve fault - Low pump pressure/flow	hydraulic fluid circuit and bleed as required - Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the dynamic response front actuator rod-side pressure regulating valve coil circuit, harness and connectors for short circuit faults. Repair circuit as required, clear the DTCs and retest - Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid - If the fault persists, check the dynamic response control module for dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest - If the fault persists, install a new dynamic response hydraulic pump. Clear the DTCs and retest
C1049-94	Front Axle Rod Pressure Regulating Valve - Unexpected operation	- Dynamic response front actuator rod-side pressure regulating valve coil circuit faulty connector - Dynamic response front	- Refer to the electrical circuit diagrams and check the dynamic response front actuator rod-side pressure regulating valve coil circuit, harness and connectors for short circuit faults. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit

		actuator rod-side pressure regulating valve coil circuit high resistance - Dynamic response hydraulic fluid circuit requires bleeding - Dynamic response hydraulic fluid low - Dynamic response hydraulic fluid leak - Dynamic response hydraulic fluid contaminated - Sensor fault - Valve fault - Low pump pressure/flow - Kinked or blocked dynamic response hydraulic fluid return line	diagrams and check the resistance of the dynamic response front actuator rod-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest - Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required - Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest - If the fault persists, check the dynamic response control module for dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest - Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest - If the fault persists, install a new dynamic response hydraulic pump. Clear the DTCs and retest - If the fault persists, check the condition and integrity of the dynamic response hydraulic return line and repair or replace as required. Clear the DTCs and retest
C104A-12	Front Axle Piston Pressure	Dynamic response front	Refer to the electrical circuit diagrams and check the dynamic

	Regulating Valve - Circuit short to battery	actuator piston-side pressure regulating valve coil circuit short circuit to power, short circuit to another circuit - Dynamic response front actuator piston-side pressure regulating valve coil circuit very low resistance - Valve fault	response front actuator piston-side pressure regulating valve coil circuit, harness and connectors for short circuit to power, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response front actuator piston-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C104A-18	Front Axle Piston Pressure Regulating Valve - Circuit current below threshold	- Dynamic response front actuator piston-side pressure regulating valve coil circuit faulty connector - Dynamic response front actuator piston-side pressure regulating valve coil circuit open circuit, high resistance - Valve fault	- Refer to the electrical circuit diagrams and check the dynamic response front actuator piston-side pressure regulating valve coil circuit, harness and connectors for open circuit, high resistance. Repair circuit as required, Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response front actuator piston-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C104A-1D	Front Axle Piston Pressure Regulating Valve - Circuit current out of range	- Dynamic response front actuator piston-side pressure regulating valve coil circuit faulty connector - Dynamic	Refer to the electrical circuit diagrams and check the dynamic response front actuator piston-side pressure regulating valve coil circuit, harness and connectors for short circuit to ground, short circuit to another circuit. Repair circuit as required, Clear the DTCs and retest

		response front actuator piston-side pressure regulating valve coil circuit short circuit to ground, short circuit to another circuit Valve fault	- Refer to the electrical circuit diagrams and check the resistance of the dynamic response front actuator piston-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C104A-28	Front Axle Piston Pressure Regulating Valve - Signal bias level out of range / zero adjustment failure	- Dynamic response front actuator piston-side pressure regulating valve coil circuit faulty connector - Dynamic response front actuator piston-side pressure regulating valve coil circuit (positive or negative) short circuit to another circuit - Dynamic response control module amplifier failure	- Refer to the electrical circuit diagrams and check the dynamic response front actuator piston-side pressure regulating valve coil circuit, harness and connectors (positive or negative) for short circuit to another circuit. Repair circuit as required, Clear the DTCs and retest - If the fault persists, install a new dynamic response control module
C104A-62	Front Axle Piston Pressure Regulating Valve - Signal compare failure	- Dynamic response hydraulic fluid circuit requires bleeding - Dynamic response hydraulic fluid low - Dynamic response hydraulic fluid leak from high	- Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required - Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest - Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of

		front axle piston pressure primary circuit, secondary circuit or dynamic response hydraulic fluid reservoir - Dynamic response hydraulic fluid contaminated - Broken stabilisation link - Broken roll bar module - Sensor fault - Valve fault sticking valve - Actuator fault - Low pump pressure/flow	contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid - Check the security and integrity of the stabilisation link. Repair or replace components as required. Clear the DTCs and retest - Check the security and integrity of the roll bar module. Repair or replace components as required. Clear the DTCs and retest - If the fault persists, check the dynamic response control module for dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest - If the fault persists, check and install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest - Using the manufacture approved diagnostic system, demand 55 bar pressure from the pressure control valve for 5 minutes to heat the system. Then, demand 50 bar from the front axle piston pressure regulating valve for 2 minutes, if pressure drops and/or the pipes to the front actuator get hot, this indicates a faulty actuator. Check and install a new roll bar module as required. Clear the DTCs and retest - If the fault persists, check and install a new dynamic response hydraulic pump. Clear the DTCs and retest
C104A-64	Front Axle Piston Pressure Regulating Valve - Signal plausibility	Dynamic response front actuator piston-side pressure regulating valve	Refer to the electrical circuit diagrams and check the dynamic response front actuator piston-side pressure regulating valve coil circuit, harness and connectors for

	failure	coil circuit faulty connector - Dynamic response front actuator piston-side pressure regulating valve coil circuit high resistance - Valve fault	short circuit faults. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response front actuator piston-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C104A-92	Front Axle Piston Pressure Regulating Valve - Performance or incorrect operation	- Dynamic response hydraulic fluid circuit requires bleeding - Dynamic response hydraulic fluid contaminated - Dynamic response hydraulic fluid low - Dynamic response front actuator piston-side pressure regulating valve coil circuit faulty connector - Sensor fault - Valve fault - Low pump pressure/flow	- Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required - Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid - Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the dynamic response front actuator piston-side pressure regulating valve coil circuit, harness and connectors for short circuit faults. Repair circuit as required, clear the DTCs and retest - If the fault persists, check the dynamic response control module for dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index.

			Clear the DTCs and retest ■ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest ■ If the fault persists, install a new dynamic response hydraulic pump. Clear the DTCs and retest
C104A-94	Front Axle Piston Pressure Regulating Valve - Unexpected operation	■ Dynamic response front actuator piston-side pressure regulating valve coil circuit - Faulty connector ■ Dynamic response front actuator piston-side pressure regulating valve coil circuit high resistance ■ Dynamic response hydraulic fluid circuit requires bleeding ■ Dynamic response hydraulic fluid contaminated ■ Dynamic response hydraulic fluid low ■ Dynamic response hydraulic fluid leak ■ Sensor fault ■ Valve fault ■ Low pump pressure/flow ■ Kinked or blocked dynamic response	■ Refer to the electrical circuit diagrams and check the dynamic response front actuator piston-side pressure regulating valve coil circuit, harness and connectors for short circuit faults. Repair circuit as required, Clear the DTCs and retest ■ Refer to the electrical circuit diagrams and check the resistance of the dynamic response front actuator piston-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, Clear the DTCs and retest ■ Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required ■ Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid ■ Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest ■ If the fault persists, check the dynamic response control module for dynamic response actuator pressure sensor fault DTCs and

		hydraulic fluid return line	refer to the relevant DTC index. Clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest ▪ If the fault persists, check and install a new dynamic response hydraulic pump. Clear the DTCs and retest ▪ If the fault persists, check the condition and integrity of the dynamic response hydraulic return line and repair or replace as required. Clear the DTCs and retest
C104B-12	Rear Axle Rod Pressure Regulating Valve - Circuit short to battery	▪ Dynamic response rear actuator rod-side pressure regulating valve coil circuit short circuit to power, short circuit to another circuit ▪ Dynamic response rear actuator rod-side pressure regulating valve coil circuit very low resistance ▪ Valve fault	▪ Refer to the electrical circuit diagrams and check the dynamic response rear actuator rod-side pressure regulating valve coil circuit, harness and connectors for short circuit to power, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the resistance of the dynamic response rear actuator rod-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C104B-18	Rear Axle Rod Pressure Regulating Valve - Circuit current below threshold	▪ Dynamic response rear actuator rod-side pressure regulating valve coil circuit, faulty connector ▪ Dynamic response rear	▪ Refer to the electrical circuit diagrams and check the dynamic response rear actuator rod-side pressure regulating valve coil circuit, harness and connectors for open circuit, high resistance. Repair circuit as required, clear the DTCs and retest ▪ Refer to the electrical circuit

		actuator rod-side pressure regulating valve coil circuit open circuit, high resistance Valve fault	diagrams and check the resistance of the dynamic response rear actuator rod-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C104B-1D	Rear Axle Rod Pressure Regulating Valve - Circuit current out of range	- Dynamic response rear actuator rod-side pressure regulating valve coil circuit, faulty connector - Dynamic response rear actuator rod-side pressure regulating valve coil circuit short circuit to ground, short circuit to another circuit - Valve fault	- Refer to the electrical circuit diagrams and check the dynamic response rear actuator rod-side pressure regulating valve coil circuit, harness and connectors for short circuit to ground, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response rear actuator rod-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C104B-28	Rear Axle Rod Pressure Regulating Valve - Signal bias level out of range / zero adjustment failure	- Dynamic response rear actuator rod-side pressure regulating valve coil circuit - Faulty connector - Dynamic response rear actuator rod-side pressure regulating valve coil circuit (positive or negative) - Short circuit to another	- Refer to the electrical circuit diagrams and check the dynamic response rear actuator rod-side pressure regulating valve coil circuit, harness and connectors (positive or negative) for short circuit to another circuit. Repair circuit as required, Clear the DTCs and retest - If the fault persists, install a new dynamic response control module

		circuit Dynamic response control module - Amplifier failure	
C104B-62	Rear Axle Rod Pressure Regulating Valve - Signal compare failure	- Dynamic response hydraulic fluid circuit requires bleeding - Dynamic response hydraulic fluid low - Dynamic response hydraulic fluid leak from high rear axle rod pressure primary circuit, secondary circuit or dynamic response hydraulic fluid reservoir - Dynamic response hydraulic fluid contaminated - Broken stabilisation link - Broken roll bar module - Sensor fault - Valve fault - Sticking valve - Actuator fault - Dynamic response hydraulic fluid reservoir suction port screen damaged - Low pump pressure/flow	- Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required - Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest - Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid - Check the security and integrity of the stabilisation link. Repair or replace components as required. Clear the DTCs and retest - Check the security and integrity of the roll bar module. Repair or replace components as required. Clear the DTCs and retest - If the fault persists, check the dynamic response control module for dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest - Using the manufacture approved diagnostic system, demand 55 bar pressure from the pressure control valve for 5 minutes to heat the

			system. Then, demand 50 bar from the rear axle rod pressure regulating valve for 2 minutes, if pressure drops and/or the pipes to the rear actuator get hot, this indicates a faulty actuator. Check and install a new roll bar module as required. Clear the DTCs and retest ▪ If DTC occurs on right hand bends only, check reservoir suction port screen for damage. If damage is evident, replace reservoir if faulty and bleed system. Clear the DTCs and retest ▪ If the fault persists, install a new dynamic response hydraulic pump. Clear the DTCs and retest
C104B-64	Rear Axle Rod Pressure Regulating Valve - Signal plausibility failure	▪ Dynamic response rear actuator rod-side pressure regulating valve coil circuit faulty connector ▪ Dynamic response rear actuator rod-side pressure regulating valve coil circuit high resistance ▪ Valve fault	▪ Refer to the electrical circuit diagrams and check the dynamic response rear actuator rod-side pressure regulating valve coil circuit, harness and connectors for short circuit faults. Repair circuit as required, clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the resistance of the dynamic response rear actuator rod-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C104B-92	Rear Axle Rod Pressure Regulating Valve - Performance or incorrect operation	▪ Dynamic response hydraulic fluid circuit requires bleeding ▪ Dynamic response hydraulic fluid contaminated	▪ Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required ▪ Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic

		- Dynamic response hydraulic fluid low - Dynamic response rear actuator rod-side pressure regulating valve coil circuit faulty connector - Sensor fault - Valve fault - Low pump pressure/flow	response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid - Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the dynamic response rear actuator rod-side pressure regulating valve coil circuit, harness and connectors for short circuit faults. Repair circuit as required, clear the DTCs and retest - If the fault persists, check the dynamic response control module for dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest - If the fault persists, install a new dynamic response hydraulic pump. Clear the DTCs and retest
C104B-94	Rear Axle Rod Pressure Regulating Valve - Unexpected operation	- Dynamic response rear actuator rod-side pressure regulating valve coil circuit faulty connector - Dynamic response rear actuator rod-side pressure regulating valve coil circuit high resistance - Dynamic response	- Refer to the electrical circuit diagrams and check the dynamic response rear actuator rod-side pressure regulating valve coil circuit, harness and connectors for short circuit faults. Repair circuit as required, Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response rear actuator rod-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, Clear the DTCs and retest

		hydraulic fluid circuit requires bleeding - Dynamic response hydraulic fluid contaminated - Dynamic response hydraulic fluid low - Dynamic response hydraulic fluid leak - Sensor fault - Valve fault - Low pump pressure/flow - Kinked or blocked dynamic response hydraulic fluid return line	- Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required - Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid - Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest - If the fault persists, check the dynamic response control module for dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest - If the fault persists, install a new dynamic response hydraulic pump. Clear the DTCs and retest - If the fault persists, check the condition and integrity of the dynamic response hydraulic return line and repair or replace as required. Clear the DTCs and retest
C104C-12	Rear Axle Piston Pressure Regulating Valve - Circuit short to battery	Dynamic response rear actuator piston-side pressure regulating valve coil circuit short circuit to power, short circuit to another circuit	Refer to the electrical circuit diagrams and check the dynamic response rear actuator piston-side pressure regulating valve coil circuit, harness and connectors for short circuit to power, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest

		- Dynamic response rear actuator piston-side pressure regulating valve coil circuit very low resistance - Valve fault	- Refer to the electrical circuit diagrams and check the resistance of the dynamic response rear actuator piston-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C104C-18	Rear Axle Piston Pressure Regulating Valve - Circuit current below threshold	- Dynamic response rear actuator piston-side pressure regulating valve coil circuit faulty connector - Dynamic response rear actuator piston-side pressure regulating valve coil circuit open circuit, high resistance - Valve fault	- Refer to the electrical circuit diagrams and check the dynamic response rear actuator piston-side pressure regulating valve coil circuit, harness and connectors for open circuit, high resistance. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response rear actuator piston-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C104C-1D	Rear Axle Piston Pressure Regulating Valve - Circuit current out of range	- Dynamic response rear actuator piston-side pressure regulating valve coil circuit faulty connector - Dynamic response rear actuator piston-side pressure regulating valve coil circuit short circuit to ground, short circuit to another circuit	- Refer to the electrical circuit diagrams and check the dynamic response rear actuator piston-side pressure regulating valve coil circuit, harness and connectors for short circuit to ground, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response rear actuator piston-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required,

		Valve fault	clear the DTCs and retest If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C104C-28	Rear Axle Piston Pressure Regulating Valve - Signal bias level out of range / zero adjustment failure	- Dynamic response rear actuator piston-side pressure regulating valve coil circuit faulty connector - Dynamic response rear actuator piston-side pressure regulating valve coil circuit (positive or negative) short circuit to another circuit - Dynamic response control module amplifier failure	- Refer to the electrical circuit diagrams and check the dynamic response rear actuator piston-side pressure regulating valve coil circuit, harness and connectors (positive or negative) for short circuit to another circuit. Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response control module
C104C-62	Rear Axle Piston Pressure Regulating Valve - Signal compare failure	- Dynamic response hydraulic fluid circuit requires bleeding - Dynamic response hydraulic fluid low - Dynamic response hydraulic fluid leak from high rear axle rod pressure primary circuit, secondary circuit or dynamic response hydraulic fluid reservoir	- Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required - Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest - Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid

		▪ Dynamic response hydraulic fluid contaminated ▪ Broken stabilisation link ▪ Broken roll bar module ▪ Sensor fault ▪ Valve fault - Sticking valve ▪ Actuator fault ▪ Low pump pressure/flow	▪ Check the security and integrity of the stabilisation link. Repair or replace components as required. Clear the DTCs and retest ▪ Check the security and integrity of the roll bar module. Repair or replace components as required. Clear the DTCs and retest ▪ If the fault persists, check the dynamic response control module for dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest ▪ If the fault persists, check and install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest ▪ Using the manufacture approved diagnostic system, demand 55 bar pressure from the pressure control valve for 5 minutes to heat the system. Then, demand 50 bar from the rear axle piston pressure regulating valve for 2 minutes, if pressure drops and/or the pipes to the rear actuator get hot, this indicates a faulty actuator. Check and install a new roll bar module as required. Clear the DTCs and retest ▪ If the fault persists, install a new dynamic response hydraulic pump. Clear the DTCs and retest
C104C-64	Rear Axle Piston Pressure Regulating Valve - Signal plausibility failure	▪ Dynamic response rear actuator piston-side pressure regulating valve coil circuit faulty connector ▪ Dynamic response rear actuator piston-side pressure regulating valve coil circuit high	▪ Refer to the electrical circuit diagrams and check the dynamic response rear actuator piston-side pressure regulating valve coil circuit, harness and connectors (positive or negative) for short circuit faults. Repair circuit as required, clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the resistance of the dynamic response rear actuator piston-side pressure

		resistance Valve fault	regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C104C-92	Rear Axle Piston Pressure Regulating Valve - Performance or incorrect operation	- Dynamic response hydraulic fluid circuit requires bleeding - Dynamic response hydraulic fluid contaminated - Dynamic response hydraulic fluid low - Dynamic response rear actuator piston-side pressure regulating valve coil circuit - Faulty connector - Sensor fault - Valve fault - Low pump pressure/flow	- Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required - Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid - Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the dynamic response rear actuator piston-side pressure regulating valve coil circuit, harness and connectors (positive or negative) for short circuit faults. Repair circuit as required, clear the DTCs and retest - If the fault persists, check the dynamic response control module for dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest - If the fault persists, install a new

			dynamic response hydraulic pump. Clear the DTCs and retest
C104C-94	Rear Axle Piston Pressure Regulating Valve - Unexpected operation	- Dynamic response rear actuator piston-side pressure regulating valve coil circuit faulty connector - Dynamic response rear actuator piston-side pressure regulating valve coil circuit high resistance - Dynamic response hydraulic fluid circuit requires bleeding - Dynamic response hydraulic fluid contaminated - Dynamic response hydraulic fluid low - Dynamic response hydraulic fluid leak - Sensor fault - Valve fault - Low pump pressure/flow - Kinked or blocked dynamic response hydraulic fluid return line	- Refer to the electrical circuit diagrams and check the dynamic response rear actuator piston-side pressure regulating valve coil circuit, harness and connectors (positive or negative) for short circuit faults. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response rear actuator piston-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest - Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required - Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid - Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest - If the fault persists, check the dynamic response control module for dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data.

			Clear the DTCs and retest ▪ If the fault persists, check and install a new dynamic response hydraulic pump as required. Clear the DTCs and retest ▪ If the fault persists, check the condition and integrity of the dynamic response hydraulic return line and repair or replace as required. Clear the DTCs and retest
C104D-92	Front to Rear Hydraulic Piston Pressure Ratio - Performance or incorrect operation	▪ Unexpected or mismatched signals/operation between front and rear dynamic response hydraulic fluid circuits ▪ Dynamic response control module - Internal failure	▪ Check for related DTCs and refer to the relevant DTC index. Clear the DTCs and retest ▪ If the fault persists, install a new dynamic response control module
C104E-92	Front to Rear Hydraulic Rod Pressure Ratio - Performance or incorrect operation	▪ Unexpected or mismatched signals/operation between front and rear dynamic response hydraulic fluid circuits ▪ Dynamic response control module internal failure	▪ Check for related DTCs and refer to the relevant DTC index. Clear the DTCs and retest ▪ If the fault persists, install a new dynamic response control module
C1050-1C	Sensor Supply Voltage C - Circuit voltage out of range	▪ Upper lateral accelerometer supply circuit short circuit to ground, short circuit to power, short circuit to another circuit ▪ Accelerometer fault	▪ Refer to the electrical circuit diagrams and check the upper lateral accelerometer supply circuit for short circuit to ground, short circuit to power, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest ▪ If the fault persists, check the output voltage of the upper lateral

		Dynamic response control module internal failure	accelerometer. With the accelerometer on a level surface, output voltage should be 2.35v to 2.65v. If recorded voltage is outside these parameters, check and install a new accelerometer as required and recalibrate the dynamic response control module. Clear the DTCs and retest If the fault persists, check the supply voltage from the dynamic response control module to the upper lateral accelerometer. The voltage to accelerometer supply connection should be >4.75 volts and <5.096 volts. If recorded voltage is outside these parameters, check and install a new dynamic response control module as required and recalibrate the dynamic response control module. Clear the DTCs and retest
C1051-18	Initial (Hit) Current-Safety Control Valve - Circuit current below threshold	- Dynamic response safety control valve coil circuit - Faulty connector - Dynamic response safety control valve coil circuit - Open circuit, high resistance	- Refer to the electrical circuit diagrams and check the dynamic response safety control valve coil circuit, harness and connectors for open circuit, high resistance. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response safety control valve circuit (nominal value should be 1.9 ohms). Repair circuit as required, clear the DTCs and retest
C1052-1D	Hold Current-Safety Control Valve - Circuit current out of range	- Dynamic response safety control valve coil circuit - Faulty connector - Dynamic response safety control valve coil circuit - Short circuit to ground, open circuit, high resistance	- Refer to the electrical circuit diagrams and check the dynamic response safety control valve coil circuit, harness and connectors for short circuit to ground, open circuit, high resistance. Repair circuit as required, Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response safety control valve circuit (nominal value

			should be 1.9 ohms). Repair circuit as required, clear the DTCs and retest
C1053-19	Off State Current Monitor-Safety Control Valve - Circuit current above threshold	- Dynamic response safety control valve coil circuit - Faulty connector - Dynamic response safety control valve coil circuit - Short circuit to another circuit	Refer to the electrical circuit diagrams and check the dynamic response dynamic response safety control valve coil circuit, harness and connectors for short circuit to another circuit. Repair circuit as required, clear the DTCs and retest
C1055-14	Front Axle Piston Pressure Regulating Valve - Circuit short to ground or open	- Dynamic response front actuator piston-side pressure regulating valve coil circuit short circuit to ground, short circuit to another circuit, open circuit, high resistance - Valve fault	- Refer to the electrical circuit diagrams and check the dynamic response front actuator piston-side pressure regulating valve coil circuit, harness and connectors for short circuit to ground, short circuit to another circuit open circuit, high resistance. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the dynamic response front actuator piston-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and reset adaptive data. Clear the DTCs and retest
C1057-14	Rear Axle Piston Pressure Regulating Valve - Circuit short to ground or open	Dynamic response rear actuator piston-side pressure regulating valve coil circuit short circuit to ground, short circuit to another circuit, open circuit,	Refer to the electrical circuit diagrams and check the dynamic response rear actuator piston-side pressure regulating valve coil circuit, harness and connectors for short circuit to ground, short circuit to another circuit, open circuit, high resistance. Repair circuit as required, clear the DTCs and retest

		high resistance Valve fault	- Refer to the electrical circuit diagrams and check the resistance of the dynamic response rear actuator piston-side pressure regulating valve coil circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and clear adaptive data. Clear the DTCs and retest
C105B-01	Actuator Circuit Group B - General Electrical Failure	- Fuse failure - Harness fault - Dynamic response control module internal failure	- Refer to the electrical circuit diagrams and check the supply circuit fuse of the dynamic response control module power. Replace as required, clear DTC and retest - Refer to the electrical circuit diagrams and check the dynamic response control module power supply circuit - Circuit reference VBATT - For short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the dynamic response valve circuits for short circuit to ground, short circuit to power, open circuit, high resistance. Repair circuit as required, Clear the DTCs and retest - If the fault persists, install a new dynamic response control module
C105B-19	Actuator Circuit Group B - Circuit current above threshold	- Fuse failure - Harness fault - Dynamic response control module internal failure	- Refer to the electrical circuit diagrams and check the dynamic response control module power supply circuit fuse. Replace as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the dynamic response control module power supply circuit, harness and

			connectors - Circuit reference VBATT - For short circuit to ground, short circuit to power. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the dynamic response valve circuits for short circuit to ground, short circuit to power. Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response control module
C105B-1D	Actuator Circuit Group B - Circuit current out of range	- Harness fault - Dynamic response control module internal failure	- Refer to the electrical circuit diagrams and check the dynamic response control module power supply circuit - Circuit reference VBATT - For short circuit to ground, short circuit to power. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the dynamic response valve circuits for short circuit to ground, short circuit to power. Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response control module
C105B-64	Actuator Circuit Group B - Signal plausibility failure	- Harness fault - Dynamic response control module internal failure	- Refer to the electrical circuit diagrams and check the dynamic response control module power supply circuit - Circuit reference VBATT - For short circuit to ground, short circuit to power, high resistance. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the dynamic response valve circuits for short circuit to ground, short circuit to power, high resistance. Repair circuit as required, Clear the DTCs and retest - If the fault persists, install a new

			dynamic response control module
C1116-62	Torque/Pressure - Signal compare failure	- Dynamic response hydraulic fluid circuit requires bleeding - Dynamic response hydraulic fluid low - Dynamic response hydraulic fluid leak - Dynamic response hydraulic fluid contaminated - Sensor fault (front or rear) - Valve fault (front or rear) - Dynamic response hydraulic pump pressure/flow too low - Actuator fault	- Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required - Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest - Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid - If the fault persists, check the dynamic response control module for front/rear dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and clear adaptive data. clear the DTCs and retest - If the fault persists, check the dynamic response hydraulic pump pressure/fluid flow. If faulty, check and install a new dynamic response hydraulic pump as required - Using the manufacture approved diagnostic system, demand 55 bar pressure from the pressure control valve for 5 minutes to heat the system. Then, demand 50 bar from the front axle rod pressure regulating valve for 2 minutes, if pressure drops and/or the pipes to the front actuator get hot, this indicates a faulty actuator. Check

			and install a new roll bar module as required. Clear the DTCs and retest Repeat this procedure for the front axle piston/rear axle rod/rear axle piston pressure regulating valves
C1116-92	Torque/Pressure - Performance or incorrect operation	- Dynamic response hydraulic fluid circuit requires bleeding - Dynamic response hydraulic fluid low - Dynamic response hydraulic fluid leak - Dynamic response hydraulic fluid contaminated - Sensor fault (front or rear) - Valve fault (front or rear) - Dynamic response hydraulic pump pressure/flow too low	- Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required - Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest - Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid - If the fault persists, check the dynamic response control module for front/rear dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and clear adaptive data. Clear the DTCs and retest - If the fault persists, check the dynamic response hydraulic pump pressure/fluid flow. If faulty, install a new dynamic response hydraulic pump
C1119-09	Hydraulic Pressure - Component Failures	- Low hydraulic fluid level - Leak in high pressure primary	- Check and top up the hydraulic fluid as required - Check integrity of hydraulic system and rectify any leaks as required.

		circuit ▪ Leaking hydraulic fluid reservoir ▪ Leak in secondary circuit ▪ Pressure control valve - Stuck valve ▪ Pressure transducer fault ▪ Actuator fault ▪ Dynamic response hydraulic pump fault	Clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and clear adaptive data. Clear the DTCs and retest ▪ If the fault persists, check the operation of the front and rear actuators and install new actuator(s) as required. Clear the DTCs and retest ▪ If the fault persists, check the dynamic response hydraulic pump pressure/fluid flow. If faulty, install a new dynamic response hydraulic pump as required
C1119-22	Hydraulic Pressure - Signal amplitude > maximum	▪ Pressure transducer fault ▪ Pressure control valve fault	▪ Check integrity of hydraulic system and rectify any leaks as required. Clear the DTCs and retest ▪ If the fault persists, install a new pressure transducer. Clear the DTCs and retest ▪ If the fault persists, install a new valve block. Clear the DTCs and retest
C1119-62	Hydraulic Pressure - Signal compare failure	▪ Low hydraulic fluid level ▪ Leak in high pressure primary circuit ▪ Leaking hydraulic fluid reservoir ▪ Air in system ▪ Leak in secondary circuit ▪ Direction control valves stuck open ▪ Pressure control valve fault	▪ Check and top up the hydraulic fluid as required ▪ Check integrity of hydraulic system and rectify any leaks as required. Carry out manual bleed procedure. Clear the DTCs and retest ▪ If the fault persists, install a new valve block. Clear the DTCs and retest ▪ If the fault persists, install a new pressure transducer. Clear the DTCs and retest ▪ If the fault persists, install a new filter. Clear the DTCs and retest ▪ If the fault persists, check the operation of the front and rear actuators and install new

		■ Pressure transducer fault ■ Blocked filter ■ Actuator fault ■ Broken drop link ■ Broken stabilizer bar	actuator(s) as required. Clear the DTCs and retest ■ If the fault persists, install a new drop link(s) or stabilizer bar(s). Clear the DTCs and retest
C1119-7B	Hydraulic Pressure - Low fluid level	■ Low hydraulic fluid level ■ Leak in high pressure primary circuit ■ Leaking hydraulic fluid reservoir ■ Leak in secondary circuit ■ Blocked filter ■ Low pump flow ■ Blocked or kinked suction hose	■ Check and top up the hydraulic fluid as required ■ Check integrity of hydraulic system and rectify any leaks as required. Clear the DTCs and retest ■ If the fault persists, install a new filter. Clear the DTCs and retest ■ If the fault persists, install a new hydraulic pump. Clear the DTCs and retest ■ If the fault persists, check the suction hose for blockage or kinking and rectify or replace as required. Clear the DTCs and retest
C1119-91	Hydraulic Pressure - Parametric	■ Residual hydraulic pressure too high ■ Contaminated hydraulic fluid ■ Blocked or kinked suction hose ■ Pressure transducer fault ■ Pressure control valve fault	■ Check integrity of hydraulic system, clean the system and replace the hydraulic fluid. Check and replace the return pipe as necessary. Clear the DTCs and retest ■ If the fault persists, check the suction hose for blockage or kinking and rectify or replace as required. Clear the DTCs and retest ■ If the fault persists, install a new pressure transducer. Clear the DTCs and retest ■ If the fault persists, install a new valve block. Clear the DTCs and retest
C1A97-	Lateral	■ Unexpected	■ Check the lower accelerometer

64	Accelerometer - Signal plausibility failure	signals received from the lower accelerometer ▪ Damaged accelerometer ▪ Bent accelerometer bracket	and bracket for security and integrity. Repair/replace as required
C1B11-12	Pressure Control Valve - Circuit short to power	▪ Pressure control valve circuit short circuit to power, short circuit to another circuit ▪ Pressure control valve circuit very low resistance ▪ Pressure control valve fault	▪ Refer to the electrical circuit diagrams and check the pressure control valve circuit, harness and connectors for short circuit to power, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the resistance of the pressure control valve circuit (nominal value should be 5.1 ohms). Repair circuit as required, Clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and clear adaptive data. Clear the DTCs and retest
C1B11-14	Pressure Control Valve - Circuit short to ground or open	▪ Pressure control valve circuit short circuit to ground, open circuit, high resistance ▪ Pressure control valve fault	▪ Refer to the electrical circuit diagrams and check the pressure control valve circuit, harness and connectors for short circuit to ground, open circuit, high resistance. Repair circuit as required, clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the resistance of the pressure control valve circuit (nominal value should be 5.1 ohms). Repair circuit as required, Clear the DTCs and retest ▪ If the fault persists, install a new dynamic response valve block as required and clear adaptive data. Clear the DTCs and retest
C1B11-	Pressure Control	▪ Pressure control	▪ Refer to the electrical circuit

18	Valve - Circuit current below threshold	valve circuit open circuit, high resistance Pressure control valve fault	diagrams and check the pressure control valve circuit, harness and connectors for open circuit, high resistance. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the pressure control valve circuit (nominal value should be 5.1 ohms). Repair circuit as required, Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and clear adaptive data. Clear the DTCs and retest
C1B11-1D	Pressure Control Valve - Circuit current out of range	- Pressure control valve circuit short circuit to ground, short circuit to another circuit - Pressure control valve fault	- Refer to the electrical circuit diagrams and check the pressure control valve circuit, harness and connectors for short circuit to ground, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the pressure control valve circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest - If the fault persists, check and install a new dynamic response valve block as required and clear adaptive data. Clear the DTCs and retest
C1B11-28	Pressure Control Valve - Signal bias level out of range / zero adjustment failure	- Pressure control valve circuit short circuit to another circuit - Dynamic response control module amplifier failure	- Refer to the electrical circuit diagrams and check the pressure control valve circuit, harness and connectors for short circuit to another circuit. Repair circuit as required, Clear the DTCs and retest - If the fault persists, install a new dynamic response control module. Clear the DTCs and retest
C1B11-	Pressure Control	Dynamic	Check for air and/or other

62	Valve - Signal compare failure	response hydraulic fluid circuit requires bleeding - Dynamic response hydraulic fluid low - Dynamic response hydraulic fluid leak from high pressure primary circuit, secondary circuit or dynamic response hydraulic fluid reservoir - Dynamic response hydraulic fluid contaminated - Broken stabilisation link - Broken roll bar module - Pressure control valve pressure sensor fault - Pressure control valve - Sticking valve - Actuator fault	contaminants in dynamic response hydraulic fluid circuit and bleed as required - Check dynamic response hydraulic fluid levels. Check the dynamic response reservoir and hydraulic circuits for leaks. Repair or replace leaking components as required. Clear the DTCs and retest - Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid - Check the security and integrity of the stabilisation link. Repair or replace components as required. Clear the DTCs and retest - Check the security and integrity of the roll bar module. Repair or replace components as required. Clear the DTCs and retest - If the fault persists, check the dynamic response control module for dynamic response actuator pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest - If the fault persists, install a new dynamic response valve block as required and clear adaptive data. Clear the DTCs and retest
C1B11-64	Pressure Control Valve - Signal plausibility failure	- Pressure control valve circuit - High resistance - Pressure control valve fault	- Refer to the electrical circuit diagrams and check the pressure control valve circuit, harness and connectors for short circuit faults. Repair circuit as required, clear the DTCs and retest - Refer to the electrical circuit diagrams and check the resistance of the pressure control valve circuit (nominal value should be 5.1 ohms). Repair circuit as required,

			clear the DTCs and retest ■ If the fault persists, install a new dynamic response valve block as required and clear adaptive data. Clear the DTCs and retest
C1B11-92	Pressure Control Valve - Performance or incorrect operation	■ Pressure control valve circuit - High resistance ■ Dynamic response hydraulic fluid circuit requires bleeding ■ Dynamic response hydraulic fluid low ■ Dynamic response hydraulic fluid contaminated ■ Pressure control valve pressure sensor fault ■ Valve fault ■ Dynamic response hydraulic pump pressure/flow too low	■ Refer to the electrical circuit diagrams and check the pressure control valve circuit, harness and connectors for short circuit faults. Repair circuit as required, clear the DTCs and retest ■ Refer to the electrical circuit diagrams and check the resistance of the pressure control valve circuit (nominal value should be 5.1 ohms). Repair circuit as required, clear the DTCs and retest ■ Check for air and/or other contaminants in dynamic response hydraulic fluid circuit and bleed as required ■ Check dynamic response hydraulic fluid levels. Rectify as required. Clear the DTCs and retest ■ Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid ■ If the fault persists, check the dynamic response control module for dynamic response pressure control valve pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest ■ If the fault persists, install a new dynamic response valve block as required and clear adaptive data. Clear the DTCs and retest ■ If the fault persists, check the dynamic response hydraulic pump

			pressure/fluid flow. If faulty, check and install a new dynamic response hydraulic pump
C1B12-14	Lower Lateral Accelerometer - Circuit short to ground or open	- Lower lateral accelerometer signal circuit - Short circuit to ground, short to another circuit, open circuit, high resistance - Lower lateral accelerometer failure	- Refer to the electrical circuit diagrams and check the lower lateral accelerometer signal circuit for short circuit to ground, short to another circuit, open circuit, high resistance. Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new lower lateral accelerometer. After installation, calibrate the accelerometer/dynamic response control module, as required
C1B12-17	Lower Lateral Accelerometer - Circuit voltage above threshold	Lower lateral accelerometer signal circuit - Short circuit to power, short to another circuit	Refer to the electrical circuit diagrams and check the lower lateral accelerometer signal circuit for short circuit to power, short to another circuit. Repair circuit as required, clear the DTCs and retest
C1B12-22	Lower Lateral Accelerometer - Signal amplitude > maximum	- Lower lateral accelerometer loose - Lower lateral accelerometer signal circuit - Short circuit to another circuit - Lower lateral accelerometer failure	- Check the lower lateral accelerometer is securely installed. Rectify as necessary. Clear the DTCs and retest - If the fault persists, refer to the electrical circuit diagrams and check the lower lateral accelerometer signal circuit for short circuit to another circuit. Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new lower lateral accelerometer. After installation, calibrate the accelerometer/dynamic response control module, as required
C1B12-26	Lower Lateral Accelerometer - Signal rate of change below threshold	Lower lateral accelerometer signal circuit - Short circuit to another circuit	Refer to the electrical circuit diagrams and check the lower lateral accelerometer signal circuit for short circuit to another circuit. Repair circuit as required, clear the

		Lower lateral accelerometer failure	DTCs and retest If the fault persists, install a new lower lateral accelerometer. After installation, calibrate the accelerometer/dynamic response control module, as required
C1B12-28	Lower Lateral Accelerometer - Signal bias level out of range/zero adjustment failure	- Lower lateral accelerometer mounting damaged - Lower lateral accelerometer loose - Lower lateral accelerometer failure	- Check the integrity of the lower lateral accelerometer mountings. Check the lower lateral accelerometer is securely installed. Rectify as necessary. Clear the DTCs and retest - If fault persists, install a new lower lateral accelerometer. After installation, calibrate the accelerometer/dynamic response control module, as required
C1B12-62	Lower Lateral Accelerometer - Signal compare failure	- Lower lateral accelerometer mounting damaged - Damaged bodywork - Lower lateral accelerometer loose - Lower or upper lateral accelerometer failure - Vehicle accelerometer failure	- Check the integrity of the lower lateral accelerometer mountings. Check the lower lateral accelerometer is securely installed. Rectify as necessary. Clear the DTCs and retest - Check body alignment and rectify as required - Using the manufacturer approved diagnostic system, check individual lower and upper accelerometer signals and replace faulty sensor if zero 'g' value $> \pm 0.175g$ - Using the manufacturer approved diagnostic system, check the operation of the vehicle accelerometer and rectify as required - Recalibrate accelerometers if any components have been replaced or repositioned
C1B12-78	Lower Lateral Accelerometer - Alignment or adjustment incorrect	- Lower lateral accelerometer mounting damaged - Lower lateral accelerometer	Check the integrity of the lower lateral accelerometer mountings. Check the lower lateral accelerometer is securely installed. Rectify as necessary. Clear the DTCs and retest

		loose Lower lateral accelerometer failure	If the fault persists, install a new lower lateral accelerometer. After installation, calibrate the accelerometer/dynamic response control module, as required
C1B13-14	Upper Lateral Accelerometer - Circuit short to ground or open	- Upper lateral accelerometer signal circuit - Short circuit to ground, short to another circuit, open circuit, high resistance - Upper lateral accelerometer failure	- Refer to the electrical circuit diagrams and check the upper lateral accelerometer signal circuit for short circuit to ground, short to another circuit, open circuit, high resistance. Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new upper lateral accelerometer. After installation, calibrate the accelerometer/dynamic response control module, as required
C1B13-17	Upper Lateral Accelerometer - Circuit voltage above threshold	Upper lateral accelerometer signal circuit - Short circuit to power, short to another circuit	Refer to the electrical circuit diagrams and check the upper lateral accelerometer signal circuit for short circuit to power, short to another circuit. Repair circuit as required, clear the DTCs and retest
C1B13-22	Upper Lateral Accelerometer - Signal amplitude > maximum	- Upper lateral accelerometer loose - Upper lateral accelerometer signal circuit - Short circuit to another circuit - Upper lateral accelerometer failure	- Check the upper lateral accelerometer is securely installed. Rectify as necessary. Clear the DTCs and retest - If the fault persists, refer to the electrical circuit diagrams and check the upper lateral accelerometer signal circuit for short circuit to another circuit. Repair circuit as required, clear the DTCs and retest - If the fault persists, check and install a new upper lateral accelerometer. After installation, calibrate the accelerometer/dynamic response control module, as required
C1B13-26	Upper Lateral Accelerometer -	Upper lateral accelerometer	Refer to the electrical circuit diagrams and check the upper

	Signal rate of change below threshold	signal circuit - Short circuit to another circuit Upper lateral accelerometer failure	lateral accelerometer signal circuit for short circuit to another circuit. Repair circuit as required, clear the DTCs and retest If the fault persists, install a new upper lateral accelerometer. After installation, calibrate the accelerometer/dynamic response control module, as required
C1B13-28	Upper Lateral Accelerometer - Signal bias level out of range/zero adjustment failure	- Upper lateral accelerometer mounting damaged - Upper lateral accelerometer loose - Upper lateral accelerometer failure	- Check the integrity of the upper lateral accelerometer mountings. Check the upper lateral accelerometer is securely installed. Rectify as necessary. Clear the DTCs and retest - If the fault persists, install a new upper lateral accelerometer. After installation, calibrate the accelerometer/dynamic response control module, as required
C1B13-62	Upper Lateral Accelerometer - Signal compare failure	- Upper lateral accelerometer mounting damaged - Damaged bodywork - Upper lateral accelerometer loose - Upper and/or lower lateral accelerometer failure - Vehicle accelerometer failure	- Check the integrity of the upper lateral accelerometer mountings. Check the upper lateral accelerometer is securely installed. Rectify as necessary. Clear the DTCs and retest - Check body alignment and rectify as required - Using the manufacturer approved diagnostic system, check individual upper and lower accelerometer signals and replace faulty sensor if zero 'g' value $> \pm 0.175g$ - Using the manufacturer approved diagnostic system, check the operation of the vehicle accelerometer and rectify as required - Recalibrate accelerometers if any components have been replaced or repositioned
C1B13-78	Upper Lateral Accelerometer - Alignment or	Upper lateral accelerometer mounting	Check the integrity of the upper lateral accelerometer mountings. Check the upper lateral

	adjustment incorrect	damaged ■ Upper lateral accelerometer loose ■ Upper lateral accelerometer failure	accelerometer is securely installed. Rectify as necessary. Clear the DTCs and retest ■ If the fault persists, install a new upper lateral accelerometer. After installation, calibrate the accelerometer/dynamic response control module, as required
C1B14-11	Sensor Supply Voltage A - Circuit short to ground	■ Dynamic response control module power or ground circuit - Open circuit, high resistance ■ Lower lateral accelerometer or front axle pressure regulating valve pressure sensors or pressure control valve pressure sensor supply circuit(s) - Short circuit to ground, short circuit to another circuit ■ Lower lateral accelerometer failure ■ Pressure sensor failure ■ Dynamic response control module - Internal failure	■ Refer to the electrical circuit diagrams and check power and ground circuits to the dynamic response control module for intermittent or poor connections. Repair the circuits as required, Clear DTC and retest ■ Refer to the electrical circuit diagrams and check these items for short circuit to ground, short circuit to another circuit- Lower lateral accelerometer, front axle pressure regulating valve pressure sensors, pressure control valve pressure sensor supply circuit(s), repair the circuit as required. Clear DTC and retest ■ If the fault persists, install a new lower lateral accelerometer. After installation, calibrate the accelerometer/dynamic response control module, as required. Clear the DTCs and retest ■ If the fault persists, check the operation of the front axle pressure regulating valve pressure sensors. If faulty, check and install a new dynamic response valve block as required and clear adaptive data. Clear the DTCs and retest ■ If the fault persists, check control module sensor supply output voltage. Measured voltage should be between 4.75 volts and 4.96 volts. If output voltage is out of range, check and install a new dynamic response control module as required. Clear the DTCs and retest

C1B14-17	Sensor Supply Voltage A - Circuit voltage above threshold	- Lower lateral accelerometer or front axle pressure regulating valve pressure sensors or pressure control valve pressure sensor supply circuit(s) - Short circuit to power, short circuit to another circuit - Dynamic response control module - Internal failure	- Refer to the electrical circuit diagrams and check the lower lateral accelerometer or front axle pressure regulating valve pressure sensor or pressure control valve pressure sensor supply circuit(s) for short circuit to power, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest - If the fault persists, check control module sensor supply output voltage. Measured voltage should be between 4.75 volts and 4.96 volts. If output voltage is out of range, check and install a new dynamic response control module as required. Clear the DTCs and retest
C1B14-1C	Sensor Supply Voltage A - Circuit voltage out of range	- Lower lateral accelerometer or front axle pressure regulating valve pressure sensor or pressure control valve pressure sensor supply circuit(s) - Short circuit to ground, short circuit to another circuit - Lower lateral accelerometer failure - Pressure sensor failure - Dynamic response control module - Internal failure	- Refer to the electrical circuit diagrams and check the lower lateral accelerometer or front axle pressure regulating valve pressure sensor or pressure control valve pressure sensor supply circuit(s) for short circuit to ground, short to another circuit. Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new lower lateral accelerometer. After installation, calibrate the accelerometer/dynamic response control module, as required. Clear the DTCs and retest - If the fault persists, check the dynamic response control module for dynamic response pressure control valve pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest - If the fault persists, check the output voltage of the pressure control valve and front axle rod and piston pressure regulating valve pressure sensors. With ignition on only, the output should be > 0.01 volts. If output voltage is

			out of range, check and install a new dynamic response valve block as required and clear adaptive data. Clear the DTCs and retest ■ If the fault persists, check control module sensor supply output voltage. Measured voltage should be between 4.75 volts and 4.96 volts. If output voltage is out of range, check and install a new dynamic response control module as required. Clear the DTCs and retest
C1B15-11	Sensor Supply Voltage B - Circuit short to ground	■ Rear axle pressure regulating valve pressure sensor supply circuit(s) - Short circuit to ground, short circuit to another circuit ■ Pressure sensor failure ■ Dynamic response control module - Internal failure	■ Refer to the electrical circuit diagrams and check the rear axle pressure regulating valve pressure sensor supply circuit(s) for short circuit to ground, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest ■ If the fault persists, check the operation of the rear axle pressure regulating valve pressure sensors. If faulty, check and install a new dynamic response valve block as required and clear adaptive data. Clear the DTCs and retest ■ If the fault persists, check control module sensor supply output voltage. Measured voltage should be between 4.75 volts and 4.96 volts. If output voltage is out of range, check and install a new dynamic response control module as required. Clear the DTCs and retest
C1B15-17	Sensor Supply Voltage B - Circuit voltage above threshold	■ Rear axle pressure regulating valve pressure sensor supply circuit(s) - Short circuit to power, short circuit to another circuit ■ Dynamic response control	■ Refer to the electrical circuit diagrams and check the rear axle pressure regulating valve pressure sensor supply circuit(s) for short circuit to power, short circuit to another circuit. Repair circuit as required, clear the DTCs and retest ■ If the fault persists, check control module sensor supply output voltage. Measured voltage should

		module - Internal failure	be between 4.75 volts and 4.96 volts. If output voltage is out of range, check and install a new dynamic response control module as required. Clear the DTCs and retest
C1B15-1C	Sensor Supply Voltage B - Circuit voltage out of range	▪ Rear axle pressure regulating valve pressure sensor supply circuit(s) - Short circuit to ground, short circuit to another circuit ▪ Pressure sensor failure ▪ Dynamic response control module - Internal failure	▪ Refer to the electrical circuit diagrams and check the rear axle pressure regulating valve pressure sensor supply circuit(s) for short circuit to ground, short to another circuit. Repair circuit as required, clear the DTCs and retest ▪ If the fault persists, check the dynamic response control module for dynamic response pressure control valve pressure sensor fault DTCs and refer to the relevant DTC index. Clear the DTCs and retest ▪ If the fault persists, check control module sensor supply output voltage. Measured voltage should be between 4.75 volts and 4.96 volts. If output voltage is out of range, check and install a new dynamic response control module as required. Clear the DTCs and retest
C1B18-2F	Module Power Supplies - Signal erratic	▪ Loss of power to the control module whilst driving	▪ Check the module connector(s) for security and integrity. Rectify as required ▪ Refer to the electrical circuit diagrams and check the power supply circuit(s) to the module for poor or intermittent connection. Repair circuit(s) as required, clear the DTCs and retest
C1B18-62	Module Power Supplies - Signal compare failure	▪ Signal compare failure ▪ Inconsistent battery and ignition voltages received by dynamic	▪ Check the module connector(s) for security and integrity. Rectify as required ▪ Refer to the electrical circuit diagrams and check the power supply circuit(s) to the module for short circuit to ground, high

		response control module - Dynamic response control module supply circuit(s) - Short circuit to ground - Dynamic response control module supply circuit(s) - High resistance	resistance. Repair circuit(s) as required, clear the DTCs and retest
C1B18-94	Module Power Supplies - Unexpected operation	- Dynamic response control module cannot power down as required - Dynamic response control module - Internal failure	Clear the DTCs and retest. If the fault persists, install a new dynamic response control module
P1145-29	Calculated Torque Error - Signal invalid	- Internal control module - Calculation failure - Dynamic response control module - Internal failure	- Check for associated DTCs giving more information and refer to the relevant DTC index - Clear the DTCs and retest. If the fault persists, install a new dynamic response control module
P1905-00	Control Module Configured for End-of-Line Test Mode - No sub type information	Dynamic response control module - Not correctly configured	Using the manufacturer approved diagnostic system, configure the module as a new module. Clear the DTCs and retest
U0001-81	High Speed CAN Communication Bus - Invalid serial data received	Invalid data received from another control module via the high speed CAN bus (chassis or powertrain)	NOTE: Do NOT install a new dynamic response control module as this will NOT rectify the fault

			Using the manufacturer approved diagnostic system, check the snapshot data to determine the invalid data source control module. Check the relevant control module for related DTCs and refer to the relevant DTC index
U0001-87	High Speed CAN Communication Bus - Missing message	Missing message from another control module via the high speed CAN bus (chassis or powertrain)	NOTE: Do NOT install a new dynamic response control module as this will NOT rectify the fault - Using the manufacturer approved diagnostic system, check the snapshot data to determine the missing message source control module. Check the relevant control module for related DTCs and refer to the relevant DTC index - Using the manufacturer approved diagnostic system, complete a CAN network integrity test. Refer to the electrical circuit diagrams and check the high speed CAN network (chassis and powertrain) between the relevant control module (i.e. as indicated by the snapshot data) and the dynamic response control module
U0001-88	High Speed CAN Communication Bus - Bus off	High speed CAN fault	- Refer to the electrical circuit diagrams and check the power and ground connections to the module - Using the manufacturer approved diagnostic system, complete a CAN network integrity test. Refer to the electrical circuit diagrams and check the CAN network
U0300-00	Internal Control Module	Car configuration	Using the manufacturer approved diagnostic system check/amend

	Software Incompatibility - No sub type information	signal not received ▪ Car configuration file incorrect ▪ The dynamic response control module is not compatible with the vehicle	the car configuration file. Clear the DTCs and retest ▪ If the fault persists, check the dynamic response control module part number, install the correct part as required. Clear the DTCs and retest
U0300-57	Internal Control Module Software Incompatibility - Invalid / incomplete software component	▪ Incorrect software for the dynamic response control module has been installed	▪ Using the manufacturer approved diagnostic system check/amend the module software. Clear the DTCs and retest
U0428-86	Invalid Data Received From Steering Angle Sensor Module - Signal invalid	▪ Calculated steering wheel offset out of range ▪ Steering angle sensor out of calibration ▪ Steering angle sensor fault ▪ Wheels out of alignment	▪ Check the operation of the steering angle sensor and re-calibrate as required. Clear the DTCs and retest ▪ If the fault persists, check wheel alignment and rectify as required. Clear the DTCs and retest ▪ If the fault persists, install a new steering angle sensor
U1A14-00	CAN Initialization Failure - No sub type information	▪ CAN network harness short circuit or disconnected	▪ Refer to the electrical circuit diagrams and check the power and ground connections to the module ▪ Using the manufacturer approved diagnostic system, complete a CAN network integrity test. Refer to the electrical circuit diagrams and check the CAN network ▪ Refer to the electrical circuit diagrams and check the CAN network between the body control module/gateway module assembly and the dynamic response control module

U2007-98	Valve(s) - Component or system over temperature	■ Pressure control valve - Over specified operating temperature ■ Blocked or restricted cooler ■ Restricted high pressure feed/return pipes ■ Contaminated hydraulic fluid ■ Vehicle has experienced prolonged lateral acceleration ■ Pressure control valve fault	■ Check pipe work and replace as required ■ Check the operation of the cooler unit and replace as necessary ■ Drain reservoir and inspect mesh filter for signs of significant contamination. Identify source of contamination (check condition and operation of dynamic response actuators and hydraulic pump) and rectify as required. Flush dynamic response hydraulic fluid circuit and recharge with clean hydraulic fluid ■ Investigate driving profile ■ Clear the DTCs and retest. If the fault persists, check the operation of the pressure control valve. If a valve fault is noted, check and install a new valve block as required and reset adaptive data
U201A-54	Control Module Main Calibration Data - Missing calibration	■ A new dynamic response control module has been installed and is not correctly configured	■ Using the manufacturer approved diagnostic system, configure the module as a new module. Clear the DTCs and retest
U201A-57	Control Module Main Calibration Data - Invalid / incomplete software component	■ A new dynamic response control module has been installed and is not correctly configured ■ Incorrect calibration data has been installed ■ Incorrect software has been installed	■ Using the manufacturer approved diagnostic system, confirm correct calibration data and software versions and install as required. Clear the DTCs and retest
U2100-00	Initial Configuration Not Complete - No sub type	■ Car configuration data has not been loaded	■ Check/amend the car configuration file using the manufacturer approved diagnostic system. Clear the DTCs and retest

	information	correctly ▪ New body control module / gateway module assembly has been fitted but not initialized ▪ Body control module / gateway module assembly fault	▪ Check the body control module / gateway module assembly for related DTCs and refer to the relevant DTC index
U2101-00	Control Module Configuration Incompatible - No sub type information	▪ Car configuration data transmitted over CAN does not match dynamic response control module internal configuration	▪ Carry out the new module software installation procedure using the manufacturers approved diagnostic system. Clear the DTCs and retest
U3000-04	Control Module - System internal failures	▪ Control module - Internal failure ▪ Incorrect software for the dynamic response control module has been installed	▪ Clear the DTCs and retest. If the fault persists, contact the Jaguar Land Rover technical helpdesk for further guidance
U3000-43	Control Module - Special memory failure	▪ Control module - Internal failure ▪ Faulty alternator ▪ High resistance connections ▪ Erratic power supply	▪ Refer to the electrical circuit diagrams and check the power and ground circuits to the module for circuit faults, including intermittent high resistance. Repair circuit as required, clear the DTCs and retest ▪ If the fault persists, check the operation of the alternator and replace as required ▪ Check for power-related DTCs and refer to the relevant DTC index ▪ If the fault persists, install a new dynamic response control module

U3000-45	Control Module - Program memory failure	- Control module - Internal failure - Faulty alternator - High resistance connections - Erratic power supply	- Refer to the electrical circuit diagrams and check the power and ground circuits to the module for circuit faults, including intermittent high resistance. Repair circuit as required, clear the DTCs and retest - If the fault persists, check the operation of the alternator and replace - Check for power-related DTCs and refer to the relevant DTC index - If the fault persists, install a new dynamic response control module
U3000-47	Control Module - Watchdog/safety microcontroller failure	- Control module - Internal watchdog/safety microcontroller failure - Faulty alternator - High resistance connections - Erratic power supply - The control module has carried out a software reset	- Refer to the electrical circuit diagrams and check the power and ground circuits to the module for circuit faults, including intermittent high resistance. Repair circuit as required, clear the DTCs and retest - If the fault persists, check the operation of the alternator and replace as required - Check for power-related DTCs and refer to the relevant DTC index - If the fault persists, install a new dynamic response control module
U3000-48	Control Module - Supervision software failure	- The dynamic response control module is not correctly programmed - Dynamic response control module - Internal fault	- Using the manufacturer approved diagnostic system, confirm correct calibration data and software versions and install as required. Clear the DTCs and retest - If the fault persists, install a new dynamic response control module
U3000-54	Control Module - Missing calibration	The control module has been replaced and no software is installed	Using the manufacturer approved diagnostic system, confirm correct calibration data and software versions and install as required. Clear the DTCs and retest

U3003-1C	Battery Voltage - Circuit voltage out of range	- Power supply circuit - Voltage out of range (supply voltage at control module below 10.5V or above 18V for 30 seconds) - Faulty alternator - High resistance connections - Erratic power supply - Dynamic response control module - Internal fault	- Check the battery is in good condition and fully charged, refer to the battery care manual - Refer to the starting and charging section of the workshop manual and check the performance of the charging system - Refer to the electrical circuit diagrams and check power and ground circuit to the control module for faults, including intermittent high resistance. Repair circuit as required, clear the DTCs and retest - If the fault persists, check the operation of the alternator and replace as required - Check for power-related DTCs and refer to the relevant DTC index - If the fault persists, install a new dynamic response control module
U3003-62	Battery Voltage - Signal compare failure	- Signal compare failure - High resistance connections - Control module - Internal failure	- Check the battery is in good condition and fully charged, refer to the battery care manual - Refer to the starting and charging section of the workshop manual and check the performance of the charging system - Refer to the electrical circuit diagrams and check power and ground circuit to the control module for faults, including intermittent high resistance. Repair circuit as required, clear the DTCs and retest - If the fault persists, install a new dynamic response control module
U300A-62	Ignition Switch - Signal compare failure	Mismatch between hardwired ignition voltage supply and control module internal measured	- Check the security and integrity of the switched ignition supply circuit connectors. Rectify as required - Refer to the electrical circuit diagrams and check the switched ignition supply circuit to the control module for faults, including

		voltage	intermittent high resistance. Repair circuit as required, clear the DTCs and retest
U300A-64	Ignition Switch - Signal plausibility failure	Switched ignition supply circuit - Short circuit to ground, open circuit, high resistance	- Check the security and integrity of the switched ignition supply circuit connectors. Rectify as required - Refer to the electrical circuit diagrams and check the switched ignition supply circuit to the control module for short circuit to ground, open circuit, high resistance. Repair circuit as required, clear the DTCs and retest