

2016.0 RANGE ROVER (LG), 100-00

GENERAL INFORMATION

DESCRIPTION AND OPERATION

KEYLESS VEHICLE MODULE (KVM)

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.

NOTES:

- If a control module or a component is suspect and the vehicle remains under manufacturer warranty, refer to the Warranty Policy and Procedures manual, or determine if any prior approval programme is in operation, prior to the installation of a new module/component.
- Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system).
- When performing voltage or resistance tests, always use a digital multimeter accurate to three decimal places, and with an up-to-date calibration certificate. When testing resistance always take the resistance of the digital multimeter leads into account.
- Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.
- Inspect connectors for signs of water ingress, and pins for damage and/or corrosion.
- If DTCs are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always check for loose connections and corroded terminals.
- Check DDW for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and carry out the recommendations as required.

The table below lists all Diagnostic Trouble Codes (DTCs) that could be logged in the Keyless Vehicle Module (KVM). For additional diagnosis and testing information, refer to the relevant Diagnosis and Testing section in the workshop manual. For additional information, refer to:

[Anti-Theft - Active](#) (419-01A Anti-Theft - Active, Diagnosis and Testing),
[Locks, Latches and Entry Systems](#) (501-14 Handles, Locks, Latches and Entry Systems, Diagnosis and Testing).

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B102B-00	Passive Key response error - No sub type information	Smart key is not configured correctly	NOTE: This DTC is set if an invalid smart key is detected when the stop/start switch is operated Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, re-configure the smart key with the latest level software
B10A9-00	Remote Keyless Entry Less Than 2 Keys Programmed - No sub type information	Secret key has been programmed to the vehicle but less than 2 key fobs have been programmed	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, re-configure the smart key with the latest level software
B10C1-15	Left Front Unlock Pull Switch - Short circuit to battery or open	Front left exterior door handle unlock switch circuit open circuit, high resistance	Refer to the electrical circuit diagrams and test the front left exterior door handle unlock switch circuit for open circuit, high resistance
B10C1-23	Left Front Unlock Pull Switch - Signal stuck low	Front left exterior door handle unlock switch circuit short circuit to ground	Refer to the electrical circuit diagrams and test the front left exterior door handle unlock switch circuit for short circuit to ground
B10C2-15	Left Rear Unlock Pull Switch - Short circuit to battery or open	Rear left exterior door handle unlock switch circuit open circuit, high resistance	Refer to the electrical circuit diagrams and test the rear left exterior door handle unlock switch circuit for open circuit, high resistance

B10C2-23	Left Rear Unlock Pull Switch - Signal stuck low	▪ Rear left exterior door handle unlock switch circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and test the rear left exterior door handle unlock switch circuit for short circuit to ground
B10C3-15	Right Front Unlock Pull Switch - Short circuit to battery or open	▪ Front right exterior door handle unlock switch circuit open circuit, high resistance	▪ Refer to the electrical circuit diagrams and test the front right exterior door handle unlock switch circuit for open circuit, high resistance
B10C3-23	Right Front Unlock Pull Switch - Signal stuck low	▪ Front right exterior door handle unlock switch circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and test the front right exterior door handle unlock switch circuit for short circuit to ground
B10C4-15	Right Rear Unlock Pull Switch - Short circuit to battery or open	▪ Rear right exterior door handle unlock switch circuit open circuit, high resistance	▪ Refer to the electrical circuit diagrams and test the rear right exterior door handle unlock switch circuit for open circuit, high resistance
B10C4-23	Right Rear Unlock Pull Switch - Signal stuck low	▪ Rear right exterior door handle unlock switch circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and test the rear right exterior door handle unlock switch circuit for short circuit to ground
B10C5-23	Trunk Unlock Pull Switch - Signal stuck low	▪ Tailgate release switch short circuit to ground	▪ Refer to the electrical circuit diagrams and test the tailgate release switch circuit for short circuit to ground
B10C6-00	Exterior Trunk Antenna - No sub type information	▪ Tailgate exterior LF antenna circuit short circuit to ground, short circuit to power	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first

			Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the tailgate exterior LF antenna circuit for short circuit to ground, short circuit to power
B10C6-11	Exterior Trunk Antenna - Circuit short to ground	Tailgate exterior LF antenna circuit short circuit to ground, short circuit between positive and negative	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the tailgate exterior LF antenna circuit for short circuit to ground, short circuit between positive and negative
B10C6-12	Exterior Trunk Antenna - Circuit short to battery	Tailgate exterior LF antenna circuit short circuit to power	Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the tailgate exterior LF antenna circuit for short circuit to power
B10C6-13	Exterior Trunk Antenna - Circuit open	Tailgate exterior LF antenna circuit open circuit, high resistance	

			NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the tailgate exterior LF antenna circuit for open circuit, high resistance
B10C7-00	Interior Trunk Antenna - No sub type information	Luggage compartment left LF antenna circuit short circuit to ground, short circuit to power	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the luggage compartment left LF antenna circuit for short circuit to ground, short circuit to power
B10C7-11	Interior Trunk Antenna - Circuit short to ground	Luggage compartment left LF antenna circuit short circuit to ground, short circuit between positive and negative	

			NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the luggage compartment left LF antenna circuit for short circuit to ground, short circuit between positive and negative
B10C7-12	Interior Trunk Antenna - Circuit short to battery	Luggage compartment left LF antenna circuit short circuit to power	Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the luggage compartment left LF antenna circuit for short circuit to power
B10C7-13	Interior Trunk Antenna - Circuit open	Luggage compartment left LF antenna circuit open circuit, high resistance	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If

			the fault persists, refer to the electrical circuit diagrams and test the luggage compartment left LF antenna circuit for open circuit, high resistance
B10C8-00	Interior Center Antenna - No sub type information	Passenger compartment rear LF antenna circuit short circuit to ground, short circuit to power	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the passenger compartment rear LF antenna circuit for short circuit to ground, short circuit to power
B10C8-11	Interior Center Antenna - Circuit short to ground	Passenger compartment rear LF antenna circuit short circuit to ground, short circuit between positive and negative	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the passenger compartment rear LF antenna circuit for short circuit to ground, short

			circuit between positive and negative
B10C8-12	Interior Center Antenna - Circuit short to battery	Passenger compartment rear LF antenna circuit short circuit to power	Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the passenger compartment rear LF antenna circuit for short circuit to power
B10C8-13	Interior Center Antenna - Circuit open	Passenger compartment rear LF antenna circuit open circuit, high resistance	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the passenger compartment rear LF antenna circuit for open circuit, high resistance
B10C9-00	Interior Front Antenna - No sub type information	Passenger compartment front LF antenna circuit short circuit to ground, short circuit to power	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system,

			clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the passenger compartment front LF antenna circuit for short circuit to ground, short circuit to power
B10C9-11	Interior Front Antenna - Circuit short to ground	Passenger compartment front LF antenna circuit short circuit to ground, short circuit between positive and negative	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the passenger compartment front LF antenna circuit for short circuit to ground, short circuit between positive and negative
B10C9-12	Interior Front Antenna - Circuit short to battery	Passenger compartment front LF antenna circuit short circuit to power	Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the passenger compartment front LF antenna circuit for short circuit to power
B10C9-13	Interior Front Antenna - Circuit open	Passenger compartment front LF antenna circuit	

		open circuit, high resistance	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the passenger compartment front LF antenna circuit for open circuit, high resistance
B10CA-00	Left rear door handle Antenna - No sub type information	Rear left exterior door handle LF antenna circuit short circuit to ground, short circuit to power	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the rear left exterior door handle LF antenna circuit for short circuit to ground, short circuit to power
B10CA-11	Left rear door handle Antenna - Circuit short to ground	Rear left exterior door handle LF antenna circuit short circuit to ground, short circuit between positive and	

		negative	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the rear left exterior door handle LF antenna circuit for short circuit to ground, short circuit between positive and negative
B10CA-12	Left rear door handle Antenna - Circuit short to battery	Rear left exterior door handle LF antenna circuit short circuit to power	Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0202). If the fault persists, refer to the electrical circuit diagrams and test the rear left exterior door handle LF antenna circuit for short circuit to power
B10CA-13	Left rear door handle Antenna - Circuit open	Rear left exterior door handle LF antenna circuit open circuit, high resistance	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If

			the fault persists, refer to the electrical circuit diagrams and test the rear left exterior door handle LF antenna circuit for open circuit, high resistance
B10CB-00	Right rear door handle Antenna - No sub type information	▪ Rear right exterior door handle LF antenna circuit short circuit to ground, short circuit to power	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the rear right exterior door handle LF antenna circuit for short circuit to ground, short circuit to power
B10CB-11	Right rear door handle Antenna - Circuit short to ground	▪ Rear right exterior door handle LF antenna circuit short circuit to ground, short circuit between positive and negative	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the rear right exterior door handle LF antenna circuit for short circuit to ground, short

			circuit between positive and negative
B10CB-12	Right rear door handle Antenna - Circuit short to battery	Rear right exterior door handle LF antenna circuit short circuit to power	Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the rear right exterior door handle LF antenna circuit for short circuit to power
B10CB-13	Right rear door handle Antenna - Circuit open	Rear right exterior door handle LF antenna circuit open circuit, high resistance	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the rear right exterior door handle LF antenna circuit for open circuit, high resistance
B10CC-23	Left Front Latch Clutch Switch - Signal stuck low	Front left door latch clutch switch circuit short circuit to ground	Refer to the electrical circuit diagrams and test the front left door latch clutch switch circuit for short circuit to ground
B10CD-23	Left Rear Latch Clutch Switch - Signal stuck low	Rear left door latch clutch switch circuit short circuit to ground	Refer to the electrical circuit diagrams and test the rear left door latch clutch switch circuit for short circuit to ground

B10CE-23	Right Front Latch Clutch Switch - Signal stuck low	Front right door latch clutch switch circuit short circuit to ground	Refer to the electrical circuit diagrams and test the front right door latch clutch switch circuit for short circuit to ground
B10CF-23	Right Rear Latch Clutch Switch - Signal stuck low	Rear right door latch clutch switch circuit short circuit to ground	Refer to the electrical circuit diagrams and test the rear right door latch clutch switch circuit for short circuit to ground
B10D1-23	Left Front Lock Button - Signal stuck low	Front left exterior door handle lock switch circuit short circuit to ground	Refer to the electrical circuit diagrams and test the front left exterior door handle lock switch circuit for short circuit to ground
B10D2-23	Left Rear Lock Button - Signal stuck low	Rear left exterior door handle lock switch circuit short circuit to ground	Refer to the electrical circuit diagrams and test the rear left exterior door handle lock switch circuit for short circuit to ground
B10D3-23	Right Front Lock Button - Signal stuck low	Front right exterior door handle lock switch circuit short circuit to ground	Refer to the electrical circuit diagrams and test the front right exterior door handle lock switch circuit for short circuit to ground
B10D4-23	Right Rear Lock Button - Signal stuck low	Rear right exterior door handle lock switch circuit short circuit to ground	Refer to the electrical circuit diagrams and test the rear right exterior door handle lock switch circuit for short circuit to ground
B12D5-16	Door Handle Proximity Sensor - Circuit voltage below threshold	- Door handle proximity sensor circuit short circuit to ground - Keyless vehicle module power or ground circuit open circuit, high resistance - Keyless vehicle	- Refer to the electrical circuit diagrams and test the door handle proximity sensor circuit for short circuit to ground - Using the manufacturer approved diagnostic system, check datalogger signal - ECU Power Supply Voltage (0xD111). Refer to the

		module failure	electrical circuit diagrams and test the keyless vehicle module power and ground circuits for open circuit, high resistance Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new keyless vehicle module
B12D6-11	Fast Door Unlock/Open Actuator - Circuit short to ground	Door E latch circuit(s) short circuit to ground	NOTE: Faults on individual pins/circuits cannot be detected. A short on any one output pin will be detected as a short on all pins/circuits Refer to the electrical circuit diagrams and test the door E latch circuits for short circuit to ground
B12D6-12	Fast Door Unlock/Open Actuator - Circuit short to battery	Door E latch circuit(s) short circuit to power	NOTE: Faults on individual pins/circuits cannot be detected. A short on any one output pin will be detected as a short on all pins/circuits Refer to the electrical circuit diagrams and test the door E latch circuits for short circuit to power
B12EA-96	Radio Frequency (RF) Receiver - Component internal failure	RF receiver failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new RF receiver

B1334-23	Tailgate Glass Release Switch - Signal stuck low	▪ Rear window switch circuit short circuit to ground ▪ Rear window switch stuck active	NOTE: This circuit/switch is available as an option ▪ Refer to the electrical circuit diagrams and test the rear window switch circuit for short circuit to ground ▪ Test the operation of the rear window switch
B1335-00	Front Triangulation / Loadspace Antenna - No sub type information	▪ Floor console front LF antenna circuit short circuit to ground, short circuit to power	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the floor console front LF antenna circuit for short circuit to ground, short circuit to power
B1335-11	Front Triangulation / Loadspace Antenna - Circuit short to ground	▪ Floor console front LF antenna circuit short circuit to ground, short circuit between positive and negative	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest.

			Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the floor console front LF antenna circuit for short circuit to ground, short circuit between positive and negative
B1335-12	Front Triangulation / Loadspace Antenna - Circuit short to battery	Floor console front LF antenna circuit short circuit to power	Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the floor console front LF antenna circuit for short circuit to power
B1335-13	Front Triangulation / Loadspace Antenna - Circuit open	Floor console front LF antenna circuit open circuit, high resistance	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the floor console front LF antenna circuit for open circuit, high resistance
B1336-00	Left Front Door External Antenna - No sub type information	Front left exterior door handle LF antenna circuit short circuit to ground, short circuit to power	

			NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the front left exterior door handle LF antenna circuit for short circuit to ground, short circuit to power
B1336-11	Left Front Door External Antenna - Circuit short to ground	Front left exterior door handle LF antenna circuit short circuit to ground, short circuit between positive and negative	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the front left exterior door handle LF antenna circuit for short circuit to ground, short circuit between positive and negative
B1336-12	Left Front Door External Antenna - Circuit short to battery	Front left exterior door handle LF antenna circuit short circuit to power	Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On

			Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the front left exterior door handle LF antenna circuit for short circuit to power
B1336-13	Left Front Door External Antenna - Circuit open	Front left exterior door handle LF antenna circuit open circuit, high resistance	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the front left exterior door handle LF antenna circuit for open circuit, high resistance
B1337-00	Right Front Door External Antenna - No sub type information	Front right exterior door handle LF antenna circuit short circuit to ground, short circuit to power	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the front right exterior door handle LF antenna circuit for short circuit to ground, short

			circuit to power
B1337-11	Right Front Door External Antenna - Circuit short to ground	Front right exterior door handle LF antenna circuit short circuit to ground, short circuit between positive and negative	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the front right exterior door handle LF antenna circuit for short circuit to ground, short circuit between positive and negative
B1337-12	Right Front Door External Antenna - Circuit short to battery	Front right exterior door handle LF antenna circuit short circuit to power	Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the front right exterior door handle LF antenna circuit for short circuit to power
B1337-13	Right Front Door External Antenna - Circuit open	Front right exterior door handle LF antenna circuit open circuit, high resistance	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer

			approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the front right exterior door handle LF antenna circuit for open circuit, high resistance
B133D-00	Loadspace/Interior Boot Antenna - No sub type information	▪ Luggage compartment right LF antenna circuit short circuit to ground, short circuit to power	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the luggage compartment right LF antenna circuit for short circuit to ground, short circuit to power
B133D-11	Loadspace/Interior Boot Antenna - Circuit short to ground	▪ Luggage compartment right LF antenna circuit short circuit to ground, short circuit between positive and negative	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams

			and test the luggage compartment right LF antenna circuit for short circuit to ground, short circuit between positive and negative
B133D-12	Loadspace/Interior Boot Antenna - Circuit short to battery	Luggage compartment right LF antenna circuit short circuit to power	Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the luggage compartment right LF antenna circuit for short circuit to power
B133D-13	Loadspace/Interior Boot Antenna - Circuit open	Luggage compartment right LF antenna circuit open circuit, high resistance	NOTE: If any other LF antenna short circuit to power DTC is also set, perform the relevant corrective action(s) first Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202). If the fault persists, refer to the electrical circuit diagrams and test the luggage compartment right LF antenna circuit for open circuit, high resistance
C1017-23	Boot/Trunk Primary Switch - Signal stuck low	NOTE: This circuit/switch is available as an option	NOTE: This circuit/switch is available as an option Refer to the electrical circuit

		- Hands-free tailgate sensor circuit short circuit to ground - Hands-free tailgate sensor fault	diagrams and check the hands-free tailgate sensor circuit for short circuit to ground. Repair circuit as required. Clear the DTCs and retest If the fault persists, install a new hands-free tailgate sensor
U0010-88	Medium Speed CAN Communication Bus - Bus off	Medium speed CAN bus (body) circuit short circuit to ground, short circuit to power, open circuit, high resistance	Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and test the medium speed CAN bus (body) circuit for short circuit to ground, short circuit to power, open circuit, high resistance
U0300-00	Internal Control Module Software Incompatibility - No sub type information	Car configuration file mismatch with vehicle specification	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs Using the manufacturer approved diagnostic system, check and up-date the car configuration file as necessary
U201F-00	External Receiver - No sub type information	- RF receiver power or ground circuit open circuit, high resistance - LIN bus circuit short circuit to ground, short circuit to power - RF receiver failure - Keyless vehicle module failure	- Refer to the electrical circuit diagrams and check the RF receiver power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the LIN bus circuit for short circuit to ground, short circuit to power, open circuit, high resistance

			▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new RF receiver ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new keyless vehicle module
U201F-31	External Receiver - No signal	▪ RF receiver power or ground circuit open circuit, high resistance ▪ LIN bus circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ RF receiver failure ▪ Keyless vehicle module failure	▪ Refer to the electrical circuit diagrams and check the RF receiver power and ground circuits for open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the LIN bus circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new RF receiver ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new keyless vehicle module
U201F-95	External Receiver - Incorrect assembly	▪ Car configuration file mismatch with vehicle specification ▪ Incorrect RF receiver installed ▪ Wrong frequency	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs ▪ Using the manufacturer approved diagnostic system, check and up-date the car configuration file as necessary

			Install a new RF receiver as necessary
U2100-00	Initial Configuration Not Complete - No sub type information	Keyless vehicle module is not configured correctly	Using the manufacturer approved diagnostic system, re-configure the keyless vehicle module with the latest level software
U2101-00	Control Module Configuration Incompatible - No sub type information	Car configuration file mismatch with vehicle specification	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs Using the manufacturer approved diagnostic system, check and up-date the car configuration file as necessary
U3000-44	Control Module - Data memory failure	Keyless vehicle control module failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202) If the fault persists, install a new keyless vehicle control module
U3000-45	Control Module - Program memory failure	Keyless vehicle control module failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202) If the fault persists, install a new keyless vehicle control module
U3000-46	Control Module - Calibration / parameter memory failure	Keyless vehicle control module configuration incorrect	Clear the DTCs and retest. If fault persists, configure the keyless vehicle control module using the manufacturer approved

		▪ Keyless vehicle control module failure	diagnostic system. Clear the DTCs and retest ▪ If the fault persists, install a new keyless vehicle control module
U3000-63	Control Module - Circuit / component protection time-out	▪ Keyless vehicle control module configuration incorrect ▪ Keyless vehicle control module failure	▪ Clear the DTCs and retest. If fault persists, check and install a keyless vehicle control module ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. Perform routine - On Demand Self Test (0x0202) If the fault persists, install a new keyless vehicle control module
U3000-95	Control Module - Incorrect assembly	▪ Incorrect keyless vehicle module installed ▪ Car configuration parameter indicates the vehicle should support full passive entry / passive start functionality, but installed module supports passive start only	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new keyless vehicle module
U3002-81	Vehicle Identification Number - Invalid serial data received	▪ Car configuration file mismatch with vehicle specification	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs ▪ Using the manufacturer approved diagnostic system, check and up-date the car configuration file as

			necessary	
--	--	--	-----------	--