

2016.0 RANGE ROVER (LG), 100-00

# GENERAL INFORMATION

DESCRIPTION AND OPERATION

---

---

## REAR INTEGRATED CONTROL PANEL (RICP)

### CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.

## NOTES:

- If a control module or a component is suspect and the vehicle remains under manufacturer warranty, refer to the Warranty Policy and Procedures manual, or determine if any prior approval programme is in operation, prior to the installation of a new module/component.
- Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system).
- When performing voltage or resistance tests, always use a digital multimeter accurate to three decimal places, and with an up-to-date calibration certificate. When testing resistance always take the resistance of the digital multimeter leads into account.
- Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.
- Inspect connectors for signs of water ingress, and pins for damage and/or corrosion.
- If DTCs are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always check for loose connections and corroded terminals.
- Check DDW for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and carry out the recommendations as required.

The table below lists all Diagnostic Trouble Codes (DTCs) that could be logged in the Rear Integrated Control Panel (RICP). For additional diagnosis and testing information, refer to the relevant Diagnosis and Testing section in the workshop manual.

For additional information, refer to: [Climate Control System](#) (412-00 Climate

## Control System - General Information, Diagnosis and Testing).

| DTC      | DESCRIPTION                                                          | POSSIBLE CAUSES                                                                                                                                                                                                                                                                         | ACTION                                                                                                                                                                                                                                                                                                                                                                              |
|----------|----------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B10B8-94 | Push Buttons - Unexpected operation                                  | <ul style="list-style-type: none"> <li>▪ Rear integrated control panel switch stuck active</li> <li>▪ Rear integrated control panel failure</li> </ul>                                                                                                                                  | <ul style="list-style-type: none"> <li>▪ Test the operation of the rear integrated control panel switches</li> <li>▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear integrated control panel</li> </ul>                                                                                                    |
| B13DE-11 | Left Rear Face Temperature Sensor - Circuit short to ground          | <p><b>NOTE:</b></p> <div>Circuit reference - LH RR FACE DUCT SENSOR</div> <ul style="list-style-type: none"> <li>▪ Rear left face duct air temperature sensor circuit short circuit to ground</li> <li>▪ Rear integrated control panel failure</li> </ul>                               | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the rear left face duct air temperature sensor circuit for short circuit to ground</li> <li>▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear integrated control panel</li> </ul>                               |
| B13DE-15 | Left Rear Face Temperature Sensor - Circuit short to battery or open | <p><b>NOTE:</b></p> <div>Circuit reference - LH RR FACE DUCT SENSOR</div> <ul style="list-style-type: none"> <li>▪ Rear left face duct air temperature sensor circuit short circuit to power, open circuit, high resistance</li> <li>▪ Rear integrated control panel failure</li> </ul> | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the rear left face duct air temperature sensor circuit for short circuit to power, open circuit, high resistance</li> <li>▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear integrated control panel</li> </ul> |

|          |                                                                       |                                                                                                                                                                                                                                                                                      |                                                                                                                                                                                                                                                                                                                                                                                  |
|----------|-----------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B13DF-11 | Right Rear Face Temperature Sensor - Circuit short to ground          | <p><b>NOTE:</b></p> <div>Circuit reference - RH RR FACE DUCT SENSOR</div> <ul style="list-style-type: none"> <li>Rear right face duct air temperature sensor circuit short circuit to ground</li> <li>Rear integrated control panel failure</li> </ul>                               | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the rear right face duct air temperature sensor circuit for short circuit to ground</li> <li>Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear integrated control panel</li> </ul>                               |
| B13DF-15 | Right Rear Face Temperature Sensor - Circuit short to battery or open | <p><b>NOTE:</b></p> <div>Circuit reference - RH RR FACE DUCT SENSOR</div> <ul style="list-style-type: none"> <li>Rear right face duct air temperature sensor circuit short circuit to power, open circuit, high resistance</li> <li>Rear integrated control panel failure</li> </ul> | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the rear right face duct air temperature sensor circuit for short circuit to power, open circuit, high resistance</li> <li>Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear integrated control panel</li> </ul> |
| B13E0-11 | Left Rear Foot Temperature Sensor - Circuit short to ground           | <p><b>NOTE:</b></p> <div>Circuit reference - LH RR FOOT DUCT SENSOR</div> <ul style="list-style-type: none"> <li>Rear left foot duct air temperature sensor circuit short circuit to ground</li> <li>Rear integrated</li> </ul>                                                      | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the rear left foot duct air temperature sensor circuit for short circuit to ground</li> <li>Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear integrated control panel</li> </ul>                                |

|          |                                                                       |                                                                                                                                                                                                                                                                                                                                                          |                                                                                                                                                                                                                                                                                                                                                                                      |
|----------|-----------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|          |                                                                       | control panel failure                                                                                                                                                                                                                                                                                                                                    |                                                                                                                                                                                                                                                                                                                                                                                      |
| B13E0-15 | Left Rear Foot Temperature Sensor - Circuit short to battery or open  | <p><b>NOTE:</b></p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> Circuit reference - LH RR FOOT DUCT SENSOR </div> <ul style="list-style-type: none"> <li>▪ Rear left foot duct air temperature sensor circuit short circuit to power, open circuit, high resistance</li> <li>▪ Rear integrated control panel failure</li> </ul> | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the rear left foot duct air temperature sensor circuit for short circuit to power, open circuit, high resistance</li> <li>▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear integrated control panel</li> </ul>  |
| B13E1-11 | Right Rear Foot Temperature Sensor - Circuit short to ground          | <p><b>NOTE:</b></p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> Circuit reference - RH RR FOOT DUCT SENSOR </div> <ul style="list-style-type: none"> <li>▪ Rear right foot duct air temperature sensor circuit short circuit to ground</li> <li>▪ Rear integrated control panel failure</li> </ul>                              | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the rear right foot duct air temperature sensor circuit for short circuit to ground</li> <li>▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear integrated control panel</li> </ul>                               |
| B13E1-15 | Right Rear Foot Temperature Sensor - Circuit short to battery or open | <p><b>NOTE:</b></p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> Circuit reference - RH RR FOOT DUCT SENSOR </div> <ul style="list-style-type: none"> <li>▪ Rear right foot duct air temperature sensor circuit short</li> </ul>                                                                                                 | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the rear right foot duct air temperature sensor circuit for short circuit to power, open circuit, high resistance</li> <li>▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear integrated control panel</li> </ul> |

|          |                                                                                      |                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                        |
|----------|--------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|          |                                                                                      | <p>circuit to power, open circuit, high resistance</p> <ul style="list-style-type: none"> <li>▪ Rear integrated control panel failure</li> </ul>                                                                                                                                                                                                |                                                                                                                                                                                                                                                                                                                                                                        |
| B13FB-11 | <p>Left Rear Massage Seat Switch Input</p> <p>- Circuit short to ground</p>          | <p><b>NOTE:</b></p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p>Circuit reference - LHR MESSAGE SWITCH</p> </div> <ul style="list-style-type: none"> <li>▪ Rear left seat massage switch circuit short circuit to ground</li> <li>▪ Rear integrated control panel failure</li> </ul>                               | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the rear left seat massage switch circuit for short circuit to ground</li> <li>▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear integrated control panel</li> </ul>                               |
| B13FB-15 | <p>Left Rear Massage Seat Switch Input</p> <p>- Circuit short to battery or open</p> | <p><b>NOTE:</b></p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p>Circuit reference - LHR MESSAGE SWITCH</p> </div> <ul style="list-style-type: none"> <li>▪ Rear left seat massage switch circuit short circuit to power, open circuit, high resistance</li> <li>▪ Rear integrated control panel failure</li> </ul> | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the rear left seat massage switch circuit for short circuit to power, open circuit, high resistance</li> <li>▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear integrated control panel</li> </ul> |
| B13FC-11 | <p>Right Rear Massage Seat Switch Input</p> <p>- Circuit short to ground</p>         | <p><b>NOTE:</b></p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p>Circuit reference - RHR MESSAGE SWITCH</p> </div>                                                                                                                                                                                                  | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the rear right seat massage switch circuit for short circuit to ground</li> <li>▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If</li> </ul>                                                                                              |

|          |                                                                         |                                                                                                                                                                                                                                                                                                                                                  |                                                                                                                                                                                                                                                                                                                                                                         |
|----------|-------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|          |                                                                         | <ul style="list-style-type: none"> <li>▪ Rear right seat massage switch circuit short circuit to ground</li> <li>▪ Rear integrated control panel failure</li> </ul>                                                                                                                                                                              | the fault persists, install a new rear integrated control panel                                                                                                                                                                                                                                                                                                         |
| B13FC-15 | Right Rear Massage Seat Switch Input - Circuit short to battery or open | <p><b>NOTE:</b></p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p>Circuit reference - RHR MESSAGE SWITCH</p> </div> <ul style="list-style-type: none"> <li>▪ Rear right seat massage switch circuit short circuit to power, open circuit, high resistance</li> <li>▪ Rear integrated control panel failure</li> </ul> | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the rear right seat massage switch circuit for short circuit to power, open circuit, high resistance</li> <li>▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear integrated control panel</li> </ul> |
| B1A59-11 | Sensor 5 Volt Supply - Circuit short to ground                          | <ul style="list-style-type: none"> <li>▪ Rear sunload sensor power supply circuit short circuit to ground</li> </ul>                                                                                                                                                                                                                             | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the rear sunload sensor power supply circuit for short circuit to ground</li> </ul>                                                                                                                                                                                         |
| B1A59-15 | Sensor 5 Volt Supply - Circuit short to battery or open                 | <ul style="list-style-type: none"> <li>▪ Rear sunload sensor power supply circuit short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                                                               | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the rear sunload sensor power supply circuit for short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                           |
| B1A63-11 | Right Solar Sensor - Circuit short to ground                            | <ul style="list-style-type: none"> <li>▪ Rear sunload sensor right signal circuit short circuit to ground</li> </ul>                                                                                                                                                                                                                             | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the rear sunload sensor right signal circuit for short circuit to ground</li> </ul>                                                                                                                                                                                         |
| B1A63-15 | Right Solar Sensor - Circuit short to battery or open                   | <ul style="list-style-type: none"> <li>▪ Rear sunload sensor right signal circuit short circuit to power, open circuit,</li> </ul>                                                                                                                                                                                                               | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the rear sunload sensor right signal circuit for short circuit to</li> </ul>                                                                                                                                                                                                |

|          |                                                                       |                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                              |
|----------|-----------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|          |                                                                       | high resistance                                                                                                                                                                                                                                                                                                                 | power, open circuit, high resistance                                                                                                                                                                                                                                                                                                                                         |
| B1A64-11 | Left Solar Sensor - Circuit short to ground                           | <ul style="list-style-type: none"> <li>Rear sunload sensor left signal circuit short circuit to ground</li> </ul>                                                                                                                                                                                                               | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the rear sunload sensor left signal circuit for short circuit to ground</li> </ul>                                                                                                                                                                                                 |
| B1A64-15 | Left Solar Sensor - Circuit short to battery or open                  | <ul style="list-style-type: none"> <li>Rear sunload sensor left signal circuit short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                                                 | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the rear sunload sensor left signal circuit for short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                                   |
| B1B81-11 | Rear Evaporator Temperature Sensor - Circuit short to ground          | <p><b>NOTE:</b></p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p>Circuit reference - REAR EVAP TEMP SEN</p> </div> <ul style="list-style-type: none"> <li>Auxiliary evaporator temperature sensor circuit short circuit to ground</li> <li>Rear integrated control panel failure</li> </ul>         | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the auxiliary evaporator temperature sensor circuit for short circuit to ground</li> <li>Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear integrated control panel</li> </ul>                               |
| B1B81-15 | Rear Evaporator Temperature Sensor - Circuit short to battery or open | <p><b>NOTE:</b></p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p>Circuit reference - REAR EVAP TEMP SEN</p> </div> <ul style="list-style-type: none"> <li>Auxiliary evaporator temperature sensor circuit short circuit to power, open circuit, high resistance</li> <li>Rear integrated</li> </ul> | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the auxiliary evaporator temperature sensor circuit for short circuit to power, open circuit, high resistance</li> <li>Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear integrated control panel</li> </ul> |



|          |                                                                              |                                                                                                                                                                                                                      |                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|----------|------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|          |                                                                              | control panel failure                                                                                                                                                                                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
| U0055-88 | Vehicle Communication Bus D - Bus off                                        | <ul style="list-style-type: none"> <li>Medium speed CAN bus (comfort) circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> </ul>                                              | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the medium speed CAN bus (comfort) circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                   |
| U0300-00 | Internal Control Module Software Incompatibility - No sub type information   | <ul style="list-style-type: none"> <li>Central junction box is not configured correctly</li> <li>Rear integrated control panel is not configured correctly</li> <li>Rear integrated control panel failure</li> </ul> | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, re-configure the central junction box with the latest level software</li> <li>Using the manufacturer approved diagnostic system, re-configure the rear integrated control panel with the latest level software</li> <li>Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear integrated control panel</li> </ul> |
| U201A-57 | Control Module Main Calibration Data - Invalid/incomplete software component | <ul style="list-style-type: none"> <li>Rear integrated control panel software invalid/corrupt</li> <li>Rear integrated control panel failure</li> </ul>                                                              | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, re-configure the rear integrated control panel with the latest level software</li> <li>Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear integrated control panel</li> </ul>                                                                                |
| U2100-00 | Initial Configuration Not Complete - No sub type                             | <ul style="list-style-type: none"> <li>Car configuration file mismatch with vehicle specification</li> </ul>                                                                                                         | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, check and up-date the car configuration file as</li> </ul>                                                                                                                                                                                                                                                                                                                          |

information

- Incorrect rear integrated control panel installed

necessary

- If the fault persists, install a new rear integrated control panel