

2016.0 RANGE ROVER (LG), 100-00

GENERAL INFORMATION

DESCRIPTION AND OPERATION

REAR SEAT ENTERTAINMENT CONTROL MODULE (RSECM)

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable.
Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.

NOTES:

- If a control module or a component is suspect and the vehicle remains under manufacturer warranty, refer to the Warranty Policy and Procedures manual, or determine if any prior approval programme is in operation, prior to the installation of a new module/component.
- Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system).
- When performing voltage or resistance tests, always use a digital multimeter accurate to three decimal places, and with an up-to-date calibration certificate. When testing resistance always take the resistance of the digital multimeter leads into account.
- Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.
- Inspect connectors for signs of water ingress, and pins for damage and/or corrosion.
- If DTCs are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always check for loose connections and corroded terminals.
- Check DDW for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and carry out the recommendations as required.

The table below lists all Diagnostic Trouble Codes (DTCs) that could be logged in the Rear Seat Entertainment Control Module (RSECM). For additional diagnosis and testing information, refer to the relevant Diagnosis and Testing section in the workshop manual.

For additional information, refer to: [Information and Entertainment System](#)

(415-00 Information and Entertainment System - General Information, Diagnosis and Testing).

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B100F-29	Video Input "B" - Signal invalid	- Auxiliary video in circuit short circuit to ground, short circuit to power, open circuit, high resistance - Auxiliary device internal failure - Rear seat entertainment control module internal failure	NOTE: This DTC can only set when routine - Test Composite Video Blanking and Synchronisation Input (0x6015) - is run and fails - Refer to the electrical circuit diagrams and check the auxiliary video in circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Connect a known functional video signal source to the audio video input/output panel and select this source using the rear seat entertainment remote control. Check the left/right rear seat entertainment screen for a valid signal - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear seat entertainment control module
B1010-29	Video Input "C" - Signal invalid	- Touch screen video in circuit short circuit to ground, short circuit to power, open circuit, high resistance - Touch screen internal failure - Rear seat entertainment control module internal failure	NOTE: This DTC can only set when routine - Test Composite Video Blanking and Synchronisation Input (0x6015) - is run and fails Refer to the electrical circuit diagrams and check the touch screen video in circuit for short

			circuit to ground, short circuit to power, open circuit, high resistance - Using the manufacturer approved diagnostic system, check the touch screen for related DTCs and refer to the relevant DTC index - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear seat entertainment control module
B1252-57	USB Port - Invalid/incomplete software component	A USB device is detected but the content format of the USB device is not supported	NOTE: This DTC can only set when routine - USB Interface Self Test (0x602E) - is run and fails Using the manufacturer approved diagnostic system, clear the DTCs, remove and reconnect the USB device, and retest. If fault persists, replace the content of the USB device with content that is correctly formatted
B1252-93	USB Port - No operation	- USB device circuit short circuit to ground, short circuit to power, open circuit, high resistance - USB device internal failure - Rear seat entertainment control module internal failure	NOTE: This DTC can only set when routine - USB Interface Self Test (0x602E) - is run and fails - Refer to the electrical circuit diagrams and check the USB circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Connect a known functional USB device to the audio video

			input/output panel and select this source using the rear seat entertainment remote control. Check the left/right rear seat entertainment screen for a valid signal Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear seat entertainment control module
B125E-4A	Left Rear Display - Incorrect component installed	- Rear seat entertainment left screen power or ground circuit open circuit, high resistance - Rear seat entertainment CAN bus circuit short circuit to ground, short circuit to power, open circuit, high resistance - Incorrect rear seat entertainment left screen installed	NOTE: This DTC is set when the rear seat entertainment control module has not read a valid serial number from the left rear seat entertainment screen within 25 seconds - Refer to the electrical circuit diagrams and check the rear seat entertainment left screen power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the rear seat entertainment CAN bus circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Check that the rear seat entertainment left screen has not been substituted
B125E-96	Left Rear Display - Component internal failure	Rear seat entertainment left screen internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear seat entertainment left screen
B125E-98	Left Rear Display - Component or	Rear seat entertainment	Allow the system to cool. Using the manufacturer approved

	system over temperature	left screen over temperature condition	diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear seat entertainment left screen
B125F-4A	Right Rear Display - Incorrect component installed	▪ Rear seat entertainment right screen power or ground circuit open circuit, high resistance ▪ Rear seat entertainment CAN bus circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Incorrect rear seat entertainment right screen installed	NOTE: This DTC is set when the rear seat entertainment control module has not read a valid serial number from the right rear seat entertainment screen within 25 seconds ▪ Refer to the electrical circuit diagrams and check the rear seat entertainment right screen power and ground circuits for open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the rear seat entertainment CAN bus circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Check that the rear seat entertainment right screen has not been substituted
B125F-96	Right Rear Display - Component internal failure	▪ Rear seat entertainment right screen internal failure	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear seat entertainment right screen
B125F-98	Right Rear Display - Component or system over temperature	▪ Rear seat entertainment right screen over temperature condition	▪ Allow the system to cool. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear seat entertainment right screen
B1285-88	Video Input "D" - Bus off	▪ TV control module low-voltage	▪ Refer to the electrical circuit diagrams and check the TV control module low-voltage

		differential signaling circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Television system fault ▪ Rear seat entertainment control module internal failure	differential signaling circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, check the TV control module for related DTCs and refer to the relevant DTC index ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear seat entertainment control module
B12A0-11	Auxiliary Input 2 - Circuit short to ground	▪ Right auxiliary audio in circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the right auxiliary audio in circuit for short circuit to ground
B12A0-12	Auxiliary Input 2 - Circuit short to battery	▪ Right auxiliary audio in circuit short circuit to power	▪ Refer to the electrical circuit diagrams and check the right auxiliary audio in circuit for short circuit to power
B12ED-88	Video Input "F" - Bus off	▪ Rear seat entertainment left screen low-voltage differential signaling circuit short circuit to ground, short circuit to power, open circuit, high resistance	▪ Refer to the electrical circuit diagrams and check the rear seat entertainment left screen low-voltage differential signaling circuit for short circuit to ground, short circuit to power, open circuit, high resistance
B12F8-88	Video Input "G" - Bus off	▪ Rear seat entertainment right screen low-voltage differential signaling circuit short circuit to ground, short circuit to power, open circuit, high resistance	▪ Refer to the electrical circuit diagrams and check the rear seat entertainment right screen low-voltage differential signaling circuit for short circuit to ground, short circuit to power, open circuit, high resistance

B1D78-11	Auxiliary Input - Circuit short to ground	Left auxiliary audio in circuit short circuit to ground	Refer to the electrical circuit diagrams and check the left auxiliary audio in circuit for short circuit to ground
B1D78-12	Auxiliary Input - Circuit short to battery	Left auxiliary audio in circuit short circuit to power	Refer to the electrical circuit diagrams and check the left auxiliary audio in circuit for short circuit to power
U0196-31	Lost Communication With Entertainment Control Module - Rear "A" - No signal	- Rear seat entertainment left screen power or ground circuit open circuit, high resistance - Rear seat entertainment CAN bus circuit short circuit to ground, short circuit to power, open circuit, high resistance	- Refer to the electrical circuit diagrams and check the rear seat entertainment left screen power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the rear seat entertainment CAN bus circuit for short circuit to ground, short circuit to power, open circuit, high resistance
U0249-31	Lost Communication With Entertainment Control Module - Rear "B" - No signal	- Rear seat entertainment right screen power or ground circuit open circuit, high resistance - Rear seat entertainment CAN bus circuit short circuit to ground, short circuit to power, open circuit, high resistance	- Refer to the electrical circuit diagrams and check the rear seat entertainment right screen power and ground circuits for open circuit, high resistance - Refer to the electrical circuit diagrams and check the rear seat entertainment CAN bus circuit for short circuit to ground, short circuit to power, open circuit, high resistance
U1009-00	Invalid Data Received From Right Rear Display Module - No sub type information	Rear seat entertainment CAN bus circuit short circuit to ground, short	

		circuit to power, open circuit, high resistance ▪ Rear seat entertainment right screen low-voltage differential signaling circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Rear seat entertainment right screen power or ground circuit open circuit, high resistance ▪ Rear seat entertainment right screen internal failure	NOTE: This DTC indicates that unexpected data was received from the rear seat entertainment right screen. This could be due to a reset, harness fault, incorrect programming or random corruption ▪ Refer to the electrical circuit diagrams and check the rear seat entertainment CAN bus circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the rear seat entertainment right screen low-voltage differential signaling circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the rear seat entertainment right screen power and ground circuits for open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear seat entertainment right screen
U100A-00	Invalid Data Received From Left Rear Display Module - No sub type information	▪ Rear seat entertainment CAN bus circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Rear seat entertainment left screen low-voltage differential	NOTE: This DTC indicates that unexpected data was received from the rear seat entertainment left screen. This could be due to a reset, harness fault, incorrect programming or random corruption

		signaling circuit short circuit to ground, short circuit to power, open circuit, high resistance ▪ Rear seat entertainment left screen power or ground circuit open circuit, high resistance ▪ Rear seat entertainment left screen internal failure	▪ Refer to the electrical circuit diagrams and check the rear seat entertainment CAN bus circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the rear seat entertainment left screen low-voltage differential signaling circuit for short circuit to ground, short circuit to power, open circuit, high resistance ▪ Refer to the electrical circuit diagrams and check the rear seat entertainment left screen power and ground circuits for open circuit, high resistance ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear seat entertainment left screen
U200D-11	Control Module Output Power A - Circuit short to ground	▪ Rear seat entertainment left/right screen circuit short circuit to ground	▪ Refer to the electrical circuit diagrams and check the rear seat entertainment left/right screen circuit for short circuit to ground
U200D-12	Control Module Output Power A - Circuit short to battery	▪ Rear seat entertainment left/right screen circuit short circuit to power	▪ Refer to the electrical circuit diagrams and check the rear seat entertainment left/right screen circuit for short circuit to power
U200D-19	Control Module Output Power A - Circuit current above threshold	▪ Rear seat entertainment left/right screen circuit short circuit to ground, short circuit to power ▪ Rear seat entertainment control module internal failure	NOTE: This DTC is logged when the combined total current consumption of the rear screens exceeds 1.35 amps ▪ Refer to the electrical circuit diagrams and check the rear seat entertainment left/right screen

			circuit for short circuit to ground, short circuit to power Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear seat entertainment control module
U2014-56	Control Module Hardware - Invalid/incomplete configuration	Rear seat entertainment control module is not configured correctly	Using the manufacturer approved diagnostic system, re-configure the rear seat entertainment control module with the latest level software
U2100-00	Initial Configuration Not Complete - No sub type information	Rear seat entertainment control module is not configured correctly	Using the manufacturer approved diagnostic system, re-configure the rear seat entertainment control module with the latest level software
U2101-00	Control Module Configuration Incompatible - No sub type information	- Car configuration file mismatch with vehicle specification - Incorrect rear seat entertainment control module installed	- Using the manufacturer approved diagnostic system, check and up-date the car configuration file as necessary - Install a new rear seat entertainment control module as necessary
U3000-19	Control Module - Circuit current above threshold	Rear seat entertainment control module internal failure	NOTE: If this DTC is set, install a new rear seat entertainment control module even if a circuit fault has been found and rectified Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear seat entertainment control module

U3000-55	Control Module - Not configured	▪ Rear seat entertainment control module is not configured correctly	▪ Using the manufacturer approved diagnostic system, re-configure the rear seat entertainment control module with the latest level software
U3000-98	Control Module - Component or system over temperature	▪ Rear seat entertainment control module over temperature	▪ Allow the vehicle to cool. Check the rear seat entertainment control module ventilation ducts for obstructions. Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear seat entertainment control module
U3003-62	Battery Voltage - Signal compare failure	▪ Mismatch between the voltage at the rear seat entertainment control module and the voltage value broadcast on the CAN bus	▪ Refer to the electrical circuit diagrams and check the rear seat entertainment control module power and ground circuits for open circuit, high resistance