

2016.0 RANGE ROVER (LG), 100-00

GENERAL INFORMATION

DESCRIPTION AND OPERATION

RESTRAINTS CONTROL MODULE (RCM)

WARNINGS:

- TO AVOID ACCIDENTAL DEPLOYMENT AND POSSIBLE PERSONAL INJURY, THE BACKUP POWER SUPPLY MUST BE DEPLETED BEFORE REPAIRING OR REPLACING ANY AIRBAG SUPPLEMENTAL RESTRAINT SYSTEM (SRS) COMPONENTS. TO DEplete THE BACKUP POWER SUPPLY ENERGY, DISCONNECT THE BATTERY GROUND CABLE AND WAIT ONE MINUTE. FAILURE TO FOLLOW THIS INSTRUCTION MAY RESULT IN PERSONAL INJURY
- Do not use a multimeter to probe the restraints control module. It is possible for the power from the meter battery to trigger the activation of the airbags. Failure to follow this instruction may result in personal injury

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.

NOTES:

- If a control module or a component is suspect and the vehicle remains under manufacturer warranty, refer to the Warranty Policy and Procedures manual, or determine if any prior approval programme is in operation, prior to the installation of a new module/component.
- Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system).
- When performing voltage or resistance tests, always use a digital multimeter accurate to three decimal places, and with an up-to-date calibration certificate. When testing resistance always take the resistance of the digital multimeter leads into account.
- Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.
- Inspect connectors for signs of water ingress, and pins for damage and/or corrosion.
- If DTCs are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always check for loose connections and corroded terminals.
- Check DDW for open campaigns. Refer to the corresponding

bulletins and SSMs which may be valid for the specific customer complaint and carry out the recommendations as required.

- It is advisable not to use a cellular phone or to have a cellular phone in close proximity when working on the restraints control module or associated systems
- Given the legal implications of a restraints system failure, harness repairs to airbag module circuits are not acceptable. Where the text refers to "REPAIR the circuit", this will normally mean the replacement of a harness

The table below lists all Diagnostic Trouble Codes (DTCs) that could be logged in the Restraints Control Module (RCM). For additional diagnosis and testing information, refer to the relevant Diagnosis and Testing section in the workshop manual.

For additional information, refer to: [Airbag Supplemental Restraint System](#) (501-20B Supplemental Restraint System, Diagnosis and Testing).

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
B0001-11	Driver Frontal Stage 1 Deployment Control - Circuit short to ground	NOTE: Airbag warning can take up to 15 seconds to reset once the ignition is switched on ▪ Driver airbag (stage 1) connector lever not engaged ▪ Clockspring harness connector fault ▪ Airbag connector(s) damaged ▪ Driver frontal airbag (stage 1) circuit short circuit to ground	

- Clockspring fault
- Harness damage
- Airbag squib component fault

NOTE:

The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.

- Visually inspect the driver airbag connector(s), the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest
- Check the lower clockspring harness 8 way connector for security, if loose reconnect. Clear the DTCs and retest
- If problem still persists, disconnect and reconnect all connectors. Also test connectors (see above note). Clear the DTCs and retest
- Refer to the electrical circuit diagrams and check the driver frontal airbag (stage 1) circuit for short circuit to ground
- Check for intermittent shorts to ground within the clockspring by

			rotating the steering column during the checks ▪ If a wiring fault is detected, replace wiring as required ▪ If no wiring harness fault exists, using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new deployable device
B0001-12	Driver Frontal Stage 1 Deployment Control - Circuit short to battery	NOTE: Airbag warning can take up to 15 seconds to reset once the ignition is switched on ▪ Driver airbag (stage 1) connector lever not engaged ▪ Clockspring harness connector fault ▪ Airbag connector(s) damaged ▪ Driver frontal airbag (stage 1) circuit short circuit to power ▪ Clockspring fault ▪ Harness damage	NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. ▪ Visually inspect the driver airbag connector(s), the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest ▪ Check the lower clockspring harness 8 way connector for security, if loose reconnect. Clear the DTCs and retest

			▪ If problem still persists, disconnect and reconnect all connectors. Also test connectors (see above note). Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the driver frontal airbag (stage 1) circuit for short circuit to power ▪ Check for intermittent shorts to power within the clockspring by rotating the steering column during the checks ▪ If a wiring fault is detected, replace wiring as required
B0001-13	Driver Frontal Stage 1 Deployment Control - Circuit open	NOTE: Airbag warning can take up to 15 seconds to reset once the ignition is switched on ▪ Driver airbag (stage 1) connector lever not engaged ▪ Clockspring harness connector fault ▪ Airbag connector(s) damaged ▪ Driver frontal airbag (stage 1) circuit open circuit, high resistance ▪ Clockspring fault ▪ Harness damage ▪ Airbag squib component fault	WARNING: Do not measure the resistance of a deployable device using any other method than that described below

NOTES:

- Driver airbag (stage 1) resistance specification should be greater than 1.70 ohms and less than 3.68 ohms at -40°C to 85°C.

- The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.

- Visually inspect the driver airbag connector(s), the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest
- Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 0 Resistance (0x5B03). If the resistance is too high, check the lower clockspring harness

			8 way connector for security, if loose disconnect and reconnect the connector. Clear the DTCs and retest ▪ If problem still persists, disconnect and reconnect all connectors. Also test connectors (see above note). Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the driver frontal airbag (stage 1) circuit for open circuit, high resistance ▪ Check for intermittent open circuit, high resistance faults within the clockspring by rotating the steering column during the checks ▪ If a wiring fault is detected, replace wiring as required ▪ If no wiring harness fault exists, using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new deployable device
B0001-1A	Driver Frontal Stage 1 Deployment Control - Circuit resistance below threshold	NOTE: Airbag warning can take up to 15 seconds to reset once the ignition is switched on ▪ Driver airbag (stage 1) connector lever not engaged ▪ Airbag connector(s)	WARNING: Do not measure the resistance of a deployable device using any other method than that described below

damaged

- Clockspring harness connector fault
- Clockspring fault
- Driver airbag (stage 1) circuit short circuit between power and ground
- Harness damage
- Airbag squib component fault

NOTES:

- A shorting bar inside the connector (deployable device side) intentionally creates a short circuit until the wiring harness connector is installed AND the connector plunger is engaged
- Driver airbag (stage 1) resistance specification should be greater than 1.70 ohms and less than 3.68 ohms at -40°C to 85°C.
- The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.

- Visually inspect the driver

				airbag connector(s), the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest ▪ Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 0 Resistance (0x5B03). If the resistance is too low, disconnect and reconnect the driver airbag (stage 1) connector, ensuring that the connector plunger is correctly engaged. Clear the DTCs and retest ▪ Check the lower clockspring harness 8 way connector for security, if loose reconnect. Clear the DTCs and retest ▪ Check for intermittent short circuits within the clockspring by rotating the steering column during the checks ▪ Refer to the electrical circuit diagrams and check the driver airbag (stage1) circuit for short circuit between power and ground. Clear the DTCs and retest. If the fault persists, install a new wiring harness as necessary ▪ If a wiring fault is detected, replace wiring as required ▪ If no wiring harness fault exists, using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new deployable device	
--	--	--	--	---	--

B0001-2B

Driver Frontal Stage 1
Deployment Control -
Signal cross coupled

- Driver airbag (stage 1) connector lever not engaged
- Clockspring harness connector fault
- Airbag connector(s) damaged
- Driver frontal airbag (stage 1) circuits short circuit
- Clockspring fault
- Harness damage

NOTE:

The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.

- Visually inspect the driver airbag connector(s), the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest
- Check the lower clockspring harness 8 way connector for security, if loose reconnect. Clear the DTCs and retest
- If problem still persists, disconnect and reconnect all connectors. Also test connectors (see above note). Clear the DTCs and retest
- Refer to the electrical circuit diagrams and check the driver frontal airbag (stage 1) circuit for short circuits to other firing circuits
- Check for intermittent short circuits within the

			clockspring by rotating the steering column during the checks ▪ If a wiring fault is detected, replace wiring as required
B0001-56	Driver Frontal Stage 1 Deployment Control - Invalid/incomplete configuration	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs ▪ Restraints control module is not configured correctly ▪ Car configuration file invalid/incomplete configuration	▪ Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software ▪ Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTC and retest
B0002-11	Driver Frontal Stage 2 Deployment Control - Circuit short to ground	NOTE: Airbag warning can take up to 15 seconds to reset once the ignition is switched on ▪ Driver airbag (stage 2) connector lever not engaged ▪ Clockspring harness connector fault ▪ Airbag connector(s) damaged ▪ Driver frontal airbag (stage 2) circuit short	

circuit to ground

- Clockspring fault
- Harness damage
- Airbag squib component fault

NOTE:

The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.

- Visually inspect the driver airbag connector(s), the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest
- Check the lower clockspring harness 8 way connector for security, if loose reconnect. Clear the DTCs and retest
- If problem still persists, disconnect and reconnect all connectors. Also test connectors (see above note). Clear the DTCs and retest
- Refer to the electrical circuit diagrams and check the driver frontal airbag (stage 2) circuit for short circuit to ground
- Check for intermittent shorts to ground within the clockspring by

			rotating the steering column during the checks ▪ If a wiring fault is detected, replace wiring as required ▪ If no wiring harness fault exists, using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new deployable device
B0002-12	Driver Frontal Stage 2 Deployment Control - Circuit short to battery	NOTE: Airbag warning can take up to 15 seconds to reset once the ignition is switched on ▪ Driver airbag (stage 2) connector lever not engaged ▪ Clockspring harness connector fault ▪ Airbag connector(s) damaged ▪ Driver frontal airbag (stage 2) circuit short circuit to power ▪ Clockspring fault ▪ Harness damage	NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. ▪ Visually inspect the driver airbag connector(s), the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest ▪ Check the lower clockspring harness 8 way connector for security, if loose reconnect. Clear the DTCs and retest

			▪ If problem still persists, disconnect and reconnect all connectors. Also test connectors (see above note). Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the driver frontal airbag (stage 2) circuit for short circuit to power ▪ Check for intermittent shorts to power within the clockspring by rotating the steering column during the checks ▪ If a wiring fault is detected, replace wiring as required
B0002-13	Driver Frontal Stage 2 Deployment Control - Circuit open	NOTE: Airbag warning can take up to 15 seconds to reset once the ignition is switched on ▪ Driver airbag (stage 2) connector lever not engaged ▪ Clockspring harness connector fault ▪ Airbag connector(s) damaged ▪ Driver frontal airbag (stage 2) circuit open circuit, high resistance ▪ Clockspring fault ▪ Harness damage ▪ Airbag squib component fault	WARNING: Do not measure the resistance of a deployable device using any other method than that described below

NOTES:

- Driver airbag (stage 2) resistance specification should be greater than 1.70 ohms and less than 3.68 ohms at -40°C to 85°C.

- The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.

- Visually inspect the driver airbag connector(s), the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest
- Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 1 Resistance (0x5B04). If the resistance is too high, check the lower clockspring harness

			8 way connector for security, if loose disconnect and reconnect the connector. Clear the DTCs and retest ▪ If problem still persists, disconnect and reconnect all connectors. Also test connectors (see above note). Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the driver frontal airbag (stage 2) circuit for open circuit, high resistance ▪ Check for intermittent open circuit, high resistance faults within the clockspring by rotating the steering column during the checks ▪ If a wiring fault is detected, replace wiring as required ▪ If no wiring harness fault exists, using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new deployable device
B0002-1A	Driver Frontal Stage 2 Deployment Control - Circuit resistance below threshold	NOTE: Airbag warning can take up to 15 seconds to reset once the ignition is switched on ▪ Driver airbag (stage 2) connector lever not engaged ▪ Airbag connector(s)	WARNING: Do not measure the resistance of a deployable device using any other method than that described below

damaged

- Clockspring harness connector fault
- Clockspring fault
- Driver airbag (stage 2) circuit short circuit between power and ground
- Harness damage
- Airbag squib component fault

NOTES:

- A shorting bar inside the connector (deployable device side) intentionally creates a short circuit until the wiring harness connector is installed AND the connector plunger is engaged
- Driver airbag (stage 2) resistance specification should be greater than 1.70 ohms and less than 3.68 ohms at -40°C to 85°C.
- The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.

- Using the manufacturer

			approved diagnostic system, check datalogger signal - Deployment Control 1 Resistance (0x5B04). If the resistance is too low, disconnect and reconnect the driver airbag (stage 2) connector, ensuring that the connector plunger is correctly engaged. Clear the DTCs and retest ▪ Check the lower clockspring harness 8 way connector for security, if loose reconnect. Clear the DTCs and retest ▪ Check for intermittent short circuits within the clockspring by rotating the steering column during the checks ▪ Refer to the electrical circuit diagrams and check the driver airbag (stage 2) circuit for short circuit between power and ground. Clear the DTCs and retest. If the fault persists, install a new wiring harness as necessary ▪ If a wiring fault is detected, replace wiring as required ▪ If no wiring harness fault exists, using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new deployable device
B0002-2B	Driver Frontal Stage 2 Deployment Control - Signal cross coupled		

			NOTE: Airbag warning can take up to 15 seconds to reset once the ignition is switched on ▪ Driver airbag (stage 2) connector lever not engaged ▪ Clockspring harness connector fault ▪ Airbag connector(s) damaged ▪ Driver frontal airbag (stage 2) circuits short circuit ▪ Clockspring fault ▪ Harness damage	NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. ▪ Visually inspect the driver airbag connector(s), the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest ▪ Check the lower clockspring harness 8 way connector for security, if loose reconnect. Clear the DTCs and retest ▪ If problem still persists, disconnect and reconnect all connectors. Also test connectors (see above note). Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the driver frontal airbag (stage 2) circuit for short circuits to other firing circuits ▪ Check for intermittent short circuits within the	
--	--	--	---	--	--

			clockspring by rotating the steering column during the checks ▪ If a wiring fault is detected, replace wiring as required
B0002-56	Driver Frontal Stage 2 Deployment Control - Invalid/incomplete configuration	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs ▪ Restraints control module is not configured correctly ▪ Car configuration file invalid/incomplete configuration	▪ Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software ▪ Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTC and retest
B0010-11	Passenger Frontal Stage 1 Deployment Control - Circuit short to ground	▪ Passenger airbag (stage 1) connector lever not engaged ▪ Passenger airbag (stage 1) circuit short to ground	

			NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. ▪ Visually inspect the passenger airbag connector(s), the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the passenger airbag (stage 1) circuit for short circuit to ground
B0010-12	Passenger Frontal Stage 1 Deployment Control - Circuit short to battery	▪ Passenger airbag (stage 1) connector lever not engaged ▪ Passenger airbag (stage 1) circuit short to power	

			NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. ▪ Visually inspect the passenger airbag connector(s), the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the passenger airbag (stage 1) circuit for short circuit to power
B0010-13	Passenger Frontal Stage 1 Deployment Control - Open circuit	▪ Passenger airbag (stage 1) circuit open circuit, high resistance ▪ Passenger airbag (stage 1) connector damaged ▪ Passenger airbag internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.

- Passenger airbag (stage 1) resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 3 Resistance (0x5B06). Refer to the electrical circuit diagrams and check the passenger airbag (stage 1) circuit for open circuit, high resistance

- Disconnect the passenger airbag (stage 1) connector and apply light pressure to the connector

			plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new passenger airbag
B0010-1A	Passenger Frontal Stage 1 Deployment Control - Circuit resistance below threshold	▪ Passenger airbag (stage 1) connector plunger not engaged ▪ Passenger airbag (stage 1) connector damaged ▪ Passenger airbag (stage 1) circuit short circuit between power and ground ▪ Passenger airbag internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- A shorting bar inside the connector (deployable device side) intentionally creates a short circuit until the wiring harness connector is installed AND the plunger is engaged.
- Passenger airbag (stage 1) resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer approved diagnostic

			system, check datalogger signal - Deployment Control 3 Resistance (0x5B06). If the resistance is too low, disconnect and reconnect the passenger airbag (stage 1) connector, ensuring that the connector plunger is correctly engaged. Clear the DTCs and retest ▪ Disconnect the passenger airbag (stage 1) connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Refer to the electrical circuit diagrams and check the passenger airbag (stage 1) circuit for short circuit between power and ground ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new passenger airbag
B0010-2B	Passenger Frontal Stage 1 Deployment Control - Signal cross coupled	▪ Passenger airbag (stage 1) circuit short circuit to another restraints circuit	

			NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. Refer to the electrical circuit diagrams and check the passenger airbag (stage 1) circuit for short circuit to another restraints circuit
B0010-56	Passenger Frontal Stage 1 Deployment Control - Invalid/incomplete configuration	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs - Restraints control module is not configured correctly - Car configuration file invalid/incomplete	- Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software - Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTC and retest

		configuration	
B0011-11	Passenger Frontal Stage 2 Deployment Control - Circuit short to ground	- Passenger airbag (stage 2) connector lever not engaged - Passenger airbag (stage 2) circuit short to ground	NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. - Visually inspect the passenger airbag connector(s), the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the passenger airbag (stage 2) circuit for short circuit to ground
B0011-12	Passenger Frontal Stage 2 Deployment Control - Circuit short to battery	- Passenger airbag (stage 2) connector lever not engaged - Passenger airbag (stage 2) circuit short to power	

			NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. ▪ Visually inspect the passenger airbag connector(s), the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the passenger airbag (stage 2) circuit for short circuit to power
B0011-13	Passenger Frontal Stage 2 Deployment Control - Circuit open	▪ Passenger airbag (stage 2) circuit open circuit, high resistance ▪ Passenger airbag (stage 2) connector damaged ▪ Passenger airbag internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.

- Passenger airbag (stage 2) resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 4 Resistance (0x5B07). Refer to the electrical circuit diagrams and check the passenger airbag (stage 2) circuit for open circuit, high resistance

- Disconnect the passenger airbag (stage 2) connector and apply light pressure to the connector

			plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new passenger airbag
B0011-1A	Passenger Frontal Stage 2 Deployment Control - Circuit resistance below threshold	▪ Passenger airbag (stage 2) connector plunger not engaged ▪ Passenger airbag (stage 2) connector damaged ▪ Passenger airbag (stage 2) circuit short circuit between power and ground ▪ Passenger airbag internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- A shorting bar inside the connector (deployable device side) intentionally creates a short circuit until the wiring harness connector is installed AND the plunger is engaged.
- Passenger airbag (stage 2) resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer approved diagnostic

			system, check datalogger signal - Deployment Control 4 Resistance (0x5B07). If the resistance is too low, disconnect and reconnect the passenger airbag (stage 2) connector, ensuring that the connector plunger is correctly engaged. Clear the DTCs and retest ▪ Disconnect the passenger airbag (stage 2) connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Refer to the electrical circuit diagrams and check the passenger airbag (stage 2) circuit for short circuit between power and ground ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new passenger airbag
B0011-2B	Passenger Frontal Stage 2 Deployment Control - Signal cross coupled	▪ Passenger airbag (stage 2) circuit short circuit to another restraints circuit	

			NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. Refer to the electrical circuit diagrams and check the passenger airbag (stage 2) circuit for short circuit to another restraints circuit
B0011-56	Passenger Frontal Stage 2 Deployment Control - Invalid/incomplete configuration	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs - Restraints control module is not configured correctly - Car configuration file invalid/incomplete	- Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software - Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTC and retest

		configuration	
B0020-11	Left Side Airbag Deployment Control - Circuit short to ground	- Left side airbag connector lever not engaged - Left side airbag (seat) circuit short circuit to ground	NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. - Visually inspect the left side airbag connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the left side airbag (seat) circuit for short circuit to ground
B0020-12	Left Side Airbag Deployment Control - Circuit short to battery	- Left side airbag connector lever not engaged - Left side airbag (seat) circuit short circuit to power	

			NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. ▪ Visually inspect the left side airbag connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the left side airbag (seat) circuit for short circuit to power
B0020-13	Left Side Airbag Deployment Control - Circuit open	▪ Left side airbag (seat) circuit open circuit, high resistance ▪ Left side airbag (seat) connector damaged ▪ Left side airbag (seat) internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
 - Left side airbag (seat) resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.
-
- Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 5 Resistance (0x5B08). Refer to the electrical circuit diagrams and check the left side airbag (seat) circuit for open circuit, high resistance
 - Disconnect the left side airbag (seat) connector and apply light pressure to the connector plunger. If the plunger moves to

			the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new left side airbag (seat)
B0020-1A	Left Side Airbag Deployment Control - Circuit resistance below threshold	▪ Left side airbag (seat) connector plunger not engaged ▪ Left side airbag (seat) connector damaged ▪ Left side airbag (seat) circuit short	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

circuit between
power and ground

- Left side airbag
(seat) internal failure

NOTES:

- The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- A shorting bar inside the connector (deployable device side) intentionally creates a short circuit until the wiring harness connector is installed AND the plunger is engaged.
- Left side airbag (seat) resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer approved diagnostic system, check datalogger

signal - Deployment Control 5 Resistance (0x5B08). If the resistance is too low, disconnect and reconnect the left side airbag (seat) connector, ensuring that the connector plunger is correctly engaged. Clear the DTCs and retest

- Disconnect the left side airbag (seat) connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary
- Refer to the electrical circuit diagrams and check the left side airbag (seat) circuit for short circuit between power and ground
- Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new left side airbag (seat)

B0020-2B	Left Side Airbag Deployment Control - Signal cross coupled	Left side airbag (seat) circuit short circuit to another restraints circuit	NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. Refer to the electrical circuit diagrams and check the left side airbag (seat) circuit for short circuit to another restraints circuit

B0020-56	Left Side Airbag Deployment Control - Invalid/incomplete configuration	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs - Restraints control module is not configured correctly - Car configuration file invalid/incomplete configuration	- Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software - Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTC and retest
B0021-11	Left Curtain Deployment Control 1 - Circuit short to ground	- Left side air curtain connector lever not engaged - Left side air curtain circuit short circuit to ground	

			NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. ▪ Visually inspect the left side air curtain connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the left side air curtain circuit for short circuit to ground
B0021-12	Left Curtain Deployment Control 1 - Circuit short to battery	▪ Left side air curtain connector lever not engaged ▪ Left side air curtain circuit short circuit to power	

			NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. ▪ Visually inspect the left side air curtain connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the left side air curtain circuit for short circuit to power
B0021-13	Left Curtain Deployment Control 1 - Circuit open	▪ Left side air curtain circuit open circuit, high resistance ▪ Left side air curtain connector damaged ▪ Left side air curtain internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.

- Left side air curtain resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 6 Resistance (0x5B09). Refer to the electrical circuit diagrams and check the left side air curtain circuit for open circuit, high resistance
- Disconnect the left side air curtain connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the

			connector is damaged. Install a new wiring harness as necessary Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new left side air curtain
B0021-1A	Left Curtain Deployment Control 1 - Circuit resistance below threshold	- Left side air curtain connector plunger not engaged - Left side air curtain connector damaged - Left side air curtain circuit short circuit between power and ground - Left side air curtain internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
 - A shorting bar inside the connector (deployable device side) intentionally creates a short circuit until the wiring harness connector is installed AND the plunger is engaged.
 - Left side air curtain resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.
-
- Using the manufacturer approved diagnostic system, check datalogger

			signal - Deployment Control 6 Resistance (0x5B09). If the resistance is too low, disconnect and reconnect the left side air curtain connector, ensuring that the connector plunger is correctly engaged. Clear the DTCs and retest ▪ Disconnect the left side air curtain connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Refer to the electrical circuit diagrams and check the left side air curtain circuit for short circuit between power and ground ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new left side air curtain
B0021-2B	Left Curtain Deployment Control 1 - Signal cross coupled	▪ Left side air curtain circuit short circuit to another restraints circuit	

			NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. Refer to the electrical circuit diagrams and check the left side air curtain circuit for short circuit to another restraints circuit
B0021-56	Left Curtain Deployment Control 1 - Invalid/incomplete configuration	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
B0028-11	Right Side Air Bag Deployment Control - Circuit short to ground	- Right side airbag connector lever not engaged - Right side airbag (seat) circuit short circuit to ground	

			NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. ▪ Visually inspect the right side airbag connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the right side airbag (seat) circuit for short circuit to ground
B0028-12	Right Side Air Bag Deployment Control - Circuit short to battery	▪ Right side airbag connector lever not engaged ▪ Right side airbag (seat) circuit short circuit to power	

			NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. ▪ Visually inspect the right side airbag connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the right side airbag (seat) circuit for short circuit to power
B0028-13	Right Side Air Bag Deployment Control - Open circuit	▪ Right side airbag (seat) circuit open circuit, high resistance ▪ Right side airbag (seat) connector damaged ▪ Right side airbag (seat) internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
 - Right side airbag (seat) resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.
-
- Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 7 Resistance (0x5B0A). Refer to the electrical circuit diagrams and check the right side airbag (seat) circuit for open circuit, high resistance
 - Disconnect the right side airbag (seat) connector and apply light pressure to the connector plunger. If the plunger moves to

			the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new right side airbag (seat)
B0028-1A	Right Side Airbag Deployment Control - Circuit resistance below threshold	▪ Right side airbag (seat) connector plunger not engaged ▪ Right side airbag (seat) connector damaged ▪ Right side airbag (seat) circuit short circuit between power and ground ▪ Right side airbag (seat) internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
 - A shorting bar inside the connector (deployable device side) intentionally creates a short circuit until the wiring harness connector is installed AND the plunger is engaged.
 - Right side airbag (seat) resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.
-
- Using the manufacturer approved diagnostic system, check datalogger

			signal - Deployment Control 7 Resistance (0x5B0A). If the resistance is too low, disconnect and reconnect the right side airbag (seat) connector, ensuring that the connector plunger is correctly engaged. Clear the DTCs and retest ▪ Disconnect the right side airbag (seat) connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Refer to the electrical circuit diagrams and check the right side airbag (seat) circuit for short circuit between power and ground ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new right side airbag (seat)
B0028-2B	Right Side Airbag Deployment Control - Signal cross coupled	▪ Right side airbag (seat) circuit short circuit to another restraints circuit	

			NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. Refer to the electrical circuit diagrams and check the right side airbag (seat) circuit for short circuit to another restraints circuit
B0028-56	Right Side Airbag Deployment Control - Invalid/incomplete configuration	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs - Restraints control module is not configured correctly - Car configuration file invalid/incomplete	- Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software - Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTC and retest

		configuration	
B0029-11	Right Curtain Deployment Control 1 - Circuit short to ground	- Right side air curtain connector lever not engaged - Right side air curtain circuit short circuit to ground	NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. - Visually inspect the right side air curtain connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the right side air curtain circuit for short circuit to ground
B0029-12	Right Curtain Deployment Control 1 - Circuit short to battery	- Right side air curtain connector lever not engaged - Right side air curtain circuit short circuit to power	

			NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. ▪ Visually inspect the right side air curtain connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the right side air curtain circuit for short circuit to power
B0029-13	Right Curtain Deployment Control 1 - Circuit open	▪ Right side air curtain circuit open circuit, high resistance ▪ Right side air curtain connector damaged ▪ Right side air curtain internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- Right side air curtain resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 8 Resistance (0x5B0B). Refer to the electrical circuit diagrams and check the right side air curtain circuit for open circuit, high resistance
- Disconnect the right side air curtain connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the

			connector is damaged. Install a new wiring harness as necessary Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new right side air curtain
B0029-1A	Right Curtain Deployment Control 1 - Circuit resistance below threshold	- Right side air curtain connector plunger not engaged - Right side air curtain connector damaged - Right side air curtain circuit short circuit between power and ground - Right side air curtain internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- A shorting bar inside the connector (deployable device side) intentionally creates a short circuit until the wiring harness connector is installed AND the plunger is engaged.
- Right side air curtain resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer approved diagnostic system, check datalogger

			signal - Deployment Control 8 Resistance (0x5B0B). If the resistance is too low, disconnect and reconnect the right side air curtain connector, ensuring that the connector plunger is correctly engaged. Clear the DTCs and retest ▪ Disconnect the right side air curtain connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Refer to the electrical circuit diagrams and check the right side air curtain circuit for short circuit between power and ground ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new right side air curtain
B0029-2B	Right Curtain Deployment Control 1 - Signal cross coupled	▪ Right side air curtain circuit short circuit to another restraints circuit	

			NOTE: The airbag connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. Refer to the electrical circuit diagrams and check the right side air curtain circuit for short circuit to another restraints circuit
B0029-56	Right Curtain Deployment Control 1 - Invalid/incomplete configuration	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs - Restraints control module is not configured correctly - Car configuration file invalid/incomplete	- Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software - Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTC and retest

		configuration	
B0050-11	Driver Seatbelt Sensor - Circuit short to ground	Driver buckle switch circuit short circuit to ground	Refer to the electrical circuit diagrams and check the driver buckle switch circuit for short circuit to ground
B0050-12	Driver Seatbelt Sensor - Circuit short to battery	Driver buckle switch circuit short circuit to power	Refer to the electrical circuit diagrams and check the driver buckle switch circuit for short circuit to power
B0050-13	Driver Seatbelt Sensor - Circuit open	Driver buckle switch circuit open circuit, high resistance	Refer to the electrical circuit diagrams and check the driver buckle switch circuit for open circuit, high resistance
B0050-1D	Driver Seatbelt Sensor - Circuit current out of range	Driver buckle switch circuit short circuit to ground, short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the driver buckle switch circuit for short circuit to ground, short circuit to power, open circuit, high resistance
B0050-2B	Driver Seatbelt Sensor - Signal cross coupled	Driver buckle switch circuit short circuit to another restraints circuit	Refer to the electrical circuit diagrams and check the driver buckle switch circuit for short circuit to another restraints circuit
B0050-56	Driver Seatbelt Sensor - Invalid/incomplete configuration	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
B0052-11	Passenger Seatbelt Sensor - Circuit short to ground	Passenger buckle switch circuit short circuit to ground	Refer to the electrical circuit diagrams and check the passenger buckle switch circuit for

			short circuit to ground
B0052-12	Passenger Seatbelt Sensor - Circuit short to battery	Passenger buckle switch circuit short circuit to power	Refer to the electrical circuit diagrams and check the passenger buckle switch circuit for short circuit to power
B0052-13	Passenger Seatbelt Sensor - Circuit open	Passenger buckle switch circuit open circuit, high resistance	Refer to the electrical circuit diagrams and check the passenger buckle switch circuit for open circuit, high resistance
B0052-1D	Passenger Seatbelt Sensor - Circuit current out of range	Passenger buckle switch circuit short circuit to ground, short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the passenger buckle switch circuit for short circuit to ground, short circuit to power, open circuit, high resistance
B0052-2B	Passenger Seatbelt Sensor - Signal cross coupled	Passenger buckle switch circuit short circuit to another restraints circuit	Refer to the electrical circuit diagrams and check the passenger buckle switch circuit for short circuit to another restraints circuit
B0052-56	Passenger Seatbelt Sensor - Invalid/incomplete configuration	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
B0073-11	Second Row Left Seatbelt Pretensioner Deployment Control - Circuit short to ground	- Rear left seatbelt retractor and pretensioner connector lever not engaged - Rear left seatbelt retractor and pretensioner circuit short circuit to	

		ground	NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. - Visually inspect the rear left seatbelt retractor and pretensioner connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the rear left seatbelt retractor and pretensioner circuit for short circuit to ground
B0073-12	Second Row Left Seatbelt Pretensioner Deployment Control - Circuit short to battery	- Rear left seatbelt retractor and pretensioner connector lever not engaged - Rear left seatbelt retractor and pretensioner circuit short circuit to power	

			NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. - Visually inspect the rear left seatbelt retractor and pretensioner connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the rear left seatbelt retractor and pretensioner circuit for short circuit to power
B0073-13	Second Row Left Seatbelt Pretensioner Deployment Control - Circuit open	- Rear left seatbelt retractor and pretensioner circuit open circuit, high resistance - Rear left seatbelt retractor and pretensioner connector damaged - Rear left seatbelt retractor and	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

pretensioner internal failure

NOTES:

- The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- Rear left seatbelt retractor and pretensioner resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 11 Resistance (0x5B0E). Refer to the electrical circuit diagrams and check the rear left seatbelt retractor and pretensioner circuit for open circuit, high resistance
- Disconnect the rear left seatbelt retractor and

			pretensioner connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear left seatbelt retractor and pretensioner
B0073-1A	Second Row Left Seatbelt Pretensioner Deployment Control - Circuit resistance below threshold	▪ Rear left seatbelt retractor and pretensioner connector lever not engaged ▪ Rear left seatbelt retractor and pretensioner connector damaged ▪ Rear left seatbelt retractor and pretensioner circuit short circuit between power and ground ▪ Pretensioner squib component fault	WARNING: Do not measure the resistance of a deployable device using any other method than that described below

NOTES:

- The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- A shorting bar inside the connector (deployable device side) intentionally creates a short circuit until the wiring harness connector is installed AND the connector plunger is engaged
- Rear left seatbelt retractor and pretensioner resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

			▪ Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 11 Resistance (0x5B0E). If the resistance is too low, disconnect and reconnect the rear left seatbelt retractor and pretensioner connector, ensuring that the connector plunger is correctly engaged. Clear the DTCs and retest ▪ Disconnect the rear left seatbelt retractor and pretensioner connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Refer to the electrical circuit diagrams and check the rear left seatbelt retractor and pretensioner circuit for short circuit between power and ground. Clear the DTCs and retest. If the fault persists, install a new wiring harness as necessary ▪ If no wiring harness fault exists, using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new deployable device
B0073-2B	Second Row Left Seatbelt Pretensioner Deployment Control - Signal cross coupled	▪ Rear left seatbelt retractor and pretensioner circuit short circuit to another restraints circuit	

			NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. Refer to the electrical circuit diagrams and check the rear left seatbelt retractor and pretensioner circuit for short circuit to another restraints circuit
B0073-56	Second Row Left Seatbelt Pretensioner Deployment Control - Invalid/incomplete configuration	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
B0075-11	Second Row Right Seatbelt Pretensioner Deployment Control - Circuit short to ground	- Rear right seatbelt retractor and pretensioner connector lever not engaged - Rear right seatbelt retractor and pretensioner circuit short circuit to ground	

			NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. ▪ Visually inspect the rear right seatbelt retractor and pretensioner connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the rear right seatbelt retractor and pretensioner circuit for short circuit to ground
B0075-12	Second Row Right Seatbelt Pretensioner Deployment Control - Circuit short to battery	▪ Rear right seatbelt retractor and pretensioner connector lever not engaged ▪ Rear right seatbelt retractor and pretensioner circuit short circuit to power	

			NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. - Visually inspect the rear right seatbelt retractor and pretensioner connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the rear right seatbelt retractor and pretensioner circuit for short circuit to power
B0075-13	Second Row Right Seatbelt Pretensioner Deployment Control - Circuit open	- Rear right seatbelt retractor and pretensioner circuit open circuit, high resistance - Rear right seatbelt retractor and pretensioner connector damaged - Rear right seatbelt	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

retractor and pretensioner internal failure

NOTES:

- The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- Rear right seatbelt retractor and pretensioner resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 11 Resistance (0x5B0E). Refer to the electrical circuit diagrams and check the rear right seatbelt retractor and pretensioner circuit for open circuit, high resistance
- Disconnect the rear right seatbelt retractor and

			pretensioner connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new rear right seatbelt retractor and pretensioner
B0075-1A	Second Row Right Seatbelt Pretensioner Deployment Control - Circuit resistance below threshold	▪ Rear right seatbelt retractor and pretensioner connector lever not engaged ▪ Rear right seatbelt retractor and pretensioner connector damaged ▪ Rear right seatbelt retractor and pretensioner circuit short circuit between power and ground ▪ Pretensioner squib component fault	WARNING: Do not measure the resistance of a deployable device using any other method than that described below

NOTES:

- The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- A shorting bar inside the connector (deployable device side) intentionally creates a short circuit until the wiring harness connector is installed AND the connector plunger is engaged
- Rear right seatbelt retractor and pretensioner resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

			▪ Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 11 Resistance (0x5B0E). If the resistance is too low, disconnect and reconnect the rear right seatbelt retractor and pretensioner connector, ensuring that the connector plunger is correctly engaged. Clear the DTCs and retest ▪ Disconnect the rear right seatbelt retractor and pretensioner connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Refer to the electrical circuit diagrams and check the rear right seatbelt retractor and pretensioner circuit for short circuit between power and ground. Clear the DTCs and retest. If the fault persists, install a new wiring harness as necessary ▪ If no wiring harness fault exists, using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new deployable device
B0075-2B	Second Row Right Seatbelt Pretensioner Deployment Control - Signal cross coupled	▪ Second row right seatbelt retractor and pretensioner circuit short circuit to another restraints circuit	

			NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. Refer to the electrical circuit diagrams and check the second row right seatbelt retractor and pretensioner circuit for short circuit to another restraints circuit
B0075-56	Second Row Right Seatbelt Pretensioner Deployment Control - Invalid/incomplete configuration	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs - Restraints control module is not configured correctly - Car configuration file	- Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software - Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTC and retest

		invalid/incomplete configuration	
B0076-11	Third Row Left Seatbelt Pretensioner Deployment Control - Circuit short to ground	- Third row left seatbelt retractor and pretensioner connector lever not engaged - Third row left seatbelt retractor and pretensioner circuit short circuit to ground	NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. - Visually inspect the third row left seatbelt retractor and pretensioner connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the third row left seatbelt retractor and pretensioner circuit for short circuit to ground
B0076-12	Third Row Left Seatbelt Pretensioner Deployment Control - Circuit short to battery	- Third row left seatbelt retractor and pretensioner connector lever not engaged - Third row left	

		seatbelt retractor and pretensioner circuit short circuit to power	NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. - Visually inspect the third row left seatbelt retractor and pretensioner connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the third row left seatbelt retractor and pretensioner circuit for short circuit to power
B0076-13	Third Row Left Seatbelt Pretensioner Deployment Control - Circuit open	- Third row left seatbelt pretensioner circuit open circuit, high resistance - Third row left seatbelt pretensioner connector damaged - Third row left	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

seatbelt
pretensioner internal
failure

NOTES:

- The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
 - Third row left seatbelt pretensioner resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.
-
- Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 23 Resistance (0x5B3D). Refer to the electrical circuit diagrams and check the third row left seatbelt pretensioner circuit for open circuit, high resistance
 - Disconnect the third row left seatbelt pretensioner connector and apply light

			pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ■ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new third row left seatbelt pretensioner
B0076-1A	Third Row Left Seatbelt Pretensioner Deployment Control - Circuit resistance below threshold	■ Third row left seatbelt pretensioner connector plunger not engaged ■ Third row left seatbelt pretensioner connector damaged ■ Third row left seatbelt pretensioner circuit short circuit between power and ground ■ Third row left seatbelt pretensioner internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- A shorting bar inside the connector (deployable device side) intentionally creates a short circuit until the wiring harness connector is installed AND the plunger is engaged.
- Third row left seatbelt pretensioner resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer

			approved diagnostic system, check datalogger signal - Deployment Control 23 Resistance (0x5B3D). If the resistance is too low, disconnect and reconnect the third row left seatbelt pretensioner connector, ensuring that the connector plunger is correctly engaged. Clear the DTCs and retest ▪ Disconnect the third row left seatbelt pretensioner connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Refer to the electrical circuit diagrams and check the third row left seatbelt pretensioner circuit for short circuit between power and ground ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new third row left seatbelt pretensioner
B0076-2B	Third Row Left Seatbelt Pretensioner Deployment Control - Signal cross coupled	▪ Third row left seatbelt retractor and pretensioner circuit short circuit to another restraints circuit	

			NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. Refer to the electrical circuit diagrams and check the third row left seatbelt retractor and pretensioner circuit for short circuit to another restraints circuit
B0076-56	Third Row Left Seatbelt Pretensioner Deployment Control - Invalid/incomplete configuration	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs - Restraints control module is not configured correctly - Car configuration file	- Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software - Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTC and retest

		invalid/incomplete configuration	
B0078-11	Third Row Right Seatbelt Pretensioner Deployment Control - Circuit short to ground	- Third row left seatbelt retractor and pretensioner connector lever not engaged - Third row right seatbelt retractor and pretensioner circuit short circuit to ground	NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. - Visually inspect the third row left seatbelt retractor and pretensioner connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the third row right seatbelt retractor and pretensioner circuit for short circuit to ground
B0078-12	Third Row Right Seatbelt Pretensioner Deployment Control - Circuit short to battery	- Third row left seatbelt retractor and pretensioner connector lever not engaged - Third row right	

		seatbelt retractor and pretensioner circuit short circuit to power	NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. - Visually inspect the third row left seatbelt retractor and pretensioner connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the third row right seatbelt retractor and pretensioner circuit for short circuit to power
B0078-13	Third Row Right Seatbelt Pretensioner Deployment Control - Circuit open	- Third row right seatbelt pretensioner circuit open circuit, high resistance - Third row right seatbelt pretensioner connector damaged - Third row right	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

seatbelt
pretensioner internal
failure

NOTES:

- The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- Third row right seatbelt pretensioner resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 24 Resistance (0x5B3E). Refer to the electrical circuit diagrams and check the third row right seatbelt pretensioner circuit for open circuit, high resistance
- Disconnect the third row right seatbelt

			pretensioner connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new third row right seatbelt pretensioner
B0078-1A	Third Row Right Seatbelt Pretensioner Deployment Control - Circuit resistance below threshold	▪ Third row right seatbelt pretensioner connector plunger not engaged ▪ Third row right seatbelt pretensioner connector damaged ▪ Third row right seatbelt pretensioner circuit short circuit between power and ground ▪ Third row right seatbelt pretensioner internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- A shorting bar inside the connector (deployable device side) intentionally creates a short circuit until the wiring harness connector is installed AND the plunger is engaged.
- Third row right seatbelt pretensioner resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer

			approved diagnostic system, check datalogger signal - Deployment Control 24 Resistance (0x5B3E). If the resistance is too low, disconnect and reconnect the third row right seatbelt pretensioner connector, ensuring that the connector plunger is correctly engaged. Clear the DTCs and retest ▪ Disconnect the third row right seatbelt pretensioner connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Refer to the electrical circuit diagrams and check the third row right seatbelt pretensioner circuit for short circuit between power and ground ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new third row right seatbelt pretensioner
B0078-2B	Third Row Right Seatbelt Pretensioner Deployment Control - Signal cross coupled	▪ Third row right seatbelt retractor and pretensioner circuit short circuit to another restraints circuit	

			NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. Refer to the electrical circuit diagrams and check the third row right seatbelt retractor and pretensioner circuit for short circuit to another restraints circuit
B0078-56	Third Row Right Seatbelt Pretensioner Deployment Control - Invalid/incomplete configuration	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs - Restraints control module is not configured correctly - Car configuration file	- Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software - Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTC and retest

		invalid/incomplete configuration	
B0082-11	Passenger Seatbelt Load Limiter Deployment Control - Circuit short to ground	- Passenger seatbelt retractor load limiter connector lever not engaged - Passenger seatbelt retractor load limiter circuit short circuit to ground	NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. - Visually inspect the passenger seatbelt retractor load limiter connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the passenger seatbelt retractor load limiter circuit for short circuit to ground
B0082-12	Passenger Seatbelt Load Limiter Deployment Control - Circuit short to battery	- Passenger seatbelt retractor load limiter connector lever not engaged - Passenger seatbelt retractor load limiter	

		circuit short circuit to power	NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. - Visually inspect the passenger seatbelt retractor load limiter connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the passenger seatbelt retractor load limiter circuit for short circuit to power
B0082-13	Passenger Seatbelt Load Limiter Deployment Control - Circuit open	- Passenger seatbelt retractor load limiter circuit open circuit, high resistance - Passenger seatbelt retractor load limiter connector damaged - Passenger seatbelt retractor load limiter internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- Passenger seatbelt retractor load limiter resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 22 Resistance (0x5B3C). Refer to the electrical circuit diagrams and check the passenger seatbelt retractor load limiter circuit for open circuit, high resistance
- Disconnect the passenger seatbelt retractor load limiter connector and

			apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new passenger seatbelt retractor load limiter
B0082-1A	Passenger Seatbelt Load Limiter Deployment Control - Circuit resistance below threshold	▪ Passenger seatbelt retractor load limiter connector plunger not engaged ▪ Passenger seatbelt retractor load limiter connector damaged ▪ Passenger seatbelt retractor load limiter circuit short circuit between power and ground ▪ Passenger seatbelt retractor load limiter internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- A shorting bar inside the connector (deployable device side) intentionally creates a short circuit until the wiring harness connector is installed AND the plunger is engaged.
- Passenger seatbelt retractor load limiter resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer

			approved diagnostic system, check datalogger signal - Deployment Control 22 Resistance (0x5B3C). If the resistance is too low, disconnect and reconnect the passenger seatbelt retractor load limiter connector, ensuring that the connector plunger is correctly engaged. Clear the DTCs and retest ▪ Disconnect the passenger seatbelt retractor load limiter connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Refer to the electrical circuit diagrams and check the passenger seatbelt retractor load limiter circuit for short circuit between power and ground ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new passenger seatbelt retractor load limiter
B0082-2B	Passenger Seatbelt Load Limiter Deployment Control - Signal cross coupled	▪ Passenger seatbelt retractor load limiter circuit short circuit to another restraints circuit	

			NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. Refer to the electrical circuit diagrams and check the passenger seatbelt retractor load limiter circuit for short circuit to another restraints circuit
B0082-56	Passenger Seatbelt Load Limiter Deployment Control - Invalid/incomplete configuration	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs - Restraints control module is not configured correctly - Car configuration file	- Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software - Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTC and retest

		invalid/incomplete configuration	
B0090-11	Left Frontal Restraints Sensor - Circuit short to ground	- Front left impact sensor power circuit short circuit to ground - Front left impact sensor circuit short circuit between power and return	- Refer to the electrical circuit diagrams and check the front left impact sensor power circuit (connector A pin 17) for short circuit to ground - Refer to the electrical circuit diagrams and check the front left impact sensor circuit (connector A pins 17 and 18) for short circuit between power and return
B0090-15	Left Frontal Restraints Sensor - Circuit short to battery or open	Front left impact sensor circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the front left impact sensor circuit for short circuit to power, open circuit, high resistance
B0090-56	Left Frontal Restraints Sensor - Invalid/incomplete configuration	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
B0090-81	Left Frontal Restraints Sensor - Invalid serial data received	- Front left impact sensor circuit electrical interference - Front left impact sensor internal failure	- Check the front left impact sensor circuit for correct routing. Check for vehicle modifications or non-genuine accessories - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left impact sensor
B0090-	Left Frontal Restraints	Front left impact	Using the manufacturer

96	Sensor - Component internal failure	sensor internal failure	approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front left impact sensor
B0091-11	Left Side Restraints Sensor 1 - Circuit short to ground	- Left B pillar impact sensor power circuit short circuit to ground - Left B pillar impact sensor circuit short circuit between power and return	NOTE: The front right door impact sensor, the left B pillar impact sensor and the right C pillar impact sensor are bussed together and will set corresponding DTCs simultaneously - Refer to the electrical circuit diagrams and check the left B pillar impact sensor power circuit (connector B pin 45) for short circuit to ground - Refer to the electrical circuit diagrams and check the left B pillar impact sensor circuit (connector B pins 45 and 46) for short circuit between power and return
B0091-15	Left Side Restraints Sensor 1 - Circuit short to battery or open	Left B pillar impact sensor circuit short circuit to power, open circuit, high resistance	NOTE: The front right door impact sensor, the left B pillar impact sensor and the right C pillar impact sensor are bussed together and will set corresponding DTCs simultaneously

			Refer to the electrical circuit diagrams and check the left B pillar impact sensor circuit for short circuit to power, open circuit, high resistance
B0091-56	Left Side Restraints Sensor 1 - Invalid/incomplete configuration	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
B0091-81	Left Side Restraints Sensor 1 - Invalid serial data received	- Left B pillar impact sensor circuit electrical interference - Left B pillar impact sensor internal failure	- Check the left B pillar impact sensor circuit for correct routing. Check for vehicle modifications or non-genuine accessories - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new left B pillar impact sensor
B0091-96	Left Side Restraints Sensor 1 - Component internal failure	Left B pillar impact sensor internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new left B pillar impact sensor
B0092-11	Left Side Restraints Sensor 2 - Circuit short to ground	- Left C pillar impact sensor power circuit short circuit to ground - Left C pillar impact sensor circuit short circuit between power and return	NOTE: The front left door impact sensor, the right B pillar impact sensor and the left C pillar impact sensor are bussed together and will set corresponding DTCs simultaneously

			- Refer to the electrical circuit diagrams and check the left C pillar impact sensor power circuit (connector B pin 32) for short circuit to ground - Refer to the electrical circuit diagrams and check the left C pillar impact sensor circuit (connector B pins 31 and 32) for short circuit between power and return
B0092-15	Left Side Restraints Sensor 2 - Circuit short to battery or open	Left C pillar impact sensor circuit short circuit to power, open circuit, high resistance	NOTE: The front left door impact sensor, the right B pillar impact sensor and the left C pillar impact sensor are bussed together and will set corresponding DTCs simultaneously Refer to the electrical circuit diagrams and check the left C pillar impact sensor circuit for short circuit to power, open circuit, high resistance
B0092-56	Left Side Restraints Sensor 2 - Invalid/incomplete configuration	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
B0092-81	Left Side Restraints Sensor 2 - Invalid serial data received	Left C pillar impact sensor circuit electrical interference	Check the left C pillar impact sensor circuit for correct routing. Check for vehicle modifications or non-genuine accessories

		Left C pillar impact sensor internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new left C pillar impact sensor
B0092-96	Left Side Restraints Sensor 2 - Component internal failure	Left C pillar impact sensor internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new left C pillar impact sensor
B0095-11	Right Frontal Restraints Sensor - Circuit short to ground	- Front right impact sensor power circuit short circuit to ground - Front right impact sensor circuit short circuit between power and return	- Refer to the electrical circuit diagrams and check the front right impact sensor power circuit (connector A pin 16) for short circuit to ground - Refer to the electrical circuit diagrams and check the front right impact sensor circuit (connector A pins 15 and 16) for short circuit between power and return
B0095-15	Right Frontal Restraints Sensor - Circuit short to battery or open	Front right impact sensor circuit short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the front right impact sensor circuit for short circuit to power, open circuit, high resistance
B0095-56	Right Frontal Restraints Sensor - Invalid/incomplete configuration	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
B0095-81	Right Frontal Restraints Sensor -	Front right impact sensor circuit	Check the front right impact sensor circuit for

	Invalid serial data received	electrical interference Front right impact sensor internal failure	correct routing. Check for vehicle modifications or non-genuine accessories Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right impact sensor
B0095-96	Right Frontal Restraints Sensor - Component internal failure	Front right impact sensor internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new front right impact sensor
B0096-11	Right Side Restraints Sensor 1 - Circuit short to ground	- Right B pillar impact sensor power circuit short circuit to ground - Right B pillar impact sensor circuit short circuit between power and return	NOTE: The front left door impact sensor, the right B pillar impact sensor and the left C pillar impact sensor are bussed together and will set corresponding DTCs simultaneously - Refer to the electrical circuit diagrams and check the right B pillar impact sensor power circuit (connector B pin 44) for short circuit to ground - Refer to the electrical circuit diagrams and check the right B pillar impact sensor circuit (connector B pins 43 and 44) for short circuit between power and return
B0096-15	Right Side Restraints Sensor 1 - Circuit	Right B pillar impact sensor circuit short	

	short to battery or open	circuit to power, open circuit, high resistance	NOTE: The front left door impact sensor, the right B pillar impact sensor and the left C pillar impact sensor are bussed together and will set corresponding DTCs simultaneously Refer to the electrical circuit diagrams and check the right B pillar impact sensor circuit for short circuit to power, open circuit, high resistance
B0096-56	Right Side Restraints Sensor 1 - Invalid/incomplete configuration	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
B0096-81	Right Side Restraints Sensor 1 - Invalid serial data received	- Right B pillar impact sensor circuit electrical interference - Right B pillar impact sensor internal failure	- Check the right B pillar impact sensor circuit for correct routing. Check for vehicle modifications or non-genuine accessories - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new right B pillar impact sensor
B0096-96	Right Side Restraints Sensor 1 - Component internal failure	Right B pillar impact sensor internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new right B pillar impact sensor

B0097-11	Right Side Restraints Sensor 2 - Circuit short to ground	▪ Right C pillar impact sensor power circuit short circuit to ground ▪ Right C pillar impact sensor circuit short circuit between power and return	NOTE: The front right door impact sensor, the left B pillar impact sensor and the right C pillar impact sensor are bussed together and will set corresponding DTCs simultaneously ▪ Refer to the electrical circuit diagrams and check the right C pillar impact sensor power circuit (connector B pin 33) for short circuit to ground ▪ Refer to the electrical circuit diagrams and check the right C pillar impact sensor circuit (connector B pins 33 and 34) for short circuit between power and return
B0097-15	Right Side Restraints Sensor 2 - Circuit short to battery or open	▪ Right C pillar impact sensor circuit short circuit to power, open circuit, high resistance	NOTE: The front right door impact sensor, the left B pillar impact sensor and the right C pillar impact sensor are bussed together and will set corresponding DTCs simultaneously ▪ Refer to the electrical circuit diagrams and check the right C pillar impact sensor circuit for short circuit to power, open circuit, high

			resistance
B0097-56	Right Side Restraints Sensor 2 - Invalid/incomplete configuration	▪ Restraints control module is not configured correctly	▪ Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
B0097-81	Right Side Restraints Sensor 2 - Invalid serial data received	▪ Right C pillar impact sensor circuit electrical interference ▪ Right C pillar impact sensor internal failure	▪ Check the right C pillar impact sensor circuit for correct routing. Check for vehicle modifications or non-genuine accessories ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new right C pillar impact sensor
B0097-96	Right Side Restraints Sensor 2 - Component internal failure	▪ Right C pillar impact sensor internal failure	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new right C pillar impact sensor
B00B5-11	Driver Seat Track Position Restraints Sensor - Circuit short to ground	▪ Driver seat position sensor power circuit short circuit to ground ▪ Driver seat position sensor circuit short circuit between power and return	▪ Refer to the electrical circuit diagrams and check the driver seat position sensor power circuit for short circuit to ground ▪ Refer to the electrical circuit diagrams and check the driver seat position sensor circuit for short circuit between power and return
B00B5-12	Driver Seat Track Position Restraints Sensor - Circuit short to battery	▪ Driver seat position sensor circuit short circuit to power	▪ Refer to the electrical circuit diagrams and check the driver seat position sensor circuit for

			short circuit to power
B00B5-13	Driver Seat Track Position Restraints Sensor - Circuit open	Driver seat position sensor circuit open circuit, high resistance	Refer to the electrical circuit diagrams and check the driver seat position sensor circuit for open circuit, high resistance
B00B5-1D	Driver Seat Track Position Restraints Sensor - Circuit current out of range	- Driver seat position sensor circuit electrical interference - Driver seat position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance - Driver seat position sensor internal failure	- Check the driver seat position sensor circuit for correct routing. Check for vehicle modifications or non-genuine accessories - Refer to the electrical circuit diagrams and check the driver seat position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persist, install a new driver seat position sensor as required
B00B5-2B	Driver Seat Track Position Restraints Sensor - Signal cross coupled	Driver seat position sensor circuit short circuit to another restraints circuit	Refer to the electrical circuit diagrams and check the driver seat position sensor circuit for short circuit to another restraints circuit
B00B5-56	Driver Seat Track Position Restraints Sensor - Invalid/incomplete configuration	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
B00C5-11	Passenger Seat Track Position Restraints Sensor - Circuit short	Passenger seat position sensor circuit short circuit to	Refer to the electrical circuit diagrams and check the passenger seat

	to ground	ground	position sensor circuit for short circuit to ground
B00C5-12	Passenger Seat Track Position Restraints Sensor - Circuit short to battery	Passenger seat position sensor circuit short circuit to power	Refer to the electrical circuit diagrams and check the passenger seat position sensor circuit for short circuit to power
B00C5-13	Passenger Seat Track Position Restraints Sensor - Circuit open	Passenger seat position sensor circuit open circuit, high resistance	Refer to the electrical circuit diagrams and check the passenger seat position sensor circuit for open circuit, high resistance
B00C5-1D	Passenger Seat Track Position Restraints Sensor - Circuit current out of range	Passenger seat position sensor circuit short circuit to ground, short circuit to power, open circuit, high resistance	Refer to the electrical circuit diagrams and check the passenger seat position sensor circuit for short circuit to ground, short circuit to power, open circuit, high resistance
B00C5-2B	Passenger Seat Track Position Restraints Sensor - Signal cross coupled	Passenger seat position sensor circuit short circuit to another restraints circuit	Refer to the electrical circuit diagrams and check the passenger seat position sensor circuit for short circuit to another restraints circuit
B00C5-56	Passenger Seat Track Position Restraints Sensor - Invalid/incomplete configuration	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
B00D2-01	Restraint System Malfunction Indicator 1 - General electrical failure	Restraints warning indicator fault reported by the instrument cluster	Using the manufacturer approved diagnostic system, check the instrument cluster for related DTCs and refer to the relevant DTC index

B00D5-11	Restraint System Passenger Disable Indicator - Circuit short to ground	Passenger airbag deactivation warning indicator circuit short circuit to ground	Refer to the electrical circuit diagrams and check the passenger airbag deactivation warning indicator circuit for short circuit to ground
B00D5-12	Restraint System Passenger Disable Indicator - Circuit short to battery	Passenger airbag deactivation warning indicator circuit short circuit to power	Refer to the electrical circuit diagrams and check the passenger airbag deactivation warning indicator circuit for short circuit to power
B00D5-13	Restraint System Passenger Disable Indicator - Circuit open	Passenger airbag deactivation warning indicator circuit open circuit, high resistance	Refer to the electrical circuit diagrams and check the passenger airbag deactivation warning indicator circuit for open circuit, high resistance
B00D5-56	Restraint System Passenger Disable Indicator - Invalid/incomplete configuration	- Restraints control module incorrectly installed - Airbag deactivation lamp circuit/connector failure - The indicator device is connected but not configured correctly	- Check the restraints control module is correctly installed - Check the integrity of the airbag deactivation lamp circuit wiring harness and check that harness connectors are correctly seated and not mis-pinned - Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
B00DF-95	Passenger Restraints Disable Switch - Incorrect assembly	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
B1193-	Crash Event Storage	The restraints	Using the manufacturer

00	Full and Locked - No sub type information	control module has stored crash events	approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new restraints control module
B11A0-11	Left Side Restraints Pressure Sensor - Circuit short to ground	NOTE: Do not apply any compressed air to the sensor when diagnosing - Left impact pressure sensor power circuit short circuit to ground - Left impact pressure sensor circuit short circuit between power and return	NOTE: The front left door impact sensor, the right B pillar impact sensor and the left C pillar impact sensor are bussed together and will set corresponding DTCs simultaneously - Refer to the electrical circuit diagrams and check the left impact pressure sensor power circuit (connector B pin 19) for short circuit to ground - Refer to the electrical circuit diagrams and check the left impact pressure sensor circuit (connector B pins 19 and 20) for short circuit between power and return
B11A0-15	Left Side Restraints Pressure Sensor - Circuit short to battery or open	NOTE: Do not apply any compressed air to the sensor when diagnosing Left impact pressure sensor circuit short circuit to power,	NOTE: The front left door impact sensor, the right B pillar impact sensor and the left C pillar impact sensor are bussed together and will set corresponding DTCs simultaneously

		open circuit, high resistance	Refer to the electrical circuit diagrams and check the left impact pressure sensor circuit for short circuit to power, open circuit, high resistance
B11A0-56	Left Side Restraints Pressure Sensor - Invalid/incomplete configuration	NOTE: Do not apply any compressed air to the sensor when diagnosing Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
B11A0-81	Left Side Restraints Pressure Sensor - Invalid serial data received	NOTE: Do not apply any compressed air to the sensor when diagnosing - Left impact pressure sensor circuit electrical interference - Left impact pressure sensor internal failure	- Check the left impact pressure sensor circuit for correct routing. Check for vehicle modifications or non-genuine accessories - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new left impact pressure sensor
B11A0-96	Left Side Restraints Pressure Sensor - Component internal failure		Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new left impact pressure sensor

		NOTE: Do not apply any compressed air to the sensor when diagnosing Left impact pressure sensor internal failure	
B11A1-11	Right Side Restraints Pressure Sensor - Circuit short to ground	NOTE: Do not apply any compressed air to the sensor when diagnosing - Right impact pressure sensor power circuit short circuit to ground - Right impact pressure sensor circuit short circuit between power and return	NOTE: The front right door impact sensor, the left B pillar impact sensor and the right C pillar impact sensor are bussed together and will set corresponding DTCs simultaneously - Refer to the electrical circuit diagrams and check the right impact pressure sensor power circuit (connector B pin 22) for short circuit to ground - Refer to the electrical circuit diagrams and check the right impact pressure sensor circuit (connector B pins 21 and 22) for short circuit between power and return
B11A1-15	Right Side Restraints Pressure Sensor - Circuit short to battery or open		

		NOTE: Do not apply any compressed air to the sensor when diagnosing Right impact pressure sensor circuit short circuit to power, open circuit, high resistance	NOTE: The front right door impact sensor, the left B pillar impact sensor and the right C pillar impact sensor are bussed together and will set corresponding DTCs simultaneously Refer to the electrical circuit diagrams and check the right impact pressure sensor circuit for short circuit to power, open circuit, high resistance
B11A1-56	Right Side Restraints Pressure Sensor - Invalid/incomplete configuration	NOTE: Do not apply any compressed air to the sensor when diagnosing Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
B11A1-81	Right Side Restraints Pressure Sensor - Invalid serial data received	NOTE: Do not apply any compressed air to the sensor when diagnosing Right impact pressure sensor	- Check the right impact pressure sensor circuit for correct routing. Check for vehicle modifications or non-genuine accessories - Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new right impact pressure sensor

		circuit electrical interference Right impact pressure sensor internal failure	
B11A1-96	Right Side Restraints Pressure Sensor - Component internal failure	NOTE: Do not apply any compressed air to the sensor when diagnosing Right impact pressure sensor internal failure	Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new right impact pressure sensor
B11D8-11	Restraint Event Notification - Circuit short to ground	Crash output signal circuit short circuit to ground	Refer to the electrical circuit diagrams and check the crash output signal circuit for short circuit to ground
B11D8-12	Restraint Event Notification - Circuit short to battery	Crash output signal circuit short circuit to power	Refer to the electrical circuit diagrams and check the crash output signal circuit for short circuit to power
B11D8-13	Restraint Event Notification - Circuit open	Crash output signal circuit open circuit, high resistance	Refer to the electrical circuit diagrams and check the crash output signal circuit for open circuit, high resistance
B1211-11	Driver Seatbelt Retractor Pretensioner Deployment Control - Circuit short to ground	- Driver seatbelt retractor and pretensioner connector lever not engaged - Driver seatbelt retractor and pretensioner circuit	

		short circuit to ground	NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. - Visually inspect the driver seatbelt retractor and pretensioner connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the driver seatbelt retractor and pretensioner circuit for short circuit to ground
B1211-12	Driver Seatbelt Retractor Pretensioner Deployment Control - Circuit short to battery	- Driver seatbelt retractor and pretensioner connector lever not engaged - Driver seatbelt retractor and pretensioner circuit short circuit to power	

			NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. ▪ Visually inspect the driver seatbelt retractor and pretensioner connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the driver seatbelt retractor and pretensioner circuit for short circuit to power
B1211-13	Driver Seatbelt Retractor Pretensioner Deployment Control - Circuit open	▪ Driver seatbelt retractor and pretensioner circuit open circuit, high resistance ▪ Driver seatbelt retractor and pretensioner connector damaged ▪ Driver seatbelt retractor and	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

pretensioner internal failure

NOTES:

- The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- Driver seatbelt retractor and pretensioner resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 13 Resistance (0x5B10). Refer to the electrical circuit diagrams and check the driver seatbelt retractor and pretensioner circuit for open circuit, high resistance
- Disconnect the driver seatbelt retractor and

			pretensioner connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new driver seatbelt retractor and pretensioner
B1211-1A	Driver Seatbelt Retractor Pretensioner Deployment Control - Circuit resistance below threshold	▪ Driver seatbelt retractor and pretensioner connector plunger not engaged ▪ Driver seatbelt retractor and pretensioner connector damaged ▪ Driver seatbelt retractor and pretensioner circuit short circuit between power and ground ▪ Driver seatbelt retractor and pretensioner internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- A shorting bar inside the connector (deployable device side) intentionally creates a short circuit until the wiring harness connector is installed AND the plunger is engaged.
- Driver seatbelt retractor and pretensioner resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer

			approved diagnostic system, check datalogger signal - Deployment Control 13 Resistance (0x5B10). If the resistance is too low, disconnect and reconnect the driver seatbelt retractor and pretensioner connector, ensuring that the connector plunger is correctly engaged. Clear the DTCs and retest ▪ Disconnect the driver seatbelt retractor and pretensioner connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Refer to the electrical circuit diagrams and check the driver seatbelt retractor and pretensioner circuit for short circuit between power and ground ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new driver seatbelt retractor and pretensioner
B1211-2B	Driver Seatbelt Retractor Pretensioner Deployment Control - Signal cross coupled	▪ Driver seatbelt retractor and pretensioner circuit short circuit to another restraints circuit	

			NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. Refer to the electrical circuit diagrams and check the driver seatbelt retractor and pretensioner circuit for short circuit to another restraints circuit
B1211-56	Driver Seatbelt Retractor Pretensioner Deployment Control - Invalid/incomplete configuration	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs - Restraints control module is not configured correctly - Car configuration file	- Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software - Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTC and retest

		invalid/incomplete configuration	
B1214-11	Passenger Seatbelt Retractor Pretensioner Deployment Control - Circuit short to ground	- Passenger seatbelt retractor and pretensioner connector lever not engaged - Passenger seatbelt retractor and pretensioner circuit short circuit to ground	NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. - Visually inspect the passenger seatbelt retractor and pretensioner connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the passenger seatbelt retractor and pretensioner circuit for short circuit to ground
B1214-12	Passenger Seatbelt Retractor Pretensioner Deployment Control - Circuit short to battery	- Passenger seatbelt retractor and pretensioner connector lever not engaged - Passenger seatbelt	

		retractor and pretensioner circuit short circuit to power	NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. - Visually inspect the passenger seatbelt retractor and pretensioner connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the passenger seatbelt retractor and pretensioner circuit for short circuit to power
B1214-13	Passenger Seatbelt Retractor Pretensioner Deployment Control - Circuit open	- Passenger seatbelt retractor and pretensioner circuit open circuit, high resistance - Passenger seatbelt retractor and pretensioner connector damaged - Passenger seatbelt	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

retractor and pretensioner internal failure

NOTES:

- The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- Passenger seatbelt retractor and pretensioner resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 14 Resistance (0x5B34). Refer to the electrical circuit diagrams and check the passenger seatbelt retractor and pretensioner circuit for open circuit, high resistance
- Disconnect the passenger seatbelt retractor and

			pretensioner connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new passenger seatbelt retractor and pretensioner
B1214-1A	Passenger Seatbelt Retractor Pretensioner Deployment Control - Circuit resistance below threshold	▪ Passenger seatbelt retractor and pretensioner connector plunger not engaged ▪ Passenger seatbelt retractor and pretensioner connector damaged ▪ Passenger seatbelt retractor and pretensioner circuit short circuit between power and ground ▪ Passenger seatbelt retractor and pretensioner internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- A shorting bar inside the connector (deployable device side) intentionally creates a short circuit until the wiring harness connector is installed AND the plunger is engaged.
- Passenger seatbelt retractor and pretensioner resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer

			approved diagnostic system, check datalogger signal - Deployment Control 14 Resistance (0x5B34). If the resistance is too low, disconnect and reconnect the passenger seatbelt retractor and pretensioner connector, ensuring that the connector plunger is correctly engaged. Clear the DTCs and retest ▪ Disconnect the passenger seatbelt retractor and pretensioner connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Refer to the electrical circuit diagrams and check the passenger seatbelt retractor and pretensioner circuit for short circuit between power and ground ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new passenger seatbelt retractor and pretensioner
B1214-2B	Passenger Seatbelt Retractor Pretensioner Deployment Control - Signal cross coupled	▪ Passenger seatbelt retractor and pretensioner circuit short circuit to another restraints circuit	

			NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. Refer to the electrical circuit diagrams and check the passenger seatbelt retractor and pretensioner circuit for short circuit to another restraints circuit
B1214-56	Passenger Seatbelt Retractor Pretensioner Deployment Control - Invalid/incomplete configuration	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs - Restraints control module is not configured correctly - Car configuration file	- Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software - Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTC and retest

		invalid/incomplete configuration	
B1408-11	Driver Seatbelt Anchor Pretensioner Deployment Control - Circuit short to ground	▪ Driver seatbelt anchor pretensioner connector lever not engaged ▪ Driver seatbelt anchor pretensioner circuit short circuit to ground	NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. ▪ Visually inspect the driver seatbelt anchor pretensioner connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest ▪ Refer to the electrical circuit diagrams and check the driver seatbelt anchor pretensioner circuit for short circuit to ground
B1408-12	Driver Seatbelt Anchor Pretensioner Deployment Control - Circuit short to battery	▪ Driver seatbelt anchor pretensioner connector lever not engaged ▪ Driver seatbelt anchor pretensioner circuit short circuit to	

		power	NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. - Visually inspect the driver seatbelt anchor pretensioner connector, the locking plunger should be flush with the housing. If not, push the locking plunger in. Clear the DTCs and retest - Refer to the electrical circuit diagrams and check the driver seatbelt anchor pretensioner circuit for short circuit to power
B1408-13	Driver Seatbelt Anchor Pretensioner Deployment Control - Circuit open	- Driver seatbelt anchor pretensioner circuit open circuit, high resistance - Driver seatbelt anchor pretensioner connector damaged - Driver seatbelt anchor pretensioner internal failure	WARNING: Do not measure the resistance of a deployable device using any other method than that described below.

NOTES:

- The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- Driver seatbelt anchor pretensioner resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

- Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 18 Resistance (0x5B38). Refer to the electrical circuit diagrams and check the driver seatbelt anchor pretensioner circuit for open circuit, high resistance
- Disconnect the driver seatbelt anchor

			pretensioner connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new driver seatbelt anchor pretensioner
B1408-1A	Driver Seatbelt Anchor Pretensioner Deployment Control - Circuit resistance below threshold	▪ Driver seatbelt anchor pretensioner connector lever not engaged ▪ Driver seatbelt anchor pretensioner connector damage ▪ Driver seatbelt anchor pretensioner circuit short circuit between power and ground ▪ Pretensioner component fault	WARNING: Do not measure the resistance of a deployable device using any other method than that described below

NOTES:

- The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary.
- A shorting bar inside the connector (deployable device side) intentionally creates a short circuit until the wiring harness connector is installed AND the connector plunger is engaged
- Driver seatbelt anchor pretensioner resistance specification should be greater than 1.70 ohms and less than 3.28 ohms at -40°C to 85°C.

			▪ Using the manufacturer approved diagnostic system, check datalogger signal - Deployment Control 18 Resistance (0x5B38). If the resistance is too low, disconnect and reconnect the driver seatbelt anchor pretensioner connector, ensuring that the connector plunger is correctly engaged. Clear the DTCs and retest ▪ Disconnect the driver seatbelt anchor pretensioner connector and apply light pressure to the connector plunger. If the plunger moves to the engaged position the connector is damaged. Install a new wiring harness as necessary ▪ Refer to the electrical circuit diagrams and check the driver seatbelt anchor pretensioner circuit for short circuit between power and ground. Clear the DTCs and retest. If the fault persists, install a new wiring harness as necessary ▪ If no wiring harness fault exists, using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new deployable device
B1408-2B	Driver Seatbelt Anchor Pretensioner Deployment Control - Signal cross coupled	▪ Driver seatbelt anchor pretensioner circuit short circuit to another restraints circuit	

			NOTE: The deployable device connector has a locking plunger (orange tab) which should only fully lock when the two connectors are securely mated, male to female. If the plunger can move to the locked position easily when not mated (ie: using reasonable pressure), then this indicates that the connector is damaged. Install a new wiring harness as necessary. Refer to the electrical circuit diagrams and check the driver seatbelt anchor pretensioner circuit for short circuit to another restraints circuit
B1408-56	Driver Seatbelt Anchor Pretensioner Deployment Control - Invalid/incomplete configuration	NOTE: After updating the car configuration file, set the ignition to on and wait 30 seconds before clearing the DTCs - Restraints control module is not configured correctly - Car configuration file invalid/incomplete	- Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software - Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTC and retest

		configuration	
U0001-81	High Speed CAN Communication Bus - Invalid serial data received	Invalid data received from another control module via the high speed CAN bus	Using the manufacturer approved diagnostic system, check the snapshot data to determine the invalid data source control module. Check the relevant control module for related DTCs and refer to the relevant DTC index. Clear the DTCs and retest
U0001-87	High Speed CAN Communication Bus - Missing message	Missing message from another control module via the high speed CAN bus (powertrain)	Using the manufacturer approved diagnostic system, check the snapshot data to determine the missing message source control module. Check the relevant control module for related DTCs and refer to the relevant DTC index
U0001-88	High Speed CAN Communication Bus - Bus off	High speed CAN bus (powertrain) circuit short circuit to ground, short circuit to power, open circuit, high resistance	Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the high speed CAN bus (powertrain) circuit for short circuit to ground, short circuit to power, open circuit, high resistance
U0073-00	Control Module Communication Bus "A" Off - No sub type information	High speed CAN bus (chassis) circuit short circuit to ground, short circuit to power, open circuit, high resistance	Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the high speed CAN bus (chassis) circuit for short circuit to ground, short circuit to

			power, open circuit, high resistance
U0300-00	Internal Control Module Software Incompatibility - No sub type information	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
U0455-56	Invalid Data Received From Restraints Occupant Classification System Module - Invalid/incomplete configuration	- Car configuration file mismatch with vehicle specification - Incorrect passenger seat/occupant classification sensor control module installed	- Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTCs and retest - Install a new passenger seat/occupant classification sensor control module as necessary
U0455-64	Invalid Data Received From Restraints Occupant Classification System Module - Signal plausibility failure	Occupant classification sensor control module fault	Using the manufacturer approved diagnostic system, check the occupant classification sensor control module for related DTCs and refer to the relevant DTC index
U0455-92	Invalid Data Received From Restraints Occupant Classification System Module - Performance or incorrect operation	Occupant classification sensor control module fault	Using the manufacturer approved diagnostic system, check the occupant classification sensor control module for related DTCs and refer to the relevant DTC index
U0455-93	Invalid Data Received From Restraints Occupant Classification System Module - No operation	Occupant classification sensor control module fault	Using the manufacturer approved diagnostic system, check the occupant classification sensor control module for related DTCs and refer to the relevant DTC index
U0455-	Invalid Data Received	Occupant	Using the manufacturer

95	From Restraints Occupant Classification System Module - Incorrect assembly	classification sensor control module fault	approved diagnostic system, check the occupant classification sensor control module for related DTCs and refer to the relevant DTC index
U1A14-46	CAN Initialisation Failure - Calibration/parameter memory failure	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software, clear the DTCs and retest. If the fault persists, check and install a new restraints control module as required
U2008-54	Sensor Cluster - Missing calibration	Restraints control module acceleration sensors not calibrated correctly	- Using the manufacturer approved diagnostic system, perform routine - calibrate acceleration sensor(s) (0x300F). Clear DTC and retest - Reconfigure the restraints control module using the manufacturer approved diagnostic system. Clear DTC and retest
U2008-92	Sensor Cluster - Performance or incorrect operation	Restraints control module acceleration sensors calibration routine failure	- Ensure that the restraints control module/vehicle is flat and level. Using the manufacturer approved diagnostic system, perform routine - calibrate acceleration sensor(s) (0x300F). Clear DTC and retest - Reconfigure the restraints control module using the manufacturer approved diagnostic system. Clear DTC and retest
U2016-51	Control Module Main Software - Not programmed	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the

			restraints control module with the latest level software
U2016-95	Control Module Main Software - Incorrect assembly	Restraints control module is not configured correctly	- Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software - Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTCs and retest
U201A-51	Control Module Main Calibration Data - Not programmed	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
U201A-57	Control Module Main Calibration Data - Invalid/incomplete software component	- Car configuration file mismatch with vehicle specification - Model year - Vehicle type	Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTCs and retest
U2023-51	Control Module Network Signal Calibration Data - Not programmed	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
U2100-00	Initial Configuration Not Complete - No sub type information	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
U2100-56	Initial Configuration Not Complete -	Restraints control module is not	Using the manufacturer approved diagnostic

	Invalid/incomplete configuration	configured correctly	system, reconfigure the restraints control module with the latest level software
U2101-00	Control Module Configuration Incompatible - No sub type information	▪ Restraints control module is not configured correctly ▪ Car configuration file mismatch with vehicle specification	▪ Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software ▪ Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTCs and retest
U2101-95	Control Module Configuration Incompatible - Incorrect assembly	▪ Car configuration file mismatch with vehicle specification	▪ Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTCs and retest
U2200-00	Control Module Configuration Memory Corrupt - No sub type information	▪ Restraints control module internal failure	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new restraints control module
U2300-54	Central Configuration - Missing calibration		▪ Using the manufacturer approved diagnostic system, check and update the Car Configuration File (CCF) as required. Clear the DTCs and retest

		NOTE: This DTC will log with the ignition set to on or with the engine running, if after 25 seconds no car configuration file information, regarding the restraints control module, has been learnt ▪ Car configuration file not received	
U3000-00	Control Module - No sub type information	▪ Restraints control module failure	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new restraints control module
U3000-46	Control Module - Calibration/parameter memory failure	▪ Restraints control module is not configured correctly	▪ Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
U3000-49	Control Module - Internal electronic failure	▪ Restraints control module failure	▪ Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new restraints control module
U3002-51	Vehicle Identification Number - Not programmed	▪ Incorrect VIN stored in the restraints control module ▪ Restraints control module not	▪ Using the manufacturer approved diagnostic system, perform routine - Learn VIN (0x0404). Clear DTC and retest

		programmed correctly	Reconfigure the restraints control module using the manufacturer approved diagnostic system. Clear DTC and retest
U3002-95	Vehicle Identification Number - Incorrect assembly	Restraints control module is not configured correctly	Using the manufacturer approved diagnostic system, reconfigure the restraints control module with the latest level software
U3003-16	Battery Voltage - Circuit voltage below threshold	- Restraints control module power or ground circuit open circuit, high resistance - Battery/charging system fault	- Using the manufacturer approved diagnostic system, check datalogger signal - Main ECU Supply Voltage (0xDD02). Refer to the electrical circuit diagrams and check the restraints control module power and ground circuits for open circuit, high resistance - Refer to the relevant section of the workshop manual and test the battery and charging system
U3003-17	Battery Voltage - Circuit voltage above threshold	Battery/charging system fault	Using the manufacturer approved diagnostic system, check datalogger signal - Main ECU Supply Voltage (0xDD02). Refer to the relevant section of the workshop manual and test the battery and charging system
U3003-1F	Battery Voltage - Circuit intermittent	RCM initialization not completed 15 seconds after power-up (Airbag warning indicator will always be ON in this case) due to voltage transients on restraints control	Using the manufacturer approved diagnostic system, check datalogger signal - Main ECU Supply Voltage (0xDD02). Refer to the electrical circuit diagrams and check the restraints control module power and ground

		module power or ground circuit	circuits for sources of interference i.e. from unapproved accessories
--	--	-----------------------------------	---