

2016.0 RANGE ROVER (LG), 100-00

# GENERAL INFORMATION

DESCRIPTION AND OPERATION

---

---

## TAILGATE CONTROL MODULE (RGTM/RGTMB) - UPPER/LOWER

### CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable.  
Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.

## NOTES:

- If a control module or a component is suspect and the vehicle remains under manufacturer warranty, refer to the Warranty Policy and Procedures manual, or determine if any prior approval programme is in operation, prior to the installation of a new module/component.
- Generic scan tools may not read the codes listed, or may read only 5-digit codes. Match the 5 digits from the scan tool to the first 5 digits of the 7-digit code listed to identify the fault (the last 2 digits give extra information read by the manufacturer-approved diagnostic system).
- When performing voltage or resistance tests, always use a digital multimeter accurate to three decimal places, and with an up-to-date calibration certificate. When testing resistance always take the resistance of the digital multimeter leads into account.
- Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.
- Inspect connectors for signs of water ingress, and pins for damage and/or corrosion.
- If DTCs are recorded and, after performing the pinpoint tests, a fault is not present, an intermittent concern may be the cause. Always check for loose connections and corroded terminals.
- Check DDW for open campaigns. Refer to the corresponding bulletins and SSMs which may be valid for the specific customer complaint and carry out the recommendations as required.

The table below lists all Diagnostic Trouble Codes (DTCs) that could be logged in the Tailgate Control Module (RGTM/RGTMB) - Upper/Lower. For additional diagnosis and testing information, refer to the relevant Diagnosis and Testing section in the workshop manual.

For additional information, refer to: [Locks, Latches and Entry Systems](#) (501-

## 14 Handles, Locks, Latches and Entry Systems, Diagnosis and Testing).

| DTC      | DESCRIPTION                                                     | POSSIBLE CAUSES                                                                                                                                                                                                          | ACTION                                                                                                                                                                                                                                                                                                                                               |
|----------|-----------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B1161-15 | Left Rear Anti-Pinch Sensor - Circuit short to battery or open  | <ul style="list-style-type: none"> <li>Upper/lower tailgate left anti-trap sensor circuit short circuit to power, open circuit, high resistance</li> </ul>                                                               | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the upper/lower tailgate left anti-trap sensor circuit for short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                |
| B1162-15 | Right Rear Anti-Pinch Sensor - Circuit short to battery or open | <ul style="list-style-type: none"> <li>Upper/lower tailgate right anti-trap sensor circuit short circuit to power, open circuit, high resistance</li> </ul>                                                              | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the upper/lower tailgate right anti-trap sensor circuit for short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                               |
| B1185-15 | Trunk Anti-Pinch Sensor - Circuit short to battery or open      | <ul style="list-style-type: none"> <li>Upper/lower tailgate centre anti-trap sensor circuit short circuit to power, open circuit, high resistance</li> </ul>                                                             | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the upper/lower tailgate centre anti-trap sensor circuit for short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                              |
| B11C4-23 | Boot/Trunk Close Button - Signal stuck low                      | <ul style="list-style-type: none"> <li>Tailgate global close switch stuck active</li> <li>Tailgate global close switch circuit short circuit to ground</li> </ul>                                                        | <ul style="list-style-type: none"> <li>Test the operation of the tailgate global close switch</li> <li>Refer to the electrical circuit diagrams and check the tailgate global close switch circuit for short circuit to ground</li> </ul>                                                                                                            |
| B1316-02 | Boot/Trunk Latch Power Close Unit - General signal failure      | <ul style="list-style-type: none"> <li>Upper tailgate soft close blocked by foreign object</li> <li>Upper tailgate soft close actuator home position switch circuit short circuit to ground, short circuit to</li> </ul> | <ul style="list-style-type: none"> <li>Remove foreign object</li> <li>Refer to the electrical circuit diagrams and check the upper tailgate soft close actuator home position switch circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Install a new upper tailgate soft close actuator</li> </ul> |

|          |                                                      |                                                                                                                                                                                                                                                                                                                                                                                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
|----------|------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|          |                                                      | <p>power, open circuit, high resistance</p> <ul style="list-style-type: none"> <li>Upper tailgate soft close actuator internal failure</li> </ul>                                                                                                                                                                                                                                                |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| B1316-93 | Boot/Trunk Latch Power Close Unit - No operation     | <ul style="list-style-type: none"> <li>Upper tailgate soft close actuator circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Upper tailgate soft close actuator home position switch circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Upper tailgate soft close actuator internal failure</li> </ul> | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the upper tailgate soft close actuator circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Refer to the electrical circuit diagrams and check the upper tailgate soft close actuator home position switch circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Install a new upper tailgate soft close actuator</li> </ul> |
| B1446-02 | Left Latch Power Close Unit - General signal failure | <ul style="list-style-type: none"> <li>Lower tailgate left soft close blocked by foreign object</li> <li>Lower tailgate left soft close actuator home position switch circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Lower tailgate left soft close actuator internal failure</li> </ul>                                                        | <ul style="list-style-type: none"> <li>Remove foreign object</li> <li>Refer to the electrical circuit diagrams and check the lower tailgate left soft close actuator home position switch circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Install a new lower tailgate left soft close actuator</li> </ul>                                                                                                                                                      |

|          |                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|----------|-------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| B1446-93 | Left Latch Power Close Unit - No operation            | <ul style="list-style-type: none"> <li>Lower tailgate left soft close actuator circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Lower tailgate left soft close actuator home position switch circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Lower tailgate left soft close actuator internal failure</li> </ul> | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the lower tailgate left soft close actuator circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Refer to the electrical circuit diagrams and check the lower tailgate left soft close actuator home position switch circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Install a new lower tailgate left soft close actuator</li> </ul> |
| B1447-02 | Right Latch Power Close Unit - General signal failure | <ul style="list-style-type: none"> <li>Lower tailgate right soft close blocked by foreign object</li> <li>Lower tailgate right soft close actuator home position switch circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Lower tailgate right soft close actuator internal failure</li> </ul>                                                                    | <ul style="list-style-type: none"> <li>Remove foreign object</li> <li>Refer to the electrical circuit diagrams and check the lower tailgate right soft close actuator home position switch circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Install a new lower tailgate right soft close actuator</li> </ul>                                                                                                                                                                   |
| B1447-93 | Right Latch Power Close Unit - No operation           | <ul style="list-style-type: none"> <li>Lower tailgate right soft close actuator circuit short circuit to ground, short circuit to power,</li> </ul>                                                                                                                                                                                                                                                             | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the lower tailgate right soft close actuator circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                                                                       |

|          |                                                                      |                                                                                                                                                                                                                                                                                                                |                                                                                                                                                                                                                                                                                                                                   |
|----------|----------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|          |                                                                      | <p>open circuit, high resistance</p> <ul style="list-style-type: none"> <li>Lower tailgate right soft close actuator home position switch circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Lower tailgate right soft close actuator internal failure</li> </ul> | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the lower tailgate right soft close actuator home position switch circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Install a new lower tailgate right soft close actuator</li> </ul> |
| B144B-11 | Anti-Pinch Hardwired Signal Input - Circuit short to ground          | <ul style="list-style-type: none"> <li>Anti-trap signal in circuit short circuit to ground</li> </ul>                                                                                                                                                                                                          | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the anti-trap signal in circuit for short circuit to ground</li> </ul>                                                                                                                                                                  |
| B144B-15 | Anti-Pinch Hardwired Signal Input - Circuit short to battery or open | <ul style="list-style-type: none"> <li>Anti-trap signal in circuit short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                                            | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the anti-trap signal in circuit for short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                    |
| B145F-02 | Left Latch - Combined Pawl/Claw Switch - General signal failure      | <ul style="list-style-type: none"> <li>Lower tailgate left latch soft close initiation switch circuit short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                         | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the lower tailgate left latch soft close initiation switch circuit for short circuit to power, open circuit, high resistance</li> </ul>                                                                                                 |
| B145F-11 | Left Latch - Combined Pawl/Claw Switch - Circuit short to ground     | <ul style="list-style-type: none"> <li>Lower tailgate left latch soft close initiation switch circuit short circuit to ground</li> </ul>                                                                                                                                                                       | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the lower tailgate left latch soft close initiation switch circuit for short circuit to ground</li> </ul>                                                                                                                               |
| B1460-02 | Left Latch - Claw Switch - General signal                            | <ul style="list-style-type: none"> <li>Lower tailgate left ajar switch circuit short</li> </ul>                                                                                                                                                                                                                | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the lower tailgate left ajar switch circuit for</li> </ul>                                                                                                                                                                              |

|          |                                                                   |                                                                                                                                                                           |                                                                                                                                                                                                                                      |
|----------|-------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|          | failure                                                           | circuit to ground, short circuit to power, open circuit, high resistance                                                                                                  | short circuit to ground, short circuit to power, open circuit, high resistance                                                                                                                                                       |
| B1461-02 | Right Latch - Combined Pawl/Claw Switch - General signal failure  | <ul style="list-style-type: none"> <li>Lower tailgate right latch soft close initiation switch circuit short circuit to power, open circuit, high resistance</li> </ul>   | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the lower tailgate right latch soft close initiation switch circuit for short circuit to power, open circuit, high resistance</li> </ul>   |
| B1461-11 | Right Latch - Combined Pawl/Claw Switch - Circuit short to ground | <ul style="list-style-type: none"> <li>Lower tailgate right latch soft close initiation switch circuit short circuit to ground</li> </ul>                                 | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the lower tailgate right latch soft close initiation switch circuit for short circuit to ground</li> </ul>                                 |
| B1462-02 | Right Latch - Claw Switch - General signal failure                | <ul style="list-style-type: none"> <li>Lower tailgate right ajar switch circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> </ul> | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the lower tailgate right ajar switch circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> </ul> |
| B1463-02 | Upper Latch - Combined Pawl/Claw Switch - General signal failure  | <ul style="list-style-type: none"> <li>Upper tailgate latch soft close initiation switch circuit short circuit to power, open circuit, high resistance</li> </ul>         | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the upper tailgate latch soft close initiation switch circuit for short circuit to power, open circuit, high resistance</li> </ul>         |
| B1463-11 | Upper Latch - Combined Pawl/Claw Switch - Circuit short to ground | <ul style="list-style-type: none"> <li>Upper tailgate latch soft close initiation switch circuit short circuit to ground</li> </ul>                                       | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the upper tailgate latch soft close initiation switch circuit for short circuit to ground</li> </ul>                                       |
| B1464-02 | Upper Latch - Claw Switch - General signal                        | <ul style="list-style-type: none"> <li>Upper tailgate ajar switch circuit short circuit to</li> </ul>                                                                     | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the upper tailgate ajar switch circuit for short</li> </ul>                                                                                |

|          |                                                      |                                                                                                                                                                                                                              |                                                                                                                                                                                                                                                                                                                                                     |
|----------|------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|          | failure                                              | ground, short circuit to power, open circuit, high resistance                                                                                                                                                                | circuit to ground, short circuit to power, open circuit, high resistance                                                                                                                                                                                                                                                                            |
| C2005-11 | Right Actuator<br>- Circuit short to ground          | <ul style="list-style-type: none"> <li>▪ Upper/lower tailgate right actuator circuit short circuit to ground</li> <li>▪ Upper/lower tailgate right actuator position sensor power circuit short circuit to ground</li> </ul> | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the upper/lower tailgate right actuator circuit for short circuit to ground</li> <li>▪ Refer to the electrical circuit diagrams and check the upper/lower tailgate right actuator position sensor supply circuit for short circuit to ground</li> </ul> |
| C2005-12 | Right Actuator<br>- Circuit short to battery         | <ul style="list-style-type: none"> <li>▪ Upper/lower tailgate right actuator circuit short circuit to power</li> </ul>                                                                                                       | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the upper/lower tailgate right actuator circuit for short circuit to power</li> </ul>                                                                                                                                                                   |
| C2005-13 | Right Actuator<br>- Circuit open                     | <ul style="list-style-type: none"> <li>▪ Upper/lower tailgate right actuator circuit open circuit, high resistance</li> </ul>                                                                                                | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the upper/lower tailgate right actuator circuit for open circuit, high resistance</li> </ul>                                                                                                                                                            |
| C2005-15 | Right Actuator<br>- Circuit short to battery or open | <ul style="list-style-type: none"> <li>▪ Upper/lower tailgate right actuator position sensor power circuit short circuit to power, open circuit, high resistance</li> </ul>                                                  | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the upper/lower tailgate right actuator position sensor supply circuit for short circuit to power, open circuit, high resistance</li> </ul>                                                                                                             |
| C2005-19 | Right Actuator<br>- Circuit current above threshold  | <ul style="list-style-type: none"> <li>▪ Upper/lower tailgate right actuator circuit short circuit to ground, short circuit to power</li> </ul>                                                                              | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the upper/lower tailgate right actuator circuit for short circuit to ground, short circuit to power</li> </ul>                                                                                                                                          |
| C2005-31 | Right Actuator<br>- No signal                        | <ul style="list-style-type: none"> <li>▪ Upper/lower tailgate right</li> </ul>                                                                                                                                               | <ul style="list-style-type: none"> <li>▪ Refer to the electrical circuit diagrams and check the</li> </ul>                                                                                                                                                                                                                                          |

|          |                                          |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                       |
|----------|------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|          |                                          | <p>actuator position sensor signal 1 circuit short circuit to ground, short circuit to power, open circuit, high resistance</p> <ul style="list-style-type: none"> <li>Upper/lower tailgate right actuator position sensor signal 2 circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Upper/lower tailgate right actuator position sensor ground circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> </ul> | <p>upper/lower tailgate right actuator position sensor signal 1 circuit for short circuit to ground, short circuit to power, open circuit, high resistance</p> <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the upper/lower tailgate right actuator position sensor signal 2 circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Refer to the electrical circuit diagrams and check the upper/lower tailgate right actuator position sensor ground circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> </ul> |
| C2006-11 | Left Actuator - Circuit short to ground  | <ul style="list-style-type: none"> <li>Upper/lower tailgate left actuator circuit short circuit to ground</li> <li>Upper/lower tailgate left actuator position sensor power circuit short circuit to ground</li> </ul>                                                                                                                                                                                                                                                                           | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the upper/lower tailgate left actuator circuit for short circuit to ground</li> <li>Refer to the electrical circuit diagrams and check the upper/lower tailgate left actuator position sensor supply circuit for short circuit to ground</li> </ul>                                                                                                                                                                                                                                                                                                         |
| C2006-12 | Left Actuator - Circuit short to battery | <ul style="list-style-type: none"> <li>Upper/lower tailgate left actuator circuit short circuit to power</li> </ul>                                                                                                                                                                                                                                                                                                                                                                              | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the upper/lower tailgate left actuator circuit for short circuit to power</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| C2006-13 | Left Actuator - Circuit open             | <ul style="list-style-type: none"> <li>Upper/lower tailgate left</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                      | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                              |

|          |                                                  |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                            |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|----------|--------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|          |                                                  | actuator circuit open circuit, high resistance                                                                                                                                                                                                                                                                                                                                                                                                                                                                             | upper/lower tailgate left actuator circuit for open circuit, high resistance                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                |
| C2006-15 | Left Actuator - Circuit short to battery or open | <ul style="list-style-type: none"> <li>Upper/lower tailgate left actuator position sensor power circuit short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                                                                                                                                   | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the upper/lower tailgate left actuator position sensor supply circuit for short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                        |
| C2006-19 | Left Actuator - Circuit current above threshold  | <ul style="list-style-type: none"> <li>Upper/lower tailgate left actuator circuit short circuit to ground, short circuit to power</li> </ul>                                                                                                                                                                                                                                                                                                                                                                               | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the upper/lower tailgate left actuator circuit for short circuit to ground, short circuit to power</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     |
| C2006-31 | Left Actuator - No signal                        | <ul style="list-style-type: none"> <li>Upper/lower tailgate left actuator position sensor signal 1 circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Upper/lower tailgate left actuator position sensor signal 2 circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Upper/lower tailgate left actuator position sensor ground circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> </ul> | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the upper/lower tailgate left actuator position sensor signal 1 circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Refer to the electrical circuit diagrams and check the upper/lower tailgate left actuator position sensor signal 2 circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Refer to the electrical circuit diagrams and check the upper/lower tailgate left actuator position sensor ground circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> </ul> |

|          |                                                                            |                                                                                                                                                                                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
|----------|----------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| U0010-88 | Medium Speed CAN Communication Bus - Bus off                               | <ul style="list-style-type: none"> <li>Medium speed CAN bus (body) circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                                                  | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the medium speed CAN bus (body) circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> </ul>                                                                                                                                                                                                                                                                                                                                                    |
| U0140-00 | Lost Communication With Body Control Module - No sub type information      | <ul style="list-style-type: none"> <li>Body control module / gateway module assembly power or ground circuit open circuit, high resistance</li> <li>Medium speed CAN bus (body) circuit short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Body control module / gateway module assembly system fault</li> </ul> | <ul style="list-style-type: none"> <li>Refer to the electrical circuit diagrams and check the body control module / gateway module assembly power and ground circuits for open circuit, high resistance</li> <li>Using the manufacturer approved diagnostic system, perform a CAN network integrity test. Refer to the electrical circuit diagrams and check the medium speed CAN bus (body) circuit for short circuit to ground, short circuit to power, open circuit, high resistance</li> <li>Using the manufacturer approved diagnostic system, check the body control module / gateway module assembly for related DTCs and refer to the relevant DTC index</li> </ul> |
| U0300-00 | Internal Control Module Software Incompatibility - No sub type information | <ul style="list-style-type: none"> <li>Car configuration file mismatch with vehicle specification</li> <li>Incorrect upper/lower tailgate control module installed</li> </ul>                                                                                                                                                                         | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, check and update the car configuration file as necessary</li> <li>Install a new upper/lower tailgate control module as necessary</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                       |
| U0401-68 | Invalid Data Received From ECM/PCM A - Event information                   | <ul style="list-style-type: none"> <li>Missing/invalid data from the engine control module <ul style="list-style-type: none"> <li>Ambient temperature</li> </ul> </li> </ul>                                                                                                                                                                          | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, check the engine control module for related DTCs and refer to the relevant DTC index</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |

|          |                                                                                              |                                                                                                                                                                                        |                                                                                                                                                                                                           |
|----------|----------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| U0415-68 | Invalid Data Received From Anti-Lock Braking System (ABS) Control Module - Event information | <ul style="list-style-type: none"> <li>Missing/invalid data from the anti-lock brake system control module <ul style="list-style-type: none"> <li>Vehicle speed</li> </ul> </li> </ul> | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, check the anti-lock brake system control module for related DTCs and refer to the relevant DTC index</li> </ul> |
| U201A-51 | Control Module Main Calibration Data - Not programmed                                        | <ul style="list-style-type: none"> <li>Upper/lower tailgate control module is not configured correctly</li> </ul>                                                                      | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, re-configure the upper/lower tailgate control module with the latest level software</li> </ul>                  |
| U201A-52 | Control Module Main Calibration Data - Not activated                                         | <ul style="list-style-type: none"> <li>Upper/lower tailgate control module is not configured correctly</li> </ul>                                                                      | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, re-configure the upper/lower tailgate control module with the latest level software</li> </ul>                  |
| U2100-00 | Initial Configuration Not Complete - No sub type information                                 | <ul style="list-style-type: none"> <li>Upper/lower tailgate control module is not configured correctly</li> </ul>                                                                      | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, re-configure the upper/lower tailgate control module with the latest level software</li> </ul>                  |
| U2101-00 | Control Module Configuration Incompatible - No sub type information                          | <ul style="list-style-type: none"> <li>Car configuration file mismatch with vehicle specification</li> </ul>                                                                           | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, check and update the car configuration file as necessary</li> </ul>                                             |
| U3000-44 | Control Module - Data memory failure                                                         | <ul style="list-style-type: none"> <li>Upper/lower tailgate control module internal failure <ul style="list-style-type: none"> <li>RAM memory failure</li> </ul> </li> </ul>           | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new upper/lower tailgate control module</li> </ul>  |
| U3000-45 | Control Module - Programme memory failure                                                    | <ul style="list-style-type: none"> <li>Upper/lower tailgate control module internal failure <ul style="list-style-type: none"> <li>ROM memory failure</li> </ul> </li> </ul>           | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new upper/lower tailgate control module</li> </ul>  |

|          |                                                         |                                                                                                                                                                                       |                                                                                                                                                                                                                                                                                                                                                                                                                                        |
|----------|---------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| U3000-46 | Control Module - Calibration / parameter memory failure | <ul style="list-style-type: none"> <li>Upper/lower tailgate control module internal failure <ul style="list-style-type: none"> <li>Non volatile memory failure</li> </ul> </li> </ul> | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new upper/lower tailgate control module</li> </ul>                                                                                                                                                                                                                               |
| U3000-49 | Control Module - Internal electronic failure            | <ul style="list-style-type: none"> <li>Upper/lower tailgate control module internal failure <ul style="list-style-type: none"> <li>Tailgate actuator drive</li> </ul> </li> </ul>     | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, clear the DTCs and retest. If the fault persists, install a new upper/lower tailgate control module</li> </ul>                                                                                                                                                                                                                               |
| U3000-4B | Control Module - Over temperature                       | <ul style="list-style-type: none"> <li>Ambient temperature signal of greater than 80°C received from the engine control module</li> </ul>                                             | <p><b>NOTE:</b></p> <div style="border: 1px solid black; padding: 10px; margin: 10px 0;"> <p>The tailgate control module will inhibit power tailgate operation when the ambient temperature exceeds 80°C to protect the actuators</p> </div> <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, check the engine control module for related DTCs and refer to the relevant DTC index</li> </ul> |
| U3003-62 | Battery Voltage - Signal compare failure                | <ul style="list-style-type: none"> <li>Mismatch between the voltage at the upper/lower tailgate control module and the voltage value broadcast on the CAN bus</li> </ul>              | <ul style="list-style-type: none"> <li>Using the manufacturer approved diagnostic system, check datalogger signal - Main ECU Supply Voltage (0xDD02). Refer to the electrical circuit diagrams and check the upper/lower tailgate control module power and ground circuits for open circuit, high resistance</li> </ul>                                                                                                                |