

PUBLISHED: 11-DEC-2013
2014.0 RANGE ROVER (LG), 303-14

ELECTRONIC ENGINE CONTROLS - V8 S/C 5.0L PETROL

BRAKE PEDAL POSITION SWITCH ADJUSTMENT

(G1395342)

CHECK

1. Remove the brake pedal rubber.

2.

 NOTE:

Make sure that the dial test indicator (DTI) gauge is in line with the brake pedal movement.



Position the DTI gauge on a suitable mounting block, as illustrated.

3. With the aid of another technician, gently press the brake pedal until the stop lamps illuminate.

4.

 NOTE:

The specification is that the stop lamps should illuminate at between 5.5 mm and 8.5mm brake pedal travel.

Note the measurement of the brake pedal travel from rest position until the stop lamps illuminated.

ADJUST

NOTE:

The Brake Pedal Position Switch is self adjusting when removed and installed.

1. Remove and install Brake Pedal Position Switch.
For additional information, refer to: Stoplamp Switch (417-01 Exterior Lighting, Removal and Installation).
2. Check the adjustment of the stop lamp switch by following the **Check** procedure in this procedure and carry out the **Adjust** procedure if required.