

2016.0 RANGE ROVER (LG), 303-01

ENGINE – TDV6 3.0L DIESEL – GEN 2/TDV6 3.0L DIESEL

DIAGNOSIS AND TESTING

PRINCIPLES OF OPERATION

For a detailed description of the engine system and operation, refer to the relevant Description and Operation section in the workshop manual. REFER to: (303-01A Engine - TDV6 3.0L Diesel - Gen 2/TDV6 3.0L Diesel)

[Engine](#) (Description and Operation),

[Engine](#) (Description and Operation),

[Engine](#) (Description and Operation).

INSPECTION AND VERIFICATION

CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault and may also cause additional faults in the vehicle being checked and/or the donor vehicle.

NOTE:

Check and rectify basic faults before beginning diagnostic routines involving pinpoint tests.

For additional information, refer to Diagnosis and Testing, Engine - 3.0L.
REFER to: Engine - TDV6 3.0L Diesel (303-00, Diagnosis and Testing).

1. Verify the customer concern.
2. Visually inspect for obvious signs of mechanical damage.

Visual Inspection

MECHANICAL

- Engine oil level
- Engine (turns freely)
- Coolant level
- Transmission fluid level
- Fuel level
- Coolant leaks
- Oil leaks
- Fuel leaks
- Visibly damaged or worn parts
- Loose or missing nuts or bolts
- Fuel contamination/grade/quality
- Sensor installation/condition

3. If an obvious cause for an observed or reported condition is found, correct the cause (if possible) before proceeding to the symptom chart.
4. If the cause is not visually evident, verify the symptom and refer to the Symptom Chart, alternatively check for Diagnostic Trouble Codes

(DTCs) and refer to the DTC Index.

D T C I N D E X

For a list of Diagnostic Trouble Codes (DTCs) that could be logged on this vehicle, please refer to Section 100-00.

REFER to: Diagnostic Trouble Code (DTC) Index - TDV6 3.0L Diesel, DTC: Engine Control Module (100-00 General Information, Description and Operation).