

PUBLISHED: 27-FEB-2013

2014.0 RANGE ROVER (LG), 303-08

ENGINE EMISSION CONTROL - V8 S/C 5.0L PETROL

PRINCIPLES OF OPERATION

For a detailed description of the engine emission system and operation, refer to the relevant Description and Operation section of the Workshop Manual.

REFER to: Engine Emission Control (303-08 Engine Emission Control - V8 S/C 5.0L Petrol, Description and Operation).

INSPECTION AND VERIFICATION



CAUTION:

Diagnosis by substitution from a donor vehicle is NOT acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle.

1. Verify the customer concern.

1. Visually inspect for obvious signs of mechanical or electrical damage.

Visual Inspection

MECHANICAL	ELECTRICAL
▪ Engine breather hoses ▪ Oil separator	▪ Fuse(s) ▪ Wiring harness ▪ Loose or corroded electrical connector(s) ▪ Intake manifold tuning (IMT) valve ▪ Engine control module (ECM)

1. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step.

1. If the cause is not visually evident, verify the symptom and refer to the Symptom Chart, alternatively check for Diagnostic Trouble Codes (DTCs) and refer to the DTC Index.

SYMPTOM CHART

SYMPTOM	POSSIBLE CAUSES	ACTION
Engine stops /stalls	■ Breather system disconnected /restricted/blocked	Check the engine breather system. Check the oil separator. Check for DTCs indicating a throttle or sensor fault. Rectify as necessary.
Excessive fuel consumption	■ Breather system restricted/blocked	
Excessive black smoke		
Excessive emissions		
Excessive blow-by	■ Breather system restricted/blocked	Check the engine breather hoses. Check the oil separator. Rectify as necessary.
Engine oil leaks	■ Breather system restricted/blocked	Check the engine breather hoses. Check the oil separator. Rectify as necessary.

DTC INDEX

For a list of Diagnostic Trouble Codes (DTCs) that could be logged on this vehicle, please refer to Section 100-00. REFER to: Diagnostic Trouble Code (DTC) Index - V8 S /C 5.0L Petrol, DTC: Engine Control Module (ECM) (100-00 General Information, Description and Operation).