

PUBLISHED: 31-JUL-2012

2015.0 RANGE ROVER (LG), 310-03

SPEED CONTROL - TDV8 4.4L DIESEL

DIAGNOSIS AND TESTING

PRINCIPLES OF OPERATION

For a detailed description of the speed control system, refer to the relevant description and operation sections in the workshop manual.

REFER to: [Speed Control](#) (310-03D Speed Control - TDV8 4.4L Diesel, Description and Operation).

INSPECTION AND VERIFICATION



CAUTION:

Diagnosis by substitution from a donor vehicle is **NOT** acceptable. Substitution of control modules does not guarantee confirmation of a fault, and may also cause additional faults in the vehicle being tested and/or the donor vehicle

1. Verify the customer concern

1. Visually inspect for obvious signs of damage and system integrity

Visual Inspection

MECHANICAL	ELECTRICAL
▪ Ensure the speed control sensor is free from obstructions ▪ Adaptive speed control module ▪ Brake switch ▪ Visibly damaged or worn components	▪ Fuse(s) ▪ Damage to wiring loom, incorrect location of wiring, wiring stretched or taught ▪ Loose or corroded electrical connector(s) ▪ Steering wheel switches ▪ Brake switch ▪ Adaptive speed control module ▪ Engine control module

1. If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step

1. If the cause is not visually evident, verify the symptom and refer to the symptom chart, alternatively, check for DTCs and refer to the DTCs index

SPEED CONTROL SENSOR ADJUSTMENT (VEHICLES WITH ADAPTIVE SYSTEM INSTALLED)

An incorrectly aligned speed control sensor can cause incorrect system operation. Before starting any repair work on the speed control system, on vehicles with the adaptive system installed, check speed control sensor for correct vertical alignment, and carry out speed control sensor alignment procedure using manufacturer approved diagnostic system

SYMPTOM CHART

SYMPTOM	POSSIBLE CAUSE	ACTION
Speed control inhibited or disabled	■ Power or ground supply to adaptive speed control module ■ Steering wheel speed control switch/circuits ■ Throttle sensors ■ Brake switch ■ ABS fault ■ Speed control sensor obstructed	■ Check for DTCs that could be caused by power or ground failure to the module and refer to DTC index ■ Check for sticking, jammed and broken speed control switches. Refer to the electrical circuit diagrams and check speed control switch circuits for short circuit, open circuit, high resistance ■ Check for engine throttle position sensor DTCs and refer to the relevant DTC index. For throttle position sensor tests REFER to: Electronic Engine Controls - 4.4L V8 - TdV8 (303-14E Electronic Engine Controls - TDV8 4.4L Diesel, Diagnosis and Testing). ■ Check for correct installation and adjustment of brake switch. Refer to the electrical circuit diagrams and check brake switch circuits for short circuit, open circuit, high resistance ■ Check ABS system for related DTCs and refer to the relevant DTC index ■ Make sure there is no snow, ice or other obstruction on the fascia in front of the speed control radar. Adaptive cruise control will not engage until the radar has detected valid target(s)
Unable to regulate /adjust vehicle speed	■ Steering wheel switch malfunction	■ Check for sticking, jammed and broken speed control switches. Refer to the electrical circuit diagrams and check speed control switch circuits for short circuit, open circuit, high resistance
Unable to cancel speed control from steering wheel	■ Steering wheel switch malfunction	■ Check for sticking, jammed and broken speed control switches. Refer to the electrical circuit diagrams and check speed control switch circuits for short circuit, open circuit, high resistance

Unable to cancel speed control from brake pedal	▪ Brake switch malfunction	▪ Check for correct installation and adjustment of brake switch. Refer to the electrical circuit diagrams and check brake switch circuits for short, open circuit, high resistance
---	--	--

For a list of DTCs that could be logged on this vehicle, please refer to Section 100-00.
REFER to:

[Diagnostic Trouble Code Index - DTC: Adaptive Speed Control Module](#) (100-00 General Information, Description and Operation),
Diagnostic Trouble Code (DTC) Index - TDV8 4.4L Diesel, DTC: Module Name: Engine Control Module (100-00, Description and Operation).