Mellanox Switch Management Interface Setup

Terminal software:

https://www.decisivetactics.com/products/serial/

Bottom switch:

switch-ca3a08 [standalone: master] > show interfaces

Interface **Io** status:

Comment:

Admin up: yes Link up: yes **DHCP running:** no IP address: 127.0.0.1 Netmask: 255.0.0.0 IPv6 enabled: yes Autoconf enabled: yes Autoconf route: yes Autoconf privacy: no DHCPv6 running: no

IPv6 address: ::1/128

IPv6 addresses: 1

Speed: N/A
Duplex: N/A

Interface type: loopback Interface source: loopback

MTU: 16436 HW address: N/A

Rx:

0 bytes 0 packets

0 mcast packets

0 discards
0 errors
0 overruns
0 frame

Tx:

0 bytes 0 packets 0 discards
0 errors
0 overruns
0 carrier
0 collisions
0 queue len

Interface mgmt0 status:

Comment:

Admin up: yes Link up: yes

DHCP running: yes (but no valid lease)

IP address: Netmask:

IPv6 enabled: yes Autoconf enabled: no Autoconf route: yes Autoconf privacy: no

DHCPv6 running: yes (but no valid lease)

IPv6 addresses: 1

IPv6 address: fe80::ee0d:9aff:feca:3a08/64

Speed: 1000Mb/s (auto)

Duplex: full (auto)
Interface type: ethernet
Interface source: bridge
MTU: 1500

HW address: EC:0D:9A:CA:3A:08

enable

configure terminal configuration jump-start

Top switch (had to reboot):

switch-cedfe2 login:

CHANGED admin password on both - save to Last Pass

VPN did not work - add to access list

switch-cedfe2 [standalone: master] > enable

switch-cedfe2 [standalone: master] # configure terminal

switch-cedfe2 [standalone: master] (config) # configuration jump-start

Configuration wizard

Step 1: Hostname? [switch-cedfe2] itb-mellanox-2

Step 2: Use DHCP on mgmt0 interface? [yes] no

Step 3: Use zeroconf on mgmt0 interface? [no]

Step 4: Primary IPv4 address and masklen? [0.0.0.0/0] 10.38.0.8

Step 5: Netmask or mask length? [255.255.255.0]

Step 6: Default gateway? 10.38.0.1

Step 7: Primary DNS server?

Step 8: Domain name? hpc.pomona.edu

Step 9: Enable IPv6? [yes] no

Step 10: Admin password (Enter to leave unchanged)?

Step 10: Confirm admin password?

You have entered the following information:

1. Hostname: itb-mellanox-2

2. Use DHCP on mgmt0 interface: no

3. Use zeroconf on mgmt0 interface: no

4. Primary IPv4 address: 10.38.0.8

5. Netmask or mask length: 255.255.255.0

6. Default gateway: 10.38.0.1

7. Primary DNS server:

8. Domain name: hpc.pomona.edu

9. Enable IPv6: no

10. Admin password (Enter to leave unchanged): (CHANGED)

To change an answer, enter the step number to return to. Otherwise hit <enter> to save changes and exit.

tb-mellanox-2 [standalone: master] (config) # show interface mgmt0 Interface mgmt0 status:

Comment:

Admin up: yes
Link up: yes
DHCP running: no
IP address: 10.38.0.8
Netmask: 255.255.255.0

IPv6 enabled: no

Speed: 1000Mb/s (auto)

Duplex: full (auto)
Interface type: ethernet
Interface source: bridge
MTU: 1500

HW address: EC:0D:9A:CE:DF:E2

Spanning Tree

en

conf t

interface ethernet 1/1

itb-mellanox-1 [standalone: master] (config interface ethernet 1/1) # spanning-tree port type network

itb-mellanox-1 [standalone: master] (config interface ethernet 1/1) # spanning-tree guard loop

itb-mellanox-1 [standalone: master] (config) # spanning-tree mode rst

itb-mellanox-1 [standalone: master] (config interface ethernet 1/1) # spanning-tree port-priority 0

itb-mellanox-1 [standalone: master] (config interface ethernet 1/1) # show spanning-tree

Switch : ethernet-default Spanning tree protocol rst : enabled

Spanning tree force version: 2

Root ID:

Priority: 32768

Address : ec:0d:9a:61:1d:c0

Bridge root : yes Hello Time (sec) : 2 Max Age (sec) : 20 Forward Delay (sec): 15

Bridge ID:

Priority: 32768

Address : ec:0d:9a:61:1d:c0

Hello Time (sec) : 2 Max Age (sec) : 20 Forward Delay (sec): 15 L: Loop Inconsistent R: Root Inconsistent

G: BPDU Guard Inconsistent

Interface	Role	Sts	Cost	Prio	Type	
Eth1/29	Designate	ed	Forwarding	500	128	normal
Eth1/31	Designate	ed	Forwarding	500	128	normal
Eth1/32	Designate	ed	Forwarding	500	128	normal

itb-mellanox-2 [standalone: master] (config) # show spanning-tree

Switch : ethernet-default Spanning tree protocol rst : enabled Spanning tree force version: 2

Root ID:

Priority: 32768

Address : ec:0d:9a:61:17:40

Bridge root : yes Hello Time (sec) : 2 Max Age (sec) : 20 Forward Delay (sec): 15

Bridge ID:

Priority: 32768

Address : ec:0d:9a:61:17:40

Hello Time (sec) : 2 Max Age (sec) : 20 Forward Delay (sec): 15

L: Loop Inconsistent R: Root Inconsistent

G: BPDU Guard Inconsistent

Interface	Role	Sts	Cost	Prio	Type

Eth1/29	Designated	Forwarding	500	128	normal
Eth1/31	Designated	Forwarding	500	128	normal
Eth1/32	Designated	Forwarding	500	128	normal

itb-mellanox-1 [standalone: master] (config interface ethernet 1/1) # show spanning-tree detail

Switch ethernet-default

Spanning tree protocol is enabled

Bridge is executing the rst compatible Spanning Tree Protocol

Bridge Identifier priority: 32768

Bridge Identifier address: ec:0d:9a:61:1d:c0

Configured hello time: 2, max age 20, forward delay 15 Current root: priority 32768, address ec:0d:9a:61:1d:c0

Number of topology changes: 0, last change occurred 00:00:00 ago

Last TCN received from: N/A

Timers: hold 6 hello 2, max age 20, forward delay 15

Default port type: normal Default bpdu filter: disabled Default bpdu guard: disabled

itb-mellanox-2 [standalone: master] (config interface ethernet 1/1) # show spanning-tree detail

Switch ethernet-default

Spanning tree protocol is enabled

Bridge is executing the rst compatible Spanning Tree Protocol

Bridge Identifier priority: 32768

Bridge Identifier address: ec:0d:9a:61:17:40

Configured hello time: 2, max age 20, forward delay 15 Current root: priority 32768, address ec:0d:9a:61:17:40

Number of topology changes: 0, last change occurred 00:00:00 ago

Last TCN received from: N/A

Timers: hold 6 hello 2, max age 20, forward delay 15

Default port type: normal Default bpdu filter: disabled Default bpdu guard: disabled

itb-mellanox-2 [standalone: master] (config) # show spanning-tree interface 1/1

% Unrecognized command "1/1".

Type "show spanning-tree interface?" for help.

itb-mellanox-2 [standalone: master] (config) # show spanning-tree interface ethernet 1/1

Interface Eth1/1

Status: Disabled Discarding

Port path cost: 500
Port priority: 128
Port Identifier: 128.1
Designated root priority: 0

Designated root address: unknown

Designated bridge priority: 0

Designated bridge address: unknown

Designated port id: 0.0 Designated path cost: 0

Number of transitions to forwarding state: 0

Port type: network
PortFast is: off
Bpdu filter: enabled
Bpdu guard: disabled
Loop guard: enabled
Root guard: enabled
Link type: point-to-point

BPDU sent: 0
BPDU received: 0

itb-mellanox-1 [standalone: master] (config interface ethernet 1/1) # show spanning-tree interface ethernet 1/1

Interface Eth1/1

Status: Disabled Discarding

Port path cost: 500 Port priority: 0 Port Identifier: 0.1

Designated root priority: 0

Designated root address: unknown

Designated bridge priority: 0

Designated bridge address: unknown

Designated port id: 0.0 Designated path cost: 0

Number of transitions to forwarding state: 0

Port type: network

PortFast is: off
Bpdu filter: enabled
Bpdu guard: disabled
Loop guard: enabled
Root guard: enabled
Link type: point-to-point

BPDU sent: 0 BPDU received: 0

itb-mellanox-2 [standalone: master] (config) # show spanning-tree root % Spanning-tree Protocol type is rst

itb-mellanox-1 [standalone: master] (config) # show spanning-tree root % Spanning-tree Protocol type is rst

itb-mellanox-1 [standalone: master] (config) # show spanning-tree topo-change-history

Interface Date Time

itb-mellanox-2 [standalone: master] (config) # show spanning-tree topo-change-history

Interface Date Time

itb-mellanox-2 [standalone: master] (config) # show mac-address-table

Vlan	Mac Address	Type	Port
1	50:6B:4B:39:5F:5F	Dynamic	Eth1/31
1	50:6B:4B:39:5F:87	Dynamic	Eth1/29
1	50:6B:4B:39:5F:DF	Dynamic	Eth1/32

Number of unicast: 3 Number of multicast: 0

itb-mellanox-1 [standalone: master] (config) # show mac-address-table

Vlan	Mac Address	Туре	Port
4		D	
1	50:6B:4B:39:5F:5E	Dynamic	Eth1/31
1	50:6B:4B:39:5F:86	Dynamic	Eth1/32
1	50:6B:4B:39:5F:DE	Dynamic	Eth1/29

Number of unicast: 3 Number of multicast: 0

itb-mellanox-1 [standalone: master] (config) # show interface switchport

Interface		Access vlan	Allowed vlans
Eth1/1			
Eth1/2	access	1	
Eth1/3	access	1	
Eth1/4	access	1	
Eth1/5	access	1	
Eth1/6	access	1	
Eth1/7	access	1	
Eth1/8	access	1	
Eth1/9	access	1	
Eth1/10	access	1	
Eth1/11	access	1	
Eth1/12	access	1	
Eth1/13	access	1	
Eth1/14	access	1	
Eth1/15	access	1	
Eth1/16	access	1	
Eth1/17	access	1	
Eth1/18	access	1	
Eth1/19	access	1	
Eth1/20	access	1	
Eth1/21	access	1	
Eth1/22	access	1	
Eth1/23	access	1	

Eth1/24	access	1
Eth1/25	access	1
Eth1/26	access	1
Eth1/27	access	1
Eth1/28	access	1
Eth1/29	access	1
Eth1/30	access	1
Eth1/31	access	1
Eth1/32	access	1

itb-mellanox-2 [standalone: master] (config) # show interface switchport

Interface Mode Access vlan Allowed vlans

Eth1/1 access 1

Eth1/2 access 1

Eth1/3 access Eth1/4 access Eth1/5 access 1 Eth1/6 1 access Eth1/7 1 access Eth1/8 access 1 Eth1/9 access 1 Eth1/10 access Eth1/11 1 access Eth1/12 access 1 Eth1/13 1 access Eth1/14 1 access Eth1/15 access 1 Eth1/16 access 1 Eth1/17 1 access Eth1/18 access 1 Eth1/19 access 1 Eth1/20 access 1 Eth1/21 1 access Eth1/22 access 1 Eth1/23 access 1 Eth1/24 1 access Eth1/25 1 access 1 Eth1/26 access

access

1

Eth1/27

Eth1/28	access	1
Eth1/29	access	1
Eth1/30	access	1
Eth1/31	access	1
Eth1/32	access	1

itb-mellanox-2 [standalone: master] (config) # show interfaces ethernet status

Port	Operational state	Speed	Negotiation
 Eth1/1	Down	 40 Gbps	 No-Negotiation
Eth1/2	Down	40 Gbps	No-Negotiation
Eth1/3	Down	40 Gbps	No-Negotiation
Eth1/4	Down	40 Gbps	No-Negotiation
Eth1/5	Down	40 Gbps	No-Negotiation
Eth1/6	Down	40 Gbps	No-Negotiation
Eth1/7	Down	40 Gbps	No-Negotiation
Eth1/8	Down	40 Gbps	No-Negotiation
Eth1/9	Down	40 Gbps	No-Negotiation
Eth1/10	Down	40 Gbps	No-Negotiation
Eth1/11	Down	40 Gbps	No-Negotiation
Eth1/12	Down	40 Gbps	No-Negotiation
Eth1/13	Down	40 Gbps	No-Negotiation
Eth1/14	Down	40 Gbps	No-Negotiation
Eth1/15	Down	40 Gbps	No-Negotiation
Eth1/16	Down	40 Gbps	No-Negotiation
Eth1/17	Down	40 Gbps	No-Negotiation
Eth1/18	Down	40 Gbps	No-Negotiation
Eth1/19	Down	40 Gbps	No-Negotiation
Eth1/20	Down	40 Gbps	No-Negotiation
Eth1/21	Down	40 Gbps	No-Negotiation
Eth1/22	Down	40 Gbps	No-Negotiation
Eth1/23	Down	40 Gbps	No-Negotiation
Eth1/24	Down	40 Gbps	No-Negotiation
Eth1/25	Down	40 Gbps	No-Negotiation
Eth1/26	Down	40 Gbps	No-Negotiation
Eth1/27	Down	40 Gbps	No-Negotiation
Eth1/28	Down	40 Gbps	No-Negotiation
Eth1/29	Up	40 Gbps	No-Negotiation
Eth1/30	Down	40 Gbps	No-Negotiation
Eth1/31	Up	40 Gbps	No-Negotiation
Eth1/32	Up	40 Gbps	No-Negotiation

itb-mellanox-1 [standalone: master] (config) # show interfaces ethernet status

Port	Operational state	Speed	Negotiation
Eth1/1	Down	40 Gbps	No-Negotiation
Eth1/2	Down	40 Gbps	No-Negotiation
Eth1/3	Down	40 Gbps	No-Negotiation
Eth1/4	Down	40 Gbps	No-Negotiation
Eth1/5	Down	40 Gbps	No-Negotiation
Eth1/6	Down	40 Gbps	No-Negotiation
Eth1/7	Down	40 Gbps	No-Negotiation
Eth1/8	Down	40 Gbps	No-Negotiation
Eth1/9	Down	40 Gbps	No-Negotiation
Eth1/10	Down	40 Gbps	No-Negotiation
Eth1/11	Down	40 Gbps	No-Negotiation
Eth1/12	Down	40 Gbps	No-Negotiation
Eth1/13	Down	40 Gbps	No-Negotiation
Eth1/14	Down	40 Gbps	No-Negotiation
Eth1/15	Down	40 Gbps	No-Negotiation
Eth1/16	Down	40 Gbps	No-Negotiation
Eth1/17	Down	40 Gbps	No-Negotiation
Eth1/18	Down	40 Gbps	No-Negotiation
Eth1/19	Down	40 Gbps	No-Negotiation
Eth1/20	Down	40 Gbps	No-Negotiation
Eth1/21	Down	40 Gbps	No-Negotiation
Eth1/22	Down	40 Gbps	No-Negotiation
Eth1/23	Down	40 Gbps	No-Negotiation
Eth1/24	Down	40 Gbps	No-Negotiation
Eth1/25	Down	40 Gbps	No-Negotiation
Eth1/26	Down	40 Gbps	No-Negotiation
Eth1/27	Down	40 Gbps	No-Negotiation
Eth1/28	Down	40 Gbps	No-Negotiation
Eth1/29	Up	40 Gbps	No-Negotiation
Eth1/30	Down	40 Gbps	No-Negotiation
Eth1/31	Up	40 Gbps	No-Negotiation
Eth1/32	Up	40 Gbps	No-Negotiation

itb-mellanox-1 [standalone: master] (config) # interface ethernet 1/1 itb-mellanox-1 [standalone: master] (config interface ethernet 1/1) # shutdown itb-mellanox-1 [standalone: master] (config interface ethernet 1/1) # exit

itb-mellanox-1 [standalone: master] (config) # interface ethernet 1/2 itb-mellanox-1 [standalone: master] (config interface ethernet 1/2) # shutdown

itb-mellanox-2 [standalone: master] (config) # interface ethernet 1/1

itb-mellanox-2 [standalone: master] (config interface ethernet 1/1) # shutdown

itb-mellanox-2 [standalone: master] (config interface ethernet 1/1) # exit

itb-mellanox-2 [standalone: master] (config) # interface ethernet 1/2

itb-mellanox-2 [standalone: master] (config interface ethernet 1/2) # shutdown

itb-mellanox-1 [standalone: master] (config interface ethernet 1/2) # exit itb-mellanox-1 [standalone: master] (config) # interface ethernet 1/1

itb-mellanox-1 [standalone: master] (config interface ethernet 1/1) # module-type qsfp-split-4

the following interfaces will be unmapped: 1/1 1/2

Type 'yes' to confirm split: yes

itb-mellanox-1 [standalone: master] (config) #

itb-mellanox-2 [standalone: master] (config interface ethernet 1/1) # module-type qsfp-split-4 the following interfaces will be unmapped: 1/1 1/2

Type 'yes' to confirm split: yes







