FRONT WHEEL BEARING

Removing and Installing Front Wheel Bearings

3 ST

Special tools:

P 30 Brake drum puller

P 63 Puller for annular tapered bearing

Arrangement of Front Wheel Bearings (Sectional view)

① Brake drum

[발 [발] ·

- ② Brake anchor plate
- 3 Seal
- 4 Washer (slotted)
- ⑤ Spacer
- 6 Outer race of bearing
- 7 Inner race of bearing
- ® Speedometer drive shaft
- Axle cover
- (Wheel bearing adjusting nut)
- ① Thrust washer
- 12 Inner race of outer bearing
- ③ Outer race of outer bearing

