
CYLINDER HEAD AND VALVES

Removing and Installing Rocker Arm Bracket 1600 Engine Special Tools: VW 118 Torque Wrench 5 mkg (36 ft. lb.) capacity

19 EN

Removal

- 1. Remove rocker box cover.
- 2. Remove spindle of long exhaust rocker by removing a lock ring.
- 1. Clean oil passages in valve adjusting screws.
- 2. Adjusting screws must turn easily. Replace screws with worn or damaged threads.



4. Tighten rocker arm bracket screws to 5 mkg (36 ft. lb.) torque.




Fig. 125

- 3. Remove long exhaust rocker arm.
- 4. Remove rocker arm bracket screws.
- 5. Remove rocker arm bracket.




Fig. 126



Fig. 127

Installation

The installation is accomplished in the reverse order of removal observing the following points:

5. Install long rocker arm with 2 thrust washers.