- 1) Hex. hd. clamping screw
- ② Tie rod, right
- (3) Suspension arm link pin
- 4 Upper suspension arm, right
- (5) Rubber stop, right
- 6 Shock absorber
- 7 Retaining screw for upper suspension arm, right
- (8) Upper suspension arm seal, right
- Torsion bar
- (1) Tubular jacket
- (1) Steering damper
- ② Carrier plate (stop)
- (3) Upper axle tube
- Drag link tube
- 15 Earthing strap
- (6) Joint disc

- (B) Steering gear adjusting screw
- (9) Rubber stop, left
- ② Steering gear
- (2) Retaining screw for upper suspension arm, left
- 2 Connection for brake line
- ② Parking brake bell crank
- (4) Suspension arm link, left
- 25) Stub axle
- 26) Brake anchor plate, left
- (27) Retaining screw for lower suspension arm, left
- 28) Rim
- 29 Retaining clip for parking brake lever shaft
- 30 Anti-roll bar bearing
- (3) Mounting shackle for anti-roll bar, left
- 32) Lower axle tube
- (3) Anti-roll bar

- 35 Lower suspension arm seal, right
- 36 Retaining screw for lower suspension arm, right
- 37 Bearing cap for anti-roll bar, right
- 38 Lower suspension arm, right
- 39 Mounting shackle anti-roll bar, right
- 40 Stub axle
- 41) Suspension arm link, right
- 42) Brake drum
- (43) Rim
- 4 Spacer
- 45 Hub cap
- (46) Clamping nut
- 47) Front wheel bearing, outer
- 48 Front wheel bearing, inner
- 49 Front wheel bearing, seal
- @ Grease nipple