Operations, Descriptions	Page
Gear Shift Shaft:	ļ
Removing and Installing Gear Shift Shaft	SR 2
Shift Linkage Connector	SR 2
Rear Wheel Suspension:	
Rear Wheel Suspension 356 C	SR 31
Adjusting Rear Wheel Suspension	SR 33
Rear Axle Pivot Stop 356 C	SR 35
	مِ ا
	1

	1

Remarks

Transmission Type 741 beginning with trans. No. 35 001