

1	Starter	
2	Generator	
3	Regulator	
4	Distributor	
6	ignition coil	
8	Spark plug	
9	Spark plug socket	
13	Battery	
15	Headlight with parking light	
15a	Sealed Beam	USA-Export only
16	Signal light	USA with parking light
18	Brake tail light	
19	License plate light	
21	Back up light	
22	Interior light	Coupe 2 ea., Cabrio 1
		Herdtop I ea.
23	Fog lights	optiona!
24	Hand brake warning light	
27	Oil pressure warning light	Combi-Instrument
28	Generator warning light	l
29	Turn signal indicator light	(
30	High beam indicator light	on tachometer
31	Parking light indicator light	Į.
37	Ignition-starter switch	
39	Head light switch	
40	Hand brake indicator switch	
41	Brake light switch	
42	Back-up light switch	
43	Oil pressure switch	
44	Signal dimmer switch	
45	Door contact switches	
46	Fog light switch	optional
48	Horn button	
50	Windshield wiper switch	
52	Horn relay	
53	Light signal relay	
55	Turn signal flasher	
56	Fog light relay	optional
61	Fuse box	•
63	Forward wire loom	
64	Battery ground strap	
-	Instrument wire loom	
65 66	Rear wire loom	
67	Ignition cables	
69	Plug connector Twin horns	
76 80	Windshield wiper	
	Willosuiaia Mibai	not with 644.46
	Class Habter	
82	Cigar lighter	not with ours. To
82 88	Tachometer	not with our
82 88 89	Tachometer Speedometer	not with ours. No
82 88 89 90	Tachometer Speedometer Combination instrument	
82 88 89 90 92	Tachometer Speedometer Combination instrument Electric clock	not with 644.46
82 88 89 90	Tachometer Speedometer Combination instrument Electric clock	

-⊗" -⊗ (19) (21)

11, 12 are 25/40 amp. 8/15 amp. For 12 Volt system all fuses are 8/15 amp.